

Understanding the Operational Status of Dial Peers on Cisco IOS Platforms

Document ID: 12426

Introduction

Prerequisites

Requirements

Components Used

Conventions

Invalid Dial–Peer Configurations

Valid Dial–Peer Configurations

Check the Dial–Peer Configuration

Related Information

Introduction

This document discusses how to understand the operational status of dial peers on Cisco IOS® platforms.

Prerequisites

Requirements

Readers of this document should have knowledge of these topics:

- Understanding Dial Peers and Call Legs on Cisco IOS Platforms
- Understanding Inbound and Outbound Dial Peers on Cisco IOS Platforms

If Voice–Network (VoIP, VoFR, VoATM) and POTS dial–peers are not valid and in the "operational status", they are not considered for the Cisco IOS router/gateway inbound and outbound dial–peer matching process. In order to be considered valid/operational, dial–peers must meet one of these criteria:

1. **Destination–pattern** *and* a **voice–port** or **session target** is configured.
2. **Incoming called–number** is configured.
3. **Answer–address** is configured.

Components Used

This document is not restricted to specific software and hardware versions.

Conventions

For more information on document conventions, refer to the Cisco Technical Tips Conventions.

Invalid Dial–Peer Configurations

Based on the previous three rule criteria, this table displays examples of dial–peer configurations that are in the down operational status.

Dial Peer Examples

```
dial-peer voice 1 pots
  port 1/0:23

  !--- Invalid dial-peer (rule 1): Has voice-port configured only.

!
dial-peer voice 2 pots
  destination-pattern 1T

  !--- Invalid dial-peer (rule 1): Has destination-pattern configured only.

!
dial-peer voice 6 voip
  session target ipv4:172.16.13.111

  !--- Invalid dial-peer (rule 1): Has session target configured only.

!
dial-peer voice 7 voip
  destination-pattern 83...

  !--- Invalid dial-peer (rule 1): Has destination-pattern configured only.

!
```

Note: A dial-peer configuration statement without any subcommands is considered invalid by violation of 1, 2, and 3.

Valid Dial-Peer Configurations

Based on the previous three rule criteria, this table displays examples of dial-peer configurations that are in up operational status.

Valid Peer Examples

```
dial-peer voice 3 pots
  destination-pattern 1T
  port 1/0:23
  prefix 1

  !--- Valid dial-peer (rule 1): Has voice-port and destination-pattern configured.

!
dial-peer voice 4 pots
  incoming called-number 83.

  !--- Valid dial-peer (rule 2): Has incoming called-number configured.

!
dial-peer voice 5 pots
  answer-address 408

  !--- Valid dial-peer (rule 2): Has answer-address configured.

ss configured.
!
dial-peer voice 8 voip
  destination-pattern 83...
  session target ipv4:172.16.13.111
```

```

!--- Valid dial-peer (rule 1): Has session target and destination-pattern configured.
!
dial-peer voice 9 voip
  incoming called-number .

!--- Valid dial-peer (rule 2): Has incoming called-number configured.
!
dial-peer voice 10 voip
  answer-address 6666

!--- Valid dial-peer (rule 2): Has answer-address configured.
!

```

Note: Assume a dial-peer intended for inbound matching has an incoming **called-number** or an **answer-address** configured and a **destination-pattern** command is added. After you add the command **destination-pattern string**, the dial-peer goes operationally down. This is because the router maps a **destination-pattern** to an address (**session target**) or a voice-port (**port**) for outbound dial-peer matching purposes. In this scenario there is nothing to map to. For example, if you add a **destination-pattern** on dial-peer 4, 5, 9 and 10, they change their operational status to down.

Note: On dial-peer 4 and 5, if you remove the **destination-pattern** and add a **port** command, the dial-peers remain valid. Similarly if we remove the **destination-pattern** and add the **session-target** command on 9 and 10, they also remain operational.

Check the Dial-Peer Configuration

In order to check the validity of the dial peer configuration, use the Cisco IOS command **show dial-peer voice summary**.

Check the Dial-Peer Configuration									
2600#show dial-peer voice summary									
dial-peer hunt 0									
									PASS
TAG	TYPE	ADMIN	OPER	PREFIX	DEST-PATTERN	PREF	THRU	SESS-TARGET	PORT
1	pots	up	down			0			1/0:23
2	pots	up	down		1T	0			
3	pots	up	up	1	1T	0			1/0:23
4	pots	up	up			0			
5	pots	up	up			0			
6	voip	up	down			0	syst	ipv4:172.16.13.111	
7	voip	up	down		83...	0	syst		
8	voip	up	up		83...	0	syst	ipv4:172.16.13.111	
9	voip	up	up			0	syst		
10	voip	up	up			0	syst		

Related Information

- Understanding Dial Peers and Call Legs on Cisco IOS Platforms
- Understanding Inbound and Outbound Dial Peers on Cisco IOS Platforms
- Understanding How Inbound and Outbound Dial Peers are Matched on Cisco IOS Platforms
- Understanding Direct-Inward-Dial (DID) on Cisco IOS Digital (T1/E1) Interfaces
- Configuring Dial Plans, Dial Peers, and Digit Manipulation
- Voice Technology Support
- Voice and IP Communications Product Support

- **Recommended Reading: Troubleshooting Cisco IP Telephony**
 - **Technical Support – Cisco Systems**
-

[Contacts & Feedback](#) | [Help](#) | [Site Map](#)

© 2008 – 2009 Cisco Systems, Inc. All rights reserved. [Terms & Conditions](#) | [Privacy Statement](#) | [Cookie Policy](#) | [Trademarks of Cisco Systems, Inc.](#)

Updated: Feb 02, 2006

Document ID: 12426
