

IP IVR Load Balance – Translation Route to VRU Node

Document ID: 63333

Introduction

Prerequisites

Requirements

Components Used

Conventions

Background

Example

Topology

Script – Data Flow

Selection Criteria

Related Information

Introduction

This document describes load balance between two IP Interactive Voice Response (IVR) units. It centers on the even distribution of calls that arrive between two IP IVRs so no single IP IVR is overwhelmed through the **Translation Route to VRU** (voice response unit) node in a Cisco IP Contact Center (IPCC) Enterprise Edition environment.

Prerequisites

Requirements

Readers of this document should have knowledge of these topics:

- Cisco Intelligent Contact Management (ICM)
- Cisco IP IVR

Components Used

The information in this document is based on these software and hardware versions:

- Cisco ICM version 4.6.2 and later
- Cisco Customer Response Solution (CRS) version 3.x and later

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

Conventions


For more information on document conventions, refer to Cisco Technical Tips Conventions.

Background

Some of the parameters below can be used to route calls to the IP IVR, when a script is developed for the **Translation Route to VRU** node:


- Confirm the peripheral is online, as shown in Figure 1.

Figure 1 Formula Editor Peripheral Online



- Check the available idle ports for a specific trunk group on the IP IVR. Then select the IP IVR with either the maximum idle trunks or the minimum trunks in service. In Figure 2, the choice is based on the maximum idle trunks.


Figure 2 Formula Editor Maximum of Trunk Idle or Minimum of Trunk in Service



- Check the peripheral status, as shown in Figure 3. If everything runs normally, the peripheral status number should be equal to zero, or the peripheral status number should be less than the number of sub-systems which are expected to be offline. For example, IP IVR is installed with database capability. If the database is not used, the database sub-system is offline. This would increment the

peripheral status number.

Figure 3 Formula Editor Peripheral Status




Example

Topology

The purpose is to achieve load balance between two IP IVRs, as shown in Figure 4.


Figure 4 Load Balance Between Two IP IVRs



Script – Data Flow

Figure 5 shows an actual ICM script. First the call arrives at the **Translation Route to VRU** node. The call is then routed to either the **Run VRU Script** node (indicated by the B arrow) or the **Run VRU Script** node (indicated by the A arrow). In this example, the failure condition is not taken into consideration.

Figure 5 Actual Script Call Flow



Selection Criteria


In the configuration process of the **Translation Route to VRU** node, you can change the type of target, click **Change** in the **Select Type** field, as shown by the A arrow in Figure 7. The **Select Type** dialog box opens, as shown in Figure 6.

For **Target Type**, select **Enterprise Service**, **Service**, or **Service Array**. In this example, **Service** is selected.

For call distribution, select **Distribute Among Targets** or **Select Most Eligible Target**, indicated by the A arrow in Figure 6. Specify whether the **Translation Route to VRU** node is to act like a **Select** or **Distribute** node. If you select the **Distribute Among Targets** option, the **Translation Route to VRU** node is to act like a **Distribute** node, which distributes calls among the targets based on the relative values. If you select the **Select Most Eligible Target** option, you must define the following:


- Whether to pick the target with the maximum value or the minimum value, as shown by the B arrow in Figure 6.
- A formula that determines which target is to be accepted.
- The type of target search, as shown by the C arrow in Figure 6.

Figure 6 Select Type



In this example, the first step is to check if the peripheral is online, as shown in the **Consider If** column in Figure 7. Next, check the maximum idle trunks, as shown under the **Select Max Value Of** column in Figure 7. The maximum value option is set in the **Success connection** field, indicated by the B arrow in Figure 6. When you configure the **Translation Route to VRU** node for multiple routes, it is necessary to select **Per-target success Connections** in the **Success connection** field.

Figure 7 Translation Route to VRU Properties Selection Criteria



Related Information

- [Cisco ICM/IP Contact Center Enterprise Edition Scripting and Media Routing Guide](#)
 - [Working with Translation Routes](#)
 - [Technical Support – Cisco Systems](#)
-

[Contacts & Feedback](#) | [Help](#) | [Site Map](#)

© 2008 – 2009 Cisco Systems, Inc. All rights reserved. [Terms & Conditions](#) | [Privacy Statement](#) | [Cookie Policy](#) | [Trademarks of Cisco Systems, Inc.](#)

Updated: May 26, 2005

Document ID: 63333
