

Alcatel 4400 Release 6.0, using E1 QSIG to Cisco Unified Communications Manager release 6.0

July 27, 2007

Table of Contents

Introduction	1
Network Topology	2
Network TopologyLimitations	2
System Components	2
Hardware Requirements	2
Software Requirements	3
System Components Hardware Requirements Software Requirements Features	3
Features Supported	3
Features Not Supported	4
Features Supported Features Not Supported Configuration Configuring the Alcatel 4400 PBX	4
Configuring the Alcatel 4400 PBX	4
Configuration Menus for Alcatel 4400 PBX	5
Configuring the Cisco Unified Communication Manager	54
Configuring 3825 Router	106
Configuring PSTN 1700 Router	
Acronyms	


Introduction

- This is an Application Note for connectivity between an Alcatel 4400 Release 6.0 PBX and Cisco Unified Communication Manager Release 6.0 using a Cisco 3825 voice gateway with MGCP and ISO QSIG protocol.
- The network topology diagrams (Figures 1 and 2) show the test setup for end-to-end interoperability with Cisco Unified Communication Manager Release 6.0 connected to the PBX via the 3825 E1 QSIG link as MGCP gateway. A NM-HDV and VWIC-2MFT-E1 were used for the E1 QSIG interfaces. Calls were made to test basic call, caller ID, conference, transfer, forward, call back, reroute, MWI, and path replacement features.
- Connectivity is achieved by using the QSIG ISDN switch type on the MGCP gateway with the Cisco Unified Communication Manager services parameter "QSIG variant" set to ISO, and ISO switch type on the Alcatel 4400 PBX.
- This Application Note uses the 3825 voice gateway. However, the use of other Cisco voice gateways is also an option since CUCM QSIG implementation does not depend on the physical interface.



Network Topology

Figure 1. Basic Call Setup



Limitations

Basic Calls - Overlap

 Connected number is sent from Cisco Unified Communication Manager, but not displayed on Alcatel phone when call is placed from PBX to IP phone.

Network/External Call Forward by Join

• The Alcatel PBX does not support call forward by join. Instead, the Alcatel PBX performs a reroute.

MWI

- Unfortunately, Cisco has not been able to validate MWI function in our labs because we do not have an internal voicemail system on our Alcatel PBX.
- Cisco Unified Communication Manager can not be the message center PINX for stations on the Alcatel 4400 Release 6.0 PBX. This is because MWI across QSIG is not supported by the Alcatel 4400 Release 6.0 PBX.

System Components

Hardware Requirements

The following hardware is required:

- Cisco MCS 7800 Unified Communication Manager Appliance
- Cisco 3825 voice gateway
- Cisco 1700 voice gateway



- NM-HDV
- VWIC-2MFT-E1
- VIC-2FXS
- Analogue Phone Panasonic KX-TSC7
- Cisco Unified IP phone 7940
- Cisco Unified IP phone 7960
- (2) Cisco Unified IP phone 7961G-GE
- (2) Alcatel 4400 PBXs
- (4) PRA2 trunk cards
- (4) 4035 Advanced Reflexes digital phones

Software Requirements

The following software is required:

- Cisco Unified Communication Manager Release 6.0
- Alcatel 4400 software release 6.0
- Cisco IOS Release 12.4(3a)

Features

This section lists new and changed features and features that are not supported.

Features Supported

- Basic Call, ENBLOC
- Basic Call, Overlap (see Limitations section for additional information)
- Sending Alerting Name
- Sending Busy Name
- CLIP-Calling Line (Number) Identification Presentation
- CLIR-Calling Line (Number) Identification Restriction
- CNIP-Calling Name Identification Presentation
- CNIR-Calling Name Identification Restriction
- COLP-Connected Line (Number) Identification Presentation
- COLR- Connected Line (Number) Identification Restriction
- CONP-Connected Name Identification Presentation
- CONR- Connected Name Identification Restriction
- Tandem PSTN call
- Consultation Transfer Local
- Consultation Transfer Network/External
- Blind Transfer Local



- Blind Transfer Network/External
- Call Forward Unconditional by Join Local
- Call Forward Unconditional by Join Network/External (See Limitations section for details.)
- Call Forward Busy by Join Local
- Call Forward Busy by Join Network/External (See Limitations section for details.)
- Call Forward No Reply by Join Local
- Call Forward No Reply by Join Network/External (See Limitations section for details.)
- Call Forward Unconditional by Reroute Network/External
- Call Forward Busy by Reroute Network/External
- Call Forward No Reply by Reroute Network/External
- Call Completion to Busy Subscriber (Call Back when Free)
- Call Completion on No Reply (Call Back Next Used)
- Path Replacement for Call Transfer by Join
- Path Replacement for Trombone Connection (accomplished by consultation transfer)

Features Not Supported

- Any Call Forward (CFU, CFB, CFNR) by join from PBX. PBX always performs a reroute.
- Path Replacement for Call Diversion by Forward Switch
- MWI (see Limitations section for details.)

Configuration

This section contains configuration menus and commands and describes configuration sequences and tasks.


Configuring the Alcatel 4400 PBX

- 1. System Software Release
- 2. Configure "ISO Function" System Parameter.
- 3. Configure Board.
- 4. Configure Digital Access
- 5. Configure PRI-ABC_F Trunk Group
- 6. Configure PSTN Trunk Group
- 7. Configure Remote Network
- 8. Configure Network Routing
- 9. Configure Network routing for "Overlap"
- 10. Configure Network Routing "Own Node".
- 11. Configure Digital Station
- 12. Configure Digital Station Phone Facilities




Configuration Menus for Alcatel 4400 PBX

System Software Version






Configure "ISO Function" System Parameter






Configure Board (Board 9)






Configure Board (Board 9) Digital Access






Configure Board (Board 4)






Configure Board (Board 4) Digital Access






Configure PRI-ABC_F Trunk Group (Trunk Group 0 for Board 9) 1 of 5






Configure PRI-ABC_F Trunk Group (Trunk Group 0 for Board 9) 2 of 5






Configure PRI-ABC_F Trunk Group (Trunk Group 0 for Board 9) 3 of 5






Configure PRI-ABC_F Trunk Group (Trunk Group 0 for Board 9) 4 of 5






Configure PRI-ABC_F Trunk Group (Trunk Group 0 for Board 9) 5 of 5






Configure PRI-ABC_F Trunk Group (Trunk Group 1 for Board 4) 1 of 5






Configure PRI-ABC_F Trunk Group (Trunk Group 1 for Board 4) 2 of 5






Configure PRI-ABC_F Trunk Group (Trunk Group 1 for Board 4) 3 of 5






Configure PRI-ABC_F Trunk Group (Trunk Group 1 for Board 4) 4 of 5






Configure PRI-ABC_F Trunk Group (Trunk Group 1 for Board 4) 5 of 5






Configure PSTN Board 9 (1 of 1)






Configure PSTN Board 9 Digital Access (1 of 1)






Configure PSTN Trunk Group (Trunk Group 16 for Board 9) 1 of 4






Configure PSTN Trunk Group (Trunk Group 16 for Board 9) 2 of 4






Configure PSTN Trunk Group (Trunk Group 16 for Board 9) 3 of 4






Configure PSTN Trunk Group (Trunk Group 16 for Board 9) 4 of 4






Configure Remote Network (Remote Network #3 for Trunk Group 0)






Configure Remote Network (Remote Network #0 for Trunk Group 1)






Configure Remote Network (Remote Network #15 for Trunk Group 16)






Configure Network Routing 4XXX (Trunk Group 0)






Configure Network Routing 6XXX (Trunk Group 1)






Configure Network routing for "Overlap" (Trunk Group 0)






Configure Network Routing Automatic Route Selection (ARS) for PSTN (1 of 7)






Configure Network Routing Automatic Route Selection (ARS) for PSTN (2 of 7)






Configure Network Routing Automatic Route Selection (ARS) for PSTN (3 of 7)






Configure Network Routing Automatic Route Selection (ARS) for PSTN (4 of 7)






Configure Network Routing Automatic Route Selection (ARS) for PSTN (5 of 7)






Configure Network Routing Automatic Route Selection (ARS) for PSTN (6 of 7)






Configure Network Routing Automatic Route Selection (ARS) for PSTN (7 of 7)






Configure Network routing for "Overlap" (Trunk Group 1)






Configure Network Routing "Own Node". (Required to enable 'Path Replacement')






Configure Digital Station 1 of 5






Configure Digital Station 2 of 5






Configure Digital Station 3 of 5






Configure Digital Station 4 of 5






Configure Digital Station 5 of 5






Configure Digital Station Phone Facilities 1 of 7






Configure Digital Station Phone Facilities 2 of 7






Configure Digital Station Phone Facilities 3 of 7






Configure Digital Station Phone Facilities 4 of 7






Configure Digital Station Phone Facilities 5 of 7






Configure Digital Station Phone Facilities 6 of 7






Configure Digital Station Phone Facilities 7 of 7






Configuring the Cisco Unified Communication Manager

CUCM Version






3825-E1 Gateway Configuration






3825-E1 Gateway Configuration port 1/0/0 (1 of 3)






3825-E1 Gateway Configuration port 1/0/0 (2 of 3)






3825-E1 Gateway Configuration port 1/0/0 (3 of 3)






3825-E1 Gateway Configuration port 1/0/1 (1 of 3)






3825-E1 Gateway Configuration port 1/0/1 (2 of 3)






3825-E1 Gateway Configuration port 1/0/1 (3 of 3)






Enbloc Route Configuration 3XXX (1 of 2)






Enbloc Route Configuration 3XXX (2 of 2)






Enbloc Route Configuration 6XXX (1 of 2)






Enbloc Route Configuration 6XXX (2 of 2)






PSTN Route Configuration (1 of 2)






PSTN Route Configuration (1 of 2)






Overlap Route Sending Configuration 3XXX (1 of 2)






Overlap Sending Route Configuration 3XXX (2 of 2)






Overlap Sending Route Configuration 6XXX (1 of 2)






Overlap Sending Route Configuration 6XXX (2 of 2)






Translation Pattern for Incoming Calls (1 of 2)






Translation Pattern for Incoming Calls (2 of 2)






CLIR Route Pattern Configuration






CNIR Route Pattern Configuration






COLR Translation Pattern Configuration






CONR Translation Pattern Configuration






MWI lamp On/Off Configuration






Voice Mail Profile Configuration




Voice Mail Pilot Configuration






Voice Mail Ports List






Voice Mail Port Configuration






Callback Service Parameters




CallBack Softkey Configuration (1 of 2)





CallBack Softkey Configuration (2 of 2)




IDivert Softkey Configuration (1 of 3)






IDivert Softkey Configuration (2 of 3)




IDivert Softkey Configuration (3 of 3)






Path Replacement Service Parameters






Path Replacement Call Pick Up Group (1 of 2)






Path Replacement Call Pick Up Group (2 of 2)






Forward by Reroute Service Parameter






IP 7960 SCCP phone Configuration (1 of 8)






IP 7960 SCCP phone Configuration (2 of 8)






IP 7960 SCCP phone Configuration (3of 8)






IP 7960 SCCP phone Configuration (4 of 8)






IP 7960 SCCP phone Configuration (5 of 8)






IP 7960 SCCP phone Configuration (6 of 8)






IP 7960 SCCP phone Configuration (7 of 8)






IP 7960 SCCP phone Configuration (8 of 8)






IP 7961 SIP phone Configuration (1 of 9)






IP 7961 SIP phone Configuration (2 of 9)






IP 7961 SIP phone Configuration (3 of 9)






IP 7961 SIP phone Configuration (4 of 9)






IP 7961 SIP phone Configuration (5 of 9)






IP 7961 SIP phone Configuration (6 of 9)






IP 7961 SIP phone Configuration (7 of 9)






IP 7961 SIP phone Configuration (8 of 9)





IP 7961 SIP phone Configuration (9 of 9)





Configuring 3825 Router

```
Vindaloo#sho ver
Cisco IOS Software, 3800 Software (C3825-IPVOICE-M), Version 12.4(3a), RELEASE
SOFTWARE (fc2)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2005 by Cisco Systems, Inc.
Compiled Fri 30-Sep-05 01:45 by hqluong
ROM: System Bootstrap, Version 12.3(11r)T1, RELEASE SOFTWARE (fc1)
Vindaloo uptime is 25 weeks, 6 days, 20 hours, 25 minutes
System returned to ROM by power-on
System image file is "flash:c3825-ipvoice-mz.124-3a.bin"
Cisco 3825 (revision 1.0) with 226304K/35840K bytes of memory.
Processor board ID FHK0847F0QC
2 Gigabit Ethernet interfaces
62 Serial interfaces
2 Channelized E1/PRI ports
2 Channelized T1/PRI ports
2 Voice FXO interfaces
4 Voice FXS interfaces
DRAM configuration is 64 bits wide with parity enabled.
479K bytes of NVRAM.
62592K bytes of ATA System CompactFlash (Read/Write)
Configuration register is 0x2102
Vindaloo#
Vindaloo#sho run
Building configuration...
Current configuration : 2981 bytes
!
version 12.4
service timestamps debug datetime msec
service timestamps log datetime msec
no service password-encryption
hostname Vindaloo
boot-start-marker
boot-end-marker
logging buffered 10000000 debugging
enable password cisco
!
no aaa new-model
!
resource policy
no network-clock-participate slot 1
no network-clock-participate wic 0
```



```
voice-card 0
no dspfarm
!
voice-card 1
dspfarm
ip subnet-zero
ip cef
!
!
!
ip host CM-VINDALOO 172.20.221.254
ip host CM-MERCURY 172.20.215.254
ip host CM-PLUTO 172.20.238.254
ip host CM-MADRAS 172.20.237.254
ip host cm-venus 172.20.214.254
ip name-server 172.20.2.181
ip name-server 172.20.221.254
ip name-server 172.20.215.254
ip name-server 172.20.237.254
ip name-server 172.20.238.254
isdn switch-type primary-net5
!
!
fax interface-type fax-mail
!
controller T1 0/0/0
framing esf
linecode b8zs
controller T1 0/0/1
 framing esf
linecode b8zs
controller E1 1/0/0
pri-group timeslots 1-31 service mgcp
controller E1 1/0/1
pri-group timeslots 1-31 service mgcp
!
!
!
```



```
interface GigabitEthernet0/0
 ip address 172.20.221.202 255.255.255.0
 duplex auto
 speed auto
 media-type rj45
 negotiation auto
interface GigabitEthernet0/1
no ip address
 shutdown
 duplex auto
 speed auto
 media-type rj45
 negotiation auto
interface Serial1/0/0:15
 no ip address
 isdn switch-type primary-qsig
 isdn incoming-voice voice
 isdn bind-13 ccm-manager
no cdp enable
interface Serial1/0/1:15
 no ip address
 isdn switch-type primary-qsig
 isdn protocol-emulate network
 isdn incoming-voice voice
 isdn T310 120000
 isdn bind-13 ccm-manager
no cdp enable
ip classless
ip route 0.0.0.0 0.0.0.0 GigabitEthernet0/0
ip route 0.0.0.0 0.0.0.0 172.20.221.1
no ip http server
1
!
tftp-server flash:c3825-ipvoice-mz.124-3a.bin
control-plane
!
!
voice-port 0/1/0
voice-port 0/1/1
voice-port 0/1/2
voice-port 0/1/3
voice-port 0/2/0
```



```
voice-port 0/2/1
voice-port 1/0/0:15
voice-port 1/0/1:15
ccm-manager mgcp
ccm-manager music-on-hold
ccm-manager config server 172.20.221.254
ccm-manager config
!
mgcp
mgcp call-agent CM-Vindaloo 2427 service-type mgcp version 0.1
mgcp dtmf-relay voip codec all mode out-of-band
mgcp rtp unreachable timeout 1000 action notify
mgcp modem passthrough voip mode nse
mgcp package-capability rtp-package
no mgcp package-capability res-package
mgcp package-capability sst-package
no mgcp package-capability fxr-package
mgcp package-capability pre-package
no mgcp timer receive-rtcp
mgcp sdp simple
mgcp fax t38 inhibit
mgcp rtp payload-type g726r16 static
!
mgcp profile default
!
dial-peer voice 4151 pots
port 0/1/0
dial-peer voice 999010 pots
service mgcpapp
port 0/1/0
!
dial-peer voice 1 pots
 service mgcpapp
dial-peer voice 2 pots
service mgcpapp
port 1/0/1:15
!
line con 0
stopbits 1
line aux 0
 stopbits 1
line vty 0 4
password cisco
 login
```



```
scheduler allocate 20000 1000
ntp clock-period 17178609
ntp server 192.168.240.254
!
end
```

Vindaloo#

Configuring PSTN 1700 Router

```
router B#sho ver
Cisco Internetwork Operating System Software
IOS (tm) C1700 Software (C1700-IPVOICE-M), Version 12.3(13a), RELEASE SOFTWARE (fc2)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2005 by cisco Systems, Inc.
Compiled Tue 26-Apr-05 07:06 by ssearch
Image text-base: 0x8000816C, data-base: 0x81428AE4
ROM: System Bootstrap, Version 12.2(4r)XL, RELEASE SOFTWARE (fc1)
ROM: C1700 Software (C1700-IPVOICE-M), Version 12.3(13a), RELEASE SOFTWARE (fc2)
router_B uptime is 2 days, 3 hours, 2 minutes
System returned to ROM by power-on
System image file is "flash:c1700-ipvoice-mz.123-13a.bin"
cisco 1760 (MPC860P) processor (revision 0x200) with 49152K/16384K bytes of memory.
Processor board ID FOC06490MS4 (245310706), with hardware revision BB67
MPC860P processor: part number 5, mask 2
Channelized E1, Version 1.0.
Bridging software.
X.25 software, Version 3.0.0.
Primary Rate ISDN software, Version 1.1.
1 FastEthernet/IEEE 802.3 interface(s)
31 Serial network interface(s)
2 Channelized E1/PRI port(s)
2 Voice FXS interface(s)
32K bytes of non-volatile configuration memory.
16384K bytes of processor board System flash (Read/Write)
Configuration register is 0x2102
router_B#
router_B#
router_B#sho run
Building configuration...
Current configuration : 1513 bytes
version 12.3
service timestamps debug datetime msec
service timestamps log datetime msec
no service password-encryption
```



```
hostname router_B
boot-start-marker
boot-end-marker
memory-size iomem 25
tdm clock E1 0/0 both export line
tdm clock E1 0/1 both import E1 0/0 internal
mmi polling-interval 60
no mmi auto-configure
no mmi pvc
mmi snmp-timeout 180
voice-card 0
voice-card 3
no aaa new-model
ip subnet-zero
ip cef
!
no ftp-server write-enable
isdn switch-type primary-net5
!
!
controller E1 0/0
 pri-group timeslots 1-31
controller E1 0/1
!
!
interface FastEthernet0/0
 ip address 100.100.100.2 255.255.255.0
 speed auto
interface Serial0/0:15
 no ip address
 no logging event link-status
 isdn switch-type primary-net5
 isdn incoming-voice voice
```



```
isdn bchan-number-order ascending
no cdp enable
ip classless
no ip http server
!
!
voice-port 0/0:15
voice-port 3/0
station-id name bal
 station-id number 16503646325
caller-id enable
!
voice-port 3/1
station-id name BAL2
station-id number 16503646326
caller-id enable
1
dial-peer cor custom
!
dial-peer voice 1 pots
destination-pattern 91408.....
direct-inward-dial
port 0/0:15
prefix 91408
dial-peer voice 2 pots
destination-pattern 3...
direct-inward-dial
port 0/0:15
prefix 3
dial-peer voice 3 pots
destination-pattern 16503646326
port 3/1
prefix 1
dial-peer voice 4 pots
destination-pattern 16503646325
port 3/0
prefix 1
line con 0
line aux 0
line vty 0 4
login
!
end
```



Acronyms

Acronym	Definitions
ANF-PR	Additional Network Feature Path Replacement
AOC	Advice-of-charge. Information element is sent with the connection setup information for incoming Euro-ISDN connections. The AOC IE is used for call charge calculation.
CUCM	Cisco Unified Communication Manager
CCBS	Call Completion to Busy Subscriber
CCNR	Call Completion on No Reply
CFB	Call Forwarding on Busy
CFNR	Call Forwarding No Reply
CFU	Call Forwarding Unconditional
CLIP	Calling Line (Number) Identification Presentation
CLIR	Calling Line (Number) Identification Restriction
CNIP	Calling Name Identification Presentation
CNIR	Calling Name Identification Restriction
COLP	Connected Line (Number) Identification Presentation
COLR	Connected Line (Number) Identification Restriction
CONP	Connected Name Identification Presentation
CONR	Connected Name Identification Restriction
CT	Call Transfer
MWI	Message Waiting Indicator
PSTN	Public Switched Telephone Network



Important Information

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.



Corporate Headquarters

Cisco Systems, Inc. 170 West Tasman Drive San Jose, CA 95134-1706 USA www.cisco.com

Tel: 408 526-4000 800 553-NETS (6387)

Fax: 408 526-4100

European Headquarters

Cisco Systems International BV
Haarlerbergpark
Haarlerbergweg 13-19
1101 CH Amsterdam
The Netherlands
www-europe.cisco.com

Tel: 31 0 20 357 1000 Fax: 31 0 20 357 1100

Americas Headquarters

Cisco Systems, Inc. 170 West Tasman Drive San Jose, CA 95134-1706 USA www.cisco.com

www.cisco.com Tel: 408 526-7660 Fax: 408 527-0883

Asia Pacific Headquarters

Cisco Systems, Inc. Capital Tower 168 Robinson Road #22-01 to #29-01 Singapore 068912 www.cisco.com Tel: +65 317 7777 Fax: +65 317 7799

Cisco Systems has more than 200 offices in the following countries and regions. Addresses, phone numbers, and fax numbers are listed on the Cisco Web site at www.cisco.com/go/offices.

Argentina • Australia • Austria • Belgium • Brazil • Bulgaria • Canada • Chile • China PRC • Colombia • Costa Rica • Croatia • Czech Republic • Denmark • Dubai, UAE • Finland • France • Germany • Greece • Hong Kong SAR • Hungary • India • Indonesia • Ireland • Israel • Italy • Japan • Korea • Luxembourg • Malaysia • Mexico • The Netherlands • New Zealand • Norway • Peru • Philippines • Poland • Portugal • Puerto Rico • Romania • Russia • Saudi Arabia • Scotland • Singapore • Slovakia • Slovenia • South Africa • Spain • Sweden • Switzerland • Taiwan • Thailand • Turkey Ukraine • United Kingdom • United States • Venezuela • Vietnam • Zimbabwe © 2007 Cisco Systems, Inc. All rights reserved.

CCDE, CCENT, Cisco Eos, Cisco Lumin, Cisco Nexus, Cisco StadiumVision, Cisco TelePresence, the Cisco logo, DCE, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn and Cisco Store are service marks; and Access Registrar, Aironet, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Collaboration Without Limitation, EtherFast, EtherSwitch, Event Center, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, iQuick Study, IronPort, the IronPort logo, LightStream, Linksys, MediaTone, MeetingPlace, MeetingPlace Chime Sound, MGX, Networkers, Networking Academy, Network Registrar, PCNow, PIX, PowerPanels, ProConnect, ScriptShare, SenderBase, SMARTnet, Spectrum Expert, StackWise, The Fastest Way to Increase Your Internet Quotient, TransPath, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0807R)

