Understand Adding New Hard Drives to an Existing Virtual Drive

Contents

 Introduction

 Prerequisites

 Requirements

 Components Used

 Background Information

 Procedure to Add New Hard Drive

 Migrating the RAID Level of a VD

Introduction

This document describes the procedure to add new hard drives to an existing VD with and without a Redundant Array of Independent Disks (RAID) change.

Prerequisites

Requirements

There are no specific requirements for this document.

Components Used

The information in this document is based on Cisco UCS-C Servers.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, ensure that you understand the potential impact of any command.

Background Information

For instance, if you have a Virtual Drive (VD) that has three hard drives and you want to add three more, the procedure to do so is mentioned in this document.

Procedure to Add New Hard Drive

This section contains the steps to add a new hard drive to an existing VD.

Note: You must perform the Procedure Task in a Maintenance Window.

Step 1. Reboot the host into webBIOS.

When the host computer is booting, this text appears: Copyright© LSI Corporation .

Press <Ctrl><H> for WebBIOS.

Then press Ctrl+H.



Step 2. The Controller Selection window appears, as shown in the image:

Cisco Virtual KVM Conso	le File View Macros	Tools Power Virtual Me	dia Help		9a 😺	🞧 🕤 🤶 74% [4] Su	un 6:50 AM Q :≣	6
Cisco Integrated Ma	nagement × New Tab	•••		10.106	6.74.202 - KVM Console		atro	Ŋ
← → C ▲ https://10.106.7	74.202/index.html	Adapter Selection						
Apps 🗰 Web Monitor C3 for	🖿 CSC 👬 Topic Search 🗎							
Ulully Cisco Integra	ated Manageme	R						
cisco Cisco Integra	ateu manageme	Adapter No.	Bus No.	Device No.	Туре	Firmware Pkg	. Version	it.
Overall Server Status	c 😃 🕹 🖸 🧮	0. 😦	130	0	LSI MegaRAID SAS 9271-8	23-29-0-0014		Ľ
Moderate Fault	Server Summary							1
Server Admin Storage	Actions				Start		P	
Summary	Power On Server							
Sensors	Power Off Server							
Remote Presence	Shut Down Server							
BIOS Power Policies	Hard Reset Server							
Faults and Logs	Launch KVM Console							
Troubleshooting	O Turn On Locator LED							
								1
							D	П
viewer(10.106.74.202jnlp *	viewer(10.106.74.202]nl;				10.10	6.74.202 admin 0.8 fp	os 0.002 KB/s 🔒	×
								3
			2		🍼 🗰 🖻 📗	🐮 🐠 🔐	a dire	1
the second se							A CONTRACTOR OF THE OWNER OWNER OF THE OWNER OWNE OWNER OWNE	-

The Main Menu Screen displays a menu of items that you can choose in order to display the information and make changes to the RAID arrays attached to the controllers in the server. This screen also shows the current configuration of the physical and logical drives from which you can configure and manage the RAID arrays.





Step 3. Choose the desired VD.

Step 4. Choose Advanced Operations and click Go, as shown in the image:



Step 5. Add an additional physical drive to the array.

🔲 14.17.2.105 - KVM Console		- • •						
File View Macros Tools Help								
KVM VM								
MegaRAID BIOS Config Utility Advanced Operations	LSI							
C Remove drive								
↓ Crive Group U ↓ K: Enclosure: Alpine(9), Slo ↓ K: Enclosure: Alpine(9), Slo ↓ K: Enclosure: Alpine(9), Slo								
C Change RAID Level								
RAID 6								
 Change RAID Level and Add Drive 								
Enclosure: Alpine(9), Slot:6, SAS, H								
Reset 📉 Go								
1 Home	ter Back							

Step 6. Let the VD reconstruct (reconstruction takes time to complete depending on the amount of disk you are adding).

Migrating the RAID Level of a VD

As the amount of data and the number of drives in your system increase, you can use RAID-level migration in order to change a VD from one RAID level to another. You do not have to power down or reboot the system. When you migrate a VD, you can keep the same number of drives, or you can add drives. You can use the WebBIOS Configuration Utility (CU) in order to migrate the RAID level of an existing VD.

Note: While you can apply RAID-level migration at any time, LSI recommends that you accomplish so when there are no reboots. Many operating systems issue I/O operations serially (one at a time) during boot. With a RAID-level migration running, a boot can often take more than fifteen minutes.

Migrations are allowed for these RAID levels:

- RAID 0 to RAID 1
- RAID 0 to RAID 5
- RAID 0 to RAID 6

- RAID 1 to RAID 0
- RAID 1 to RAID 5
- RAID 1 to RAID 6
- RAID 5 to RAID 0
- RAID 5 to RAID 6
- RAID 6 to RAID 0
- RAID 6 to RAID 5