



C Show Commands

- [show callhome, on page 5](#)
- [show callhome destination-profile, on page 7](#)
- [show callhome destination-profile profile, on page 8](#)
- [show callhome destination-profile profile CiscoTAC-1, on page 9](#)
- [show callhome destination-profile profile full-txt-destination, on page 10](#)
- [show callhome destination-profile profile short-txt-destination, on page 11](#)
- [show callhome transport-email, on page 12](#)
- [show callhome transport, on page 13](#)
- [show callhome user-def-cmds, on page 15](#)
- [show cdp, on page 16](#)
- [show cdp all, on page 18](#)
- [show cdp global, on page 19](#)
- [show cdp neighbors, on page 20](#)
- [show cdp neighbors detail, on page 21](#)
- [show cdp traffic interface2, on page 23](#)
- [show cdp traffic interface2 all, on page 24](#)
- [show cfs application, on page 25](#)
- [show cfs lock, on page 26](#)
- [show cfs lock, on page 27](#)
- [show cfs merge status, on page 28](#)
- [show cfs merge status, on page 29](#)
- [show cfs peers, on page 31](#)
- [show cfs peers, on page 32](#)
- [show cfs regions, on page 33](#)
- [show cfs static peers, on page 35](#)
- [show cfs status, on page 36](#)
- [show checkpoint, on page 37](#)
- [show checkpoint, on page 38](#)
- [show checkpoint summary, on page 39](#)
- [show class-map, on page 40](#)
- [show class-map type control-plane, on page 42](#)
- [show class-map type network-qos, on page 43](#)
- [show cli alias, on page 44](#)

- [show cli dynamic integers, on page 45](#)
- [show cli dynamic strings, on page 46](#)
- [show cli history, on page 47](#)
- [show cli interface table, on page 48](#)
- [show cli list, on page 49](#)
- [show cli syntax, on page 50](#)
- [show cli variables, on page 51](#)
- [show clock, on page 52](#)
- [show config-profile, on page 53](#)
- [show config-profile applied, on page 54](#)
- [show config-replace log exec, on page 55](#)
- [show config-replace status, on page 57](#)
- [show configuration, on page 58](#)
- [show configuration, on page 59](#)
- [show configuration commit, on page 60](#)
- [show configuration failed, on page 61](#)
- [show configuration file, on page 62](#)
- [show configuration session, on page 63](#)
- [show configuration session, on page 64](#)
- [show configuration session global-info, on page 65](#)
- [show configuration session status, on page 66](#)
- [show configuration session summary, on page 67](#)
- [show configuration session vsh, on page 68](#)
- [show consistency-checker copp, on page 69](#)
- [show consistency-checker copp extended module, on page 70](#)
- [show consistency-checker dme interfaces, on page 71](#)
- [show consistency-checker egress-xlate private-vlan, on page 72](#)
- [show consistency-checker ehm interface, on page 73](#)
- [show consistency-checker fcoe, on page 74](#)
- [show consistency-checker fex-interfaces fex, on page 76](#)
- [show consistency-checker forwarding, on page 77](#)
- [show consistency-checker forwarding ipv6, on page 79](#)
- [show consistency-checker forwarding single-route ipv4 vrf, on page 81](#)
- [show consistency-checker fsync, on page 82](#)
- [show consistency-checker gwmacdb, on page 83](#)
- [show consistency-checker hardware-telemetry inband brief, on page 84](#)
- [show consistency-checker hardware-telemetry postcard brief, on page 85](#)
- [show consistency-checker kim, on page 86](#)
- [show consistency-checker kim interface, on page 87](#)
- [show consistency-checker l2-tahoe mac-address, on page 88](#)
- [show consistency-checker l2-tahoe sub-interface, on page 89](#)
- [show consistency-checker l2-tahoe sub-interface vlan, on page 90](#)
- [show consistency-checker l2-tahoe switchport, on page 91](#)
- [show consistency-checker l2 module, on page 92](#)
- [show consistency-checker l2 multicast group source vlan, on page 93](#)
- [show consistency-checker l2 multicast mac vlan, on page 94](#)

- show consistency-checker l3-interface, on page 95
- show consistency-checker l3 multicast group source vrf, on page 96
- show consistency-checker link-state fabric-ieth, on page 97
- show consistency-checker link-state module, on page 98
- show consistency-checker membership port-channels, on page 99
- show consistency-checker membership vlan, on page 100
- show consistency-checker multicast nlb cluster-ip vrf, on page 101
- show consistency-checker multicast vlan, on page 102
- show consistency-checker niv datapath interface, on page 103
- show consistency-checker pacl extended ingress ip interface, on page 104
- show consistency-checker pacl extended ingress ip module, on page 105
- show consistency-checker pacl extended ingress ipv6 module, on page 106
- show consistency-checker pacl extended ingress ipv6 interface, on page 107
- show consistency-checker pacl extended ingress mac module, on page 108
- show consistency-checker pacl extended ingress mac interface, on page 109
- show consistency-checker pacl extended module, on page 110
- show consistency-checker pacl module, on page 111
- show consistency-checker pacl port-channels, on page 112
- show consistency-checker port-state, on page 113
- show consistency-checker port-state fabric-ieth, on page 114
- show consistency-checker qinq, on page 115
- show consistency-checker racl extended egress ip module, on page 116
- show consistency-checker racl extended egress ipv6 module, on page 117
- show consistency-checker racl extended egress ip interface, on page 118
- show consistency-checker racl extended egress ipv6 interface, on page 119
- show consistency-checker racl extended ingress ip module, on page 120
- show consistency-checker racl extended ingress ipv6 module, on page 121
- show consistency-checker racl extended ingress ip interface, on page 122
- show consistency-checker racl extended ingress ipv6 interface, on page 123
- show consistency-checker racl extended module, on page 124
- show consistency-checker racl module, on page 125
- show consistency-checker racl port-channels, on page 126
- show consistency-checker racl svi interface, on page 127
- show consistency-checker segment-routing mpls, on page 128
- show consistency-checker selective-qinq, on page 129
- show consistency-checker selective-qinq interface, on page 130
- show consistency-checker sflow, on page 131
- show consistency-checker storm-control, on page 132
- show consistency-checker stp-state vlan, on page 133
- show consistency-checker vacl, on page 134
- show consistency-checker vacl extended ingress ipv6 vlan, on page 135
- show consistency-checker vacl extended ingress ip vlan, on page 136
- show consistency-checker vacl extended ingress mac vlan, on page 137
- show consistency-checker vpc, on page 138
- show consistency-checker vpgrouping interface, on page 139
- show consistency-checker vxlan config-check, on page 140

- [show consistency-checker vxlan infra](#), on page 141
- [show consistency-checker vxlan l2 mac-address module](#), on page 142
- [show consistency-checker vxlan l2 module](#), on page 143
- [show consistency-checker vxlan l3 single-route ipv4 vrf](#), on page 144
- [show consistency-checker vxlan l3 vrf start](#), on page 145
- [show consistency-checker vxlan mh mac-addresses](#), on page 146
- [show consistency-checker vxlan mh pathlist](#), on page 147
- [show consistency-checker vxlan pv](#), on page 148
- [show consistency-checker vxlan qinq-qinvni](#), on page 149
- [show consistency-checker vxlan qinvni](#), on page 150
- [show consistency-checker vxlan selective-qinvni](#), on page 151
- [show consistency-checker vxlan selective-qinvni interface](#), on page 152
- [show consistency-checker vxlan vlan](#), on page 153
- [show consistency-checker vxlan xconnect](#), on page 154
- [show controller accounting log](#), on page 155
- [show copp diff profile profile2](#), on page 156
- [show copp profile](#), on page 157
- [show copp status](#), on page 162
- [show copyright](#), on page 163
- [show cores](#), on page 164
- [show crypto ca certificates](#), on page 165
- [show crypto ca certificates](#), on page 166
- [show crypto ca certstore](#), on page 167
- [show crypto ca crl](#), on page 168
- [show crypto ca remote-certstore](#), on page 169
- [show crypto ca trustpoints](#), on page 170
- [show crypto ca trustpool](#), on page 171
- [show crypto ca trustpool last download status](#), on page 172
- [show crypto ca trustpool policy](#), on page 173
- [show crypto certificate map](#), on page 174
- [show crypto key mypubkey rsa](#), on page 175
- [show crypto ssh-auth-map](#), on page 176
- [show cts](#), on page 177
- [show current](#), on page 178

show callhome

```
show callhome [ __readonly__ <output_state> <info> <per_name> [ <name> ] <email_info> [ <email_conf> ]
[ <ph_info> [ <ph_conf> ] <str_addr> [ <str_conf> ] <site_id> [ <site_id_conf> ] <cust_id> [ <cus_id_conf>
] <contr_id> [ <contr_id_conf> ] <swi_pri> [ <swi_pri_value> ] <dup_mess> <per_inv> <per_time>
<per_timeofday> <dist> ]
```

Syntax Description

<code>show</code>	Show running system information
<code>callhome</code>	Show callhome information
<code>__readonly__</code>	(Optional)
<code>output_state</code>	(Optional)
<code>info</code>	(Optional)
<code>per_name</code>	(Optional)
<code>name</code>	(Optional)
<code>email_info</code>	(Optional)
<code>email_conf</code>	(Optional)
<code>ph_info</code>	(Optional)
<code>ph_conf</code>	(Optional)
<code>str_addr</code>	(Optional)
<code>str_conf</code>	(Optional)
<code>site_id</code>	(Optional)
<code>site_id_conf</code>	(Optional)
<code>cust_id</code>	(Optional)
<code>cus_id_conf</code>	(Optional)
<code>contr_id</code>	(Optional)
<code>contr_id_conf</code>	(Optional)
<code>swi_pri</code>	(Optional)
<code>swi_pri_value</code>	(Optional)
<code>dup_mess</code>	(Optional)
<code>per_inv</code>	(Optional)

show callhome

<i>per_time</i>	(Optional)
<i>per_timeofday</i>	(Optional)
<i>dist</i>	(Optional)

Command Mode

- /exec

show callhome destination-profile

```
show callhome destination-profile [ __readonly__ { TABLE_call_info [ <dest_full_info> ] [ <dest_short_info> ] [ <dest_xml_info> ] [ <dest_def_info> ] <max_mess_size> <mess_format> <mess_level> <trans_method> <email_info> [ <index> <email_conf> ] <url_info> [ <index> <url_conf> ] <alert_groups> [ <alert_conf> ] } ]
```

Syntax Description

show	Show running system information
callhome	Show callhome information
destination-profile	Show callhome destination profile information
<u>__readonly__</u>	(Optional)
TABLE_call_info	(Optional)
<i>dest_full_info</i>	(Optional)
<i>dest_short_info</i>	(Optional)
<i>dest_xml_info</i>	(Optional)
<i>dest_def_info</i>	(Optional)
<i>max_mess_size</i>	(Optional)
<i>mess_format</i>	(Optional)
<i>mess_level</i>	(Optional)
<i>trans_method</i>	(Optional)
<i>index</i>	(Optional)
<i>email_info</i>	(Optional)
<i>email_conf</i>	(Optional)
<i>url_info</i>	(Optional)
<i>url_conf</i>	(Optional)
<i>alert_groups</i>	(Optional)
<i>alert_conf</i>	(Optional)

Command Mode

- /exec

show callhome destination-profile profile

show callhome destination-profile profile

```
show callhome destination-profile profile <s0> [ __readonly__ <user_txt_info> <max_mess_size>
<mess_format> <mess_level> <trans_method> <email_info> [ TABLE_email [ <index> <email_conf> ] ]
<url_info> [ TABLE_url [ <index> <url_conf> ] ] <alert_groups> [ TABLE_alert [ <alert_conf> ] ] ]
```

Syntax Description

show	Show running system information
callhome	Show callhome information
destination-profile	Show callhome destination profile information
profile	Specify the destination profile
<i>s0</i>	Show information for user defined destination profile
<i>__readonly__</i>	(Optional)
<i>user_txt_info</i>	(Optional)
<i>max_mess_size</i>	(Optional)
<i>mess_format</i>	(Optional)
<i>mess_level</i>	(Optional)
<i>trans_method</i>	(Optional)
<i>email_info</i>	(Optional)
<i>index</i>	(Optional)
TABLE_email	(Optional)
<i>email_conf</i>	(Optional)
<i>url_info</i>	(Optional)
TABLE_url	(Optional)
<i>url_conf</i>	(Optional)
<i>alert_groups</i>	(Optional)
TABLE_alert	(Optional)
<i>alert_conf</i>	(Optional)

Command Mode

- /exec

show callhome destination-profile profile CiscoTAC-1

```
show callhome destination-profile profile CiscoTAC-1 [ __readonly__ <tac_xml_info> <max_mess_size>
<mess_level> <trans_method> <email_info> [ <index> <email_conf> ] <url_info> [ <index> <url_conf> ]
<alert_groups> [ <alert_conf> ] ]
```

Syntax Description

show	Show running system information
callhome	Show callhome information
destination-profile	Show callhome destination profile information
profile	Specify the destination profile
CiscoTAC-1	Show information for CiscoTAC-1 destination profile
__readonly__	(Optional)
tac_xml_info	(Optional)
max_mess_size	(Optional)
mess_level	(Optional)
trans_method	(Optional)
email_info	(Optional)
index	(Optional)
email_conf	(Optional)
url_info	(Optional)
url_conf	(Optional)
alert_groups	(Optional)
alert_conf	(Optional)

Command Mode

- /exec

show callhome destination-profile profile full-txt-destination

show callhome destination-profile profile full-txt-destination

show callhome destination-profile profile full-txt-destination [*_readonly_* <full_txt_info> <max_mess_size> <mess_level> <trans_method> <email_info> [<index> <email_conf>] <url_info> [<index> <url_conf>] <alert_groups> [<alert_conf>]]

Syntax Description

show	Show running system information
callhome	Show callhome information
destination-profile	Show callhome destination profile information
profile	Specify the destination profile
full-txt-destination	Show information for full-txt-destination destination profile
<i>_readonly_</i>	(Optional)
<i>full_txt_info</i>	(Optional)
<i>max_mess_size</i>	(Optional)
<i>mess_level</i>	(Optional)
<i>trans_method</i>	(Optional)
<i>email_info</i>	(Optional)
<i>index</i>	(Optional)
<i>email_conf</i>	(Optional)
<i>url_info</i>	(Optional)
<i>url_conf</i>	(Optional)
<i>alert_groups</i>	(Optional)
<i>alert_conf</i>	(Optional)

Command Mode

- /exec

show callhome destination-profile profile short-txt-destination

show callhome destination-profile profile short-txt-destination [__readonly__ <shrt_txt_info> <max_mess_size> <mess_level> <trans_method> <email_info> [<index> <email_conf>] <url_info> [<index> <url_conf>] <alert_groups> [<alert_conf>]]

Syntax Description

show	Show running system information
callhome	Show callhome information
destination-profile	Show callhome destination profile information
profile	Specify the destination profile
short-txt-destination	Show information for short-txt-destination destination profile
__readonly__	(Optional)
shrt_txt_info	(Optional)
max_mess_size	(Optional)
mess_level	(Optional)
trans_method	(Optional)
email_info	(Optional)
index	(Optional)
email_conf	(Optional)
url_info	(Optional)
url_conf	(Optional)
alert_groups	(Optional)
alert_conf	(Optional)

Command Mode

- /exec

show callhome transport-email

show callhome transport-email

```
show callhome transport-email [ __readonly__ { <from_email> } [ <reply_to_email> ] [ <return_receipt_addr> ] { <smtp_server> } [ <smtp_server_port> ] ]
```

Syntax Description

<u>__readonly__</u>	(Optional)
show	Show running system information
callhome	Show callhome information
transport-email	Show callhome email transport configuration
<i>from_email</i>	(Optional)
<i>reply_to_email</i>	(Optional)
<i>return_receipt_addr</i>	(Optional)
<i>smtp_server</i>	(Optional)
<i>smtp_server_port</i>	(Optional)

Command Mode

- /exec

show callhome transport

```
show callhome transport [ __readonly__ <vrf> <from_email> [ <rep_email> ] [ <ret_email> ] [ <smtp_ser> ]
[ <smtp_ser_port> ] [ <smtp_ser_vrf> ] [ <smtp_ser_prior> ] [ <smtp_ser_do> ] [ <smtp_ser_port_do> ] [
<smtp_ser_vrf_do> ] [ <smtp_ser_prior_do> ] [ <smtp_ser_got> ] [ <smtp_ser_port_got> ] [
<smtp_ser_vrf_got> ] [ <smtp_ser_prior_got> ] <http_prox> <http_port> <http_state> ]
```

Syntax Description

show	Show running system information
callhome	Show callhome information
transport	Show callhome transport configuration (email and http)
<u>__readonly__</u>	(Optional)
vrf	(Optional)
from_email	(Optional)
rep_email	(Optional)
ret_email	(Optional)
smtp_ser	(Optional)
smtp_ser_port	(Optional)
smtp_ser_vrf	(Optional)
smtp_ser_prior	(Optional)
smtp_ser_do	(Optional)
smtp_ser_port_do	(Optional)
smtp_ser_vrf_do	(Optional)
smtp_ser_prior_do	(Optional)
smtp_ser_got	(Optional)
smtp_ser_port_got	(Optional)
smtp_ser_vrf_got	(Optional)
smtp_ser_prior_got	(Optional)
http_prox	(Optional)
http_port	(Optional)
http_state	(Optional)

```
show callhome transport
```

Command Mode

- /exec

show callhome user-def-cmds

```
show callhome user-def-cmds [ __readonly__ { <user_configured_cmds> } [ { TABLE_user_def_cmds  
<alert_group> <index> <user_defined_cmds> } ] ]
```

Syntax Description

show	Show running system information
callhome	Show callhome information
user-def-cmds	Show the cli commands configured for each alert group
__readonly__	(Optional)
<i>user_configured_cmds</i>	(Optional) List of user configured commands
TABLE_user_def_cmds	(Optional)
<i>index</i>	(Optional)
<i>alert_group</i>	(Optional)
<i>user_defined_cmds</i>	(Optional)

Command Mode

- /exec

show cdp

show cdp

```
show cdp { entry { all1 | name <s0> } } [ __readonly__ TABLE_cdp_entry_all <device_id> [ <sysname> ] <numaddr> [ { <v4addr> | <v6addr> } + ] <platform_id> <capability> + <intf_id> <port_id> <ttl> <version> <version_no> [ <nativevlan> ] [ <vtppname> ] [ <duplexmode> ] [ <syslocation> ] [ <num_mgmtaddr> [ { <v4mgmtaddr> | <v6mgmtaddr> } + ] ] ]
```

Syntax Description

show	Show running system information
cdp	Show Cisco Discovery Protocol information
entry	Show CDP entries in database
all1	Show all CDP entries in database
name	Show a specific CDP entry matching a name
<i>s0</i>	
<u>__readonly__</u>	(Optional) Read only
TABLE_cdp_entry_all	(Optional) output of show cdp entry all
<i>device_id</i>	(Optional) Device Identifier
<i>sysname</i>	(Optional) System Name
<i>numaddr</i>	(Optional) No of IP Address configured
<i>v4addr</i>	(Optional) Interface IP V4 Address
<i>v6addr</i>	(Optional) Interface IP V6 Address
<i>platform_id</i>	(Optional) Platform Id
<i>capability</i>	(Optional) Capability
<i>intf_id</i>	(Optional) Interface Id
<i>port_id</i>	(Optional) Port Identifier
<i>ttl</i>	(Optional) Hold Time
<i>version</i>	(Optional) Software Version
<i>version_no</i>	(Optional) CDP version number
<i>nativevlan</i>	(Optional) NativeVLAN
<i>vtppname</i>	(Optional) Vtp Management Domain Name
<i>duplexmode</i>	(Optional) Duplex Mode

<i>syslocation</i>	(Optional) System Location
<i>num_mgmtaddr</i>	(Optional) No of Mgmt Address configured
<i>v4mgmtaddr</i>	(Optional) IP V4 Mgmt Address
<i>v6mgmtaddr</i>	(Optional) IP V6 Mgmt Address

Command Mode

- /exec

show cdp all

show cdp all

```
show cdp { all | interface <if0> } [ __readonly__ TABLE_cdp_all <intf_id> <port_up> [ <cdp_global_enabled> ] <cdp_intf_enabled> [ <oper_mode> ] <refresh_time> <ttl> ]
```

Syntax Description

show	Show running system information
cdp	Show Cisco Discovery Protocol information
all	Show all interfaces in CDP database
interface	Show CDP parameters for an interface
<i>if0</i>	
<u>__readonly__</u>	(Optional) Read only
TABLE_cdp_all	(Optional) output of show cdp all
<i>intf_id</i>	(Optional) Interface Id
<i>port_up</i>	(Optional) Port status
<i>cdp_global_enabled</i>	(Optional) CDP global status
<i>cdp_intf_enabled</i>	(Optional) CDP interface status
<i>oper_mode</i>	(Optional) CDP operation mode
<i>refresh_time</i>	(Optional) Refresh Time
<i>ttl</i>	(Optional) Hold Time

Command Mode

- /exec

show cdp global

```
show cdp global [ __readonly__ <cdp_global_enabled> <refresh_time> <ttl> <v2_advertisement> <deviceid_format> ]
```

Syntax Description

show	Show running system information
cdp	Show Cisco Discovery Protocol information
global	Show CDP global parameters
__readonly__	(Optional) Read only
<i>cdp_global_enabled</i>	(Optional) CDP global status
<i>refresh_time</i>	(Optional) Refresh Time
<i>ttl</i>	(Optional) Hold Time
<i>v2_advertisement</i>	(Optional) Show v2 advertisement
<i>deviceid_format</i>	(Optional) Show deviceId Format

Command Mode

- /exec

show cdp neighbors

show cdp neighbors

```
show cdp neighbors [ interface <if> ] [ __readonly__ { TABLE_cdp_neighbor_brief_info <ifindex>
<device_id> <intf_id> <ttl> <capability> + <platform_id> <port_id> } { <neigh_count> } ]
```

Syntax Description

show	Show running system information
cdp	Show Cisco Discovery Protocol information
neighbors	Show CDP neighbors
interface	(Optional) Show CDP neighbors on an interface
<i>if</i>	(Optional) Specify Interface
<u>__readonly__</u>	(Optional) Read only
TABLE_cdp_neighbor_brief_info	(Optional) output of show cdp neighbor - in brief
<i>ifindex</i>	(Optional) Interface index
<i>device_id</i>	(Optional) System Name (or) Device Identifier
<i>intf_id</i>	(Optional) Interface Id
<i>port_id</i>	(Optional) Port Identifier
<i>platform_id</i>	(Optional) Platform Id
<i>ttl</i>	(Optional) Hold Time
<i>capability</i>	(Optional) Capability
<i>neigh_count</i>	(Optional) Neighbor Count

Command Mode

- /exec

show cdp neighbors detail

```
show cdp neighbors [ interface <if> ] detail [ __readonly__ TABLE_cdp_neighbor_detail_info <ifindex>
<device_id> [ <sysname> ] [ <vtpname> ] <numaddr> [ { <v4addr> | <v6addr> } + ] <platform_id>
<capability> + <intf_id> <port_id> <ttl> <version> <version_no> [ <nativvlan> ] [ <duplexmode> ] [ <mtu>
] [ <syslocation> ] [ <num_mgmtaddr> [ { <v4mgmtaddr> | <v6mgmtaddr> } + ] ] <local_intf_mac>
<remote_intf_mac> ]
```

Syntax Description

show	Show running system information
cdp	Show Cisco Discovery Protocol information
neighbors	Show CDP neighbors
detail	Show CDP neighbors detailed
interface	(Optional) Show CDP neighbors on an interface
<i>if</i>	(Optional) Specify Interface
<u>__readonly__</u>	(Optional) Read only
TABLE_cdp_neighbor_detail_info	(Optional) output of show cdp neighbor detail
<i>ifindex</i>	(Optional) Interface index
<i>device_id</i>	(Optional) Device Identifier
<i>sysname</i>	(Optional) System Name
<i>vtpname</i>	(Optional) Vtp Management Domain Name
<i>numaddr</i>	(Optional) No of IP Address configured
<i>v4addr</i>	(Optional) Interface IP V4 Address
<i>v6addr</i>	(Optional) Interface IP V6 Address
<i>platform_id</i>	(Optional) Platform Id
<i>capability</i>	(Optional) Capability
<i>intf_id</i>	(Optional) Interface Id
<i>port_id</i>	(Optional) Port Identifier
<i>ttl</i>	(Optional) Hold Time
<i>version</i>	(Optional) Software Version
<i>version_no</i>	(Optional) CDP version number
<i>nativvlan</i>	(Optional) NativeVLAN

```
show cdp neighbors detail
```

<i>duplexmode</i>	(Optional) Duplex Mode
<i>mtu</i>	(Optional) MTU
<i>syslocation</i>	(Optional) System Location
<i>num_mgmtaddr</i>	(Optional) No of Mgmt Address configured
<i>v4mgmtaddr</i>	(Optional) IP V4 Mgmt Address
<i>v6mgmtaddr</i>	(Optional) IP V6 Mgmt Address
<i>local_intf_mac</i>	(Optional) Local interface MAC
<i>remote_intf_mac</i>	(Optional) Remote interface MAC

Command Mode

- /exec

show cdp traffic interface2

```
show cdp traffic interface2 <if2> [ __readonly__ <intf_id> <total_input_packets> <valid_cdp_packets>
<input_v1_packets> <input_v2_packets> <invalid_cdp_packets> <unsupported_version> <checksum_errors>
<malformed_packets> <total_output_packets> <output_v1_packets> <output_v2_packets> <send_errors>
<flap_cnt> ]
```

Syntax Description

show	Show running system information
cdp	Show Cisco Discovery Protocol information
traffic	Show CDP traffic statistics
interface2	Show CDP traffic statistics on an interface
<i>if2</i>	
<i>__readonly__</i>	(Optional) Read only
<i>intf_id</i>	(Optional) Interface Id
<i>total_input_packets</i>	(Optional) Total input cdp packets
<i>valid_cdp_packets</i>	(Optional) Total valid cdp packets
<i>input_v1_packets</i>	(Optional) Input version1 packets
<i>input_v2_packets</i>	(Optional) Input version2 packets
<i>invalid_cdp_packets</i>	(Optional) Invalid cdp packets
<i>unsupported_version</i>	(Optional) Packets having unsupported version
<i>checksum_errors</i>	(Optional) Packets having checksum errors
<i>malformed_packets</i>	(Optional) Total malformed packets
<i>total_output_packets</i>	(Optional) Total output packets
<i>output_v1_packets</i>	(Optional) Output version1 packets
<i>output_v2_packets</i>	(Optional) Output version2 packets
<i>send_errors</i>	(Optional) Number of send errors
<i>flap_cnt</i>	(Optional) Number of PDU timeout

Command Mode

- /exec

show cdp traffic interface2 all

show cdp traffic interface2 all

```
show cdp traffic interface2 all [ __readonly__ TABLE_cdp_traffic <intf_id> <total_input_packets>
<valid_cdp_packets> <input_v1_packets> <input_v2_packets> <invalid_cdp_packets> <unsupported_version>
<checksum_errors> <malformed_packets> <total_output_packets> <output_v1_packets> <output_v2_packets>
<send_errors> <flap_cnt> ]
```

Syntax Description

show	Show running system information
cdp	Show Cisco Discovery Protocol information
traffic	Show CDP traffic statistics
interface2	Show CDP traffic statistics on an interface
all	Display all interface traffic
<u>__readonly__</u>	(Optional) Read only
TABLE_cdp_traffic	(Optional) output of show cdp traffic
<i>intf_id</i>	(Optional) Interface Id
<i>total_input_packets</i>	(Optional) Total input cdp packets
<i>valid_cdp_packets</i>	(Optional) Total valid cdp packets
<i>input_v1_packets</i>	(Optional) Input version1 packets
<i>input_v2_packets</i>	(Optional) Input version2 packets
<i>invalid_cdp_packets</i>	(Optional) Invalid cdp packets
<i>unsupported_version</i>	(Optional) Packets having unsupported version
<i>checksum_errors</i>	(Optional) Packets having checksum errors
<i>malformed_packets</i>	(Optional) Total malformed packets
<i>total_output_packets</i>	(Optional) Total output packets
<i>output_v1_packets</i>	(Optional) Output version1 packets
<i>output_v2_packets</i>	(Optional) Output version2 packets
<i>send_errors</i>	(Optional) Number of send errors
<i>flap_cnt</i>	(Optional) Number of PDU timeout

Command Mode

- /exec

show cfs application

```
show cfs application [ { name <cfs-dyn-app-name> | sap <i0> } ] [ __readonly__ [ <enabled> <timeout> <merge_capable> <scope> <region> ] [ { TABLE_apps <app_name> <app_enabled> <app_scope> } ] ]
```

Syntax Description

show	Show running system information
cfs	CFS Show Command handler
application	Show locally registered applications
name	(Optional) Show local application information by name
<i>cfs-dyn-app-name</i>	(Optional) Registered name of the local application
sap	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
<i>i0</i>	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
<u>__readonly__</u>	(Optional)
<i>enabled</i>	(Optional) whether application is CFS enabled
<i>timeout</i>	(Optional) timeout
<i>merge_capable</i>	(Optional) merge_capable
<i>scope</i>	(Optional) scope
<i>region</i>	(Optional) region
TABLE_apps	(Optional) all cfs applications
<i>app_name</i>	(Optional) name of cfs application
<i>app_enabled</i>	(Optional) whether application is cfs enabled
<i>app_scope</i>	(Optional) distribution scope of cfs application

Command Mode

- /exec

show cfs lock

show cfs lock

show cfs lock [{ name <cfs-dyn-app-name> [vsan <i0>] | sap <i1> [vsan1 <i2>] }]

Syntax Description

show	Show running system information
cfs	CFS Show Command handler
lock	Show state of application's logical/physical locks
name	(Optional) Application name for which the lock status is required
<i>cfs-dyn-app-name</i>	(Optional) Registered name of the local application
vsan	(Optional) Show application's locks per vsan
<i>i0</i>	(Optional) Vsan Range
sap	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
<i>i1</i>	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
vsan1	(Optional) Show application's locks per vsan
<i>i2</i>	(Optional) Vsan Range

Command Mode

- /exec

show cfs lock

```
show cfs lock [ { name <cfs-dyn-app-name> | sap <i1> } ] [ __readonly__ [ { TABLE_locks [ <app_name> <app_scope> [ <vsan> ] [ <domain> ] [ <wwn> ] <ip_addr> <u_name> <u_type> [ <hostname> ] } ] ] ]
```

Syntax Description

show	Show running system information
cfs	CFS Show Command handler
lock	Show state of application's logical/physical locks
name	(Optional) Application name for which the lock status is required
<i>cfs-dyn-app-name</i>	(Optional) Registered name of the local application
sap	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
<i>i1</i>	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
<u>__readonly__</u>	(Optional)
TABLE_locks	(Optional) table of all CFS locks
<i>app_name</i>	(Optional) name of CFS application
<i>app_scope</i>	(Optional) scope of CFS application
<i>vsan</i>	(Optional) vsan
<i>domain</i>	(Optional) domain
<i>wwn</i>	(Optional) wwn of switch holding CFS lock
<i>ip_addr</i>	(Optional) ip address of switch holding CFS lock
<i>u_name</i>	(Optional) user name
<i>u_type</i>	(Optional) user type
<i>hostname</i>	(Optional) hostname

Command Mode

- /exec

show cfs merge status

show cfs merge status

show cfs merge status [{ name <cfs-dyn-app-name> [vsan <i0>] | sap <i1> [vsan1 <i2>] }]

Syntax Description

show	Show running system information
cfs	CFS Show Command handler
merge	Show cfs merge information
status	Show status of merge
name	(Optional) Show merge status by name
<i>cfs-dyn-app-name</i>	(Optional) Registered name of the local application
vsan	(Optional) Show merge information based on vsan
<i>i0</i>	(Optional) Vsan Range
sap	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
<i>i1</i>	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
vsan1	(Optional) Show merge information based on vsan
<i>i2</i>	(Optional) Vsan Range

Command Mode

- /exec

show cfs merge status

```
show cfs merge status [ { name <cfs-dyn-app-name> [ detail ] | sap <i1> [ detail2 ] } ] [ __readonly__ [ { scope <scope> } ] [ { merge_status <status> } ] [ { failure_reason <reason> } ] [ { TABLE_all_merge <app_name> <scope> <vsan> <status> } ] [ { TABLE_local_fabric [ <domain> ] <wwn> <ip_addr> <app_scope> [ <master> ] [ <hostname> ] } ] [ { TABLE_remote_fabric [ <domain> ] <wwn> <ip_addr> <app_scope> [ <master> ] [ <hostname> ] } ] [ { TABLE_remaining_fabric [ <domain> ] <wwn> <ip_addr> [ <hostname> ] } ] ]
```

Syntax Description

show	Show running system information
cfs	CFS Show Command handler
merge	Show cfs merge information
status	Show status of merge
name	(Optional) Show merge status by name
<i>cfs-dyn-app-name</i>	(Optional) Registered name of the local application
detail	(Optional) Show merge status by name in detail
sap	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
<i>i1</i>	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
detail2	(Optional) Show merge status by sap in detail
__readonly__	(Optional)
scope	(Optional) distribution scope of application
<i>scope</i>	(Optional) scope
merge_status	(Optional) status
<i>status</i>	(Optional) status
failure_reason	(Optional) reason
<i>reason</i>	(Optional) reason
TABLE_all_merge	(Optional) all
<i>app_name</i>	(Optional) name
<i>scope</i>	(Optional) scope
<i>vsan</i>	(Optional) vsan
<i>status</i>	(Optional) status

show cfs merge status

TABLE_local_fabric	(Optional) local fabric
<i>domain</i>	(Optional) domain
<i>wwn</i>	(Optional) wwn
<i>ip_addr</i>	(Optional) ip_addr
<i>app_scope</i>	(Optional) scope
<i>master</i>	(Optional) master
<i>hostname</i>	(Optional) hname
TABLE_remote_fabric	(Optional) remote fabric
<i>domain</i>	(Optional) domain
<i>wwn</i>	(Optional) wwn
<i>ip_addr</i>	(Optional) ip_addr
<i>app_scope</i>	(Optional) scope
<i>master</i>	(Optional) master
<i>hostname</i>	(Optional) hname
TABLE_remaining_fabric	(Optional) remote fabric
<i>domain</i>	(Optional) domain
<i>wwn</i>	(Optional) wwn
<i>ip_addr</i>	(Optional) ip_addr
<i>hostname</i>	(Optional) hname

Command Mode

- /exec

show cfs peers

```
show cfs peers [ { name <cfs-dyn-app-name> | sap <i1> } ] [ __readonly__ [ { scope <scope> } ] [ { TABLE_peers <wwn> <ip_addr> [ <local> ] [ <hostname> ] [ <domain> ] } ] ]
```

Syntax Description

show	Show running system information
cfs	CFS Show Command handler
peers	Show all the peers in the physical fabric
name	(Optional) Show peers for given application name
<i>cfs-dyn-app-name</i>	(Optional) Registered name of the local application
sap	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
<i>i1</i>	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
<u>__readonly__</u>	(Optional)
scope	(Optional) scope
<i>scope</i>	(Optional) scope
TABLE_peers	(Optional) all peers
<i>wwn</i>	(Optional) wwn
<i>ip_addr</i>	(Optional) ip_addr
<i>local</i>	(Optional) local
<i>hostname</i>	(Optional) hname
<i>domain</i>	(Optional) domain

Command Mode

- /exec

show cfs peers

show cfs peers

show cfs peers [{ name <cfs-dyn-app-name> [vsan <i0>] | sap <i1> [vsan1 <i2>] }]

Syntax Description

show	Show running system information
cfs	CFS Show Command handler
peers	Show all the peers in the physical fabric
name	(Optional) Show peers for given application name
<i>cfs-dyn-app-name</i>	(Optional) Registered name of the local application
vsan	(Optional) Show peers for a specified vsan(s)
<i>i0</i>	(Optional) Vsan Range
sap	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
<i>i1</i>	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
vsan1	(Optional) Show peers for a specified vsan(s)
<i>i2</i>	(Optional) Vsan Range

Command Mode

- /exec

show cfs regions

```
show cfs regions [ { brief [ region <i0> ] | name <cfs-dyn-app-name> | region1 <i1> } ] [ __readonly__ [ { region <id> } ] [ { application <name> } ] [ { scope <scope> } ] [ { TABLE_PEERS <wwn><ip_addr> <local> [ <hostname> ] [ <domain> ] } ] [ { TABLE_switches [ <wwn> ] [ <ip_addr> ] <region> <app_name> <enabled> [ <scope> ] } ] ]
```

Syntax Description

show	Show running system information
cfs	CFS Show Command handler
regions	Show all the applications with peers and region information
brief	(Optional) Show all configured regions and applications(no peers)
region	(Optional) Show all configured applications(no peers)
<i>i0</i>	(Optional) Region Id
name	(Optional) Show peers and region information for a given application
<i>cfs-dyn-app-name</i>	(Optional) Registered name of the local application
region1	(Optional) Show all configured applications with peers
<i>i1</i>	(Optional) Region Id
__readonly__	(Optional)
region	(Optional) region
<i>id</i>	(Optional) id
application	(Optional) app
<i>name</i>	(Optional) name
scope	(Optional) scope
<i>scope</i>	(Optional) scope
TABLE_PEERS	(Optional) all region peers
<i>wwn</i>	(Optional) wwn
<i>ip_addr</i>	(Optional) ip_address
<i>local</i>	(Optional) local
<i>hostname</i>	(Optional) hname
<i>domain</i>	(Optional) domain

show cfs regions

TABLE_switches	(Optional) all switches in region
<i>wwn</i>	(Optional) wwn
<i>ip_addr</i>	(Optional) ip_addr
<i>region</i>	(Optional) region
<i>app_name</i>	(Optional) name
<i>enabled</i>	(Optional) enabled
<i>scope</i>	(Optional) scope

Command Mode

- /exec

show cfs static peers

show cfs static peers

Syntax Description

show	Show running system information
cfs	CFS Show Command handler
static	Show all static peers with status
peers	Show all configured static peers with status

Command Mode

- /exec

show cfs status

```
show cfs status [ __readonly__ <distribution> <dist_over_ip> <ipv4_mcast_addr> <ipv6_mcast_addr>
<dist_over_eth> ]
```

Syntax Description

show	Show running system information
cfs	CFS Show Command handler
status	Show current status of CFS
<u>__readonly__</u>	(Optional)
<i>distribution</i>	(Optional) operational status of CFS distribution
<i>dist_over_ip</i>	(Optional) operational status of CFS overIP
<i>ipv4_mcast_addr</i>	(Optional) ipv4 multicast address
<i>ipv6_mcast_addr</i>	(Optional) ipv6 multicast address
<i>dist_over_eth</i>	(Optional) operations status of CFSoE

Command Mode

- /exec

show checkpoint

```
show checkpoint [ all ] [ user | system ] [ __readonly__ TABLE_checkpoint_details <name> <checkpoint_config> + ]
```

Syntax Description

show	Show running system information
checkpoint	Show configuration rollback checkpoints
all	(Optional) Show default config
user	(Optional) Show only user configuration rollback checkpoints
system	(Optional) Show only system configuration rollback checkpoints
__readonly__	(Optional) Read only
TABLE_checkpoint_details	(Optional) checkpoint details
<i>name</i>	(Optional) Checkpoint name
<i>checkpoint_config</i>	(Optional) Configuration entry from checkpoint

Command Mode

- /exec

show checkpoint

show checkpoint

```
show checkpoint <chkpoint_name> [ all ] [ __readonly__ TABLE_checkpoint_details <name1>
<checkpoint_config> + ]
```

Syntax Description

show	Show running system information
checkpoint	Show configuration rollback checkpoint contents
<i>chkpoint_name</i>	Checkpoint name
all	(Optional) Show default config
<u>__readonly__</u>	(Optional) Read only
TABLE_checkpoint_details	(Optional) Checkpoint details
<i>name1</i>	(Optional) Checkpoint name
<i>checkpoint_config</i>	(Optional) Configuration entry from checkpoint

Command Mode

- /exec

show checkpoint summary

```
show checkpoint summary [ user | system ] [ __readonly__ TABLE_checkpoint_header_info <name>
<user_name> <timestamp> <file_path> <chkpt_type> <description> ]
```

Syntax Description

show	Show running system information
checkpoint	Show configuration rollback checkpoints
summary	Show configuration rollback checkpoints summary
user	(Optional) Show only user configuration rollback checkpoints summary
system	(Optional) Show only system configuration rollback checkpoints summary
__readonly__	(Optional) Read only
TABLE_checkpoint_header_info	(Optional) Checkpoint header info
<i>user_name</i>	(Optional) Username
<i>name</i>	(Optional) Checkpoint name
<i>file_path</i>	(Optional) Checkpoint name
<i>timestamp</i>	(Optional) Timestamp of checkpoint creation
<i>chkpt_type</i>	(Optional) Type of checkpoint either user or system
<i>description</i>	(Optional) Checkpoint description

Command Mode

- /exec

show class-map

show class-map

```
show class-map [ { [ type qos ] [ <cmap-name> | xxx <color-map-enum-name> ] } | { type queuing [ yyy <cmap-enum-name> | zzz <default-cmap-enum-name> | <cmap-dce-name> | <cmap-name-hque> ] } ] [ __readonly__ { [ <display-all> ] [ TABLE_cmap [ <cmap-key> ] [ <nq-cmap-key> ] [ <nq-cmap-name> ] [ <nq-cos-list> ] [ <nq-qos-group-list> ] [ <protocol> ] [ <id> ] <xqos-or-q> [ <any_or_all> ] <cmap-name-out> [ <desc> ] [ <nq-desc> ] [ TABLE_match <match-key> [ <not> ] [ <dscp-list> ] [ <precedence-list> ] [ <cos-list> ] [ <qos-group-list> ] [ <discard-class-list> ] [ <vlan-list> ] [ <match-cmap-name> ] [ <match-acl-name> ] [ <note-string> ] [ <pkt-len-list> ] [ <rtp-port-list> ] [ <roce-port-list> ] [ <prot> ] [ <input-iface-list> ] [ <exp-list> ] [ <cl-def> ] ] ] } ]
```

Syntax Description

xxx	(Optional) xxx
yyy	(Optional) yyy
zzz	(Optional) zzz
show	Show running system information
class-map	Show class maps
type	(Optional) Type of the class-map
qos	(Optional) type qos
queuing	(Optional) type queuing
cmap-name	(Optional) class map name
cmap-enum-name	(Optional)
default-cmap-enum-name	(Optional)
cmap-dce-name	(Optional) Queuing class-map name
cmap-name-hque	(Optional) Hierarchical class-map name
color-map-enum-name	(Optional)
__readonly__	(Optional)
display-all	(Optional) Display all kinds of class-maps
TABLE_cmap	(Optional) all cmap xml sessions
cmap-key	(Optional) Class-map name: xml key
nq-cmap-key	(Optional) Class-map name nq: xml key
nq-cmap-name	(Optional) Class-map xname
protocol	(Optional) protocol

TABLE_match	(Optional) all match xml sessions
<i>match-key</i>	(Optional) match count: xml key
<i>cmap-name-out</i>	(Optional) Class-map name
<i>xqos-or-q</i>	(Optional)
<i>any_or_all</i>	(Optional) Enter match-any or match-all
<i>id</i>	(Optional) Class-map ID
<i>desc</i>	(Optional) Description string
<i>nq-desc</i>	(Optional) Description xstring
<i>not</i>	(Optional) Negate this match result
<i>dscp-list</i>	(Optional) List of DSCP values
<i>precedence-list</i>	(Optional) List of precedence values
<i>cos-list</i>	(Optional) List of class-of-service values
<i>nq-cos-list</i>	(Optional) List of class-of-service values
<i>qos-group-list</i>	(Optional) List of qos-group values
<i>nq-qos-group-list</i>	(Optional) List of qos-group values
<i>discard-class-list</i>	(Optional) List of discard-class values
<i>vlan-list</i>	(Optional) List of vlan-ids
<i>match-cmap-name</i>	(Optional) class-map name
<i>match-acl-name</i>	(Optional) Match class-map name
<i>note-string</i>	(Optional) Placeholder string param to display any info in string format
<i>pkt-len-list</i>	(Optional) Packet length multi-range
<i>rtp-port-list</i>	(Optional) IP RTP UDP port multi-range
<i>roce-port-list</i>	(Optional) IP ROCE UDP port multi-range
<i>prot</i>	(Optional) Protocol
<i>input-iface-list</i>	(Optional) Input Interface multi-range
<i>exp-list</i>	(Optional) List of MPLS exp values
<i>cl-def</i>	(Optional) Match any criteria for class-default only

Command Mode

- /exec

show class-map type control-plane

show class-map type control-plane

```
show class-map type control-plane [ <cmap-name> ] [ __readonly__ [ { TABLE_cmap <cmap-key>
<cmap-name-out> <opt_any_or_all> [ TABLE_match <match-key> [ access_grp <acc_grp_name> ] [ redirect
<opt_match_redirect> ] [ exception <opt_match_excpt> ] [ protocol <opt_match_protocol> ] ] } ] ]
```

Syntax Description

show	Show running system information
class-map	Show class maps
type	Type of the class-map
control-plane	This is for copp policy
<i>cmap-name</i>	(Optional) Name of the class-map
<i>__readonly__</i>	(Optional)
TABLE_cmap	(Optional) all cmap xml sessions
<i>cmap-name-out</i>	(Optional) Name of the class-map
<i>cmap-key</i>	(Optional) Class-map name: xml key
<i>opt_any_or_all</i>	(Optional) Enter match-any or match-all
TABLE_match	(Optional) all match xml sessions
<i>match-key</i>	(Optional) match count: xml key
<i>access_grp</i>	(Optional)
<i>acc_grp_name</i>	(Optional)
<i>redirect</i>	(Optional)
<i>opt_match_redirect</i>	(Optional) Match criteria for redirected packets
<i>exception</i>	(Optional)
<i>opt_match_excpt</i>	(Optional) Match criteria for exception packets
<i>protocol</i>	(Optional)
<i>opt_match_protocol</i>	(Optional) Match criteria for protocol packets

Command Mode

- /exec

show class-map type network-qos

```
show class-map type network-qos [ <cmap-name-nq> ] [ __readonly__ { [ <display-all> ] [ TABLE_cmap
<cmap-key> <xcmmap-name> [ <desc> ] [ <cos-list> ] [ <qos-group-list> ] [ <protocol> ] [ TABLE_xmatch
<xmatch-key> [ <xcos-list> ] [ <xqos-group-list> ] [ <xprotocol> ] ] } ] }
```

Syntax Description

show	Show running system information
class-map	Show class maps
type	Type of the class-map
<i>cmap-name-nq</i>	(Optional) Class-map name
network-qos	type network-qos
<u>__readonly__</u>	(Optional)
<i>display-all</i>	(Optional) Display all network-qos class-maps
TABLE_cmap	(Optional) all network-qos cmap xml sessions
<i>cmap-key</i>	(Optional) Class-map name: xml key
<i>xcmmap-name</i>	(Optional) Class-map name
<i>desc</i>	(Optional) Description string
TABLE_xmatch	(Optional) all match xml sessions
<i>xmatch-key</i>	(Optional) match count: xml key
<i>cos-list</i>	(Optional) List of class-of-service values
<i>qos-group-list</i>	(Optional) List of qos-group values
<i>protocol</i>	(Optional) protocol
<i>xcos-list</i>	(Optional) List of class-of-service values
<i>xqos-group-list</i>	(Optional) List of qos-group values
<i>xprotocol</i>	(Optional) xprotocol

Command Mode

- /exec

show cli alias

show cli alias

show cli alias [name <s0>] [__readonly__ { TABLE_cli_alias <alias> <name> }]

Syntax Description

show	Show running system information
cli	Show CLI information
alias	Display the alias configuration
name	(Optional) Display a specific alias
s0	(Optional) Specify the alias
__readonly__	(Optional)
TABLE_cli_alias	(Optional) cli alias table
alias	(Optional) alias
name	(Optional) name

Command Mode

- /exec

show cli dynamic integers

```
show cli dynamic integers [ <name> ] [ __readonly__ TABLE_dynamic_integers <name-o> <min> <max> ]
```

Syntax Description

show	Show running system information
cli	CLI commands
dynamic	Display current range of dynamic parameters
integers	Display current range of dynamic integer parameters
<i>name</i>	(Optional) name of the dynamic parameter
<u>__readonly__</u>	(Optional)
TABLE_dynamic_integers	(Optional)
<i>name-o</i>	(Optional)
<i>min</i>	(Optional)
<i>max</i>	(Optional)

Command Mode

- /exec

show cli dynamic strings

show cli dynamic strings

show cli dynamic strings [<name>] [__readonly__ TABLE_dynamic_strings <name-o> <value> +]

Syntax Description

show	Show running system information
cli	CLI commands
dynamic	Display current range of dynamic parameters
strings	Display current range of dynamic string parameters
<i>name</i>	(Optional) name of the dynamic parameter
<u>__readonly__</u>	(Optional)
TABLE_dynamic_strings	(Optional)
<i>name-o</i>	(Optional)
<i>value</i>	(Optional)

Command Mode

- /exec

show cli history

show cli history [this-mode-only | exec-mode | config-mode] [<count> | unformatted] +

Syntax Description

show	Show running system information
cli	debug cli
history	history of cli commands
<i>count</i>	(Optional) number of lines to display (from end)
unformatted	(Optional) display just the commands
this-mode-only	(Optional) display history from current mode only
exec-mode	(Optional) display history of exec commands only
config-mode	(Optional) display history of config commands only

Command Mode

- /exec

show cli interface table

show cli interface table

show cli interface table

Syntax Description

show	show
cli	cli
interface	interface
table	table

Command Mode

- /exec

show cli list

show cli list [detail | recurse | <component> | <max-per-cmd> | has-xml-out] +

Syntax Description

show	Show running system information
cli	Show CLI information
list	show
<i>component</i>	(Optional) component
<i>max-per-cmd</i>	(Optional) max
has-xml-out	(Optional) show
recurse	(Optional) go
detail	(Optional) formats

Command Mode

- /exec

show cli syntax

show cli syntax

show cli syntax [long | recurse] + [has-xml-out | has-no-xml-out | is-data-modeled] [roles [network-admin | network-operator | <roles-mask>]]

Syntax Description

show	Show running system information
cli	Show CLI information
syntax	show
long	(Optional) use
recurse	(Optional) also
has-xml-out	(Optional) show
has-no-xml-out	(Optional) show
is-data-modeled	(Optional) show
roles	(Optional) show
network-admin	(Optional) show
network-operator	(Optional) show
<i>roles-mask</i>	(Optional) show

Command Mode

- /exec

show cli variables

```
show cli variables [ __readonly__ <switchname> <timestamp> <currentuser> [ { TABLE_variable <key> <value> } ] [ { TABLE_session_variable <key> <value> } ] ]
```

Syntax Description

show	Show running system information
cli	Show CLI information
variables	Show CLI variables
__readonly__	(Optional)
switchname	(Optional) Switch Name
timestamp	(Optional) Timestamp
currentuser	(Optional) Current User
TABLE_variable	(Optional) Variable table
key	(Optional) key
value	(Optional) value
TABLE_session_variable	(Optional) Session variable table
key	(Optional) key
value	(Optional) value

Command Mode

- /exec

show clock

show clock

```
show clock [ detail ] [ __readonly__ { <simple_time> <time_source> [ <daylight_zone> <daylight_start_week>
<daylight_start_weekday> <daylight_start_month> <daylight_start_time> <daylight_end_week>
<daylight_end_weekday> <daylight_end_month> <daylight_end_time> <daylight_utc_min_offset> ] } ]
```

Syntax Description

show	Show running system information
clock	Display current Date
detail	(Optional) Display current date and summertime configuration
__readonly__	(Optional)
<i>simple_time</i>	(Optional) simple clock format
<i>time_source</i>	(Optional) Time source
<i>daylight_zone</i>	(Optional) summer-time daylight zone
<i>daylight_start_week</i>	(Optional) daylight start week
<i>daylight_start_weekday</i>	(Optional) daylight start weekday
<i>daylight_start_month</i>	(Optional) daylight start month
<i>daylight_start_time</i>	(Optional) daylight start time
<i>daylight_end_week</i>	(Optional) daylight end week
<i>daylight_end_weekday</i>	(Optional) daylight end weekday
<i>daylight_end_month</i>	(Optional) daylight end month
<i>daylight_end_time</i>	(Optional) daylight end time
<i>daylight_utc_min_offset</i>	(Optional) daylight utc offset

Command Mode

- /exec

show config-profile

```
show config-profile [ name <all_conf_profile_name> ] [ __readonly__ TABLE_conf_profile_all
<conf_profile_name> { [ <conf_profile_desc> ] <conf_profile_cfg> +[ <conf_profile_applied> ] +[
<conf_profile_include> ] + } ]
```

Syntax Description

show	Show running system information
config-profile	Show config-profiles
name	(Optional) config-profile name
<i>all_conf_profile_name</i>	(Optional) Enter the name of configuration profile
<i>__readonly__</i>	(Optional)
TABLE_conf_profile_all	(Optional)
<i>conf_profile_name</i>	(Optional)
<i>conf_profile_desc</i>	(Optional)
<i>conf_profile_cfg</i>	(Optional)
<i>conf_profile_applied</i>	(Optional)
<i>conf_profile_include</i>	(Optional)

Command Mode

- /exec

show config-profile applied

show config-profile applied

```
show config-profile { applied [ auto | manually ] | non-applied } [ match-name <profile_substring> ] [ __readonly__ [ <profiles> ] + ]
```

Syntax Description

show	Show running system information
config-profile	Show config-profiles
applied	List of config-profiles that are applied
auto	(Optional) List of config-profiles that are applied via auto-config
manually	(Optional) List of all config-profiles which were applied directly from cli
non-applied	List of config-profiles that are not applied
match-name	(Optional) List of all config-profiles that have matching sub-string
__readonly__	(Optional)
<i>profiles</i>	(Optional)
<i>profile_substring</i>	(Optional) Enter a substring to match with config-profile name

Command Mode

- /exec

show config-replace log exec

```
show config-replace log { exec | verify } [ __readonly__ [ <last_operation> ] [ <checkpoint_name> ] [ <scheme> ] [ <user> ] [ <config_replace_type> ] [ <verbose> ] [ <start_time> ] [ <start_time_utc> ] [ <log_entry> + ] [ <end_time> ] [ <end_time_utc> ] [ <status> ] [ <restoring_previous_status> + ] [ <executing_switch_profile_patch> + ] [ <tobe_removed_present> + ] [ <tobe_added_missing> + ] [ <executing_patch> + ] [ <validating_patch> + ] [ <executing_patch_post_validation> + ] [ <retrying_patch> + ] [ <restore_previous_config> + ] [ <undo_end_time> ] [ <undo_end_time_utc> ] [ <undo_status> ] ]
```

Syntax Description

show	Show running system information
config-replace	Show config-replace
log	show config-replace log
exec	show config-replace execution log
verify	show config-replace verify log
__readonly__	(Optional) Read only
<i>last_operation</i>	(Optional) last operation
<i>checkpoint_name</i>	(Optional) checkpoint name
<i>scheme</i>	(Optional) scheme
<i>user</i>	(Optional) user
<i>config_replace_type</i>	(Optional) config-replace type
<i>verbose</i>	(Optional) verbose
<i>start_time</i>	(Optional) Start Time
<i>start_time_utc</i>	(Optional) Start Time UTC
<i>log_entry</i>	(Optional) log entry from configure replace log
<i>end_time</i>	(Optional) End Time
<i>end_time_utc</i>	(Optional) End Time UTC
<i>status</i>	(Optional) status
<i>restoring_previous_status</i>	(Optional) Restoring Previous Config Status
<i>executing_switch_profile_patch</i>	(Optional) Executing Switch profile Patch
<i>tobe_removed_present</i>	(Optional) log entry from configure replace log
<i>tobe_added_missing</i>	(Optional) log entry from configure replace log

```
show config-replace log exec
```

<i>undo_end_time</i>	(Optional) Undo End Time
<i>undo_end_time_utc</i>	(Optional) Undo End Time UTC
<i>executing_patch</i>	(Optional) Executing Patch
<i>validating_patch</i>	(Optional) Validating Patch
<i>executing_patch_post_validation</i>	(Optional) Executing Patch post validation
<i>retrying_patch</i>	(Optional) Retrying Rollback Patch
<i>restore_previous_config</i>	(Optional) Restoring previous config
<i>undo_status</i>	(Optional) undo status

Command Mode

- /exec

show config-replace status

```
show config-replace status [ __readonly__ <last_operation> [ <config_replace_type> ] [ <name> ] [ <start_time> ] [ <end_time> ] [ <operation_status> ] [ <commit_status> ] [ <commit_timeout_remaining> ] ]
```

Syntax Description

show	Show running system information
config-replace	show config-replace
status	show status of last configure replace operation
<u>__readonly__</u>	(Optional) Read only
<i>last_operation</i>	(Optional) last operation
<i>config_replace_type</i>	(Optional) config-replace type
<i>name</i>	(Optional) name
<i>start_time</i>	(Optional) start time
<i>end_time</i>	(Optional) end time
<i>operation_status</i>	(Optional) operation status
<i>commit_status</i>	(Optional) Commit status
<i>commit_timeout_remaining</i>	(Optional) commit timeout remaining

Command Mode

- /exec

show configuration

show configuration

```
show configuration { commit list | dual-stage sessions }
```

Syntax Description

show	Show running system information
configuration	Show information about configuration sessions
commit	commit information
list	Information about commit-id
dual-stage	Active dual stage session
sessions	Users with active configuration sessions

Command Mode

- /exec

show configuration

show configuration

Syntax Description

show	Show running system information
configuration	Show information about configuration sessions

Command Mode

- /exec

show configuration commit

show configuration commit

```
show configuration commit { changes <conf-commit-id> | <conf-commit-id> | log }
```

Syntax Description

show	Show running system information
configuration	Show information about configuration sessions
commit	commit information
changes	difference in committed configs
<i>conf-commit-id</i>	commit ID
log	Displays execution logs of last commit

Command Mode

- /exec

show configuration failed

show configuration failed [noerrors]

Syntax Description

show	Show running system information
configuration	Show information about configuration sessions
failed	Contents of failed configuration
noerrors	(Optional) Failed items in last commit (exclude error reasons)

Command Mode

- /exec

show configuration file

show configuration file

show configuration file <uri0> [clear-text]

Syntax Description

show	Show running system information
configuration	Show information about configuration sessions
file	Displays content of files
<i>uri0</i>	Filename to be displayed
clear-text	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED

Command Mode

- /exec

show configuration session

```
show configuration session [ __readonly__ [ TABLE_session_all <ssn-name> [ TABLE_session_all_cmd [ <ssn-cmd-num> ] [ <command> ] ] ] <activesesscnt> ]
```

Syntax Description

show	Show running system information
configuration	Show information about configuration sessions
session	Show active configuration sessions
__readonly__	(Optional) Read only
TABLE_session_all	(Optional) Show session table
<i>ssn-name</i>	(Optional)
TABLE_session_all_cmd	(Optional) Show session related commands
<i>ssn-cmd-num</i>	(Optional)
<i>command</i>	(Optional)
<i>activesesscnt</i>	(Optional) Number of active configuration sessions

Command Mode

- /exec

show configuration session

show configuration session

show configuration session <s3> [__readonly__ <ssn-name> [TABLE_session_details [<ssn-cmd-num>] [<command>]]]

Syntax Description

show	Show running system information
configuration	Show information about configuration sessions
session	Show active configuration sessions
<i>s3</i>	Shows configuration session given a name
__readonly__	(Optional) Read only
<i>ssn-name</i>	(Optional)
TABLE_session_details	(Optional) Show session details for given name
<i>ssn-cmd-num</i>	(Optional)
<i>command</i>	(Optional)

Command Mode

- /exec

show configuration session global-info

```
show configuration session global-info [ __readonly__ <max-ssns> <max-cmds> <curr-num-ssns> <curr-num-cmds> ]
```

Syntax Description

show	Show running system information
configuration	Show information about configuration sessions
session	Show active configuration sessions
global-info	Show configuration sessions global-info
__readonly__	(Optional) Read only
<i>max-ssns</i>	(Optional)
<i>max-cmds</i>	(Optional)
<i>curr-num-ssns</i>	(Optional)
<i>curr-num-cmds</i>	(Optional)

Command Mode

- /exec

show configuration session status

show configuration session status

```
show configuration session status [ <s3> ] [ __readonly__ [ TABLE_session_status <ssn-name> <last-action>
<ac-status> <ac-reason> <ac-tstamp> [ <failed-cmd-num> ] [ <failed-cmd> ] [ <last-vfy-cmd-num> ] [
<last-vfy-cmd> ] [ <last-vfy-tstamp> ] [ <rollback-status> ] ] ]
```

Syntax Description

show	Show running system information
configuration	Show information about configuration sessions
session	Show active configuration sessions
status	Show configuration session-mgr status
<i>s3</i>	(Optional) Shows configuration session status given a name
<u>__readonly__</u>	(Optional) Read only
TABLE_session_status	(Optional) Show session status table
<i>ssn-name</i>	(Optional)
<i>last-action</i>	(Optional) Last Action
<i>ac-status</i>	(Optional) Last Action Status
<i>ac-reason</i>	(Optional) Last Action Reason
<i>ac-tstamp</i>	(Optional) Last Action Timestamp
<i>failed-cmd-num</i>	(Optional) Failed Command Number
<i>failed-cmd</i>	(Optional) Failed Command
<i>last-vfy-cmd-num</i>	(Optional) Last Verified Command Number
<i>last-vfy-cmd</i>	(Optional) Last Verified Command
<i>last-vfy-tstamp</i>	(Optional) Last Verified Command Timestamp
<i>rollback-status</i>	(Optional) Rollback Status

Command Mode

- /exec

show configuration session summary

```
show configuration session summary [ __readonly__ [ TABLE_session_summary <ssn-name> <username> <tstamp> ] [ <activesesscnt> ] ]
```

Syntax Description

show	Show running system information
configuration	Show information about configuration sessions
session	Show active configuration sessions
summary	Show summary of the active configuration sessions
__readonly__	(Optional) Read only
TABLE_session_summary	(Optional) Show session summary table
<i>ssn-name</i>	(Optional)
<i>username</i>	(Optional) Session Owner
<i>tstamp</i>	(Optional) Creation Time
<i>activesesscnt</i>	(Optional) Number of active configuration sessions

Command Mode

- /exec

show configuration session vsh

show configuration session vsh

```
show configuration session <s3> vsh [ __readonly__ <ssn-name> [ TABLE_session_details_vsh [ <ssn-cmd-num> ] [ <command> ] ] ]
```

Syntax Description

show	Show running system information
configuration	Show information about configuration sessions
session	Show active configuration sessions
<i>s3</i>	Shows configuration session given a name
vsh	
<u>__readonly__</u>	(Optional) Read only
TABLE_session_details_vsh	(Optional) Show session details for given name on vsh
<i>ssn-name</i>	(Optional)
<i>ssn-cmd-num</i>	(Optional)
<i>command</i>	(Optional)

Command Mode

- /exec

show consistency-checker copp

show consistency-checker copp

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
copp	Verify copp programming from software context

Command Mode

- /exec

```
show consistency-checker copp extended module
```

show consistency-checker copp extended module

show consistency-checker copp extended module <module-id> [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
copp	Verify copp programming from software context
extended	extended
module	Limit display to this module
<i>module-id</i>	Enter module number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker dme interfaces

show consistency-checker dme interfaces

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
dme	DME (ObjectStore)
interfaces	interfaces oper data

Command Mode

- /exec

```
show consistency-checker egress-xlate private-vlan
```

show consistency-checker egress-xlate private-vlan

show consistency-checker egress-xlate private-vlan <vlan>

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
egress-xlate	Check PVLAN egress-xlate
private-vlan	Verifies private-vlan egress-xlate in the hardware
<i>vlan</i>	Enter private-vlan id

Command Mode

- /exec

show consistency-checker ehm interface

show consistency-checker ehm interface { <intf> | all }

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
ehm	Show EHM Info
interface	Show interface status and information
<i>intf</i>	Virtual Interface
all	Display All Interfaces

Command Mode

- /exec

show consistency-checker fcoe

show consistency-checker fcoe

```
show consistency-checker fcoe [ { interface <ifI> [ { exclude ping } ] } | { npv [ server-interface <svr_ifI> external-interface <ext_ifI> ] } | { hw-table { pif | vif | ucpcfg | vsan | acl | fib [ flogi | domain [ local | remote ] ] | fcf | zone | mac } } | { [ exclude ] ping } | { drop [ ingress | egress ] } ] [ verbose [ detail ] ]
```

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
fcoe	FCoE manager
interface	(Optional) Interface Test
<i>ifI</i>	(Optional) Interface name
npv	(Optional) NPV server to external interface pinning test
server-interface	(Optional) Server Interface Name
<i>svr_ifI</i>	(Optional) Server Interface name
external-interface	(Optional) External Interface Name
<i>ext_ifI</i>	(Optional) External Interface name
hw-table	(Optional) Consistency checker for Hardware Tables
pif	(Optional) PIF Table Test
vif	(Optional) VIF Table Test
ucpcfg	(Optional) Port-channel Program Table Test
vsan	(Optional) VSAN VLAN related tables
acl	(Optional) ACL Test
fib	(Optional) FIB Test
flogi	(Optional) FIB Test for FLOGIs
domain	(Optional) FIB Test for domains
local	(Optional) FIB Test for local domains
remote	(Optional) FIB Test for remote domains
fcf	(Optional) FCF Test
zone	(Optional) ZONE Test
mac	(Optional) MAC Table Test

exclude	(Optional) Exclude given test
ping	(Optional) FCPING Test
drop	(Optional) Hardware drops
ingress	(Optional) Ingress Drop Test
egress	(Optional) Egress Drop Test
verbose	(Optional) To get debugs
detail	(Optional) To get detailed debugs

Command Mode

- /exec

```
show consistency-checker fex-interfaces fex
```

show consistency-checker fex-interfaces fex

show consistency-checker fex-interfaces { fex <id> | interface <ifid> } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
fex-interfaces	Compares software and hardware state of fex interfaces
fex	Limit display to interfaces on this fex
<i>id</i>	Enter module number
interface	Limit display to FEX interface
<i>ifid</i>	FEX interface name
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker forwarding

```
show consistency-checker forwarding [ ip | ipv4 ] [ unicast ] [ suppress-transient ] [ vrf { <vrf-name> | all_vrfs } ] [ module { <module> | all_modules } ] [ __readonly__ [ <err_str> ] [ <cc_header> ] [ <table_id> ] [ <slot_id> ] [ <exec_time> ] [ <elapsed_time> ] [ <inconsis_adjs> ] [ TABLE_inconsistency_adjs { <id> <slot> [ <unit> ] <vrf> [ <ipaddr> ] [ <ipprefix> ] [ <interface> ] <reason> } ] [ <inconsis_routes> ] [ TABLE_inconsistency_routes { <id> <slot> [ <unit> ] <vrf> [ <ipaddr> ] [ <ipprefix> ] [ <interface> ] <reason> } ] [ <run_status> ] ]
```

Syntax Description

show	show
consistency-checker	Consistency Checker
forwarding	Display Forwarding Information
ip	(Optional) ipv4
ipv4	(Optional) ipv4
unicast	(Optional) unicast
suppress-transient	(Optional) Supress Transient state
vrf	(Optional) check routes for a specific VRF
<i>vrf-name</i>	(Optional) VRF name
module	(Optional) check routes for a specific module
<i>module</i>	(Optional) module number
all_modules	(Optional) all module's
all_vrfs	(Optional) all vrf's
__readonly__	(Optional)
<i>err_str</i>	(Optional)
<i>cc_header</i>	(Optional)
<i>table_id</i>	(Optional)
<i>slot_id</i>	(Optional)
<i>exec_time</i>	(Optional)
<i>elapsed_time</i>	(Optional)
<i>inconsis_adjs</i>	(Optional)
TABLE_inconsistency_adjs	(Optional)

show consistency-checker forwarding

<i>id</i>	(Optional)
<i>slot</i>	(Optional)
<i>unit</i>	(Optional)
<i>vrf</i>	(Optional)
<i>ipaddr</i>	(Optional)
<i>ipprefix</i>	(Optional)
<i>interface</i>	(Optional)
<i>reason</i>	(Optional)
<i>inconsis_routes</i>	(Optional)
TABLE_inconsistency_routes	(Optional)
<i>id</i>	(Optional)
<i>slot</i>	(Optional)
<i>unit</i>	(Optional)
<i>vrf</i>	(Optional)
<i>ipaddr</i>	(Optional)
<i>ipprefix</i>	(Optional)
<i>interface</i>	(Optional)
<i>reason</i>	(Optional)
<i>run_status</i>	(Optional)

Command Mode

- /exec

show consistency-checker forwarding ipv6

```
show consistency-checker forwarding ipv6 [ unicast ] [ suppress-transient ] [ vrf { <vrf-name> | all_vrfs } ]
[ module { <module> | all_modules } ] [ __readonly__ [ <err_str> ] [ <cc_header> ] [ <table_id> ] [ <slot_id>
] [ <exec_time> ] [ <elapsed_time> ] [ <inconsis_adjs> ] [ TABLE_inconsistency_adjs { <idipv6><slotipv6>
<unitipv6> } <vrifipv6> [ <ipv6addr> ] [ <ipv6prefix> ] [ <interfaceipv6> ] <reasonipv6> } ] [
<inconsis_routes> ] [ TABLE_inconsistency_routes { <idipv6><slotipv6> [ <unitipv6> ] <vrifipv6> [
<ipv6addr> ] [ <ipv6prefix> ] [ <interfaceipv6> ] <reasonipv6> } ] [ <run_status> ] ]
```

Syntax Description

show	show
consistency-checker	Consistency Checker
forwarding	Display Forwarding Information
ipv6	ipv6
unicast	(Optional) unicast
suppress-transient	(Optional) Supress Transient state
vrf	(Optional) check routes for a specific VRF
<i>vrf-name</i>	(Optional) VRF name
module	(Optional) check routes for a specific module
<i>module</i>	(Optional) module number
all_modules	(Optional) all module's
all_vrfs	(Optional) all vrf's
__readonly__	(Optional)
<i>err_str</i>	(Optional)
<i>cc_header</i>	(Optional)
<i>table_id</i>	(Optional)
<i>slot_id</i>	(Optional)
<i>exec_time</i>	(Optional)
<i>elapsed_time</i>	(Optional)
<i>inconsis_adjs</i>	(Optional)
TABLE_inconsistency_adjs	(Optional)
<i>idipv6</i>	(Optional)

show consistency-checker forwarding ipv6

<i>slotipv6</i>	(Optional)
<i>unitipv6</i>	(Optional)
<i>vrfipv6</i>	(Optional)
<i>interfaceipv6</i>	(Optional)
<i>reasonipv6</i>	(Optional)
<i>inconsis_routes</i>	(Optional)
TABLE_inconsistency_routes	(Optional)
<i>idipv6</i>	(Optional)
<i>slotipv6</i>	(Optional)
<i>unitipv6</i>	(Optional)
<i>vrfipv6</i>	(Optional)
<i>interfaceipv6</i>	(Optional)
<i>reasonipv6</i>	(Optional)
<i>run_status</i>	(Optional)

Command Mode

- /exec

show consistency-checker forwarding single-route ipv4 vrf

show consistency-checker forwarding single-route { ipv4 | ipv6 } <ip-prefix> vrf { <vrf-name> | <vrf-known-name> } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
forwarding	Display Forwarding Information
single-route	Run the consistency checker for a single route
ipv4	IPv4 address
ipv6	IPv6 address
<i>ip-prefix</i>	Specify an IP prefix/mask
vrf	check routes for a specific VRF
<i>vrf-name</i>	VRF name
<i>vrf-known-name</i>	Known VRF name
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

```
show consistency-checker fsync
```

show consistency-checker fsync

show consistency-checker fsync [debug-logs] [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
fsync	Do consistency check for frequency synchronization
debug-logs	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker gwmacdb

show consistency-checker gwmacdb [interface { <int-id> | <ch-id> | <vlan-id> }] [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
gwmacdb	Check gateway mac table
interface	(Optional) interface
<i>int-id</i>	(Optional) Physical or Logical interface
<i>ch-id</i>	(Optional) Port-Channel name
<i>vlan-id</i>	(Optional) SVI VLAN
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

```
show consistency-checker hardware-telemetry inband brief
```

show consistency-checker hardware-telemetry inband brief

show consistency-checker hardware-telemetry inband { brief | detail }

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
hardware-telemetry	feature hardware-telemetry
inband	inband-telemetry version
brief	Show consistency checker structured output in brief
detail	Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker hardware-telemetry postcard brief

show consistency-checker hardware-telemetry postcard { brief | detail }

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
hardware-telemetry	feature hardware-telemetry
postcard	postcard-telemetry version
brief	Show consistency checker structured output in brief
detail	Show consistency checker structured output in detail

Command Mode

- /exec

```
show consistency-checker kim
```

show consistency-checker kim

show consistency-checker kim

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
kim	Kernel Interface

Command Mode

- /exec

show consistency-checker kim interface

show consistency-checker kim { interface <ifid> } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
kim	kernel interface
interface	Limit display to interface
<i>ifid</i>	Interface
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

```
show consistency-checker l2-tahoe mac-address
```

show consistency-checker l2-tahoe mac-address

show consistency-checker l2-tahoe mac-address <mac-addr> [module <module>] [unit <unit>] [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
l2-tahoe	Verify l2 mac programming in the hardware
mac-address	MAC address
<i>mac-addr</i>	address
module	(Optional) Module to run the consistency-checker on
<i>module</i>	(Optional) Module number
unit	(Optional) Unit to run the consistency checker on
<i>unit</i>	(Optional) Enter Unit Number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker l2-tahoe sub-interface

show consistency-checker l2-tahoe sub-interface { <if_name> } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
l2-tahoe	Verify l2 sub-interface programming in the hardware
sub-interface	sub-interface
<i>if_name</i>	Physical or Logical interface
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

```
show consistency-checker l2-tahoe sub-interface vlan
```

show consistency-checker l2-tahoe sub-interface vlan

show consistency-checker l2-tahoe sub-interface vlan <vlan-id>

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
l2-tahoe	Verify l2 sub-interface programming in the hardware
sub-interface	sub-interface
vlan	Do consistency check for vlan
<i>vlan-id</i>	vlan number

Command Mode

- /exec

show consistency-checker l2-tahoe switchport

show consistency-checker l2-tahoe switchport { interface { <if_name> | all } | module { <module> | all } } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
l2-tahoe	Verify l2 mac programming in the hardware
switchport	Switchport Interface
interface	interface
<i>if_name</i>	Physical or Logical interface
all	All switchport interfaces
module	Module to run the consistency-checker on
<i>module</i>	Enter module number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker l2 module

show consistency-checker l2 module

show consistency-checker { l2-tahoe | l2-mtc } module <module> [unit <unit>] [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
l2-tahoe	Verify l2 mac programming in the hardware
l2-mtc	Verify l2 mac programming in the hardware
module	Module to run the consistency-checker on
<i>module</i>	Enter module number
unit	(Optional) Unit to run the consistency checker on
<i>unit</i>	(Optional) Enter unit number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker l2 multicast group source vlan

show consistency-checker l2 multicast group { <grp-address> | <grp-ipv6-address> } source { <src-address> | <src-ipv6-address> } vlan <vlan-id> [debug-logs] [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
l2	Verify l2 mac programming in the hardware
multicast	multicast related information
group	Do consistency check for group
<i>grp-address</i>	group IP address
source	Do consistency check for source
<i>src-address</i>	source IP address
vlan	Do consistency check for vlan
<i>vlan-id</i>	vlan number
debug-logs	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

```
show consistency-checker l2 multicast mac vlan
```

show consistency-checker l2 multicast mac vlan

show consistency-checker l2 multicast mac <mac-address> vlan <vlan-id> [debug-logs] [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
l2	Verify l2 mac programming in the hardware
multicast	multicast related information
mac	Do consistency check for multicast mac address lookup
<i>mac-address</i>	mac address
vlan	Do consistency check for vlan
<i>vlan-id</i>	vlan number
debug-logs	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker l3-interface

show consistency-checker l3-interface { all | module <moduleid> | interface { <ifid> | <ch-id> | <vlan-id> } } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
l3-interface	Compares software and hardware properties of L3 interfaces
all	Run on all modules on the switch
module	Limit display to interfaces on module
<i>moduleid</i>	Module number
interface	Limit display to interface
<i>ifid</i>	Interface name
<i>ch-id</i>	Port-Channel name
<i>vlan-id</i>	SVI VLAN
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

```
show consistency-checker l3 multicast group source vrf
```

show consistency-checker l3 multicast group source vrf

show consistency-checker l3 multicast group { <grp-address> [<mask>] | <gprefix> | <grp-ipv6-address> } source { <src-address> | <src-ipv6-address> } vrf { <vrf-name> | <vrf-known-name> } [debug-logs] [brief] [detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
l3	l3 consistency
multicast	multicast related information
group	Do consistency check for group
<i>grp-address</i>	group IP address
<i>mask</i>	(Optional) mask for group ip address
<i>gprefix</i>	IPv4 Multicast Group Prefix
source	Do consistency check for source
<i>src-address</i>	source IP address
vrf	Do consistancy check for vrf
<i>vrf-name</i>	VRF name
<i>vrf-known-name</i>	Known VRF name
debug-logs	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker link-state fabric-ieth

show consistency-checker link-state fabric-ieth { [module <module>] } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
link-state	Compares software and hardware link state of interfaces
fabric-ieth	Internal Fabric ports
module	(Optional) Limit display to interfaces on module
<i>module</i>	(Optional) Enter module number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker link-state module

show consistency-checker link-state module

show consistency-checker link-state { module <module> | interface <ifid> } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
link-state	Compares software and hardware link state of interfaces
module	Limit display to interfaces on module
<i>module</i>	Module number
interface	Limit display to interface
<i>ifid</i>	Interface name
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker membership port-channels

show consistency-checker membership port-channels [interface <ch-id>] [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
membership	Check various memberships
port-channels	Verifies port channel membership in the hardware
interface	(Optional) Port-channel number
<i>ch-id</i>	(Optional) Port-Channel name
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

```
show consistency-checker membership vlan
```

show consistency-checker membership vlan

show consistency-checker membership vlan <vlanid> [[interface [<intf-id> | <ch-id>]] || [private-vlan [interface [<int-id> | <ch-id>]]] [native-vlan] [brief | detail]]

Syntax Description

show	Show running system information
vlan	Verifies vlan membership in the hardware
<i>vlanid</i>	Enter vlan id
consistency-checker	Consistency Checker
membership	Check various memberships
interface	(Optional) Interface
<i>intf-id</i>	(Optional) Interface
<i>ch-id</i>	(Optional) Port-Channel name
private-vlan	(Optional) Check private-vlan primary vlan
interface	(Optional) Interface
<i>int-id</i>	(Optional) Interface name
<i>ch-id</i>	(Optional) Port-Channel name
native-vlan	(Optional) Check for native vlans
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker multicast nlb cluster-ip vrf

show consistency-checker multicast nlb cluster-ip <ip-address> vrf { <vrf-name> | <vrf-known-name> } [debug-logs] [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
multicast	multicast related information
nlb	Do consistency check for Multicast NLB
cluster-ip	Cluster virtual unicast IP address
<i>ip-address</i>	Cluster IP address
vrf	Do consistancy check for vrf
<i>vrf-name</i>	VRF name
<i>vrf-known-name</i>	Known VRF name
debug-logs	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker multicast vlan

show consistency-checker multicast vlan

show consistency-checker multicast vlan <vlanid> [group <group_ip> | destination-mac <dst_mac>]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
multicast	Verify Multicast
vlan	Verifies vlan flood sharing
<i>vlanid</i>	Enter vlan id
group	(Optional) Do consistency check for a group
<i>group_ip</i>	(Optional) Multicast IP address of single group to display
destination-mac	(Optional) Do consistency check for a destination-mac
<i>dst_mac</i>	(Optional) Multicast Destination mac Address for Vlan to display

Command Mode

- /exec

show consistency-checker niv-d datapath interface

show consistency-checker niv-d datapath interface <intf>

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
niv-d datapath	Verify NIV Datapath for a given interface
interface	Show interface status and information
<i>intf</i>	Virtual interface

Command Mode

- /exec

show consistency-checker pacl extended ingress ip interface

show consistency-checker pacl extended ingress ip interface

show consistency-checker pacl extended ingress ip interface { <int-id> | <ch-id> } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
pacl	Verify pacl programming in the hardware
extended	extended
ingress	ingress direction
ip	ip protocol
interface	Interface
<i>int-id</i>	Interface
<i>ch-id</i>	Port-Channel name
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker pacl extended ingress ip module

show consistency-checker pacl extended ingress ip module <module-id> [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
pacl	Verify pacl programming in the hardware
extended	extended
ingress	ingress direction
ip	ip protocol
module	Limit display to L2 interfaces on this module
<i>module-id</i>	Enter module number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker pacl extended ingress ipv6 module

show consistency-checker pacl extended ingress ipv6 module

show consistency-checker pacl extended ingress ipv6 module <module-id> [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
pacl	Verify pacl programming in the hardware
extended	extended
ingress	ingress direction
ipv6	ipv6 protocol
module	Limit display to L2 interfaces on this module
<i>module-id</i>	Enter module number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker pacl extended ingress ipv6 interface

show consistency-checker pacl extended ingress ipv6 interface { <int-id> | <ch-id> } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
pacl	Verify pacl programming in the hardware
extended	extended
ingress	ingress direction
ipv6	ipv6 protocol
interface	Interface
<i>int-id</i>	Interface
<i>ch-id</i>	Port-Channel name
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker pacl extended ingress mac module

show consistency-checker pacl extended ingress mac module

show consistency-checker pacl extended ingress mac module <module-id> [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
pacl	Verify pacl programming in the hardware
extended	extended
ingress	ingress direction
mac	ethernet protocol
module	Limit display to L2 interfaces on this module
<i>module-id</i>	Enter module number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker pacl extended ingress mac interface

show consistency-checker pacl extended ingress mac interface { <int-id> | <ch-id> } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
pacl	Verify pacl programming in the hardware
extended	extended
ingress	ingress direction
mac	ethernet protocol
interface	Interface
<i>int-id</i>	Interface
<i>ch-id</i>	Port-Channel name
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker pacl extended module

show consistency-checker pacl extended module

show consistency-checker pacl extended module { all | <module-id> } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
pacl	Verify pacl programming in the hardware
extended	extended
module	Limit display to L2 interfaces on this module
all	To run cc across all the modules
<i>module-id</i>	Enter module number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker pacl module

show consistency-checker pacl module <module>

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
pacl	Verify pacl programming in the hardware
module	Limit display to L2 interfaces on this module
<i>module</i>	Enter module number

Command Mode

- /exec

```
show consistency-checker pacl port-channels
```

show consistency-checker pacl port-channels

show consistency-checker pacl port-channels [interface <ch-id>]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
pacl	Verify pacl programming in the hardware
port-channels	Verifies port channel pacl programming in the hardware
interface	(Optional) Port-channel number
<i>ch-id</i>	(Optional) Port-Channel name

Command Mode

- /exec

show consistency-checker port-state

show consistency-checker port-state [{ module <module> | interface <ifid> }] [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
port-state	Validates SI, MTU and IPG Settings
module	(Optional) Limit display to interfaces on module
<i>module</i>	(Optional) Enter module number
interface	(Optional) Limit display to interface
<i>ifid</i>	(Optional) Interface name
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

```
show consistency-checker port-state fabric-ieth
```

show consistency-checker port-state fabric-ieth

show consistency-checker port-state fabric-ieth [module <module> [ieth-port <ieth-port>]] [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
port-state	Validates SI, FEC and MTU Settings
fabric-ieth	Internal Fabric ports
module	(Optional) Limit display to interfaces on module
<i>module</i>	(Optional) Enter module number
ieth-port	(Optional) Enter ieth-port number
<i>ieth-port</i>	(Optional) Enter ieth-port number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker qinq

show consistency-checker qinq [interface [<int-id> | <ch-id>]]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
qinq	QinQ consistency checker
interface	(Optional) Interface
<i>int-id</i>	(Optional) Eth Interface
<i>ch-id</i>	(Optional) Port-Channel

Command Mode

- /exec

show consistency-checker racl extended egress ip module

show consistency-checker racl extended egress ip module

show consistency-checker racl extended egress ip module <module-id> [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
racl	Verify racl programming in the hardware
extended	extended
egress	egress direction
ip	ip protocol
module	Limit display to L3 interfaces on this module
<i>module-id</i>	Enter module number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker racl extended egress ipv6 module

show consistency-checker racl extended egress ipv6 module <module-id> [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
racl	Verify racl programming in the hardware
extended	extended
egress	egress direction
ipv6	ipv6 protocol
module	Limit display to L3 interfaces on this module
<i>module-id</i>	Enter module number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker racl extended egress ip interface

show consistency-checker racl extended egress ip interface

show consistency-checker racl extended egress ip interface { <int-id> | <ch-id> | <vlan-id> } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
racl	Verify racl programming in the hardware
extended	extended
egress	egress direction
ip	ip protocol
interface	Interface
<i>int-id</i>	Interface
<i>ch-id</i>	Port-Channel name
<i>vlan-id</i>	SVI VLAN
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker racl extended egress ipv6 interface

show consistency-checker racl extended egress ipv6 interface { <int-id> | <ch-id> | <vlan-id> } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
racl	Verify racl programming in the hardware
extended	extended
egress	egress direction
ipv6	ipv6 protocol
interface	Interface
<i>int-id</i>	Interface
<i>ch-id</i>	Port-Channel name
<i>vlan-id</i>	SVI VLAN
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker racl extended ingress ip module

show consistency-checker racl extended ingress ip module

show consistency-checker racl extended ingress ip module <module-id> [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
racl	Verify racl programming in the hardware
extended	extended
ingress	ingress direction
ip	ip protocol
module	Limit display to L3 interfaces on this module
<i>module-id</i>	Enter module number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker racl extended ingress ipv6 module

show consistency-checker racl extended ingress ipv6 module <module-id> [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
racl	Verify racl programming in the hardware
extended	extended
ingress	ingress direction
ipv6	ipv6 protocol
module	Limit display to L3 interfaces on this module
<i>module-id</i>	Enter module number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker racl extended ingress ip interface

show consistency-checker racl extended ingress ip interface

show consistency-checker racl extended ingress ip interface { <int-id> | <ch-id> | <vlan-id> } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
racl	Verify racl programming in the hardware
extended	extended
ingress	ingress direction
ip	ip protocol
interface	Interface
<i>int-id</i>	Interface
<i>ch-id</i>	Port-Channel name
<i>vlan-id</i>	SVI VLAN
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker racl extended ingress ipv6 interface

show consistency-checker racl extended ingress ipv6 interface { <int-id> | <ch-id> | <vlan-id> } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
racl	Verify racl programming in the hardware
extended	extended
ingress	ingress direction
ipv6	ipv6 protocol
interface	Interface
<i>int-id</i>	Interface
<i>ch-id</i>	Port-Channel name
<i>vlan-id</i>	SVI VLAN
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker racl extended module

show consistency-checker racl extended module

show consistency-checker racl extended module { all | <module-id> } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
racl	Verify racl programming in the hardware
extended	extended
module	Limit display to L3 interfaces on this module
all	To run CC across all the modules
<i>module-id</i>	Enter module number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker racl module

show consistency-checker racl module <module>

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
racl	Verify racl programming in the hardware
module	Limit display to L3 interfaces on this module
<i>module</i>	Enter module number

Command Mode

- /exec

show consistency-checker racl port-channels

show consistency-checker racl port-channels

show consistency-checker racl port-channels [interface <ch-id>]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
racl	Verify racl programming in the hardware
port-channels	Verifies port channel racl programming in the hardware
interface	(Optional) Port-channel number
<i>ch-id</i>	(Optional) Port-Channel name

Command Mode

- /exec

show consistency-checker racl svi interface

show consistency-checker racl svi interface <vlan-id>

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
racl	Verify racl programming in the hardware
svi	Verifies SVI racl programming in the hardware
interface	SVI number
<i>vlan-id</i>	SVI VLAN

Command Mode

- /exec

show consistency-checker segment-routing mpls

show consistency-checker segment-routing mpls

show consistency-checker segment-routing mpls { ip <ip-address> mask <ip-mask> vrf <vrf-name> | label <label> } [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
segment-routing	Segment-routing
mpls	MPLS Information
ip	IP Information
<i>ip-address</i>	IP Address
mask	Mask Information
<i>ip-mask</i>	Mask Length
vrf	VRF Information
<i>vrf-name</i>	VRF Name
label	Label Information
<i>label</i>	Label Name
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker selective-qinq

show consistency-checker selective-qinq

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
selective-qinq	Selective QinQ consistency checker

Command Mode

- /exec

```
show consistency-checker selective-qinq interface
```

show consistency-checker selective-qinq interface

show consistency-checker selective-qinq interface { <int-id> | <ch-id> }

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
selective-qinq	Selective QinQ consistency checker
interface	Interface
<i>int-id</i>	Interface
<i>ch-id</i>	Port-Channel name

Command Mode

- /exec

show consistency-checker sflow

show consistency-checker sflow [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
sflow	Compares software and hardware sflow details
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

```
show consistency-checker storm-control
```

show consistency-checker storm-control

show consistency-checker storm-control

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
storm-control	Storm control consistency checker

Command Mode

- /exec

show consistency-checker stp-state vlan

show consistency-checker stp-state vlan <vlan> [interface <int-id>] [brief | detail]

Syntax Description

show	Show running system information
vlan	Verifies spanning tree state in the hardware for all interfaces in the vlan
<i>vlan</i>	Enter vlan id
interface	(Optional) Interface
<i>int-id</i>	(Optional) Interface
consistency-checker	Consistency Checker
stp-state	Verify spanning tree state in the hardware
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

```
show consistency-checker vacl
```

show consistency-checker vacl

show consistency-checker vacl

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vacl	Verify vacl programming in the hardware

Command Mode

- /exec

show consistency-checker vACL extended ingress ipv6 vlan

show consistency-checker vACL extended ingress ipv6 vlan <vlan-id> [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vACL	Verify vACL programming in the hardware
extended	extended
ingress	ingress direction
ipv6	ipv6 protocol
vlan	VLAN
<i>vlan-id</i>	vlan number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

```
show consistency-checker vACL extended ingress ip vlan
```

show consistency-checker vACL extended ingress ip vlan

show consistency-checker vACL extended ingress ip vlan <vlan-id> [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vACL	Verify vACL programming in the hardware
extended	extended
ingress	ingress direction
ip	ip protocol
vlan	VLAN
<i>vlan-id</i>	vlan number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker vACL extended ingress mac vlan

show consistency-checker vACL extended ingress mac vlan <vlan-id> [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vACL	Verify vACL programming in the hardware
extended	extended
ingress	ingress direction
mac	ethernet protocol
vlan	VLAN
<i>vlan-id</i>	vlan number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

```
show consistency-checker vpc
```

show consistency-checker vpc

show consistency-checker vpc [source-interface [<int-id> | <ch-id>]] [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vpc	vPC related information
source-interface	(Optional) Source vPC member
<i>int-id</i>	(Optional) Eth Interface
<i>ch-id</i>	(Optional) Port-Channel
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker vpgrouping interface

show consistency-checker vpgrouping interface { <intf> | all }

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vpgrouping	Show VP Grouping Info
interface	Show interface status and information
<i>intf</i>	Physical or Logical Interface
all	Display All Interfaces

Command Mode

- /exec

```
show consistency-checker vxlan config-check
```

show consistency-checker vxlan config-check

show consistency-checker vxlan config-check [verbose-mode] [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vxlan	VxLAN consistency checker
config-check	Check the inconsistencies in the config
verbose-mode	(Optional) config-check verbose
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker vxlan infra

show consistency-checker vxlan infra [verbose-mode] [brief | detail]

Syntax Description

show	Show running system information
vxlan	VxLAN consistency checker
consistency-checker	Consistency Checker
infra	infra
verbose-mode	(Optional) detailed CC output
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

```
show consistency-checker vxlan l2 mac-address module
```

show consistency-checker vxlan l2 mac-address module

show consistency-checker vxlan l2 mac-address <mac-addr> module <module> [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vxlan	VxLAN consistency checker
l2	l2
mac-address	MAC address
<i>mac-addr</i>	address
module	Module to run the consistency-checker on
<i>module</i>	Module number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker vxlan l2 module

show consistency-checker vxlan l2 module <module> [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vxlan	VxLAN consistency checker
l2	Check L2 inconsistencies
module	Module to run the consistency-checker on
<i>module</i>	Enter module number
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

```
show consistency-checker vxlan l3 single-route ipv4 vrf
```

show consistency-checker vxlan l3 single-route ipv4 vrf

show consistency-checker vxlan l3 single-route { ipv4 | ipv6 } <ip-prefix> vrf { <vrf-name> | <vrf-known-name> } [debug-logs] [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vxlan	VxLAN consistency checker
l3	l3
single-route	Run the consistency checker for a single route
ipv4	IPv4 address
ipv6	IPv6 address
<i>ip-prefix</i>	Overlay L3 Route IP Address in prefix/mask format
vrf	Do consistancy check for vrf
<i>vrf-name</i>	VRF name
<i>vrf-known-name</i>	Known VRF name
debug-logs	THIS KEYWORD OR VARIABLE IS NOT SUPPORTED
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker vxlan l3 vrf start

show consistency-checker vxlan l3 vrf { <vrf-name> | all } { start-scan | report }

Syntax Description

show	Show running system information
vxlan	VxLAN consistency checker
consistency-checker	Consistency Checker
l3	l3
vrf	VRF
<i>vrf-name</i>	vrf name
all	All VRFs
start-scan	Start Route CC
report	Show Route CC report

Command Mode

- /exec

```
show consistency-checker vxlan mh mac-addresses
```

show consistency-checker vxlan mh mac-addresses

show consistency-checker vxlan mh mac-addresses [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vxlan	VxLAN consistency checker
mh	VxLAN BGP EVPN Multi Homing CC commands
mac-addresses	Check mac address consistency between L2RIB and L2FM
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

show consistency-checker vxlan mh pathlist

show consistency-checker vxlan mh pathlist [brief | detail]

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vxlan	VxLAN consistency checker
mh	VxLAN BGP EVPN Multi Homing CC commands
pathlist	Check Vxlan BGP EVPN MH Control plane and resultant pathlists consistency
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

```
show consistency-checker vxlan pv
```

show consistency-checker vxlan pv

show consistency-checker vxlan pv

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vxlan	VxLAN consistency checker
pv	pv consistency checker

Command Mode

- /exec

show consistency-checker vxlan qinq-qinvni

show consistency-checker vxlan qinq-qinvni

Syntax Description

show	Show running system information
vxlan	VxLAN consistency checker
consistency-checker	Consistency Checker
qinq-qinvni	QinQ consistency checker

Command Mode

- /exec

```
show consistency-checker vxlan qinvni
```

show consistency-checker vxlan qinvni

show consistency-checker vxlan qinvni

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vxlan	VxLAN consistency checker
qinvni	QinVNI consistency checker

Command Mode

- /exec

show consistency-checker vxlan selective-qinvni

show consistency-checker vxlan selective-qinvni

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vxlan	VxLAN consistency checker
selective-qinvni	Selective QinVNI consistency checker

Command Mode

- /exec

```
show consistency-checker vxlan selective-qinvni interface
```

show consistency-checker vxlan selective-qinvni interface

show consistency-checker vxlan selective-qinvni interface { <int-id> | <ch-id> }

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vxlan	VxLAN consistency checker
selective-qinvni	Selective QinVNI consistency checker
interface	Interface
<i>int-id</i>	Interface
<i>ch-id</i>	Port-Channel name

Command Mode

- /exec

show consistency-checker vxlan vlan

show consistency-checker vxlan vlan { <vlanid> | all } [verbose-mode] [brief | detail]

Syntax Description

show	Show running system information
vxlan	VxLAN consistency checker
vlan	Verifies flood list programming for vxlan vlans
consistency-checker	Consistency Checker
<i>vlanid</i>	Enter vlan id
all	Check CC for all vxlans
verbose-mode	(Optional) detailed CC output
brief	(Optional) Show consistency checker structured output in brief
detail	(Optional) Show consistency checker structured output in detail

Command Mode

- /exec

```
show consistency-checker vxlan xconnect
```

show consistency-checker vxlan xconnect

show consistency-checker vxlan xconnect

Syntax Description

show	Show running system information
consistency-checker	Consistency Checker
vxlan	VxLAN consistency checker
xconnect	Cross-Connect consistency checker

Command Mode

- /exec

show controller accounting log

show controller <ctrl-id> accounting log

Syntax Description

show	Show running system information
controller	Controller command
<i>ctrl-id</i>	Controller id value
accounting	Accounting
log	Show log information

Command Mode

- /exec

show copp diff profile profile2

show copp diff profile profile2

show copp diff profile <profile_type> [prior-ver] profile2 <profile_type2>

Syntax Description

show	Show running system information
copp	Control-Plane Policing
diff	Difference between CoPP Profiles
profile	CoPP Profile
<i>profile_type</i>	CoPP Profile Types
prior-ver	(Optional) Previous Configured Version
profile2	CoPP Profile
<i>profile_type2</i>	CoPP Profile Types

Command Mode

- /exec

show copp profile

```

show copp profile { strict | moderate | lenient | dense } [ __readonly__ { TABLE_coppprof <acl-type> {<acl-grp-name> { TABLE_sequence <permitdeny> [ { <proto_str> | <proto> | <ip> | <ipv6> } ] { [ <src_any> | <src_ip_prefix> | <src_ip_addr> <src_ip_mask> | <src_ipv6_prefix> | <src_addrgrp> | <src_mac_any> | <src_mac_addr> <src_mac_mask> ] } [ <src_port_op> { <src_port1_str> | <src_port1_num> } [ <src_port2_str> | <src_port2_num> ] | <src_portgrp> ] { <dest_any> | <dest_ip_prefix> | <dest_ip_addr> <dest_ip_mask> | <dest_ipv6_prefix> | <dest_addrgrp> | <dest_mac_any> | <dest_mac_addr> <dest_mac_mask> } [ <dest_port_op> { <dest_port1_str> | <dest_port1_num> } [ <dest_port2_str> | <dest_port2_num> ] | <dest_portgrp> ] [ { <icmp_type> [ <icmp_code> ] | <icmp_str> } | { <icmpv6_type> [ <icmpv6_code> ] | <icmpv6_str> } ] <eth_proto> ] } } <newline> [ { TABLE_classmap <opt_any_or_all> [ <cmap_name> ] { access_grp <acc_grp_name>+ } ] [ { redirect <opt_match_redirect>+ } ] [ { exception <opt_match_except>+ } ] [ { protocol <opt_match_protocol>+ } ] } ] [ { TABLE_policymap [ <class-name> ] [ <pmap_name> ] [ <set_vld_flg> ] [ { cos [ inner ] <cos-val> } ] [ { dscp [ tunnel ] [ <dscp-val> ] } ] [ { precedence [ tunnel1 ] [ <prec-val> ] } ] [ <policer_show_flags> ] [ <cir> ] [ <opt_kbps_mbps_gbps_pps_cir> ] [ { percent <cir-perc> } ] [ <bc>+ ] [ <opt_kbytes_mbytes_gbytes_bc>+ ] [ <pir> ] [ <opt_kbps_mbps_gbps_pps_pir> ] [ { percent1 <pir-perc> } ] [ <be> ] [ <opt_kbytes_mbytes_gbytes_be> ] [ <opt_drop_transmit_conform> ] [ <opt_drop_transmit_violate> ] [ { { [ <opt_drop_transmit_conform1> ] } | { set-cos-transmit [ <set-cos-val> ] } | { set-dscp-transmit [ <set-dscp-val> ] } | { set-prec-transmit [ <set-prec-val> ] } } ] [ { { [ <opt_drop_transmit_exceed> ] } | { set dscp1 dscp2 table cir-markdown-map } } ] [ { { [ <opt_drop_transmit_violate1> ] } | { set1 dscp3 dscp4 table1 pir-markdown-map } } ] } ]

```

Syntax Description

<code>show</code>	Show running system information
<code>copp</code>	Control-Plane Policing
<code>profile</code>	CoPP Profile
<code>strict</code>	display strict profile
<code>moderate</code>	display moderate profile
<code>lenient</code>	display lenient profile
<code>dense</code>	display dense profile
<code><u>readonly</u></code>	(Optional) Read Only
<code><i>acl-type</i></code>	(Optional) access-list type
<code>TABLE_coppprof</code>	(Optional) copp profile
<code><i>acl-grp-name</i></code>	(Optional) name of the access-list
<code>TABLE_sequence</code>	(Optional) ACE RULE SYNTAX TABLE
<code><i>permitdeny</i></code>	(Optional) permit/deny
<code><i>proto</i></code>	(Optional) A protocol number
<code><i>proto_str</i></code>	(Optional) Protocol name

show copp profile

<i>ip</i>	(Optional) IP
<i>ipv6</i>	(Optional) IPV6
<i>src_any</i>	(Optional) SRCAny
<i>dest_any</i>	(Optional) DESTAny
<i>src_ip_prefix</i>	(Optional) Source IP prefix
<i>src_ip_addr</i>	(Optional) Source IP address
<i>src_ip_mask</i>	(Optional) Source IP mask
<i>src_mac_addr</i>	(Optional) Source MAC address
<i>src_mac_mask</i>	(Optional) Source MAC mask
<i>src_mac_any</i>	(Optional) SRCMACAny
<i>dest_ip_prefix</i>	(Optional) Destination IP prefix
<i>dest_ip_addr</i>	(Optional) Destination IP address
<i>dest_ip_mask</i>	(Optional) Destination IP mask
<i>dest_mac_addr</i>	(Optional) Destination MAC address
<i>dest_mac_mask</i>	(Optional) Destination MAC mask
<i>dest_mac_any</i>	(Optional) DESTMACAny
<i>src_port_op</i>	(Optional) Source Port operator
<i>dest_port_op</i>	(Optional) Destination Port operator
<i>src_port1_str</i>	(Optional) Source port name
<i>src_port1_num</i>	(Optional) Source port number
<i>src_port2_str</i>	(Optional) Source port name
<i>src_port2_num</i>	(Optional) Source port number
<i>dest_port1_str</i>	(Optional) Destination port name
<i>dest_port1_num</i>	(Optional) Destination port number
<i>dest_port2_str</i>	(Optional) Destination port name
<i>dest_port2_num</i>	(Optional) Destination port number
<i>icmp_type</i>	(Optional) ICMP type
<i>icmp_code</i>	(Optional) ICMP code
<i>icmp_str</i>	(Optional) ICMP message

<i>icmpv6_type</i>	(Optional) ICMP type
<i>icmpv6_code</i>	(Optional) ICMP code
<i>icmpv6_str</i>	(Optional) ICMP message
<i>src_addrgrp</i>	(Optional) Source address group
<i>dest_addrgrp</i>	(Optional) Destination address group
<i>src_portgrp</i>	(Optional) Source port group
<i>dest_portgrp</i>	(Optional) Destination port group
<i>eth_proto</i>	(Optional) MAC protocol number
<i>newline</i>	(Optional) newline between access-list and cmaps
TABLE_classmap	(Optional) Class Map
<i>opt_any_or_all</i>	(Optional) Enter match-any or match-all
<i>cmap_name</i>	(Optional) Name of the class-map
<i>access_grp</i>	(Optional) Access Group
<i>acc_grp_name</i>	(Optional)
<i>redirect</i>	(Optional)
<i>opt_match_redirect</i>	(Optional) Match criteria for redirected packets
<i>exception</i>	(Optional)
<i>opt_match_except</i>	(Optional) Match criteria for exception packets
<i>protocol</i>	(Optional)
<i>opt_match_protocol</i>	(Optional) Match criteria for protocol packets
TABLE_policymap	(Optional) Policy Map table
<i>class-name</i>	(Optional) Name if the policy member
<i>pmap_name</i>	(Optional) Name of the Policy-map
<i>set_vld_flg</i>	(Optional) Set valid flag
<i>cos-val</i>	(Optional) Set cos val
<i>opt_kbps_mbps_gbps_pps_cir</i>	(Optional) Units
<i>percent</i>	(Optional)
<i>opt_kbytes_mbytes_gbytes_bc</i>	(Optional) Units
<i>opt_drop_transmit_conform</i>	(Optional) Set the action

show copp profile

<i>opt_drop_transmit_violate</i>	(Optional) Set the action
<i>opt_kbps_mbps_gbpc_pps_pir</i>	(Optional) Units
<i>percent1</i>	(Optional)
<i>opt_kbytes_mbytes_gbytes_be</i>	(Optional) Units
<i>opt_drop_transmit_conform1</i>	(Optional) Set the action
<i>set-cos-transmit</i>	(Optional)
<i>set-cos-val</i>	(Optional) Conform action cos val
<i>set-dscp-transmit</i>	(Optional)
<i>set-dscp-val</i>	(Optional) Conform action dscp val
<i>set-prec-transmit</i>	(Optional)
<i>set-prec-val</i>	(Optional) Conform action prec val
<i>policer_show_flags</i>	(Optional) Policer show flags
<i>opt_drop_transmit_exceed</i>	(Optional) Set the action
<i>set</i>	(Optional)
<i>dscp1</i>	(Optional)
<i>dscp2</i>	(Optional)
<i>table</i>	(Optional)
<i>cir-markdown-map</i>	(Optional)
<i>opt_drop_transmit_violate1</i>	(Optional) Set the action
<i>set1</i>	(Optional)
<i>dscp3</i>	(Optional)
<i>dscp4</i>	(Optional)
<i>table1</i>	(Optional)
<i>pir-markdown-map</i>	(Optional)
<i>cos</i>	(Optional)
<i>inner</i>	(Optional)
<i>dscp</i>	(Optional)
<i>tunnel</i>	(Optional)
<i>dscp-val</i>	(Optional) Set dscp val

precedence	(Optional)
tunnell	(Optional)
<i>prec-val</i>	(Optional) Set prec val

Command Mode

- /exec

show copp status

show copp status

```
show copp status [ __readonly__ { last_config_operation <last_cfg_oper> } { last_config_operation_time
<last_cfg_oper_time> } { last_config_operation_status <last_cfg_oper_status> } [ last_config_operation_error
<last_cfg_oper_error> ] { service_policy <srv_policy> } ]
```

Syntax Description

show	Show running system information
copp	Control-Plane Policing
status	Show the internal status of CoPP
<u>__readonly__</u>	(Optional)
last_config_operation	(Optional) last config operation
<i>last_cfg_oper</i>	(Optional) last config operation
last_config_operation_time	(Optional) timestamp of last config operation
<i>last_cfg_oper_time</i>	(Optional) timestamp of last config operation
last_config_operation_status	(Optional) status of last config operation
<i>last_cfg_oper_status</i>	(Optional) status of last config operation
last_config_operation_error_time	(Optional) timestamp of last config operation's error
<i>last_cfg_oper_error_time</i>	(Optional) timestamp of last config operation's error
last_config_operation_error	(Optional) last config operation's error
<i>last_cfg_oper_error</i>	(Optional) last config operation's error
service_policy	(Optional) policy-map attached to control-plane
<i>srv_policy</i>	(Optional) policy-map attached to control-plane

Command Mode

- /exec

show copyright

show copyright [__readonly__ { <content> }]

Syntax Description

show	Show running system information
copyright	Copyright information
__readonly__	(Optional)
<i>content</i>	(Optional) Copyrigh information

Command Mode

- /exec

show cores

show cores

```
show cores [ vdc-all | { vdc [ <e-vdc2> | <vdc-id> ] } ] [ __readonly__ { [ TABLE_cores <vdc_id> <module_id><instance><process_name><pid><sys_time> ] } ]
```

Syntax Description

show	Show running system information
cores	show all core dumps for the current vdc
vdc-all	(Optional) show core dumps from all vdc's
vdc	(Optional) show all core dumps for the vdc
__readonly__	(Optional)
TABLE_cores	(Optional)
<i>vdc_id</i>	(Optional) vdc id
<i>module_id</i>	(Optional) module id
<i>instance</i>	(Optional) instance number
<i>process_name</i>	(Optional) name of the process
<i>pid</i>	(Optional) process id
<i>sys_time</i>	(Optional) core generate time
<i>e-vdc2</i>	(Optional) Enter VDC <vdc-id>
<i>vdc-id</i>	(Optional) vdc number

Command Mode

- /exec

show crypto ca certificates

```
show crypto ca certificates [ __readonly__ [ { TABLE_ca_certificates <trustpoint> [ <certificate> ] [ { TABLE_ca_cert_chains <index> <ca_certificate> } ] } ]]
```

Syntax Description

show	Show running system information
crypto	show crypto configuration
ca	show trustpoint configuration
certificates	show various certificates
__readonly__	(Optional)
TABLE_ca_certificates	(Optional) Table of CA certificates
<i>trustpoint</i>	(Optional) Trustpoint name
<i>certificate</i>	(Optional) Certificate
TABLE_ca_cert_chains	(Optional) Table of CA certificates in chain
<i>index</i>	(Optional) CA Certificate Index
<i>ca_certificate</i>	(Optional) CA certificate

Command Mode

- /exec

show crypto ca certificates

show crypto ca certificates

```
show crypto ca certificates <s0> [ __readonly__ { Trustpoint <trustpoint> } [ { Certificate <certificate> } ] [ { TABLE_ca_cert_chains <index> <ca_certificate> } ] ]
```

Syntax Description

show	Show running system information
crypto	show crypto configuration
ca	show trustpoint configuration
certificates	show various certificates
<i>s0</i>	trustpoint label
<u>__readonly__</u>	(Optional)
Trustpoint	(Optional) Trustpoint
<i>trustpoint</i>	(Optional) Trustpoint
Certificate	(Optional) Certificate
<i>certificate</i>	(Optional) Certificate
TABLE_ca_cert_chains	(Optional) Table of CA certificates in chain
<i>index</i>	(Optional) CA Certificate Index
<i>ca_certificate</i>	(Optional) CA certificate

Command Mode

- /exec

show crypto ca certstore

```
show crypto ca certstore [ __readonly__ { certstore_lookup <lookup_type> } ]
```

Syntax Description

show	Show running system information
crypto	Show crypto configuration
ca	show crypto ca configuration
certstore	Show the configured certstore
__readonly__	(Optional)
certstore_lookup	(Optional) Certificate strore lookup
<i>lookup_type</i>	(Optional) Lookup type

Command Mode

- /exec

show crypto ca crl

show crypto ca crl <s0> [__readonly__ { Trustpoint <trustpoint> } [{ CRL <crl> }]]

Syntax Description

show	Show running system information
crypto	show crypto configuration
ca	show trustpoint configuration
crl	show CRL
<i>s0</i>	trustpoint label
__readonly__	(Optional)
Trustpoint	(Optional) Trustpoint
<i>trustpoint</i>	(Optional) Trustpoint
CRL	(Optional) Certificate Revocation List
<i>crl</i>	(Optional) Certificate Revocation List

Command Mode

- /exec

show crypto ca remote-certstore

```
show crypto ca remote-certstore [ __readonly__ { remote_cert_store <rem_cert_store> } [ { crl_timer <crltimer> } { ldap_server_group <ldap_server_grp> } ] ]
```

Syntax Description

show	Show running system information
crypto	Show crypto configuration
ca	show crypto ca configuration
remote-certstore	Show remote certstore configuration
__readonly__	(Optional)
remote_cert_store	(Optional) Remote cert store
rem_cert_store	(Optional) Remote certificate store
crl_timer	(Optional) CRL timer
crltimer	(Optional) CRL timer
ldap_server_group	(Optional) LDAP Server Group
ldap_server_grp	(Optional) LDAP Server Group

Command Mode

- /exec

show crypto ca trustpoints

show crypto ca trustpoints

```
show crypto ca trustpoints [ __readonly__ [ { TABLE_ca_truspoints <trustpoint> <key-pair> [ { TABLE_revocation_methods <revocation-method> } ] [ <ocsp-url> ] } ]]
```

Syntax Description

show	Show running system information
crypto	show crypto configuration
ca	show trustpoint configuration
trustpoints	show trustpoint configuration
<u>__readonly__</u>	(Optional)
<i>trustpoint</i>	(Optional) Trustpoint
<i>key-pair</i>	(Optional) Key pair
TABLE_revocation_methods	(Optional) Table of revocation methods
<i>revocation-method</i>	(Optional) Revocation mehtod
<i>ocsp-url</i>	(Optional) OCSP URL
TABLE_ca_truspoints	(Optional) Table of CA trustpoints

Command Mode

- /exec

show crypto ca trustpool

```
show crypto ca trustpool [ __readonly__ [ { TABLE_ca_trustpool <serial-number> <subject> <issued-by> <validity-start> <validity-end> } ] ]
```

Syntax Description

show	Show running system information
crypto	show crypto information
ca	show trustpool data
trustpool	trustpool contents
__readonly__	(Optional)
TABLE_ca_trustpool	(Optional) Table of CA trustpool
<i>serial-number</i>	(Optional) Serial number
<i>subject</i>	(Optional) subject
<i>issued-by</i>	(Optional) Issued by
<i>validity-start</i>	(Optional) validity start date
<i>validity-end</i>	(Optional) validity end date

Command Mode

- /exec

show crypto ca trustpool last download status

show crypto ca trustpool last download status

show crypto ca trustpool last download status [__readonly__ [http_url <http_url>] [download_time <download_time>] [trustpool_download_status <status>] [download_failure <reason>]]

Syntax Description

show	Show running system information
crypto	show crypto information
ca	show trustpool data
trustpool	trustpool data
last	last trustpool download status
download	download of trustpool
status	download status
__readonly__	(Optional)
http_url	(Optional) http url configured
http_url	(Optional) HTTP url
download_time	(Optional) Download time
download_time	(Optional) Download time
trustpool_download_status	(Optional) Status of trutspool policy download
status	(Optional) Download status
download_failure	(Optional) Download failure
reason	(Optional) Download failure reason

Command Mode

- /exec

show crypto ca trustpool policy

show crypto ca trustpool policy [__readonly__ [http_url <http_url>] [config_vrf[<config_vrf>] [<src_intf>]] [proxy_server [<proxy_server>] [<proxy_server_port>]]]

Syntax Description

show	Show running system information
crypto	show crypto information
ca	show Certificate authority related config
trustpool	show trustpool policy
policy	trustpool configuration
__readonly__	(Optional)
http_url	(Optional) http url configured
http_url	(Optional) HTTP url
config_vrf	(Optional) Configured vrf
config_vrf	(Optional) vrf configured
src_intf	(Optional) source interface for vrf
proxy_server	(Optional) Configured proxy server
proxy_server	(Optional) proxy server
proxy_server_port	(Optional) proxy server port

Command Mode

- /exec

show crypto certificatemap

show crypto certificatemap

```
show crypto certificatemap [ __readonly__ [ { TABLE_certmap <map_name> <subject_name>
<alternate_email> <alternate_upn> } ] ]
```

Syntax Description

show	Show running system information
crypto	show crypto configuration
certificatemap	show certificatemap filters
__readonly__	(Optional)
TABLE_certmap	(Optional) Table of Certificate Map
<i>map_name</i>	(Optional) Map name
<i>subject_name</i>	(Optional) Subject name
<i>alternate_email</i>	(Optional) Alternate Email
<i>alternate_upn</i>	(Optional) Alternate UPN

Command Mode

- /exec

show crypto key mypubkey rsa

```
show crypto key mypubkey rsa [ __readonly__ [ { TABLE_rsa_keys <key_label> <key_size> <exportable>
<err_string> } ] ]
```

Syntax Description

show	Show running system information
crypto	show crypto configuration
key	show key configuration
mpubkey	show my public keys configuration
rsa	show my rsa public keys configuration
__readonly__	(Optional)
TABLE_rsa_keys	(Optional) Table of RSA keys
key_label	(Optional) Key Label
key_size	(Optional) Key size
exportable	(Optional) Exportable
err_string	(Optional) Error String

Command Mode

- /exec

show crypto ssh-auth-map

show crypto ssh-auth-map

show crypto ssh-auth-map [__readonly__ [{ TABLE_ssh_auth_map <issuer_name> <map1> [<map2>] }]]

Syntax Description

show	Show running system information
crypto	show crypto configuration
ssh-auth-map	show mapping filters applied for ssh authentication
__readonly__	(Optional)
TABLE_ssh_auth_map	(Optional) Table of SSH Auth MAP
<i>issuer_name</i>	(Optional) Issuer Name
<i>map1</i>	(Optional) Map 1
<i>map2</i>	(Optional) Map 2

Command Mode

- /exec

show cts

```
show cts [ __readonly__ <device-id> <cache_en> <num-dot1x> <num-man> <sgt> ]
```

Syntax Description

cts	Show CTS global configuration
__readonly__	(Optional)
<i>device-id</i>	(Optional) name
<i>cache_en</i>	(Optional) enable/disable
<i>num-dot1x</i>	(Optional) number of interfaces in dot1x mode
<i>num-man</i>	(Optional) number of interfaces in manual mode
<i>sgt</i>	(Optional)

Command Mode

- /exec

show current

show current

show current

Syntax Description

show	Display region configurations
current	Display mst configuration currently used

Command Mode

- /exec/configure/spanning-tree/mst/configuration