



## Troubleshooting Guide for Cisco NCS 1004, IOS XR Release 7.7.x

**First Published:** 2022-07-26

**Last Modified:** 2024-04-05

### Americas Headquarters

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883





## CHAPTER 1

# General Troubleshooting

---

This chapter provides procedures for troubleshooting the most common problems encountered when operating the NCS 1004 chassis. To troubleshoot specific alarms, see the *Alarm Troubleshooting* chapter. If you cannot find what you are looking for, contact Cisco Technical Support (1 800 553-2447).

- [Validate and Troubleshoot Installation of Software Packages, on page 1](#)
- [Troubleshoot the Management Interface, on page 3](#)
- [Troubleshoot Environmental Parameters, on page 5](#)
- [Verify Firmware Version, on page 9](#)
- [Loopback, on page 12](#)
- [LLDP Drop, on page 28](#)
- [Trail Trace Identifier, on page 31](#)
- [Troubleshoot the Trunk Port, on page 39](#)
- [Troubleshoot a Failed Commit Configuration, on page 41](#)
- [Verify the Performance Monitoring Parameters of Controllers, on page 41](#)
- [Using SNMP for Troubleshooting, on page 45](#)
- [Using Netconf for Troubleshooting, on page 46](#)
- [Verify Alarms, on page 49](#)
- [Using Onboard Failure Logging, on page 50](#)
- [Capture Logs, on page 52](#)
- [Verify Process Details and Crash Dump, on page 54](#)

## Validate and Troubleshoot Installation of Software Packages

### Procedure

---

#### Step 1 show version

Displays the software version and details such as system uptime.

**Example:**

```
RP/0/RP0/CPU0:ios# show version
Mon Nov 22 22:50:09.240 IST
Cisco IOS XR Software, Version 7.5.1
Copyright (c) 2013-2021 by Cisco Systems, Inc.
```

## Validate and Troubleshoot Installation of Software Packages

```

Build Information:
Built By      : xxxxxxxxx
Built On      : Sun Nov 21 23:25:35 PST 2021
Built Host    : iox-lnx-054
Workspace    : /auto/srcarchive15/prod/7.5.1/ncs1004/ws
Version       : 7.5.1
Location      : /opt/cisco/XR/packages/
Label         : 7.5.1

cisco NCS-1004 () processor
System uptime is 2 minutes

```

### Step 2 show install repository

Displays a list of all the installed software packages on NCS 1004.

#### Example:

```

RP/0/RP0/CPU0:ios# show install repository
Wed Oct 13 20:14:15.984 IST
6 package(s) in XR repository:
  ncs1004-mini-x-7.5.1
  ncs1004-mpls-2.0.0.0-r751
  ncs1004-k9sec-2.1.0.0-r751.x86_64
  ncs1004-xr-7.5.1
  ncs1004-mpls-te-rsvp-2.1.0.0-r751

```

### Step 3 show install active

Displays a list of all the installed and active software packages on NCS 1004.

The following sample output displays active software packages.

#### Example:

```

RP/0/RP0/CPU0:ios# show install active           Mon Mar 11 07:31:12.302 UTC
Wed Oct 13 20:14:15.984 IST
Node 0/RP0/CPU0 [RP]
  Boot Partition: xr_lv19
  Active Packages: 5
    ncs1004-mini-x-7.5.1
    ncs1004-mpls-2.0.0.0-r751
    ncs1004-k9sec-2.1.0.0-r751.x86_64
    ncs1004-xr-7.5.1
    ncs1004-mpls-te-rsvp-2.1.0.0-r751

```

### Step 4 show install committed

Displays a list of all committed software packages on NCS 1004.

The committed software packages are the software packages that are booted on an NCS 1004 reload. Committed packages are the packages that are persistent across reloads. If you install and activate a package, it remains active until the next reload. If you commit a package set, all packages in that set remain active across reloads until the package set is replaced with another committed package set.

The following sample output displays the committed software packages.

#### Example:

```

RP/0/RP0/CPU0:ios# show install committed
Wed Oct 13 20:14:15.984 IST
Node 0/RP0/CPU0 [RP]
  Boot Partition: xr_lv19
  Committed Packages: 5
    ncs1004-mini-x-7.5.1
    ncs1004-mpls-2.0.0.0-r751

```

```
ncs1004-k9sec-2.1.0.0-r751.x86_64
ncs1004-xr-7.5.1
ncs1004-mpls-te-rsvp-2.1.0.0-r751
```

### Step 5 show install log

Displays information on the history of the installation operations. This command provides information about both successful and failed installation operations on NCS 1004. You can also verify a Service Maintenance Update (SMU) installation using this command.

#### Example:

```
RP/0/RP0/CPU0:ios# show install log 49 detail
Wed Dec  9 01:19:18.680 UTC
Dec 09 01:19:07 Install operation 49 started by root:
  install add source tftp://10.105.236.167 ncs1004-k9sec.rpm
Dec 09 01:19:08 Action 1: install add action started
Dec 09 01:19:08 ERROR! Either file is not proper or error in getting rpm metadata from rpm
  file

Dec 09 01:19:08 ERROR!! failed to complete install add precheck

Dec 09 01:19:09 Install operation 49 aborted
Dec 09 01:19:10 Ending operation 49
```

In the above example, either a wrong rpm package is used or the rpm package is corrupted.

For failure on install add source, check that the package is correctly named and is available at the location.

#### What to do next

If the expected active software packages are not displayed, install the packages (if required) and activate the packages using the **install activate package\_name** command.

## Troubleshoot the Management Interface

#### Before you begin

Management interface should be configured.

#### Procedure

### Step 1 show interfaces mgmtEth *instance*

Displays the management interface configuration.

#### Example:

```
RP/0/RP0/CPU0:ios# show interfaces MgmtEth 0/RP0/CPU0/0
Fri Nov 13 19:42:29.716 UTC
MgmtEth0/RP0/CPU0/0 is administratively down, line protocol is administratively down
  Interface state transitions: 0
  Hardware is Management Ethernet, address is badb.adba.d098 (bia badb.adba.d098)
  Internet address is 10.58.227.183/24
  MTU 1514 bytes, BW 100000 Kbit (Max: 100000 Kbit)
```

## Troubleshoot the Management Interface

```

    reliability 255/255, txload 0/255, rxload 0/255
Encapsulation ARPA,
Full-duplex, 100Mb/s, CX, link type is autonegotiation
loopback not set,
ARP type ARPA, ARP timeout 04:00:00
Last input never, output never
Last clearing of "show interface" counters never
5 minute input rate 0 bits/sec, 0 packets/sec
5 minute output rate 0 bits/sec, 0 packets/sec
    0 packets input, 0 bytes, 0 total input drops
    0 drops for unrecognized upper-level protocol
    Received 0 broadcast packets, 0 multicast packets
        0 runts, 0 giants, 0 throttles, 0 parity
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
    0 packets output, 0 bytes, 0 total output drops
    Output 0 broadcast packets, 0 multicast packets
    0 output errors, 0 underruns, 0 applique, 0 resets
    0 output buffer failures, 0 output buffers swapped out
    0 carrier transitions

```

- a) In the above result, the management interface is administratively down. Use the **no shut** command to enable the management interface.

The following example shows sample output from the **show running-config interface mgmtEth** command when the management interface is in the no shut state.

```

RP/0/RP0/CPU0:ios#show running-config interface mgmtEth 0/RP0/CPU0/0
Fri Nov 13 19:42:54.368 UTC
interface MgmtEth0/RP0/CPU0/0
    ipv4 address dhcp
!

```

You can also use the **show interfaces summary** and **show interfaces brief** commands in the Cisco IOS XR EXEC mode to verify the management interface status.

- The following example shows sample output from the **show interfaces summary** command.

```

RP/0/RP0/CPU0:ios# show interfaces summary
Wed Mar  4 06:14:52.995 UTC
Interface Type      Total     UP       Down     Admin Down
-----  -----
ALL TYPES          4         2        0        2
-----
IFT_ETHERNET       3         1        0        2
IFT_NULL           1         1        0        0

```

- The following example shows sample output from the **show interfaces brief** command.

```

RP/0/RP0/CPU0:ios# show interfaces brief
Wed Mar  4 06:15:51.689 UTC

      Intf      Intf      LineP      Encap      MTU      BW
      Name      State     State     Type (byte)   (Kbps)
-----  -----
          Nu0      up       up      Null      1500      0
Mg0/RP0/CPU0/0      up       up     ARPA     1514  1000000
Mg0/RP0/CPU0/1  admin-down  admin-down  ARPA     1514  1000000
Mg0/RP0/CPU0/2  admin-down  admin-down  ARPA     1514  1000000

```

**Step 2** When the line protocol is down, you must verify the Layer 3 connectivity. You can perform the following steps.

- a) Check the Ethernet cable connection and physical connectivity of NCS 1004 to get the line protocol up.

- b) Ensure ARP connectivity.
  - c) Use the **ping** command to check reachability and network connectivity on the IP network.
  - d) Verify the static IP and default gateway configuration.
- 

## Troubleshoot Environmental Parameters

Some of the common environmental problems are listed below.

- Fan failure
- Fan not detected
- Fan speed problem
- Power module fails
- Power module not detected
- Temperature of the device exceeds a threshold value
- Voltage of the device exceeds a threshold value

### Procedure

---

#### Step 1 admin

Enters system admin EXEC mode.

**Example:**

```
RP/0/RP0/CPU0:ios# admin
```

#### Step 2 show environment [all | fan | power | voltages | current | temperatures ] [ location | location ]

Displays the environmental parameters of NCS 1004.

**Example:**

The following example shows sample output from the **show environment** command with the **fan** keyword.

```
sysadmin-vm:0_RP0# show environment fanWed Mar  4  05:36:33.678 UTC+00:00
=====
                                         Fan speed (rpm)
Location     FRU Type          FAN_0    FAN_1
-----
0/FT0        NCS1K4-FAN      7020     6930
0/FT1        NCS1K4-FAN      6780     6690
0/FT2        NCS1K4-FAN      6810     6720
0/PM0        NCS1K4-AC-PSU   25376    24352
0/PM1        NCS1K4-AC-PSU   11200    11232
```

The following example shows sample output from the **show environment** command with the **temperatures** keyword.

## Troubleshoot Environmental Parameters

```
sysadmin-vm:0_RP0# show environment temperatures location 0/RP0
Wed Mar 4 05:44:51.221 UTC+00:00
=====
Location    TEMPERATURE           Value   Crit Major Minor Minor Major Crit
Sensor          (deg C)      (Lo) (Lo) (Lo) (Hi) (Hi) (Hi)
-----
0/RP0
    TEMP_LOCAL            32     -10     -5     0    55    65    70
    TEMP_REMOTE1          32     -10     -5     0    55    65    70
    TEMP_CPU_DIE          31     -10     -5     0    75    80    90
```

The following example shows sample output from the **show environment** command with the **power** keyword.

```
sysadmin-vm:0_RP0# show environment power
Wed Mar 4 05:45:35.640 UTC+00:00
=====
CHASSIS LEVEL POWER INFO: 0
=====
Total output power capacity (N + 1) : 2000W + 0W
Total output power required : 910W
Total power input : 456W
Total power output : 407W

Power Group 0:
=====
Power      Supply      -----Input----  -----Output--- Status
Module     Type       Volts     Amps     Volts     Amps
-----
0/PM0      2kW-AC     0.0       0.0      0.0       0.0    FAILED or NO PWR

Total of Power Group 0: 0W/ 0.0A      0W/ 0.0A

Power Group 1:
=====
Power      Supply      -----Input----  -----Output--- Status
Module     Type       Volts     Amps     Volts     Amps
-----
0/PM1      2kW-AC     227.8     2.0      12.0     33.9    OK

Total of Power Group 1: 456W/ 2.0A      407W/ 33.9A

=====
Location   Card Type      Power      Power      Status
          Allocated Used
          Watts     Watts
-----
0/0        NCS1K4-LC-FILLER 0         -        RESERVED
0/1        NCS1K4-1.2T-K9  260       101      ON
0/2        NCS1K4-1.2TL-K9 260       168      ON
0/3        NCS1K4-LC-FILLER 0         -        RESERVED
0/RP0      NCS1K4-CNTLR-K9 55        -        ON
0/FT0      NCS1K4-FAN      100       -        ON
0/FT1      NCS1K4-FAN      100       -        ON
0/FT2      NCS1K4-FAN      100       -        ON
0/SCO     NCS1004          35        -        ON
```

The following example shows sample output from the **show environment** command with the **voltages** keyword.

```
sysadmin-vm:0_RP0# show environment voltages location 0/RP0
Wed Mar 4 05:47:24.668 UTC+00:00
=====
Location    VOLTAGE           Value   Crit Minor Minor Crit
Sensor          (mV)      (Lo) (Lo) (Hi) (Hi)
-----

```

0/RP0							
ADM1266_VH1_12V	12028	10800	11040	12960	13200		
ADM1266_VH3_3V3	3306	3036	3135	3465	3564		
ADM1266_VH4_2V5	2492	2300	2375	2625	2700		
ADM1266_VP1_1V8	1801	1656	1710	1890	1944		
ADM1266_VP2_1V2	1201	1104	1140	1260	1296		
ADM1266_3V3_STAND_BY	3293	3036	3135	3465	3564		
ADM1266_VP4_3V3_CPU	3301	3036	3135	3465	3564		
ADM1266_VP5_2V5_CPU	2494	2300	2375	2625	2700		
ADM1266_VP6_1V8_CPU	1797	1656	1710	1890	1944		
ADM1266_VP7_1V24_VCCREF	1236	1140	1178	1302	1339		
ADM1266_VP8_1V05_CPU	1045	966	997	1102	1134		
ADM1266_VP9_1V2_DDR_VDDQ	1196	1104	1140	1260	1296		
ADM1266_VP10_1V0_VCCRAM	1074	500	650	1300	1400		
ADM1266_VP11_VNN	882	400	550	1300	1400		
ADM1266_VP12_VCCP	1068	300	450	1300	1400		
ADM1266_VP13_0V6_VTT	599	552	570	630	648		
ADM1293_DB_5V0	5007	4600	4750	5250	5400		
ADM1293_DB_3V3	3305	3036	3135	3465	3564		
ADM1293_DB_5V0_USB_0	5007	4000	4500	5500	6000		
ADM1293_DB_5V0_USB_1	5017	4000	4500	5500	6000		
ADM1293_MB_5V0_PMODO	5062	4600	4750	5250	5400		
ADM1293_MB_5V0_PMOD1	5032	4600	4750	5250	5400		
ADM1293_MB_2V5_PLL	2483	2300	2375	2625	2700		

### Step 3 show inventory

Displays inventory information for all the physical entities of NCS 1004.

```
RP/0/RP0/CPU0:ios# show inventory
Wed Mar  4 05:10:17.107 UTC
NAME: "0/0", DESCRIPTOR: "Network Convergence System 1004 Filler"
PID: NCS1K4-LC-FILLER, VID: V01, SN: N/A

NAME: "0/1", DESCRIPTOR: "NCS1K4 12x QSFP28 2 Trunk C-Band DWDM card"
PID: NCS1K4-1.2T-K9, VID: V00, SN: CAT2250B0AE

NAME: "0/1-Optics0/1/0/2", DESCRIPTOR: "Cisco 100G QSFP28 AOC Pluggable Optics Module"
PID: QSFP-100G-AOC3M , VID: V03, SN: INL22262339-A

NAME: "0/1-Optics0/1/0/4", DESCRIPTOR: "Cisco 100GE QSFP28 SR4 Pluggable Optics Module"
PID: QSFP-100G-SR4-S, VID: V03, SN: AVF2219S16U

NAME: "0/1-Optics0/1/0/5", DESCRIPTOR: "Cisco 100G QSFP28 LR4-S Pluggable Optics Module"
PID: QSFP-100G-LR4-S, VID: V02, SN: JFQ2145701U

NAME: "0/1-Optics0/1/0/6", DESCRIPTOR: "Cisco 100GE QSFP28 SR4 Pluggable Optics Module"
PID: QSFP-100G-SR4-S, VID: ES1, SN: AVF1925G012

NAME: "0/1-Optics0/1/0/7", DESCRIPTOR: "Cisco 100G QSFP28 LR4-S Pluggable Optics Module"
PID: QSFP-100G-LR4-S, VID: V02, SN: JFQ2145706N

NAME: "0/1-Optics0/1/0/8", DESCRIPTOR: "Cisco QSFP-100G-LR4 Pluggable Optics Module"
PID: ONS-QSFP28-LR4, VID: V01, SN: JFQ19026014

NAME: "0/1-Optics0/1/0/9", DESCRIPTOR: "Cisco 100G QSFP28 LR4-S Pluggable Optics Module"
PID: QSFP-100G-LR4-S, VID: V02, SN: OPM220518HS

NAME: "0/1-Optics0/1/0/10", DESCRIPTOR: "Cisco 100G QSFP28 SM-SR Pluggable Optics Module"
PID: QSFP-100G-SM-SR, VID: V02, SN: INL21490043

NAME: "0/1-Optics0/1/0/11", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
PID: QSFP-100G-CWDM4-S , VID: V01, SN: JFQ211930JL

NAME: "0/1-Optics0/1/0/12", DESCRIPTOR: "Cisco 100G QSFP28 CWDM4 Pluggable Optics Module"
```

## Troubleshoot Environmental Parameters

```

PID: QSFP-100G-CWDM4-S, VID: V02, SN: JFQ2210801H

NAME: "0/2", DESCRIPTOR: "NCS1K4 12x QSFP28 2 Trunk L-Band DWDM card"
PID: NCS1K4-1.2TL-K9 , VID: V00, SN: CAT2337B0S4

NAME: "0/2-Optics0/2/0/2", DESCRIPTOR: "Cisco 100G QSFP28 AOC Pluggable Optics Module"
PID: QSFP-100G-AOC3M, VID: V03, SN: INL22262332-A

NAME: "0/2-Optics0/2/0/4", DESCRIPTOR: "Cisco 100G QSFP28 SM-SR Pluggable Optics Module"
PID: QSFP-100G-SM-SR, VID: V02, SN: FNS22070HWF

NAME: "0/2-Optics0/2/0/5", DESCRIPTOR: "Cisco 100G QSFP28 SM-SR Pluggable Optics Module"
PID: QSFP-100G-SM-SR, VID: V02, SN: SPT2225302D

NAME: "0/2-Optics0/2/0/6", DESCRIPTOR: "Cisco 100G QSFP28 LR4-S Pluggable Optics Module"
PID: QSFP-100G-LR4-S, VID: V02, SN: FNS22310Z1X

NAME: "0/2-Optics0/2/0/8", DESCRIPTOR: "Cisco QSFP-100G-LR4 Pluggable Optics Module"
PID: ONS-QSFP28-LR4, VID: V01, SN: FNS20520R8Z

NAME: "0/2-Optics0/2/0/9", DESCRIPTOR: "Cisco 100G QSFP28 AOC Pluggable Optics Module"
PID: QSFP-100G-AOC3M, VID: V03, SN: INL23312282-A

NAME: "0/2-Optics0/2/0/10", DESCRIPTOR: "Cisco 100G QSFP28 AOC Pluggable Optics Module"
PID: QSFP-100G-AOC3M, VID: V03, SN: INL23312282-B

NAME: "0/2-Optics0/2/0/11", DESCRIPTOR: "Cisco 100G QSFP28 LR4-S Pluggable Optics Module"
PID: QSFP-100G-LR4-S, VID: V02, SN: FNS23080LKF

NAME: "0/3", DESCRIPTOR: "Network Convergence System 1004 Filler"
PID: NCS1K4-LC-FILLER, VID: V01, SN: N/A

NAME: "0/RP0", DESCRIPTOR: "Network Convergence System 1004 Controller"
PID: NCS1K4-CNTLR-K9, VID: V00, SN: CAT2231B069

NAME: "0/SC0", DESCRIPTOR: "Network Convergence System 1004 Chassis"
PID: NCS1004, VID: V00, SN: CAT2231B192

NAME: "Rack 0", DESCRIPTOR: "Network Convergence System 1004 Chassis"
PID: NCS1004, VID: V00, SN: CAT2231B192

NAME: "0/FT0", DESCRIPTOR: "Network Convergence System 1004 Fan"
PID: NCS1K4-FAN, VID: V00, SN: CAT2231B2GL

NAME: "0/FT1", DESCRIPTOR: "Network Convergence System 1004 Fan"
PID: NCS1K4-FAN, VID: V00, SN: CAT2231B2H4

NAME: "0/FT2", DESCRIPTOR: "Network Convergence System 1004 Fan"
PID: NCS1K4-FAN, VID: V00, SN: CAT2231B2GW

NAME: "0/PM0", DESCRIPTOR: "Network Convergence System 1004 AC Power Supply Unit"
PID: NCS1K4-AC-PSU, VID: V00, SN: POG2221CL1V

NAME: "0/PM1", DESCRIPTOR: "Network Convergence System 1004 AC Power Supply Unit"
PID: NCS1K4-AC-PSU, VID: V00, SN: POG2221CL04

```

### What to do next

Environment parameter anomalies are logged in the syslog. Hence, if an environment parameter displayed in the **show environment** command output is not as expected, check the syslog using the **show logging** command. The syslog provides details on any logged problems.

# Verify Firmware Version

The firmware on various hardware components of NCS 1004 must be compatible with the installed Cisco IOS XR image. Incompatibility may cause the NCS 1004 to malfunction.

To verify the firmware version, perform the following procedure.

## Procedure

### Step 1 show hw-module fpd

```
RP/0/RP0/CPU0:ios# show hw-module fpd
Fri Nov 26 14:53:27.188 UTC
```

Auto-upgrade:Disabled

Location	Card type	HWver	FPD device	ATR	FPD Versions		
					Status	Running	Programd
0/0	NCS1K4-OTN-XPL	3.0	LC_CPU_MOD_FW	CURRENT	75.10	75.10	
0/0	NCS1K4-OTN-XPL	7.0	LC_DP_MOD_FW	CURRENT	3.10	3.10	
0/0	NCS1K4-OTN-XPL	2.0	LC_QSFPDD_PORT_11	CURRENT	61.2013	61.2013	
0/0	NCS1K4-OTN-XPL	2.0	LC_QSFPDD_PORT_9	CURRENT	61.2013	61.2013	
0/1	NCS1K4-OTN-XP	2.0	LC_CPU_MOD_FW	CURRENT	75.10	75.10	
0/1	NCS1K4-OTN-XP	7.0	LC_DP_MOD_FW	CURRENT	3.10	3.10	
0/1	NCS1K4-OTN-XP	2.0	LC_QSFPDD_PORT_11	CURRENT	61.2013	61.2013	
0/1	NCS1K4-OTN-XP	2.0	LC_QSFPDD_PORT_9	CURRENT	61.2013	61.2013	
0/RP0	NCS1K4-CNTLR-K9	5.0	CSB_IMG	S	CURRENT	0.200	0.200
0/RP0	NCS1K4-CNTLR-K9	5.0	TAM_FW		CURRENT	36.08	36.08
0/RP0	NCS1K4-CNTLR-K9	1.14	BIOS	S	CURRENT	5.30	5.30
0/RP0	NCS1K4-CNTLR-K9	5.0	CPU_FPGA		CURRENT	1.14	1.14
0/PM1	NCS1K4-AC-PSU	0.1	PO-PrimCU		CURRENT	2.70	2.70
0/SC0	NCS1004	2.0	BP_FPGA		CURRENT	1.25	1.25
0/SC0	NCS1004	2.0	XGE_FLASH		CURRENT	18.04	18.04

Displays firmware information of various hardware components of NCS 1004 in the Cisco IOS XR EXEC mode.

In the previous output, some of the significant fields are:

- FPD Device—Name of the hardware component such as FPD, CFP, and so on.
- ATR—Attribute of the hardware component. Some of the attributes are:
  - B—Backup Image
  - S—Secure Image
  - P—Protected Image
- Status—Upgrade status of the firmware. The different states are:
  - CURRENT—The firmware version is the latest version.
  - NOT READY—The firmware of the FPD is not ready for upgrade.

**Verify Firmware Version**

- NEED UPGD—A newer firmware version is available in the installed image. We recommended that upgrade be performed.
- UPGD PREP—The firmware of the FPD is preparing for upgrade.
- RLOAD REQ—The upgrade is completed, and the card requires a reload.
- UPGD DONE—The firmware upgrade is successful.
- UPGD FAIL—The firmware upgrade has failed.
- UPGD SKIP—The upgrade is skipped because the installed firmware version is higher than the version available in the image.
- Running—Current version of the firmware running on the FPD.

**Step 2 show fpd package**

Use the **show fpd package** command to display the FPD image version available with this software release for each hardware component.

```
RP/0/RP0/CPU0:ios# show fpd package
Fri May  8 05:11:47.819 UTC
```

Field Programmable Device Package					
Card Type	FPD Description	Req Reload	SW Ver	Min Req SW Ver	Min Req Board Ver
NCS1004-K9	BP_FPGA(A)	NO	1.25	1.25	0.0
	XGE_FLASH(A)	YES	18.04	18.04	0.0
NCS1K4-1.2T-K9	LC_CPU_MOD_FW(A)	YES	75.10	75.10	0.0
	LC_OPT_MOD_FW(A)	YES	1.25	1.25	0.0
NCS1K4-1.2T-L-K9	LC_CPU_MOD_FW(A)	YES	75.10	75.10	0.0
	LC_OPT_MOD_FW(A)	YES	1.25	1.25	0.0
NCS1K4-1.2TL-K9	LC_CPU_MOD_FW(A)	YES	75.10	75.10	0.0
	LC_OPT_MOD_FW(A)	YES	1.25	1.25	0.0
NCS1K4-2-QDD-C-K9	LC_CPU_MOD_FW(A)	YES	75.10	75.10	0.0
	LC_OPT_MOD_FW(A)	YES	1.26	1.26	0.0
NCS1K4-2KW-AC	PO-PrIMCU(A)	NO	2.70	2.70	0.0
	PO-PrIMCU(A)	NO	2.70	2.70	0.1
NCS1K4-AC-PSU	PO-PrIMCU(A)	NO	2.70	2.70	0.0
	PO-PrIMCU(A)	NO	2.70	2.70	0.1
NCS1K4-CNTLR	BIOS(A)	YES	5.30	5.30	1.5
	CSB_IMG	YES	0.200	0.200	0.0
NCS1K4-CNTLR-B-K9	BIOS(A)	YES	5.30	5.30	1.0
	CSB_IMG	YES	0.200	0.200	0.0
NCS1K4-DC-PSU	PO-PrIMCU(A)	NO	1.12	1.12	0.0
	PO-PrIMCU(A)	NO	1.12	1.12	0.1
NCS1K4-OTN-XP	LC_CFP2_PORT_0(A)	NO	0.00	0.00	0.0

LC_CFP2_PORT_0 (A)	NO	1.00	1.00	1.0		
LC_CFP2_PORT_0 (A)	NO		1.52	1.52	2.0	
LC_CFP2_PORT_1 (A)	NO		0.00	0.00	0.0	
LC_CFP2_PORT_1 (A)	NO		1.00	1.00	1.0	
LC_CFP2_PORT_1 (A)	NO		1.52	1.52	2.0	
LC_CPU_MOD_FW (A)	YES		75.10	75.10	0.0	
LC_DP_MOD_FW (A)	YES		3.10	3.10	1.0	
LC_DP_MOD_FW (A)	YES		11.10	11.10	2.0	
LC_DP_MOD_FW (A)	YES		11.10	11.10	3.0	
LC_DP_MOD_FW (A)	YES		1.10	1.10	4.0	
LC_DP_MOD_FW (A)	YES		3.10	3.10	7.0	
LC_DP_MOD_FW (A)	YES		1.10	1.10	8.0	
LC_QSFPDD_PORT_11 (A)	NO		0.00	0.00	0.0	
LC_QSFPDD_PORT_11 (A)	NO		61.2013	61.2013	1.0	
LC_QSFPDD_PORT_11 (A)	NO		61.2013	61.2013	2.0	
LC_QSFPDD_PORT_9 (A)	NO		0.00	0.00	0.0	
LC_QSFPDD_PORT_9 (A)	NO		61.2013	61.2013	1.0	
LC_QSFPDD_PORT_9 (A)	NO		61.2013	61.2013	2.0	
<hr/>						
NCS1K4-OTN-XPL	LC_CFP2_PORT_0 (A)		NO	0.00	0.00	0.0
LC_CFP2_PORT_0 (A)	NO	1.00	1.00	1.0		
LC_CFP2_PORT_0 (A)	NO		1.52	1.52	2.0	
LC_CFP2_PORT_1 (A)	NO		0.00	0.00	0.0	
LC_CFP2_PORT_1 (A)	NO		1.00	1.00	1.0	
LC_CFP2_PORT_1 (A)	NO		1.52	1.52	2.0	
LC_CPU_MOD_FW (A)	YES		75.10	75.10	0.0	
LC_DP_MOD_FW (A)	YES		3.10	3.10	1.0	
LC_DP_MOD_FW (A)	YES		11.10	11.10	2.0	
LC_DP_MOD_FW (A)	YES		11.10	11.10	3.0	
LC_DP_MOD_FW (A)	YES		1.10	1.10	4.0	
LC_DP_MOD_FW (A)	YES		3.10	3.10	7.0	
LC_DP_MOD_FW (A)	YES		1.10	1.10	8.0	
LC_QSFPDD_PORT_11 (A)	NO		0.00	0.00	0.0	
LC_QSFPDD_PORT_11 (A)	NO		61.2013	61.2013	1.0	
LC_QSFPDD_PORT_11 (A)	NO		61.2013	61.2013	2.0	
LC_QSFPDD_PORT_9 (A)	NO		0.00	0.00	0.0	
LC_QSFPDD_PORT_9 (A)	NO		61.2013	61.2013	1.0	
LC_QSFPDD_PORT_9 (A)	NO		61.2013	61.2013	2.0	
<hr/>						
NCS1K4-TESTUNIT	LC_CPU_MOD_FW (A)		YES	0.01	0.01	0.0

### What to do next

Upgrade all the FPDs using the **upgrade hw-module location all fpd all** command in the Cisco IOS XR EXEC mode. After upgrade is completed, the Status column shows RLOAD REQ if the software requires reload.

### If Reload is required

If the FPGA location is 0/RP0, use the **admin hw-module location 0/RP0 reload** command. This command reboots only the CPU. As a result, traffic is not impacted. If the FPGA location is 0/0, use the **admin hw-module location all reload** command. This command reboots the chassis. As a result, traffic is impacted. After the reload is completed, the new FPGA runs the current version.



**Caution** The upgrade of OTNXP LC\_DP\_MOD\_FW and LC\_OPT\_MOD\_FW FPDs affect traffic. Hence, you must perform this upgrade during a maintenance window.

### If Firmware Upgrade Fails

If firmware upgrade fails, use the **show logging** command to view the details and upgrade the firmware again using the above commands.



**Note** You can upgrade the firmware version of power modules, only when both the power modules are present and powered on.

## Loopback

You can configure the loopback on the CoherentDSP, FC, OTU, and Ethernet controllers to identify connection problems. The loopback can be configured only in the maintenance mode. Use the **controller controller-type** and the **secondary-admin-state maintenance** commands to place the controllers in the maintenance mode.



**Note** Internal and line loopbacks are supported on the FC, OTU, and Ethernet controllers whereas only internal loopbacks are supported on the CoherentDSP controllers.

### Configuring Loopback on the 1.2T Card

To configure the loopback, use the following commands:

**configure**

**controller controller-type Rack/Slot/Instance/Port**

**sec-admin-state maintenance**

**loopback [ line | internal ]**

**commit**

### Example 1

The following example shows how a line loopback is configured on the Ethernet controller.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller HundredGigECtrlr 1/0/1/10 secondary-admin-state
maintenance
RP/0/RP0/CPU0:ios(config)#commit
Fri Feb 22 19:49:46.504 UTC
RP/0/RP0/CPU0:ios(config)#exit
```

The following example shows how to verify a line loopback configured on the Ethernet controller.

```
RP/0/RP0/CPU0:ios#show controller HundredGigECtrlr 0/1/0/10
Fri Feb 22 19:50:08.328 UTC
Operational data for interface HundredGigECtrlr0/1/0/10:

State:
Administrative state: enabled
Operational state: Up
LED state: Green On
```

```

Maintenance: Enabled
AINS Soak: Pending
    Total Duration: 0 hour(s) 30 minute(s)
    Remaining Duration: 0 hour(s) 30 minute(s) 0 second(s)
Laser Squelch: Enabled

Phy:
Media type: Not known
Statistics:
FEC:
    Corrected Codeword Count: 0
    Uncorrected Codeword Count: 0

Autonegotiation disabled.

Operational values:
Speed: 100Gbps
Duplex: Full Duplex
Flowcontrol: None
Loopback: None (or external)
BER monitoring:
    Not supported
    Forward error correction: Standard (Reed-Solomon)
    Holdoff Time: 0ms
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller HundredGigECtrlr 0/1/0/10 loopback line
RP/0/RP0/CPU0:ios(config)#commit
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show controller HundredGigECtrlr 0/1/0/10
Fri Feb 22 20:01:00.521 UTC
Operational data for interface HundredGigECtrlr0/1/0/10:

State:
Administrative state: enabled
Operational state: Up
LED state: Green On
Maintenance: Enabled
AINS Soak: Pending
    Total Duration: 0 hour(s) 30 minute(s)
    Remaining Duration: 0 hour(s) 30 minute(s) 0 second(s)
Laser Squelch: Enabled

Phy:
Media type: Not known
Statistics:
FEC:
    Corrected Codeword Count: 0
    Uncorrected Codeword Count: 6

Autonegotiation disabled.

Operational values:
Speed: 100Gbps
Duplex: Full Duplex
Flowcontrol: None
Loopback: Line
BER monitoring:
    Not supported
    Forward error correction: Standard (Reed-Solomon)
    Holdoff Time: 0ms

```

## Example 2

The following example shows how to verify an internal loopback configured on the coherent DSP controller.

**Loopback**

```

RP/0/RP0/CPU0:ios#show controllers coherentDSP 0/0/0/0
Fri Mar 13 22:00:20.951 UTC

Port : CoherentDSP 0/0/0/0
Controller State : Up
Inherited Secondary State : Normal
Configured Secondary State : Maintenance
Derived State : Maintenance
Loopback mode : Internal
BER Thresholds : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring : Enable
Bandwidth : 200.0Gb/s

Alarm Information:
LOS = 0 LOF = 1 LOM = 0
OOF = 0 OOM = 0 AIS = 0
IAE = 0 BIAE = 0 SF_BER = 0
SD_BER = 0 BDI = 3 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0
Detected Alarms : None

Bit Error Rate Information
PREFEC BER : 0.00E+00
POSTFEC BER : 0.00E+00
Q-Factor : 16.70 dB

Q-Margin : 0.99dB

TTI :
    Remote hostname : ios
    Remote interface : CoherentDSP 0/0/0/0
    Remote IP addr : 0.0.0.0

FEC mode : Soft-Decision 27

AINS Soak : None
AINS Timer : 0h, 0m
AINS remaining time : 0 seconds

```

**Configuring Loopback on OTN-XP Card**

From R7.2.1 onwards, OTN-XP card supports loopback on the OTU2, OTU2e, OTU4, 10GE, and CoherentDSP controllers.

From R7.3.2 onwards, OTN-XP card supports loopback on the 100GE and 400GE controllers.

From R7.5.2 onwards, OTN-XP card supports loopback on the 16G FC and 32G FC controllers.

The CoherentDSP controller supports both line and internal.

To configure the loopback on the controllers, use the following commands:

**configure**

**controller controller type Rack/Slot/Instance/Port/Lane number**

**sec-admin-state maintenance**

**loopback [ line | internal ]**

**commit**

The range of *Lane number* is 1–4.

**Example 1**

The following example shows how an internal loopback is configured on the 10GE controller.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller tenGigEController 0/0/0/5/2
RP/0/RP0/CPU0:ios(config-eth-controller)#sec-admin-state maintenance
RP/0/RP0/CPU0:ios(config-eth-controller)#loopback internal
RP/0/RP0/CPU0:ios(config-eth-controller)#commit
```

The following example shows how to verify an internal loopback configured on the 10GE controller.

```
RP/0/RP0/CPU0:ios#show controllers tenGigEController 0/0/0/5/2
Thu Apr 23 10:47:48.020 UTC
Operational data for interface TenGigEController0/0/5/2:

State:
    Administrative state: enabled
    Operational state: Up
    LED state: Green On
    Maintenance: Enabled
    AINS Soak: None
        Total Duration: 0 hour(s) 0 minute(s)
        Remaining Duration: 0 hour(s) 0 minute(s) 0 second(s)
    Laser Squelch: Disabled

Phy:
    Media type: Not known

Autonegotiation disabled.

Operational values:
    Speed: 10Gbps
    Duplex: Full Duplex
    Flowcontrol: None
    Loopback: Internal
    Inter-packet gap: standard (12)
    BER monitoring:
        Not supported
    Holdoff Time: 0ms
```

**Example 2**

The following example shows how a line loopback is configured on the OTU2e controller.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller otu2e 0/0/0/11/3
RP/0/RP0/CPU0:ios(config-otu2e)#secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config-otu2e)#loopback line
RP/0/RP0/CPU0:ios(config-otu2e)#commit
Thu Apr 23 10:55:19.319 UTC
RP/0/RP0/CPU0:ios(config-otu2e)#end
```

The following example shows how to verify a line loopback configured on the OTU2e controller.

```
RP/0/RP0/CPU0:ios#show controllers otu2e 0/0/0/11/3
Thu Apr 23 10:55:28.014 UTC

Port : OTU2E 0/0/0/11/3
Controller State : Up
Inherited Secondary State : Normal
```

**Loopback**

```

Configured Secondary State : Maintenance
Derived State : Maintenance
Loopback mode : Line
BER Thresholds : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring : Enable
Bandwidth : 10.0Gb/s

Alarm Information:
LOS = 0 LOF = 1 LOM = 0
OOF = 1 OOM = 1 AIS = 0
IAE = 0 BIAE = 0 SF_BER = 0
SD_BER = 0 BDI = 0 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0
Detected Alarms : None

Bit Error Rate Information
PREFEC BER : 0.00E+00
POSTFEC BER : 0.00E+00

TTI :
    Remote hostname : ios
    Remote interface : OTU2E 0/0/0/11/3
    Remote IP addr : 0.0.0.0

FEC mode : STANDARD

AINS Soak : None
AINS Timer : 0h, 0m
AINS remaining time : 0 seconds

```

**Example 3**

The following example shows how an internal loopback is configured on the OTU2 controller.

```

RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller otu2 0/0/0/5/1
RP/0/RP0/CPU0:ios(config-otu2)#secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config-otu2)#loopback internal
RP/0/RP0/CPU0:ios(config-otu2)#commit
Thu Apr 23 11:01:00.562 UTC
RP/0/RP0/CPU0:ios(config-otu2)#end

```

The following example shows how to verify an internal loopback configured on the OTU2 controller.

```

RP/0/RP0/CPU0:ios#show controllers otu2 0/0/0/5/1
Thu Apr 23 11:01:04.126 UTC

Port : OTU2 0/0/0/5/1
Controller State : Up
Inherited Secondary State : Normal
Configured Secondary State : Maintenance
Derived State : Maintenance
Loopback mode : Internal
BER Thresholds : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring : Enable
Bandwidth : 10.0Gb/s

Alarm Information:
LOS = 0 LOF = 0 LOM = 0
OOF = 0 OOM = 0 AIS = 0
IAE = 0 BIAE = 0 SF_BER = 0
SD_BER = 0 BDI = 0 TIM = 0

```

```

FECMISMATCH = 0 FEC-UNC = 0
Detected Alarms : None

Bit Error Rate Information
PREFEC BER : 0.00E+00
POSTFEC BER : 0.00E+00

TTI :
    Remote hostname : SM-TRC SAPI-SECSM-TRC DA
    Remote IP addr : 192.0.2.67

FEC mode : STANDARD

AINS Soak : None
AINS Timer : 0h, 0m
AINS remaining time : 0 seconds

```

#### Example 4

The following example shows how an internal loopback is configured on the OTU4 controller.

```

RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller otu4 0/0/0/0
RP/0/RP0/CPU0:ios(config-otu4)#secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config-otu4)#loopback internal
RP/0/RP0/CPU0:ios(config-otu4)#commit
Thu Apr 23 11:05:22.429 UTC
RP/0/RP0/CPU0:ios(config-otu4)#end

```

The following example shows how to verify an internal loopback configured on the OTU4 controller.

```

RP/0/RP0/CPU0:ios#show controllers otu4 0/0/0/0
Thu Apr 23 11:05:30.281 UTC

Port : OTU4 0/0/0/0
Controller State : Up
Inherited Secondary State : Normal
Configured Secondary State : Maintenance
Derived State : Maintenance
Loopback mode : Internal
BER Thresholds : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring : Enable
Bandwidth : 100.0Gb/s

Alarm Information:
LOS = 1 LOF = 0 LOM = 0
OOF = 0 OOM = 0 AIS = 0
IAE = 0 BIAE = 0 SF_BER = 0
SD_BER = 0 BDI = 0 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0
Detected Alarms : None

Bit Error Rate Information
PREFEC BER : 0.00E+00
POSTFEC BER : 0.00E+00

TTI :
    Remote hostname : ios
    Remote interface : OTU4 0/0/0/0
    Remote IP addr : 0.0.0.0

FEC mode : STANDARD

```

AINS Soak	: None
AINS Timer	: 0h, 0m
AINS remaining time	: 0 seconds

### Example 5

The following example shows how an internal loopback is configured on the 16G FC controller:

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller SixteenGigFibreChanCtrlr 0/2/0/1/1
RP/0/RP0/CPU0:ios(config-SixteenGigFibreChanCtrlr)#sec-admin-state maintenance
RP/0/RP0/CPU0:ios(config-SixteenGigFibreChanCtrlr)#loopback internal
RP/0/RP0/CPU0:ios(config-SixteenGigFibreChanCtrlr)#commit
Thu Apr 11 10:05:21.429 UTC
RP/0/RP0/CPU0:ios(config-otu4)#end
```

The following example shows how to verify the internal loopback configured on the 16G FC controller:

```
RP/0/RP0/CPU0:ios#show controller SixteenGigFibreChanCtrlr 0/1/0/0/2
Sat Apr 9 22:50:38.930 UTC
Operational data for Fibre Channel controller SixteenGigFibreChanCtrlr0/1/0/0/2

State:
Admin State      : Up
Operational state : Up
LED state        : Green On
Secondary admin state : Maintenance
AINS Soak         : None
    Total Duration   : 0 hour(s) 0 minute(s)
    Remaining Duration: 0 hour(s) 0 minute(s) 0 second(s)
Laser Squelch     : Disabled

Performance Monitoring is enabled

Operational values:
Speed             : 16 Gbps
Loopback          : Internal
BER monitoring:
    Not supported
Hold-off Time      : 0 ms
Forward Error Correction : Not Configured
RP/0/RP0/CPU0:ios#
```

### Example 6

The following example shows how an internal loopback is configured on the 32G FC controller:

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller ThirtyTwoGigFibreChanCtrlr 0/1/0/6/4
RP/0/RP0/CPU0:ios(config-ThirtyTwoGigFibreChanCtrlr)#loopback internal

RP/0/RP0/CPU0:ios(config-ThirtyTwoGigFibreChanCtrlr)#commit

Sat Apr 9 22:50:11.666 UTC
RP/0/RP0/CPU0:ios(config-ThirtyTwoGigFibreChanCtrlr)#end
```

The following example shows how to verify the internal loopback configured on the 32G FC controller:

```

RP/0/RP0/CPU0:ios#show controller ThirtyTwoGigFibreChanCtrlr 0/1/0/6/4
Sat Apr  9 22:50:39.082 UTC
Operational data for Fibre Channel controller ThirtyTwoGigFibreChanCtrlr0/1/0/6/4

State:
  Admin State      : Up
  Operational state : Up
  LED state        : Green On
  Secondary admin state : Maintenance
  AINS Soak        : None
    Total Duration   : 0 hour(s) 0 minute(s)
    Remaining Duration: 0 hours(s) 0 minute(s) 0 second(s)
  Laser Squelch     : Disabled

Performance Monitoring is enabled

Operational values:
  Speed            : 32 Gbps
  Loopback        : Internal
  BER monitoring:
    Not supported
  Hold-off Time     : 0 ms
  Forward Error Correction : Standard(Reed Solomon)
RP/0/RP0/CPU0:ios#

```

### **Example: Loopback Configuration in 4X100G MXP on 100GE Controller**

The following example shows how the client internal loopback is configured on the 100GE controller:

```

RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller HundredGigECtrlr 0/2/0/1
RP/0/RP0/CPU0:ios(config-eth Ctrlr)#sec-admin-state maintenance
RP/0/RP0/CPU0:ios(config-eth Ctrlr)#loopback internal
RP/0/RP0/CPU0:ios(config-otu4)#commit
Thu Sep 23 11:05:22.429 UTC
RP/0/RP0/CPU0:ios(config-otu4)#end

```

The following example shows how the client line loopback is configured on the 100GE controller:

```

RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller HundredGigECtrlr 0/2/0/1
RP/0/RP0/CPU0:ios(config-eth Ctrlr)#sec-admin-state maintenance
RP/0/RP0/CPU0:ios(config-eth Ctrlr)#loopback line
RP/0/RP0/CPU0:ios(config-otu4)#commit
Thu Sep 23 11:05:22.429 UTC
RP/0/RP0/CPU0:ios(config-otu4)#end

```

The following example shows how the trunk internal is configured on the coherentDSP controller:

```

RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/2/0/11
RP/0/RP0/CPU0:ios(config-CoDSP)#secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config-CoDSP)#loopback internal
RP/0/RP0/CPU0:ios(config-otu4)#commit
Thu Sep 23 11:05:22.429 UTC
RP/0/RP0/CPU0:ios(config-otu4)#end

```

The following example shows how the trunk line is configured on the coherentDSP controller:

**Loopback**

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/2/0/11
RP/0/RP0/CPU0:ios(config-CoDSP)#secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config-CoDSP)#loopback line
RP/0/RP0/CPU0:ios(config-otu4)#commit
Thu Sep 23 11:05:22.429 UTC
RP/0/RP0/CPU0:ios(config-otu4)#end
```

**Example: Loopback Configuration in 400G-TXP on 400GE Controller**

The following example shows how the client internal loopback is configured on the 400GE controller:

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller FourHundredGigECtrlr 0/2/0/10
RP/0/RP0/CPU0:ios(config-eth-ctrlr)#sec-admin-state maintenance
RP/0/RP0/CPU0:ios(config-eth-ctrlr)#loopback internal
RP/0/RP0/CPU0:ios(config-otu4)#commit
Thu Sep 23 11:05:22.429 UTC
RP/0/RP0/CPU0:ios(config-otu4)#end
```

The following example shows how the client line loopback is configured on the 100GE controller:

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller FourHundredGigECtrlr 0/2/0/10
RP/0/RP0/CPU0:ios(config-eth-ctrlr)#sec-admin-state maintenance
RP/0/RP0/CPU0:ios(config-eth-ctrlr)#loopback line
RP/0/RP0/CPU0:ios(config-otu4)#commit
Thu Sep 23 11:05:22.429 UTC
RP/0/RP0/CPU0:ios(config-otu4)#end
```

The following example shows how the trunk internal is configured on the coherentDSP controller:

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/2/0/10
RP/0/RP0/CPU0:ios(config-CoDSP)#secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config-CoDSP)#loopback internal
RP/0/RP0/CPU0:ios(config-otu4)#commit
Thu Sep 23 11:05:22.429 UTC
RP/0/RP0/CPU0:ios(config-otu4)#end
```

The following example shows how the trunk line is configured on the coherentDSP controller:

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/2/0/10
RP/0/RP0/CPU0:ios(config-CoDSP)#secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config-CoDSP)#loopback line
RP/0/RP0/CPU0:ios(config-otu4)#commit
Thu Sep 23 11:05:22.429 UTC
RP/0/RP0/CPU0:ios(config-otu4)#end
```

**Configure Loopback in Inverse Muxponder Configured on the OTN-XP Card**

You can configure loopback on the coherentDSP controllers in the inverse muxponder configuration.



**Note** You must configure loopback on both trunk ports 12 and 13, otherwise traffic goes down.

The following example shows how loopback is configured on both the trunk ports:

```
RP/0/RP0/CPU0:ios#configure
Thu Sep 30 14:16:04.678 UTC
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/2/0/12
RP/0/RP0/CPU0:ios(config-CoDSP)#secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config-CoDSP)#loopback internal
RP/0/RP0/CPU0:ios(config-CoDSP)#commit
Thu Sep 30 14:16:19.594 UTC
RP/0/RP0/CPU0:ios(config-CoDSP)#controller coherentDSP 0/2/0/13
RP/0/RP0/CPU0:ios(config-CoDSP)#secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config-CoDSP)#loopback internal
RP/0/RP0/CPU0:ios(config-CoDSP)#commit
Thu Sep 30 14:16:32.390 UTC
RP/0/RP0/CPU0:ios(config-CoDSP)#

```

The following examples shows how to verify loopback configured on the OTN-XP card in the inverse muxponder configuration:

```
RP/0/RP0/CPU0:ios#show controllers coherentDSP 0/2/0/12
Thu Sep 30 14:17:04.411 UTC

Port : CoherentDSP 0/2/0/12
Controller State : Up
Inherited Secondary State : Normal
Configured Secondary State : Maintenance
Derived State : Maintenance
Loopback mode : Internal
BER Thresholds : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring : Enable
Bandwidth : 200.0Gb/s

Alarm Information:
LOS = 2 LOF = 0 LOM = 0
OOF = 1 OOM = 0 AIS = 1
IAE = 0 BIAE = 0 SF_BER = 0
SD_BER = 0 BDI = 0 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0 FLEXO_GIDM = 0
FLEXO-MM = 0 FLEXO-LOM = 0 FLEXO-RDI = 1
FLEXO-LOF = 0
Detected Alarms : None

Bit Error Rate Information
PREFEC BER : 2.46E-08
POSTFEC BER : 0.00E+00
Q-Factor : 14.60 dB

Q-Margin : 8.30dB

TTI :
    Remote hostname : ios
    Remote interface : CoherentDSP 0/2/0/12
    Remote IP addr : 0.0.0.0

FEC mode : O_FEC

Flexo-Mode : Enable
Flexo Details:
    Tx GID : 1
    TX IID : 1, 2,
    Rx GID : 1
    RX IID : 1, 2,

Flexo Peers Information:
    Controller : CoherentDSP0_2_0_13

```

**Loopback**

```

OTUCn rate : OTUC2

AINS Soak : None
AINS Timer : 0h, 0m
AINS remaining time : 0 seconds

RP/0/RP0/CPU0:ios#sh controllers coherentDSP 0/2/0/13
Thu Sep 30 14:17:08.140 UTC

Port : CoherentDSP 0/2/0/13
Controller State : Up
Inherited Secondary State : Normal
Configured Secondary State : Maintenance
Derived State : Maintenance
Loopback mode : Internal
BER Thresholds : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring : Enable
Bandwidth : 200.0Gb/s

Alarm Information:
LOS = 1 LOF = 0 LOM = 0
OOF = 0 OOM = 0 AIS = 0
IAE = 0 BIAE = 0 SF_BER = 0
SD_BER = 0 BDI = 0 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0 FLEXO_GIDM = 0
FLEXO-MM = 0 FLEXO-LOM = 0 FLEXO-RDI = 1
FLEXO-LOF = 0
Detected Alarms : None

Bit Error Rate Information
PREFEC BER : 0.00E+00
POSTFEC BER : 0.00E+00
Q-Factor : 15.70 dB

Q-Margin : 9.50dB

TTI :
    Remote IP addr : 0.0.0.0

FEC mode : O_FEC

Flexo-Mode : Enable
Flexo Details:
    Tx GID : 1
    TX IID : 3, 4,
    Rx GID : 1
    RX IID : 3, 4,

Flexo Peers Information:
    Controller : CoherentDSP0_2_0_12
    OTUCn rate : OTUC2

AINS Soak : None
AINS Timer : 0h, 0m
AINS remaining time : 0 seconds

```

**Configuring Loopback on 2-QDD-C Card**

From R7.3.1 onwards, 2-QDD-C card supports loopback on the 100 and 400GE controllers.



**Note** On applying client-side loopbacks, traffic is looped and does not continue in the 2-QDD-C card. QSFP squelching happens on applying internal loopback.

To configure the loopback on the controllers, use the following commands.

**configure**

**controller** *controllertype Rack/Slot/Instance/Port/Lanenumber*

**sec-admin-state maintenance**

**loopback [ line | internal ]**

**commit**

From R7.5.2 onwards, Loopback is supported for the OTUCn-REGEN mode on the coherent DSP controller.

### Example

The following example shows how to configure an internal loopback on a coherent DSP controller.

```
Sun Dec 26 14:34:02.733 UTC
RP/0/RP0/CPU0:ios(config)#controller CoherentDSP 0/3/0/12
RP/0/RP0/CPU0:ios(config-CoDSP)#secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config-CoDSP)#commit
Sun Dec 26 14:34:03.437 UTC
RP/0/RP0/CPU0:ios(config-CoDSP)#end
```

The following example shows how to verify internal loopback configured on a coherent DSP controller.

```
RP/0/RP0/CPU0:ios#show controller CoherentDSP 0/3/0/12
Sun Dec 26 14:34:28.391 UTC

Port : CoherentDSP 0/3/0/12
Controller State : Up
Inherited Secondary State : Normal
Configured Secondary State : Maintenance
Derived State : Maintenance
Loopback mode : Line
BER Thresholds : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring : Enable
Bandwidth : 200.0Gb/s

Alarm Information:
LOS = 1 LOF = 0 LOM = 0
OOF = 1 OOM = 0 AIS = 1
IAE = 0 BIAE = 0 SF_BER = 0
SD_BER = 0 BDI = 5 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0 FLEXO_GIDM = 0
FLEXO-MM = 0 FLEXO-LOM = 0 FLEXO-RDI = 0
FLEXO-LOF = 0
Detected Alarms : None

Bit Error Rate Information
PREFEC BER : 3.12E-07
POSTFEC BER : 0.00E+00
Q-Factor : 14.00 dB

Q-Margin : 6.40dB
```

```

TTI :
Remote hostname : ios
Remote interface : CoherentDSP 0/2/0/13
Remote IP addr : 0.0.0.0

FEC mode : O_FEC

Flexo-Mode : Enable
Flexo Details:
Tx GID : 1
TX IID : 1, 2,
Rx GID : 1
RX IID : 1, 2,

AINS Soak : None
AINS Timer : 0h, 0m
AINS remaining time : 0 seconds

```

### Configuring Loopback on the QXP Card

#### Example 1

The following example shows how to configure internal loopback on a coherent DSP controller.

```

RP/0/RP0/CPU0:ios#configure
Fri Jul 8 10:42:51.329 UTC
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/0/0/0
RP/0/RP0/CPU0:ios(config-CoDSP) #secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config-CoDSP) #loopback internal
RP/0/RP0/CPU0:ios(config-CoDSP) #commit
Fri Jul 8 10:43:48.644 UTC
RP/0/RP0/CPU0:ios(config-CoDSP) #end

```

The following example shows how to verify the internal loopback configured on a coherent DSP controller.

```

RP/0/RP0/CPU0:ios#show controllers coherentDSP 0/0/0/0
Fri Jul 8 10:45:53.820 UTC
Port : CoherentDSP 0/0/0/0
Controller State : Down
Inherited Secondary State : Normal
Configured Secondary State : Maintenance
Derived State : Maintenance
Loopback mode : Internal
BER Thresholds : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring : Enable
Bandwidth : 400.0Gb/s
Alarm Information:
LOS = 2 LOF = 0 LOM = 0
OOF = 0 OOM = 0 AIS = 0
IAE = 0 BIAE = 0 SF_BER = 0
SD_BER = 0 BDI = 0 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0 FLEXO_GIDM = 0
FLEXO-MM = 0 FLEXO-LOM = 0 FLEXO-RDI = 0
FLEXO-LOF = 0
Detected Alarms : LOS
Bit Error Rate Information
PREFEC BER : 5.00E-01
POSTFEC BER : 0.00E+00
Q-Factor : 0.00 dB
Q-Margin : 0.00dB
OTU TTI Received
FEC mode : C_FEC
Flexo-Mode : Enable
Flexo Details:

```

```

Tx GID : 0
Rx GID : 0
AINS Soak : None
AINS Timer : 0h, 0m
AINS remaining time : 0 seconds

```

### Example 2

The following example shows how to configure line loopback on a coherent DSP controller.

```

RP/0/RP0/CPU0:ios#configure
Fri Jul 8 10:48:48.577 UTC
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/0/0/0
RP/0/RP0/CPU0:ios(config-CoDSP)#secondary-admin-state maintenance
RP/0/RP0/CPU0:ios(config-CoDSP)#loopback line
RP/0/RP0/CPU0:ios(config-CoDSP)#commit
Fri Jul 8 10:49:26.809 UTC
RP/0/RP0/CPU0:ios(config-CoDSP)#end

```

The following example shows how to verify the line loopback configured on a coherent DSP controller.

```

RP/0/RP0/CPU0:ios#show controllers coherentDSP 0/0/0/0
Fri Jul 8 10:49:44.073 UTC
Port : CoherentDSP 0/0/0/0
Controller State : Down
Inherited Secondary State : Normal
Configured Secondary State : Maintenance
Derived State : Maintenance
Loopback mode : Line
BER Thresholds : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring : Enable
Bandwidth : 400.0Gb/s
Alarm Information:
LOS = 2 LOF = 0 LOM = 0
OOF = 0 OOM = 0 AIS = 0
IAE = 0 BIAE = 0 SF_BER = 0
SD_BER = 0 BDI = 0 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0 FLEXO_GIDM = 0
FLEXO-MM = 0 FLEXO-LOM = 0 FLEXO-RDI = 0
FLEXO-LOF = 0
Detected Alarms : LOS
Bit Error Rate Information
PREFEC BER : 5.00E-01
POSTFEC BER : 0.00E+00
Q-Factor : 0.00 dB
Q-Margin : 0.00dB
OTU TTI Received
FEC mode : C_FEC
Flexo-Mode : Enable
Flexo Details:
Tx GID : 0
Rx GID : 0
AINS Soak : None
AINS Timer : 0h, 0m
AINS remaining time : 0 seconds

```

### Example 3

The following example shows how to configure internal loopback on the 400GE controller.

```

RP/0/RP0/CPU0:ios#configure
Fri Jul 8 11:19:26.286 UTC
RP/0/RP0/CPU0:ios(config)#controller FourHundredGigECtrlr 0/0/0/3
RP/0/RP0/CPU0:ios(config-eth-ctrlr)#sec-admin-state maintenance

```

**Loopback**

```
RP/0/RP0/CPU0:ios(config-eth-ctrlr)#loopback internal
RP/0/RP0/CPU0:ios(config-eth-ctrlr)#commit
Fri Jul 8 11:19:47.496 UTC
RP/0/RP0/CPU0:ios(config-eth-ctrlr)#end
```

The following example shows how to verify the internal loopback configured on the 400GE controller.

```
RP/0/RP0/CPU0:ios#show controllers FourHundredGigECtrlr 0/0/0/3
Fri Jul 8 11:19:59.597 UTC
Operational data for interface FourHundredGigECtrlr0/0/0/3:
State:
Administrative state: enabled
Operational state: Down (Reason: State undefined)
LED state: Red On
Maintenance: Enabled
AINS Soak: None
Total Duration: 0 hour(s) 0 minute(s)
Remaining Duration: 0 hour(s) 0 minute(s) 0 second(s)
Laser Squelch: Disabled
Insert Idle Ingress: Disabled
Insert Idle Egress: Disabled
Phy:
Media type: Not known
Alarms:
Current:
Loss of Signal
Statistics:
FEC:
Corrected Codeword Count: 702710
Uncorrected Codeword Count: 1147
Autonegotiation disabled.
Operational values:
Speed: 400Gbps
Duplex: Full Duplex
Flowcontrol: None
Loopback: Internal
BER monitoring:
Not supported
Forward error correction: Standard (Reed-Solomon)
Holdoff Time: 0ms
```

**Example 4**

The following example shows how to configure line loopback on the 4X100GE MXP.

```
RP/0/RP0/CPU0:ios(config)#controller hundredGigECtrlr 0/3/0/1/1
RP/0/RP0/CPU0:ios(config-eth-ctrlr)#loopback line
RP/0/RP0/CPU0:ios(config-eth-ctrlr)#sec-admin-state maintenance
RP/0/RP0/CPU0:ios(config-eth-ctrlr)#commit
```

The following example shows how to verify the line loopback configured on the 4X100GE MXP.

```
RP/0/RP0/CPU0:ios#sh controllers hundredGigECtrlr 0/3/0/1/1
Fri Jul 22 10:34:39.730 UTC
Operational data for interface HundredGigECtrlr0/3/0/1/1:

State:
Administrative state: enabled
Operational state: Up
LED state: Green On
Maintenance: Enabled
AINS Soak: None
Total Duration: 0 hour(s) 0 minute(s)
Remaining Duration: 0 hour(s) 0 minute(s) 0 second(s)
Laser Squelch: Disabled
```

```

Insert Idle Ingress: Disabled
Insert Idle Egress: Disabled

Phy:
  Media type: Not known
  Statistics:
    FEC:
      Corrected Codeword Count: 6110368          Valid: True   Start time:
    13:10:41 Thu Jul 21 2022
      Uncorrected Codeword Count: 2771          Valid: True   Start time:
    13:10:41 Thu Jul 21 2022
    PCS:
      Total BIP errors: 63700992            Valid: True   Start time:
    13:10:41 Thu Jul 21 2022
      Total frame errors: 0                Valid: False  Start time:
    13:10:41 Thu Jul 21 2022
      Total Bad SH: 0                  Valid: False  Start time:
    13:10:41 Thu Jul 21 2022

Autonegotiation disabled.

Operational values:
  Speed: 100Gbps
  Duplex: Full Duplex
  Flowcontrol: None
  Loopback: Line
  BER monitoring:
    Not supported
  Forward error correction: Standard (Reed-Solomon)
  Holdoff Time: 0ms

```

### Example 5

The following example shows how to configure internal loopback on the 4X100GE MXP.

```

RP/0/RP0/CPU0:ios#conf
RP/0/RP0/CPU0:ios(config)#controller hundredGigECtrlr 0/3/0/7/1
RP/0/RP0/CPU0:ios(config-eth-ctrlr)#sec-admin-state maintenance
RP/0/RP0/CPU0:ios(config-eth-ctrlr)#loopback internal
RP/0/RP0/CPU0:ios(config-eth-ctrlr)#commit

```

The following example shows how to verify the internal loopback configured on the 4X100GE MXP.

```

RP/0/RP0/CPU0:ios#show controller HundredGigECtrlr 0/3/0/7/1
Fri Jul 22 10:40:34.928 UTC

```

Operational data for interface HundredGigECtrlr0/3/0/7/1:

```

State:
  Administrative state: enabled
  Operational state: Down (Reason: State undefined)
  LED state: Red On
  Maintenance: Enabled
  AINS Soak: None
    Total Duration: 0 hour(s) 0 minute(s)
    Remaining Duration: 0 hour(s) 0 minute(s) 0 second(s)
  Laser Squelch: Disabled
  Insert Idle Ingress: Disabled
  Insert Idle Egress: Disabled

Phy:
  Media type: Not known
  Alarms:
    Current:

```

```

Loss of Signal
Statistics:
  FEC:
    Corrected Codeword Count: 31426046
    Uncorrected Codeword Count: 2187

Autonegotiation disabled.

Operational values:
  Speed: 100Gbps
  Duplex: Full Duplex
  Flowcontrol: None
  Loopback: Internal
  BER monitoring:
    Not supported
  Forward error correction: Standard (Reed-Solomon)
  Holdoff Time: 0ms

```

## LLDP Drop

Link Layer Discovery Protocol (LLDP) Snooping is enabled by default on all ethernet controllers.

To verify the LLDP neighbors, use the following commands:

```

RP/0/RP0/CPU0:ios#show lldp neighbors detail
Tue Mar 12 11:49:20.819 IST
Capability codes:
  (R) Router, (B) Bridge, (T) Telephone, (C) DOCSIS Cable Device
  (W) WLAN Access Point, (P) Repeater, (S) Station, (O) Other

-----
Local Interface: HundredGigEController0/1/0/7
Chassis id: 008a.96cd.34e1
Port id: Hu0/0/0/4
Port Description - not advertised
System Name: ncs5500_node

System Description:
  6.1.4, NCS-5500

Time remaining: 116 seconds
Hold Time: 120 seconds
System Capabilities: R
Enabled Capabilities: R
Management Addresses - not advertised
Peer MAC Address: 00:8a:96:cd:34:10

-----
Local Interface: HundredGigEController0/1/0/13
Chassis id: 008a.96cd.34e1
Port id: Hu0/0/0/5
Port Description - not advertised
System Name: ncs5500_node

System Description:
  6.1.4, NCS-5500

Time remaining: 90 seconds
Hold Time: 120 seconds
System Capabilities: R

```

```
Enabled Capabilities: R
Management Addresses - not advertised
Peer MAC Address: 00:8a:96:cd:34:14
```

Total entries displayed: 2

```
RP/0/RP0/CPU0:ios#show lldp neighbors
Tue Mar 12 16:17:56.713 IST
Capability codes:
(R) Router, (B) Bridge, (T) Telephone, (C) DOCSIS Cable Device
(W) WLAN Access Point, (P) Repeater, (S) Station, (O) Other
```

Device ID	Local Intf	Hold-time	Capability	Port ID
ncs5500_node	HundredGigEController0/1/0/7	120	R	Hu0/0/0/4
ncs5500_node	HundredGigEController0/1/0/13	120	R	Hu0/0/0/5

Total entries displayed: 2

When you enable LLDP drop on the client controller ports of the muxponder or muxponder slice, the LLDP frames drop on the ports without forwarding.



**Note** LLDP on 400GE is not supported on the OTN-XP card.

## Configuring LLDP Drop

You can configure the LLDP drop for a muxponder or muxponder slice. By default, the LLDP drop status is set to False. On enabling the LLDP Drop, the status is set to True.

To configure LLDP drop on a muxponder use the following command:

**configure**

**hw-module location *location* mxponder drop-lldp**



**Note** Use the **no** form of the command to disable LLDP drop.

**commit**

### Limitation

- When you disable LLDP globally, the LLDP gets disabled on all the interfaces.



**Note** By default, LLDP is enabled for NCS 1004. But when you enable and disable LLDP in the global configuration mode, LLDP gets disabled on all the interfaces.

**Workaround:** You must enable LLDP globally or reload the Router.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios#hw-module location 0/1 mxponder drop-lldp
RP/0/RP0/CPU0:ios#commit
```

## Verifying the Status of LLDP Drop

### configure

**hw-module location *location* mxponder-slice *slice-number* drop-lldp**



**Note** Use the **no** form of the command to disable LLDP drop.

To configure LLDP drop on a muxponder slice, use the following command:

### commit

The following is a sample in which slice 0 client ports are enabled with LLDP drop.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#hw-module location 0/1 mxponder-slice 0 drop-lldp
RP/0/RP0/CPU0:ios(config)#commit
```

## Verifying the Status of LLDP Drop

To verify the LLDP drop enabled status, use the following command.

```
RP/0/RP0/CPU0:ios#show hw-module location all mxponder
Fri Feb 22 13:22:19.281 UTC

Location:          0/0
Client Bitrate:    NONE
Trunk Bitrate:     NONE
Status:            Not Provisioned

Location:          0/1
Slice ID:          0
Client Bitrate:    100GE
Trunk Bitrate:     500G
Status:            Provisioned
LLDP Drop Enabled: FALSE
Client Port           Mapper/Trunk Port           CoherentDSP0/1/0/0
                      Traffic Split Percentage
HundredGigECtrlr0/1/0/2      ODU40/1/0/0/0          100
HundredGigECtrlr0/1/0/3      ODU40/1/0/0/1          100
HundredGigECtrlr0/1/0/4      ODU40/1/0/0/2          100
HundredGigECtrlr0/1/0/5      ODU40/1/0/0/3          100
HundredGigECtrlr0/1/0/6      ODU40/1/0/0/4          100

Location:          0/1
Slice ID:          1
Client Bitrate:    100GE
Trunk Bitrate:     500G
Status:            Provisioned
LLDP Drop Enabled: FALSE
Client Port           Mapper/Trunk Port           CoherentDSP0/1/0/1
                      Traffic Split Percentage
HundredGigECtrlr0/1/0/8      ODU40/1/0/1/0          100
HundredGigECtrlr0/1/0/9      ODU40/1/0/1/1          100
HundredGigECtrlr0/1/0/10     ODU40/1/0/1/2          100
HundredGigECtrlr0/1/0/11     ODU40/1/0/1/3          100
HundredGigECtrlr0/1/0/12     ODU40/1/0/1/4          100
```

Location:	0/2		
Slice ID:	0		
Client Bitrate:	100GE		
Trunk Bitrate:	500G		
Status:	Provisioned		
<b>LLDP Drop Enabled:</b>	<b>FALSE</b>		
Client Port		Mapper/Trunk Port	CoherentDSP0/2/0/0
		Traffic Split Percentage	
HundredGigECtrlr0/2/0/2	ODU40/2/0/0/0	100	
HundredGigECtrlr0/2/0/3	ODU40/2/0/0/1	100	
HundredGigECtrlr0/2/0/4	ODU40/2/0/0/2	100	
HundredGigECtrlr0/2/0/5	ODU40/2/0/0/3	100	
HundredGigECtrlr0/2/0/6	ODU40/2/0/0/4	100	
Location:	0/2		
Slice ID:	1		
Client Bitrate:	100GE		
Trunk Bitrate:	500G		
Status:	Provisioned		
<b>LLDP Drop Enabled:</b>	<b>FALSE</b>		
Client Port		Mapper/Trunk Port	CoherentDSP0/2/0/1
		Traffic Split Percentage	
HundredGigECtrlr0/2/0/8	ODU40/2/0/1/0	100	
HundredGigECtrlr0/2/0/9	ODU40/2/0/1/1	100	
HundredGigECtrlr0/2/0/10	ODU40/2/0/1/2	100	
HundredGigECtrlr0/2/0/11	ODU40/2/0/1/3	100	
HundredGigECtrlr0/2/0/12	ODU40/2/0/1/4	100	
Location:	0/3		
Slice ID:	0		
Client Bitrate:	100GE		
Trunk Bitrate:	300G		
Status:	Provisioned		
<b>LLDP Drop Enabled:</b>	<b>TRUE</b>		
Client Port		Mapper/Trunk Port	CoherentDSP0/3/0/0
		Traffic Split Percentage	
HundredGigECtrlr0/3/0/2	ODU40/3/0/0/0	100	
HundredGigECtrlr0/3/0/3	ODU40/3/0/0/1	100	
HundredGigECtrlr0/3/0/4	ODU40/3/0/0/2	100	

## Trail Trace Identifier

The Trail trace identifier (TTI) feature helps you to identify the signal from the source to the destination within the network. You can configure the TTI sent or expected string only in ASCII string format. When the expected TTI string does not match the received TTI trace string, the controller goes down and the OTUK-TIM alarm is raised. To configure TTI on the coherent DSP controllers, use the following commands:

**configure**

**controller coherentDSP R/S/I/P tti {sent | expected} ascii tti-string**

**commit**



**Note** The *tti-string* can have a maximum of 64 characters.

The following sample displays how to configure TTI on a coherent DSP controller with the sent and expected strings set to the same ASCII string. The state of the controller is up.

```

RP/0/RP0/CPU0:ios#config
Fri Mar 15 08:03:02.094 UTC
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/1/0/1 tti sent ascii 1234
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/1/0/1 tti expected ascii 1234
RP/0/RP0/CPU0:ios(config)#commit
Fri Mar 15 08:03:49.725 UTC
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show controllers coherentDSP 0/1/0/1
Fri Mar 15 08:04:06.290 UTC

Port                               : CoherentDSP 0/1/0/1
Controller State                  : Up
Inherited Secondary State        : Normal
Configured Secondary State       : Normal
Derived State                     : In Service
Loopback mode                     : None
BER Thresholds                   : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring            : Enable

Alarm Information:
LOS = 0 LOF = 0 LOM = 0
OOF = 0 OOM = 0 AIS = 0
IAE = 0 BIAE = 0      SF_BER = 0
SD_BER = 0      BDI = 1 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0
Detected Alarms                  : None

Bit Error Rate Information
PREFEC BER                      : 7.7E-03
POSTFEC BER                     : 0.0E+00

OTU TTI Sent
    OPERATOR SPECIFIC ASCII      : 1234
    OPERATOR SPECIFIC HEX        :
OTU TTI Received
    OPERATOR SPECIFIC ASCII      : 1234
    OPERATOR SPECIFIC HEX        :
OTU TTI Expected
    OPERATOR SPECIFIC ASCII      : 1234
    OPERATOR SPECIFIC HEX        :
FEC mode                          : Soft-Decision 27

AINS Soak                         : None
AINS Timer                        : On, 0m
AINS remaining time               : 0 seconds

```

The following example shows how to configure TTI on a coherent DSP controller with the sent and expected strings set to different ASCII strings. The state of the controller goes down and the TIM alarm is raised.

```

RP/0/RP0/CPU0:ios#config
Fri Mar 15 08:54:29.780 UTC
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/1/0/1 tti sent ascii 1234
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/1/0/1 tti expected ascii 5678
RP/0/RP0/CPU0:ios(config)#commit
Fri Mar 15 08:56:12.293 UTC
RP/0/RP0/CPU0:ios(config)#exit
RP/0/RP0/CPU0:ios#show controllers coherentDSP 0/1/0/1
Fri Mar 15 08:56:33.910 UTC

Port : CoherentDSP 0/1/0/1
Controller State : Down
Inherited Secondary State : Normal
Configured Secondary State : Normal
Derived State : In Service
Loopback mode : None
BER Thresholds : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring : Enable

Alarm Information:
LOS = 1 LOF = 0 LOM = 0
OOF = 0 OOM = 0 AIS = 0
IAE = 0 BIAE = 0 SF_BER = 0
SD_BER = 0 BDI = 3 TIM = 1
FECMISMATCH = 0 FEC-UNC = 0
Detected Alarms : BDI TIM

Bit Error Rate Information
PREFEC BER : 8.2E-03
POSTFEC BER : 0.0E+00

OTU TTI Sent
    OPERATOR SPECIFIC ASCII : 1234
    OPERATOR SPECIFIC HEX : 3132333400000000000000000000000000000000
OTU TTI Received
    OPERATOR SPECIFIC ASCII : 1234
    OPERATOR SPECIFIC HEX : 31323334000000000000000000000000
OTU TTI Expected
    OPERATOR SPECIFIC ASCII : 5678
    OPERATOR SPECIFIC HEX : 35363738000000000000000000000000
FEC mode : Soft-Decision 27

AINS Soak : None
AINS Timer : 0h, 0m
AINS remaining time : 0 seconds

```

## Configure TTI on OTN-XP Card

You can configure the TTI sent or expected string in the full ASCII format, or Source Access Point Identifier (SAPI)/Destination Access Point Identifier (DAPI) format on OTU, ODU, ODU-flex, ODUCn, and coherentDSP controllers for the OTN-XP card.

From R7.3.1 onwards, coherentDSP controller supports only the full ASCII string format.

From R7.3.2 onwards, coherentDSP controller supports SAPI/DAPI string format in addition to the full ASCII string format.

## Configure TTI on OTN-XP Card

You can configure TTI for the following muxponder modes:

- 10G-Grey-MXP
- 4x100G-MXP-400G-TXP

The following table lists the ASCII format that is supported on each muxponder mode for TTI:

**Table 1: ASCII Format Supported on Each Muxponder Mode**

Muxponder Mode	ASCII with Character String	Controller
10G Grey	Full ASCII 64-character	OTU2, OTU2E, OTU4, ODU4, ODU2E (10G mapper)
	SAPI ASCII 15-character	OTU2, OTU2E, OTU4, ODU4, ODU2E (10G mapper)
	DAPI ASCII 15-character	OTU2, OTU2E, OTU4, ODU4, ODU2E (10G mapper)
	Operator-specific ASCII 32-character	OTU2, OTU2E, OTU4, ODU4, ODU2E (10G mapper)
4x100G-MXP-400G-TXP	Full ASCII 64-character	OTU4, coherentDSP, ODUC4, ODU4 (100G mapper), and ODU-FLEX (400G mapper)
	SAPI ASCII 15-character	OTU4, coherentDSP, ODUC4, ODU4 (100G mapper), and ODU-FLEX (400G mapper)
	DAPI ASCII 15-character	OTU4, coherentDSP, ODUC4, ODU4 (100G mapper), and ODU-FLEX (400G mapper)
	Operator-specific ASCII 32-character	OTU4, coherentDSP, ODUC4, ODU4 (100G mapper), and ODU-FLEX (400G mapper)

To configure TTI, use the following commands:

**configure**

**controller controller-type R/S/I/P tti {sent | expected} {ascii | sapi ascii | dapi ascii | operator-specific ascii } tti-string**

**commit**



**Note** We recommend that you configure TTI in the SAPI/DAPI ASCII format.

The following is a sample configuration on ODU4 controller:

```
RP/0/RP0/CPU0:ios#configure
Thu Sep 30 17:19:11.804 UTC
Current Configuration Session  Line       User       Date                                Lock
00001000-00005c15-00000000    vty0      root      Thu Sep 30 11:50:12 2021
RP/0/RP0/CPU0:ios(config)#controller odU4 0/1/0/12/7 tti sent sapi ascii cisco123
RP/0/RP0/CPU0:ios(config)#controller odU4 0/1/0/12/7 tti expect sapi ascii 123cisco
RP/0/RP0/CPU0:ios(config)#controller odU4 0/1/0/12/7 tti sent dapi ascii dapistring123
RP/0/RP0/CPU0:ios(config)#controller odU4 0/1/0/12/7 tti expected dapi ascii 123stringdapi
RP/0/RP0/CPU0:ios(config)#controller odU4 0/1/0/12/7 tti sent operator-specific ascii
operation123
RP/0/RP0/CPU0:ios(config)#controller odU4 0/1/0/12/7 tti expected operator-specific ascii
123operator
RP/0/RP0/CPU0:ios(config)#commit
Thu Sep 30 17:21:49.521 UTC
RP/0/RP0/CPU0:ios(config)#end
```

The following is a sample output of the TTI configuration on the ODU4 controller:

## Configure TTI on OTN-XP Card

AINS remaining time : 0 seconds  
Private Line Emulation(PLE) supported : No

You can configure TTI on OTUCn-REGEN mode on the OTN-XP Card.

The following sample displays how to configure TTI on a coherent DSP controller port 12 on the OTUCn-REGEN mode.

```
Mon Dec 27 12:03:53.642 UTC
RP/0/RP0/CPU0:ios(config)#controller CoherentDSP 0/3/0/12 tti sent ascii 1234cisco
RP/0/RP0/CPU0:ios(config)#commit
Mon Dec 27 12:03:54.333 UTC
RP/0/RP0/CPU0:ios(config)#end
Mon Dec 27 12:03:55.434 UTC
RP/0/RP0/CPU0:ios(config)#controller CoherentDSP 0/3/0/12 tti expected ascii cisco1234
RP/0/RP0/CPU0:ios(config)#commit
Mon Dec 27 12:03:56.137 UTC
RP/0/RP0/CPU0:ios(config)#end
```

The following sample verifies the TTI configuration on the inverse muxponder configured on the OTUCn-REGEN mode.

```
RP/0/RP0/CPU0:ios#show controllers coherentDSP 0/0/0/12  
Tue May 24 17:49:14.301 UTC
```

```

FULL TTI ASCII : 123cisco
FULL TTI HEX   : 313233636973636F0000000000000000
FEC mode       : O_FEC

Flexo-Mode          : Enable
Flexo Details:
  Tx GID           : 1
  TX IID           : 1, 2, 3, 4,
  Rx GID           : 1
  RX IID           : 1, 2, 3, 4,

AINS Soak          : None
AINS Timer         : 0h, 0m
AINS remaining time: 0 seconds

RP/0/RP0/CPU0:ios#
RP/0/RP0/CPU0:ios#show running-config controller coherentDSP 0/0/0/12
Tue May 24 17:49:21.749 UTC
controller CoherentDSP0/0/0/12
tti
  expected ascii 123cisco
  sent ascii cisco123
!
!
```

### Configure TTI on Inverse Muxponder Configuration on the OTN-XP Card

The following sample displays how to configure TTI on a coherent DSP controller port 12 on the OTN-XP in inverse muxponder configuration mode.



**Note** TTI configuration is not supported on the DSP controller port 13.

```

RP/0/RP0/CPU0:ios#configure
Thu Sep 30 14:18:13.288 UTC
RP/0/RP0/CPU0:ios(config)#controller coherentDSP 0/2/0/12
RP/0/RP0/CPU0:ios(config-CoDSP)#tti sent sapi ascii cisco
RP/0/RP0/CPU0:ios(config-CoDSP)#commit
```

The following sample verifies the TTI configuration on the inverse muxponder configured on the OTN-XP Card.

```

RP/0/RP0/CPU0:ios#show controllers coherentDSP 0/2/0/12
Thu Sep 30 14:19:05.367 UTC

Port                      : CoherentDSP 0/2/0/12
Controller State          : Up
Inherited Secondary State : Normal
Configured Secondary State: Maintenance
Derived State              : Maintenance
Loopback mode              : Internal
BER Thresholds            : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring    : Enable
Bandwidth                 : 200.0Gb/s

Alarm Information:
LOS = 2 LOF = 0 LOM = 0
OOF = 1 OOM = 0 AIS = 1
```

## Configure TTI on OTN-XP Card

```

IAE = 0 BIAE = 0      SF_BER = 0
SD_BER = 0      BDI = 0 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0      FLEXO_GIDM = 0
FLEXO-MM = 0      FLEXO-LOM = 0      FLEXO-RDI = 1
FLEXO-LOF = 0
Detected Alarms : None

Bit Error Rate Information
PREFEC BER : 4.11E-09
POSTFEC BER : 0.00E+00
Q-Factor : 14.90 dB

Q-Margin : 8.60dB

OTU TTI Sent
    SAPI ASCII : cisco
    SAPI HEX : 00636973636F00000000000000000000000000000000
    DAPI ASCII :
    DAPI HEX :
    OPERATOR SPECIFIC ASCII :
    OPERATOR SPECIFIC HEX :
CDCDCDCDED00DBBE21000000000000000050D9D29AD7F00007603BADC7698BADC

OTU TTI Received
    SAPI ASCII : cisco
    SAPI HEX : 00636973636F00000000000000000000000000000000
    FEC mode : O_FEC

Flexo-Mode : Enable
Flexo Details:
    Tx GID : 1
    TX IID : 1, 2,
    Rx GID : 1
    RX IID : 1, 2,

Flexo Peers Information:
    Controller : CoherentDSP0_2_0_13
    OTUCn rate : OTUC2

AINS Soak : None
AINS Timer : 0h, 0m
AINS remaining time : 0 seconds

```

### Enable TIM CA on Path Monitoring Layer

You can enable Trace Identifier Mismatch (TIM) consequent action (CA) on the Path Monitoring (PM) layer using the **pm-tim-ca** command on mapper ODUs for Ethernet controller. The TTI transmit string in the SAPI/DAPI format is not configurable on ODUs that are transparent.

For example, the clients that are supported are ODU4, ODU2, and ODU2E, and lower-order ODUs such as ODU2 or ODU2E.

You can configure **pm-tim-ca** only on mapper ODUs such as ODU2E (10G mapper), ODU4 (100G mapper), and ODU-FLEX (400G mapper).

To configure **pm-tim-ca** on mapper ODU in the 4x100G-MXP-400G-TXP muxponder mode, use the following commands

**configure**

**controller controller-type R/S/I/P**

**pm-tim-ca**

**commit**

# Troubleshoot the Trunk Port

## Procedure

---

### Step 1 show controller coherentDSP R/S/I/P

Displays details of the coherent DSP controller.

**Example:**

```
RP/0/RP0/CPU0:ios# show controller coherentDSP 0/0/0/0
Tue Feb 25 11:26:08.235 UTC
```

```
Port : CoherentDSP 0/0/0/0
Controller State : Up
Inherited Secondary State : Normal
Configured Secondary State : Normal
Derived State : In Service
Loopback mode : None
BER Thresholds : SF = 1.0E-5 SD = 1.0E-7
Performance Monitoring : Enable
Bandwidth : 50.0Gb/s

Alarm Information:
LOS = 1 LOF = 0 LOM = 0
OOF = 0 OOM = 0 AIS = 0
IAE = 0 BIAE = 0 SF_BER = 0
SD_BER = 0 BDI = 0 TIM = 0
FECMISMATCH = 0 FEC-UNC = 0
Detected Alarms : None
Bit Error Rate Information
PREFEC BER : 0.00E+00
POSTFEC BER : 0.00E+00
Q-Factor : 0.00 dB
Q-Margin : -5.00dB
Instantaneous Q_margin : 0 dB

TTI :
    Remote IP addr : 0.0.0.0
    FEC mode : Soft-Decision 15

AINS Soak : None
AINS Timer : 0h, 0m
AINS remaining time : 0 seconds
```

In the above output, you can verify the state of the controller and also verify the alarms related to the trunk port.

### Step 2 show controller optics R/S/I/P

Displays details of the optics controller.

**Example:**

```
RP/0/RP0/CPU0:ios# show controller optics 0/1/0/3
Thu Feb 21 19:45:41.088 UTC
```

**Troubleshoot the Trunk Port**

Controller State: Up

Transport Admin State: Automatic In Service

Laser State: On

LED State: Green

Optics Status

Optics Type: Grey optics

Alarm Status:

-----

Detected Alarms: None

LOS/LOL/Fault Status:

Alarm Statistics:

-----

HIGH-RX-PWR = 0	LOW-RX-PWR = 0
HIGH-TX-PWR = 0	LOW-TX-PWR = 0
HIGH-LBC = 0	HIGH-DGD = 0
OOR-CD = 0	OSNR = 0
WVL-OOL = 0	MEA = 0
IMPROPER-REM = 0	
TX-POWER-PROV-MISMATCH = 0	

Performance Monitoring: Enable

THRESHOLD VALUES

-----

Parameter	High Alarm	Low Alarm	High Warning	Low Warning
Rx Power Threshold(dBm)	4.9	-12.0	0.0	0.0
Tx Power Threshold(dBm)	3.5	-10.1	0.0	0.0
LBC Threshold(mA)	N/A	N/A	0.00	0.00

LBC High Threshold = 98 %

Polarization parameters not supported by optics

Total TX Power = 6.39 dBm

Total RX Power = 5.85 dBm

Lane	Laser Bias	TX Power	RX Power	Output Frequency
1	75.0 %	0.59 dBm	0.63 dBm	230.43 THz
2	68.6 %	0.06 dBm	-0.68 dBm	230.43 THz
3	69.0 %	0.26 dBm	-0.63 dBm	230.43 THz
4	69.1 %	0.56 dBm	-0.10 dBm	230.43 THz

Transceiver Vendor Details

Form Factor	:	QSFP28
Name	:	CISCO-FINISAR
Part Number	:	FTLC1152RGPL-C2
Rev Number	:	CISCO-FINISAR
Serial Number	:	FNS22150LEC
PID	:	QSFP-100G-CWDM4-S
VID	:	V02

```
CISCO-FINISAR
Date Code(yy/mm/dd)      : 18/04/11
Fiber Connector Type: LC
Sonet Application Code: Not Set
Ethernet Compliance Code: 100GBASE-CWDM4

Transceiver Temperature : 32 Celsius
```

```
AINS Soak          : Running
AINS Timer        : 0h, 15m
AINS remaining time : 771 seconds
```

In the above output, you can verify the state of the controller, LED state, TX power, RX power, OSNR, and the alarms.

- Step 3** If there is an LOS alarm on the trunk port, verify the fiber continuity to the port of NCS 1004 and fix the fiber connection.
- 

#### What to do next

Verify the performance monitoring parameters of the Optics, Ethernet, and coherent DSP controllers. For more information, see [#unique\\_13](#).

## Troubleshoot a Failed Commit Configuration

Use the **show configuration failed** command to get information on why the configuration failed.

```
RP/0/RP0/CPU0:ios(config-hwmod-mxp)#show configuration failed
Fri Nov 26 15:27:22.629 UTC
!! SEMANTIC ERRORS: This configuration was rejected by
!! the system due to semantic errors. The individual
!! errors with each failed configuration command can be
!! found below.

hw-module location 0/0
mxponder-slice 0
  client-port-rate 1 client-type 400GE
!!% Total group bandwidth exceeds the limit: Total group bandwidth exceeds the limit
!
!
end
```

## Verify the Performance Monitoring Parameters of Controllers

Performance monitoring (PM) parameters are used by service providers to gather, store, set thresholds for, and report performance data for early detection of problems. The user can retrieve both current and historical PM counters for the various controllers in 15 minutes and 1 day intervals.

## Verify the Performance Monitoring Parameters of Controllers

### Procedure

```
show controllers controller-type R/S/I/P { pm { current | history } { 30 sec | 15-min | 24-hour } { optics | ether | fec | otn } linenumber }
```

The following sample output displays the current performance monitoring parameters of the Optics controller in 15-minute intervals. Client optics have four lanes.

```
RP/0/RP0/CPU0:ios#show controller optics 0/1/0/3 pm current 15-min optics 3
```

```
Sat Feb 9 19:33:42.480 UTC
Optics in the current interval [19:30:00 - 19:33:42 Sat Feb 9 2019]
Optics current bucket type : Valid
      MIN      AVG      MAX      Operational      Configured      TCA      Operational
Configured          TCA
                                         Threshold(min)      Threshold(min)  (min)  Threshold(max)
      Threshold(max)  (max)
LBC[%]   : 0.0      0.0      0.0      0.0      NA      NO  100.0
          NA          NO
OPT[dBm]  : -40.00  -40.00  -40.00  -30.00      NA      NO  63.32
          NA          NO
OPR[dBm]  : -40.00  -40.00  -40.00  -30.00      NA      NO  63.32
          NA          NO
FREQ_OFF[Mhz]: 0      0      0      0      NA      NO      0
          NA          NO
```

The following sample output displays the current performance monitoring parameters of the Optics controller in 15-minute intervals. Trunk optics have one lane.

```
RP/0/RP0/CPU0:ios#show controller optics 0/2/0/1 pm current 15-min optics 1
```

```
Sat Feb 9 11:19:15.234 UTC
Optics in the current interval [11:15:00 - 11:19:15 Sat Feb 9 2019]
Optics current bucket type : Valid
      MIN      AVG      MAX      Operational      Configured      TCA      Operational
Configured          TCA
                                         Threshold(min)      Threshold(min)  (min)  Threshold(max)
      Threshold(max)  (max)
LBC[%]   : 0.0      0.0      0.0      0.0      NA      NO  100.0
          NA          NO
OPT[dBm]  : -1.51    -1.49    -1.48    -30.00      NA      NO  63.32
          NA          NO
OPR[dBm]  : -9.11    -9.07    -9.03    -30.00      NA      NO  63.32
          NA          NO
CD[ps/nm] : 13      15      18    -180000      NA      NO  180000
          NA          NO
DGD[ps]    : 2.00    2.33    3.00     0.01      NA      NO  21474836.46
          NA          NO
SOPMD[ps^2] : 5.00    33.02   79.00     0.01      NA      NO  21474836.46
```

	NA	NO				NA	NO	21474836.46
OSNR [dB]	: 31.50	31.97	32.50	0.01		NA	NO	21474836.46
NA		NO						
PDL [dB]	: 0.20	0.34	0.50	0.01		NA	NO	21474836.46
NA		NO						
PCR [rad/s]	: 0.00	19.92	93.00	0.01		NA	NO	21474836.46
NA		NO						
RX_SIG [dBm]	: -9.05	-9.02	-8.99	-30.00		NA	NO	63.32
NA		NO						
FREQ_OFF [Mhz]	: -302	-178	-74	-1500		NA	NO	1500
NA		NO						

The following sample output displays the current performance monitoring parameters of the Ethernet controller 15-minute intervals.

```
RP/0/RP0/CPU0:ios#show controller HundredGigECtrlr 0/1/0/2 pm current 15-min ether
Fri Aug 30 00:37:53.527 UTC
```

```
ETHER in the current interval [00:30:00 - 00:37:53 Fri Aug 30 2019]
```

ETHER current bucket type : Valid			
RX-UTIL[%]	: 100.00	Threshold : 0.00	TCA(enable) : NO
TX-UTIL[%]	: 10.00	Threshold : 0.00	TCA(enable) : NO
RX-PKT	: 3852414442	Threshold : 0	TCA(enable) : NO
STAT-PKT	: 0	Threshold : 0	TCA(enable) : NO
OCTET-STAT	: 5847965122956	Threshold : 0	TCA(enable) : NO
OVERSIZE-PKT	: 0	Threshold : 0	TCA(enable) : NO
FCS-ERR	: 0	Threshold : 0	TCA(enable) : NO
LONG-FRAME	: 0	Threshold : 0	TCA(enable) : NO
JABBER-STATS	: 0	Threshold : 0	TCA(enable) : NO
64-OCTET	: 0	Threshold : 0	TCA(enable) : NO
65-127-OCTET	: 0	Threshold : 0	TCA(enable) : NO
128-255-OCTET	: 0	Threshold : 0	TCA(enable) : NO
256-511-OCTET	: 0	Threshold : 0	TCA(enable) : NO
512-1023-OCTET	: 0	Threshold : 0	TCA(enable) : NO
1024-1518-OCTET	: 0	Threshold : 0	TCA(enable) : NO
IN-UCAST	: 0	Threshold : 0	
IN-MCAST	: 0	Threshold : 0	TCA(enable) : NO
IN-BCAST	: 0	Threshold : 0	TCA(enable) : NO
OUT-UCAST	: 0	Threshold : 0	TCA(enable) : NO
OUT-BCAST	: 0	Threshold : 0	TCA(enable) : NO
OUT-MCAST	: 0	Threshold : 0	TCA(enable) : NO
TX-PKT	: 7053588067	Threshold : 0	TCA(enable) : NO
OUT-OCTET	: 451429636288	Threshold : 0	TCA(enable) : NO
IFIN-ERRORS	: 0	Threshold : 0	TCA(enable) : NO
IFIN-OCTETS	: 0	Threshold : 0	TCA(enable) : NO
STAT-MULTICAST-PKT	: 0	Threshold : 0	TCA(enable) : NO
STAT-BROADCAST-PKT	: 0	Threshold : 0	TCA(enable) : NO
STAT-UNDERSIZED-PKT	: 0	Threshold : 0	TCA(enable) : NO
IN_GOOD_BYTES	: 5847965122956	Threshold : 0	TCA(enable) : NO
IN_GOOD_PKTS	: 3852414442	Threshold : 0	TCA(enable) : NO
IN_DROP_OTHER	: 0	Threshold : 0	TCA(enable) : NO
OUT_GOOD_BYTES	: 451429636288	Threshold : 0	TCA(enable) : NO
OUT_GOOD_PKTS	: 7053588067	Threshold : 0	TCA(enable) : NO
IN_PKT_64_OCTET	: 0	Threshold : 0	TCA(enable) : NO
IN_PKTS_65_127_OCTETS	: 0	Threshold : 0	TCA(enable) : NO
IN_PKTS_128_255_OCTETS	: 0	Threshold : 0	TCA(enable) : NO

## Verify the Performance Monitoring Parameters of Controllers

IN_PKTS_256_511_OCTETS	:	0	Threshold :	0	TCA(enable) :	NO
IN_PKTS_512_1023_OCTETS	:	0	Threshold :	0	TCA(enable) :	NO
IN_PKTS_1024_1518_OCTETS	:	3852414442	Threshold :	0	TCA(enable) :	NO
OUT_PKT_64_OCTET	:	7053588067	Threshold :	0	TCA(enable) :	NO
OUT_PKTS_65_127_OCTETS	:	0	Threshold :	0	TCA(enable) :	NO
OUT_PKTS_128_255_OCTETS	:	0	Threshold :	0	TCA(enable) :	NO
OUT_PKTS_256_511_OCTETS	:	0	Threshold :	0	TCA(enable) :	NO
OUT_PKTS_512_1023_OCTETS	:	0	Threshold :	0	TCA(enable) :	NO
OUT_PKTS_1024_1518_OCTETS	:	0	Threshold :	0	TCA(enable) :	NO
TX_UNDERSIZED_PKT	:	0	Threshold :	0	TCA(enable) :	NO
TX_OVERSIZED_PKT	:	0	Threshold :	0	TCA(enable) :	NO
TX_JABBER	:	0	Threshold :	0	TCA(enable) :	NO
TX_BAD_FCS	:	0	Threshold :	0	TCA(enable) :	NO

The following sample output displays the current performance monitoring parameters of the Coherent DSP controller 15-minute intervals.

```
RP/0/RP0/CPU0:ios#show controller coherentDSP 0/2/0/1 pm current 15-min fec
```

Sat Feb 9 11:23:42.196 UTC

g709 FEC in the current interval [11:15:00 - 11:23:42 Sat Feb 9 2019]

FEC current bucket type : Valid							
EC-BITS : 291612035786			Threshold :	903330			TCA(enable) :
YES							
UC-WORDS : 0			Threshold :	5			TCA(enable) :
YES							
MIN      AVG      MAX      Threshold      TCA      Threshold      TCA			(min)	(enable)	(max)	(enable)	
PreFEC BER : 7.1E-03	7.2E-03	8.1E-03	0E-15	NO	0E-15	NO	
PostFEC BER : 0E-15	0E-15	0E-15	0E-15	NO	0E-15	NO	

The following sample output displays the current performance monitoring parameters of the optics controller 10-second intervals as flexi-bin.

```
RP/0/RP0/CPU0:ios#show controllers optics 0/0/0/0 pm current flex-bin optics 1
Thu May 21 07:43:38.964 UTC
```

Optics in the current interval [07:43:30 - 07:43:38 Thu May 21 2020]

Flexible bin interval size: 10 seconds

Optics current bucket type : Valid							
MIN      AVG      MAX      Operational      Configured      TCA      Operational							
Configured      TCA							
Threshold(max)      (max)			Threshold(min)	Threshold(min)	(min)	Threshold(max)	
LBC[%] : 0.0	0.0	0.0	0.0	0.0	NA	NO	0.0
NA		NO					
OPT[dBm] : -0.13	-0.10	-0.06	0.00		NA	NO	0.00
NA		NO					
OPR[dBm] : -3.01	-2.96	-2.92	0.00		NA	NO	0.00
NA		NO					
CD[ps/nm] : -3	-2	-1	0		NA	NO	0
NA		NO					
DGD[ps] : 1.00	1.67	2.00	0.00		NA	NO	0.00
NA		NO					
SOPMD[ps^2] : 17.00	37.00	81.00	0.00		NA	NO	0.00
NA		NO					
OSNR[dB] : 37.60	37.60	37.60	0.00		NA	NO	0.00

NA	NO							
PDL [dB]	: 0.60	0.66	0.70	0.00	NA	NA	NO	0.00
NA	NO							
PCR [rad/s]	: 0.00	29.11	80.00	0.00	NA	NA	NO	0.00
NA	NO							
RX_SIG [dBm]	: -3.49	-3.41	-3.36	0.00	NA	NA	NO	0.00
NA	NO							
FREQ_OFFSET [MHz]	: 191	241	301	0	NA	NA	NO	0
NA	NO							
SNR [dB]	: 14.50	14.62	14.70	0.00	NA	NA	NO	0.00
NA	NO							
SNR-AX [dB]	: 17.10	17.19	17.30	0.00	NA	NA	NO	0.00
NA	NO							
SNR-AY [dB]	: 11.90	12.06	12.10	0.00	NA	NA	NO	0.00
NA	NO							
SNR-BX [dB]	: 0.00	0.00	0.00	0.00	NA	NA	NO	0.00
NA	NO							
SNR-BY [dB]	: 0.00	0.00	0.00	0.00	NA	NA	NO	0.00
NA	NO							
SOP-S1	: 0.50	0.55	0.59	0.00	NA	NA	NO	0.00
NA	NO							
SOP-S2	: -0.59	-0.52	-0.48	0.00	NA	NA	NO	0.00
NA	NO							
SOP-S3	: -0.67	-0.64	-0.60	0.00	NA	NA	NO	0.00
NA	NO							

Last clearing of "show controllers OPTICS" counters never

---

## Using SNMP for Troubleshooting

The supported MIBs in NCS 1004 are documented in the *SNMP* chapter of *Configuration Guide for Cisco NCS 1004*.

### Procedure

---

Use the following commands in EXEC mode to verify and monitor the SNMP for network monitoring and management.

- show snmp — Displays the status of SNMP communications.
  - show snmp mib access — Displays the counters per OID that indicate the number of times an operation was done on an OID.
  - show snmp mib access time — Displays the timestamp of the last operation on an OID.
  - show snmp trace requests — Displays a log of the high level PDU processing trace points.
  - debug snmp packet — Displays information about every SNMP packet sent or received by NCS 1004.
  - debug snmp requests — Displays information about every SNMP request made by the SNMP manager.
-

# Using Netconf for Troubleshooting

Netconf provides mechanisms to install, manipulate, and delete the configuration of network devices. The Netconf protocol provides a set of operations to manage device configurations and retrieve device state information.

Use the following commands in EXEC mode to retrieve device state information.

## Before you begin

- Verify the installation of k9sec package.
- Generate the crypto key for SSH using the **crypto key generate dsa** command.



**Note** If you access NCS 1004 after regenerating the crypto key, you must remove the **~/.ssh/known\_hosts** file as there will be a key mismatch between the host and NCS 1004.

- Configure SSH.

```
RP/0/RP0/CPU0:ios# configure
RP/0/RP0/CPU0(config)# ssh server v2
RP/0/RP0/CPU0(config)# ssh server netconf port 830
RP/0/RP0/CPU0(config)# ssh server netconf vrf default
```



**Note** Port 830 is the default Netconf port.

- Configure Netconf.

```
RP/0/RP0/CPU0:ios# configure
RP/0/RP0/CPU0(config)# netconf-yang agent ssh
```

## Procedure

### Step 1 show netconf-yang clients

Displays the client details for netconf-yang.

#### Example:

```
RP/0/RP0/CPU0:ios# show netconf-yang clients
Fri Nov 26 15:28:50.942 UTC
No active netconf sessions found.
```

### Step 2 show netconf-yang statistics

Displays the statistical details for netconf-yang.

#### Example:

```

RP/0/RP0/CPU0:ios# show netconf-yang statistics
Fri Nov 26 15:24:06.612 UTC
Summary statistics
      # requests|          total time| min time per request| max
      time per request| avg time per request|
other           0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
close-session   0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
kill-session    0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
get-schema      0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
get             0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
get-config       0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
edit-config     0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
commit          0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
cancel-commit   0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
lock            0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
unlock          0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
discard-changes 0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
validate         0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
xml parse        0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
netconf processor 0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
YFW              0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
pending requests 0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
invoke rpc       0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
copy-config      0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
create-subscription 0 | 0h 0m 0s 0ms | 0h 0m 0s 0ms |
List is empty.

```

### Step 3 show netconf-yang trace

Debugs and verifies Netconf.

#### Example:

```

RP/0/RP0/CPU0:ios# show netconf-yang trace
Fri Nov 26 15:29:31.430 UTC
68703 wrapping entries (203392 possible, 161152 allocated, 0 filtered, 68703 total)
Nov 25 17:05:39.003 netconf/netconf.trace 0/RP0/CPU0 t8790 #61984: TRC:
nc_pxs_ipc_notify_callback_fn:319 IPC_NOTIFY_OPEN
Nov 25 17:05:39.003 netconf/netconf.trace 0/RP0/CPU0 t8790 #61985: TRC:
nc_sm_pxs_notify_callback_fn:7243 New NETCONF SSH proxy client connection: 0x7f4868942c90
Nov 25 17:05:39.005 netconf/netconf.trace 0/RP0/CPU0 t8790 #61986: DBG:
nc_sm_yf_start_session_generate:877 cidl_yfw_request malloced 0x5607192903c0
Nov 25 17:05:39.005 netconf-yfw/brief.trace 0/RP0/CPU0 t8790 #61987: TRC: yfw_trace:3389
ctx=0x5607173dc830,[Server->yfw] new session
Nov 25 17:05:39.005 netconf-yfw/nacm.trace 0/RP0/CPU0 t8790 #61988: TRC:

```

## Using Netconf for Troubleshooting

```

yfw_nacm_req_author_enforcement:1342 ctx=0x5607173dcc70,[REQ] sess_id: 0, <(null)> is not
supported. Skip checking.
Nov 25 17:05:39.006 netconf-yfw/processor.trace 0/RP0/CPU0 t8790 #61989: DBG:
yfw_request_process:2702 ctx=0x5607173da7a0,cidl_yfw_request 0x5607192903c0
Nov 25 17:05:39.006 netconf-yfw/brief.trace 0/RP0/CPU0 t8790 #61990: TRC:
yfw_request_process:2704 ctx=0x5607173dc830,req_cidl_START_SESSION==
Nov 25 17:05:39.006 netconf-yfw/map.trace 0/RP0/CPU0 t8790 #61991: TRC:
yfw_map_transform_request:1719 ctx=0x5607173dd0b0,Start
Nov 25 17:05:39.006 netconf-yfw/map.trace 0/RP0/CPU0 t8790 #61992: TRC:
yfw_map_transform_request:1763 ctx=0x5607173dd0b0,Mapping not required for this request.
Nov 25 17:05:39.006 netconf-yfw/processor.trace 0/RP0/CPU0 t8790 #61993: DBG:
yfw_session_create:174 ctx=0x5607173da7a0,assigned session-id=743885753
Nov 25 17:05:39.006 netconf-yfw/processor.trace 0/RP0/CPU0 t8790 #61994: TRC:
yfw_req_session_start:655 ctx=0x5607173da7a0,ses=0x560719330a50,op=11,yfw session not mdt
743885753
Nov 25 17:05:39.006 netconf-yfw/me.trace 0/RP0/CPU0 t8790 #61995: DBG: me_session_create:33072
ctx=0x5607173e9390,session create: usr=0x560719344b00,ses=0x560719330a60
Nov 25 17:05:39.006 netconf-yfw/me.trace 0/RP0/CPU0 t8790 #61996: TRC: me_session_create:33093
ctx=0x5607173e9390,super_user=0
Nov 25 17:05:39.006 netconf-yfw/me.trace 0/RP0/CPU0 t8790 #61997: TRC:
me_session_xpath_hash_init:36053 ctx=0x5607173e9390,session_id 743885753, init successfully
Nov 25 17:05:39.011 netconf-yfw/nacm.trace 0/RP0/CPU0 t8790 #61998: TRC:
yfw_nacm_session_init:1664 ctx=0x5607173dcc70,sess_id: 743885753, aaa_nacm_is_enabled() rc:
0
Nov 25 17:05:39.011 netconf-yfw/brief.trace 0/RP0/CPU0 t8790 #61999: TRC:
me_session_create:33164 ctx=0x5607173dc830,sess (0x560719290be0), session_id: 743885753
Nov 25 17:05:39.011 netconf-yfw/me.trace 0/RP0/CPU0 t8790 #62000: DBG: me_session_create:33190
ctx=0x5607173e9390,Update session info: START
Nov 25 17:05:39.015 netconf-yfw/bk.trace 0/RP0/CPU0 t8790 #62001: TRC:
me_bk_sysdb_auth_user_init:561 ctx=0x5607173f7d20,Using authorization methodlist 'default'.
Nov 25 17:05:39.022 netconf-yfw/bk.trace 0/RP0/CPU0 t8790 #62002: TRC:
sysdb_backend_session_create:1715 ctx=0x5607173f7d20,auth user init successess, caller
ctx=0x560719292570
Nov 25 17:05:39.022 netconf-yfw/bk.trace 0/RP0/CPU0 t8790 #62003: DBG:
sysdb_backend_session_create:1719 ctx=0x5607173f7d20,SysDB backend session successfully
created (0x56071929bb00).
Nov 25 17:05:39.022 netconf-yfw/me.trace 0/RP0/CPU0 t8790 #62004: TRC:
me_noqt_session_create:35378 ctx=0x5607173e9390,creating non-QT backend session(s)
Nov 25 17:05:39.022 netconf-yfw/calvados.trace 0/RP0/CPU0 t8790 #62005: TRC:
calvados_backend_session_create:1635 ctx=0x5607174650a0,tid=0x7f48e9e83840,calvados enqueued
session 0x56071929bf40
Nov 25 17:05:39.022 netconf-yfw/calvados.trace 0/RP0/CPU0 t8790 #62006: TRC:
calvados_backend_session_create:1692 ctx=0x5607174650a0,tid=0x7f48e9e83840,calling dm_execute
Nov 25 17:05:39.022 netconf-yfw/me.trace 0/RP0/CPU0 t8790 #62007: TRC: me_session_create:33284
ctx=0x5607173e9390,Session ref count incremented (1)
Nov 25 17:05:39.022 netconf-yfw/processor.trace 0/RP0/CPU0 t8790 #62008: DBG:
yfw_me_request_result_check:590 ctx=0x5607173da7a0,ses=0x560719330a50,op=11,ME request
success.
Nov 25 17:05:39.022 netconf-yfw/bk.trace 0/RP0/CPU0 t8849 #62009: TRC:
me_bk_sysdb_auth_request_process:366 ctx=0x5607173f7d20,getting authorization taskmap of
user (user ctx=0x56071929bb00).
Nov 25 17:05:39.022 netconf-yfw/bk.trace 0/RP0/CPU0 t8849 #62010: TRC:
me_bk_sysdb_get_user_taskmap_netconf_ssh:107 ctx=0x5607173f7d20,agent_name: netconf
Nov 25 17:05:39.022 netconf-yfw/bk.trace 0/RP0/CPU0 t8849 #62011: TRC:
me_bk_sysdb_get_user_taskmap_netconf_ssh:142 ctx=0x5607173f7d20,Retrieving authorization
taskmap from SSHD child handler, PID: 26449
Nov 25 17:05:39.022 netconf/netconf.trace 0/RP0/CPU0 t8790 #62012: DBG:
nc_sm_ses_timeout_elapsed_check_timer_set:6942 Setting abs and idle timeouts
Nov 25 17:05:39.022 netconf-yfw/confd.trace 0/RP0/CPU0 t8864 #62013: TRC:
calvados_backend_xdm_wait:1001 ctx=0x56071747d3a0,tid=0x7f48694be700,[Calvados XDM threadpool]
dm_wait returned with 0
Nov 25 17:05:39.022 netconf-yfw/confd.trace 0/RP0/CPU0 t8864 #62014: DBG:
calvados_backend_xdm_dispatch:1012 ctx=0x56071747d3a0,tid=0x7f48694be700,CA_API_GET_INSTANCE
ref_count:-8

```

# Verify Alarms

You can view the alarm information using the **show alarms** command.

## Procedure

```
show alarms [ brief [ card | rack | system ] [ location location ] [ active | history ] | detail [ card | rack | system ] [ location location ] [ active | clients | history | stats ] ]
```

Displays alarms in brief or detail.

### Example:

```
RP/0/RP0/CPU0:ios# show alarms brief card location 0/RP0/CPU0 active
```

```
Wed Mar 4 06:10:55.959 UTC
```

---

#### Active Alarms

---

Location	Severity	Group	Set Time	Description
0/1	Major	FPD_Infra	03/02/2020 07:09:04 UTC	One Or More FPDs Need Upgrade Or Not In Current State
0/2	Major	FPD_Infra	03/03/2020 14:27:33 UTC	One Or More FPDs Need Upgrade Or Not In Current State
0/2	Major	Ethernet	03/03/2020 20:33:33 UTC	HundredGigECtrlr0/2/0/9 - Carrier Loss On The LAN
0/2	Critical	Controller	03/03/2020 20:34:05 UTC	Optics0/2/0/3 - Improper Removal
0/2	NotAlarmed	OTN	03/03/2020 20:34:08 UTC	ODU40/2/0/0/2 - OPUK Client Signal Failure
0/2	NotAlarmed	OTN	03/03/2020 20:34:05 UTC	ODU40/2/0/1/2 - OPUK Client Signal Failure

```
RP/0/RP0/CPU0:ios# show alarms brief card location 0/RP0/CPU0 active
```

```
Fri May 8 04:46:29.582 UTC
```

---

#### Active Alarms

---

Location	Severity	Group	Set Time	Description
0/2	NotReported	OTN	05/07/2020 14:25:05 UTC	ODU20/2/0/0/2/3 - Path Monitoring Alarm Indication Signal

## Using Onboard Failure Logging

0/2	NotReported	OTN	05/07/2020 14:25:05 UTC	ODU2E0/2/0/0/2/4
-	Path Monitoring	Alarm Indication Signal		
0/1	NotReported	OTN	05/07/2020 14:24:41 UTC	ODU20/1/0/0/2/3 -
-	Path Monitoring	Alarm Indication Signal		
0/1	NotReported	OTN	05/07/2020 14:25:03 UTC	ODU20/1/0/1/11/3
-	Path Monitoring	Alarm Indication Signal		
0/1	NotReported	OTN	05/07/2020 14:25:03 UTC	ODU2E0/1/0/1/11/4
-	Path Monitoring	Alarm Indication Signal		
0/3	NotReported	OTN	05/07/2020 14:24:41 UTC	ODU20/3/0/0/2/3 -
-	Path Monitoring	Alarm Indication Signal		
0/3	NotReported	OTN	05/07/2020 14:24:41 UTC	ODU2E0/3/0/0/2/4
-	Path Monitoring	Alarm Indication Signal		
0/1	Major	Ethernet	05/07/2020 14:24:41 UTC	TenGigECtr1r0/1/0/4/1
-	Remote Fault			

**Note** In the maintenance mode, all the alarms are suppressed and the **show alarms** command will not show the alarms details. Use the **show controllers controller-type R/S/I/P** command to view the client and trunk alarms.

# Using Onboard Failure Logging

Onboard Failure Logging (OBFL) collects and stores boot, environmental, and critical hardware data in the nonvolatile flash memory of the CPU controller card. This information is used for troubleshooting, testing, and diagnosis if a failure or other error occurs. This data provides improved accuracy in hardware troubleshooting and root cause isolation analysis. The data collected includes field-replaceable unit (FRU) serial number, OS version, total run time, boot status, temperature and voltage at boot, temperature and voltage history, and other board specific errors.

## Procedure

**show logging onboard {fmea | inventory | temperature | uptime | voltage}**

Displays OBFL data.

### Example:

The following example shows the *uptime* information.

```
sysadmin-vm:0_RP0# show logging onboard uptime
```

```
OBFL Uptime Information For : 0/RP0
  * indicates incomplete time-sync while record was written
  ! indicates time reset backwards while system was running
-----
----- UPTIME CARD INFORMATION -----
----- Entity Name      : Value
----- Previous Chassis SN : CAT2311B0C5
```

Current Chassis SN	:	CAT2311B0CM
Previous R/S/I	:	0/0/0
Current R/S/I	:	0/0/0
Write Interval	:	15 (min)
First Power On TS	:	07/30/2019 07:33:56
Last Erase TS	:	--/--- ---:--
Rack Change Count	:	8
Slot Change Count	:	8

---

#### UPTIME INFORMATION

---

Start Time (UTC) mm/dd/yyyy hh:mm:ss	End Time (UTC) mm/dd/yyyy hh:mm:ss	Card Uptime info Weeks.Days.Hrs.Min.Sec
---	---------------------------------------	--

---

10/28/2021 12:23:17	11/14/2021 21:09:18	2.3.8.46.1
11/14/2021 21:09:18	11/18/2021 16:31:15	0.3.19.21.57
11/18/2021 16:31:15	11/18/2021 21:10:35	0.0.4.39.20
11/18/2021 21:10:35	11/19/2021 12:40:39	0.0.15.30.4
11/19/2021 12:40:39	11/19/2021 14:16:10	0.0.1.35.31
11/19/2021 14:16:10	11/22/2021 11:49:20	0.2.21.33.10
11/22/2021 11:49:20	11/22/2021 22:51:48	0.0.11.2.28
11/22/2021 22:51:48	11/23/2021 17:17:41	0.0.18.25.53
11/24/2021 21:22:12	11/24/2021 23:11:16	0.0.1.49.4
11/24/2021 23:11:16	11/24/2021 23:39:49	0.0.0.28.33
11/24/2021 23:39:49	11/25/2021 15:25:32	0.0.15.45.43
11/25/2021 15:25:32	11/25/2021 16:10:05	0.0.0.44.33
11/25/2021 16:10:05	11/25/2021 16:25:08	0.0.0.15.3
11/25/2021 16:25:08	11/25/2021 16:37:18	0.0.0.12.10
11/25/2021 16:37:18	11/26/2021 15:08:27	0.0.22.31.9

#### OBFL Uptime Information For : 0/SCO

\* indicates incomplete time-sync while record was written  
! indicates time reset backwards while system was running

---

#### UPTIME CARD INFORMATION

---

Entity Name	:	Value
-------------	---	-------

---

Previous Chassis SN	:	-----
Current Chassis SN	:	CAT2311B0CM
Previous R/S/I	:	-/-/-
Current R/S/I	:	0/1/0
Write Interval	:	15 (min)
First Power On TS	:	06/07/2019 08:52:42
Last Erase TS	:	--/--- ---:--
Rack Change Count	:	0
Slot Change Count	:	0

---

#### UPTIME INFORMATION

---

Start Time (UTC) mm/dd/yyyy hh:mm:ss	End Time (UTC) mm/dd/yyyy hh:mm:ss	Card Uptime info Weeks.Days.Hrs.Min.Sec
---	---------------------------------------	--

---

10/24/2021 05:48:29	10/24/2021 06:27:51	0.0.0.39.22
10/24/2021 06:27:51	10/24/2021 07:05:24	0.0.0.37.33
10/24/2021 07:05:24	10/26/2021 23:43:32	0.2.16.38.8
10/26/2021 23:43:32	10/26/2021 23:55:49	0.0.0.12.17
10/26/2021 23:55:49	10/27/2021 00:09:49	0.0.0.14.0
10/27/2021 00:09:49	10/27/2021 00:16:08	0.0.0.6.19
10/27/2021 00:16:08	10/27/2021 23:37:51	0.0.23.21.43
10/27/2021 23:37:51	10/27/2021 23:50:33	0.0.0.12.42

**Capture Logs**

```

11/24/2021 21:22:12 | 11/24/2021 23:11:16 | 0.0.1.49.4
11/24/2021 23:11:16 | 11/24/2021 23:39:49 | 0.0.0.28.33
11/24/2021 23:39:49 | 11/25/2021 15:25:32 | 0.0.15.45.43
11/25/2021 15:25:32 | 11/25/2021 16:10:05 | 0.0.0.44.33
11/25/2021 16:10:05 | 11/25/2021 16:25:08 | 0.0.0.15.3
11/25/2021 16:25:08 | 11/25/2021 16:37:18 | 0.0.0.12.10
11/25/2021 16:37:18 | 11/26/2021 15:09:27 | 0.0.22.32.9

```

---

# Capture Logs

## Procedure

**Step 1 show logging**

Displays the contents of the logging buffers. You can also view details of FPD upgrade failures.

**Example:**

```

RP/0/RP0/CPU0:ios# show logging
Fri Nov 26 15:03:48.886 UTC
Syslog logging: enabled (0 messages dropped, 0 flushes, 0 overruns)
  Console logging: Disabled
  Monitor logging: level debugging, 0 messages logged
  Trap logging: level informational, 0 messages logged
  Buffer logging: level debugging, 1025 messages logged

Log Buffer (2097152 bytes):

RP/0/RP0/CPU0:Nov 25 16:40:28.533 UTC: syslogd[155]: %SECURITY-XR_SSL-6-INFO : XR SSL info:
  Setting fips register
RP/0/RP0/CPU0:Nov 25 16:40:36.323 UTC: cfgmgr-rp[120]: %MGBL-CONFIG-7-INTERNAL : Configuration
  Manager was unable to find subtree for 'sh_p_service_role_daemon' partition. : cfgmgr-rp
  : (PID=2522) : -Traceback= 7f1be3f92420 7f1be4bdd0c6 7f1be4bdd208 7f1be4bd74a4 7f1be4bd7e45
  7f1be4bdb972 7f1be4bd7f0e 55e025a46170 55e025a42429 55e025a3168f
RP/0/RP0/CPU0:Nov 25 16:40:36.457 UTC: aib[291]: Registering with IM
RP/0/RP0/CPU0:Nov 25 16:40:36.661 UTC: cma_partner[350]: Packet received on undiscovered
  module 160
RP/0/RP0/CPU0:Nov 25 16:40:37.113 UTC: ifmgr[142]: platform_pfi_ifh_get_if_alloc_info:
  Setting pic
  .....
  .....

```

**a) logging buffered size**

Configures the size of the logging buffer. The range is from 2097152 to 125000000 bytes.

**Example:**

```
RP/0/RP0/CPU0:ios(config)#logging buffered 3000000
```

**Step 2 show tech-support ncs1004**

Creates a .tgz file that contains the dump of the configuration and show command outputs. This file provides system information for the Cisco Technical Support.

**Example:**

```
RP/0/RP0/CPU0:ios# show tech-support ncs1004
Fri Nov 26 15:05:28.996 UTC
++ Show tech start time: 2021-Nov-26.150529.UTC ++
Fri Nov 26 15:05:30 UTC 2021 Waiting for gathering to complete
.....
Fri Nov 26 15:10:38 UTC 2021 Compressing show tech output
Show tech output available at 0/RP0/CPU0 :
/harddisk:/showtech/showtech-ncs1004-2021-Nov-26.150529.UTC.tgz
++ Show tech end time: 2021-Nov-26.151040.UTC ++
```

### Step 3 show tech-support alarm-mgr

Collects the Cisco support file for the alarm manager component.

**Example:**

```
RP/0/RP0/CPU0:ios#show tech-support alarm-mgr
Fri Nov 26 15:06:06.916 UTC
++ Show tech start time: 2021-Nov-26.150607.UTC ++
Fri Nov 26 15:06:08 UTC 2021 Waiting for gathering to complete
.....
Fri Nov 26 15:06:23 UTC 2021 Compressing show tech output
Show tech output available at 0/RP0/CPU0 :
/harddisk:/showtech/showtech-alarm_mgr-2021-Nov-26.150607.UTC.tgz
++ Show tech end time: 2021-Nov-26.150624.UTC ++
```

### Step 4 admin

Enters system admin EXEC mode.

**Example:**

```
RP/0/RP0/CPU0:ios#admin
```

### Step 5 show tech ncs1004-admin

Collects show tech logs that can be copied to IOS XR hard disk.

**Example:**

```
sysadmin-vm:0_RP0# show tech ncs1004-admin
Thu May  5 15:22:08.520 UTC+00:00
++ Show tech start time: 2022-May-05.152208.UTC ++
Waiting for gathering to complete
.....
Compressing show tech output
Show tech output available at
/misc/disk1//showtech/showtech-ncs1004-admin-2022-May-05.152208.UTC.tgz
Please collect show tech-support ctrace in addition to any sysadmin show-tech-support
collection

sysadmin-vm:0_RP0# run
Thu May  5 15:31:54.352 UTC+00:00
[sysadmin-vm:0_RP0:~]$scp
/misc/disk1//showtech/showtech-ncs1004-admin-2022-May-05.152208.UTC.tgz 192.0.2.3:/misc/disk1/
showtech-ncs1004-admin-2022-May-05.152208.UTC.tgz
12.8MB/s 00:00
[sysadmin-vm:0_RP0:~]$exit
```

### What to do next

You should gather the above information before calling the Cisco Technical Assistance Center (TAC).

# Verify Process Details and Crash Dump

## Procedure

### Step 1 show processes

Displays information about active processes.

**Example:**

The following example shows the output of the **show processes** command in the EXEC mode.

```
RP/0/RP0/CPU0:ios# show processes
Fri Nov 26 14:59:31.671 UTC
JID    TID  Stack  pri  state      NAME          rt_pri
1       1     OK    20   Sleeping   init           0
66985  1359  OK    20   Sleeping   oom.sh        0
66911  1375  OK    20   Sleeping   cgroup_oom.sh  0
66912  1376  OK    20   Sleeping   oom.sh        0
66932  1396  OK    0    Sleeping   cgroup_oom   0
67172  1636  OK    20   Sleeping   app_config_back 0
67176  1640  OK    20   Sleeping   bash           0
67203  1667  OK    20   Sleeping   inotifywait   0
67205  1669  OK    20   Sleeping   bash           0
67242  1706  OK    20   Sleeping   dbus-daemon   0
67242  1707  OK    20   Sleeping   dbus-daemon   0
67260  1724  OK    20   Sleeping   sshd           0
67271  1735  OK    20   Sleeping   rpcbind        0
.....
.....
.....
```

The following example shows the output of the **show processes** command in the system admin EXEC mode.

```
sysadmin-vm:0_RP0# show processes all location 0/rp0
Fri Nov 26 15:01:44.450 UTC+00:00
-----
node: 0/RP0
-----
LAST STARTED          STATE  RE-  MANDA- MAINT- NAME (IID)  ARGS
START    TORY      MODE
-----
11/25/2021 16:37:56.000 Run   1                aaad(0)
11/25/2021 16:39:12.000 Run   1                ael_mgb1(0)
11/25/2021 16:37:56.000 Run   1                bh_cardmgr(0) -M 3
11/25/2021 16:37:56.000 Run   1                bh_esd(0)
11/25/2021 16:37:56.000 Run   1                calv_alarm_mgr(0)
11/25/2021 16:37:56.000 Run   1                cm(0)
11/25/2021 16:37:56.000 Run   1                confd_helper(0) -t token -d -w 400
               -b 30 -p 600 -r 10 -f 10
11/25/2021 16:39:12.000 Run   1                debug_agent(0)
11/25/2021 16:37:56.000 Run   1                debug_client(0)
11/25/2021 16:37:56.000 Run   1                dr_calv(0) 0
11/25/2021 16:37:56.000 Run   1                ds(0) -r
11/25/2021 16:37:56.000 Run   1                dumper(0)
11/25/2021 16:37:56.000 Run   1                envmon(0)
11/25/2021 16:39:12.000 Run   1                envmon_ui(0)
11/25/2021 16:39:12.000 Run   1                fit_mgb1(0)
11/25/2021 16:39:12.000 Run   1                fpdserv(0)
11/25/2021 16:39:12.000 Run   1                gaspp_mgb1(0)
11/25/2021 16:37:56.000 Run   1                inst_agent(0)
```

```

11/25/2021 16:39:13.000 Run      1           inst_mgr(0)
11/25/2021 16:37:56.000 Run      1           M          issu_agt(0)
11/25/2021 16:39:12.000 Run      1           issu_dir(0)
11/25/2021 16:39:11.000 Run      2           led_mgr(0)
11/25/2021 16:37:56.000 Run      1           mediasvr(0)
11/25/2021 16:37:56.000 Run      1           obfl_mgr(0)
11/25/2021 16:37:56.000 Run      1           obfl_show(0)
11/25/2021 16:37:56.000 Run      1           pam_manager(0)
11/25/2021 16:37:56.000 Run      1           pm(0)
11/25/2021 16:37:56.000 Run      1           M          rvm_mgr(0)
11/25/2021 16:37:56.000 Run      1           M          sdr_mgr(0)
11/25/2021 16:37:56.000 Run      1           set_hostname(0)
11/25/2021 16:37:56.000 Run      1           M          shelf_mgr(0)
11/25/2021 16:37:56.000 Run      1           M          ship_server(0)
11/25/2021 16:37:56.000 Run      1           ssh_key_client(0)
11/25/2021 16:39:12.000 Run      1           ssh_key_server(0)
11/25/2021 16:37:56.000 Run      1           M          syslogd_helper(0)
11/25/2021 16:37:56.000 Run      1           syslogd_relay(0)
11/25/2021 16:37:56.000 Run      1           tacacs(0)
11/25/2021 16:37:56.000 Run      1           timezone_config(0)
11/25/2021 16:37:56.000 Run      1           M          vm_manager(0) -W -c -n -v -e
/opt/cisco/qemu-system-x86_64.wrapper
11/25/2021 16:37:56.000 Run      1           M          wd_diskmon(0)
11/25/2021 16:37:56.000 Run      1           M          wd_memmon(0)
11/25/2021 16:37:56.000 Run      1           M          wd_sysmon(0)
11/25/2021 16:37:56.000 Run      1           M          wdmon(0) -q
-----
Total pcbs: 43
-----
```

**Step 2****show processes process-name**

Displays detailed information about a process.

**Example:**

```

RP/0/RP0/CPU0:ios#show processes dsr
Fri Nov 26 15:02:55.728 UTC
    Job Id: 53
        PID: 2246
    Process name: dsr
  Executable path: /opt/cisco/XR/packages/ncs1004-iosxr-os-1.0.0.0-r751/all/bin/dsr
    Instance #: 1
    Version ID: 00.00.0000
        Respawn: ON
    Respawn count: 1
    Last started: Thu Nov 25 16:40:26 2021
    Process state: Run
    Package state: Normal
        core: DUMPFALLBACK
    Max. core: 0
        Level: 11
    Mandatory: ON
    MaintModeProc: ON
        Placement: None
    startup_path:
/opt/cisco/XR/packages/ncs1004-iosxr-os-1.0.0.0-r751/all/init.d/dsr.init
    Ready: 0.375s
    Process cpu time: 2.050 user, 0.930 kernel, 2.980 total
    JID   TID  Stack  pri  state       NAME          rt_pri
    53    2246    OK   20  Sleeping    dsr            0
    53    2330    OK   20  Sleeping    lwm_service_thr 0
    53    2331    OK   20  Sleeping    qsm_service_thr 0
    53    2336    OK   20  Sleeping    dsr            0
    53    2377    OK   20  Sleeping    dsr            0

```

## Verify Process Details and Crash Dump

```
53      2378      0K 20   Sleeping    dsr          0
53      2379      0K 20   Sleeping    dsr          0
53      2380      0K 20   Sleeping    dsr          0
-----
```

### Step 3 show context

Displays information about process crashes.

#### Example:

```
RP/0/RP0/CPU0:ios# show context
Fri Nov 26 15:03:26.008 UTC
```

```
node: node0_RP0_CPU0
-----
```

```
No context
```

The command output is empty during system upgrade.



## CHAPTER 2

# Alarm Troubleshooting

---

This chapter provides a description, severity, and troubleshooting procedure for each commonly encountered Cisco NCS 1004 alarm and condition. When an alarm is raised, refer to its clearing procedure.

- [XGE\\_EEPROM\\_ERROR](#), on page 59
- [AVST-Failure Alarm](#), on page 60
- [BH-CARD-NOT-SEATED](#), on page 60
- [BH-CARD-POWER-OFF-STATUS](#), on page 60
- [BH-CARD-PWR-ON-TIMEOUT](#), on page 61
- [BH-CPU-CARD-NOT-SEATED](#), on page 61
- [BH-INVALID-CARD-SLOT](#), on page 62
- [BIOS-IMAGE-CORRUPTION](#), on page 62
- [BP\\_FPGA-SEU-UNCORRECTED-ERROR](#), on page 63
- [BP-FPGA-ERROR](#), on page 63
- [CD Alarm](#), on page 64
- [CPU-FPGA-PCIE-ERROR](#), on page 64
- [CPU-FLASH-0-ERROR](#), on page 65
- [CPU-FLASH-1-ERROR](#), on page 65
- [CPU\\_SSD\\_ATA-ERRORS Alarm](#), on page 65
- [CPU\\_SSD-TEMPERATURE\\_HIGH Alarm](#), on page 66
- [CRYPTO\\_HW\\_FAILURE](#), on page 66
- [CRYPTO-INDEX-MISMATCH](#), on page 67
- [CRYPTO-KEY-EXPIRED](#), on page 67
- [DISASTER-RECOVERY-DISABLED Alarm](#), on page 68
- [DATAPATH-DEV-FAILURE Alarm](#), on page 68
- [DGD Alarm](#), on page 69
- [EQUIPMENT\\_FAILURE](#), on page 69
- [EQUIPMENT-FAILURE Alarm](#), on page 69
- [FAN FAIL Alarm](#), on page 70
- [FAN-POWER-ERROR](#), on page 70
- [FAN SPEED SENSOR 0: OUT OF TOLERANCE FAULT Alarm](#), on page 71
- [FAN-TRAY-REMOVAL Alarm](#), on page 71
- [Flexo-LOF Alarm](#), on page 72
- [Flexo-LOM Alarm](#), on page 72
- [Flexo MM Alarm](#), on page 73

- GIDM Alarm, on page 73
- FPD IN NEED UPGD Alarm, on page 73
- FPD Infra Alarm, on page 74
- HIBER Alarm, on page 74
- HI-SER Alarm, on page 75
- HI-LASERBIAS Alarm, on page 75
- HI-RXPOWER Alarm, on page 76
- HI-TXPOWER Alarm, on page 76
- IMPROPRMVL Alarm, on page 77
- IMPROPRMVL Alarm, on page 77
- INSTALL IN PROGRESS Alarm, on page 78
- BP-FPGA-PCIE-ERROR, on page 78
- BP-FPGA-IMAGE-CORRUPTION, on page 79
- BP\_FPGA\_XR\_EP-FPGA-PCIE-ERROR, on page 79
- LCMODE-CONFIG-CHANGED Alarm, on page 80
- LCMODE-CONFIG-INVALID Alarm, on page 80
- LCMODE-NOT-CONFIG Alarm, on page 80
- LC\_BOOT\_TIMEOUT Alarm, on page 81
- LC-CPU-IMAGE-CORRUPTION, on page 81
- LC-DP-IMAGE-CORRUPTION Alarm, on page 82
- TEMPERATURE Alarm, on page 82
- LC-DISCONNECTED, on page 82
- LC-OFFLINE-ERROR, on page 83
- LC-SUDI-CERT-VERIFICATION-FAILURE Alarm, on page 83
- LO-RXPOWER Alarm, on page 84
- LO-TXPOWER Alarm, on page 84
- LOCAL-FAULT Alarm, on page 85
- LOCAL-DEG-SER Alarm, on page 85
- LOM Alarm, on page 85
- LOS Alarm, on page 86
- MB\_SSD\_ATA-ERRORS Alarm, on page 87
- MEA Alarm, on page 87
- NODE-OBFL-ERROR, on page 88
- ODU-AIS Alarm, on page 88
- ODU-BDI Alarm, on page 89
- ODU-CSF Alarm, on page 89
- ODU-IAE/BIAE, on page 90
- ODU-LCK, on page 90
- ODU-OCI, on page 90
- OSNR Alarm, on page 91
- OTNSEC-LOCALLY-SECURED, on page 91
- OTUK-AIS, on page 92
- OTUK-BDI Alarm, on page 92
- OTUK-LOF Alarm, on page 93
- OTUK-SD Alarm, on page 93
- OTUK-SF Alarm, on page 94

- OTUK-TIM Alarm, on page 94
- OTN-XP-DP-FPD-PKG-MISSING Alarm, on page 95
- PEX\_SWITCH\_ACCESS\_FAILURE Alarm, on page 95
- POWER MODULE OUTPUT DISABLED Alarm, on page 96
- POWER-MODULE-REDUNDANCY-LOST Alarm, on page 96
- PPM FAIL Alarm, on page 97
- Provisioning Failed Alarm, on page 97
- PROVISIONING-INCOMPAT Alarm, on page 97
- Provisioning in Progress Alarm, on page 98
- RACK-OBFL-ERROR, on page 98
- RDI Alarm, on page 99
- REMOTE-FAULT Alarm, on page 99
- REMOTE-DEG-SER Alarm, on page 100
- RUNNING FANS AT MAX SPEED Alarm, on page 100
- SIGLOSS Alarm, on page 101
- SQUELCHED Alarm, on page 101
- SYNCLOSS Alarm, on page 101
- TIM, on page 102
- UNC-WORD Alarm, on page 102
- USB\_OC\_1, on page 103
- USB\_OC\_0, on page 104
- VOLTAGE Alarm, on page 104
- WVL-OUT-OF-LOCK Alarm, on page 104
- XGE-FLASH-ERROR, on page 105
- NOT-OPERATIONAL-PRIMITIVE-SEQUENCE, on page 105
- Chassis-ACT2LITE-Failure, on page 106
- CPU-FPGA-Image-Corruption, on page 106
- DP-Device-SEU-Error, on page 107
- MB-SSD-Temperature-High, on page 107

## XGE\_EEPROM\_ERROR

Default Severity: Major (MJ), Service-Affecting (SA))

Logical Object: SC

XGE\_EEPROM\_ERROR is raised when system detects the XGE EEPROM corruption.

### Clear the XGE\_EEPROM\_ERROR Alarm

#### Procedure

---

This alarm is cleared after the XGE EEPROM corruption is cleared.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## AVST-Failure Alarm

Default Severity: Major (MJ), Non-Service-Affecting (NSA)

Logical Object: LC

An AVST-Failure alarm is raised when the FPGA configuration fails on the line card inserted on any port from 0 to 13.

## Clear the AVST-FAILURE Alarm

Copy the **Datapath FPGA** file to the /emmedata/fpd location for the line card.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## BH-CARD-NOT-SEATED

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: LC

The BH-CARD-NOT-SEATED alarm is raised when the line card is not inserted completely into the chassis.

## Clear the BH-CARD-NOT-SEATED Alarm

### Procedure

This alarm is cleared when the line card is reinserted properly into the chassis.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## BH-CARD-POWER-OFF-STATUS

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: LC

The BH-CARD-POWER-OFF-STATUS alarm is raised in the following conditions: a. When you perform a line card shut operation b. When the line card fails to get the power allocation due to power budget.

## Clear the BH-CARD-POWER-OFF-STATUS Alarm

### Procedure

---

This alarm is cleared when line card is reloaded, OIR of the line card, or if the line card is successful in getting the power allocation.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## BH-CARD-PWR-ON-TIMEOUT

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: LC

The BH-CARD-PWR-ON-TIMEOUT alarm is raised if there is a delay in getting the PWR\_ON request from the shelf\_mgr.

## Clear the BH-CARD-PWR-ON-TIMEOUT Alarm

### Procedure

---

This alarm is cleared immediately after the PWR\_ON request is received from the shelf\_mgr.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## BH-CPU-CARD-NOT-SEATED

Default Severity: Critical(CR), Service-Affecting (SA)

Logical Object: RP

The BH-CPU-CARD-NOT-SEATED alarm is raised when the CPU card is not inserted completely into the chassis.

**Procedure**

---

This alarm is cleared when the CPU card is reinserted properly by removing it and reinserting it into the chassis.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## BH-INVALID-CARD-SLOT

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: LC

The BH-INVALID-CARD-SLOT alarm is raised when the line card EEPROM is corrupted or when the line card fails to connect within the timeout period of a maximum of two minutes.

## Clear the BH-INVALID-CARD-SLOT Alarm

**Procedure**

---

This alarm is cleared when the line card is inserted with the proper EEPROM.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## BIOS-IMAGE-CORRUPTION

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: RP

The BIOS-IMAGE-CORRUPTION alarm is raised when the BIOS image is corrupted and system is booted with the Golden image.

## Clear the BIOS-IMAGE-CORRUPTION Alarm

### Procedure

---

This alarm is cleared after the BIOS corruption is corrected and reloaded.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## BP\_FPGA-SEU-UNCORRECTED-ERROR

Default Severity: Major (MJ), Service-Affecting (SA))

Logical Object: SC

The BP\_FPGA-SEU-UNCORRECTED-ERROR alarm is raised when the BP detects the corruption of the FPGA.

## Clear the BP\_FPGA-SEU-UNCORRECTED-ERROR Alarm

### Procedure

---

This alarm is cleared when the hardware corrects the FPGA corruption.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## BP-FPGA-ERROR

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: SC

The BP-FPGA-ERROR alarm is raised when the BP FPGA SPI flash is not accessible.

## Clear the BP-FPGA-ERROR Alarm

### Procedure

---

This alarm is cleared when the BP FPGA SPI Flash error is corrected.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## CD Alarm

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: TRUNK

The Chromatic Dispersion (CD) alarm is raised when the detected chromatic dispersion value is above or below the configured threshold values.

## Clear the CD Alarm

### Procedure

Configure threshold value within range if CD value is not within the threshold range.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## CPU-FPGA-PCIE-ERROR

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: RP

The CPU-FPGA-PCIE-ERROR alarm is raised when the device goes out of the PCIe tree.

## Clear the CPU-FPGA-PCIE-ERROR Alarm

### Procedure

This alarm is cleared when the device comes back to the PCIe tree.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

# CPU-FLASH-0-ERROR

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: RP

The CPU-FLASH-0-ERROR alarm is raised when the BIOS upgrade flash is not accessible.

## Clear the CPU-FLASH-0-ERROR Alarm

### Procedure

---

This alarm is cleared when the BIOS upgrade flash access is restored.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

# CPU-FLASH-1-ERROR

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: RP

The CPU-FLASH-1-ERROR alarm is raised when BIOS primary is not accessible.

## Clear the CPU-FLASH-1-ERROR Alarm

### Procedure

---

This alarm is cleared when the BIOS primary flash access is restored.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

# CPU\_SSD\_ATA-ERRORS Alarm

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: LC

The CPU\_SSD\_ATA-ERRORS alarm is raised when the CPU Solid State Disk (SSD) has ATA errors.

## Clear the CPU\_SSD\_ATA-ERRORS Alarm

### Procedure

The CPU\_SSD\_ATA-ERRORS alarm is cleared when the CPU SSD is replaced.

If the alarm does not clear, log into the Technical Support Website at  
<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## CPU\_SSD-TEMPERATURE\_HIGH Alarm

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: LC

The CPU\_SSD-TEMPERATURE\_HIGH alarm is raised when the CPU SSD temperature is high.

## Clear the CPU\_SSD-TEMPERATURE\_HIGH Alarm

### Procedure

The CPU\_SSD-TEMPERATURE\_HIGH alarm is cleared when the CPU SSD temperature returns to the normal range.

If the alarm does not clear, log into the Technical Support Website at  
<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## CRYPTO\_HW\_FAILURE

Default Severity: Critical (CR) , Service-Affecting (SA)

Logical Object: Shelf

The CRYPTO\_HW\_FAILURE alarm is raised whenever any one of the line card port related KAT tests fail and the card is locked that prevents any card configurations.

## Clear the CRYPTO\_HW\_FAILURE Alarm

### Procedure

If the line card is locked and in failed state due to KAT errors, power-cycle the line card to restart the KAT process again. If it is successful, the system continues its regular operations else contact TAC for further assistance.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## CRYPTO-INDEX-MISMATCH

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: OTN

The CRYPTO-INDEX-MISMATCH alarm is raised when the AN# of Rx on the near end node does not match the AN# of Tx on the far end node, or

the AN# of Tx on the near end node does not match with the AN# of Rx on the far end node.



**Note** The CRYPTO-INDEX-MISMATCH alarm is interchangeably known as OTN-Sec-Association-Mismatch alarm.

## Clear the CRYPTO-INDEX-MISMATCH Alarm

### Procedure

The alarm is cleared when the index AN numbers match with the peer node.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## CRYPTO-KEY-EXPIRED

Default Severity: Critical (CR) , Service-Affecting (SA)

Logical Object: OTN

## Clear the CRYPTO-KEY-EXPIRED Alarm

### Procedure

The alarm is cleared after the new sak key is made available.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## DISASTER-RECOVERY-DISABLED Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: SC

The **Disaster recovery is disabled due to corrupted ISO** alarm is raised when the backup ISO image is not properly backed up and is corrupted.

## Clear the DISASTER-RECOVERY-DISABLED Alarm

To clear the alarm, log in to the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## DATAPATH-DEV-FAILURE Alarm

Default Severity: Major (MJ)

Logical Object: LC

The DATAPATH-DEV-FAILURE alarm is raised when the datapath FPGA fails to configure on the line card inserted, which will impact ports from 0 - 13.

## Clear the DATAPATH-DEV-FAILURE Alarm

Reload the line card.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## DGD Alarm

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: TRUNK

The Differential Group Delay (DGD) alarm is raised when the value of the differential group delay read by the pluggable port module exceeds the configured threshold value.

## Clear the DGD Alarm

### Procedure

---

Configure the threshold value within range if DGD value is not within the threshold range.

If the alarm does not clear, log into the Technical Support Website at  
<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## EQUIPMENT\_FAILURE

Default Severity: Major/Minor (MJ/MI), Service-Affecting (SA) / Non Service-Affecting(NSA)

Logical Object: LC

The EQUIPMENT\_FAILURE alarm is raised when an optical module, PLL device, CDR device, line card RAM device, line card, FPGA, or line card disk has failed.

## Clear the EQUIPMENT\_FAILURE Alarm

### Procedure

---

This alarm is cleared when the failed device is recovers.

If the alarm does not clear, log into the Technical Support Website at  
<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## EQUIPMENT-FAILURE Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object:

## Clear the EQUIPMENT-FAILURE Alarm

The EQUIPMENT-FAILURE alarm is raised because of one of these reasons:

- When the system fails to detect equipment on IO port 12.
- When the system fails to detect equipment on IO port 13.
- When a software sequence failure occurs on any port from 0 - 13, and it fails to turn on the motherboard successfully.

## Clear the EQUIPMENT-FAILURE Alarm

Reload the line card.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## FAN FAIL Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: ENVMON

The FAN FAIL alarm is raised on the NCS 1004 when one of the three fans fail. When any fan fails, the temperature of the NCS 1004 can rise above its normal operating range. This condition can trigger the TEMPERATURE alarm.

## Clear the FAN FAIL Alarm

### Procedure

---

Verify that a fan is correctly inserted. The fan should run immediately when correctly inserted.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## FAN-POWER-ERROR

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: Environ

The FAN-POWER-ERROR alarm is raised when POWER to FT has failed.

## Clear the FAN-POWER-ERROR Alarm

### Procedure

---

This alarm is cleared when the power failure is recovered or OIR of the FT.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## FAN SPEED SENSOR 0: OUT OF TOLERANCE FAULT Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: Environ

The FAN SPEED SENSOR 0: OUT OF TOLERANCE FAULT alarm is raised when one or more fans in the fan tray are faulty.

## Clear the FAN SPEED SENSOR 0: OUT OF TOLERANCE FAULT Alarm

### Procedure

---

Replace the fans in the chassis.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## FAN-TRAY-REMOVAL Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: Environ

The FAN-TRAY-REMOVAL alarm is raised on the NCS 1004 when all the fan trays are removed from the chassis.

## Clear the FAN-TRAY-REMOVAL Alarm

### Procedure

---

Insert the fan trays into the chassis.

**Flexo-LOF Alarm**

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## Flexo-LOF Alarm

Default Severity: Critical

Logical Object: Trunk

Flexo LOF alarm is raised when loss of alignment is detected on the Flexo frame for more than 3ms.

## Clear the Flexo-LOF Alarm

### Procedure

---

Identify and correct the underlying cause of mis-alignment. The Flexo LOF (Loss of Frame) alarm is cleared when good alignment is detected on the Flexo frame for more than 3ms.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## Flexo-LOM Alarm

Default Severity: Critical

Logical Object: Trunk

Flexo LOM (Loss of Multi-Frame) is raised when loss of multi-frame alignment is detected on the Flexo multi-frame for more than 10ms

## Clear the Flexo-LOM Alarm

### Procedure

---

Identify and correct the underlying cause of mis-alignment. The Flexo LOM alarm is cleared when good multi-frame alignment is detected on the Flexo multi-frame.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## Flexo MM Alarm

Default Severity: Critical

Logical Object: Trunk

The Flexo MM alarm is raised when the received Flexo Map is not equal to the expected Flexo Map.

## Clear the Flexo-MM Alarm

### Procedure

---

The Flexo-MM alarm is cleared when the received Flexo MAP is equal to the expected Flexo MAP. Ensure that the IID programmed on the remote trunk and the local trunk ports match.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## GIDM Alarm

Default Severity: Critical

Logical Object: Trunk

The GIDM (Group ID Mismatch) alarm is raised when the received GID is not equal to the expected GID.

## Clear the GIDM Alarm

### Procedure

---

The GIDM alarm is cleared when the received GID is equal to the expected GID on all the flexo group members. Ensure that the GID programmed on the remote trunk and local trunk ports match.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## FPD IN NEED UPGD Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: ANY

## Clear the FPD IN NEED UPGD Alarm

The FPD IN NEED UPGD alarm is raised when the FPD image is not aligned with the available package version.

## Clear the FPD IN NEED UPGD Alarm

### Procedure

---

Upgrade the respective FPD with the **upgrade hw-module location 0/x fpd y** command.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## FPD Infra Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: ANY

The FPD Infra alarm is raised when LC\_CPU\_MOD\_FW is corrupt and the system is booted with golden copy.

## Clear the FPD Infra Alarm

### Procedure

---

You must do FPD upgrade to clear the alarm.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## HIBER Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: CLIENT

The High Bit Error Rate (HIBER) alarm is raised when the client and trunk ports receive 16 or more invalid sync-headers in 125 microseconds.

## Clear the HIBER Alarm

### Procedure

---

**Step 1** Ensure the card port does not receive a high bit error rate.

**Step 2** Clean the optical connectors.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## HI-SER Alarm

Default Severity: Major

Logical Object: Client

The High Symbol Error Rate alarm is raised when 5560 or more errored FEC symbols are present in 8000 codewords.

## Clear the HI-SER Alarm

### Procedure

---

Identify the cause of high FEC errors and clear them.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## HI-LASERBIAS Alarm

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: PPM

The HI-LASERBIAS alarm is raised when the physical pluggable port laser detects a laser bias value beyond the configured high threshold.

**Procedure**

Configure the threshold value within range if high laser bias threshold value is not within the threshold range.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## HI-RXPOWER Alarm

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: PPM

The HI-RXPOWER alarm occurs on the client optics controller when the measured individual lane optical signal power of the received signal exceeds the default or user-defined threshold. The HI-RXPOWER alarm occurs on the trunk optics controller when the total optical signal power of the received signal exceeds the default or user-defined threshold.

## Clear the HI-RXPOWER Alarm

**Procedure**

Configure the high receive power threshold value in range. If the value is within the range of the high receive power threshold, physically verify, that the optical input power is overcoming the expected power threshold using a standard power meter.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## HI-TXPOWER Alarm

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: PPM

The HI-TXPOWER alarm occurs on the client optics controller when the measured individual lane optical signal power of the transmitted signal exceeds the default or user-defined threshold. The HI-TXPOWER alarm occurs on the trunk optics controller when the total optical signal power of the transmitted signal exceeds the default or user-defined threshold.

## Clear the HI-TXPOWER Alarm

### Procedure

---

Configure the high transmit power threshold in range. If the value is within the range of the high transmit power threshold, physically verify, that the optical output power is overcoming the expected power threshold using a standard power meter.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## IMPROPRMVL Alarm

Default Severity: Critical(CR), Service affecting (SA)

Logical Object: LC

The IMPROPRMVL Alarm is raised when the configured line card is physically removed from the chassis.

## Clear the IMPROPRMVL Alarm

### Procedure

---

The IMPROPRMVL Alarm is cleared when the line card is re-inserted into the chassis.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## IMPROPRMVL Alarm

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: PPM

The Improper Removal (IMPROPRMVL) alarm is raised when a physical pluggable is not present on a service-provisioned port.

## Clear the IMPROPRMVL Alarm

### Procedure

---

Insert the appropriate QSFP.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## INSTALL IN PROGRESS Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: Environ

The INSTALL IN PROGRESS alarm is raised when the install operation is in progress or if an install commit is not performed after activating a new image or package.

## Clear the INSTALL IN PROGRESS Alarm

### Procedure

---

**Step 1** Wait until the install operation is over.

**Step 2** Perform the "install commit" operation after the "install activate" operation.

If the alarm does not clear, log into the Technical Support Website at

<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## BP-FPGA-PCIE-ERROR

Default Severity: Major (MJ), Service-Affecting (SA))

Logical Object: SC

The BP-FPGA-PCIE-ERROR alarm is raised when the BP device goes out of the PCIe tree.

## Clear the BP-FPGA-PCIE-ERROR Alarm

### Procedure

This alarm is cleared when the BP device comes back to the PCIe tree.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## BP-FPGA-IMAGE-CORRUPTION

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: SC

The BP-FPGA-IMAGE-CORRUPTION alarm is raised when the system detects the BP corruption and boots with the Golden image.

## Clear the BP-FPGA-IMAGE-CORRUPTION Alarm

### Procedure

This alarm is cleared after the BP corruption is corrected and reloaded.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## BP\_FPGA\_XR\_EP-FPGA-PCIE-ERROR

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: SC

The BP\_FPGA\_XR\_EP-FPGA-PCIE-ERROR alarm is raised when the BP device XR end point goes out of the PCIe tree.

## Clear the BP\_FPGA\_XR\_EP-FPGA-PCIE-ERROR Alarm

### Procedure

This alarm is cleared when BP device XR end point comes back to the PCIe tree.

**LCMODE-CONFIG-CHANGED** Alarm

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## LCMODE-CONFIG-CHANGED Alarm

Default Severity: Not Alarmed (NA), Non-Service-Affecting (NSA)

Logical Object: EQPT

The LCMODE-CONFIG-CHANGED alarm is raised when the LC Mode configuration of the line card is changed.



**Note** This alarm is specific to OTN-XP line card on NCS 1004. It is not supported for 1.2T card.

### Clear the LCMODE-CONFIG-CHANGED Alarm

Delete the existing configuration on the line card and reload the card.

## LCMODE-CONFIG-INVALID Alarm

Default Severity: Not Alarmed (NA), Non-Service-Affecting (NSA)

Logical Object: EQPT

The LCMODE-CONFIG-INVALID alarm is raised when the LC-MODE configuration is invalid for the chosen line card.



**Note** This alarm is specific to OTN-XP line card on NCS 1004. It is not supported for 1.2T card.

### Clear the LCMODE-CONFIG-INVALID Alarm

Configure the line card with a configuration that is supported on the card.

## LCMODE-NOT-CONFIG Alarm

Default Severity: Not Alarmed (NA), Non-Service-Affecting (NSA)

Logical Object: EQPT

The LCMODE-NOT-CONFIG alarm is raised when the LC-MODE configuration is not successfully configured for the chosen line card.



**Note** This alarm is specific to OTN-XP Line card on NCS 1004. It is not supported for 1.2T card.

## Clear the LCMODE-NOT-CONFIG Alarm

Configure the line card with a configuration that is supported on the card.

## LC\_BOOT\_TIMEOUT Alarm

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: LC

The LC\_BOOT\_TIMEOUT Alarm is raised when the line card fails to boot in the expected amount of time or when the line card modules do not boot correctly.

## Clear the LC\_BOOT\_TIMEOUT Alarm

### Procedure

The LC\_BOOT\_TIMEOUT alarm is cleared when the line card successfully reboots.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## LC-CPU-IMAGE-CORRUPTION

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: LC

The LC-CPU-IMAGE-CORRUPTION alarm is raised when the line card is booted with the Golden image.

## Clear the LC-CPU-IMAGE-CORRUPTION Alarm

### Procedure

This alarm is cleared when the line card boots with a proper CPU image.

**LC-DP-IMAGE-CORRUPTION Alarm**

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## **LC-DP-IMAGE-CORRUPTION Alarm**

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: EQPT

The LC-DP-IMAGE-CORRUPTION alarm is raised when the Datapath FPGA bootup with back up or golden image due to corruption of primary image.

### **Clear the LC-DP-IMAGE-CORRUPTION Alarm**

Perform a force upgrade of DP FPD to load proper image to the line card.

If the alarm does not clear, log into the Technical Support Website at

<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## **TEMPERATURE Alarm**

Default Severity: Critical (CR) , Service-Affecting (SA)

Logical Object: Environ

The TEMPERATURE alarm is raised when the temperature is not within the operating range.

### **Clear the TEMPERATURE Alarm**

#### **Procedure**

---

This alarm clears when the temperature falls within the operating range.

If the alarm does not clear, log into the Technical Support Website at

<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## **LC-DISCONNECTED**

Default Severity: Major (MJ)

Logical Object: LC

The LC-DISCONNECTED alarm is raised in IOS XR if the Line Card Application (LCAPP) crashes or restarts.

## Clear the LC- DISCONNECTED Alarm

### Procedure

---

The LC-DISCONNECTED alarm is raised until the LCAPP connects back to the line card. The administrator must log in to the line card and verify if the LCAPP is running fine.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## LC-OFFLINE-ERROR

Default Severity: Not Alarmed (NA), Non Service-Affecting (NSA)

Logical Object: LC

The LC-OFFLINE-ERROR alarm is raised when the LC app is disconnected due to lcapp crash, restart, or warm reload of lcapp.

## Clear the LC-OFFLINE-ERROR Alarm

### Procedure

---

This alarm is cleared if the LC app connects within one minute.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## LC-SUDI-CERT-VERIFICATION-FAILURE Alarm

Default Severity: Major (MJ), Non-Service-Affecting (NSA)

Logical Object: LC

The LC-SUDI-CERT-VERIFICATION-FAILURE alarm is raised when the SUDI certificates are not programmed.

## Clear the LC-SUDI-CERT-VERIFICATION-FAILURE Alarm

To clear the alarm, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## LO-RXPOWER Alarm

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: PPM

The LO-RXPOWER alarm is raised on the client or trunk optics controller when the measured individual lane optical signal power of the received signal falls below the default or user-defined threshold.

## Clear the LO-RXPOWER Alarm

### Procedure

---

**Step 1** Configure low receive power threshold in range.

**Step 2** or

**Step 3** Verify that the trunk-rx port is cabled correctly, and clean the fiber connecting the faulty TXP/MXP card to the drop port of the DWDM card.

If the alarm does not clear, log into the Technical Support Website at  
<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## LO-TXPOWER Alarm

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: PPM

The LO-TXPOWER alarm is raised on the client or trunk optics controller when the measured individual lane optical signal power of the transmitted signal falls below the default or user-defined threshold.

## Clear the LO-TXPOWER Alarm

### Procedure

---

Configure low transmit power threshold in range.

If the alarm does not clear, log into the Technical Support Website at  
<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## LOCAL-FAULT Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: CLIENT

The LOCAL-FAULT alarm is raised when a local fault character sequence is received in the incoming MAC stream.

### Clear the LOCAL-FAULT Alarm

#### Procedure

---

Verify that the port receives proper MAC streams from the far-end router or switch.

If the alarm does not clear, log into the Technical Support Website at  
<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## LOCAL-DEG-SER Alarm

Default Severity: Major

Logical Object: Client

The Local FEC DEG-SER (Degraded SER) alarm is received from remote end when it detects excessive FEC errors on the receiver side or when it sees AIS on the mapper ODU.

### Clear the LOCAL-DEG-SER Alarm

#### Procedure

---

This alarm is cleared when you clear the errors at the remote end.

If the alarm does not clear, log into the Technical Support Website at  
<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## LOM Alarm

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: TRUNK

**Clear the LOM Alarm**

The Loss of Multiframe (LOM) alarm is raised when the MFAS overhead field is invalid for more than five frames and persists for more than three milliseconds.

**Clear the LOM Alarm****Procedure**

- 
- Step 1** If the bit error rate (BER) threshold is correct and at the expected level, use an optical test set to measure the power level of the line to ensure it is within guidelines.
  - Step 2** If the optical power level is good, verify that optical receive levels are within the acceptable range.
  - Step 3** If the receive levels are good, clean the fibers at both ends according to site practice.
  - Step 4** If the condition does not clear, verify that a single-mode fiber is used.
  - Step 5** If the fiber is of the correct type, verify that a single-mode laser is used at the far-end node.
  - Step 6** Clean the fiber connectors at both ends for a signal degrade according to site practice.
  - Step 7** Verify that a single-mode laser is used at the far end.
  - Step 8** If the problem does not clear, the transmitter at the other end of the optical line could be failing and requires replacement.
- If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).
- 

**LOS Alarm**

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: CLIENT

The Equipment Low Receive Power alarm is an indicator for the received optical signal power. LOS occurs when the measured optical power of the received signal falls below the threshold value.

In non-Optical Signal to Noise Ratio (OSNR) loaded links, the RX power threshold for LOS condition (as LOS is expected before the actual traffic) goes down approximately to -23 dBm.

**Clear the LOS Alarm****Procedure**

- 
- Step 1** Verify that the client port is configured with the proper wavelength.
  - Step 2** Verify whether there is a loss of received optical power. Compare the actual power levels with the expected power range.
  - Step 3** Verify the fiber continuity to the port of NCS 1004 and fix the fiber connection.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## MB\_SSD\_ATA-ERRORS Alarm

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: LC

The MB\_SSD\_ATA-ERRORS alarm is raised when the chassis SSD has ATA errors.

## Clear the MB\_SSD\_ATA-ERRORS Alarm

### Procedure

The MB\_SSD\_ATA-ERRORS alarm is cleared when the chassis SSD is replaced.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## MEA Alarm

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: PPM

The Mismatch Equipment Attributes (MEA) alarm for the PPM or QSFP is raised on a pluggable port when there is a mismatch in the configured client data rate and the supported QSFP physical data rate.

The Line-card slot is capable of holding different type of cards supported by the platform. The Mismatch Equipment Attributes (MEA) alarm for Line-card is raised, when you replace the current type of card with a different type of card in the working slot.

## Clear the MEA Alarm

### Procedure

**Step 1** Verify the supported physical data rate of the QSFP on NCS 1004 using the **show inventory** command.

**Step 2** Verify the configured client data rate on NCS 1004 using the **show hw-module slice** command.

**Step 3** If the above values do not match, insert the appropriate QSFP pluggable or configure the required client data rate.

**NODE-OBFL-ERROR**

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

**Note** When you mistakenly insert a different card in a previously configured slot, the solution is to have a new configuration to couple specific slot with card type. The MEA alarm is raised , when the card type inserted is different than the configuration.

The Card-type keywords to be fetched from supported LCs for a given platform.

---

## **NODE-OBFL-ERROR**

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: RP

The NODE-OBFL-ERROR alarm is raised when there is an OBFL read or write failure for the NODE scope.

### **Clear the NODE-OBFL-ERROR Alarm**

#### **Procedure**

---

This alarm is cleared when the OBFL flash access is restored.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## **ODU-AIS Alarm**

Default Severity: Not Reported (NR), Non-Service-Affecting (NSA)

Logical Object: TRUNK-ODU

The ODU-AIS alarm is raised on ODU controllers when there is an alarm on the upstream data.

### **Clear the ODU-AIS Alarm**

#### **Procedure**

---

The ODU-AIS alarm clears when the alarm clears on the upstream data.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## ODU-BDI Alarm

Default Severity: Not Reported (NR), Non-Service-Affecting (NSA)

Logical Object: TRUNK-ODU

The Optical Data Unit Backward Defect Indication (ODU BDI) alarm is raised when there is a path termination error in the upstream data. This error is read as a BDI bit in the path monitoring area of the ODU controller.

### Clear the ODU-BDI Alarm

#### Procedure

The ODU-BDI alarm clears when the path termination error clears on the upstream data.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## ODU-CSF Alarm

Default Severity: Not Alarmed (NA), Non-Service-Affecting (NSA)

Logical Object: TRUNK-ODU

The ODU-CSF alarm is raised when there is a failure of the client signal.

### Clear the ODU-CSF Alarm

#### Procedure

This alarm clears when no alarm exists on the client port.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## ODU-IAE/BIAE

Default Severity: Not Reported (NR), Non-Service-Affecting (NSA)

Logical Object: TRUNK-ODU

The ODU-IAE/BIAE alarm is raised when there are incoming alignment errors on the upstream data.

## Clear the ODU-IAE/BIAE Alarm

### Procedure

---

This alarm is cleared when the alignment errors are cleared on the upstream data.

If the alarm does not clear, log into the Technical Support Website at  
<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## ODU-LCK

Default Severity: Not Reported (NR), Non-Service-Affecting (NSA)

Logical Object: TRUNK-ODU

The Locked (ODU-LCK) signal is raised when an OTN interface is administratively locked out and not available to carry traffic.

## Clear the ODU-LCK Alarm

### Procedure

---

This alarm is cleared when the administrator releases the lock out on the OTN interface.

If the alarm does not clear, log into the Technical Support Website at  
<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## ODU-OCI

Default Severity: Not Reported (NR), Non-Service-Affecting (NSA)

Logical Object: TRUNK-ODU

The Open Connection Indication (ODU-OCI) alarm is raised when there is no connection between the client and trunk ports.

## Clear the ODU-OCI Alarm

### Procedure

This alarm is cleared when the connection is created between the client and trunk ports.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## OSNR Alarm

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: TRUNK

The Optical Signal Noise Ratio (OSNR) alarm occurs when the measured OSNR falls below the threshold.

## Clear the OSNR Alarm

### Procedure

**Step 1** Verify the value of the minimum acceptable OSNR value of NCS 1004 using the **show controller optics R/S/I/P** command.

**Step 2** If the value is not within the OSNR threshold range, configure the minimum acceptable OSNR value using the **controller optics R/S/I/P osnr-low-threshold** command in the configuration mode. The range is 0 to 4000 (in units of 0.1db).

**Step 3** If the value is within the range of the minimum acceptable OSNR, contact TAC .

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## OTNSEC-LOCALLY-SECURED

Default Severity: Not Alarmed (NA), Non Service-Affecting (NSA)

Logical Object: Software

The OTNSEC-LOCALLY-SECURED alarm is raised when the IKE session goes down and the OTNsec session is locally secured.

**Procedure**

---

This alarm is cleared when the respective IKE session is up.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## OTUK-AIS

Default Severity: Not Reported (NR), Non-Service-Affecting (NSA)

Logical Object: TRUNK

An Alarm Indication Signal (AIS) signal communicates to the receiving node when the transmit node does not send a valid signal. AIS is not an error. The OTUK-AIS alarm is raised by the receiving node on each input when it detects the AIS instead of an actual signal.

## Clear the OTUK-AIS Alarm

**Procedure**

---

This alarm will be cleared when the signal recovers.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## OTUK-BDI Alarm

Default Severity: Not Reported (NR), Non-Service-Affecting (NSA)

Logical Object: TRUNK

The Optical Transport Unit Backward Defect Indication (OTUK BDI) alarm is raised when there is a path termination error in the upstream data. This error is read as a BDI bit in the path monitoring area of the digital wrapper overhead.

## Clear the OTUK-BDI Alarm

### Procedure

---

- Step 1** At the near-end node, use site practices to clean trunk transmitting fiber toward the far-end node and the client receiving fiber.
- Step 2** At the far-end node, determine whether any OTUK-AIS condition, is present on the trunk rx port. If yes, inspect the trunk rx side on the near-end card (the one alarmed for OTUK-BDI) because the AIS bit must be inserted in that section.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## OTUK-LOF Alarm

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: TRUNK

The Optical Transport Unit Loss of Frame (OTUK-LOF) alarm is raised when a frame loss is detected by an invalid frame alignment in the received frames. This alarm indicates that the card has lost frame delineation on the input data. Loss of frame occurs when the optical transport unit overhead frame alignment (FAS) area is invalid for more than five frames and that the error persists more than three milliseconds.

This alarm is also raised when the FEC settings on the trunk ports of the source and destination cards are different.

## Clear the OTUK-LOF Alarm

### Procedure

---

Verify whether the FEC settings on the trunk ports of the source and destination cards are the same.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## OTUK-SD Alarm

Default Severity: Not Alarmed (NA), Non Service-Affecting (NSA)

Logical Object: TRUNK

## Clear the OTUK-SD Alarm

### Procedure

Identify the cause for poor quality signal and resolve. This alarm typically indicates poor incoming signal strength due to bad fiber or dirt in the pluggable or fiber.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## OTUK-SF Alarm

Default Severity: Not Alarmed (NA), Non Service-Affecting (NSA)

Logical Object: TRUNK

The Optical Transport Unit Signal Fail (OTUK-SF) is raised on hardware and software when LOS, LOF, and LOM alarms exist.

## Clear the OTUK-SF Alarm

### Procedure

The alarm is cleared when the LOS, LOF, or LOM alarms are cleared.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## OTUK-TIM Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: TRUNK

The Trail Trace Identifier Mismatch (OTUK-TIM) alarm is raised when the expected TTI string does not match the received TTI string.

## Clear the OTUK-TIM Alarm

### Procedure

---

Identify the cause for different expected and received TTI strings and resolve. The TIM mismatch can be caused due to mismatch in fiber connections.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## OTN-XP-DP-FPD-PKG-MISSING Alarm

Default Severity: Not Alarmed (NA), Non-Service-Affecting (NSA)

Logical Object: EQPT

The OTN-XP-DP-FPD-PKG-MISSING alarm is raised when the user tries to update DP FPD without installing the OTN-XP-DP-FPD software package.

## Clear the OTN-XP-DP-FPD-PKG-MISSING Alarm

This alarm is cleared when you download and install the OTN-XP-DP-FPD package.

## PEX\_SWITCH\_ACCESS\_FAILURE Alarm

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: LC

The PEX\_SWITCH\_ACCESS\_FAILURE Alarm is raised when the Chassis PEX PCIe switch is not accessible.

## Clear the PEX\_SWITCH\_ACCESS\_FAILURE Alarm

### Procedure

---

The PEX\_SWITCH\_ACCESS\_FAILURE Alarm is cleared when the PEX PCIe switch is accessible again. The chassis needs to be reloaded manually if it does not reload on its own in a few minutes.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: PEM

The POWER MODULE OUTPUT DISABLED alarm is raised on the NCS 1004 when the power supply is disabled on the active PEM.

## Clear the POWER MODULE OUTPUT DISABLED Alarm

### Procedure

---

Enable the power supply.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## POWER-MODULE-REDUNDANCY-LOST Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: PEM

The POWER-MODULE-REDUNDANCY-LOST alarm is raised on the NCS 1004 under one of the following conditions.

- When power supply to PSU is removed.
- When PEM is removed from NCS 1004.

## Clear the POWER-MODULE-REDUNDANCY-LOST Alarm

### Procedure

---

This alarm clears when the user re-inserts the power supply or when the user connects the power cable again.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

# PPM FAIL Alarm

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: PPM

The PPM FAIL alarm is raised on the pluggable when a fault is detected in the PPM and the pluggable cannot be accessed.

## Clear the PPM FAIL Alarm

### Procedure

---

Replace the pluggable.

If the alarm does not clear, log into the Technical Support Website at  
<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

# Provisioning Failed Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: LC

The Provisioning Failed alarm is raised when invalid configuration is configured on the controller; For example, configuring an invalid CD-min value on the optics controller.

## Clear the Provisioning Failed Alarm

### Procedure

---

**Step 1** Verify whether the provisioning configurations are supported for the line card.

**Step 2** Change it to supported configurations for the line card.

If the alarm does not clear, log into the Technical Support Website at  
<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

# PROVISIONING-INCOMPAT Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

**Clear the PROVISIONING-INCOMPAT Alarm**

Logical Object: LC

The PROVISIONING-INCOMPAT alarm is raised when you configure incompatible submarine parameters on 1.2T line card.

**Clear the PROVISIONING-INCOMPAT Alarm****Procedure**


---

The alarm is cleared only when valid submarine parameters are provided.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

**Provisioning in Progress Alarm**

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: LC

The Provisioning in Progress alarm is raised when the provisioning request is in progress on the line card or controller.

**Clear the Provisioning in Progress Alarm****Procedure**


---

**Step 1** Verify the status of the alarm using the following debug command:

```
RP/0/RP0/CPU0:ios#show hw-module location '<0/n>' mxponder
```

**Step 2** Wait till the status changes to **Provisioned**.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

**RACK-OBFL-ERROR**

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: SC

The RACK-OBFL-ERROR alarm is raised when there is an OBFL read or write failure for the RACK scope.

## Clear the RACK-OBFL-ERROR Alarm

### Procedure

---

This alarm is cleared when the OBFL flash access is restored.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## RDI Alarm

Default Severity: Critical

Logical Object: Trunk

The RDI is inserted by the remote trunk and indicates that the remote trunk detects a fault in the incoming signal.

## Clear the RDI Alarm

### Procedure

---

The RDI alarm is cleared when you identify and clear the fault on the remote trunk.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## REMOTE-FAULT Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: CLIENT

The REMOTE-FAULT alarm is raised on the NCS 1004 when a remote fault character sequence is received in the incoming MAC stream.

## Clear the REMOTE-FAULT Alarm

### Procedure

---

- Step 1** Verify and resolve the client port fault and remote fault errors on the remote or upstream node.

**REMOTE-DEG-SER Alarm**

- Step 2** Verify and resolve loss of signal synchronization error on the remote or upstream node.  
 If the alarm does not clear, log into the Technical Support Website at  
<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).
- 

## REMOTE-DEG-SER Alarm

Default Severity: Major

Logical Object: Client

The remote FEC DEG-SER (Degraded SER) alarm is received from the remote Router when it sees Local Degraded SER on the receiver side.

## Clear the REMOTE-DEG-SER Alarm

### Procedure

This alarm is cleared when you clear the errors at the remote end..

If the alarm does not clear, log into the Technical Support Website at  
<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## RUNNING FANS AT MAX SPEED Alarm

Default Severity: Critical (CR) , Service-Affecting (SA)

Logical Object: environ

The RUNNING FANS AT MAX SPEED alarm is raised when one or more line cards are missing or when one or more fans fail or are removed or when the temperature exceeds threshold values.

## Clear the RUNNING FANS AT MAX SPEED Alarm

### Procedure

- Step 1** Insert line card or filler card in all the slots.

- Step 2** Insert all the fan trays and ensure all are working.

If the alarm does not clear, log into the Technical Support Website at  
<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

# SIGLOSS Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: CLIENT

The Signal Loss on Data Interface (SIGLOSS) alarm is raised on the client-side QSFP when there is a loss of ethernet signal.

## Clear the SIGLOSS Alarm

### Procedure

---

**Step 1** Ensure that the port connection at the near end of the client peer router is operational.

**Step 2** Verify fiber continuity to the port.

If the alarm does not clear, log into the Technical Support Website at

<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

# SQUELCHED Alarm

Default Severity: Not Alarmed (NA), Non-Service-Affecting (NSA)

Logical Object: CLIENT

Laser-squelch is configured under the client controller. Laser-squelching occurs on a QSFP pluggable when all the four lanes operating in the 10GE client mode are turned off after the upstream receive facility has experienced a loss of signal such as LOS or LOF.

## Clear the SQUELCHED Alarm

### Procedure

---

This alarm will be cleared when optical alarms clear.

If the alarm does not clear, log into the Technical Support Website at

<http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

# SYNCLOSS Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

## Clear the SYNCLOSS Alarm

Logical Object: CLIENT

The Loss of Synchronization on Data Interface (SYNCLOSS) alarm is raised on the client and trunk ports when there is a loss of signal synchronization on the port. This alarm is demoted by the SIGLOSS alarm.

## Clear the SYNCLOSS Alarm

### Procedure

- 
- Step 1** Ensure that the data port connection at the near end of the ethernet link is operational.
  - Step 2** Verify the fiber continuity to the port. To do this, follow site practices.
  - Step 3** For 100 GE, verify that the FEC settings match between the router.  
If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).
- 

## TIM

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: CLIENT

The received trace identifier is different from the expected trace identifier. The optical fiber link is from the wrong source (misconnected). If the fiber connection is correct and as expected, then either the expected trace identifier that is configured on the local interface is incorrect, or the trace identifier that is configured on the remote interface is incorrect.

## Clear the TIM Alarm

### Procedure

- 
- Step 1** Check that the optical fiber link is coming from the correct source.
  - Step 2** Check and reconfigure the expected trace identifier.
  - Step 3** Check and reconfigure the trace identifier on the remote interface.  
If the alarm does not clear, log in to the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).
- 

## UNC-WORD Alarm

Default Severity: Not Reported (NR), Non-Service-Affecting (NSA)

Logical Object: TRUNK

The Uncorrected FEC Word (UNC-WORD) condition is raised when the FEC is unable to correct the frame.

## Clear the UNC-WORD Alarm

### Procedure

---

- Step 1** Ensure that the fiber connector for the card is completely plugged in.
  - Step 2** Ensure that the ports on the far end and near end nodes have the same port rates and FEC settings.
  - Step 3** If the BER threshold is correct and at the expected level, use an optical test set to measure the power level of the line to ensure it is within guidelines. For specific procedures to use the test set equipment, consult the manufacturer.
  - Step 4** If the optical power level is good, verify that the optical receive levels are within the acceptable range.
  - Step 5** If receive levels are good, clean the fibers at both ends.
  - Step 6** If the condition does not clear, verify that a single-mode fiber is used.
  - Step 7** Verify if the fiber is of single-mode type.
  - Step 8** Clean the fiber connectors at both ends for a signal degrade.  
If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).
- 

## USB\_OC\_1

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: RP

The USB\_OC\_1 alarm is raised when the over current is observed on USB1.

## Clear the USB\_OC\_1 Alarm

### Procedure

---

This alarm is cleared when the over current is removed for the USB.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## USB\_OC\_0

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: RP

The USB\_OC\_0 alarm is raised when the over current is observed on USB0.

### Clear the USB\_OC\_0 Alarm

#### Procedure

---

This alarm is cleared when the over current is removed for the USB.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## VOLTAGE Alarm

Default Severity: Critical (CR) , Service-Affecting (SA)

Logical Object: environ

The VOLTAGE alarm is raised on the NCS 1004 when the voltage is not within the operating range.

### Clear the VOLTAGE Alarm

#### Procedure

---

This alarm clears when the voltage falls within the operating range.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## WVL-OUT-OF-LOCK Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: TRUNK

The Wavelength Out of Lock (WVL-OUT-OF-LOCK) alarm is raised when the trunk port detects the optical input frequency to be out of range.

## Clear the WVL-OUT-OF-LOCK Alarm

### Procedure

---

**Step 1** Verify the wavelength configuration.

**Step 2** Verify whether the pluggable is inserted properly.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## XGE-FLASH-ERROR

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: SC

The XGE-FPGA-ERROR alarm is raised when the XGE FPGA SPI flash is not accessible.

## Clear the XGE-FLASH-ERROR Alarm

### Procedure

---

This alarm is cleared when the XGE FPGA SPI Flash error is corrected.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## NOT-OPERATIONAL-PRIMITIVE-SEQUENCE

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: FC CLIENT

The NOT-OPERATIONAL-PRIMITIVE-SEQUENCE (NOS) alarm is raised when a NOS sequence is received in the incoming FC stream.

## Clear the NOT-OPERATIONAL-PRIMITIVE-SEQUENCE Alarm

### Procedure

The NOT-OPERATIONAL-PRIMITIVE-SEQUENCE (NOS) alarm is raised until the sender stops sending NOS ordered set.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## Chassis-ACT2LITE-Failure

Default Severity: Major (MJ)

Logical Object: RP

The Chassis-act2lite-Failure alarm is raised when communication with chassis ACT2LITE fails.

## Clear the Chassis-ACT2LITE-Failure Alarm

### Procedure

To clear the alarm, check with Technical Support.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

## CPU- FPGA- Image-Corruption

Default Severity: Major (MJ)

Logical Object: RP

The CPU-FPGA-IMAGE-CORRUPTION alarm is raised when the system detects the CPU corruption and boots with the golden image.

## Clear the CPU-FPGA- Image-Corruption Alarm

### Procedure

This alarm is cleared after the CPU corruption is corrected and reloaded.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## DP-Device-SEU-Error

Default Severity: Critical (CR)

Logical Object: RP

The DP-Device-SEU-Error alarm is raised when the DP detects error in the Unit.

## Clear the DP-Device-SEU-Error Alarm

### Procedure

---

To clear the alarm, check with Technical Support.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## MB-SSD-Temperature-High

Default Severity: Major (MJ)

Logical Object: RP

The MB-SSD-TEMPERATURE-High alarm is raised when the Chassis SSD Temperature exceeds the threshold.

## Clear the MB-SSD-Temperature-High Alarm

### Procedure

---

This alarm gets cleared when the temperature falls within the operating range.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

---

## Clear the MB-SSD-Temperature-High Alarm