



Cisco Intrusion Prevention System CLI Configuration Guide for IPS 7.1

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

Text Part Number: OL-19892-01

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

Cisco Intrusion Prevention System CLI Configuration Guide for IPS 7.1
© 2011-2013 Cisco Systems, Inc. All rights reserved.



Preface xxxi

Contents xxxi

Audience xxxi

Organization xxxii

Conventions xxxiii

Related Documentation xxxiv

Obtaining Documentation, Using the Cisco Bug Search Tool, and Submitting a Service Request xxxv

CHAPTER 1

Getting Started 1-1

Introducing the IME 1-1

Advisory 1-2

Participating in the SensorBase Network 1-2

IME Home Pane 1-3

System Requirements 1-4

IME Demo Mode 1-7

Installing the IME and Migrating Data In to the IME 1-8

Creating and Changing the IME Password 1-9

Recovering the IME Password 1-10

Configuring General Options 1-11

Configuring the Data Archive 1-12

Configuring Email Setup 1-14

Configuring Email Notification 1-15

Configuring Reports 1-17

Installation Error 1-20

CHAPTER 2

Configuring Device Lists 2-1

Device List Pane 2-1

Device List Pane Field Definitions 2-2

Add and Edit Device List Dialog Boxes Field Definitions 2-3

Adding, Editing, and Deleting Devices 2-4

Starting, Stopping, and Displaying Device, Event, Health, and Global Correlation Connection Status	2-5
Using Tools for Devices	2-6

CHAPTER 3

Configuring Dashboards	3-1
Understanding Dashboards	3-1
Adding and Deleting Dashboards	3-1
IME Gadgets	3-2
Sensor Information Gadget	3-2
Sensor Health Gadget	3-3
Licensing Gadget	3-5
Interface Status Gadget	3-5
Global Correlation Reports Gadget	3-6
Global Correlation Health Gadget	3-7
Network Security Gadget	3-8
Top Applications Gadget	3-9
Memory & Load Gadget	3-10
RSS Feed Gadget	3-11
Top Attackers Gadget	3-11
Top Victims Gadget	3-12
Top Signatures Gadget	3-13
Attacks Over Time Gadget	3-13
Working With a Single Event for Individual Top Attacker and Victim IP Addresses	3-14
Working With a Single Event for a Top Signature	3-15
Configuring Filters	3-16
Manage Filter Rules Dialog Box Field Definitions	3-18
Add and Edit Filter Dialog Boxes Field Definitions	3-19

CHAPTER 4

Configuring RSS Feeds	4-1
Understanding RSS Feeds	4-1
Configuring RSS Feeds	4-1

CHAPTER 5

Using the Startup Wizard	5-1
Startup Wizard Introduction Window	5-1
Setting up the Sensor	5-2
Sensor Setup Window	5-2
Add and Edit ACL Entry Dialog Boxes	5-3
Configure Summertime Dialog Box	5-4

Configuring Sensor Settings	5-4
Configuring Interfaces	5-7
Interface Summary Window	5-7
Restore Defaults to an Interface Dialog Box	5-8
Traffic Inspection Mode Window	5-8
Interface Selection Window	5-9
Inline Interface Pair Window	5-9
Inline VLAN Pairs Window	5-9
Add and Edit Inline VLAN Pair Entry Dialog Boxes	5-10
Configuring Inline VLAN Pairs	5-10
Configuring Virtual Sensors	5-11
Virtual Sensors Window	5-11
Add Virtual Sensor Dialog Box	5-12
Adding a Virtual Sensor	5-13
Applying Signature Threat Profiles	5-14
Configuring Auto Update	5-16

CHAPTER 6
Setting Up the Sensor 6-1

Understanding Sensor Setup	6-1
Configuring Network Settings	6-1
Network Pane	6-2
Network Pane Field Definitions	6-2
Configuring Network Settings	6-3
Configuring Allowed Hosts/Networks	6-5
Allowed Hosts/Networks Pane	6-5
Allowed Hosts/Network Pane and Add and Edit Allowed Host Dialog Boxes Field Definitions	6-6
Configuring Allowed Hosts and Networks	6-6
Configuring Time	6-7
Time Pane	6-7
Time Pane Field Definitions	6-7
Configure Summertime Dialog Box Field Definitions	6-8
Configuring Time on the Sensor	6-9
Time Sources and the Sensor	6-10
Synchronizing IPS Module System Clocks with Parent Device System Clocks	6-11
Verifying the Sensor is Synchronized with the NTP Server	6-11
Correcting Time on the Sensor	6-12
Configuring NTP	6-12
Configuring a Cisco Router to be an NTP Server	6-13

Configuring the Sensor to Use an NTP Time Source	6-14
Manually Setting the System Clock	6-15
Clearing Events	6-16
Configuring Authentication	6-16
Understanding User Roles	6-17
Understanding the Service Account	6-18
The Service Account and RADIUS Authentication	6-18
RADIUS Authentication Functionality and Limitations	6-19
Authentication Pane	6-19
Authentication Pane Field Definitions	6-20
Add and Edit User Dialog Boxes Field Definitions	6-22
Adding, Editing, Deleting Users, and Creating Accounts	6-22
Locking User Accounts	6-25
Unlocking User Accounts	6-26

CHAPTER 7

Configuring Interfaces	7-1
Sensor Interfaces	7-1
Understanding Interfaces	7-1
Command and Control Interface	7-2
Sensing Interfaces	7-3
Interface Support	7-4
TCP Reset Interfaces	7-8
Understanding Alternate TCP Reset Interfaces	7-8
Designating the Alternate TCP Reset Interface	7-9
Hardware Bypass Mode	7-9
Hardware Bypass Card	7-10
Hardware Bypass Configuration Restrictions	7-10
Interface Configuration Restrictions	7-11
Understanding Interface Modes	7-13
Promiscuous Mode	7-14
IPv6, Switches, and Lack of VACL Capture	7-14
Inline Interface Mode	7-15
Inline VLAN Pair Mode	7-16
VLAN Groups Mode	7-17
Interface Configuration Summary	7-18
Configuring Interfaces	7-18
Interfaces Pane	7-18
Interfaces Pane Field Definitions	7-19
Enabling and Disabling Interfaces	7-20

Edit Interface Dialog Box Field Definitions	7-20
Editing Interfaces	7-21
Configuring Inline Interface Pairs	7-22
Interface Pairs Pane	7-22
Interface Pairs Pane Field Definitions	7-22
Add and Edit Interface Pair Dialog Boxes Field Definitions	7-22
Configuring Inline Interface Pairs	7-23
Configuring Inline VLAN Pairs	7-23
VLAN Pairs Pane	7-23
VLAN Pairs Pane Field Definitions	7-24
Add and Edit VLAN Pair Dialog Boxes Field Definitions	7-24
Configuring Inline VLAN Pairs	7-25
Configuring VLAN Groups	7-25
VLAN Groups Pane	7-26
Deploying VLAN Groups	7-26
VLAN Groups Pane Field Definitions	7-27
Add and Edit VLAN Group Dialog Boxes Field Definitions	7-27
Configuring VLAN Groups	7-27
Configuring Bypass Mode	7-28
Bypass Pane	7-28
Bypass Pane Field Definitions	7-29
Adaptive Security Appliance, ASA 5500 AIP SSM, and Bypass Mode	7-30
Configuring Traffic Flow Notifications	7-30
Configuring CDP Mode	7-31

CHAPTER 8
Configuring Policies 8-1

Understanding Security Policies	8-1
IPS Policies Components	8-1
Understanding Analysis Engine	8-2
Understanding the Virtual Sensor	8-2
Advantages and Restrictions of Virtualization	8-3
Inline TCP Session Tracking Mode	8-3
Understanding Normalizer Mode	8-4
Understanding HTTP Advanced Decoding	8-4
Understanding Event Action Overrides	8-5
Calculating the Risk Rating	8-5
Understanding Threat Rating	8-6
Event Action Summarization	8-7
Event Action Aggregation	8-7

Configuring IPS Policies	8-8
IPS Policies Pane	8-8
IPS Policies Pane Field Definitions	8-9
Add and Edit Virtual Sensor Dialog Boxes Field Definitions	8-10
Add and Edit Event Action Override Dialog Boxes Field Definitions	8-12
Adding, Editing, and Deleting Virtual Sensors	8-13
The ASA 5500 AIP SSM, ASA 5500-X IPS SSP, ASA 5585-X IPS SSP, and Virtual Sensors	8-15
Understanding the ASA IPS Modules and Virtual Sensors	8-15
Configuration Sequence for the ASA IPS Modules	8-15
Creating Virtual Sensors on the ASA 5585-X IPS SSP and ASA IPS Modules	8-16
Assigning Virtual Sensors to Adaptive Security Appliance Contexts	8-18
Configuring Event Action Filters	8-20
Understanding Event Action Filters	8-20
Event Action Filters Tab	8-21
Event Action Filters Tab Field Definitions	8-21
Add and Edit Event Action Filter Dialog Boxes Field Definitions	8-22
Adding, Editing, Deleting, Enabling, Disabling, and Moving Event Action Filters	8-23
Configuring IPv4 Target Value Rating	8-25
IPv4 Target Value Rating Tab	8-26
IPv4 Target Value Rating Tab Field Definitions	8-26
Add and Edit Target Value Rating Dialog Boxes Field Definitions	8-26
Adding, Editing, and Deleting IPv4 Target Value Ratings	8-26
Configuring IPv6 Target Value Rating	8-27
IPv6 Target Value Rating Tab	8-27
IPv6 Target Value Rating Tab Field Definitions	8-27
Add and Edit Target Value Rating Dialog Boxes Field Definitions	8-28
Adding, Editing, and Deleting IPv6 Target Value Ratings	8-28
Configuring OS Identifications	8-29
Understanding Passive OS Fingerprinting	8-30
Configuring Passive OS Fingerprinting	8-31
OS Identifications Tab	8-31
OS Identifications Tab Field Definitions	8-32
Add and Edit Configured OS Map Dialog Boxes Field Definitions	8-32
Adding, Editing, Deleting, and Moving Configured OS Maps	8-33
Configuring Event Variables	8-34
Event Variables Tab	8-34
Event Variables Tab Field Definitions	8-35
Add and Edit Event Variable Dialog Boxes Field Definitions	8-35

Adding, Editing, and Deleting Event Variables	8-36
Configuring Risk Category	8-37
Risk Category Tab	8-37
Risk Category Tab Field Definitions	8-38
Add and Edit Risk Level Dialog Boxes Field Definitions	8-38
Adding, Editing, and Deleting Risk Categories	8-38
Configuring Threat Category	8-39
Configuring General Settings	8-40
General Tab	8-40
General Tab Field Definitions	8-41
Configuring the General Settings	8-41

CHAPTER 9
Configuring Shared Policies and Group Policies 9-1

Configuring Shared Policies	9-1
Understanding Shared Policies	9-1
Add Policy Field Definitions	9-2
Adding and Deleting Shared Policies	9-3
Deploying Shared Policies	9-3
Configuring Policy Groups	9-4

CHAPTER 10
Defining Signatures 10-1

Understanding Security Policies	10-1
Understanding Signatures	10-1
Event Actions	10-2
Signature Engines	10-4
Configuring Signature Definition Policies	10-7
Signature Definitions Pane	10-7
Signature Definitions Pane Field Definitions	10-8
Add and Clone Policy Dialog Boxes Field Definitions	10-8
Adding, Cloning, and Deleting Signature Policies	10-8
sig0 Pane	10-9
MySDN	10-10
Configuring Signatures	10-11
Sig0 Pane Field Definitions	10-11
Add, Clone, and Edit Signatures Dialog Boxes Field Definitions	10-12
Edit Actions Dialog Box Field Definitions	10-14
Enabling, Disabling, and Retiring Signatures	10-17
Adding Signatures	10-17

Cloning Signatures	10-19
Tuning Signatures	10-20
Assigning Actions to Signatures	10-21
Configuring Alert Frequency	10-23
Example Meta Engine Signature	10-25
Example Atomic IP Advanced Engine Signature	10-28
Example String XL TCP Match Offset Signature	10-30
Example String XL TCP Engine Minimum Match Length Signature	10-33
Configuring Signature Variables	10-36
Signature Variables Tab	10-36
Signature Variables Field Definitions	10-36
Adding, Editing, and Deleting Signature Variables	10-37
Configuring Miscellaneous Settings	10-38
Miscellaneous Tab	10-38
Miscellaneous Tab Field Definitions	10-39
Configuring Application Policy Signatures	10-40
Understanding AIC Signatures	10-40
AIC Engine and Sensor Performance	10-41
AIC Request Method Signatures	10-42
AIC MIME Define Content Type Signatures	10-43
AIC Transfer Encoding Signatures	10-46
AIC FTP Commands Signatures	10-46
Configuring Application Policy	10-47
Tuning an AIC Signature	10-48
Configuring IP Fragment Reassembly Signatures	10-49
Understanding IP Fragment Reassembly Signatures	10-49
IP Fragment Reassembly Signatures and Configurable Parameters	10-50
Configuring the IP Fragment Reassembly Mode	10-51
Tuning an IP Fragment Reassembly Signature	10-51
Configuring TCP Stream Reassembly Signatures	10-52
Understanding TCP Stream Reassembly Signatures	10-52
TCP Stream Reassembly Signatures and Configurable Parameters	10-53
Configuring the TCP Stream Reassembly Mode	10-58
Tuning a TCP Stream Reassembly Signature	10-59
Configuring IP Logging	10-60

CHAPTER 11

Using the Custom Signature Wizard 11-1

Understanding the Custom Signature Wizard	11-1
Using a Signature Engine	11-1

Signature Engines Not Supported for the Custom Signature Wizard	11-2
Not Using a Signature Engine	11-4
Creating Custom Signatures	11-4
Custom Signature Wizard Field Definitions	11-9
Welcome Window	11-10
Protocol Type Window	11-10
Signature Identification Window	11-11
Service MSRPC Engine Parameters Window	11-11
ICMP Traffic Type Window	11-12
Inspect Data Window	11-12
UDP Traffic Type Window	11-12
UDP Sweep Type Window	11-12
TCP Traffic Type Window	11-12
Service Type Window	11-13
TCP Sweep Type Window	11-13
Atomic IP Engine Parameters Window	11-13
Example Atomic IP Advanced Engine Signature	11-14
Service HTTP Engine Parameters Window	11-16
Example Service HTTP Engine Signature	11-17
Service RPC Engine Parameters Window	11-19
State Engine Parameters Window	11-20
String ICMP Engine Parameters Window	11-21
String TCP Engine Parameters Window	11-21
Example String TCP Engine Signature	11-22
String UDP Engine Parameters Window	11-24
Sweep Engine Parameters Window	11-24
Alert Response Window	11-26
Alert Behavior Window	11-26
Event Count and Interval Window	11-26
Alert Summarization Window	11-27
Alert Dynamic Response Fire All Window	11-27
Alert Dynamic Response Fire Once Window	11-28
Alert Dynamic Response Summary Window	11-28
Global Summarization Window	11-29

CHAPTER 12
Configuring Event Action Rules 12-1

Understanding Security Policies	12-1
Event Action Rules Components	12-2
Understanding Event Action Rules	12-2

Calculating the Risk Rating	12-2
Understanding Threat Rating	12-4
Understanding Event Action Overrides	12-4
Understanding Event Action Filters	12-4
Event Action Summarization	12-5
Event Action Aggregation	12-5
Signature Event Action Processor	12-6
Event Actions	12-8
Configuring Event Action Rules Policies	12-11
Event Action Rules Pane	12-11
Event Action Rules Pane Field Definitions	12-12
Add and Clone Policy Dialog Boxes Field Definitions	12-12
Adding, Cloning, and Deleting Event Action Rules Policies	12-12
rules0 Pane	12-13
Configuring Event Action Overrides	12-13
Event Action Overrides Tab	12-13
Event Action Overrides Tab Field Definitions	12-13
Add and Edit Event Action Override Dialog Boxes Field Definitions	12-13
Adding, Editing, Deleting, Enabling, and Disabling Event Action Overrides	12-14
Configuring Event Action Filters	12-15
Event Action Filters Tab	12-15
Event Action Filters Tab Field Definitions	12-15
Add and Edit Event Action Filter Dialog Boxes Field Definitions	12-16
Adding, Editing, Deleting, Enabling, Disabling, and Moving Event Action Filters	12-17
Configuring IPv4 Target Value Rating	12-19
IPv4 Target Value Rating Tab	12-20
IPv4 Target Value Rating Tab Field Definitions	12-20
Add and Edit Target Value Rating Dialog Boxes Field Definitions	12-20
Adding, Editing, and Deleting IPv4 Target Value Ratings	12-20
Configuring IPv6 Target Value Rating	12-21
IPv6 Target Value Rating Tab	12-21
IPv6 Target Value Rating Tab Field Definitions	12-21
Add and Edit IPv6 Target Value Rating Dialog Boxes Field Definitions	12-22
Adding, Editing, and Deleting IPv6 Target Value Ratings	12-22
Configuring OS Identifications	12-23
OS Identifications Tab	12-23
Understanding Passive OS Fingerprinting	12-24
Configuring Passive OS Fingerprinting	12-25
OS Identifications Tab Field Definitions	12-25

Add and Edit Configured OS Map Dialog Boxes Field Definitions	12-26
Adding, Editing, Deleting, and Moving Configured OS Maps	12-27
Configuring Event Variables	12-28
Event Variables Tab	12-28
Event Variables Tab Field Definitions	12-29
Add and Edit Event Variable Dialog Boxes Field Definitions	12-29
Adding, Editing, and Deleting Event Variables	12-29
Configuring Risk Category	12-31
Risk Category Tab	12-31
Risk Category Tab Field Definitions	12-31
Add and Edit Risk Level Dialog Boxes Field Definitions	12-31
Adding, Editing, and Deleting Risk Categories	12-32
Configuring Threat Category	12-32
Configuring General Settings	12-33
General Tab	12-33
General Tab Field Definitions	12-34
Configuring the General Settings	12-34

CHAPTER 13

Configuring Anomaly Detection	13-1
Understanding Security Policies	13-1
Anomaly Detection Components	13-2
Understanding Anomaly Detection	13-2
Worms	13-2
Anomaly Detection Modes	13-3
Enabling Anomaly Detection	13-4
Anomaly Detection Zones	13-5
Anomaly Detection Configuration Sequence	13-5
Anomaly Detection Signatures	13-7
Configuring Anomaly Detections Policies	13-9
Anomaly Detections Pane	13-9
Anomaly Detections Pane Field Definitions	13-9
Add and Clone Policy Dialog Boxes Field Definitions	13-9
Adding, Cloning, and Deleting Anomaly Detection Policies	13-10
ad0 Pane	13-10
Configuring Operation Settings	13-11
Operation Settings Tab	13-11
Operating Settings Tab Field Definitions	13-11
Configuring Anomaly Detection Operation Settings	13-11

Configuring Learning Accept Mode	13-12
Learning Accept Mode Tab	13-12
The KB and Histograms	13-12
Learning Accept Mode Tab Field Definitions	13-14
Add and Edit Start Time Dialog Boxes Field Definitions	13-14
Configuring Learning Accept Mode	13-14
Configuring the Internal Zone	13-15
Internal Zone Tab	13-15
General Tab	13-16
TCP Protocol Tab	13-16
Add and Edit Destination Port Dialog Boxes Field Definitions	13-17
Add and Edit Histogram Dialog Boxes Field Definitions	13-17
UDP Protocol Tab	13-17
Other Protocols Tab	13-18
Add and Edit Protocol Number Dialog Boxes Field Definitions	13-18
Configuring the Internal Zone	13-19
Configuring the Illegal Zone	13-22
Illegal Zone Tab	13-22
General Tab	13-23
TCP Protocol Tab	13-23
Add and Edit Destination Port Dialog Boxes Field Definitions	13-23
Add and Edit Histogram Dialog Boxes Field Definitions	13-24
UDP Protocol Tab	13-24
Other Protocols Tab	13-25
Add and Edit Protocol Number Dialog Boxes Field Definitions	13-25
Configuring the Illegal Zone	13-25
Configuring the External Zone	13-29
External Zone Tab	13-29
TCP Protocol Tab	13-29
Add and Edit Destination Port Dialog Boxes Field Definitions	13-30
Add and Edit Histogram Dialog Boxes Field Definitions	13-30
UDP Protocol Tab	13-31
Other Protocols Tab	13-31
Add and Edit Protocol Number Dialog Boxes Field Definitions	13-32
Configuring the External Zone	13-32
Disabling Anomaly Detection	13-35

CHAPTER 14

Configuring Global Correlation 14-1

Understanding Global Correlation	14-1
----------------------------------	------

Participating in the SensorBase Network	14-2
Understanding Reputation	14-2
Understanding Network Participation	14-3
Understanding Efficacy	14-4
Reputation and Risk Rating	14-5
Global Correlation Features and Goals	14-5
Global Correlation Requirements	14-6
Understanding Global Correlation Sensor Health Metrics	14-7
Configuring Global Correlation Inspection and Reputation Filtering	14-7
Inspection/Reputation Pane	14-8
Inspection/Reputation Pane Field Definitions	14-9
Configuring Global Correlation Inspection and Reputation Filtering	14-9
Configuring Network Participation	14-10
Network Participation Pane	14-10
Network Participation Pane Field Definitions	14-10
Configuring Network Participation	14-11
Troubleshooting Global Correlation	14-11
Disabling Global Correlation	14-12

CHAPTER 15

Configuring SSH and Certificates	15-1
Understanding SSH	15-1
Configuring Authorized RSA Keys	15-2
Authorized RSA Keys Pane	15-2
Authorized RSA Keys Pane Field Definitions	15-2
Add and Edit Authorized RSA Key Dialog Boxes Field Definitions	15-3
Defining Authorized RSA Keys	15-3
Configuring Authorized RSA1 Keys	15-4
Authorized RSA1 Keys Pane	15-4
Authorized RSA1 Keys Pane Field Definitions	15-4
Add and Edit Authorized RSA1 Key Dialog Boxes Field Definitions	15-5
Defining Authorized RSA1 Keys	15-5
Configuring Known Host RSA Keys	15-6
Known Host RSA Keys Pane	15-6
Known Host RSA Keys Pane Field Definitions	15-7
Add and Edit Known Host RSA Key Dialog Boxes Field Definitions	15-7
Defining Known RSA Host Keys	15-7
Configuring Known Host RSA1 Keys	15-8
Known Host RSA1 Keys Pane	15-8

Known Host RSA1 Keys Pane Field Definitions	15-9
Add and Edit Known Host RSA1 Key Dialog Boxes Field Definitions	15-9
Defining Known Host RSA1 Keys	15-9
Generating the Sensor Key	15-10
Understanding Certificates	15-11
Configuring Trusted Hosts	15-12
Trusted Hosts Pane	15-13
Trusted Hosts Pane Field Definitions	15-13
Add Trusted Host Dialog Box Field Definitions	15-13
Adding Trusted Hosts	15-13
Adding Trusted Root Certificates	15-14
Trusted Root Certificates Pane	15-14
Trusted Root Certificates Field Definitions	15-15
Add and Update Trusted Root Certificates Dialog Box Field Definitions	15-15
Adding and Updating Trusted Root Certificates	15-15
Generating the Server Certificate	15-16

CHAPTER 16

Configuring Attack Response Controller for Blocking and Rate Limiting 16-1

ARC Components	16-1
Understanding Blocking	16-2
Understanding Rate Limiting	16-4
Understanding Service Policies for Rate Limiting	16-5
Before Configuring the ARC	16-5
Supported Devices	16-5
Configuring Blocking Properties	16-7
Blocking Properties Pane	16-7
Understanding Blocking Properties	16-7
Blocking Properties Pane Field Definitions	16-8
Configuring Blocking Properties	16-9
Add and Edit Never Block Address Dialog Boxes Field Definitions	16-10
Adding, Editing, and Deleting IP Addresses Never to be Blocked	16-11
Configuring Device Login Profiles	16-11
Device Login Profiles Pane	16-12
Device Login Profiles Pane Field Definitions	16-12
Add and Edit Device Login Profile Dialog Boxes Field Definitions	16-12
Configuring Device Login Profiles	16-13
Configuring Blocking Devices	16-14
Blocking Device Pane	16-14
Blocking Devices Pane Field Definitions	16-14

Add and Edit Blocking Device Dialog Boxes Field Definitions	16-15
Adding, Editing, and Deleting Blocking and Rate Limiting Devices	16-15
Configuring Router Blocking Device Interfaces	16-17
Router Blocking Device Interfaces Pane	16-17
Understanding Router Blocking Device Interfaces	16-17
How the Sensor Manages Devices	16-18
Router Blocking Device Interfaces Pane Field Definitions	16-19
Add and Edit Router Blocking Device Interface Dialog Boxes Field Definitions	16-19
Configuring the Router Blocking and Rate Limiting Device Interfaces	16-20
Configuring Cat 6K Blocking Device Interfaces	16-21
Cat 6K Blocking Device Interfaces Pane	16-21
Understanding Cat 6K Blocking Device Interfaces	16-21
Cat 6K Blocking Device Interfaces Pane Field Definitions	16-22
Add and Edit Cat 6K Blocking Device Interface Dialog Boxes Field Definitions	16-22
Configuring Cat 6K Blocking Device Interfaces	16-23
Configuring the Master Blocking Sensor	16-24
Master Blocking Sensor Pane	16-24
Understanding the Master Blocking Sensor	16-24
Master Blocking Sensor Pane Field Definitions	16-25
Add and Edit Master Blocking Sensor Dialog Boxes Field Definitions	16-25
Configuring the Master Blocking Sensor	16-25

CHAPTER 17
Configuring SNMP 17-1

Understanding SNMP	17-1
Configuring General Configuration	17-2
General Configuration Pane	17-2
General Configuration Pane Field Definitions	17-2
Configuring General Parameters	17-3
Configuring SNMP Traps	17-3
Traps Configuration Pane	17-4
Traps Configuration Pane Field Definitions	17-4
Add and Edit SNMP Trap Destination Dialog Boxes Field Definitions	17-5
Configuring SNMP Traps	17-5
Supported MIBs	17-6

CHAPTER 18
Managing Time-Based Actions 18-1

Configuring and Monitoring Denied Attackers	18-1
Denied Attackers Pane	18-1
Denied Attackers Pane Field Definitions	18-2

Monitoring the Denied Attackers List and Adding Denied Attackers	18-2
Configuring Host Blocks	18-3
Host Blocks Pane	18-3
Host Block Pane Field Definitions	18-3
Add Host Block Dialog Box Field Definitions	18-4
Adding, Deleting, and Managing Host Blocks	18-4
Configuring Network Blocks	18-5
Network Blocks Pane	18-6
Network Blocks Pane Field Definitions	18-6
Add Network Block Dialog Box Field Definitions	18-6
Adding, Deleting, and Managing Network Blocks	18-6
Configuring Rate Limits	18-7
Rate Limits Pane	18-7
Rate Limits Pane Field Definitions	18-8
Add Rate Limit Dialog Box Field Definitions	18-8
Adding, Deleting, and Managing Rate Limiting	18-9
Configuring IP Logging	18-10
Understanding IP Logging	18-10
IP Logging Pane	18-11
IP Logging Pane Field Definitions	18-11
Add and Edit IP Logging Dialog Boxes Field Definitions	18-11
Configuring IP Logging	18-12

CHAPTER 19

Configuring External Product Interfaces	19-1
Understanding External Product Interfaces	19-1
Understanding CSA MC	19-1
External Product Interface Issues	19-3
Configuring the CSA MC to Support IPS Interfaces	19-3
Configuring External Product Interfaces	19-4
External Product Interfaces Pane	19-4
External Product Interfaces Pane Field Definitions	19-5
Add and Edit External Product Interface Dialog Boxes Field Definitions	19-6
Add and Edit Posture ACL Dialog Boxes Field Definitions	19-7
Adding, Editing, and Deleting External Product Interfaces and Posture ACLs	19-7
Troubleshooting External Product Interfaces	19-10

CHAPTER 20

Managing the Sensor	20-1
Configuring Passwords	20-1

Passwords Pane	20-1
Passwords Pane Field Definitions	20-2
Configuring Password Requirements	20-2
Configuring Packet Logging	20-3
Recovering the Password	20-4
Understanding Password Recovery	20-4
Recovering the Appliance Password	20-5
Using the GRUB Menu	20-5
Using ROMMON	20-6
Recovering the ASA 5500 AIP SSM Password	20-7
Recovering the ASA 5500-X IPS SSP Password	20-9
Recovering the ASA 5585-X IPS SSP Password	20-11
Disabling Password Recovery	20-13
Troubleshooting Password Recovery	20-14
Verifying the State of Password Recovery	20-14
Configuring Licensing	20-14
Licensing Pane	20-15
Understanding Licensing	20-15
Service Programs for IPS Products	20-16
Licensing Pane Field Definitions	20-16
Obtaining and Installing the License Key	20-17
Obtaining a New License Key for the IPS 4270-20	20-18
Licensing the ASA 5500-X IPS SSP	20-18
Uninstalling the License Key	20-19
Configuring Sensor Health	20-20
Configuring IP Logging Variables	20-21
Configuring Automatic Update	20-22
Auto/Cisco.com Update Pane	20-22
Supported FTP and HTTP Servers	20-23
UNIX-Style Directory Listings	20-23
Signature Updates and Installation Time	20-23
Auto/Cisco.com Update Pane Field Definitions	20-24
Configuring Auto Update	20-25
Manually Updating the Sensor	20-26
Update Sensor Pane	20-26
Update Sensor Pane Field Definitions	20-27
Updating the Sensor	20-27
Restoring Defaults	20-29
Rebooting the Sensor	20-29

Shutting Down the Sensor 20-30

CHAPTER 21

Monitoring the Sensor 21-1

Monitoring Events 21-1

Events Pane 21-1

Events Pane Field Definitions 21-2

Event Viewer Pane Field Definitions 21-3

Configuring Event Display 21-3

Clearing Event Store 21-4

Displaying Inspection Load Statistics 21-4

Displaying Interface Statistics 21-5

Monitoring Anomaly Detection KBs 21-7

Anomaly Detection Pane 21-7

Understanding KBs 21-8

Anomaly Detection Pane Field Definitions 21-8

Showing Thresholds 21-9

Threshold for KB_Name Window 21-9

Thresholds for KB_Name Window Field Definitions 21-10

Monitoring the KB Thresholds 21-10

Comparing KBs 21-11

Compare Knowledge Base Dialog Box 21-11

Differences between knowledge bases KB_Name and KB_Name Window 21-11

Difference Thresholds between knowledge bases KB_Name and KB_Name Window 21-11

Comparing KBs 21-12

Saving the Current KB 21-12

Save Knowledge Base Dialog Box 21-13

Loading a KB 21-13

Saving a KB 21-13

Deleting a KB 21-14

Renaming a KB 21-14

Downloading a KB 21-15

Uploading a KB 21-15

Configuring OS Identifications 21-16

Configuring Learned Operating Systems 21-16

Configuring Imported Operating Systems 21-17

Clearing Flow States 21-18

Clear Flow States Pane 21-18

Clear Flow States Pane Field Definitions 21-19

Clearing Flow States	21-19
Resetting Network Security Health	21-20
Generating a Diagnostics Report	21-20
Viewing Statistics	21-21
Viewing System Information	21-22

CHAPTER 22

Configuring Event Monitoring	22-1
Understanding Event Monitoring	22-1
Group By, Color Rules, Fields, and General Tabs	22-2
Understanding Filters	22-2
Filter Tab and Add Filter Dialog Box Field Definitions	22-3
Working With Event Views	22-4
Working With a Single Event	22-5
Configuring Filters for Event Views	22-6

CHAPTER 23

Configuring and Generating Reports	23-1
Understanding IME Reporting	23-1
Configuring and Generating Reports	23-3

CHAPTER 24

Logging In to the Sensor	24-1
Supported User Roles	24-1
Logging In to the Appliance	24-2
Connecting an Appliance to a Terminal Server	24-3
Logging In to the ASA 5500 AIP SSM	24-4
Logging In to the ASA 5500-X IPS SSP	24-5
Logging In to the ASA 5585-X IPS SSP	24-6
Logging In to the Sensor	24-7

CHAPTER 25

Initializing the Sensor	25-1
Understanding Initialization	25-1
Simplified Setup Mode	25-2
System Configuration Dialog	25-2
Basic Sensor Setup	25-4
Advanced Setup	25-7
Appliance Advanced Setup	25-7
ASA 5500 AIP SSM Advanced Setup	25-13

ASA 5500-X IPS SSP Advanced Setup	25-17
ASA 5585-X IPS SSP Advanced Setup	25-20
Verifying Initialization	25-24

CHAPTER 26

Obtaining Software 26-1

IPS 7.1 File List	26-1
Obtaining Cisco IPS Software	26-1
IPS Software Versioning	26-3
Software Release Examples	26-5
Accessing IPS Documentation	26-7
Cisco Security Intelligence Operations	26-7

CHAPTER 27

Upgrading, Downgrading, and Installing System Images 27-1

Understanding Upgrades, Downgrades, and System Images	27-1
Supported FTP and HTTP/HTTPS Servers	27-2
Upgrading the Sensor	27-2
IPS 7.1 Upgrade Files	27-3
Upgrade Notes and Caveats	27-3
Manually Upgrading the Sensor	27-3
Upgrading the Recovery Partition	27-6
Configuring Automatic Upgrades	27-7
Understanding Automatic Upgrades	27-7
Automatically Upgrading the Sensor	27-7
Downgrading the Sensor	27-10
Recovering the Application Partition	27-11
Installing System Images	27-12
ROMMON	27-13
TFTP Servers	27-13
Connecting an Appliance to a Terminal Server	27-13
Installing the IPS 4240 and IPS 4255 System Image	27-14
Installing the IPS 4260 System Image	27-17
Installing the IPS 4270-20 System Image	27-19
Installing the IPS 4345 and IPS 4360 System Image	27-21
Installing the IPS 4510 and IPS 4520 System Image	27-25
Installing the ASA 5500 AIP SSM System Image	27-27
Installing the ASA 5500-X IPS SSP Image	27-29
Installing the ASA 5585-X IPS SSP System Image	27-31

Installing the ASA 5585-X IPS SSP System Image Using the hw-module Command	27-31
Installing the ASA 5585-X IPS SSP System Image Using ROMMON	27-33

APPENDIX A

System Architecture	A-1
Purpose of Cisco IPS	A-1
System Design	A-1
System Applications	A-4
User Interaction	A-5
Security Features	A-5
MainApp	A-6
Understanding the MainApp	A-6
MainApp Responsibilities	A-6
Event Store	A-7
Understanding the Event Store	A-7
Event Data Structures	A-8
IPS Events	A-9
NotificationApp	A-9
CtlTransSource	A-11
Attack Response Controller	A-12
Understanding the ARC	A-13
ARC Features	A-14
Supported Blocking Devices	A-15
ACLs and VACLs	A-16
Maintaining State Across Restarts	A-16
Connection-Based and Unconditional Blocking	A-17
Blocking with Cisco Firewalls	A-18
Blocking with Catalyst Switches	A-19
Logger	A-19
InterfaceApp	A-20
AuthenticationApp	A-20
Understanding the AuthenticationApp	A-20
Authenticating Users	A-20
Configuring Authentication on the Sensor	A-21
Managing TLS and SSH Trust Relationships	A-21
Web Server	A-23
SensorApp	A-23
Understanding the SensorApp	A-23
Inline, Normalization, and Event Risk Rating Features	A-24

SensorApp New Features	A-25
Packet Flow	A-26
Signature Event Action Processor	A-26
CollaborationApp	A-28
Understanding the CollaborationApp	A-28
Update Components	A-28
Error Events	A-29
SwitchApp	A-30
CLI	A-30
Understanding the CLI	A-30
User Roles	A-30
Service Account	A-31
Communications	A-32
IDAPI	A-32
IDIOM	A-33
IDCONF	A-33
SDEE	A-34
CIDEE	A-34
Cisco IPS File Structure	A-35
Summary of Cisco IPS Applications	A-36

APPENDIX B

Signature Engines	B-1
Understanding Signature Engines	B-1
Master Engine	B-4
General Parameters	B-4
Alert Frequency	B-7
Event Actions	B-8
Regular Expression Syntax	B-9
AIC Engine	B-10
Understanding the AIC Engine	B-10
AIC Engine and Sensor Performance	B-11
AIC Engine Parameters	B-11
Atomic Engine	B-13
Atomic ARP Engine	B-13
Atomic IP Advanced Engine	B-14
Atomic IP Engine	B-24
Atomic IPv6 Engine	B-27
Fixed Engine	B-28

Flood Engine	B-31
Meta Engine	B-32
Multi String Engine	B-34
Normalizer Engine	B-36
Service Engines	B-39
Understanding the Service Engines	B-39
Service DNS Engine	B-39
Service FTP Engine	B-41
Service Generic Engine	B-42
Service H225 Engine	B-43
Service HTTP Engine	B-46
Service IDENT Engine	B-48
Service MSRPC Engine	B-48
Service MSSQL Engine	B-50
Service NTP Engine	B-51
Service P2P	B-52
Service RPC Engine	B-52
Service SMB Advanced Engine	B-54
Service SNMP Engine	B-56
Service SSH Engine	B-57
Service TNS Engine	B-57
State Engine	B-59
String Engines	B-61
String XL Engines	B-63
Sweep Engines	B-66
Sweep Engine	B-66
Sweep Other TCP Engine	B-69
Traffic Anomaly Engine	B-69
Traffic ICMP Engine	B-72
Trojan Engines	B-72

APPENDIX C

Troubleshooting	C-1
Cisco Bug Search	C-1
Preventive Maintenance	C-2
Understanding Preventive Maintenance	C-2
Creating and Using a Backup Configuration File	C-2
Backing Up and Restoring the Configuration File Using a Remote Server	C-3
Creating the Service Account	C-5

Disaster Recovery	C-6
Password Recovery	C-7
Understanding Password Recovery	C-7
Recovering the Appliance Password	C-8
Using the GRUB Menu	C-8
Using ROMMON	C-9
Recovering the ASA 5500 AIP SSM Password	C-10
Recovering the ASA 5500-X IPS SSP Password	C-12
Recovering the ASA 5585-X IPS SSP Password	C-14
Disabling Password Recovery	C-15
Verifying the State of Password Recovery	C-16
Troubleshooting Password Recovery	C-17
Time Sources and the Sensor	C-17
Time Sources and the Sensor	C-17
Synchronizing IPS Module Clocks with Parent Device Clocks	C-18
Verifying the Sensor is Synchronized with the NTP Server	C-18
Correcting Time on the Sensor	C-19
Advantages and Restrictions of Virtualization	C-19
Supported MIBs	C-20
When to Disable Anomaly Detection	C-21
The Analysis Engine is Not Responding	C-22
Troubleshooting RADIUS Authentication	C-23
Troubleshooting Global Correlation	C-23
Troubleshooting External Product Interfaces	C-23
External Product Interfaces Issues	C-24
External Product Interfaces Troubleshooting Tips	C-24
Troubleshooting the Appliance	C-25
The Appliance and Jumbo Packet Frame Size	C-25
Troubleshooting Loose Connections	C-25
The Analysis Engine is Busy	C-26
Connecting the IPS 4240 to a Cisco 7200 Series Router	C-26
Communication Problems	C-27
Cannot Access the Sensor CLI Through Telnet or SSH	C-27
Correcting a Misconfigured Access List	C-29
Duplicate IP Address Shuts Interface Down	C-30
The SensorApp and Alerting	C-31
The SensorApp Not Running	C-31
Physical Connectivity, SPAN, or VACL Port Issue	C-33
Unable to See Alerts	C-34

Sensor Not Seeing Packets	C-36
Cleaning Up a Corrupted SensorApp Configuration	C-37
Blocking	C-38
Troubleshooting Blocking	C-38
Verifying the ARC is Running	C-39
Verifying ARC Connections are Active	C-40
Device Access Issues	C-42
Verifying the Interfaces and Directions on the Network Device	C-43
Enabling SSH Connections to the Network Device	C-44
Blocking Not Occurring for a Signature	C-45
Verifying the Master Blocking Sensor Configuration	C-46
Logging	C-47
Understanding Debug Logging	C-47
Enabling Debug Logging	C-47
Zone Names	C-51
Directing cidLog Messages to SysLog	C-52
TCP Reset Not Occurring for a Signature	C-53
Software Upgrades	C-55
Upgrading	C-55
Which Updates to Apply and Their Prerequisites	C-55
Issues With Automatic Update	C-56
Updating a Sensor with the Update Stored on the Sensor	C-57
Troubleshooting the IDM	C-57
Cannot Launch the IDM - Loading Java Applet Failed	C-58
Cannot Launch the IDM - the Analysis Engine Busy	C-59
The IDM, Remote Manager, or Sensing Interfaces Cannot Access Sensor	C-59
Signatures Not Producing Alerts	C-60
Troubleshooting the IME	C-60
Time Synchronization on the IME and the Sensor	C-61
Not Supported Error Message	C-61
Installation Error	C-61
Troubleshooting the ASA 5500 AIP SSM	C-62
Failover Scenarios	C-62
The ASA 5500 AIP SSM and the Data Plane	C-63
Health and Status Information	C-63
The ASA 5500 AIP SSM and the Normalizer Engine	C-65
The ASA 5500 AIP SSM and Jumbo Packet Frame Size	C-66
The ASA 5500 AIP SSM and Jumbo Packets	C-66
TCP Reset Differences Between IPS Appliances and ASA IPS Modules	C-67

IPS Reloading Messages	C-67
Troubleshooting the ASA 5500-X IPS SSP	C-67
Failover Scenarios	C-68
Health and Status Information	C-69
The ASA 5500-X IPS SSP and the Normalizer Engine	C-70
The ASA 5500-X IPS SSP and Memory Usage	C-71
The ASA 5500-X IPS SSP and Jumbo Packet Frame Size	C-71
The ASA 5500-X IPS SSP and Jumbo Packets	C-72
TCP Reset Differences Between IPS Appliances and ASA IPS Modules	C-72
IPS Reloading Messages	C-72
IPS Not Loading	C-73
Troubleshooting the ASA 5585-X IPS SSP	C-73
Failover Sceneries	C-73
Traffic Flow Stopped on IPS Switchports	C-75
Health and Status Information	C-75
The ASA 5585-X IPS SSP and the Normalizer Engine	C-78
The ASA 5585-X IPS SSP and Jumbo Packet Frame Size	C-79
The ASA 5585-X IPS SSP and Jumbo Packets	C-79
TCP Reset Differences Between IPS Appliances and ASA IPS Modules	C-79
IPS Reloading Messages	C-79
Gathering Information	C-80
Understanding Information Gathering	C-80
Health and Network Security Information	C-80
Tech Support Information	C-81
Understanding the show tech-support Command	C-81
Displaying Tech Support Information	C-82
Tech Support Command Output	C-83
Version Information	C-85
Understanding the show version Command	C-85
Displaying Version Information	C-86
Statistics Information	C-88
Understanding the show statistics Command	C-88
Displaying Statistics	C-89
Interfaces Information	C-100
Understanding the show interfaces Command	C-100
Interfaces Command Output	C-101
Events Information	C-101
Sensor Events	C-102
Understanding the show events Command	C-102

Displaying Events	C-102
Clearing Events	C-105
cidDump Script	C-105
Uploading and Accessing Files on the Cisco FTP Site	C-106

APPENDIX D
Open Source License Files Used In Cisco IPS 7.1 D-1

Contents	D-1
bash 3.2	D-2
busybox 1.13.1	D-7
cracklib 2.8.12	D-13
curl 7.18.2 1	D-18
diffutils 2.8.1	D-19
e2fsprogs 1.39	D-23
Expat XML parser 2.0.1	D-28
expect 5.4.3	D-29
freeradius-server 2.1.8	D-29
freeradius-server-src-lib 2.1.8	D-34
glibc 2.9	D-40
gnupg 1.4.5	D-44
hotplug 2004_03_29	D-49
i2c-tools 3.0.2	D-53
ipmiutil 2.3.3	D-58
iptables 1.4.1	D-59
kernel 2.6.29.1	D-63
KVM inter-VM shared memory module	D-73
libpcap 0.9.8	D-77
libtecla 1.6.1	D-78
Linux-Pam 1.0.1	D-78
lm_sensors 3.0.2	D-79
module-init-tools 3.2.2 1.0.0.0900084	D-84
Neurses 5.6	D-88
net-snmp 5.4.1	D-89
NTP 4.2.4p5	D-93
openssh 5.1p1	D-96
openssl 0.9.8j	D-102
pciutils 3.0.1	D-105

procps 3.2.7	D-111
sysfsutils 2.1.0	D-115
sysstat 8.1.3	D-116
tcl 8.4.9	D-120
tcpdump 3.9.8 1.0.1.0801182	D-121
tipc 1.7.6-bundle	D-121
util-linux 2.12r	D-123
zlib 1.2.3	D-124

GLOSSARY

INDEX



Preface

Published: March 31, 2011 , OL-19892-01

Revised: October 17, 2014

Contents

This document describes how to configure the sensor using the Cisco IPS 7.1 CLI. It contains the following sections:

- [Audience, page xxv](#)
- [Organization, page xxv](#)
- [Conventions, page xxvii](#)
- [Related Documentation, page xxviii](#)
- [Obtaining Documentation, Using the Cisco Bug Search Tool, and Submitting a Service Request, page xxviii](#)

Audience

This guide is intended for administrators who need to do the following:

- Configure the sensor for intrusion prevention using the CLI.
- Secure their network with IPS sensors.
- Prevent intrusion on their networks and monitor subsequent alerts.

Organization

This guide includes the following sections:

Section	Title	Description
1	“Introducing the CLI Configuration Guide”	Describes the purpose of the CLI Configuration Guide.
2	“Logging In to the Sensor”	Describes how to log in to the various sensors.

Section	Title	Description
3	“Initializing the Sensor”	Describes how to use the setup command to initialize sensors.
4	“Setting Up the Sensor”	Describes how to use the CLI to configure initial settings on the sensor.
5	“Configuring Interfaces”	Describes how to configure promiscuous, inline, inline VLAN pair, and VLAN group interfaces.
6	“Configuring Virtual Sensors”	Describes how to configure virtual sensors.
7	“Configuring Event Action Rules”	Describes how to configure event action rules policies on the sensor.
8	“Defining Signatures”	Describes how to add, clone, and edit signatures.
9	“Configuring Global Correlation”	Describes how to configure anomaly detection policies on the sensor.
10	“Configuring Global Correlation”	Describes how to configure global correlation features on the sensor.
11	“Configuring External Product Interfaces”	Describes how to configure external product interfaces for CSA MC.
12	“Configuring IP Logging”	Describes how to configure IP logging on the sensor.
13	“Displaying and Capturing Live Traffic on an Interface”	Describes how to display and capture live traffic on sensor interfaces.
14	“Configuring Attack Response Controller for Blocking and Rate Limiting”	Describes how to configure blocking and rate limiting on Cisco routers, and switches, and how to configure a master blocking sensor.
15	“Configuring SNMP”	Describes how to configure SNMP on the sensor.
16	“Working With Configuration Files”	Describes how to use configuration files on the sensor.
17	“Administrative Tasks for the Sensor”	Describes various administrative procedures to help you keep your sensor working and up to date.
19	“Configuring the ASA 5500 AIP SSM”	Describes how to configure the ASA 5500 AIP SSM.
20	“Configuring the ASA 5500-X IPS SSP”	Describes how to configure the ASA 5500-X IPS SSP.
21	“Configuring the ASA 5585-X IPS SSP”	Describes how to configure the ASA 5585-X IPS SSP.
22	“Obtaining Software”	Describes where to go to get the latest IPS software and describes the naming conventions.
23	“Upgrading, Downgrading, and Installing System Images”	Describes how to upgrade sensors and reimage the various sensors.
A	“System Architecture”	Describes the IPS system architecture.
B	“Signature Engines”	Describes the IPS signature engines and their parameters.
C	“Troubleshooting”	Contains troubleshooting tips for IPS hardware and software.

Section	Title	Description
D	“CLI Error Messages”	Lists the CLI error messages.
E	“Open Source License Files Used In Cisco IPS 7.1”	Lists the open source license files used by the IPS.
	“Glossary”	Contains IPS acronyms and terms.

Conventions

This document uses the following conventions:

Convention	Indication
bold font	Commands and keywords and user-entered text appear in bold font.
<i>italic</i> font	Document titles, new or emphasized terms, and arguments for which you supply values are in <i>italic</i> font.
[]	Elements in square brackets are optional.
{ x y z }	Required alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
<code>courier</code> font	Terminal sessions and information the system displays appear in <code>courier</code> font.
< >	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.



Note

Means *reader take note*.



Tip

Means *the following information will help you solve a problem*.



Caution

Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.



Timesaver

Means *the described action saves time*. You can save time by performing the action described in the paragraph.



Warning

Means reader be warned. In this situation, you might perform an action that could result in bodily injury.

Related Documentation

For more information on Cisco IPS, refer to the following documentation found at this URL:

http://www.cisco.com/en/US/products/hw/vpndevc/ps4077/tsd_products_support_series_home.html

- *Documentation Roadmap for Cisco Intrusion Prevention System*
- *Release Notes for Cisco Intrusion Prevention System*
- *Cisco Intrusion Prevention System Device Manager Configuration Guide*
- *Cisco Intrusion Prevention System Manager Express Configuration Guide*
- *Cisco Intrusion Prevention System Command Reference*
- *Cisco Intrusion Prevention System Appliance and Module Installation Guide*
- *Installing and Removing Interface Cards in Cisco IPS-4260 and IPS 4270-20*
- *Regulatory Compliance and Safety Information for the Cisco Intrusion Prevention System 4300 Series Appliance Sensor*
- *Regulatory Compliance and Safety Information for the Cisco ASA 5500-X Series Appliances and the Cisco Intrusion Prevention System 4300 Series Appliances*
- *Regulatory Compliance and Safety Information for the Cisco Intrusion Prevention System 4500 Series Sensor Appliance*

Obtaining Documentation, Using the Cisco Bug Search Tool, and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see *What's New in Cisco Product Documentation* at: <http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>.

Subscribe to *What's New in Cisco Product Documentation*, which lists all new and revised Cisco technical documentation, as an RSS feed and deliver content directly to your desktop using a reader application. The RSS feeds are a free service.



Introducing the CLI Configuration Guide

This chapter introduces the IPS CLI configuration guide, and contains the following sections:

- [Sensor Configuration Sequence, page 1-1](#)
- [IPS CLI Configuration Guide, page 1-1](#)
- [User Roles, page 1-3](#)
- [CLI Behavior, page 1-5](#)
- [Command Line Editing, page 1-6](#)
- [IPS Command Modes, page 1-7](#)
- [Regular Expression Syntax, page 1-8](#)
- [Generic CLI Commands, page 1-10](#)
- [CLI Keywords, page 1-10](#)

IPS CLI Configuration Guide

This guide is a task-based configuration guide for the Cisco IPS 7.1 CLI. The term “sensor” is used throughout this guide to refer to all sensor models, unless a procedure refers to a specific appliance or module, then the specific model name is used.

For an alphabetical list of all IPS commands, refer to the [Command Reference for Cisco Intrusion Prevention System 7.1](#). For information on locating all IPS 7.1 documents on Cisco.com, refer to the [Documentation Roadmap for Cisco Intrusion Prevention System 7.1](#).

You can also use an IPS manager to configure your sensor. For information on how to access documentation that describes how to use IPS managers, refer to the [Documentation Roadmap for Cisco Intrusion Prevention System 7.1](#).

Sensor Configuration Sequence

Perform the following tasks to configure the sensor:

1. Log in to the sensor.
2. Initialize the sensor by running the **setup** command.
3. Verify the sensor initialization.

4. Create the service account. A service account is needed for special debug situations directed by TAC. Only one user with the role of service is allowed.
5. License the sensor.
6. Perform the other initial tasks, such as adding users and trusted hosts, and so forth.
7. Make changes to the interface configuration if necessary. You configure the interfaces during initialization.
8. Add or delete virtual sensors as necessary. You configure the virtual sensors during initialization.
9. Configure event action rules.
10. Configure the signatures for intrusion prevention.
11. Configure the sensor for global correlation.
12. Configure anomaly detection if needed. You can run anomaly detection using the default values or you can tailor it to suit your network needs.

**Note**

Anomaly detection is disabled by default in IPS 7.1(2)E4 and later. You must enable it to configure or apply an anomaly detection policy. Enabling anomaly detection results in a decrease in performance.

13. Set up any external product interfaces if needed. The CSA MC is the only external product supported by the Cisco IPS.
14. Configure IP logging if needed.
15. Configure blocking if needed.
16. Configure SNMP if needed.
17. Perform miscellaneous tasks to keep your sensor running smoothly.
18. Upgrade the IPS software with new signature updates and service packs.
19. Reimage the application partition when needed.

For More Information

- For the procedure for logging in to your sensor, see [Chapter 2, “Logging In to the Sensor.”](#)
- For the procedure for using the **setup** command to initialize your sensor, see [Chapter 3, “Initializing the Sensor.”](#)
- For the procedure for verifying sensor initialization, see [Verifying Initialization, page 3-25](#).
- For the procedure for obtaining and installing the license key, see [Installing the License Key, page 4-56](#).
- For the procedures for setting up your sensor, see [Chapter 4, “Setting Up the Sensor.”](#)
- For the procedure for creating the service account, see [Creating the Service Account, page 4-26](#).
- For the procedures for configuring interfaces on your sensor, see [Chapter 5, “Configuring Interfaces.”](#)
- For the procedures for configuring virtual sensors on your sensor, see [Chapter 6, “Configuring Virtual Sensors.”](#)
- For the procedures for configuring event action rules policies, see [Chapter 7, “Configuring Event Action Rules.”](#)

- For the procedures for configuring signatures for intrusion prevention, see [Chapter 8, “Defining Signatures.”](#)
- For the procedures for configuring global correlation, see [Chapter 10, “Configuring Global Correlation.”](#)
- For the procedure for configuring anomaly detection policies, see [Chapter 9, “Configuring Anomaly Detection.”](#)
- For the procedure for setting up external product interfaces, see [Chapter 11, “Configuring External Product Interfaces.”](#)
- For the procedures for configuring IP logging, see [Chapter 12, “Configuring IP Logging.”](#)
- For the procedures for configuring blocking on your sensor, see [Chapter 14, “Configuring Attack Response Controller for Blocking and Rate Limiting.”](#)
- For the procedures for configuring SNMP on your sensor, see [Chapter 15, “Configuring SNMP.”](#)
- For the administrative procedures, see [Chapter 17, “Administrative Tasks for the Sensor.”](#)
- For more information on how to obtain Cisco IPS software, see [Chapter 21, “Obtaining Software.”](#)
- For the procedures for installing system images, see [Chapter 22, “Upgrading, Downgrading, and Installing System Images.”](#)
- For procedures specific to the ASA 5500 AIP SSM, see [Chapter 18, “Configuring the ASA 5500 AIP SSM.”](#)
- For the procedures specific to the ASA 5500-X IPS SSP, see [Chapter 19, “Configuring the ASA 5500-X IPS SSP.”](#)
- For the procedures specific to the ASA 5585-X IPS SSP, see [Chapter 20, “Configuring the ASA 5585-X IPS SSP.”](#)

User Roles

The Cisco CLI permits multiple users to log in at the same time. You can create and remove users from the local sensor. You can modify only one user account at a time. Each user is associated with a role that controls what that user can and cannot modify. The CLI supports four user roles: administrator, operator, viewer, and service. The privilege levels for each role are different; therefore, the menus and available commands vary for each role.

Administrator

This user role has the highest level of privileges. Administrators have unrestricted view access and can perform the following functions:

- Add users and assign passwords
- Enable and disable control of physical interfaces and virtual sensors
- Assign physical sensing interfaces to a virtual sensor
- Modify the list of hosts allowed to connect to the sensor as a configuring or viewing agent
- Modify sensor address configuration
- Tune signatures
- Assign configuration to a virtual sensor
- Manage routers

Operators

This user role has the second highest level of privileges. Operators have unrestricted view access and can perform the following functions:

- Modify their passwords
- Tune signatures
- Manage routers
- Assign configuration to a virtual sensor

Viewers

This user role has the lowest level of privileges. Viewers can view configuration and event data and can modify their passwords.



Tip

Monitoring applications only require viewer access to the sensor. You can use the CLI to set up a user account with viewer privileges and then configure the event viewer to use this account to connect to the sensor.

Service

This user role does not have direct access to the CLI. Service account users are logged directly into a bash shell. Use this account for support and troubleshooting purposes only. Unauthorized modifications are not supported and require the device to be reimaged to guarantee proper operation. You can create only one user with the service role. In the service account you can also switch to user root by executing **su-**. The root password is synchronized to the service account password. Some troubleshooting procedures may require you to execute commands as the root user.

When you log in to the service account, you receive the following warning:

```
***** WARNING *****
UNAUTHORIZED ACCESS TO THIS NETWORK DEVICE IS PROHIBITED.
This account is intended to be used for support and troubleshooting purposes only.
Unauthorized modifications are not supported and will require this device to be re-imaged
to guarantee proper operation.
*****
```



Note

The service role is a special role that allows you to bypass the CLI if needed. Only a user with administrator privileges can edit the service account.



Note

For IPS 5.0 and later, you can no longer remove the **cisco** account. You can disable it using the **no password cisco** command, but you cannot remove it. To use the **no password cisco** command, there must be another administrator account on the sensor. Removing the **cisco** account through the service account is not supported. If you remove the **cisco** account through the service account, the sensor most likely will not boot up, so to recover the sensor you must reinstall the sensor system image.

CLI Behavior

The following tips help you use the Cisco IPS CLI.

Prompts

- You cannot change the prompt displayed for the CLI commands.
- User interactive prompts occur when the system displays a question and waits for user input. The default input is displayed inside brackets []. To accept the default input, press **Enter**.

Help

- To display the help for a command, type **?** after the command.

The following example demonstrates the **?** function:

```
sensor# configure ?  
terminal      Configure from the terminal  
sensor# configure
```



Note When the prompt returns from displaying help, the command previously entered is displayed without the **?**.

- You can type **?** after an incomplete token to view the valid tokens that complete the command. If there is a trailing space between the token and the **?**, you receive an ambiguous command error:

```
sensor# show c ?  
% Ambiguous command: "show c"
```

If you enter the token without the space, a selection of available tokens for the completion (with no help description) appears:

```
sensor# show c?  
clock configuration  
sensor# show c
```

- Only commands available in the current mode are displayed by help.

Tab Completion

- Only commands available in the current mode are displayed by tab complete and help.
- If you are unsure of the complete syntax for a command, you can type a portion of the command and press **Tab** to complete the command.
- If multiple commands match for tab completion, nothing is displayed.

Recall

- To recall the commands entered in a mode, use the Up Arrow or Down Arrow keys or press **Ctrl-P** or **Ctrl-N**.



Note Help and tab complete requests are not reported in the recall list.

- A blank prompt indicates the end of the recall list.

Case Sensitivity

- The CLI is not case sensitive, but it does echo back the text in the same case you typed it. For example, if you type:

```
sensor# CONF
```

and press **Tab**, the sensor displays:

```
sensor# CONFigure
```

**Note**

CLI commands are not case sensitive, but values are case sensitive. Remember this when you are creating regular expressions in signatures. A regular expression of “STRING” will not match “string” seen in a packet.

Display Options

- More--** is an interactive prompt that indicates that the terminal output exceeds the allotted display space. To display the remaining output, press the **spacebar** to display the next page of output or press **Enter** to display the output one line at a time.
- To clear the current line contents and return to a blank command line, press **Ctrl-C**.

For More Information

For more information on CLI command regular expression syntax, see [Regular Expression Syntax, page 1-8](#).

Command Line Editing

[Table 1-1](#) describes the command line editing capabilities provided by the Cisco IPS CLI.

Table 1-1 Command Line Editing

Keys	Description
Tab	Completes a partial command name entry. When you type a unique set of characters and press Tab, the system completes the command name. If you type a set of characters that could indicate more than one command, the system beeps to indicate an error. Type a question mark (?) immediately following the partial command (no space). The system provides a list of commands that begin with that string.
Backspace	Erases the character to the left of the cursor.
Enter	At the command line, pressing Enter processes a command. At the --More-- prompt on a terminal screen, pressing Enter scrolls down a line.
Spacebar	Enables you to see more output on the terminal screen. Press the Spacebar when you see the line --More-- on the screen to display the next screen.
Left arrow	Moves the cursor one character to the left. When you type a command that extends beyond a single line, you can press the Left Arrow key repeatedly to scroll back toward the system prompt and verify the beginning of the command entry.
Right arrow	Moves the cursor one character to the right.
Up Arrow or Ctrl-P	Recalls commands in the history buffer, beginning with the most recent command. Repeat the key sequence to recall successively older commands.

Table 1-1 *Command Line Editing (continued)*

Keys	Description
Down Arrow or Ctrl-N	Returns to more recent commands in the history buffer after recalling commands with the Up Arrow or Ctrl-P. Repeat the key sequence to recall successively more recent commands.
Ctrl-A	Moves the cursor to the beginning of the line.
Ctrl-B	Moves the cursor back one character.
Ctrl-D	Deletes the character at the cursor.
Ctrl-E	Moves the cursor to the end of the command line.
Ctrl-F	Moves the cursor forward one character.
Ctrl-K	Deletes all characters from the cursor to the end of the command line.
Ctrl-L	Clears the screen and redisplay the system prompt and command line
Ctrl-T	Transposes the character to the left of the cursor with the character located at the cursor.
Ctrl-U	Deletes all characters from the cursor to the beginning of the command line.
Ctrl-V	Inserts a code to indicate to the system that the keystroke immediately following should be treated as a command entry, <i>not</i> as an editing key.
Ctrl-W	Deletes the word to the left of the cursor.
Ctrl-Y	Recalls the most recent entry in the delete buffer. The delete buffer contains the last ten items you deleted or cut.
Ctrl-Z	Ends configuration mode and returns you to the EXEC prompt.
Esc-B	Moves the cursor back one word.
Esc-C	Capitalizes the word at the cursor.
Esc-D	Deletes from the cursor to the end of the word.
Esc-F	Moves the cursor forward one word.
Esc-L	Changes the word at the cursor to lowercase.
Esc-U	Capitalizes from the cursor to the end of the word.

IPS Command Modes

The Cisco IPS CLI has the following command modes:

- privileged EXEC—Entered when you log in to the CLI interface.
- global configuration—Entered from privileged EXEC mode by entering **configure terminal**. The command prompt is `sensor(config)#`.
- service mode configuration—Entered from global configuration mode by entering **service service-name**. The command prompt is `sensor(config-ser)#`, where `ser` is the first three characters of the service name.
- multi-instance service mode—Entered from global configuration mode by entering **service service-name component-instance-name**. The command prompt is `sensor(config-com)#` where `com` is the first three characters of the component instance name. The only multi-instance services in the system are anomaly detection, signature definition, and event action rules.

Regular Expression Syntax

**Note**

The syntax in this section applies only to regular expressions used as part of a CLI command. It does not apply to regular expressions used by signatures.

Regular expressions are text patterns that are used for string matching. Regular expressions contain a mix of plain text and special characters to indicate what kind of matching to do. For example, if you are looking for a numeric digit, the regular expression to search for is “[0-9]”. The brackets indicate that the character being compared should match any one of the characters enclosed within the bracket. The dash (-) between 0 and 9 indicates that it is a range from 0 to 9. Therefore, this regular expression will match any character from 0 to 9, that is, any digit.

To search for a specific special character, you must use a backslash before the special character. For example, the single character regular expression “*” matches a single asterisk.

The regular expressions defined in this section are similar to a subset of the POSIX Extended Regular Expression definitions. In particular, “[.]”, “[==]”, and “[::]” expressions are not supported. Also, escaped expressions representing single characters are supported. A character can be represented as its hexadecimal value, for example, \x61 equals ‘a,’ so \x61 is an escaped expression representing the character ‘a.’

The regular expressions are case sensitive. To match “STRING” or “string” use the following regular expression: “[Ss][Tt][Rr][Ii][Nn][Gg].”

Table 1-2 lists the special characters.

Table 1-2 Regular Expression Syntax

Character	Description
^	Beginning of the string. The expression “^A” will match an “A” only at the beginning of the string.
^	Immediately following the left-bracket ([). Excludes the remaining characters within brackets from matching the target string. The expression “[^0-9]” indicates that the target character should not be a digit.
\$	Matches the end of the string. The expression “abc\$” matches the sub-string “abc” only if it is at the end of the string.
	Allows the expression on either side to match the target string. The expression “alb” matches “a” as well as “b.”
.	Matches any character.
*	Indicates that the character to the left of the asterisk in the expression should match 0 or more times.
+	Similar to * but there should be at least one match of the character to the left of the + sign in the expression.
?	Matches the character to its left 0 or 1 times.
()	Affects the order of pattern evaluation and also serves as a tagged expression that can be used when replacing the matched sub-string with another expression.

Table 1-2 *Regular Expression Syntax (continued)*

Character	Description
[]	Enclosing a set of characters indicates that any of the enclosed characters may match the target character.
\	<p>Allows specifying a character that would otherwise be interpreted as special.</p> <p>\xHH represents the character whose value is the same as the value represented by (HH) hexadecimal digits [0-9A-Fa-f]. The value must be non-zero.</p> <p>BEL is the same as \x07, BS is \x08, FF is \x0C, LF is \x0A, CR is \x0D, TAB is \x09, and VT is \x0B.</p> <p>For any other character 'c', '\c' is the same as 'c' except that it is never interpreted as special</p>

The following examples demonstrate the special characters:

- **a*** matches any number of occurrences of the letter a, including none.
- **a+** requires that at least one letter a be in the string to be matched.
- **ba?b** matches the string bb or bab.
- ****** matches any number of asterisks (*).

To use multipliers with multiple-character patterns, you enclose the pattern in parentheses.

- **(ab)*** matches any number of the multiple-character string ab.
- **([A-Za-z][0-9])+** matches one or more instances of alphanumeric pairs, but not none (that is, an empty string is not a match).

The order for matches using multipliers (*, +, or ?) is to put the longest construct first. Nested constructs are matched from outside to inside. Concatenated constructs are matched beginning at the left side of the construct. Thus, the regular expression matches A9b3, but not 9Ab3 because the letters are specified before the numbers.

You can also use parentheses around a single- or multiple-character pattern to instruct the software to remember a pattern for use elsewhere in the regular expression.

To create a regular expression that recalls a previous pattern, you use parentheses to indicate memory of a specific pattern and a backslash (\) followed by a digit to reuse the remembered pattern. The digit specifies the occurrence of a parentheses in the regular expression pattern. If you have more than one remembered pattern in your regular expression, \1 indicates the first remembered pattern, and \2 indicates the second remembered pattern, and so on.

The following regular expression uses parentheses for recall:

- **a(.)bc(.)\1\2** matches an *a* followed by any character, followed by *bc* followed by any character, followed by the first *any* character again, followed by the second *any* character again.

For example, the regular expression can match aZbcTZT. The software remembers that the first character is Z and the second character is T and then uses Z and T again later in the regular expression.

Generic CLI Commands

The following CLI commands are generic to the Cisco IPS.

- **configure terminal**—Enters global configuration mode.

Global configuration commands apply to features that affect the system as a whole rather than just one protocol or interface.

```
sensor# configure terminal
sensor(config)#
```

- **service**—Takes you to the following configuration submodes: analysis-engine, anomaly-detection, authentication, event-action-rules, external-product-interfaces, health-monitor, host, interface, logger, network-access, notification, signature-definition, ssh-known-hosts, trusted-certificates, and web-server.



Note

The anomaly-detection, event-action-rules, and signature-definition submodes are multiple instance services. One predefined instance is allowed for each. For anomaly-detection, the predefined instance name is ad0. For event-action-rules, the predefined instance name is rules0. For signature-definition, the predefined instance name is sig0. You can create additional instances.

```
sensor# configure terminal
sensor(config)# service event-action-rules rules0
sensor(config-rul)#
```

- **end**—Exits configuration mode or any configuration submodes. It takes you back to the top-level EXEC menu.

```
sensor# configure terminal
sensor(config)# end
sensor#
```

- **exit**—Exits any configuration mode or closes an active terminal session and terminates the EXEC mode. It takes you to the previous menu session.

```
sensor# configure terminal
sensor(config)# service event-action-rules rules0
sensor(config-rul)# exit
sensor(config)# exit
sensor#
```

CLI Keywords

In general, use the **no** form of a command to disable a feature or function. Use the command without the keyword **no** to enable a disabled feature or function. For example, the command **ssh host-key ip_address** adds an entry to the known hosts table, the command **no ssh host-key ip_address** removes the entry from the known hosts table. Refer to the individual commands for a complete description of what the **no** form of that command does.

Service configuration commands can also have a default form. Use the **default** form of the command to return the command setting to its default. This keyword applies to the **service** submenu commands used for application configuration. Entering **default** with the command resets the parameter to the default value. You can only use the **default** keyword with commands that specify a default value in the configuration files.



Logging In to the Sensor

This chapter explains how to log in to the sensor. It contains the following sections:

- [Logging In Notes and Caveats, page 2-1](#)
- [Supported User Roles, page 2-1](#)
- [Logging In to the Appliance, page 2-2](#)
- [Connecting an Appliance to a Terminal Server, page 2-3](#)
- [Logging In to the ASA 5500 AIP SSM, page 2-4](#)
- [Logging In to the ASA 5500-X IPS SSP, page 2-5](#)
- [Logging In to the ASA 5585-X IPS SSP, page 2-6](#)
- [Logging In to the Sensor, page 2-7](#)

Logging In Notes and Caveats

The following notes and caveats apply to logging in to the sensor:

- All IPS platforms allow ten concurrent log in sessions.
- The service role is a special role that allows you to bypass the CLI if needed. Only a user with administrator privileges can edit the service account.
- You must initialize the appliance (run the **setup** command) from the console. After networking is configured, SSH and Telnet are available. You can log in to the appliance from a console port.
- You log in to the ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP from the adaptive security appliance.

Supported User Roles

You can log in with the following user privileges:

- Administrator
- Operator
- Viewer
- Service

The service role does not have direct access to the CLI. Service account users are logged directly into a bash shell. Use this account for support and troubleshooting purposes only. Unauthorized modifications are not supported and will require the sensor to be reimaged to guarantee proper operation. You can create only one user with the service role.

When you log in to the service account, you receive the following warning:

```
***** WARNING *****
UNAUTHORIZED ACCESS TO THIS NETWORK DEVICE IS PROHIBITED.
This account is intended to be used for support and troubleshooting purposes only.
Unauthorized modifications are not supported and will require this device to be re-imaged
to guarantee proper operation.
*****
```



Note

The service role is a special role that allows you to bypass the CLI if needed. Only a user with administrator privileges can edit the service account.

For More Information

- For the procedure for creating the service account, see [Creating the Service Account, page 4-26](#).
- For the procedures for adding and deleting users, see [Configuring Authentication and User Parameters, page 4-16](#).

Logging In to the Appliance



Note

You can log in to the appliance from a console port. The currently supported Cisco IPS appliances are the IPS 4240, IPS 4255, and IPS 4260 [IPS 7.1(5) and later], IPS 4270-20 [IPS 7.1(3) and later], IPS 4345 and IPS 4360 [IPS 7.1(3) and later], and IPS 4510 and IPS 4520 [IPS 7.1(4) and later].

To log in to the appliance, follow these steps:

Step 1 Connect a console port to the sensor to log in to the appliance.

Step 2 Enter your username and password at the login prompt.



Note

The default username and password are both **cisco**. You are prompted to change them the first time you log in to the appliance. You must first enter the UNIX password, which is **cisco**. Then you must enter the new password twice.

```
login: cisco
```

```
Password:
```

```
***NOTICE***
```

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at:
<http://www.cisco.com/wwl/export/crypto/tool/stqrg.html>

If you require further assistance please contact us by sending email to export@cisco.com.

```
***LICENSE NOTICE***
There is no license key installed on the system.
Please go to http://www.cisco.com/go/license to obtain a new license or install a license.
sensor#
```

For More Information

- For the procedure for connecting an appliance to a terminal server, see [Connecting an Appliance to a Terminal Server, page 2-3](#).
- For the procedure for using the **setup** command to initialize the appliance, see [Basic Sensor Setup, page 3-5](#).

Connecting an Appliance to a Terminal Server

A terminal server is a router with multiple, low speed, asynchronous ports that are connected to other serial devices. You can use terminal servers to remotely manage network equipment, including appliances. To set up a Cisco terminal server with RJ-45 or hydra cable assembly connections, follow these steps:

-
- Step 1** Connect to a terminal server using one of the following methods:
- For terminal servers with RJ-45 connections, connect a rollover cable from the console port on the appliance to a port on the terminal server.
 - For hydra cable assemblies, connect a straight-through patch cable from the console port on the appliance to a port on the terminal server.
- Step 2** Configure the line and port on the terminal server. In enable mode, enter the following configuration, where # is the line number of the port to be configured.
- ```
config t
line #
login
transport input all
stopbits 1
flowcontrol hardware
speed 9600
exit
exit
wr mem
```
- Step 3** Be sure to properly close a terminal session to avoid unauthorized access to the appliance. If a terminal session is not stopped properly, that is, if it does not receive an exit(0) signal from the application that initiated the session, the terminal session can remain open. When terminal sessions are not stopped properly, authentication is not performed on the next session that is opened on the serial port.



#### Caution

Always exit your session and return to a login prompt before terminating the application used to establish the connection.

---

**Caution**

If a connection is dropped or terminated by accident, you should reestablish the connection and exit normally to prevent unauthorized access to the appliance.

## Logging In to the ASA 5500 AIP SSM

You log in to the ASA 5500 AIP SSM from the adaptive security appliance.

To session in to the ASA 5500 AIP SSM from the adaptive security appliance, follow these steps:

**Step 1** Log in to the adaptive security appliance.

**Note**

If the adaptive security appliance is operating in multi-mode, use the **change system** command to get to the system level prompt before continuing.

**Step 2** Session to the ASA 5500 AIP SSM. You have 60 seconds to log in before the session times out.

```
asa# session 1
Opening command session with slot 1.
Connected to slot 1. Escape character sequence is 'CTRL-^X'.
```

**Step 3** Enter your username and password at the login prompt.

**Note**

The default username and password are both **cisco**. You are prompted to change them the first time you log in to the module. You must first enter the UNIX password, which is **cisco**. Then you must enter the new password twice.

```
login: cisco
Password:
NOTICE
This product contains cryptographic features and is subject to United States and local
country laws governing import, export, transfer and use. Delivery of Cisco cryptographic
products does not imply third-party authority to import, export, distribute or use
encryption. Importers, exporters, distributors and users are responsible for compliance
with U.S. and local country laws. By using this product you agree to comply with
applicable laws and regulations. If you are unable to comply with U.S. and local laws,
return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at:
http://www.cisco.com/wwl/export/crypto/tool/stqrg.html

If you require further assistance please contact us by sending email to export@cisco.com.

LICENSE NOTICE
There is no license key installed on the system.
Please go to http://www.cisco.com/go/license to obtain a new license or install a license.
aip-ssm#
```

- Step 4** To escape from a session and return to the adaptive security appliance prompt, do one of the following:
- Enter **exit**.
  - Press **CTRL-Shift-6-x** (represented as **CTRL^X**).

#### For More Information

For the procedure for using the **setup** command to initialize the ASA 5500 AIP SSM, see [Advanced Setup for the ASA 5500 AIP SSM, page 3-14](#).

## Logging In to the ASA 5500-X IPS SSP

You log in to the ASA 5500-X IPS SSP from the adaptive security appliance.

To session in to the ASA 5500-X IPS SSP from the adaptive security appliance, follow these steps:

- Step 1** Log in to the adaptive security appliance.



**Note** If the adaptive security appliance is operating in multi-mode, use the **change system** command to get to the system level prompt before continuing.

- Step 2** Session to the IPS. You have 60 seconds to log in before the session times out.

```
asa# session ips
Opening command session with slot 1.
Connected to slot 1. Escape character sequence is 'CTRL-^X'.
```

- Step 3** Enter your username and password at the login prompt.



**Note** The default username and password are both **cisco**. You are prompted to change them the first time you log in to the module. You must first enter the UNIX password, which is **cisco**. Then you must enter the new password twice.

```
login: cisco
Password:
NOTICE
This product contains cryptographic features and is subject to United States and local
country laws governing import, export, transfer and use. Delivery of Cisco cryptographic
products does not imply third-party authority to import, export, distribute or use
encryption. Importers, exporters, distributors and users are responsible for compliance
with U.S. and local country laws. By using this product you agree to comply with
applicable laws and regulations. If you are unable to comply with U.S. and local laws,
return this product immediately.
```

A summary of U.S. laws governing Cisco cryptographic products may be found at:  
<http://www.cisco.com/wwl/export/crypto/tool/stqrg.html>

If you require further assistance please contact us by sending email to [export@cisco.com](mailto:export@cisco.com).

```
LICENSE NOTICE
There is no license key installed on this IPS platform.
The system will continue to operate with the currently installed
signature set. A valid license must be obtained in order to apply
```

signature updates. Please go to <http://www.cisco.com/go/license> to obtain a new license or install a license.

asa-ips#

- Step 4** To escape from a session and return to the adaptive security appliance prompt, do one of the following:
- Enter **exit**.
  - Press **CTRL-Shift-6-x** (represented as **CTRL^X**).

#### For More Information

For the procedure for using the **setup** command to initialize the ASA 5500-X IPS SSP, see [Advanced Setup for the ASA 5500-X IPS SSP, page 3-18](#).

## Logging In to the ASA 5585-X IPS SSP

You log in to the ASA 5585-X IPS SSP from the adaptive security appliance.

To session in to the ASA 5585-X IPS SSP from the adaptive security appliance, follow these steps:

- Step 1** Log in to the adaptive security appliance.



**Note** If the adaptive security appliance is operating in multi-mode, use the **change system** command to get to the system level prompt before continuing.

- Step 2** Session to the ASA 5585-X IPS SSP. You have 60 seconds to log in before the session times out.

```
asa# session 1
Opening command session with slot 1.
Connected to slot 1. Escape character sequence is 'CTRL-^X'.
```

- Step 3** Enter your username and password at the login prompt.



**Note** The default username and password are both **cisco**. You are prompted to change them the first time you log in to the module. You must first enter the UNIX password, which is **cisco**. Then you must enter the new password twice.

```
login: cisco
Password:
NOTICE
```

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at:  
<http://www.cisco.com/wwl/export/crypto/tool/stqrg.html>

If you require further assistance please contact us by sending email to [export@cisco.com](mailto:export@cisco.com).

```
LICENSE NOTICE
There is no license key installed on the system.
Please go to http://www.cisco.com/go/license to obtain a new license or install a license.
ips-ssp#
```

- Step 4** To escape from a session and return to the adaptive security appliance prompt, do one of the following:
- Enter **exit**.
  - Press **CTRL-Shift-6-x** (represented as **CTRL^X**).

#### For More Information

For the procedure for using the **setup** command to initialize the ASA 5585-X IPS SSP, see [Advanced Setup for the ASA 5585-X IPS SSP, page 3-21](#).

## Logging In to the Sensor



#### Note

After you have initialized the sensor using the **setup** command and enabled Telnet, you can use SSH or Telnet to log in to the sensor.

To log in to the sensor using Telnet or SSH, follow these steps:

- Step 1** To log in to the sensor over the network using SSH or Telnet.

```
ssh sensor_ip_address
telnet sensor_ip_address
```

- Step 2** Enter your username and password at the login prompt.

```
login: *****
Password: *****
NOTICE
```

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable law s and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at:  
<http://www.cisco.com/ww1/export/crypto/tool/stqrg.html>

If you require further assistance please contact us by sending email to [export@cisco.com](mailto:export@cisco.com).

```
LICENSE NOTICE
There is no license key installed on the system.
Please go to http://www.cisco.com/go/license to obtain a new license or install a license.
sensor#
```







## Initializing the Sensor

---

This chapter describes how to use the **setup** command to initialize the sensor, and contains the following sections:

- [Initializing Notes and Caveats, page 3-1](#)
- [Understanding Initialization, page 3-2](#)
- [Participating in the SensorBase Network, page 3-2](#)
- [Simplified Setup Mode, page 3-3](#)
- [System Configuration Dialog, page 3-3](#)
- [Basic Sensor Setup, page 3-5](#)
- [Advanced Setup, page 3-8](#)
- [Advanced Setup, page 3-8](#)
- [Verifying Initialization, page 3-25](#)

## Initializing Notes and Caveats

The following notes and caveats apply to initializing the sensor:

- You must be administrator to use the **setup** command.
- You must have a valid sensor license for global correlation features to function. You can still configure and display statistics for the global correlation features, but the global correlation databases are cleared and no updates are attempted. Once you install a valid license, the global correlation features are reactivated.
- The currently supported Cisco IPS appliances are the IPS 4240, IPS 4255, and IPS 4260 [IPS 7.1(5) and later], IPS 4270-20 [IPS 7.1(3) and later], IPS 4345 and IPS 4360 [IPS 7.1(3) and later], and IPS 4510 and IPS 4520 [IPS 7.1(4) and later].
- You do not need to configure interfaces on the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP). You should ignore the modify interface default VLAN setting in setup. The separation of traffic across virtual sensors is configured differently for the ASA IPS modules than for other sensors.

# Understanding Initialization

After you install the sensor on your network, you must use the **setup** command to initialize it so that you can communicate with it over the network. You cannot use the IDM or the IME to configure the sensor until you initialize the sensor using the **setup** command.

With the **setup** command, you configure basic sensor settings, including the hostname, IP interfaces, access control lists, global correlation servers, and time settings. You can continue using advanced setup in the CLI to enable Telnet, configure the web server, and assign and enable virtual sensors and interfaces, or you can use the Startup Wizard in the IDM or the IME. After you configure the sensor with the **setup** command, you can change the network settings in the IDM or the IME.

**Note**

You must be administrator to use the **setup** command.

## Participating in the SensorBase Network

The Cisco IPS contains a security capability, Cisco Global Correlation, which uses the immense security intelligence that we have amassed over the years. At regular intervals, the Cisco IPS receives threat updates from the Cisco SensorBase Network, which contain detailed information about known threats on the Internet, including serial attackers, Botnet harvesters, Malware outbreaks, and dark nets. The IPS uses this information to filter out the worst attackers before they have a chance to attack critical assets. It then incorporates the global threat data in to its system to detect and prevent malicious activity even earlier.

If you agree to participate in the SensorBase Network, Cisco will collect aggregated statistics about traffic sent to your IPS. This includes summary data on the Cisco IPS network traffic properties and how this traffic was handled by the Cisco appliances. We do not collect the data content of traffic or other confidential business or personal information. All data is aggregated and sent by secure HTTP to the Cisco SensorBase Network servers in periodic intervals. All data shared with Cisco will be anonymous and treated as strictly confidential.

Table 3-1 shows how we use the data.

**Table 3-1** Cisco Network Participation Data Use

| Participation Level | Type of Data                                                                                 | Purpose                                                              |
|---------------------|----------------------------------------------------------------------------------------------|----------------------------------------------------------------------|
| Partial             | Protocol attributes (TCP maximum segment size and options string, for example)               | Tracks potential threats and helps us to understand threat exposure. |
|                     | Attack type (signature fired and risk rating, for example)                                   | Used to understand current attacks and attack severity.              |
|                     | Connecting IP address and port                                                               | Identifies attack source.                                            |
|                     | Summary IPS performance (CPU utilization, memory usage, inline vs. promiscuous, for example) | Tracks product efficacy.                                             |
| Full                | Victim IP address and port                                                                   | Detects threat behavioral patterns.                                  |

When you enable Partial or Full Network Participation, the Network Participation Disclaimer appears. You must click **Agree** to participate. If you do not have a license installed, you receive a warning telling you that global correlation inspection and reputation filtering are disabled until the sensor is licensed. You can obtain a license at <http://www.cisco.com/go/license>.

#### For More Information

- For more information about global correlation, see [Chapter 10, “Configuring Global Correlation.”](#)
- For the procedure for obtaining a sensor license, see [Installing the License Key, page 4-56](#).

## Simplified Setup Mode

The sensor automatically calls the **setup** command when you connect to the sensor using a console cable and the sensor basic network settings have not yet been configured. The sensor does not call automatic setup under the following conditions:

- When initialization has already been successfully completed.
- If you have recovered or downgraded the sensor.
- If you have set the host configuration to default after successfully configuring the sensor using automatic setup.

When you enter the **setup** command, an interactive dialog called the System Configuration Dialog appears on the system console screen. The System Configuration Dialog guides you through the configuration process. The values shown in brackets next to each prompt are the default values last set.

## System Configuration Dialog

When you enter the **setup** command, an interactive dialog called the System Configuration Dialog appears on the system console screen. The System Configuration Dialog guides you through the configuration process. The values shown in brackets next to each prompt are the current values.

You must go through the entire System Configuration Dialog until you come to the option that you want to change. To accept default settings for items that you do not want to change, press **Enter**.

To return to the EXEC prompt without making changes and without going through the entire System Configuration Dialog, press **Ctrl-C**. The System Configuration Dialog also provides help text for each prompt. To access the help text, enter **?** at a prompt.

When you complete your changes, the System Configuration Dialog shows you the configuration that you created during the setup session. It also asks you if you want to use this configuration. If you enter **yes**, the configuration is saved. If you enter **no**, the configuration is not saved and the process begins again. There is no default for this prompt; you must enter either **yes** or **no**.

You can configure daylight savings time either in recurring mode or date mode. If you choose recurring mode, the start and end days are based on week, day, month, and time. If you choose date mode, the start and end days are based on month, day, year, and time. Choosing disable turns off daylight savings time.



#### Note

You only need to set the date and time in the System Configuration Dialog if the system is an appliance and is NOT using NTP.

**Note**

The System Configuration Dialog is an interactive dialog. The default settings are displayed.

[Example 3-1](#) shows a sample System Configuration Dialog.

**Example 3-1 Example System Configuration Dialog**

```
--- Basic Setup ---
```

```
--- System Configuration Dialog ---
```

At any point you may enter a question mark '?' for help.  
User ctrl-c to abort configuration dialog at any prompt.  
Default settings are in square brackets '['].

```
Current time: Wed Nov 11 21:19:51 2009
```

```
Setup Configuration last modified:
```

```
Enter host name[sensor]:
Enter IP interface[192.168.1.2/24,192.168.1.1]:
Modify current access list?[no]:
Current access list entries:
 [1] 0.0.0.0/0
Delete:
Permit:
Use DNS server for Global Correlation?[no]:
 DNS server IP address[171.68.226.120]:
Use HTTP proxy server for Global Correlation?[no]:
 HTTP proxy server IP address[128.107.241.169]:
 HTTP proxy server Port number[8080]:
Modify system clock settings?[no]: yes
 Modify summer time settings?[no]:yes
 Use USA SummerTime Defaults?[yes]:no
 Recurring, Date or Disable?[Recurring]:
 Start Month[march]:
 Start Week[second]:
 Start Day[sunday]:
 Start Time[02:00:00]:
 End Month[november]:
 End Week[first]:
 End Day[sunday]:
 End Time[02:00:00]:
 DST Zone[]:
 Offset[60]:
 Modify system timezone?[no]:
 Timezone[UTC]:
 UTC Offset[0]:
 Use NTP?[no]: yes
 NTP Server IP Address[]:
 Use NTP Authentication?[no]: yes
 NTP Key ID[]: 1
 NTP Key Value[]: 8675309
Participation in the SensorBase Network allows Cisco to collect aggregated statistics
about traffic sent to your IPS.
SensorBase Network Participation level?[off]: full

If you agree to participate in the SensorBase Network, Cisco will collect aggregated
statistics about traffic sent to your IPS.
```

This includes summary data on the Cisco IPS network traffic properties and how this traffic was handled by the Cisco appliances. We do not collect the data content of traffic or other sensitive business or personal information. All data is aggregated and sent via secure HTTP to the Cisco SensorBase Network servers in periodic intervals. All data shared with Cisco will be anonymous and treated as strictly confidential.

The table below describes how the data will be used by Cisco.

Participation Level = "Partial":

- \* Type of Data: Protocol Attributes (e.g. TCP max segment size and options string)  
Purpose: Track potential threats and understand threat exposure
- \* Type of Data: Attack Type (e.g. Signature Fired and Risk Rating)  
Purpose: Used to understand current attacks and attack severity
- \* Type of Data: Connecting IP Address and port  
Purpose: Identifies attack source
- \* Type of Data: Summary IPS performance (CPU utilization memory usage, inline vs. promiscuous, etc)  
Purpose: Tracks product efficacy

Participation Level = "Full" additionally includes:

- \* Type of Data: Victim IP Address and port  
Purpose: Detect threat behavioral patterns

Do you agree to participate in the SensorBase Network?[no]:

## Basic Sensor Setup

You can perform basic sensor setup using the **setup** command, and then finish setting up the sensor using the CLI, IDM, or IME. To perform basic sensor setup using the **setup** command, follow these steps:

---

**Step 1** Log in to the sensor using an account with administrator privileges.




---

**Note** Both the default username and password are **cisco**.

---

**Step 2** The first time you log in to the sensor you are prompted to change the default password. Passwords must be at least eight characters long and be strong, that is, not be a dictionary word. After you change the password, basic setup begins.

**Step 3** Enter the **setup** command. The System Configuration Dialog is displayed.

**Step 4** Specify the hostname. The hostname is a case-sensitive character string up to 64 characters. Numbers, “\_” and “-” are valid, but spaces are not acceptable. The default is sensor.

**Step 5** Specify the IP interface. The IP interface is in the form of IP Address/Netmask, Gateway: X.X.X.X/nn.Y.Y.Y.Y, where X.X.X.X specifies the sensor IP address as a 32-bit address written as 4 octets separated by periods, nn specifies the number of bits in the netmask, and Y.Y.Y.Y specifies the default gateway as a 32-bit address written as 4 octets separated by periods.

**Step 6** Enter **yes** to modify the network access list:

- a. If you want to delete an entry, enter the number of the entry and press **Enter**, or press **Enter** to get to the Permit line.
- b. Enter the IP address and netmask of the network you want to add to the access list.

**Note**

For example, 10.0.0.0/8 permits all IP addresses on the 10.0.0.0 network (10.0.0.0-10.255.255.255) and 10.1.1.0/24 permits only the IP addresses on the 10.1.1.0 subnet (10.1.1.0-10.1.1.255). If you want to permit access to a single IP address than the entire network, use a 32-bit netmask. For example, 10.1.1.1/32 permits just the 10.1.1.1 address.

- c. Repeat Step b until you have added all networks that you want to add to the access list, and then press **Enter** at a blank permit line to go to the next step.

**Step 7** You must configure a DNS server or an HTTP proxy server for global correlation to operate:

- a. Enter **yes** to add a DNS server, and then enter the DNS server IP address.
- b. Enter **yes** to add an HTTP proxy server, and then enter the HTTP proxy server IP address and port number.

**Caution**

You must have a valid sensor license for global correlation features to function. You can still configure and display statistics for the global correlation features, but the global correlation databases are cleared and no updates are attempted. Once you install a valid license, the global correlation features are reactivated.

**Step 8** Enter **yes** to modify the system clock settings:

- a. Enter **yes** to modify summertime settings.

**Note**

Summertime is also known as DST. If your location does not use Summertime, go to Step m.

- b. Enter **yes** to choose the USA summertime defaults, or enter **no** and choose recurring, date, or disable to specify how you want to configure summertime settings. The default is recurring.
- c. If you chose recurring, specify the month you want to start summertime settings. Valid entries are january, february, march, april, may, june, july, august, september, october, november, and december. The default is march.
- d. Specify the week you want to start summertime settings. Valid entries are first, second, third, fourth, fifth, and last. The default is second.
- e. Specify the day you want to start summertime settings. Valid entries are sunday, monday, tuesday, wednesday, thursday, friday, and saturday. The default is sunday.
- f. Specify the time you want to start summertime settings. The default is 02:00:00.

**Note**

The default recurring summertime parameters are correct for time zones in the United States. The default values specify a start time of 2:00 a.m. on the second Sunday in March, and a stop time of 2:00 a.m. on the first Sunday in November. The default summertime offset is 60 minutes.

- g. Specify the month you want summertime settings to end. Valid entries are january, february, march, april, may, june, july, august, september, october, november, and december. The default is november.
- h. Specify the week you want the summertime settings to end. Valid entries are first, second, third, fourth, fifth, and last. The default is first.

- i. Specify the day you want the summertime settings to end. Valid entries are sunday, monday, tuesday, wednesday, thursday, friday, and saturday. The default is sunday.
- j. Specify the time you want summertime settings to end. The default is 02:00:00.
- k. Specify the DST zone. The zone name is a character string up to 24 characters long in the pattern [A-Za-z0-9()+:;\_-]+\$.
- l. Specify the summertime offset. Specify the summertime offset from UTC in minutes (negative numbers represent time zones west of the Prime Meridian). The default is 60.
- m. Enter **yes** to modify the system time zone.
- n. Specify the standard time zone name. The zone name is a character string up to 24 characters long.
- o. Specify the standard time zone offset. Specify the standard time zone offset from UTC in minutes (negative numbers represent time zones west of the Prime Meridian). The default is 0.
- p. Enter **yes** if you want to use NTP. To use authenticated NTP, you need the NTP server IP address, the NTP key ID, and the NTP key value. If you do not have those at this time, you can configure NTP later. Otherwise, you can choose unauthenticated NTP.

**Step 9** Enter **off**, **partial**, or **full** to participate in the SensorBase Network Participation:

- Off—No data is contributed to the SensorBase Network.
- Partial—Data is contributed to the SensorBase Network, but data considered potentially sensitive is filtered out and never sent.
- Full—All data is contributed to the SensorBase Network except the attacker/victim IP addresses that you exclude.

The SensorBase Network Participation disclaimer appears. It explains what is involved in participating in the SensorBase Network.

**Step 10** Enter **yes** to participate in the SensorBase Network.

```
The following configuration was entered.
service host
network-settings
host-ip 192.168.1.2/24, 192.168.1.1
host-name sensor
telnet-option disabled
sshd1-fallback enabled
access-list 10.0.0.0/8
ftp-timeout 300
no login-banner-text
dns-primary-server enabled
address 171.68.226.120
exit
dns-secondary-server disabled
dns-tertiary-server disabled
http-proxy proxy-server
address 128.107.241.170
port 8080
exit
time-zone-settings
offset -360
standard-time-zone-name CST
exit
summertime-option recurring
offset 60
summertime-zone-name CDT
start-summertime
month march
week-of-month second
```

```

day-of-week sunday
time-of-day 02:00:00
exit
end-summertime
month november
week-of-month first
day-of-week sunday
time-of-day 02:00:00
exit
exit
ntp-option enabled
ntp-keys 1 md5-key 8675309
ntp-servers 10.10.1.2 key-id 1
exit
service global-correlation
network-participation full
exit

```

```

[0] Go to the command prompt without saving this config.
[1] Return to setup without saving this config.
[2] Save this configuration and exit setup.
[3] Continue to Advanced setup.

```

**Step 11** Enter **2** to save the configuration (or **3** to continue with advanced setup using the CLI).

```

Enter your selection[2]: 2
Configuration Saved.

```

**Step 12** If you changed the time setting, enter **yes** to reboot the sensor.

#### For More Information

For the procedure for obtaining the most recent IPS software, see [Obtaining Cisco IPS Software](#), page 21-1.

## Advanced Setup

This section describes how to continue with Advanced Setup in the CLI for the various Cisco IPS platforms. It contains the following sections:

- [Advanced Setup for the Appliance](#), page 3-8
- [Advanced Setup for the ASA 5500 AIP SSM](#), page 3-14
- [Advanced Setup for the ASA 5500-X IPS SSP](#), page 3-18
- [Advanced Setup for the ASA 5585-X IPS SSP](#), page 3-21

## Advanced Setup for the Appliance



#### Note

The currently supported Cisco IPS appliances are the IPS 4240, IPS 4255, and IPS 4260 [IPS 7.1(5) and later], IPS 4270-20 [IPS 7.1(3) and later], IPS 4345 and IPS 4360 [IPS 7.1(3) and later], and IPS 4510 and IPS 4520 [IPS 7.1(4) and later].



**Note**

Adding new subinterfaces is a two-step process. You first organize the interfaces when you edit the virtual sensor configuration. You then choose which interfaces and subinterfaces are assigned to which virtual sensors.

The interfaces change according to the appliance model, but the prompts are the same for all models. To continue with advanced setup for the appliance, follow these steps:

- 
- Step 1** Log in to the appliance using an account with administrator privileges.
  - Step 2** Enter the **setup** command. The System Configuration Dialog is displayed. Press **Enter** or the spacebar to skip to the menu to access advanced setup.
  - Step 3** Enter **3** to access advanced setup.
  - Step 4** Specify the Telnet server status. The default is disabled.
  - Step 5** Specify the SSHv1 fallback setting. The default is enabled.
  - Step 6** Specify the web server port. The web server port is the TCP port used by the web server (1 to 65535). The default is 443.

**Note**

The web server is configured to use TLS/SSL encryption by default. Setting the port to 80 does not disable the encryption.

- 
- Step 7** Enter **yes** to modify the interface and virtual sensor configuration and to see the current interface configuration.

```
Current interface configuration
Command control: Management0/0
Unassigned:
Promiscuous:
GigabitEthernet0/0
GigabitEthernet0/1
GigabitEthernet0/2
GigabitEthernet0/3

Virtual Sensor: vs0
Anomaly Detection: ad0
Event Action Rules: rules0
Signature Definitions: sig0

Virtual Sensor: vs1
Anomaly Detection: ad0
Event Action Rules: rules0
Signature Definitions: sig0

Virtual Sensor: vs2
Anomaly Detection: ad0
Event Action Rules: rules0
Signature Definitions: sig0

[1] Edit Interface Configuration
[2] Edit Virtual Sensor Configuration
[3] Display configuration
Option:
```

- Step 8** Enter **1** to edit the interface configuration.

**Note**

The following options let you create and delete interfaces. You assign the interfaces to virtual sensors in the virtual sensor configuration. If you are using promiscuous mode for your interfaces and are not subdividing them by VLAN, no additional configuration is necessary.

```
[1] Remove interface configurations.
[2] Add/Modify Inline Vlan Pairs.
[3] Add/Modify Promiscuous Vlan Groups.
[4] Add/Modify Inline Interface Pairs.
[5] Add/Modify Inline Interface Pair Vlan Groups.
[6] Modify interface default-vlan.
```

Option:

**Step 9** Enter **2** to add inline VLAN pairs and display the list of available interfaces.

**Caution**

The new VLAN pair is not automatically added to a virtual sensor.

```
Available Interfaces
[1] GigabitEthernet0/0
[2] GigabitEthernet0/1
[3] GigabitEthernet0/2
[4] GigabitEthernet0/3
```

Option:

**Step 10** Enter **1** to add an inline VLAN pair to GigabitEthernet 0/0, for example.

```
Inline Vlan Pairs for GigabitEthernet0/0
None
```

**Step 11** Enter a subinterface number and description.

```
Subinterface Number:
Description[Created via setup by user asmith]:
```

**Step 12** Enter numbers for VLAN 1 and 2.

```
Vlan1[]: 200
Vlan2[]: 300
```

**Step 13** Press **Enter** to return to the available interfaces menu.

**Note**

Entering a carriage return at a prompt without a value returns you to the previous menu.

```
[1] GigabitEthernet0/0
[2] GigabitEthernet0/1
[3] GigabitEthernet0/2
[4] GigabitEthernet0/3
```

Option:

**Note**

At this point, you can configure another interface, for example, GigabitEthernet 0/1, for inline VLAN pair.

**Step 14** Press **Enter** to return to the top-level interface editing menu.

```
[1] Remove interface configurations.
[2] Add/Modify Inline Vlan Pairs.
```

```
[3] Add/Modify Promiscuous Vlan Groups.
[4] Add/Modify Inline Interface Pairs.
[5] Add/Modify Inline Interface Pair Vlan Groups.
[6] Modify interface default-vlan.
Option:
```

**Step 15** Enter **4** to add an inline interface pair and see these options.

```
Available Interfaces
GigabitEthernet0/1
GigabitEthernet0/2
GigabitEthernet0/3
```

**Step 16** Enter the pair name, description, and which interfaces you want to pair.

```
Pair name: newPair
Description[Created via setup by user asmith:
Interface1[]: GigabitEthernet0/1
Interface2[]: GigabitEthernet0/2
Pair name:
```

**Step 17** Press **Enter** to return to the top-level interface editing menu.

```
[1] Remove interface configurations.
[2] Add/Modify Inline Vlan Pairs.
[3] Add/Modify Promiscuous Vlan Groups.
[4] Add/Modify Inline Interface Pairs.
[5] Add/Modify Inline Interface Pair Vlan Groups.
[6] Modify interface default-vlan.
Option:
```

**Step 18** Press **Enter** to return to the top-level editing menu.

```
[1] Edit Interface Configuration
[2] Edit Virtual Sensor Configuration
[3] Display configuration
Option:
```

**Step 19** Enter **2** to edit the virtual sensor configuration.

```
[1] Remove virtual sensor.
[2] Modify "vs0" virtual sensor configuration.
[3] Create new virtual sensor.
Option:
```

**Step 20** Enter **2** to modify the virtual sensor configuration, vs0.

```
Virtual Sensor: vs0
Anomaly Detection: ad0
Event Action Rules: rules0
Signature Definitions: sig0

No Interfaces to remove.

Unassigned:
Promiscuous:
[1] GigabitEthernet0/3
[2] GigabitEthernet0/0
Inline Vlan Pair:
[3] GigabitEthernet0/0:1 (Vlans: 200, 300)
Inline Interface Pair:
[4] newPair (GigabitEthernet0/1, GigabitEthernet0/2)
Add Interface:
```

**Step 21** Enter **3** to add inline VLAN pair GigabitEthernet0/0:1.

**Step 22** Enter **4** to add inline interface pair NewPair.

**Step 23** Press **Enter** to return to the top-level virtual sensor menu.

```
Virtual Sensor: vs0
 Anomaly Detection: ad0
 Event Action Rules: rules0
 Signature Definitions: sig0
 Inline Vlan Pair:
 GigabitEthernet0/0:1 (Vlans: 200, 300)
 Inline Interface Pair:
 newPair (GigabitEthernet0/1, GigabitEthernet0/2)

[1] Remove virtual sensor.
[2] Modify "vs0" virtual sensor configuration.
[3] Create new virtual sensor.
Option: GigabitEthernet0/1, GigabitEthernet0/2
Add Interface:
```

**Step 24** Press **Enter** to return to the top-level interface and virtual sensor configuration menu.

```
[1] Edit Interface Configuration
[2] Edit Virtual Sensor Configuration
[3] Display configuration
Option:
```

**Step 25** Enter **yes** if you want to modify the default threat prevention settings.




---

**Note** The sensor comes with a built-in override to add the deny packet event action to high risk rating alerts. If you do not want this protection, disable automatic threat prevention.

---

```
Virtual sensor newVs is configured to prevent high risk threats in inline mode. (Risk
Rating 90-100)
Virtual sensor vs0 is configured to prevent high risk threats in inline mode.(Risk Rating
90-100)
Do you want to disable automatic threat prevention on all virtual sensors?[no]:
```

**Step 26** Enter **yes** to disable automatic threat prevention on all virtual sensors.

**Step 27** Press **Enter** to exit the interface and virtual sensor configuration.

```
The following configuration was entered.
service host
network-settings
host-ip 192.168.1.2/24,192.168.1.1
host-name sensor
telnet-option disabled
sshdv1-fallback enabled
ftp-timeout 300
no login-banner-text
exit
time-zone-settings
offset 0
standard-time-zone-name UTC
exit
summertime-option disabled
ntp-option disabled
exit
service web-server
port 342
exit
service interface
physical-interfaces GigabitEthernet0/0
```

```

admin-state enabled
subinterface-type inline-vlan-pair
subinterface 1
description Created via setup by user asmith
vlan1 200
vlan2 300
exit
exit
exit
physical-interfaces GigabitEthernet0/1
admin-state enabled
exit
physical-interfaces GigabitEthernet0/2
admin-state enabled
exit
physical-interfaces GigabitEthernet0/0
admin-state enabled
exit
inline-interfaces newPair
description Created via setup by user asmith
interface1 GigabitEthernet0/1
interface2 GigabitEthernet0/2
exit
exit
service analysis-engine
virtual-sensor newVs
description Created via setup by user cisco
signature-definition newSig
event-action-rules rules0
anomaly-detection
anomaly-detection-name ad0
operational-mode inactive
exit
physical-interface GigabitEthernet0/0
exit
virtual-sensor vs0
physical-interface GigabitEthernet0/0 subinterface-number 1
logical-interface newPair
service event-action-rules rules0
overrides deny-packet-inline
override-item-status Disabled
risk-rating-range 90-100
exit
exit

```

[0] Go to the command prompt without saving this config.

[1] Return back to the setup without saving this config.

[2] Save this configuration and exit setup.

**Step 28** Enter **2** to save the configuration.

```

Enter your selection[2]: 2
Configuration Saved.

```

**Step 29** Reboot the appliance.

```

sensor# reset
Warning: Executing this command will stop all applications and reboot the node.
Continue with reset? []:

```

**Step 30** Enter **yes** to continue the reboot.

- Step 31** Apply the most recent service pack and signature update. You are now ready to configure your appliance for intrusion prevention.

#### For More Information

For the procedure for obtaining the most recent IPS software, see [Obtaining Cisco IPS Software, page 21-1](#).

## Advanced Setup for the ASA 5500 AIP SSM

To continue with advanced setup for the ASA 5500 AIP SSM, follow these steps:

- Step 1** Session in to the ASA 5500 AIP SSM using an account with administrator privileges.
- ```
asa# session 1
```
- Step 2** Enter the **setup** command. The System Configuration Dialog is displayed. Press **Enter** or the spacebar to skip to the menu to access advanced setup.
- Step 3** Enter **3** to access advanced setup.
- Step 4** Specify the Telnet server status. You can disable or enable Telnet services. The default is disabled.
- Step 5** Specify the SSHv1 fallback setting. The default is enabled.
- Step 6** Specify the web server port. The web server port is the TCP port used by the web server (1 to 65535). The default is 443.



Note The web server is configured to use TLS/SSL encryption by default. Setting the port to 80 does not disable the encryption.

- Step 7** Enter **yes** to modify the interface and virtual sensor configuration.

```
Current interface configuration
Command control: Management0/0
Unassigned:
Monitored:
GigabitEthernet0/1

Virtual Sensor: vs0
Anomaly Detection: ad0
Event Action Rules: rules0
Signature Definitions: sig0

[1] Edit Interface Configuration
[2] Edit Virtual Sensor Configuration
[3] Display configuration
Option:
```

- Step 8** Enter **1** to edit the interface configuration.



Note You do not need to configure interfaces on the ASA 5500 AIP SSM. You should ignore the modify interface default VLAN setting. The separation of traffic across virtual sensors is configured differently for the ASA 5500 AIP SSM than for other sensors.

```
[1] Modify interface default-vlan.
Option:
```

Step 9 Press **Enter** to return to the top-level interface and virtual sensor configuration menu.

```
[1] Edit Interface Configuration
[2] Edit Virtual Sensor Configuration
[3] Display configuration
Option:
```

Step 10 Enter **2** to edit the virtual sensor configuration.

```
[1] Remove virtual sensor.
[2] Modify "vs0" virtual sensor configuration.
[3] Create new virtual sensor.
Option:
```

Step 11 Enter **2** to modify the virtual sensor vs0 configuration.

```
Virtual Sensor: vs0
Anomaly Detection: ad0
Event Action Rules: rules0
Signature Definitions: sig0
```

```
No Interfaces to remove.
```

```
Unassigned:
Monitored:
  [1] GigabitEthernet0/1
Add Interface:
```

Step 12 Enter **1** to add GigabitEthernet 0/1 to virtual sensor vs0.



Note

Multiple virtual sensors are supported. The adaptive security appliance can direct packets to specific virtual sensors or can send packets to be monitored by a default virtual sensor. The default virtual sensor is the virtual sensor to which you assign GigabitEthernet 0/1. We recommend that you assign GigabitEthernet 0/1 to vs0, but you can assign it to another virtual sensor if you want to.

Step 13 Press **Enter** to return to the main virtual sensor menu.

Step 14 Enter **3** to create a virtual sensor.

```
Name[]:
```

Step 15 Enter a name and description for your virtual sensor.

```
Name[]: newVs
Description[Created via setup by user cisco]: New Sensor
Anomaly Detection Configuration
  [1] ad0
  [2] Create a new anomaly detection configuration
Option[2]:
```

Step 16 Enter **1** to use the existing anomaly detection configuration, ad0.

```
Signature Definition Configuration
  [1] sig0
  [2] Create a new signature definition configuration
Option[2]:
```

Step 17 Enter **2** to create a signature-definition configuration file.

Step 18 Enter the signature-definition configuration name, **newSig**.

```
Event Action Rules Configuration
[1] rules0
[2] Create a new event action rules configuration
Option[2]:
```

Step 19 Enter **1** to use the existing event-action-rules configuration, rules0.



Note If GigabitEthernet 0/1 has not been assigned to vs0, you are prompted to assign it to the new virtual sensor.

```
Virtual Sensor: newVs
Anomaly Detection: ad0
Event Action Rules: rules0
Signature Definitions: newSig
Monitored:
  GigabitEthernet0/1

[1] Remove virtual sensor.
[2] Modify "newVs" virtual sensor configuration.
[3] Modify "vs0" virtual sensor configuration.
[4] Create new virtual sensor.
Option:
```

Step 20 Press **Enter** to exit the interface and virtual sensor configuration menu.

```
Modify default threat prevention settings?[no]:
```

Step 21 Enter **yes** if you want to modify the default threat prevention settings.



Note The sensor comes with a built-in override to add the deny packet event action to high risk rating alerts. If you do not want this protection, disable automatic threat prevention.

```
Virtual sensor newVs is configured to prevent high risk threats in inline mode. (Risk
Rating 90-100)
Virtual sensor vs0 is configured to prevent high risk threats in inline mode.(Risk Rating
90-100)
Do you want to disable automatic threat prevention on all virtual sensors?[no]:
```

Step 22 Enter **yes** to disable automatic threat prevention on all virtual sensors.

The following configuration was entered.

```
service host
network-settings
host-ip 10.1.9.201/24,10.1.9.1
host-name aip-ssm
telnet-option disabled
sshv1-fallback enabled
access-list 10.0.0.0/8
access-list 64.0.0.0/8
ftp-timeout 300
no login-banner-text
exit
time-zone-settings
offset 0
standard-time-zone-name UTC
exit
summertime-option disabled
```



```

ntp-option disabled
exit
service web-server
port 342
exit
service analysis-engine
virtual-sensor newVs
description New Sensor
signature-definition newSig
event-action-rules rules0
anomaly-detection
anomaly-detection-name ad0
exit
physical-interfaces GigabitEthernet0/1
exit
exit
service event-action-rules rules0
overrides deny-packet-inline
override-item-status Disabled
risk-rating-range 90-100
exit
exit

```

[0] Go to the command prompt without saving this config.
 [1] Return back to the setup without saving this config.
 [2] Save this configuration and exit setup.

Step 23 Enter **2** to save the configuration.

```

Enter your selection[2]: 2
Configuration Saved.

```

Step 24 Reboot the ASA 5500 AIP SSM.

```

aip-ssm# reset
Warning: Executing this command will stop all applications and reboot the node.
Continue with reset? []:

```

Step 25 Enter **yes** to continue the reboot.

Step 26 After reboot, log in to the sensor, and display the self-signed X.509 certificate (needed by TLS).

```

aip-ssm# show tls fingerprint
MD5: C4:BC:F2:92:C2:E2:4D:EB:92:0F:E4:86:53:6A:C6:01
SHA1: 64:9B:AC:DE:21:62:0C:D3:57:2E:9B:E5:3D:04:8F:A7:FD:CD:6F:27

```

Step 27 Write down the certificate fingerprints. You need the fingerprints to check the authenticity of the certificate when using HTTPS to connect to this ASA 5500 AIP SSM with a web browser.

Step 28 Apply the most recent service pack and signature update. You are now ready to configure your ASA 5500 AIP SSM for intrusion prevention.

For More Information

For the procedure for obtaining the most recent IPS software, see [Obtaining Cisco IPS Software](#), page 21-1.

Advanced Setup for the ASA 5500-X IPS SSP

To continue with advanced setup for the ASA 5500-X IPS SSP, follow these steps:

- Step 1** Session in to the IPS using an account with administrator privileges.

```
asa# session ips
```

- Step 2** Enter the **setup** command. The System Configuration Dialog is displayed. Press **Enter** or the spacebar to skip to the menu to access advanced setup.

- Step 3** Enter **3** to access advanced setup.

- Step 4** Specify the Telnet server status. You can disable or enable Telnet services. The default is disabled.

- Step 5** Specify the SSHv1 fallback setting. The default is enabled.

- Step 6** Specify the web server port. The web server port is the TCP port used by the web server (1 to 65535). The default is 443.



Note The web server is configured to use TLS/SSL encryption by default. Setting the port to 80 does not disable the encryption.

- Step 7** Enter **yes** to modify the interface and virtual sensor configuration.

```
Current interface configuration
Command control: Management0/0
Unassigned:
Monitored:
PortChannel 0/0

Virtual Sensor: vs0
Anomaly Detection: ad0
Event Action Rules: rules0
Signature Definitions: sig0

[1] Edit Interface Configuration
[2] Edit Virtual Sensor Configuration
[3] Display configuration
Option:
```

- Step 8** Enter **1** to edit the interface configuration.



Note You do not need to configure interfaces on the ASA 5500-X IPS SSP. You should ignore the modify interface default VLAN setting. The separation of traffic across virtual sensors is configured differently for the ASA 5500-X IPS SSP than for other sensors.

```
[1] Modify interface default-vlan.
Option:
```

- Step 9** Press **Enter** to return to the top-level interface and virtual sensor configuration menu.

```
[1] Edit Interface Configuration
[2] Edit Virtual Sensor Configuration
[3] Display configuration
Option:
```

Step 10 Enter **2** to edit the virtual sensor configuration.

```
[1] Remove virtual sensor.
[2] Modify "vs0" virtual sensor configuration.
[3] Create new virtual sensor.
```

Option:

Step 11 Enter **2** to modify the virtual sensor vs0 configuration.

```
Virtual Sensor: vs0
  Anomaly Detection: ad0
  Event Action Rules: rules0
  Signature Definitions: sig0
```

No Interfaces to remove.

```
Unassigned:
Monitored:
  [1] PortChannel 0/0
Add Interface:
```

Step 12 Enter **1** to add PortChannel 0/0 to virtual sensor vs0.



Note

Multiple virtual sensors are supported. The adaptive security appliance can direct packets to specific virtual sensors or can send packets to be monitored by a default virtual sensor. The default virtual sensor is the virtual sensor to which you assign PortChannel 0/0. We recommend that you assign PortChannel 0/0 to vs0, but you can assign it to another virtual sensor if you want to.

Step 13 Press **Enter** to return to the main virtual sensor menu.

Step 14 Enter **3** to create a virtual sensor.

Name[]:

Step 15 Enter a name and description for your virtual sensor.

```
Name[]: newVs
Description[Created via setup by user cisco]: New Sensor
Anomaly Detection Configuration
  [1] ad0
  [2] Create a new anomaly detection configuration
Option[2]:
```

Step 16 Enter **1** to use the existing anomaly-detection configuration, ad0.

```
Signature Definition Configuration
  [1] sig0
  [2] Create a new signature definition configuration
Option[2]:
```

Step 17 Enter **2** to create a signature-definition configuration file.

Step 18 Enter the signature-definition configuration name, **newSig**.

```
Event Action Rules Configuration
  [1] rules0
  [2] Create a new event action rules configuration
Option[2]:
```

Step 19 Enter **1** to use the existing event-action-rules configuration, rules0.



Note If PortChannel 0/0 has not been assigned to vs0, you are prompted to assign it to the new virtual sensor.

```
Virtual Sensor: newVs
  Anomaly Detection: ad0
  Event Action Rules: rules0
  Signature Definitions: newSig
  Monitored:
    PortChannel0/0

[1] Remove virtual sensor.
[2] Modify "newVs" virtual sensor configuration.
[3] Modify "vs0" virtual sensor configuration.
[4] Create new virtual sensor.
Option:
```

Step 20 Press **Enter** to exit the interface and virtual sensor configuration menu.

```
Modify default threat prevention settings?[no]:
```

Step 21 Enter **yes** if you want to modify the default threat prevention settings.



Note The sensor comes with a built-in override to add the deny packet event action to high risk rating alerts. If you do not want this protection, disable automatic threat prevention.

```
Virtual sensor newVs is configured to prevent high risk threats in inline mode. (Risk
Rating 90-100)
Virtual sensor vs0 is configured to prevent high risk threats in inline mode. (Risk Rating
90-100)
Do you want to disable automatic threat prevention on all virtual sensors?[no]:
```

Step 22 Enter **yes** to disable automatic threat prevention on all virtual sensors.

The following configuration was entered.

```
service host
network-settings
host-ip 192.168.1.2/24,192.168.1.1
host-name asa-ips
telnet-option disabled
sshv1-fallback enabled
access-list 10.0.0.0/8
access-list 64.0.0.0/8
ftp-timeout 300
no login-banner-text
exit
time-zone-settings
offset 0
standard-time-zone-name UTC
exit
summertime-option disabled
ntp-option disabled
exit
service web-server
port 342
exit
service analysis-engine
virtual-sensor newVs
description New Sensor
```

```
signature-definition newSig
event-action-rules rules0
anomaly-detection
anomaly-detection-name ad0
exit
physical-interfaces PortChannel0/0
exit
exit
service event-action-rules rules0
overrides deny-packet-inline
override-item-status Disabled
risk-rating-range 90-100
exit
exit
```

```
[0] Go to the command prompt without saving this config.
[1] Return back to the setup without saving this config.
[2] Save this configuration and exit setup.
```

Step 23 Enter **2** to save the configuration.

```
Enter your selection[2]: 2
Configuration Saved.
```

Step 24 Reboot the ASA 5500-X IPS SSP.

```
asa-ips# reset
Warning: Executing this command will stop all applications and reboot the node.
Continue with reset? []:
```

Step 25 Enter **yes** to continue the reboot.

Step 26 After reboot, log in to the sensor, and display the self-signed X.509 certificate (needed by TLS).

```
asa-ips# show tls fingerprint
MD5: C4:BC:F2:92:C2:E2:4D:EB:92:0F:E4:86:53:6A:C6:01
SHA1: 64:9B:AC:DE:21:62:0C:D3:57:2E:9B:E5:3D:04:8F:A7:FD:CD:6F:27
```

Step 27 Write down the certificate fingerprints. You need the fingerprints to check the authenticity of the certificate when using HTTPS to connect to this ASA 5500-X IPS SSP with a web browser.

Step 28 Apply the most recent service pack and signature update. You are now ready to configure the ASA 5500-X IPS SSP for intrusion prevention.

For More Information

For the procedure for obtaining the most recent IPS software, see [Obtaining Cisco IPS Software, page 21-1](#).

Advanced Setup for the ASA 5585-X IPS SSP

To continue with advanced setup for the ASA 5585-X IPS SSP, follow these steps:

Step 1 Session in to the ASA 5585-X IPS SSP using an account with administrator privileges.

```
asa# session 1
```

Step 2 Enter the **setup** command. The System Configuration Dialog is displayed. Press **Enter** or the spacebar to skip to the menu to access advanced setup.

- Step 3** Enter **3** to access advanced setup.
- Step 4** Specify the Telnet server status. You can disable or enable Telnet services. The default is disabled.
- Step 5** Specify the SSHv1 fallback setting. The default is enabled.
- Step 6** Specify the web server port. The web server port is the TCP port used by the web server (1 to 65535). The default is 443.



Note The web server is configured to use TLS/SSL encryption by default. Setting the port to 80 does not disable the encryption.

- Step 7** Enter **yes** to modify the interface and virtual sensor configuration.

```
Current interface configuration
Command control: Management0/0
Unassigned:
Monitored:
  PortChannel0/0

Virtual Sensor: vs0
Anomaly Detection: ad0
Event Action Rules: rules0
Signature Definitions: sig0

[1] Edit Interface Configuration
[2] Edit Virtual Sensor Configuration
[3] Display configuration
Option:
```

- Step 8** Enter **1** to edit the interface configuration.



Note You do not need to configure interfaces on the ASA 5585-X IPS SSP. You should ignore the modify interface default VLAN setting. The separation of traffic across virtual sensors is configured differently for the ASA 5585-X IPS SSP than for other sensors.

```
[1] Modify interface default-vlan.
Option:
```

- Step 9** Press **Enter** to return to the top-level interface and virtual sensor configuration menu.

```
[1] Edit Interface Configuration
[2] Edit Virtual Sensor Configuration
[3] Display configuration
Option:
```

- Step 10** Enter **2** to edit the virtual sensor configuration.

```
[1] Remove virtual sensor.
[2] Modify "vs0" virtual sensor configuration.
[3] Create new virtual sensor.
Option:
```

- Step 11** Enter **2** to modify the virtual sensor vs0 configuration.

```
Virtual Sensor: vs0
Anomaly Detection: ad0
Event Action Rules: rules0
Signature Definitions: sig0
```

```
No Interfaces to remove.
```

```

Unassigned:
Monitored:
  [1] PortChannel0/0
Add Interface:

```

Step 12 Enter **1** to add PortChannel 0/0 to virtual sensor vs0.



Note Multiple virtual sensors are supported. The adaptive security appliance can direct packets to specific virtual sensors or can send packets to be monitored by a default virtual sensor. The default virtual sensor is the virtual sensor to which you assign PortChannel 0/0. We recommend that you assign PortChannel 0/0 to vs0, but you can assign it to another virtual sensor if you want to.

Step 13 Press **Enter** to return to the main virtual sensor menu.

Step 14 Enter **3** to create a virtual sensor.

```
Name[]:
```

Step 15 Enter a name and description for your virtual sensor.

```

Name[]: newVs
Description[Created via setup by user cisco]: New Sensor
Anomaly Detection Configuration
  [1] ad0
  [2] Create a new anomaly detection configuration
Option[2]:

```

Step 16 Enter **1** to use the existing anomaly-detection configuration, ad0.

```

Signature Definition Configuration
  [1] sig0
  [2] Create a new signature definition configuration
Option[2]:

```

Step 17 Enter **2** to create a signature-definition configuration file.

Step 18 Enter the signature-definition configuration name, **newSig**.

```

Event Action Rules Configuration
  [1] rules0
  [2] Create a new event action rules configuration
Option[2]:

```

Step 19 Enter **1** to use the existing event action rules configuration, rules0.



Note If PortChannel 0/0 has not been assigned to vs0, you are prompted to assign it to the new virtual sensor.

```

Virtual Sensor: newVs
Anomaly Detection: ad0
Event Action Rules: rules0
Signature Definitions: newSig
Monitored:
  PortChannel0/0

[1] Remove virtual sensor.
[2] Modify "newVs" virtual sensor configuration.
[3] Modify "vs0" virtual sensor configuration.

```

[4] Create new virtual sensor.
Option:

Step 20 Press **Enter** to exit the interface and virtual sensor configuration menu.

Modify default threat prevention settings?[no]:

Step 21 Enter **yes** if you want to modify the default threat prevention settings.



Note The sensor comes with a built-in override to add the deny packet event action to high risk rating alerts. If you do not want this protection, disable automatic threat prevention.

Virtual sensor newVs is configured to prevent high risk threats in inline mode. (Risk Rating 90-100)
Virtual sensor vs0 is configured to prevent high risk threats in inline mode. (Risk Rating 90-100)
Do you want to disable automatic threat prevention on all virtual sensors?[no]:

Step 22 Enter **yes** to disable automatic threat prevention on all virtual sensors.

The following configuration was entered.

```
service host
network-settings
host-ip 10.1.9.201/24,10.1.9.1
host-name ips-ssm
telnet-option disabled
sshv1-fallback enabled
access-list 10.0.0.0/8
access-list 64.0.0.0/8
ftp-timeout 300
no login-banner-text
exit
time-zone-settings
offset 0
standard-time-zone-name UTC
exit
summertime-option disabled
ntp-option disabled
exit
service web-server
port 342
exit
service analysis-engine
virtual-sensor newVs
description New Sensor
signature-definition newSig
event-action-rules rules0
anomaly-detection
anomaly-detection-name ad0
exit
physical-interfaces PortChannel0/0
exit
exit
service event-action-rules rules0
overrides deny-packet-inline
override-item-status Disabled
risk-rating-range 90-100
exit
exit
```

[0] Go to the command prompt without saving this config.


```
[1] Return back to the setup without saving this config.
[2] Save this configuration and exit setup.
```

Step 23 Enter **2** to save the configuration.

```
Enter your selection[2]: 2
Configuration Saved.
```

Step 24 Reboot the ASA 5585-X IPS SSP.

```
ips-ssp# reset
Warning: Executing this command will stop all applications and reboot the node.
Continue with reset? []:
```

Step 25 Enter **yes** to continue the reboot.

Step 26 After reboot, log in to the sensor, and display the self-signed X.509 certificate (needed by TLS).

```
ips-ssp# show tls fingerprint
MD5: C4:BC:F2:92:C2:E2:4D:EB:92:0F:E4:86:53:6A:C6:01
SHA1: 64:9B:AC:DE:21:62:0C:D3:57:2E:9B:E5:3D:04:8F:A7:FD:CD:6F:27
```

Step 27 Write down the certificate fingerprints. You need the fingerprints to check the authenticity of the certificate when using HTTPS to connect to this ASA 5585-X IPS SSP with a web browser.

Step 28 Apply the most recent service pack and signature update. You are now ready to configure your ASA 5585-X IPS SSP for intrusion prevention.

For More Information

For the procedure for obtaining the most recent IPS software, see [Obtaining Cisco IPS Software](#), page 21-1.

Verifying Initialization



Note

The CLI output is an example of what your configuration may look like. It will not match exactly due to the optional setup choices, sensor model, and IPS 7.1 version you have installed.

To verify that you initialized your sensor, follow these steps:

Step 1 Log in to the sensor.

Step 2 View your configuration.

```
sensor# show configuration
! -----
! Current configuration last modified Tue Nov 01 10:40:39 2011
! -----
! Version 7.1(3)
! Host:
!   Realm Keys          key1.0
! Signature Definition:
!   Signature Update    S581.0   2011-07-11
! -----
service interface
exit
! -----
```

```

service authentication
permit-packet-logging true
exit
! -----
service event-action-rules rules0
exit
! -----
service host
network-settings
host-ip 192.168.1.2/24,192.168.1.1
host-name sensor
telnet-option enabled
sshdv1-fallback enabled
access-list 0.0.0.0/0
dns-primary-server disabled
dns-secondary-server disabled
dns-tertiary-server disabled
exit
time-zone-settings
offset -360
standard-time-zone-name GMT-06:00
exit
exit
! -----
service logger
exit
! -----
service network-access
exit
! -----
service notification
exit
! -----
service signature-definition sig0
signatures 2000 0
alert-frequency
summary-mode fire-all
exit
exit
status
enabled true
exit
exit
signatures 2004 0
alert-frequency
summary-mode fire-all
exit
exit
status
enabled true
exit
exit
exit
! -----
service ssh-known-hosts
rsa1-keys 10.89.146.1
length 1024
exponent 35
modulus 127830942922883267670156151321687733281150975610206071962216325709559802
69998149478748431202060218539250569954487820368372742332963486465122675278103455
02382074147081976580477367448761372704018006749147530115354456086472735887860780
20923203565649165402391893192805445031000304938986412742328940379711869015427
exit
exit

```

```

! -----
service trusted-certificates
exit
! -----
service web-server
exit
! -----
service anomaly-detection ad0
exit
! -----
service external-product-interface
exit
! -----
service health-monitor
exit
! -----
service global-correlation
exit
! -----
service aaa
exit
! -----
service analysis-engine
exit
sensor#

```



Note You can also use the **more current-config** command to view your configuration.

Step 3 Display the self-signed X.509 certificate (needed by TLS).

```

sensor# show tls fingerprint
MD5: C4:BC:F2:92:C2:E2:4D:EB:92:0F:E4:86:53:6A:C6:01
SHA1: 64:9B:AC:DE:21:62:0C:D3:57:2E:9B:E5:3D:04:8F:A7:FD:CD:6F:27

```

Step 4 Write down the certificate fingerprints. You need the fingerprints to check the authenticity of the certificate when connecting to this sensor with a web browser.

For More Information

For the procedure for logging in to the sensor, see [Chapter 2, “Logging In to the Sensor.”](#)



Setting Up the Sensor

This chapter contains procedures for the setting up the sensor, and contains the following sections:

- [Setup Notes and Caveats, page 4-1](#)
- [Understanding Sensor Setup, page 4-2](#)
- [Changing Network Settings, page 4-2](#)
- [Changing the CLI Session Timeout, page 4-13](#)
- [Changing Web Server Settings, page 4-14](#)
- [Configuring Authentication and User Parameters, page 4-16](#)
- [Configuring Time, page 4-34](#)
- [Configuring SSH, page 4-44](#)
- [Configuring TLS, page 4-50](#)
- [Installing the License Key, page 4-56](#)

Setup Notes and Caveats

The following notes and caveats apply to setting up the sensor:

- By default SSHv1 fallback is enabled.
- When updating the hostname, the CLI prompt of the current session and other existing sessions is not updated with the new hostname immediately. Subsequent CLI login sessions reflect the new hostname in the prompt.
- Telnet is not a secure access service and therefore is disabled by default on the sensor. However, SSH is always running on the sensor and it is a secure service.
- For global correlation to function, you must have either a DNS server or an HTTP proxy server configured at all times.
- DNS resolution is supported only for accessing the global correlation update server.
- The default web server port is 443 if TLS is enabled and 80 if TLS is disabled.
- The **username** command provides username and password authentication for login purposes only. You cannot use this command to remove a user who is logged in to the system. You cannot use this command to remove yourself from the system.

- You cannot use the **privilege** command to give a user service privileges. If you want to give an existing user service privileges, you must remove that user and then use the **username** command to create the service account.
- Do not make modifications to the sensor through the service account except under the direction of TAC. If you use the service account to configure the sensor, your configuration is not supported by TAC. Adding services to the operating system through the service account affects proper performance and functioning of the other IPS services. TAC does not support a sensor on which additional services have been added.
- You should carefully consider whether you want to create a service account. The service account provides shell access to the system, which makes the system vulnerable. However, you can use the service account to create a password if the administrator password is lost. Analyze your situation to decide if you want a service account existing on the system.
- Administrators may need to disable the password recovery feature for security reasons.
- We recommend that you use an NTP server to regulate time on your sensor. You can use authenticated or unauthenticated NTP. For authenticated NTP, you must obtain the NTP server IP address, NTP server key ID, and the key value from the NTP server. You can set up NTP during initialization or you can configure NTP through the CLI, IDM, IME, or ASDM.
- In addition to a valid Cisco.com username and password, you must also have a Cisco Services for IPS service contract before you can apply for a license key.

Understanding Sensor Setup

Setting up the sensor involves such tasks as changing sensor initialization information, adding and deleting users, configuring time and setting up NTP, creating a service account, configuring SSH and TLS, and installing the license key. You configured most of these settings when you initialized the sensor using the **setup** command.

For More Information

For more information on using the **setup** command to initialize the sensor, see [Chapter 3, “Initializing the Sensor.”](#)

Changing Network Settings

After you initialize your sensor, you may need to change some of the network settings that you configured when you ran the **setup** command. This section describes how to change network settings, and contains the following topics:

- [Changing the Hostname, page 4-3](#)
- [Changing the IP Address, Netmask, and Gateway, page 4-4](#)
- [Enabling and Disabling Telnet, page 4-5](#)
- [Changing the Access List, page 4-6](#)
- [Changing the FTP Timeout, page 4-8](#)
- [Adding a Login Banner, page 4-9](#)
- [Configuring the DNS and Proxy Servers for Global Correlation, page 4-10](#)
- [Enabling SSHv1 Fallback, page 4-12](#)

Changing the Hostname



Note

The CLI prompt of the current session and other existing sessions will not be updated with the new hostname. Subsequent CLI login sessions will reflect the new hostname in the prompt.

Use the **host-name** *host_name* command in the service host submode to change the hostname of the sensor after you have run the **setup** command. The default is sensor. To change the sensor hostname, follow these steps:

Step 1 Log in to the sensor using an account with administrator privileges.

Step 2 Enter network settings submode.

```
sensor# configure terminal
sensor(config)# service host
sensor(config-hos)# network-settings
```

Step 3 Change the sensor hostname.

```
sensor(config-hos-net)# host-name firesafe
```

Step 4 Verify the new hostname.

```
sensor(config-hos-net)# show settings
network-settings
-----
host-ip: 192.0.2.1/24,192.0.2.2 default:
192.168.1.2/24,192.168.1.1
host-name: firesafe default: sensor
telnet-option: enabled default: disabled
access-list (min: 0, max: 512, current: 1)
-----
network-address: 0.0.0.0/0
-----
ftp-timeout: 300 seconds <defaulted>
login-banner-text: <defaulted>
-----
sensor(config-hos-net)#
```

Step 5 To change the hostname back to the default setting, use the **default** form of the command.

```
sensor(config-hos-net)# default host-name
```

Step 6 Verify the change to the default hostname sensor.

```
sensor(config-hos-net)# show settings
network-settings
-----
host-ip: 192.0.2.1/24,192.0.2.2 default:
192.168.1.2/24,192.168.1.1
host-name: sensor <defaulted>
telnet-option: enabled default: disabled
access-list (min: 0, max: 512, current: 1)
-----
network-address: 0.0.0.0/0
-----
ftp-timeout: 300 seconds <defaulted>
login-banner-text: <defaulted>
-----
```

```
sensor(config-hos-net)#
```

Step 7 Exit network settings mode.

```
sensor(config-hos-net)# exit
sensor(config-hos)# exit
Apply Changes:[yes]:
```

Step 8 Press **Enter** to apply the changes or enter **no** to discard them.

Changing the IP Address, Netmask, and Gateway

Use the **host-ip** *ip_address/netmask,default_gateway* command in the service host submode to change the IP address, netmask, and default gateway after you have run the **setup** command. The default is 192.168.1.2/24,192.168.1.1.

The **host-ip** is in the form of IP Address/Netmask/Gateway: X.X.X.X/nn,Y.Y.Y.Y, where X.X.X.X specifies the sensor IP address as a 32-bit address written as 4 octets separated by periods where X = 0-255, nn specifies the number of bits in the netmask, and Y.Y.Y.Y specifies the default gateway as a 32-bit address written as 4 octets separated by periods where Y = 0-255.

To change the sensor IP address, netmask, and default gateway, follow these steps:

Step 1 Log in to the sensor using an account with administrator privileges.

Step 2 Enter network settings mode.

```
sensor# configure terminal
sensor(config)# service host
sensor(config-hos)# network-settings
```

Step 3 Change the sensor IP address, netmask, and default gateway.

```
sensor(config-hos-net)# host-ip 192.0.2.1/24,192.0.2.2
```



Note The default gateway must be in the same subnet as the IP address of the sensor or the sensor generates an error and does not accept the configuration change.

Step 4 Verify the new information.

```
sensor(config-hos-net)# show settings
network-settings
-----
host-ip: 192.0.2.1/24,192.0.2.2
default: 192.168.1.2/24,192.168.1.1
host-name: sensor default: sensor
telnet-option: enabled default: disabled
access-list (min: 0, max: 512, current: 1)
-----
network-address: 0.0.0.0/0
-----
ftp-timeout: 300 seconds <defaulted>
login-banner-text: <defaulted>
-----
```


Step 5 To change the information back to the default setting, use the **default** form of the command.

```
sensor(config-hos-net)# default host-ip
```

Step 6 Verify that the host IP is now the default of 192.168.1.2/24,192.168.1.1.

```
sensor(config-hos-net)# show settings
network-settings
-----
host-ip: 192.168.1.2/24,192.168.1.1 <defaulted>
host-name: sensor default: sensor
telnet-option: enabled default: disabled
access-list (min: 0, max: 512, current: 1)
-----
network-address: 0.0.0.0/0
-----

ftp-timeout: 300 seconds <defaulted>
login-banner-text: <defaulted>
-----
sensor(config-hos-net)#
```

Step 7 Exit network settings mode.

```
sensor(config-hos-net)# exit
sensor(config-hos)# exit
Apply Changes?[yes]:
```

Step 8 Press **Enter** to apply the changes or enter **no** to discard them.

Enabling and Disabling Telnet



Caution

Telnet is not a secure access service and therefore is disabled by default. However, SSH is always running on the sensor and it is a secure service.

Use the **telnet-option {enabled | disabled}** command in the service host submode to enable Telnet for remote access to the sensor. The default is disabled. To enable or disable Telnet services, follow these steps:

Step 1 Log in to the sensor using an account with administrator privileges.

Step 2 Enter network settings mode.

```
sensor# configure terminal
sensor(config)# service host
sensor(config-hos)# network-settings
```

Step 3 Enable Telnet services.

```
sensor(config-hos-net)# telnet-option enabled
sensor(config-hos-net)#
```

Step 4 Verify that Telnet is enabled.

```
sensor(config-hos-net)# show settings
network-settings
-----
```

```

host-ip: 192.0.2.1/24,192.0.2.2
default: 192.168.1.2/24,192.168.1.1
host-name: sensor default: sensor
telnet-option: enabled default: disabled
access-list (min: 0, max: 512, current: 1)
-----
network-address: 0.0.0.0/0
-----
ftp-timeout: 300 seconds <defaulted>
login-banner-text: <defaulted>
-----
sensor(config-hos-net)#

```

Step 5 Exit network settings mode.

```

sensor(config-hos-net)# exit
sensor(config-hos)# exit
Apply Changes?[yes]:

```

Step 6 Press **Enter** to apply the changes or enter **no** to discard them.



Note

To Telnet to the sensor, you must enable Telnet and configure the access list to allow the Telnet clients to connect.

For More Information

For the procedure for configuring the access list, see [Changing the Access List, page 4-6](#).

Changing the Access List

Use the **access-list** *ip_address/netmask* command in the service host submode to configure the access list, the list of hosts or networks that you want to have access to your sensor. Use the **no** form of the command to remove an entry from the list. The default access list is empty.

The following hosts must have an entry in the access list:

- Hosts that need to Telnet to your sensor.
- Hosts that need to use SSH with your sensor.
- Hosts, such as the IDM and the IME, that need to access your sensor from a web browser.
- Management stations, such as the CSM, that need access to your sensor.
- If your sensor is a master blocking sensor, the IP addresses of the blocking forwarding sensors must have an entry in the list.

To modify the access list, follow these steps:

Step 1 Log in to the sensor using an account with administrator privileges.

Step 2 Enter network settings mode.

```

sensor# configure terminal
sensor(config)# service host
sensor(config-hos)# network-settings

```

Step 3 Add an entry to the access list. The netmask for a single host is 32.

```
sensor(config-hos-net)# access-list 192.0.2.110/32
```

Step 4 Verify the change you made to the access-list.

```
sensor(config-hos-net)# show settings
network-settings
-----
host-ip: 192.168.1.2/24,192.168.1.1 <defaulted>
host-name: sensor <defaulted>
telnet-option: enabled default: disabled
access-list (min: 0, max: 512, current: 2)
-----
network-address: 10.1.9.0/24
-----
network-address: 192.0.2.110/32
-----
ftp-timeout: 300 seconds <defaulted>
login-banner-text: <defaulted>
-----
```

Step 5 Remove the entry from the access list.

```
sensor(config-hos-net)# no access-list 192.0.2.110/32
```

Step 6 Verify that the host is no longer in the list.

```
sensor(config-hos-net)# show settings
network-settings
-----
host-ip: 192.168.1.2/24,192.168.1.1 <defaulted>
host-name: sensor <defaulted>
telnet-option: enabled default: disabled
access-list (min: 0, max: 512, current: 1)
-----
network-address: 10.1.9.0/24
-----
ftp-timeout: 300 seconds <defaulted>
login-banner-text: <defaulted>
-----
sensor(config-hos-net)#
```

Step 7 Change the value back to the default.

```
sensor(config-hos-net)# default access-list
```

Step 8 Verify the value has been set back to the default.

```
sensor(config-hos-net)# show settings
network-settings
-----
host-ip: 192.168.1.2/24,192.168.1.1 <defaulted>
host-name: sensor <defaulted>
telnet-option: enabled default: disabled
access-list (min: 0, max: 512, current: 0)
-----
ftp-timeout: 300 seconds <defaulted>
login-banner-text: <defaulted>
-----
sensor(config-hos-net)#
```

Step 9 Exit network settings mode.

```
sensor(config-hos-net)# exit
sensor(config-hos)# exit
Apply Changes?[yes]:
```

Step 10 Press **Enter** to apply the changes or enter **no** to discard them.

Changing the FTP Timeout



Note

You can use the FTP client for downloading updates and configuration files from your FTP server.

Use the **ftp-timeout** command in the service host submode to change the number of seconds that the FTP client waits before timing out when the sensor is communicating with an FTP server. The default is 300 seconds. To change the FTP timeout, follow these steps:

Step 1 Log in to the sensor using an account with administrator privileges.

Step 2 Enter network settings mode.

```
sensor# configure terminal
sensor(config)# service host
sensor(config-hos)# network-settings
```

Step 3 Change the number of seconds of the FTP timeout.

```
sensor(config-hos-net)# ftp-timeout 500
```

Step 4 Verify the FTP timeout change.

```
sensor(config-hos-net)# show settings
network-settings
-----
host-ip: 192.0.2.1/24,192.0.2.2
default: 192.168.1.2/24,192.168.1.1
host-name: sensor default: sensor
telnet-option: enabled default: disabled
access-list (min: 0, max: 512, current: 1)
-----
network-address: 0.0.0.0/0
-----

ftp-timeout: 500 seconds default: 300
login-banner-text: <defaulted>
-----
sensor(config-hos-net)#
```

Step 5 Change the value back to the default.

```
sensor(config-hos-net)# default ftp-timeout
```

Step 6 Verify the value has been set back to the default.

```
sensor(config-hos-net)# show settings
network-settings
-----
host-ip: 192.0.2.1/24,192.0.2.2
default: 192.168.1.2/24,192.168.1.1
```

```

host-name: sensor default: sensor
telnet-option: enabled default: disabled
access-list (min: 0, max: 512, current: 1)
-----
network-address: 0.0.0.0/0
-----
ftp-timeout: 300 seconds <defaulted>
login-banner-text: <defaulted>
-----
sensor(config-hos-net)#

```

Step 7 Exit network settings mode.

```

sensor(config-hos-net)# exit
sensor(config-hos)# exit
Apply Changes:[yes]:

```

Step 8 Press **Enter** to apply the changes or enter **no** to discard them.

Adding a Login Banner

Use the **login-banner-text** *text_message* command to add a login banner that the user sees during login. There is no default. When you want to start a new line in your message, press **Ctrl-V Enter**.

To add a login banner, follow these steps:

Step 1 Log in to the sensor using an account with administrator privileges.

Step 2 Enter network settings mode.

```

sensor# configure terminal
sensor(config)# service host
sensor(config-hos)# network-settings

```

Step 3 Add the banner login text.

```

sensor(config-hos-net)# login-banner-text This is the banner login text message.

```

Step 4 Verify the banner login text message.

```

sensor(config-hos-net)# show settings
network-settings
-----
host-ip: 192.0.2.1/24,192.0.2.2
default: 192.168.1.2/24,192.168.1.1
host-name: sensor default: sensor
telnet-option: enabled default: disabled
access-list (min: 0, max: 512, current: 1)
-----
network-address: 0.0.0.0/0
-----
ftp-timeout: 300 seconds <defaulted>
login-banner-text: This is the banner login text message. default:
-----
sensor(config-hos-net)#

```

Step 5 To remove the login banner text, use the **no** form of the command.

```
sensor(config-hos-net)# no login-banner-text
```

Step 6 Verify the login text has been removed.

```
sensor(config-hos-net)# show settings
network-settings
-----
host-ip: 192.0.2.1/24,192.0.2.2
default: 192.168.1.2/24,192.168.1.1
host-name: sensor default: sensor
telnet-option: enabled default: disabled
access-list (min: 0, max: 512, current: 1)
-----
network-address: 0.0.0.0/0
-----

ftp-timeout: 300 seconds <defaulted>
login-banner-text: default:
-----

sensor(config-hos-net)#
```

Step 7 Exit network settings mode.

```
sensor(config-hos-net)# exit
sensor(config-hos)# exit
Apply Changes?[yes]:
```

Step 8 Press **Enter** to apply the changes or enter **no** to discard them.

Configuring the DNS and Proxy Servers for Global Correlation

Use the **http-proxy**, **dns-primary-server**, **dns-secondary-server**, and **dns-tertiary-server** commands in network-settings submode to configure servers to support the global correlation features.

You must configure either an HTTP proxy server or DNS server to support global correlation. You may need a proxy server to download global correlation updates if you use proxy in your network. If you are using a DNS server, you must configure at least one DNS server and it must be reachable for global correlation updates to be successful. You can configure other DNS servers as backup servers. DNS queries are sent to the first server in the list. If it is unreachable, DNS queries are sent to the next configured DNS server.



Caution

For global correlation to function, you must have either a DNS server or an HTTP proxy server configured at all times.



Caution

DNS resolution is supported only for accessing the global correlation update server.

The following options apply:

- **http-proxy {no-proxy | proxy-sensor}**—Configures the HTTP proxy server:
 - **address** *ip_address* —Specifies the IP address of the HTTP proxy server.
 - **port** *port_number* —Specifies the port number of the HTTP proxy server.

- **dns-primary-server {enabled | disabled}**—Enables a DNS primary server:
 - **address ip_address** —Specifies the IP address of the DNS primary server.
- **dns-secondary-server {enabled | disabled}**—Enables a DNS secondary server:
 - **address ip_address** —Specifies the IP address of the DNS secondary server.
- **dns-tertiary-server {enabled | disabled}**—Enables the DNS tertiary server:
 - **address ip_address** —Specifies the IP address of the DNS tertiary server.

Configuring DNS and Proxy Servers for Global Correlation

To configure DNS and proxy servers to support global correlation, follow these steps:

Step 1 Log in to the sensor using an account with administrator privileges.

Step 2 Enter network settings submode.

```
sensor# configure terminal
sensor(config)# service host
sensor(config-hos)# network-settings
```

Step 3 Enable a proxy or DNS server to support global correlation:

a. Enable a proxy server.

```
sensor(config-hos-net)# http-proxy proxy-server
sensor(config-hos-net-pro)# address 10.10.10.1
sensor(config-hos-net-pro)# port 65
sensor(config-hos-net-pro)#
```

b. Enable a DNS server.

```
sensor(config-hos-net)# dns-primary-server enabled
sensor(config-hos-net-ena)# address 10.10.10.1
sensor(config-hos-net-ena)#
```

Step 4 Verify the settings.

```
sensor(config-hos-net)# show settings
network-settings
-----
host-ip: 10.89.147.24/25,10.89.147.126 default: 192.168.1.2/24,192.168.1.1
host-name: sensor <defaulted>
telnet-option: enabled default: disabled
access-list (min: 0, max: 512, current: 1)
-----
network-address: 0.0.0.0/0
-----

ftp-timeout: 300 seconds <defaulted>
login-banner-text: <defaulted>
dns-primary-server
-----
enabled
-----
address: 10.10.10.1
-----

dns-secondary-server
-----
disabled
-----
-----
```

```

-----
dns-tertiary-server
-----
disabled
-----
-----
http-proxy
-----
proxy-server
-----
address: 10.10.10.1
port: 65
-----
-----
sensor(config-hos-net)#

```

Step 5 Exit network settings mode.

```

sensor(config-hos-net)# exit
sensor(config-hos)# exit
Apply Changes?[yes]:

```

Step 6 Press **Enter** to apply the changes or enter **no** to discard them.

For More Information

For more information on global correlation features, see [Chapter 10, “Configuring Global Correlation.”](#)

Enabling SSHv1 Fallback



Note

The IPS supports a management connection through both SSHv1 and SSHv2 (SSHv2 is supported in IPS 7.1(8)E4). In 7.1(8)E4 and later, support for both SSHv1 and SSHv2 is enabled by default.

Use the **sshv1-fallback {enabled | disabled}** command in the service host submode to enable/disable the sensor to fall back to SSH protocol version 1. Fallback to SSHv1 is provided in case the peer client/server does not support SSHv2.

To enable or disable SSHv1 fallback, follow these steps:

Step 1 Log in to the sensor using an account with administrator privileges.

Step 2 Enter network settings mode.

```

sensor# configure terminal
sensor(config)# service host
sensor(config-hos)# network-settings

```

Step 3 Enable SSHv1 fallback.

```

sensor(config-hos-net)# sshv1-fallback enabled
sensor(config-hos-net)#

```

Step 4 Verify that SSHv1 fallback is enabled.

```

sensor(config-hos-net)# show settings

```



```

network-settings
-----
host-ip: 10.106.164.52/24,10.106.164.1 default: 192.168.1.2/24,192.168.1.1
host-name: p32-ips4240-52 default: sensor
telnet-option: enabled default: disabled
sshv1-fallback: enabled default: enabled
access-list (min: 0, max: 512, current: 1)
-----
network-address: 0.0.0.0/0
-----
ftp-timeout: 300 seconds <defaulted>
login-banner-text: mmmm default:
sensor(config-hos-net)#

```

Step 5 Exit network settings mode.

```

sensor(config-hos-net)# exit
sensor(config-hos)# exit
Apply Changes:[yes]:

```

Step 6 Press **Enter** to apply the changes or enter **no** to discard them.

Changing the CLI Session Timeout

Use the **cli-inactivity-timeout** command in the service authentication submode to change the number of seconds that the CLI waits before timing out. Setting the CLI session timeout increases the security of a CLI session. The default is 0 seconds, which means that it is an unlimited value and thus will never time out. The valid range is 0 to 100,000 minutes. This command is supported in IPS 7.1(3)E4 and later.

To change the CLI session timeout, follow these steps:

Step 1 Log in to the sensor using an account with administrator privileges.

Step 2 Enter authentication mode.

```

sensor# configure terminal
sensor(config)# service authentication

```

Step 3 Change the number of seconds of the CLI session timeout.

```

sensor(config-aut)# cli-inactivity-timeout 5000

```

Step 4 Verify the CLI session timeout change.

```

sensor(config-aut)# show settings
attemptLimit: 0 <defaulted>
password-strength
-----
size: 8-64 <defaulted>
digits-min: 0 <defaulted>
uppercase-min: 0 <defaulted>
lowercase-min: 0 <defaulted>
other-min: 0 <defaulted>
number-old-passwords: 0 <defaulted>
-----
permit-packet-logging: true <defaulted>
cli-inactivity-timeout: 5000 default: 0
sensor(config-aut)#

```

Step 5 Change the value back to the default.

```
sensor(config-aut)# default cli-inactivity-timeout
```

Step 6 Verify the value has been set back to the default.

```
sensor(config-aut)# show settings
attemptLimit: 0 <defaulted>
password-strength
-----
size: 8-64 <defaulted>
digits-min: 0 <defaulted>
uppercase-min: 0 <defaulted>
lowercase-min: 0 <defaulted>
other-min: 0 <defaulted>
number-old-passwords: 0 <defaulted>
-----
permit-packet-logging: true <defaulted>
cli-inactivity-timeout: 0 <defaulted>
sensor(config-aut)#
```

Step 7 Exit authentication mode.

```
sensor(config-aut)# exit
Apply Changes:[yes]:
```

Step 8 Press **Enter** to apply the changes or enter **no** to discard them.

Changing Web Server Settings



Note

The default web server port is 443 if TLS is enabled and 80 if TLS is disabled.

After you run the **setup** command, you can change the following web server settings: the web server port, whether TLS encryption is being used, and the HTTP server header message.

HTTP is the protocol that web clients use to make requests from web servers. The HTTP specification requires a server to identify itself in each response. Attackers sometimes exploit this protocol feature to perform reconnaissance. If the IPS web server identified itself by providing a predictable response, an attacker might learn that an IPS sensor is present.

We recommend that you not reveal to attackers that you have an IPS sensor. Change the **server-id** to anything that does not reveal any information, especially if your web server is available to the Internet. For example, if you forward a port through a firewall so you can monitor a sensor remotely, you need to set the **server-id**.

To change the web server settings, follow these steps:

Step 1 Log in to the sensor using an account with administrator privileges.

Step 2 Enter web server mode.

```
sensor# configure terminal
sensor(config)# service web-server
```

Step 3 Change the port number.

```
sensor(config-web)# port 8080
```

If you change the port number from the default of 443 to 8080, you receive this message:

Warning: The web server's listening port number has changed from 443 to 8080. This change will not take effect until the web server is re-started

Step 4 Enable or disable TLS.

```
sensor(config-web)# enable-tls {true | false}
```

If you disable TLS, you receive this message:

Warning: TLS protocol support has been disabled. This change will not take effect until the web server is re-started.

Step 5 Change the HTTP server header.

```
sensor(config-web)# server-id Nothing to see here. Move along.
```

Step 6 Verify the web server changes.

```
sensor(config-web)# show settings
  enable-tls: true default: true
  port: 8001 default: 443
  server-id: Nothing to see here. Move along. default: HTTP/1.1 compliant
sensor(config-web)#
```

Step 7 To revert to the defaults, use the **default** form of the commands.

```
sensor(config-web)# default port
sensor(config-web)# default enable-tls
sensor(config-web)# default server-id
```

Step 8 Verify the defaults have been replaced.

```
sensor(config-web)# show settings
  enable-tls: true <defaulted>
  port: 443 <defaulted>
  server-id: HTTP/1.1 compliant <defaulted>
  configurable-service (min: 0, max: 99, current: 1)
  -----
    <protected entry>
    service-name: rdep-event-server
    -----
      enabled: true default: false
      file-name: event-server <protected>
    -----
  -----
sensor(config-web)#
```

Step 9 Exit web server submenu.

```
sensor(config-web)# exit
Apply Changes:[yes]:
```

Step 10 Press **Enter** to apply the changes or enter **no** to discard them.

**Note**

If you change the port or enable TLS settings, you must reset the sensor to make the web server use the new settings.

For More Information

- For the procedure for resetting the appliance, see [Resetting the Appliance, page 17-47](#).
- For the procedure for resetting the ASA 5500 AIP SSM, see [Reloading, Shutting Down, Resetting, and Recovering the ASA 5500 AIP SSM, page 18-15](#).
- For the procedure for resetting the ASA 5500-X IPS SSP, see [Reloading, Shutting Down, Resetting, and Recovering the ASA 5500-X IPS SSP, page 19-12](#).
- For the procedure for resetting the ASA 5585-X IPS SSP, see [Reloading, Shutting Down, Resetting, and Recovering the ASA 5585-X IPS SSP, page 20-12](#).

Configuring Authentication and User Parameters

The following section explains how to create users, configure RADIUS authentication, create the service account, configure passwords, specify privilege level, view a list of users, configure password policy, and lock and unlock user accounts. It contains the following topics:

- [Adding and Removing Users, page 4-16](#)
- [Configuring Authentication, page 4-18](#)
- [Configuring Packet Command Restriction, page 4-24](#)
- [Creating the Service Account, page 4-26](#)
- [The Service Account and RADIUS Authentication, page 4-27](#)
- [RADIUS Authentication Functionality and Limitations, page 4-28](#)
- [Configuring Passwords, page 4-28](#)
- [Changing User Privilege Levels, page 4-29](#)
- [Showing User Status, page 4-30](#)
- [Configuring the Password Policy, page 4-30](#)
- [Locking User Accounts, page 4-32](#)
- [Unlocking User Accounts, page 4-33](#)

Adding and Removing Users

Use the **username** command to create users on the local system. You can add a new user, set the privilege level—administrator, operator, viewer—and set the password for the new user. Use the **no** form of this command to remove a user from the system. This removes the user from CLI and web access.

**Caution**

The **username** command provides username and password authentication for login purposes only. You cannot use this command to remove a user who is logged in to the system. You cannot use this command to remove yourself from the system.

If you do not specify a password, the system prompts you for one. Use the **password** command to change the password for existing users. Use the **privilege** command to change the privilege for existing users.

The username follows the pattern `^[A-Za-z0-9()+;,-/_]+$`, which means the username must start with a letter or number, and can include any letter A to Z (capital or small), any number 0 to 9, - and _, and can contain 1 to 64 characters. A valid password is 8 to 32 characters long. All characters except space are allowed.

You receive the following error messages if you do not create a valid password:

- Error: `setEnabledAuthenticationTokenStatus` : The password is too short.
- Error: `setEnabledAuthenticationTokenStatus` : Failure setting the account's password: it does not contain enough DIFFERENT characters

**Note**

You cannot use the **privilege** command to give a user service privileges. If you want to give an existing user service privileges, you must remove that user and then use the **username** command to create the service account.

To add and remove users, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter configuration mode.

```
sensor# configure terminal
```

Step 3 Specify the parameters for the user.

```
sensor(config)# username username password password privilege
administrator/operator/viewer
```

For example, to add the user “tester” with a privilege level of administrator and the password “testpassword,” enter the following command:

**Note**

If you do not want to see the password in clear text, wait for the password prompt. Do not enter the password along with the username and privilege.

```
sensor(config)# username tester privilege administrator
Enter Login Password: *****
Re-enter Login Password: *****
sensor(config)#
```

**Note**

If you do not specify a privilege level for the user, the user is assigned the default viewer privilege.

Step 4 Verify that the user has been added. A list of users is displayed.

```
sensor(config)# exit
sensor# show users all
CLI ID      User      Privilege
```

```
* 13491    cisco      administrator
           jsmith     operator
           jtaylor    service
           jroberts   viewer

sensor#
```

Step 5 To remove a user, use the **no** form of the command.

```
sensor# configure terminal
sensor(config)# no username jsmith
```



Note You cannot use this command to remove yourself from the system.

Step 6 Verify that the user has been removed. The user `jsmith` has been removed.

```
sensor(config)# exit
sensor# show users all
      CLI ID   User      Privilege
* 13491    cisco      administrator
           jtaylor    service
           jroberts   viewer

sensor#
```

For More Information

- For the procedure for creating the service account, see [Creating the Service Account, page 4-26](#).
- For the procedure for configuring local or RADIUS authentication, see [Configuring Authentication, page 4-18](#).

Configuring Authentication



Caution

Make sure you have a RADIUS server already configured before you configure RADIUS authentication on the sensor. IPS has been tested with CiscoSecure ACS 4.2 and 5.1 servers. Refer to your RADIUS server documentation for information on how to set up a RADIUS server.

You can create and remove users from the local sensor. You can only modify one user account at a time. Each user is associated with a role that controls what that user can and cannot modify. The requirements that must be used for user passwords are set with the **password** command.

Users are authenticated through AAA either locally or through RADIUS servers. Local authentication is enabled by default. You must configure RADIUS authentication before it is active.

You must specify the user role that is authenticated through RADIUS either by configuring the user role on the RADIUS server or specifying a default user role. The username and password are sent in an authentication request to the configured RADIUS server. The response of the server determines whether the login is authenticated.



Note

If the sensor is not configured to use a default user role and the sensor user role information is not in the Accept Message of the CiscoSecure ACS server, the sensor rejects RADIUS authentication even if the CiscoSecure ACS server accepts the username and password.

You can configure a primary RADIUS server and a secondary RADIUS server. The secondary RADIUS server authenticates and authorizes users if the primary RADIUS server is unresponsive.

You can also configure the sensor to use local authentication (local fallback) if no RADIUS servers are responding. In this case, the sensor authenticates against the locally configured user accounts. The sensor will only use local authentication if the RADIUS servers are not available, not if the RADIUS server rejects the authentication requests of the user. You can also configure how users connected through the console port are authenticated—through local user accounts, through RADIUS first and if that fails through local user accounts, or through RADIUS alone.

To configure a RADIUS server, you must have the IP address, port, and shared secret of the RADIUS server. You must also either have the NAS-ID of the RADIUS server, or have the RADIUS server configured to authenticate clients without a NAS-ID or with the default IPS NAS-ID of cisco-ips.

**Note**

Enabling RADIUS authentication on the sensor does not disconnect already established connections. RADIUS authentication is only enforced for new connections to the sensor. Existing CLI, IDM, and IME connections remain established with the login credentials used prior to configuring RADIUS authentication. To force disconnection of these established connections, you must reset the sensor after RADIUS is configured.

RADIUS Authentication Options

Use the **aaa** command in service aaa submode to configure either local authentication or authentication using a RADIUS server. The following options apply:

- **local**—Lets you specify local authentication. To continue to create users, use the **password** command.
- **radius**—Lets you specify RADIUS as the method of authentication:
 - **nas-id**—Identifies the service requesting authentication. The value can be **no nas-id**, **cisco-ips**, or a NAS-ID already configured on the RADIUS server. The default is **cisco-ips**.
 - **default-user-role**—Lets you assign a default user role on the sensor that is only applied when there is NOT a Cisco av pair specifying the user role. The value can be **unspecified**, **viewer**, **operator**, or **administrator**. Service cannot be the default user role. The default is **unspecified**.

If you do not want to configure a default user role on the sensor that is applied in the absence of a Cisco av pair, you need to configure the Cisco IOS/PIX 6.x RADIUS Attributes [009\001] cisco-av-pair under the group or user profile with one of the following options:

ips-role=viewer, **ips-role=operator**, **ips-role=administrator**, **ips-role=service**, or **ips-role=unspecified**. The default is **ips-role=unspecified**.

**Note**

If the sensor is not configured to use a default user role and the sensor user role information is not in the Accept Message of the CiscoSecure ACS server, the sensor rejects RADIUS authentication even if the CiscoSecure ACS server accepts the username and password.

**Note**

The default user role is used only when the user has not been configured with a specific role on the ACS server. Local users are always configured with a specific role so the default user role will never apply to locally authenticated users.

**Caution**

Do not add multiple Cisco av-pairs with the same key. You should have only one instance of `ips-role=value`. Make sure the key and the value are correct or the feature may not work as expected. For example, do not use the following configuration:

```
ips-role= administer
ips-role=ad
```

- **local-fallback {enabled | disabled}**—Lets you default to local authentication if the RADIUS servers are not responding. The default is **enabled**.
- **primary-server**—Lets you configure the main RADIUS server:
 - **server-address**—IP address of the RADIUS server.
 - **server-port**—Port of the RADIUS server. If not specified, the default RADIUS port is used.
 - **timeout** (seconds)—Specifies the number of seconds the sensor waits for a response from a RADIUS server before it considers the server to be unresponsive.
 - **shared-secret**—The secret value configured on the RADIUS server. You must obtain the secret value of the RADIUS server to enter with the **shared-secret** command.

**Note**

You must have the same secret value configured on both the RADIUS server and the IPS sensor so that the server can authenticate the requests of the client and the client can authenticate the responses of the server.

- **secondary-server {enabled | disabled}**— (Optional) Lets you configure a secondary RADIUS server:
 - **server-address**—IP address of the RADIUS server.
 - **server-port**—Port of the RADIUS server. If not specified, the default RADIUS port is used.
 - **timeout** (seconds)—Specifies the number of seconds the sensor waits for a response from a RADIUS server before it considers the server to be unresponsive.
 - **shared-secret**—The secret value configured on the RADIUS server. You must obtain the secret value of the RADIUS server to enter with the **shared-secret** command.

**Note**

You must have the same secret value configured on both the RADIUS server and the IPS sensor so that the server can authenticate the requests of the client and the client can authenticate the responses of the server.

- **console-authentication**—Lets you choose how users connected through the console port are authenticated:
 - **local**—Users connected through the console port are authenticated through local user accounts.
 - **radius-and-local**—Users connected through the console port are authenticated through RADIUS first. If RADIUS fails, local authentication is attempted. This is the default.
 - **radius**—Users connected through the console port are authenticated by RADIUS. If you also have **local-fallback** enabled, users can also be authenticated through the local user accounts.

Configuring Local or RADIUS Authentication



Caution

Make sure you have a RADIUS server already configured before you configure RADIUS authentication on the sensor. IPS has been tested with CiscoSecure ACS 4.2 and 5.1 servers. Refer to your RADIUS server documentation for information on how to set up a RADIUS server.



Note

Enabling RADIUS authentication on the sensor does not disconnect already established connections. RADIUS authentication is only enforced for new connections to the sensor. Existing CLI, IDM, and IME connections remain established with the login credentials used prior to configuring RADIUS authentication. To force disconnection of these established connections, you must reset the sensor after RADIUS is configured.

To configure local or RADIUS AAA authentication on the sensor, follow these steps:

- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter configuration mode.

```
sensor# configure terminal
```
- Step 3** Enter AAA submode.

```
sensor(config)# service aaa
sensor(config-aaa)#
```
- Step 4** Configure local authentication. To continue to create users on the local system, enter **yes** to save your configuration, and use the **username** command in configure terminal mode. To configure AAA RADIUS authentication, go to Step 5.

```
sensor(config-aaa)# aaa local
sensor(config-aaa)# exit
Apply Changes?[yes]:yes
```
- Step 5** Configure AAA RADIUS authentication:
 - a.** Enter RADIUS authentication submode.

```
sensor(config-aaa)# aaa radius
sensor(config-aaa-rad)#
```
 - b.** Enter the Network Access ID. The NAS-ID is an identifier that clients send to servers to communicate the type of service they are attempting to authenticate. The value can be **no nas-id**, **cisco-ips**, or a NAS-ID already configured on the RADIUS server. The default is **cisco-ips**.

```
sensor(config-aaa-rad)# nas-id cisco-ips
sensor(config-aaa-rad)#
```
 - c.** (Optional) Configure a default user role if you are not configuring a Cisco av pair. You can configure a default user role on the sensor that is only applied when there is NOT a Cisco av pair specifying the user role. The values are **unspecified**, **viewer**, **operator**, or **administrator**. The default is **unspecified**.

```
sensor(config-aaa-rad)# default-user-role operator
sensor(config-aaa-rad)#
```



Note

Service cannot be the default role.

- d. Configure a Cisco av pair. If you do not want to configure a default user role on the sensor that is applied in the absence of a Cisco av pair, you need to configure the Cisco IOS/PIX 6.x RADIUS Attributes [009\001] cisco-av-pair under the group or user profile with one of the following options:

- **ips-role=viewer**
- **ips-role=operator**
- **ips-role=administrator**
- **ips-role=service**

**Note**

If the sensor is not configured to use a default user role and the sensor user role information is not in the Accept Message of the CiscoSecure ACS server, the sensor rejects RADIUS authentication even if the CiscoSecure ACS server accepts the username and password.

**Note**

The default user role is used only when the user has not been configured with a specific role on the ACS server. Local users are always configured with a specific role so the default user role will never apply to locally authenticated users.

**Caution**

Do not add multiple Cisco av-pairs with the same key. You should have only one instance of ips-role=value. Make sure the key and the value are correct or the feature may not work as expected. For example, do not use the following configuration:

```
ips-role= administer
ips-role=ad
```

- e. Configure the sensor to switch over to local authentication if the RADIUS server becomes unresponsive.

```
sensor(config-aaa-rad)# local-fallback enabled
sensor(config-aaa-rad)#
```

Step 6 Configure the primary RADIUS server:

- a. Enter primary server submode.

```
sensor(config-aaa-rad)# primary-server
sensor(config-aaa-rad-pri)#
```

- b. Enter the RADIUS server IP address.

```
sensor(config-aaa-rad-pri)# server-address 10.1.2.3
sensor(config-aaa-rad-pri)#
```

- c. Enter the RADIUS server port. If not specified, the default RADIUS port is used.

```
sensor(config-aaa-rad-pri)# server-port 1812
sensor(config-aaa-rad-pri)#
```

- d. Enter the amount of time in seconds you want to wait for the RADIUS server to respond.

```
sensor(config-aaa-rad-pri)# time-out 5
sensor(config-aaa-rad-pri)#
```

- e. Enter the secret value that you obtained from the RADIUS server. The shared secret is a piece of data known only to the parties involved in a secure communication.

```
sensor(config-aaa-rad-pri) # shared-secret kkkk
sensor(config-aaa-rad-pri) #
```

**Note**

You must have the same secret value configured on both the RADIUS server and the IPS sensor so that the server can authenticate the requests of the client and the client can authenticate the responses of the server.

- Step 7** (Optional) Enable a secondary RADIUS server to perform authentication in case the primary RADIUS server is not responsive:

- a. Enter secondary server submode.

```
sensor(config-aaa-rad) # secondary-server enabled
sensor(config-aaa-rad-sec) #
```

- b. Enter the IP address of the second RADIUS server.

```
sensor(config-aaa-rad-sec) # server-address 10.4.5.6
sensor(config-aaa-rad-sec) #
```

- c. Enter the RADIUS server port. If not specified, the default RADIUS port is used.

```
sensor(config-aaa-rad-sec) # server-port 1812
sensor(config-aaa-rad-sec) #
```

- d. Enter the amount of time in seconds you want to wait for the RADIUS server to respond.

```
sensor(config-aaa-rad-sec) # time-out 8
sensor(config-aaa-rad-sec) #
```

- e. Enter the secret value you obtained for this RADIUS server. The shared secret is a piece of data known only to the parties involved in a secure communication.

```
sensor(config-aaa-rad-sec) # shared-secret yyyyy
sensor(config-aaa-rad-sec) #
```

**Note**

You must have the same secret value configured on both the RADIUS server and the IPS sensor so that the server can authenticate the requests of the client and the client can authenticate the responses of the server.

- Step 8** Specify the type of console authentication.

```
sensor(config-aaa-rad) # console-authentication radius-and-local
sensor(config-aaa-rad) #
```

You can choose local, local and RADIUS, or RADIUS.

- Step 9** Verify the settings:

```
sensor(config-aaa-rad) # show settings
```

```
radius
```

```
-----
primary-server
-----
```

```
server-address: 10.1.2.3
server-port: 1812 <defaulted>
shared-secret: kkkk
```

```

        timeout: 3 <defaulted>
-----
secondary-server
-----
        enabled
-----
        server-address: 10.4.5.6
        server-port: 1816 default: 1812
        shared-secret: yyyy
        timeout: 8 default: 3
-----
nas-id: cisco-ips default: cisco-ips
local-fallback: enabled default: enabled
console-authentication: radius-and-local <defaulted>
default-user-role: operator default: unspecified
-----
sensor(config-aaa-rad)#

```

Step 10 Exit AAA mode.

```

sensor(config-aaa-rad)# exit
sensor(config-aaa)# exit
Apply Changes?[yes]:

```

Step 11 Press **Enter** to apply the changes or enter **no** to discard them.

For More Information

- For the procedure for adding and removing users, see [Adding and Removing Users, page 4-16](#).
- For the procedure for configuring passwords, see [Configuring Passwords, page 4-28](#).
- For the procedure for specifying password requirements, see [Configuring the Password Policy, page 4-30](#).
- For detailed information on RADIUS and the service account, see [The Service Account and RADIUS Authentication, page 4-27](#).

Configuring Packet Command Restriction

Use the **permit-packet-logging** command to restrict the use of packet capture-related commands—packet capture/display and IP logging—for local and AAA RADIUS users. The default is to permit packet capture/display and IP log commands. Local users with the correct permissions can use the packet capture/display and IP log commands. AAA RADIUS users with the correct av-pair can use the packet capture/display and IP log commands. This command is supported in IPS 7.1(3)E4 and later.



Note

IP log actions configured for signatures are not impacted by the packet command restriction feature.

When you modify the packet command restriction option, you receive the following warning:

Modified packet settings would take effect only for new sessions, existing sessions will continue with previous settings.

The following options apply:

- **permit-packet-logging true**—Allows users to execute packet-related commands based on privilege level.
- **permit-packet-logging false**—Restricts all users from executing any packet-related commands.

AAA RADIUS Users

AAA RADIUS users with the correct av-pair are authorized to execute packet capture/display and IP logging commands. RADIUS users with no av-pair value are restricted. The correct av-pair, **permit-packet-logging=true**, allows users to execute packet-related commands based on privilege level. This av-pair is in addition to the authentication role related av-pair:

- **ips-role=viewer**
- **ips-role=operator**
- **ips-role=administrator**
- **ips-role=service**

Status Events

As part of the packet command restriction option, status events are triggered for the following actions:

- When an administrator enables or disables the packet command restriction.
- When an authorized user executes any of the restricted commands.
- When an unauthorized user executes any of the restricted commands.

To permit or restrict packet command restrictions, follow these steps:

Step 1 Log in to the sensor using an account with administrator privileges.

Step 2 Enter authentication submode.

```
sensor# configure terminal
sensor(config)# service authentication
sensor(config-aut)#
```

Step 3 Allow AAA RADIUS users with the correct av-pair (**permit-packet-logging=true**) and local users with the correct privilege levels to execute all packet capture/display and IP log commands.

```
sensor(config-aut)# permit-packet-logging true
```



Note Existing CLI sessions are not affected by the changes made in restriction settings.

Step 4 Check your new setting.

```
sensor(config-aut)# show settings
attemptLimit: 0 <defaulted>
password-strength
-----
size: 8-64 <defaulted>
digits-min: 0 <defaulted>
uppercase-min: 0 <defaulted>
lowercase-min: 0 <defaulted>
other-min: 0 <defaulted>
number-old-passwords: 0 <defaulted>
-----
permit-packet-logging: true default: true
cli-inactivity-timeout: 0 <defaulted>
```

```
sensor(config-aut)#
```

- Step 5** Restrict all users from executing packet capture/display and IP log commands.

```
sensor(config-aut)# permit-packet-logging false
```

- Step 6** Check your new setting.

```
sensor(config-aut)# show settings
  attemptLimit: 0 <defaulted>
  password-strength
  -----
    size: 8-64 <defaulted>
    digits-min: 0 <defaulted>
    uppercase-min: 0 <defaulted>
    lowercase-min: 0 <defaulted>
    other-min: 0 <defaulted>
    number-old-passwords: 0 <defaulted>
  -----
  permit-packet-logging: false default: true
  cli-inactivity-timeout: 0 <defaulted>
sensor(config-aut)#
```

- Step 7** Exit authentication mode.

```
sensor(config-aut)# exit
Apply Changes:[yes]:
```

- Step 8** Press **Enter** to apply the changes or enter **no** to discard them.
-

Creating the Service Account

You can create a service account for TAC to use during troubleshooting. Although more than one user can have access to the sensor, only one user can have service privileges on a sensor. The service account is for support purposes only.

The root user password is synchronized to the service account password when the service account is created. To gain root access you must log in with the service account and switch to user root with the **su - root** command.



Caution

Do not make modifications to the sensor through the service account except under the direction of TAC. If you use the service account to configure the sensor, your configuration is not supported by TAC. Adding services to the operating system through the service account affects proper performance and functioning of the other IPS services. TAC does not support a sensor on which additional services have been added.



Caution

You should carefully consider whether you want to create a service account. The service account provides shell access to the system, which makes the system vulnerable. However, you can use the service account to create a password if the administrator password is lost. Analyze your situation to decide if you want a service account existing on the system.

**Note**

For IPS 5.0 and later, you can no longer remove the **cisco** account. You can disable it using the **no password cisco** command, but you cannot remove it. To use the **no password cisco** command, there must be another administrator account on the sensor. Removing the **cisco** account through the service account is not supported. If you remove the **cisco** account through the service account, the sensor most likely will not boot up, so to recover the sensor you must reinstall the sensor system image.

To create the service account, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter configuration mode.
- ```
sensor# configure terminal
```
- Step 3** Specify the parameters for the service account. The username follows the pattern `^[A-Za-z0-9()+;._/-]+$`, which means the username must start with a letter or number, and can include any letter A to Z (capital or small), any number 0 to 9, - and \_, and can contain 1 to 64 characters.
- ```
sensor(config)# user username privilege service
```
- Step 4** Specify a password when prompted. A valid password is 8 to 32 characters long. All characters except space are allowed. If a service account already exists for this sensor, the following error is displayed and no service account is created.
- ```
Error: Only one service account may exist
```
- Step 5** Exit configuration mode.
- ```
sensor(config)# exit
sensor#
```

When you use the service account to log in to the CLI, you receive this warning.

```
***** WARNING *****
UNAUTHORIZED ACCESS TO THIS NETWORK DEVICE IS PROHIBITED. This account is intended to be
used for support and troubleshooting purposes only. Unauthorized modifications are not
supported and will require this device to be reimaged to guarantee proper operation.
*****
```

The Service Account and RADIUS Authentication

If you are using RADIUS authentication and want to create and use a service account, you must create the service account both on your sensor and on the RADIUS server. You must use local authentication to access the service account on the sensor. The service account must be created manually as a local account on the sensor. Then when you configure RADIUS authentication, the service account must also be configured manually on the RADIUS server with the accept message set to `ips-role=service`.

When you log in to the service account, you are authenticated against both the sensor account and the RADIUS server account. By whatever method you use to access the service account—serial console port, direct monitor/keyboard (for sensors that support it), or a network connection, such as SSH or Telnet—you have to log in using local authentication.

RADIUS Authentication Functionality and Limitations

The current AAA RADIUS implementation has the following functionality and limitations:

- Authentication with a RADIUS server—However, you cannot change the password of the RADIUS server from the IPS.
- Authorization—You can perform role-based authorization by specifying the IPS role of the user on the RADIUS server.
- Accounting—The login attempts of the user and the configuration changes are logged as events locally on the IPS. However, these account messages are not communicated to the RADIUS server.

Configuring Passwords

Use the **password** command to update the password on the local sensor. You can also use this command to change the password for an existing user or to reset the password for a locked account. A valid password is 8 to 32 characters long. All characters except space are allowed.

To change the password, follow these steps:

Step 1 To change the password for another user or reset the password for a locked account, follow these steps:

- a. Log in to the CLI using an account with administrator privileges.
- b. Enter configuration mode.

```
sensor# configure terminal
```

- c. Change the password for a specific user. This example modifies the password for the user “tester.”

```
sensor(config)# password tester
Enter New Login Password: *****
Re-enter New Login Password: *****
```

Step 2 To change your password, follow these steps:

- a. Log in to the CLI.
- b. Enter configuration mode.

```
sensor# configure terminal
```

- c. Change your password.

```
sensor(config)# password
Enter Old Login Password:*****
Enter New Login Password: *****
Re-enter New Login Password: *****
```

For More Information

For the procedures for recovering sensor passwords, see [Recovering the Password, page 17-2](#).

Changing User Privilege Levels



Note

You cannot use the **privilege** command to give a user service privileges. If you want to give an existing user service privileges, you must remove that user and then use the **username** command to create the service account. There can only be one person with service privileges.

Use the **privilege** command to change the privilege level—administrator, operator, viewer—for a user. To change the privilege level for a user, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Verify the current privilege of the user *jsmith*.

```
sensor# show users all
      CLI ID   User      Privilege
*   13491    cisco      administrator
      jsmith    viewer
      operator  operator
      service   service
      viewer    viewer
sensor#
```

Step 3 Change the privilege level from viewer to operator.

```
sensor# configure terminal
sensor(config)# privilege user jsmith operator
Warning: The privilege change does not apply to current CLI sessions. It will be applied
to subsequent logins.
sensor(config)#
```

Step 4 Verify that the privilege of the user has been changed. The privilege of the user *jsmith* has been changed from viewer to operator.

```
sensor(config)# exit
sensor# show users all

      CLI ID   User      Privilege
*   13491    cisco      administrator
      jsmith    operator
      operator  operator
      service   service
      viewer    viewer
sensor#
```

Step 5 Display your current level of privilege.

```
sensor# show privilege
Current privilege level is administrator
```

For More Information

For the procedure for creating the service account, see [Creating the Service Account, page 4-26](#).

Showing User Status



Note

All IPS platforms allow ten concurrent log in sessions.

Use the **show users** command to view information about the username and privilege of all users logged in to the sensor, and all user accounts on the sensor regardless of login status. An asterisk (*) indicates the current user. If an account is locked, the username is surrounded by parentheses. A locked account means that the user failed to enter the correct password after the configured attempts.

To show user information, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Verify the users logged in to the sensor.

```
sensor# show users
      CLI ID   User      Privilege
*   13491    cisco    administrator
sensor#
```

Step 3 Verify all users. The account of the user jsmith is locked.

```
sensor# show users all
      CLI ID   User      Privilege
*   13491    cisco    administrator
    5824    (jsmith) viewer
    9802    tester   operator
sensor#
```

Step 4 To unlock the account of jsmith, reset the password.

```
sensor# configure terminal
sensor(config)# password jsmith
Enter New Login Password: *****
Re-enter New Login Password: *****
```

Configuring the Password Policy

As sensor administrator, you can configure how passwords are created. All user-created passwords must conform to the policy that you set up. You can set login attempts and the size and minimum characters requirements for a password. The minimum password length is eight characters. If you forget your password, there are various ways to recover the password depending on your sensor platform.



Caution

If the password policy includes minimum numbers of character sets, such as upper case or number characters, the sum of the minimum number of required character sets cannot exceed the minimum password size. For example, you cannot set a minimum password size of eight and also require that passwords must contain at least five lowercase and five uppercase characters.

Example

For example, you can set a policy where passwords must have at least 10 characters and no more than 40, and must have a minimum of 2 upper case and 2 numeric characters. Once that policy is set, every password configured for each user account must conform to this password policy.

To set up a password policy, follow these steps:

-
- Step 1** Log in to the sensor using an account with administrator privileges.
- Step 2** Enter password strength authentication submode.
- ```
sensor# configure terminal
sensor(config)# service authentication
sensor(config-aut)# password-strength
```
- Step 3** Set the minimum number of numeric digits that must be in a password. The range is 0 to 64.
- ```
sensor(config-aut-pas)# digits-min 6
```
- Step 4** Set the minimum number of nonalphanumeric printable characters that must be in a password. The range is 0 to 64.
- ```
sensor(config-aut-pas)# other-min 3
```
- Step 5** Set the minimum number of uppercase alphabet characters that must be in a password. The range is 0 to 64.
- ```
sensor(config-aut-pas)# uppercase-min 3
```
- Step 6** Set the minimum number of lower-case alphabet characters that must be in a password.
- ```
sensor(config-aut-pas)# lowercase-min 3
```
- Step 7** Set the number of old passwords to remember for each account. A new password cannot match any of the old passwords of an account.
- ```
sensor(config-aut-pas)# number-old-passwords 3
```
- Step 8** Check your new setting.
- ```
sensor(config-aut-pas)# show settings
password-strength

size: 8-64 <defaulted>
digits-min: 6 default: 0
uppercase-min: 3 default: 0
lowercase-min: 3 default: 0
other-min: 3 default: 0
number-old-passwords: 3 default: 0

sensor(config-aut-pas)#
```
- 

**For More Information**

For the procedures for recovering sensor passwords, see [Recovering the Password](#), page 17-2.

## Locking User Accounts



### Note

When you configure account locking, local authentication, as well as RADIUS authentication, is affected. After a specified number of failed attempts to log in locally or in to a RADIUS account, the account is locked locally on the sensor. For local accounts, you can reset the password or use the **unlock user username** command to unlock the account. For RADIUS user accounts, you must use the **unlock user username** command to unlock the account.



### Note

For RADIUS users, the attempt limit feature is enforced only after the RADIUS user's first successful login to the sensor.

Use the **attemptLimit number** command in authentication submode to lock accounts so that users cannot keep trying to log in after a certain number of failed attempts. The default is 0, which indicates unlimited authentication attempts. For security purposes, you should change this number.

To configure account locking, follow these steps:

**Step 1** Log in to the sensor using an account with administrator privileges.

**Step 2** Enter service authentication submode.

```
sensor# configure terminal
sensor(config)# service authentication
```

**Step 3** Set the number of attempts users will have to log in to accounts.

```
sensor(config-aut)# attemptLimit 3
```

**Step 4** Check your new setting.

```
sensor(config-aut)# show settings
 attemptLimit: 3 defaulted: 0
sensor(config-aut)#
```

**Step 5** Set the value back to the system default setting.

```
sensor(config-aut)# default attemptLimit
```

**Step 6** Check that the setting has returned to the default.

```
sensor(config-aut)# show settings
 attemptLimit: 0 <defaulted>
sensor(config-aut)#
```

**Step 7** Check to see if any users have locked accounts. The account of the user `jsmith` is locked as indicated by the parentheses.



### Note

When you apply a configuration that contains a non-zero value for `attemptLimit`, a change is made in the SSH server that may subsequently impact your ability to connect with the sensor. When `attemptLimit` is non-zero, the SSH server requires the client to support challenge-response authentication. If you experience problems after your SSH client connects but before it prompts for a password, you need to enable challenge-response authentication. Refer to the documentation for your SSH client for instructions.

```

sensor(config-aut)# exit
sensor(config)# exit
sensor# show users all
 CLI ID User Privilege
* 1349 cisco administrator
 5824 (jsmith) viewer
 9802 tester operator

```

**Step 8** To unlock the account of jsmith, reset the password.

```

sensor# configure terminal
sensor(config)# password jsmith
Enter New Login Password: *****
Re-enter New Login Password: *****

```

#### For More Information

For the procedure for unlocking the user accounts, see [Unlocking User Accounts, page 4-33](#).

## Unlocking User Accounts



#### Note

The **unlock** command is supported in IPS 7.1(3)E4 and later.

Use the **unlock user *username*** command in global configuration mode to unlock local and RADIUS accounts for users who have been locked out after a specified number of failed attempts.

To configure account unlocking, follow these steps:

**Step 1** Log in to the sensor using an account with administrator privileges.

**Step 2** Check to see if any users have locked accounts. The account of the user jsmith is locked as indicated by the parentheses.

```

sensor# show users all
 CLI ID User Privilege
* 1349 cisco administrator
 5824 (jsmith) viewer
 9802 tester operator

```

**Step 3** Enter global configuration mode.

```

sensor# configure terminal
sensor(config)#

```

**Step 4** Unlock the account.

```

sensor(config)# unlock user jsmith

```

- Step 5** Check your new setting. The account of the user jsmith is now unlocked as indicated by the lack of parenthesis.

```
sensor# show users all
 CLI ID User Privilege
* 1349 cisco administrator
 5824 jsmith viewer
 9802 tester operator
```

---

#### For More Information

For the procedure for locking the user accounts, see [Locking User Accounts, page 4-32](#).

## Configuring Time

This section describes the importance of having a reliable time source for the sensor. It contains the following topics:

- [Time Sources and the Sensor, page 4-34](#)
- [Synchronizing IPS Module System Clocks with the Parent Device System Clock, page 4-35](#)
- [Correcting Time on the Sensor, page 4-35](#)
- [Configuring Time on the Sensor, page 4-35](#)
- [Configuring NTP, page 4-41](#)

## Time Sources and the Sensor



#### Note

We recommend that you use an NTP server to regulate time on your sensor. You can use authenticated or unauthenticated NTP. For authenticated NTP, you must obtain the NTP server IP address, NTP server key ID, and the key value from the NTP server. You can set up NTP during initialization or you can configure NTP through the CLI, IDM, IME, or ASDM.

---

The sensor requires a reliable time source. All events (alerts) must have the correct UTC and local time stamp, otherwise, you cannot correctly analyze the logs after an attack. When you initialize the sensor, you set up the time zones and summertime settings. This section provides a summary of the various ways to set the time on sensors.

#### The IPS Standalone Appliances

- Use the **clock set** command to set the time. This is the default.
- Configure the appliance to get its time from an NTP time synchronization source.



#### Note

The currently supported Cisco IPS appliances are the IPS 4240, IPS 4255, and IPS 4260 [IPS 7.1(5) and later], IPS 4270-20 [IPS 7.1(3) and later], IPS 4345 and IPS 4360 [IPS 7.1(3) and later], and IPS 4510 and IPS 4520 [IPS 7.1(4) and later].

---

### The ASA IPS Modules

- The ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP automatically synchronize their clocks with the clock in the adaptive security appliance in which they are installed. This is the default.
- Configure them to get their time from an NTP time synchronization source, such as a Cisco router other than the parent router.

## Synchronizing IPS Module System Clocks with the Parent Device System Clock

The ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) synchronize their clocks to the parent chassis clock (switch, router, or adaptive security appliance) each time the IPS boots up and any time the parent chassis clock is set. The IPS clock and parent chassis clock tend to drift apart over time. The difference can be as much as several seconds per day. To avoid this problem, make sure that both the IPS clock and the parent clock are synchronized to an external NTP server. If only the IPS clock or only the parent chassis clock is synchronized to an NTP server, the time drift occurs.

## Correcting Time on the Sensor

If you set the time incorrectly, your stored events will have the incorrect time because they are stamped with the time the event was created. The Event Store time stamp is always based on UTC time. If during the original sensor setup, you set the time incorrectly by specifying 8:00 p.m. rather than 8:00 a.m., when you do correct the error, the corrected time will be set backwards. New events might have times older than old events.

For example, if during the initial setup, you configure the sensor as central time with daylight saving time enabled and the local time is 8:04 p.m., the time is displayed as 20:04:37 CDT and has an offset from UTC of -5 hours (01:04:37 UTC, the next day). A week later at 9:00 a.m., you discover the error: the clock shows 21:00:23 CDT. You then change the time to 9:00 a.m. and now the clock shows 09:01:33 CDT. Because the offset from UTC has not changed, it requires that the UTC time now be 14:01:33 UTC, which creates the time stamp problem.

To ensure the integrity of the time stamp on the event records, you must clear the event archive of the older events by using the **clear events** command.

**Note**

You cannot remove individual events.

## Configuring Time on the Sensor

This section describes how to configure time on the sensor so that your events are time-stamped correctly. It contains the following topics:

- [Displaying the System Clock, page 4-36](#)
- [Manually Setting the System Clock, page 4-36](#)
- [Configuring Recurring Summertime Settings, page 4-37](#)
- [Configuring Nonrecurring Summertime Settings, page 4-39](#)
- [Configuring Time Zones Settings, page 4-41](#)

## Displaying the System Clock

Use the **show clock [detail]** command to display the system clock. You can use the **detail** option to indicate the clock source (NTP or system) and the current summertime setting (if any). The system clock keeps an authoritative flag that indicates whether the time is authoritative (believed to be accurate). If the system clock has been set by a timing source, such as NTP, the flag is set.

Table 4-1 lists the system clock flags.

**Table 4-1 System Clock Flags**

| Symbol  | Description                                         |
|---------|-----------------------------------------------------|
| *       | Time is not authoritative.                          |
| (blank) | Time is authoritative.                              |
| .       | Time is authoritative, but NTP is not synchronized. |

To display the system clock, follow these steps:

- 
- Step 1** Log in to the CLI.
- Step 2** Display the system clock.
- ```
sensor# show clock
*19:04:52 UTC Thu Apr 03 2008
```
- Step 3** Display the system clock with details. The following example indicates that the sensor is getting its time from NTP and that is configured and synchronized.
- ```
sensor# show clock detail
20:09:43 UTC Thu Apr 03 2011
Time source is NTP
Summer time starts 03:00:00 UTC Sun Mar 09 2011
Summer time stops 01:00:00 UTC Sun Nov 02 2011
```
- Step 4** Display the system clock with details. The following example indicates that no time source is configured.
- ```
sensor# show clock detail
*20:09:43 UTC Thu Apr 03 2011
No time source
Summer time starts 03:00:00 UTC Sun Mar 09 2011
Summer time stops 01:00:00 UTC Sun Nov 02 2011
```
-

Manually Setting the System Clock



Note

You do not need to set the system clock if your sensor is synchronized by a valid outside timing mechanism such as an NTP clock source.

Use the **clock set hh:mm [:ss] month day year** command to manually set the clock on the appliance. Use this command if no other time sources are available. The **clock set** command does not apply to the following platforms, because they get their time from the adaptive security appliance in which they are installed:

- ASA 5500 AIP SSM
- ASA 5500-X IPS SSP
- ASA 5585-X IPS SSP

To manually set the clock on the appliance, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Set the clock manually.

```
sensor# clock set 13:21 Mar 29 2011
```



Note The time format is 24-hour time.

Configuring Recurring Summertime Settings



Note Summertime is a term for daylight saving time.

Use the **summertime-option recurring** command to configure the sensor to switch to summertime settings on a recurring basis. The default is recurring.

To configure the sensor to switch to summertime settings on a recurring basis, follow these steps:

Step 1 Log in to the sensor using an account with administrator privileges.

Step 2 Enter summertime recurring submode.

```
sensor# configure terminal
sensor(config)# service host
sensor(config-hos)# summertime-option recurring
```

Step 3 Enter start summertime submode.

```
sensor(config-hos-rec)# start-summertime
```

Step 4 Configure the start summertime parameters:

- a. Enter the day of the week you want to start summertime settings.

```
sensor(config-hos-rec-sta)# day-of-week monday
```

- b. Enter the month you want to start summertime settings.

```
sensor(config-hos-rec-sta)# month april
```

- c. Enter the time of day you want to start summertime settings. The format is hh:mm:ss.

```
sensor(config-hos-rec-sta)# time-of-day 12:00:00
```

- d. Enter the week of the month you want to start summertime settings. The values are first through fifth, or last.

```
sensor(config-hos-rec-sta)# week-of-month first
```

- e. Verify your settings.

```
sensor(config-hos-rec-sta)# show settings
start-summertime
-----
month: april default: april
week-of-month: first default: first
day-of-week: monday default: sunday
time-of-day: 12:00:00 default: 02:00:00
-----
sensor(config-hos-rec-sta)#
```

- Step 5** Enter end summertime submode.

```
sensor(config-hos-rec-sta)# exit
sensor(config-hos-rec)# end-summertime
```

- Step 6** Configure the end summertime parameters:

- a. Enter the day of the week you want to end summertime settings.

```
sensor(config-hos-rec-end)# day-of-week friday
```

- b. Enter the month you want to end summertime settings.

```
sensor(config-hos-rec-end)# month october
```

- c. Enter the time of day you want to end summertime settings. The format is hh:mm:ss.

```
sensor(config-hos-rec-end)# time-of-day 05:15:00
```

- d. Enter the week of the month you want to end summertime settings. The values are first through fifth, or last.

```
sensor(config-hos-rec-end)# week-of-month last
```

- e. Verify your settings.

```
sensor(config-hos-rec-end)# show settings
end-summertime
-----
month: october default: october
week-of-month: last default: last
day-of-week: friday default: sunday
time-of-day: 05:15:00 default: 02:00:00
-----
sensor(config-hos-rec-end)#
```

- Step 7** Specify the local time zone used during summertime.

```
sensor(config-hos-rec-end)# exit
sensor(config-hos-rec)# summertime-zone-name CDT
```

- Step 8** Specify the offset.

```
sensor(config-hos-rec)# offset 60
```

- Step 9** Verify your settings.

```
sensor(config-hos-rec)# show settings
recurring
-----
offset: 60 minutes default: 60
summertime-zone-name: CDT
start-summertime
-----
month: april default: april
```

```

week-of-month: first default: first
day-of-week: monday default: sunday
time-of-day: 12:00:00 default: 02:00:00
-----
end-summertime
-----
month: october default: october
week-of-month: last default: last
day-of-week: friday default: sunday
time-of-day: 05:15:00 default: 02:00:00
-----
-----

```

Step 10 Exit recurring summertime submode.

```

sensor(config-hos-rec)# exit
sensor(config-hos)# exit
Apply Changes:[yes]:

```

Step 11 Press **Enter** to apply the changes or enter **no** to discard them.

Configuring Nonrecurring Summertime Settings



Note

Summertime is a term for daylight saving time.

Use the **summertime-option non-recurring** command to configure the sensor to switch to summer time settings on a one-time basis. The default is recurring.

To configure the sensor to switch to summertime settings on a one-time basis, follow these steps:

Step 1 Log in to the sensor using an account with administrator privileges.

Step 2 Enter summertime non-recurring submode.

```

sensor# configure terminal
sensor(config)# service host
sensor(config-hos)# summertime-option non-recurring

```

Step 3 Enter start summertime submode.

```

sensor(config-hos-non)# start-summertime

```

Step 4 Configure the start summertime parameters:

- a. Enter the date you want to start summertime settings. The format is yyyy-mm-dd.

```

sensor(config-hos-non-sta)# date 2004-05-15

```

- b. Enter the time you want to start summertime settings. The format is hh:mm:ss.

```

sensor(config-hos-non-sta)# time 12:00:00

```

- c. Verify your settings.

```

sensor(config-hos-non-sta)# show settings
start-summertime
-----
date: 2004-05-15
time: 12:00:00

```

```
-----
sensor(config-hos-non-sta)#
```

Step 5 Enter end summertime submode.

```
sensor(config-hos-non-sta)# exit
sensor(config-hos-non)# end-summertime
```

Step 6 Configure the end summertime parameters:

a. Enter the date you want to end summertime settings. The format is yyyy-mm-dd.

```
sensor(config-hos-non-end)# date 2004-10-31
```

b. Enter the time you want to end summertime settings. The format is hh:mm:ss.

```
sensor(config-hos-non-end)# time 12:00:00
```

c. Verify your settings.

```
sensor(config-hos-non-end)# show settings
end-summertime
```

```
-----
date: 2004-10-31
time: 12:00:00
-----
```

```
sensor(config-hos-non-end)#
```

Step 7 Specify the local time zone used during summertime.

```
sensor(config-hos-non-end)# exit
sensor(config-hos-non)# summertime-zone-name CDT
```

Step 8 Specify the offset.

```
sensor(config-hos-non)# offset 60
```

Step 9 Verify your settings.

```
sensor(config-hos-non)# show settings
non-recurring
```

```
-----
offset: 60 minutes default: 60
summertime-zone-name: CDT
start-summertime
```

```
-----
date: 2004-05-15
time: 12:00:00
-----
```

```
end-summertime
```

```
-----
date: 2004-10-31
time: 12:00:00
-----
```

```
-----
sensor(config-hos-non)#
```

Step 10 Exit non-recurring summertime submode.

```
sensor(config-hos-non)# exit
sensor(config-hos)# exit
Apply Changes?[yes]:
```

Step 11 Press **Enter** to apply the changes or enter **no** to discard them.

Configuring Time Zones Settings

Use the **time-zone-settings** command to configure the time zone settings on the sensor, such as the time zone name the sensor displays whenever summertime settings are not in effect and the offset.

To configure the time zone settings on the sensor, follow these steps:

-
- Step 1** Log in to the sensor using an account with administrator privileges.
- Step 2** Enter time zone settings submode.
- ```
sensor# configure terminal
sensor(config)# service host
sensor(config-hos)# time-zone-settings
```
- Step 3** Configure the time zone name that is displayed whenever summertime settings are not in effect. The default is UTC.
- ```
sensor(config-hos-tim)# standard-time-zone-name CST
```
- Step 4** Configure the offset in minutes. The offset is the number of minutes you add to UTC to get the local time. The default is 0.
- ```
sensor(config-hos-tim)# offset -360
```
- Step 5** Verify your settings.
- ```
sensor(config-hos-tim)# show settings
time-zone-settings
-----
offset: -360 minutes default: 0
standard-time-zone-name: CST default: UTC
-----
sensor(config-hos-tim)#
```
- Step 6** Exit time zone settings submode.
- ```
sensor(config-hos-tim)# exit
sensor(config-hos)# exit
Apply Changes?[yes]:
```
- Step 7** Press **Enter** to apply the changes or enter **no** to discard them.
- 

## Configuring NTP

This section describes how to configure a Cisco router to be an NTP server and how to configure the sensor to use an NTP server as its time source. It contains the following topics:

- [Configuring a Cisco Router to be an NTP Server, page 4-41](#)
- [Configuring the Sensor to Use an NTP Time Source, page 4-43](#)

### Configuring a Cisco Router to be an NTP Server

The sensor requires an authenticated connection with an NTP server if it is going to use the NTP server as its time source. The sensor supports only the MD5 hash algorithm for key encryption. Use the following procedure to activate a Cisco router to act as an NTP server and use its internal clock as the time source.

**Caution**

The sensor NTP capability is designed to be compatible with Cisco routers acting as NTP servers. The sensor may work with other NTP servers, but is not tested or supported.

**Note**

Remember the NTP server key ID and key values. You need them along with the NTP server IP address when you configure the sensor to use the NTP server as its time source.

To set up a Cisco router to act as an NTP server, follow these steps:

**Step 1** Log in to the router.

**Step 2** Enter configuration mode.

```
router# configure terminal
```

**Step 3** Create the key ID and key value. The key ID can be a number between 1 and 65535. The key value is text (numeric or character). It is encrypted later.

```
router(config)# ntp authentication-key key_ID md5 key_value
```

Example

```
router(config)# ntp authentication-key 100 md5 attack
```

**Note**

The sensor only supports MD5 keys.

**Note**

Keys may already exist on the router. Use the **show running configuration** command to check for other keys. You can use those values for the trusted key in Step 4.

**Step 4** Designate the key you just created in Step 3 as the trusted key (or use an existing key). The trusted key ID is the same number as the key ID in Step 3.

```
router(config)# ntp trusted-key key_ID
```

Example

```
router(config)# ntp trusted-key 100
```

**Step 5** Specify the interface on the router with which the sensor will communicate.

```
router(config)# ntp source interface_name
```

Example

```
router(config)# ntp source FastEthernet 1/0
```

- Step 6** Specify the NTP master stratum number to be assigned to the sensor. The NTP master stratum number identifies the relative position of the server in the NTP hierarchy. You can choose a number between 1 and 15. It is not important to the sensor which number you choose.

```
router(config)# ntp master stratum_number
```

Example

```
router(config)# ntp master 6
```

## Configuring the Sensor to Use an NTP Time Source

The sensor requires a consistent time source. We recommend that you use an NTP server. Use the following procedure to configure the sensor to use the NTP server as its time source. You can use authenticated or unauthenticated NTP.



### Note

For authenticated NTP, you must obtain the NTP server IP address, NTP server key ID, and the key value from the NTP server.



### Caution

The sensor NTP capability is designed to be compatible with Cisco routers acting as NTP servers. The sensor may work with other NTP servers, but is not tested or supported.

To configure the sensor to use an NTP server as its time source, follow these steps:

- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter configuration mode.
- ```
sensor# configure terminal
```
- Step 3** Enter service host mode.
- ```
sensor(config)# service host
```
- Step 4** Configure unauthenticated NTP:
- Enter NTP configuration mode.

```
sensor(config-hos)# ntp-option enabled-ntp-unauthenticated
```
- Specify the NTP server IP address.

```
sensor(config-hos-ena)# ntp-server ip_address
```
- Verify the unauthenticated NTP settings.

```
sensor(config-hos-ena)# show settings
enabled-ntp-unauthenticated

ntp-server: 10.89.147.45

sensor(config-hos-ena)#
```

**Step 5** Configure authenticated NTP:

- a. Enter NTP configuration mode.

```
sensor(config-hos)# ntp-option enable
```

- b. Specify the NTP server IP address and key ID. The key ID is a number between 1 and 65535. This is the key ID that you already set up on the NTP server.

```
sensor(config-hos-ena)# ntp-servers ip_address key-id key_ID
```

## Example

```
sensor(config-hos-ena)# ntp-servers 10.16.0.0 key-id 100
```

- c. Specify the key value NTP server. The key value is text (numeric or character). This is the key value that you already set up on the NTP server.

```
sensor(config-hos-ena)# ntp-keys key_ID md5-key key_value
```

## Example

```
sensor(config-hos-ena)# ntp-keys 100 md5-key attack
```

- d. Verify the NTP settings.

```
sensor(config-hos-ena)# show settings
enabled

ntp-keys (min: 1, max: 1, current: 1)

key-id: 100

md5-key: attack

ntp-servers (min: 1, max: 1, current: 1)

ip-address: 10.16.0.0
key-id: 100

sensor(config-hos-ena)#
```

**Step 6** Exit NTP configuration mode.

```
sensor(config-hos-ena)# exit
sensor(config-hos)# exit
Apply Changes:[yes]
```

**Step 7** Press **Enter** to apply the changes or enter **no** to discard them.

## Configuring SSH

This section describes SSH on the sensor, and contains the following topics:

- [Understanding SSH, page 4-45](#)
- [Adding Hosts to the SSH Known Hosts List, page 4-45](#)



- [Adding Authorized RSA1 and RSA2 Keys, page 4-47](#)
- [Generating a RSA Server Host Key, page 4-48](#)

## Understanding SSH

SSH provides strong authentication and secure communications over channels that are not secure. SSH encrypts your connection to the sensor and provides a key so you can validate that you are connecting to the correct sensor. SSH also provides authenticated and encrypted access to other devices that the sensor connects to for blocking. The IPS supports a management connection through both SSHv1 and SSHv2 (SSHv2 is supported in IPS 7.1(8)E4 and later, and IPS 7.2(1)E4 and later). In 7.1(8)E4 and later, support for both SSHv1 and SSHv2 is enabled by default.

SSH authenticates the hosts or networks using one or both of the following:

- Password
- User RSA public key



---

**Note** SSH never sends passwords in clear text.

---

SSH protects against the following:

- IP spoofing—A remote host sends out packets pretending to come from another trusted host.



---

**Note** SSH even protects against a spoofer on the local network who can pretend he is your router to the outside.

---

- IP source routing—A host pretends an IP packet comes from another trusted host.
- DNS spoofing—An attacker forges name server records.
- Interception of clear text passwords and other data by intermediate hosts.
- Manipulation of data by those in control of intermediate hosts.
- Attacks based on listening to X authentication data and spoofed connection to the X11 server.

## Adding Hosts to the SSH Known Hosts List

You must add hosts to the SSH known hosts list so that the sensor can recognize the hosts that it can communicate with through SSH. These hosts are SSH servers that the sensor needs to connect to for upgrades and file copying, and other hosts, such as Cisco routers, firewalls, and switches that the sensor will connect to for blocking.

For SSHv1, use the **ssh host-key ip-address rsa1-key[key-modulus-length public-exponent public-modulus]** command to add an entry to the known hosts list. If you do not know the values for the modulus, exponent, and length, the system displays the bubble babble for the requested IP address. You can then choose to add the key to the list. To modify a key for an IP address, the entry must be removed and recreated. Use the **no** form of the command to remove the entry.

**Caution**

When you use the **ssh host-key ip-address** command, the SSH server at the specified IP address is contacted to obtain the required key over the network. The specified host must be accessible at the moment the command is issued. If the host is unreachable, you must use the full form of the command, **ssh host-key ip-address rsa1-key [key-modulus-length public-exponent public-modulus]**, to confirm the fingerprint of the key displayed to protect yourself from accepting the key of an attacker.

For SSHv2, use the **ssh host-key ip-address rsa-key [key]** command to add an entry to the known hosts list.

The following options apply:

- **ip address**—Specifies the IP address to add to the system.
- **rsa-key**—Specifies the RSA (SSHv2) key details.
  - **key**—Specifies the Base64 encoded public key.
- **rsa1-key**—Specifies the RSA1 (SSHv1) key details:
  - **key-modulus-length**—Specifies an ASCII decimal integer in the range[511, 2048].
  - **public-exponent**—Specifies an ASCII decimal integer in the range [3, 2<sup>32</sup>].
  - **public-modulus**—Specifies an ASCII decimal integer,  $x$ , such that  $(2^{(\text{key-modulus-length}-1)}) < x < (2^{\text{key-modulus-length}})$ .

To add a host to the SSH known hosts list, follow these steps:

**Step 1** Log in to the CLI using an account with administrator or operator privileges.

**Step 2** Enter configuration mode.

```
sensor# configure terminal
```

**Step 3** Add an entry to the known hosts list.

```
sensor(config)# ssh host-key 10.16.0.0
Bubble Babble is xucis-hehon-kizog-nedeg-zunom-kolyn-syzec-zasyk-symuf-rykum-sexyx
Would you like to add this to the known hosts table for this host?[yes]
```

The Bubble Babble appears. You are prompted to add it to the known hosts list.

If the host is not accessible when the command is issued, this message appears.

```
Error: getHostSshKey : socket connect failed [4,111]
```

**Step 4** Enter **yes** to have the fingerprint added to the known hosts list.

**Step 5** Verify that the host was added.

```
sensor(config)# exit
sensor# show ssh host-keys
10.89.146.110
```

**Step 6** View the key for a specific IP address.

```
sensor# show ssh host-keys 10.16.0.0
1024 35
139306213541835240385332922253968814685684523520064131997839905113640120217816869696708721
704631322844292073851730565044879082670677554157937058485203995572114631296604552161309712
601068614812749969593513740598331393154884988302302182922353335152653860589163651944997842
874583627883277460138506084043415861927
Bubble Babble: xebiz-vykyk-fekuh-rukuh-cabaz-paret-gosym-serum-korus-fypop-huxyx
sensor#
```

**Step 7** Remove an entry. The host is removed from the SSH known hosts list.

```
sensor(config)# no ssh host-key 10.16.0.0
```

**Step 8** Verify the host was removed. The IP address no longer appears in the list.

```
sensor(config)# exit
sensor# show ssh host-keys
```

## Adding Authorized RSA1 and RSA2 Keys

Use the **ssh authorized-key** command to define public keys for a client allowed to use RSA1 or RSA2 authentication to log in to the local SSH server. The default is RSA2. You can configure the sensor to fall back to RSA1. To modify an authorized key, you must remove and recreate the entry. Use the **no** form of the command to remove the entry. Users can only create and remove their own keys.

The following options apply:

- **id**—Specifies a 1 to 256-character string that uniquely identifies the authorized key. You can use numbers, “\_,” and “-,” but spaces and “?” are not accepted.
- **rsa-pubkey**—Specifies the RSA (SSHv2) key details.
  - **pubkey**—Specifies the Base64 encoded public key.
- **rsa1-pubkey**—Specifies the RSA1 (SSHv1) key details:
  - **key-modulus-length**—Specifies an ASCII decimal integer in the range[511, 2048].
  - **public-exponent**—Specifies an ASCII decimal integer in the range [3, 2^32].
  - **public-modulus**—Specifies an ASCII decimal integer, x, such that  $(2^{(\text{key-modulus-length}-1)} < x < (2^{\text{key-modulus-length}}))$ .

Each user who can log in to the sensor has a list of authorized public keys. An SSH client with access to any of the corresponding RSA private keys can log in to the sensor as the user without entering a password.

For SSHv1, use an RSA key generation tool on the client where the private key is going to reside. Then, display the generated public key as a set of three numbers (modulus length, public exponent, public modulus) and enter those numbers as parameters for the **ssh authorized-key** command. For SSHv2, you just need the ID and the public key.



### Note

You configure your own list of SSH authorized keys. An administrator cannot manage the list of SSH authorized keys for other users on the sensor.



### Note

An SSH authorized key provides better security than passwords if the private key is adequately safeguarded. The best practice is to create the private key on the same host where it will be used and store it with a pass phrase on a local file system. To minimize password or pass phrase prompts, use a key agent.

To add a key entry to the SSHv1 or SSHv2 authorized keys list for the current user, follow these steps:

**Step 1** Log in to the CLI.

**Step 2** Add a key to the authorized keys list for the current user.



**Note** You receive an error message if you try to add a key less than the 2048-bit key size and if the measured key length and input key length do not match.

For SSHv1:

```
sensor# configure terminal
sensor(config)# ssh authorized-key mhs rsa1-pubkey 512 34 87777777777777

sensor(config)#
```

For SSHv2:

```
sensor# configure terminal
sensor(config)# ssh authorized-key phs rsa-pubkey AAAAAAAslkfjslkfjsjfs
```

**Step 3** Enter **yes** to add the key to the authorized key list.

**Step 4** Verify that the key was added.

```
sensor(config)# exit
sensor# show ssh authorized-keys
mhs
phs
sensor#
```

**Step 5** View the key for a specific ID.

```
sensor# show ssh authorized-keys mhs
512 34 87777777777777
sensor#
```

**Step 6** Remove an entry from the list of SSH authorized keys.

```
sensor# configure terminal
sensor(config)# no ssh authorized-key mhs rsa1-key
```

**Step 7** Verify the entry was removed.

```
sensor(config)# exit
sensor# show ssh authorized-keys
```

**Step 8** If you enter the former ID, you receive an error message.

```
sensor# show ssh authorized-keys mhs
Error: Requested id does not exist for the current user.
sensor#
```

## Generating a RSA Server Host Key

The server uses the SSHv1 or SSHv2 host key to prove its identity. Clients know they have contacted the correct server when they see a known key. The sensor generates an SSHv1 or SSHv2 host key the first time it starts up.

Use the **ssh generate-key** command to change the SSH server host key. The displayed fingerprint matches the one displayed in the remote SSH client in future connections with this sensor if the remote client is using SSH.

**Note**

The sensor only supports RSA keys. Peers that communicate with IPS need to support RSA keys; otherwise, the connection is not established.

To generate a new SSH server host key, follow these steps:

**Step 1** Log in to the CLI using an account with administrator privileges.

**Step 2** Generate the new server host key.

```
sensor# ssh generate-key
MD5: 93:F5:51:58:C7:FD:40:8C:07:26:5E:29:13:C8:33:AE
Bubble Babble: ximal-sudez-kusot-gosym-levag-fegoc-holez-cakar-kunel-nylis-kyxox
sensor#
```

**Caution**

The new key replaces the existing key, which requires you to update the known hosts tables on remote systems with the new host key so that future connections succeed. You can update the known hosts tables on remote systems using the **ssh host-key** command.

**Step 3** Display the current SSH server host key. The sensor displays the RSA1 (SSHv1) and the RSA (SSHv2) keys.

```
sensor# show ssh server-key
RSA1 Key: 2048 65537 2128152265420783669193575644355553045267729811163188158123
19221105282706971156372834395971442406711584211050336190060471149429624658777668
77772213935517164097668879617982452141055538222385354775671320871325156194364534
01964293900473562985740703815287014221909604447874565966052932190994239169399973
0945177474532210315062968583278733113245586019053499876586171642882215702812368
29552879443164044336379548314607826859130457872422419997317349512539506437629934
62410481738789963850532157078406908293224279442047344280835594921181229802312694
953678513524852911662327237984274983550808940893737598517019547234622411280871
RSA1 Bubble Babble: xucor-gidyg-comym-zipib-pilyk-vucal-pekyd-hipuc-tuven-gigyr-fixyx

RSA Key: AAAAB3NzaC1yc2EAAAADAQABAAQAC/zpG5nXqlAfc/aNzgQweipp9tjAqd1Xr5tuCJa+m
ccscEPHc25zUKLQG+8HkvieG2Pf11Y7mZk2POJICjXSV5izFczaFnZhBBUS+QOMH0nsk+S6F9Cujmz99
/OseRwQK16o2o2ds9otNfctAhVgex86SX5cWI0dyAYU1ZpwZCpK5sKxTtgzUkOEOsFPcHthf1DJvJfuj
1rWSJ/VAUHH4T5aomZ4m/is8jTp+nog5O5tDt6huqWYZt6MNTROXTq0UgDgG0lueoGM6Sqk0nCwUlsBG
TNaEoJbN0elRk+qNnSGo4FQYLVcRYmZYi6GOxZVxwPST3IGuEHTunAw6aUnRl
RSA Bubble Babble: xucot-sapaf-sufiz-duriv-rigud-kezol-tupif-buvih-zokap-sohoz-kixox
sensor#
```

**For More Information**

For the procedure for updating the known hosts table, see [Adding Hosts to the SSH Known Hosts List](#), page 4-45.

# Configuring TLS

This section describes TLS on the sensor, and contains the following topics:

- [Understanding TLS, page 4-50](#)
- [Adding TLS Trusted Hosts, page 4-51](#)
- [Enabling Strict TLS Certificate Checks, page 4-52](#)
- [Adding and Updating TLS Trusted Root Certificates, page 4-53](#)
- [Displaying TLS Trusted Root Certificates, page 4-55](#)
- [Displaying and Generating the Server Certificate, page 4-56](#)

## Understanding TLS

The Cisco IPS contains a web server that is running the IDM. Management stations connect to this web server. Blocking forwarding sensors also connect to the web server of the master blocking sensor. To provide security, this web server uses an encryption protocol known as TLS, which is closely related to SSL protocol. When you enter a URL into the web browser that starts with `https://ip_address`, the web browser responds by using either TLS or SSL protocol to negotiate an encrypted session with the host.

**Caution**

The web browser initially rejects the certificate presented by the IDM because it does not trust the certificate authority (CA).

**Note**

The IDM is enabled by default to use TLS and SSL. We highly recommend that you use TLS and SSL.

The process of negotiating an encrypted session in TLS is called “handshaking,” because it involves a number of coordinated exchanges between client and server. The server sends its certificate to the client. The client performs the following three-part test on this certificate:

1. Is the issuer identified in the certificate trusted?

Every web browser ships with a list of trusted third-party CAs. If the issuer identified in the certificate is among the list of CAs trusted by your browser, the first test is passed.

2. Is the date within the range of dates during which the certificate is considered valid?

Each certificate contains a Validity field, which is a pair of dates. If the date falls within this range of dates, the second test is passed.

3. Does the common name of the subject identified in the certificate match the URL hostname?

The URL hostname is compared with the subject common name. If they match, the third test is passed.

When you direct your web browser to connect with the IDM, the certificate that is returned fails because the sensor issues its own certificate (the sensor is its own CA) and the sensor is not already in the list of CAs trusted by your browser.

When you receive an error message from your browser, you have three options:

- Disconnect from the site immediately.
- Accept the certificate for the remainder of the web browsing session.

- Add the issuer identified in the certificate to the list of trusted CAs of the web browser and trust the certificate until it expires.

The most convenient option is to permanently trust the issuer. However, before you add the issuer, use out-of-band methods to examine the fingerprint of the certificate. This prevents you from being victimized by an attacker posing as a sensor. Confirm that the fingerprint of the certificate appearing in your web browser is the same as the one on your sensor.

**Caution**

If you change the organization name or hostname of the sensor, a new certificate is generated the next time the sensor is rebooted. The next time your web browser connects to the IDM, you will receive the manual override dialog boxes. You must perform the certificate fingerprint validation again for Internet Explorer and Firefox.

## Adding TLS Trusted Hosts

In certain situations, the sensor uses TLS/SSL to protect a session it establishes with a remote web server. For these sessions to be secure from man-in-the-middle attacks you must establish trust of the TLS certificates of the remote web servers. A copy of the TLS certificate of each trusted remote host is stored in the trusted hosts list.

Use the **tls trusted-host ip-address [port port]** command to add a trusted host to the trusted hosts list. This command retrieves the TLS certificate from the specified host/port and displays its fingerprint. You can accept or reject the fingerprint based on information retrieved directly from the host you are requesting to add. The default port is 443.

Each certificate is stored with an identifier field (**id**). For the IP address and default port, the identifier field is **ipaddress**. For the IP address and specified port, the identifier field is **ipaddress:port**.

**Caution**

TLS at the specified IP address is contacted to obtain the required fingerprint over the network. The specified host must be accessible at the moment the command is issued. Use an alternate method to confirm the fingerprint to protect yourself from accepting a certificate of an attacker.

To add a trusted host to the trusted hosts list, follow these steps:

**Step 1** Log in to the CLI using an account with administrator or operator privileges.

**Step 2** Add the trusted host.

```
sensor# configure terminal
sensor(config)# tls trusted-host ip-address 10.16.0.0
Certificate MD5 fingerprint is 4F:BA:15:67:D3:E6:FB:51:8A:C4:57:93:4D:F2:83:FE
Certificate SHA1 fingerprint is B1:6F:F5:DA:F3:7A:FB:FB:93:E9:2D:39:B9:99:08:D4:
47:02:F6:12
Would you like to add this to the trusted certificate table for this host?[yes]:
```

The MD5 and SHA1 fingerprints appear. You are prompted to add the trusted host.

If the connection cannot be established, the transaction fails.

```
sensor(config)# tls trusted-host ip-address 10.89.146.110 port 8000
Error: getHostCertificate : socket connect failed [4,111]
```

- Step 3** Enter **yes** to accept the fingerprint. The host is added to the TLS trusted host list. The Certificate ID stored for the requested certificate is displayed when the command is successful.

```
Certificate ID: 10.89.146.110 successfully added to the TLS trusted host table.
sensor(config)#
```

- Step 4** Verify that the host was added.

```
sensor(config)# exit
sensor# show tls trusted-hosts
10.89.146.110
sensor#
```

- Step 5** View the fingerprint for a specific host.

```
sensor# show tls trusted-hosts 10.89.146.110
MD5: 4F:BA:15:67:D3:E6:FB:51:8A:C4:57:93:4D:F2:83:FE
SHA1: B1:6F:F5:DA:F3:7A:FB:FB:93:E9:2D:39:B9:99:08:D4:47:02:F6:12
sensor#
```

- Step 6** Remove an entry from the trusted hosts list.

```
sensor# configure terminal
sensor(config)# no tls trusted-host 10.89.146.110
```

- Step 7** Verify the entry was removed from the trusted host list. The IP address no longer appears in the list.

```
sensor(config)# exit
sensor# show tls trusted-hosts
No entries
```

## Enabling Strict TLS Certificate Checks

Use the **strict-tls-server-validation {enable | disable}** command in service web server submode to enable the sensor to use strict TLS certificate validation for global correlation updates and automatic signature updates. The default is disabled. If the root CA validation fails, the TLS connection is not established to download the signature updates from the Cisco server or the global correlation updates from the update server.

To enable strict TLS server validation, follow these steps:

- Step 1** Log in to the sensor using an account with administrator privileges.

- Step 2** Enter web server submode.

```
sensor# configure terminal
sensor(config)# service web-server
```

- Step 3** Make sure TLS is enabled.

```
sensor(config-web)# enable-tls true
```

If you disable TLS, you receive this message:

```
Warning: TLS protocol support has been disabled. This change will not take effect until
the web server is re-started.
```

- Step 4** Enable strict TLS server validation.

```
sensor(config-web)# strict-tls-server-validation enable
```



**Step 5** Verify the web server changes.

```

sensor(config-web)# show settings
 enable-tls: true <defaulted>
 strict-tls-server-validation: enable default: disable
 port: 443 <defaulted>
 server-id: HTTP/1.1 compliant <defaulted>
 configurable-service (min: 0, max: 99, current: 0)

 websession-inactivity-timeout: 3600 <defaulted>
 enable-websession-inactivity-timeout-logging: false <defaulted>
 tls-client-ciphers-restriction: enable <defaulted>
sensor(config-web)#

```

**Step 6** Exit web server submenu.

```

sensor(config-web)# exit
Apply Changes:[yes]:

```

**Step 7** Press **Enter** to apply the changes or enter **no** to discard them.**Note**

If you enable TLS settings, you must reset the sensor to make the web server uses the new settings.

## Adding and Updating TLS Trusted Root Certificates

Use the **tls trusted-root-certificate** command in global configuration mode to add a new certificate or to update an existing certificate to the trusted root certificates list. The protocols used for copying the TLS root certificate are SCP and HTTPs.

The following commands apply:

- **destination-url**—Specifies the location of the TLS trusted root certificate.
- **scp**—Source or destination URL for the SCP network server. The syntax for this prefix is:  
 scp://[[username@]location]/[relativeDirectory]/filename  
 scp://[[username@]location]/[absoluteDirectory]/filename

**Note**

If you use SCP protocol, you are prompted for a password and you must add the remote host to the SSH known hosts list.

- **https**—Source URL for the Web server. The syntax for this prefix is:  
 https://[[username@]location]/[directory]/filename

To add a trusted root certificate to the trusted root certificates list, follow these steps:

**Step 1** Log in to the CLI using an account with administrator privileges.**Step 2** Add the trusted root certificate.

```

sensor# configure terminal
sensor(config)# tls trusted-root-certificate scp:
User: jsmith

```

```

Server's IP Address: 173.39.51.249
Port[22]:
File name: /ws/jsmith-bgl/CertiPostRootCert.cer
Password: *****
SHA1 fingerprint of this certificate is
74:2c:df:15:94:04:9c:bf:17:a2:04:6c:c6:39:bb:38:88:e0:2e:33
Would you like to add this to the TLS trusted certificate store (yes/no)?[yes]:

```

- Step 3** Enter **yes** to accept the trusted root certificate. The certificate is added to the TLS trusted root certificates list.

```

Certificate with SHA1 fingerprint
74:2c:df:15:94:04:9c:bf:17:a2:04:6c:c6:39:bb:38:88:e0:2e:33 successfully added to the TLS
trusted root certificate store.
sensor(config)#

```

If the connection cannot be established, the transaction fails.

```

sensor(config)# tls trusted-root-certificate
Error: Unable to receive the certificate file from the specified URL - ssh: connect to
host 10.89.12.45 port 22: Connection timed out

```

- Step 4** Update the trusted root certificate.

```

sensor(config)# tls trusted-root-certificate scp:
User: jsmith
Server's IP Address: 173.39.51.249
Port[22]:
File name: /ws/jsmith-bgl/CertiPostRootCert.cer
Password: *****
SHA1 fingerprint of this certificate is
74:2c:df:15:94:04:9c:bf:17:a2:04:6c:c6:39:bb:38:88:e0:2e:33
This certificate is going to replace an existing certificate in the TLS trusted
certificate store.
Validity of the existing certificate is same as the one you are trying to add.
Are you sure you want to proceed (yes/no)?[yes]:

```

- Step 5** Enter **yes** to update the trusted root certificate. The certificate is updated in the TLS trusted root certificates list.

```

Certificate with SHA1 fingerprint
74:2c:df:15:94:04:9c:bf:17:a2:04:6c:c6:39:bb:38:88:e0:2e:33 already exists in the TLS
trusted root certificate store.
sensor(config)#

```

- Step 6** Verify that the trusted root certificate was added.

```

sensor(config)# exit
sensor# show tls trusted-root-certificates

```

```

TLS Certificate Name: GeoTrust Global CA

```

```

Issued To: c=US,o=GeoTrust Inc.,cn=GeoTrust Global CA

```

```

Issued By: c=US,o=GeoTrust Inc.,cn=GeoTrust Global CA

```

```

SHA1-fingerprint: de:28:f4:a4:ff:e5:b9:2f:a3:c5:03:d1:a3:49:a7:f9:96:2a:82:12

```

```

MD5-fingerprint: f7:75:ab:29:fb:51:4e:b7:77:5e:ff:05:3c:99:8e:f5

```

```
Expiration Date: Sat May 21 04:00:00 2022

sensor#
```

## Displaying TLS Trusted Root Certificates

Use the **show tls trusted-root-certificates** command in privileged EXEC mode to list the current TLS trusted root certificates on the sensor.

To display the TLS trusted root certificates on the sensor, follow these steps:

**Step 1** Log in to the CLI.

**Step 2** Display the TLS trusted root certificates:

```
sensor# show tls trusted-root-certificates
TLS Certificate Name: GeoTrust Global CA
Issued To: c=US,o=GeoTrust Inc.,cn=GeoTrust Global CA
Issued By: c=US,o=GeoTrust Inc.,cn=GeoTrust Global CA
SHA1-fingerprint: de:28:f4:a4:ff:e5:b9:2f:a3:c5:03:d1:a3:49:a7:f9:96:2a:82:12
MD5-fingerprint: f7:75:ab:29:fb:51:4e:b7:77:5e:ff:05:3c:99:8e:f5
Expiration Date: Sat May 21 04:00:00 2022

TLS Certificate Name: GeoTrust Primary Certification Authority
Issued To: c=US,o=GeoTrust Inc.,cn=GeoTrust Primary Certification Authority
Issued By: c=US,o=GeoTrust Inc.,cn=GeoTrust Primary Certification Authority
SHA1-fingerprint: 32:3c:11:8e:1b:f7:b8:b6:52:54:e2:e2:10:0d:d6:02:90:37:f0:96
MD5-fingerprint: 02:26:c3:01:5e:08:30:37:43:a9:d0:7d:cf:37:e6:bf
Expiration Date: Wed Jul 16 23:59:59 2036

TLS Certificate Name: GeoTrust Universal CA
Issued To: c=US,o=GeoTrust Inc.,cn=GeoTrust Universal CA
Issued By: c=US,o=GeoTrust Inc.,cn=GeoTrust Universal CA
SHA1-fingerprint: e6:21:f3:35:43:79:05:9a:4b:68:30:9d:8a:2f:74:22:15:87:ec:79
MD5-fingerprint: 92:65:58:8b:a2:1a:31:72:73:68:5c:b4:a5:7a:07:48
Expiration Date: Sun Mar 4 05:00:00 2029

TLS Certificate Name:
Issued To: c=US,o=VeriSign, Inc.,ou=Class 3 Public Primary Certification
Authority
Issued By: c=US,o=VeriSign, Inc.,ou=Class 3 Public Primary Certification
Authority
SHA1-fingerprint: a1:db:63:93:91:6f:17:e4:18:55:09:40:04:15:c7:02:40:b0:ae:6b
MD5-fingerprint: ef:5a:f1:33:ef:f1:cd:bb:51:02:ee:12:14:4b:96:c4
Expiration Date: Wed Aug 2 23:59:59 2028

TLS Certificate Name: Thawte Premium Server CA
Issued To: c=ZA,st=Western Cape,l=Cape Town,o=Thawte Consulting
cc,ou=Certification Services Division,cn=Thawte Premium Server
CA,e=premium-server@thawte.com
Issued By: c=ZA,st=Western Cape,l=Cape Town,o=Thawte Consulting
cc,ou=Certification Services Division,cn=Thawte Premium Server
CA,e=premium-server@thawte.com
SHA1-fingerprint: e0:ab:05:94:20:72:54:93:05:60:62:02:36:70:f7:cd:2e:fc:66:66
MD5-fingerprint: a6:6b:60:90:23:9b:3f:2d:bb:98:6f:d6:a7:19:0d:46
```

```
Expiration Date: Fri Jan 1 23:59:59 2021
sensor#
```

---

## Displaying and Generating the Server Certificate

A TLS certificate is generated when the sensor is first started. Use the **tls generate-key** command to generate a new server self-signed X.509 certificate. The IP address of the sensor is included in the certificate. If you change the sensor IP address, the sensor automatically generates a new certificate.



### Caution

The new certificate replaces the existing certificate, which requires you to update the trusted hosts lists on remote systems with the new certificate so that future connections succeed. You can update the trusted hosts lists on remote IPS sensors using the **tls trusted-host** command. If the sensor is a master blocking sensor, you must update the trusted hosts lists on the remote sensors that are sending block requests to the master blocking sensor.

To generate a new TLS certificate, follow these steps:

---

**Step 1** Log in to the CLI using an account with administrator privileges.

**Step 2** Generate the new certificate.

```
sensor# tls generate-key
MD5 fingerprint is FD:83:6E:41:D3:88:48:1F:44:7F:AF:5D:52:60:89:DE
SHA1 fingerprint is 4A:2B:79:A0:82:8B:65:3A:83:B5:D9:50:C0:8E:F6:C6:B0:30:47:BB
sensor#
```

**Step 3** Verify that the key was generated.

```
sensor# show tls fingerprint
MD5: FD:83:6E:41:D3:88:48:1F:44:7F:AF:5D:52:60:89:DE
SHA1: 4A:2B:79:A0:82:8B:65:3A:83:B5:D9:50:C0:8E:F6:C6:B0:30:47:BB
sensor#
```

---

### For More Information

For the procedure for updating the trusted hosts lists on remote sensors, see [Adding TLS Trusted Hosts, page 4-51](#).

## Installing the License Key

This section describes the IPS license key and how to install it. It contains the following topics:

- [Understanding the License Key, page 4-57](#)
- [Service Programs for IPS Products, page 4-57](#)
- [Obtaining and Installing the License Key, page 4-58](#)
- [Obtaining a New License for the IPS 4270-20, page 4-60](#)
- [Licensing the ASA 5500-X IPS SSP, page 4-61](#)

- [Uninstalling the License Key, page 4-61](#)

## Understanding the License Key

Although the sensor functions without the license key, you must have a license key to obtain signature updates and use the global correlation features. To obtain a license key, you must have the following:

- Cisco Service for IPS service contract—Contact your reseller, Cisco service or product sales to purchase a contract.
- Your IPS device serial number—To find the IPS device serial number in the IDM or the IME, for the IDM choose **Configuration > Sensor Management > Licensing**, and for the IME choose **Configuration > sensor\_name > Sensor Management > Licensing**, or in the CLI use the **show version** command.
- Valid Cisco.com username and password.

Trial license keys are also available. If you cannot get your sensor licensed because of problems with your contract, you can obtain a 60-day trial license that supports signature updates that require licensing.

You can obtain a license key from the Cisco.com licensing server, which is then delivered to the sensor. Or, you can update the license key from a license key provided in a local file. Go to <http://www.cisco.com/go/license> and click **IPS Signature Subscription Service** to apply for a license key.

You can view the status of the license key in these places:

- The IDM Home window Licensing section on the Health tab
- The IDM Licensing pane (**Configuration > Licensing**)
- The IME Home page in the Device Details section on the Licensing tab
- License Notice at CLI login

Whenever you start the IDM, the IME, or the CLI, you are informed of your license status—whether you have a trial, invalid, or expired license key. With no license key, an invalid license key, or an expired license key, you can continue to use the IDM, the IME, and the CLI, but you cannot download signature updates.

If you already have a valid license on the sensor, you can click **Download** on the License pane to download a copy of your license key to the computer that the IDM or the IME is running on and save it to a local file. You can then replace a lost or corrupted license, or reinstall your license after you have reimaged the sensor.

## Service Programs for IPS Products

You must have a Cisco Services for IPS service contract for any IPS product so that you can download a license key and obtain the latest IPS signature updates. If you have a direct relationship with Cisco Systems, contact your account manager or service account manager to purchase the Cisco Services for IPS service contract. If you do not have a direct relationship with Cisco Systems, you can purchase the service account from a one-tier or two-tier partner.

When you purchase the following IPS products you must also purchase a Cisco Services for IPS service contract:

- IPS 4240
- IPS 4255

- IPS 4260
- IPS 4270-20
- IPS 4345
- IPS 4360
- IPS 4510
- IPS 4520

When you purchase an ASA 5500 series adaptive security appliance product that does not contain IPS, you must purchase a SMARTnet contract.

**Note**

SMARTnet provides operating system updates, access to Cisco.com, access to TAC, and hardware replacement NBD on site.

When you purchase an ASA 5500 series adaptive security appliance product that ships with an IPS module installed, or if you purchase one to add to your ASA 5500 series adaptive security appliance product, you must purchase the Cisco Services for IPS service contract.

**Note**

Cisco Services for IPS provides IPS signature updates, operating system updates, access to Cisco.com, access to TAC, and hardware replacement NBD on site.

For example, if you purchase an ASA 5585-X and then later want to add IPS and purchase an ASA-IPS10-K9, you must now purchase the Cisco Services for IPS service contract. After you have the Cisco Services for IPS service contract, you must also have your product serial number to apply for the license key.

**Caution**

If you ever send your product for RMA, the serial number changes. You must then get a new license key for the new serial number.

## Obtaining and Installing the License Key

**Note**

You cannot install an older license key over a newer license key.

Use the **copy source-url license\_file\_name license-key** command to copy the license key to your sensor.

The following options apply:

- *source-url*—The location of the source file to be copied. It can be a URL or keyword.
- *destination-url*—The location of the destination file to be copied. It can be a URL or a keyword.
- **license-key**—The subscription license file.
- *license\_file\_name*—The name of the license file you receive.

The exact format of the source and destination URLs varies according to the file. Here are the valid types:

- **ftp**—Source URL for an FTP network server. The syntax for this prefix is:  
`ftp://[[username@]location]/[relativeDirectory]/filename`

ftp://[[username@]location][//absoluteDirectory]/filename



**Note** You are prompted for a password.

- scp:—Source URL for the SCP network server. The syntax for this prefix is:

scp://[[username@]location][//relativeDirectory]/filename

scp://[[username@]location][//absoluteDirectory]/filename



**Note** You are prompted for a password. You must add the remote host to the SSH known hosts list.

- http:—Source URL for the web server. The syntax for this prefix is:

http://[[username@]location][//directory]/filename



**Note** The directory specification should be an absolute path to the desired file.

- https:—Source URL for the web server. The syntax for this prefix is:

https://[[username@]location][//directory]/filename



**Note** The directory specification should be an absolute path to the desired file. The remote host must be a TLS trusted host.

### Installing the License Key

To install the license key, follow these steps:

**Step 1** Log in to [Cisco.com](https://www.cisco.com).

**Step 2** Apply for the license key at this URL: [www.cisco.com/go/license](https://www.cisco.com/go/license).



**Note** In addition to a valid Cisco.com username and password, you must also have a Cisco Services for IPS service contract before you can apply for a license key.

**Step 3** Fill in the required fields. Your Cisco IPS Signature Subscription Service license key will be sent by email to the e-mail address you specified.



**Note** You must have the correct IPS device serial number and product identifier (PID) because the license key only functions on the device with that number.

**Step 4** Save the license key to a system that has a Web server, FTP server, or SCP server.

**Step 5** Log in to the CLI using an account with administrator privileges.

**Step 6** Copy the license key to the sensor.

```
sensor# copy scp://user@192.168.1.2/24://tftpboot/dev.lic license-key
Password: *****
```

**Step 7** Verify the sensor is licensed.

```

sensor# show version
Application Partition:

Cisco Intrusion Prevention System, Version 7.1(3)E4

Host:
 Realm Keys key1.0
Signature Definition:
 Signature Update S605.0 2011-10-25
OS Version: 2.6.29.1
Platform: ASA5585-SSP-IPS10
Serial Number: 123456789AB
Licensed, expires: <07-Aug-2013 UTC >
Sensor up-time is 12 days.
Using 4395M out of 5839M bytes of available memory (75% usage)
system is using 26.2M out of 160.0M bytes of available disk space (16% usage)
application-data is using 69.6M out of 171.6M bytes of available disk space (43% usage)
boot is using 57.3M out of 70.5M bytes of available disk space (86% usage)
application-log is using 494.0M out of 513.0M bytes of available disk space (96% usage)

MainApp S-2011_NOV_16_00_20_7_1_3_46 (Release) 2011-11-16T00:23:0
6-0600 Running
AnalysisEngine S-2011_NOV_16_00_20_7_1_3_46 (Release) 2011-11-16T00:23:0
6-0600 Running
CollaborationApp S-2011_NOV_16_00_20_7_1_3_46 (Release) 2011-11-16T00:23:0
6-0600 Running
CLI S-2011_NOV_16_00_20_7_1_3_46 (Release) 2011-11-16T00:23:0
6-0600

Upgrade History:

 IPS-K9-7.1-3-E4 00:30:07 UTC Wed Nov 16 2011

Recovery Partition Version 1.1 - 7.1(3)E4

Host Certificate Valid from: 16-Nov-2011 to 16-Nov-2013
sensor#

```

## Obtaining a New License for the IPS 4270-20

If your IPS 4270-20 has a license that was generated for IPS 6.0.x versions or earlier, you need to get a new license.

To obtain a new license for your IPS 4270-20, follow these steps:

- 
- Step 1** Log in to [Cisco.com](http://Cisco.com).
  - Step 2** Go to [www.cisco.com/go/license](http://www.cisco.com/go/license).
  - Step 3** Under Licenses Not Requiring a PAK, click **Demo and Evaluation licenses**.
  - Step 4** Under Security Products/Cisco Services for IPS service license (Version 6.1 and later), click **All IPS Hardware Platforms**.
  - Step 5** Fill in the required fields. Your license key will be sent to the email address you specified.



**Caution**

You must have the correct IPS device serial number and product identifier (PID) because the license key only functions on the device with that number.

- 
- Step 6** Save the license key to a hard-disk drive or a network drive that the client running the IDM or the IME can access.
- Step 7** Log in to the IDM or the IME.
- Step 8** For the IDM choose **Configuration > Sensor Management > Licensing**. For the IME choose **Configuration > *sensor\_name* > Sensor Management > Licensing**.
- Step 9** Under Update License, click the **License File** radio button.
- Step 10** In the Local File Path field, specify the path to the license file or click **Browse Local** to browse to the file.
- Step 11** Browse to the license file and click **Open**.
- Step 12** Click **Update License**.
- 

## Licensing the ASA 5500-X IPS SSP

For the ASA 5500-X series adaptive security appliances with the IPS SSP, the ASA requires the IPS Module license. To view your current ASA licenses, in ASDM choose **Home > Device Dashboard > Device Information > Device License**. For more information about ASA licenses, refer to the licensing chapter in the configuration guide. After you obtain the ASA IPS Module license, you can obtain and install the IPS license key.

### For More Information

- For more information about getting started using the ASA 5500-X IPS SSP, refer to the [Cisco IPS Module on the ASA Quick Start Guide](#).
- For the procedures for obtaining and installing the IPS License key, see [Obtaining and Installing the License Key](#), page 4-58.

## Uninstalling the License Key

Use the **erase license-key** command to uninstall the license key on your sensor. This allows you to delete an installed license key from a sensor without restarting the sensor or logging into the sensor using the service account. Uninstalling the license key is supported in IPS 7.1(3)E4 and later.

To uninstall the license key, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Uninstall the license key on the sensor.

```
sensor# erase license-key
```

```
Warning: Executing this command will remove the license key installed on the sensor.
```

You must have a valid license key installed on the sensor to apply the Signature Updates and use the Global Correlation features.

```
Continue? []: yes
```

```
sensor#
```

**Step 3** Verify the sensor key has been uninstalled.

```
sensor# show version
```

```
Application Partition:
```

```
Cisco Intrusion Prevention System, Version 7.1(5)E4
```

```
Host:
```

```
 Realm Keys key1.0
```

```
Signature Definition:
```

```
 Signature Update S615.0 2012-01-03
```

```
OS Version: 2.6.29.1
```

```
Platform: IPS-4345-K9
```

```
Serial Number: FCH1445V00N
```

```
No license present
```

```
Sensor up-time is 5 days.
```

```
Using 5318M out of 7864M bytes of available memory (67% usage)
```

```
system is using 33.6M out of 160.0M bytes of available disk space (21% usage)
```

```
application-data is using 70.5M out of 169.4M bytes of available disk space (44% usage)
```

```
boot is using 62.5M out of 70.1M bytes of available disk space (94% usage)
```

```
application-log is using 494.0M out of 513.0M bytes of available disk space (96% usage)
```

```
MainApp S-2012_APR_26_07_45_7_1_4_68 (Release) 2012-04-26T07:48:4
3-0500 Running
AnalysisEngine S-2012_APR_26_07_45_7_1_4_68 (Release) 2012-04-26T07:48:4
3-0500 Running
CollaborationApp S-2012_APR_26_07_45_7_1_4_68 (Release) 2012-04-26T07:48:4
3-0500 Running
CLI S-2012_APR_26_07_45_7_1_4_68 (Release) 2012-04-26T07:48:4
3-0500
```

```
Upgrade History:
```

```
 IPS-K9-7.1-5-E4 08:05:07 UTC Thu Apr 26 2012
```

```
Recovery Partition Version 1.1 - 7.1(5)E4
```

```
Host Certificate Valid from: 25-Apr-2012 to 26-Apr-2014
```

---



## Configuring Interfaces

---

This chapter describes how to configure interfaces on the sensor. You configured the interfaces when you initialized the sensor with the **setup** command, but if you need to change or add anything to your interface configuration, use the following procedures. For more information on configuring interfaces using the **setup** command, see [Chapter 3, “Initializing the Sensor.”](#)

This chapter contains the following sections:

- [Interface Notes and Caveats, page 5-1](#)
- [Understanding Interfaces, page 5-2](#)
- [Configuring Physical Interfaces, page 5-15](#)
- [Configuring Promiscuous Mode, page 5-19](#)
- [Configuring Inline Interface Mode, page 5-20](#)
- [Configuring Inline VLAN Pair Mode, page 5-25](#)
- [Configuring VLAN Group Mode, page 5-31](#)
- [Configuring Inline Bypass Mode, page 5-38](#)
- [Configuring Interface Notifications, page 5-40](#)
- [Configuring CDP Mode, page 5-41](#)
- [Displaying Interface Statistics, page 5-42](#)
- [Displaying Interface Traffic History, page 5-45](#)

## Interface Notes and Caveats

The following notes and caveats apply to configuring interfaces on the sensor:

- On appliances, all sensing interfaces are disabled by default. You must enable them to use them. On modules, the sensing interfaces are permanently enabled.
- In IPS 7.1, rx/tx flow control is disabled on the IPS 4200 series sensors. This is a change from IPS 7.0 where rx/tx flow control is enabled by default.
- There is only one sensing interface on the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP), so you cannot designate an alternate TCP reset interface.
- You can only assign a sensing interface as an alternate TCP reset interface. You cannot configure the management interface as an alternate TCP reset interface.

- You configure the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, ASA 5585-X IPS SSP) for promiscuous mode from the adaptive security appliance CLI and not from the Cisco IPS CLI.
- You can configure the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) to operate inline even though they have only one sensing interface.
- The ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) do not support inline VLAN pairs.
- The ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) do not support VLAN groups mode.
- There are security consequences when you put the sensor in bypass mode. When bypass mode is on, the traffic bypasses the sensor and is not inspected; therefore, the sensor cannot prevent malicious attacks.
- As with signature updates, when the sensor applies a global correlation update, it may trigger bypass. Whether or not bypass is triggered depends on the traffic load of the sensor and the size of the signature/global correlation update. If bypass mode is turned off, an inline sensor stops passing traffic while the update is being applied.
- The ASA 5500-X IPS SSP and ASA 5585-X IPS SSP do not support bypass mode. The adaptive security appliance will either fail open, fail close, or fail over depending on the configuration of the adaptive security appliance and the type of activity being done on the IPS.
- The **show interface** command output for the IPS 4510 and IPS 4520 does not include the total undersize packets or total transmit FIFO overruns.
- When the IPS 4510 and IPS 4520 are configured in VLAN pairs, the **packet display** command does not work without the VLAN option if the **expression** keyword is also used.
- For the IPS 4510 and IPS 4520, the maximum number of inline VLAN pairs you can create system wide is 150. On all other platforms, the limit is 255 per interface.
- On the IPS 4510 and IPS 4520, no interface-related configurations are allowed when the SensorApp is down.
- For IPS standalone appliances with 1 G and 10 G fixed or add-on interfaces, the maximum jumbo frame size is 9216 bytes. For integrated IPS sensors, such as the ASA 5500-X and ASA 5585-X series, refer to the following URL for information:

[http://www.cisco.com/en/US/docs/security/asa/asa84/configuration/guide/interface\\_start.html#wp1328869](http://www.cisco.com/en/US/docs/security/asa/asa84/configuration/guide/interface_start.html#wp1328869)

**Note**

A jumbo frame is an Ethernet packet that is larger than the standard maximum of 1518 bytes (including Layer 2 header and FCS).

## Understanding Interfaces

This section describes the IPS interfaces and modes, and contains the following topics:

- [IPS Interfaces, page 5-3](#)
- [Command and Control Interface, page 5-3](#)
- [Sensing Interfaces, page 5-4](#)
- [TCP Reset Interfaces, page 5-5](#)

- [Interface Support, page 5-7](#)
- [Hardware Bypass Mode, page 5-11](#)
- [Interface Configuration Restrictions, page 5-12](#)
- [Interface Configuration Sequence, page 5-15](#)

## IPS Interfaces

The sensor interfaces are named according to the maximum speed and physical location of the interface. The physical location consists of a port number and a slot number. All interfaces that are built-in on the sensor motherboard are in slot 0, and the interface card expansion slots are numbered beginning with slot 1 for the bottom slot with the slot numbers increasing from bottom to top (except for the IPS 4270-20, where the ports are numbered from top to bottom). Each physical interface can be divided in to VLAN group subinterfaces, each of which consists of a group of VLANs on that interface.

There are three interface roles:

- Command and control
- Sensing
- Alternate TCP reset

There are restrictions on which roles you can assign to specific interfaces and some interfaces have multiple roles. You can configure any sensing interface to any other sensing interface as its TCP reset interface. The TCP reset interface can also serve as an IDS (promiscuous) sensing interface at the same time. The following restriction applies: The TCP reset interface that is assigned to a sensing interface has no effect in inline interface or inline VLAN pair mode, because TCP resets are always sent on the sensing interfaces in those modes.



### Note

There is only one sensing interface on the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP), so you cannot designate an alternate TCP reset interface.



### Caution

On the IPS 4510 and IPS 4520, no interface-related configurations are allowed when the SensorApp is down.

## Command and Control Interface

The command and control interface has an IP address and is used for configuring the sensor. It receives security and status events from the sensor and queries the sensor for statistics. The command and control interface is permanently enabled. It is permanently mapped to a specific physical interface, which depends on the specific model of sensor. You cannot use the command and control interface as either a sensing or alternate TCP reset interface.

Table 5-1 lists the command and control interfaces for each sensor.

**Table 5-1 Command and Control Interfaces**

| Sensor                | Command and Control Interface |
|-----------------------|-------------------------------|
| ASA 5500 AIP SSM-10   | GigabitEthernet 0/0           |
| ASA 5500 AIP SSM-20   | GigabitEthernet 0/0           |
| ASA 5500 AIP SSM-40   | GigabitEthernet 0/0           |
| ASA 5512-X IPS SSP    | Management 0/0                |
| ASA 5515-X IPS SSP    | Management 0/0                |
| ASA 5525-X IPS SSP    | Management 0/0                |
| ASA 5545-X IPS SSP    | Management 0/0                |
| ASA 5555-X IPS SSP    | Management 0/0                |
| ASA 5585-X IPS SSP-10 | Management 0/0                |
| ASA 5585-X IPS SSP-20 | Management 0/0                |
| ASA 5585-X IPS SSP-40 | Management 0/0                |
| ASA 5585-X IPS SSP-60 | Management 0/0                |
| IPS 4240              | Management 0/0                |
| IPS 4255              | Management 0/0                |
| IPS 4260              | Management 0/0                |
| IPS 4270-20           | Management 0/0                |
| IPS 4345              | Management 0/0                |
| IPS 4360              | Management 0/0                |
| IPS 4510              | Management 0/0                |
| IPS 4520              | Management 0/0                |

## Sensing Interfaces

Sensing interfaces are used by the sensor to analyze traffic for security violations. A sensor has one or more sensing interfaces depending on the sensor. Sensing interfaces can operate individually in promiscuous mode or you can pair them to create inline interfaces.



### Note

On appliances, all sensing interfaces are disabled by default. You must enable them to use them. On modules, the sensing interfaces are permanently enabled.

Some appliances support optional interface cards that add sensing interfaces to the sensor. You must insert or remove these optional cards while the sensor is powered off. The sensor detects the addition or removal of a supported interface card. If you remove an optional interface card, some of the interface configuration is deleted, such as the speed, duplex, description string, enabled/disabled state of the interface, and any inline interface pairings. These settings are restored to their default settings when the card is reinstalled. However, the assignment of promiscuous and inline interfaces to the Analysis Engine is not deleted from the Analysis Engine configuration, but is ignored until those cards are reinserted and you create the inline interface pairs again.

**For More Information**

- For more information on supported interfaces, see [Interface Support](#), page 5-7.
- For more information on interface modes, see [Configuring Promiscuous Mode](#), page 5-20, [Configuring Inline Interface Pairs](#), page 5-21, [Understanding Inline VLAN Pair Mode](#), page 5-25, [Understanding VLAN Group Mode](#), page 5-31, [Configuring Inline Bypass Mode](#), page 5-38.

## TCP Reset Interfaces

This section explains the TCP reset interfaces and when to use them. It contains the following topics:

- [Understanding Alternate TCP Reset Interfaces](#), page 5-5
- [Designating the Alternate TCP Reset Interface](#), page 5-6

### Understanding Alternate TCP Reset Interfaces

You can configure sensors to send TCP reset packets to try to reset a network connection between an attacker host and its intended target host. In some installations when the interface is operating in promiscuous mode, the sensor may not be able to send the TCP reset packets over the same sensing interface on which the attack was detected. In such cases, you can associate the sensing interface with an alternate TCP reset interface and any TCP resets that would otherwise be sent on the sensing interface when it is operating in promiscuous mode are instead sent out on the associated alternate TCP reset interface.

If a sensing interface is associated with an alternate TCP reset interface, that association applies when the sensor is configured for promiscuous mode but is ignored when the sensing interface is configured for inline mode. any sensing interface can serve as the alternate TCP reset interface for another sensing interface.

**Note**

There is only one sensing interface on the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP), so you cannot designate an alternate TCP reset interface.

[Table 5-2](#) lists the alternate TCP reset interfaces.

**Table 5-2**      **Alternate TCP Reset Interfaces**

| Sensor                | Alternate TCP Reset Interface |
|-----------------------|-------------------------------|
| ASA 5500 AIP SSM-10   | None                          |
| ASA 5500 AIP SSM-20   | None                          |
| ASA 5500 AIP SSM-40   | None                          |
| ASA 5512-X IPS SSP    | None                          |
| ASA 5515-X IPS SSP    | None                          |
| ASA 5525-X IPS SSP    | None                          |
| ASA 5545-X IPS SSP    | None                          |
| ASA 5555-X IPS SSP    | None                          |
| ASA 5585-X IPS SSP-10 | None                          |

**Table 5-2** *Alternate TCP Reset Interfaces (continued)*

| Sensor                | Alternate TCP Reset Interface |
|-----------------------|-------------------------------|
| ASA 5585-X IPS SSP-20 | None                          |
| ASA 5585-X IPS SSP-40 | None                          |
| ASA 5585-X IPS SSP-60 | None                          |
| IPS 4240              | Any sensing interface         |
| IPS 4255              | Any sensing interface         |
| IPS 4260              | Any sensing interface         |
| IPS 4270-20           | Any sensing interface         |
| IPS 4345              | Any sensing interface         |
| IPS 4360              | Any sensing interface         |
| IPS 4510              | Any sensing interface         |
| IPS 4520              | Any sensing interface         |

**For More Information**

For more information on choosing the alternate TCP interface, see [Designating the Alternate TCP Reset Interface, page 5-6](#).

## Designating the Alternate TCP Reset Interface

**Note**

There is only one sensing interface on the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP), so you cannot designate an alternate TCP reset interface.

You need to designate an alternate TCP reset interface in the following situations:

- When a switch is being monitored with either SPAN or VACL capture and the switch does not accept incoming packets on the SPAN or VACL capture port.
- When a switch is being monitored with either SPAN or VACL capture for multiple VLANs, and the switch does not accept incoming packets with 802.1q headers. The TCP resets need 802.1q headers to tell which VLAN the resets should be sent on.
- When a network tap is used for monitoring a connection. Taps do not permit incoming traffic from the sensor.

**Caution**

You can only assign a sensing interface as an alternate TCP reset interface. You cannot configure the management interface as an alternate TCP reset interface.



## Interface Support

Table 5-3 describes the interface support for appliances and modules running Cisco IPS.

**Table 5-3**      *Interface Support*

| Base Chassis          | Added Interface Cards | Interfaces Supporting Inline VLAN Pairs (Sensing Ports)                               | Combinations Supporting Inline Interface Pairs                                        | Interfaces Not Supporting Inline (Command and Control Port) |
|-----------------------|-----------------------|---------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|-------------------------------------------------------------|
| ASA 5500 AIP SSM-10   | —                     | GigabitEthernet 0/1 by security context instead of VLAN pair or inline interface pair | GigabitEthernet 0/1 by security context instead of VLAN pair or inline interface pair | GigabitEthernet 0/0                                         |
| ASA 5500 AIP SSM-20   | —                     | GigabitEthernet 0/1 by security context instead of VLAN pair or inline interface pair | GigabitEthernet 0/1 by security context instead of VLAN pair or inline interface pair | GigabitEthernet 0/0                                         |
| ASA 5500 AIP SSM-40   | —                     | GigabitEthernet 0/1 by security context instead of VLAN pair or inline interface pair | GigabitEthernet 0/1 by security context instead of VLAN pair or inline interface pair | GigabitEthernet 0/0                                         |
| ASA 5512-X IPS SSP    | —                     | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair     | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair     | Management 0/0                                              |
| ASA 5515-X IPS SSP    | —                     | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair     | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair     | Management 0/0                                              |
| ASA 5525-X IPS SSP    | —                     | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair     | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair     | Management 0/0                                              |
| ASA 5545-X IPS SSP    | —                     | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair     | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair     | Management 0/0                                              |
| ASA 5555-X IPS SSP    | —                     | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair     | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair     | Management 0/0                                              |
| ASA 5585-X IPS SSP-10 | —                     | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair     | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair     | Management 0/0                                              |
| ASA 5585-X IPS SSP-20 | —                     | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair     | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair     | Management 0/0                                              |
| ASA 5585-X IPS SSP-40 | —                     | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair     | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair     | Management 0/0                                              |

**Table 5-3** *Interface Support (continued)*

| Base Chassis          | Added Interface Cards | Interfaces Supporting Inline VLAN Pairs (Sensing Ports)                                  | Combinations Supporting Inline Interface Pairs                                    | Interfaces Not Supporting Inline (Command and Control Port) |
|-----------------------|-----------------------|------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-------------------------------------------------------------|
| ASA 5585-X IPS SSP-60 | —                     | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair        | PortChannel 0/0 by security context instead of VLAN pair or inline interface pair | Management 0/0                                              |
| IPS 4240              | —                     | GigabitEthernet 0/0<br>GigabitEthernet 0/1<br>GigabitEthernet 0/2<br>GigabitEthernet 0/3 | 0/0<->0/1<br>0/0<->0/2<br>0/0<->0/3<br>0/1<->0/2<br>0/1<->0/3<br>0/2<->0/3        | Management 0/0                                              |
| IPS 4255              | —                     | GigabitEthernet 0/0<br>GigabitEthernet 0/1<br>GigabitEthernet 0/2<br>GigabitEthernet 0/3 | 0/0<->0/1<br>0/0<->0/2<br>0/0<->0/3<br>0/1<->0/2<br>0/1<->0/3<br>0/2<->0/3        | Management 0/0                                              |
| IPS 4260              | —                     | GigabitEthernet 0/1                                                                      | N/A                                                                               | Management 0/0                                              |
| IPS 4260              | 4GE-BP                | GigabitEthernet 0/1                                                                      |                                                                                   | Management 0/0                                              |
|                       | Slot 1                | GigabitEthernet 2/0<br>GigabitEthernet 2/1<br>GigabitEthernet 2/2<br>GigabitEthernet 2/3 | 2/0<->2/1 <sup>1</sup><br>2/2<->2/3                                               |                                                             |
|                       | Slot 2                | GigabitEthernet 3/0<br>GigabitEthernet 3/1<br>GigabitEthernet 3/2<br>GigabitEthernet 3/3 | 3/0<->3/1<br>3/2<->3/3                                                            |                                                             |
| IPS 4260              | 2SX                   | GigabitEthernet 0/1                                                                      | All sensing ports can be paired together                                          | Management 0/0                                              |
|                       | Slot 1                | GigabitEthernet 2/0<br>GigabitEthernet 2/1                                               |                                                                                   |                                                             |
|                       | Slot 2                | GigabitEthernet 3/0<br>GigabitEthernet 3/1                                               |                                                                                   |                                                             |
| IPS 4260              | 10GE                  | GigabitEthernet 0/1                                                                      |                                                                                   | Management 0/0                                              |
|                       | Slot 1                | TenGigabitEthernet 2/0<br>TenGigabitEthernet 2/1                                         | 2/0<->2/1 <sup>2</sup>                                                            |                                                             |
| IPS 4270-20           | —                     | —                                                                                        | N/A                                                                               | Management 0/0<br>Management 0/1 <sup>3</sup>               |

**Table 5-3**      **Interface Support (continued)**

| Base Chassis | Added Interface Cards | Interfaces Supporting Inline VLAN Pairs (Sensing Ports)                                                                                                                              | Combinations Supporting Inline Interface Pairs | Interfaces Not Supporting Inline (Command and Control Port) |
|--------------|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------|-------------------------------------------------------------|
| IPS 4270-20  | 4GE-BP                |                                                                                                                                                                                      |                                                | Management 0/0<br>Management 0/1 <sup>4</sup>               |
|              | Slot 1                | GigabitEthernet 3/0<br>GigabitEthernet 3/1<br>GigabitEthernet 3/2<br>GigabitEthernet 3/3                                                                                             | 3/0<->3/1 <sup>4</sup><br>3/2<->3/3            |                                                             |
|              | Slot 2                | GigabitEthernet 4/0<br>GigabitEthernet 4/1<br>GigabitEthernet 4/2<br>GigabitEthernet 4/3                                                                                             | 4/0<->4/1<br>4/2<->4/3                         |                                                             |
| IPS 4270-20  | 2SX                   |                                                                                                                                                                                      | All sensing ports can be paired together       | Management 0/0<br>Management 0/1 <sup>4</sup>               |
|              | Slot 1                | GigabitEthernet 3/0<br>GigabitEthernet 3/1                                                                                                                                           |                                                |                                                             |
|              | Slot 2                | GigabitEthernet 4/0<br>GigabitEthernet 4/1                                                                                                                                           |                                                |                                                             |
| IPS 4270-20  | 10GE                  |                                                                                                                                                                                      | All sensing ports can be paired together       | Management 0/0<br>Management 0/1 <sup>4</sup>               |
|              | Slot 1                | TenGigabitEthernet 5/0<br>TenGigabitEthernet 5/1                                                                                                                                     |                                                |                                                             |
|              | Slot 2                | TenGigabitEthernet 7/0<br>TenGigabitEthernet 7/1                                                                                                                                     |                                                |                                                             |
| IPS 4345     | —                     | GigabitEthernet 0/0<br>GigabitEthernet 0/1<br>GigabitEthernet 0/2<br>GigabitEthernet 0/3<br>GigabitEthernet 0/4<br>GigabitEthernet 0/5<br>GigabitEthernet 0/6<br>GigabitEthernet 0/7 | All sensing ports can be paired together       | Management 0/0<br>Management 0/1 <sup>5</sup>               |

**Table 5-3**      **Interface Support (continued)**

| Base Chassis | Added Interface Cards | Interfaces Supporting Inline VLAN Pairs (Sensing Ports)                                                                                                                                                                                        | Combinations Supporting Inline Interface Pairs | Interfaces Not Supporting Inline (Command and Control Port) |
|--------------|-----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------|-------------------------------------------------------------|
| IPS 4360     | —                     | GigabitEthernet 0/0<br>GigabitEthernet 0/1<br>GigabitEthernet 0/2<br>GigabitEthernet 0/3<br>GigabitEthernet 0/4<br>GigabitEthernet 0/5<br>GigabitEthernet 0/6<br>GigabitEthernet 0/7                                                           | All sensing ports can be paired together       | Management 0/0<br>Management 0/1 <sup>5</sup>               |
| IPS 4510     | —                     | GigabitEthernet 0/0<br>GigabitEthernet 0/1<br>GigabitEthernet 0/2<br>GigabitEthernet 0/3<br>GigabitEthernet 0/4<br>GigabitEthernet 0/5<br>TenGigabitEthernet 0/6<br>TenGigabitEthernet 0/7<br>TenGigabitEthernet 0/8<br>TenGigabitEthernet 0/9 | All sensing ports can be paired together       | Management 0/0<br>Management 0/1                            |
| IPS 4520     | —TX                   | GigabitEthernet 0/0<br>GigabitEthernet 0/1<br>GigabitEthernet 0/2<br>GigabitEthernet 0/3<br>GigabitEthernet 0/4<br>GigabitEthernet 0/5<br>TenGigabitEthernet 0/6<br>TenGigabitEthernet 0/7<br>TenGigabitEthernet 0/8<br>TenGigabitEthernet 0/9 | All sensing ports can be paired together       | Management 0/0<br>Management 0/1                            |

1. To disable hardware bypass, pair the interfaces in any other combination (2/0<->2/2 and 2/1<->2/3, for example).
2. To disable hardware bypass, pair the interfaces in any other combination (2/0<->2/2 and 2/1<->2/3, for example).
3. Reserved for future use.
4. To disable hardware bypass, pair the interfaces in any other combination (2/0<->2/2 and 2/1<->2/3, for example).
5. Does not currently support hardware bypass.

**Note**

The IPS 4260 supports a mixture of 4GE-BP, 2SX, and 10GE cards. The IPS 4270-20 supports a mixture of 4GE-BP, 2SX, and 10GE cards up to a total of either six cards, or sixteen total ports, whichever is reached first, but is limited to only two 10GE card in the mix of cards.

## Hardware Bypass Mode

In addition to Cisco IPS software bypass, the IPS 4260 and the IPS 4270-20 also support hardware bypass. This section describes the hardware bypass card and its configuration restrictions, and contains the following topics:

- [Hardware Bypass Card, page 5-11](#)
- [Hardware Bypass Configuration Restrictions, page 5-12](#)

### Hardware Bypass Card

The IPS 4260 and the IPS 4270-20 support the 4-port GigabitEthernet card (part number IPS-4GE-BP-INT=) with hardware bypass. This 4GE bypass interface card supports hardware bypass only between ports 0 and 1 and between ports 2 and 3.

**Note**

To disable hardware bypass, pair the interfaces in any other combination, for example 2/0<->2/2 and 2/1<->2/3.

Hardware bypass complements the existing software bypass feature in Cisco IPS. The following conditions apply to hardware bypass and software bypass:

- When bypass is set to OFF, software bypass is not active.

For each inline interface for which hardware bypass is available, the component interfaces are set to disable the fail-open capability. If SensorApp fails, the sensor is powered off, reset, or if the NIC interface drivers fail or are unloaded, the paired interfaces enter the fail-closed state (no traffic flows through inline interface or inline VLAN subinterfaces).

- When bypass is set to ON, software bypass is active.

Software bypass forwards packets between the paired physical interfaces in each inline interface and between the paired VLANs in each inline VLAN subinterface. For each inline interface on which hardware bypass is available, the component interfaces are set to standby mode. If the sensor is powered off, reset, or if the NIC interfaces fail or are unloaded, those paired interfaces enter fail-open state in hardware (traffic flows unimpeded through inline interface). Any other inline interfaces enter fail-closed state.

- When bypass is set to AUTO (traffic flows without inspection), software bypass is activated if SensorApp fails.

For each inline interface on which hardware bypass is available, the component interfaces are set to standby mode. If the sensor is powered off, reset, or if the NIC interfaces fail or are unloaded, those paired interfaces enter fail-open state in hardware. Any other inline interfaces enter the fail-closed state.

**Note**

To test fail-over, set the bypass mode to ON or AUTO, create one or more inline interfaces and power down the sensor and verify that traffic still flows through the inline path.

**For More Information**

For the procedure for configuring inline bypass mode, see [Configuring Inline Bypass Mode, page 5-39](#).

## Hardware Bypass Configuration Restrictions

To use the hardware bypass feature on the 4GE bypass interface card, you must pair interfaces to support the hardware design of the card. If you create an inline interface that pairs a hardware-bypass-capable interface with an interface that violates one or more of the hardware-bypass configuration restrictions, hardware bypass is deactivated on the inline interface and you receive a warning message similar to the following:

```
Hardware bypass functionality is not available on Inline-interface pair0.
Physical-interface GigabitEthernet2/0 is capable of performing hardware bypass only when
paired with GigabitEthernet2/1, and both interfaces are enabled and configured with the
same speed and duplex settings.
```

The following configuration restrictions apply to hardware bypass:

- The 4-port bypass card is only supported on the IPS 4260 and IPS 4270-20.
- Fail-open hardware bypass only works on inline interfaces (interface pairs), not on inline VLAN pairs.
- Fail-open hardware bypass is available on an inline interface if all of the following conditions are met:
  - Both of the physical interfaces support hardware bypass.
  - Both of the physical interfaces are on the same interface card.
  - The two physical interfaces are associated in hardware as a bypass pair.
  - The speed and duplex settings are identical on the physical interfaces.
  - Both of the interfaces are administratively enabled.
- Autonegotiation must be set on MDI/X switch ports connected to the IPS 4260 and IPS 4270-20.

You must configure both the sensor ports and the switch ports for autonegotiation for hardware bypass to work. The switch ports must support MDI/X, which automatically reverses the transmit and receive lines if necessary to correct any cabling problems. The sensor is only guaranteed to operate correctly with the switch if both of them are configured for identical speed and duplex, which means that the sensor must be set for autonegotiation too.

**Hardware Bypass Turned Off for System Image Recovery or Reimage**

Hardware bypass starts when you enter the **recover application** command and the interfaces are paired correctly. Hardware bypass works until the IPS starts up again with the empty configuration. Because all interfaces default to `disabled` and are no longer paired, when the SensorApp loads, it stops hardware bypass and sets the interfaces to `link down`. BEFORE you perform a reimage or recover, make sure you bypass the traffic at the switch.

## Interface Configuration Restrictions

For IPS standalone appliances with 1 G and 10 G fixed or add-on interfaces, the maximum jumbo frame size is 9216 bytes. For integrated IPS sensors, such as the ASA 5500-X and ASA 5585-X series, refer to the following URL for information:

[http://www.cisco.com/en/US/docs/security/asa/asa84/configuration/guide/interface\\_start.html#wp1328869](http://www.cisco.com/en/US/docs/security/asa/asa84/configuration/guide/interface_start.html#wp1328869)

**Note**

A jumbo frame is an Ethernet packet that is larger than the standard maximum of 1518 bytes (including Layer 2 header and FCS).

The following restrictions apply to configuring interfaces on the sensor:

- Physical Interfaces
  - In IPS 7.1, rx/tx flow control is disabled on the IPS 4200 series sensors. This is a change from IPS 7.0 where rx/tx flow control is enabled by default.
  - On the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) all backplane interfaces have fixed speed, duplex, and state settings. These settings are protected in the default configuration on all backplane interfaces.
  - For nonbackplane FastEthernet interfaces the valid speed settings are 10 Mbps, 100 Mbps, and auto. Valid duplex settings are full, half, and auto.
  - For Gigabit copper interfaces (1000-TX on the IPS 4240, IPS 4255, IPS 4260, IPS 4270-20, IPS 4345, IPS 4360, IPS 4510, and IPS 4520), valid speed settings are 10 Mbps, 100 Mbps, 1000 Mbps, and auto. Valid duplex settings are full, half, and auto.
  - For Gigabit (copper or fiber) interfaces, if the speed is configured for 1000 Mbps, the only valid duplex setting is auto.
  - The command and control interface cannot also serve as a sensing interface.
- Inline Interface Pairs
  - Inline interface pairs can contain any combination of sensing interfaces regardless of the physical interface type (copper versus fiber), speed, or duplex settings of the interface. However, pairing interfaces of different media type, speeds, and duplex settings may not be fully tested or supported.
  - The command and control interface cannot be a member of an inline interface pair.
  - You cannot pair a physical interface with itself in an inline interface pair.
  - A physical interface can be a member of only one inline interface pair.
  - You can only configure bypass mode and create inline interface pairs on sensor platforms that support inline mode.
  - A physical interface cannot be a member of an inline interface pair unless the subinterface mode of the physical interface is **none**.
  - You can configure the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) to operate inline even though they have only one sensing interface.
- Inline VLAN Pairs
  - You cannot pair a VLAN with itself.
  - You cannot use the default VLAN as one of the paired VLANs in an inline VLAN pair.
  - For a given sensing interface, a VLAN can be a member of only one inline VLAN pair. However, a given VLAN can be a member of an inline VLAN pair on more than one sensing interface.
  - The order in which you specify the VLANs in an inline VLAN pair is not significant.
  - A sensing interface in Inline VLAN Pair mode can have from 1 to 255 inline VLAN pairs.

- The ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) do not support inline VLAN pairs.
  - For the IPS 4510 and IPS 4520, the maximum number of inline VLAN pairs you can create system wide is 150. On all other platforms, the limit is 255 per interface.
- Alternate TCP Reset Interface
  - You can only assign the alternate TCP reset interface to a sensing interface. You cannot configure the command and control interface as an alternate TCP reset interface. The alternate TCP reset interface option is set to **none** as the default and is protected for all interfaces except the sensing interfaces.
  - You can assign the same physical interface as an alternate TCP reset interface for multiple sensing interfaces.
  - A physical interface can serve as both a sensing interface and an alternate TCP reset interface.
  - The command and control interface cannot serve as the alternate TCP reset interface for a sensing interface.
  - A sensing interface cannot serve as its own alternate TCP reset interface.
  - You can only configure interfaces that are capable of TCP resets as alternate TCP reset interfaces.
  - There is only one sensing interface on the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP), so you cannot designate an alternate TCP reset interface.
- VLAN Groups
  - You can configure any single interface for promiscuous, inline interface pair, or inline VLAN pair mode, but no combination of these modes is allowed.
  - You cannot add a VLAN to more than one group on each interface.
  - You cannot add a VLAN group to multiple virtual sensors.
  - An interface can have no more than 255 user-defined VLAN groups.
  - When you pair a physical interface, you cannot subdivide it; you can subdivide the pair.
  - You can use a VLAN on multiple interfaces; however, you receive a warning for this configuration.
  - You can assign a virtual sensor to any combination of one or more physical interfaces and inline VLAN pairs, subdivided or not.
  - You can subdivide both physical and logical interfaces into VLAN groups.
  - The CLI, IDM, and IME prompt you to remove any dangling references. You can leave the dangling references and continue editing the configuration.
  - The CLI, IDM, and IME do not allow configuration changes in Analysis Engine that conflict with the interface configuration.
  - The CLI allows configuration changes in the interface configuration that cause conflicts in the Analysis Engine configuration. The IDM and IME do *not* allow changes in the interface configuration that cause conflicts in the Analysis Engine configuration.
  - The ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) do not support VLAN groups mode.



**For More Information**

- For a list of supported sensor interfaces, see [Interface Support, page 5-7](#).
- For more information on alternate TCP reset, see [TCP Reset Interfaces, page 5-5](#).
- For more information on physical interfaces, see [Configuring Physical Interfaces, page 5-15](#).

## Interface Configuration Sequence

Follow these steps to configure interfaces on the sensor:

1. Configure the physical interface settings (speed, duplex, and so forth) and enable the interfaces.
2. Create or delete inline interfaces, inline VLAN subinterfaces, and VLAN groups, and set the inline bypass mode.
3. Assign the physical, subinterfaces, and inline interfaces to the virtual sensor.

**For More Information**

- For the procedure for configuring the physical interface settings, see [Configuring Physical Interfaces, page 5-15](#).
- For the procedures for creating and deleting different kinds of interfaces, see [Configuring Inline Interface Mode, page 5-20](#), [Configuring Inline VLAN Pair Mode, page 5-25](#), [Configuring VLAN Group Mode, page 5-31](#), and [Configuring Inline Bypass Mode, page 5-38](#).
- For the procedure for configuring virtual sensors, see [Adding, Editing, and Deleting Virtual Sensors, page 6-5](#).

## Configuring Physical Interfaces

**Note**

For information on what you need to configure if you are using the hardware bypass card on the IPS 4260 and the IPS 4270-20, see [Hardware Bypass Configuration Restrictions, page 5-12](#).

Use the **physical-interfaces** *interface\_name* command in the service interface submode to configure promiscuous interfaces. The interface name is FastEthernet, GigabitEthernet, or PortChannel.

**Note**

You configure the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) for promiscuous mode from the adaptive security appliance CLI and not from the Cisco IPS CLI.

The following options apply:

- **admin-state {enabled | disabled}**—Specifies the administrative link state of the interface, whether the interface is enabled or disabled.

**Note**

On all backplane sensing interfaces on all modules, **admin-state** is set to enabled and is protected (you cannot change the setting). The **admin-state** has no effect (and is protected) on the command and control interface. It only affects sensing interfaces. The command and control interface does not need to be enabled because it cannot be monitored.

- **alt-tcp-reset-interface**—Sends TCP resets out an alternate interface when this interface is used for promiscuous monitoring and the reset action is triggered by a signature firing.



**Note** You can only assign a sensing interface as an alternate TCP reset interface. You cannot configure the management interface as an alternate TCP reset interface.



**Note** There is only one sensing interface on the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP), so you cannot designate an alternate TCP reset interface.

- *interface\_name*—Specifies the name of the interface on which TCP resets should be sent when this interface is used for promiscuous monitoring and the reset action is triggered by a signature firing. This setting is ignored when this interface is a member of an inline interface.
- **none** —Disables the use of an alternate TCP reset interface. TCP resets triggered by the reset action when in promiscuous mode will be sent out of this interface instead.
- **default**—Sets the value back to the system default setting.
- **description**—Specifies your description of the promiscuous interface.
- **duplex**—Specifies the duplex setting of the interface:
  - **auto**—Sets the interface to auto negotiate duplex.
  - **full**—Sets the interface to full duplex.
  - **half**—Sets the interface to half duplex.



**Note** The **duplex** option is protected on all modules.



**Note** For TenGigabit SFP+ ports, the permitted values are auto and full.

- **no**—Removes an entry or selection setting.
- **speed**—Specifies the speed setting of the interface:
  - **auto**—Sets the interface to auto negotiate speed.
  - **10**—Sets the interface to 10 MB (for TX interfaces only).
  - **100**—Sets the interface to 100 MB (for TX interfaces only).
  - **1000**—Sets the interface to 1 GB (for Gigabit interfaces only).



**Note** The **speed** option is protected on all modules.



**Note** For TenGigabit SFP+ ports with a 10 Gb connector, the permitted values are auto and 10000, and for TenGigabit SFP+ ports with a 1 Gb connector, the permitted value is auto.

### Configuring the Physical Interface Settings

To configure the physical interface settings for promiscuous mode on the sensor, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter interface submenu.
- ```
sensor# configure terminal
sensor(config)# service interface
```
- Step 3** Display the list of available interfaces.
- ```
sensor(config-int)# physical-interfaces ?
GigabitEthernet0/0 GigabitEthernet0/0 physical interface.
GigabitEthernet0/1 GigabitEthernet0/1 physical interface.
GigabitEthernet0/2 GigabitEthernet0/2 physical interface.
GigabitEthernet0/3 GigabitEthernet0/3 physical interface.
Management0/0 Management0/0 physical interface.
sensor(config-int)# physical-interfaces
```
- Step 4** Specify the interface for promiscuous mode.
- ```
sensor(config-int)# physical-interfaces GigabitEthernet0/2
```
- Step 5** Enable the interface. You must assign the interface to a virtual sensor and enable it before it can monitor traffic.
- ```
sensor(config-int-phy)# admin-state enabled
```
- Step 6** Add a description of this interface.
- ```
sensor(config-int-phy)# description INT1
```
- Step 7** Specify the duplex settings. This option is not available on the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, ASA 5585-X IPS SSP).
- ```
sensor(config-int-phy)# duplex full
```
- Step 8** Specify the speed. This option is not available on the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, ASA 5585-X IPS SSP).
- ```
sensor(config-int-phy)# speed 1000
```
- Step 9** Enable TCP resets for this interface if desired. This option is not available on the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, ASA 5585-X IPS SSP).
- ```
sensor(config-int-phy)# alt-tcp-reset-interface interface-name GigabitEthernet2/0
```
- Step 10** Repeat Steps 4 through 9 for any other interfaces you want to designate as promiscuous interfaces.
- Step 11** Verify the settings.



**Note** Make sure the `subinterface-type` is `none`, the default. You use the `subinterface-type` command to configure inline VLAN pairs.

```
sensor(config-int-phy)# show settings
<protected entry>
name: GigabitEthernet0/2

media-type: tx <protected>
description: INT1 default:
admin-state: enabled default: disabled
```

```

duplex: full default: auto
speed: 1000 default: auto
alt-tcp-reset-interface

interface-name: GigabitEthernet2/0

subinterface-type

none

sensor(config-int-phy) #

```

**Step 12** Remove TCP resets from an interface.

```
sensor(config-int-phy) # alt-tcp-reset-interface none
```

**Step 13** Verify the settings.

```

sensor(config-int-phy) # show settings
<protected entry>
name: GigabitEthernet0/0

media-type: tx <protected>
description: <defaulted>
admin-state: disabled <protected>
duplex: auto <defaulted>
speed: auto <defaulted>
alt-tcp-reset-interface

none

sensor(config-int-phy) #

```

**Step 14** Exit interface submenu.

```

sensor(config-int-phy) # exit
sensor(config-int) # exit
Apply Changes?[yes]:

```

**Step 15** Press **Enter** to apply the changes or enter **no** to discard them.

---

#### For More Information

- For a list of possible interfaces for your sensor, see [Interface Support](#), page 5-7.
- For the procedure for sending traffic to the ASA 5500 AIP SSM, see [Sending Traffic to the ASA 5500 AIP SSM](#), page 18-10.
- For the procedure for sending traffic to the ASA 5500-X IPS SSP, see [Creating Virtual Sensors for the ASA 5500-X IPS SSP](#), page 19-3.
- For the procedure for sending traffic to the ASA 5585-X IPS SSP, see [Creating Virtual Sensors for the ASA 5585-X IPS SSP](#), page 20-4.
- For more information on the alternate TCP reset interface, see [Understanding Alternate TCP Reset Interfaces](#), page 5-5 and [Designating the Alternate TCP Reset Interface](#), page 5-6.

- For the procedure for configuring inline VLAN pairs, see [Configuring Inline VLAN Pair Mode, page 5-25](#).
- For the procedure for adding interfaces to virtual sensors, see [Adding, Editing, and Deleting Virtual Sensors, page 6-5](#).

## Configuring Promiscuous Mode

This section describes promiscuous mode on the sensor, and contains the following topics:


- [Understanding Promiscuous Mode, page 5-19](#)
- [Configuring Promiscuous Mode, page 5-20](#)
- [IPv6, Switches, and Lack of VACL Capture, page 5-20](#)

## Understanding Promiscuous Mode

In promiscuous mode, packets do not flow through the sensor. The sensor analyzes a copy of the monitored traffic rather than the actual forwarded packet. The advantage of operating in promiscuous mode is that the sensor does not affect the packet flow with the forwarded traffic. The disadvantage of operating in promiscuous mode, however, is the sensor cannot stop malicious traffic from reaching its intended target for certain types of attacks, such as atomic attacks (single-packet attacks). The response actions implemented by promiscuous sensor devices are post-event responses and often require assistance from other networking devices, for example, routers and firewalls, to respond to an attack. While such response actions can prevent some classes of attacks, in atomic attacks the single packet has the chance of reaching the target system before the promiscuous-based sensor can apply an ACL modification on a managed device (such as a firewall, switch, or router).

By default, all sensing interfaces are in promiscuous mode. To change an interface from inline interface mode to promiscuous mode, delete any inline interface that contains that interface and delete any inline VLAN pair subinterfaces of that interface from the interface configuration.

[Figure 5-1](#) illustrates promiscuous mode:



## Configuring Promiscuous Mode

By default, all sensing interfaces are in promiscuous mode. To change an interface from inline mode to promiscuous mode, delete the inline interface that contains that interface from the interface configuration.

## IPv6, Switches, and Lack of VACL Capture

VACLs on Catalyst switches do not have IPv6 support. The most common method for copying traffic to a sensor configured in promiscuous mode is to use VACL capture. If you want to have IPv6 support, you can use SPAN ports.

However, you can only configure up to two monitor sessions on a switch unless you use the following configuration:

- Monitor session
- Multiple trunks to one or more sensors
- Restrict per trunk port which VLANs are allowed to perform monitoring of many VLANs to more than two different sensors or virtual sensors within one IPS

The following configuration uses one SPAN session to send all of the traffic on any of the specified VLANs to all of the specified ports. Each port configuration only allows a particular VLAN or VLANs to pass. Thus you can send data from different VLANs to different sensors or virtual sensors all with one SPAN configuration line:

```
clear trunk 4/1-4 1-4094
set trunk 4/1 on dot1q 930
set trunk 4/2 on dot1q 932
set trunk 4/3 on dot1q 960
set trunk 4/4 on dot1q 962
set span 930, 932, 960, 962 4/1-4 both
```

**Note**

The SPAN/Monitor configuration is valuable when you want to assign different IPS policies per VLAN or when you have more bandwidth to monitor than one interface can handle.

## Configuring Inline Interface Mode

This section describes inline mode on the sensor, and contains the following topics:

- [Understanding Inline Interface Mode, page 5-20](#)
- [Configuring Inline Interface Pairs, page 5-21](#)

## Understanding Inline Interface Mode

Operating in inline interface pair mode puts the IPS directly into the traffic flow and affects packet-forwarding rates making them slower by adding latency. This allows the sensor to stop attacks by dropping malicious traffic before it reaches the intended target, thus providing a protective service. Not only is the inline device processing information on Layers 3 and 4, but it is also analyzing the contents

and payload of the packets for more sophisticated embedded attacks (Layers 3 to 7). This deeper analysis lets the system identify and stop and/or block attacks that would normally pass through a traditional firewall device.

In inline interface pair mode, a packet comes in through the first interface of the pair on the sensor and out the second interface of the pair. The packet is sent to the second interface of the pair unless that packet is being denied or modified by a signature.

**Note**


You can configure the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) to operate inline even though they have only one sensing interface.

**Note**

If the paired interfaces are connected to the same switch, you should configure them on the switch as access ports with different access VLANs for the two ports. Otherwise, traffic does not flow through the inline interface.

Figure 5-2 illustrates inline interface pair mode:

**Figure 5-2 Inline Interface Pair Mode**



## Configuring Inline Interface Pairs

**Note**

For information on what you need to configure if you are using the hardware bypass card on the IPS 4260 and the IPS 4270-20, see [Hardware Bypass Configuration Restrictions, page 5-12](#).

Use the **inline-interfaces** *name* command in the service interface submode to create inline interface pairs.

**Note**

You can configure the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) to operate inline even though they have only one sensing interface.

The following options apply:

- **inline-interfaces** *name*—Specifies the name of the logical inline interface pair.
- **default**—Sets the value back to the system default setting.
- **description**—Specifies your description of the inline interface pair.
- **interface1** *interface\_name*—Specifies the first interface in the inline interface pair.
- **interface2** *interface\_name*—Specifies the second interface in the inline interface pair.

- **no**—Removes an entry or selection setting.
- **admin-state {enabled | disabled}**—Specifies the administrative link state of the interface, whether the interface is enabled or disabled.

**Note**

On all backplane sensing interfaces on all modules, **admin-state** is set to enabled and is protected (you cannot change the setting). The **admin-state** has no effect (and is protected) on the command and control interface. It only affects sensing interfaces. The command and control interface does not need to be enabled because it cannot be monitored.

### Creating Inline Interface Pairs

To create inline interface pairs, follow these steps:

**Step 1** Log in to the CLI using an account with administrator privileges.

**Step 2** Enter interface submode.

```
sensor# configure terminal
sensor(config)# service interface
sensor(config-int)#
```

**Step 3** Verify that the subinterface mode is “none” for both of the physical interfaces you are pairing in the inline interface.

```
sensor(config-int)# show settings
physical-interfaces (min: 0, max: 999999999, current: 2)

<protected entry>
name: GigabitEthernet0/0 <defaulted>

media-type: tx <protected>
description: <defaulted>
admin-state: disabled <protected>
duplex: auto <defaulted>
speed: auto <defaulted>
alt-tcp-reset-interface

none

subinterface-type

none


```

**Step 4** Name the inline pair.

```
sensor(config-int)# inline-interfaces PAIR1
```

**Step 5** Display the available interfaces.

```
sensor(config-int)# interface1 ?
GigabitEthernet0/0 GigabitEthernet0/0 physical interface.
GigabitEthernet0/1 GigabitEthernet0/1 physical interface.
GigabitEthernet0/2 GigabitEthernet0/2 physical interface.
GigabitEthernet0/3 GigabitEthernet0/3 physical interface.
Management0/0 Management0/0 physical interface.
```



- Step 6** Configure two interfaces into a pair. You must assign the interface to a virtual sensor and enable it before it can monitor traffic (see Step 10).

```
sensor(config-int-inl)# interface1 GigabitEthernet0/0
sensor(config-int-inl)# interface2 GigabitEthernet0/1
```

- Step 7** Add a description of the interface pair.

```
sensor(config-int-inl)# description PAIR1 Gig0/0 and Gig0/1
```

- Step 8** Repeat Steps 4 through 7 for any other interfaces that you want to configure into inline interface pairs.

- Step 9** Verify the settings.

```
sensor(config-int-inl)# show settings
name: PAIR1

description: PAIR1 Gig0/0 & Gig0/1 default:
interface1: GigabitEthernet0/0
interface2: GigabitEthernet0/1

```

- Step 10** Enable the interfaces assigned to the interface pair.

```
sensor(config-int)# exit
sensor(config-int)# physical-interfaces GigabitEthernet0/0
sensor(config-int-phy)# admin-state enabled
sensor(config-int-phy)# exit
sensor(config-int)# physical-interfaces GigabitEthernet0/1
sensor(config-int-phy)# admin-state enabled
sensor(config-int-phy)# exit
sensor(config-int)#
```

- Step 11** Verify that the interfaces are enabled.

```
sensor(config-int)# show settings
physical-interfaces (min: 0, max: 999999999, current: 5)

<protected entry>
name: GigabitEthernet0/0

media-type: tx <protected>
description: <defaulted>
admin-state: enabled default: disabled
duplex: auto <defaulted>
speed: auto <defaulted>
default-vlan: 0 <defaulted>
alt-tcp-reset-interface

none

subinterface-type

none

<protected entry>
name: GigabitEthernet0/1

media-type: tx <protected>
```

```

description: <defaulted>
admin-state: enabled default: disabled
duplex: auto <defaulted>
speed: auto <defaulted>
default-vlan: 0 <defaulted>
alt-tcp-reset-interface

none

subinterface-type

none

<protected entry>
name: GigabitEthernet0/2 <defaulted>

media-type: tx <protected>
description: <defaulted>
admin-state: disabled <defaulted>
duplex: auto <defaulted>
speed: auto <defaulted>
default-vlan: 0 <defaulted>
alt-tcp-reset-interface

none

subinterface-type

none

<protected entry>
name: GigabitEthernet0/3 <defaulted>

media-type: tx <protected>
--MORE--

```

- Step 12** Delete an inline interface pair and return the interfaces to promiscuous mode. You must also delete the inline interface pair from the virtual sensor to which it is assigned.

```
sensor(config-int)# no inline-interfaces PAIR1
```

- Step 13** Verify the inline interface pair has been deleted.

```

sensor(config-int)# show settings

command-control: Management0/0 <protected>
inline-interfaces (min: 0, max: 999999999, current: 0)

bypass-mode: auto <defaulted>
interface-notifications

```

**Step 14** Exit interface configuration submode.

```
sensor(config-int)# exit
Apply Changes:[yes]:
```

**Step 15** Press **Enter** to apply the changes or enter **no** to discard them.

---

#### For More Information

- For the procedure for configuring inline interface mode for the ASA 5500 AIP SSM, see [Sending Traffic to the ASA 5500 AIP SSM, page 18-10](#).
- For the procedure for configuring inline interface mode for the ASA 5500-X IPS SSP, see [Assigning Virtual Sensors to Adaptive Security Appliance Contexts, page 19-6](#).
- For the procedure for configuring inline interface mode for the ASA 5585-X IPS SSP, see [Assigning Virtual Sensors to Adaptive Security Appliance Contexts, page 20-7](#).
- For the procedure for assigning inline interface pairs to a virtual sensor, or deleting the inline interface pair from the virtual sensor to which it is assigned, see [Adding, Editing, and Deleting Virtual Sensors, page 6-5](#).

## Configuring Inline VLAN Pair Mode

This section describes inline VLAN pair mode and how to configure inline VLAN pairs. It contains the following topics:

- [Understanding Inline VLAN Pair Mode, page 5-25](#)
- [Configuring Inline VLAN Pairs, page 5-26](#)

## Understanding Inline VLAN Pair Mode



#### Note

For information on what you need to configure if you are using the hardware bypass card on the IPS 4260 and the IPS 4270-20, see [Hardware Bypass Configuration Restrictions, page 5-12](#).



#### Note

The ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) do not support inline VLAN pairs.



#### Note

For the IPS 4510 and IPS 4520, the maximum number of inline VLAN pairs you can create system wide is 150. On all other platforms, the limit is 255 per interface.

You can associate VLANs in pairs on a physical interface. This is known as inline VLAN pair mode. Packets received on one of the paired VLANs are analyzed and then forwarded to the other VLAN in the pair.


Inline VLAN pair mode is an active sensing mode where a sensing interface acts as an 802.1q trunk port, and the sensor performs VLAN bridging between pairs of VLANs on the trunk. The sensor inspects the traffic it receives on each VLAN in each pair, and can either forward the packets on the other VLAN in the pair, or drop the packet if an intrusion attempt is detected. You can configure an IPS sensor to simultaneously bridge up to 255 VLAN pairs on each sensing interface. The sensor replaces the VLAN ID field in the 802.1q header of each received packet with the ID of the egress VLAN on which the sensor forwards the packet. The sensor drops all packets received on any VLANs that are not assigned to inline VLAN pairs.

**Note**

You cannot use the default VLAN as one of the paired VLANs in an inline VLAN pair.

Figure 5-3 illustrates inline VLAN pair mode:

**Figure 5-3**      **Inline VLAN Pair Mode**



## Configuring Inline VLAN Pairs

Use the **physical-interfaces** *interface\_name* command in the service interface submode to configure inline VLAN pairs. The interface name is FastEthernet or GigabitEthernet.

The following options apply:

- **admin-state {enabled | disabled}**—Specifies the administrative link state of the interface, whether the interface is enabled or disabled.

**Note**

On all backplane sensing interfaces on all modules, **admin-state** is set to enabled and is protected (you cannot change the setting). The **admin-state** has no effect (and is protected) on the command and control interface. It only affects sensing interfaces. The command and control interface does not need to be enabled because it cannot be monitored.

- **default**—Sets the value back to the system default setting.
- **description**—Specifies the description of the interface.
- **duplex**—Specifies the duplex setting of the interface:
  - **auto**—Sets the interface to auto negotiate duplex.
  - **full**—Sets the interface to full duplex.

- **half**—Sets the interface to half duplex.



**Note** The **duplex** option is protected on all modules.

- **no**—Removes an entry or selection setting.
- **speed**—Specifies the speed setting of the interface:
  - **auto**—Sets the interface to auto negotiate speed.
  - **10**—Sets the interface to 10 MB (for TX interfaces only).
  - **100**—Sets the interface to 100 MB (for TX interfaces only).
  - **1000**—Sets the interface to 1 GB (for Gigabit interfaces only).



**Note** The **speed** option is protected on all modules.

- **subinterface-type**—Specifies that the interface is a subinterface and what type of subinterface is defined.
  - **inline-vlan-pair**—Lets you define the subinterface as an inline VLAN pair.
  - **none**—No subinterfaces defined.
- **subinterface** *name*—Defines the subinterface as an inline VLAN pair:
  - **vlan1**—Specifies the first VLAN in the inline VLAN pair.
  - **vlan2**—Specifies the second VLAN in the inline VLAN pair.

### Configuring Inline VLAN Pairs

To configure the inline VLAN pair settings on the sensor, follow these steps:

- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter interface submode.
- ```
sensor# configure terminal
sensor(config)# service interface
sensor(config-int)#
```
- Step 3** Verify if any inline interfaces exist (the subinterface type should read “none” if no inline interfaces have been configured).

```
sensor(config-int)# show settings
physical-interfaces (min: 0, max: 999999999, current: 5)
-----
<protected entry>
name: GigabitEthernet0/0 <defaulted>
-----
media-type: tx <protected>
description: <defaulted>
admin-state: disabled <defaulted>
duplex: auto <defaulted>
speed: auto <defaulted>
alt-tcp-reset-interface
-----
none
-----
-----
```

```

-----
subinterface-type
-----
    none
-----
-----

<protected entry>
name: GigabitEthernet0/1 <defaulted>
-----

media-type: tx <protected>
description: <defaulted>
admin-state: disabled <defaulted>
duplex: auto <defaulted>
speed: auto <defaulted>
alt-tcp-reset-interface
-----
    none
-----
-----

subinterface-type
-----
    none
-----
-----

<protected entry>
name: GigabitEthernet0/2 <defaulted>
-----

media-type: tx <protected>
description: <defaulted>
admin-state: disabled <defaulted>
duplex: auto <defaulted>
speed: auto <defaulted>
alt-tcp-reset-interface
-----
    none
-----
-----

subinterface-type
-----
    none
-----
-----

<protected entry>
name: GigabitEthernet0/3 <defaulted>
-----

media-type: tx <protected>
description: <defaulted>
admin-state: disabled <defaulted>
duplex: auto <defaulted>
speed: auto <defaulted>
alt-tcp-reset-interface
-----
    none
-----
-----

```

```

subinterface-type
-----
none
-----
-----
-----
<protected entry>
name: Management0/0 <defaulted>
-----
media-type: tx <protected>
description: <defaulted>
admin-state: disabled <protected>
duplex: auto <defaulted>
speed: auto <defaulted>
alt-tcp-reset-interface
-----
none
-----
-----
subinterface-type
-----
none
-----
-----
-----
command-control: Management0/0 <protected>
inline-interfaces (min: 0, max: 999999999, current: 0)
-----
-----
bypass-mode: auto <defaulted>
interface-notifications
-----
missed-percentage-threshold: 0 percent <defaulted>
notification-interval: 30 seconds <defaulted>
idle-interface-delay: 30 seconds <defaulted>
-----
sensor(config-int)#

```

- Step 4** If there are inline interfaces that are using this physical interface, remove them. You must also delete the inline interface from the virtual sensor to which it is assigned.

```
sensor(config-int)# no inline-interfaces interface_name
```

- Step 5** Display the list of available interfaces.

```

sensor(config-int)# physical-interfaces ?
GigabitEthernet0/0    GigabitEthernet0/0 physical interface.
GigabitEthernet0/1    GigabitEthernet0/1 physical interface.
GigabitEthernet0/2    GigabitEthernet0/2 physical interface.
GigabitEthernet0/3    GigabitEthernet0/3 physical interface.
Management0/0         Management0/0 physical interface.
sensor(config-int)# physical-interfaces

```

- Step 6** Designate an interface.

```
sensor(config-int)# physical-interfaces GigabitEthernet0/2
```

- Step 7** Enable the interface. You must assign the interface to a virtual sensor and enable it before it can monitor traffic.

```
sensor(config-int-phy) # admin-state enabled
```

- Step 8** Add a description of this interface.

```
sensor(config-int-phy) # description INT1
```

- Step 9** Configure the duplex settings. This option is not available on the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP).

```
sensor(config-int-phy) # duplex full
```

- Step 10** Configure the speed. This option is not available on the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP).

```
sensor(config-int-phy) # speed 1000
```

- Step 11** Set up the inline VLAN pair.

```
sensor(config-int-phy) # subinterface-type inline-vlan-pair
sensor(config-int-phy-inl) # subinterface 1
sensor(config-int-phy-inl-sub) # vlan1 52
sensor(config-int-phy-inl-sub) # vlan2 53
```

- Step 12** Add a description for the inline VLAN pair.

```
sensor(config-int-phy-inl-sub) # description INT1 vlans 52 and 53
```

- Step 13** Verify the inline VLAN pair settings.

```
sensor(config-int-phy-inl-sub) # show settings
subinterface-number: 1
-----
description: INT1 vlans 52 and 53 default:
vlan1: 52
vlan2: 53
-----
sensor(config-int-phy-inl-sub) #
```

- Step 14** To delete VLAN pairs:

- a. Delete one VLAN pair.

```
sensor(config-int-phy-inl-sub) # exit
sensor(config-int-phy-inl) # no subinterface 1
```

If this VLAN pair is the last one on the sensor, you receive the following error message:

```
Error: This "subinterface-type" contains less than the required number of
"subinterface" entries. Please add entry(s) to reach the minimum required entries or
select a different "subinterface-type".
```

Go to Step b to remove the last VLAN pair.

- b. Delete all VLAN pairs.

```
sensor(config-int-phy-inl-sub) # exit
sensor(config-int-phy-inl) # exit
sensor(config-int-phy) # subinterface-type none
```

- Step 15** Exit interface submenu. You must also delete the interface from the virtual sensor to which it is assigned.

```
sensor(config-int-phy-inl-sub) # exit
sensor(config-int-phy-inl) # exit
sensor(config-int-phy) # exit
```



```
sensor(config-int)# exit  
Apply Changes:[yes]:
```

Step 16 Press **Enter** to apply the changes or enter **no** to discard them.

For More Information

For the procedure for assigning inline interface pairs to a virtual sensor, or deleting the inline interface pair from the virtual sensor to which it is assigned, see [Adding, Editing, and Deleting Virtual Sensors](#), page 6-5.

Configuring VLAN Group Mode

This section describes VLAN Group mode and how to configure VLAN groups. It contains the following topics:

- [Understanding VLAN Group Mode](#), page 5-31
- [Deploying VLAN Groups](#), page 5-32
- [Configuring VLAN Groups](#), page 5-32

Understanding VLAN Group Mode



Note

The ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) do not support VLAN groups mode.

You can divide each physical interface or inline interface into VLAN group subinterfaces, each of which consists of a group of VLANs on that interface. Analysis Engine supports multiple virtual sensors, each of which can monitor one or more of these interfaces. This lets you apply multiple policies to the same sensor. The advantage is that now you can use a sensor with only a few interfaces as if it had many interfaces.



Note

You cannot divide physical interfaces that are in inline VLAN pairs into VLAN groups.

VLAN group subinterfaces associate a set of VLANs with a physical or inline interface. No VLAN can be a member of more than one VLAN group subinterface. Each VLAN group subinterface is identified by a number between 1 and 255. Subinterface 0 is a reserved subinterface number used to represent the entire unvirtualized physical or logical interface. You cannot create, delete, or modify subinterface 0 and no statistics are reported for it.

An unassigned VLAN group is maintained that contains all VLANs that are not specifically assigned to another VLAN group. You cannot directly specify the VLANs that are in the unassigned group. When a VLAN is added to or deleted from another VLAN group subinterface, the unassigned group is updated.

Packets in the native VLAN of an 802.1q trunk do not normally have 802.1q encapsulation headers to identify the VLAN number to which the packets belong. A default VLAN variable is associated with each physical interface and you should set this variable to the VLAN number of the native VLAN or to 0. The value 0 indicates that the native VLAN is either unknown or you do not care if it is specified. If the default VLAN setting is 0, the following occurs:

- Any alerts triggered by packets without 802.1q encapsulation have a VLAN value of 0 reported in the alert.
- Non-802.1q encapsulated traffic is associated with the unassigned VLAN group and it is not possible to assign the native VLAN to any other VLAN group.

**Note**

You can configure a port on a switch as either an access port or a trunk port. On an access port, all traffic in a single VLAN is called the access VLAN. On a trunk port, multiple VLANs can be carried over the port, and each packet has a special header attached called the 802.1q header that contains the VLAN ID. This header is commonly referred to as the VLAN tag. However, a trunk port has a special VLAN called the native VLAN. Packets in the native VLAN do not have the 802.1q headers attached.

Deploying VLAN Groups

Because a VLAN group of an inline pair does not translate the VLAN ID, an inline paired interface must exist between two switches to use VLAN groups on a logical interface. For an appliance, you can connect the two pairs to the same switch, make them access ports, and then set the access VLANs for the two ports differently. In this configuration, the sensor connects between two VLANs, because each of the two ports is in access mode and carries only one VLAN. In this case the two ports must be in different VLANs, and the sensor bridges the two VLANs, monitoring any traffic that flows between the two VLANs.

You can also connect appliances between two switches. There are two variations. In the first variation, the two ports are configured as access ports, so they carry a single VLAN. In this way, the sensor bridges a single VLAN between the two switches.

In the second variation, the two ports are configured as trunk ports, so they can carry multiple VLANs. In this configuration, the sensor bridges multiple VLANs between the two switches. Because multiple VLANs are carried over the inline interface pair, the VLANs can be divided into groups and each group can be assigned to a virtual sensor.

Configuring VLAN Groups

**Note**

For information on what you need to configure if you are using the hardware bypass card on the IPS 4260 and the IPS 4270-20, see [Hardware Bypass Configuration Restrictions](#), page 5-12.

Use the **physical-interfaces** *interface_name* command in the service interface submode to configure inline VLAN groups. The interface name is FastEthernet or GigabitEthernet.

The following options apply:

- **admin-state {enabled | disabled}**—Specifies the administrative link state of the interface, whether the interface is enabled or disabled.



Note

On all backplane sensing interfaces on all modules, **admin-state** is set to enabled and is protected (you cannot change the setting). The **admin-state** has no effect (and is protected) on the command and control interface. It only affects sensing interfaces. The command and control interface does not need to be enabled because it cannot be monitored.

- **default**—Sets the value back to the system default setting.
- **description**—Specifies the description of the interface.
- **duplex**—Specifies the duplex setting of the interface:
 - **auto**—Sets the interface to auto negotiate duplex.
 - **full**—Sets the interface to full duplex.
 - **half**—Sets the interface to half duplex.



Note

The **duplex** option is protected on all modules.

- **no**—Removes an entry or selection setting.
- **speed**—Specifies the speed setting of the interface:
 - **auto**—Sets the interface to auto negotiate speed.
 - **10**—Sets the interface to 10 MB (for TX interfaces only).
 - **100**—Sets the interface to 100 MB (for TX interfaces only).
 - **1000**—Sets the interface to 1 GB (for Gigabit interfaces only).



Note

The **speed** option is protected on all modules.

- **subinterface-type**—Specifies that the interface is a subinterface and what type of subinterface is defined.
 - **vlan-group**—Lets you define the subinterface as a VLAN group.
 - **none**—Specifies that no subinterfaces are defined.
- **subinterface name**—Defines the subinterface as a VLAN group:
 - **vlan {range | unassigned}**—Specifies the set of VLANs in the VLAN group. The value for **range** is 1 to 4095 in a comma-separated pattern of individual VLAN IDs or ranges: 1,5-8,10-15. There are no spaces between the entries.

Configuring Inline VLAN Groups

To configure the inline VLAN group settings on the sensor, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter interface submode.

```
sensor# configure terminal
```

```
sensor(config)# service interface
sensor(config-int)#
```

Step 3 Verify if any inline interfaces exist (the subinterface type should read “none” if no inline interfaces have been configured).

```
sensor(config-int)# show settings
  physical-interfaces (min: 0, max: 999999999, current: 5)
  -----
  <protected entry>
  name: GigabitEthernet0/0 <defaulted>
  -----
    media-type: tx <protected>
    description: <defaulted>
    admin-state: disabled <defaulted>
    duplex: auto <defaulted>
    speed: auto <defaulted>
    alt-tcp-reset-interface
    -----
      none
      -----
    -----
    subinterface-type
    -----
      none
      -----
    -----
  -----
  <protected entry>
  name: GigabitEthernet0/1 <defaulted>
  -----
    media-type: tx <protected>
    description: <defaulted>
    admin-state: disabled <defaulted>
    duplex: auto <defaulted>
    speed: auto <defaulted>
    alt-tcp-reset-interface
    -----
      none
      -----
    -----
    subinterface-type
    -----
      none
      -----
    -----
  -----
  <protected entry>
  name: GigabitEthernet0/2 <defaulted>
  -----
    media-type: tx <protected>
    description: <defaulted>
    admin-state: disabled <defaulted>
    duplex: auto <defaulted>
    speed: auto <defaulted>
    alt-tcp-reset-interface
    -----
      none
      -----
    -----
```

```

-----
subinterface-type
-----
    none
-----
-----

<protected entry>
name: GigabitEthernet0/3 <defaulted>
-----
    media-type: tx <protected>
    description: <defaulted>
    admin-state: disabled <defaulted>
    duplex: auto <defaulted>
    speed: auto <defaulted>
    alt-tcp-reset-interface
    -----
        none
    -----
    -----
subinterface-type
-----
    none
-----
-----

<protected entry>
name: Management0/0 <defaulted>
-----
    media-type: tx <protected>
    description: <defaulted>
    admin-state: disabled <protected>
    duplex: auto <defaulted>
    speed: auto <defaulted>
    alt-tcp-reset-interface
    -----
        none
    -----
    -----
subinterface-type
-----
    none
-----
-----

command-control: Management0/0 <protected>
inline-interfaces (min: 0, max: 999999999, current: 0)
-----
bypass-mode: auto <defaulted>
interface-notifications
-----
    missed-percentage-threshold: 0 percent <defaulted>
    notification-interval: 30 seconds <defaulted>
    idle-interface-delay: 30 seconds <defaulted>
-----
sensor(config-int)#

```

- Step 4** If there are inline interfaces that are using this physical interface, remove them.

```
sensor(config-int)# no inline-interfaces interface_name
```

- Step 5** Display the list of available interfaces.

```
sensor(config-int)# physical-interfaces ?
GigabitEthernet0/0    GigabitEthernet0/0 physical interface.
GigabitEthernet0/1    GigabitEthernet0/1 physical interface.
GigabitEthernet0/2    GigabitEthernet0/2 physical interface.
GigabitEthernet0/3    GigabitEthernet0/3 physical interface.
Management0/0        Management0/0 physical interface.
sensor(config-int)# physical-interfaces
```

- Step 6** Specify an interface.

```
sensor(config-int)# physical-interfaces GigabitEthernet0/2
```

- Step 7** Enable the interface. You must also assign the interface to a virtual sensor and enable it before it can monitor traffic.

```
sensor(config-int-phy)# admin-state enabled
```

- Step 8** Add a description of this interface.

```
sensor(config-int-phy)# description INT1
```

- Step 9** Specify the duplex settings. This option is not available on the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, ASA 5585-X IPS SSP).

```
sensor(config-int-phy)# duplex full
```

- Step 10** Specify the speed. This option is not available on the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, ASA 5585-X IPS SSP).

```
sensor(config-int-phy)# speed 1000
```

- Step 11** Set up the VLAN group.

```
sensor(config-int-phy)# subinterface-type vlan-group
sensor(config-int-phy-vla)# subinterface 1
```

- Step 12** Assign the VLANs to this group:

- a. Assign specific VLANs.

```
sensor(config-int-phy-vla-sub)# vlans range 1,5-8,10-15
sensor(config-int-phy-vla-sub)#
```

- b. Verify the settings.

```
sensor(config-int-phy-vla-sub)# show settings
subinterface-number: 1
-----
description: <defaulted>
vlans
-----
range: 1,5-8,10-15
-----
sensor(config-int-phy-vla-sub)#
```

- c. Configure unassigned VLANs.

```
sensor(config-int-phy-vla-sub)# vlans unassigned
sensor(config-int-phy-vla-sub)#
```

d. Verify the settings.

```

sensor(config-int-phy-vla-sub)# show settings
subinterface-number: 1
-----
description: <defaulted>
vlangs
-----
unassigned
-----
-----
sensor(config-int-phy-vla-sub)#

```



Note Assigning the unassigned VLANs to a separate virtual sensor allows you to specify a policy for all VLANs that you have not specifically assigned to other groups. For example, you can group your important internal VLANs in one group and apply a stringent security policy to that group. You can group the other less important unassigned VLANs into another group, and apply the default security policy to that group, so that only very serious alerts are reported.

Step 13 Add a description for the VLAN group.

```

sensor(config-int-phy-inl-sub)# description INT1 vlans 52 and 53

```

Step 14 Verify the VLAN group settings.

```

sensor(config-int-phy-vla-sub)# show settings
subinterface-number: 1
-----
description: GROUP1 default:
vlangs
-----
unassigned
-----
-----
sensor(config-int-phy-vla-sub)#

```

Step 15 Delete VLAN groups:

a. Delete one VLAN group.

```

sensor(config-int-phy-vla-sub)# exit
sensor(config-int-phy-vla)# no subinterface 1

```

If this VLAN group is the last one on the sensor, you receive an error message.

```

Error: This "subinterface-type" contains less than the required number of
"subinterface" entries. Please add entry(s) to reach the minimum required entries or
select a different "subinterface-type".

```

Go to Step b to remove the last VLAN group.

b. Delete all VLAN groups. You must also delete the VLAN group from the virtual sensor to which it is assigned.

```

sensor(config-int-phy-vla-sub)# exit
sensor(config-int-phy-vla)# exit
sensor(config-int-phy)# subinterface-type none

```

Step 16 Exit interface submenu.

```
sensor(config-int-phy-vla-sub)# exit
sensor(config-int-phy-vla)# exit
sensor(config-int-phy)# exit
sensor(config-int)# exit
Apply Changes:[yes]:
```

Step 17 Press **Enter** to apply the changes or enter **no** to discard them.

For More Information

For the procedure for assigning inline interface pairs to a virtual sensor, or deleting the inline interface pair from the virtual sensor to which it is assigned, see [Adding, Editing, and Deleting Virtual Sensors](#), page 6-5.

Configuring Inline Bypass Mode

This section describes inline bypass mode for sensors configured as inline interface and inline VLAN pairs, and contains the following topics:

- [Understanding Inline Bypass Mode](#), page 5-38
- [Configuring Inline Bypass Mode](#), page 5-39

Understanding Inline Bypass Mode



Note

The ASA 5500-X IPS SSP and ASA 5585-X IPS SSP do not support bypass mode. The adaptive security appliance will either fail open, fail close, or fail over depending on the configuration of the adaptive security appliance and the type of activity being done on the IPS.



Note

For information on what you need to configure if you are using the hardware bypass card on the IPS 4260 and the IPS 4270-20, see [Hardware Bypass Configuration Restrictions](#), page 5-12.



Caution

There are security consequences when you put the sensor in bypass mode. When bypass mode is on, the traffic bypasses the sensor and is not inspected; therefore, the sensor cannot prevent malicious attacks.



Caution

As with signature updates, when the sensor applies a global correlation update, it may trigger bypass. Whether or not bypass is triggered depends on the traffic load of the sensor and the size of the signature/global correlation update. If bypass mode is turned off, an inline sensor stops passing traffic while the update is being applied.

You can use inline bypass as a diagnostic tool and a failover protection mechanism. Normally, the sensor Analysis Engine performs packet analysis. When inline bypass is activated, the Analysis Engine is bypassed, allowing traffic to flow through the inline interfaces and inline VLAN pairs without inspection. Inline bypass ensures that packets continue to flow through the sensor when the sensor processes are temporarily stopped for upgrades or when the sensor monitoring processes fail. There are three modes: on, off, and automatic. By default, bypass mode is set to automatic.

The inline bypass functionality is implemented in software, so it only functions when the operating system is running. If the sensor is powered off or shut down, inline bypass does not work—traffic does not flow through the sensor.

For IPS 4510 and IPS 4520, when the SensorApp is not running or if bypass mode is on, the following occurs:

- The output from the **packet capture/display** command does not show any packets.
- The **show interface** and **show interface interface_name** commands do not show VLAN statistics.

Configuring Inline Bypass Mode

Use the **bypass-mode** command in the service interface submode to configure bypass mode. The following options apply:

- **off**—Turns off inline bypassing. Packet inspection is performed on inline data traffic. However, inline traffic is interrupted if the Analysis Engine is stopped.
- **on**—Turns on inline bypassing. No packet inspection is performed on the traffic. Inline traffic continues to flow even if the Analysis Engine is stopped.
- **auto**—Turns on automatic bypassing. The sensor automatically begins bypassing inline packet inspection if the Analysis Engine stops processing packets. This prevents data interruption on inline interfaces. This is the default.

Configuring Bypass Mode

To configure bypass mode, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter interface submode.

```
sensor# configure terminal
sensor(config)# service interface
```

Step 3 Configure bypass mode.

```
sensor(config-int)# bypass-mode off
```

Step 4 Verify the settings.

```
sensor(config-int)# show settings
-----
bypass-mode: off default: auto
interface-notifications
-----
missed-percentage-threshold: 0 percent <defaulted>
notification-interval: 30 seconds <defaulted>
idle-interface-delay: 30 seconds <defaulted>
-----
sensor(config-int)#
```

Step 5 Exit interface submode.

```
sensor(config-int)# exit  
Apply Changes:[yes]:
```

Step 6 Press **Enter** to apply the changes or enter **no** to discard them.

For More Information

- For detailed information on the ASA 5500 AIP SSM and bypass mode, see [The Adaptive Security Appliance, ASA 5500 AIP SSM, and Bypass Mode, page 18-12](#).
- For more information on inline bypass mode, see [Configuring Inline Bypass Mode, page 5-38](#).

Configuring Interface Notifications

You can configure the sensor to monitor the flow of packets across an interface and send notification if that flow changes (starts/stops) during a specified interval. You can configure the missed packet threshold within a specific notification interval and also configure the interface idle delay before a status event is reported.

Use the **interface-notifications** command in the service interface submode to configure traffic notifications.

The following options apply:

- **default**—Sets the value back to the system default setting.
- **idle-interface-delay**—Specifies the number of seconds an interface must be idle before sending a notification. The valid range is 5 to 3600. The default is 30 seconds.
- **missed-percentage-threshold**—Specifies the percentage of packets that must be missed during a specified interval before notification will be sent. The valid range is 0 to 100. The default is 0.
- **notification-interval**—Specifies the interval to check for missed packet percentage. The valid range is 5 to 3600. The default is 30 seconds

Configuring Interface Notifications

To configure the interface notification settings, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter global configuration mode.

```
sensor# configure terminal
```

Step 3 Enter interface submode.

```
sensor(config)# service interface
```

Step 4 Enter interface notifications submode.

```
sensor(config-int)# interface-notifications
```

Step 5 Specify the idle interface delay.

```
sensor(config-int-int)# idle-interface-delay 60
```

- Step 6** Specify the missed percentage threshold.
- ```
sensor(config-int-int)# missed-percentage-threshold 1
```
- Step 7** Specify the notification interval.
- ```
sensor(config-int-int)# notification-interval 60
```
- Step 8** Verify the settings.
- ```
sensor(config-int-int)# show settings
interface-notifications

missed-percentage-threshold: 1 percent default: 0
notification-interval: 60 seconds default: 30
idle-interface-delay: 60 seconds default: 30

sensor(config-int-int)#
```
- Step 9** Exit interface notifications submenu.
- ```
sensor(config-int-int)# exit
sensor(config-int)# exit
Apply Changes?[yes]:
```
- Step 10** Press **Enter** to apply the changes or enter **no** to discard them.

Configuring CDP Mode



Note

The ASA 5500-X IPS SSP and the ASA 5585-X IPS SSP do not support CDP mode.

You can configure the sensor to enable or disable the forwarding of CDP packets. This action applies globally to all interfaces.

Cisco Discovery Protocol is a media- and protocol-independent device-discovery protocol that runs on all Cisco-manufactured equipment, including routers, access servers, bridges, and switches. Using CDP, a device can advertise its existence to other devices and receive information about other devices on the same LAN or on the remote side of a WAN. CDP runs on all media that support SNAP, including LANs, Frame Relay, and ATM media.

User the **cdp-mode** command in service interface mode to have the sensor either forward or drop CDP packets.

The following option applies:

- **cdp-mode {forward-cdp-packets | drop-cdp-packets}**—Configures the sensor to either forward CDP packets or drop CDP packets. The default is drop-cdp-packets.

Enabling CDP Mode

To configure CDP mode, follow these steps:

- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter interface submenu.
- ```
sensor# configure terminal
```

```
sensor(config)# service interface
```

**Step 3** Enable CDP mode.

```
sensor(config-int)# cdp-mode forward-cdp-packets
```

**Step 4** Verify the settings.

```
sensor(config-int)# show settings

bypass-mode: auto <defaulted>
interface-notifications

missed-percentage-threshold: 0 percent <defaulted>
notification-interval: 30 seconds <defaulted>
idle-interface-delay: 30 seconds <defaulted>

cdp-mode: forward-cdp-packets default: drop-cdp-packets
sensor(config-int)#
```

## Displaying Interface Statistics



### Note

The **show interface** command output for the IPS 4510 and IPS 4520 does not include the total undersize packets or total transmit FIFO overruns.



### Note

When the IPS 4510 and IPS 4520 are in bypass mode, VLAN statistics in the **show interface** and packet **display/capture** command output do not show any packets.



### Note

For IPS standalone appliances with 1 G and 10 G fixed or add-on interfaces, the maximum jumbo frame size is 9216 bytes. For integrated IPS sensors, such as the ASA 5500-X and ASA 5585-X series, refer to the following URL for information:

[http://www.cisco.com/en/US/docs/security/asa/asa84/configuration/guide/interface\\_start.html#wp132869](http://www.cisco.com/en/US/docs/security/asa/asa84/configuration/guide/interface_start.html#wp132869)

A jumbo frame is an Ethernet packet that is larger than the standard maximum of 1518 bytes (including Layer 2 header and FCS).



### Note

The jumbo packet count in the **show interface** command output from the lines `Total Jumbo Packets Received` and `Total Jumbo Packets Transmitted` for ASA IPS modules may be larger than expected due to some packets that were almost jumbo size on the wire being counted as jumbo size by the IPS. This miscount is a result of header bytes added to the packet by the ASA before the packet is transmitted to the IPS. For IPv4, 58 bytes of header data are added. For IPv6, 78 bytes of header data are added. The ASA removes the added IPS header before the packet leaves the ASA.

Use the **show interfaces** [**clear** | **brief**] command in EXEC mode to display statistics for all system interfaces. Use the **show interfaces** {**FastEthernet** | **GigabitEthernet** | **Management** | **PortChannel**} [**slot/port**] command to display statistics for specific interfaces.

The following options apply:

- **clear**—(Optional) Clears the diagnostics.
- **brief**—(Optional) Displays a summary of the usability status information for each interface.
- **FastEthernet**—Displays statistics for FastEthernet interfaces.
- **GigabitEthernet**—Displays statistics for GigabitEthernet interfaces.
- **Management**—Displays statistics for Management interfaces.



**Note** Only platforms with external ports marked *Management* support this keyword.

- **PortChannel**—Displays statistics for PortChannel interfaces
- *slot/port*—Displays statistics for the specific slot/port of the interface.

To display interface statistics, follow these steps:

**Step 1** Log in to the CLI.

**Step 2** Display statistics for all interfaces.

```
sensor# show interfaces
Interface Statistics
 Total Packets Received = 0
 Total Bytes Received = 0
 Missed Packet Percentage = 0
 Current Bypass Mode = Auto_off
MAC statistics from interface GigabitEthernet0/0
 Statistics From Subinterface 12
 Vlans in this group = 12
 Total Packets Received On This Vlan Group = 0
 Total Bytes Received On This Vlan Group = 0
 Total Packets Transmitted On This Vlan Group = 0
 Total Bytes Transmitted On This Vlan Group = 0
 Statistics From Subinterface 16
 Vlans in this group = 10
 Total Packets Received On This Vlan Group = 0
 Total Bytes Received On This Vlan Group = 0
 Total Packets Transmitted On This Vlan Group = 0
 Total Bytes Transmitted On This Vlan Group = 0
 Statistics From Subinterface 25
 Vlans in this group = 11
 Total Packets Received On This Vlan Group = 0
 Total Bytes Received On This Vlan Group = 0
 Total Packets Transmitted On This Vlan Group = 0
 Total Bytes Transmitted On This Vlan Group = 0
--MORE--
```

**Step 3** Show a brief summary of the interfaces. The \* indicates that the interface is the command and control interface.

```
sensor# show interfaces brief
CC Interface Sensing State Link Inline Mode Pair Status
* GigabitEthernet0/0 Disabled Down Unpaired N/A
 Management0/0 Disabled Up Unpaired N/A
 GigabitEthernet0/1 Disabled Down Unpaired N/A
 GigabitEthernet0/2 Disabled Down Unpaired N/A
 GigabitEthernet0/3 Disabled Down Unpaired N/A
sensor#
```

**Step 4** Display the statistics for a specific interface.

```
sensor# show interfaces Management0/0
MAC statistics from interface Management0/0
 Interface function = Command-control interface
 Description =
 Media Type = TX
 Default Vlan = 0
 Link Status = Up
 Link Speed = Auto_100
 Link Duplex = Auto_Full
 Total Packets Received = 4305909
 Total Bytes Received = 280475712
 Total Multicast Packets Received = 0
 Total Receive Errors = 0
 Total Receive FIFO Overruns = 0
 Total Packets Transmitted = 973627
 Total Bytes Transmitted = 437632618
 Total Transmit Errors = 0
 Total Transmit FIFO Overruns = 0
sensor#
```

**Step 5** Clear the statistics.

```
sensor# show interfaces clear
Interface Statistics
 Total Packets Received = 0
 Total Bytes Received = 0
 Missed Packet Percentage = 0
 Current Bypass Mode = Auto_off
MAC statistics from interface GigabitEthernet0/0
 Statistics From Subinterface 12
 Vlans in this group = 12
 Total Packets Received On This Vlan Group = 0
 Total Bytes Received On This Vlan Group = 0
 Total Packets Transmitted On This Vlan Group = 0
 Total Bytes Transmitted On This Vlan Group = 0
 Statistics From Subinterface 16
 Vlans in this group = 10
 Total Packets Received On This Vlan Group = 0
 Total Bytes Received On This Vlan Group = 0
 Total Packets Transmitted On This Vlan Group = 0
 Total Bytes Transmitted On This Vlan Group = 0
 Statistics From Subinterface 25
 Vlans in this group = 11
 Total Packets Received On This Vlan Group = 0
 Total Bytes Received On This Vlan Group = 0
 Total Packets Transmitted On This Vlan Group = 0
 Total Bytes Transmitted On This Vlan Group = 0
--MORE--
```

---

**For More Information**

For information on slot and port numbers and which platforms have a Management port, refer to [Cisco Intrusion Prevention System Appliances and Modules Installation Guide for IPS 7.1](#).

# Displaying Interface Traffic History

Use the **show interfaces-history** [**traffic-by-hour** | **traffic-by-minute**] command in EXEC mode to display historical interfaces statistics for all system interfaces. The historical information for each interface is maintained for three days with 60 seconds granularity. Use the **show interfaces-history** {**FastEthernet** | **GigabitEthernet** | **Management** | **PortChannel**} [**traffic-by-hour** | **traffic-by-minute**] command to display statistics for specific interfaces.

**Note**

You must have health monitoring enabled to support the historic interface function.

Each record has the following details:

- Total packets received
- Total bytes received
- FIFO overruns
- Receive errors
- Received Mbps
- Missed packet percentage
- Average load
- Peak load

**Note**

Historical data for each interface for the past 72 hours is also included in the **show tech-support** command.

The following options apply:

- **traffic-by-hour**—Displays interface traffic history by the hour.
- **traffic-by-minute**—Displays interface traffic history by the minute.
- **past**—Displays historical interface traffic information.
- **HH:MM**—Specifies the amount of time to go back in the past to begin the traffic display. The range for HH is 0 to 72. The range for MM is 0 to 59. The minimum value is 00:01 and the maximum value is 72:00.
- **FastEthernet**—Displays statistics for FastEthernet interfaces.
- **GigabitEthernet**—Displays statistics for GigabitEthernet interfaces.
- **Management**—Displays statistics for Management interfaces.

**Note**

Only platforms with external ports marked *Management* support this keyword.

- **PortChannel**—Displays statistics for PortChannel interfaces.

### Displaying Historical Interface Statistics

Use the **show interfaces-history** [**traffic-by-hour** | **traffic-by-minute**] command in EXEC mode to display historical interfaces statistics for all system interfaces. The historical information for each interface is maintained for three days with 60 seconds granularity. Use the **show interfaces-history** {**FastEthernet** | **GigabitEthernet** | **Management** | **PortChannel**} [**traffic-by-hour** | **traffic-by-minute**] command to display statistics for specific interfaces.



#### Note

You must have health monitoring enabled to support the historic interface function.

Each record has the following details:

- Total packets received
- Total bytes received
- FIFO overruns
- Receive errors
- Received Mbps
- Missed packet percentage
- Average load
- Peak load



#### Note

Historical data for each interface for the past 72 hours is also included in the **show tech-support** command.

The following options apply:

- **traffic-by-hour**—Displays interface traffic history by the hour.
- **traffic-by-minute**—Displays interface traffic history by the minute.
- **past**—Displays historical interface traffic information.
- **HH:MM**—Specifies the amount of time to go back in the past to begin the traffic display. The range for HH is 0 to 72. The range for MM is 0 to 59. The minimum value is 00:01 and the maximum value is 72:00.
- **FastEthernet**—Displays statistics for FastEthernet interfaces.
- **GigabitEthernet**—Displays statistics for GigabitEthernet interfaces.
- **Management**—Displays statistics for Management interfaces.



#### Note

Only platforms with external ports marked *Management* support this keyword.

- **PortChannel**—Displays statistics for PortChannel interfaces.



## Displaying Historical Interface Statistics

To display interface traffic history, follow these steps:

**Step 1** Log in to the CLI.

**Step 2** Display the interface traffic history by the hour.

```
sensor# show interfaces-history traffic-by-hour past 02:15
```

```
GigabitEthernet0/0
Time Packets Received Bytes Received Mbps MPP FIFO Overruns Receive Errors Avg Load Peak Load
11:30:31 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
10:27:32 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0

GigabitEthernet0/1
Time Packets Received Bytes Received Mbps MPP FIFO Overruns Receive Errors Avg Load Peak Load
11:30:31 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
10:27:32 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0

GigabitEthernet0/2
Time Packets Received Bytes Received Mbps MPP FIFO Overruns Receive Errors Avg Load Peak Load
11:30:31 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
10:27:32 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0

GigabitEthernet0/3
Time Packets Received Bytes Received Mbps MPP FIFO Overruns Receive Errors Avg Load Peak Load
11:30:31 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
10:27:32 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0

Management0/0
Time Packets Received Bytes Received Mbps MPP FIFO Overruns Receive Errors Avg Load Peak Load
11:30:31 UTC Tue Mar 05 2013 31071600 3240924703 0 0 0 0 0 0 0
10:27:32 UTC Tue Mar 05 2013 30859941 3216904786 0 0 0 0 0 0 0

--MORE--
```

**Step 3** Display the interface traffic history by the minute.

```
sensor# show interfaces-history traffic-by-minute past 00:45
```

```
GigabitEthernet0/0
Time Packets Received Bytes Received Mbps MPP FIFO Overruns Receive Errors Avg Load Peak
Load
12:27:49 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:26:45 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:25:48 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:24:42 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:23:37 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:22:30 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:21:31 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:20:29 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:19:25 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:18:18 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:17:12 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:16:07 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:15:00 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:13:54 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:12:49 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:11:43 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:10:36 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:09:30 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:08:24 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:07:25 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:06:23 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
12:05:25 UTC Tue Mar 05 2013 0 0 0 0 0 0 0 0 0
sensor#
```

**Step 4** Display the interface traffic history for a specific interface.

```
sensor# show interfaces-history GigabitEthernet0/0 traffic-by-minute past 00:05
```

```
GigabitEthernet0/0
```

| Time                         | Packets Received | Bytes Received | Mbps | MPP | FIFO | Overruns | Receive Errors | Avg Load | Peak Load |
|------------------------------|------------------|----------------|------|-----|------|----------|----------------|----------|-----------|
| 13:34:38 UTC Thu Mar 07 2013 | 0                | 0              | 0    | 0   | 0    |          | 0              | 0        | 0         |
| 13:33:35 UTC Thu Mar 07 2013 | 0                | 0              | 0    | 0   | 0    |          | 0              | 0        | 0         |
| 13:32:32 UTC Thu Mar 07 2013 | 0                | 0              | 0    | 0   | 0    |          | 0              | 0        | 0         |
| 13:31:27 UTC Thu Mar 07 2013 | 0                | 0              | 0    | 0   | 0    |          | 0              | 0        | 0         |
| 13:30:25 UTC Thu Mar 07 2013 | 0                | 0              | 0    | 0   | 0    |          | 0              | 0        | 0         |

```
sensor#
```

---

**For More Information**

For information on enabling health monitoring, see [Configuring Health Status Information, page 17-15](#).



## Configuring Virtual Sensors

---

This chapter explains the function of the Analysis Engine and how to create, edit, and delete virtual sensors. It also explains how to assign interfaces to a virtual sensor. It contains the following sections:

- [Virtual Sensor Notes and Caveats, page 6-1](#)
- [Understanding the Analysis Engine, page 6-2](#)
- [Understanding Virtual Sensors, page 6-2](#)
- [Advantages and Restrictions of Virtualization, page 6-2](#)
- [Inline TCP Session Tracking Mode, page 6-3](#)
- [Normalization and Inline TCP Evasion Protection Mode, page 6-4](#)
- [HTTP Advanced Decoding, page 6-4](#)
- [Adding, Editing, and Deleting Virtual Sensors, page 6-5](#)
- [Configuring Global Variables, page 6-12](#)

### Virtual Sensor Notes and Caveats

The following notes and caveats apply to configuring the virtual sensor:

- The Cisco IPS does not support more than four virtual sensors. You cannot delete the default virtual sensor vs0.
- The ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) do not support the inline TCP session tracking mode.
- For the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP), normalization is performed by the adaptive security appliance and not the IPS.
- Anomaly detection is disabled by default in IPS 7.1(2)E4 and later. You must enable it to configure or apply an anomaly detection policy. Enabling anomaly detection results in a decrease in performance.

## Understanding the Analysis Engine

The Analysis Engine performs packet analysis and alert detection. It monitors traffic that flows through specified interfaces.

You create virtual sensors in the Analysis Engine. Each virtual sensor has a unique name with a list of interfaces, inline interface pairs, inline VLAN pairs, and VLAN groups associated with it. To avoid definition ordering issues, no conflicts or overlaps are allowed in assignments. You assign interfaces, inline interface pairs, inline VLAN pairs, and VLAN groups to a specific virtual sensor so that no packet is processed by more than one virtual sensor. Each virtual sensor is also associated with a specifically named signature definition, event action rules, and anomaly detection configuration. Packets from interfaces, inline interface pairs, inline VLAN pairs, and VLAN groups that are not assigned to any virtual sensor are disposed of according to the inline bypass configuration.

**Note**

The Cisco IPS does not support more than four virtual sensors. You cannot delete the default virtual sensor vs0.

## Understanding Virtual Sensors

The sensor can receive data inputs from one or many monitored data streams. These monitored data streams can either be physical interface ports or virtual interface ports. For example, a single sensor can monitor traffic from in front of the firewall, from behind the firewall, or from in front of and behind the firewall concurrently. And a single sensor can monitor one or more data streams. In this situation a single sensor policy or configuration is applied to all monitored data streams.

A virtual sensor is a collection of data that is defined by a set of configuration policies. The virtual sensor is applied to a set of packets as defined by interface component.

A virtual sensor can monitor multiple segments, and you can apply a different policy or configuration for each virtual sensor within a single physical sensor. You can set up a different policy per monitored segment under analysis. You can also apply the same policy instance, for example, sig0, rules0, or ad0, to different virtual sensors. You can assign interfaces, inline interface pairs, inline VLAN pairs, and VLAN groups to a virtual sensor.

**Note**

The default virtual sensor is vs0. You cannot delete the default virtual sensor. The interface list, the anomaly detection operational mode, the inline TCP session tracking mode, and the virtual sensor description are the only configuration features you can change for the default virtual sensor. You cannot change the signature definition, event action rules, or anomaly detection policies.

## Advantages and Restrictions of Virtualization

Virtualization has the following advantages:

- You can apply different configurations to different sets of traffic.
- You can monitor two networks with overlapping IP spaces with one sensor.
- You can monitor both inside and outside of a firewall or NAT device.

Virtualization has the following restrictions:

- You must assign both sides of asymmetric traffic to the same virtual sensor.
- Using VACL capture or SPAN (promiscuous monitoring) is inconsistent with regard to VLAN tagging, which causes problems with VLAN groups.
  - When using Cisco IOS software, a VACL capture port or a SPAN target does not always receive tagged packets even if it is configured for trunking.
  - When using the MSFC, fast path switching of learned routes changes the behavior of VACL captures and SPAN.
- Persistent store is limited.

Virtualization has the following traffic capture requirements:

- The virtual sensor must receive traffic that has 802.1q headers (other than traffic on the native VLAN of the capture port).
- The sensor must see both directions of traffic in the same VLAN group in the same virtual sensor for any given sensor.

The following sensors support virtualization:

- ASA 5500 AIP SSM
- ASA 5500-X IPS SSP
- ASA 5585-X IPS SSP
- IPS 4240
- IPS 4255
- IPS 4260
- IPS 4270-20
- IPS 4345
- IPS 4360
- IPS 4510
- IPS 4520

## Inline TCP Session Tracking Mode



### Note

The ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) do not support the inline TCP session tracking mode.

When you choose to modify packets inline, if the packets from a stream are seen twice by the Normalizer engine, it cannot properly track the stream state and often the stream is dropped. This situation occurs most often when a stream is routed through multiple VLANs or interfaces that are being monitored by the IPS. A further complication in this situation is the necessity of allowing asymmetric traffic to merge for proper tracking of streams when the traffic for either direction is received from different VLANs or interfaces. To deal with this situation, you can set the mode so that streams are perceived as unique if they are received on separate interfaces and/or VLANs (or the subinterface for VLAN pairs).

The following inline TCP session tracking modes apply:

- **Interface and VLAN**—All packets with the same session key (AaBb) in the same VLAN (or inline VLAN pair) and on the same interface belong to the same session. Packets with the same key but on different VLANs are tracked separately.
- **VLAN Only**—All packets with the same session key (AaBb) in the same VLAN (or inline VLAN pair) regardless of the interface belong to the same session. Packets with the same key but on different VLANs are tracked separately.
- **Virtual Sensor**—All packets with the same session key (AaBb) within a virtual sensor belong to the same session. This is the default and almost always the best option to choose.

## Normalization and Inline TCP Evasion Protection Mode



### Note

For the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP), normalization is performed by the adaptive security appliance and not the IPS.

Normalization only applies when the sensor is operating in inline mode. The default is strict evasion protection, which is full enforcement of TCP state and sequence tracking. The Normalizer enforces duplicate packets, changed packets, out-of-order packets, and so forth, which helps prevent attackers from evading the IPS.

Asymmetric mode disables most of the Normalizer checks. Use asymmetric mode only when the entire stream cannot be inspected, because in this situation, attackers can now evade the IPS.

## HTTP Advanced Decoding



### Note

HTTP advanced decoding is supported in IPS 7.1(5)E4 and later.

HTTP advanced decoding facilitates analysis of encoded HTTP return web traffic by using on-the-fly decoding. Changes to HTTP advanced decoding take effect immediately and only affect the new traffic flows.

The following restrictions apply when you enable HTTP advanced decoding:

- Although HTTP advanced decoding does not fire any new signatures, drop packets, or modify traffic, it allows existing signatures to match on content that was previously not detectable because of encodings.
- HTTP advanced decoding only acts on return web response traffic.



### Caution

Enabling HTTP advanced decoding severely impacts system performance.

**Note**

Because HTTP advanced decoding requires the Regex card and the String XL engine, it is available only to those platforms that have them. HTTP advanced decoding is supported on the IPS 4345, IPS 4360, IPS 4510, IPS 4520, ASA 5585-X IPS SSP, ASA 5525-X IPS SSP, ASA 5545-X IPS SSP, and ASA 5555-X IPS SSP.

## Adding, Editing, and Deleting Virtual Sensors

This section describes how to add, edit, and delete virtual sensors, and contains the following topics:

- [Adding Virtual Sensors, page 6-5](#)
- [Editing and Deleting Virtual Sensors, page 6-9](#)

### Adding Virtual Sensors

Use the **virtual-sensor** *name* command in service analysis engine submode to create a virtual sensor. You can create up to four virtual sensors. You assign policies (anomaly detection, event action rules, and signature definition) to the virtual sensor. Then you assign interfaces (promiscuous, inline interface pairs, inline VLAN pairs, and VLAN groups) to the virtual sensor. You must configure the inline interface pairs and VLAN pairs before you can assign them to a virtual sensor.

**Note**

Anomaly detection is disabled by default in IPS 7.1(2)E4 and later. You must enable it to configure or apply an anomaly detection policy. Enabling anomaly detection results in a decrease in performance.

The following options apply:

- **http-advanced-decoding {true | false}**—Enables deeper inspection of HTTP traffic. The default is disabled. Valid for IPS 7.1(5)E4 and later.

**Note**

HTTP advanced decoding is supported on the IPS 4345, IPS 4360, IPS 4510, IPS 4520, ASA 5585-X IPS SSP, and ASA 5525-X IPS SSP, ASA 5545-X IPS SSP, and ASA 5555-X IPS SSP

**Caution**

Enabling HTTP advanced decoding severely impacts system performance.

- **anomaly-detection**—Specifies the anomaly detection parameters:
  - **anomaly-detection-name** *name*—Specifies the name of the anomaly detection policy.
  - **operational-mode**—Specifies the anomaly detection mode (**inactive**, **learn**, **detect**).
- **description**—Description of the virtual sensor.
- **event-action-rules**—Specifies the name of the event action rules policy.

- **inline-TCP-evasion-protection-mode**—Lets you choose which type of normalization you need for traffic inspection:

- **asymmetric** —Specifies that the sensor can only see one direction of bidirectional traffic flow. Asymmetric mode protection relaxes the evasion protection at the TCP layer.



**Note** Asymmetric mode lets the sensor synchronize state with the flow and maintain inspection for those engines that do not require both directions. Asymmetric mode lowers security because full protection requires both sides of traffic to be seen.

- **strict**—Specifies that if a packet is missed for any reason, all packets after the missed packet are not processed. Strict evasion protection provides full enforcement of TCP state and sequence tracking.



**Note** Any out-of-order packets or missed packets can produce Normalizer engine signatures 1300 or 1330 firings, which try to correct the situation, but can result in denied connections.



**Note** For the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP), normalization is performed by the adaptive security appliance and not the IPS.

- **inline-TCP-session-tracking-mode**—Enables an advanced method used to identify duplicate TCP sessions in inline traffic. The default is virtual sensor, which is almost always the best choice.

- **virtual-sensor** —Specifies that all packets with the same session key (AaBb) within a virtual sensor belong to the same session.
- **interface-and-vlan**—Specifies that all packets with the same session key (AaBb) in the same VLAN (or inline VLAN pair) and on the same interface belong to the same session. Packets with the same key but on different VLANs or interfaces are tracked independently.
- **vlan-only**—Specifies that all packets with the same session key (AaBb) in the same VLAN (or inline VLAN pair) regardless of the interface belong to the same session. Packets with the same key but on different VLANs are tracked independently.



**Note** The ASA IPS modules, (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) do not support the inline TCP session tracking mode.

- **signature-definition**—Specifies the name of the signature definition policy.
- **logical-interfaces**—Specifies the name of the logical interfaces (inline interface pairs).
- **physical-interfaces**—Specifies the name of the physical interfaces (promiscuous, inline VLAN pairs, and VLAN groups):
  - **subinterface-number**—Specifies the physical subinterface number. If the subinterface-type is none, the value of 0 indicates the entire interface is assigned in promiscuous mode.
- **no**—Removes an entry or selection.



### Adding a Virtual Sensor

To add a virtual sensor, follow these steps:

**Step 1** Log in to the CLI using an account with administrator privileges.

**Step 2** Enter service analysis mode.

```
sensor# configure terminal
sensor(config)# service analysis-engine
sensor(config-ana)#
```

**Step 3** Add a virtual sensor.

```
sensor(config-ana)# virtual-sensor vs1
sensor(config-ana-vir)#
```

**Step 4** Add a description for this virtual sensor.

```
sensor(config-ana-vir)# description virtual sensor 1
```

**Step 5** Assign an anomaly detection policy and operational mode to this virtual sensor.

```
sensor(config-ana-vir)# anomaly-detection
sensor(config-ana-vir-ano)# anomaly-detection-name ad1
sensor(config-ana-vir-ano)# operational-mode learn
```

**Step 6** Assign an event action rules policy to this virtual sensor.

```
sensor(config-ana-vir-ano)# exit
sensor(config-ana-vir)# event-action-rules rules1
```

**Step 7** Assign a signature definition policy to this virtual sensor.

```
sensor(config-ana-vir)# signature-definition sig1
```

**Step 8** Enable HTTP advanced decoding.

```
sensor(config-ana-vir)# http-advanced-decoding true
```



#### Caution

Enabling HTTP advanced decoding severely impacts system performance.

**Step 9** Assign the inline TCP session tracking mode. The default is virtual sensor mode, which is almost always the best option to choose.

```
sensor(config-ana-vir)# inline-TCP-session-tracking-mode virtual-sensor
```

**Step 10** Assign the inline TCP evasion protection mode. The default is strict mode, which is almost always the best option to choose.

```
sensor(config-ana-vir)# inline-TCP-evasion-protection-mode strict
```

**Step 11** Enable HTTP advanced decoding.

```
sensor(config-ana-vir)# http-advanced-decoding true
```

**Step 12** Display the list of available interfaces.

```
sensor(config-ana-vir)# physical-interface ?
GigabitEthernet0/0 GigabitEthernet0/0 physical interface.
GigabitEthernet0/1 GigabitEthernet0/1 physical interface.
GigabitEthernet2/0 GigabitEthernet0/2 physical interface.
GigabitEthernet2/1 GigabitEthernet0/3 physical interface.
```

```
sensor(config-ana-vir)# physical-interface
```

```
sensor(config-ana-vir)# logical-interface ?
<none available>
```

- Step 13** Assign the promiscuous mode interfaces you want to add to this virtual sensor. Repeat this step for all the promiscuous interfaces that you want to assign to this virtual sensor.

```
sensor(config-ana-vir)# physical-interface GigabitEthernet0/3
```

- Step 14** Assign the inline interface pairs you want to add to this virtual sensor. You must have already paired the interfaces.

```
sensor(config-ana-vir)# logical-interface inline_interface_pair_name
```

- Step 15** Assign the subinterfaces of the inline VLAN pairs or groups you want to add to this virtual sensor. You must have already subdivided any interfaces into VLAN pairs or groups.

```
sensor(config-ana-vir)# physical-interface GigabitEthernet2/0 subinterface-number
subinterface_number
```

- Step 16** Verify the virtual sensor settings.

```
sensor(config-ana-vir)# show settings
name: vs1

description: virtual sensor 1 default:
signature-definition: sig1 default: sig0
event-action-rules: rules1 default: rules0
anomaly-detection

anomaly-detection-name: ad1 default: ad0
operational-mode: learn default: detect

physical-interface (min: 0, max: 999999999, current: 2)

name: GigabitEthernet0/3
subinterface-number: 0 <defaulted>

inline-TCP-session-tracking-mode: virtual-sensor default: virtual-sensor

logical-interface (min: 0, max: 999999999, current: 0)

sensor(config-ana-vir)#
```

- Step 17** Exit analysis engine mode.

```
sensor(config-ana-vir)# exit
sensor(config-ana)# exit
sensor(config)#
Apply Changes?[yes]:
```

- Step 18** Press **Enter** to apply the changes or enter **no** to discard them.
-

**For More Information**

- For the procedure for creating virtual sensors on the ASA 5500 AIP SSM, see [Creating Virtual Sensors for the ASA 5500 AIP SSM, page 18-4](#).
- For the procedure for creating virtual sensors on the ASA 5500-X IPS SSP, see [Creating Virtual Sensors for the ASA 5500-X IPS SSP, page 19-3](#).
- For the procedure for creating virtual sensors on the ASA 5585-X IPS SSP, see [Creating Virtual Sensors for the ASA 5585-X IPS SSP, page 20-4](#).
- For more information on creating and configuring anomaly detection policies, see [Working With Anomaly Detection Policies, page 9-9](#).
- For more information on creating and configuring event action rules policies, see [Working With Event Action Rules Policies, page 7-8](#).
- For more information on creating and configuring signature definition policies, see [Working With Signature Definition Policies, page 8-2](#).
- For more information about normalization, see [Normalization and Inline TCP Evasion Protection Mode, page 6-4](#).
- For more information about inline TCP session tracking mode, see [Inline TCP Session Tracking Mode, page 6-3](#).
- For the procedure for pairing inline interfaces, see [Configuring Inline Interface Pairs, page 5-21](#). Repeat Step 11 for all the inline interface pairs that you want to assign to this virtual sensor.
- For the procedure for pairing and grouping inline VLANs, see [Configuring Inline VLAN Pairs, page 5-26](#) and [Configuring VLAN Groups, page 5-32](#). Repeat Step 12 for all inline VLAN pairs or VLAN groups that you want to assign to this virtual sensor.
- For the procedure for enabling anomaly detection, see [Enabling Anomaly Detection, page 9-8](#).

## Editing and Deleting Virtual Sensors

You can edit the following parameters of a virtual sensor:

- Signature definition policy
- Event action rules policy
- Anomaly detection policy



**Note** Anomaly detection is disabled by default in IPS 7.1(2)E4 and later. You must enable it to configure or apply an anomaly detection policy. Enabling anomaly detection results in a decrease in performance.

- Anomaly detection operational mode
- Inline TCP session tracking mode



**Note** The ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) do not support the inline TCP session tracking mode.

- Description
- Interfaces assigned

### Editing or Deleting a Virtual Sensor

To edit or delete a virtual sensor, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter analysis engine mode.
- ```
sensor# configure terminal
sensor(config)# service analysis-engine
sensor(config-ana)#
```
- Step 3** Edit the virtual sensor, vs1.
- ```
sensor(config-ana)# virtual-sensor vs1
sensor(config-ana-vir)#
```
- Step 4** Edit the description of this virtual sensor.
- ```
sensor(config-ana-vir)# description virtual sensor A
```
- Step 5** Change the anomaly detection policy and operational mode assigned to this virtual sensor.
- ```
sensor(config-ana-vir)# anomaly-detection
sensor(config-ana-vir-ano)# anomaly-detection-name ad0
sensor(config-ana-vir-ano)# operational-mode learn
```
- Step 6** Change the event action rules policy assigned to this virtual sensor.
- ```
sensor(config-ana-vir-ano)# exit
sensor(config-ana-vir)# event-action-rules rules0
```
- Step 7** Change the signature definition policy assigned to this virtual sensor.
- ```
sensor(config-ana-vir)# signature-definition sig0
```
- Step 8** Change the inline TCP session tracking mode. The default is virtual sensor mode, which is almost always the best option to choose.
- ```
sensor(config-ana-vir)# inline-TCP-session-tracking-mode interface-and-vlan
```
- Step 9** Display the list of available interfaces.
- ```
sensor(config-ana-vir)# physical-interface ?
GigabitEthernet0/0 GigabitEthernet0/0 physical interface.
GigabitEthernet0/1 GigabitEthernet0/1 physical interface.
GigabitEthernet2/0 GigabitEthernet0/2 physical interface.
GigabitEthernet2/1 GigabitEthernet0/3 physical interface.
sensor(config-ana-vir)# physical-interface

sensor(config-ana-vir)# logical-interface ?
<none available>
```
- Step 10** Change the promiscuous mode interfaces assigned to this virtual sensor.
- ```
sensor(config-ana-vir)# physical-interface GigabitEthernet0/2
```
- Step 11** Change the inline interface pairs assigned to this virtual sensor. You must have already paired the interfaces.
- ```
sensor(config-ana-vir)# logical-interface inline_interface_pair_name
```

- Step 12** Change the subinterface with the inline VLAN pairs or groups assigned to this virtual sensor. You must have already subdivided any interfaces into VLAN pairs or groups.

```
sensor(config-ana-vir)# physical-interface GigabitEthernet2/0 subinterface-number
subinterface_number
```

- Step 13** Verify the edited virtual sensor settings.

```
ssensor(config-ana-vir)# show settings
name: vs1

description: virtual sensor 1 default:
signature-definition: sig1 default: sig0
event-action-rules: rules1 default: rules0
anomaly-detection

anomaly-detection-name: ad1 default: ad0
operational-mode: learn default: detect

physical-interface (min: 0, max: 999999999, current: 2)

name: GigabitEthernet0/3
subinterface-number: 0 <defaulted>

inline-TCP-session-tracking-mode: interface-and-vlan default: virtual-sensor

logical-interface (min: 0, max: 999999999, current: 0)

sensor(config-ana-vir)#
```

- Step 14** Delete a virtual sensor.

```
sensor(config-ana-vir)# exit
sensor(config-ana)# no virtual-sensor vs1
```

- Step 15** Verify the deleted virtual sensor. Only the default virtual sensor, vs0, is present.

```
sensor(config-ana)# show settings
global-parameters

ip-logging

max-open-iplog-files: 20 <defaulted>

virtual-sensor (min: 1, max: 255, current: 2)

<protected entry>
name: vs0 <defaulted>

description: default virtual sensor <defaulted>
signature-definition: sig0 <protected>
event-action-rules: rules0 <protected>
anomaly-detection

anomaly-detection-name: ad0 <protected>
operational-mode: detect <defaulted>

physical-interface (min: 0, max: 999999999, current: 0)

logical-interface (min: 0, max: 999999999, current: 0)

```

```

sensor(config-ana)#
```

**Step 16** Exit analysis engine mode.

```
sensor(config-ana)# exit
sensor(config)#
Apply Changes:[yes]:
```

**Step 17** Press **Enter** to apply the changes or enter **no** to discard them.

#### For More Information

- For more information on creating and configuring anomaly detection policies, see [Working With Anomaly Detection Policies, page 9-9](#).
- For more information on creating and configuring event action rules policies, see [Working With Event Action Rules Policies, page 7-8](#).
- For more information on creating and configuring signature definition policies, see [Working With Signature Definition Policies, page 8-2](#).
- For the procedure for pairing inline interfaces, see [Configuring Inline VLAN Pairs, page 5-26](#). Repeat Step 11 for all the inline interface pairs that you want to assign to this virtual sensor.
- For the procedure for pairing and grouping inline VLANs, see [Configuring Inline VLAN Pairs, page 5-26](#) and [Configuring VLAN Groups, page 5-32](#). Repeat Step 12 for all inline VLAN pairs or VLAN groups that you want to assign to this virtual sensor.
- For the procedure for enabling anomaly detection, see [Enabling Anomaly Detection, page 9-8](#).

## Configuring Global Variables

Use the **global-parameters** command in service analysis engine submode to create global variables, such as IP logging and specifying the flow depth. Flow depth is used for String, Multi-String, Service HTTP, and State engines. It does not apply to the XL String engine and the platforms that support it.



#### Note

The IPS 4345, IPS 4360, IPS 4510, IPS 4520, ASA 5525-X IPS SSP, ASA 5545-X IPS SSP, ASA 5555-X IPS SSP, and ASA 5585-X IPS SSP support the String XL engines and the Regex accelerator card.

The following options apply:

- **ip-logging**—Enables global IP logging parameters.
  - **max-open-iplog-files**—Specifies the maximum number of concurrently open log files. The range is 20 to 100. The default is 20.
- **specify-flow-depth**—Lets you specify the inspection depth of the flow. Flow depth is the number of bytes inspected in a flow. The new value applies for new flows only. The valid range is from 0 to 429496296. The default is 0, which is infinite. Creating a Global Variable

To create a global variable, follow these steps:

---

**Step 1** Log in to the CLI using an account with administrator privileges.

**Step 2** Enter service analysis mode.

```
sensor# configure terminal
sensor(config)# service analysis-engine
sensor(config-ana)#
```

**Step 3** Create the variable for the maximum number of open IP logs.

```
sensor(config-ana)# global-parameters
sensor(config-ana-glo)# ip-logging
sensor(config-ana-glo-ip)# max-open-iplog-files 50
sensor(config-ana-glo-ip)# exit
sensor(config-ana-glo)#
```

**Step 4** Create the flow depth variable.

```
sensor(config-ana-glo)# specify-flow-depth 500
sensor(config-ana-glo)# exit
sensor(config-ana)#
```

**Step 5** Verify the global variable settings.

```
sensor(config-ana-glo)# show settings
global-parameters

specify-flow-depth: 500 default: 0

ip-logging

max-open-iplog-files: 50 default: 20

sensor(config-ana-glo)#
```

**Step 6** Exit analysis engine mode.

```
sensor(config-ana)# exit
sensor(config)#
Apply Changes:[yes]:
```

**Step 7** Press **Enter** to apply the changes or enter **no** to discard them.

---







# Configuring Event Action Rules

This chapter explains how to add event action rules policies and how to configure event action rules. It contains the following sections:

- [Event Action Rules Notes and Caveats, page 7-1](#)
- [Understanding Security Policies, page 7-2](#)
- [Understanding Event Action Rules, page 7-2](#)
- [Signature Event Action Processor, page 7-3](#)
- [Event Actions, page 7-5](#)
- [Event Action Rules Configuration Sequence, page 7-8](#)
- [Working With Event Action Rules Policies, page 7-8](#)
- [Event Action Variables, page 7-10](#)
- [Configuring Target Value Ratings, page 7-13](#)
- [Configuring Event Action Overrides, page 7-17](#)
- [Configuring Event Action Filters, page 7-20](#)
- [Configuring OS Identifications, page 7-26](#)
- [Configuring General Settings, page 7-33](#)
- [Configuring the Denied Attackers List, page 7-36](#)
- [Monitoring Events, page 7-39](#)

## Event Action Rules Notes and Caveats

The following notes and caveats apply to configuring event action rules:

- Rate limiting and blocking are not supported for IPv6 traffic. If a signature is configured with a block or rate limit event action and is triggered by IPv6 traffic, an alert is generated but the action is not carried out.
- Global correlation inspection and the reputation filtering deny features do not support IPv6 addresses. For global correlation inspection, the sensor does not receive or process reputation data for IPv6 addresses. The risk rating for IPv6 addresses is not modified for global correlation inspection. Similarly, network participation does not include event data for attacks from IPv6 addresses. And finally, IPv6 addresses do not appear in the deny list.

- You must preface the event variable with a dollar (\$) sign to indicate that you are using a variable rather than a string.
- Connection blocks and network blocks are not supported on adaptive security appliances. Adaptive security appliances only support host blocks with additional connection information.
- You cannot delete the event action override for deny-packet-inline because it is protected. If you do not want to use that override, set the override-item-status to disabled for that entry.
- Passive OS fingerprinting is enabled by default and the IPS contains a default vulnerable OS list for each signature.

## Understanding Security Policies

You can create multiple security policies and apply them to individual virtual sensors. A security policy is made up of a signature definition policy, an event action rules policy, and an anomaly detection policy. Cisco IPS contains a default signature definition policy called sig0, a default event action rules policy called rules0, and a default anomaly detection policy called ad0. You can assign the default policies to a virtual sensor or you can create new policies. The use of multiple security policies lets you create security policies based on different requirements and then apply these customized policies per VLAN or physical interface.

## Understanding Event Action Rules

Event action rules are a group of settings you configure for the event action processing component of the sensor. These rules dictate the actions the sensor performs when an event occurs. The event action processing component is responsible for the following functions:

- Calculating the risk rating
- Adding event action overrides
- Filtering event action
- Executing the resulting event action
- Summarizing and aggregating events
- Maintaining a list of denied attackers

**Note**

Rate limiting and blocking are not supported for IPv6 traffic. If a signature is configured with a block or rate limit event action and is triggered by IPv6 traffic, an alert is generated but the action is not carried out.

# Signature Event Action Processor

The Signature Event Action Processor coordinates the data flow from the signature event in the Alarm Channel to processing through the Signature Event Action Override, the Signature Event Action Filter, and the Signature Event Action Handler. It consists of the following components:

- Alarm Channel—The unit that represents the area to communicate signature events from the SensorApp inspection path to signature event handling.
- Signature Event Action Override—Adds actions based on the risk rating value. Signature Event Action Override applies to all signatures that fall in the range of the configured risk rating threshold. Each Signature Event Action Override is independent and has a separate configuration value for each action type.
- Signature Event Action Filter—Subtracts actions based on the signature ID, addresses, and risk rating of the signature event. The input to the Signature Event Action Filter is the signature event with actions possibly added by the Signature Event Action Override.



---


**Note** The Signature Event Action Filter can only subtract actions, it cannot add new actions.

---

The following parameters apply to the Signature Event Action Filter:

- Signature ID
  - Subsignature ID
  - Attacker address
  - Attacker port
  - Victim address
  - Victim port
  - Risk rating threshold range
  - Actions to subtract
  - Sequence identifier (optional)
  - Stop-or-continue bit
  - Enable action filter line bit
  - Victim OS relevance or OS relevance
- Signature Event Action Handler—Performs the requested actions. The output from the Signature Event Action Handler is the actions being performed and possibly an evIdsAlert written to the Event Store.

[Figure 7-1 on page 7-4](#) illustrates the logical flow of the signature event through the Signature Event Action Processor and the operations performed on the action for this event. It starts with the signature event with configured action received in the Alarm Channel and flows top to bottom as the signature event passes through the functional components of the Signature Event Action Processor.

**Figure 7-1** Signature Event Through Signature Event Action Processor

132188

**For More Information**

For more information on risk rating, see [Calculating the Risk Rating](#), page 7-13.

# Event Actions

The Cisco IPS supports the following event actions. Most of the event actions belong to each signature engine unless they are not appropriate for that particular engine.

## Alert and Log Actions

- produce-alert—Writes the event to the Event Store as an alert.



**Note** The produce-alert action is not automatic when you enable alerts for a signature. To have an alert created in the Event Store, you must select produce-alert. If you add a second action, you must include produce-alert if you want an alert sent to the Event Store. Also, every time you configure the event actions, a new list is created and it replaces the old list. Make sure you include all the event actions you need for each signature.



**Note** There are other event actions that force a produce-alert. These actions use produce-alert as the vehicle for performing the action. Even if produce-alert is not selected or is filtered, the alert is still produced. The actions are the following: produce-verbose-alert, request-snmp-trap, log-attacker-packets, log-victim-packets, and log-pair-packets.



**Note** A produce-alert event action is added for an event when global correlation has increased the risk rating of an event, and has added either the deny-packet-inline or deny-attacker-inline event action.

- produce-verbose-alert—Includes an encoded dump of the offending packet in the alert. This action causes an alert to be written to the Event Store, even if produce-alert is not selected.
- log-attacker-packets—Starts IP logging on packets that contain the attacker address and sends an alert. This action causes an alert to be written to the Event Store, even if produce-alert is not selected.
- log-victim-packets—Starts IP logging on packets that contain the victim address and sends an alert. This action causes an alert to be written to the Event Store, even if produce-alert is not selected.
- log-pair-packets—Starts IP logging on packets that contain the attacker/victim address pair. This action causes an alert to be written to the Event Store, even if produce-alert is not selected.
- request-snmp-trap—Sends a request to the Notification Application component of the sensor to perform SNMP notification. This action causes an alert to be written to the Event Store, even if produce-alert is not selected. You must have SNMP configured on the sensor to implement this action.

## Deny Actions

- deny-packet-inline (inline only)—Terminates the packet.



**Note** You cannot delete the event action override for deny-packet-inline because it is protected. If you do not want to use that override, set the override-item-status to disabled for that entry.

- deny-connection-inline (inline only)—Terminates the current packet and future packets on this TCP flow.

- deny-attacker-victim-pair-inline (inline only)—Does not transmit this packet and future packets on the attacker/victim address pair for a specified period of time.
- deny-attacker-service-pair-inline (inline only)—Does not transmit this packet and future packets on the attacker address victim port pair for a specified period of time.
- deny-attacker-inline (inline only)—Terminates the current packet and future packets from this attacker address for a specified period of time.

The sensor maintains a list of attackers being denied by the system. To remove an entry from the denied attacker list, you can view the list of attackers and clear the entire list, or you can wait for the timer to expire. The timer is a sliding timer for each entry. Therefore, if attacker A is being denied, but issues another attack, the timer for attacker A is reset and attacker A remains in the denied attacker list until the timer expires. If the denied attacker list is at capacity and cannot add a new entry, the packet is still denied.

- modify-packet-inline (inline only)—Modifies packet data to remove ambiguity about what the end point might do with the packet.



**Note** You cannot use modify-packet-inline as an action when adding event action filters or overrides.

#### Other Actions

- request-block-connection—Sends a request to ARC to block this connection. You must have blocking devices configured to implement this action.



**Note** Connection blocks and network blocks are not supported on adaptive security appliances. Adaptive security appliances only support host blocks with additional connection information.



**Note** IPv6 does not support request-block-connection.

- request-block-host—Sends a request to ARC to block this attacker host. You must have blocking devices configured to implement this action.



**Note** IPv6 does not support request-block-host.

- request-rate-limit—Sends a rate limit request to ARC to perform rate limiting. You must have rate limiting devices configured to implement this action.



**Note** The request-rate-limit action applies to a select set of signatures.



**Note** IPv6 does not support request-rate-limit.

- reset-tcp-connection—Sends TCP resets to hijack and terminate the TCP flow. The reset-tcp-connection action only works on TCP signatures that analyze a single connection. It does not work for sweeps or floods.

### Understanding deny-packet-inline

For signatures that have deny-packet-inline configured as an action or for an event action override that adds deny-packet-inline as an action, the following actions may be taken:

- dropped-packet
- denied-flow
- tcp-one-way-reset-sent

The deny-packet-inline action is represented as a dropped packet action in the alert. When a deny-packet-inline occurs for a TCP connection, it is automatically upgraded to a deny-connection-inline action and seen as a denied flow in the alert. If the IPS denies just one packet, the TCP continues to try to send that same packet again and again, so the IPS denies the entire connection to ensure it never succeeds with the resends.

When a deny-connection-inline occurs, the IPS also automatically sends a TCP one-way reset, which shows up as a TCP one-way reset sent in the alert. When the IPS denies the connection, it leaves an open connection on both the client (generally the attacker) and the server (generally the victim). Too many open connections can result in resource problems on the victim. So the IPS sends a TCP reset to the victim to close the connection on the victim side (usually the server), which conserves the resources of the victim. It also prevents a failover that would otherwise allow the connection to fail over to a different network path and reach the victim. The IPS leaves the attacker side open and denies all traffic from it.

### TCP Reset Differences Between IPS Appliances and ASA IPS Modules

The IPS appliance sends TCP reset packets to both the attacker and victim when reset-tcp-connection is selected. The IPS appliance sends a TCP reset packet only to the victim under the following circumstances:

- When a deny-packet-inline or deny-connection-inline is selected
- When TCP-based signatures and reset-tcp-connection have NOT been selected

In the case of the ASA IPS module, the TCP reset request is sent to the ASA, and the ASA then sends the TCP reset packets. The ASA sends TCP reset packets to both the attacker and victim when the reset-tcp-connection is selected. When deny-packet-inline or deny-connection-inline is selected, the ASA sends the TCP reset packet to either the attacker or victim depending on the configuration of the signature. Signatures configured to swap the attacker and victim when reporting the alert can cause the ASA to send the TCP reset packet to the attacker.

### TCP Normalizer Signature Warning

You receive the following warning if you disable a default-enabled TCP Normalizer signature or remove a default-enabled modify-packet-inline, deny-packet-inline, or deny-connection-inline action:

Use caution when disabling, retiring, or changing the event action settings of a <Sig ID> TCP Normalizer signature for a sensor operating in IPS mode. The TCP Normalizer signature default values are essential for proper operation of the sensor.

If the sensor is seeing duplicate packets, consider assigning the traffic to multiple virtual sensors. If you are having problems with asymmetric or out-of-order TCP packets, consider changing the normalizer mode from strict evasion protection to asymmetric mode protection. Contact Cisco TAC if you require further assistance.

### Understanding deny-packet-inline and reset-tcp-connection

Pay attention to the following when configuring deny-packet-inline and reset-tcp-connection:

- If you want to deny attack packets from reaching the victim and also reset the TCP connection for that flow, then you must configure BOTH deny-packet-inline AND reset-tcp-connection.

- Configuring `reset-tcp-connection` alone only resets the TCP connection but the attack packet is not denied from reaching the victim.
- Configuring `deny-packet-inline` alone only denies the attack packet from reaching the victim. It does not trigger a TCP reset.

#### For More Information

- For procedure for configuring denied attackers, see [Monitoring and Clearing the Denied Attackers List, page 7-37](#).
- For the procedure for configuring the general settings, see [Configuring the General Settings, page 7-34](#).
- For the procedures for configuring blocking devices, see [Chapter 14, “Configuring Attack Response Controller for Blocking and Rate Limiting.”](#)
- For the procedures for configuring SNMP, see [Chapter 15, “Configuring SNMP.”](#)

## Event Action Rules Configuration Sequence

Follow these steps when configuring the event action rules component of the IPS:

1. Create any variables that you want to use in event action filters.
2. Create target value ratings. Assign target value ratings to your network assets so that you can calculate the risk rating.
3. Create overrides to add actions based on the risk rating value. Assign a risk rating to each event action type.
4. Create filters. Assign filters to subtract actions based on the ID, IP addresses, and risk rating of the signature.
5. Create OS mappings. OS mappings are used for the attack relevance rating in the calculation of the risk rating for an alert.
6. Configure the general settings. Specify whether you want to use the summarizer, the meta event generator, or configure denied attacker parameters.

## Working With Event Action Rules Policies

Use the **`service event-action-rules name`** command in service event action rules submode to create an event action rules policy. The values of this event action rules policy are the same as the default event action rules policy, `rules0`, until you edit them. Or you can use the **`copy event-action-rules source_destination`** command in privileged EXEC mode to make a copy of an existing policy and then edit the values of the new policy as needed. Use the **`list event-action-rules-configurations`** command in privileged EXEC mode to list the event action rules policies. Use the **`no service event-action-rules name`** command in global configuration mode to delete an event action rules policy. Use the **`default service event-action-rules name`** command in global configuration mode to reset the event action rules policy to factory settings.



### Working With Event Action Rules Policies

To create, copy, display, edit, and delete event action rules policies, follow these steps:

**Step 1** Log in to the CLI using an account with administrator privileges.

**Step 2** Create an event action rules policy.

```
sensor# configure terminal
sensor(config)# service event-action-rules MyRules
sensor(config-eve)# exit
Apply Changes?[yes]: yes
sensor(config)# exit
sensor#
```

**Step 3** Copy an existing event action rules policy to a new event action rules policy.

```
sensor# copy event-action-rules rules0 rules1
sensor#
```



**Note** You receive an error if the policy already exists or if there is not enough space available for the new policy.

**Step 4** Accept the default event action rules policy values or edit the following parameters.

- a. Add event action rules variables.
- b. Configure event action rules overrides.
- c. Configure event action rules filters.
- d. Configure the event action rules general settings.
- e. Configure the event action rules target value rating.
- f. Configure the event action rules OS identification settings.

**Step 5** Display a list of event action rules policies on the sensor:

```
sensor# list event-action-rules-configurations
Event Action Rules
 Instance Size Virtual Sensor
 rules0 255 vs0
 temp 707 N/A
 MyRules 255 N/A
 rules1 141 vs1
sensor#
```

**Step 6** Delete an event action rules policy.

```
sensor(config)# no service event-action-rules MyRules
sensor(config)#
```



**Note** You cannot delete the default event action rules policy, rules0.

**Step 7** Confirm the event action rules instance has been deleted.

```
sensor# list event-action-rules-configurations
Event Action Rules
 Instance Size Virtual Sensor
 rules0 112 vs0
 rules1 142 N/A
```

```
sensor#
```

**Step 8** Reset an event action rules policy to factory settings.

```
sensor# configure terminal
sensor(config)# default service event-action-rules rules1
sensor(config)#
```

---

#### For More Information

- For the procedure for adding event action rules variables, see [Event Action Variables, page 7-10](#).
- For the procedure for configuring event action rules overrides, see [Configuring Event Action Overrides, page 7-17](#).
- For the procedure for configuring event action rules filters, see [Configuring Event Action Filters, page 7-20](#).
- For the procedure for configuring the general settings, see [Configuring General Settings, page 7-33](#).
- For the procedure for configuring event action rules target value ratings, see [Configuring Target Value Ratings, page 7-13](#).
- For the procedure for configuring OS maps, see [Configuring OS Identifications, page 7-26](#).

## Event Action Variables

This section describes event action variables, and contains the following topics:

- [Understanding Event Action Variables, page 7-10](#)
- [Adding, Editing, and Deleting Event Action Variables, page 7-11](#)

## Understanding Event Action Variables



#### Note

Global correlation inspection and the reputation filtering deny features do not support IPv6 addresses. For global correlation inspection, the sensor does not receive or process reputation data for IPv6 addresses. The risk rating for IPv6 addresses is not modified for global correlation inspection. Similarly, network participation does not include event data for attacks from IPv6 addresses. And finally, IPv6 addresses do not appear in the deny list.



#### Note

Rate limiting and blocking are not supported for IPv6 traffic. If a signature is configured with a block or rate limit event action and is triggered by IPv6 traffic, an alert is generated but the action is not carried out.

You can create event variables and then use those variables in event action filters. When you want to use the same value within multiple filters, use a variable. When you change the value of the variable, any filter that uses that variable is updated with the new value.

**Note**

You must preface the event variable with a dollar (\$) sign to indicate that you are using a variable rather than a string.

Some variables cannot be deleted because they are necessary to the signature system. If a variable is protected, you cannot select it to edit it. You receive an error message if you try to delete protected variables. You can edit only one variable at a time.

**IPv4 Addresses**

When configuring IPv4 addresses, specify the full IP address or ranges or set of ranges:

- 192.0.2.3-192.0.2.26
- 10.90.1.1
- 192.56.10.1-192.56.10.255
- 10.1.1.1-10.2.255.255, 192.0.2.3-192.0.2.26

**IPv6 Addresses**

When configuring IPv6 addresses, use the following format:

```
<XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>-<XXXX:XXXX:XXXX:XXXX:XX
XX:XXXX:XXXX:XXXX>[,<XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>-<XXX
X:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>]
```

**Note**

IPv6 addresses are 128 bits represented in hexadecimal and divided into eight 16-bit groups separated by colons. You can skip the leading zeros and you can represent the zeroed groups in the middle with a double colon (::). You must start the address with the 2001:db8 prefix.

**Timesaver**

If you have an IP address space that applies to your engineering group and there are no Windows systems in that group, and you are not worried about any Windows-based attacks to that group, you could set up a variable to be the IP address space of the engineering group. You could then use this variable to configure a filter that would ignore all Windows-based attacks for this group.

## Adding, Editing, and Deleting Event Action Variables

**Note**

Global correlation inspection and the reputation filtering deny features do not support IPv6 addresses. For global correlation inspection, the sensor does not receive or process reputation data for IPv6 addresses. The risk rating for IPv6 addresses is not modified for global correlation inspection. Similarly, network participation does not include event data for attacks from IPv6 addresses. And finally, IPv6 addresses do not appear in the deny list.

**Note**

Rate limiting and blocking are not supported for IPv6 traffic. If a signature is configured with a block or rate limit event action and is triggered by IPv6 traffic, an alert is generated but the action is not carried out.

Use the **variables** *variable\_name* **address** *ip\_address* command in service event action rules submode to create an IPv4 event action variable. The IPv4 address can be one address, a range, or ranges separated by a comma. Use the **variables** *variable\_name* **ipv6-address** *ip\_address* command in service event action rules submode to create an IPv6 event action variable. Use the **no variables** *variable\_name* command in service event action rules submode to delete an event action variable.

**Note**

IPv6 addresses are 128 bits represented in hexadecimal and divided into eight 16-bit groups separated by colons. You can skip the leading zeros and you can represent the zeroed groups in the middle with a double colon (::). You must start the address with the 2001:db8 prefix.

**Working With Event Action Variables**

To add, delete, and edit event action variables, follow these steps:

**Step 1** Log in to the CLI using an account with administrator privileges.

**Step 2** Enter event action rules submode.

```
sensor# configure terminal
sensor(config)# service event-action-rules rules0
```

**Step 3** Add an IPv4 event action rules variable. The valid values for **address** are A.B.C.D-A.B.C.D [,A.B.C.D-A.B.C.D].

```
sensor(config-eve)# variables variable-ipv4 address 192.0.2.3
```

**Step 4** Add an IPv6 event action rules variable. The valid form for **ipv6-address** is:

```
<XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>-<XXXX:XXXX:XXXX:XXXX:XX
XX:XXXX:XXXX:XXXX>[,<XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>-<XXX
X:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>]
```

```
sensor(config-eve)# variables variable-ipv6 ipv6-address
2001:0db8:3c4d:0015:0000:0000:abcd:ef12
```

**Step 5** Verify that you added the event action rules variable.

```
sensor(config-eve)# show settings
variables (min: 0, max: 256, current: 2)

variableName: variable-ipv6

ipv6-address: 2001:0db8:3c4d:0015:0000:0000:abcd:ef12 default: ::0-FFFF
:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF

variableName: variable-ipv4

address: 192.0.2.3 default: 0.0.0.0-255.255.255.255


```

**Step 6** To edit an event action rules variable, change the IPv6 address to a range.

```
sensor(config-eve)# variables variable-ipv6 ipv6-address
::0-FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF
```

**Step 7** Verify that you edited the event action rules variable.

```
sensor(config-eve)# show settings
variables (min: 0, max: 256, current: 2)

variableName: variable-ipv6
```

```

ipv6-address: ::0-FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF default: ::0
FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF

```

**Step 8** Delete an event action rules variable.

```
sensor(config-eve)# no variables variable-ipv6
```

**Step 9** Verify the event action rules variable you deleted.

```

sensor(config-eve)# show settings
variables (min: 0, max: 256, current: 1)

variableName: variableipv4

address: 192.0.2.3 default: 0.0.0.0-255.255.255.255


```

**Step 10** Exit event action rules submode.

```

sensor(config-eve)# exit
Apply Changes?[yes]:

```

**Step 11** Press **Enter** to apply your changes or enter **no** to discard them.

## Configuring Target Value Ratings

This section describes what risk rating is and how to use it to configure target value ratings. This section contains the following topics:

- [Calculating the Risk Rating, page 7-13](#)
- [Understanding Threat Rating, page 7-15](#)
- [Adding, Editing, and Deleting Target Value Ratings, page 7-15](#)

## Calculating the Risk Rating

A risk rating (RR) is a value between 0 and 100 that represents a numerical quantification of the risk associated with a particular event on the network. The calculation takes into account the value of the network asset being attacked (for example, a particular server), so it is configured on a per-signature basis using the attack severity rating and the signature fidelity rating, and on a per-server basis using the target value rating. The risk rating is calculated from several components, some of which are configured, some collected, and some derived.



### Note

The risk rating is associated with alerts not signatures.

Risk ratings let you prioritize alerts that need your attention. These risk rating factors take into consideration the severity of the attack if it succeeds, the fidelity of the signature, the reputation score of the attacker from the global correlation data, and the overall value of the target host to you. The risk rating is reported in the evIdsAlert.

The following values are used to calculate the risk rating for a particular event:

- **Signature fidelity rating (SFR)**—A weight associated with how well this signature might perform in the absence of specific knowledge of the target. The signature fidelity rating is configured per signature and indicates how accurately the signature detects the event or condition it describes.

Signature fidelity rating is calculated by the signature author on a per-signature basis. The signature author defines a baseline confidence ranking for the accuracy of the signature in the absence of qualifying intelligence on the target. It represents the confidence that the detected behavior would produce the intended effect on the target platform if the packet under analysis were allowed to be delivered. For example, a signature that is written with very specific rules (specific regular expression) has a higher signature fidelity rating than a signature that is written with generic rules.



**Note** The signature fidelity rating does not indicate how bad the detected event may be.

- **Attack severity rating (ASR)**—A weight associated with the severity of a successful exploit of the vulnerability. The attack severity rating is derived from the alert severity parameter (informational, low, medium, or high) of the signature. The attack severity rating is configured per signature and indicates how dangerous the event detected is.



**Note** The attack severity rating does not indicate how accurately the event is detected.

- **Target value rating (TVR)**—A weight associated with the perceived value of the target.  
Target value rating is a user-configurable value (zero, low, medium, high, or mission critical) that identifies the importance of a network asset (through its IP address). You can develop a security policy that is more stringent for valuable corporate resources and looser for less important resources. For example, you could assign a target value rating to the company web server that is higher than the target value rating you assign to a desktop node. In this example, attacks against the company web server have a higher risk rating than attacks against the desktop node. Target value rating is configured in the event action rules policy.
- **Attack relevance rating (ARR)**—A weight associated with the relevancy of the targeted operating system. Attack relevancy rating is a derived value (relevant, unknown, or not relevant), which is determined at alert time. The relevant operating systems are configured per signature.
- **Promiscuous delta (PD)**—A weight associated with the promiscuous delta, which can be subtracted from the overall risk rating in promiscuous mode. Promiscuous delta is in the range of 0 to 30 and is configured per signature.



**Note** If the trigger packet is not inline, the promiscuous delta is subtracted from the rating.

- **Watch list rating (WLR)**—A weight associated with the CSA MC watch list in the range of 0 to 100 (CSA MC only uses the range 0 to 35). If the attacker for the alert is found on the watch list, the watch list rating for that attacker is added to the rating.

Figure 7-2 illustrates the risk rating formula:

**Figure 7-2 Risk Rating Formula**

$$RR = \frac{ASR * TVR * SFR}{10000} + ARR - PD + WLR$$

191016

## Understanding Threat Rating

Threat rating is risk rating that has been lowered by event actions that have been taken. Nonlogging event actions have a threat rating adjustment. The largest threat rating from all the event actions taken is subtracted from the risk rating. The event actions have the following threat ratings:

- deny-attacker-inline—45
- deny-attacker-victim-pair-inline—40
- deny-attacker-service-pair-inline—40
- deny-connection-inline—35
- deny-packet-inline—35
- modify-packet-inline—35
- request-block-host—20
- request-block-connection—20
- reset-tcp-connection—20
- request-rate-limit—20

## Adding, Editing, and Deleting Target Value Ratings



### Note

Global correlation inspection and the reputation filtering deny features do not support IPv6 addresses. For global correlation inspection, the sensor does not receive or process reputation data for IPv6 addresses. The risk rating for IPv6 addresses is not modified for global correlation inspection. Similarly, network participation does not include event data for attacks from IPv6 addresses. And finally, IPv6 addresses do not appear in the deny list.



### Note

Rate limiting and blocking are not supported for IPv6 traffic. If a signature is configured with a block or rate limit event action and is triggered by IPv6 traffic, an alert is generated but the action is not carried out.

You can assign a target value rating to your network assets. The target value rating is one of the factors used to calculate the risk rating value for each alert. You can assign different target value ratings to different targets. Events with a higher risk rating trigger more severe signature event actions.

For IPv4 address, use the **target-value** {**zerovalue** | **low** | **medium** | **high** | **mission-critical**} **target-address** *ip\_address* command in service event action rules submode to add target value ratings for your network assets. The default is medium. Use the **no target-value** {**zerovalue** | **low** | **medium** | **high** | **mission-critical**} command in service event action rules submode to delete target value ratings.

For IPv6 addresses, use the **ipv6-target-value** {**zerovalue** | **low** | **medium** | **high** | **mission-critical**} **ipv6-target-address** *ip\_address* command in service event action rules submode to add target value ratings for your network assets. The default is medium. Use the **no ipv6-target-value** {**zerovalue** | **low** | **medium** | **high** | **mission-critical**} command in service event action rules submode to delete target value ratings.

The following options apply:

- **target-value**—Specifies the IPv4 target value rating:
  - **zerovalue**—No value of this target.
  - **low**—Lower value of this target.
  - **medium**—Normal value of this target (default).
  - **high**—Elevated value of this target.
  - **mission-critical**—Extreme value of this target.
- **no target-value**—Removes the IPv4 target value rating.
- **target-address ip\_address**—Specifies the range set of IP address(es) for IPv4 addresses in the following form: <A.B.C.D>-<A.B.C.D>[,<A.B.C.D>-<A.B.C.D>]
- **ipv6-target-value**—Specifies the IPv6 target value rating:
  - **zerovalue**—No value of this target.
  - **low**—Lower value of this target.
  - **medium**—Normal value of this target (default).
  - **high**—Elevated value of this target.
  - **mission-critical**—Extreme value of this target.
- **no ipv6-target-value**—Removes the IPv6 target value rating.
- **ipv6-target-address ip\_address**—Specifies the range set of IP address(es) for IPv6 addresses in the following form:  
 <XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>-<XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>[,<XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>-<XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>]

### Adding, Editing, and Deleting Target Value Ratings

To add, edit, and delete target value ratings for your network assets, follow these steps:

---

**Step 1** Log in to the CLI using an account with administrator privileges.

**Step 2** Enter event action rules submode.

```
sensor# configure terminal
sensor(config)# service event-action-rules rules1
```

**Step 3** Assign an IPv4 target value rating to the network asset.

```
sensor(config-eve)# target-value mission-critical target-address 192.0.2.0
```

**Step 4** Assign an IPv6 target value rating to the network asset.

```
sensor(config-eve)# ipv6-target-value mission-critical ipv6-target-address
2001:0db8:3c4d:0015:0000:0000:abcd:ef12
```

**Step 5** Verify that you added the target value rating.

```
sensor(config-eve)# show settings

target-value (min: 0, max: 5, current: 1)

target-value-setting: mission-critical
target-address: 192.0.2.0 default: 0.0.0.0-255.255.255.255

```



```

ipv6-target-value (min: 0, max: 5, current: 2)

 ipv6-target-value-setting: mission-critical
 ipv6-target-address: 2001:0db8:3c4d:0015:0000:0000:abcd:ef12 default: ::0-
 FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF

sensor(config-eve)#

```

**Step 6** To edit a target value rating, change the target value rating setting of the asset.

```

sensor(config-eve)# target-value low target-address 192.0.2.0

```

**Step 7** Verify that you edited the target value rating.

```

sensor(config-eve)# show settings

target-value (min: 0, max: 5, current: 1)

 target-value-setting: low
 target-address: 192.0.2.0 default: 0.0.0.0-255.255.255.255

```

**Step 8** Delete the target value rating.

```

sensor(config-eve)# no ipv6-target-value mission-critical

```

**Step 9** Verify that you deleted the target value rating.

```

sensor(config-eve)# show settings

ipv6-target-value (min: 0, max: 5, current: 0)


```

**Step 10** Exit event action rules submode.

```

sensor(config-rul)# exit
Apply Changes?[yes]:

```

**Step 11** Press **Enter** to apply your changes or enter **no** to discard them.

## Configuring Event Action Overrides

This section describes event action overrides, and contains the following topics:

- [Understanding Event Action Overrides, page 7-17](#)
- [Adding, Editing, Enabling, and Disabling Event Action Overrides, page 7-18](#)

## Understanding Event Action Overrides

You can add an event action override to change the actions associated with an event based on the risk rating of that event. Event action overrides are a way to add event actions globally without having to configure each signature individually. Each event action has an associated risk rating range. If a signature event occurs and the risk rating for that event falls within the range for an event action, that

action is added to the event. For example, if you want any event with a risk rating of 85 or more to generate an SNMP trap, you can set the risk rating range for request-snmp-trap to 85-100. If you do not want to use action overrides, you can disable the entire event action override component.

**Note**

Connection blocks and network blocks are not supported on adaptive security appliances. Adaptive security appliances only support host blocks with additional connection information.

## Adding, Editing, Enabling, and Disabling Event Action Overrides

Use the **overrides** {**request-block-connection** | **request-block-host** | **deny-attacker-inline** | **deny-packet-inline** | **deny-attacker-service-pair-inline** | **deny-attacker-victim-pair-inline** | **deny-connection-inline** | **log-attacker-packets** | **log-victim-packets** | **log-pair-packets** | **reset-tcp-connection** | **produce-alert** | **produce-verbose-alert** | **request-rate-limit** | **request-snmp-trap**} command in service event action rules submode to configure the parameters of event action overrides. Use the **no overrides** command in service event action rules submode to delete the parameters of event action overrides.

**Note**

You cannot delete the event action override for deny-packet-inline because it is protected. If you do not want to use that override, set the override-item-status to disabled for that entry.

Configure the override event actions, then the risk rating range, then enable or disable the override. The following options apply:

- **no overrides**—Removes an entry or selection setting.
- **override-item-status** {**enabled** | **disabled**}—Enables or disables the use of this override item. The default is enabled.
- **risk-rating-range**—Specifies the range of risk rating values for this override item. The default is 0 to 100.
- **show**—Displays system settings and/or history information.

### Configuring Event Action Overrides

To add event action overrides, follow these steps:

**Step 1** Log in to the CLI using an account with administrator privileges.

**Step 2** Enter event action rules submode.

```
sensor# configure terminal
sensor(config)# service event-action-rules rules0
sensor(config-eve)#
```

**Step 3** Assign the action for the override:

- Deny packets from the source IP address of the attacker.
 

```
sensor(config-eve)# overrides deny-attacker-inline
sensor(config-eve-ove)#
```
- Do not transmit the single packet causing the alert.
 

```
sensor(config-eve)# overrides deny-packet-inline
sensor(config-eve-ove)#
```

- Do not transmit packets on the specified TCP connection.

```
sensor(config-eve)# overrides deny-connection-inline
sensor(config-eve-ove)#
```

- Send TCP RST packets to terminate the connection.

```
sensor(config-eve)# overrides reset-tcp-connection
sensor(config-eve-ove)#
```

- Request a block of the connection.

```
sensor(config-eve)# overrides request-block-connection
sensor(config-eve-ove)#
```

- Request a block of the attacker host.

```
sensor(config-eve)# overrides request-block-host
sensor(config-eve-ove)#
```

- Log the packets from the attacker IP address.

```
sensor(config-eve)# overrides log-attacker-packets
sensor(config-eve-ove)#
```

- Log the packets from the victim IP address.

```
sensor(config-eve)# overrides log-victim-packets
sensor(config-eve-ove)#
```

- Log packets from both the attacker and victim IP addresses.

```
sensor(config-eve)# overrides log-pair-packets
sensor(config-eve-ove)#
```

- Write an alert to Event Store.

```
sensor(config-eve)# overrides produce-alert
sensor(config-eve-ove)#
```

- Write verbose alerts to Event Store.

```
sensor(config-eve)# overrides produce-verbose-alert
sensor(config-eve-ove)#
```

- Write events that request an SNMP trap to the Event Store.

```
sensor(config-eve)# overrides request-snmp-trap
sensor(config-eve-ove)#
```

**Step 4** Configure the risk rating for this override item. The default risk rating range is 0 to 100. Set it to a different value, such as 85 to 100.

```
sensor(config-eve-ove)# risk-rating-range 85-100
```

**Step 5** Enable or disable the use of this override item. The default is enabled.

```
sensor(config-eve-ove)# override-item-status {enabled | disabled}
```

**Step 6** Verify the settings.

```
sensor(config-eve-ove)# exit
sensor(config-eve)# show settings
action-to-add: deny-attacker-inline

override-item-status: Enabled default: Enabled
risk-rating-range: 85-100 default: 0-100
```

**Step 7** Edit the risk rating of an event action override.

```
sensor(config-eve)# overrides deny-attacker-inline
sensor(config-eve-ove)# risk-rating 95-100
```

**Step 8** Verify that you edited the event action override.

```
sensor(config-eve-ove)# exit
sensor(config-eve)# show settings

overrides (min: 0, max: 14, current: 1)

override-item-status: Enabled <defaulted>
risk-rating-range: 95-100 default: 0-100

```

**Step 9** Delete the event action override.

```
sensor(config-eve)# no overrides deny-attacker-inline
sensor(config-eve-ove)#
```

**Step 10** Verify that you deleted the event action override.

```
sensor(config-eve-ove)# exit
sensor(config-eve)# show settings
overrides (min: 0, max: 14, current: 1)

action-to-add: deny-attacker-inline

override-item-status: Enabled <defaulted>
risk-rating-range: 95 default: 0-100

override-item-status: Enabled <defaulted>
risk-rating-range: 90-100 <defaulted>


```

**Step 11** Exit event action rules submode.

```
sensor(config-eve)# exit
Apply Changes:[yes]:
```

**Step 12** Press **Enter** to apply your changes or enter **no** to discard them.

#### For More Information

For a detailed description of all the event actions, see [Event Actions, page 7-5](#).

## Configuring Event Action Filters

This section describes event action filters, and contains the following topics:

- [Understanding Event Action Filters, page 7-21](#)
- [Configuring Event Action Filters, page 7-21](#)

## Understanding Event Action Filters

**Note**

Global correlation inspection and the reputation filtering deny features do not support IPv6 addresses. For global correlation inspection, the sensor does not receive or process reputation data for IPv6 addresses. The risk rating for IPv6 addresses is not modified for global correlation inspection. Similarly, network participation does not include event data for attacks from IPv6 addresses. And finally, IPv6 addresses do not appear in the deny list.

**Note**

Rate limiting and blocking are not supported for IPv6 traffic. If a signature is configured with a block or rate limit event action and is triggered by IPv6 traffic, an alert is generated but the action is not carried out.

Event action filters are processed as an ordered list and you can move filters up or down in the list. Filters let the sensor perform certain actions in response to the event without requiring the sensor to perform all actions or remove the entire event. Filters work by removing actions from an event. A filter that removes all actions from an event effectively consumes the event.

**Note**

When filtering sweep signatures, we recommend that you do not filter the destination addresses. If there are multiple destination addresses, only the last address is used for matching the filter.

**Caution**

Event action filters based on source and destination IP addresses do not function for the Sweep engine, because they do not filter as regular signatures. To filter source and destination IP addresses in sweep alerts, use the source and destination IP address filter parameters in the Sweep engine signatures.

## Configuring Event Action Filters

**Note**

Global correlation inspection and the reputation filtering deny features do not support IPv6 addresses. For global correlation inspection, the sensor does not receive or process reputation data for IPv6 addresses. The risk rating for IPv6 addresses is not modified for global correlation inspection. Similarly, network participation does not include event data for attacks from IPv6 addresses. And finally, IPv6 addresses do not appear in the deny list.

**Note**

Rate limiting and blocking are not supported for IPv6 traffic. If a signature is configured with a block or rate limit event action and is triggered by IPv6 traffic, an alert is generated but the action is not carried out.

You can configure event action filters to remove specific actions from an event or to discard an entire event and prevent further processing by the sensor. You can use event action variables that you defined to group addresses for your filters.

**Note**

You must preface the event variable with a dollar sign (\$) to indicate that you are using a variable rather than a string. Otherwise, you receive the `Bad source and destination error`.

Use the **filters** {**edit** | **insert** | **move**} **name1** [**begin** | **end** | **inactive** | **before** | **after**] command in service event action rules submode to set up event action filters. The following options apply:

- **actions-to-remove**—Specifies the event actions to remove for this filter item.
- **attacker-address-range**—Specifies the range set of IPv4 attacker address(es) for this item (for example, 192.0.2.0-192.0.2.254,192.3.2.0-192.3.2.254).

**Note**

The second IP address in the range must be greater then or equal to the first IP address. If you do not specify an attacker address range, all IPv4 attacker addresses are matched.

- **attacker-port-range**—Specifies the range set of attacker port(s) for this item (for example, 147-147,8000-10000).
- **default**—Sets the value back to the system default setting.
- **deny-attacker-percentage**—Specifies the percentage of packets to deny for deny attacker features. The valid range is 0 to 100. The default is 100.
- **filter-item-status** {**enabled** | **disabled**}—Enables or disables the use of this filter item.
- **ipv6-attacker-address-range**—Specifies the range set of IPv6 attacker address(es) for this item (for example,  
`<XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>-<XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>`  
`XXXX:XXXX:XXXX:XXXX>[,<XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>-<XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>]`.

**Note**

The second IPv6 address in the range must be greater than or equal to the first IPv6 address. If you do not specify an IPv6 attacker address range, all IPv6 attacker addresses are matched.

- **ipv6-victim-address-range**—Specifies the range set of victim address(es) for this item (for example,  
`<XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>-<XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>`  
`XXXX:XXXX:XXXX:XXXX>[,<XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>-<XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX:XXXX>]`.

**Note**

The second IPv6 address in the range must be greater than or equal to the first IPv6 address. If you do not specify an IPv6 victim address range, all IPv6 victim addresses are matched.

- **no**—Removes an entry or selection setting.
- **os-relevance**—Specifies the event OS relevance for this filter:
  - **relevant**—Specifies that the event is relevant to the target OS.
  - **not-relevant**—Specifies that the event is not relevant to the target OS.
  - **unknown**—It is unknown whether the event is relevant to the target OS.
- **risk-rating-range**—Specifies the range of risk rating values for this filter item.

- **signature-id-range**—Specifies the range set of signature ID(s) for this item (for example, 1000-2000,3000-3000).
- **stop-on-match {true | false}**—Specifies to continue evaluating filters or stop when this filter item is matched.
- **subsignature-id-range**—Specifies the range set of subsignature ID(s) for this item (for example, 0-2,5-5).
- **user-comment** —Lets you add your comments about this filter item.
- **victim-address-range**—Specifies the range set of victim address(es) for this item (for example, 10.20.1.0-10.20.1.255,10.20.5.0-10.20.5.255).



**Note** The second IP address in the range must be greater than or equal to the first IP address. If you do not specify a victim address range, all IPv4 attacker addresses are matched.

- **victim-port-range**—Specifies the range set of victim port(s) for this item (for example, 147-147,8000-10000).

### Configuring Event Action Filters

To configure event action filters, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter event action rules submode.
- ```
sensor# configure terminal
sensor(config)# service event-action-rules rules1
sensor(config-eve)#
```
- Step 3** Create the filter name. Use **name1**, **name2**, and so forth to name your event action filters. Use the **begin** | **end** | **inactive** | **before** | **after** keywords to specify where you want to insert the filter.
- ```
sensor(config-eve)# filters insert name1 begin
```
- Step 4** Specify the values for this filter:
- Specify the signature ID range. The default is 900 to 65535.
- ```
sensor(config-eve-fil)# signature-id-range 1000-1005
```
- Specify the subsignature ID range. The default is 0 to 255.
- ```
sensor(config-eve-fil)# subsignature-id-range 1-5
```
- Specify the attacker address range for IPv4 or IPv6.
- ```
sensor(config-eve-fil)# attacker-address-range 192.0.2.3-192.0.2.26
sensor(config-eve-fil)# ipv6-attacker-address-range
2001:0db8:3c4d:0015:0000:0000:abcd:ef12
```
- Specify the victim address range for IPv4 or IPv6.
- ```
sensor(config-eve-fil)# victim-address-range 192.56.10.1-192.56.10.255
sensor(config-eve-fil)# ipv6-victim-address-range ::0-FFFF:FFFF:FFFF:FFFF:FFFF:
FFFF:FFFF:FFFF
```
- Specify the victim port range. The default is 0 to 65535.
- ```
sensor(config-eve-fil)# victim-port-range 0-434
```

- f. Specify the OS relevance. The default is 0 to 100.

```
sensor(config-eve-fil)# os-relevance relevant
```

- g. Specify the risk rating range. The default is 0 to 100.

```
sensor(config-eve-fil)# risk-rating-range 85-100
```

- h. Specify the actions to remove.

```
sensor(config-eve-fil)# actions-to-remove reset-tcp-connection
```

- i. If you are filtering a deny action, set the percentage of deny actions you want. The default is 100.

```
sensor(config-eve-fil)# deny-attacker-percentage 90
```

- j. Specify the status of the filter to either disabled or enabled. The default is enabled.

```
sensor(config-eve-fil)# filter-item-status {enabled | disabled}
```

- k. Specify the stop on match parameter. **True** tells the sensor to stop processing filters if this item matches. **False** tells the sensor to continue processing filters even if this item matches.

```
sensor(config-eve-fil)# stop-on-match {true | false}
```

- l. Add any comments you want to use to explain this filter.

```
sensor(config-eve-fil)# user-comment NEW FILTER
```

Step 5 Verify the settings for the filter.

```
sensor(config-eve-fil)# show settings
```

```
NAME: name1
```

```
-----
signature-id-range: 1000-10005 default: 900-65535
subsignature-id-range: 1-5 default: 0-255
attacker-address-range: 192.0.2.3-192.0.2.26 default: 0.0.0.0-255.255.255.255
victim-address-range: 192.56.10.1-192.56.10.255 default: 0.0.0.0-255.255.255.255
  ipv6-attacker-address-range: 2001:0db8:3c4d:0015:0000:0000:abcd:ef12 default:
::0-FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF
  ipv6-victim-address-range: ::0-FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF default:
::0-FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF
attacker-port-range: 0-65535 <defaulted>
victim-port-range: 1-343 default: 0-65535
risk-rating-range: 85-100 default: 0-100
actions-to-remove: reset-tcp-connection default:
deny-attacker-percentage: 90 default: 100
filter-item-status: Enabled default: Enabled
stop-on-match: True default: False
user-comment: NEW FILTER default:
os-relevance: relevant default: relevant|not-relevant|unknown
-----
```

```
senor(config-eve-fil)#
```

Step 6 Edit an existing filter.

```
sensor(config-eve)# filters edit name1
```

Step 7 Edit the parameters (see Steps 4a through 4l).

Step 8 Move a filter up or down in the filter list.

```
sensor(config-eve-fil)# exit
```

```
sensor(config-eve)# filters move name5 before name1
```

Step 9 Verify that you have moved the filters.


```

sensor(config-eve-fil)# exit
sensor(config-eve)# show settings
-----
filters (min: 0, max: 4096, current: 5 - 4 active, 1 inactive)
-----
ACTIVE list-contents
-----
NAME: name5
-----
signature-id-range: 900-65535 <defaulted>
subsignature-id-range: 0-255 <defaulted>
attacker-address-range: 0.0.0.0-255.255.255.255 <defaulted>
victim-address-range: 0.0.0.0-255.255.255.255 <defaulted>
attacker-port-range: 0-65535 <defaulted>
victim-port-range: 0-65535 <defaulted>
risk-rating-range: 0-100 <defaulted>
actions-to-remove: <defaulted>
filter-item-status: Enabled <defaulted>
stop-on-match: False <defaulted>
user-comment: <defaulted>
-----
NAME: name1
-----
signature-id-range: 900-65535 <defaulted>
subsignature-id-range: 0-255 <defaulted>
attacker-address-range: 0.0.0.0-255.255.255.255 <defaulted>
victim-address-range: 0.0.0.0-255.255.255.255 <defaulted>
attacker-port-range: 0-65535 <defaulted>
victim-port-range: 0-65535 <defaulted>
risk-rating-range: 0-100 <defaulted>
actions-to-remove: <defaulted>
filter-item-status: Enabled <defaulted>
stop-on-match: False <defaulted>
user-comment: <defaulted>
-----
NAME: name2
-----
signature-id-range: 900-65535 <defaulted>
subsignature-id-range: 0-255 <defaulted>
attacker-address-range: 0.0.0.0-255.255.255.255 <defaulted>
victim-address-range: 0.0.0.0-255.255.255.255 <defaulted>
attacker-port-range: 0-65535 <defaulted>
victim-port-range: 0-65535 <defaulted>
risk-rating-range: 0-100 <defaulted>
actions-to-remove: <defaulted>
filter-item-status: Enabled <defaulted>
stop-on-match: False <defaulted>
user-comment: <defaulted>
-----
INACTIVE list-contents
-----
sensor(config-eve)#

```

Step 10 Move a filter to the inactive list.

```
sensor(config-eve)# filters move name1 inactive
```

Step 11 Verify that the filter has been moved to the inactive list.

```

sensor(config-eve-fil)# exit
sensor(config-eve)# show settings
-----
INACTIVE list-contents
-----
NAME: name1
-----
signature-id-range: 900-65535 <defaulted>
subsignature-id-range: 0-255 <defaulted>
attacker-address-range: 0.0.0.0-255.255.255.255 <defaulted>
victim-address-range: 0.0.0.0-255.255.255.255 <defaulted>
attacker-port-range: 0-65535 <defaulted>
victim-port-range: 0-65535 <defaulted>
risk-rating-range: 0-100 <defaulted>
actions-to-remove: <defaulted>
filter-item-status: Enabled <defaulted>
stop-on-match: False <defaulted>
user-comment: <defaulted>
-----
sensor(config-eve)#

```

Step 12 Exit event action rules submode.

```

sensor(config-eve)# exit
Apply Changes?[yes]:

```

Step 13 Press **Enter** to apply your changes or enter **no** to discard them.

For More Information

- For the procedure for configuring event action variables, see [Adding, Editing, and Deleting Event Action Variables, page 7-11](#).
- For a detailed description of the event actions, see [Event Actions, page 7-5](#).

Configuring OS Identifications

This section describes OS identifications and how to configure OS maps, and contains the following topics:

- [Understanding Passive OS Fingerprinting, page 7-26](#)
- [Passive OS Fingerprinting Configuration Considerations, page 7-28](#)
- [Adding, Editing, Deleting, and Moving Configured OS Maps, page 7-28](#)
- [Displaying and Clearing OS Identifications, page 7-32](#)

Understanding Passive OS Fingerprinting

Passive OS fingerprinting lets the sensor determine the OS that hosts are running. The sensor analyzes network traffic between hosts and stores the OS of these hosts with their IP addresses. The sensor inspects TCP SYN and SYNACK packets exchanged on the network to determine the OS type.

The sensor then uses the OS of the target host OS to determine the relevance of the attack to the victim by computing the attack relevance rating component of the risk rating. Based on the relevance of the attack, the sensor may alter the risk rating of the alert for the attack and/or the sensor may filter the alert for the attack. You can then use the risk rating to reduce the number of false positive alerts (a benefit in IDS mode) or definitively drop suspicious packets (a benefit in IPS mode). Passive OS fingerprinting also enhances the alert output by reporting the victim OS, the source of the OS identification, and the relevance to the victim OS in the alert.

Passive OS fingerprinting consists of three components:

- **Passive OS learning**—Passive OS learning occurs as the sensor observes traffic on the network. Based on the characteristics of TCP SYN and SYNACK packets, the sensor makes a determination of the OS running on the host of the source IP address.
- **User-configurable OS identification**—You can configure OS host maps, which take precedence over learned OS maps.
- **Computation of attack relevance rating and risk rating**—The sensor uses OS information to determine the relevance of the attack signature to the targeted host. The attack relevance is the attack relevance rating component of the risk rating value for the attack alert. The sensor uses the OS type reported in the host posture information imported from the CSA MC to compute the attack relevance rating.

There are three sources of OS information. The sensor ranks the sources of OS information in the following order:

1. **Configured OS maps**—OS maps you enter. Configured OS maps reside in the event action rules policy and can apply to one or many virtual sensors.

**Note**

You can specify multiple operating systems for the same IP address. The last one in the list is the operating system that is matched.

2. **Imported OS maps**—OS maps imported from an external data source. Imported OS maps are global and apply to all virtual sensors.

**Note**

Currently the CSA MC is the only external data source.

3. **Learned OS maps**—OS maps observed by the sensor through the fingerprinting of TCP packets with the SYN control bit set. Learned OS maps are local to the virtual sensor that sees the traffic.

When the sensor needs to determine the OS for a target IP address, it consults the configured OS maps. If the target IP address is not in the configured OS maps, the sensor looks in the imported OS maps. If the target IP address is not in the imported OS maps, the sensor looks in the learned OS maps. If it cannot find it there, the sensor treats the OS of the target IP address as unknown.

**Note**

Passive OS fingerprinting is enabled by default and the IPS contains a default vulnerable OS list for each signature.

Passive OS Fingerprinting Configuration Considerations

You do not have to configure passive OS fingerprinting for it to function. IPS provides a default vulnerable OS list for each signature and passive analysis is enabled by default.

You can configure the following aspects of passive OS fingerprinting:

- Define OS maps—We recommend configuring OS maps to define the identity of the OS running on critical systems. It is best to configure OS maps when the OS and IP address of the critical systems are unlikely to change.
- Limit the attack relevance rating calculation to a specific IP address range—This limits the attack relevance rating calculations to IP addresses on the protected network.
- Import OS maps—Importing OS maps provides a mechanism for accelerating the learning rate and fidelity of the OS identifications made through passive analysis. If you have an external product interface, such as the CSA MC, you can import OS identifications from it.
- Define event action rules filters using the OS relevance value of the target—This provides a way to filter alerts solely on OS relevance.
- Disable passive analysis—Stops the sensor from learning new OS maps.
- Edit signature vulnerable OS lists—The vulnerable OS list specifies what OS types are vulnerable to each signature. The default, general-os, applies to all signatures that do not specify a vulnerable OS list.

Adding, Editing, Deleting, and Moving Configured OS Maps

Use the **os-identifications** command in the service event action rules submode to configure OS host mappings, which take precedence over learned OS mappings. You can add, edit, and delete configured OS maps. You can move them up and down in the list to change the order in which the sensor computes the attack relevance rating and risk rating for that particular IP address and OS type combination.

You can also move them up and down in the list to change the order in which the sensor resolves the OS associated with a particular IP address. Configured OS mappings allow for ranges, so for network 192.168.1.0/24 an administrator might define the following (Table 7-1):

Table 7-1 Example Configured OS Mapping

| IP Address Range Set | OS |
|---------------------------------------|---------|
| 192.168.1.1 | IOS |
| 192.168.1.2-192.168.1.10,192.168.1.25 | UNIX |
| 192.168.1.1-192.168.1.255 | Windows |

More specific mappings should be at the beginning of the list. Overlap in the IP address range sets is allowed, but the entry closest to the beginning of the list takes precedence. The following options apply:

- **calc-arr-for-ip-range**—Calculates the attack relevance rating for victims in this range. The value is <A.B.C.D>-<A.B.C.D>[,<A.B.C.D>-<A.B.C.D>], for example, 10.20.1.0-10.20.1.255,10.20.5.0-10.20.5.255).

**Note**

The second IP address in the range must be greater than or equal to the first IP address.

- **configured-os-map {edit | insert | move} name1[begin | end | inactive | before | after]**—Specifies a collection of administrator-defined mappings of IP addresses to OS IDs (configured OS mappings take precedence over imported and learned OS mappings).
- **ip**—Specifies the host IP address (or addresses) running the specified OS. The value is <A.B.C.D>-<A.B.C.D>[,<A.B.C.D>-<A.B.C.D>], for example, 10.20.1.0-10.20.1.255,10.20.5.0-10.20.5.255.



Note The second IP address in the range must be greater than or equal to the first IP address.

- **os**—Specifies the OS type the host (or hosts) is running:
 - **general-os**—All OS types
 - **ios**—Variants of Cisco IOS
 - **mac-os**—Variants of the Apple System OS prior to OS X
 - **netware**—Netware
 - **other**—Any Other OS
 - **unix**—Variants of UNIX
 - **aix**—Variants of AIX
 - **bsd**—Variants of BSD
 - **hp-ux**—Variants of HP-UX
 - **irix**—Variants of IRIX
 - **linux**—Variants of Linux
 - **solaris**—Variants of Solaris
 - **windows**—Variants of Microsoft Windows
 - **windows-nt-2k-xp**—Variants of NT, 2000, and XP
 - **win-nt**—Specific variants of Windows NT
 - **unknown**—Unknown OS
- **default**—Sets the value back to the system default setting.
- **no**—Removes an entry or selection setting.
- **passive-traffic-analysis {enabled | disabled}**—Enables/disables passive OS fingerprinting analysis.

Configuring OS Maps

To configure OS maps, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter event action rules submode.

```
sensor# configure terminal
sensor(config)# service event-action-rules rules1
sensor(config-eve)#
```

- Step 3** Create the OS map. Use **name1**, **name2**, and so forth to name your OS maps. Use the **begin** | **end** | **inactive** | **before** | **after** keywords to specify where you want to insert the filter.

```
sensor(config-eve)# os-identification
sensor(config-eve-os)# configured-os-map insert name1 begin
sensor(config-eve-os-con)#
```

- Step 4** Specify the values for this OS map:

- a. Specify the host IP address.

```
sensor(config-eve-os-con)# ip 192.0.2.0-192.0.2.255
```

- b. Specify the host OS type.

```
sensor(config-eve-os-con)# os unix
```



Caution

You can specify multiple operating systems for the same IP address. The last one in the list is the operating system that is matched.

- Step 5** Verify the settings for the OS map.

```
sensor(config-eve-os-con)# show settings
NAME: name1
-----
ip: 192.0.2.0-192.0.2.255 default:
os: unix
-----
sensor(config-eve-os-con)#
```

- Step 6** Specify the attack relevance rating range for the IP address.

```
sensor(config-eve-os-con)# exit
sensor(config-eve-os)# calc-arr-for-ip-range 192.0.2.1 to 192.0.2.25
```

- Step 7** Enable passive OS fingerprinting.

```
sensor(config-eve-os)# passive-traffic-analysis enabled
```

- Step 8** Edit an existing OS map.

```
sensor(config-eve-os)# configured-os-map edit name1
sensor(config-eve-os-con)#
```

- Step 9** Edit the parameters (see Steps 4 through 7).

- Step 10** Move an OS map up or down in the OS maps list.

```
sensor(config-eve-os-con)# exit
sensor(config-eve-os)# configured-os-map move name5 before name1
```

- Step 11** Verify that you have moved the OS maps.

```
sensor(config-eve-os)# show settings
os-identification
-----
calc-arr-for-ip-range: 192.0.2.1-192.0.2.25 default: 0.0.0.0-255.255.255.255
configured-os-map (ordered min: 0, max: 50, current: 2 - 2 active, 0 inactive)
-----
ACTIVE list-contents
-----
NAME: name2
-----
ip: 192.0.2.33 default:
```

```

os: aix
-----
NAME: name1
-----
ip: 192.0.2.0-192.0.2.255 default:
os: unix
-----
-----
passive-traffic-analysis: Enabled default: Enabled
-----
ips-ssp(config-eve-os)#

```

Step 12 Move an OS map to the inactive list.

```
sensor(config-eve-os)# configured-os-map move name1 inactive
```

Step 13 Verify that the filter has been moved to the inactive list.

```

sensor(config-eve-os)# show settings
os-identification
-----
calc-arr-for-ip-range: 192.0.2.33 default: 0.0.0.0-255.255.255.255
configured-os-map (ordered min: 0, max: 50, current: 2 - 1 active, 1 inactive)
-----
ACTIVE list-contents
-----
NAME: name2
-----
ip: 192.0.2.33 default:
os: aix
-----
-----
INACTIVE list-contents
-----
NAME: name1
-----
ip: 192.0.2.0-192.0.2.255 default:
os: unix
-----
-----
passive-traffic-analysis: Enabled default: Enabled
--MORE--#

```

Step 14 Delete an OS map.

```
sensor(config-eve-os)# no configured-os-map name2
```

Step 15 Verify that the OS map has been deleted.

```

sensor(config-eve-os)# show settings
os-identification
-----
calc-arr-for-ip-range: 192.0.2.33 default: 0.0.0.0-255.255.255.255
configured-os-map (ordered min: 0, max: 50, current: 1 - 0 active, 1 inactive)
-----
INACTIVE list-contents
-----
NAME: name1
-----
ip: 192.0.2.0-192.0.2.255 default:
os: unix

```

```

-----
-----
passive-traffic-analysis: Enabled default: Enabled
-----
ips-ssp(config-eve-os)#

```

Step 16 Exit event action rules submode.

```

sensor(config-eve-os)# exit
sensor(config-eve)# exit
Apply Changes:[yes]:

```

Step 17 Press **Enter** to apply your changes or enter **no** to discard them.

Displaying and Clearing OS Identifications

Use the **show os-identification** [*virtual-sensor*] **learned** [*ip-address*] command in EXEC mode to display OS IDs associated with IP addresses that were learned by the sensor through passive analysis.

Use the **clear os-identification** [*virtual-sensor*] **learned** [*ip-address*] command in EXEC mode to delete OS IDs associated with IP addresses that were learned by the sensor through passive analysis.

When you specify an IP address, only the OS identification for the specified IP address is displayed or cleared. If you specify a virtual sensor, only the OS identifications for the specified sensor is displayed or cleared. If you specify an IP address without a virtual sensor, the IP address is displayed or cleared on all virtual sensors.

The following options apply:

- *virtual-sensor*—(Optional) Specifies the learned addresses of the virtual sensor that should be displayed or cleared.
- *ip-address*—(Optional) Specifies the IP address to query or clear. The sensor displays or clears the OS ID mapped to the specified IP address.

Displaying and Clearing OS Identifications

To display and clear OS IDs, follow these steps:

Step 1 Log in to the CLI using an account with administrator or operator privileges.



Note An account with viewer privileges can display OS IDs.

Step 2 Display the learned OS IDs associated with a specific IP address.

```

sensor# show os-identification learned 192.0.2.0
Virtual Sensor vs0:
  10.1.1.12 windows
sensor# show os-identification learned
Virtual Sensor vs0:
  10.1.1.12 windows
Virtual Sensor vs1:
  10.1.0.1  unix
  10.1.0.2  windows
  10.1.0.3  windows
sensor#

```


Step 3 Clear the learned OS IDs for a specific IP address on all virtual sensors.

```
sensor# clear os-identification learned 192.0.2.0
```

Step 4 Verify that the OS IDs have been cleared.

```
sensor# show statistics os-identification
Statistics for Virtual Sensor vs0
  OS Identification
    Configured
    Imported
    Learned
Statistics for Virtual Sensor vs1
  OS Identification
    Configured
    Imported
    Learned
sensor#
```

Configuring General Settings

This section describes the general settings, and contains the following topics:

- [Understanding Event Action Summarization, page 7-33](#)
- [Understanding Event Action Aggregation, page 7-33](#)
- [Configuring the General Settings, page 7-34](#)

Understanding Event Action Summarization

Summarization decreases the volume of alerts sent out from the sensor by providing basic aggregation of events into a single alert. Special parameters are specified for each signature and they influence the handling of the alerts. Each signature is created with defaults that reflect a preferred normal behavior. However, you can tune each signature to change this default behavior within the constraints for each engine type.

The nonalert-generating actions (deny, block, TCP reset) go through the filters for each signature event unsummarized. The alert-generating actions are not performed on these summarized alerts; instead the actions are applied to the one summary alert and then put through the filters.

If you select one of the other alert-generating actions and do not have it filtered out, the alert is created even if you do not select produce-alert. To prevent alerts from being created, you must have all alert-generating actions filtered out.

Summarization and event actions are processed after the Meta engine has processed the component events. This lets the sensor watch for suspicious activity transpiring over a series of events.

Understanding Event Action Aggregation

Basic aggregation provides two operating modes. The simple mode involves configuring a threshold number of hits for a signature that must be met before the alert is sent. A more advanced mode is timed-interval counting. In this mode, the sensor tracks the number of hits per second and only sends

alerts when that threshold is met. In this example, a hit is a term used to describe an event, which is basically an alert, but it is not sent out of the sensor as an alert until the threshold number of hits has been exceeded.

You can choose from the following summarization options:

- **fire-all**—Fires an alert each time the signature is triggered. If the threshold is set for summarization, alerts are fired for each execution until summarization occurs. After summarization starts, only one alert every summary interval fires for each address set. Alerts for other address sets are either all seen or separately summarized. The signature reverts to fire all mode after a period of no alerts for that signature.
- **summary**—Fires an alert the first time a signature is triggered, and then additional alerts for that signature are summarized for the duration of the summary interval. Only one alert every summary interval should fire for each address set. If the global summary threshold is reached, the signature goes into global summarization mode.
- **global-summarization**—Fires an alert for every summary interval. Signatures can be preconfigured for global summarization.
- **fire-once**—Fires an alert for each address set. You can upgrade this mode to global summarization mode.

Configuring the General Settings

Use the following commands in service event action rules submode to configure general event action rules settings:

- **global-block-timeout** —Specifies the number of minutes to block a host or connection. The valid range is 0 to 10000000. The default is 30 minutes.
- **global-deny-timeout**—Specifies the number of seconds to deny attackers inline. The valid range is 0 to 518400. The default is 3600.
- **global-filters-status {enabled | disabled}**—Enables or disables the use of the filters. The default is enabled.
- **global-metaevent-status {enabled | disabled}**—Enables or disables the use of the Meta Event Generator. The default is enabled.
- **global-overrides-status {enabled | disabled}**—Enables or disables the use of the overrides. The default is enabled.
- **global-summarization-status {enabled | disabled}**—Enables or disables the use of the summarizer. The default is enabled.
- **max-denied-attackers**—Limits the number of denied attackers possible in the system at any one time. The valid range is 0 to 100000000. The default is 10000.

Configuring Event Action General Settings

To configure event action general settings, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter event action rules submode.

```
sensor# configure terminal
sensor(config)# service event-action-rules rules0
```

- Step 3** Enter general submode.
- ```
sensor(config)# general
```
- Step 4** Enable or disable the meta event generator. The default is enabled.
- ```
sensor(config-eve-gen)# global-metaevent-status {enabled | disabled}
```
- Step 5** Enable or disable the summarizer. The default is enabled.
- ```
sensor(config-eve-gen)# global-summarization-status {enabled | disabled}
```
- Step 6** Configure the denied attackers inline event action:
- Limit the number of denied attackers in the system at any given time. The default is 1000.
- ```
sensor(config-eve-gen)# max-denied-attackers 100
```
- Configure the amount of seconds to deny attackers in the system. The default is 3600 seconds.
- ```
sensor(config-eve-gen)# global-deny-timeout 1000
```
- Step 7** Configure the number of minutes to block a host or a connection. The default is 30 minutes.
- ```
sensor(config-eve-gen)# global-block-timeout 20
```
- Step 8** Enable or disable any overrides that you have set up. The default is enabled.
- ```
sensor(config-eve-gen)# global-overrides-status {enabled | disabled}
```
- Step 9** Enable or disable any filters that you have set up. The default is enabled.
- ```
sensor(config-eve-gen)# global-filters-status {enabled | disabled}
```
- Step 10** Verify the settings for general submode.
- ```
sensor(config-eve-gen)# show settings
general

global-overrides-status: Enabled default: Enabled
global-filters-status: Enabled default: Enabled
global-summarization-status: Enabled default: Enabled
global-metaevent-status: Enabled default: Enabled
global-deny-timeout: 1000 default: 3600
global-block-timeout: 20 default: 30
max-denied-attackers: 100 default: 10000

sensor(config-eve-gen)#
```
- Step 11** Exit event action rules submode.
- ```
sensor(config-eve-gen)# exit
sensor(config-eve)# exit
Apply Changes:[yes]:
```
- Step 12** Press **Enter** to apply your changes or enter **no** to discard them.
-

Configuring the Denied Attackers List

This section describes the denied attackers list and how to add, clear, and monitor the list. It contains the following topics:

- [Adding a Deny Attacker Entry to the Denied Attackers List, page 7-36](#)
- [Monitoring and Clearing the Denied Attackers List, page 7-37](#)

Adding a Deny Attacker Entry to the Denied Attackers List

Use the **deny attacker** [*virtual-sensor name*] [*ip-address attacker-ip-address*] | **victim** *victim-ip-address* | **port** *port-number*] command to add a single deny attacker entry to the list of denied attackers. Use the **no** form of the command to delete the deny attacker entry from the list.

The following options apply:

- *name*—(Optional) Specifies the name of the virtual sensor to which the deny attackers entry should be added.
- *attacker-ip-address*—Specifies the attacker IP address.
- *victim-ip-address*—(Optional) Specifies the victim IP address.
- *port-number*—(Optional) Specifies the victim port number. The valid range is 0 to 65535.

Adding Entries to the Denied Attacker List

To add a deny attacker entry to the list of denied attackers, follow these steps:

Step 1 Log in to the CLI using an account with administrator or operator privileges.

Step 2 Add a deny attacker entry with an IP address of 192.0.2.0.

```
sensor# deny attacker ip-address 192.0.2.0
Warning: Executing this command will add deny attacker address on all virtual sensors.
Continue? [yes]:
```

Step 3 Enter **yes** to add this deny attacker entry for all virtual sensors.

Step 4 Add a deny attacker entry to a specific virtual sensor.

```
sensor# deny attacker virtual-sensor vs0 ip-address 192.0.2.0
```

Step 5 Remove the deny attacker entry from the list.

```
sensor# no deny attacker ip-address 10.1.1.1
Warning: Executing this command will delete this address from the list of attackers being
denied by all virtual sensors.
Continue? [yes]:
```

Step 6 Enter **yes** to remove the deny attacker entry from the list.



Note To immediately stop denying attackers, you must use the **clear denied-attackers** command to clear the denied attackers list.

For More Information

For the procedure for clearing denied attackers permanently from the denied attackers list, see [Monitoring and Clearing the Denied Attackers List, page 7-37](#).

Monitoring and Clearing the Denied Attackers List

Use the **show statistics denied-attackers** command to display the list of denied attackers. Use the **clear denied-attackers** [*virtual_sensor*] [*ip-address ip_address*] command to delete the denied attackers list and clear the virtual sensor statistics.

If your sensor is configured to operate in inline mode, the traffic is passing through the sensor. You can configure signatures to deny packets, connections, and attackers while in inline mode, which means that single packets, connections, and specific attackers are denied, that is, not transmitted, when the sensor encounters them. When the signature fires, the attacker is denied and placed in a list. As part of sensor administration, you may want to delete the list or clear the statistics in the list.

The following options apply:

- *virtual_sensor*—(Optional) Specifies the virtual sensor whose denied attackers list should be cleared.
- *ip_address*—(Optional) Specifies the IP address to clear.

Displaying and Deleting Denied Attackers

To display the list of denied attackers and delete the list and clear the statistics, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Display the list of denied IP addresses. The statistics show that there are two IP addresses being denied at this time.
- ```
sensor# show statistics denied-attackers
Denied Attackers and hit count for each.
 10.20.4.2 = 9
 10.20.5.2 = 5
```
- Step 3** Delete the denied attackers list.
- ```
sensor# clear denied-attackers
Warning: Executing this command will delete all addresses from the list of attackers
currently being denied by the sensor.
Continue with clear? [yes]:
```
- Step 4** Enter **yes** to clear the list.
- Step 5** Delete the denied attackers list for a specific virtual sensor.
- ```
sensor# clear denied-attackers vs0
Warning: Executing this command will delete all addresses from the list of attackers being
denied by virtual sensor vs0.
Continue with clear? [yes]:
```
- Step 6** Enter **yes** to clear the list.
- Step 7** Remove a specific IP address from the denied attackers list for a specific virtual sensor.
- ```
sensor# clear denied-attackers vs0 ip-address 192.0.2.0
Warning: Executing this command will delete ip address 192.0.2.0 from the list of
attackers being denied by virtual sensor vs0.
Continue with clear? [yes]:
```

Step 8 Enter **yes** to clear the list.

Step 9 Verify that you have cleared the list. You can use the **show statistics denied-attackers** or **show statistics virtual-sensor** command.

```
sensor# show statistics denied-attackers
Denied Attackers and hit count for each.
Denied Attackers and hit count for each.
Statistics for Virtual Sensor vs0
  Denied Attackers with percent denied and hit count for each.

  Denied Attackers with percent denied and hit count for each.

Statistics for Virtual Sensor vs1
  Denied Attackers with percent denied and hit count for each.

  Denied Attackers with percent denied and hit count for each.
sensor#

sensor# show statistics virtual-sensor
Virtual Sensor Statistics
  Statistics for Virtual Sensor vs0
    Name of current Signature-Definition instance = sig0
    Name of current Event-Action-Rules instance = rules0
    List of interfaces monitored by this virtual sensor = mypair
    Denied Address Information
      Number of Active Denied Attackers = 0
      Number of Denied Attackers Inserted = 2
      Number of Denied Attackers Total Hits = 287
      Number of times max-denied-attackers limited creation of new entry = 0
      Number of exec Clear commands during uptime = 1
    Denied Attackers and hit count for each.
```

Step 10 Clear only the statistics.

```
sensor# show statistics virtual-sensor clear
```

Step 11 Verify that you have cleared the statistics. The statistics have all been cleared except for the Number of Active Denied Attackers and Number of exec Clear commands during uptime categories. It is important to know if the list has been cleared.

```
sensor# show statistics virtual-sensor
Virtual Sensor Statistics
  Statistics for Virtual Sensor vs0
    Name of current Signature-Definition instance = sig0
    Name of current Event-Action-Rules instance = rules0
    List of interfaces monitored by this virtual sensor = mypair
    Denied Address Information
      Number of Active Denied Attackers = 2
      Number of Denied Attackers Inserted = 0
      Number of Denied Attackers Total Hits = 0
      Number of times max-denied-attackers limited creation of new entry = 0
      Number of exec Clear commands during uptime = 1
    Denied Attackers and hit count for each.
      10.20.2.5 = 0
      10.20.5.2 = 0
```

Monitoring Events

This section describes how to display and clear events from the Event Store, and contains the following topics:

- [Displaying Events, page 7-39](#)
- [Clearing Events from Event Store, page 7-42](#)

Displaying Events



Note

The Event Store has a fixed size of 30 MB for all platforms.



Note

Events are displayed as a live feed. To cancel the request, press **Ctrl-C**.

Use the **show events** [{**alert** [informational] [low] [medium] [high] [**include-traits** *traits*] [**exclude-traits** *traits*] [**min-threat-rating** *min-rr*] [**max-threat-rating** *max-rr*] | **error** [warning] [error] [fatal] | **NAC** | **status**}] [*hh:mm:ss* [*month* *day* [*year*]]] | **past** *hh:mm:ss*] command to display events from Event Store. Events are displayed beginning at the start time. If you do not specify a start time, events are displayed beginning at the current time. If you do not specify an event type, all events are displayed.

The following options apply:

- **alert**—Displays alerts. Provides notification of some suspicious activity that may indicate an attack is in process or has been attempted. Alert events are generated by the Analysis Engine whenever a signature is triggered by network activity. If no level is selected (informational, low, medium, or high), all alert events are displayed.
- **include-traits**—Displays alerts that have the specified traits.
- **exclude-traits**—Does not display alerts that have the specified traits.
- **traits**—Specifies the trait bit position in decimal (0 to 15).
- **min-threat-rating**—Displays events with a threat rating above or equal to this value. The default is 0. The valid range is 0 to 100.
- **max-threat-rating**—Displays events with a threat rating below or equal to this value. The default is 100. The valid range is 0 to 100.
- **error**—Displays error events. Error events are generated by services when error conditions are encountered. If no level is selected (warning, error, or fatal), all error events are displayed.
- **NAC**—Displays the ARC (block) requests.



Note

The ARC is formerly known as NAC. This name change has not been completely implemented throughout the IDM, the IME, and the CLI for Cisco IPS 7.1.

- **status**—Displays status events.
- **past**—Displays events starting in the past for the specified hours, minutes, and seconds.
- *hh:mm:ss*—Specifies the hours, minutes, and seconds in the past to begin the display.

**Note**

The **show events** command continues to display events until a specified event is available. To exit, press **Ctrl-C**.

Displaying Events

To display events from the Event Store, follow these steps:

Step 1 Log in to the CLI.

Step 2 Display all events starting now. The feed continues showing all events until you press **Ctrl-C**.

```
sensor# show events
evError: eventId=1041472274774840147 severity=warning vendor=Cisco
  originator:
    hostId: sensor2
    appName: cidwebserver
    appInstanceId: 12075
  time: 2011/01/07 04:41:45 2011/01/07 04:41:45 UTC
  errorMessage: name=errWarning received fatal alert: certificate_unknown

evError: eventId=1041472274774840148 severity=error vendor=Cisco
  originator:
    hostId: sensor2
    appName: cidwebserver
    appInstanceId: 351
  time: 2011/01/07 04:41:45 2011/01/07 04:41:45 UTC
  errorMessage: name=errTransport WebSession::sessionTask(6) TLS connection exception: handshake incomplete.
```

Step 3 Display the block requests beginning at 10:00 a.m. on February 9, 2011.

```
sensor# show events NAC 10:00:00 Feb 9 2011
evShunRqst: eventId=1106837332219222281 vendor=Cisco
  originator:
    deviceName: Sensor1
    appName: NetworkAccessControllerApp
    appInstanceId: 654
  time: 2011/02/09 10:33:31 2011/08/09 13:13:31
  shunInfo:
    host: connectionShun=false
    srcAddr: 11.0.0.1
    destAddr:
    srcPort:
    destPort:
    protocol: numericType=0 other
    timeoutMinutes: 40
  evAlertRef: hostId=esendHost 123456789012345678
sensor#
```

Step 4 Display errors with the warning level starting at 10:00 a.m. on February 9, 2011.

```
sensor# show events error warning 10:00:00 Feb 9 2011
evError: eventId=1041472274774840197 severity=warning vendor=Cisco
  originator:
    hostId: sensor
    appName: cidwebserver
    appInstanceId: 12160
  time: 2011/01/07 04:49:25 2011/01/07 04:49:25 UTC
  errorMessage: name=errWarning received fatal alert: certificate_unknown
```


Step 5 Display alerts from the past 45 seconds.

```

sensor# show events alert past 00:00:45

evIdsAlert: eventId=1109695939102805307 severity=medium vendor=Cisco
originator:
  hostId: sensor
  appName: sensorApp
  appInstanceId: 367
time: 2011/03/02 14:15:59 2011/03/02 14:15:59 UTC
signature: description=Nachi Worm ICMP Echo Request id=2156 version=S54
  subsigId: 0
  sigDetails: Nachi ICMP
interfaceGroup:
vlan: 0
participants:
  attacker:
    addr: locality=OUT 10.89.228.202
  target:
    addr: locality=OUT 10.89.150.185
riskRatingValue: 70
interface: fe0_1
protocol: icmp

evIdsAlert: eventId=1109695939102805308 severity=medium vendor=Cisco
originator:
--MORE--

```

Step 6 Display events that began 30 seconds in the past.

```

sensor# show events past 00:00:30
evStatus: eventId=1041526834774829055 vendor=Cisco
originator:
  hostId: sensor
  appName: mainApp
  appInstanceId: 2215
time: 2011/01/08 02:41:00 2011/01/08 02:41:00 UTC
controlTransaction: command=getVersion successful=true
description: Control transaction response.
requestor:
  user: cids
  application:
    hostId: 64.101.182.101
    appName: -cidcli
    appInstanceId: 2316

evStatus: eventId=1041526834774829056 vendor=Cisco
originator:
  hostId: sensor
  appName: login(pam_unix)
  appInstanceId: 2315
time: 2011/01/08 02:41:00 2011/01/08 02:41:00 UTC
syslogMessage:
  description: session opened for user cisco by cisco(uid=0)

```

Clearing Events from Event Store

Use the **clear events** command to clear the Event Store. To clear events from the Event Store, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Clear the Event Store.

```
sensor# clear events
```

```
Warning: Executing this command will remove all events currently stored in the event store.
```

```
Continue with clear? []:
```

Step 3 Enter **yes** to clear the events.



Defining Signatures

This chapter describes how to define and create signatures. It contains the following sections:

- [Signature Definition Notes and Caveats, page 8-1](#)
- [Understanding Policies, page 8-1](#)
- [Working With Signature Definition Policies, page 8-2](#)
- [Understanding Signatures, page 8-3](#)
- [Configuring Signature Variables, page 8-4](#)
- [Configuring Signatures, page 8-6](#)
- [Creating Custom Signatures, page 8-40](#)

Signature Definition Notes and Caveats

The following notes and caveats apply to defining signatures:

- You must preface signature variables with a dollar (\$) sign to indicate that you are using a variable rather than a string.
- We recommend that you do NOT change the promiscuous delta setting for a signature.
- The parameters **tcp-3-way-handshake-required** and **tcp-reassembly-mode** only impact sensors inspecting traffic in promiscuous mode, not inline mode. To configure asymmetric options for sensors inspecting inline traffic, use the **inline-TCP-evasion-protection-mode** parameter.
- A custom signature can affect the performance of your sensor. Test the custom signature against a baseline sensor performance for your network to determine the overall impact of the signature.

Understanding Policies

You can create multiple security policies and apply them to individual virtual sensors. A security policy is made up of a signature definition policy, an event action rules policy, and an anomaly detection policy. Cisco IPS contains a default signature definition policy called sig0, a default event action rules policy called rules0, and a default anomaly detection policy called ad0. You can assign the default policies to a virtual sensor or you can create new policies. The use of multiple security policies lets you create security policies based on different requirements and then apply these customized policies per VLAN or physical interface.

Working With Signature Definition Policies

Use the **service signature-definition** *name* command in service signature definition mode to create a signature definition policy. The values of this signature definition policy are the same as the default signature definition policy, sig0, until you edit them.

Or you can use the **copy signature-definition** *source_destination* command in privileged EXEC mode to make a copy of an existing policy and then edit the values of the new policy as needed.

Use the **list signature-definition-configurations** command in privileged EXEC mode to list the signature definition policies.

Use the **no service signature-definition** *name* command in global configuration mode to delete a signature definition policy. Use the **default service signature-definition** *name* command in global configuration mode to reset the signature definition policy to factory settings.

Creating, Copying, Editing, and Deleting Signature Definition Policies

To create, copy, edit, and delete signature definition policies, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Create a signature definition policy.

```
sensor# configure terminal
sensor(config)# service signature-definition MySig
Editing new instance MySig.
sensor(config-sig)# exit
Apply Changes?[yes]: yes
sensor(config)# exit
```

Step 3 Or copy an existing signature definition policy to a new signature definition policy.

```
sensor# copy signature-definition sig0 sig1
sensor#
```



Note You receive an error if the policy already exists or if there is not enough space available for the new policy.

Step 4 Accept the default signature definition policy values or edit the following parameters:

- a. Add signature definition variables.
- b. Configure the general signature options.

Step 5 Display a list of signature definition policies on the sensor.

```
sensor# list signature-definition-configurations
Signature Definition
  Instance   Size   Virtual Sensor
  sig0       255    vs0
  temp       707    N/A
  MySig      255    N/A
  sig1       141    vs1
sensor#
```

Step 6 Delete a signature definition policy.

```
sensor# configure terminal
sensor(config)# no service signature-definition MySig
sensor(config)# exit
```

```
sensor#
```



Note You cannot delete the default signature definition policy, sig0.

Step 7 Confirm the signature definition policy has been deleted.

```
sensor# list signature-definition-configurations
Signature Definition
  Instance   Size   Virtual Sensor
  sig0       255   vs0
  temp       707   N/A
  sig1       141   vs1
sensor#
```

Step 8 Reset a signature definition policy to factory settings.

```
sensor# configure terminal
sensor(config)# default service signature-definition sig1
sensor(config)#
```

For More Information

- For the procedure for adding signature variables, see [Configuring Signature Variables, page 8-4](#).
- For the procedure for configuring the general settings, see [Configuring Signatures, page 8-6](#).

Understanding Signatures

Attacks or other misuses of network resources can be defined as network intrusions. Sensors that use a signature-based technology can detect network intrusions. A signature is a set of rules that your sensor uses to detect typical intrusive activity, such as DoS attacks. As sensors scan network packets, they use signatures to detect known attacks and respond with actions that you define.

The sensor compares the list of signatures with network activity. When a match is found, the sensor takes an action, such as logging the event or sending an alert. Sensors let you modify existing signatures and define new ones.

Signature-based intrusion detection can produce false positives because certain normal network activity can be misinterpreted as malicious activity. For example, some network applications or operating systems may send out numerous ICMP messages, which a signature-based detection system might interpret as an attempt by an attacker to map out a network segment. You can minimize false positives by tuning your signatures.

To configure a sensor to monitor network traffic for a particular signature, you must enable the signature. By default, the most critical signatures are enabled when you install the signature update. When an attack is detected that matches an enabled signature, the sensor generates an alert, which is stored in the Event Store of the sensor. The alerts, as well as other events, may be retrieved from the Event Store by web-based clients. By default the sensor logs all Informational alerts or higher.

Some signatures have subsignatures, that is, the signature is divided into subcategories. When you configure a subsignature, changes made to the parameters of one subsignature apply only to that subsignature. For example, if you edit signature 3050 subsignature 1 and change the severity, the severity change applies to only subsignature 1 and not to 3050 2, 3050 3, and 3050 4.

The Cisco IPS contains over 10,000 built-in default signatures. You cannot rename or delete signatures from the list of built-in signatures, but you can retire signatures to remove them from the sensing engine. You can later activate retired signatures; however, this process requires the sensing engines to rebuild their configuration, which takes time and could delay the processing of traffic. You can tune built-in signatures by adjusting several signature parameters. Built-in signatures that have been modified are called tuned signatures.

**Note**

We recommend that you retire any signatures that you are not using. This improves sensor performance.

You can create signatures, which are called custom signatures. Custom signature IDs begin at 60000. You can configure them for several things, such as matching of strings on UDP connections, tracking of network floods, and scans. Each signature is created using a signature engine specifically designed for the type of traffic being monitored.

Configuring Signature Variables

This section describes signature variables, and contains the following topics:

- [Understanding Signature Variables, page 8-4](#)
- [Creating Signature Variables, page 8-4](#)

Understanding Signature Variables

When you want to use the same value within multiple signatures, use a variable. When you change the value of a variable, that variable is updated in all signatures in which it appears. This saves you from having to change the variable repeatedly as you configure signatures.

**Note**

You must preface signature variables with a dollar (\$) sign to indicate that you are using a variable rather than a string.

Some variables cannot be deleted because they are necessary to the signature system. If a variable is protected, you cannot select it to edit it. You receive an error message if you try to delete protected variables. You can edit only one variable at a time.

Creating Signature Variables

Use the **variables** command in the signature definition submode to create signature variables. The following options apply:

- **variable_name**—Identifies the name assigned to this variable. A valid name can only contain numbers or letters. You can also use a hyphen (-) or underscore (_).
- **ip-addr-range**—Specifies the system-defined variable for grouping IP addresses. The valid values are: A.B.C.D-A.B.C.D[,A.B.C.D-A.B.C.D]
- **web-ports**—Specifies the system-defined variable for ports to look for HTTP traffic. To designate multiple port numbers for a single variable, place a comma between the entries. For example, 80, 3128, 8000, 8010, 8080, 8888, 24326.

Adding, Editing, and Deleting Signature Variables

To add, edit, and delete signature variables, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator or operator privileges.
- Step 2** Enter signature definition submode.
- ```
sensor# configure terminal
sensor(config)# service signature-definition sig1
```
- Step 3** Create a signature variable for a group of IP addresses.
- ```
sensor(config-sig)# variables IPADD ip-addr-range 10.1.1.1-10.1.1.24
```
- Step 4** Edit the signature variable for web ports. WEBPORTS has a predefined set of ports where web servers are running, but you can edit the value. This variable affects all signatures that have web ports. The default is 80, 3128, 8000, 8010, 8080, 8888, 24326.
- ```
sensor(config-sig)# variables WEBPORTS web-ports 80,3128,8000
```
- Step 5** Verify the changes.
- ```
sensor(config-sig)# show settings
variables (min: 0, max: 256, current: 2)
-----
variable-name: IPADD
-----
ip-addr-range: 10.1.1.1-10.1.1.24
-----
<protected entry>
variable-name: WEBPORTS
-----
web-ports: 80,3128,8000 default: 80-80,3128-3128,8000-8000,8010-8010,80
80-8080,8888-8888,24326-24326
-----
```
- Step 6** Delete a variable.
- ```
sensor(config-sig)# no variables IPADD
```
- Step 7** Verify the variable has been deleted.
- ```
sensor(config-sig)# show settings
variables (min: 0, max: 256, current: 1)
-----
<protected entry>
variable-name: WEBPORTS
-----
web-ports: 80,3128,8000 default: 80-80,3128-3128,8000-8000,8010-8010,80
80-8080,8888-8888,24326-24326
-----
```
- Step 8** Exit signature definition submode.
- ```
sensor(config-sig)# exit
Apply Changes?[yes]:
```
- Step 9** Press **Enter** to apply the changes or enter **no** to discard them.
-

# Configuring Signatures

This section describes how to configure signature parameters, and contains the following topics:

- [Signature Definition Options, page 8-6](#)
- [Configuring Alert Frequency, page 8-7](#)
- [Configuring Alert Severity, page 8-9](#)
- [Configuring the Event Counter, page 8-10](#)
- [Configuring Signature Fidelity Rating, page 8-12](#)
- [Configuring the Status of Signatures, page 8-13](#)
- [Configuring the Vulnerable OSEs for a Signature, page 8-14](#)
- [Assigning Actions to Signatures, page 8-15](#)
- [Configuring AIC Signatures, page 8-17](#)
- [Configuring IP Fragment Reassembly, page 8-28](#)
- [Configuring TCP Stream Reassembly, page 8-31](#)
- [Configuring IP Logging, page 8-39](#)

## Signature Definition Options

The following options apply to configuring the general parameters of a specific signature:

- **alert-frequency**—Sets the summary options for grouping alerts.
- **alert-severity**—Sets the severity of the alert.
- **engine**—Specifies the signature engine. You can assign actions when you are in the engine submode.
- **event-counter**—Sets the event count.
- **promisc-delta**—Specifies the delta value used to determine the seriousness of the alert.



### Caution

We recommend that you do NOT change the promiscuous delta setting for a signature.

Promiscuous delta lowers the risk rating of certain alerts in promiscuous mode. Because the sensor does not know the attributes of the target system and in promiscuous mode cannot deny packets, it is useful to lower the prioritization of promiscuous alerts (based on the lower risk rating) so the administrator can focus on investigating higher risk rating alerts.

In inline mode, the sensor can deny the offending packets and they never reach the target host, so it does not matter if the target was vulnerable. The attack was not allowed on the network and so we do not subtract from the risk rating value.

Signatures that are not service, OS, or application specific have 0 for the promiscuous delta. If the signature is specific to an OS, service, or application, it has a promiscuous delta of 5, 10, or 15 calculated from 5 points for each category.

- **sig-description**—Your description of the signature.
- **sig-fidelity-rating**—Specifies the rating of the fidelity of signature.
- **status**—Sets the status of the signature to enabled or retired.



- **vulnerable-os**—Specifies the list of OS types that are vulnerable to this attack signature.

#### For More Information

- For the procedure for configuring alert frequency, see [Configuring Alert Frequency, page 8-7](#).
- For more information about signature engines, see [Appendix B, “Signature Engines.”](#)
- For the procedure for assigning actions, see [Assigning Actions to Signatures, page 8-15](#).
- For the procedure for configuring event counts, see [Configuring the Event Counter, page 8-10](#).
- For the procedure for configuring the signature fidelity rating, see [Configuring Signature Fidelity Rating, page 8-12](#).
- For the procedure for enabling and disabling signatures, see [Configuring the Status of Signatures, page 8-13](#).
- For the procedure for configuring vulnerable OSES, see [Configuring the Vulnerable OSES for a Signature, page 8-14](#).

## Configuring Alert Frequency

Use the **alert-frequency** command in signature definition submode to configure the alert frequency for a signature. The **alert-frequency** command specifies how often the sensor alerts you when this signature is firing.

The following options apply:

- **sig\_id**—Identifies the unique numerical value assigned to this signature. This value lets the sensor identify a particular signature. The value is 1000 to 65000.
- **subsig\_id**—Identifies the unique numerical value assigned to this subsignature. A subsignature ID is used to identify a more granular version of a broad signature. The value is 0 to 255.
- **summary-mode**—Specifies the way you want the sensor to group the alerts:
  - **fire-all**—Fires an alert on all events.
  - **fire-once**—Fires an alert only once.
  - **global-summarize**—Summarizes an alert so that it only fires once regardless of how many attackers or victims.
  - **summarize**—Summarize all the alerts.
- **specify-summary-threshold {yes | no}**—Enables summary threshold mode:
  - **summary-threshold**—Specifies the minimum number of hits the sensor must receive before sending a summary alert for this signature. The value is 0 to 65535.
  - **summary-interval**—Specifies the time in seconds used in each summary alert. The value is 1 to 1000.
- **summary-key**—Specifies the storage type on which to summarize this signature:
  - **Axxx**—Attacker address.
  - **Axxb**—Attacker address and victim port.
  - **AxBx**—Attacker and victim addresses.
  - **AaBb**—Attacker and victim addresses and ports.
  - **xxBx**—Victim address.

- **specify-global-summary-threshold {yes | no}**—(Optional) Enables global summary threshold mode:
  - **global-summary-threshold**—Specifies the threshold number of events to take alert in to global summary. The value is 1 to 65535.

### Configuring Alert Frequency

To configure the alert frequency parameters of a signature, follow these steps:

**Step 1** Log in to the CLI using an account with administrator or operator privileges.

**Step 2** Enter signature definition submode.

```
sensor# configure terminal
sensor(config)# service signature-definition sig1
```

**Step 3** Specify the signature you want to configure.

```
sensor(config-sig)# signatures 9000 0
```

**Step 4** Enter alert frequency submode.

```
sensor(config-sig-sig)# alert-frequency
```

**Step 5** Specify the alert frequency of this signature:

- a. Configure the summary mode to, for example, fire once.

```
sensor(config-sig-sig-ale)# summary-mode fire-once
sensor(config-sig-sig-ale-fir)# specify-global-summary-threshold yes
sensor(config-sig-sig-ale-fir-yes)# global-summary-threshold 3000
sensor(config-sig-sig-ale-fir-yes)# summary-interval 5000
```

- b. Specify the summary key.

```
sensor(config-sig-sig-ale-fir-yes)# exit
sensor(config-sig-sig-ale-fir)# summary-key AxBx
```

- c. Verify the settings.

```
sensor(config-sig-sig-ale-fir)# show settings
fire-once

summary-key: AxBx default: Axxx
specify-global-summary-threshold

yes

global-summary-threshold: 3000 default: 120
summary-interval: 5000 default: 15

sensor(config-sig-sig-ale-fir)#
```

**Step 6** Exit alert-frequency submode.

```
sensor(config-sig-sig-ale-fir)# exit
sensor(config-sig-sig-ale)# exit
sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:
```

**Step 7** Press **Enter** to apply the changes or enter **no** to discard them.

## Configuring Alert Severity

Use the **alert-severity** command in signature definition submode to configure the severity of a signature. The following options apply:

- **sig\_id**—Identifies the unique numerical value assigned to this signature. This value lets the sensor identify a particular signature. The value is 1000 to 65000.
- **subsig\_id**—Identifies the unique numerical value assigned to this subsignature. A subsignature ID is used to identify a more granular version of a broad signature. The value is 0 to 255.
- **alert-severity**—Specifies the severity of the alert:
  - **high**—Dangerous alert.
  - **medium**—Medium level alert (default).
  - **low**—Low level alert.
  - **informational**—Informational alert.

### Configuring Alert Severity

To configure the alert severity, follow these steps:

**Step 1** Log in to the CLI using an account with administrator or operator privileges.

**Step 2** Enter signature definition submode.

```
sensor# configure terminal
sensor(config)# service signature-definition sig1
```

**Step 3** Specify the signature you want to configure.

```
sensor(config-sig)# signatures 9000 0
```

**Step 4** Assign the alert severity.

```
sensor(config-sig-sig)# alert-severity medium
```

**Step 5** Verify the settings.

```
sensor(config-sig-sig)# show settings
<protected entry>
sig-id: 9000
subsig-id: 0

alert-severity: medium default: medium
sig-fidelity-rating: 75 <defaulted>
promisc-delta: 0 <defaulted>
sig-description

sig-name: Back Door Probe (TCP 12345) <defaulted>
sig-string-info: SYN to TCP 12345 <defaulted>
sig-comment: <defaulted>
alert-traits: 0 <defaulted>
release: 40 <defaulted>

vulnerable-os: general-os <defaulted>
```

```

engine

 atomic-ip

 event-action: produce-alert <defaulted>
 fragment-status: any <defaulted>
 specify-l4-protocol

--MORE--

```

**Step 6** Exit signatures submode.

```

sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:

```

**Step 7** Press **Enter** to apply the changes or enter **no** to discard them.

---

## Configuring the Event Counter

Use the **event-counter** command in signature definition submode to configure how the sensor counts events. For example, you can specify that you want the sensor to send an alert only if the same signature fires 5 times for the same address set.

The following options apply:

- **event-count**—Specifies the number of times an event must occur before an alert is generated. The valid range is 1 to 65535. The default is 1.
- **event-count-key**—Specifies the storage type on which to count events for this signature:
  - **Axxx**—Attacker address
  - **AxBx**—Attacker and victim addresses
  - **Axxb**—Attacker address and victim port
  - **xxBx**—Victim address
  - **AaBb**—Attacker and victim addresses and ports
- **specify-alert-interval [yes | no]**—Enables alert interval:
  - **alert-interval**—Specifies the time in seconds before the event count is reset. The default is 60.

### Configuring the Event Counter

To configure event counter, follow these steps:

---

**Step 1** Log in to the CLI using an account with administrator or operator privileges.

**Step 2** Enter signature definition submode.

```

sensor# configure terminal
sensor(config)# service signature-definition sig1

```

**Step 3** Specify the signature for which you want to configure event counter.

```

sensor(config-sig)# signatures 9000 0

```

**Step 4** Enter event counter submode.

```
sensor(config-sig-sig)# event-counter
```

**Step 5** Specify how many times an event must occur before an alert is generated.

```
sensor(config-sig-sig-eve)# event-count 2
```

**Step 6** Specify the storage type on which you want to count events for this signature.

```
sensor(config-sig-sig-eve)# event-count-key AxBx
```

**Step 7** (Optional) Enable alert interval.

```
sensor(config-sig-sig-eve)# specify-alert-interval yes
```

**Step 8** (Optional) Specify the amount of time in seconds before the event count should be reset.

```
sensor(config-sig-sig-eve-yes)# alert-interval 30
```

**Step 9** Verify the settings.

```
sensor(config-sig-sig-eve-yes)# exit
sensor(config-sig-sig-eve)# show settings
event-counter

event-count: 2 default: 1
event-count-key: AxBx default: Axxx
specify-alert-interval

yes

alert-interval: 30 default: 60

sensor(config-sig-sig-eve)#
```

**Step 10** Exit signatures submode.

```
sensor(config-sig-sig-eve)# exit
sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:
```

**Step 11** Press **Enter** to apply the changes or enter **no** to discard them.

---

## Configuring Signature Fidelity Rating

Use the **sig-fidelity-rating** command in signature definition submode to configure the signature fidelity rating for a signature. The following option applies:

- **sig-fidelity-rating**—Identifies the weight associated with how well this signature might perform in the absence of specific knowledge of the target. The valid value is 0 to 100.

### Configuring the Signature Fidelity Rating

To configure the signature fidelity rating for a signature, follow these steps:

---

**Step 1** Log in to the CLI using an account with administrator or operator privileges.

**Step 2** Enter signature definition submode.

```
sensor# configure terminal
sensor(config)# service signature-definition sig0
```

**Step 3** Specify the signature you want to configure.

```
sensor(config-sig)# signatures 12000 0
```

**Step 4** Specify the signature fidelity rating for this signature.

```
sensor(config-sig-sig)# sig-fidelity-rating 50
```

**Step 5** Verify the settings.

```
sensor(config-sig-sig)# show settings
<protected entry>
sig-id: 12000
subsig-id: 0

alert-severity: low <defaulted>
sig-fidelity-rating: 50 default: 85
promisc-delta: 15 <defaulted>
sig-description

sig-name: Gator Spyware Beacon <defaulted>
sig-string-info: /download/ User-Agent: Gator <defaulted>
sig-comment: <defaulted>
alert-traits: 0 <defaulted>
release: 71 <defaulted>

```

**Step 6** Exit signatures submode.

```
sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:
```

**Step 7** Press **Enter** to apply the changes or enter **no** to discard them.

---

## Configuring the Status of Signatures

Use the **status** command in signature definition submode to specify the status of a specific signature. The following options apply:

- **status**—Identifies whether the signature is enabled, disabled, or retired:
  - **enabled {true | false}**—Enables the signature.
  - **retired {true | false}**—Retires the signature.
  - **obsoletes *signature\_ID***—Shows the other signatures that have been obsoleted by this signature.



### Caution

Activating and retiring signatures can take 30 minutes or longer.

### Changing the Signature Status

To change the status of a signature, follow these steps:

**Step 1** Log in to the CLI using an account with administrator or operator privileges.

**Step 2** Enter signature definition submode.

```
sensor# configure terminal
sensor(config)# service signature-definition sig1
```

**Step 3** Choose the signature you want to configure.

```
sensor(config-sig)# signatures 12000 0
```

**Step 4** Change the status for this signature.

```
sensor(config-sig-sig)# status
sensor(config-sig-sig-sta)# enabled true
```

**Step 5** Verify the settings.

```
sensor(config-sig-sig-sta)# show settings
status

enabled: true default: false
retired: false <defaulted>

sensor(config-sig-sig-sta)#
```

**Step 6** Exit signatures submode.

```
sensor(config-sig-sig-sta)# exit
sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:
```

**Step 7** Press **Enter** to apply the changes or enter **no** to discard them.

## Configuring the Vulnerable OSeS for a Signature

Use the **vulnerable-os** command in signature definition submode to configure the list of vulnerable OSeS for a signature. The following options apply:

- **general-os**—Specifies all OS types
- **ios**—Specifies the variants of Cisco IOS
- **mac-os**—Specifies the variants of Macintosh OS
- **netware**—Specifies Netware
- **other**—Specifies any other OS
- **unix**—Specifies the variants of UNIX
- **aix**—Specifies the variants of AIX
- **bsd**—Specifies the variants of BSD
- **hp-ux**—Specifies the variants of HP-UX
- **irix**—Specifies the variants of IRIX
- **linux**—Specifies the variants of Linux
- **solaris**—Specifies the variants of Solaris
- **windows**—Specifies the variants of Microsoft Windows
- **windows-nt-2k-xp**—Specifies the variants of Microsoft NT, 2000, and XP
- **win-nt**—Specifies the specific variants of Windows NT

### Configuring Vulnerable OSeS

To configure the vulnerable OSeS for a signature, follow these steps:

---

**Step 1** Log in to the CLI using an account with administrator or operator privileges.

**Step 2** Enter signature definition submode.

```
sensor# configure terminal
sensor(config)# service signature-definition sig1
```

**Step 3** Specify the signature you want to configure.

```
sensor(config-sig)# signatures 6000 0
```

**Step 4** Specify the vulnerable OSeS for this signature.

```
sensor(config-sig-sig)# vulnerable-os linux|aix
```

**Step 5** Verify the settings.

```
sensor(config-sig-sig)# show settings
sig-id: 60000
subsig-id: 0

alert-severity: medium <defaulted>
sig-fidelity-rating: 75 <defaulted>
promisc-delta: 0 <defaulted>
sig-description

sig-name: My Sig <defaulted>
sig-string-info: My Sig Info <defaulted>
sig-comment: Sig Comment <defaulted>
```



```

 alert-traits: 0 <defaulted>
 release: custom <defaulted>

vulnerable-os: aix|linux default: general-os
*----> engine

event-counter

 event-count: 1 <defaulted>
 event-count-key: Axxx <defaulted>
 specify-alert-interval

--MORE--

```

**Step 6** Exit signatures submode.

```

sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:

```

**Step 7** Press **Enter** to apply the changes or enter **no** to discard them.

## Assigning Actions to Signatures

Use the **event-action** command in signature definition submode to configure the actions the sensor takes when the signature fires. The following options apply:

- **event-action**—Specifies the type of event action the sensor should perform:
  - **deny-attacker-inline** (inline only)—Does not transmit this packet and future packets from the attacker address for a specified period of time.
  - **deny-attacker-service-pair-inline** (inline only)—Does not transmit this packet and future packets on the attacker address victim port pair for a specified period of time.
  - **deny-attacker-victim-pair-inline** (inline only)—Does not transmit this packet and future packets on the attacker/victim address pair for a specified period of time.
  - **deny-connection-inline** (inline only)—Does not transmit this packet and future packets on the TCP flow.
  - **deny-packet-inline** (inline only)—Does not transmit this packet.
  - **log-attacker-packets**—Starts IP logging of packets containing the attacker address.
  - **log-pair-packets**—Starts IP logging of packets containing the attacker-victim address pair.
  - **log-victim-packets**—Starts IP logging of packets containing the victim address.
  - **produce-alert** —Writes the event to the Event Store as an alert.
  - **produce-verbose-alert**—Includes an encoded dump (possibly truncated) of the offending packet in the alert.
  - **request-block-connection**—Sends a request to the ARC to block this connection.
  - **request-block-host**—Sends a request to the ARC to block this attacker host.
  - **request-rate-limit**—Sends a rate limit request to the ARC to perform rate limiting.
  - **request-snmp-trap**—Sends a request to the Notification Application component of the sensor to perform SNMP notification.

- **reset-tcp-connection**—Sends TCP resets to hijack and terminate the TCP flow.
- **modify-packet-inline**—Modifies packet data to remove ambiguity about what the end point might do with the packet.
- **event-action-settings**—Enables the **external-rate-limit-type**:
  - **none**—No rate limiting configured.
  - **percentage**—Specifies the rate limit by traffic percentage (**external-rate-limit-percentage**).

### Configuring Event Actions

To configure event actions and event action settings for a signature, follow these steps:

**Step 1** Log in to the CLI using an account with administrator privileges.

**Step 2** Enter signature definition mode.

```
sensor# configure terminal
sensor(config)# service signature-definition sig0
sensor(config-sig)#
```

**Step 3** Specify the signature you want to configure.

```
sensor(config-sig)# signatures 1200 0
```

**Step 4** Specify the signature engine (for signature 1200 it is the Normalizer engine).

```
sensor(config-sig-sig)# engine normalizer
```

**Step 5** Configure the event action.

```
sensor(config-sig-sig-nor)# event-action produce-alert|request-snmp-trap
```



**Note** Each time you configure the event actions for a signature, you overwrite the previous configuration. For example, if you always want to produce an alert when the signature is fired, you must configure it along with the other event actions you want. Use the | symbol to add more than one event action, for example, **product-alert|deny-packet-inline|request-snmp-trap**.

**Step 6** Verify the settings.

```
sensor(config-sig-sig-nor)# show settings
normalizer

event-action: produce-alert|request-snmp-trap default:
produce-alert|deny-packet-inline
```

**Step 7** Specify the percentage for rate limiting.

```
sensor(config-sig-sig-nor)# event-action-settings
sensor(config-sig-sig-nor-eve)# external-rate-limit-type percentage
sensor(config-sig-sig-nor-eve-per)# external-rate-limit-percentage 50
```

**Step 8** Verify the settings.

```
sensor(config-sig-sig-nor-eve-per)# show settings
percentage

external-rate-limit-percentage: 50 default: 100

```

**Step 9** Exit event action submode.

```
sensor(config-sig-sig-nor-eve-per)# exit
sensor(config-sig-sig-nor-eve)# exit
sensor(config-sig-sig-nor)# exit
sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:
```

**Step 10** Press **Enter** to apply the changes or enter **no** to discard them.

---

#### For More Information

For a detailed description of the event actions, see [Event Actions, page 7-5](#).

## Configuring AIC Signatures

This section describes the Application Inspection and Control (AIC) signatures and how to configure them. It contains the following topics:

- [Understanding the AIC Engine, page 8-17](#)
- [AIC Engine and Sensor Performance, page 8-18](#)
- [Configuring the Application Policy, page 8-18](#)
- [AIC Request Method Signatures, page 8-20](#)
- [AIC MIME Define Content Type Signatures, page 8-21](#)
- [AIC Transfer Encoding Signatures, page 8-24](#)
- [AIC FTP Commands Signatures, page 8-25](#)
- [Creating an AIC Signature, page 8-26](#)

## Understanding the AIC Engine

AIC provides thorough analysis of web traffic. It provides granular control over HTTP sessions to prevent abuse of the HTTP protocol. It allows administrative control over applications, such as instant messaging and gotomypc, that try to tunnel over specified ports. Inspection and policy checks for P2P and instant messaging are possible if these applications are running over HTTP. AIC also provides a way to inspect FTP traffic and control the commands being issued. You can enable or disable the predefined signatures or you can create policies through custom signatures.



#### Note

The AIC engines run when HTTP traffic is received on AIC web ports. If traffic is web traffic, but not received on the AIC web ports, the Service HTTP engine is executed. AIC inspection can be on any port if it is configured as an AIC web port and the traffic to be inspected is HTTP traffic.

---

AIC has the following categories of signatures:

- HTTP request method
  - Define request method
  - Recognized request methods

- MIME type
  - Define content type
  - Recognized content type

- Define web traffic policy

There is one predefined signature, 12674, that specifies the action to take when noncompliant HTTP traffic is seen. The parameter Alarm on Non HTTP Traffic enables the signature. By default this signature is enabled.

- Transfer encodings
  - Associate an action with each method
  - List methods recognized by the sensor
  - Specify which actions need to be taken when a chunked encoding error is seen
- FTP commands
  - Associates an action with an FTP command.

#### For More Information

- For a list of signature IDs and descriptions for these signatures, see [AIC Request Method Signatures, page 8-20](#), [AIC MIME Define Content Type Signatures, page 8-21](#), [AIC Transfer Encoding Signatures, page 8-24](#), and [AIC FTP Commands Signatures, page 8-25](#).
- For the procedure for creating a custom MIME signature, see [Creating an AIC Signature, page 8-26](#).

## AIC Engine and Sensor Performance

Application policy enforcement is a unique sensor feature. Rather than being based on traditional IPS technologies that inspect for exploits, vulnerabilities, and anomalies, AIC policy enforcement is designed to enforce HTTP and FTP service policies. The inspection work required for this policy enforcement is extreme compared with traditional IPS inspection work. A large performance penalty is associated with using this feature. When AIC is enabled, the overall bandwidth capacity of the sensor is reduced.

AIC policy enforcement is disabled in the IPS default configuration. If you want to activate AIC policy enforcement, we highly recommend that you carefully choose the exact policies of interest and disable those you do not need. Also, if your sensor is near its maximum inspection load capacity, we recommend that you not use this feature since it can oversubscribe the sensor. We recommend that you use the adaptive security appliance firewall to handle this type of policy enforcement.

## Configuring the Application Policy

Use the **application-policy** command in signature definition submode to enable the web AIC feature. You can configure the sensor to provide Layer 4 to Layer 7 packet inspection to prevent malicious attacks related to web and FTP services.

The following options apply:

- **ftp-enable {true | false}**—Enables protection for FTP services. Set to true to require the sensor to inspect FTP traffic. The default is false.
- **http-policy**—Enables inspection of HTTP traffic:
  - **aic-web-ports**—Specifies the variable for ports to look for AIC traffic. The valid range is 0 to 65535. A comma-separated list of integer ranges a-b[,c-d] within 0-65535. The second number in the range must be greater than or equal to the first number. The default is 80-80,3128-3128,8000-8000,8010-8010,8080-8080,8888-8888,24326-24326.
  - **http-enable [true | false]**—Enables protection for web services. Set to true to require the sensor to inspect HTTP traffic for compliance with the RFC. The default is false.
  - **max-outstanding-http-requests-per-connection**—Specifies the maximum allowed HTTP requests per connection. The valid value is 1 to 16. The default is 10.

### Configuring the Application Policy

To configure the application policy, follow these steps:

---

**Step 1** Log in to the CLI using an account with administrator or operator privileges.

**Step 2** Enter application policy submode.

```
sensor# configure terminal
sensor(config)# service signature-definition sig1
sensor(config-sig)# application-policy
```

**Step 3** Enable inspection of FTP traffic.

```
sensor(config-sig-app)# ftp-enable true
```

**Step 4** Configure the HTTP application policy:

a. Enter HTTP application policy submode.

```
sensor(config-sig-app)# http-policy
```

b. Enable HTTP application policy enforcement.

```
sensor(config-sig-app-http)# http-enable true
```

c. Specify the number of outstanding HTTP requests per connection that can be outstanding without having received a response from the server.

```
sensor(config-sig-app-http)# max-outstanding-http-requests-per-connection 5
```

d. Edit the AIC ports.

```
sensor(config-sig-app-http)# aic-web-ports 80-80,3128-3128
```

**Step 5** Verify your settings.

```
sensor(config-sig-app-http)# exit
sensor(config-sig-app)# show settings
application-policy

http-policy

http-enable: true default: false
max-outstanding-http-requests-per-connection: 5 default: 10
aic-web-ports: 80-80,3128-3128 default: 80-80,3128-3128,8000-8000,8010-
8010,8080-8080,8888-8888,24326-24326
```

```

ftp-enable: true default: false

sensor(config-sig-app) #

```

**Step 6** Exit signature definition submode.

```

sensor(config-sig-app) # exit
sensor(config-sig) # exit
Apply Changes:[yes]:

```

**Step 7** Press **Enter** to apply the changes or enter **no** to discard them.

## AIC Request Method Signatures

The HTTP request method has two categories of signatures:

- Define request method—Allows actions to be associated with request methods. You can expand and modify the signatures (Define Request Method).
- Recognized request methods—Lists methods that are recognized by the sensor (Recognized Request Methods).

Table 8-1 lists the predefined define request method signatures. Enable the signatures that have the predefined method you need.

**Table 8-1 Request Method Signatures**

Signature ID	Define Request Method
12676	Request Method Not Recognized
12677	Define Request Method PUT
12678	Define Request Method CONNECT
12679	Define Request Method DELETE
12680	Define Request Method GET
12681	Define Request Method HEAD
12682	Define Request Method OPTIONS
12683	Define Request Method POST
12685	Define Request Method TRACE
12695	Define Request Method INDEX
12696	Define Request Method MOVE
12697	Define Request Method MKDIR
12698	Define Request Method COPY
12699	Define Request Method EDIT
12700	Define Request Method UNEDIT
12701	Define Request Method SAVE
12702	Define Request Method LOCK
12703	Define Request Method UNLOCK

**Table 8-1 Request Method Signatures (continued)**

Signature ID	Define Request Method
12704	Define Request Method REVLABEL
12705	Define Request Method REVLOG
12706	Define Request Method REVADD
12707	Define Request Method REVNUM
12708	Define Request Method SETATTRIBUTE
12709	Define Request Method GETATTRIBUTENAME
12710	Define Request Method GETPROPERTIES
12711	Define Request Method STARTENV
12712	Define Request Method STOPREV

**For More Information**

For the procedure for enabling signatures, see [Configuring the Status of Signatures, page 8-13](#).

## AIC MIME Define Content Type Signatures

There are two policies associated with MIME types:

- Define content type—Associates specific actions for the following cases (Define Content Type):
  - Deny a specific MIME type, such as an image/jpeg
  - Message size violation
  - MIME-type mentioned in header and body do not match
- Recognized content type (Recognized Content Type)

[Table 8-2](#) lists the predefined define content type signatures. Enable the signatures that have the predefined content type you need. You can also create custom define content type signatures.

**Table 8-2 Define Content Type Signatures**

Signature ID	Signature Description
12621	Content Type image/gif Invalid Message Length
12622 2	Content Type image/png Verification Failed
12623 0	Content Type image/tiff Header Check
12623 1	Content Type image/tiff Invalid Message Length
12623 2	Content Type image/tiff Verification Failed
12624 0	Content Type image/x-3ds Header Check
12624 1	Content Type image/x-3ds Invalid Message Length
12624 2	Content Type image/x-3ds Verification Failed
12626 0	Content Type image/x-portable-bitmap Header Check
12626 1	Content Type image/x-portable-bitmap Invalid Message Length
12626 2	Content Type image/x-portable-bitmap Verification Failed

**Table 8-2** *Define Content Type Signatures (continued)*

<b>Signature ID</b>	<b>Signature Description</b>
12627 0	Content Type image/x-portable-graymap Header Check
12627 1	Content Type image/x-portable-graymap Invalid Message Length
12627 2	Content Type image/x-portable-graymap Verification Failed
12628 0	Content Type image/jpeg Header Check
12628 1	Content Type image/jpeg Invalid Message Length
12628 2	Content Type image/jpeg Verification Failed
12629 0	Content Type image/cgf Header Check
12629 1	Content Type image/cgf Invalid Message Length
12631 0	Content Type image/x-xpm Header Check
12631 1	Content Type image/x-xpm Invalid Message Length
12633 0	Content Type audio/midi Header Check
12633 1	Content Type audio/midi Invalid Message Length
12633 2	Content Type audio/midi Verification Failed
12634 0	Content Type audio/basic Header Check
12634 1	Content Type audio/basic Invalid Message Length
12634 2	Content Type audio/basic Verification Failed
12635 0	Content Type audio/mpeg Header Check
12635 1	Content Type audio/mpeg Invalid Message Length
12635 2	Content Type audio/mpeg Verification Failed
12636 0	Content Type audio/x-adpcm Header Check
12636 1	Content Type audio/x-adpcm Invalid Message Length
12636 2	Content Type audio/x-adpcm Verification Failed
12637 0	Content Type audio/x-aiff Header Check
12637 1	Content Type audio/x-aiff Invalid Message Length
12637 2	Content Type audio/x-aiff Verification Failed
12638 0	Content Type audio/x-ogg Header Check
12638 1	Content Type audio/x-ogg Invalid Message Length
12638 2	Content Type audio/x-ogg Verification Failed
12639 0	Content Type audio/x-wav Header Check
12639 1	Content Type audio/x-wav Invalid Message Length
12639 2	Content Type audio/x-wav Verification Failed
12641 0	Content Type text/html Header Check
12641 1	Content Type text/html Invalid Message Length
12641 2	Content Type text/html Verification Failed
12642 0	Content Type text/css Header Check
12642 1	Content Type text/css Invalid Message Length
12643 0	Content Type text/plain Header Check
12643 1	Content Type text/plain Invalid Message Length
12644 0	Content Type text/richtext Header Check
12644 1	Content Type text/richtext Invalid Message Length
12645 0	Content Type text/sgml Header Check
12645 1	Content Type text/sgml Invalid Message Length
12645 2	Content Type text/sgml Verification Failed



**Table 8-2 Define Content Type Signatures (continued)**

<b>Signature ID</b>	<b>Signature Description</b>
12646 0	Content Type text/xml Header Check
12646 1	Content Type text/xml Invalid Message Length
12646 2	Content Type text/xml Verification Failed
12648 0	Content Type video/flc Header Check
12648 1	Content Type video/flc Invalid Message Length
12648 2	Content Type video/flc Verification Failed
12649 0	Content Type video/mpeg Header Check
12649 1	Content Type video/mpeg Invalid Message Length
12649 2	Content Type video/mpeg Verification Failed
12650 0	Content Type text/xmcd Header Check
12650 1	Content Type text/xmcd Invalid Message Length
12651 0	Content Type video/quicktime Header Check
12651 1	Content Type video/quicktime Invalid Message Length
12651 2	Content Type video/quicktime Verification Failed
12652 0	Content Type video/sgi Header Check
12652 1	Content Type video/sgi Verification Failed
12653 0	Content Type video/x-avi Header Check
12653 1	Content Type video/x-avi Invalid Message Length
12654 0	Content Type video/x-fli Header Check
12654 1	Content Type video/x-fli Invalid Message Length
12654 2	Content Type video/x-fli Verification Failed
12655 0	Content Type video/x-mng Header Check
12655 1	Content Type video/x-mng Invalid Message Length
12655 2	Content Type video/x-mng Verification Failed
12656 0	Content Type application/x-msvideo Header Check
12656 1	Content Type application/x-msvideo Invalid Message Length
12656 2	Content Type application/x-msvideo Verification Failed
12658 0	Content Type application/ms-word Header Check
12658 1	Content Type application/ms-word Invalid Message Length
12659 0	Content Type application/octet-stream Header Check
12659 1	Content Type application/octet-stream Invalid Message Length
12660 0	Content Type application/postscript Header Check
12660 1	Content Type application/postscript Invalid Message Length
12660 2	Content Type application/postscript Verification Failed
12661 0	Content Type application/vnd.ms-excel Header Check
12661 1	Content Type application/vnd.ms-excel Invalid Message Length
12662 0	Content Type application/vnd.ms-powerpoint Header Check
12662 1	Content Type application/vnd.ms-powerpoint Invalid Message Length
12663 0	Content Type application/zip Header Check
12663 1	Content Type application/zip Invalid Message Length
12663 2	Content Type application/zip Verification Failed

**Table 8-2** *Define Content Type Signatures (continued)*

Signature ID	Signature Description
12664 0	Content Type application/x-gzip Header Check
12664 1	Content Type application/x-gzip Invalid Message Length
12664 2	Content Type application/x-gzip Verification Failed
12665 0	Content Type application/x-java-archive Header Check
12665 1	Content Type application/x-java-archive Invalid Message Length
12666 0	Content Type application/x-java-vm Header Check
12666 1	Content Type application/x-java-vm Invalid Message Length
12667 0	Content Type application/pdf Header Check
12667 1	Content Type application/pdf Invalid Message Length
12667 2	Content Type application/pdf Verification Failed
12668 0	Content Type unknown Header Check
12668 1	Content Type unknown Invalid Message Length
12669 0	Content Type image/x-bitmap Header Check
12669 1	Content Type image/x-bitmap Invalid Message Length
12673 0	Recognized content type

**For More Information**

- For the procedure for enabling signatures, see [Configuring the Status of Signatures, page 8-13](#).
- For the procedure for creating an ACI signature, see [Creating an AIC Signature, page 8-26](#).

## AIC Transfer Encoding Signatures

There are three policies associated with transfer encoding:

- Associate an action with each method (Define Transfer Encoding)
- List methods recognized by the sensor (Recognized Transfer Encodings)
- Specify which actions need to be taken when a chunked encoding error is seen (Chunked Transfer Encoding Error)

[Table 8-3](#) lists the predefined transfer encoding signatures. Enable the signatures that have the predefined transfer encoding method you need.

**Table 8-3** *Transfer Encoding Signatures*

Signature ID	Transfer Encoding Method
12686	Recognized Transfer Encoding
12687	Define Transfer Encoding Deflate
12688	Define Transfer Encoding Identity
12689	Define Transfer Encoding Compress
12690	Define Transfer Encoding GZIP
12693	Define Transfer Encoding Chunked
12694	Chunked Transfer Encoding Error

**For More Information**

For the procedure for enabling signatures, see [Configuring the Status of Signatures, page 8-13](#).

**AIC FTP Commands Signatures**

[Table 8-4](#) lists the predefined FTP commands signatures. Enable the signatures that have the predefined FTP command you need.

**Table 8-4** *FTP Commands Signatures*

Signature ID	FTP Command
12900	Unrecognized FTP command
12901	Define FTP command abor
12902	Define FTP command acct
12903	Define FTP command allo
12904	Define FTP command appe
12905	Define FTP command cdup
12906	Define FTP command cwd
12907	Define FTP command dele
12908	Define FTP command help
12909	Define FTP command list
12910	Define FTP command mkd
12911	Define FTP command mode
12912	Define FTP command nlst
12913	Define FTP command noop
12914	Define FTP command pass
12915	Define FTP command pasv
12916	Define FTP command port
12917	Define FTP command pwd
12918	Define FTP command quit
12919	Define FTP command rein
12920	Define FTP command rest
12921	Define FTP command retr
12922	Define FTP command rmd
12923	Define FTP command rnfr
12924	Define FTP command rnto
12925	Define FTP command site
12926	Define FTP command smnt
12927	Define FTP command stat
12928	Define FTP command stor
12929	Define FTP command stou

**Table 8-4** *FTP Commands Signatures (continued)*

Signature ID	FTP Command
12930	Define FTP command stru
12931	Define FTP command syst
12932	Define FTP command type
12933	Define FTP command user

**For More Information**

For the procedure for enabling signatures, see [Configuring the Status of Signatures, page 8-13](#).

## Creating an AIC Signature

**Caution**

A custom signature can affect the performance of your sensor. Test the custom signature against a baseline sensor performance for your network to determine the overall impact of the signature.

The following example demonstrates how to create a MIME-type signature based on the AIC engine. The following options apply:

- **event-action**—Specifies the action(s) to perform when alert is triggered:
  - **deny-attacker-inline** (inline only)—Does not transmit this packet and future packets from the attacker address for a specified period of time.
  - **deny-attacker-service-pair-inline** (inline only)—Does not transmit this packet and future packets on the attacker address victim port pair for a specified period of time.
  - **deny-attacker-victim-pair-inline** (inline only)—Does not transmit this packet and future packets on the attacker/victim address pair for a specified period of time.
  - **deny-connection-inline** (inline only)—Does not transmit this packet and future packets on the TCP flow.
  - **deny-packet-inline** (inline only)—Does not transmit this packet.
  - **log-attacker-packets**—Starts IP logging of packets containing the attacker address.
  - **log-pair-packets**—Starts IP logging of packets containing the attacker-victim address pair.
  - **log-victim-packets**—Starts IP logging of packets containing the victim address.
  - **produce-alert** —Writes the event to the Event Store as an alert.
  - **produce-verbose-alert**—Includes an encoded dump (possibly truncated) of the offending packet in the alert.
  - **request-block-connection**—Sends a request to the ARC to block this connection.
  - **request-block-host**—Sends a request to the ARC to block this attacker host.
  - **request-rate-limit**—Sends a rate limit request to the ARC to perform rate limiting.
  - **request-snmp-trap**—Sends a request to the Notification Application component of the sensor to perform SNMP notification.
  - **reset-tcp-connection**—Sends TCP resets to hijack and terminate the TCP flow.

- **modify-packet-inline**—Modifies packet data to remove ambiguity about what the end point might do with the packet.
- **no**—Removes an entry or selection setting
- **signature-type**—Specifies the type of signature desired:
  - **content-types**—Content-types.
  - **define-web-traffic-policy**—Defines web traffic policy.
  - **max-outstanding-requests-overflow**—Inspects for large number of outstanding HTTP requests.
  - **msg-body-pattern**—Message body pattern.
  - **request-methods**—Signature types that deal with request methods.
  - **transfer-encodings**—Signature types that deal with transfer encodings.

### Defining a MIME-Type Policy Signature

To define a MIME-type policy signature, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator or operator privileges.
- Step 2** Enter application policy enforcement submode.
- ```
sensor# configure terminal
sensor(config)# service signature-definition sig1
sensor(config-sig)# signatures 60001 0
sensor(config-sig-sig)# engine application-policy-enforcement-http
```
- Step 3** Specify the event action.
- ```
sensor(config-sig-sig-app)# event-action produce-alert|log-pair-packets
```
- Step 4** Define the signature type.
- ```
sensor(config-sig-sig-app)# signature-type content-type define-content-type
```
- Step 5** Define the content type.
- ```
sensor(config-sig-sig-app-def)# name MyContent
```
- Step 6** Verify your settings.
- ```
sensor(config-sig-sig-app-def)# show settings
-> define-content-type
-----
      name: MyContent
*---> content-type-details
-----
-----
sensor(config-sig-sig-app-def)#
```
- Step 7** Exit signatures submode.
- ```
sensor(config-sig-sig-app-def)# exit
sensor(config-sig-sig-app)# exit
sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:
```

**Step 8** Press **Enter** to apply the changes or enter **no** to discard them.

## Configuring IP Fragment Reassembly

This section describes IP fragment reassembly, lists the IP fragment reassembly signatures with the configurable parameters, describes how to configure these parameters, and how to configure the method for IP fragment reassembly. It contains the following topics:

- [Understanding IP Fragment Reassembly, page 8-28](#)
- [IP Fragment Reassembly Signatures and Configurable Parameters, page 8-28](#)
- [Configuring IP Fragment Reassembly Parameters, page 8-30](#)
- [Configuring the Method for IP Fragment Reassembly, page 8-30](#)

## Understanding IP Fragment Reassembly

You can configure the sensor to reassemble a datagram that has been fragmented over multiple packets. You can specify boundaries that the sensor uses to determine how many datagram fragments it reassembles and how long to wait for more fragments of a datagram. The goal is to ensure that the sensor does not allocate all its resources to datagrams that cannot be completely reassembled, either because the sensor missed some frame transmissions or because an attack has been launched that is based on generating random fragmented datagrams.



### Note

You configure the IP fragment reassembly per signature.

## IP Fragment Reassembly Signatures and Configurable Parameters

[Table 8-5](#) lists IP fragment reassembly signatures with the parameters that you can configure for IP fragment reassembly. The IP fragment reassembly signatures are part of the Normalizer engine.

**Table 8-5** *IP Fragment Reassembly Signatures*

Signature ID and Name	Description	Parameter With Default Value and Range	Default Action
1200 IP Fragmentation Buffer Full	Fires when the total number of fragments in the system exceeds the threshold set by Max Fragments.	Specify Max Fragments 10000 (0-42000)	Deny Packet Inline Produce Alert <sup>1</sup>
1201 IP Fragment Overlap	Fires when the fragments queued for a datagram overlap each other.	— <sup>2</sup>	Deny Packet Inline Produce Alert <sup>1</sup>
1202 IP Fragment Overrun - Datagram Too Long	Fires when the fragment data (offset and size) exceeds the threshold set with Max Datagram Size.	Specify Max Datagram Size 65536 (2000-65536)	Deny Packet Inline Produce Alert <sup>3</sup>
1203 IP Fragment Overwrite - Data is Overwritten	Fires when the fragments queued for a datagram overlap each other and the overlapping data is different. <sup>4</sup>	—	Deny Packet Inline Produce Alert <sup>5</sup>

**Table 8-5** *IP Fragment Reassembly Signatures (continued)*

Signature ID and Name	Description	Parameter With Default Value and Range	Default Action
1204 IP Fragment Missing Initial Fragment	Fires when the datagram is incomplete and missing the initial fragment.	—	Deny Packet Inline Produce Alert <sup>6</sup>
1205 IP Fragment Too Many Datagrams	Fires when the total number of partial datagrams in the system exceeds the threshold set by Max Partial Datagrams.	Specify Max Partial Datagrams 1000 (0-10000)	Deny Packet Inline Produce Alert <sup>7</sup>
1206 IP Fragment Too Small	Fires when there are more than Max Small Frags of a size less than Min Fragment Size in one datagram. <sup>8</sup>	Specify Max Small Frags 2 (8-1500) Specify Min Fragment Size 400 (1-8)	Deny Packet Inline Produce Alert <sup>9</sup>
1207 IP Fragment Too Many Fragments in a Datagram	Fires when there are more than Max Fragments per Datagram in one datagram.	Specify Max Fragments per Datagram 170 (0-8192)	Deny Packet Inline Produce Alert <sup>6</sup>
1208 IP Fragment Incomplete Datagram	Fires when all of the fragments for a datagram have not arrived during the Fragment Reassembly Timeout. <sup>10</sup>	Specify Fragment Reassembly Timeout 60 (0-360)	Deny Packet Inline Produce Alert <sup>6</sup>
1225 Fragment Flags Invalid	Fires when a bad combination of fragment flags is detected.	— <sup>11</sup>	—

1. Modify Packet Inline and Deny Connection Inline have no effect on this signature. Deny Packet Inline drops the packets and all associated fragments for this datagram. If you disable this signature, the default values are still used and packets are dropped (inline mode) or not analyzed (promiscuous mode) and no alert is sent.
2. This signature does not fire when the datagram is an exact duplicate. Exact duplicates are dropped in inline mode regardless of the settings. Modify Packet Inline removes the overlapped data from all but one fragment so there is no ambiguity about how the endpoint treats the datagram. Deny Connection Inline has no effect on this signature. Deny Packet Inline drops the packet and all associated fragments for this datagram.
3. Modify Packet Inline and Deny Connection Inline have no effect on this signature. Deny Packet Inline drops the packet and all associated fragments for this datagram. Regardless of the actions set the datagram is not processed by the IPS if the datagram is larger than the Max Datagram size.
4. This is a very unusual event.
5. Modify Packet Inline removes the overlapped data from all but one fragment so there is no ambiguity about how the endpoint treats the datagram. Deny Connection Inline has no effect on this signature. Deny Packet Inline drops the packets and all associated fragments for this datagram.
6. IPS does not inspect a datagram missing the first fragments regardless of the settings. Modify Packet Inline and Deny Connection Inline have no effect on this signature. Deny Packet Inline drops the packet and all associated fragments for this datagram.
7. Modify Packet Inline and Deny Connection Inline have no effect on this signature. Deny Packet Inline drops the packet and all associated fragments for this datagram.
8. IPS does not inspect the datagram if this signature is on and the number of small fragments is exceeded.
9. Modify Packet Inline and Deny Connection Inline have no effect on this signature. Deny Packet Inline drops the packet and all associated fragments for this datagram.
10. The timer starts when the packet for the datagram arrives.
11. Modify Packet Inline modifies the flags to a valid combination. Deny Connection Inline has no effect on this signature. Deny Packet Inline drops the packet and all associated fragments for this datagram.

**For More Information**

For more information about the Normalizer engine, see [Normalizer Engine, page B-37](#).

## Configuring IP Fragment Reassembly Parameters

To configure IP fragment reassembly parameters for a specific signature, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator or operator privileges.
- Step 2** Enter signature definition submode.
- ```
sensor# configure terminal
sensor(config)# service signature-definition sig1
```
- Step 3** Specify the IP fragment reassembly signature ID and subsignature ID.
- ```
sensor(config-sig)# signatures 1200 0
```
- Step 4** Specify the engine.
- ```
sensor(config-sig-sig)# engine normalizer
```
- Step 5** Enter edit default signatures submode.
- ```
sensor(config-sig-sig-nor)# edit-default-sigs-only default-signatures-only
```
- Step 6** Enable and change the default setting (if desired) of any of the IP fragment reassembly parameter for signature 1200, for example, specifying the maximum fragments.
- ```
sensor(config-sig-sig-nor-def)# specify-max-fragments yes
sensor(config-sig-sig-nor-def-yes)# max-fragments 20000
```
- Step 7** Verify the settings.
- ```
sensor(config-sig-sig-nor-def-yes)# show settings
yes

max-fragments: 20000 default: 10000

sensor(config-sig-sig-nor-def-yes)#
```
- Step 8** Exit signature definition submode.
- ```
sensor(config-sig-sig-nor-def-yes)# exit
sensor(config-sig-sig-nor-def)# exit
sensor(config-sig-sig-nor)# exit
sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:
```
- Step 9** Press **Enter** for apply the changes or enter **no** to discard them.
-

Configuring the Method for IP Fragment Reassembly

Use the **fragment-reassembly** command in the signature definition submode to configure the method the sensor will use to reassemble fragments. You can configure this option if your sensor is operating in promiscuous mode. If your sensor is operating in line mode, the method is NT only.

The following options apply:

- **ip-reassemble-mode**—Identifies the method the sensor uses to reassemble the fragments based on the operating system:
 - **nt**—Specifies the Windows systems (default).

- **solaris**—Specifies the Solaris systems.
- **linux**—Specifies the GNU/Linux systems.
- **bsd**—Specifies the BSD UNIX systems.

Configuring the IP Fragment Reassembly Method

To configure the method for IP fragment reassembly, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator or operator privileges.
- Step 2** Enter fragment reassembly submenu.
- ```
sensor# configure terminal
sensor(config)# service signature-definition sig1
sensor(config-sig)# fragment-reassembly
```
- Step 3** Configure the operating system you want the sensor to use to reassemble IP fragments.
- ```
sensor(config-sig-fra)# ip-reassemble-mode linux
```
- Step 4** Verify the setting.
- ```
sensor(config-sig-fra)# show settings
fragment-reassembly

ip-reassemble-mode: linux default: nt

sensor(config-sig-fra)#
```
- Step 5** Exit signature definition submenu.
- ```
sensor(config-sig-fra)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:
```
- Step 6** Press **Enter** to apply the changes or enter **no** to discard them.
-

Configuring TCP Stream Reassembly

This section describes TCP stream reassembly, lists the TCP stream reassembly signatures with the configurable parameters, describes how to configure TCP stream signatures, and how to configure the mode for TCP stream reassembly. It contains the following topics:

- [Understanding TCP Stream Reassembly, page 8-31](#)
- [TCP Stream Reassembly Signatures and Configurable Parameters, page 8-32](#)
- [Configuring TCP Stream Reassembly Signatures, page 8-37](#)
- [Configuring the Mode for TCP Stream Reassembly, page 8-38](#)

Understanding TCP Stream Reassembly

You can configure the sensor to monitor only TCP sessions that have been established by a complete three-way handshake. You can also configure how long to wait for the handshake to complete, and how long to keep monitoring a connection where no more packets have been seen. The goal is to prevent the

sensor from creating alerts where a valid TCP session has not been established. There are known attacks against sensors that try to get the sensor to generate alerts by simply replaying pieces of an attack. The TCP session reassembly feature helps to mitigate these types of attacks against the sensor.

You configure TCP stream reassembly parameters per signature. You can configure the mode for TCP stream reassembly.

TCP Stream Reassembly Signatures and Configurable Parameters

Table 8-6 lists TCP stream reassembly signatures with the parameters that you can configure for TCP stream reassembly. TCP stream reassembly signatures are part of the Normalizer engine.

Table 8-6 TCP Stream Reassembly Signatures

| Signature ID and Name | Description | Parameter With Default Value and Range | Default Actions |
|--|---|---|-----------------------------------|
| 1301 TCP Session Inactivity Timeout ¹ | Fires when a TCP session has been idle for a TCP Idle Timeout. | TCP Idle Timeout
3600 (15-3600) | — ² |
| 1302 TCP Session Embryonic Timeout ³ | Fires when a TCP session has not completes the three-way handshake in TCP embryonic timeout seconds. | TCP Embryonic Timeout 15
(3-300) | — ⁴ |
| 1303 TCP Session Closing Timeout ⁵ | Fires when a TCP session has not closed completely in TCP Closed Timeout seconds after the first FIN. | TCP Closed Timeout
5 (1-60) | — ⁶ |
| 1304 TCP Session Packet Queue Overflow | This signature allows for setting the internal TCP Max Queue size value for the Normalizer engine. As a result it does not function in promiscuous mode. By default this signature does not fire an alert. If a custom alert event is associated with this signature and if the queue size is exceeded, an alert fires.

Note The IPS signature team discourages modifying this value. | TCP Max Queue 32
(0-128)
TCP Idle Timeout
3600 | — ⁷ |
| 1305 TCP Urg Flag Set ⁸ | Fires when the TCP urgent flag is seen | TCP Idle Timeout
3600 | Modify Packet Inline ⁹ |

Table 8-6 *TCP Stream Reassembly Signatures (continued)*

| Signature ID and Name | Description | Parameter With Default Value and Range | Default Actions |
|---|---|--|---|
| 1306 0 TCP Option Other | Fires when a TCP option in the range of TCP Option Number is seen. All 1306 signatures fire an alert and do not function in promiscuous mode. | TCP Option Number 6-7,9-255
(Integer Range Allow Multiple 0-255 constraints)
TCP Idle Timeout 3600 | Modify Packet Inline
Produce Alert ¹⁰ |
| 1306 1 TCP SACK Allowed Option | Fires when a TCP selective ACK allowed option is seen. All 1306 signatures fire an alert and do not function in promiscuous mode. | TCP Idle Timeout 3600 | Modify Packet Inline ¹¹ |
| 1306 2 TCP SACK Data Option | Fires when a TCP selective ACK data option is seen. All 1306 signatures fire an alert and do not function in promiscuous mode. | TCP Idle Timeout 3600 | Modify Packet Inline ¹² |
| 1306 3 TCP Timestamp Option | Fires when a TCP timestamp option is seen. All 1306 signatures fire an alert and do not function in promiscuous mode. | TCP Idle Timeout 3600 | Modify Packet Inline ¹³ |
| 1306 4 TCP Window Scale Option | Fires when a TCP window scale option is seen. All 1306 signatures fire an alert and do not function in promiscuous mode. | TCP Idle Timeout 3600 | Modify Packet Inline ¹⁴ |
| 1306 5 TCP MSS Option | Fires when a TCP MSS option is detected. All 1306 signatures fire an alert and do not function in promiscuous mode. | TCP Idle Timeout 3600 | Modify Packet Inline |
| 1306 6 TCP option data after EOL option | Fires when the TCP option list has data after the EOL option. All 1306 signatures fire an alert and do not function in promiscuous mode. | TCP Idle Timeout 3600 | Modify Packet Inline |

Table 8-6 TCP Stream Reassembly Signatures (continued)

| Signature ID and Name | Description | Parameter With Default Value and Range | Default Actions |
|---|--|--|---|
| 1307 TCP Window Variation | Fires when the right edge of the rcv window for TCP moves to the right (decreases). | TCP Idle Timeout
3600 | Deny Connection Inline
Produce Alert ¹⁵ |
| 1308 TTL Evasion ¹⁶ | Fires when the TTL seen on one direction of a session is higher than the minimum that has been observed. | TCP Idle Timeout
3600 | Modify Packet Inline ¹⁷ |
| 1309 TCP Reserved Flags Set | Fires when the reserved bits (including bits used for ECN) are set on the TCP header. | TCP Idle Timeout
3600 | Modify Packet Inline
Produce Alert ¹⁸ |
| 1311 TCP Packet Exceeds MSS | Fires when a packet exceeds the MSS that was exchanged during the three-way handshake. | TCP Idle Timeout
3600 | Produce Alert ¹⁹ |
| 1312 TCP MSS Below Minimum | Fires when the MSS value in a packet containing a SYN flag is less than TCP Min MSS. | TCP Min MSS 400
(0-16000)
TCP Idle Timeout
3600 | Modify Packet Inline ²⁰ |
| 1313 TCP Max MSS | Fires when the MSS value in a packet containing a SYN flag exceeds TCP Max MSS. | TCP Max MSS 1460
(0-16000) | Modify Packet Inline
disabled ²¹ |
| 1314 TCP Data SYN | Fires when TCP payload is sent in the SYN packet. | — | Deny Packet Inline
disabled ²² |
| 1315 ACK Without TCP Stream | Fires when an ACK packet is sent that does not belong to a stream. | — | Produce Alert disabled ²³ |
| 1317 Zero Window Probe | Fires when a zero window probe packet is detected. | Modify Packet Inline removes data from the Zero Window Probe packet. | Modify Packet Inline |
| 1330 ²⁴ 0 TCP Drop - Bad Checksum | Fires when TCP packet has bad checksum. | Modify Packet Inline corrects the checksum. | Deny Packet Inline |
| 1330 1 TCP Drop - Bad TCP Flags | Fires when TCP packet has bad flag combination. | — | Deny Packet Inline |
| 1330 2 TCP Drop - Urgent Pointer With No Flag | Fires when TCP packet has a URG pointer and no URG flag. | Modify Packet Inline clears the pointer. | Modify Packet Inline
disabled |

Table 8-6 *TCP Stream Reassembly Signatures (continued)*

| Signature ID and Name | Description | Parameter With Default Value and Range | Default Actions |
|---|---|--|------------------------|
| 1330 3 TCP Drop - Bad Option List | Fires when TCP packet has a bad option list. | — | Deny Packet Inline |
| 1330 4 TCP Drop - Bad Option Length | Fires when TCP packet has a bad option length. | — | Deny Packet Inline |
| 1330 5 TCP Drop - MSS Option Without SYN | Fires when TCP MSS option is seen in packet without the SYN flag set. | Modify Packet Inline clears the MSS option. | Modify Packet Inline |
| 1330 6 TCP Drop - WinScale Option Without SYN | Fires when TCP window scale option is seen in packet without the SYN flag set. | Modify Packet Inline clears the window scale option. | Modify Packet Inline |
| 1330 7 TCP Drop - Bad WinScale Option Value | Fires when a TCP packet has a bad window scale value. | Modify Packet Inline sets the value to the closest constraint value. | Modify Packet Inline |
| 1330 8 TCP Drop - SACK Allow Without SYN | Fires when the TCP SACK allowed option is seen in a packet without the SYN flags set. | Modify Packet Inline clears the SACK allowed option. | Modify Packet Inline |
| 1330 9 TCP Drop - Data in SYN ACK | Fires when TCP packet with SYN and ACK flags set also contains data. | — | Deny Packet Inline |
| 1330 10 TCP Drop - Data Past FIN | Fires when TCP data is sequenced after FIN. | — | Deny Packet Inline |
| 1330 11 TCP Drop - Timestamp not Allowed | Fires when TCP packet has timestamp option when timestamp option is not allowed. | — | Deny Packet Inline |
| 1330 12 TCP Drop - Segment Out of Order | Fires when TCP segment is out of order and cannot be queued. | — | Deny Packet Inline |
| 1330 13 TCP Drop - Invalid TCP Packet | Fires when TCP packet has invalid header. | — | Deny Packet Inline |
| 1330 14 TCP Drop - RST or SYN in window | Fires when TCP packet with RST or SYN flag was sent in the sequence window but was not the next sequence. | — | Deny Packet Inline |
| 1330 15 TCP Drop - Segment Already ACKed | Fires when TCP packet sequence is already ACKed by peer (excluding keepalives). | — | Deny Packet Inline |

Table 8-6 TCP Stream Reassembly Signatures (continued)

| Signature ID and Name | Description | Parameter With Default Value and Range | Default Actions |
|---|---|--|--------------------|
| 1330 16 TCP Drop - PAWS Failed | Fires when TCP packet fails PAWS check. | — | Deny Packet Inline |
| 1330 17 TCP Drop - Segment out of State Order | Fires when TCP packet is not proper for the TCP session state. | — | Deny Packet Inline |
| 1330 18 TCP Drop - Segment out of Window | Fires when TCP packet sequence number is outside of allowed window. | — | Deny Packet Inline |
| 3050 Half Open SYN Attack | | syn-flood-max-embryonic 5000 | |
| 3250 TCP Hijack | | max-old-ack 200 | |
| 3251 TCP Hijack Simplex Mode | | max-old-ack 100 | |

1. The timer is reset to 0 after each packet on the TCP session. By default, this signature does not produce an alert. You can choose to produce alerts for expiring TCP connections if desired. A statistic of total number of expired flows is updated any time a flow expires.
2. Modify Packet Inline, Deny Connection Inline, and Deny Packet Inline have no effect on this signature.
3. The timer starts with the first SYN packet and is not reset. State for the session is reset and any subsequent packets for this flow appear to be out of order (unless it is a SYN).
4. Modify Packet Inline, Deny Connection Inline, and Deny Packet Inline have no effect on this signature.
5. The timer starts with the first FIN packet and is not reset. State for the session is reset and any subsequent packets for this flow appear to be out of order (unless it is a SYN).
6. Modify Packet Inline, Deny Connection Inline, and Deny Packet Inline have no effect on this signature.
7. Modify Packet Inline and Deny Packet Inline have no effect on this signature. Deny Connection Inline drops the current packet and the TCP session.
8. Phrak 57 describes a way to evade security policy using URG pointers. You can normalize the packet when it is in inline mode with this signature.
9. Modify Packet Inline strips the URG flag and zeros the URG pointer from the packet. Deny Connection Inline drops the current packet and the TCP session. Deny Packet Inline drops the packet.
10. Modify Packet Inline strips the selected option(s) from the packet. Deny Connection Inline drops the current packet and the TCP session. Deny Packet Inline drops the packet.
11. Modify Packet Inline strips the selected ACK allowed option from the packet. Deny Connection Inline drops the current packet and the TCP session. Deny Packet Inline drops the packet.
12. Modify Packet Inline strips the selected ACK allowed option from the packet. Deny Connection Inline drops the current packet and the TCP session. Deny Packet Inline drops the packet.
13. Modify Packet Inline strips the timestamp option from the packet. Deny Connection Inline drops the current packet and the TCP session. Deny Packet Inline drops the packet.
14. Modify Packet Inline strips the window scale option from the packet. Deny Connection Inline drops the current packet and the TCP session. Deny Packet Inline drops the packet.
15. Modify Packet Inline has no effect on this signature. Deny Connection Inline drops the current packet and the TCP connection. Deny Packet Inline drops the packet.
16. This signature is used to cause TTLs to monotonically decrease for each direction on a session. For example, if TTL 45 is the lowest TTL seen from A to B, then all future packets from A to B will have a maximum of 45 if Modify Packet Inline is set. Each new low TTL becomes the new maximum for packets on that session.
17. Modify Packet Inline ensures that the IP TTL monotonically decreases. Deny Connection Inline drops the current packet and the TCP session. Deny Packet Inline drops the packet.
18. Modify Packet Inline clears all reserved TCP flags. Deny Connection Inline drops the current packet and the TCP session. Deny Packet Inline drops the packet.
19. Modify Packet Inline has no effect on this signature. Deny Connection Inline drops the current packet and the TCP connection. Deny Packet Inline drops the packet.


20. 2.4.21-15.EL.cisco.1 Modify Packet Inline raises the MSS value to TCP Min MSS. Deny Connection Inline drops the current packet and the TCP session. Deny Packet Inline drops the packet 2.4.21-15.EL.cisco.1.
21. Modify Packet Inline lowers the MSS value to TCP Max MSS. Deny Connection Inline drops the current packet and the TCP session. Deny Packet Inline drops the packet 2.4.21-15.EL.cisco.1.
22. Modify Packet Inline has no effect on this signature. Deny Connection Inline drops the current packet and the TCP session. Deny Packet Inline drops the packet.
23. Modify Packet Inline, Deny Connection Inline, and Deny Packet Inline have no effect on this signature. By default, the 1330 signatures drop packets for which this signature sends alerts.
24. These subsignatures represent the reasons why the Normalizer might drop a TCP packet. By default these subsignatures drop packets. These subsignatures let you permit packets that fail the checks in the Normalizer through the IPS. The drop reasons have an entry in the TCP statistics. By default these subsignatures do not produce an alert.

For More Information

For more information about the Normalizer engine, see [Normalizer Engine, page B-37](#).

Configuring TCP Stream Reassembly Signatures

To configure TCP stream reassembly for a specific signature, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator or operator privileges.
- Step 2** Enter signature definition submode.
- ```
sensor# configure terminal
sensor(config)# service signature-definition sig1
```
- Step 3** Specify the TCP stream reassembly signature ID and subsignature ID.
- ```
sensor(config-sig)# signatures 1313 0
```
- Step 4** Specify the engine.
- ```
sensor(config-sig-sig)# engine normalizer
```
- Step 5** Enter edit default signatures submode.
- ```
sensor(config-sig-sig-nor)# edit-default-sigs-only default-signatures-only
```
- Step 6** Enable and change the default setting (if desired) of the maximum MSS parameter for signature 1313.
- ```
sensor(config-sig-sig-nor-def)# specify-tcp-max-mss yes
sensor(config-sig-sig-nor-def-yes)# tcp-max-mss 1380
```
- 

**Note** Changing this parameter from the default of 1460 to 1380 helps prevent fragmentation of traffic going through a VPN tunnel.
- 
- Step 7** Verify the settings.
- ```
sensor(config-sig-sig-nor-def-yes)# show settings
yes
-----
tcp-max-mss: 1380 default: 1460
-----
sensor(config-sig-sig-nor-def-yes)#
```
- Step 8** Exit signature definition submode.
- ```
sensor(config-sig-sig-nor-def-yes)# exit
sensor(config-sig-sig-nor-def)# exit
```

```

sensor(config-sig-sig-nor)# exit
sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes?[yes]:

```

**Step 9** Press **Enter** for apply the changes or enter **no** to discard them.

## Configuring the Mode for TCP Stream Reassembly



### Note

The parameters **tcp-3-way-handshake-required** and **tcp-reassembly-mode** only impact sensors inspecting traffic in promiscuous mode, not inline mode. To configure asymmetric options for sensors inspecting inline traffic, use the **inline-TCP-evasion-protection-mode** parameter.

Use the **stream-reassembly** command in the signature definition submode to configure the mode that the sensor will use to reassemble TCP sessions. The following options apply:

- **tcp-3-way-handshake-required [true | false]**—Specifies that the sensor should only track sessions for which the 3-way handshake is completed. The default is true.
- **tcp-reassembly-mode**—Specifies the mode the sensor should use to reassemble TCP sessions:
  - **strict**—Only allows the next expected in the sequence (default).
  - **loose**—Allows gaps in the sequence.
  - **asym**—Allows asymmetric traffic to be reassembled.



### Caution

The asymmetric option disables TCP window evasion checking.

### Configuring the TCP Stream Reassembly Parameters

To configure the TCP stream reassembly parameters, follow these steps:

**Step 1** Log in to the CLI using an account with administrator or operator privileges.

**Step 2** Enter TCP stream reassembly submode.

```

sensor# configure terminal
sensor(config)# service signature-definition sig1
sensor(config-sig)# stream-reassembly

```

**Step 3** Specify that the sensor should only track session for which the 3-way handshake is completed.

```

sensor(config-sig-str)# tcp-3-way-handshake-required true

```

**Step 4** Specify the mode the sensor should use to reassemble TCP sessions.

```

sensor(config-sig-str)# tcp-reassembly-mode strict

```

**Step 5** Verify the settings.

```

sensor(config-sig-str)# show settings
stream-reassembly

tcp-3-way-handshake-required: true default: true
tcp-reassembly-mode: strict default: strict

```



```
sensor(config-sig-str)#
```

**Step 6** Exit signature definition submode.

```
sensor(config-sig-str)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:
```

**Step 7** Press **Enter** to apply the changes or enter **no** to discard them.

### For More Information

For information on asymmetric inspection options for sensors configured in inline mode, see [Inline TCP Session Tracking Mode, page 6-3](#) and [Adding, Editing, and Deleting Virtual Sensors, page 6-5](#).

## Configuring IP Logging

You can configure a sensor to generate an IP session log when the sensor detects an attack. When IP logging is configured as a response action for a signature and the signature is triggered, all packets to and from the source address of the alert are logged for a specified period of time.



### Note

IP logging allows a maximum limit of 20 concurrent IP log files. Once the limit of 20 is reached, you receive the following message in main.log: Cid/W errWarnIpLogProcessor::addIpLog: Ran out of file descriptors.

Use the **ip-log** command in the signature definition submode to configure IP logging. The following options apply:

- **ip-log-bytes**—Identifies the maximum number of bytes you want logged. The valid value is 0 to 2147483647. The default is 0.
- **ip-log-packets**—Identifies the number of packets you want logged. The valid value is 0 to 65535. The default is 0.
- **ip-log-time**—Identifies the duration you want the sensor to log. The valid value is 30 to 300 seconds. The default is 30 seconds.



### Note

When the sensor meets any one of the IP logging conditions, it stops IP logging.

### Configuring IP Logging Parameters

To configure the IP logging parameters, follow these steps:

**Step 1** Log in to the CLI using an account with administrator or operator privileges.

**Step 2** Enter IP log submode.

```
sensor# configure terminal
sensor(config)# service signature-definition sig1
sensor(config-sig)# ip-log
```

**Step 3** Specify the IP logging parameters:

- a. Specify the maximum number of bytes you want logged.

```
sensor(config-sig-ip)# ip-log-bytes 200000
```

- b. Specify the number of packets you want logged.

```
sensor(config-sig-ip)# ip-log-packets 150
```

- c. Specify the length of time you want the sensor to log.

```
sensor(config-sig-ip)# ip-log-time 60
```

**Step 4** Verify the settings.

```
sensor(config-sig-ip)# show settings
ip-log

ip-log-packets: 150 default: 0
ip-log-time: 60 default: 30
ip-log-bytes: 200000 default: 0

sensor(config-sig-ip)#
```

**Step 5** Exit signature definition submode.

```
sensor(config-sig-ip)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:
```

**Step 6** Press **Enter** to apply the changes or enter **no** to discard them.

## Creating Custom Signatures

This section describes how to create custom signatures and contains the following topics:

- [Sequence for Creating a Custom Signature, page 8-41](#)
- [Example String TCP Engine Signature, page 8-41](#)
- [Example Service HTTP Engine Signature, page 8-44](#)
- [Example Meta Engine Signature, page 8-47](#)
- [Example IPv6 Engine Signature, page 8-51](#)
- [Example String XL TCP Engine Match Offset Signature, page 8-52](#)
- [Example String XL TCP Engine Minimum Match Length Signature, page 8-55](#)

## Sequence for Creating a Custom Signature

Use the following sequence when you create a custom signature:

- 
- |               |                                                                                                                                                                                                                         |
|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Select a signature engine.                                                                                                                                                                                              |
| <b>Step 2</b> | Assign the signature identifiers: <ul style="list-style-type: none"><li>• Signature ID</li><li>• SubSignature ID</li><li>• Signature name</li><li>• Alert notes (optional)</li><li>• User comments (optional)</li></ul> |
| <b>Step 3</b> | Assign the engine-specific parameters. The parameters differ for each signature engine, although there is a group of master parameters that applies to each engine.                                                     |
| <b>Step 4</b> | Assign the alert response: <ul style="list-style-type: none"><li>• Signature fidelity rating</li><li>• Severity of the alert</li></ul>                                                                                  |
| <b>Step 5</b> | Assign the alert behavior.                                                                                                                                                                                              |
| <b>Step 6</b> | Apply the changes.                                                                                                                                                                                                      |
- 

## Example String TCP Engine Signature

The String engine is a generic-based pattern-matching inspection engine for ICMP, TCP, and UDP protocols. The String engine uses a regular expression engine that can combine multiple patterns into a single pattern-matching table allowing for a single search through the data. There are three String engines: String ICMP, String TCP, and String UDP.

**Caution**

A custom signature can affect the performance of your sensor. Test the custom signature against a baseline sensor performance for your network to determine the overall impact of the signature.

**Note**

This procedure also applies to String UDP and ICMP signatures.

The following options apply:

- **default**—Sets the value back to the system default setting.
- **direction**—Specifies the direction of the traffic:
  - **from-service**—Traffic from service port destined to client port.
  - **to-service**—Traffic from client port destined to service port.
- **event-action**—Specifies the action(s) to perform when alert is triggered:
  - **deny-attacker-inline** (inline only)—Does not transmit this packet and future packets from the attacker address for a specified period of time.

- **deny-attacker-service-pair-inline** (inline only)—Does not transmit this packet and future packets on the attacker address victim port pair for a specified period of time.
- **deny-attacker-victim-pair-inline** (inline only)—Does not transmit this packet and future packets on the attacker/victim address pair for a specified period of time.
- **deny-connection-inline** (inline only)—Does not transmit this packet and future packets on the TCP flow.
- **deny-packet-inline** (inline only)—Does not transmit this packet.
- **log-attacker-packets**—Starts IP logging of packets containing the attacker address.
- **log-pair-packets**—Starts IP logging of packets containing the attacker-victim address pair.
- **log-victim-packets**—Starts IP logging of packets containing the victim address.
- **produce-alert** —Writes the event to the Event Store as an alert.
- **produce-verbose-alert**—Includes an encoded dump (possibly truncated) of the offending packet in the alert.
- **request-block-connection**—Sends a request to the ARC to block this connection.
- **request-block-host**—Sends a request to the ARC to block this attacker host.
- **request-rate-limit**—Sends a rate limit request to the ARC to perform rate limiting.
- **request-snmp-trap**—Sends a request to the Notification Application component of the sensor to perform SNMP notification.
- **reset-tcp-connection**—Sends TCP resets to hijack and terminate the TCP flow.
- **modify-packet-inline**—Modifies packet data to remove ambiguity about what the end point might do with the packet.
- **no**—Removes an entry or selection setting.
- **regex-string** —Specifies a regular expression to search for in a single TCP packet.
- **service-ports**—Specifies the ports or port ranges where the target service may reside. The valid range is 0 to 65535. It is a separated list of integer ranges a-b[,c-d] within 0 to 65535. The second number in the range must be greater than or equal to the first number.
- **specify-exact-match-offset {yes | no}**—(Optional) Enables exact match offset:
  - **exact-match-offset**—Specifies the exact stream offset the regular expression string must report for a match to be valid. The value is 0 to 65535.
- **specify-min-match-length {yes | no}**—(Optional) Enables minimum match length:
  - **min-match-length**—Specifies the minimum number of bytes the regular expression string must match. The value is 0 to 65535.
- **strip-telnet-options {true | false}**—Strips the Telnet option characters from the data before the pattern is searched.
- **swap-attacker-victim {true | false}**—Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken. The default is false.

### Creating a String TCP Engine Signature

To create a signature based on the String TCP engine, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator or operator privileges.
- Step 2** Enter signature definition submode.
- ```
sensor# configure terminal
sensor(config)# service signature-definition sig1
```
- Step 3** Specify a signature ID and subsignature ID for the signature. Custom signatures are in the range of 60000 to 65000.
- ```
sensor(config-sig)# signatures 60025 0
```
- Step 4** Enter signature description submode.
- ```
sensor(config-sig-sig)# sig-description
```
- Step 5** Specify a name for the new signature. You can also specify a additional comments about the sig using the **sig-comment** command or additional information about the signature using the **sig-string-info** command.
- ```
sensor(config-sig-sig-sig)# sig-name This is my new name
```
- Step 6** Exit signature description submode.
- ```
sensor(config-sig-sig-sig)# exit
```
- Step 7** Specify the string TCP engine.
- ```
sensor(config-sig-sig)# engine string-tcp
```
- Step 8** Specify the service ports.
- ```
sensor(config-sig-sig-str)# service-ports 23
```
- Step 9** Specify the direction.
- ```
sensor(config-sig-sig-str)# direction to-service
```
- Step 10** Specify the regex string to search for in the TCP packet. You can change the event actions if needed according to your security policy using the **event-action** command. The default event action is **produce-alert**.
- ```
sensor(config-sig-sig-str)# regex-string This-is-my-new-Sig-regex
```
- Step 11** You can modify the following optional parameters for this custom String TCP signature:
- **specify-exact-match-offset**
 - **specify-min-match-length**
 - **strip-telnet-options**
 - **swap-attacker-victim**.
- Step 12** Verify the settings.
- ```
sensor(config-sig-sig-str)# show settings
string-tcp

event-action: produce-alert <defaulted>
strip-telnet-options: false <defaulted>
specify-min-match-length

```

```

no

regex-string: This-is-my-new-Sig-regex
service-ports: 23
direction: to-service default: to-service
specify-exact-match-offset

no

specify-max-match-offset

no

specify-min-match-offset

no

swap-attacker-victim: false <defaulted>

sensor(config-sig-sig-str)#

```

**Step 13** Exit signature definition submode.

```

sensor(config-sig-sig-str)# exit
sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:

```

**Step 14** Press **Enter** to apply the changes or enter **no** to discard them.

## Example Service HTTP Engine Signature

The Service HTTP engine is a service-specific string-based pattern-matching inspection engine. The HTTP protocol is one of the most commonly used in networks of today. In addition, it requires the most amount of preprocessing time and has the most number of signatures requiring inspection making it critical to the overall performance of the system.

The Service HTTP engine uses a Regex library that can combine multiple patterns into a single pattern-matching table allowing a single search through the data. This engine searches traffic directed only to web services, or HTTP requests. You cannot inspect return traffic with this engine. You can specify separate web ports of interest in each signature in this engine.

HTTP deobfuscation is the process of decoding an HTTP message by normalizing encoded characters to ASCII equivalent characters. It is also known as ASCII normalization.

Before an HTTP packet can be inspected, the data must be deobfuscated or normalized to the same representation that the target system sees when it processes the data. It is ideal to have a customized decoding technique for each host target type, which involves knowing what operating system and web server version is running on the target. The Service HTTP engine has default deobfuscation behavior for the Microsoft IIS web server.

The following options apply:

- **de-obfuscate {true | false}**—Applies anti-evasive deobfuscation before searching.
- **default**—Sets the value back to the system default setting.
- **event-action** —Specifies the action(s) to perform when alert is triggered:
  - **deny-attacker-inline** (inline only)—Does not transmit this packet and future packets from the attacker address for a specified period of time.
  - **deny-attacker-service-pair-inline** (inline only)—Does not transmit this packet and future packets on the attacker address victim port pair for a specified period of time.
  - **deny-attacker-victim-pair-inline** (inline only)—Does not transmit this packet and future packets on the attacker/victim address pair for a specified period of time.
  - **deny-connection-inline** (inline only)—Does not transmit this packet and future packets on the TCP flow.
  - **deny-packet-inline** (inline only)—Does not transmit this packet.
  - **log-attacker-packets**—Starts IP logging of packets containing the attacker address.
  - **log-pair-packets**—Starts IP logging of packets containing the attacker-victim address pair.
  - **log-victim-packets**—Starts IP logging of packets containing the victim address.
  - **produce-alert** —Writes the event to the Event Store as an alert.
  - **produce-verbose-alert**—Includes an encoded dump (possibly truncated) of the offending packet in the alert.
  - **request-block-connection**—Sends a request to the ARC to block this connection.
  - **request-block-host**—Sends a request to the ARC to block this attacker host.
  - **request-rate-limit**—Sends a rate limit request to the ARC to perform rate limiting.
  - **request-snmp-trap**—Sends a request to the Notification Application component of the sensor to perform SNMP notification.
  - **reset-tcp-connection**—Sends TCP resets to hijack and terminate the TCP flow.
  - **modify-packet-inline**—Modifies packet data to remove ambiguity about what the end point might do with the packet.
- **max-field-sizes** —Grouping for maximum field sizes:
  - **specify-max-arg-field-length {yes | no}**—Enables max-arg-field-length (optional).
  - **specify-max-header-field-length {yes | no}**—Enables max-header-field-length (optional).
  - **specify-max-request-length {yes | no}**—Enables max-request-length (optional).
  - **specify-max-uri-field-length {yes | no}**—Enables max-uri-field-length (optional).
- **no**—Removes an entry or selection setting.
- **regex**—Regular expression grouping:
  - **specify-arg-name-regex**—Enables arg-name-regex (optional).
  - **specify-header-regex** —Enables header-regex (optional).
  - **specify-request-regex**—Enables request-regex (optional).
  - **specify-uri-regex**—Enables uri-regex (optional).
- **service-ports** —A comma-separated list of ports or port ranges where the target service may reside.

- **swap-attacker-victim {true | false}**—Whether address (and ports) source and destination are swapped in the alarm message. The default is false for no swapping.

### Creating a Service HTTP Engine Signature

To create a custom signature based on the Service HTTP engine, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator or operator privileges.
- Step 2** Enter signature definition submode.
- ```
sensor# configure terminal
sensor(config)# service signature-definition sig1
```
- Step 3** Specify a signature ID and a subsignature ID for the signature. Custom signatures are in the range of 60000 to 65000.
- ```
sensor(config-sig)# signatures 63000 0
```
- Step 4** Enter signature description mode.
- ```
sensor(config-sig-sig)# sig-description
```
- Step 5** Specify a signature name.
- ```
sensor(config-sig-sig-sig)# sig-name myWebSig
```
- Step 6** Specify the alert traits. The valid range is from 0 to 65535.
- ```
sensor(config-sig-sig-sig)# alert-traits 2
```
- Step 7** Exit signature description submode.
- ```
sensor(config-sig-sig-sig)# exit
```
- Step 8** Specify the alert frequency.
- ```
sensor(config-sig-sig)# alert-frequency
sensor(config-sig-sig-ale)# summary-mode fire-all
sensor(config-sig-sig-ale-fir)# summary-key Axxx
sensor(config-sig-sig-ale-fir)# specify-summary-threshold yes
sensor(config-sig-sig-ale-fir-yes)# summary-threshold 200
```
- Step 9** Exit alert frequency submode.
- ```
sensor(config-sig-sig-ale-fir-yes)# exit
sensor(config-sig-sig-ale-fir)# exit
sensor(config-sig-sig-ale)# exit
```
- Step 10** Configure the signature to apply anti-evasive deobfuscation before searching:
- ```
sensor(config-sig-sig)# engine service-http
sensor(config-sig-sig-ser)# de-obfuscate true
```


Step 11 Configure the Regex parameters.

```
sensor(config-sig-sig)# engine service-http
sensor(config-sig-sig-ser)# regex
sensor(config-sig-sig-ser-reg)# specify-uri-regex yes
sensor(config-sig-sig-ser-reg-yes)# uri-regex [Mm][Yy][Ff][Oo][Oo]
```

Step 12 Exit Regex submode.

```
sensor(config-sig-sig-ser-reg-yes)# exit
sensor(config-sig-sig-ser-reg)# exit
```

Step 13 Configure the service ports using the signature variable WEBPORTS.

```
sensor(config-sig-sig-ser)# service-ports $WEBPORTS
```

Step 14 Exit signature definition submode.

```
sensor(config-sig-sig-ser)# exit
sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:
```

Step 15 Press **Enter** to apply the changes or enter **no** to discard them.

Example Meta Engine Signature



Caution

A custom signature can affect the performance of your sensor. Test the custom signature against a baseline sensor performance for your network to determine the overall impact of the signature.

The Meta engine is different from other engines in that it takes alerts as input where most engines take packets as input.

The following options apply:

- **component-list** *name1*—Specifies the list of Meta components:
 - **edit**—Edits an existing entry in the list.
 - **insert**—Inserts a new entry into the list.
 - **move**—Moves an entry in the list.
 - **begin**—Places the entry at the beginning of the active list.
 - **end**—Places the entry at the end of the active list.
 - **inactive**—Places the entry into the inactive list.
 - **before**—Places the entry before the specified entry.
 - **after**—Places the entry after the specified entry.
 - **component-count**—Specifies the number of times component must fire before this component is satisfied.
 - **component-sig-id**—Specifies the signature ID of the signature to match this component on.
 - **component-subsig-id**—Specifies the subsignature ID of the signature to match this component on.

- **is-not-component {true | false}**—Specifies that the component is a NOT component.
- **component-list-in-order {true | false}**—Specifies whether to have the component list fire in order. For example, if signature 1001 in the m2 component fires before signature 1000 in the m1 component, the Meta signature will not fire.
- **all-components-required {true | false}**—Specifies to use all components. This option works with the **all-not-components-required** option, if you have NOT components configured as required, the Meta signature will not fire.
- **all-not-components-required {true | false}**—Specifies to use all of the NOT components.
- **swap-attacker-victim {true | false}**—Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.
- **meta-reset-interval**—Specifies the time in seconds to reset the Meta signature. The valid range is 0 to 3600 seconds. The default is 60 seconds.
- **meta-key**—Specifies the storage type for the Meta signature:
 - **AaBb**—Attacker and victim addresses and ports.
 - **AxBx**—Attacker and victim addresses.
 - **Axxx**—Attacker address.
 - **xxBx**—Victim address.
- **unique-victim-ports**—Specifies the number of unique victims ports required per Meta signature. The valid range is 1 to 256.
- **event-action**—Specifies the action(s) to perform when an alert is triggered:
 - **deny-attacker-inline** (inline only)—Does not transmit this packet and future packets from the attacker address for a specified period of time.
 - **deny-attacker-service-pair-inline** (inline only)—Does not transmit this packet and future packets on the attacker address victim port pair for a specified period of time.
 - **deny-attacker-victim-pair-inline** (inline only)—Does not transmit this packet and future packets on the attacker/victim address pair for a specified period of time.
 - **deny-connection-inline** (inline only)—Does not transmit this packet and future packets on the TCP flow.
 - **deny-packet-inline** (inline only)—Does not transmit this packet.
 - **log-attacker-packets**—Starts IP logging of packets containing the attacker address.
 - **log-pair-packets**—Starts IP logging of packets containing the attacker-victim address pair.
 - **log-victim-packets**—Starts IP logging of packets containing the victim address.
 - **produce-alert** —Writes the event to the Event Store as an alert.
 - **produce-verbose-alert**—Includes an encoded dump (possibly truncated) of the offending packet in the alert.
 - **request-block-connection**—Sends a request to the ARC to block this connection.
 - **request-block-host**—Sends a request to the ARC to block this attacker host.
 - **request-rate-limit**—Sends a rate limit request to the ARC to perform rate limiting.
 - **request-snmp-trap**—Sends a request to the Notification Application component of the sensor to perform SNMP notification.
 - **reset-tcp-connection**—Sends TCP resets to hijack and terminate the TCP flow.

- **modify-packet-inline**—Modifies packet data to remove ambiguity about what the end point might do with the packet.

**Note**

Signature 64000 subsignature 0 will fire when it sees the alerts from signature 1000 subsignature 0 and signature 1001 subsignature 0 on the same source address. The source address selection is a result of the meta key default value of Axxx. You can change the behavior by changing the meta key setting to xxBx (destination address) for example.

Creating a Meta Engine Signature

To create a signature based on the Meta engine, follow these steps:

Step 1 Log in to the CLI using an account with administrator or operator privileges.

Step 2 Enter signature definition submode.

```
sensor# configure terminal
sensor(config)# service signature-definition sig1
```

Step 3 Specify a signature ID and a subsignature ID for the signature. Custom signatures are in the range of 60000 to 65000.

```
sensor(config-sig)# signatures 64000 0
```

Step 4 Specify the signature engine.

```
sensor(config-sig-sig)# engine meta
```

Step 5 Insert a signature (named m1) at the beginning of the list.

```
sensor(config-sig-sig-met)# component-list insert m1 begin
```

Step 6 Specify the signature ID of the signature on which to match this component.

```
sensor(config-sig-sig-met-com)# component-sig-id 1000
```

Step 7 Exit component list submode.

```
sensor(config-sig-sig-met-com)# exit
```

Step 8 Insert another signature (named m2) at the end of the list.

```
sensor(config-sig-sig-met)# component-list insert m2 end
```

Step 9 Specify the signature ID of the signature on which to match this component.

```
sensor(config-sig-sig-met-com)# component-sig-id 1001
```

Step 10 Configure the component list not to fire in order.

```
sensor(config-sig-sig-met-com)# component-list-in-order false
```

Step 11 Specify to use all components you have created.

```
sensor(config-sig-sig-met-com)# all-components-required true
```

Step 12 Specify not to use all of the NOT components.

```
sensor(config-sig-sig-met-com)# all-not-components-required false
```

Step 13 Verify the settings.

```
sensor(config-sig-sig-met-com)# exit
sensor-128(config-sig-sig-met)# show settings
```

```

meta
-----
event-action: produce-alert <defaulted>
swap-attacker-victim: false <defaulted>
meta-reset-interval: 60 <defaulted>
component-list (ordered min: 1, max: 32, current: 2 - 2 active, 0 inactive)
-----
ACTIVE list-contents
-----
    NAME: m1
    -----
        component-sig-id: 1000
        component-subsig-id: 0 default: 0
        component-count: 1 default: 1
        is-not-component: false <defaulted>
        -----
    NAME: m2
    -----
        component-sig-id: 1001
        component-subsig-id: 0 <defaulted>
        component-count: 1 <defaulted>
        is-not-component: true default: false
        -----
meta-key
-----
    Axxx
    -----
        unique-victims: 1 <defaulted>
        -----
        component-list-in-order: false default: false
        all-components-required: true default: true
        all-nots-required: false default: false
        -----
sensor(config-sig-sig-met)#

```

Step 14 Exit signature definition submode.

```

sensor(config-sig-sig-met)# exit
sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:

```

Step 15 Press **Enter** to apply the changes or enter **no** to discard them.

For More Information

- For more information on Signature Event Action Processor, see [Signature Event Action Processor, page 7-3](#).
- For more information on the Meta engine, see [Meta Engine, page B-33](#).

Example IPv6 Engine Signature



Caution

A custom signature can affect the performance of your sensor. Test the custom signature against a baseline sensor performance for your network to determine the overall impact of the signature.

The following example Atomic IP Advanced custom signature prohibits Protocol ID 88 over IPv6. To create a signature based on the Atomic IP Advanced signature engine, follow these steps:

Step 1 Log in to the CLI using an account with administrator or operator privileges.

Step 2 Enter signature definition submode.

```
sensor# configure terminal
sensor(config)# service signature-definition sig0
```

Step 3 Specify a signature ID and a subsignature ID for the signature. Custom signatures are in the range of 60000 to 65000.

```
sensor(config-sig)# signatures 60000 0
```

Step 4 Specify the signature engine.

```
sensor(config-sig-sig)# engine atomic-ip-advanced
```

Step 5 Specify the IP version.

```
sensor(config-sig-sig-ato)# specify-ip-version yes
```

Step 6 Specify IPv6.

```
sensor(config-sig-sig-ato-yes)# version ipv6
```

Step 7 Specify the L4 protocol.

```
sensor(config-sig-sig-ato-yes-ipv)# exit
sensor(config-sig-sig-ato-yes)# exit
sensor(config-sig-sig-ato)# specify-l4-protocol yes
```

Step 8 Specify protocol ID 88.

```
sensor(config-sig-sig-ato-yes)# l4-protocol other-protocol
sensor(config-sig-sig-ato-yes-oth)# other-ip-protocol-id 88
```

Step 9 Verify the settings.

```
sensor(config-sig-sig-ato-yes-oth)# show settings
other-protocol
-----
other-ip-protocol-id: 88
-----
sensor(config-sig-sig-ato-yes-oth)#
```

Step 10 Exit signature definition submode.

```
sensor(config-sig-sig-ato-yes-oth)# exit
sensor(config-sig-sig-ato-yes)# exit
sensor(config-sig-sig-ato)# exit
sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes?[yes]:
```

Step 11 Press **Enter** to apply the changes or enter **no** to discard them.

For More Information

- For more information about the Atomic IP Advanced engine and a list of the parameters, see [Atomic IP Advanced Engine, page B-15](#).
- For more information on the Atomic engines, see [Atomic Engine, page B-14](#).

Example String XL TCP Engine Match Offset Signature



Caution

A custom signature can affect the performance of your sensor. Test the custom signature against a baseline sensor performance for your network to determine the overall impact of the signature.



Note

This procedure also applies to String XLUDP and String XL ICMP signatures, with the exception of the parameter **service-ports**, which does not apply to String XL ICMP signatures.

The following example demonstrates how to create a custom String XL TCP signature that searches for exact, maximum, or minimum offsets. You can modify the following optional match offset parameters for this custom String XL TCP signature:

- **specify-exact-match-offset {yes |no}**—Enables exact match offset:
 - **exact-match-offset**—Specifies the exact stream offset in bytes the regular expression string must report for a match to be valid. The value is 0 to 65535.
- **specify-max-match-offset {yes |no}**—Enables maximum match length:
 - **max-match-offset**—Specifies the maximum stream offset in bytes the regular expression string must report for a match to be valid. The value is 0 to 65535.
- **specify-min-match-offset {yes |no}**—Enables minimum match offset:
 - **min-match-offset**—Specifies the minimum stream offset in bytes the regular expression string must report for a match to be valid. The value is 0 to 65535.

Creating a String XL TCP Engine Signature

To create a custom signature based on the String XL TCP engine that searches for matches, follow these steps:

Step 1 Log in to the CLI using an account with administrator or operator privileges.

Step 2 Enter signature definition submode.

```
sensor# configure terminal
sensor(config)# service signature-definition sig1
```

Step 3 Specify a signature ID and subsignature ID for the signature. Custom signatures are in the range of 60000 to 65000.

```
sensor(config-sig)# signatures 60003 0
```

Step 4 Enter signature description submode.

```
sensor(config-sig-sig)# sig-description
```

Step 5 Specify a name for the new signature. You can also specify additional comments about the sig using the **sig-comment** command or additional information about the signature using the **sig-string-info** command.

```
sensor(config-sig-sig-sig)# sig-name This is my new name
```

Step 6 Exit signature description submode.

```
sensor(config-sig-sig-sig)# exit
```

Step 7 Specify the String XL TCP engine.

```
sensor(config-sig-sig)# engine string-xl-tcp
```

Step 8 Specify the service ports.

```
sensor(config-sig-sig-str)# service-ports 80
```

Step 9 Specify the direction.

```
sensor(config-sig-sig-str)# direction to-service
```

Step 10 Change the event actions if needed according to your security policy by using the **event-action** command. The default event action is **produce-alert**.

Step 11 Make sure raw regex is turned off:

```
sensor(config-sig-sig-str)# specify-raw-regex-string no
```



Note

Raw Regex is regular expression syntax used for raw mode processing. It is expert mode only and targeted for use by the Cisco IPS signature development team or only those who are under supervision by the Cisco IPS signature development team. You can configure a String XL signature in either regular Regex or raw Regex.

Step 12 Specify the regex string to search for in the TCP packet.

```
sensor(config-sig-sig-str-no)# regex-string tcpstring
```

Step 13 Exit raw regex mode to configure optional String XL TCP parameters.

```
sensor(config-sig-sig-str-no)# exit  
sensor(config-sig-sig-str)#
```

Step 14 Specify an exact match offset for this signature.

```
sensor(config-sig-sig-str)# specify-exact-match-offset yes  
sensor(config-sig-sig-str-yes)# exact-match-offset 20
```



Note

If you have exact match offset set to yes, you cannot configure maximum or minimum match offset. If you have exact match offset set to no, you can configure both maximum and minimum match offset at the same time.

Step 15 Turn off exact match offset and specify a maximum match offset for this signature.

```
sensor(config-sig-sig-str-yes)# exit  
sensor(config-sig-sig-str)# specify-exact-match-offset no  
sensor(config-sig-sig-str-no)# specify-max-match-offset yes
```

```
sensor(config-sig-sig-str-no-yes)# max-match-offset 30
```

Step 16 Specify a minimum match offset for this signature.

```
sensor(config-sig-sig-str-no-yes)# exit
sensor(config-sig-sig-str-no)# specify-min-match-offset yes
sensor(config-sig-sig-str-no-yes)# min-match-offset 20
```

Step 17 Verify the settings.

```
sensor(config-sig-sig-str-no-yes)# exit
sensor(config-sig-sig-str-no)# exit
sensor(config-sig-sig-str)# show settings
string-xl-tcp
-----
event-action: produce-alert <defaulted>
strip-telnet-options: false <defaulted>
direction: to-service default: to-service
service-ports: 80
specify-max-stream-length
-----
no
-----
-----
-----
specify-raw-regex-string
-----
no
-----
-----
regex-string: tcpstring
dot-all: false <defaulted>
end-optional: false <defaulted>
no-case: false <defaulted>
stingy: false <defaulted>
utf8: false <defaulted>
specify-min-match-length
-----
no
-----
-----
-----
swap-attacker-victim: false <defaulted>
specify-exact-match-offset
-----
no
-----
specify-max-match-offset
-----
yes
-----
max-match-offset: 30
-----
specify-min-match-offset
-----
yes
-----
min-match-offset: 20
-----
-----
-----
-----
```



```
-----
sensor(config-sig-sig-str)#
```

Step 18 Exit signature definition submode.

```
sensor(config-sig-sig-str)# exit
sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:
```

Step 19 Press **Enter** to apply the changes or enter **no** to discard them.

For More Information

For detailed information about the String XL signature engine, see [String XL Engines, page B-66](#).

Example String XL TCP Engine Minimum Match Length Signature



Caution

A custom signature can affect the performance of your sensor. Test the custom signature against a baseline sensor performance for your network to determine the overall impact of the signature.



Note

This procedure also applies to String XL UDP and String XL ICMP signatures, with the exception of the parameter **service-ports**, which does not apply to String XL ICMP signatures.

You can modify the following optional parameters to work with a specific Regex string:

- **dot-all true {true | false}**—If set to true, matches [\x00-\xFF] including \n; if set to false, matches anything in the range [\x00-\xFF] except \n. The default is false.
- **specify-min-match-length {yes | no}**—Enables minimum match length:
 - **min-match-length**—Specifies the maximum number of bytes the regular expression string must match for the pattern to be considered a hit. The value is 0 to 65535.
- **stingy {true | false}**—If set to true, specifies to stop looking for larger matches after the first completed match. The default is false.



Note

Stingy can only be used with **min-match-length**; otherwise, it is ignored.

- **utf8 {true | false}**—If set to true, treats all legal UTF-8 byte sequences in the expression as a single character. The default is false.

Creating a String XL TCP Engine Signature

The following example demonstrates how to create a custom String XL TCP signature that searches for minimum match length with stingy, dot all, and UTF-8 turned on.

To create a custom signature based on the String XL TCP engine that searches for minimum match length with stingy, dot all, and UTF-8 turned on, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator or operator privileges.
- Step 2** Enter signature definition submode.
- ```
sensor# configure terminal
sensor(config)# service signature-definition sig1
```
- Step 3** Specify a signature ID and subsignature ID for the signature.
- ```
sensor(config-sig)# signatures 60004 0
```
- Custom signatures are in the range of 60000 to 65000.
- Step 4** Enter signature description submode.
- ```
sensor(config-sig-sig)# sig-description
```
- Step 5** Specify a name for the new signature. You can also specify a additional comments about the sig using the **sig-comment** command or additional information about the signature using the **sig-string-info** command.
- ```
sensor(config-sig-sig-sig)# sig-name This is my new name
```
- Step 6** Exit signature description submode.
- ```
sensor(config-sig-sig-sig)# exit
```
- Step 7** Specify the String XL TCP engine.
- ```
sensor(config-sig-sig)# engine string-xl-tcp
```
- Step 8** Specify the service ports.
- ```
sensor(config-sig-sig-str)# service-ports 80
```
- Step 9** Specify the direction.
- ```
sensor(config-sig-sig-str)# direction to-service
```
- Step 10** Change the event actions if needed according to your security policy by using the **event-action** command. The default event action is **produce-alert**.
- Step 11** Make sure raw regex is turned off:
- ```
sensor(config-sig-sig-str)# specify-raw-regex-string no
```



**Note** Raw Regex is regular expression syntax used for raw mode processing. It is expert mode only and targeted for use by the Cisco IPS signature development team or only those who are under supervision by the Cisco IPS signature development team. You can configure a String XL signature in either regular Regex or raw Regex.

- Step 12** Specify the regex string to search for in the TCP packet with dot all turned on.

```
sensor(config-sig-sig-str-no)# regex-string ht+p[\r].
sensor(config-sig-sig-str-no)# dot-all true
```

**Step 13** Specify a minimum match length for this signature that can only be used with stingy.

```
sensor(config-sig-sig-str-no)# specify-min-match-length yes
sensor(config-sig-sig-str-no-yes)# min-match-length 100
sensor(config-sig-sig-str-no-yes)# exit
sensor(config-sig-sig-str-no)# stingy true
```

**Step 14** Verify the settings.

```
sensor(config-sig-sig-str-no)# show settings
no

regex-string: ht+p[\r\].
dot-all: true default: false
end-optional: false <defaulted>
no-case: false <defaulted>
stingy: true default: false
utf8: false <defaulted>
specify-min-match-length

yes

min-match-length: 100

sensor(config-sig-sig-str-no)#
```

**Step 15** Specify a new Regex string to search for and turn on UTF-8.

```
sensor(config-sig-sig-str-no)# regex-string \x5c\x31\x30\x2e\x30[\x00-\xff]+\
x2e\x31\x5c\x74\x65\x6d\x70
sensor(config-sig-sig-str-no)# utf8 true
```

**Step 16** Verify the settings:

```
sensor(config-sig-sig-str-no)# show settings
no

regex-string: \x5c\x31\x30\x2e\x30[\x00-\xff]+\x2e\x31\x5c\x74\x65\x6d\x70
dot-all: true default: false
end-optional: false <defaulted>
no-case: false <defaulted>
stingy: true default: false
utf8: true default: false
specify-min-match-length

yes

min-match-length: 100

sensor(config-sig-sig-str-no)#
```

**Step 17** Exit signature definition submenu.

```
sensor(config-sig-sig-str-no)# exit
sensor(config-sig-sig-str)# exit
sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:
```

**Step 18** Press **Enter** to apply the changes or enter **no** to discard them.

---

**For More Information**

For detailed information about the String XL signature engine, see [String XL Engines, page B-66](#).



# Configuring Anomaly Detection

---

This chapter describes anomaly detection (AD) and its features and how to configure them. This chapter contains the following topics:

- [Anomaly Detection Notes and Caveats, page 9-2](#)
- [Understanding Security Policies, page 9-2](#)
- [Understanding Anomaly Detection, page 9-2](#)
- [Understanding Worms, page 9-2](#)
- [Anomaly Detection Modes, page 9-3](#)
- [Anomaly Detection Zones, page 9-4](#)
- [Anomaly Detection Configuration Sequence, page 9-5](#)
- [Anomaly Detection Signatures, page 9-6](#)
- [Enabling Anomaly Detection, page 9-8](#)
- [Working With Anomaly Detection Policies, page 9-9](#)
- [Configuring Anomaly Detection Operational Settings, page 9-10](#)
- [Configuring the Internal Zone, page 9-12](#)
- [Configuring the Illegal Zone, page 9-20](#)
- [Configuring the External Zone, page 9-29](#)
- [Configuring Learning Accept Mode, page 9-37](#)
- [Working With KB Files, page 9-40](#)
- [Displaying Anomaly Detection Statistics, page 9-47](#)
- [Disabling Anomaly Detection, page 9-49](#)

# Anomaly Detection Notes and Caveats

The following notes and caveats apply to configuring anomaly detection:

- Anomaly detection is disabled by default in IPS 7.1(2)E4 and later. You must enable it to configure or apply an anomaly detection policy. Enabling anomaly detection results in a decrease in performance.
- Anomaly detection assumes it gets traffic from both directions. If the sensor is configured to see only one direction of traffic, you should turn off anomaly detection. Otherwise, when anomaly detection is running in an asymmetric environment, it identifies all traffic as having incomplete connections, that is, as scanners, and sends alerts for all traffic flows. Using asymmetric mode protection with anomaly detection enabled causes excessive resource usage and possible false positives for anomaly detection signatures.

## Understanding Security Policies

You can create multiple security policies and apply them to individual virtual sensors. A security policy is made up of a signature definition policy, an event action rules policy, and an anomaly detection policy. Cisco IPS contains a default signature definition policy called sig0, a default event action rules policy called rules0, and a default anomaly detection policy called ad0. You can assign the default policies to a virtual sensor or you can create new policies. The use of multiple security policies lets you create security policies based on different requirements and then apply these customized policies per VLAN or physical interface.

## Understanding Anomaly Detection

The anomaly detection component of the sensor detects worm-infected hosts. This enables the sensor to be less dependent on signature updates for protection against worms and scanners, such as Code Red and SQL Slammer and so forth. The anomaly detection component lets the sensor learn normal activity and send alerts or take dynamic response actions for behavior that deviates from what it has learned as normal behavior.

**Note**

Anomaly detection does not detect email-based worms, such as Nimda.

Anomaly detection detects the following two situations:

- When the network starts on the path of becoming congested by worm traffic.
- When a single worm-infected source enters the network and starts scanning for other vulnerable hosts.

## Understanding Worms

**Caution**

Anomaly detection assumes it gets traffic from both directions. If the sensor is configured to see only one direction of traffic, you should turn off anomaly detection. Otherwise, when anomaly detection is running in an asymmetric environment, it identifies all traffic as having incomplete connections, that is,

as scanners, and sends alerts for all traffic flows. Using asymmetric mode protection with anomaly detection enabled causes excessive resource usage and possible false positives for anomaly detection signatures.

Worms are automated, self-propagating, intrusion agents that make copies of themselves and then facilitate their spread. Worms attack a vulnerable host, infect it, and then use it as a base to attack other vulnerable hosts. They search for other hosts by using a form of network inspection, typically a scan, and then propagate to the next target. A scanning worm locates vulnerable hosts by generating a list of IP addresses to probe, and then contacts the hosts. Code Red worm, Sasser worm, Blaster worm, and the Slammer worm are examples of worms that spread in this manner.

Anomaly detection identifies worm-infected hosts by their behavior as scanners. To spread, a worm must find new hosts. It finds them by scanning the Internet or network using TCP, UDP, and other protocols to generate unsuccessful attempts to access different destination IP addresses. A scanner is defined as a source IP address that generates events on the same destination port (in TCP and UDP) for too many destination IP addresses.

The events that are important for TCP protocol are nonestablished connections, such as a SYN packet that does not have its SYN-ACK response for a given amount of time. A worm-infected host that scans using TCP protocol generates nonestablished connections on the same destination port for an anomalous number of IP addresses.

The events that are important for UDP protocol are unidirectional connections, such as a UDP connection where all packets are going only in one direction. A worm-infected host that scans using UDP protocol generates UDP packets but does not receive UDP packets on the same quad within a timeout period on the same destination port for multiple destination IP addresses.

The events that are important for other protocols, such as ICMP, are from a source IP address to many different destination IP addresses, that is, packets that are received in only one direction.

**Caution**

If a worm has a list of IP addresses it should infect and does not have to use scanning to spread itself (for example, it uses passive mapping—listening to the network as opposed to active scanning), it is not detected by the anomaly detection worm policies. Worms that receive a mailing list from probing files within the infected host and email this list are also not detected, because no Layer 3/Layer 4 anomaly is generated.

**For More Information**

For the procedure for turning off anomaly detection, see [Disabling Anomaly Detection, page 9-49](#).

## Anomaly Detection Modes

If you have anomaly detection enabled, it initially conducts a “peacetime” learning process when the most normal state of the network is reflected. Anomaly detection then derives a set of policy thresholds that best fit the normal network.

Anomaly detection has the following modes:

- Learning accept mode—Anomaly detection conducts an initial learning accept mode for the default period of 24 hours. We assume that during this phase no attack is being carried out. Anomaly detection creates an initial baseline, known as a knowledge base (KB), of the network traffic. The default interval value for periodic schedule is 24 hours and the default action is rotate, meaning that a new KB is saved and loaded, and then replaces the initial KB after 24 hours.

**Note**

Anomaly detection does not detect attacks when working with the initial KB, which is empty. After the default of 24 hours, a KB is saved and loaded and now anomaly detection also detects attacks.

**Note**

Depending on your network complexity, you may want to have anomaly detection in learning accept mode for longer than the default 24 hours.

- Detect mode—For ongoing operation, the sensor should remain in detect mode. This is for 24 hours a day, 7 days a week. Once a KB is created and replaces the initial KB, anomaly detection detects attacks based on it. It looks at the network traffic flows that violate thresholds in the KB and sends alerts. As anomaly detection looks for anomalies, it also records gradual changes to the KB that do not violate the thresholds and thus creates a new KB. The new KB is periodically saved and takes the place of the old one thus maintaining an up-to-date KB.
- Inactive mode—You can turn anomaly detection off by putting it in inactive mode. Under certain circumstances, anomaly detection should be in inactive mode, for example, if the sensor is running in an asymmetric environment. Because anomaly detection assumes it gets traffic from both directions, if the sensor is configured to see only one direction of traffic, anomaly detection identifies all traffic as having incomplete connections, that is, as scanners, and sends alerts for all traffic flows. Having anomaly detection running also lowers performance.

**Example**

The following example summarizes the default anomaly detection configuration. If you add a virtual sensor at 11:00 pm and do not change the default anomaly detection configuration, anomaly detection begins working with the initial KB and only performs learning. Although it is in detect mode, it cannot detect attacks until it has gathered information for 24 hours and replaced the initial KB. At the first start time (10:00 am by default), and the first interval (24 hours by default), the learning results are saved to a new KB and this KB is loaded and replaces the initial KB. Because the anomaly detection is in detect mode by default, now that anomaly detection has a new KB, the anomaly detection begins to detect attacks.

**For More Information**

- For the procedures for putting anomaly detection in different modes, see [Adding, Editing, and Deleting Virtual Sensors, page 6-5](#).
- For more information about how worms operate, see [Understanding Worms, page 9-2](#).

## Anomaly Detection Zones

By subdividing the network into zones, you can achieve a lower false negative rate. A zone is a set of destination IP addresses. There are three zones, internal, illegal, and external, each with its own thresholds.



The external zone is the default zone with the default Internet range of 0.0.0.0-255.255.255.255. By default, the internal and illegal zones contain no IP addresses. Packets that do not match the set of IP addresses in the internal or illegal zone are handled by the external zone.

We recommend that you configure the internal zone with the IP address range of your internal network. If you configure it in this way, the internal zone is all the traffic that comes to your IP address range, and the external zone is all the traffic that goes to the Internet.

You can configure the illegal zone with IP address ranges that should never be seen in normal traffic, for example, unallocated IP addresses or part of your internal IP address range that is unoccupied. An illegal zone can be very helpful for accurate detection, because we do not expect any legal traffic to reach this zone. This allows very low thresholds, which in turn can lead to very quick worm virus detection.

#### For More Information

For the procedures for configuring zones, see [Configuring the Internal Zone, page 9-12](#), [Configuring the Illegal Zone, page 9-20](#), and [Configuring the External Zone, page 9-29](#).

## Anomaly Detection Configuration Sequence

You can configure the detection part of anomaly detection. You can configure a set of thresholds that override the KB learned thresholds. However, anomaly detection continues learning regardless of how you configure the detection. You can also import, export, and load a KB and you can view a KB for data.

Follow this sequence when configuring anomaly detection:

1. Create an anomaly detection policy to add to the virtual sensors. Or you can use the default anomaly detection policy, `ad0`.
2. Add the anomaly detection policy to your virtual sensors.
3. Enable anomaly detection.
4. Configure the anomaly detection zones and protocols.
5. For the first 24 hours anomaly detection performs learning to create a populated KB. The initial KB is empty and during the default 24 hours, anomaly detection collects data to use to populate the KB. If you want the learning period to be longer than the default period of 24 hours, you must manually set the mode to learning accept.
6. Let the sensor run in learning accept mode for at least 24 hours (the default). You should let the sensor run in learning accept mode for at least 24 hours so it can gather information on the normal state of the network for the initial KB. However, you should change the amount of time for learning accept mode according to the complexity of your network. After the time period, the sensor saves the initial KB as a baseline of the normal activity of your network.



**Note** We recommend leaving the sensor in learning accept mode for at least 24 hours, but letting the sensor run in learning accept mode for longer, even up to a week, is better.

7. If you manually set anomaly detection to learning accept mode, switch back to detect mode.
8. Configure the anomaly detection parameters:
  - Configure the worm timeout and which source and destination IP addresses should be bypassed by anomaly detection. After this timeout, the scanner threshold returns to the configured value.
  - Decide whether you want to enable automatic KB updates when anomaly detection is in detect mode.

- Configure the 18 anomaly detection worm signatures to have more event actions than just the default produce-alert. For example, configure them to have deny-attacker event actions.

#### For More Information

- For the procedures for putting anomaly detection in different modes, see [Adding, Editing, and Deleting Virtual Sensors, page 6-5](#).
- For the procedure for configuring a new anomaly detection policy, see [Working With Anomaly Detection Policies, page 9-9](#).
- For more information on configuring zones, see [Configuring the Internal Zone, page 9-12](#), [Configuring the Illegal Zone, page 9-20](#), and [Configuring the External Zone, page 9-29](#).
- For more information on anomaly detection modes, see [Anomaly Detection Modes, page 9-3](#).
- For more information about configuring learning accept mode, see [Configuring Learning Accept Mode, page 9-37](#).
- For more information on configuring anomaly detection signatures, see [Anomaly Detection Signatures, page 9-6](#).
- For more information on Deny Attacker event actions, see [Event Actions, page 7-5](#).

## Anomaly Detection Signatures

The Traffic Anomaly engine contains nine anomaly detection signatures covering three protocols (TCP, UDP, and other). Each signature has two subsignatures, one for the scanner and the other for the worm-infected host (or a scanner under worm attack). When anomaly detection discovers an anomaly, it triggers an alert for these signatures. All anomaly detection signatures are enabled by default and the alert severity for each one is set to high.

When a scanner is detected but no histogram anomaly occurred, the scanner signature fires for that attacker (scanner) IP address. If the histogram signature is triggered, the attacker addresses that are doing the scanning each trigger the worm signature (instead of the scanner signature). The alert details state which threshold is being used for the worm detection now that the histogram has been triggered. From that point on, all scanners are detected as worm-infected hosts.

The following anomaly detection event actions are possible:

- produce-alert—Writes the event to the Event Store.
- deny-attacker-inline (inline only)—Does not transmit this packet and future packets originating from the attacker address for a specified period of time.
- log-attacker-packets—Starts IP logging for packets that contain the attacker address.
- deny-attacker-service-pair-inline—Blocks the source IP address and the destination port.
- request-snmp-trapRequest—Sends a request to NotificationApp to perform SNMP notification.
- request-block-host—Sends a request to ARC to block this host (the attacker).

Table 9-1 lists the anomaly detection worm signatures.

**Table 9-1 Anomaly Detection Worm Signatures**

Signature ID	Subsignature ID	Name	Description
13000	0	Internal TCP Scanner	Identified a single scanner over a TCP protocol in the internal zone.
13000	1	Internal TCP Scanner	Identified a worm attack over a TCP protocol in the internal zone; the TCP histogram threshold was crossed and a scanner over a TCP protocol was identified.
13001	0	Internal UDP Scanner	Identified a single scanner over a UDP protocol in the internal zone.
13001	1	Internal UDP Scanner	Identified a worm attack over a UDP protocol in the internal zone; the UDP histogram threshold was crossed and a scanner over a UDP protocol was identified.
13002	0	Internal Other Scanner	Identified a single scanner over an Other protocol in the internal zone.
13002	1	Internal Other Scanner	Identified a worm attack over an Other protocol in the internal zone; the Other histogram threshold was crossed and a scanner over an Other protocol was identified.
13003	0	External TCP Scanner	Identified a single scanner over a TCP protocol in the external zone.
13003	1	External TCP Scanner	Identified a worm attack over a TCP protocol in the external zone; the TCP histogram threshold was crossed and a scanner over a TCP protocol was identified.
13004	0	External UDP Scanner	Identified a single scanner over a UDP protocol in the external zone.
13004	1	External UDP Scanner	Identified a worm attack over a UDP protocol in the external zone; the UDP histogram threshold was crossed and a scanner over a UDP protocol was identified.
13005	0	External Other Scanner	Identified a single scanner over an Other protocol in the external zone.
13005	1	External Other Scanner	Identified a worm attack over an Other protocol in the external zone; the Other histogram threshold was crossed and a scanner over an Other protocol was identified.

**Table 9-1** *Anomaly Detection Worm Signatures (continued)*

Signature ID	Subsignature ID	Name	Description
13006	0	Illegal TCP Scanner	Identified a single scanner over a TCP protocol in the illegal zone.
13006	1	Illegal TCP Scanner	Identified a worm attack over a TCP protocol in the illegal zone; the TCP histogram threshold was crossed and a scanner over a TCP protocol was identified.
13007	0	Illegal UDP Scanner	Identified a single scanner over a UDP protocol in the illegal zone.
13007	1	Illegal UDP Scanner	Identified a worm attack over a UDP protocol in the illegal zone; the UDP histogram threshold was crossed and a scanner over a UDP protocol was identified.
13008	0	Illegal Other Scanner	Identified a single scanner over an Other protocol in the illegal zone.
13008	1	Illegal Other Scanner	Identified a worm attack over an Other protocol in the illegal zone; the Other histogram threshold was crossed and a scanner over an Other protocol was identified.

**For More Information**

For the procedure for assigning actions to signatures, see [Assigning Actions to Signatures](#), page 8-15.

## Enabling Anomaly Detection

To enable anomaly detection, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter analysis engine submode.
- ```
sensor# configure terminal
sensor(config)# service analysis-engine
sensor(config-ana)#
```
- Step 3** Enter the virtual sensor name that contains the anomaly detection policy you want to enable.
- ```
sensor(config-ana)# virtual-sensor vs0
sensor(config-ana-vir)#
```
- Step 4** Enable anomaly detection operational mode.
- ```
sensor(config-ana-vir)# anomaly-detection
sensor(config-ana-vir-ano)# operational-mode detect
sensor(config-ana-vir-ano)#
```

Step 5 Exit analysis engine submode.

```
sensor(config-ana-vir-ano)# exit
sensor(config-ana-vir)# exit
sensor(config-ana-)# exit
Apply Changes:[yes]:
```

Step 6 Press **Enter** to apply your changes or enter **no** to discard them.

Working With Anomaly Detection Policies

Use the **service anomaly-detection name** command in service anomaly detection submode to create an anomaly detection policy. The values of this anomaly detection policy are the same as the default anomaly detection policy, ad0, until you edit them. Or you can use the **copy anomaly-detection source_destination** command in privileged EXEC mode to make a copy of an existing policy and then edit the values of the new policy as needed. Use the **list anomaly-detection-configurations** command in privileged EXEC mode to list the anomaly detection policies. Use the **no service anomaly-detection name** command in global configuration mode to delete an anomaly detection policy. Use the **default service anomaly-detection name** command in global configuration mode to reset the anomaly detection policy to factory settings.

Working With Anomaly Detection Policies

To create, copy, display, edit, and delete anomaly detection policies, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Create an anomaly detection policy.

```
sensor# configure terminal
sensor(config)# service anomaly-detection MyAnomaly Detection
Editing new instance MyAnomaly Detection.
sensor(config-ano)# exit
Apply Changes?[yes]: yes
sensor(config)# exit
sensor#
```

Step 3 Or copy an existing anomaly detection policy to a new anomaly detection policy.

```
sensor# copy anomaly-detection ad0 ad1
sensor#
```



Note You receive an error if the policy already exists or if there is not enough space available for the new policy.

Step 4 Accept the default anomaly detection policy values or edit the following parameters:

- a. Configure the operational settings.
- b. Configure the zones.
- c. Configure learning accept mode.
- d. Learn how to work with KBs.

Step 5 Display a list of anomaly detection policies on the sensor.

```
sensor# list anomaly-detection-configurations
Anomaly Detection
  Instance  Size  Virtual Sensor
  ad0       255  vs0
  temp      707  N/A
  MyAnomaly Detection 255  N/A
  ad1       141  vs1
sensor#
```

Step 6 Delete an anomaly detection policy.

```
sensor# configure terminal
sensor(config)# no service anomaly-detection MyAnomaly Detection
sensor(config)# exit
sensor#
```



Note You cannot delete the default anomaly detection policy, ad0.

Step 7 Verify that the anomaly detection instance has been deleted.

```
sensor# list anomaly-detection-configurations
Anomaly Detection
  Instance  Size  Virtual Sensor
  ad0       204  vs0
  ad1       141  N/A
sensor#
```

Step 8 Reset an anomaly detection policy to factory settings.

```
sensor# configure terminal
sensor(config)# default service anomaly-detection ad1
sensor(config)#
```

For More Information

- For the procedure for configuring operational settings, see [Configuring Anomaly Detection Operational Settings, page 9-10](#).
- For the procedures for configuring anomaly detection zones, see [Configuring the Internal Zone, page 9-12](#), [Configuring the Illegal Zone, page 9-20](#), and [Configuring the External Zone, page 9-29](#).
- For the procedure for configuring learning accept mode, see [Configuring Learning Accept Mode, page 9-38](#).
- For the procedure for working with KBs, see [Working With KB Files, page 9-40](#).

Configuring Anomaly Detection Operational Settings

Use the **worm-timeout** command in service anomaly detection submode to set the worm detection timeout. After this timeout, the scanner threshold returns to the configured value. Use the **ignore** command in service anomaly detection submode to configure source and destination IP addresses that you want the sensor to ignore when anomaly detection is gathering information for a KB. Anomaly detection does not track these source and destination IP addresses and the KB thresholds are not affected by these IP addresses.

The following options apply:

- **worm-timeout**—Specifies the amount of time in seconds for the worm termination timeout. The range is 120 to 10,000,000 seconds. The default is 600 seconds.
- **ignore**—Specifies the IP addresses that should be ignored while anomaly detection is processing:
 - **enabled {true | false}**—Enables/disables the list of ignored IP addresses. The default is enabled.
 - **source-ip-address-range**—Specifies the source IP addresses that you want anomaly detection to ignore during processing.
 - **dest-ip-address-range**—Specifies the destination IP addresses that you want anomaly detection to ignore during processing.



Note

IP addresses are in the form of <A.B.C.D>-<A.B.C.D>[,<A.B.C.D>-<A.B.C.D>].

Configuring Anomaly Detection Operational Settings

To specify anomaly detection operational settings, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter anomaly detection submode.
- ```
sensor# configure terminal
sensor(config)# service anomaly-detection ad1
```
- Step 3** Specify the worm timeout.
- ```
sensor(config-ano)# worm-timeout 800
```
- Step 4** Verify the setting.
- ```
sensor(config-ano)# show settings
worm-timeout: 800 seconds default: 600
```
- Step 5** Specify the destination IP addresses that you want to be ignored while anomaly detection is processing.
- ```
sensor(config-ano)# ignore
sensor(config-ano-ign)# dest-ip-address-range 10.10.5.5,10.10.2.1-10.10.2.30
```
- Step 6** Specify the source IP addresses that you want to be ignored while anomaly detection is processing.
- ```
sensor(config-ano-ign)# source-ip-address-range 10.20.30.108-10.20.30.191
```
- Step 7** Verify the settings.
- ```
sensor(config-ano-ign)# show settings
ignore
-----
enabled: true default: true
source-ip-address-range: 10.20.30.108-10.20.30.191 default: 0.0.0.0
dest-ip-address-range: 10.10.5.5,10.10.2.1-10.10.2.30 default: 0.0.0.0
-----
sensor(config-ano-ign)#
```
- Step 8** Exit anomaly detection submode.
- ```
sensor(config-ano-ign)# exit
sensor(config-ano)# exit
Apply Changes?[yes]:
```

**Step 9** Press **Enter** to apply your changes or enter **no** to discard them.

---

## Configuring the Internal Zone

This section describes how to configure the internal zone, and contains the following topics:

- [Understanding the Internal Zone, page 9-12](#)
- [Configuring the Internal Zone, page 9-12](#)
- [Configuring TCP Protocol for the Internal Zone, page 9-13](#)
- [Configuring UDP Protocol for the Internal Zone, page 9-16](#)
- [Configuring Other Protocols for the Internal Zone, page 9-18](#)

## Understanding the Internal Zone

The internal zone should represent your internal network. It should receive all the traffic that comes to your IP address range. If the zone is disabled, packets to this zone are ignored. By default the zone is enabled. You then add the IP addresses that belong to this zone. If you do not configure IP addresses for all zones, all packets are sent to the default zone, the external zone.

You can enable or disable TCP, UDP, and other protocols for the internal zone. You can configure a destination port for the TCP and UDP protocols and a protocol number for the other protocols. You can either use the default thresholds or override the scanner settings and add your own thresholds and histograms.

## Configuring the Internal Zone

Use the **internal-zone {enabled | ip-address-range | tcp | udp | other}** command in service anomaly-detection submode to enable the internal zone, add IP addresses to the internal zone, and specify protocols.

The following options apply:

- **enabled {false | true}**—Enables/disables the zone.
- **ip-address-range**—Specifies the IP addresses of the subnets in the zone. The valid value is <A.B.C.D>-<A.B.C.D>[,<A.B.C.D>-<A.B.C.D>].



---

**Note** The second IP address in the range must be greater than or equal to the first IP address.

---

- **tcp**—Lets you configure TCP protocol.
- **udp**—Lets you configure UDP protocol.
- **other**—Lets you configure other protocols besides TCP and UDP.



### Configuring the Internal Zone

To configure the internal zone, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter anomaly detection internal zone submode.
- ```
sensor# configure terminal
sensor(config)# service anomaly-detection ad0
sensor(config-ano)# internal-zone
sensor(config-ano-int)#
```
- Step 3** Enable the internal zone.
- ```
sensor(config-ano-int)# enabled true
```
- Step 4** Configure the IP addresses to be included in the internal zone.
- ```
sensor(config-ano-int)# ip-address-range 192.0.2.72-192.0.2.108
```
- Step 5** Configure TCP protocol.
- Step 6** Configure UDP protocol.
- Step 7** Configure the other protocols.
-

For More Information

- For the procedure for configuring TCP protocol, see [Configuring TCP Protocol for the Internal Zone, page 9-13](#).
- For the procedure for configuring UDP protocol, see [Configuring UDP Protocol for the Internal Zone, page 9-16](#).
- For the procedure for configuring other protocols, see [Configuring Other Protocols for the Internal Zone, page 9-18](#).

Configuring TCP Protocol for the Internal Zone

Use the **tcp** {**enabled** | **dst-port** *number* | **default-thresholds**} command in service anomaly detection internal zone submode to enable and configure the TCP service. The following options apply:

- **enabled** {**false** | **true**}—Enables/disables TCP protocol.
- **default-thresholds**—Defines thresholds to be used for all ports not specified in the destination port map:
 - **threshold-histogram** {**low** | **medium** | **high**} **num-source-ips** *number*—Sets values in the threshold histogram.
 - **scanner-threshold**—Sets the scanner threshold. The default is 200.
- **dst-port** *number*—Defines thresholds for specific destination ports. The valid values are 0 to 65535.
- **enabled** {**true** | **false**}—Enables/disables the service.
- **override-scanner-settings** {**yes** | **no**}—Lets you override the scanner values:
 - **threshold-histogram** {**low** | **medium** | **high**} **num-source-ips** *number*—Sets values in the threshold histogram.

- **scanner-threshold**—Sets the scanner threshold. The default is 200.

Configuring Internal Zone TCP Protocol

To configure TCP protocol for the internal zone, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter anomaly detection internal zone submode.
- ```
sensor# configure terminal
sensor(config)# service anomaly-detection ad0
sensor(config-ano)# internal-zone
sensor(config-ano-int)#
```
- Step 3** Enable TCP protocol.
- ```
sensor(config-ano-int)# tcp
sensor(config-ano-int-tcp)# enabled true
```
- Step 4** Associate a specific port with TCP protocol.
- ```
sensor(config-ano-int-tcp)# dst-port 20
sensor(config-ano-int-tcp-dst)#
```
- Step 5** Enable the service for that port.
- ```
sensor(config-ano-int-tcp-dst)# enabled true
```
- Step 6** To override the scanner values for that port. You can use the default scanner values, or you can override them and configure your own scanner values.
- ```
sensor(config-ano-int-tcp-dst)# override-scanner-settings yes
sensor(config-ano-int-tcp-dst-yes)#
```
- Step 7** To add a histogram for the new scanner settings. Enter the number of destination IP addresses (low, medium, or high) and the number of source IP addresses you want associated with this histogram.
- ```
sensor(config-ano-int-tcp-dst-yes)# threshold-histogram low num-source-ips 100
```
- Step 8** Set the scanner threshold.
- ```
sensor(config-ano-int-tcp-dst-yes)# scanner-threshold 100
```
- Step 9** Configure the default thresholds for all other unspecified ports.
- ```
sensor(config-ano-int-tcp-dst-yes)# exit
sensor(config-ano-int-tcp-dst)# exit
sensor(config-ano-int-tcp)# exit
sensor(config-ano-int-tcp)# default-thresholds
sensor(config-ano-int-tcp-def)# default-thresholds
sensor(config-ano-int-tcp-def)# threshold-histogram medium num-source-ips 120
sensor(config-ano-int-tcp-def)# scanner-threshold 120
```
- Step 10** Verify the TCP configuration settings.
- ```
sensor(config-ano-int-tcp)# show settings
tcp

dst-port (min: 0, max: 65535, current: 4)

number: 20

override-scanner-settings

```

```

yes

scanner-threshold: 120 default: 200
threshold-histogram (min: 0, max: 3, current: 1)

dest-ip-bin: low
num-source-ips: 100

enabled: true default: true

number: 23

override-scanner-settings

no

enabled: true <defaulted>

number: 113

override-scanner-settings

no

enabled: true <defaulted>

number: 567

override-scanner-settings

no

enabled: true <defaulted>

default-thresholds

scanner-threshold: 120 default: 200
threshold-histogram (min: 0, max: 3, current: 3)

<protected entry>
dest-ip-bin: low <defaulted>
num-source-ips: 10 <defaulted>
<protected entry>
dest-ip-bin: medium
num-source-ips: 120 default: 1
<protected entry>
dest-ip-bin: high <defaulted>
num-source-ips: 1 <defaulted>


```

```

 enabled: true <defaulted>

sensor(config-ano-int-tcp)#

```

---

## Configuring UDP Protocol for the Internal Zone

Use the **udp** {**enabled** | **dst-port** *number* | **default-thresholds**} command in service anomaly detection internal zone submode to enable and configure the UDP service. The following options apply:

- **enabled** {**false** | **true**}—Enables/disables UDP protocol.
- **default-thresholds**—Defines thresholds to be used for all ports not specified in the destination port map:
  - **threshold-histogram** {**low** | **medium** | **high**} **num-source-ips** *number*—Sets values in the threshold histogram.
  - **scanner-threshold**—Sets the scanner threshold. The default is 200.
- **dst-port** *number*—Defines thresholds for specific destination ports. The valid values are 0 to 65535.
- **enabled** {**true** | **false**}—Enables/disables the service.
- **override-scanner-settings** {**yes** | **no**}—Lets you override the scanner values:
  - **threshold-histogram** {**low** | **medium** | **high**} **num-source-ips** *number*—Sets values in the threshold histogram.
  - **scanner-threshold**—Sets the scanner threshold. The default is 200.

### Configuring the Internal Zone UDP Protocol

To configure UDP protocol for a zone, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter anomaly detection internal zone submode.
- ```

sensor# configure terminal
sensor(config)# service anomaly-detection ad0
sensor(config-ano)# internal-zone
sensor(config-ano-int)#

```
- Step 3** Enable UDP protocol.
- ```

sensor(config-ano-int)# udp
sensor(config-ano-int-udp)# enabled true

```
- Step 4** Associate a specific port with UDP protocol.
- ```

sensor(config-ano-int-udp)# dst-port 20
sensor(config-ano-int-udp-dst)#

```
- Step 5** Enable the service for that port.
- ```

sensor(config-ano-int-udp-dst)# enabled true

```
- Step 6** To override the scanner values for that port. You can use the default scanner values, or you can override them and configure your own scanner values.
- ```

sensor(config-ano-int-udp-dst)# override-scanner-settings yes
sensor(config-ano-int-udp-dst-yes)#

```

- Step 7** To add a histogram for the new scanner settings. Enter the number of destination IP addresses (low, medium, or high) and the number of source IP addresses you want associated with this histogram.

```
sensor(config-ano-int-udp-dst=yes)# threshold-histogram low num-source-ips 100
```

- Step 8** Set the scanner threshold.

```
sensor(config-ano-int-udp-dst=yes)# scanner-threshold 100
```

- Step 9** Configure the default thresholds for all other unspecified ports.

```
sensor(config-ano-int-udp-dst=yes)# exit
sensor(config-ano-int-udp-dst)# exit
sensor(config-ano-int-udp)# default-thresholds
sensor(config-ano-int-udp-def)# default-thresholds
sensor(config-ano-int-udp-def)# threshold-histogram medium num-source-ips 120
sensor(config-ano-int-udp-def)# scanner-threshold 120
```

- Step 10** Verify the UDP configuration settings.

```
sensor(config-ano-int-udp)# show settings
udp
-----
dst-port (min: 0, max: 65535, current: 4)
-----
number: 20
-----
override-scanner-settings
-----
yes
-----
scanner-threshold: 100 default: 200
threshold-histogram (min: 0, max: 3, current: 1)
-----
dest-ip-bin: low
num-source-ips: 100
-----
-----
enabled: true default: true
-----
number: 23
-----
override-scanner-settings
-----
no
-----
-----
enabled: true <defaulted>
-----
number: 113
-----
override-scanner-settings
-----
no
-----
-----
enabled: true <defaulted>
-----
number: 567
-----
override-scanner-settings
```

```

-----
no
-----
-----
enabled: true <defaulted>
-----
-----
default-thresholds
-----
scanner-threshold: 120 default: 200
threshold-histogram (min: 0, max: 3, current: 3)
-----
<protected entry>
dest-ip-bin: low <defaulted>
num-source-ips: 10 <defaulted>
<protected entry>
dest-ip-bin: medium
num-source-ips: 120 default: 1
<protected entry>
dest-ip-bin: high <defaulted>
num-source-ips: 1 <defaulted>
-----
enabled: true <defaulted>
-----
sensor(config-ano-int-udp)#

```

Configuring Other Protocols for the Internal Zone

Use the **other** { **enabled** | **protocol number** | **default-thresholds** } command in service anomaly detection internal zone submode to enable and configure the other services. The following options apply:

- **enabled** { **false** | **true** }—Enables/disables other protocols.
- **default-thresholds**—Defines thresholds to be used for all ports not specified in the destination port map:
 - **threshold-histogram** { **low** | **medium** | **high** } **num-source-ips number**—Sets values in the threshold histogram.
 - **scanner-threshold**—Sets the scanner threshold. The default is 200.
- **protocol-number number**—Defines thresholds for specific protocols. The valid values are 0 to 255.
- **enabled** { **true** | **false** }—Enables/disables the service.
- **override-scanner-settings** { **yes** | **no** }—Lets you override the scanner values:
 - **threshold-histogram** { **low** | **medium** | **high** } **num-source-ips number**—Sets values in the threshold histogram.
 - **scanner-threshold**—Sets the scanner threshold. The default is 200.

Configuring the Internal Zone Other Protocols

To configure other protocols for a zone, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter anomaly detection internal zone submode.
- ```
sensor# configure terminal
sensor(config)# service anomaly-detection ad0
sensor(config-ano)# internal-zone
sensor(config-ano-int)#
```
- Step 3** Enable the other protocols.
- ```
sensor(config-ano-int)# other
sensor(config-ano-int-oth)# enabled true
```
- Step 4** Associate a specific number for the other protocols.
- ```
sensor(config-ano-int-oth)# protocol-number 5
sensor(config-ano-int-oth-pro)#
```
- Step 5** Enable the service for that port.
- ```
sensor(config-ano-int-oth-pro)# enabled true
```
- Step 6** To override the scanner values for that protocol. You can use the default scanner values, or you can override them and configure your own scanner values.
- ```
sensor(config-ano-int-oth-pro)# override-scanner-settings yes
sensor(config-ano-int-oth-pro-yes)#
```
- Step 7** To add a histogram for the new scanner settings. Enter the number of destination IP addresses (low, medium, or high) and the number of source IP addresses you want associated with this histogram.
- ```
sensor(config-ano-int-oth-pro-yes)# threshold-histogram high num-source-ips 75
```
- Step 8** Set the scanner threshold.
- ```
sensor(config-ano-int-oth-pro-yes)# scanner-threshold 100
```
- Step 9** Configure the default thresholds for all other unspecified ports.
- ```
sensor(config-ano-int-oth-pro-yes)# exit
sensor(config-ano-int-oth-pro)# exit
sensor(config-ano-int-oth)# default-thresholds
sensor(config-ano-int-oth-def)# default-thresholds
sensor(config-ano-int-oth-def)# threshold-histogram medium num-source-ips 120
sensor(config-ano-int-oth-def)# scanner-threshold 120
```
- Step 10** Verify the other configuration settings.
- ```
sensor(config-ano-int-oth)# show settings
other

protocol-number (min: 0, max: 255, current: 1)

number: 5

override-scanner-settings

yes

scanner-threshold: 95 default: 200
threshold-histogram (min: 0, max: 3, current: 1)
```

```

 dest-ip-bin: high
 num-source-ips: 75

 enabled: true default: true

default-thresholds

 scanner-threshold: 200 <defaulted>
 threshold-histogram (min: 0, max: 3, current: 3)

 <protected entry>
 dest-ip-bin: low <defaulted>
 num-source-ips: 10 <defaulted>
 <protected entry>
 dest-ip-bin: medium <defaulted>
 num-source-ips: 1 <defaulted>
 <protected entry>
 dest-ip-bin: high <defaulted>
 num-source-ips: 1 <defaulted>

 enabled: true default: true

sensor(config-ano-int-oth)#

```

---

## Configuring the Illegal Zone

This section describes how to configure the illegal zone, and contains the following topics:

- [Understanding the Illegal Zone, page 9-20](#)
- [Configuring the Illegal Zone, page 9-21](#)
- [Configuring TCP Protocol for the Illegal Zone, page 9-22](#)
- [Configuring UDP Protocol for the Illegal Zone, page 9-24](#)
- [Configuring Other Protocols for the Illegal Zone, page 9-27](#)

## Understanding the Illegal Zone

The illegal zone should represent IP address ranges that should never be seen in normal traffic, for example, unallocated IP addresses or part of your internal IP address range that is unoccupied. You then add the IP addresses that belong to this zone. If you do not configure IP addresses for all zones, all packets are sent to the default zone, the external zone.

You can enable or disable TCP, UDP, and other protocols for the internal zone. You can configure a destination port for the TCP and UDP protocols and a protocol number for the other protocols. You can either use the default thresholds or override the scanner settings and add your own thresholds and histograms.



## Configuring the Illegal Zone

Use the **illegal-zone** {**enabled** | **ip-address-range** | **tcp** | **udp** | **other**} command in service anomaly detection submode to enable the illegal zone, add IP addresses to the illegal zone, and specify protocols. The following options apply:

- **enabled** {**false** | **true**}—Enables/disables the zone.
- **ip-address-range**—Specifies the IP addresses of the subnets in the zone. The valid value is <A.B.C.D>-<A.B.C.D>[,<A.B.C.D>-<A.B.C.D>].



**Note** The second IP address in the range must be greater than or equal to the first IP address.

- **tcp**—Lets you configure TCP protocol.
- **udp**—Lets you configure UDP protocol.
- **other**—Lets you configure other protocols besides TCP and UDP.

### Configuring the Illegal Zone

To configure the illegal zone, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter anomaly detection illegal zone submode.
- ```
sensor# configure terminal
sensor(config)# service anomaly-detection ad0
sensor(config-ano)# illegal-zone
sensor(config-ano-ill)#
```
- Step 3** Enable the illegal zone.
- ```
sensor(config-ano-ill)# enabled true
```
- Step 4** Configure the IP addresses to be included in the illegal zone.
- ```
sensor(config-ano-ill)# ip-address-range 192.0.2.72-192.0.2.108
```
- Step 5** Configure TCP protocol.
- Step 6** Configure UDP protocol.
- Step 7** Configure the other protocols.
-

For More Information

- For the procedure for configuring TCP protocol, see [Configuring TCP Protocol for the Illegal Zone, page 9-22](#).
- For the procedure for the UDP protocol, see [Configuring UDP Protocol for the Illegal Zone, page 9-24](#).
- For the procedure for configuring other protocols, see [Configuring Other Protocols for the Illegal Zone, page 9-27](#).

Configuring TCP Protocol for the Illegal Zone

Use the **tcp {enabled | dst-port *number* | default-thresholds}** command in service anomaly detection illegal zone submode to enable and configure the TCP service. The following options apply:

- **enabled {false | true}**—Enables/disables TCP protocol.
- **default-thresholds**—Defines thresholds to be used for all ports not specified in the destination port map:
 - **threshold-histogram {low | medium | high} num-source-ips *number***—Sets values in the threshold histogram.
 - **scanner-threshold**—Sets the scanner threshold. The default is 200.
- **dst-port *number***—Defines thresholds for specific destination ports. The valid values are 0 to 65535.
- **enabled {true | false}**—Enables/disables the service.
- **override-scanner-settings {yes | no}**—Lets you override the scanner values:
 - **threshold-histogram {low | medium | high} num-source-ips *number***—Sets values in the threshold histogram.
 - **scanner-threshold**—Sets the scanner threshold. The default is 200.

Configuring the Illegal Zone TCP Protocol

To configure TCP protocol for illegal zone, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter anomaly detection illegal zone submode.
- ```
sensor# configure terminal
sensor(config)# service anomaly-detection ad0
sensor(config-ano)# illegal-zone
sensor(config-ano-ill)#
```
- Step 3** Enable TCP protocol.
- ```
sensor(config-ano-ill)# tcp
sensor(config-ano-ill-tcp)# enabled true
```
- Step 4** Associate a specific port with TCP protocol.
- ```
sensor(config-ano-ill-tcp)# dst-port 20
sensor(config-ano-ill-tcp-dst)#
```
- Step 5** Enable the service for that port.
- ```
sensor(config-ano-ill-tcp-dst)# enabled true
```
- Step 6** Override the scanner values for that port. You can use the default scanner values, or you can override them and configure your own scanner values.
- ```
sensor(config-ano-ill-tcp-dst)# override-scanner-settings yes
sensor(config-ano-ill-tcp-dst-yes)#
```
- Step 7** Add a histogram for the new scanner settings. Enter the number of destination IP addresses (low, medium, or high) and the number of source IP addresses you want associated with this histogram.
- ```
sensor(config-ano-ill-tcp-dst-yes)# threshold-histogram low num-source-ips 100
```

Step 8 Set the scanner threshold.

```
sensor(config-ano-ill-tcp-dst=yes)# scanner-threshold 100
```

Step 9 Configure the default thresholds for all other unspecified ports.

```
sensor(config-ano-ill-tcp-dst=yes)# exit
sensor(config-ano-ill-tcp-dst)# exit
sensor(config-ano-ill-tcp)# exit
sensor(config-ano-ill-tcp)# default-thresholds
sensor(config-ano-ill-tcp-def)# default-thresholds
sensor(config-ano-ill-tcp-def)# threshold-histogram medium num-source-ips 120
sensor(config-ano-ill-tcp-def)# scanner-threshold 120
```

Step 10 Verify the TCP configuration settings.

```
sensor(config-ano-ill-tcp)# show settings
tcp
-----
dst-port (min: 0, max: 65535, current: 4)
-----
number: 20
-----
override-scanner-settings
-----
yes
-----
scanner-threshold: 100 default: 200
threshold-histogram (min: 0, max: 3, current: 1)
-----
dest-ip-bin: low
num-source-ips: 100
-----
-----
enabled: true default: true
-----
number: 23
-----
override-scanner-settings
-----
no
-----
-----
enabled: true <defaulted>
-----
number: 113
-----
override-scanner-settings
-----
no
-----
-----
enabled: true <defaulted>
-----
number: 567
-----
override-scanner-settings
-----
no
-----
-----
-----
```

```

        enabled: true <defaulted>
-----
default-thresholds
-----
scanner-threshold: 120 default: 200
threshold-histogram (min: 0, max: 3, current: 3)
-----
<protected entry>
dest-ip-bin: low <defaulted>
num-source-ips: 10 <defaulted>
<protected entry>
dest-ip-bin: medium
num-source-ips: 120 default: 1
<protected entry>
dest-ip-bin: high <defaulted>
num-source-ips: 1 <defaulted>
-----
enabled: true <defaulted>
-----
sensor(config-ano-ill-tcp)#

```

Configuring UDP Protocol for the Illegal Zone

Use the **udp {enabled | dst-port *number* | default-thresholds}** command in service anomaly detection illegal zone submode to enable and configure the UDP service. The following options apply:

- **enabled {false | true}**—Enables/disables UDP protocol.
- **default-thresholds**—Defines thresholds to be used for all ports not specified in the destination port map:
 - **threshold-histogram {low | medium | high} num-source-ips *number***—Sets values in the threshold histogram.
 - **scanner-threshold**—Sets the scanner threshold. The default is 200.
- **dst-port *number***—Defines thresholds for specific destination ports. The valid values are 0 to 65535.
- **enabled {true | false}**—Enables/disables the service.
- **override-scanner-settings {yes | no}**—Lets you override the scanner values:
 - **threshold-histogram {low | medium | high} num-source-ips *number***—Sets values in the threshold histogram.
 - **scanner-threshold**—Sets the scanner threshold. The default is 200.

Configuring the Illegal Zone UDP Protocol

To configure UDP protocol for a zone, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter anomaly detection illegal zone submode.

```

sensor# configure terminal
sensor(config)# service anomaly-detection ad0
sensor(config-ano)# illegal-zone
sensor(config-ano-ill)#

```

Step 3 Enable UDP protocol.

```
sensor(config-ano-ill)# udp
sensor(config-ano-ill-udp)# enabled true
```

Step 4 Associate a specific port with UDP protocol.

```
sensor(config-ano-ill-udp)# dst-port 20
sensor(config-ano-ill-udp-dst)#
```

Step 5 Enable the service for that port.

```
sensor(config-ano-ill-udp-dst)# enabled true
```

Step 6 Override the scanner values for that port. You can use the default scanner values, or you can override them and configure your own scanner values.

```
sensor(config-ano-ill-udp-dst)# override-scanner-settings yes
sensor(config-ano-ill-udp-dst-yes)#
```

Step 7 Add a histogram for the new scanner settings. Enter the number of destination IP addresses (low, medium, or high) and the number of source IP addresses you want associated with this histogram.

```
sensor(config-ano-ill-udp-dst-yes)# threshold-histogram low num-source-ips 100
```

Step 8 Set the scanner threshold.

```
sensor(config-ano-ill-udp-dst-yes)# scanner-threshold 100
```

Step 9 Configure the default thresholds for all other unspecified ports.

```
sensor(config-ano-ill-udp-dst-yes)# exit
sensor(config-ano-ill-udp-dst)# exit
sensor(config-ano-ill-udp)# exit
sensor(config-ano-ill-udp)# default-thresholds
sensor(config-ano-ill-udp-def)# default-thresholds
sensor(config-ano-ill-udp-def)# threshold-histogram medium num-source-ips 120
sensor(config-ano-ill-udp-def)# scanner-threshold 120
```

Step 10 Verify the UDP configuration settings.

```
sensor(config-ano-ill-udp)# show settings
udp
-----
dst-port (min: 0, max: 65535, current: 4)
-----
number: 20
-----
override-scanner-settings
-----
yes
-----
scanner-threshold: 100 default: 200
threshold-histogram (min: 0, max: 3, current: 1)
-----
dest-ip-bin: low
num-source-ips: 100
-----
-----
enabled: true default: true
-----
number: 23
-----
override-scanner-settings
```

```

-----
no
-----

-----
enabled: true <defaulted>
-----
number: 113
-----
override-scanner-settings
-----
no
-----

-----
enabled: true <defaulted>
-----
number: 567
-----
override-scanner-settings
-----
no
-----

-----
enabled: true <defaulted>
-----
default-thresholds
-----
scanner-threshold: 120 default: 200
threshold-histogram (min: 0, max: 3, current: 3)
-----
<protected entry>
dest-ip-bin: low <defaulted>
num-source-ips: 10 <defaulted>
<protected entry>
dest-ip-bin: medium
num-source-ips: 120 default: 1
<protected entry>
dest-ip-bin: high <defaulted>
num-source-ips: 1 <defaulted>
-----

-----
enabled: true <defaulted>
-----
sensor(config-ano-ill-udp)#

```

Configuring Other Protocols for the Illegal Zone

Use the **other {enabled | protocol number | default-thresholds}** command in service anomaly detection illegal zone submode to enable and configure the other services. The following options apply:

- **enabled {false | true}**—Enables/disables other protocols.
- **default-thresholds**—Defines thresholds to be used for all ports not specified in the destination port map:
 - **threshold-histogram {low | medium | high} num-source-ips number**—Sets values in the threshold histogram.
 - **scanner-threshold**—Sets the scanner threshold. The default is 200.
- **protocol-number number**—Defines thresholds for specific protocols. The valid values are 0 to 255.
- **enabled {true | false}**—Enables/disables the service.
- **override-scanner-settings {yes | no}**—Lets you override the scanner values:
 - **threshold-histogram {low | medium | high} num-source-ips number**—Sets values in the threshold histogram.
 - **scanner-threshold**—Sets the scanner threshold. The default is 200.

Configuring the Illegal Zone Other Protocols

To configure other protocols for a zone, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter anomaly detection illegal zone submode.
- ```
sensor# configure terminal
sensor(config)# service anomaly-detection ad0
sensor(config-ano)# illegal-zone
sensor(config-ano-ill)#
```
- Step 3** Enable the other protocols.
- ```
sensor(config-ano-ill)# other
sensor(config-ano-ill-oth)# enabled true
```
- Step 4** Associate a specific number for the other protocols.
- ```
sensor(config-ano-ill-oth)# protocol-number 5
sensor(config-ano-ill-oth-pro)#
```
- Step 5** Enable the service for that port.
- ```
sensor(config-ano-ill-oth-pro)# enabled true
```
- Step 6** Override the scanner values for that protocol. You can use the default scanner values, or you can override them and configure your own scanner values.
- ```
sensor(config-ano-ill-oth-pro)# override-scanner-settings yes
sensor(config-ano-ill-oth-pro-yes)#
```
- Step 7** Add a histogram for the new scanner settings. Enter the number of destination IP addresses (low, medium, or high) and the number of source IP addresses you want associated with this histogram.
- ```
sensor(config-ano-ill-oth-pro-yes)# threshold-histogram high num-source-ips 75
```

Step 8 Set the scanner threshold.

```
sensor(config-ano-ill-oth-pro-yes)# scanner-threshold 100
```

Step 9 Configure the default thresholds for all other unspecified ports.

```
sensor(config-ano-ill-oth-pro-yes)# exit
sensor(config-ano-ill-oth-pro)# exit
sensor(config-ano-ill-oth)# default-thresholds
sensor(config-ano-ill-oth-def)# default-thresholds
sensor(config-ano-ill-oth-def)# threshold-histogram medium num-source-ips 120
sensor(config-ano-ill-oth-def)# scanner-threshold 120
```

Step 10 Verify the other protocols configuration settings.

```
sensor(config-ano-ill-oth)# show settings
other
-----
protocol-number (min: 0, max: 255, current: 1)
-----
number: 5
-----
override-scanner-settings
-----
yes
-----
scanner-threshold: 95 default: 200
threshold-histogram (min: 0, max: 3, current: 1)
-----
dest-ip-bin: high
num-source-ips: 75
-----
-----
enabled: true default: true
-----
default-thresholds
-----
scanner-threshold: 200 <defaulted>
threshold-histogram (min: 0, max: 3, current: 3)
-----
<protected entry>
dest-ip-bin: low <defaulted>
num-source-ips: 10 <defaulted>
<protected entry>
dest-ip-bin: medium <defaulted>
num-source-ips: 1 <defaulted>
<protected entry>
dest-ip-bin: high <defaulted>
num-source-ips: 1 <defaulted>
-----
-----
enabled: true default: true
-----
sensor(config-ano-ill-oth)#
```


Configuring the External Zone

This section describes how to configure the external zone, and contains the following topics:

- [Understanding the External Zone, page 9-29](#)
- [Configuring the External Zone, page 9-29](#)
- [Configuring TCP Protocol for the External Zone, page 9-30](#)
- [Configuring UDP Protocol for the External Zone, page 9-32](#)
- [Configuring Other Protocols for the External Zone, page 9-35](#)

Understanding the External Zone

The external zone is the default zone with the default Internet range of 0.0.0.0-255.255.255.255. By default, the internal and illegal zones contain no IP addresses. Packets that do not match the set of IP addresses in the internal or illegal zone are handled by the external zone.

You can enable or disable TCP, UDP, and other protocols for the external zone. You can configure a destination port for the TCP and UDP protocols and a protocol number for the other protocols. You can either use the default thresholds or override the scanner settings and add your own thresholds and histograms.

Configuring the External Zone

Use the **external-zone {enabled | tcp | udp | other}** command in service anomaly detection submode to enable the external zone and specify protocols. The following options apply:

- **enabled {false | true}**—Enables/disables the zone.
- **tcp**—Lets you configure TCP protocol.
- **udp**—Lets you configure UDP protocol.
- **other**—Lets you configure other protocols besides TCP and UDP.

Configuring the External Zone

To configure the external zone, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter anomaly detection external zone submode.

```
sensor# configure terminal
sensor(config)# service anomaly-detection ad0
sensor(config-ano)# external-zone
sensor(config-ano-ext)#
```

Step 3 Enable the external zone.

```
sensor(config-ano-ext)# enabled true
```

Step 4 Configure TCP protocol.

Step 5 Configure UDP protocol.

Step 6 Configure the other protocols.**For More Information**

- For the procedure for configuring TCP protocol, see [Configuring TCP Protocol for the External Zone, page 9-30](#).
- For the procedure for configuring UDP protocol, see [Configuring UDP Protocol for the External Zone, page 9-32](#).
- For the procedure for configuring other protocols, see [Configuring Other Protocols for the External Zone, page 9-35](#).

Configuring TCP Protocol for the External Zone

Use the **tcp {enabled | dst-port *number* | default-thresholds}** command in service anomaly detection external zone submode to enable and configure the TCP service. The following options apply:

- **enabled {false | true}**—Enables/disables TCP protocol.
- **default-thresholds**—Defines thresholds to be used for all ports not specified in the destination port map:
 - **threshold-histogram {low | medium | high} num-source-ips *number***—Sets values in the threshold histogram.
 - **scanner-threshold**—Sets the scanner threshold. The default is 200.
- **dst-port *number***—Defines thresholds for specific destination ports. The valid values are 0 to 65535.
- **enabled {true | false}**—Enables/disables the service.
- **override-scanner-settings {yes | no}**—Lets you override the scanner values:
 - **threshold-histogram {low | medium | high} num-source-ips *number***—Sets values in the threshold histogram.
 - **scanner-threshold**—Sets the scanner threshold. The default is 200.

Configuring the External Zone TCP Protocol

To configure TCP protocol for the external zone, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter anomaly detection external zone submode.

```
sensor# configure terminal
sensor(config)# service anomaly-detection ad0
sensor(config-ano)# external-zone
sensor(config-ano-ext)#
```

Step 3 Enable TCP protocol.

```
sensor(config-ano-ext)# tcp
sensor(config-ano-ext-tcp)# enabled true
```

Step 4 Associate a specific port with TCP protocol.

```
sensor(config-ano-ext-tcp)# dst-port 20
sensor(config-ano-ext-tcp-dst)#
```

Step 5 Enable the service for that port.

```
sensor(config-ano-ext-tcp-dst)# enabled true
```

Step 6 Override the scanner values for that port. You can use the default scanner values, or you can override them and configure your own scanner values.

```
sensor(config-ano-ext-tcp-dst)# override-scanner-settings yes
sensor(config-ano-ext-tcp-dst-yes)#
```

Step 7 Add a histogram for the new scanner settings. Enter the number of destination IP addresses (low, medium, or high) and the number of source IP addresses you want associated with this histogram.

```
sensor(config-ano-ext-tcp-dst-yes)# threshold-histogram low num-source-ips 100
```

Step 8 Set the scanner threshold.

```
sensor(config-ano-ext-tcp-dst-yes)# scanner-threshold 100
```

Step 9 Configure the default thresholds for all other unspecified ports.

```
sensor(config-ano-ext-tcp-dst-yes)# exit
sensor(config-ano-ext-tcp-dst)# exit
sensor(config-ano-ext-tcp)# exit
sensor(config-ano-ext-tcp)# default-thresholds
sensor(config-ano-ext-tcp-def)# default-thresholds
sensor(config-ano-ext-tcp-def)# threshold-histogram medium num-source-ips 120
sensor(config-ano-ext-tcp-def)# scanner-threshold 120
```

Step 10 Verify the TCP configuration settings.

```
sensor(config-ano-ext-tcp)# show settings
tcp
-----
dst-port (min: 0, max: 65535, current: 4)
-----
number: 20
-----
override-scanner-settings
-----
yes
-----
scanner-threshold: 100 default: 200
threshold-histogram (min: 0, max: 3, current: 1)
-----
dest-ip-bin: low
num-source-ips: 100
-----
-----
enabled: true default: true
-----
number: 23
-----
override-scanner-settings
-----
no
-----
-----
enabled: true <defaulted>
-----
number: 113
-----
override-scanner-settings
```

```

-----
no
-----
-----
enabled: true <defaulted>
-----
number: 567
-----
override-scanner-settings
-----
no
-----
-----
enabled: true <defaulted>
-----
-----
default-thresholds
-----
scanner-threshold: 120 default: 200
threshold-histogram (min: 0, max: 3, current: 3)
-----
<protected entry>
dest-ip-bin: low <defaulted>
num-source-ips: 10 <defaulted>
<protected entry>
dest-ip-bin: medium
num-source-ips: 120 default: 1
<protected entry>
dest-ip-bin: high <defaulted>
num-source-ips: 1 <defaulted>
-----
-----
enabled: true <defaulted>
-----
sensor(config-ano-ext-tcp)#

```

Configuring UDP Protocol for the External Zone

Use the **udp** {**enabled** | **dst-port** *number* | **default-thresholds**} command in service anomaly detection external zone submode to enable and configure the UDP service. The following options apply:

- **enabled** {**false** | **true**}—Enables/disables UDP protocol.
- **default-thresholds**—Defines thresholds to be used for all ports not specified in the destination port map:
 - **threshold-histogram** {**low** | **medium** | **high**} **num-source-ips** *number*—Sets values in the threshold histogram.
 - **scanner-threshold**—Sets the scanner threshold. The default is 200.
- **dst-port** *number*—Defines thresholds for specific destination ports. The valid values are 0 to 65535.
- **enabled** {**true** | **false**}—Enables/disables the service.

- **override-scanner-settings {yes | no}**—Lets you override the scanner values:
 - **threshold-histogram {low | medium | high} num-source-ips number**—Sets values in the threshold histogram.
 - **scanner-threshold**—Sets the scanner threshold. The default is 200.

Configuring the External Zone UDP Protocol

To configure UDP protocol for a zone, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter anomaly detection external zone submode.
- ```
sensor# configure terminal
sensor(config)# service anomaly-detection ad0
sensor(config-ano)# external-zone
sensor(config-ano-ext)#
```
- Step 3** Enable UDP protocol.
- ```
sensor(config-ano-ext)# udp
sensor(config-ano-ext-udp)# enabled true
```
- Step 4** Associate a specific port with UDP protocol.
- ```
sensor(config-ano-ext-udp)# dst-port 20
sensor(config-ano-ext-udp-dst)#
```
- Step 5** Enable the service for that port.
- ```
sensor(config-ano-ext-udp-dst)# enabled true
```
- Step 6** Override the scanner values for that port. You can use the default scanner values, or you can override them and configure your own scanner values.
- ```
sensor(config-ano-ext-udp-dst)# override-scanner-settings yes
sensor(config-ano-ext-udp-dst-yes)#
```
- Step 7** Add a histogram for the new scanner settings. Enter the number of destination IP addresses (low, medium, or high) and the number of source IP addresses you want associated with this histogram.
- ```
sensor(config-ano-ext-udp-dst-yes)# threshold-histogram low num-source-ips 100
```
- Step 8** Set the scanner threshold.
- ```
sensor(config-ano-ext-udp-dst-yes)# scanner-threshold 100
```
- Step 9** Configure the default thresholds for all other unspecified ports.
- ```
sensor(config-ano-ext-udp-dst-yes)# exit
sensor(config-ano-ext-udp-dst)# exit
sensor(config-ano-ext-udp)# default-thresholds
sensor(config-ano-ext-udp-def)# default-thresholds
sensor(config-ano-ext-udp-def)# threshold-histogram medium num-source-ips 120
sensor(config-ano-ext-udp-def)# scanner-threshold 120
```
- Step 10** Verify the UDP configuration settings.
- ```
sensor(config-ano-ext-udp)# show settings
udp

dst-port (min: 0, max: 65535, current: 4)

number: 20
```

```

override-scanner-settings

yes

scanner-threshold: 100 default: 200
threshold-histogram (min: 0, max: 3, current: 1)

dest-ip-bin: low
num-source-ips: 100

enabled: true default: true

number: 23

override-scanner-settings

no

enabled: true <defaulted>

number: 113

override-scanner-settings

no

enabled: true <defaulted>

number: 567

override-scanner-settings

no

enabled: true <defaulted>

default-thresholds

scanner-threshold: 120 default: 200
threshold-histogram (min: 0, max: 3, current: 3)

<protected entry>
dest-ip-bin: low <defaulted>
num-source-ips: 10 <defaulted>
<protected entry>
dest-ip-bin: medium
num-source-ips: 120 default: 1
<protected entry>
dest-ip-bin: high <defaulted>
num-source-ips: 1 <defaulted>

enabled: true <defaulted>

```

```
sensor(config-ano-ext-udp) #
```

---

## Configuring Other Protocols for the External Zone

Use the **other {enabled | protocol *number* | default-thresholds}** command in service anomaly detection external zone submode to enable and configure the other services. The following options apply:

- **enabled {false | true}**—Enables/disables other protocols.
- **default-thresholds**—Defines thresholds to be used for all ports not specified in the destination port map:
  - **threshold-histogram {low | medium | high} num-source-ips *number***—Sets values in the threshold histogram.
  - **scanner-threshold**—Sets the scanner threshold. The default is 200.
- **protocol-number *number***—Defines thresholds for specific protocols. The valid values are 0 to 255.
- **enabled {true | false}**—Enables/disables the service.
- **override-scanner-settings {yes | no}**—Lets you override the scanner values:
  - **threshold-histogram {low | medium | high} num-source-ips *number***—Sets values in the threshold histogram.
  - **scanner-threshold**—Sets the scanner threshold. The default is 200.

### Configuring the External Zone Other Protocols

To configure other protocols for a zone, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter anomaly detection external zone submode.
- ```
sensor# configure terminal
sensor(config)# service anomaly-detection ad0
sensor(config-ano)# external-zone
sensor(config-ano-ext)#
```
- Step 3** Enable the other protocols.
- ```
sensor(config-ano-ext)# other
sensor(config-ano-ext-oth)# enabled true
```
- Step 4** Associate a specific number for the other protocols.
- ```
sensor(config-ano-ext-oth)# protocol-number 5
sensor(config-ano-ext-oth-pro)#
```
- Step 5** Enable the service for that port.
- ```
sensor(config-ano-ext-oth-pro)# enabled true
```
- Step 6** Override the scanner values for that protocol. You can use the default scanner values, or you can override them and configure your own scanner values.
- ```
sensor(config-ano-ext-oth-pro)# override-scanner-settings yes
sensor(config-ano-ext-oth-pro-yes)#
```

- Step 7** Add a histogram for the new scanner settings. Enter the number of destination IP addresses (low, medium, or high) and the number of source IP addresses you want associated with this histogram.

```
sensor(config-ano-ext-oth-pro-yes) # threshold-histogram high num-source-ips 75
```

- Step 8** Set the scanner threshold.

```
sensor(config-ano-ext-oth-pro-yes) # scanner-threshold 100
```

- Step 9** Configure the default thresholds for all other unspecified ports.

```
sensor(config-ano-ext-oth-pro-yes) # exit
sensor(config-ano-ext-oth-pro) # exit
sensor(config-ano-ext-oth) # default-thresholds
sensor(config-ano-ext-oth-def) # default-thresholds
sensor(config-ano-ext-oth-def) # threshold-histogram medium num-source-ips 120
sensor(config-ano-ext-oth-def) # scanner-threshold 120
```

- Step 10** Verify the other protocols configuration settings.

```
sensor(config-ano-ext-oth) # show settings
other
-----
protocol-number (min: 0, max: 255, current: 1)
-----
number: 5
-----
override-scanner-settings
-----
yes
-----
scanner-threshold: 95 default: 200
threshold-histogram (min: 0, max: 3, current: 1)
-----
dest-ip-bin: high
num-source-ips: 75
-----
-----
enabled: true default: true
-----
default-thresholds
-----
scanner-threshold: 200 <defaulted>
threshold-histogram (min: 0, max: 3, current: 3)
-----
<protected entry>
dest-ip-bin: low <defaulted>
num-source-ips: 10 <defaulted>
<protected entry>
dest-ip-bin: medium <defaulted>
num-source-ips: 1 <defaulted>
<protected entry>
dest-ip-bin: high <defaulted>
num-source-ips: 1 <defaulted>
-----
-----
enabled: true default: true
-----
sensor(config-ano-ext-oth) #
```


Configuring Learning Accept Mode

This section describes KBs and histograms and how to configure learning accept mode. It contains the following topics:

- [The KB and Histograms, page 9-37](#)
- [Configuring Learning Accept Mode, page 9-38](#)

The KB and Histograms

The KB has a tree structure, and contains the following information:

- KB name
- Zone name
- Protocol
- Service

The KB holds a scanner threshold and a histogram for each service. If you have learning accept mode set to auto and the action set to rotate, a new KB is created every 24 hours and used in the next 24 hours. If you have learning accept mode set to auto and the action is set to save only, a new KB is created, but the current KB is used. If you do not have learning accept mode set to auto, no KB is created.

**Note**

Learning accept mode uses the sensor local time.

The scanner threshold defines the maximum number of zone IP addresses that a single source IP address can scan. The histogram threshold defines the maximum number of source IP addresses that can scan more than the specified numbers of zone IP addresses.

Anomaly detection identifies a worm attack when there is a deviation from the histogram that it has learned when no attack was in progress (that is, when the number of source IP addresses that concurrently scan more than the defined zone destination IP address is exceeded). For example, if the scanning threshold is 300 and the histogram for port 445, if anomaly detection identifies a scanner that scans 350 zone destination IP addresses, it produces an action indicating that a mass scanner was detected. However, this scanner does not yet verify that a worm attack is in progress. [Table 9-2](#) describes this example.

Table 9-2 **Example Histogram**

Number of source IP addresses	10	5	2
Number of destination IP addresses	5	20	100

When anomaly detection identifies six concurrent source IP addresses that scan more than 20 zone destination IP addresses on port 445, it produces an action with an unspecified source IP address that indicates anomaly detection has identified a worm attack on port 445. The dynamic filter threshold, 20, specifies the new internal scanning threshold and causes anomaly detection to lower the threshold definition of a scanner so that anomaly detection produces additional dynamic filters for each source IP address that scans more than the new scanning threshold (20).

You can override what the KB learned per anomaly detection policy and per zone. If you understand your network traffic, you may want to use overrides to limit false positives.

Triggering the High Category Histogram Before the Single-Scanner Threshold

Based on the default histogram (nonlearned knowledge base [KB]) values, histogram-based detection can occur before single-scanner detection.

Single scanner detection is based on the scanner threshold settings. The scanner threshold setting is a single number for that port or protocol and zone. Any single IP address scanning more than that number of hosts of that port or protocol in that zone is alerted as a scanner.

There is a histogram for that port or protocol and zone that tracks how many systems normally scan a smaller number of hosts (10 hosts, 20 hosts, or 100 hosts). When more than that normal number of scanners are seen, then a worm is declared and all IPs scanning more than the associated number of hosts are alerted on as being a worm scanner.



Note

An IP source address can be alerted on as being a worm scanner without ever reaching the scanner threshold. The scanner threshold is used to detect single systems scanning a large number of hosts and is tracked separately from the algorithms for detecting worms.

Configuring Learning Accept Mode

Use the **learning-accept-mode** command in service anomaly detection submode to configure whether you want the sensor to create a new KB every so many hours. You can configure whether the KB is created and loaded (rotate) or saved (save only). You can schedule how often and when the KB is loaded or saved.

The new updated KB file name is the current date and time, *YYYY-Mon-dd-hh_mm_ss*, where *Mon* is the three-letter abbreviation of the month.



Note

Anomaly detection learning accept mode uses the sensor local time.

The following options apply:

- **learning-accept-mode**—Specifies if and when the KB is saved and loaded:
 - **auto**—Configures the sensor to automatically accept the KB.
 - **manual**—Does not save the KB.



Note

You can save and load the KB using the **anomaly-detection {load | save}** commands.

- **action**—Specifies whether to rotate or save the KB:
 - **save-only**—Saves the new KB. You can examine it and decide whether to load it into anomaly detection.



Note

You can load the KB using the **anomaly-detection load** command.

- **rotate**—Saves the new KB and loads it as the current KB according to the schedule you define.
- **schedule**—Configures a schedule to accept the KB:
 - **calendar-schedule {days-of-week} {times-of-day}**—Starts learning accept mode at specific times on specific days.

- **periodic-schedule {interval} {start-time}**—Starts learning accept mode at specific periodic intervals.

Configuring Learning Accept Mode

The first saving begins after a full interval between configuration time and start time. For example, if the time is now 16:00 and you configure start time at 16:30 with an interval of one hour, the first KB is saved at 17:30, because there was no one-hour interval between 16:00 and 16:30.

To configure learning accept mode, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter anomaly detection submode.
- ```
sensor# configure terminal
sensor(config)# service anomaly-detection ad1
```
- Step 3** Specify how the KB is saved and loaded:
- Specify that the KB is automatically saved and loaded. Go to Step 4.
- ```
sensor(config-ano)# learning-accept-mode auto
sensor(config-ano-aut)#
```
- Specify that the KB is going to be manually saved and loaded. Go to Step 6.
- ```
sensor(config-ano)# learning-accept-mode manual
sensor(config-ano-man)#
```
- Step 4** Specify how you want the KB automatically accepted:
- Save the KB so that you can inspect it and decide whether to load it. Go to Step 6.
- ```
sensor(config-ano-aut)# action save-only
```
- Have the KB saved and loaded as the current KB according to the schedule you define. Continue with Step 5.
- ```
sensor(config-ano-aut)# action rotate
```
- Step 5** Schedule the automatic KB saves and loads:
- Calendar schedule—With this schedule the KB is saved and loaded every Monday at midnight.
- ```
sensor(config-ano-aut)# schedule calendar-schedule
sensor(config-ano-aut-cal)# days-of-week monday
sensor(config-ano-aut-cal)# times-of-day time 24:00:00
```
- Periodic schedule—With this schedule the KB is saved and loaded every 24 hours at midnight.
- ```
sensor(config-ano-aut)# schedule periodic-schedule
sensor(config-ano-aut-per)# start-time 24:00:00
sensor(config-ano-aut-per)# interval 24
```
- Step 6** Verify the settings.
- ```
sensor(config-ano-aut-per)# exit
sensor(config-ano-aut)# show settings
auto
-----
action: rotate default: rotate
schedule
-----
periodic-schedule
-----
```

```
start-time: 12:00:00 default: 10:00:00
interval: 24 hours default: 24
-----
-----
-----
```

Step 7 Exit anomaly detection submode.

```
sensor(config-ano-aut)# exit
sensor(config-ano)# exit
Apply Changes:[yes]:
```

Step 8 Press **Enter** to apply your changes or enter **no** to discard them.

For More Information

For the procedures for saving and loading anomaly detection KBs manually, see [Saving and Loading KBs Manually, page 9-41](#).

Working With KB Files

This section describes how to display, load, save, copy, rename and delete KB files. It also provides the procedures for comparing two KB files and for displaying the thresholds of a KB file. It contains the following topics:

- [Displaying KB Files, page 9-40](#)
- [Saving and Loading KBs Manually, page 9-41](#)
- [Copying, Renaming, and Erasing KBs, page 9-42](#)
- [Displaying the Differences Between Two KBs, page 9-44](#)
- [Displaying the Thresholds for a KB, page 9-45](#)

Displaying KB Files

Use the **show ad-knowledge-base** [*virtual-sensor*] **files** command in privileged EXEC mode to display the available KB files for a virtual sensor.



Note

The * before the file name indicates that this KB file is the currently loaded KB file.

To display KB files, follow these steps:

Step 1 Log in to the CLI.

Step 2 Display the KB files for all virtual sensors.

```
sensor# show ad-knowledge-base files
Virtual Sensor vs0
  Filename      Size  Created
  initial       84    04:27:07 CDT Wed Jan 29 2003
* 2003-Jan-28-10_00_01 84    04:27:07 CDT Wed Jan 29 2003
Virtual Sensor vs1
  Filename      Size  Created
```

```

initial            84      14:35:38 CDT Tue Mar 14 2006
2006-Mar-16-10_00_00 84      10:00:00 CDT Thu Mar 16 2006
2006-Mar-17-10_00_00 84      10:00:00 CDT Fri Mar 17 2006
2006-Mar-18-10_00_00 84      10:00:00 CDT Sat Mar 18 2006
2006-Mar-19-10_00_00 84      10:00:00 CDT Sun Mar 19 2006
2006-Mar-20-10_00_00 84      10:00:00 CDT Mon Mar 20 2006
2006-Mar-21-10_00_00 84      10:00:00 CDT Tue Mar 21 2006
2006-Mar-22-10_00_00 84      10:00:00 CDT Wed Mar 22 2006
2006-Mar-23-10_00_00 84      10:00:00 CDT Thu Mar 23 2006
2006-Mar-24-10_00_00 84      10:00:00 CDT Fri Mar 24 2006
2006-Mar-25-10_00_00 84      10:00:00 CDT Sat Mar 25 2006
2006-Mar-26-10_00_00 84      10:00:00 CDT Sun Mar 26 2006
2006-Mar-27-10_00_00 84      10:00:00 CDT Mon Mar 27 2006
2003-Jan-02-10_00_00 84      10:00:00 CDT Thu Jan 02 2003
2003-Jan-03-10_00_00 84      10:00:00 CDT Fri Jan 03 2003
2003-Jan-04-10_00_00 84      10:00:00 CDT Sat Jan 04 2003
2003-Jan-05-10_00_00 84      10:00:00 CDT Sun Jan 05 2003
2003-Jan-06-10_00_00 84      10:00:00 CDT Mon Jan 06 2003
sensor#

```

Step 3 Display the KB files for a specific virtual sensor.

```

sensor# show ad-knowledge-base vs0 files
Virtual Sensor vs0
  Filename      Size  Created
  initial       84    10:24:58 CDT Tue Mar 14 2006
  2006-Mar-16-10_00_00 84    10:00:00 CDT Thu Mar 16 2006
  2006-Mar-17-10_00_00 84    10:00:00 CDT Fri Mar 17 2006
  2006-Mar-18-10_00_00 84    10:00:00 CDT Sat Mar 18 2006
  2006-Mar-19-10_00_00 84    10:00:00 CDT Sun Mar 19 2006
  2006-Mar-20-10_00_00 84    10:00:00 CDT Mon Mar 20 2006

```

Saving and Loading KBs Manually

Use these commands in privileged EXEC mode to manually save and load KBs. The following options apply:

- **show ad-knowledge-base virtual-sensor files**—Displays the available KB files per virtual sensor.
- **anomaly-detection virtual-sensor load {initial | file name}**—Sets the KB file as the current KB for the specified virtual sensor. If AD is active, the file is loaded as the current KB.
- **anomaly-detection virtual-sensor save [new-name]**—Retrieves the current KB file and saves it locally.

Manually Saving and Loading KBs

To manually save and load a KB, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Locate the KB you want to load.

```

sensor# show ad-knowledge-base vs0 files
Virtual Sensor vs0
  Filename      Size  Created
  initial       84    10:24:58 CDT Tue Mar 14 2006
  2006-Mar-16-10_00_00 84    10:00:00 CDT Thu Mar 16 2006
  2006-Mar-17-10_00_00 84    10:00:00 CDT Fri Mar 17 2006

```

```

2006-Mar-18-10_00_00 84 10:00:00 CDT Sat Mar 18 2006
2006-Mar-19-10_00_00 84 10:00:00 CDT Sun Mar 19 2006
2006-Mar-20-10_00_00 84 10:00:00 CDT Mon Mar 20 2006

```

Step 3 Load the KB file as the current KB file for a specific virtual sensor.

```

sensor# anomaly-detection vs0 load file 2006-Mar-16-10_00_00
sensor#

```

Step 4 Save the current KB file and store it as a new name.

```

sensor# anomaly-detection vs0 save my-KB
sensor#

```



Note An error is generated if anomaly detection is not active when you enter this command. You cannot overwrite the initial file.

Copying, Renaming, and Erasing KBs

Use these commands in privileged EXEC mode to manually copy, rename, and erase KB files. The following options apply:

- **copy ad-knowledge-base virtual-sensor {current | initial | file name} destination-url**—Copies the KB file (current, initial, or the file name you enter) to a specified destination URL.



Note Copying a file to a name that already exists overwrites it.

- **copy ad-knowledge-base virtual-sensor source-url new-name**—Copies a KB with a new file name to the source URL you specify.



Note You cannot use the **current** keyword as a *new-name*. A new current KB file is created with the **load** command.

- **rename ad-knowledge-base virtual-sensor {current | file name} new-name**—Renames an existing KB file.
- **erase ad-knowledge-base [virtual-sensor [name]]**—Removes all KB files from a virtual sensor, or just one KB file if you use the *name* option.

You cannot erase the initial KB file or the KB file loaded as the current KB. The exact format of the source and destination URLs varies according to the file. Here are the valid types:

- **ftp:**—Source URL for an FTP network server. The syntax for this prefix is:

```
ftp://[[username@]location][relativeDirectory]/filename
```

```
ftp://[[username@]location][absoluteDirectory]/filename
```



Note You are prompted for a password.

- **scp:**—Source URL for the SCP network server. The syntax for this prefix is:

scp://[[username@]location][relativeDirectory]/filename

scp://[[username@]location][absoluteDirectory]/filename



Note You are prompted for a password. You must add the remote host to the SSH known hosts list.

- **http:**—Source URL for the web server. The syntax for this prefix is:

http://[[username@]location][directory]/filename



Note The directory specification should be an absolute path to the desired file.

- **https:**—Source URL for the web server. The syntax for this prefix is:

https://[[username@]location][directory]/filename



Note The directory specification should be an absolute path to the desired file. The remote host must be a TLS trusted host.

Copying, Renaming, and Removing KB Files

To copy, rename, and remove KB files, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Locate the KB file you want to copy.

```
sensor# show ad-knowledge-base vs0 files
Virtual Sensor vs0
  Filename                Size  Created
  initial                 84    10:24:58 CDT Tue Mar 14 2006
  2006-Mar-16-10_00_00    84    10:00:00 CDT Thu Mar 16 2006
  2006-Mar-17-10_00_00    84    10:00:00 CDT Fri Mar 17 2006
  2006-Mar-18-10_00_00    84    10:00:00 CDT Sat Mar 18 2006
  2006-Mar-19-10_00_00    84    10:00:00 CDT Sun Mar 19 2006
  2006-Mar-20-10_00_00    84    10:00:00 CDT Mon Mar 20 2006
```

Step 3 Copy the KB file to a user on a computer with the IP address 10.1.1.1.

```
sensor# copy ad-knowledge-base vs0 file 2006-Mar-16-10_00_00
scp://cidsuser@10.1.1.1/AD/my-KB
password: *****
sensor#
```

Step 4 Rename a KB file.

```
sensor# rename ad-knowledge-base vs0 2006-Mar-16-10_00_00 My-KB
sensor#
```

Step 5 Remove a KB file from a specific virtual sensor.

```
sensor# erase ad-knowledge-base vs0 2006-Mar-16-10_00_00
sensor#
```

Step 6 Remove all KB files except the file loaded as current and the initial KB file from a virtual sensor.

```
sensor# erase ad-knowledge-base vs0
```

```
Warning: Executing this command will delete all virtual sensor 'vs0' knowledge bases
except the file loaded as current and the initial knowledge base.
Continue with erase? [yes]: yes
sensor#
```

Step 7 Remove all KB files except the file loaded as current and the initial KB file from all virtual sensors.

```
sensor# erase ad-knowledge-base
Warning: Executing this command will delete all virtual sensor knowledge bases except the
file loaded as current and the initial knowledge base.
Continue with erase? [yes]: yes
sensor#
```

For More Information

- For the procedure for creating a new KB using the **load** command, see [Saving and Loading KBs Manually, page 9-41](#).
- For the procedure for adding hosts to the SSH known hosts list, see [Adding Hosts to the SSH Known Hosts List, page 4-45](#).
- For the procedure for adding TLS trusted hosts, see [Adding TLS Trusted Hosts, page 4-51](#).

Displaying the Differences Between Two KBs

Use the **show ad-knowledge-base virtual-sensor diff {current | initial | file name1} {current | initial | file name2} [diff-percentage]** command in privileged EXEC mode to display the differences between two KBs. The following options apply:

- **virtual-sensor**—Specifies the name of the virtual sensor that contains the KB files you want to compare.
- **name1**—Specifies the name of the first existing KB file to compare.
- **name2**—Specifies the name of the second existing KB file to compare.
- **current**—Specifies the currently loaded KB.
- **initial**—Specifies the initial KB.
- **file**—Specifies the name of an existing KB file.
- **diff-percentage**—(Optional) Displays the services where the thresholds differ more than the specified percentage. The valid values are 1 to 100. The default is 10%.

Comparing Two KBs

To compare two KBs, follow these steps:

Step 1 Log in to the CLI.

Step 2 Locate the file you want to compare.

```
sensor# show ad-knowledge-base vs0 files
Virtual Sensor vs0
  Filename           Size  Created
  initial            84    04:27:07 CDT Wed Jan 29 2003
* 2006-Jun-28-10_00_01 84    04:27:07 CDT Thu Jun 29 2006
sensor#
```


Step 3 Compare the currently loaded file (the file with the *) with the initial KB for virtual sensor vs0.

```

sensor# show ad-knowledge-base vs0 diff initial file 2006-Jun-28-10_00_01
Initial Only Services/Protocols
  External Zone
    TCP Services
      Service = 30
      Service = 20
    UDP Services
      None
    Other Protocols
      Protocol = 1
  Illegal Zone
    None
  Internal Zone
    None
2006-Jun-28-10_00_01 Only Services/Protocols
  External Zone
    None
  Illegal Zone
    None
  Internal Zone
    None
Thresholds differ more than 10%
  External Zone
    None
  Illegal Zone
    TCP Services
      Service = 31
      Service = 22
    UDP Services
      None
    Other Protocols
      Protocol = 3
  Internal Zone
    None
sensor#

```

Displaying the Thresholds for a KB

Use the `show ad-knowledge-base virtual-sensor thresholds {current | initial | file name} [zone {external | illegal | internal}] {[protocol {tcp | udp}] [dst-port port] | [protocol other] [number protocol-number]}` command in privileged EXEC mode to display the thresholds in a KB.

The following options apply:

- *virtual-sensor*—Specifies the name of the virtual sensor that contains the KB files you want to compare.
- *name*—Specifies the name of the existing KB file.
- **current**—Specifies the currently loaded KB.
- **initial**—Specifies the initial KB.
- **file**—Specifies the name of an existing KB file.
- **zone**—(Optional) Displays the thresholds for the specified zone. The default displays information for all zones.
- **external**—Displays the thresholds for the external zone.

- **illegal**—Displays the thresholds for the illegal zone.
- **internal**—Displays the thresholds for the internal zone.
- **protocol**—(Optional) Displays the thresholds for the specified protocol. The default displays information about all protocols.
- **tcp**—Displays the thresholds for the TCP protocol.
- **udp**—Displays the thresholds for the UDP protocol.
- **other**—Displays the thresholds for the other protocols besides TCP or UDP.
- **dst-port**—(Optional) Displays thresholds for the specified port. The default displays information about all TCP and/or UDP ports.
- **port**—Specifies the port number. The valid values are 0 to 65535.
- **number**—(Optional) Displays thresholds for the specified other protocol number. The default displays information for all other protocols.
- **protocol-number**—Specifies the protocol number. The valid values are 0 to 255.

Displaying KB Thresholds

To display the KB thresholds, follow these steps:

Step 1 Log in to the CLI.

Step 2 Locate the file for which you want to display thresholds:

```
sensor# show ad-knowledge-base vs1 files
Virtual Sensor vs1
      Filename      Size  Created
      -----
      initial       84    10:24:58 CDT Tue Mar 14 2006
      2006-Mar-16-10_00_00 84    10:00:00 CDT Thu Mar 16 2006
      2006-Mar-17-10_00_00 84    10:00:00 CDT Fri Mar 17 2006
      2006-Mar-18-10_00_00 84    10:00:00 CDT Sat Mar 18 2006
      2006-Mar-19-10_00_00 84    10:00:00 CDT Sun Mar 19 2006
      2006-Mar-27-10_00_00 84    10:00:00 CDT Mon Mar 27 2006
      2006-Apr-24-05_00_00 88    05:00:00 CDT Mon Apr 24 2006
      * 2006-Apr-25-05_00_00 88    05:00:00 CDT Tue Apr 25 2006
```

Step 3 Display thresholds contained in a specific file for the illegal zone.

```
sensor# show ad-knowledge-base vs0 thresholds file 2006-Nov-11-10_00_00 zone illegal

AD Thresholds
  Creation Date = 2006-Nov-11-10_00_00
  KB = 2006-Nov-11-10_00_00
  Illegal Zone
    TCP Services
      Default
        Scanner Threshold
          User Configuration = 200
        Threshold Histogram - User Configuration
          Low = 10
          Medium = 3
          High = 1
    UDP Services
      Default
        Scanner Threshold
          User Configuration = 200
        Threshold Histogram - User Configuration
          Low = 10
          Medium = 3
```

```

        High = 1
    Other Services
    Default
        Scanner Threshold
        User Configuration = 200
        Threshold Histogram - User Configuration
        Low = 10
        Medium = 3
        High = 1
sensor#

```

Step 4 Display thresholds contained in the current KB illegal zone, protocol TCP, and destination port 20.

```

sensor# show ad-knowledge-base vs0 thresholds current zone illegal protocol tcp dst-port
20

AD Thresholds
Creation Date = 2006-Nov-14-10_00_00
KB = 2006-Nov-14-10_00_00
Illegal Zone
TCP Services
    Default
        Scanner Threshold
        User Configuration = 200
        Threshold Histogram - User Configuration
        Low = 10
        Medium = 3
        High = 1
sensor#

```

Step 5 Display thresholds contained in the current KB illegal zone, and protocol other.

```

sensor# show ad-knowledge-base vs0 thresholds current zone illegal protocol other

AD Thresholds
Creation Date = 2006-Nov-14-10_00_00
KB = 2006-Nov-14-10_00_00
Illegal Zone
Other Services
    Default
        Scanner Threshold
        User Configuration = 200
        Threshold Histogram - User Configuration
        Low = 10
        Medium = 3
        High = 1
sensor#

```

Displaying Anomaly Detection Statistics

Use the **show statistics anomaly-detection** *[virtual-sensor-name]* command in privileged EXEC mode to display the statistics for anomaly detection. You can see if an attack is in progress (*Attack in progress* or *No attack*). You can also see when the next KB will be saved (*Next KB rotation at 10:00:00 UTC Wed Apr 26 2006*).



Note

The **clear** command is not available for anomaly detection statistics.

To display anomaly detection statistics, follow these steps:

Step 1 Log in to the CLI.

Step 2 Display the anomaly detection statistics for a specific virtual sensor.

```
sensor# show statistics anomaly-detection vs0
Statistics for Virtual Sensor vs0
  No attack
  Detection - ON
  Learning - ON
  Next KB rotation at 10:00:00 UTC Wed Apr 26 2006
  Internal Zone
    TCP Protocol
    UDP Protocol
    Other Protocol
  External Zone
    TCP Protocol
    UDP Protocol
    Other Protocol
  Illegal Zone
    TCP Protocol
    UDP Protocol
    Other Protocol
sensor#
```

Step 3 Display the statistics for all virtual sensors.

```
sensor# show statistics anomaly-detection
Statistics for Virtual Sensor vs0
  No attack
  Detection - ON
  Learning - ON
  Next KB rotation at 10:00:01 UTC Wed Jun 29 2006
  Internal Zone
    TCP Protocol
    UDP Protocol
    Other Protocol
  External Zone
    TCP Protocol
    UDP Protocol
    Other Protocol
  Illegal Zone
    TCP Protocol
    UDP Protocol
    Other Protocol
Statistics for Virtual Sensor vs1
  No attack
  Detection - ON
  Learning - ON
  Next KB rotation at 10:00:00 UTC Wed Jul 29 2006
  Internal Zone
    TCP Protocol
    UDP Protocol
    Other Protocol
  External Zone
    TCP Protocol
    UDP Protocol
    Other Protocol
```

```
Illegal Zone
TCP Protocol
UDP Protocol
Other Protocol
sensor#
```

Disabling Anomaly Detection

If you have anomaly detection enabled and you have your sensor configured to see only one direction of traffic, you should disable anomaly detection. Otherwise, you will receive many alerts, because anomaly detection sees asymmetric traffic as having incomplete connections, that is, like worm scanners, and fires alerts.

To disable anomaly detection, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter analysis engine submode.
- ```
sensor# configure terminal
sensor(config)# service analysis-engine
sensor(config-ana)#
```
- Step 3** Enter the virtual sensor name that contains the anomaly detection policy you want to disable.
- ```
sensor(config-ana)# virtual-sensor vs0
sensor(config-ana-vir)#
```
- Step 4** Disable anomaly detection operational mode.
- ```
sensor(config-ana-vir)# anomaly-detection
sensor(config-ana-vir-ano)# operational-mode inactive
sensor(config-ana-vir-ano)#
```
- Step 5** Exit analysis engine submode.
- ```
sensor(config-ana-vir-ano)# exit
sensor(config-ana-vir)# exit
sensor(config-ana)# exit
Apply Changes?[yes]:
```
- Step 6** Press **Enter** to apply your changes or enter **no** to discard them.
-

For More Information

For more information about how worms operate, see [Understanding Worms](#), page 9-2.



Configuring Global Correlation

This chapter provides information for configuring global correlation. It contains the following sections:

- [Global Correlation Notes and Caveats, page 10-1](#)
- [Understanding Global Correlation, page 10-2](#)
- [Participating in the SensorBase Network, page 10-2](#)
- [Understanding Reputation, page 10-3](#)
- [Understanding Network Participation, page 10-4](#)
- [Understanding Efficacy, page 10-5](#)
- [Understanding Reputation and Risk Rating, page 10-6](#)
- [Global Correlation Features and Goals, page 10-6](#)
- [Global Correlation Requirements, page 10-7](#)
- [Understanding Global Correlation Sensor Health Metrics, page 10-8](#)
- [Configuring Global Correlation Inspection and Reputation Filtering, page 10-8](#)
- [Configuring Network Participation, page 10-11](#)
- [Troubleshooting Global Correlation, page 10-13](#)
- [Disabling Global Correlation, page 10-13](#)
- [Displaying Global Correlation Statistics, page 10-14](#)

Global Correlation Notes and Caveats

The following notes and caveats apply to configuring global correlation:

- The global correlation features are supported in IPS 7.0 and later.
- As with signature updates, when the sensor applies a global correlation update, it may trigger bypass. Whether or not bypass is triggered depends on the traffic load of the sensor and the size of the signature/global correlation update. If bypass mode is turned off, an inline sensor stops passing traffic while the update is being applied.
- Network participation requires a network connection to the Internet.
- Valid license—You must have a valid sensor license for global correlation features to function. You can still configure and display statistics for the global correlation features, but the global correlation databases are cleared and no updates are attempted. Once you install a valid license, the global correlation features are reactivated.

- Global correlation inspection and the reputation filtering deny features do not support IPv6 addresses. For global correlation inspection, the sensor does not receive or process reputation data for IPv6 addresses. The risk rating for IPv6 addresses is not modified for global correlation inspection. Similarly, network participation does not include event data for attacks from IPv6 addresses. And finally, IPv6 addresses do not appear in the deny list.
- The sensor must operate in inline mode so that the global correlation features can increase efficacy by being able to use the inline deny actions.
- For global correlation to function, you must have either a DNS server or an HTTP proxy server configured at all times.

Understanding Global Correlation

You can configure global correlation so that your sensors are aware of network devices with a reputation for malicious activity, and can take action against them. Participating IPS devices in a centralized Cisco threat database, the SensorBase Network, receive and absorb global correlation updates. The reputation information contained in the global correlation updates is factored in to the analysis of network traffic, which increases IPS efficacy, since traffic is denied or allowed based on the reputation of the source IP address. The participating IPS devices send data back to the Cisco SensorBase Network, which results in a feedback loop that keeps the updates current and global.

You can configure the sensor to participate in the global correlation updates and/or in sending telemetry data or you can turn both services off. You can view reputation scores in events and see the reputation score of the attacker. You can also view statistics from the reputation filter.

Participating in the SensorBase Network

The Cisco IPS contains a security capability, Cisco Global Correlation, which uses the immense security intelligence that we have amassed over the years. At regular intervals, the Cisco IPS receives threat updates from the Cisco SensorBase Network, which contain detailed information about known threats on the Internet, including serial attackers, Botnet harvesters, Malware outbreaks, and dark nets. The IPS uses this information to filter out the worst attackers before they have a chance to attack critical assets. It then incorporates the global threat data in to its system to detect and prevent malicious activity even earlier.

If you agree to participate in the SensorBase Network, Cisco will collect aggregated statistics about traffic sent to your IPS. This includes summary data on the Cisco IPS network traffic properties and how this traffic was handled by the Cisco appliances. We do not collect the data content of traffic or other confidential business or personal information. All data is aggregated and sent by secure HTTP to the Cisco SensorBase Network servers in periodic intervals. All data shared with Cisco will be anonymous and treated as strictly confidential.

Table 10-1 shows how we use the data.

Table 10-1 Cisco Network Participation Data Use

Participation Level	Type of Data	Purpose
Partial	Protocol attributes (TCP maximum segment size and options string, for example)	Tracks potential threats and helps us to understand threat exposure.
	Attack type (signature fired and risk rating, for example)	Used to understand current attacks and attack severity.
	Connecting IP address and port	Identifies attack source.
	Summary IPS performance (CPU utilization, memory usage, inline vs. promiscuous, for example)	Tracks product efficacy.
Full	Victim IP address and port	Detects threat behavioral patterns.

When you enable Partial or Full Network Participation, the Network Participation Disclaimer appears. You must enter **yes** to participate. If you do not have a license installed, you receive a warning telling you that global correlation inspection and reputation filtering are disabled until the sensor is licensed. You can obtain a license at <http://www.cisco.com/go/license>.

For More Information

For information on how to obtain and install a sensor license, see [Installing the License Key, page 4-56](#).


Understanding Reputation

Similar to human social interaction, reputation is an opinion toward a device on the Internet. It enables the installed base of IPS sensors in the field to collaborate using the existing network infrastructure. A network device with reputation is most likely either malicious or infected. You can view reputation information and statistics in the IDM, IME, or the CLI.

The IPS sensor collaborates with the global correlation servers (also known as reputation servers) to improve the efficacy of the sensor.

Figure 10-1 shows the role of the sensor and the global correlation servers.

Figure 10-1 *IPS Management and Global Correlation Server Interaction*



The global correlation servers provide information to the sensor about certain IP addresses that may identify malicious or infected hosts. The sensor uses this information to determine which actions, if any, to perform when potentially harmful traffic is received from a host with known reputation. Because the global correlation database changes rapidly, the sensor must periodically download global correlation updates from the global correlation servers.



Caution

As with signature updates, when the sensor applies a global correlation update, it may trigger bypass. Whether or not bypass is triggered depends on the traffic load of the sensor and the size of the signature/global correlation update. If bypass mode is turned off, an inline sensor stops passing traffic while the update is being applied.

For More Information

For more information about viewing global correlation statistics, see [Displaying Statistics](#), page 17-31.

Understanding Network Participation

Network participation lets us collect nearly real-time data from sensors around the world. Sensors installed at customer sites can send data to the SensorBase Network. These data feed in to the global correlation database to increase reputation fidelity. Communication between sensors and the SensorBase Network involves an HTTPS request and response over TCP/IP. Network participation gathers the following data:

- Signature ID
- Attacker IP address
- Attacker port
- Maximum segment size
- Victim IP address
- Victim port
- Signature version
- TCP options string
- Reputation score
- Risk rating

- Data gathered from the sensor health metrics

The statistics for network participation show the hits and misses for alerts, the reputation actions, and the counters of packets that have been denied.

**Note**

Network participation requires a network connection to the Internet.

There are three modes for network participation:

- Off—The network participation server does not collect data, track statistics, or try to contact the Cisco SensorBase Network.
- Partial Participation—The network participation server collects data, tracks statistics, and communicates with the SensorBase Network. Data considered to be potentially sensitive is filtered out and never sent.
- Full Participation—The network participation server collects data, tracks statistics, and communicates with the SensorBase Network. All data collected is sent except the IP addresses that you exclude from the network participation data.

**Caution**

As with signature updates, when the sensor applies a global correlation update, it may trigger bypass. Whether or not bypass is triggered depends on the traffic load of the sensor and the size of the signature/global correlation update. If bypass mode is turned off, an inline sensor stops passing traffic while the update is being applied.

For More Information

- For more information on network participation, see [Configuring Network Participation, page 10-11](#).
- For more information on bypass mode, see [Configuring Inline Bypass Mode, page 5-38](#).

Understanding Efficacy

Obtaining data from participating IPS clients and using that in conjunction with the existing corpus of threat knowledge improves the efficacy of the IPS. We measure efficacy based on the following:

- False positives as a percentage of actionable events
- False negatives as a percentage of threats that do not result in actionable events
- Actionable events as a percentage of all events

The IPS signature team uses the data to improve signature fidelity and the IPS engineering team uses the data to better understand the various types of sensor deployment.

For More Information

For more information about reputation and risk rating, see [Understanding Reputation and Risk Rating, page 10-6](#).

Understanding Reputation and Risk Rating

Risk rating is the concept of the probability that a network event is malicious. You assign a numerical quantification of the risk associated with a particular event on the network. By default, an alert with an extreme risk rating shuts down traffic. Reputation indicates the probability that a particular attacker IP address will initiate malicious behavior based on its known past activity. A certain score is computed for this reputation by the Alarm Channel and added to risk rating, thus improving the efficacy of the IPS. When the attacker has a bad reputation score, an incremental risk is added to the risk rating to make it more aggressive.

The Alarm Channel handles signature events from the data path. The alert processing units have multiple aggregation techniques, action overrides, action filters, attacker reputation, and per-action custom handling methods. We use the large reputation data from the reputation participation client to score attackers in the Alarm Channel and then use this score to influence the risk rating and actions of the alert.

For More Information

- For a detailed description of risk rating, see [Calculating the Risk Rating, page 7-13](#).
- For a detailed description of threat rating, see [Understanding Threat Rating, page 7-15](#).
- For a detailed description of event action filters, see [Configuring Event Action Filters, page 7-20](#).
- For a detailed description of the Alarm Channel, see [Understanding the SensorApp, page A-23](#).
- For a detailed description of event action aggregation, see [Understanding Event Action Aggregation, page 7-33](#).

Global Correlation Features and Goals

There are three main features of global correlation:

- Global Correlation Inspection—We use the global correlation reputation knowledge of attackers to influence alert handling and deny actions when attackers with a bad score are seen on the sensor.
- Reputation Filtering—Applies automatic deny actions to packets from known malicious sites.
- Network Reputation—Sensor sends alert and TCP fingerprint data to the SensorBase Network.

Global correlation has the following goals:

- Dealing intelligently with alerts thus improving efficacy.
- Improving protection against known malicious sites.
- Sharing telemetry data with the SensorBase Network to improve visibility of alerts and sensor actions on a global scale.
- Simplifying configuration settings.
- Automatic handling of the uploads and downloads of the information.

Global Correlation Requirements

Global correlation has the following requirements:

- Valid license—You must have a valid sensor license for global correlation features to function. You can still configure and display statistics for the global correlation features, but the global correlation databases are cleared and no updates are attempted. Once you install a valid license, the global correlation features are reactivated.
- Network Participation disclaimer—You must agree to the disclaimer to participate.
- External connectivity for the sensor and a DNS server—The global correlation features of Cisco IPS require the sensor to connect to the Cisco SensorBase Network. Domain name resolution is also required for these features to function. You can either configure the sensor to connect through an HTTP proxy server that has a DNS client running on it, or you can assign an Internet routeable address to the management interface of the sensor and configure the sensor to use a DNS server. In Cisco IPS the HTTP proxy and DNS servers are used only by the global correlation features.

If you are connecting through an HTTP proxy, make sure you have the following configuration:

- The proxy must allow HTTP requests from the IPS systems to `http://updates.ironport.com/ibrs/` on port 80.
- The proxy must allow HTTPS requests from the IPS systems to `update-manifests.ironport.com` on port 443.
- The firewall must allow access from the proxy to the internet (any destination address) on ports 80 and 443.

If you are NOT connecting through the HTTP proxy:

- The firewall must allow access from each IPS to the Internet (any destination address) on ports 80 and 443.



Note The IPS does not support the use of authenticated proxies.

- Sensors deployed in an environment with a slow command and control connection will be slow to download global correlation updates.
- No IPv6 address support—Global correlation inspection and the reputation filtering deny features do not support IPv6 addresses. For global correlation inspection, the sensor does not receive or process reputation data for IPv6 addresses. The risk rating for IPv6 addresses is not modified for global correlation inspection. Similarly, network participation does not include event data for attacks from IPv6 addresses. And finally, IPv6 addresses do not appear in the deny list.
- Sensor in inline mode—The sensor must operate in inline mode so that the global correlation features can increase efficacy by being able to use the inline deny actions.
- Sensor that supports the global correlation features.
- IPS version that supports the global correlation features.

For More Information

- For information on how to obtain and install a sensor license, see [Installing the License Key, page 4-56](#).
- For information about the Network Participation disclaimer, see [Participating in the SensorBase Network, page 10-2](#).

- For information about configuring an HTTP proxy or DNS server to support global correlation, see [Configuring the DNS and Proxy Servers for Global Correlation, page 4-10](#).

Understanding Global Correlation Sensor Health Metrics

For global correlation, the following metrics are added to sensor health monitoring:

- Green indicates that the last update was successful.
- Yellow indicates that there has not been a successful update within the past day (86,400 seconds).
- Red indicates that there has not been a successful update within the last three days (259,200 seconds).

For network participation, the following metrics are added to sensor health monitoring:

- Green indicates that the last connection was successful.
- Yellow indicates that less than 6 connections failed in a row.
- Red indicates that more than 6 connections failed in a row.

Use the **health-monitor** command in service submode to configure the health statistics for the sensor. Use the **show health** command to see the results of the **health-monitor** command.

Global correlation health status defaults to red and changes to green after a successful global correlation update. Successful global correlation updates require a DNS server or an HTTP proxy server. Because DNS and HTTP proxy server configuration features are beginning with IPS 7.0(1)E3, they are unconfigured after an upgrade from 6.x to 7.0(1)E3 or higher. As a result, global correlation health and overall sensor health status are red until you configure a DNS or HTTP proxy server on the sensor. If the sensor is deployed in an environment where a DNS or HTTP proxy server is not available, you can address the red global correlation health and overall sensor health status by disabling global correlation and configuring sensor health status not to include global correlation health status.

For More Information

- For more information about the sensor health metrics and how to enable/disable Global Correlation health status, see [Configuring Health Status Information, page 17-15](#).
- For the procedure to view sensor health metrics, see [Showing Sensor Overall Health Status, page 17-20](#).
- For information about configuring an HTTP proxy or DNS server to support global correlation, see [Configuring the DNS and Proxy Servers for Global Correlation, page 4-10](#).
- For the procedure to disable global correlation, see [Configuring Global Correlation Inspection and Reputation Filtering, page 10-10](#).

Configuring Global Correlation Inspection and Reputation Filtering

This section describes global correlation inspection and reputation filtering, and how to configure them. It contains the following topics:


- [Understanding Global Correlation Inspection and Reputation Filtering, page 10-9](#)
- [Configuring Global Correlation Inspection and Reputation Filtering, page 10-10](#)

Understanding Global Correlation Inspection and Reputation Filtering

You can configure the sensor to use updates from the SensorBase Network to adjust the risk rating. The client determines which updates are available and applicable to the sensor by communicating with the global correlation update server and a file server, which is a two-phase process. In the first phase the sensor sends a client manifest to the global correlation update server via an HTTPS POST request. The server then returns the server manifest document in the HTTPS response. In the next phase the sensor identifies the updates that are available and how to obtain them from a file server. The sensor downloads the encrypted update files via HTTP from the file server using the information in the server manifest. The integrity of these update files has been verified by comparing its MD5 hash with the hash value specified in the server manifest.

Figure 10-2 demonstrates how the global correlation update client obtains the files.

Figure 10-2 Global Correlation Update Client



Caution

You must have a valid sensor license for global correlation features to function. You can still configure and display statistics for the global correlation features, but the global correlation databases are cleared and no updates are attempted. Once you install a valid license, the global correlation features are reactivated.

Once you configure global correlation, updates are automatic and happen at regular intervals, approximately every five minutes by default, but this interval may be modified by the global correlation server. The sensor gets a full update and then applies an incremental update periodically.

You configure an HTTP proxy or a DNS server in the service network-setting submode. If you turn on global correlation, you can choose how aggressively you want the deny actions to be enforced against malicious hosts. You can then enable reputation filtering to deny access to known malicious hosts. If you only want a report of what could have happened, you can enable **test-global-correlation**. This puts the sensor in audit mode, and actions the sensor would have performed are generated in the events.

Use the **show health** command in privileged EXEC mode to display the overall health status information of the sensor. The health status categories are rated by red and green with red being critical.



Caution

As with signature updates, when the sensor applies a global correlation update, it may trigger bypass. Whether or not bypass is triggered depends on the traffic load of the sensor and the size of the signature/global correlation update. If bypass mode is turned off, an inline sensor stops passing traffic while the update is being applied.

For More Information

- For the procedure for configuring global correlation features, see [Configuring Global Correlation Inspection and Reputation Filtering, page 10-10](#).
- For the procedure to view sensor health metrics, see [Showing Sensor Overall Health Status, page 17-20](#).
- For information on the CollaborationApp, see [CollaborationApp, page A-28](#).
- For more information on bypass mode, see [Configuring Inline Bypass Mode, page 5-38](#).

Configuring Global Correlation Inspection and Reputation Filtering

**Caution**

For global correlation to function, you must have either a DNS server or an HTTP proxy server configured at all times.

The following options apply:

- **global-correlation-inspection {on | off}**—Turns global correlation inspection on or off. When turned on, the sensor uses updates from the SensorBase network to adjust the risk rating. The default is on.
- **global-correlation-inspection-influence {permissive | standard | aggressive}**—Lets you choose the level of global correlation inspection. The default is standard.
 - **permissive**—Global correlation data has little influence in the decision to deny traffic.
 - **standard**—Global correlation moderately influences the decision to deny traffic.
 - **aggressive**—Global correlation data heavily influences the decision to deny traffic.
- **reputation-filtering {on | off}**—Turns reputation filtering on or off. When turned on, the sensor denies access to malicious hosts that are listed in the global correlation database. The default is on.
- **test-global-correlation {on | off}**—Enables reporting of deny actions that are affected by global correlation. Allows you to test the global correlation features without actually denying any hosts. The default is off.

Configuring Global Correlation

To configure global correlation features, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter global correlation submode.

```
sensor# configure terminal
sensor(config)# service global-correlation
sensor(config-glo)#
```

Step 3 Turn on global correlation inspection.

```
sensor(config-glo)# global-correlation-inspection on
sensor(config-glo)#
```

Step 4 Specify the level of global correlation inspection.

```
sensor(config-glo)# global-correlation-inspection-influence aggressive
sensor(config-glo)#
```


Step 5 Turn on reputation filtering.

```
sensor(config-glo)# reputation-filtering on
sensor(config-glo)#
```

Step 6 Test global correlation data, but do not actually deny traffic.

```
sensor(config-glo)# test-global-correlation on
sensor(config-glo)#
```

Step 7 Verify the settings.

```
sensor(config-glo)# show settings
  global-correlation-inspection: on default: on
  global-correlation-inspection-influence: aggressive default: standard
  reputation-filtering: on default: on
  test-global-correlation: on default: off
sensor(config-glo)#
```

Step 8 Exit global correlation submode.

```
sensor(config-glo)# exit
Apply Changes:[yes]:
```

Step 9 Press **Enter** to apply your changes or enter **no** to discard them.

For More Information

- For information about configuring a proxy or DNS server to support global correlation, see [Configuring the DNS and Proxy Servers for Global Correlation, page 4-10](#).
- For information on how to obtain and install a sensor license, see [Installing the License Key, page 4-56](#).
- For more information about the sensor health metrics, see [Showing Sensor Overall Health Status, page 17-20](#).

Configuring Network Participation

You can configure the sensor to send data to the SensorBase Network. You can configure the sensor to fully participate and send all data to the SensorBase Network. Or you can configure the sensor to collect the data but to omit potentially sensitive data, such as the destination IP address of trigger packets.



Note

Configuring the sensor for partial network participation limits a third party from extracting reconnaissance information about your internal network from the global correlation database.

The following option applies:

- **network-participation**—Sets the level of network participation. The default is off.
 - **off**—No data is contributed to the SensorBase network.
 - **partial**—Data is contributed to the SensorBase network but potentially sensitive information is withheld.
 - **full**—All data is contributed to the SensorBase network.

**Note**

You must accept the network participation disclaimer to turn on network participation.

Turning on Network Participation

To turn on network participation, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter global correlation submode.

```
sensor# configure terminal
sensor(config)# service global-correlation
sensor(config-glo)#
```

Step 3 Turn on network participation.

```
sensor(config-glo)# network-participation [full | partial]
sensor(config-glo)# exit
```

Step 4 Enter **yes** to agree to participate in the SensorBase Network.

If you agree to participate in the SensorBase Network, Cisco will collect aggregated statistics about traffic sent to your IPS. This includes summary data on the Cisco IPS network traffic properties and how this traffic was handled by the Cisco appliances. We do not collect the data content of traffic or other sensitive business or personal information. All data is aggregated and sent via secure HTTP to the Cisco SensorBase Network servers in periodic intervals. All data shared with Cisco will be anonymous and treated as strictly confidential.

The table below describes how the data will be used by Cisco.

Participation Level = "Partial":

- * Type of Data: Protocol Attributes (e.g. TCP max segment size and options string)
Purpose: Track potential threats and understand threat exposure
- * Type of Data: Attack Type (e.g. Signature Fired and Risk Rating)
Purpose: Used to understand current attacks and attack severity
- * Type of Data: Connecting IP Address and port
Purpose: Identifies attack source
- * Type of Data: Summary IPS performance (CPU utilization memory usage, inline vs. promiscuous, etc)
Purpose: Tracks product efficacy

Participation Level = "Full" additionally includes:

- * Type of Data: Victim IP Address and port
Purpose: Detect threat behavioral patterns

Do you agree to participate in the SensorBase Network?[no]:

Step 5 Verify the settings.

```
sensor(config-glo)# show settings
network-participation: full default: off
global-correlation-inspection: on default: on
global-correlation-inspection-influence: aggressive default: standard
reputation-filtering: on default: on
test-global-correlation: on default: off
sensor(config-glo)#
```

Step 6 Exit global correlation submode.

```
sensor(config-glo)# exit
Apply Changes:[yes]:
```

Step 7 Press **Enter** to apply your changes or enter **no** to discard them.

For More Information

For more information about participating in the SensorBase Network, see [Participating in the SensorBase Network, page 10-2](#).

Troubleshooting Global Correlation

Make sure you observe the following when configuring global correlation:

- Because global correlation updates occur through the sensor management interface, firewalls must allow port 443/80 traffic.
- You must have an HTTP proxy server or a DNS server configured to allow global correlation features to function.
- cYou must have a valid IPS license to allow global correlation features to function.
- Global correlation features only contain external IP addresses, so if you position a sensor in an internal lab, you may never receive global correlation information.
- Make sure your sensor supports the global correlation features.
- Make sure your IPS version supports the global correlation features.

For More Information

- For the procedure for configuring a DNS or HTTP proxy server, see [Configuring the DNS and Proxy Servers for Global Correlation, page 4-10](#).
- For the procedure for obtaining an IPS license, see [Installing the License Key, page 4-56](#).
- For detailed information about HTTP proxy server configuration, see [Global Correlation Requirements, page 10-7](#).

Disabling Global Correlation

If your sensor is deployed in an environment where a DNS server or HTTP proxy server is not available, you may want to disable global correlation so that global correlation health does not appear as red in the overall sensor health, thus indicating a problem. You can also configure sensor health to exclude global correlation status.

The following options apply:

- **global-correlation-inspection {on | off}**—Turns global correlation inspection on or off. When turned on, the sensor uses updates from the SensorBase network to adjust the risk rating. The default is on.
- **reputation-filtering {on | off}**—Turns reputation filtering on or off. When turned on, the sensor denies access to malicious hosts that are listed in the global correlation database. The default is on.
- **network-participation**—Sets the level of network participation. The default is off.
 - **off**—No data is contributed to the SensorBase network.
 - **partial**—Data is contributed to the SensorBase network but potentially sensitive information is withheld.

- **full**—All data is contributed to the SensorBase network.

Disabling Global Correlation

To disable global correlation features, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter global correlation submode.

```
sensor# configure terminal
sensor(config)# service global-correlation
sensor(config-glo)#
```

Step 3 Turn off global correlation inspection.

```
sensor(config-glo)# global-correlation-inspection off
sensor(config-glo)#
```

Step 4 Turn off reputation filtering.

```
sensor(config-glo)# reputation-filtering off
sensor(config-glo)#
```

Step 5 Turn off network participation.

```
sensor(config-glo)# network-participation off
sensor(config-glo)# exit
```

Step 6 Verify the settings.

```
sensor(config-glo)# show settings
  network-participation: full default: off
  global-correlation-inspection: on default: off
  reputation-filtering: on default: off
sensor(config-glo)#
```

Step 7 Exit global correlation submode.

```
sensor(config-glo)# exit
Apply Changes:[yes]:
```

Step 8 Press **Enter** to apply your changes or enter **no** to discard them.

Displaying Global Correlation Statistics

Use the **show statistics global-correlation** command to display global correlation statistics. Use the **show statistics global-correlation [name | clear]** command to display statistics for these components for all virtual sensors. If you provide the virtual sensor name, the statistics for that virtual sensor only are displayed.



Note

For IPS 7.0(7)E4 and later and IPS 7.1(5)E4 and later, the output includes any failures that have been detected.

To display and clear global correlation statistics for the sensor, follow these steps:

Step 1 Log in to the CLI.

Step 2 Display the statistics for global correlation.

```
sensor# show statistics global-correlation
Network Participation:
  Counters:
    Total Connection Attempts = 4347
    Total Connection Failures = 155
    Connection Failures Since Last Success = 0
  Connection History:
    Connection Attempt on June 17 2012, at 21:57:19 UTC = Successful
    Connection Attempt on June 17 2012, at 21:54:18 UTC = Successful
    Connection Attempt on June 17 2012, at 21:51:17 UTC = Successful
    Connection Attempt on June 17 2012, at 21:48:17 UTC = Successful
    Connection Attempt on June 17 2012, at 21:45:16 UTC = Successful
Updates:
  Status Of Last Update Attempt = Disabled
  Time Since Last Successful Update = never
  Counters:
    Update Failures Since Last Success = 0
    Total Update Attempts = 0
    Total Update Failures = 0
  Update Interval In Seconds = 300
  Update Server = update-manifests.ironport.com
  Update Server Address = Unknown
  Current Versions:
Warnings:
Details:
  Last fail log =
sensor#
```

Step 3 Clear the statistics for global correlation:

```
sensor# show statistics global-correlation clear
Network Participation:
  Counters:
    Total Connection Attempts = 0
    Total Connection Failures = 0
    Connection Failures Since Last Success = 0
  Connection History:
    Connection Attempt on June 17 2012, at 22:03:20 UTC = Successful
    Connection Attempt on June 17 2012, at 22:00:19 UTC = Successful
    Connection Attempt on June 17 2012, at 21:57:19 UTC = Successful
    Connection Attempt on June 17 2012, at 21:54:18 UTC = Successful
    Connection Attempt on June 17 2012, at 21:51:17 UTC = Successful
Updates:
  Status Of Last Update Attempt = Disabled
  Time Since Last Successful Update = never
  Counters:
    Update Failures Since Last Success = 0
    Total Update Attempts = 0
    Total Update Failures = 0
```

```
Update Interval In Seconds = 300
Update Server = update-manifests.ironport.com
Update Server Address = Unknown
Current Versions:
Warnings:
Details:
  Last fail log =
sensor#
```



Configuring External Product Interfaces

This chapter explains how to configure external product interfaces. It contains the following sections:

- [External Product Interface Notes and Caveats, page 11-1](#)
- [Understanding External Product Interfaces, page 11-1](#)
- [Understanding the CSA MC, page 11-2](#)
- [External Product Interface Issues, page 11-3](#)
- [Configuring the CSA MC to Support the IPS Interface, page 11-4](#)
- [Adding External Product Interfaces and Posture ACLs, page 11-4](#)
- [Troubleshooting External Product Interfaces, page 11-8](#)

External Product Interface Notes and Caveats

The following notes and caveats apply to external product interfaces:

- In Cisco IPS, you can only add interfaces to the CSA MC.
- You can only enable two CSA MC interfaces.
- You must add the CSA MC as a trusted host so the sensor can communicate with it.

Understanding External Product Interfaces



Note

In Cisco IPS, you can only add interfaces to the CSA MC.

The external product interface is designed to receive and process information from external security and management products. These external security and management products collect information that can be used to automatically enhance the sensor configuration information. For example, the types of information that can be received from external products include host profiles (the host OS configuration, application configuration, and security posture) and IP addresses that have been identified as causing malicious network activity.

Understanding the CSA MC

The CSA MC enforces a security policy on network hosts. It has two components:

- Agents that reside on and protect network hosts.
- Management Console (MC)—An application that manages agents. It downloads security policy updates to agents and uploads operational information from agents.

The CSA MC receives host posture information from the CSA agents it manages. It also maintains a watch list of IP addresses that it has determined should be quarantined from the network. The CSA MC sends two types of events to the sensor—host posture events and quarantined IP address events.

Host posture events (called imported OS identifications in IPS) contain the following information:

- Unique host ID assigned by the CSA MC
- CSA agent status
- Host system hostname
- Set of IP addresses enabled on the host
- CSA software version
- CSA polling status
- CSA test mode status
- NAC posture

For example, when an OS-specific signature fires whose target is running that OS, the attack is highly relevant and the response should be greater. If the target OS is different, then the attack is less relevant and the response may be less critical. The signature attack relevance rating is adjusted for this host.

The quarantined host events (called the watch list in IPS) contain the following information:

- IP address
- Reason for the quarantine
- Protocol associated with a rule violation (TCP, UDP, or ICMP)
- Indicator of whether a rule-based violation was associated with an established session or a UDP packet.

For example, if a signature fires that lists one of these hosts as the attacker, it is presumed to be that much more serious. The risk rating is increased for this host. The magnitude of the increase depends on what caused the host to be quarantined.

The sensor uses the information from these events to determine the risk rating increase based on the information in the event and the risk rating configuration settings for host postures and quarantined IP addresses.

**Note**

The host posture and watch list IP address information is not associated with a virtual sensor, but is treated as global information.

Secure communications between the CSA MC and the IPS sensor are maintained through SSL/TLS. The sensor initiates SSL/TLS communications with the CSA MC. This communication is mutually authenticated. The CSA MC authenticates by providing X.509 certificates. The sensor uses username/password authentication.

**Note**

You can only enable two CSA MC interfaces.

**Caution**

You must add the CSA MC as a trusted host so the sensor can communicate with it.

For More Information

For the procedure for adding trusted hosts, see [Adding TLS Trusted Hosts, page 4-51](#).

External Product Interface Issues

When the external product interface receives host posture and quarantine events, the following issues can arise:

- The sensor can store only a certain number of host records:
 - If the number of records exceeds 10,000, subsequent records are dropped.
 - If the 10,000 limit is reached and then it drops to below 9900, new records are no longer dropped.
- Hosts can change an IP address or appear to use another host IP address, for example, because of DHCP lease expiration or movement in a wireless network. In the case of an IP address conflict, the sensor presumes the most recent host posture event to be the most accurate.
- A network can include overlapping IP address ranges in different VLANs, but host postures do not include VLAN ID information. You can configure the sensor to ignore specified address ranges.
- A host can be unreachable from the CSA MC because it is behind a firewall. You can exclude unreachable hosts.
- The CSA MC event server allows up to ten open subscriptions by default. You can change this value. You must have an administrative account and password to open subscriptions.
- CSA data is not virtualized; it is treated globally by the sensor.
- Host posture OS and IP addresses are integrated into passive OS fingerprinting storage. You can view them as imported OS profiles.
- You cannot see the quarantined hosts.
- The sensor must recognize each CSA MC host X.509 certificate. You must add them as a trusted host.
- You can configure a maximum of two external product devices.

For More Information

- For more information on working with OS maps and identifications, see [Adding, Editing, Deleting, and Moving Configured OS Maps, page 7-28](#) and [Displaying and Clearing OS Identifications, page 7-32](#).
- For the procedure for adding trusted hosts, see [Adding TLS Trusted Hosts, page 4-51](#).

Configuring the CSA MC to Support the IPS Interface

**Note**

For more detailed information about host posture events and quarantined IP address events, refer to [Using Management Center for Cisco Security Agents 5.1](#).

You must configure the CSA MC to send host posture events and quarantined IP address events to the sensor. To configure the CSA MC to support IPS interfaces, follow these steps:

Step 1 Choose **Events > Status Summary**.

Step 2 In the Network Status section, click **No** beside **Host history collection enabled**, and then click **Enable** in the popup window.

**Note**

Host history collection is enabled globally for the system. This feature is disabled by default because the MC log file tends to fill quickly when it is turned on.

Step 3 Choose **Systems > Groups** to create a new group (with no hosts) to use in conjunction with administrator account you will next create.

Step 4 Choose **Maintenance > Administrators > Account Management** to create a new CSA MC administrator account to provide IPS access to the MC system.

Step 5 Create a new administrator account with the role of **Monitor**. This maintains the security of the MC by not allowing this new account to have configure privileges.

**Note**

Remember the username and password for this administrator account because you need them to configure external product interfaces on the sensor.

Step 6 Choose **Maintenance > Administrators > Access Control** to further limit this administrator account.

Step 7 In the Access Control window, select the administrator you created and select the group you created.

**Note**

When you save this configuration, you further limit the MC access of this new administrator account with the purpose of maintaining security on the CSA MC.

Adding External Product Interfaces and Posture ACLs

**Caution**

In the Cisco IPS, the only external product interfaces you can add are CSA MC interfaces. The Cisco IPS supports two CSA MC interfaces.

Use the **cisco-security-agents-mc-settings** *ip-address* command in service external product interfaces submode to add the CSA MC as an external product interface. The following options apply:

- **enabled {yes | no}**—Enables/disables the receipt of information from the CSA MC.
- **host-posture-settings**—Specifies how host postures received from the CSA MC are handled:
 - **allow-unreachable-postures {yes | no}**—Allows postures for hosts that are not reachable by the CSA MC.

A host is not reachable if the CSA MC cannot establish a connection with the host on any IP addresses in the posture of the host. This option is useful in filtering the postures whose IP addresses may not be visible to the IPS or may be duplicated across the network. This filter is most applicable in network topologies where hosts that are not reachable by the CSA MC are also not reachable by the IPS, for example if the IPS and the CSA MC are on the same network segment.
 - **enabled {yes | no}**—Enables/disables receipt of host postures from the CSA MC.
 - **posture-acls {edit | insert | move} name1 {begin | end | inactive | before | after}**—Specifies the list of permitted or denied posture addresses. This command provides a mechanism for filtering postures that have IP addresses that may not be visible to the IPS or may be duplicated across the network.
 - **action {permit | deny}**—Specifies the permit or deny postures that match the specified network address.
 - **network-address address**—Specifies the network address, in the form x.x.x.x/nn, for postures to be permitted or denied.
- **password**—Specifies the password used to log in to the CSA MC.
- **port**—Specifies the TCP port to connect to on the CSA MC. The valid range is 1 to 65535. The default is 443.
- **username**—Specifies the username used to log in to the CSA MC.
- **watchlist-address-settings**—Specifies how watch listed addresses received from the CSA MC are handled:
 - **enabled {yes | no}**—Enables/disables receipt of watch list addresses from the CSA MC.
 - **manual-rr-increase**—Specifies the number added to an event RR because the attacker has been manually watch-listed by the CSA MC. The valid range is 0 to 35. The default is 25.
 - **packet-rr-increase**—Specifies the number added to an event risk rating because the attacker has been watch listed by the CSA MC because of a sessionless packet-based policy violation. The valid range is 0 to 35. The default is 10.
 - **session-rr-increase**—Specifies the number added to an event risk rating because the attacker has been watch-listed by the CSA MC because of a session-based policy violation. The valid range is 0 to 35. The default is 25.



Note

Make sure you add the external product as a trusted host so the sensor can communicate with it.

Adding External Product Interfaces

To add external product interfaces, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter external product interfaces submode.

```
sensor# configure terminal
sensor(config)# service external-product-interface
```

Step 3 Add the CSA MC interface.

```
sensor(config-ext)# cisco-security-agents-mc-settings 209.165.200.225

sensor(config-ext-cis)#
```

Step 4 Enable receipt of information from the CSA MC.

```
sensor(config-ext-cis)# enabled yes
```

Step 5 Change the default port setting.

```
sensor(config-ext-cis)# port 80
```

Step 6 Configure the login settings:

a. Enter the username.

```
sensor(config-ext-cis)# username jsmith
```

b. Enter and confirm the password.

```
sensor(config-ext-cis)# password
Enter password[]: *****
Re-enter password: *****
sensor(config-ext-cis)#
```



Note

Steps 7 through 10 are optional. If you do not perform Steps 7 through 10, the default values are used to receive all the CSA MC information with no filters applied.

Step 7 (Optional) Configure the watch list settings:

a. Allow the watch list information to be passed from the external product to the sensor.

```
sensor(config-ext-cis-wat)# enabled yes
```



Note

If you do not enable the watch list, the watch list information received from a CSA MC is deleted.

b. Change the percentage of the manual watch list RR from the default of 25.

```
sensor(config-ext-cis-wat)# manual-rr-increase 30
```

c. Change the percentage of the session-based watch list RR from the default of 25.

```
sensor(config-ext-cis-wat)# session-rr-increase 30
```

d. Change the percentage of the packet-based watch list RR from the default of 10.

```
sensor(config-ext-cis-wat)# packet-rr-increase 20
```

- Step 8** (Optional) Allow the host posture information to be passed from the external product to the sensor.

```
sensor(config-ext-cis)# host-posture-settings
sensor(config-ext-cis-hos)# enabled yes
```



Note If you do not enable the host posture information, the host posture information received from a CSA MC is deleted.

- Step 9** (Optional) Allow the host posture information from unreachable hosts to be passed from the external product to the sensor.

```
sensor(config-ext-cis-hos)# allow-unreachable-postures yes
```



Note A host is not reachable if the CSA MC cannot establish a connection with the host on any of the IP addresses in the host's posture. This option is useful in filtering the postures whose IP addresses may not be visible to the IPS or may be duplicated across the network. This filter is most applicable in network topologies where hosts that are not reachable by the CSA MC are also not reachable by the IPS, for example if the IPS and the CSA MC are on the same network segment.

- Step 10** Configure a posture ACL:

- a. Add the posture ACL into the ACL list.

```
sensor(config-ext-cis-hos)# posture-acls insert name1 begin
sensor(config-ext-cis-hos-pos)#
```



Note Posture ACLs are network address ranges for which host postures are allowed or denied. Use posture ACLs to filter postures that have IP addresses that may not be visible to the IPS or may be duplicated across the network.

- b. Enter the network address the posture ACL will use.

```
sensor(config-ext-cis-hos-pos)# network-address 192.0.2.0/24
```

- c. Choose the action (deny or permit) the posture ACL will take.

```
sensor(config-ext-cis-hos-pos)# action permit
```

- Step 11** Verify the settings.

```
sensor(config-ext-cis-hos-pos)# exit
sensor(config-ext-cis-hos)# exit
sensor(config-ext-cis)# exit
sensor(config-ext)# show settings
cisco-security-agents-mc-settings (min: 0, max: 2, current: 1)
-----
ip-address: 209.165.200.225

-----
interface-type: extended-sdee <protected>
enabled: yes default: yes
url: /csamc50/sdee-server <protected>
port: 80 default: 443
use-ssl

-----
always-yes: yes <protected>
-----
```

```

username: jsmith
password: <hidden>
host-posture-settings
-----
enabled: yes default: yes
allow-unreachable-postures: yes default: yes
posture-acls (ordered min: 0, max: 10, current: 1 - 1 active, 0 inactive)
-----
ACTIVE list-contents
-----
NAME: name1
-----
network-address: 192.0.2.0/24
action: permit
-----
-----
watchlist-address-settings
-----
enabled: yes default: yes
manual-rr-increase: 30 default: 25
session-rr-increase: 30 default: 25
packet-rr-increase: 20 default: 10
-----
-----
sensor(config-ext)#

```

Step 12 Exit external product interface submode.

```

sensor(config-ext)# exit
Apply Changes?[yes]:

```

Step 13 Press **Enter** to apply the changes or enter **no** to discard them.

For More Information

For the procedure for adding trusted hosts, see [Adding TLS Trusted Hosts, page 4-51](#).

Troubleshooting External Product Interfaces

To troubleshoot external product interfaces, check the following:

- Make sure the interface is active by checking the output from the **show statistics external-product-interface** command in the CLI, or choose **Monitoring > Sensor Monitoring > Support Information > Statistics** in the IDM and check the Interface state line in the response, or choose **Configuration > sensor_name > Sensor Monitoring > Support Information > Statistics** in the IME, and check the Interface state line in the response.
- Make sure you have added the CSA MC IP address to the trusted hosts. If you forgot to add it, add it, wait a few minutes and then check again.
- Confirm subscription login information by opening and closing a subscription on the CSA MC using the browser.
- Check the Event Store for the CSA MC subscription errors.

For More Information

- For the procedure for adding trusted hosts, see [Adding TLS Trusted Hosts, page 4-51](#).
- For the procedure for displaying events, see [Clearing Events from Event Store, page 7-42](#).



Configuring IP Logging

This chapter describes how to configure IP logging on the sensor. It contains the following sections:

- [Understanding IP Logging, page 12-2](#)
- [Configuring Automatic IP Logging, page 12-2](#)
- [Configuring Manual IP Logging for a Specific IP Address, page 12-3](#)
- [Displaying the Contents of IP Logs, page 12-5](#)
- [Stopping Active IP Logs, page 12-6](#)
- [Copying IP Log Files to Be Viewed, page 12-7](#)

IP Logging Notes and Caveats

The following notes and caveats apply to IP logging:

- Enabling IP logging slows down system performance.
- IP logging allows a maximum limit of 20 concurrent IP log files. Once the limit of 20 is reached, you receive the following message in `main.log`: `Cid/W errWarnIpLogProcessor::addIpLog: Ran out of file descriptors.`
- You cannot delete or manage IP log files. The **no iplog** command does not delete IP logs, it only stops more packets from being recorded for that IP log. IP logs are stored in a circular buffer that is never filled because new IP logs overwrite old ones.
- You can configure IP logging restrictions using the **permit-packet-logging true | false** command.
- On IPS sensors with multiple processors (for example, the IPS 4260 and IPS 4270-20), packets may be captured out of order in the IP logs and by the **packet** command. Because the packets are not processed using a single processor, the packets can become out of sync when received from multiple processors.

For More Information

For detailed information about the packet-related command restrictions, see [Configuring Packet Command Restriction, page 4-24](#).

Understanding IP Logging

You can manually configure the sensor to capture all IP traffic associated with a host you specify by IP address. You can specify how long you want the IP traffic to be logged, how many packets you want logged, and how many bytes you want logged. The sensor stops logging IP traffic at the first parameter you specify.

You can also have the sensor log IP packets every time a particular signature is fired. You can specify how long you want the sensor to log IP traffic and how many packets and bytes you want logged.

You can copy the IP logs from the sensor and have them analyzed by a tool that can read packet files in a libpcap format, such as Wireshark or TCPDUMP.

**Note**

Each alert references IP logs that are created because of that alert. If multiple alerts create IP logs for the same IP address, only one IP log is created for all the alerts. Each alert references the same IP log. However, the output of the IP log status only shows the event ID of the first alert triggering the IP log.

**Note**

IP logging allows a maximum limit of 20 concurrent IP log files. Once the limit of 20 is reached, you receive the following message in main.log: `Cid/W errWarnIpLogProcessor::addIpLog: Ran out of file descriptors.`

Configuring Automatic IP Logging

Use the **ip-log-packets** *number*, **ip-log-time** *number*, and **ip-log-bytes** *number* commands to configure automatic IP logging parameters on the sensor.

The following options apply:

- **ip-log-packets**—Identifies the number of packets you want logged. The valid value is 0 to 65535. The default is 0.
- **ip-log-time**—Identifies the duration in seconds you want the sensor to log packets. The valid value is 30 to 300 seconds. The default is 30 seconds.
- **ip-log-bytes** —Identifies the maximum number of bytes you want logged. The valid value is 0 to 2147483647. The default is 0.
- **default**—Resets the parameters.

**Note**

An automatic IP log continues capturing packets until one of these parameters is reached.

Automatic IP logging is configured on a per signature basis or as an event action override. The following actions trigger automatic IP logging:

- log-attacker-packets
- log-victim-packets
- log-pair-packets

Configuring Automatic IP Logging

To configure automatic IP logging parameters, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator or operator privileges.
- Step 2** Enter signature definition IP log configuration submode.
- ```
sensor# configure terminal
sensor(config)# service signature-definition sig0
sensor(config-sig)# ip-log
```
- Step 3** Specify the number of packets you want the sensor to log. The range is 0 to 65535.
- ```
sensor(config-sig-ip)# ip-log-packets 200
```
- Step 4** Specify the duration in seconds you want the sensor to log packets. The range is 30 to 300 seconds.
- ```
sensor(config-sig-ip)# ip-log-time 60
```
- Step 5** Specify the number of bytes you want logged. The range is 0 to 2147483647.
- ```
sensor(config-sig-ip)# ip-log-bytes 5024
```
- Step 6** Verify the settings.
- ```
sensor(config-sig-ip)# show settings
ip-log

ip-log-packets: 200 default: 0
ip-log-time: 60 default: 30
ip-log-bytes: 5024 default: 0

sensor(config-sig-ip)#
```
- Step 7** Exit IP logging submode.
- ```
sensor(config-sig-ip)# exit
sensor(config-sig)# exit
Apply Changes?:[yes]:
```
- Step 8** Press **Enter** to apply the changes or type **no** to discard the changes.
-

For More Information

- To copy and view an IP log file, see [Copying IP Log Files to Be Viewed](#), page 12-7.
- For more information on event actions, see [Assigning Actions to Signatures](#), page 8-15 and [Configuring Event Action Overrides](#), page 7-17.

Configuring Manual IP Logging for a Specific IP Address

Use the **iplog name ip_address [duration minutes] [packets numPackets] [bytes numBytes]** command to log IP packets manually on a virtual sensor for a specific IP address. The following options apply:

- *name*—Specifies the virtual sensor on which to begin and end logging.
- *ip_address*—Logs packets containing the specified source and/or destination IP address.
- *minutes*—Specifies the duration the logging should be active. The valid range is 1 to 60 minutes. The default is 10 minutes.

- *numPackets*—Specifies the maximum number of packets to log. The valid range is 0 to 4294967295. The default is 1000 packets.
- *numBytes*—Specifies the maximum number of bytes to log. The valid range is 0 to 4294967295. A value of 0 indicates unlimited bytes.

**Note**

The *minutes*, *numPackets*, and *numBytes* parameters are optional, you do not have to specify all three. However, if you include more than one parameter, the sensor continues logging only until the first threshold is reached. For example, if you set the duration to 5 minutes and the number of packets to 1000, the sensor stops logging after the 1000th packet is captured, even if only 2 minutes have passed.

Configuring Manual IP Logging

To manually log packets on a virtual sensor for a specific IP address, follow these steps:

Step 1 Log in to the CLI using an account with administrator or operator privileges.

Step 2 Start IP logging for a specific IP address. The range is 1 to 60 minutes.

```
sensor# iplog vs0 10.16.0.0 duration 5
Logging started for virtual sensor vs0, IP address 192.0.2.1, Log ID 1
Warning: IP Logging will affect system performance.
sensor#
```

The example shows the sensor logging all IP packets for 5 minutes to and from the IP address 192.0.2.1.



Note Make note of the Log ID for future reference.

Step 3 Monitor the IP log status with the **iplog-status** command.

```
sensor# iplog-status
Log ID:          1
IP Address 1:    192.0.2.1
Virtual Sensor:  vs0
Status:          added
Event ID:        0
Bytes Captured:  0
Packets Captured: 0
sensor
```



Note Each alert references IP logs that are created because of that alert. If multiple alerts create IP logs for the same IP address, only one IP log is created for all the alerts. Each alert references the same IP log. However, the output of the IP log status only shows the event ID of the first alert triggering the IP log.

For More Information

- To stop logging IP packets for a specific IP address, see [Stopping Active IP Logs, page 12-6](#).
- To log IP packets as an event associated with a signature, see [Configuring Automatic IP Logging, page 12-2](#).
- To copy and view an IP log file, see [Copying IP Log Files to Be Viewed, page 12-7](#).

Displaying the Contents of IP Logs

Use the **iplog-status** [**log-id** *log_id*] [**brief**] [**reverse**] [| {**begin** *regular_expression* | **exclude** *regular_expression* | **include** *regular_expression*}] command to display the description of the available IP log contents.

When the log is created, the status reads *added*. If and when the first entry is inserted in the log, the status changes to *started*. When the log is completed, because it reaches the packet count limit, for example, the status changes to *completed*.

The following options apply:

- **log_id**—(Optional) Specifies the log ID of the file for which you want to see the status.
- **brief**—(Optional) Displays a summary of IP log status information for each log.
- **reverse**—(Optional) Displays the list in reverse chronological order (newest log first).
- **|**—(Optional) Indicates that an output processing specification follows.
- **regular_expression**—Specifies any regular expression found in the IP log status output.
- **begin**—Searches the output of the **more** command and displays the output from the first instance of a specified string.
- **exclude**—Filters the IP log status output so that it excludes lines that contain a particular regular expression.
- **include**—Filters the IP log status output so that it includes lines that contain a particular regular expression.

Displaying IP Logs

To view the contents of IP logs, follow these steps:

-
- Step 1** Log in to the CLI.
- Step 2** Display the status of all IP logs.

```

sensor# iplog-status
Log ID:                2425
IP Address 1:          192.0.2.1
Virtual Sensor:        vs0
Status:                started
Start Time:            2003/07/30 18:24:18 2002/07/30 12:24:18 CST
Packets Captured:      1039438

Log ID:                2342
IP Address 1:          192.0.2.10
IP Address 2:          192.0.2.20
Virtual Sensor:        vs0
Status:                completed
Event ID:              209348
Start Time:            2003/07/30 18:24:18 2002/07/30 12:24:18 CST
End Time:              2003/07/30 18:34:18 2002/07/30 12:34:18 CST
sensor#

```

Step 3 Display a brief list of all IP logs.

```
sensor# iplog-status brief
Log ID   VS    IP Address1   Status      Event ID   Start Date
2425     vs0   192.0.2.10    started     N/A        2003/07/30
2342     vs0   192.0.2.20    completed   209348     2003/07/30
sensor#
```

Stopping Active IP Logs

Use the **no iplog** [**log-id** *log_id* | **name** *name*] command to stop logging for the logs that are in the *started* state and to remove logs that are in the *added* state. The **no iplog** command does not remove or delete the IP log. It only signals to the sensor to stop capturing additional packets on that IP log.



Note

Using the **no iplog** command on an *added* state IP log stops the IP log. The *added* state means that the IP log is still empty (no packets). Stopping it when there are no packets means you are stopping an empty IP log. An empty log is removed when it is stopped.

The following options apply:

- *log_id*—Specifies the log ID of the logging session to stop. Use the **iplog-status** command to find the log ID.
- *name*—Specifies the virtual sensor on which to begin or end logging.

Disabling IP Logging Sessions

To disable one or all IP logging sessions, follow these steps:

Step 1 Log in to the CLI using an account with administrator or operator privileges.

Step 2 Stop a particular IP logging session:

- Find the log ID of the session you want to stop.

```
sensor# iplog-status
Log ID:          1
IP Address 1:    192.0.2.1
Virtual Sensor:  vs0
Status:          added
Event ID:        0
Bytes Captured:  0
Packets Captured: 0
sensor#
```



Note

Each alert references IP logs that are created because of that alert. If multiple alerts create IP logs for the same IP address, only one IP log is created for all the alerts. Each alert references the same IP log. However, the output of the IP log status only shows the event ID of the first alert triggering the IP log.

- Stop the IP log session.

```
sensor# no iplog log-id 137857512
```

Step 3 Stop all IP logging sessions on a virtual sensor.

```
sensor# no iplog name vs0
```

Step 4 Verify that IP logging has been stopped. When the logs are stopped, the status shows them as completed.

```
sensor# iplog-status
Log ID:          1
IP Address 1:    192.0.2.1
Virtual Sensor:  vs0
Status:          completed
Event ID:        0
Bytes Captured:  0
Packets Captured: 0
sensor#
```

Copying IP Log Files to Be Viewed

Use the **copy iplog log_id destination_url** command to copy IP log files to an FTP or SCP server so that you can view them with a sniffing tool such as Ethereal or tcpdump. The following options apply:

- *log_id*—Specifies the log ID of the logging session. You can retrieve the log ID using the **iplog-status** command.
- *destination_url*—Specifies the location of the destination file to be copied. It can be a URL or a keyword.

The exact format of the source and destination URLs varies according to the file. Here are the valid types:

- **ftp**—Destination URL for an FTP network server. The syntax for this prefix is:
ftp://[[username@] location]/relativeDirectory]/filename
ftp://[[username@]location]//absoluteDirectory]/filename
- **scp**—Destination URL for the SCP network server. The syntax for this prefix is:
scp://[[username@] location]/relativeDirectory]/filename
scp://[[username@] location]//absoluteDirectory]/filename

When you use FTP or SCP protocol, you are prompted for a password.

Copying IP Log Files

To copy IP log files to an FTP or SCP server, follow these steps:

Step 1 Log in to the CLI.

Step 2 Monitor the IP log status with the **iplog-status** command until you see that the status reads completed for the log ID of the log file that you want to copy.

```
sensor# iplog-status
Log ID:          2425
IP Address:      192.0.2.1
Virtual Sensor:  vs0
Status:          started
Start Time:      2003/07/30 18:24:18 2002/07/30 12:24:18 CST
Packets Captured: 1039438
```

```

Log ID:          2342
IP Address:      192.0.2.2
Virtual Sensor:  vs0
Status:          completed
Event ID:        209348
Start Time:      2003/07/30 18:24:18 2002/07/30 12:24:18 CST
End Time:        2003/07/30 18:34:18 2002/07/30 12:34:18 CST
sensor#

```

Step 3 Copy the IP log to your FTP or SCP server.

```

sensor# copy iplog 2342 ftp://root@209.165.200.225/user/iplog1
Password: ***** Connected to 209.165.200.225 (209.165.200.225). 220 linux.machine.com
FTP server (Version wu-2.6.0(1) Mon Feb 28 10:30 :36 EST 2000) ready. ftp> user (username)
root 331 Password required for root. Password:230 User root logged in. ftp> 200 Type set
to I. ftp> put iplog.8518.tmp iplog1 local: iplog.8518.tmp remote: iplog1 227 Entering
Passive Mode (2,4,6,8,179,125) 150 Opening BINARY mode data connection for iplog1. 226
Transfer complete. 30650 bytes sent in 0.00246 secs (1.2e+04 Kbytes/sec) ftp>

```

Step 4 Open the IP log using a sniffer program such as Wireshark or TCPDUMP. For more information on Wireshark, go to <http://www.wireshark.org>. For more information on TCPDUMP, go to <http://www.tcpdump.org/>.



Displaying and Capturing Live Traffic on an Interface

This chapter describes how to display, capture, copy, and erase packet files. It contains the following sections:

- [Packet Display And Capture Notes and Caveats, page 13-1](#)
- [Understanding Packet Display and Capture, page 13-2](#)
- [Displaying Live Traffic on an Interface, page 13-2](#)
- [Capturing Live Traffic on an Interface, page 13-4](#)
- [Copying the Packet File, page 13-6](#)
- [Erasing the Packet File, page 13-7](#)

Packet Display And Capture Notes and Caveats

The following notes and caveats apply to capturing packet files:

- Although capturing live traffic off the interface does not disrupt any of the functionality of the sensor, it does cause significant performance degradation.
- Changing the interface configuration results in abnormal termination of any **packet** command running on that interface.
- You can configure packet capture/display restrictions using the **permit-packet-logging true | false** command.
- On IPS sensors with multiple processors (for example, the IPS 4260 and IPS 4270-20), packets may be captured out of order in the IP logs and by the **packet** command. Because the packets are not processed using a single processor, the packets can become out of sync when received from multiple processors.
- When the IPS 4510 and IPS 4520 are configured in VLAN pairs, the **packet display** command does not work without the VLAN option if the **expression** keyword is also used.

For More Information

For detailed information about the packet-related command restrictions, see [Configuring Packet Command Restriction, page 4-24](#).

Understanding Packet Display and Capture

You can display or capture live traffic from an interface and have the live traffic or a previously captured file put directly on the screen. Storage is available for one local file only, subsequent capture requests overwrites an existing file. The size of the storage file varies depending on the platform. A message may be displayed if the maximum file size is reached before the requested packet count is captured.

Displaying Live Traffic on an Interface

Use the **packet display** *interface_name* [**snaplen** *length*] [**count** *count*] [**verbose**] [**expression** *expression*] command to display live traffic from an interface directly on your screen. Use the **packet display iplog** *id* [**verbose**] [**expression** *expression*] to display iplogs.

**Note**

To terminate the live display, press **Ctrl-C**.

The following options apply:

- **interface_name**—Specifies the interface name, interface type (GigabitEthernet, FastEthernet, Management, PortChannel) followed by slot/port. You can only use an interface name that exists in the system.
- **snaplen**—(Optional) Specifies the maximum number of bytes captured for each packet. The valid range is 68 to 1600. The default is 0. A value of 0 means use the required length to catch whole packets.
- **count**—(Optional) Specifies the maximum number of packets to capture. The valid range is 1 to 10000.

**Note**

If you do not specify this option, the capture terminates after the maximum file size is captured.

- **verbose**—(Optional) Displays the protocol tree for each packet rather than a one-line summary.
- **expression**—Specifies the packet-display filter expression. This expression is passed directly to TCPDUMP and must meet the TCPDUMP expression syntax.

**Note**

The expression syntax is described in the TCPDUMP man page.

**Note**

If you use the **expression** option when monitoring packets with VLAN headers, the expression does not match properly unless **vlan and** is added to the beginning of the expression. For example, **packet display iplog 926299444 verbose expression icmp** Will NOT show ICMP packets; **packet display iplog 926299444 verbose expression vlan and icmp** WILL show ICMP packets. It is often necessary to use **expression vlan and** on the IPS appliance interfaces connected to trunk ports.

- **file-info**—Displays information about the stored packet file. **File-info** displays the following information:

```
Captured by: user:id, Cmd: cliCmd
Start: yyyy/mm/dd hh:mm:ss zone, End: yyyy/mm/dd hh:mm:ss zone or in-progress.
```

Where *user* = the username of user initiating capture, *id* = the CLI ID of the user, and *cliCmd* = the command entered to perform the capture.



Caution

Executing the **packet display** command causes significant performance degradation.

Displaying Live Traffic From an Interface

To configure the sensor to display live traffic from an interface on the screen, follow these steps:

- Step 1** Log in to the sensor using an account with administrator or operator privileges.
- Step 2** Display the live traffic on the interface you are interested in, for example, GigabitEthernet0/1.

```
sensor# packet display GigabitEthernet0/1
Warning: This command will cause significant performance degradation
tcpdump: listening on ge0_1, link-type EN10MB (Ethernet), capture size 65535 bytes
03:43:05.691883 IP (tos 0x10, ttl 64, id 55460, offset 0, flags [DF], length: 100)
10.89.147.31.22 > 10.89.147.50.41805: P [tcp sum ok] 4233955485:4233955533(48) ack
1495691730 win 8576 <nop,nop,timestamp 44085169 226014949>
03:43:05.691975 IP (tos 0x10, ttl 64, id 55461, offset 0, flags [DF], length: 164)
10.89.147.31.22 > 10.89.147.50.41805: P [tcp sum ok] 48:160(112) ack 1 win 8576
<nop,nop,timestamp 44085169 226014949>
03:43:05.691998 IP (tos 0x10, ttl 64, id 53735, offset 0, flags [DF], length: 52)
10.89.147.50.41805 > 10.89.147.31.22: . [tcp sum ok] 1:1(0) ack 48 win 11704
<nop,nop,timestamp 226014949 44085169>
03:43:05.693165 IP (tos 0x10, ttl 64, id 53736, offset 0, flags [DF], length: 52)
10.89.147.50.41805 > 10.89.147.31.22: . [tcp sum ok] 1:1(0) ack 160 win 11704
<nop,nop,timestamp 226014949 44085169>
03:43:05.693351 IP (tos 0x10, ttl 64, id 55462, offset 0, flags [DF], length: 316)
10.89.147.31.22 > 10.89.147.50.41805: P [tcp sum ok] 160:424(264) ack 1 win 8576
<nop,nop,timestamp 44085169 226014949>
03:43:05.693493 IP (tos 0x10, ttl 64, id 55463, offset 0, flags [DF], length: 292)
10.89.147.31.22 > 10.89.147.50.41805: P [tcp sum ok] 424:664(240) ack 1 win 8576
<nop,nop,timestamp 44085169 226014949>
03:43:05.693612 IP (tos 0x10, ttl 64, id 55464, offset 0, flags [DF], length: 292)
10.89.147.31.22 > 10.89.147.50.41805: P [tcp sum ok] 664:904(240) ack 1 win 8576
<nop,nop,timestamp 44085169 226014949>
03:43:05.693628 IP (tos 0x10, ttl 64, id 53737, offset 0, flags [DF], length: 52)
10.89.147.50.41805 > 10.89.147.31.22: . [tcp sum ok] 1:1(0) ack 424 win 11704
<nop,nop,timestamp 226014949 44085169>
03:43:05.693654 IP (tos 0x10, ttl 64, id 53738, offset 0, flags [DF], length: 52)
10.89.147.50.41805 > 10.89.147.31.22: . [tcp sum ok] 1:1(0) ack 664 win 11704
<nop,nop,timestamp 226014949 44085169>
03:43:05.693926 IP (tos 0x10, ttl 64, id 55465, offset 0, flags [DF], length: 292)
10.89.147.31.22 > 10.89.147.50.41805: P [tcp sum ok] 904:1144(240) ack 1 win 8576
<nop,nop,timestamp 44085169 226014949>
03:43:05.694043 IP (tos 0x10, ttl 64, id 55466, offset 0, flags [DF], length: 292)
10.89.147.31.22 > 10.89.147.50.41805: P [tcp sum ok] 1144:1384(240) ack 1 win 8576
<nop,nop,timestamp 44085169 226014949>
03:43:05.694163 IP (tos 0x10, ttl 64, id 55467, offset 0, flags [DF], length: 292)
10.89.147.31.22 > 10.89.147.50.41805: P [tcp sum ok] 1384:1624(240) ack 1 win 8576
<nop,nop,timestamp 44085169 226014949>
03:43:05.694209 IP (tos 0x10, ttl 64, id 53739, offset 0, flags [DF], length: 52)
10.89.147.50.41805 > 10.89.147.31.22: . [tcp sum ok] 1:1(0) ack 1384 win 11704
<nop,nop,timestamp 226014950 44085169>
```

```

03:43:05.694283 IP (tos 0x10, ttl 64, id 55468, offset 0, flags [DF], length: 292)
10.89.147.31.22 > 10.89.147.50.41805: P [tcp sum ok] 1624:1864(240) ack 1 win 8576
<nop,nop,timestamp 44085169 226014950>
03:43:05.694402 IP (tos 0x10, ttl 64, id 55469, offset 0, flags [DF], length: 292)
10.89.147.31.22 > 10.89.147.50.41805: P [tcp sum ok] 1864:2104(240) ack 1 win 8576
<nop,nop,timestamp 44085169 226014950>
03:43:05.694521 IP (tos 0x10, ttl 64, id 55470, offset 0, flags [DF], length: 292)
10.89.147.31.22 > 10.89.147.50.41805: P [tcp sum ok] 2104:2344(240) ack 1 win 8576
<nop,nop,timestamp 44085169 226014950>
03:43:05.694690 IP (tos 0x10, ttl 64, id 53740, offset 0, flags [DF], length: 52)
10.89.147.50.41805 > 10.89.147.31.22: . [tcp sum ok] 1:1(0) ack 2344 win 11704
<nop,nop,timestamp 226014950 44085169>
03:43:05.694808 IP (tos 0x10, ttl 64, id 55471, offset 0, flags [DF], length: 300)
10.89.147.31.22 > 10.89.147.50.41805: P [tcp sum ok] 2344:2592(248) ack 1 win 8576
<nop,nop,timestamp 44085169 226014950>

```

Step 3 You can use the **expression** option to limit what you display, for example, only TCP packets.



Note As described in the TCPDUMP man page, the protocol identifiers tcp, udp, and icmp are also keywords and must be escaped by using two back slashes (\\).

```

sensor# packet display GigabitEthernet0/1 verbose expression ip proto \\tcp
Warning: This command will cause significant performance degradation
tcpdump: listening on ge0_1, link-type EN10MB (Ethernet), capture size 65535 bytes
03:42:02.509738 IP (tos 0x10, ttl 64, id 27743, offset 0, flags [DF], length: 88)
10.89.147.31.22 > 64.101.182.54.47039: P [tcp sum ok] 3449098782:3449098830(48) ack
3009767154 win 8704
03:42:02.509834 IP (tos 0x10, ttl 64, id 27744, offset 0, flags [DF], length: 152)
10.89.147.31.22 > 64.101.182.54.47039: P [tcp sum ok] 48:160(112) ack 1 win 8704
03:42:02.510248 IP (tos 0x0, ttl 252, id 55922, offset 0, flags [none], length: 40)
64.101.182.54.47039 > 10.89.147.31.22: . [tcp sum ok] 1:1(0) ack 160 win 8760
03:42:02.511262 IP (tos 0x10, ttl 64, id 27745, offset 0, flags [DF], length: 264)
10.89.147.31.22 > 64.101.182.54.47039: P [tcp sum ok] 160:384(224) ack 1 win 8704
03:42:02.511408 IP (tos 0x10, ttl 64, id 27746, offset 0, flags [DF], length: 248)
10.89.147.31.22 > 64.101.182.54.47039: P [tcp sum ok] 384:592(208) ack 1 win 8704
03:42:02.511545 IP (tos 0x10, ttl 64, id 27747, offset 0, flags [DF], length: 240)
10.89.147.31.22 > 64.101.182.54.47039: P [tcp sum ok] 592:792(200) ack 1 win 8704

```

Step 4 Display information about the packet file.

```

sensor# packet display file-info
Captured by: cisco:25579, Cmd: packet capture GigabitEthernet0/1
Start: 2003/02/03 02:56:48 UTC, End: 2003/02/03 02:56:51 UTC
sensor#

```

Capturing Live Traffic on an Interface

Use the **packet capture** *interface_name* [snaplen *length*] [count *count*] [**expression** *expression*] command to capture live traffic on an interface. Only one user can use the **packet capture** command at a time. A second user request results in an error message containing information about the user currently executing the capture.



Caution

Executing the **packet capture** command causes significant performance degradation.

The **packet capture** command captures the libpcap output into a local file. Use the **packet display** **packet-file** [**verbose**] [**expression** *expression*] command to view the local file. Use the **packet display** **file-info** to display information about the local file, if any.

The following options apply:

- *interface_name*—Specifies the logical interface name. You can only use an interface name that exists in the system.
- **snaptlen**—Specifies the maximum number of bytes captured for each packet (optional). The valid range is 68 to 1600. The default is 0.
- **count**—Specifies the maximum number of packets to capture (optional). The valid range is 1 to 10000.



Note If you do not specify this option, the capture terminates after the maximum file size is captured.

- **expression**—Specifies the packet-capture filter expression. This expression is passed directly to TCPDUMP and must meet the TCPDUMP expression syntax.
- **file-info**—Displays information about the stored packet file.

File-info displays the following information:

```
Captured by: user:id, Cmd: cliCmd
Start: yyyy/mm/dd hh:mm:ss zone, End: yyyy/mm/dd hh:mm:ss zone or in-progress
```

Where *user* = username of user initiating capture, *id* = CLI ID of the user, and *cliCmd* = command entered to perform the capture.

- **verbose**—Displays the protocol tree for each packet rather than a one-line summary. This parameter is optional.

Capturing Live Traffic on an Interface

To configure the sensor to capture live traffic on an interface, follow these steps:

- Step 1** Log in to the sensor using an account with administrator or operator privileges.
- Step 2** Capture the live traffic on the interface you are interested in, for example, GigabitEthernet0/1.

```
sensor# packet capture GigabitEthernet0/1
Warning: This command will cause significant performance degradation
tcpdump: WARNING: ge0_1: no IPv4 address assigned
tcpdump: listening on ge0_1, link-type EN10MB (Ethernet), capture size 65535 bytes
125 packets captured
126 packets received by filter
0 packets dropped by kernel
```

- Step 3** View the captured packet file.

```
sensor# packet display packet-file
reading from file /usr/cids/idsRoot/var/packet-file, link-type EN10MB (Ethernet)
03:03:13.216768 802.1d config TOP_CHANGE 8000.00:04:9a:66:35:01.8025 root 8000.0
0:04:6d:f9:e8:82 pathcost 8 age 2 max 20 hello 2 fdelay 15
03:03:13.232881 IP 64.101.182.244.1978 > 10.89.130.108.23: . ack 3266153791 win
64328
03:03:13.232895 IP 10.89.130.108.23 > 64.101.182.244.1978: P 1:157(156) ack 0 wi
n 5840
03:03:13.433136 IP 64.101.182.244.1978 > 10.89.130.108.23: . ack 157 win 65535
03:03:13.518335 IP 10.89.130.134.42342 > 255.255.255.255.42342: UDP, length: 76
```

```

03:03:15.218814 802.1d config TOP_CHANGE 8000.00:04:9a:66:35:01.8025 root 8000.0
0:04:6d:f9:e8:82 pathcost 8 age 2 max 20 hello 2 fdelay 15
03:03:15.546866 IP 64.101.182.244.1978 > 10.89.130.108.23: P 0:2(2) ack 157 win
65535
03:03:15.546923 IP 10.89.130.108.23 > 64.101.182.244.1978: P 157:159(2) ack 2 wi
n 5840
03:03:15.736377 IP 64.101.182.244.1978 > 10.89.130.108.23: . ack 159 win 65533
03:03:17.219612 802.1d config TOP_CHANGE 8000.00:04:9a:66:35:01.8025 root 8000.0
0:04:6d:f9:e8:82 pathcost 8 age 2 max 20 hello 2 fdelay 15
03:03:19.218535 802.1d config TOP_CHANGE 8000.00:04:9a:66:35:01.8025 root 8000.0
0:04:6d:f9:e8:82 pathcost 8 age 2 max 20 hello 2 fdelay 15
03:03:19.843658 IP 64.101.182.143.3262 > 10.89.130.23.445: P 3749577803:37495778
56(53) ack 3040953472 win 64407
03:03:20.174835 IP 161.44.55.250.1720 > 10.89.130.60.445: S 3147454533:314745453
3(0) win 65520 <mss 1260,nop,nop,sackOK>
03:03:21.219958 802.1d config TOP_CHANGE 8000.00:04:9a:66:35:01.8025 root 8000.0
0:04:6d:f9:e8:82 pathcost 8 age 2 max 20 hello 2 fdelay 15
03:03:21.508907 IP 161.44.55.250.1809 > 10.89.130.61.445: S 3152179859:315217985
9(0) win 65520 <mss 1260,nop,nop,sackOK>
03:03:23.221004 802.1d config TOP_CHANGE 8000.00:04:9a:66:35:01.8025 root 8000.0
0:04:6d:f9:e8:82 pathcost 8 age 2 max 20 hello 2 fdelay 15
03:03:23.688099 IP 161.44.55.250.1975 > 10.89.130.63.445: S 3160484670:316048467
0(0) win 65520 <mss 1260,nop,nop,sackOK>
03:03:25.219054 802.1d config TOP_CHANGE 8000.00:04:9a:66:35:01.8025 root 8000.0
0:04:6d:f9:e8:82 pathcost 8 age 2 max 20 hello 2 fdelay 15
03:03:25.846552 IP 172.20.12.10.2984 > 10.89.130.127.445: S 1345848756:134584875
6(0) win 64240 <mss 1460,nop,nop,sackOK>
03:03:26.195342 IP 161.44.55.250.2178 > 10.89.130.65.445: S 3170518052:317051805
2(0) win 65520 <mss 1260,nop,nop,sackOK>
03:03:27.222725 802.1d config TOP_CHANGE 8000.00:04:9a:66:35:01.8025 root 8000.0
0:04:6d:f9:e8:82 pathcost 8 age 2 max 20 hello 2 fdelay 15
03:03:27.299178 IP 161.44.55.250.2269 > 10.89.130.66.445: S 3174717959:317471795
9(0) win 65520 <mss 1260,nop,nop,sackOK>
03:03:27.308798 arp who-has 161.44.55.250 tell 10.89.130.66
03:03:28.383028 IP 161.44.55.250.2349 > 10.89.130.67.445: S 3178636061:317863606
1(0) win 65520 <mss 1260,nop,nop,sackOK>
--MORE--

```

Step 4 View any information about the packet file.

```

sensor# packet display file-info
Captured by: cisco:8874, Cmd: packet capture GigabitEthernet0/1
Start: 2003/01/07 00:12:50 UTC, End: 2003/01/07 00:15:30 UTC
sensor#

```

Copying the Packet File

Use the **copy packet-file *destination_url*** command to copy the packet file to an FTP or SCP server for saving or further analysis with another tool, such as Wireshark or TCPDUMP. The following options apply:

- **packet-file**—Specifies the locally stored libpcap file that you captured using the **packet capture** command.
- **destination_url**—Specifies the location of the destination file to be copied. It can be a URL or a keyword.



Note The exact format of the source and destination URLs varies according to the file.

- ftp:—Destination URL for an FTP network server. The syntax for this prefix is:
ftp:[//[username@] location]/relativeDirectory]/filename
ftp:[//[username@] location]/absoluteDirectory]/filename
- scp:—Destination URL for the SCP network server. The syntax for this prefix is:
scp:[//[username@] location]/relativeDirectory]/filename
scp:[//[username@] location]/absoluteDirectory]/filename



Note When you use FTP or SCP protocol, you are prompted for a password.

To copy packets files to an FTP or SCP server, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Copy the packet-file to an FTP or SCP server.

```
sensor# copy packet-file scp://jbrown@209.165.200.225/work/
Password: *****
packet-file                               100% 1670      0.0KB/s   00:00
sensor#
```

Step 3 View the packet file with Wireshark or TCPDUMP.

Erasing the Packet File

Use the **erase packet-file** command to erase the packet file. There is only one packet file. It is 16 MB and is over-written each time you use the **packet capture** command. To erase the packet file, follow these steps:

Step 1 Display information about the current captured packet file.

```
sensor# packet display file-info
Captured by: cisco:1514, Cmd: packet capture GigabitEthernet0/1
Start: 2005/02/15 03:55:00 CST, End: 2005/02/15 03:55:05 CST
sensor#
```

Step 2 Erase the packet file.

```
sensor# erase packet-file
sensor#
```

Step 3 Verify that you have erased the packet file.

```
sensor# packet display file-info
No packet-file available.
sensor#
```




Configuring Attack Response Controller for Blocking and Rate Limiting

This chapter provides information for setting up the ARC to perform blocking and rate limiting on the sensor. It the following sections:

- [Blocking Notes and Caveats, page 14-1](#)
- [Understanding Blocking, page 14-2](#)
- [Understanding Rate Limiting, page 14-4](#)
- [Understanding Service Policies for Rate Limiting, page 14-5](#)
- [Before Configuring ARC, page 14-5](#)
- [Supported Devices, page 14-6](#)
- [Configuring Blocking Properties, page 14-7](#)
- [Configuring User Profiles, page 14-20](#)
- [Configuring Blocking and Rate Limiting Devices, page 14-21](#)
- [Configuring the Sensor to be a Master Blocking Sensor, page 14-28](#)
- [Configuring Host Blocking, page 14-31](#)
- [Configuring Network Blocking, page 14-32](#)
- [Configuring Connection Blocking, page 14-32](#)
- [Obtaining a List of Blocked Hosts and Connections, page 14-33](#)

Blocking Notes and Caveats

The following notes and caveats apply to blocking:

- The ARC is formerly known as Network Access Controller. Although the name has been changed, the IDM, the IME, and the CLI contain references to Network Access Controller, **nac**, and **network-access**.
- Blocking is not supported on the FWSM in multiple mode admin context.
- Connection blocks and network blocks are not supported on adaptive security appliances. Adaptive security appliances only support host blocks with additional connection information.

- Do not confuse blocking with the ability of the sensor to drop packets. The sensor can drop packets when the following actions are configured for a sensor in inline mode: deny packet inline, deny connection inline, and deny attacker inline.
- The ACLs that ARC makes should never be modified by you or any other system. These ACLs are temporary and new ACLs are constantly being created by the sensor. The only modifications that you can make are to the Pre- and Post-Block ACLs.
- Rate limiting and blocking are not supported for IPv6 traffic. If a signature is configured with a block or rate limit event action and is triggered by IPv6 traffic, an alert is generated but the action is not carried out.
- Two sensors cannot control blocking or rate limiting on the same device. If this situation is needed, configure one sensor as the master blocking sensor to manage the devices and the other sensors can forward their requests to the master blocking sensor.
- Pre-Block and Post-Block ACLS do not apply to rate limiting.
- When you add a master blocking sensor, you reduce the number of blocking devices per sensor. For example, if you want to block on 10 security appliances and 10 routers with one blocking interface/direction each, you can assign 10 to the sensor and assign the other 10 to a master blocking sensor.
- While blocking is disabled, the ARC continues to receive blocks and track the time on active blocks, but will not apply new blocks or remove blocks from the managed devices. After blocking is reenabled, the blocks on the devices are updated.
- We recommend that you do not permit the sensor to block itself, because it may stop communicating with the blocking device. You can configure this option if you can ensure that if the sensor creates a rule to block its own IP address, it will not prevent the sensor from accessing the blocking device.
- You **MUST** create a user profile before configuring the blocking device.

Understanding Blocking

The ARC is responsible for managing network devices in response to suspicious events by blocking access from attacking hosts and networks. The ARC blocks the IP address on the devices it is managing. It sends the same block to all the devices it is managing, including any other master blocking sensors. The ARC monitors the time for the block and removes the block after the time has expired.

The ARC completes the action response for a new block in no more than 7 seconds. In most cases, it completes the action response in less time. To meet this performance goal, you should not configure the sensor to perform blocks at too high a rate or to manage too many blocking devices and interfaces. We recommend that the maximum number of blocks not exceed 250 and the maximum number of blocking items not exceed 10. To calculate the maximum number of blocking items, a security appliance counts as one blocking item per blocking context. A router counts as one blocking item per blocking interface/direction. A switch running Catalyst software counts as one blocking item per blocking VLAN. If the recommended limits are exceeded, the ARC may not apply blocks in a timely manner or may not be able to apply blocks at all.



Caution

Blocking is not supported on the FWSM in multiple mode admin context.

For security appliances configured in multi-mode, Cisco IPS does not include VLAN information in the block request. Therefore you must make sure the IP addresses being blocked are correct for each security appliance. For example, the sensor is monitoring packets on a security appliance customer context that

is configured for VLAN A, but is blocking on a different security appliance customer context that is configured for VLAN B. Addresses that trigger blocks on VLAN A may refer to a different host on VLAN B.

There are three types of blocks:

- Host block—Blocks all traffic from a given IP address.
- Connection block—Blocks traffic from a given source IP address to a given destination IP address and destination port. Multiple connection blocks from the same source IP address to either a different destination IP address or destination port automatically switch the block from a connection block to a host block.
- Network block—Blocks all traffic from a given network. You can initiate host and connection blocks manually or automatically when a signature is triggered. You can only initiate network blocks manually.

**Note**

Connection blocks and network blocks are not supported on adaptive security appliances. Adaptive security appliances only support host blocks with additional connection information.

**Caution**

Do not confuse blocking with the ability of the sensor to drop packets. The sensor can drop packets when the following actions are configured for a sensor in inline mode: deny packet inline, deny connection inline, and deny attacker inline.

For automatic blocks, you must configure **request-block-host** or **request-block-connection** as the event action for particular signatures, and add them to any event action overrides you have configured, so that the SensorApp sends a block request to the ARC when the signature is triggered. When the ARC receives the block request from the SensorApp, it updates the device configurations to block the host or connection.

On Cisco routers and Catalyst 6500 series switches, ARC creates blocks by applying ACLs or VACLs. ACLs and VACLs permit or deny passage of data packets through interface directions or VLANs. Each ACL or VACL contains permit and deny conditions that apply to IP addresses. The security appliances do not use ACLs or VACLs. The built-in **shun** and **no shun** command is used.

**Caution**

The ACLs that ARC makes should never be modified by you or any other system. These ACLs are temporary and new ACLs are constantly being created by the sensor. The only modifications that you can make are to the Pre- and Post-Block ACLs.

You need the following information for the ARC to manage a device:

- Login user ID (if the device is configured with AAA).
- Login password.
- Enable password (not needed if the user has enable privileges).
- Interfaces to be managed (for example, ethernet0, vlan100).
- Any existing ACL or VACL information you want applied at the beginning (Pre-Block ACL or VACL) or end (Post-Block ACL or VACL) of the ACL or VACL that will be created. This does not apply to the security appliances because they do not use ACLs to block.
- Whether you are using Telnet or SSH to communicate with the device.
- IP addresses (host or range of hosts) you never want blocked.

- How long you want the blocks to last.

**Tip**

To check the status of the ARC, type **show statistics network-access** at the `sensor#`. The output shows the devices you are managing, any active blocks and rate limits, and the status of all devices.

**Note**

Rate limiting and blocking are not supported for IPv6 traffic. If a signature is configured with a block or rate limit event action and is triggered by IPv6 traffic, an alert is generated but the action is not carried out.

For More Information

- For the procedure to add request-block-host or request-block-connection event actions to a signature, see [Assigning Actions to Signatures, page 8-15](#).
- For the procedure for configuring overrides that add the **request-block-host** or **request-block-connection** event actions to alerts of a specific risk rating, see [Adding, Editing, Enabling, and Disabling Event Action Overrides, page 7-18](#).
- For more information on Pre- and Post-Block ACLs, see [How the Sensor Manages Devices, page 14-21](#).

Understanding Rate Limiting

The ARC is responsible for rate limiting traffic in protected networks. Rate limiting lets sensors restrict the rate of specified traffic classes on network devices. Rate limit responses are supported for the Host Flood and Net Flood engines, and the TCP half-open SYN signature. The ARC can configure rate limits on network devices running Cisco IOS 12.3 or later. Master blocking sensors can also forward rate limit requests to blocking forwarding sensors.

To add a rate limit, you specify the following:

- Source address and/or destination address for any rate limit
- Source port and/or destination port for rate limits with TCP or UDP protocol

You can also tune rate limiting signatures. You must also set the action to **request-rate-limit** and set the percentage for these signatures.

**Note**

Rate limiting and blocking are not supported for IPv6 traffic. If a signature is configured with a block or rate limit event action and is triggered by IPv6 traffic, an alert is generated but the action is not carried out.

[Table 14-1](#) lists the supported rate limiting signatures and parameters.

Table 14-1 *Rate Limiting Signatures*

Signature ID	Signature Name	Protocol	Destination IP Address Allowed	Data
2152	ICMP Flood Host	ICMP	Yes	echo-request
2153	ICMP Smurf Attack	ICMP	Yes	echo-reply

Table 14-1 *Rate Limiting Signatures (continued)*

Signature ID	Signature Name	Protocol	Destination IP Address Allowed	Data
4002	UDP Flood Host	UDP	Yes	none
6901	Net Flood ICMP Reply	ICMP	No	echo-reply
6902	Net Flood ICMP Request	ICMP	No	echo-request
6903	Net Flood ICMP Any	ICMP	No	None
6910	Net Flood UDP	UDP	No	None
6920	Net Flood TCP	TCP	No	None
3050	TCP HalfOpenSyn	TCP	No	halfOpenSyn

**Tip**

To check the status of the ARC, type **show statistics network-access** at the `sensor#`. The output shows the devices you are managing, any active blocks and rate limits, and the status of all devices.

For More Information

- For the procedure for configuring rate limiting on a router, see [Configuring Blocking and Rate Limiting Devices, page 14-21](#).
- For the procedure for configuring a sensor to be a master blocking sensor, see [Configuring the Sensor to be a Master Blocking Sensor, page 14-28](#).

Understanding Service Policies for Rate Limiting

You must not apply a service policy to an interface/direction that is configured for rate limiting. If you do so, the rate limit action will fail. Before configuring rate limits, confirm that there is no service policy on the interface/direction, and remove it if one exists. The ARC does not remove the existing rate limit unless it is one that the ARC had previously added.

Rate limits use ACLs, but not in the same way as blocks. Rate limits use **acls** and **class-map** entries to identify traffic, and **policy-map** and **service-policy** entries to police the traffic.

Before Configuring ARC

**Caution**

Two sensors cannot control blocking or rate limiting on the same device. If this situation is needed, configure one sensor as the master blocking sensor to manage the devices and the other sensors can forward their requests to the master blocking sensor.

**Note**

When you add a master blocking sensor, you reduce the number of blocking devices per sensor. For example, if you want to block on 10 security appliances and 10 routers with one blocking interface/direction each, you can assign 10 to the sensor and assign the other 10 to a master blocking sensor.

Before you configure the ARC for blocking or rate limiting, make sure you do the following:

- Analyze your network topology to understand which devices should be blocked by which sensor, and which addresses should never be blocked.
- Gather the usernames, device passwords, enable passwords, and connections types (Telnet or SSH) needed to log in to each device.
- Know the interface names on the devices.
- Know the names of the Pre-Block ACL or VACL and the Post-Block ACL or VACL if needed.
- Understand which interfaces should and should not be blocked and in which direction (in or out). You do not want to accidentally shut down an entire network.

For More Information

For the procedure for configuring the master blocking sensor, see [Configuring the Sensor to be a Master Blocking Sensor, page 14-28](#).

Supported Devices



Caution

If the recommended limits are exceeded, the ARC may not apply blocks in a timely manner or may not be able to apply blocks at all.

By default, the ARC supports up to 250 devices in any combination. The following devices are supported for blocking by the ARC:

- Cisco series routers using Cisco IOS 11.2 or later (ACLs):
 - Cisco 1600 series router
 - Cisco 1700 series router
 - Cisco 2500 series router
 - Cisco 2600 series router
 - Cisco 2800 series router
 - Cisco 3600 series router
 - Cisco 3800 series router
 - Cisco 7200 series router
 - Cisco 7500 series router
- Catalyst 5000 switches with RSM with IOS 11.2(9)P or later (ACLs)
- Catalyst 6500 switches and 7600 routers with IOS 12.1(13)E or later (ACLs)
- Catalyst 6500 switches 7600 routers with Catalyst software version 7.5(1) or later (VACLs)
 - Supervisor Engine 1A with PFC
 - Supervisor Engine 1A with MSFC1
 - Supervisor Engine 1A with MFSC2
 - Supervisor Engine 2 with MSFC2
 - Supervisor Engine 720 with MSFC3

**Note**

We support VACL blocking on the Supervisor Engine and ACL blocking on the MSFC.

- PIX Firewall with version 6.0 or later (**shun** command)
 - 501
 - 506E
 - 515E
 - 525
 - 535
- ASA with version 7.0 or later (**shun** command)
 - ASA 5510
 - ASA 5520
 - ASA 5540
- FWSM 1.1 or later (**shun** command)

You configure blocking using either ACLs, VACLs, or the **shun** command. All firewall and ASA models support the **shun** command.

The following devices are supported for rate limiting by the ARC:

- Cisco series routers using Cisco IOS 12.3 or later:
 - Cisco 1700 series router
 - Cisco 2500 series router
 - Cisco 2600 series router
 - Cisco 2800 series router
 - Cisco 3600 series router
 - Cisco 3800 series router
 - Cisco 7200 series router
 - Cisco 7500 series router

**Caution**

The ARC cannot perform rate limits on 7500 routers with VIP. The ARC reports the error but cannot rate limit.

Configuring Blocking Properties

You can change the default blocking properties. It is best to use the default properties, but if you need to change them, use the following procedures:

- [Allowing the Sensor to Block Itself, page 14-8](#)
- [Disabling Blocking, page 14-9](#)
- [Specifying Maximum Block Entries, page 14-11](#)
- [Specifying the Block Time, page 14-13](#)
- [Enabling ACL Logging, page 14-14](#)

- [Enabling Writing to NVRAM, page 14-15](#)
- [Logging All Blocking Events and Errors, page 14-16](#)
- [Configuring the Maximum Number of Blocking Interfaces, page 14-17](#)
- [Configuring Addresses Never to Block, page 14-19](#)

Allowing the Sensor to Block Itself



Caution

We recommend that you do not permit the sensor to block itself, because it may stop communicating with the blocking device. You can configure this option if you can ensure that if the sensor creates a rule to block its own IP address, it will not prevent the sensor from accessing the blocking device.

Use the **allow-sensor-block {true | false}** command in the service network access submode to configure the sensor to block itself. To allow the sensor to block itself, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter network access submode.

```
sensor# configure terminal
sensor(config)# service network-access
```

Step 3 Enter general submode.

```
sensor(config-net)# general
```

Step 4 Configure the sensor to block itself. By default, this value is false.

```
sensor(config-net-gen)# allow-sensor-block true
```

Step 5 Verify the settings.

```
sensor(config-net-gen)# show settings
general
-----
log-all-block-events-and-errors: true <defaulted>
enable-nvram-write: false <defaulted>
enable-acl-logging: false <defaulted>
allow-sensor-block: true default: false
block-enable: true default: true
block-max-entries: 100 default: 250
max-interfaces: 250 <defaulted>
master-blocking-sensors (min: 0, max: 100, current: 0)
-----
never-block-hosts (min: 0, max: 250, current: 1)
-----
ip-address: 192.0.2.1
-----
never-block-networks (min: 0, max: 250, current: 1)
-----
ip-address: 209.165.200.224/27
-----
block-hosts (min: 0, max: 250, current: 0)
-----
--MORE--
```


Step 6 Configure the sensor not to block itself.

```
sensor(config-net-gen)# allow-sensor-block false
```

Step 7 Verify the setting.

```
sensor(config-net-gen)# show settings
general
-----
log-all-block-events-and-errors: true <defaulted>
enable-nvram-write: false <defaulted>
enable-acl-logging: false <defaulted>
allow-sensor-block: false default: false
block-enable: true default: true
block-max-entries: 100 default: 250
max-interfaces: 250 <defaulted>
master-blocking-sensors (min: 0, max: 100, current: 0)
-----
never-block-hosts (min: 0, max: 250, current: 1)
-----
ip-address: 192.0.2.1
-----
never-block-networks (min: 0, max: 250, current: 1)
-----
ip-address: 209.165.200.224/27
-----
block-hosts (min: 0, max: 250, current: 0)
-----
--MORE--
```

Step 8 Exit network access submode.

```
sensor(config-net-gen)# exit
sensor(config-net)# exit
Apply Changes:[yes]:
```

Step 9 Press **Enter** to apply the changes or enter **no** to discard them.

Disabling Blocking



Note

For blocking to operate, you must set up devices to do the blocking.

Use the **block-enable {true | false}** command in the service network access submode to enable or disable blocking on the sensor. By default, blocking is enabled on the sensor. If the ARC is managing a device and you need to manually configure something on that device, you should disable blocking first. You want to avoid a situation in which both you and the ARC could be making a change at the same time on the same device. This could cause the device and/or the ARC to crash.



Caution

If you disable blocking for maintenance on the devices, make sure you enable it after the maintenance is complete or the network will be vulnerable to attacks that would otherwise be blocked

**Note**

While blocking is disabled, the ARC continues to receive blocks and track the time on active blocks, but will not apply new blocks or remove blocks from the managed devices. After blocking is reenabled, the blocks on the devices are updated.

To disable blocking or rate limiting, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter network access submode.

```
sensor# configure terminal
sensor(config)# service network-access
sensor(config-net)#
```

Step 3 Enter general submode.

```
sensor(config-net)# general
```

Step 4 Disable blocking on the sensor. By default, this value is set to true.

```
sensor(config-net-gen)# block-enable false
```

Step 5 Verify the settings.

```
sensor(config-net-gen)# show settings
general
-----
log-all-block-events-and-errors: true <defaulted>
enable-nvram-write: false <defaulted>
enable-acl-logging: false <defaulted>
allow-sensor-block: false default: false
block-enable: false default: true
block-max-entries: 100 default: 250
max-interfaces: 250 <defaulted>
master-blocking-sensors (min: 0, max: 100, current: 0)
-----
never-block-hosts (min: 0, max: 250, current: 1)
-----
ip-address: 192.0.2.1
-----
never-block-networks (min: 0, max: 250, current: 1)
-----
ip-address: 209.165.200.224/27
-----
block-hosts (min: 0, max: 250, current: 0)
-----
--MORE--
```

Step 6 Enable blocking on the sensor.

```
sensor(config-net-gen)# block-enable true
```

Step 7 Verify that the setting has been returned to the default.

```
sensor(config-net-gen)# show settings
general
-----
log-all-block-events-and-errors: true <defaulted>
enable-nvram-write: false <defaulted>
```

```

enable-acl-logging: false <defaulted>
allow-sensor-block: false default: false
block-enable: true default: true
block-max-entries: 100 default: 250
max-interfaces: 250 <defaulted>
master-blocking-sensors (min: 0, max: 100, current: 0)
-----
never-block-hosts (min: 0, max: 250, current: 1)
-----
      ip-address: 192.0.2.1
      -----
never-block-networks (min: 0, max: 250, current: 1)
-----
      ip-address: 209.165.200.224/27
      -----
block-hosts (min: 0, max: 250, current: 0)
-----
--MORE--

```

Step 8 Exit network access submode.

```

sensor(config-net-gen)# exit
sensor(config-net)# exit
Apply Changes:[yes]:

```

Step 9 Press **Enter** to apply the changes or enter **no** to discard them.

For More Information

- For the procedure for configuring the sensor to manage Cisco routers, see [Configuring the Sensor to Manage Cisco Routers, page 14-23](#).
- For the procedure for configuring the sensor to manage Cisco routers and switches, see [Configuring the Sensor to Manage Catalyst 6500 Series Switches and Cisco 7600 Series Routers, page 14-25](#).

Specifying Maximum Block Entries



Caution

We do not recommend setting the maximum block entries higher than 250. Some devices have problems with larger numbers of ACL or shun entries. Refer to the documentation for each device to determine its limits before increasing this number.



Note

The number of blocks will not exceed the maximum block entries. If the maximum is reached, new blocks will not occur until existing blocks time out and are removed.

Use the **block-max-entries** command in the service network access submode to configure the maximum block entries. You can set how many blocks are to be maintained simultaneously (1 to 65535). The default value is 250.

To change the maximum number of block entries, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter network access submode.

```
sensor# configure terminal
sensor(config)# service network-access
sensor(config-net)#
```

Step 3 Enter general submode.

```
sensor(config-net)# general
```

Step 4 Change the maximum number of block entries.

```
sensor(config-net-gen)# block-max-entries 100
```

Step 5 Verify the setting.

```
sensor(config-net-gen)# show settings
general
-----
log-all-block-events-and-errors: true <defaulted>
enable-nvram-write: false <defaulted>
enable-acl-logging: false <defaulted>
allow-sensor-block: false default: false
block-enable: true <defaulted>
block-max-entries: 100 default: 250
max-interfaces: 250 <defaulted>
master-blocking-sensors (min: 0, max: 100, current: 0)
-----
never-block-hosts (min: 0, max: 250, current: 1)
-----
ip-address: 192.0.2.1
-----
never-block-networks (min: 0, max: 250, current: 1)
-----
ip-address: 209.165.200.224/27
-----
block-hosts (min: 0, max: 250, current: 0)
-----
--MORE--
```

Step 6 Return to the default value of 250 blocks.

```
sensor(config-net-gen)# default block-max-entries
```

Step 7 Verify the setting.

```
sensor(config-net-gen)# show settings
general
-----
log-all-block-events-and-errors: true <defaulted>
enable-nvram-write: false <defaulted>
enable-acl-logging: false <defaulted>
allow-sensor-block: false default: false
block-enable: true <defaulted>
block-max-entries: 250 <defaulted>
max-interfaces: 250 <defaulted>
master-blocking-sensors (min: 0, max: 100, current: 0)
-----
```

```

-----
never-block-hosts (min: 0, max: 250, current: 1)
-----
ip-address: 192.0.2.1
-----
never-block-networks (min: 0, max: 250, current: 1)
-----
ip-address: 209.165.200.224/27
-----
block-hosts (min: 0, max: 250, current: 0)
-----
--MORE--

```

Step 8 Exit network access submode.

```

sensor(config-net-gen)# exit
sensor(config-net)# exit
Apply Changes:[yes]:

```

Step 9 Press **Enter** to apply the changes or enter **no** to discard them.

Specifying the Block Time



Note

If you change the default block time, you are changing a signature parameter, which affects all signatures.



Note

The time for manual blocks is set when you request the block.

Use the **global-block-timeout** command in the service event action rules submode to change the amount of time an automatic block lasts. The default is 30 minutes. To change the default block time, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter event action rules submode.

```

sensor# configure terminal
sensor(config)# service event-action-rules rules0
sensor(config-rul)#

```

Step 3 Enter general submode.

```

sensor(config-rul)# general

```

Step 4 Specify the block time. The value is the time duration of the block event in minutes (0 to 10000000).

```

sensor(config-rul-gen)# global-block-timeout 60

```

Step 5 Verify the setting.

```

sensor(config-rul-gen)# show settings
general
-----

```

```

global-overrides-status: Enabled <defaulted>
global-filters-status: Enabled <defaulted>
global-summarization-status: Enabled <defaulted>
global-metaevent-status: Enabled <defaulted>
global-deny-timeout: 3600 <defaulted>
global-block-timeout: 60 default: 30
max-denied-attackers: 10000 <defaulted>
-----
sensor(config-rul-gen)#

```

Step 6 Exit event action rules submode.

```

sensor(config-rul-gen)# exit
sensor(config-rul)# exit
Apply Changes:[yes]:

```

Step 7 Press **Enter** to apply the changes or enter **no** to discard them.



Note There is a time delay while the signatures are updated.

Enabling ACL Logging

Use the **enable-acl-logging {true | false}** command in the service network access submode to enable ACL logging, which causes ARC to append the log parameter to block entries in the ACL or VACL. This causes the device to generate syslog events when packets are filtered. Enable ACL logging only applies to routers and switches. The default is disabled.

To enable ACL logging, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter network access submode:

```

sensor# configure terminal
sensor(config)# service network-access
sensor(config-net)#

```

Step 3 Enter general submode.

```

sensor(config-net)# general

```

Step 4 Enable ACL logging.

```

sensor(config-net-gen)# enable-acl-logging true

```

Step 5 Verify that ACL logging is enabled.

```

sensor(config-net-gen)# show settings
general
-----
log-all-block-events-and-errors: true <defaulted>
enable-nvram-write: false <defaulted>
enable-acl-logging: true default: false
allow-sensor-block: false <defaulted>
block-enable: true <defaulted>
block-max-entries: 250 <defaulted>
max-interfaces: 250 <defaulted>

```

```
master-blocking-sensors (min: 0, max: 100, current: 0)
-----
```

Step 6 Disable ACL logging by using the **false** keyword.

```
sensor(config-net-gen)# enable-acl-logging false
```

Step 7 Verify that ACL logging is disabled.

```
sensor(config-net-gen)# show settings
general
-----
log-all-block-events-and-errors: true <defaulted>
enable-nvram-write: false <defaulted>
enable-acl-logging: false default: false
allow-sensor-block: false <defaulted>
block-enable: true <defaulted>
block-max-entries: 250 <defaulted>
max-interfaces: 250 <defaulted>
master-blocking-sensors (min: 0, max: 100, current: 0)
-----
```

Step 8 Exit network access mode.

```
sensor(config-net-gen)# exit
sensor(config-net)# exit
Apply Changes:[yes]:
```

Step 9 Press **Enter** to apply the changes or enter **no** to discard them.

Enabling Writing to NVRAM

Use the **enable-nvram-write {true | false}** command to configure the sensor to have the router write to NVRAM when ARC first connects. If enable-nvram-write is enabled, NVRAM is written each time the ACLs are updated. The default is disabled.

Enabling NVRAM writing ensures that all changes for blocking are written to NVRAM. If the router is rebooted, the correct blocks will still be active. If NVRAM writing is disabled, a short time without blocking occurs after a router reboot. And not enabling NVRAM writing increases the life of the NVRAM and decreases the time for new blocks to be configured.

To enable writing to NVRAM, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter network access submenu.

```
sensor# configure terminal
sensor(config)# service network-access
sensor(config-net)#
```

Step 3 Enter general submenu.

```
sensor(config-net)# general
```

Step 4 Enable writing to NVRAM.

```
sensor(config-net-gen)# enable-nvram-write true
```

Step 5 Verify that writing to NVRAM is enabled.

```

sensor(config-net-gen)# show settings
general
-----
log-all-block-events-and-errors: true <defaulted>
enable-nvram-write: true default: false
enable-acl-logging: false default: false
allow-sensor-block: false <defaulted>
block-enable: true <defaulted>
block-max-entries: 250 <defaulted>
max-interfaces: 250 <defaulted>
master-blocking-sensors (min: 0, max: 100, current: 0)
-----

```

Step 6 Disable writing to NVRAM.

```

sensor(config-net-gen)# enable-nvram-write false

```

Step 7 Verify that writing to NVRAM is disabled.

```

sensor(config-net-gen)# show settings
general
-----
log-all-block-events-and-errors: true <defaulted>
enable-nvram-write: false default: false
enable-acl-logging: false default: false
allow-sensor-block: false <defaulted>
block-enable: true <defaulted>
block-max-entries: 250 <defaulted>
max-interfaces: 250 <defaulted>
master-blocking-sensors (min: 0, max: 100, current: 0)
-----

```

Step 8 Exit network access submode.

```

sensor(config-net-gen)# exit
sensor(config-net)# exit
Apply Changes?[yes]:

```

Step 9 Press **Enter** to apply the changes or enter **no** to discard them.

Logging All Blocking Events and Errors

Use the **log-all-block-events-and-errors {true | false}** command in the service network access submode to configure the sensor to log events that follow blocks from start to finish. For example, when a block is added to or removed from a device, an event is logged. You may not want all these events and errors to be logged. Disabling **log-all-block-events-and-errors** suppresses the new events and errors. The default is enabled.

To disable blocking event and error logging, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.**Step 2** Enter network access mode.

```

sensor# configure terminal
sensor(config)# service network-access
sensor(config-net)#

```


- Step 3** Enter general submode.
- ```
sensor(config-net)# general
```
- Step 4** Disable blocking event and error logging.
- ```
sensor(config-net-gen)# log-all-block-events-and-errors false
```
- Step 5** Verify that logging is disabled.
- ```
sensor(config-net-gen)# show settings
general

log-all-block-events-and-errors: false default: true
enable-nvram-write: false default: false
enable-acl-logging: false default: false
allow-sensor-block: false <defaulted>
block-enable: true <defaulted>
block-max-entries: 250 <defaulted>
max-interfaces: 250 <defaulted>
master-blocking-sensors (min: 0, max: 100, current: 0)

```
- Step 6** Enable blocking event and error logging.
- ```
sensor(config-net-gen)# log-all-block-events-and-errors true
```
- Step 7** Verify that logging is enabled.
- ```
sensor(config-net-gen)# show settings
general

log-all-block-events-and-errors: true default: true
enable-nvram-write: false default: false
enable-acl-logging: false default: false
allow-sensor-block: false <defaulted>
block-enable: true <defaulted>
block-max-entries: 250 <defaulted>
max-interfaces: 250 <defaulted>
master-blocking-sensors (min: 0, max: 100, current: 0)

```
- Step 8** Exit network access mode.
- ```
sensor(config-net-gen)# exit
sensor(config-net)# exit
Apply Changes:[yes]:
```
- Step 9** Press **Enter** to apply the changes or type **no** to discard them.
-

Configuring the Maximum Number of Blocking Interfaces

Use the **max-interfaces** command to configure the maximum number of interfaces for performing blocks. For example, a PIX Firewall counts as one interface. A router with one interface counts as one, but a router with two interfaces counts as two. At most you can configure 250 blocking interfaces on a router, switch, or firewall. You can configure up to 250 Catalyst 6K switches, 250 routers, and 250 firewalls.

The **max-interfaces** command configures the limit of the sum total of all interfaces and devices. In addition to configuring the limit on the sum total of interfaces and devices, there is a fixed limit on the number of blocking interfaces you can configure per device. Use the **show settings** command in network access mode to view the specific maximum limits per device.

To configure the maximum number of blocking interfaces, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter network access mode.

```
sensor# configure terminal
sensor(config)# service network-access
sensor(config-net)#
```

Step 3 Enter general submodule.

```
sensor(config-net)# general
```

Step 4 Specify the maximum number of interfaces.

```
sensor(config-net-gen)# max-interfaces 50
```

Step 5 Verify the number of maximum interfaces.

```
sensor(config-net-gen)# show settings
general
-----
log-all-block-events-and-errors: true default: true
enable-nvram-write: false default: false
enable-acl-logging: false default: false
allow-sensor-block: false <defaulted>
block-enable: true <defaulted>
block-max-entries: 250 <defaulted>
max-interfaces: 50 default: 250
master-blocking-sensors (min: 0, max: 100, current: 0)
-----
```

Step 6 Return the setting to the default of 250.

```
sensor(config-net-gen)# default max-interfaces
```

Step 7 Verify the default setting.

```
sensor(config-net-gen)# show settings
general
-----
log-all-block-events-and-errors: true default: true
enable-nvram-write: false default: false
enable-acl-logging: false default: false
allow-sensor-block: false <defaulted>
block-enable: true <defaulted>
block-max-entries: 250 <defaulted>
max-interfaces: 250 <defaulted>
master-blocking-sensors (min: 0, max: 100, current: 0)
-----
```

Step 8 Exit network access mode.

```
sensor(config-net-gen)# exit
sensor(config-net)# exit
Apply Changes?[yes]:
```

Step 9 Press **Enter** to apply the changes or enter **no** to discard them.

Configuring Addresses Never to Block

Use the **never-block-hosts** and the **never-block-networks** commands in the service network access submode to configure hosts and network that should never be blocked. The following options apply:

- *ip_address*—Specifies the IP address of the device that should never be blocked.
- *ip_address/netmask*—Specifies the IP address of the network that should never be blocked. The format is A.B.C.D/nn.

You must tune your sensor to identify hosts and networks that should never be blocked, not even manually, because you may have a trusted network device whose normal, expected behavior appears to be an attack. Such a device should never be blocked, and trusted, internal networks should never be blocked. You can specify a single host or an entire network.



Note

The **never-block-hosts** and the **never-block-networks** commands apply only to the Request Block Host and Request Block Connection event actions. It does not apply to the Deny Attacker Inline, Deny Connection Inline, or Deny Packet Inline event actions. Use event action rules to filter out the hosts that you do not want blocked, denied, or dropped.

Configuring Addresses Never to Be Blocked

To set up addresses never to be blocked by blocking devices, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter network access submode.

```
sensor# configure terminal
sensor(config)# service network-access
sensor(config-net)#
```

Step 3 Enter general submode.

```
sensor(config-net)# general
```

Step 4 Specify the address that should never be blocked:

- For a single host

```
sensor(config-net-gen)# never-block-hosts 192.0.2.1
```

- For a network

```
sensor(config-net-gen)# never-block-networks 209.165.200.224/27
```

Step 5 Verify the settings.

```
sensor(config-net-gen)# show settings
general
-----
log-all-block-events-and-errors: true <defaulted>
enable-nvram-write: false <defaulted>
enable-acl-logging: false <defaulted>
allow-sensor-block: false default: false
block-enable: true default: true
```

```

block-max-entries: 100 default: 250
max-interfaces: 250 <defaulted>
master-blocking-sensors (min: 0, max: 100, current: 0)
-----
never-block-hosts (min: 0, max: 250, current: 2)
-----
ip-address: 192.0.2.1
-----
never-block-networks (min: 0, max: 250, current: 2)
-----
ip-address: 209.165.200.224/27
--MORE--

```

Step 6 Exit network access submode.

```

sensor(config-net-gen)# exit
sensor(config-net)# exit
Apply Changes?[yes]:

```

Step 7 Press **Enter** to apply the changes or enter **no** to discard them.

For More Information

For the procedure for configuring event action filters, see [Configuring Event Action Filters, page 7-21](#).

Configuring User Profiles



Note

If the username or password is not needed to log in to the device, do not set a value for it.



Note

You **MUST** create a user profile before configuring the blocking device.

Use the **user-profiles** *profile_name* command in the service network access submode to set up user profiles for the other devices that the sensor will manage. The user profiles contain userid, password, and enable password information. For example, routers that all share the same passwords and usernames can be under one user profile.

To set up user profiles, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter network access mode.

```

sensor# configure terminal
sensor(config)# service network-access
sensor(config-net)#

```

Step 3 Create the user profile name.

```

sensor(config-net)# user-profiles PROFILE1

```

- Step 4** Enter the username for that user profile.
- ```
sensor(config-net-use)# username username
```
- Step 5** Specify the password for the user.
- ```
sensor(config-net-use)# password
Enter password[:] *****
Re-enter password *****
```
- Step 6** Specify the enable password for the user.
- ```
sensor(config-net-use)# enable-password
Enter enable-password[:] *****
Re-enter enable-password *****
```
- Step 7** Verify the settings.
- ```
sensor(config-net-use)# show settings
profile-name: PROFILE1
-----
enable-password: <hidden>
password: <hidden>
username: jsmith default:
-----
sensor(config-net-use)#
```
- Step 8** Exit network access submode.
- ```
sensor(config-net-use)# exit
sensor(config-net)# exit
Apply Changes:[yes]:
```
- Step 9** Press **Enter** to apply the changes or enter **no** to discard them.
- 

## Configuring Blocking and Rate Limiting Devices

This section describes how to configure devices that the sensor uses to perform blocking or rate limiting. It contains the following topics:

- [How the Sensor Manages Devices, page 14-21](#)
- [Configuring the Sensor to Manage Cisco Routers, page 14-23](#)
- [Configuring the Sensor to Manage Catalyst 6500 Series Switches and Cisco 7600 Series Routers, page 14-25](#)
- [Configuring the Sensor to Manage Cisco Firewalls, page 14-27](#)

## How the Sensor Manages Devices



### Note

ACLs do not apply to rate limiting devices.

The ARC uses ACLs on Cisco routers and switches to manage those devices. These ACLs are built as follows:

1. A **permit** line with the sensor IP address or, if specified, the NAT address of the sensor.



**Note** If you permit the sensor to be blocked, this line does not appear in the ACL.

2. Pre-Block ACL (if specified). This ACL must already exist on the device.



**Note** The ARC reads the lines in the ACL and copies these lines to the beginning of the ACL.

3. Any active blocks.

4. Either specify a Post-Block ACL, which must already exist on the device, or specify **permit ip any any** (do not use if a Post-Block ACL is specified). The ARC reads the lines in the ACL and copies these lines to the end of the ACL.



**Note** Make sure the last line in the ACL is **permit ip any any** if you want all unmatched packets to be permitted.

The ARC uses two ACLs to manage devices. Only one is active at any one time. It uses the offline ACL name to build the new ACL, then applies it to the interface. The ARC then reverses the process on the next cycle.



#### Caution

The ACLs that the ARC makes should never be modified by you or any other system. These ACLs are temporary and new ACLs are constantly being created by the sensor. The only modifications that you can make are to the Pre- and Post-Block ACLs.

If you need to modify the Pre-Block or Post-Block ACL, do the following:

1. Disable blocking on the sensor.
2. Make the changes to the configuration of the device.
3. Reenable blocking on the sensor.

When blocking is reenabled, the sensor reads the new device configuration.



#### Caution

A single sensor can manage multiple devices, but you cannot use multiple sensors to control a single device. In this case, use a master blocking sensor.

#### For More Information

- For the procedure for enabling blocking, see [Configuring Blocking Properties, page 14-7](#).
- For the procedure for configuring the sensor to be a master blocking sensor, see [Configuring the Sensor to be a Master Blocking Sensor, page 14-28](#).

## Configuring the Sensor to Manage Cisco Routers

This section describes how to configure the sensor to manage Cisco routers. It contains the following topics:

- [Routers and ACLs, page 14-23](#)
- [Configuring the Sensor to Manage Cisco Routers, page 14-23](#)

### Routers and ACLs

**Note**

Pre-Block and Post-Block ACLs do not apply to rate limiting.

You create and save Pre-Block and Post-Block ACLs in your router configuration. These ACLs must be extended IP ACLs, either named or numbered. See your router documentation for more information on creating ACLs. Enter the names of these ACLs that are already configured on your router in the Pre-Block ACL and Post-Block ACL fields.

The Pre-Block ACL is mainly used for permitting what you do not want the sensor to ever block. When a packet is checked against the ACL, the first line that gets matched determines the action. If the first line matched is a permit line from the Pre-Block ACL, the packet is permitted even though there may be a deny line (from an automatic block) listed later in the ACL. The Pre-Block ACL can override the deny lines resulting from the blocks.

The Post-Block ACL is best used for additional blocking or permitting that you want to occur on the same interface or direction. If you have an existing ACL on the interface or direction that the sensor will manage, that existing ACL can be used as a Post-Block ACL. If you do not have a Post-Block ACL, the sensor inserts **permit ip any any** at the end of the new ACL.

When the sensor starts up, it reads the contents of the two ACLs. It creates a third ACL with the following entries:

- A **permit** line for the sensor IP address
- Copies of all configuration lines of the Pre-Block ACL
- A **deny** line for each address being blocked by the sensor
- Copies of all configuration lines of the Post-Block ACL

The sensor applies the new ACL to the interface and direction that you designate.

**Note**

When the new ACL is applied to an interface or direction of the router, it removes the application of any other ACL to that interface or direction.

## Configuring the Sensor to Manage Cisco Routers

To configure a sensor to manage a Cisco router to perform blocking and rate limiting, follow these steps:

**Step 1** Log in to the CLI using an account with administrator privileges.

**Step 2** Enter network access submode.

```
sensor# configure terminal
sensor(config)# service network-access
```

```
sensor(config-net)#
```

**Step 3** Specify the IP address for the router controlled by the ARC.

```
sensor(config-net)# router-devices ip_address
```

**Step 4** Enter the logical device name that you created when you configured the user profile. The ARC accepts anything you enter. It does not check to see if the user profile exists.

```
sensor(config-net-rou)# profile-name user_profile_name
```

**Step 5** Specify the method used to access the sensor. If unspecified, SSH 3DES is used.

```
sensor(config-net-rou)# communication {telnet | ssh-3des}
```



**Note** If you are using 3DES, you must use the command **ssh host-key ip\_address** to accept the key or ARC cannot connect to the device.

**Step 6** Specify the sensor NAT address.

```
sensor(config-net-rou)# nat-address nat_address
```



**Note** This changes the IP address in the first line of the ACL from the address of the sensor to the NAT address. This is not a NAT address configured on the device being managed. It is the address the sensor is translated to by an intermediate device, one that is between the sensor and the device being managed.

**Step 7** Specify whether the router will perform blocking, rate limiting, or both.



**Note** The default is blocking. You do not have to configure response capabilities if you want the router to perform blocking only.

a. Rate limiting only

```
sensor(config-net-rou)# response-capabilities rate-limit
```

b. Both blocking and rate limiting

```
sensor(config-net-rou)# response-capabilities block|rate-limit
```

**Step 8** Specify the interface name and direction.

```
sensor(config-net-rou)# block-interfaces interface_name {in | out}
```



**Caution**

The name of the interface must either be the complete name of the interface or an abbreviation that the router recognizes with the **interface** command.

**Step 9** (Optional) Add the pre-ACL name (blocking only).

```
sensor(config-net-rou-blo)# pre-acl-name pre_acl_name
```

**Step 10** (Optional) Add the post-ACL name (blocking only).

```
sensor(config-net-rou-blo)# post-acl-name post_acl_name
```



**Step 11** Verify the settings.

```

sensor(config-net-rou-blo)# exit
sensor(config-net-rou)# show settings
 ip-address: 192.0.2.1

 communication: ssh-3des default: ssh-3des
 nat-address: 19.89.149.219 default: 0.0.0.0
 profile-name: PROFILE1
 block-interfaces (min: 0, max: 100, current: 1)

 interface-name: GigabitEthernet0/1
 direction: in

 pre-acl-name: <defaulted>
 post-acl-name: <defaulted>

 response-capabilities: block|rate-limit default: block

sensor(config-net-rou)#

```

**Step 12** Exit network access submode.

```

sensor(config-net-rou)# exit
sensor(config-net)# exit
sensor(config)# exit
Apply Changes:[yes]:

```

**Step 13** Press **Enter** to apply the changes or enter **no** to discard them.**For More Information**

- For the procedure for configuring user profiles, see [Configuring User Profiles, page 14-20](#).
- For the procedure for adding a device to the known hosts list, see [Adding Hosts to the SSH Known Hosts List, page 4-45](#).

## Configuring the Sensor to Manage Catalyst 6500 Series Switches and Cisco 7600 Series Routers

This section describes how to configure the sensor to manage Cisco switches. It contains the following topics:

- [Switches and VACLs, page 14-25](#)
- [Configuring the Sensor to Manage Catalyst 6500 Series Switches and Cisco 7600 Series Routers, page 14-26](#)

### Switches and VACLs

You can configure the ARC to block using VACLs on the switch itself when running Cisco Catalyst software, or to block using router ACLs on the MSFC or on the switch itself when running Cisco IOS software. This section describes blocking using VACLs. You cannot configure switches that use VACLs to perform rate limiting. You must configure the blocking interfaces on the Catalyst 6500 series switch and specify the VLAN of traffic you want blocked.

You create and save Pre-Block and Post-Block VACLs in your switch configuration. These VACLs must be extended IP VACLs, either named or numbered. See your switch documentation for more information on creating VACLs. Enter the names of these VACLs that are already configured on your switch in the Pre-Block VACL and Post-Block VACL fields.

The Pre-Block VACL is used mainly for permitting what you do not want the sensor to ever block. When a packet is checked against the VACL, the first line that gets matched determines the action. If the first line matched is a permit line from the Pre-Block VACL, the packet is permitted even though there may be a deny line (from an automatic block) listed later in the VACL. The Pre-Block VACL can override the deny lines resulting from the blocks.

The Post-Block VACL is best used for additional blocking or permitting that you want to occur on the same VLAN. If you have an existing VACL on the VLAN that the sensor will manage, the existing VACL can be used as a Post-Block VACL. If you do not have a Post-Block VACL, the sensor inserts **permit ip any any** at the end of the new VACL.

When the sensor starts up, it reads the contents of the two VACLs. It creates a third VACL with the following entries:

- A **permit** line for the sensor IP address
- Copies of all configuration lines of the Pre-Block VACL
- A **deny** line for each address being blocked by the sensor
- Copies of all configuration lines of the Post-Block VACL

The sensor applies the new VACL to the VLAN that you designate.


**Note**

When the new VACL is applied to a VLAN of the switch, it removes the application of any other VACL to that VLAN.

**For More Information**

For the procedure for configuring blocking using router ACLs, see [Configuring Blocking and Rate Limiting Devices, page 14-21](#).

## Configuring the Sensor to Manage Catalyst 6500 Series Switches and Cisco 7600 Series Routers

To configure the sensor to manage Catalyst 6500 series switches and Cisco 7600 series routers, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter network access submode.
- ```
sensor# configure terminal
sensor(config)# service network-access
sensor(config-net)#
```
- Step 3** Specify the IP address for the router controlled by the ARC.
- ```
sensor(config-net)# cat6k-devices ip_address
```
- Step 4** Enter the user profile name that you created when you configured the user profile. The ARC accepts anything you type. It does not accept it, check to see if the logical device exists.
- ```
sensor(config-net-cat)# profile-name user_profile_name
```

Step 5 Specify the method used to access the sensor. If unspecified, SSH 3DES is used.

```
sensor(config-net-cat)# communication {telnet | ssh-3des}
```



Note If you are using 3DES, you must use the command **ssh host-key ip_address** to accept the key or ARC cannot connect to the device.

Step 6 Specify the sensor NAT address.

```
sensor(config-net-cat)# nat-address nat_address
```



Note This changes the IP address in the first line of the ACL from the IP address of the sensor to the NAT address. This is not a NAT address configured on the device being managed. It is the address the sensor is translated to by an intermediate device, one that is between the sensor and the device being managed.

Step 7 Specify the VLAN number.

```
sensor(config-net-cat)# block-vlans vlan_number
```

Step 8 (Optional) Add the pre-VACL name.

```
sensor(config-net-cat-blo)# pre-vacl-name pre_vacl_name
```

Step 9 (Optional) Add the post-VACL name.

```
sensor(config-net-cat-blo)# post-vacl-name post_vacl_name
```

Step 10 Exit network access submode.

```
sensor(config-net-cat-blo)# exit
sensor(config-net-cat)# exit
sensor(config-net)# exit
sensor(config)# exit
Apply Changes:[yes]:
```

Step 11 Press **Enter** to apply the changes or enter **no** to discard them.

For More Information

- For the procedure for configuring user profiles, see [Configuring User Profiles, page 14-20](#).
- For the procedure for adding a device to the known hosts list, see [Adding Hosts to the SSH Known Hosts List, page 4-45](#).

Configuring the Sensor to Manage Cisco Firewalls

To configure the sensor to manage Cisco firewalls, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter network access submode.

```
sensor# configure terminal
sensor(config)# service network-access
```

```
sensor(config-net)#
```

Step 3 Specify the IP address for the firewall controlled by the ARC.

```
sensor(config-net)# firewall-devices ip_address
```

Step 4 Enter the user profile name that you created when you configured the user profile. ARC accepts anything you type. It does not check to see if the logical device exists.

```
sensor(config-net-fir)# profile-name user_profile_name
```

Step 5 Specify the method used to access the sensor. If unspecified, SSH 3DES is used.

```
sensor(config-net-fir)# communication {telnet | ssh-3des}
```



Note If you are using 3DES, you must use the command **ssh host-key ip_address** to accept the key or the ARC cannot connect to the device.

Step 6 Specify the sensor NAT address.

```
sensor(config-net-fir)# nat-address nat_address
```



Note This changes the IP address in the first line of the ACL from the IP address of the sensor to the NAT address. This is not a NAT address configured on the device being managed. It is the address the sensor is translated to by an intermediate device, one that is between the sensor and the device being managed.

Step 7 Exit network access submode.

```
sensor(config-net-fir)# exit
sensor(config-net)# exit
sensor(config)# exit
Apply Changes:[yes]:
```

Step 8 Press **Enter** to apply the changes or enter **no** to discard them.

For More Information

- For the procedure for configuring user profiles, see [Configuring User Profiles, page 14-20](#).
- For the procedure for adding a device to the known hosts list, see [Adding Hosts to the SSH Known Hosts List, page 4-45](#).

Configuring the Sensor to be a Master Blocking Sensor

Multiple sensors (blocking forwarding sensors) can forward blocking requests to a specified master blocking sensor, which controls one or more devices. The master blocking sensor is the ARC running on a sensor that controls blocking on one or more devices on behalf of one or more other sensors. The ARC on a master blocking sensor controls blocking on devices at the request of the ARCs running on other sensors. Master blocking sensors can also forward rate limits.

**Caution**

Two sensors cannot control blocking or rate limiting on the same device. If this situation is needed, configure one sensor as the master blocking sensor to manage the devices and the other sensors can forward their requests to the master blocking sensor.

When you add a master blocking sensor, you reduce the number of blocking devices per sensor. For example, if you want to block on 10 firewalls and 10 routers with one blocking interface/direction each, you can assign 10 to the sensor and assign the other 10 to a master blocking sensor.

On the blocking forwarding sensor, identify which remote host serves as the master blocking sensor; on the master blocking sensor you must add the blocking forwarding sensors to its access list.

If the master blocking sensor requires TLS for web connections, you must configure the ARC of the blocking forwarding sensor to accept the X.509 certificate of the master blocking sensor remote host. Sensors by default have TLS enabled, but you can change this option.

**Note**

Typically the master blocking sensor is configured to manage the network devices. Blocking forwarding sensors are not normally configured to manage other network devices, although doing so is permissible.

Even if you have no devices configured for blocking or rate limiting, a sensor that is configured for blocking or rate limiting can forward blocking and rate limiting requests to a master blocking sensor. When a signature fires that has blocking or rate limit requests configured as event actions, the sensor forwards the block or rate limit request to the master blocking sensor, which then performs the block or rate limit.

**Caution**

Only one sensor should control all blocking interfaces on a device.

Use the **master-blocking-sensors** *master_blocking_sensor_ip_address* command in the service network access submode to configure a master blocking sensor. The following options apply:

- *master_blocking_sensor_ip_address*—Specifies the IP address of sensor for forward block requests.
- **password**—Specifies the account password of sensor for forward block requests.
- **port**—Specifies the port of sensor for forward block requests.
- **tls {true | false}** —Set to true if the remote sensor requires TLS; otherwise, set to false.
- **username**—Specifies the account name of sensor for forward block requests.

Configuring the Master Blocking Sensor

To configure ARC on a sensor to forward blocks to a master blocking sensor, follow these steps:

- Step 1** Log in to the CLI using an account with administrator privileges on both the master blocking sensor and the blocking forwarding sensor.
- Step 2** Enter configuration mode on both sensors.

```
sensor# configure terminal
```
- Step 3** Configure TLS if necessary:
 - a. On the master blocking sensor, check to see if it requires TLS and what port number is used. If *enable-tls* is true, go to Step b.

```
sensor(config)# service web-server
```

```
sensor(config-web)# show settings
  enable-tls: true <defaulted>
  port: 443 <defaulted>
  server-id: HTTP/1.1 compliant <defaulted>
sensor(config-web)#
```

- b. On the blocking forwarding sensor, configure it to accept the X.509 certificate of the master blocking sensor.

```
sensor(config-web)# exit
sensor(config)# tls trusted-host ip-address master_blocking_sensor_ip_address port
port_number
```

Example

```
sensor(config)# tls trusted-host ip-address 192.0.2.1 port 8080
Certificate MD5 fingerprint is
F4:4A:14:BA:84:F4:51:D0:A4:E2:15:38:7E:77:96:D8Certificate SHA1 fingerprint is
84:09:B6:85:C5:43:60:5B:37:1E:6D:31:6A:30:5F:7E:4D:4D:E8:B2
Would you like to add this to the trusted certificate table for this host?[yes]:
```



Note

You are prompted to accept the certificate based on the certificate fingerprint. Sensors provide only self-signed certificates (instead of certificates signed by a recognized certificate authority). You can verify the master blocking sensor host sensor certificate by logging in to the host sensor and typing the **show tls fingerprint** command to see that the fingerprints of the host certificate match.

Step 4 Enter **yes** to accept the certificate from the master blocking sensor.

Step 5 Enter network access mode.

```
sensor(config)# service network-access
```

Step 6 Enter general submode.

```
sensor(config-net)# general
```

Step 7 Add a master blocking sensor entry.

```
sensor(config-net-gen)# master-blocking-sensors master_blocking_sensor_ip_address
```

Step 8 Specify the username for an administrative account on the master blocking sensor host.

```
sensor(config-net-gen-mas)# username username
```

Step 9 Specify the password for the user.

```
sensor(config-net-gen-mas)# password
Enter password []: *****
Re-enter mbs-password []: *****
sensor(config-net-gen-mas)#
```

Step 10 Specify the port number for the host HTTP communications. The default is 80/443 if not specified.

```
sensor(config-net-gen-mas)# port port_number
```

Step 11 Specify whether or not the host uses TLS/SSL.

```
sensor(config-net-gen-mas)# tls {true | false}
sensor(config-net-gen-mas)
```



Note If you set the value to true, you need to use the command **tls trusted-host ip-address master_blocking_sensor_ip_address**.

Step 12 Exit network access submode.

```
sensor(config-net-gen-mas)# exit
sensor(config-net-gen)# exit
sensor(config-net)# exit
sensor(config)# exit
Apply Changes?[yes]:
```

Step 13 Press **Enter** to apply the changes or enter **no** to discard them.

Step 14 On the master blocking sensor, add the block forwarding sensor IP address to the access list.

For More Information

For the procedure for adding the blocking forward sensor IP address to the access list, see [Changing the Access List, page 4-6](#).

Configuring Host Blocking



Note

Connection blocks and network blocks are not supported on adaptive security appliances. Adaptive security appliances only support host blocks with additional connection information.

Use the **block host ip-address [timeout minutes]** command in privileged EXEC mode to block a host. Use the **no** form of the command to remove a block on a host. You must have blocking configured before you can set up host blocks. You can also view a list of hosts that are being blocked. If you do not configure the amount of time for the host block, it is permanent.

The following options apply:

- *ip-address*—Specifies the IP address of the host to be blocked.
- *minutes*—(Optional) Specifies the duration of the host block in minutes. The valid range is 0 to 70560 minutes.

Blocking a Host

To block a host, follow these steps:

Step 1 Log in to the CLI using an account with administrator or operator privileges.

Step 2 Configure the host block for 15 minutes, for example. The host block ends in 15 minutes.

```
sensor# block host 192.0.2.1 timeout 15
```

Step 3 Start a host block. The host block lasts until you remove it.

```
sensor# block host 192.0.2.1
```

Step 4 End the host block.

```
sensor# no block host 192.0.2.1
sensor#
```

Configuring Network Blocking



Note

Connection blocks and network blocks are not supported on adaptive security appliances. Adaptive security appliances only support host blocks with additional connection information.

Use the **block network** *ip-address/netmask* [**timeout** *minutes*] command in privileged EXEC mode to block a network. Use the **no** form of the command to remove a block on a network. You must have blocking configured before you can set up network blocks. You can also view a list of networks that are being blocked. If you do not configure the amount of time for the network block, it is permanent.

The following options apply:

- *ip-address/netmask*—Specifies the network subnet to be blocked in *X.X.X.X/nn* format, where *X.X.X.X* specifies the sensor IP address as a 32-bit address written as 4 octets separated by periods where *X* = 0-255, and *nn* specifies the number of bits (1032) in the netmask.
- *minutes*—(Optional) Specifies the duration of the network block in minutes. The valid range is 0 to 70560 minutes.

Blocking a Network

To block a network, follow these steps:

Step 1 Log in to the CLI using an account with administrator or operator privileges.

Step 2 Configure the network block for 15 minutes, for example. The network block ends in 15 minutes.

```
sensor# block network 192.0.2.0/24 timeout 15
```

Step 3 Start a network block. The network block lasts until you remove it.

```
sensor# block network 192.0.2.0/24
```

Step 4 End the network block.

```
sensor# no block network 192.0.2.0/24
sensor#
```

Configuring Connection Blocking



Note

Connection blocks and network blocks are not supported on adaptive security appliances. Adaptive security appliances only support host blocks with additional connection information.

Use the **block connection** *source-ip-address destination-ip-address* [**port** *port-number*] [**protocol** *type*] [**timeout** *minutes*] command in privileged EXEC mode to block a connection between two IP addresses. Use the **no** form of the command to remove the connection block. You must have blocking configured before you can set up connection blocks. You can also view a list of connections that are being blocked. If you do not configure the amount of time for the connection block, it is permanent.

The following options apply:

- *source-ip-address*—Specifies the source IP address in a connection block.
- *destination-ip-address*—Specifies the destination IP address in a connection block.
- *port-number*—(Optional) Specifies the destination port number. The valid range is 0 to 65535.
- *type*—(Optional) Specifies the protocol type. The valid types are **tcp** or **udp**.
- *minutes*—(Optional) Specifies the duration of the connection block in minutes. The valid range is 0 to 70560 minutes.

Blocking a Connection

To block a connection, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator or operator privileges.
- Step 2** Configure the connection block between a source IP address and a destination IP address specifying the port, protocol, and time, for example. The connection block ends in 30 minutes.
- ```
sensor# block connection 10.0.0.0 172.16.0.0 port 80 protocol tcp timeout 30
```
- Step 3** Start a connection block. The connection block lasts until you remove it.
- ```
sensor# block connection 10.0.0.0 172.16.0.0
```
- Step 4** End the connection block.
- ```
sensor# no block connection 10.0.0.0
sensor#
```
- 

## Obtaining a List of Blocked Hosts and Connections

Use the **show statistics** command to obtain a list of blocked hosts and blocked connections. To obtain a list of blocked hosts and connections, follow these steps:

- 
- Step 1** Log in to the CLI.
- Step 2** Check the statistics for the ARC. The `Host` entry indicates which hosts are being blocked and how long the blocks are.
- ```
sensor# show statistics network-access
Current Configuration
  LogAllBlockEventsAndSensors = true
  EnableNvramWrite = false
  EnableAclLogging = false
  AllowSensorBlock = false
  BlockMaxEntries = 250
  MaxDeviceInterfaces = 250
  NetDevice
    Type = Cisco
```

■ Obtaining a List of Blocked Hosts and Connections

```
IP = 10.1.1.1
NATAddr = 0.0.0.0
Communications = telnet
BlockInterface
    InterfaceName = fa0/0
    InterfaceDirection = in
State
    BlockEnable = true
NetDevice
    IP = 10.1.1.1
    AclSupport = uses Named ACLs
    Version = 12.2
    State = Active
BlockedAddr
    Host
        IP = 192.168.1.1
        Vlan =
        ActualIp =
        BlockMinutes = 80
        MinutesRemaining = 76
```



Configuring SNMP

This chapter describes how to configure SNMP, and contains the following sections:

- [SNMP Notes and Caveats, page 15-1](#)
- [Understanding SNMP, page 15-1](#)
- [Configuring SNMP, page 15-2](#)
- [Configuring SNMP Traps, page 15-4](#)
- [Supported MIBS, page 15-6](#)

SNMP Notes and Caveats

The following notes and caveats apply to SNMP:

- To have the sensor send SNMP traps, you must also select **request-snmp-trap** as the event action when you configure signatures.
- MIB II is available on the sensor, but we do not support it. We know that some elements are not correct (for example, the packet counts from the IF MIB on the sensing interfaces). While you can use elements from MIB II, we do not guarantee that they all provide correct information. We fully support the other listed MIBs and their output is correct.
- CISCO-PROCESS-MIB is available on the sensor, but we do not support it. We know that some elements are not available. While you can use elements from CISCO-PROCESS-MIB, we do not guarantee that they all provide correct information. We fully support the other listed MIBs and their output is correct.

Understanding SNMP

SNMP is an application layer protocol that facilitates the exchange of management information between network devices. SNMP enables network administrators to manage network performance, find and solve network problems, and plan for network growth.

SNMP is a simple request/response protocol. The network-management system issues a request, and managed devices return responses. This behavior is implemented by using one of four protocol operations: Get, GetNext, Set, and Trap.

You can configure the sensor for monitoring by SNMP. SNMP defines a standard way for network management stations to monitor the health and status of many types of devices, including switches, routers, and sensors.

You can configure the sensor to send SNMP traps. SNMP traps enable an agent to notify the management station of significant events by way of an unsolicited SNMP message.

Trap-directed notification has the following advantage—if a manager is responsible for a large number of devices, and each device has a large number of objects, it is impractical to poll or request information from every object on every device. The solution is for each agent on the managed device to notify the manager without solicitation. It does this by sending a message known as a trap of the event.

After receiving the event, the manager displays it and can take an action based on the event. For instance, the manager can poll the agent directly, or poll other associated device agents to get a better understanding of the event.

**Note**

Trap-directed notification results in substantial savings of network and agent resources by eliminating frivolous SNMP requests. However, it is not possible to totally eliminate SNMP polling. SNMP requests are required for discovery and topology changes. In addition, a managed device agent cannot send a trap if the device has had a catastrophic outage.

Configuring SNMP

**Caution**

To have the sensor send SNMP traps, you must also select **request-snmp-trap** as the event action when you configure signatures.

Configure general SNMP parameters in the service notification submode. The following options apply:

- **default**—Sets the value back to the system default setting.
- **enable-set-get {true | false}**—Enables the **gets** and **sets** of object identifiers (OIDs).
- **no**—Removes an entry or selection setting.
- **read-only-community**—Specifies the read-only community name for the SNMP agent. The default is public.
- **read-write-community**—Specifies the read-write community name for the SNMP agent. The default is private.
- **snmp-agent-port**—Specifies the port the SNMP agent will listen on. The default SNMP port number is 161.
- **snmp-agent-protocol**—Specifies the protocol the SNMP agent will communicate with. The default protocol is UDP.
- **system-contact**—Specifies the contact information for this sensor. The system-contact option modifies the SNMPv2-MIB::sysContact.0 value.
- **system-location**—Specifies the location of the sensor. The system-location option modifies the SNMPv2-MIB::sysLocation.0 value.

Configuring SNMP General Parameters

To configure SNMP general parameters, follow these steps:

- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter notification submode.
- ```
sensor# configure terminal
sensor(config)# service notification
sensor(config-not)#
```

- Step 3** Enable SNMP so that the SNMP management workstation can issue requests to the sensor SNMP agent.
- ```
sensor(config-not)# enable-set-get true
```

- Step 4** Specify the SNMP agent parameters. These values configure the community name on the sensor SNMP agent. A community name is a plain-text password mechanism that is used to weakly authenticate SNMP queries.

- a. Assign the read-only community string. The read-only community name specifies the password for queries to the SNMP agent.

```
sensor(config-not)# read-only-community PUBLIC1
```

- b. Assign the read-write community string. The read-write community name specifies the password for sets to the SNMP agent.

```
sensor(config-not)# read-write-community PRIVATE1
```



Note The management workstation sends SNMP requests to the sensor SNMP agent, which resides on the sensor. If the management workstation issues a request and the community string does not match what is on the sensor, the sensor rejects it.

- c. Assign the sensor contact user ID.

```
sensor(config-not)# system-contact BUSINESS
```

- d. Enter the location of the sensor.

```
sensor(config-not)# system-location AUSTIN
```

- e. Enter the port of the sensor SNMP agent.

```
sensor(config-not)# snmp-agent-port 161
```



Note You must reboot the sensor if you change the port or protocol.

- f. Specify the protocol the sensor SNMP agent will use.

```
sensor(config-not)# snmp-agent-protocol udp
```



Note You must reboot the sensor if you change the port or protocol.

- Step 5** Verify the settings.

```
sensor(config-not)# show settings
trap-destinations (min: 0, max: 10, current: 0)
```

```

-----
error-filter: error|fatal <defaulted>
enable-detail-traps: false <defaulted>
enable-notifications: false <defaulted>
enable-set-get: true default: false
snmp-agent-port: 161 default: 161
snmp-agent-protocol: udp default: udp
read-only-community: PUBLIC1 default: public
read-write-community: PRIVATE1 default: private
trap-community-name: public <defaulted>
system-location: AUSTIN default: Unknown
system-contact: BUSINESS default: Unknown
sensor(config-not)#

```

Step 6 Exit notification submode.

```

sensor(config-not)# exit
Apply Changes:[yes]:

```

Step 7 Press **Enter** to apply the changes or enter **no** to discard them.

For More Information

For the procedure for assigning actions to signatures, see [Assigning Actions to Signatures](#), page 8-15.

Configuring SNMP Traps



Caution

To have the sensor send SNMP traps, you must also select **request-snmp-trap** as the event action when you configure signatures.

Configure the SNMP traps in the service notification submode. The following options apply:

- **enable-detail-traps {true | false}**—Enables the sending of detailed traps with no size limit. Otherwise traps are sent in sparse mode (less than 484 bytes).
- **enable-health-traps {true | false}** —Enables the sending of both heartbeat and health metric change traps.



Note

To receive sensor health information through SNMP traps, you must have the sensor health metrics enabled. Use the **heartbeat-events enable** command in service health monitor submode to enable sensor health metrics.

- **enable-notifications {true | false}**—Enables event notifications.
- **error-filter {warning | error | fatal}**—Determines which errors generate an SNMP trap. An SNMP trap is generated for every evError event that matches the filter. The default is error and fatal.
- **trap-community-name**—Specifies the community name used when sending traps if no name is specified when defining the trap destinations.
- **trap-destinations**—Defines the destinations to send error events and alert events generated from signature actions:

- **trap-community-name**—Specifies the community name used when sending the trap. If no community name is specified the general trap community name is used.
- **trap-port**—Specifies the port number to send the SNMP trap to.

Configuring SNMP Traps

To configure SNMP traps, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter notification submode.

```
sensor# configure terminal
sensor(config)# service notification
sensor(config-not)#
```

Step 3 Enable SNMP traps.

```
sensor(config-not)# enable-notifications true
```

Step 4 Specify the parameters for the SNMP trap:

- a. Specify the error events you want to be notified about through SNMP traps.

```
sensor(config-not)# error-filter {error | warning | fatal}
```



Note The **error-filter [error | warning | fatal]** command includes error, warning, and fatal traps. It filters in (not filters out) the traps based on severity.

- b. Specify whether you want detailed SNMP traps.

```
sensor(config-not)# enable-detail-traps true
```

- c. Specify whether you want health traps (heartbeat and health metric change traps).

```
sensor(config-not)# enable-health-traps true
```



Note Make sure heartbeat and sensor health metrics are enabled.

- d. Enter the community string to be included in the detailed traps.

```
sensor(config-not)# trap-community-name TRAP1
```

Step 5 Specify the parameters for the SNMP trap destinations so the sensor knows which management workstations to send them to:

- a. Enter the IP address of the SNMP management station.

```
sensor(config-not)# trap-destinations 10.0.0.0
```

- b. Enter the UDP port of the SNMP management station. The default is 162

```
sensor(config-not-tra)# trap-port 162
```

- c. Enter the trap community string.

```
sensor(config-not-tra)# trap-community-name AUSTIN_PUBLI
```

**Note**

The community string appears in the trap and is useful if you are receiving multiple types of traps from multiple agents. For example, a router or sensor could be sending the traps, and if you put something that identifies the router or sensor specifically in your community string, you can filter the traps based on the community string.

Step 6 Verify the settings.

```

sensor(config-not-tra)# exit
sensor(config-not)# show settings
  trap-destinations (min: 0, max: 10, current: 1)
  -----
    ip-address: 10.1.1.1
    -----
      trap-community-name: AUSTIN_PUBLIC default:
      trap-port: 161 default: 162
      -----
error-filter: warning|error|fatal default: error|fatal
enable-detail-traps: true default: false
enable-health-traps: true default: false
enable-notifications: true default: false
enable-set-get: true default: false
snmp-agent-port: 161 default: 161
snmp-agent-protocol: udp default: udp
read-only-community: PUBLIC1 default: public
read-write-community: PRIVATE1 default: private
trap-community-name: PUBLIC1 default: public
system-location: AUSTIN default: Unknown
system-contact: BUSINESS default: Unknown
sensor(config-not)#

```

Step 7 Exit notification submenu.

```

sensor(config-not)# exit
Apply Changes:[yes]:

```

Step 8 Press **Enter** to apply the changes or enter **no** to discard them.**For More Information**

For the procedure for assigning actions to signatures, see [Assigning Actions to Signatures](#), page 8-15.

Supported MIBS

The following private MIBs are supported on the sensor:

- CISCO-CIDS-MIB

The CISCO-CIDS-MIB has been updated to include SNMP health data in IPS 7.1(3)E4 and later.

- CISCO-ENHANCED-MEMPOOL-MIB
- CISCO-ENTITY-ALARM-MIB

You can obtain these private Cisco MIBs under the heading SNMP v2 MIBs at this URL:

<http://www.cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml>

**Note**

MIB II is available on the sensor, but we do not support it. We know that some elements are not correct (for example, the packet counts from the IF MIB on the sensing interfaces). While you can use elements from MIB II, we do not guarantee that they all provide correct information. We fully support the other listed MIBs and their output is correct.

**Note**

CISCO-PROCESS-MIB is available on the sensor, but we do not support it. We know that some elements are not available. While you can use elements from CISCO-PROCESS-MIB, we do not guarantee that they all provide correct information. We fully support the other listed MIBs and their output is correct.



Working With Configuration Files

This chapter describes how to use commands that show, copy, and erase the configuration file. It contains the following sections:

- [Displaying the Current Configuration, page 16-1](#)
- [Displaying the Current Submode Configuration, page 16-3](#)
- [Filtering the Current Configuration Output, page 16-16](#)
- [Filtering the Current Submode Configuration Output, page 16-18](#)
- [Displaying the Contents of a Logical File, page 16-19](#)
- [Backing Up and Restoring the Configuration File Using a Remote Server, page 16-21](#)
- [Creating and Using a Backup Configuration File, page 16-23](#)
- [Erasing the Configuration File, page 16-23](#)

Displaying the Current Configuration



Note

The CLI output is an example of what your configuration may look like. It will not match exactly due to the optional setup choices, sensor model, and IPS 7.1 version you have installed.

Use the **show configuration** or the **more current-config** command to display the contents of the current configuration. To display the contents of the current configuration, follow these steps:

- Step 1** Log in to the CLI.
- Step 2** Display the current configuration.

```
sensor# show configuration
! -----
! Current configuration last modified Fri Apr 10 13:29:06 2010
! -----
! Version 7.1(1)
! Host:
!   Realm Keys          key1.0
! Signature Definition:
!   Signature Update    S383.0   2009-02-20
!   Virus Update        V1.4     2007-03-02
! -----
service interface
```

```

exit
! -----
service authentication
exit
! -----
service event-action-rules rules0
exit
! -----
service host
network-settings
host-ip 192.0.2.0/24,192.0.2.17
telnet-option enabled
access-list 0.0.0.0/0
exit
exit
! -----
service logger
exit
! -----
service network-access
exit
! -----
service notification
exit
! -----
service signature-definition sig0
exit
! -----
service ssh-known-hosts
exit
! -----
service trusted-certificates
exit
! -----
service web-server
exit
! -----
service anomaly-detection ad0
exit
! -----
service external-product-interface
exit
! -----
service health-monitor
exit
! -----
service global-correlation
exit
! -----
service analysis-engine
exit
sensor#

```

Displaying the Current Submode Configuration

Use the **show settings** command in a submode to display the current configuration of that submode. To display the current configuration of a submode, follow these steps:

Step 1 Log in to the CLI.

Step 2 Display the current configuration of the service analysis engine submode.

```
sensor# configure terminal
sensor(config)# service analysis-engine
sensor(config-ana)# show settings
global-parameters
-----
ip-logging
-----
max-open-iplog-files: 20 <defaulted>
-----
virtual-sensor (min: 1, max: 255, current: 1)
-----
<protected entry>
name: vs0 <defaulted>
-----
description: default virtual sensor <defaulted>
signature-definition: sig0 <protected>
event-action-rules: rules0 <protected>
physical-interface (min: 0, max: 999999999, current: 0)
-----
logical-interface (min: 0, max: 999999999, current: 0)
-----
-----
sensor(config-ana)# exit
sensor(config)# exit
sensor#
```

Step 3 Display the current configuration of the service anomaly detection submode.

```
sensor(config)# service anomaly-detection ad0
sensor(config-ano)# show settings
worm-timeout: 600 seconds <defaulted>
learning-accept-mode
-----
auto
-----
action: rotate <defaulted>
schedule
-----
periodic-schedule
-----
start-time: 10:00:00 <defaulted>
interval: 24 hours <defaulted>
-----
-----
internal-zone
-----
enabled: true <defaulted>
```

```

ip-address-range: 0.0.0.0 <defaulted>
tcp
-----
dst-port (min: 0, max: 65535, current: 0)
-----
default-thresholds
-----
scanner-threshold: 100 <defaulted>
threshold-histogram (min: 0, max: 3, current: 3)
-----
<protected entry>
dest-ip-bin: low <defaulted>
num-source-ips: 10 <defaulted>
<protected entry>
dest-ip-bin: medium <defaulted>
num-source-ips: 1 <defaulted>
<protected entry>
dest-ip-bin: high <defaulted>
num-source-ips: 1 <defaulted>
-----
enabled: true <defaulted>
-----
udp
-----
dst-port (min: 0, max: 65535, current: 0)
-----
default-thresholds
-----
scanner-threshold: 100 <defaulted>
threshold-histogram (min: 0, max: 3, current: 3)
-----
<protected entry>
dest-ip-bin: low <defaulted>
num-source-ips: 10 <defaulted>
<protected entry>
dest-ip-bin: medium <defaulted>
num-source-ips: 1 <defaulted>
<protected entry>
dest-ip-bin: high <defaulted>
num-source-ips: 1 <defaulted>
-----
enabled: true <defaulted>
-----
other
-----
protocol-number (min: 0, max: 255, current: 0)
-----
default-thresholds
-----
scanner-threshold: 100 <defaulted>
threshold-histogram (min: 0, max: 3, current: 3)
-----
<protected entry>
dest-ip-bin: low <defaulted>
num-source-ips: 10 <defaulted>
<protected entry>
dest-ip-bin: medium <defaulted>
num-source-ips: 1 <defaulted>
<protected entry>

```

```

        dest-ip-bin: high <defaulted>
        num-source-ips: 1 <defaulted>
-----
        enabled: true <defaulted>
-----
illegal-zone
-----
        enabled: true <defaulted>
        ip-address-range: 0.0.0.0 <defaulted>
        tcp
-----
            dst-port (min: 0, max: 65535, current: 0)
            -----
            -----
            default-thresholds
            -----
                scanner-threshold: 100 <defaulted>
                threshold-histogram (min: 0, max: 3, current: 3)
                -----
                    <protected entry>
                    dest-ip-bin: low <defaulted>
                    num-source-ips: 10 <defaulted>
                    <protected entry>
                    dest-ip-bin: medium <defaulted>
                    num-source-ips: 1 <defaulted>
                    <protected entry>
                    dest-ip-bin: high <defaulted>
                    num-source-ips: 1 <defaulted>
                    -----
                -----
            enabled: true <defaulted>
            -----
        udp
        -----
            dst-port (min: 0, max: 65535, current: 0)
            -----
            -----
            default-thresholds
            -----
                scanner-threshold: 100 <defaulted>
                threshold-histogram (min: 0, max: 3, current: 3)
                -----
                    <protected entry>
                    dest-ip-bin: low <defaulted>
                    num-source-ips: 10 <defaulted>
                    <protected entry>
                    dest-ip-bin: medium <defaulted>
                    num-source-ips: 1 <defaulted>
                    <protected entry>
                    dest-ip-bin: high <defaulted>
                    num-source-ips: 1 <defaulted>
                    -----
                -----
            enabled: true <defaulted>
            -----
        other
        -----
            protocol-number (min: 0, max: 255, current: 0)
            -----
            -----
            default-thresholds
            -----

```

```

scanner-threshold: 100 <defaulted>
threshold-histogram (min: 0, max: 3, current: 3)
-----
<protected entry>
dest-ip-bin: low <defaulted>
num-source-ips: 10 <defaulted>
<protected entry>
dest-ip-bin: medium <defaulted>
num-source-ips: 1 <defaulted>
<protected entry>
dest-ip-bin: high <defaulted>
num-source-ips: 1 <defaulted>
-----

enabled: true <defaulted>
-----

external-zone
-----
enabled: true <defaulted>
tcp
-----
dst-port (min: 0, max: 65535, current: 0)
-----
default-thresholds
-----
scanner-threshold: 100 <defaulted>
threshold-histogram (min: 0, max: 3, current: 3)
-----
<protected entry>
dest-ip-bin: low <defaulted>
num-source-ips: 10 <defaulted>
<protected entry>
dest-ip-bin: medium <defaulted>
num-source-ips: 1 <defaulted>
<protected entry>
dest-ip-bin: high <defaulted>
num-source-ips: 1 <defaulted>
-----

enabled: true <defaulted>
-----

udp
-----
dst-port (min: 0, max: 65535, current: 0)
-----
default-thresholds
-----
scanner-threshold: 100 <defaulted>
threshold-histogram (min: 0, max: 3, current: 3)
-----
<protected entry>
dest-ip-bin: low <defaulted>
num-source-ips: 10 <defaulted>
<protected entry>
dest-ip-bin: medium <defaulted>
num-source-ips: 1 <defaulted>
<protected entry>
dest-ip-bin: high <defaulted>
num-source-ips: 1 <defaulted>
-----

```



```

        enabled: true <defaulted>
-----
other
-----
    protocol-number (min: 0, max: 255, current: 0)
    -----
    default-thresholds
    -----
        scanner-threshold: 100 <defaulted>
        threshold-histogram (min: 0, max: 3, current: 3)
        -----
            <protected entry>
            dest-ip-bin: low <defaulted>
            num-source-ips: 10 <defaulted>
            <protected entry>
            dest-ip-bin: medium <defaulted>
            num-source-ips: 1 <defaulted>
            <protected entry>
            dest-ip-bin: high <defaulted>
            num-source-ips: 1 <defaulted>
            -----
        enabled: true <defaulted>
        -----
    ignore
    -----
        enabled: true <defaulted>
        source-ip-address-range: 0.0.0.0 <defaulted>
        dest-ip-address-range: 0.0.0.0 <defaulted>
        -----
sensor(config-ano)# exit
sensor(config)# exit
sensor# exit

```

Step 4 Display the current configuration of the service authentication submode.

```

sensor# configure terminal
sensor(config)# service authentication
sensor(config-aut)# show settings
    attemptLimit: 0 <defaulted>
sensor(config-aut)# exit
sensor(config)# exit
sensor#

```

Step 5 Display the current configuration of the service event action rules submode.

```

sensor# configure terminal
sensor(config)# service event-action-rules rules0
sensor(config-rul)# show settings
    variables (min: 0, max: 256, current: 0)
    -----
    overrides (min: 0, max: 12, current: 0)
    -----
    filters (min: 0, max: 4096, current: 0 - 0 active, 0 inactive)
    -----
    general
    -----
        global-overrides-status: Enabled <defaulted>
        global-filters-status: Enabled <defaulted>
        global-summarization-status: Enabled <defaulted>

```

```

    global-metaevent-status: Enabled <defaulted>
    global-deny-timeout: 3600 <defaulted>
    global-block-timeout: 30 <defaulted>
    max-denied-attackers: 10000 <defaulted>
    -----
    target-value (min: 0, max: 5, current: 0)
    -----
sensor(config-rul)# exit
sensor(config)# exit
sensor# exit

```

Step 6 Display the current configuration of the external product interface submode.

```

sensor(config)# service external-product-interface
sensor(config-ext)# show settings
    cisco-security-agents-mc-settings (min: 0, max: 2, current: 0)
    -----
sensor(config-ext)# exit
sensor(config)# exit
sensor#

```

Step 7 Display the current configuration of the service global-correlation submode.

```

sensor# configure terminal
sensor(config)# service global-correlation
sensor(config-glo)# show settings
    network-participation: off <defaulted>
    global-correlation-inspection: on <defaulted>
    global-correlation-inspection-influence: standard <defaulted>
    reputation-filtering: on <defaulted>
    test-global-correlation: off <defaulted>
sensor(config-glo)# exit
sensor(config)# exit
sensor# exit

```

Step 8 Display the current configuration of the service health-monitor submode.

```

sensor# configure terminal
sensor(config)# service health-monitor
sensor(config-hea)# show settings
    enable-monitoring: true <defaulted>
    persist-security-status: 5 minutes <defaulted>
    heartbeat-events
    -----
    enable: 300 seconds <defaulted>
    -----
    application-failure-policy
    -----
    enable: true <defaulted>
    status: red <defaulted>
    -----
    bypass-policy
    -----
    enable: true <defaulted>
    status: red <defaulted>
    -----
    interface-down-policy
    -----
    enable: true <defaulted>
    status: red <defaulted>
    -----
    inspection-load-policy
    -----

```

```

enable: true <defaulted>
yellow-threshold: 80 percent <defaulted>
red-threshold: 91 percent <defaulted>
-----
missed-packet-policy
-----
enable: true <defaulted>
yellow-threshold: 1 percent <defaulted>
red-threshold: 6 percent <defaulted>
-----
memory-usage-policy
-----
enable: false <defaulted>
yellow-threshold: 80 percent <defaulted>
red-threshold: 91 percent <defaulted>
-----
signature-update-policy
-----
enable: true <defaulted>
yellow-threshold: 30 days <defaulted>
red-threshold: 60 days <defaulted>
-----
license-expiration-policy
-----
enable: true <defaulted>
yellow-threshold: 30 days <defaulted>
red-threshold: 0 days <defaulted>
-----
event-retrieval-policy
-----
enable: true <defaulted>
yellow-threshold: 300 seconds <defaulted>
red-threshold: 600 seconds <defaulted>
-----
global-correlation-policy
-----
enable: true <defaulted>
yellow-threshold: 86400 seconds <protected>
red-threshold: 259200 seconds <protected>
-----
network-participation-policy
-----
enable: false <defaulted>
yellow-threshold: 1 connection failures <protected>
red-threshold: 6 connection failures <protected>
-----
sensor(config-hea)# exit
sensor(config)# exit
sensor# exit

```

Step 9 Display the current configuration of the service host submode.

```

sensor# configure terminal
sensor(config)# service host
sensor(config-hos)# show settings
network-settings
-----
host-ip: 192.0.2.0/24,192.0.2.17 default: 192.168.1.2/24,192.168.1.1
host-name: sensor default: sensor
telnet-option: enabled default: disabled
access-list (min: 0, max: 512, current: 2)
-----
network-address: 10.0.0.0/8
-----

```

```

        network-address: 64.0.0.0/8
        -----
        ftp-timeout: 300 seconds <defaulted>
        login-banner-text: <defaulted>
        -----
    time-zone-settings
    -----
        offset: 0 minutes default: 0
        standard-time-zone-name: UTC default: UTC
        -----
    ntp-option
    -----
        disabled
        -----
    summertime-option
    -----
        disabled
        -----
    auto-upgrade-option
    -----
        disabled
        -----
    crypto
    -----
        key (min: 0, max: 10, current: 2)
        -----
            <protected entry>
            name: realm-cisco.pub <defaulted>
            type
            -----
                rsa-pubkey
                -----
                    length: 2048 <defaulted>
                    exponent: 65537 <defaulted>
                    modulus: 24442189989357747083874855335232628843599968934198559648
63019947387841151932503911172668940194754549155390407658020393330611891292508300
85940304031186014499632568812428068058089581614196337399623060624990057049103055
90153955935086060008679776808073640186063435723252375575293126304558068704301863
80562114437439289069456670922074995827390284761610591515752008405140243673083189
77822469964934598367010389389888297490802884118543730076293589703535912161993319
47093130298688830012547215572646349623539468838641064915313947806852904082351955
13217273138099965383039716130153270715220046567107828128924197692417332033911704
3 <defaulted>
            -----
                <protected entry>
                name: realm-trend.pub <defaulted>
                type
                -----
                    rsa-pubkey
                    -----
                        length: 2048 <defaulted>
                        exponent: 65537 <defaulted>
                        modulus: 21765561422573021314159855351418723031625093380777053696
63817289527060570932551065489818190713745672148260527030060667208366606603802679
30439066724143390626495479300550101618179584637287052936465692146572612651375969
20354521585644221602944203520804404212975401970895119903756769601133853673296766

```

```

45289795777973491984056587045214514820063366950731346400044308491594626434706999
47608668822814014830063399534204647069509052443439525363706527255224510771122235
80181150460544783251498481432705991010069844368525754878413669427639752950801767
99905309235232456295580086724203297914095984224328444391582223138423799100838191
9 <defaulted>

```

```

-----
-----
-----
sensor(config-hos)# exit
sensor(config)# exit
sensor#

```

Step 10 Display the current configuration of the service interface submode.

```

sensor# configure terminal
sensor(config)# service interface
sensor(config-int)# show settings
physical-interfaces (min: 0, max: 999999999, current: 4)
-----
<protected entry>
name: GigabitEthernet0/0 <defaulted>
-----
media-type: tx <protected>
description: <defaulted>
admin-state: disabled <defaulted>
duplex: auto <defaulted>
speed: auto <defaulted>
alt-tcp-reset-interface
-----
none
-----
-----
subinterface-type
-----
none
-----
-----
-----
<protected entry>
name: GigabitEthernet0/1 <defaulted>
-----
media-type: tx <protected>
description: <defaulted>
admin-state: disabled <protected>
duplex: auto <defaulted>
speed: auto <defaulted>
alt-tcp-reset-interface
-----
none
-----
-----
subinterface-type
-----
none
-----
-----
-----
<protected entry>
name: GigabitEthernet2/0 <defaulted>

```

```

-----
media-type: xl <protected>
description: <defaulted>
admin-state: disabled <defaulted>
duplex: auto <defaulted>
speed: auto <defaulted>
alt-tcp-reset-interface
-----
none
-----
-----
subinterface-type
-----
none
-----
-----
-----
<protected entry>
name: GigabitEthernet2/1 <defaulted>
-----
media-type: xl <protected>
description: <defaulted>
admin-state: disabled <defaulted>
duplex: auto <defaulted>
speed: auto <defaulted>
alt-tcp-reset-interface
-----
none
-----
-----
subinterface-type
-----
none
-----
-----
-----
command-control: GigabitEthernet0/1 <protected>
inline-interfaces (min: 0, max: 999999999, current: 0)
-----
bypass-mode: auto <defaulted>
interface-notifications
-----
missed-percentage-threshold: 0 percent <defaulted>
notification-interval: 30 seconds <defaulted>
idle-interface-delay: 30 seconds <defaulted>
-----
sensor(config-int)# exit
sensor(config)# exit
sensor#

```

Step 11 Display the current configuration for the service logger submode.

```

sensor# configure terminal
sensor(config)# service logger
sensor(config-log)# show settings
master-control
-----
enable-debug: false <defaulted>

```

```

individual-zone-control: false <defaulted>
-----
zone-control (min: 0, max: 999999999, current: 14)
-----
  <protected entry>
  zone-name: Cid
  severity: debug <defaulted>
  <protected entry>
  zone-name: AuthenticationApp
  severity: warning <defaulted>
  <protected entry>
  zone-name: Cli
  severity: warning <defaulted>
  <protected entry>
  zone-name: csi
  severity: warning <defaulted>
  <protected entry>
  zone-name: ctlTransSource
  severity: warning <defaulted>
  <protected entry>
  zone-name: IdapiCtlTrans
  severity: warning <defaulted>
  <protected entry>
  zone-name: IdsEventStore
  severity: warning <defaulted>
  <protected entry>
  zone-name: MpInstaller
  severity: warning <defaulted>
  <protected entry>
  zone-name: nac
  severity: warning <defaulted>
  <protected entry>
  zone-name: sensorApp
  severity: warning <defaulted>
  <protected entry>
  zone-name: tls
  severity: warning <defaulted>
  <protected entry>
  zone-name: intfc
  severity: warning <defaulted>
  <protected entry>
  zone-name: cmgr
  severity: warning <defaulted>
  <protected entry>
  zone-name: cplane
  severity: warning <defaulted>
-----
sensor(config-log)# exit
sensor(config)# exit
sensor#

```

Step 12 Display the current configuration for the service network access submode.

```

sensor# configure terminal
sensor(config)# service network-access
sensor(config-net)# show settings
general
-----
log-all-block-events-and-errors: true <defaulted>
enable-nvram-write: false <defaulted>
enable-acl-logging: false <defaulted>
allow-sensor-block: false <defaulted>
block-enable: true <defaulted>
block-max-entries: 250 <defaulted>

```

```

max-interfaces: 250 <defaulted>
rate-limit-max-entries: 250 <defaulted>
master-blocking-sensors (min: 0, max: 100, current: 0)
-----
never-block-hosts (min: 0, max: 250, current: 0)
-----
never-block-networks (min: 0, max: 250, current: 0)
-----
block-hosts (min: 0, max: 250, current: 0)
-----
block-networks (min: 0, max: 250, current: 0)
-----
user-profiles (min: 0, max: 250, current: 1)
-----
  profile-name: test
  -----
    enable-password: <hidden>
    password: <hidden>
    username: <defaulted>
  -----
cat6k-devices (min: 0, max: 250, current: 0)
-----
router-devices (min: 0, max: 250, current: 0)
-----
firewall-devices (min: 0, max: 250, current: 0)
-----
sensor(config-net)# exit
sensor(config)# exit
sensor#

```

Step 13 Display the current configuration for the notification submode.

```

sensor# configure terminal
sensor(config)# service notification
sensor(config-not)# show settings
  trap-destinations (min: 0, max: 10, current: 0)
  -----
  error-filter: error|fatal <defaulted>
  enable-detail-traps: false <defaulted>
  enable-notifications: false <defaulted>
  enable-set-get: false <defaulted>
  snmp-agent-port: 161 <defaulted>
  snmp-agent-protocol: udp <defaulted>
  read-only-community: public <defaulted>
  read-write-community: private <defaulted>
  trap-community-name: public <defaulted>
  system-location: Unknown <defaulted>
  system-contact: Unknown <defaulted>
sensor(config-not)# exit
sensor(config)# exit
sensor#

```


Step 14 Display the current configuration for the signature definition submode.

```

sensor# configure terminal
sensor(config)# service signature-definition sig0
sensor(config-sig)# show settings
    variables (min: 0, max: 256, current: 1)
    -----
    <protected entry>
    variable-name: WEBPORTS
    -----
    web-ports: 80-80,3128-3128,8000-8000,8010-8010,8080-8080,8888-8888,2432
6-24326 <defaulted>
    -----
    application-policy
    -----
    http-policy
    -----
    http-enable: false <defaulted>
    max-outstanding-http-requests-per-connection: 10 <defaulted>
    aic-web-ports: 80-80,3128-3128,8000-8000,8010-8010,8080-8080,8888-8888,
24326-24326 <defaulted>
    -----
    ftp-enable: false <defaulted>
    -----
    fragment-reassembly
    -----
    ip-reassemble-mode: nt <defaulted>
    -----
    stream-reassembly
    -----
--MORE--

```

Step 15 Display the current configuration for the SSH known hosts submode.

```

sensor# configure terminal
sensor(config)# service ssh-known-hosts
sensor(config-ssh)# show settings
    rsal-keys (min: 0, max: 500, current: 0)
    -----

sensor(config-ssh)# exit
sensor(config)# exit
sensor#

```

Step 16 Display the current configuration for the trusted certificates submode.

```

sensor# configure terminal
sensor(config)# service trusted-certificate
sensor(config-tru)# show settings
    trusted-certificates (min: 0, max: 500, current: 1)
    -----
    common-name: 10.89.130.108
    certificate: MIICJDCCAY0CCPbSkgXUchJIMA0GCSqGSIB3DQEBBQUAMFcxCzAJBgNVBAYTA
1VTMRwwGgYDVQQKEExNDaXNjbyBTeXN0ZW1zLCBjb2MwMRIwEAYDVQQLEw1TU00tSVBtMjAxFjAUBgNVB
AMTDTEwLjg5LjEzMC4xMDgwHhcNMDMwMTAzMDE1MjEwWhcNMDUwMTAzMDE1MjEwWjBXMQswCQYDVQQGE
wJVUzEcMBoGA1UEChMTQ2l2Y28gU3lzdGVtcywgSW5jLjESMBAGA1UECzMJU1NNLU1QUzIwMRYwFAYDV
QQDEw0xMC44OS4xMzAuMTA4MIGfMA0GCSqGSIB3DQEBBQUAA4GNADCBiQKBgQCzldqLFG4MT4bfg3mJ
fP/DCilnnaLfzHK9FdnhmWI4FY+9MVvAI7MOhAcuV6HYfyp6n6cYvH+Eswz19uv7H5nouID9St9GI3Yr
SUT1lQAJ4QVL2DwWP230x6KdHrYqcj+Nmhc7AnnPypjidwGSff+VetIJLEerFh/mI2JcmwF2QIDAQABM
A0GCSqGSIB3DQEBBQUAA4GBAAUI2PLANTOehxvCfwd6UAFXvy8uifbjqKMC1jrrF+f9KGkxmR+XZvUaG
OS83FYDX1XJvB5XyXms+Y01wGjzKKpxegBoan8OB8o193Ueszdppv2xYmiEgywCDyVJRsw3hAFMXWMS5
XsBuiHtw0btHH0j7ElFZxUjZv12fGz8hlnY
    -----
sensor(config-tru)# exit

```

```
sensor(config)# exit
sensor#
```

Step 17 Display the current configuration for the web server submode.

```
sensor# configure terminal
sensor(config)# service web-server
sensor(config-web)# show settings
    enable-tls: true <defaulted>
    port: 443 <defaulted>
    server-id: HTTP/1.1 compliant <defaulted>
sensor(config-web)# exit
sensor(config)# exit
sensor#
```

Filtering the Current Configuration Output

Use the **more** keyword | [**begin** | **exclude** | **include**] *regular-expression* command to search the output of the more command. The following options apply:

- *keyword*—Specifies either the current-config or the backup-config:
 - **current-config**—Specifies the current running configuration. This configuration becomes persistent as the commands are entered.
 - **backup-config**—Specifies the storage location for the configuration backup file.
- |—The pipe symbol indicates that an output processing specification follows.
- **begin**—Begins unfiltered output of the **more** command with the first line that contains the regular expression specified.
- **exclude**—Excludes lines in the output of the **more** command that contain a particular regular expression.
- **include**—Includes only the lines in the output of the **more** command that contain the regular expression you specify.
- *regular-expression*—Specifies any regular expression found in the **more** command output.



Note The *regular-expression* option is case sensitive and allows for complex matching requirements.

Filtering Using the More Command

To filter the more command, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Filter the current-config output beginning with the regular expression “ip,” for example.

```
sensor# more current-config | begin ip
generating current config:
host-ip 192.0.2.0/24,192.0.2.17
host-name sensor
telnet-option enabled
access-list 10.0.0.0/8
access-list 64.0.0.0/8
```

```

exit
time-zone-settings
offset 0
standard-time-zone-name UTC
exit
exit
! -----
service interface
exit
! -----
service logger
master-control
enable-debug true
exit
exit
! -----
service network-access
general
log-all-block-events-and-errors true
--MORE--

```



Note Press **Ctrl-C** to stop the output and return to the CLI prompt.

Step 3 Exclude the regular expression “ip” from the current-config output.

```

sensor# more current-config | exclude ip
generating current config:
! -----
! Version 7.0(1)
! Current configuration last modified Fri Feb 11 15:10:57 2009
! -----
service analysis-engine
virtual-sensor vs0
physical-interface FastEthernet0/1
exit
exit
! -----
service authentication
exit
! -----
service event-action-rules rules0
exit
! -----
service host
network-settings
host-name sensor
telnet-option enabled
access-list 10.0.0.0/8
access-list 64.0.0.0/8
exit
time-zone-settings
--MORE--

```



Note Press **Ctrl-C** to stop the output and return to the CLI prompt.

Step 4 Include the regular expression “ip” in the current-config output.

```

sensor# more current-config | include ip
generating current config:

```

```
host-ip 192.0.2.0/24,192.0.2.17
engine atomic-ip
```

Filtering the Current Submode Configuration Output

Use the **show settings** | [**begin** | **exclude** | **include**] *regular_expression* command in the submode you are interested in to search or filter the output of the contents of the submode configuration. The following options apply:

- |—The pipe symbol indicates that an output processing specification follows.
- **begin**—Begins unfiltered output of the **show settings** command with the first line that contains the regular expression specified.
- **exclude**—Excludes lines in the output of the **show settings** command that contain a particular regular expression.
- **include**—Includes only the lines in the output of the **show settings** command that contain the regular expression you specify.
- *regular_expression*—Specifies any regular expression found in the **show settings** command output.



Note The *regular_expression* option is case sensitive and allows for complex matching requirements.

Filtering the Submode Output

To search or filter the output of the contents of the submode configuration, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Search the output of the event action rules settings for the regular expression, “filters,” for example.

```
sensor# configure terminal
sensor(config)# service event-action-rules
sensor(config-rul)# show settings | begin filters
filters (min: 0, max: 4096, current: 0 - 0 active, 0 inactive)
-----
general
-----
global-overrides-status: Enabled <defaulted>
global-filters-status: Enabled <defaulted>
global-summarization-status: Enabled <defaulted>
global-metaevent-status: Enabled <defaulted>
global-deny-timeout: 3600 <defaulted>
global-block-timeout: 15 default: 30
max-denied-attackers: 10000 <defaulted>
-----
target-value (min: 0, max: 5, current: 0)
-----
sensor(config-rul)#
```

Step 3 Filter the output of the network access settings to exclude the regular expression.

```
sensor# configure terminal
sensor(config)# service network-access
```

```

sensor(config-net)# show settings | exclude false
general
-----
log-all-block-events-and-errors: true default: true
block-enable: true default: true
block-max-entries: 11 default: 250
max-interfaces: 13 default: 250
master-blocking-sensors (min: 0, max: 100, current: 1)
-----
ipaddress: 192.0.2.0
-----
password: <hidden>
port: 443 default: 443
tls: true default: true
username: cisco default:
-----
never-block-hosts (min: 0, max: 250, current: 1)
-----
ip-address: 10.89.146.112
-----
never-block-networks (min: 0, max: 250, current: 1)
-----
ip-address: 88.88.88.0/24
--MORE--

```

Step 4 Filter the output of the host settings to include the regular expression “ip.”

```

sensor# configure terminal
sensor(config)# service host
sensor(config-hos)# show settings | include ip
host-ip: 192.0.2.0/24,192.0.2.17 default: 192.168.1.2/24,192.168.1.1
sensor(config-hos)#

```

Displaying the Contents of a Logical File



Note

Operators and viewers can only display the current configuration. Only administrators can view hidden fields such as passwords.

Use the **more** *keyword* command to display the contents of a logical file, such as the current system configuration or the saved backup system configuration. The following options apply:

- *keyword*—Specifies either the current-config or the backup-config:
 - **current-config**—Specifies the current running configuration. This configuration becomes persistent as the commands are entered.
 - **backup-config**—Specifies the storage location for the configuration backup file.

You can disable the more prompt in **more current-config** or **more backup-config** by setting the terminal length to zero using the **terminal length 0** command. The **more** command then displays the entire file content without pausing.

Displaying the Logical File Contents

To display the contents of a logical file, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Display the contents of the current configuration file.

```
sensor# more current-config
Generating current config:
```

The current configuration is displayed.

```
! -----
! Current configuration last modified Fri Apr 10 13:29:06 2011
! -----
! Version 7.1(1)
! Host:
!   Realm Keys          key1.0
! Signature Definition:
!   Signature Update    S383.0    2009-02-20
!   Virus Update        V1.4      2007-03-02
! -----
service interface
exit
! -----
service authentication
exit
! -----
service event-action-rules rules0
exit
! -----
service host
network-settings
host-ip 192.168.1.2/24,192.168.1.1
telnet-option enabled
access-list 0.0.0.0/0
exit
exit
! -----
service logger
exit
! -----
service network-access
exit
! -----
service notification
exit
! -----
service signature-definition sig0
exit
! -----
service ssh-known-hosts
exit
! -----
service trusted-certificates
exit
! -----
service web-server
exit
! -----
service anomaly-detection ad0
exit
! -----
```

```

service external-product-interface
exit
! -----
service health-monitor
exit
! -----
service global-correlation
exit
! -----
service analysis-engine
exit
sensor#

```

For More Information

For the procedure for using the **terminal** command, see [Modifying Terminal Properties, page 17-23](#).

Backing Up and Restoring the Configuration File Using a Remote Server



Note

We recommend copying the current configuration file to a remote server before upgrading.

Use the **copy** [/erase] *source_url destination_url keyword* command to copy the configuration file to a remote server. You can then restore the current configuration from the remote server. You are prompted to back up the current configuration first. The following options apply:

- **/erase**—Erases the destination file before copying.
This keyword only applies to the current-config; the backup-config is always overwritten. If this keyword is specified for destination current-config, the source configuration is applied to the system default configuration. If it is not specified for the destination current-config, the source configuration is merged with the current-config.
- *source_url*—The location of the source file to be copied. It can be a URL or keyword.
- *destination_url*—The location of the destination file to be copied. It can be a URL or a keyword.
- **current-config**—The current running configuration. The configuration becomes persistent as the commands are entered.
- **backup-config**—The storage location for the configuration backup.

The exact format of the source and destination URLs varies according to the file. Here are the valid types:

- **ftp**:—Source or destination URL for an FTP network server. The syntax for this prefix is:
ftp://[[username@] location]/relativeDirectory/filename
ftp://[[username@]location]//absoluteDirectory/filename
- **scp**:—Source or destination URL for the SCP network server. The syntax for this prefix is:
scp://[[username@] location]/relativeDirectory/filename
scp://[[username@] location]//absoluteDirectory/filename

**Note**

If you use FTP or SCP protocol, you are prompted for a password. If you use SCP protocol, you must also add the remote host to the SSH known hosts list.

- **http:**—Source URL for the web server. The syntax for this prefix is:
http://[[username@]location]/directory]/filename
- **https:**—Source URL for the web server. The syntax for this prefix is:
https://[[username@]location]/directory]/filename

**Note**

HTTP and HTTPS prompt for a password if a username is required to access the website. If you use HTTPS protocol, the remote host must be a TLS trusted host.

**Caution**

Copying a configuration file from another sensor may result in errors if the sensing interfaces and virtual sensors are not configured the same.

Backing Up the Current Configuration to a Remote Server

To back up your current configuration to a remote server, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Back up the current configuration to the remote server.

```
sensor# copy current-config scp://user@192.0.2.0//configuration/cfg current-config
Password: *****
Warning: Copying over the current configuration may leave the box in an unstable state.
Would you like to copy current-config to backup-config before proceeding? [yes]:
```

Step 3 Enter **yes** to copy the current configuration to a backup configuration.

```
cfg                               100% | ***** | 36124          00:00
```

Restoring the Current Configuration From a Backup File

To restore your current configuration from a backup file, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Back up the current configuration to the remote server.

```
sensor# copy scp://user@192.0.2.0//configuration/cfg current-config
Password: *****
Warning: Copying over the current configuration may leave the box in an unstable state.
Would you like to copy current-config to backup-config before proceeding? [yes]:
```

Step 3 Enter **yes** to copy the current configuration to a backup configuration.

```
cfg                               100% | ***** | 36124          00:00
```

```
Warning: Replacing existing network-settings may leave the box in an unstable state.
Would you like to replace existing network settings
(host-ipaddress/netmask/gateway/access-list) on sensor before proceeding? [no]:
sensor#
```


- Step 4** Enter **no** to retain the currently configured hostname, IP address, subnet mask, management interface, and access list. We recommend you retain this information to preserve access to your sensor after the rest of the configuration has been restored.
-

For More Information

- For the procedure for adding the remote host to the SSH known host list, see [Adding Hosts to the SSH Known Hosts List, page 4-45](#).
- For the procedure for adding the remote host to the TLS trusted hosts list, see [Adding TLS Trusted Hosts, page 4-51](#).

Creating and Using a Backup Configuration File

To protect your configuration, you can back up the current configuration and then display it to confirm that is the configuration you want to save. If you need to restore this configuration, you can merge the backup configuration file with the current configuration or overwrite the current configuration file with the backup configuration file.

To back up your current configuration, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Save the current configuration. The current configuration is saved in a backup file.
- ```
sensor# copy current-config backup-config
```
- Step 3** Display the backup configuration file. The backup configuration file is displayed.
- ```
sensor# more backup-config
```
- Step 4** You can either merge the backup configuration with the current configuration, or you can overwrite the current configuration:
- Merge the backup configuration into the current configuration.
- ```
sensor# copy backup-config current-config
```
- Overwrite the current configuration with the backup configuration.
- ```
sensor# copy /erase backup-config current-config
```
-

Erasing the Configuration File

Use the **erase {backup-config | current-config}** command to delete a logical file. The following options apply:

- **current-config**—The current running configuration. The configuration becomes persistent as the commands are entered.
- **backup-config**—The storage location for the configuration backup.

To erase the current configuration and return all settings back to the default, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

```
sensor# erase current-config
```

```
Warning: Removing the current-config file will result in all configuration being reset to  
default, including system information such as IP address.
```

```
User accounts will not be erased. They must be removed manually using the "no username"  
command.
```

```
Continue? []:
```

Step 2 Press **Enter** to continue or enter **no** to stop.



Administrative Tasks for the Sensor

This chapter contains procedures that will help you with the administrative aspects of your sensor. It contains the following sections:

- [Administrative Notes and Caveats, page 17-2](#)
- [Recovering the Password, page 17-2](#)
- [Clearing the Sensor Databases, page 17-12](#)
- [Displaying the Inspection Load of the Sensor, page 17-13](#)
- [Configuring Health Status Information, page 17-15](#)
- [Showing Sensor Overall Health Status, page 17-20](#)
- [Creating a Banner Login, page 17-21](#)
- [Terminating CLI Sessions, page 17-22](#)
- [Modifying Terminal Properties, page 17-23](#)
- [Configuring Events, page 17-24](#)
- [Configuring the System Clock, page 17-27](#)
- [Clearing the Denied Attackers List, page 17-28](#)
- [Displaying Policy Lists, page 17-30](#)
- [Displaying Statistics, page 17-31](#)
- [Displaying Tech Support Information, page 17-43](#)
- [Displaying Version Information, page 17-44](#)
- [Diagnosing Network Connectivity, page 17-46](#)
- [Resetting the Appliance, page 17-47](#)
- [Displaying Command History, page 17-48](#)
- [Displaying Hardware Inventory, page 17-49](#)
- [Tracing the Route of an IP Packet, page 17-51](#)
- [Displaying Submode Settings, page 17-52](#)

Administrative Notes and Caveats

The following notes and caveats apply to administrative tasks for the sensor:

- Administrators may need to disable the password recovery feature for security reasons.
- If you try to recover the password on a sensor on which password recovery is disabled, the process proceeds with no errors or warnings; however, the password is not reset. If you cannot log in to the sensor because you have forgotten the password, and password recovery is set to disabled, you must reimage your sensor.
- We do not recommend that you use **clear database** command unless under the direction of the TAC or in some testing conditions when you need to clear accumulated state information and start with a clean database.
- The ASA 5500-X IPS SSP and ASA 5585-X IPS SSP do not support bypass mode. The adaptive security appliance will either fail open, fail close, or fail over depending on the configuration of the adaptive security appliance and the type of activity being done on the IPS.
- When the sensor is first starting, it is normal for certain health metric statuses to be red until the sensor is fully up and running.
- You do not need to set the system clock if your sensor is synchronized by a valid outside timing mechanism such as an NTP clock source.
- The **show inventory** command does not apply to the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP).

Recovering the Password

For most IPS platforms, you can now recover the password on the sensor rather than using the service account or reimaging the sensor. This section describes how to recover the password for the various IPS platforms. It contains the following topics:

- [Understanding Password Recovery, page 17-2](#)
- [Recovering the Password for the Appliance, page 17-3](#)
- [Recovering the Password for the ASA 5500 AIP SSM, page 17-5](#)
- [Recovering the Password for the ASA 5500-X IPS SSP, page 17-7](#)
- [Recovering the Password for the ASA 5585-X IPS SSP, page 17-9](#)
- [Disabling Password Recovery, page 17-10](#)
- [Verifying the State of Password Recovery, page 17-11](#)
- [Troubleshooting Password Recovery, page 17-12](#)

Understanding Password Recovery

**Note**

Administrators may need to disable the password recovery feature for security reasons.

Password recovery implementations vary according to IPS platform requirements. Password recovery is implemented only for the cisco administrative account and is enabled by default. The IPS administrator can then recover user passwords for other accounts using the CLI. The cisco user password reverts to **cisco** and must be changed after the next login.

Table 17-1 lists the password recovery methods according to platform.

Table 17-1 Password Recovery Methods According to Platform

Platform	Description	Recovery Method
4200 series sensors 4300 series sensors 4500 series sensors	Standalone IPS appliances	GRUB prompt or ROMMON
ASA 5500 AIP SSM ASA 5500-X IPS SSP ASA 5585-X IPS SSP	ASA 5500 series adaptive security appliance IPS modules	Adaptive security appliance CLI command

Recovering the Password for the Appliance

This section describes the two ways to recover the password for appliances. It contains the following topics:

- [Using the GRUB Menu, page 17-3](#)
- [Using ROMMON, page 17-4](#)

Using the GRUB Menu



Note

You must have a terminal server or direct serial connection to the appliance to use the GRUB menu to recover the password.

For the IPS 4270-20, IPS 4355, IPS 4360, IPS 4510, and IPS 4520 appliances, the password recovery is found in the GRUB menu, which appears during bootup. When the GRUB menu appears, press any key to pause the boot process. To recover the password on appliances, follow these steps:

Step 1 Reboot the appliance to see the GRUB menu.

```
GNU GRUB version 0.94 (632K lower / 523264K upper memory)
-----
0: Cisco IPS
1: Cisco IPS Recovery
2: Cisco IPS Clear Password (cisco)
-----
```

```
Use the ^ and v keys to select which entry is highlighted.
Press enter to boot the selected OS, 'e' to edit the
Commands before booting, or 'c' for a command-line.
```

```
Highlighted entry is 0:
```

Step 2 Press any key to pause the boot process.

- Step 3** Choose **2: Cisco IPS Clear Password (cisco)**. The password is reset to **cisco**. Log in to the CLI with username **cisco** and password **cisco**. You can then change the password.

Using ROMMON

For the IPS 4240, IPS 4255, IPS 4345, IPS 4360, IPS 4510, and IPS 4520, you can use the ROMMON to recover the password. To access the ROMMON CLI, reboot the sensor from a terminal server or direct connection and interrupt the boot process.



Note

After recovering the password, you must reset the confreg to **0**, otherwise, when you try to upgrade the sensor, the upgrade fails because when the sensor reboots, it goes to password recovery (**confreg 0x7**) rather than to the upgrade option.

To recover the password using the ROMMON CLI, follow these steps:

- Step 1** Reboot the appliance.
- Step 2** To interrupt the boot process, press **ESC** or **Control-R** (terminal server) or send a **BREAK** command (direct connection). The boot code either pauses for 10 seconds or displays something similar to one of the following:

- Evaluating boot options
- Use BREAK or ESC to interrupt boot

- Step 3** Enter the following commands to reset the password:

```
confreg 0x7
boot
```

Sample ROMMON session:

```
Booting system, please wait...
CISCO SYSTEMS
Embedded BIOS Version 1.0(11)2 01/25/06 13:21:26.17
...
Evaluating BIOS Options...
Launch BIOS Extension to setup ROMMON
Cisco Systems ROMMON Version (1.0(11)2) #0: Thu Jan 26 10:43:08 PST 2006
Platform IPS-4360-K9
Use BREAK or ESC to interrupt boot.
Use SPACE to begin boot immediately.
Boot interrupted.
Management0/0
Link is UP
MAC Address:000b.fcfa.d155
Use ? for help.
rommon #0> confreg 0x7
Update Config Register (0x7) in NVRAM...
rommon #1> boot
```

- Step 4** Enter the following command to reset the confreg value to 0:

```
confreg 0
```

Recovering the Password for the ASA 5500 AIP SSM



Note

To reset the password, you must have ASA 7.2.2 or later.

You can reset the password to the default (**cisco**) for the ASA 5500 AIP SSM using the CLI or the ASDM. Resetting the password causes it to reboot. IPS services are not available during a reboot.

Use the **hw-module module slot_number password-reset** command to reset the password to the default **cisco**. If the module in the specified slot has an IPS version that does not support password recovery, the following error message is displayed:

```
ERROR: the module in slot <n> does not support password recovery.
```

Resetting the Password Using the CLI

To reset the password on the ASA 5500 AIP SSM, follow these steps:

- Step 1** Log into the adaptive security appliance and enter the following command to verify the module slot number:

```
asa# show module
```

Mod	Card	Type	Model	Serial No.
0	ASA	5510 Adaptive Security Appliance	ASA5510	JMX1135L097
1	ASA	5500 Series Security Services Module-40	ASA-SSM-40	JAF1214AMRL

Mod	MAC	Address Range	Hw Version	Fw Version	Sw Version
0	001b.d5e8.e0c8	to 001b.d5e8.e0cc	2.0	1.0(11)2	8.4(3)
1	001e.f737.205f	to 001e.f737.205f	1.0	1.0(14)5	7.0(7)E4

Mod	SSM Application Name	Status	SSM Application Version
1	IPS	Up	7.0(7)E4

Mod	Status	Data Plane Status	Compatibility
0	Up Sys	Not Applicable	
1	Up	Up	

- Step 2** Reset the password for module 1.

```
asa# hw-module module 1 password-reset
Reset the password on module in slot 1? [confirm]
```

- Step 3** Press **Enter** to confirm.

```
Password-Reset issued for slot 1.
```

- Step 4** Verify the status of the module. Once the status reads Up, you can session to the ASA 5500 AIP SSM.

```
asa# show module 1
```

Mod	Card	Type	Model	Serial No.
1	ASA	5500 Series Security Services Module-40	ASA-SSM-40	JAF1214AMRL

Mod	MAC	Address Range	Hw Version	Fw Version	Sw Version
1	001e.f737.205f	to 001e.f737.205f	1.0	1.0(14)5	7.0(7)E4

Mod	SSM Application Name	Status	SSM Application Version
1	IPS	Up	7.0(7)E4

```

-----
 1 IPS                               Up                               7.0(7)E4

Mod Status           Data Plane Status       Compatibility
-----
 1 Up                Up

```

Step 5 Session to the ASA 5500 AIP SSM.

```
asa# session 1
Opening command session with slot 1.
Connected to slot 1. Escape character sequence is 'CTRL-^X'.
```

Step 6 Enter the default username (**cisco**) and password (**cisco**) at the login prompt.

```
login: cisco
Password: cisco
```

```
You are required to change your password immediately (password aged)
Changing password for cisco.
(current) password: cisco
```

Step 7 Enter your new password twice.

```
New password: new password
Retype new password: new password
```

```
***NOTICE***
```

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at:
<http://www.cisco.com/wwl/export/crypto/tool/stqrg.html>

If you require further assistance please contact us by sending email to export@cisco.com.

```
***LICENSE NOTICE***
```

There is no license key installed on this IPS platform. The system will continue to operate with the currently installed signature set. A valid license must be obtained in order to apply signature updates. Please go to <http://www.cisco.com/go/license> to obtain a new license or install a license.

```
aip_ssm#
```

Using the ASDM

To reset the password in the ASDM, follow these steps:

Step 1 From the ASDM menu bar, choose **Tools > IPS Password Reset**.

Note This option does not appear in the menu if there is no IPS present.

- Step 2** In the IPS Password Reset confirmation dialog box, click **OK** to reset the password to the default (**cisco**). A dialog box displays the success or failure of the password reset. If the reset fails, make sure you have the correct ASA and IPS software versions.
- Step 3** Click **Close** to close the dialog box. The sensor reboots.

Recovering the Password for the ASA 5500-X IPS SSP

You can reset the password to the default (**cisco**) for the ASA 5500-X IPS SSP using the CLI or the ASDM. Resetting the password causes it to reboot. IPS services are not available during a reboot.



Note

To reset the password, you must have ASA 8.6.1 or later.

Use the **sw-module module ips password-reset** command to reset the password to the default **cisco**. If the module in the specified slot has an IPS version that does not support password recovery, the following error message is displayed:

```
ERROR: the module in slot <n> does not support password recovery.
```

To reset the password on the ASA 5500-X IPS SSP, follow these steps:

- Step 1** Log into the adaptive security appliance and enter the following command:
- ```
asa# sw-module module ips password-reset
Reset the password on module ips? [confirm]
```
- Step 2** Press **Enter** to confirm.
- ```
Password-Reset issued for module ips.
```
- Step 3** Verify the status of the module. Once the status reads **Up**, you can session to the ASA 5500-X IPS SSP.

```
asa# show module ips
Mod Card Type                               Model                Serial No.
---
ips ASA 5555-X IPS Security Services Processor ASA5555-IPS         FCH151070GR

Mod MAC Address Range                      Hw Version   Fw Version   Sw Version
---
ips 503d.e59c.7c4c to 503d.e59c.7c4c  N/A          N/A          7.1(4)E4

Mod SSM Application Name                    Status        SSM Application Version
---
ips IPS                                    Up            7.1(4)E4

Mod Status      Data Plane Status  Compatibility
---
ips Up          Up

Mod License Name  License Status  Time Remaining
---
ips IPS Module    Enabled         210 days
```

- Step 4** Session to the ASA 5500-X IPS SSP.

```
asa# session ips
Opening command session with module ips.
```

Connected to module ips. Escape character sequence is 'CTRL-^X'.

- Step 5** Enter the default username (**cisco**) and password (**cisco**) at the login prompt.

```
login: cisco
Password: cisco
```

```
You are required to change your password immediately (password aged)
Changing password for cisco.
(current) password: cisco
```

- Step 6** Enter your new password twice.

```
New password: new password
Retype new password: new password
```

NOTICE

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at:
<http://www.cisco.com/wwl/export/crypto/tool/stqrg.html>

If you require further assistance please contact us by sending email to export@cisco.com.

LICENSE NOTICE

There is no license key installed on this IPS platform. The system will continue to operate with the currently installed signature set. A valid license must be obtained in order to apply signature updates. Please go to <http://www.cisco.com/go/license> to obtain a new license or install a license.

```
asa-ssp#
```

Using the ASDM

To reset the password in the ASDM, follow these steps:

- Step 1** From the ASDM menu bar, choose **Tools > IPS Password Reset**.



Note This option does not appear in the menu if there is no IPS present.

- Step 2** In the IPS Password Reset confirmation dialog box, click **OK** to reset the password to the default (**cisco**). A dialog box displays the success or failure of the password reset. If the reset fails, make sure you have the correct ASA and IPS software versions.

- Step 3** Click **Close** to close the dialog box. The sensor reboots.
-

Recovering the Password for the ASA 5585-X IPS SSP



Note

To reset the password, you must have ASA 8.2.(4.4) or later or ASA 8.4.2 or later. The ASA 5585-X IPS SSP is not supported in ASA 8.3(x).

You can reset the password to the default (**cisco**) for the ASA 5585-X IPS SSP using the CLI or the ASDM. Resetting the password causes it to reboot. IPS services are not available during a reboot.

Use the **hw-module module slot_number password-reset** command to reset the password to the default **cisco**. If the module in the specified slot has an IPS version that does not support password recovery, the following error message is displayed:

```
ERROR: the module in slot <n> does not support password recovery.
```

To reset the password on the ASA 5585-X IPS SSP, follow these steps:

Step 1 Log into the adaptive security appliance and enter the following command:

```
asa# hw-module module 1 password-reset
Reset the password on module in slot 1? [confirm]
```

Step 2 Press **Enter** to confirm.

```
Password-Reset issued for slot 1.
```

Step 3 Verify the status of the module. Once the status reads **Up**, you can session to the ASA 5585-X IPS SSP.

```
asa# show module 1
```

Mod	Card	Type	Model	Serial No.
1	ASA 5585-X IPS Security Services Processor-4	ASA5585-SSP-IPS40	JAF1436ABSG	

Mod	MAC Address Range	Hw Version	Fw Version	Sw Version
1	5475.d029.8c74 to 5475.d029.8c7f	0.1	2.0(12)3	7.1(4)E4

Mod	SSM Application Name	Status	SSM Application Version
1	IPS	Up	7.1(4)E4

Mod	Status	Data Plane Status	Compatibility
1	Up	Up	

Step 4 Session to the ASA 5585-X IPS SSP.

```
asa# session 1
Opening command session with slot 1.
Connected to slot 1. Escape character sequence is 'CTRL-^X'.
```

Step 5 Enter the default username (**cisco**) and password (**cisco**) at the login prompt.

```
login: cisco
Password: cisco
```

```
You are required to change your password immediately (password aged)
Changing password for cisco.
(current) password: cisco
```

Step 6 Enter your new password twice.

New password: **new password**
 Retype new password: **new password**

*****NOTICE*****

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at:
<http://www.cisco.com/wwl/export/crypto/tool/stqrg.html>

If you require further assistance please contact us by sending email to export@cisco.com.

*****LICENSE NOTICE*****

There is no license key installed on this IPS platform. The system will continue to operate with the currently installed signature set. A valid license must be obtained in order to apply signature updates. Please go to <http://www.cisco.com/go/license> to obtain a new license or install a license.
 ips_ssp#

Using the ASDM

To reset the password in the ASDM, follow these steps:

Step 1 From the ASDM menu bar, choose **Tools > IPS Password Reset**.

Note This option does not appear in the menu if there is no IPS present.

Step 2 In the IPS Password Reset confirmation dialog box, click **OK** to reset the password to the default (**cisco**). A dialog box displays the success or failure of the password reset. If the reset fails, make sure you have the correct ASA and IPS software versions.**Step 3** Click **Close** to close the dialog box. The sensor reboots.

Disabling Password Recovery

**Caution**

If you try to recover the password on a sensor on which password recovery is disabled, the process proceeds with no errors or warnings; however, the password is not reset. If you cannot log in to the sensor because you have forgotten the password, and password recovery is set to disabled, you must reimaged your sensor.

Password recovery is enabled by default. You can disable password recovery through the CLI, IDM, or IME.

Disabling Password Recovery Using the CLI

To disable password recovery in the CLI, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter global configuration mode.

```
sensor# configure terminal
```

Step 3 Enter host mode.

```
sensor(config)# service host
```

Step 4 Disable password recovery.

```
sensor(config-hos)# password-recovery disallowed
```

Disabling Password Recovery Using the IDM or IME

To disable password recovery in the IDM or IME, follow these steps:

Step 1 Log in to the IDM or IME using an account with administrator privileges.

Step 2 Choose **Configuration > sensor_name > Sensor Setup > Network**.

Step 3 To disable password recovery, uncheck the **Allow Password Recovery** check box.

Verifying the State of Password Recovery

Use the **show settings | include password** command to verify whether password recovery is enabled. To verify whether password recovery is enabled, follow these steps:

Step 1 Log in to the CLI.

Step 2 Enter service host submode.

```
sensor# configure terminal
sensor (config)# service host
sensor (config-hos)#
```

Step 3 Verify the state of password recovery by using the **include** keyword to show settings in a filtered output.

```
sensor(config-hos)# show settings | include password
password-recovery: allowed <defaulted>
sensor(config-hos)#
```

Troubleshooting Password Recovery

When you troubleshoot password recovery, pay attention to the following:

- You cannot determine whether password recovery has been disabled in the sensor configuration from the ROMMON prompt, GRUB menu, switch CLI, or router CLI. If you attempt password recovery, it always appears to succeed. If it has been disabled, the password is not reset to **cisco**. The only option is to reimage the sensor.
- You can disable password recovery in the host configuration. For the platforms that use external mechanisms, such as ROMMON, although you can run commands to clear the password, if password recovery is disabled in the IPS, the IPS detects that password recovery is not allowed and rejects the external request.
- To check the state of password recovery, use the **show settings | include password** command.

Clearing the Sensor Databases



Caution

We do not recommend that you use **clear database** command unless under the direction of the TAC or in some testing conditions when you need to clear accumulated state information and start with a clean database.

Use the **clear database** [*virtual-sensor*] **all** | **nodes** | **alerts** | **inspectors** command in privileged EXEC mode to clear specific parts of the sensor database. The **clear database** command is useful for troubleshooting and testing. The following options apply:

- *virtual-sensor*—Specifies the name of a virtual sensor configured on the sensor.
- **all**— Clears all nodes, inspectors, and alerts databases.



Caution

This command causes summary alerts to be discarded.

- **nodes**—Clears the overall packet database elements, including the packet nodes, TCP session information, and inspector lists.
- **alerts**—Clears the alert database including the alerts nodes, Meta inspector information, summary state, and event count structures.
- **inspectors**—Clears the inspector lists in the nodes. Inspector lists represent the packet work and observations collected during the time the sensor is running.

Clearing the Sensor Database

To clear the sensor database, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Clear the entire sensor database.

```
sensor# clear database all
Warning: Executing this command will delete database on all virtual sensors
Continue? [yes]:
```

Step 3 Enter **yes** to clear all the databases on the sensor.

Step 4 Clear the packet nodes.

```
sensor# clear database nodes
Warning: Executing this command will delete database on all virtual sensors
Continue? [yes]:
```

Step 5 Enter **yes** to clear the packet nodes database.

Step 6 Clear the alerts database on a specific virtual sensor.

```
sensor# clear database vs0 alerts
Warning: Executing this command will delete database on all virtual sensors
Continue? [yes]:
```

Step 7 Enter **yes** to clear the alerts database.

Step 8 Clear inspector lists on the sensor.

```
sensor# clear database inspectors
Warning: Executing this command will delete database on all virtual sensors
Continue? [yes]:
```

Step 9 Enter **yes** to clear the inspectors database.

Displaying the Inspection Load of the Sensor

Use the **show inspection-load** command in privileged EXEC mode to display a timestamp and the current inspection load of the sensor. Use the **history** option to display a histogram of the inspection load over the past 60 minutes and over the past 72 hours.

Use this command to determine the load on the sensor instead of the CPU Usage information from the **show statistics host** command. The inspection load is a more accurate representation of the processing level of the sensor. The calculation of the inspection load has also been enhanced to provide a more accurate calculation of the sensor load at lower traffic levels.



Note

The Processing Load category in the **show statistics virtual-sensor** output has been renamed to Inspection Load and shows the same value seen in the **show inspection load** command.



Note

The **show inspection-load** command is not currently supported for the IPS 4500 series sensors.

To display the inspection load of the sensor, follow these steps:

Step 1 Log in to the CLI.

Step 2 Show the current inspection load with a timestamp of the sensor.

```
sensor# show inspection-load

sensor 08:18:13 PM Friday Jan 15 2011 UTC

Inspection Load Percentage = 1
```

Step 3 Show the histogram of the inspection load:

```
sensor# show inspection-load history
```

■ Displaying the Inspection Load of the Sensor

```
sensor 15:36:42 UTC Mon Jan 30 2012
```

```
sensor 08:18:13 PM Friday Jan 15 2011 UTC
```

```
Inspection Load Percentage = 65
```

```

100
90
80
70 * *
60 * * *** * ***** ** * * * * * * * * * *
50 * * *** * ***** ** * * * * * * * * * *
40 * * *** ***** * * * * * * * * * *
30 *****
20 *****
10 *****
0.....1.....2.....3.....4.....5.....6

```

```
Inspection Load Percentage (last 6 minutes at 10 second intervals)
```

```

100
90
80
70
60 * * *** * ***** ** * * * * * * * * * *
50 * * *** * ***** ** * * * * * * * * * *
40 * * *** *****###***** * * * * * * * * * *
30 #####*#####*#####*#####*#####*#####*#####
20 #####
10 #####
0...5...1...1...2...2...3...3...4...4...5...5...6
      0      5      0      5      0      5      0      5      0      5      0

```

```
Inspection Load Percentage (last 60 minutes) *=maximum #=average
```



```

100
90
80
70
60 * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
50 * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
40 * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
30 * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
20 * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
10 * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
0...5...1...1...2...2...3...3...4...4...5...5...6...6...7...
      0      5      0      5      0      5      0      5      0      5      0      5      0

```

Inspection Load Percentage (last 72 hours) *=maximum #=average
sensor#

Configuring Health Status Information

Configure the health statistics for the sensor in service health monitor submode. Use the **show health** command to see the results. The health status categories are rated by red and green with red being critical. The following options apply:

- **application-failure-policy {enable | disable} {true | false} status {green | yellow | red}**—Lets you choose to have an application failure applied to the overall sensor health rating.
- **bypass-policy {enable | disable} {true | false} status {green | yellow | red}**—Lets you choose to know if bypass mode is active and have that apply to the overall sensor health rating.



Note

The ASA 5500-X IPS SSP and the ASA 5585-X IPS SSP do not support bypass mode. The adaptive security appliance will either fail open, fail close, or fail over depending on the configuration of the adaptive security appliance and the type of activity being done on the IPS.

- **enable-monitoring {true | false}**—Lets you choose to monitor sensor health and security.
- **event-retrieval-policy {enable | disable} {true | false} red-threshold yellow-threshold seconds**—Lets you set a threshold for when the last event was retrieved and have that apply to the overall sensor health rating. The health status is degraded to red or yellow when that threshold is met. The range for the threshold is 0 to 4294967295 seconds.

**Note**

The event retrieval metric keeps track of when the last event was retrieved by an external monitoring application such as the IME. Disable **event retrieval policy** if you are not doing external event monitoring.

- **global-correlation-policy {enable | disable} {true | false}**—Lets you apply this metric to the overall sensor health rating.
- **heartbeat-events {enable | disable} seconds**—Lets you enable heartbeat events to be emitted at the specified interval in seconds and have that apply to the overall sensor health rating. The range for the interval is 15 to 86400 seconds.
- **inspection-load-policy {enable | disable} {true | false} red-threshold yellow-threshold seconds**—Lets you set the threshold for inspection load. The health status is degraded to red or yellow when that threshold is met. The range is 0 to 100.
- **interface-down-policy {enable | disable} {true | false} status {green | yellow | red}**—Lets you choose to know if one or more enabled interfaces are down and have that apply to the overall sensor health rating.
- **license-expiration-policy {enable | disable} {true | false} red-threshold yellow-threshold**—Lets you set a threshold for when the license expires and whether this metric is applied to the overall sensor health rating. The range for the threshold is 0 to 4294967295 seconds.
- **memory-usage-policy {enable | disable} {true | false} red-threshold yellow-threshold**—Lets you set a threshold percentage for memory usage and whether this metric is applied to the overall sensor health rating. The range is 0 to 100. The default for red is 91% and the default for yellow is 80%.
- **missed-packet-policy {enable | disable} {true | false} red-threshold yellow-threshold**—Lets you set a threshold percentage for missed packets and whether this metric is applied to the overall sensor health rating.
- **network-participation-policy {enable | disable} {true | false}**—Lets you apply this metric to the overall sensor health rating.
- **persist-security-status**—Lets you set the number of minutes that a lower security persists following the occurrence of the latest event to lower the security status.
- **signature-update-policy {enable | disable} {true | false} red-threshold yellow-threshold**—Lets you set a threshold for the number of days elapsed since the last signature update and whether this metric is applied to the overall sensor health rating. The range for the threshold is 0 to 4294967295 seconds

ASA 5500-X IPS SSP and Memory Usage

For the ASA 5500-X IPS SSP, the memory usage is 93%. The default health thresholds for the sensor are 80% for yellow and 91% for red, so the sensor health will be shown as red on these platforms even for normal operating conditions. You can tune the threshold percentage for memory usage so that it reads more accurately for these platforms by configuring the **memory-usage-policy** option in the sensor health metrics.

**Note**

Make sure you have the **memory-usage-policy** option in the sensor health metrics enabled.

Table 17-2 lists the yellow-threshold health values.

Table 17-2 ASA 5500-X IPS SSP Memory Usage Values

Platform	Yellow	Red	Memory Used
ASA 5512-X IPS SSP	85%	91%	28%
ASA 5515-X IPS SSP	88%	92%	14%
ASA 5525-X IPS SSP	88%	92%	14%
ASA 5545-X IPS SSP	93%	96%	13%
ASA 5555-X IPS SSP	95%	98%	17%

Configuring Health Statistics

To configure the health statistics for the sensor, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter service health monitor submode.

```
sensor# configure terminal
sensor(config)# service health-monitor
sensor(config-hea)#
```

Step 3 Enable the metrics for application failure status.

```
sensor(config-hea)# application-failure-policy
sensor(config-hea-app)# enable true
sensor(config-hea-app)# status red
sensor(config-hea-app)# exit
sensor(config-hea)#
```

Step 4 Enable the metrics for bypass policy.

```
sensor(config-hea)# bypass-policy
sensor(config-hea-byp)# enable true
sensor(config-hea-byp)# status yellow
sensor(config-hea-byp)# exit
sensor(config-hea)#
```

Step 5 Enable the metrics for sensor health and security monitoring.

```
sensor(config-hea)# enable-monitoring true
sensor(config-hea)#
```

Step 6 Set the event retrieval thresholds for event retrieval metrics.

```
sensor(config-hea)# event-retrieval-policy
sensor(config-hea-eve)# enable true
sensor(config-hea-eve)# red-threshold 100000
sensor(config-hea-eve)# yellow-threshold 100
sensor(config-hea-eve)# exit
sensor(config-hea)#
```

Step 7 Enable health metrics for global correlation.

```
sensor(config-hea)# global-correlation-policy
sensor(config-hea-glo)# enable true
sensor(config-hea-glo)# exit
sensor(config-hea)#
```

Step 8 Enable the metrics for heartbeat events to be emitted at the specified interval of seconds.

```
sensor(config-hea)# heartbeat-events enable 20000
sensor(config-hea)#
```

Step 9 Set the inspection load threshold.

```
sensor(config-hea)# inspection-load-policy
sensor(config-hea-ins)# enable true
sensor(config-hea-ins)# red-threshold 100
sensor(config-hea-ins)# yellow-threshold 50
sensor(config-hea-ins)# exit
sensor(config-hea)#
```

Step 10 Enable the interface down policy.

```
sensor(config-hea)# interface-down-policy
```

```

sensor(config-hea-int)# enable true
sensor(config-hea-int)# status yellow
sensor(config-hea-int)# exit
sensor(config-hea)#

```

Step 11 Set the number of days until the license expires.

```

sensor(config-hea)# license-expiration-policy
sensor(config-hea-lic)# enable true
sensor(config-hea-lic)# red-threshold 400000
sensor(config-hea-lic)# yellow-threshold 200000
sensor(config-hea-lic)# exit
sensor(config-hea)#

```

Step 12 Set the threshold for memory usage.

```

sensor(config-hea)# memory-usage-policy
sensor(config-hea-mem)# enable true
sensor(config-hea-mem)# red-threshold 100
sensor(config-hea-mem)# yellow-threshold 50
sensor(config-hea-mem)# exit
sensor(config-hea)#

```

Step 13 Set the missed packet threshold.

```

sensor(config-hea)# missed-packet-policy
sensor(config-hea-mis)# enable true
sensor(config-hea-mis)# red-threshold 50
sensor(config-hea-mis)# yellow-threshold 20
sensor(config-hea-mis)# exit
sensor(config-hea)#

```

Step 14 Set the number of minutes that a lower security persists following the occurrence of the latest event to lower the security status.

```

sensor(config-hea)# persist-security-status 10
sensor(config-hea)#

```

Step 15 Set the number of days since the last signature update.

```

sensor(config-hea)# signature-update-policy
sensor(config-hea-sig)# enable true
sensor(config-hea-sig)# red-threshold 30000
sensor(config-hea-sig)# yellow-threshold 10000
sensor(config-hea-sig)# exit
sensor(config-hea)#

```

Step 16 Verify your settings.

```

sensor(config-hea)# show settings
  enable-monitoring: true default: true
  persist-security-status: 10 minutes default: 5
  heartbeat-events
  -----
    enable: 20000 seconds default: 300
  -----
  application-failure-policy
  -----
    enable: true default: true
    status: red default: red
  -----
  bypass-policy
  -----
    enable: true default: true
    status: yellow default: red

```

```

-----
interface-down-policy
-----
    enable: true default: true
    status: yellow default: red
-----

inspection-load-policy
-----
    enable: true default: true
    yellow-threshold: 50 percent default: 80
    red-threshold: 100 percent default: 91
-----

missed-packet-policy
-----
    enable: true default: true
    yellow-threshold: 20 percent default: 1
    red-threshold: 50 percent default: 6
-----

memory-usage-policy
-----
    enable: true default: false
    yellow-threshold: 50 percent default: 80
    red-threshold: 100 percent default: 91
-----

signature-update-policy
-----
    enable: true default: true
    yellow-threshold: 10000 days default: 30
    red-threshold: 30000 days default: 60
-----

license-expiration-policy
-----
    enable: true default: true
    yellow-threshold: 200000 days default: 30
    red-threshold: 400000 days default: 0
-----

event-retrieval-policy
-----
    enable: true <defaulted>
    yellow-threshold: 100000 seconds default: 300
    red-threshold: 100 seconds default: 600
-----

sensor(config-hea)#

```

Step 17 Exit health monitoring submode.

```

sensor(config-hea)# exit
Apply Changes:[yes]:

```

Step 18 Press **Enter** to apply the changes or enter **no** to discard them.

Showing Sensor Overall Health Status



Caution

When the sensor is first starting, it is normal for certain health metric statuses to be red until the sensor is fully up and running.

**Note**

The ASA 5500-X IPS SSP and the ASA 5585-X IPS SSP do not support bypass mode. The adaptive security appliance will either fail open, fail close, or fail over depending on the configuration of the adaptive security appliance and the type of activity being done on the IPS.

Use the **show health** command in privileged EXEC mode to display the overall health status information of the sensor. The health status categories are rated by red and green with red being critical. To display the overall health status of the sensor, follow these steps:

Step 1 Log in to the CLI.

Step 2 Show the health and security status of the sensor.

```
sensor# show health
Overall Health Status                      Red
Health Status for Failed Applications      Green
Health Status for Signature Updates        Green
Health Status for License Key Expiration   Red
Health Status for Running in Bypass Mode   Green
Health Status for Interfaces Being Down    Red
Health Status for the Inspection Load     Green
Health Status for the Time Since Last Event Retrieval Green
Health Status for the Number of Missed Packets Green
Health Status for the Memory Usage         Not Enabled
Health Status for Global Correlation       Red
Health Status for Network Participation    Not Enabled

Security Status for Virtual Sensor vs0     Green
sensor#
```

Creating a Banner Login

Use the **banner login** command to create a banner login that will be displayed before the user and password login prompts. The maximum message length is 2500 characters. Use the **no banner login** command to remove the banner. To create a banner login, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter global configuration mode.

```
sensor# configure terminal
```

Step 3 Create the banner login.

```
sensor(config)# banner login
Banner[ ]:
```

Step 4 Enter your message.

```
Banner[ ]: This message will be displayed on banner login. ^M Thank you
sensor(config)#
```

**Note**

To use a ? or a carriage return in the message, press **Ctrl-V-?** or **Ctrl-V-Enter**. They are represented by ^M.

Example

```
This message will be displayed on login.
Thank you
login: cisco
Password:****
```

- Step 5** Remove the banner login. The banner no longer appears at login.

```
sensor(config)# no banner login
```

Terminating CLI Sessions

**Caution**

You can only clear CLI login sessions with the **clear line** command. You cannot clear service logins with this command.

Use the **clear line** *cli_id* [**message**] command to terminate another CLI session. If you use the **message** keyword, you can send a message along with the termination request to the receiving user. The maximum message length is 2500 characters. The following options apply:

- **cli_id**—Specifies the CLI ID number associated with the login session. Use the **show users** command to find the CLI ID number.
- **message**—Specifies the message to send to the receiving user.

If an administrator tries to log in when the maximum sessions have been reached, the following message appears:

```
Error: The maximum allowed CLI sessions are currently open, would you like to terminate
one of the open sessions? [no]
```

If an operator or viewer tries to log in when the maximum sessions are open, the following message appears:

```
Error: The maximum allowed CLI sessions are currently open, please try again later.
```

To terminate a CLI session, follow these steps:

- Step 1** Log in to the CLI using an account with administrator privileges.

**Note**

Operator and viewer can only clear lines with the same username as the current login.

- Step 2** Find the CLI ID number associated with the login session.

```
sensor# show users
      CLI ID  User      Privilege
*    13533   jtaylor  administrator
      15689   jsmith   operator
      20098   viewer   viewer
```


Step 3 Terminate the CLI session of jsmith.

```
sensor# clear line cli_id message
Message[]:
```

Example

```
sensor# clear line 15689 message
Message(): Sorry! I need to terminate your session.
sensor#
```

The user jsmith receives the following message from the administrator jtaylor.

```
sensor#
***
***
*** Termination request from jtaylor
***
Sorry! I need to terminate your session.
```

Modifying Terminal Properties



Note

You are not required to specify the screen length for some types of terminal sessions because the specified screen length can be learned by some remote hosts.

Use the **terminal [length] screen _length** command to modify terminal properties for a login session. The *screen_length* option lets you set the number of lines that appear on the screen before the `--more--` prompt is displayed. A value of zero results in no pause in the output. The default value is 24 lines.

To modify the terminal properties, follow these steps:

Step 1 Log in to the CLI.

Step 2 To have no pause between multi-screen outputs, use 0 for the screen length value.

```
sensor# terminal length 0
```



Note

The screen length values are not saved between login sessions.

Step 3 To have the CLI pause and display the `--more--` prompt every 10 lines, use 10 for the *screen length* value.

```
sensor# terminal length 10
```

Configuring Events

This section describes how to display and clear events from the Event Store, and contains the following topics:

- [Displaying Events, page 17-24](#)
- [Clearing Events from the Event Store, page 17-27](#)

Displaying Events



Note

The Event Store has a fixed size of 30 MB for all platforms.



Note

Events are displayed as a live feed. To cancel the request, press **Ctrl-C**.

Use the **show events** [{**alert** [informational] [low] [medium] [high] [**include-traits** *traits*] [**exclude-traits** *traits*] [**min-threat-rating** *min-rr*] [**max-threat-rating** *max-rr*] | **error** [warning] [error] [fatal] | **NAC** | **status**}] [*hh:mm:ss* [*month* *day* [*year*]]] | **past** *hh:mm:ss*] command to display events from Event Store. Events are displayed beginning at the start time. If you do not specify a start time, events are displayed beginning at the current time. If you do not specify an event type, all events are displayed. The following options apply:

- **alert**—Displays alerts. Provides notification of some suspicious activity that may indicate an attack is in process or has been attempted. Alert events are generated by the Analysis Engine whenever a signature is triggered by network activity. If no level is selected (informational, low, medium, or high), all alert events are displayed.
- **include-traits**—Displays alerts that have the specified traits.
- **exclude-traits**—Does not display alerts that have the specified traits.
- **traits**—Specifies the trait bit position in decimal (0 to 15).
- **min-threat-rating**—Displays events with a threat rating above or equal to this value. The default is 0. The valid range is 0 to 100.
- **max-threat-rating**—Displays events with a threat rating below or equal to this value. The default is 100. The valid range is 0 to 100.
- **error**—Displays error events. Error events are generated by services when error conditions are encountered. If no level is selected (warning, error, or fatal), all error events are displayed.
- **NAC**—Displays the ARC (block) requests.



Note

The ARC is formerly known as NAC. This name change has not been completely implemented throughout the IDM, the IME, and the CLI for Cisco IPS 7.1.

- **status**—Displays status events.
- **past**—Displays events starting in the past for the specified hours, minutes, and seconds.
- *hh:mm:ss*—Specifies the hours, minutes, and seconds in the past to begin the display.

**Note**

The **show events** command continues to display events until a specified event is available. To exit, press **Ctrl-C**.

Displaying Events

To display events from the Event Store, follow these steps:

Step 1 Log in to the CLI.

Step 2 Display all events starting now. The feed continues showing all events until you press **Ctrl-C**.

```
sensor# show events
evError: eventId=1041472274774840147 severity=warning vendor=Cisco
  originator:
    hostId: sensor2
    appName: cidwebserver
    appInstanceId: 12075
  time: 2011/01/07 04:41:45 2011/01/07 04:41:45 UTC
  errorMessage: name=errWarning received fatal alert: certificate_unknown

evError: eventId=1041472274774840148 severity=error vendor=Cisco
  originator:
    hostId: sensor2
    appName: cidwebserver
    appInstanceId: 351
  time: 2011/01/07 04:41:45 2011/01/07 04:41:45 UTC
  errorMessage: name=errTransport WebSession::sessionTask(6) TLS connection exception:
  handshake incomplete.
```

Step 3 Display the block requests beginning at 10:00 a.m. on February 9, 2011.

```
sensor# show events NAC 10:00:00 Feb 9 2011
evShunRqst: eventId=1106837332219222281 vendor=Cisco
  originator:
    deviceName: Sensor1
    appName: NetworkAccessControllerApp
    appInstance: 654
  time: 2011/02/09 10:33:31 2011/08/09 13:13:31
  shunInfo:
    host: connectionShun=false
    srcAddr: 11.0.0.1
    destAddr:
    srcPort:
    destPort:
    protocol: numericType=0 other
    timeoutMinutes: 40
  evAlertRef: hostId=esendHost 123456789012345678
sensor#
```

Step 4 Display errors with the warning level starting at 10:00 a.m. on February 9, 2011.

```
sensor# show events error warning 10:00:00 Feb 9 2011
evError: eventId=1041472274774840197 severity=warning vendor=Cisco
  originator:
    hostId: sensor
    appName: cidwebserver
    appInstanceId: 12160
  time: 2011/01/07 04:49:25 2011/01/07 04:49:25 UTC
  errorMessage: name=errWarning received fatal alert: certificate_unknown
```

Step 5 Display alerts from the past 45 seconds.

```
sensor# show events alert past 00:00:45
```

```
evIdsAlert: eventId=1109695939102805307 severity=medium vendor=Cisco
  originator:
    hostId: sensor
    appName: sensorApp
    appInstanceId: 367
  time: 2011/03/02 14:15:59 2011/03/02 14:15:59 UTC
  signature: description=Nachi Worm ICMP Echo Request id=2156 version=S54
    subsigId: 0
    sigDetails: Nachi ICMP
  interfaceGroup:
  vlan: 0
  participants:
    attacker:
      addr: locality=OUT 10.89.228.202
    target:
      addr: locality=OUT 10.89.150.185
  riskRatingValue: 70
  interface: fe0_1
  protocol: icmp
```

```
evIdsAlert: eventId=1109695939102805308 severity=medium vendor=Cisco
  originator:
--MORE--
```

Step 6 Display events that began 30 seconds in the past.

```
sensor# show events past 00:00:30
```

```
evStatus: eventId=1041526834774829055 vendor=Cisco
  originator:
    hostId: sensor
    appName: mainApp
    appInstanceId: 2215
  time: 2011/01/08 02:41:00 2011/01/08 02:41:00 UTC
  controlTransaction: command=getVersion successful=true
  description: Control transaction response.
  requestor:
    user: cids
    application:
      hostId: 64.101.182.101
      appName: -cidcli
      appInstanceId: 2316
```

```
evStatus: eventId=1041526834774829056 vendor=Cisco
  originator:
    hostId: sensor
    appName: login(pam_unix)
    appInstanceId: 2315
  time: 2011/01/08 02:41:00 2011/01/08 02:41:00 UTC
  syslogMessage:
    description: session opened for user cisco by cisco(uid=0)
```

Clearing Events from the Event Store

Use the **clear events** command to clear the Event Store. To clear events from the Event Store, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Clear the Event Store.

```
sensor# clear events
```

```
Warning: Executing this command will remove all events currently stored in the event store.
```

```
Continue with clear? []:
```

Step 3 Enter **yes** to clear the events.

Configuring the System Clock

This section explains how to display and manually set the system clock. It contains the following topics:

- [Displaying the System Clock, page 17-27](#)
- [Manually Setting the System Clock, page 17-28](#)

Displaying the System Clock

Use the **show clock [detail]** command to display the system clock. You can use the **detail** option to indicate the clock source (NTP or system) and the current summertime setting (if any). The system clock keeps an authoritative flag that indicates whether the time is authoritative (believed to be accurate). If the system clock has been set by a timing source, such as NTP, the flag is set.

[Table 17-3](#) lists the system clock flags.

Table 17-3 System Clock Flags

Symbol	Description
*	Time is not authoritative.
(blank)	Time is authoritative.
.	Time is authoritative, but NTP is not synchronized.

To display the system clock, follow these steps:

Step 1 Log in to the CLI.

Step 2 Display the system clock.

```
sensor# show clock
```

```
*19:04:52 UTC Thu Apr 03 2008
```

- Step 3** Display the system clock with details. The following example indicates that the sensor is getting its time from NTP and that is configured and synchronized.

```
sensor# show clock detail
20:09:43 UTC Thu Apr 03 2011
Time source is NTP
Summer time starts 03:00:00 UTC Sun Mar 09 2011
Summer time stops 01:00:00 UTC Sun Nov 02 2011
```

- Step 4** Display the system clock with details. The following example indicates that no time source is configured.

```
sensor# show clock detail
*20:09:43 UTC Thu Apr 03 2011
No time source
Summer time starts 03:00:00 UTC Sun Mar 09 2011
Summer time stops 01:00:00 UTC Sun Nov 02 2011
```

Manually Setting the System Clock



Note

You do not need to set the system clock if your sensor is synchronized by a valid outside timing mechanism such as an NTP clock source.

Use the **clock set** *hh:mm [:ss] month day year* command to manually set the clock on the appliance. Use this command if no other time sources are available. The **clock set** command does not apply to the following platforms, because they get their time from the adaptive security appliance in which they are installed:

- ASA 5500 AIP SSM
- ASA 5500-X IPS SSP
- ASA 5585-X IPS SSP

To manually set the clock on the appliance, follow these steps:

- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Set the clock manually.

```
sensor# clock set 13:21 Mar 29 2011
```



Note

The time format is 24-hour time.

Clearing the Denied Attackers List

Use the **show statistics denied-attackers** command to display the list of denied attackers. Use the **clear denied-attackers** *[virtual_sensor] [ip-address ip_address]* command to delete the denied attackers list and clear the virtual sensor statistics.

If your sensor is configured to operate in inline mode, the traffic is passing through the sensor. You can configure signatures to deny packets, connections, and attackers while in inline mode, which means that single packets, connections, and specific attackers are denied, that is, not transmitted, when the sensor encounters them. When the signature fires, the attacker is denied and placed in a list. As part of sensor administration, you may want to delete the list or clear the statistics in the list.

The following options apply:

- *virtual_sensor*—(Optional) Specifies the virtual sensor whose denied attackers list should be cleared.
- *ip_address*—(Optional) Specifies the IP address to clear.

Displaying and Deleting Denied Attackers

To display the list of denied attackers and delete the list and clear the statistics, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Display the list of denied IP addresses. The statistics show that there are two IP addresses being denied at this time.
- ```
sensor# show statistics denied-attackers
Denied Attackers and hit count for each.
 10.20.4.2 = 9
 10.20.5.2 = 5
```
- Step 3** Delete the denied attackers list.
- ```
sensor# clear denied-attackers
Warning: Executing this command will delete all addresses from the list of attackers
currently being denied by the sensor.
Continue with clear? [yes]:
```
- Step 4** Enter **yes** to clear the list.
- Step 5** Delete the denied attackers list for a specific virtual sensor.
- ```
sensor# clear denied-attackers vs0
Warning: Executing this command will delete all addresses from the list of attackers being
denied by virtual sensor vs0.
Continue with clear? [yes]:
```
- Step 6** Enter **yes** to clear the list.
- Step 7** Remove a specific IP address from the denied attackers list for a specific virtual sensor.
- ```
sensor# clear denied-attackers vs0 ip-address 192.0.2.0
Warning: Executing this command will delete ip address 192.0.2.0 from the list of
attackers being denied by virtual sensor vs0.
Continue with clear? [yes]:
```
- Step 8** Enter **yes** to clear the list.
- Step 9** Verify that you have cleared the list. You can use the **show statistics denied-attackers** or **show statistics virtual-sensor** command.
- ```
sensor# show statistics denied-attackers
Denied Attackers and hit count for each.
Denied Attackers and hit count for each.
Statistics for Virtual Sensor vs0
 Denied Attackers with percent denied and hit count for each.

 Denied Attackers with percent denied and hit count for each.
```

```

Statistics for Virtual Sensor vs1
 Denied Attackers with percent denied and hit count for each.

 Denied Attackers with percent denied and hit count for each.
sensor#

sensor# show statistics virtual-sensor
Virtual Sensor Statistics
 Statistics for Virtual Sensor vs0
 Name of current Signature-Definition instance = sig0
 Name of current Event-Action-Rules instance = rules0
 List of interfaces monitored by this virtual sensor = mypair
 Denied Address Information
 Number of Active Denied Attackers = 0
 Number of Denied Attackers Inserted = 2
 Number of Denied Attackers Total Hits = 287
 Number of times max-denied-attackers limited creation of new entry = 0
 Number of exec Clear commands during uptime = 1
 Denied Attackers and hit count for each.

```

**Step 10** Clear only the statistics.

```
sensor# show statistics virtual-sensor clear
```

**Step 11** Verify that you have cleared the statistics. The statistics have all been cleared except for the Number of Active Denied Attackers and Number of exec Clear commands during uptime categories. It is important to know if the list has been cleared.

```

sensor# show statistics virtual-sensor
Virtual Sensor Statistics
 Statistics for Virtual Sensor vs0
 Name of current Signature-Definition instance = sig0
 Name of current Event-Action-Rules instance = rules0
 List of interfaces monitored by this virtual sensor = mypair
 Denied Address Information
 Number of Active Denied Attackers = 2
 Number of Denied Attackers Inserted = 0
 Number of Denied Attackers Total Hits = 0
 Number of times max-denied-attackers limited creation of new entry = 0
 Number of exec Clear commands during uptime = 1
 Denied Attackers and hit count for each.
 10.20.2.5 = 0
 10.20.5.2 = 0

```

## Displaying Policy Lists

Use the **list {anomaly-detection-configurations | event-action-rules-configurations | signature-definition-configurations}** in EXEC mode to display the list of policies for these components. The file size is in bytes. A virtual sensor with N/A indicates that the policy is not assigned to a virtual sensor.



To display a list of policies on the sensor, follow these steps:

**Step 1** Log in to the CLI.

**Step 2** Display the list of policies for anomaly detection.

```
sensor# list anomaly-detection-configurations
Anomaly Detection
 Instance Size Virtual Sensor

 ad0 255 vs0
 temp 707 N/A
 MyAD 255 N/A
 ad1 141 vs1
sensor#
```

**Step 3** Display the list of policies for event action rules.

```
sensor# list event-action-rules-configurations
Event Action Rules
 Instance Size Virtual Sensor

 rules0 112 vs0
 rules1 141 vs1
sensor#
```

**Step 4** Display the list of policies for signature definition.

```
sensor# list signature-definition-configurations
Signature Definition
 Instance Size Virtual Sensor

 sig0 336 vs0
 sig1 141 vs1
 sig2 141 N/A
sensor#
```

## Displaying Statistics

Use the **show statistics** [analysis-engine | anomaly-detection | authentication | denied-attackers | event-server | event-store | external-product-interface | global-correlation | host | logger | network-access | notification | os-identification | sdee-server | transaction-server | virtual-sensor | web-server] [clear] command to display statistics for each sensor application.

Use the **show statistics** {anomaly-detection | denied-attackers | os-identification | virtual-sensor} [name | clear] command to display statistics for these components for all virtual sensors. If you provide the virtual sensor name, the statistics for that virtual sensor only are displayed.



### Note

The **clear** option is not available for the analysis engine, anomaly detection, host, network access, or OS identification applications.

For the IPS 4510 and IPS 4520, at the end of the command output, there are extra details for the Ethernet controller statistics, such as the total number of packets received at the Ethernet controller, the total number of packets dropped at the Ethernet controller under high load conditions, and the total packets transmitted including the customer traffic packets and the internal keepalive packet count.

**Note**

The Ethernet controller statistics are polled at an interval of 5 seconds from the hardware side. The keepalives are sent or updated at an interval of 10 ms. Because of this, there may be a disparity in the actual count reflected in the total packets transmitted. At times, it is even possible that the total packets transmitted may be less than the keepalive packets transmitted.

To display statistics for the sensor, follow these steps:

**Step 1** Log in to the CLI.

**Step 2** Display the statistics for the Analysis Engine.

```

sensor# show statistics analysis-engine
Analysis Engine Statistics
 Number of seconds since service started = 431157
 Processing Load Percentage
 Thread 5 sec 1 min 5 min
 0 1 1 1
 1 1 1 1
 2 1 1 1
 3 1 1 1
 4 1 1 1
 5 1 1 1
 6 1 1 1
 Average 1 1 1

 The rate of TCP connections tracked per second = 0
 The rate of packets per second = 0
 The rate of bytes per second = 0
 Receiver Statistics
 Total number of packets processed since reset = 0
 Total number of IP packets processed since reset = 0
 Transmitter Statistics
 Total number of packets transmitted = 133698
 Total number of packets denied = 203
 Total number of packets reset = 3
 Fragment Reassembly Unit Statistics
 Number of fragments currently in FRU = 0
 Number of datagrams currently in FRU = 0
 TCP Stream Reassembly Unit Statistics
 TCP streams currently in the embryonic state = 0
 TCP streams currently in the established state = 0
 TCP streams currently in the closing state = 0
 TCP streams currently in the system = 0
 TCP Packets currently queued for reassembly = 0
 The Signature Database Statistics.
 Total nodes active = 0
 TCP nodes keyed on both IP addresses and both ports = 0
 UDP nodes keyed on both IP addresses and both ports = 0
 IP nodes keyed on both IP addresses = 0
 Statistics for Signature Events
 Number of SigEvents since reset = 0
 Statistics for Actions executed on a SigEvent
 Number of Alerts written to the IdsEventStore = 0
 Inspection Stats
 Inspector active call create delete loadPct
 AtomicAdvanced 0 2312 4 4 33
 Fixed 0 1659 1606 1606 1
 MSRPC_TCP 0 20 4 4 0
 MSRPC_UDP 0 1808 1575 1575 0
 MultiString 0 145 10 10 2

```

|                    |   |      |      |      |    |
|--------------------|---|------|------|------|----|
| ServiceDnsUdp      | 0 | 1841 | 3    | 3    | 0  |
| ServiceGeneric     | 0 | 2016 | 14   | 14   | 1  |
| ServiceHttp        | 0 | 2    | 2    | 2    | 51 |
| ServiceNtp         | 0 | 3682 | 3176 | 3176 | 0  |
| ServiceP2PTCP      | 0 | 21   | 9    | 9    | 0  |
| ServiceRpcUDP      | 0 | 1841 | 3    | 3    | 0  |
| ServiceRpcTCP      | 0 | 130  | 9    | 9    | 0  |
| ServiceSMBAdvanced | 0 | 139  | 3    | 3    | 0  |
| ServiceSnmp        | 0 | 1841 | 3    | 3    | 0  |
| ServiceTNS         | 0 | 18   | 14   | 14   | 0  |
| String             | 0 | 225  | 16   | 16   | 0  |
| SweepUDP           | 0 | 1808 | 1555 | 1555 | 6  |
| SweepTCP           | 0 | 576  | 17   | 17   | 0  |
| SweepOtherTcp      | 0 | 288  | 6    | 6    | 0  |
| TrojanBO2K         | 0 | 261  | 11   | 11   | 0  |
| TrojanUdp          | 0 | 1808 | 1555 | 1555 | 0  |

```

GlobalCorrelationStats
SwVersion = 7.1(4.70)E4
SigVersion = 645.0
DatabaseRecordCount = 0
DatabaseVersion = 0
RuleVersion = 0
ReputationFilterVersion = 0
AlertsWithHit = 0
AlertsWithMiss = 0
AlertsWithModifiedRiskRating = 0
AlertsWithGlobalCorrelationDenyAttacker = 0
AlertsWithGlobalCorrelationDenyPacket = 0
AlertsWithGlobalCorrelationOtherAction = 0
AlertsWithAuditRepDenies = 0
ReputationForcedAlerts = 0
EventStoreInsertTotal = 0
EventStoreInsertWithHit = 0
EventStoreInsertWithMiss = 0
EventStoreDenyFromGlobalCorrelation = 0
EventStoreDenyFromOverride = 0
EventStoreDenyFromOverlap = 0
EventStoreDenyFromOther = 0
ReputationFilterDataSize = 0
ReputationFilterPacketsInput = 0
ReputationFilterRuleMatch = 0
DenyFilterHitsNormal = 0
DenyFilterHitsGlobalCorrelation = 0
SimulatedReputationFilterPacketsInput = 0
SimulatedReputationFilterRuleMatch = 0
SimulatedDenyFilterInsert = 0
SimulatedDenyFilterPacketsInput = 0
SimulatedDenyFilterRuleMatch = 0
TcpDeniesDueToGlobalCorrelation = 0
TcpDeniesDueToOverride = 0
TcpDeniesDueToOverlap = 0
TcpDeniesDueToOther = 0
SimulatedTcpDeniesDueToGlobalCorrelation = 0
SimulatedTcpDeniesDueToOverride = 0
SimulatedTcpDeniesDueToOverlap = 0
SimulatedTcpDeniesDueToOther = 0
LateStageDenyDueToGlobalCorrelation = 0
LateStageDenyDueToOverride = 0
LateStageDenyDueToOverlap = 0
LateStageDenyDueToOther = 0
SimulatedLateStageDenyDueToGlobalCorrelation = 0
SimulatedLateStageDenyDueToOverride = 0
SimulatedLateStageDenyDueToOverlap = 0

```

```

 SimulatedLateStageDenyDueToOther = 0
 AlertHistogram
 RiskHistogramEarlyStage
 RiskHistogramLateStage
 ConfigAggressiveMode = 0
 ConfigAuditMode = 0
 RegexAccelerationStats
 Status = Enabled
 DriverVersion = 6.2.1
 Devices = 1
 Agents = 12
 Flows = 7
 Channels = 0
 SubmittedJobs = 4968
 CompletedJobs = 4968
 SubmittedBytes = 72258005
 CompletedBytes = 168
 TCPFlowsWithoutLCB = 0
 UDPFlowsWithoutLCB = 0
 TCPMissedPacketsDueToUpdate = 0
 UDPMissedPacketsDueToUpdate = 0
 MemorySize = 1073741824
 HostDirectMemSize = 0
 MaliciousSiteDenyHitCounts
 MaliciousSiteDenyHitCountsAUDIT
Ethernet Controller Statistics
 Total Packets Received = 0
 Total Received Packets Dropped = 0
 Total Packets Transmitted = 13643"
sensor#

```

### Step 3 Display the statistics for anomaly detection.

```

sensor# show statistics anomaly-detection
Statistics for Virtual Sensor vs0
 No attack
 Detection - ON
 Learning - ON
 Next KB rotation at 10:00:01 UTC Sat Jan 18 2008
 Internal Zone
 TCP Protocol
 UDP Protocol
 Other Protocol
 External Zone
 TCP Protocol
 UDP Protocol
 Other Protocol
 Illegal Zone
 TCP Protocol
 UDP Protocol
 Other Protocol
Statistics for Virtual Sensor vs1
 No attack
 Detection - ON
 Learning - ON
 Next KB rotation at 10:00:00 UTC Sat Jan 18 2008
 Internal Zone
 TCP Protocol
 UDP Protocol
 Other Protocol
 External Zone
 TCP Protocol
 UDP Protocol
 Other Protocol

```

```

Illegal Zone
TCP Protocol
UDP Protocol
Other Protocol
sensor#

```

**Step 4** Display the statistics for authentication.

```

sensor# show statistics authentication
General
 totalAuthenticationAttempts = 128
 failedAuthenticationAttempts = 0
sensor#

```

**Step 5** Display the statistics for the denied attackers in the system.

```

sensor# show statistics denied-attackers
Denied Attackers and hit count for each.
Denied Attackers and hit count for each.
Statistics for Virtual Sensor vs0
 Denied Attackers with percent denied and hit count for each.

 Denied Attackers with percent denied and hit count for each.

Statistics for Virtual Sensor vs1
 Denied Attackers with percent denied and hit count for each.

 Denied Attackers with percent denied and hit count for each.

sensor#

```

**Step 6** Display the statistics for the Event Server.

```

sensor# show statistics event-server
General
 openSubscriptions = 0
 blockedSubscriptions = 0
Subscriptions
sensor#

```

**Step 7** Display the statistics for the Event Store.

```

sensor# show statistics event-store
Event store statistics
 General information about the event store
 The current number of open subscriptions = 2
 The number of events lost by subscriptions and queries = 0
 The number of filtered events not written to the event store = 850763
 The number of queries issued = 0
 The number of times the event store circular buffer has wrapped = 0
 Number of events of each type currently stored
 Status events = 4257
 Shun request events = 0
 Error events, warning = 669
 Error events, error = 8
 Error events, fatal = 0
 Alert events, informational = 0
 Alert events, low = 0
 Alert events, medium = 0
 Alert events, high = 0
 Alert events, threat rating 0-20 = 0

```

```

Alert events, threat rating 21-40 = 0
Alert events, threat rating 41-60 = 0
Alert events, threat rating 61-80 = 0
Alert events, threat rating 81-100 = 0
Cumulative number of each type of event
Status events = 4257
Shun request events = 0
Error events, warning = 669
Error events, error = 8
Error events, fatal = 0
Alert events, informational = 0
Alert events, low = 0
Alert events, medium = 0
Alert events, high = 0
Alert events, threat rating 0-20 = 0
Alert events, threat rating 21-40 = 0
Alert events, threat rating 41-60 = 0
Alert events, threat rating 61-80 = 0
Alert events, threat rating 81-100 = 0
sensor#

```

### Step 8 Display the statistics for global correlation.

```

sensor# show statistics global-correlation
Network Participation:
 Counters:
 Total Connection Attempts = 0
 Total Connection Failures = 0
 Connection Failures Since Last Success = 0
 Connection History:
Updates:
 Status Of Last Update Attempt = Disabled
 Time Since Last Successful Update = never
 Counters:
 Update Failures Since Last Success = 0
 Total Update Attempts = 0
 Total Update Failures = 0
 Update Interval In Seconds = 300
 Update Server = update-manifests.ironport.com
 Update Server Address = Unknown
 Current Versions:
Warnings:
 Unlicensed = Global correlation inspection and reputation filtering have been
disabled because the sensor is unlicensed.
 Action Required = Obtain a new license from http://www.cisco.com/go/license.
sensor#

```

### Step 9 Display the statistics for the host.

```

sensor# show statistics host
General Statistics
 Last Change To Host Config (UTC) = 25-Jan-2012 02:59:18
 Command Control Port Device = Management0/0
Network Statistics
 = ma0_0 Link encap:Ethernet HWaddr 00:04:23:D5:A1:8D
 = inet addr:10.89.130.98 Bcast:10.89.131.255 Mask:255.255.254.0
 = UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1
 = RX packets:1688325 errors:0 dropped:0 overruns:0 frame:0
 = TX packets:38546 errors:0 dropped:0 overruns:0 carrier:0
 = collisions:0 txqueuelen:1000
 = RX bytes:133194316 (127.0 MiB) TX bytes:5515034 (5.2 MiB)
 = Base address:0xcc80 Memory:fcee0000-fcf00000
NTP Statistics
 status = Not applicable

```

```

Memory Usage
 usedBytes = 1889357824
 freeBytes = 2210988032
 totalBytes = 4100345856
CPU Statistics
 Note: CPU Usage statistics are not a good indication of the sensor processin load. The
 Inspection Load Percentage in the output of 'show inspection-load' should be used instead.
 Usage over last 5 seconds = 0
 Usage over last minute = 2
 Usage over last 5 minutes = 2
 Usage over last 5 seconds = 0
 Usage over last minute = 1
 Usage over last 5 minutes = 1
Memory Statistics
 Memory usage (bytes) = 1889357824
 Memory free (bytes) = 2210988032
Auto Update Statistics
 lastDirectoryReadAttempt = N/A
 lastDownloadAttempt = N/A
 lastInstallAttempt = N/A
 nextAttempt = N/A
Auxilliary Processors Installed
sensor#

```

**Step 10** Display the statistics for the logging application.

```

sensor# show statistics logger
The number of Log interprocessor FIFO overruns = 0
The number of syslog messages received = 11
The number of <evError> events written to the event store by severity
 Fatal Severity = 0
 Error Severity = 64
 Warning Severity = 35
 TOTAL = 99
The number of log messages written to the message log by severity
 Fatal Severity = 0
 Error Severity = 64
 Warning Severity = 24
 Timing Severity = 311
 Debug Severity = 31522
 Unknown Severity = 7
 TOTAL = 31928
sensor#

```

**Step 11** Display the statistics for the ARC.

```

sensor# show statistics network-access
Current Configuration
 LogAllBlockEventsAndSensors = true
 EnableNvramWrite = false
 EnableAclLogging = false
 AllowSensorBlock = false
 BlockMaxEntries = 11
 MaxDeviceInterfaces = 250
NetDevice
 Type = PIX
 IP = 10.89.150.171
 NATAddr = 0.0.0.0
 Communications = ssh-3des
NetDevice
 Type = PIX
 IP = 192.0.2.4
 NATAddr = 0.0.0.0
 Communications = ssh-3des

```

```
NetDevice
 Type = PIX
 IP = 192.0.2.5
 NATAddr = 0.0.0.0
 Communications = telnet
NetDevice
 Type = Cisco
 IP = 192.0.2.6
 NATAddr = 0.0.0.0
 Communications = telnet
 BlockInterface
 InterfaceName = ethernet0/1
 InterfaceDirection = out
 InterfacePostBlock = Post_Acl_Test
 BlockInterface
 InterfaceName = ethernet0/1
 InterfaceDirection = in
 InterfacePreBlock = Pre_Acl_Test
 InterfacePostBlock = Post_Acl_Test
NetDevice
 Type = CAT6000_VACL
 IP = 192.0.2.1
 NATAddr = 0.0.0.0
 Communications = telnet
 BlockInterface
 InterfaceName = 502
 InterfacePreBlock = Pre_Acl_Test
 BlockInterface
 InterfaceName = 507
 InterfacePostBlock = Post_Acl_Test
State
 BlockEnable = true
NetDevice
 IP = 192.0.2.3
 AclSupport = Does not use ACLs
 Version = 6.3
 State = Active
 Firewall-type = PIX
NetDevice
 IP = 192.0.2.7
 AclSupport = Does not use ACLs
 Version = 7.0
 State = Active
 Firewall-type = ASA
NetDevice
 IP = 102.0.2.8
 AclSupport = Does not use ACLs
 Version = 2.2
 State = Active
 Firewall-type = FWSM
NetDevice
 IP = 192.0.2.9
 AclSupport = uses Named ACLs
 Version = 12.2
 State = Active
NetDevice
 IP = 192.0.2.10
 AclSupport = Uses VACLs
 Version = 8.4
 State = Active
BlockedAddr
 Host
 IP = 203.0.113.1
 Vlan =
```



```

 ActualIp =
 BlockMinutes =
 Host
 IP = 203.0.113.2
 Vlan =
 ActualIp =
 BlockMinutes =
 Host
 IP = 203.0.113.4
 Vlan =
 ActualIp =
 BlockMinutes = 60
 MinutesRemaining = 24
 Network
 IP = 203.0.113.9
 Mask = 255.255.0.0
 BlockMinutes =
sensor#

```

**Step 12** Display the statistics for the notification application.

```

sensor# show statistics notification
General
 Number of SNMP set requests = 0
 Number of SNMP get requests = 0
 Number of error traps sent = 0
 Number of alert traps sent = 0
sensor#

```

**Step 13** Display the statistics for OS identification.

```

sensor# show statistics os-identification
Statistics for Virtual Sensor vs0
 OS Identification
 Configured
 Imported
 Learned
sensor#

```

**Step 14** Display the statistics for the SDEE server.

```

sensor# show statistics sdee-server
General
 Open Subscriptions = 1
 Blocked Subscriptions = 1
 Maximum Available Subscriptions = 5
 Maximum Events Per Retrieval = 500
Subscriptions
 sub-4-d074914f
 State = Read Pending
 Last Read Time = 23:54:16 UTC Wed Nov 30 2011
 Last Read Time (nanoseconds) = 1322697256078549000
sensor#

```

**Step 15** Display the statistics for the transaction server.

```

sensor# show statistics transaction-server
General
 totalControlTransactions = 35
 failedControlTransactions = 0
sensor#

```

**Step 16** Display the statistics for a virtual sensor.

```

sensor# show statistics virtual-sensor vs0

```

```

Statistics for Virtual Sensor vs0
 Name of current Signature-Definition instance = sig0
 Name of current Event-Action-Rules instance = rules0
 List of interfaces monitored by this virtual sensor =
 General Statistics for this Virtual Sensor
 Number of seconds since a reset of the statistics = 1151770
 MemoryAlloPercent = 23
 MemoryUsedPercent = 22
 MemoryMaxCapacity = 3500000
 MemoryMaxHighUsed = 4193330
 MemoryCurrentAllo = 805452
 MemoryCurrentUsed = 789047
 Processing Load Percentage = 1
 Total packets processed since reset = 0
 Total IP packets processed since reset = 0
 Total IPv4 packets processed since reset = 0
 Total IPv6 packets processed since reset = 0
 Total IPv6 AH packets processed since reset = 0
 Total IPv6 ESP packets processed since reset = 0
 Total IPv6 Fragment packets processed since reset = 0
 Total IPv6 Routing Header packets processed since reset = 0
 Total IPv6 ICMP packets processed since reset = 0
 Total packets that were not IP processed since reset = 0
 Total TCP packets processed since reset = 0
 Total UDP packets processed since reset = 0
 Total ICMP packets processed since reset = 0
 Total packets that were not TCP, UDP, or ICMP processed since reset = 0
 Total ARP packets processed since reset = 0
 Total ISL encapsulated packets processed since reset = 0
 Total 802.1q encapsulated packets processed since reset = 0
 Total GRE Packets processed since reset = 0
 Total GRE Fragment Packets processed since reset = 0
 Total GRE Packets skipped since reset = 0
 Total GRE Packets with Bad Header skipped since reset = 0
 Total IpIp Packets with Bad Header skipped since reset = 0
 Total Encapsulated Tunnel Packets with Bad Header skipped since reset = 0
 Total packets with bad IP checksums processed since reset = 0
 Total packets with bad layer 4 checksums processed since reset = 0
 Total cross queue TCP packets processed since reset = 0
 Total cross queue UDP packets processed since reset = 0
 Packets dropped due to regex resources unavailable since reset = 0
 Total number of bytes processed since reset = 0
 The rate of packets per second since reset = 0
 The rate of bytes per second since reset = 0
 The average bytes per packet since reset = 0
 Denied Address Information
 Number of Active Denied Attackers = 0
 Number of Denied Attackers Inserted = 0
 Number of Denied Attacker Victim Pairs Inserted = 0
 Number of Denied Attacker Service Pairs Inserted = 0
 Number of Denied Attackers Total Hits = 0
 Number of times max-denied-attackers limited creation of new entry = 0
 Number of exec Clear commands during uptime = 0
 Denied Attackers and hit count for each.
 Denied Attackers with percent denied and hit count for each.

The Signature Database Statistics.
 The Number of each type of node active in the system
 Total nodes active = 0
 TCP nodes keyed on both IP addresses and both ports = 0
 UDP nodes keyed on both IP addresses and both ports = 0
 IP nodes keyed on both IP addresses = 0
 The number of each type of node inserted since reset

```

```

Total nodes inserted = 0
TCP nodes keyed on both IP addresses and both ports = 0
UDP nodes keyed on both IP addresses and both ports = 0
IP nodes keyed on both IP addresses = 0
The rate of nodes per second for each time since reset
Nodes per second = 0
TCP nodes keyed on both IP addresses and both ports per second = 0
UDP nodes keyed on both IP addresses and both ports per second = 0
IP nodes keyed on both IP addresses per second = 0
The number of root nodes forced to expire because of memory constraints
TCP nodes keyed on both IP addresses and both ports = 0
Packets dropped because they would exceed Database insertion rate limits = 0
Fragment Reassembly Unit Statistics for this Virtual Sensor
Number of fragments currently in FRU = 0
Number of datagrams currently in FRU = 0
Number of fragments received since reset = 0
Number of fragments forwarded since reset = 0
Number of fragments dropped since last reset = 0
Number of fragments modified since last reset = 0
Number of complete datagrams reassembled since last reset = 0
Fragments hitting too many fragments condition since last reset = 0
Number of overlapping fragments since last reset = 0
Number of Datagrams too big since last reset = 0
Number of overwriting fragments since last reset = 0
Number of Initial fragment missing since last reset = 0
Fragments hitting the max partial dgrams limit since last reset = 0
Fragments too small since last reset = 0
Too many fragments per dgram limit since last reset = 0
Number of datagram reassembly timeout since last reset = 0
Too many fragments claiming to be the last since last reset = 0
Fragments with bad fragment flags since last reset = 0
TCP Normalizer stage statistics
Packets Input = 0
Packets Modified = 0
Dropped packets from queue = 0
Dropped packets due to deny-connection = 0
Duplicate Packets = 0
Current Streams = 0
Current Streams Closed = 0
Current Streams Closing = 0
Current Streams Embryonic = 0
Current Streams Established = 0
Current Streams Denied = 0
Total SendAck Limited Packets = 0
Total SendAck Limited Streams = 0
Total SendAck Packets Sent = 0
Statistics for the TCP Stream Reassembly Unit
Current Statistics for the TCP Stream Reassembly Unit
TCP streams currently in the embryonic state = 0
TCP streams currently in the established state = 0
TCP streams currently in the closing state = 0
TCP streams currently in the system = 0
TCP Packets currently queued for reassembly = 0
Cumulative Statistics for the TCP Stream Reassembly Unit since reset
TCP streams that have been tracked since last reset = 0
TCP streams that had a gap in the sequence jumped = 0
TCP streams that was abandoned due to a gap in the sequence = 0
TCP packets that arrived out of sequence order for their stream = 0
TCP packets that arrived out of state order for their stream = 0
The rate of TCP connections tracked per second since reset = 0
SigEvent Preliminary Stage Statistics
Number of Alerts received = 0
Number of Alerts Consumed by AlertInterval = 0
Number of Alerts Consumed by Event Count = 0

```

```

Number of FireOnce First Alerts = 0
Number of FireOnce Intermediate Alerts = 0
Number of Summary First Alerts = 0
Number of Summary Intermediate Alerts = 0
Number of Regular Summary Final Alerts = 0
Number of Global Summary Final Alerts = 0
Number of Active SigEventDataNodes = 0
Number of Alerts Output for further processing = 0
--MORE--

```

**Step 17** Display the statistics for the web server.

```

sensor# show statistics web-server
listener-443
 session-11
 remote host = 64.101.182.167
 session is persistent = no
 number of requests serviced on current connection = 1
 last status code = 200
 last request method = GET
 last request URI = cgi-bin/sdee-server
 last protocol version = HTTP/1.1
 session state = processingGetServlet
 number of server session requests handled = 957134
 number of server session requests rejected = 0
 total HTTP requests handled = 365871
 maximum number of session objects allowed = 40
 number of idle allocated session objects = 12
 number of busy allocated session objects = 1
 summarized log messages
 number of TCP socket failure messages logged = 0
 number of TLS socket failure messages logged = 0
 number of TLS protocol failure messages logged = 0
 number of TLS connection failure messages logged = 595015
 number of TLS crypto warning messages logged = 0
 number of TLS expired certificate warning messages logged = 0
 number of receipt of TLS fatal alert message messages logged = 594969
 crypto library version = 6.2.1.0
sensor#

```

**Step 18** Clear the statistics for an application, for example, the logging application. The statistics are retrieved and cleared.

```

sensor# show statistics logger clear
The number of Log interprocessor FIFO overruns = 0
The number of syslog messages received = 141
The number of <evError> events written to the event store by severity
 Fatal Severity = 0
 Error Severity = 14
 Warning Severity = 142
 TOTAL = 156
The number of log messages written to the message log by severity
 Fatal Severity = 0
 Error Severity = 14
 Warning Severity = 1
 Timing Severity = 0
 Debug Severity = 0
 Unknown Severity = 28
 TOTAL = 43

```

**Step 19** Verify that the statistics have been cleared. The statistics now all begin from 0.

```

sensor# show statistics logger
The number of Log interprocessor FIFO overruns = 0

```

```

The number of syslog messages received = 0
The number of <evError> events written to the event store by severity
 Fatal Severity = 0
 Error Severity = 0
 Warning Severity = 0
 TOTAL = 0
The number of log messages written to the message log by severity
 Fatal Severity = 0
 Error Severity = 0
 Warning Severity = 0
 Timing Severity = 0
 Debug Severity = 0
 Unknown Severity = 0
 TOTAL = 0
sensor#

```

## Displaying Tech Support Information



### Note

The **show tech-support** command now displays historical interface data for each interface for the past 72 hours.

Use the **show tech-support [page] [destination-url destination\_url]** command to display system information on the screen or have it sent to a specific URL. You can use the information as a troubleshooting tool with the TAC.

The following parameters are optional:

- **page**—Displays the output, one page of information at a time. Press **Enter** to display the next line of output or use the spacebar to display the next page of information.
- **destination-url**—Indicates the information should be formatted as HTML and sent to the destination that follows this command. If you use this keyword, the output is not displayed on the screen.
- **destination\_url**—Indicates the information should be formatted as HTML. The URL specifies where the information should be sent. If you do not use this keyword, the information is displayed on the screen.
- You can specify the following destination types:
  - **ftp**—Destination URL for FTP network server. The syntax for this prefix is:  
`ftp:[[/username@location]/relativeDirectory]/filename` OR  
`ftp:[[/username@location]//absoluteDirectory]/filename.`
  - **scp**—Destination URL for the SCP network server. The syntax for this prefix is:  
`scp:[[/username@]location]/relativeDirectory]/filename` OR  
`scp:[[/username@]location]//absoluteDirectory]/filename.`

### Varlog Files

The `/var/log/messages` file has the latest logs. A new softlink called `varlog` has been created under the `/usr/cids/idsRoot/log` folder that points to the `/var/log/messages` file. Old logs are stored in `varlog.1` and `varlog.2` files. The maximum size of these `varlog` files is 200 KB. Once they cross the size limit the content is rotated. The content of `varlog`, `varlog.1`, and `varlog.2` is displayed in the output of the **show tech-support** command.

**Displaying Tech Support Information**

To display tech support information, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** View the output on the screen. The system information appears on the screen, one page at a time. Press the spacebar to view the next page or press **Ctrl-C** to return to the prompt

```
sensor# show tech-support page
```

- Step 3** To send the output (in HTML format) to a file:

- a. Enter the following command, followed by a valid destination. The `password:` prompt appears.

```
sensor# show tech-support destination-url destination_url
```

Example

To send the tech support output to the file `/absolute/reports/sensor1Report.html`:

```
sensor# show tech support dest
ftp://csidsuser@10.2.1.2//absolute/reports/sensor1Report.html
```

- b. Enter the password for this user account. The `Generating report:` message is displayed.
- 

## Displaying Version Information

Use the **show version** command to display version information for all installed operating system packages, signature packages, and IPS processes running on the system. To view the configuration for the entire system, use the **more current-config** command.

**Note**

The CLI output is an example of what your configuration may look like. It will not match exactly due to the optional setup choices, sensor model, and IPS 7.1 version you have installed.

---

**Note**

For the IPS 4500 series sensors, the **show version** command output contains an extra application called the SwitchApp.

---

To display the version and configuration, follow these steps:

- 
- Step 1** Log in to the CLI.
- Step 2** View version information.

```
sensor# show version
Application Partition:

Cisco Intrusion Prevention System, Version 7.1(3)E4

Host:
 Realm Keys key1.0
Signature Definition:
 Signature Update S605.0 2011-10-25
OS Version: 2.6.29.1
```

```

Platform: ASA5585-SSP-IPS10
Serial Number: 123456789AB
No license present
Sensor up-time is 13 days.
Using 4395M out of 5839M bytes of available memory (75% usage)
system is using 26.2M out of 160.0M bytes of available disk space (16% usage)
application-data is using 69.7M out of 171.6M bytes of available disk space (43%
usage)
boot is using 57.3M out of 70.5M bytes of available disk space (86% usage)
application-log is using 494.0M out of 513.0M bytes of available disk space (96%
usage)

```

```

MainApp S-2011_NOV_16_00_20_7_1_3_46 (Release) 2011-11-16T00:23:0
6-0600 Running
AnalysisEngine S-2011_NOV_16_00_20_7_1_3_46 (Release) 2011-11-16T00:23:0
6-0600 Running
CollaborationApp S-2011_NOV_16_00_20_7_1_3_46 (Release) 2011-11-16T00:23:0
6-0600 Running
CLI S-2011_NOV_16_00_20_7_1_3_46 (Release) 2011-11-16T00:23:0
6-0600

```

#### Upgrade History:

```
IPS-K9-7.1-3-E4 00:30:07 UTC Wed Nov 16 2011
```

Recovery Partition Version 1.1 - 7.1(3)E4

Host Certificate Valid from: 16-Nov-2011 to 16-Nov-2013

sensor#



**Note** If the --MORE-- prompt is displayed, press the spacebar to see more information or **Ctrl-C** to cancel the output and get back to the CLI prompt.

### Step 3 View configuration information.



**Note** You can use the **more current-config** or **show configuration** commands.

```

sensor# more current-config
! -----
! Current configuration last modified Tue Nov 22 16:11:35 2011
! -----
! Version 7.1(3)
! Host:
! Realm Keys key1.0
! Signature Definition:
! Signature Update S605.0 2011-10-25
! -----
service interface
exit
! -----
service authentication
exit
! -----
service event-action-rules rules0
exit
! -----
service host
network-settings

```

```

host-ip 192.168.1.2/24, 192.168.1.1
host-name sensor
telnet-option enabled
access-list 0.0.0.0/0
dns-primary-server disabled
exit
! -----
service logger
exit
! -----
service network-access
exit
! -----
service notification
exit
! -----
service signature-definition sig0
exit
! -----
service ssh-known-hosts
exit
! -----
service trusted-certificates
exit
! -----
service web-server
exit
! -----
service anomaly-detection ad0
exit
! -----
service external-product-interface
exit
! -----
service health-monitor
exit
! -----
service global-correlation
exit
! -----
service aaa
exit
! -----
service analysis-engine
sensor#

```

## Diagnosing Network Connectivity



### Caution

No command interrupt is available for this command. It must run to completion.

Use the **ping** *ip\_address* [**count**] command to diagnose basic network connectivity. To diagnose basic network connectivity, follow these steps:



**Step 1** Log in to the CLI.

**Step 2** Ping the address you are interested in. The count is the number of echo requests to send. If you do not specify a number, 4 requests are sent. The range is 1 to 10,000.

```
sensor# ping ip_address count
```

The following example shows a successful ping:

```
sensor# ping 192.0.2.1 6
PING 192.0.2.1 (192.0.2.1): 56 data bytes
64 bytes from 192.0.2.1: icmp_seq=0 ttl=61 time=0.3 ms
64 bytes from 192.0.2.1: icmp_seq=1 ttl=61 time=0.1 ms
64 bytes from 192.0.2.1: icmp_seq=2 ttl=61 time=0.1 ms
64 bytes from 192.0.2.1: icmp_seq=3 ttl=61 time=0.2 ms
64 bytes from 192.0.2.1: icmp_seq=4 ttl=61 time=0.2 ms
64 bytes from 192.0.2.1: icmp_seq=5 ttl=61 time=0.2 ms

--- 192.0.2.1 ping statistics ---
6 packets transmitted, 6 packets received, 0% packet loss
round-trip min/avg/max = 0.1/0.1/0.3 ms
```

The following example shows an unsuccessful ping:

```
sensor# ping 172.16.0.0 3
PING 172.16.0.0 (172.16.0.0): 56 data bytes

--- 172.16.0.0 ping statistics ---
3 packets transmitted, 0 packets received, 100% packet loss
sensor#
```

## Resetting the Appliance

Use the **reset [powerdown]** command to shut down the applications running on the appliance and to reboot the appliance. You can include the **powerdown** option to power off the appliance, if possible, or to have the appliance left in a state where the power can be turned off.

Shutdown (stopping the applications) begins immediately after you execute the command. Shutdown can take a while, and you can still access CLI commands while it is taking place, but the session is terminated without warning.

To reset the appliance, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** To stop all applications and reboot the appliance, follow these Steps 2 and 3. Otherwise, to power down the appliance, go to Steps 4 and 5.
- ```
sensor# reset
Warning: Executing this command will stop all applications and reboot the node.
Continue with reset? []:
```
- Step 3** Enter **yes** to continue the reset.
- ```
sensor# yes
Request Succeeded.
sensor#
```
- Step 4** Stop all applications and power down the appliance.
- ```
sensor# reset powerdown
Warning: Executing this command will stop all applications and power off the node if
possible. If the node can not be powered off it will be left in a state that is safe to
manually power down.
Continue with reset? []:
```
- Step 5** Enter **yes** to continue with the reset and power down.
- ```
sensor# yes
Request Succeeded.
sensor#
```
- 

#### For More Information

- To reset the ASA 5500 AIP SSM, see [Reloading, Shutting Down, Resetting, and Recovering the ASA 5500 AIP SSM, page 18-15](#).
- To reset the ASA 5500-X IPS SSP, see [Reloading, Shutting Down, Resetting, and Recovering the ASA 5500-X IPS SSP, page 19-12](#).
- To reset the ASA 5585-X IPS SSP, see [Reloading, Shutting Down, Resetting, and Recovering the ASA 5585-X IPS SSP, page 20-12](#).

## Displaying Command History

Use the **show history** command to obtain a list of the commands you have entered in the current menu. The maximum number of commands in the list is 50. To obtain a list of the commands you have used recently, follow these steps:

- 
- Step 1** Log in to the CLI.
- Step 2** Show the history of the commands you have used in EXEC mode, for example.
- ```
sensor# show history
clear line
configure terminal
show history
```

Step 3 Show the history of the commands you have used in network access mode, for example.

```
sensor# configure terminal
sensor (config)# service network-access
sensor (config-net)# show history
show settings
show settings terse
show settings | include profile-name|ip-address
exit
show history
sensor (config-net)#
```

Displaying Hardware Inventory

Use the **show inventory** command to display PEP information. This command displays the UDI information that consists of the PID, the VID, and the SN of your sensor. If your sensor supports SFP/SFP+ modules and Regex accelerator cards, they are also displayed. PEP information provides an easy way to obtain the hardware version and serial number through the CLI.

To display PEP information, follow these steps:

Step 1 Log in to the CLI.

Step 2 Display the PEP information. You can use this information when dealing with TAC.

```
sensor# show inventory
```

```
Name: "Chassis", DESCR: "IPS 4255 Intrusion Prevention Sensor"
PID: IPS-4255-K9, VID: V01 , SN: JAB0815R017
```

```
Name: "Power Supply", DESCR: ""
PID: ASA-180W-PWR-AC, VID: V01 , SN: 123456789AB
sensor#
```

```
sensor# show inventory
```

```
Name: "Module", DESCR: "ASA 5500 Series Security Services Module-20"
PID: ASA-SSM-20, VID: V01 , SN: JAB0815R036
sensor#
```

```
sensor# show inventory
```

```
Name: "Chassis", DESCR: "IPS 4240 Appliance Sensor"
PID: IPS-4240-K9, VID: V01 , SN: P3000000653
sensor#
```

```
sensor# show inventory
```

```
Name: `Chassis`, DESCR: `IPS 4345 with SW, 8 GE Data + 1 GE Mgmt, AC Power`
PID: IPS-4345-K9 , VID: V01 , SN: FGL162740GG
```

```
Name: `RegexAccelerator/0`, DESCR: `LCPX8640 (humphrey)`
PID: FCH162177B2 , VID: 33554537, SN: LXXXXXXYYY
```

```
Name: `HwBypassCard`, DESCR: `Hardware bypass card`
PID: PE2G4BPFi35CS , VID: 3.0, SN: , PortOMAC: 00E0ED22FD92
```

```
Name: `power supply 1`, DESCR: `IPS4345 AC Power Supply`
```

```

PID: IPS-4345-PWR-AC      , VID: A0, SN: 003437
sensor#

sensor# show inventory

Name: "Module", DESCR: "IPS 4520- 6 Gig E, 4 10 Gig E SFP+"
PID: IPS-4520-INC-K9      , VID: V01, SN: JAF1547BJTJ

Name: "Chassis", DESCR: "ASA 5585-X"
PID: ASA5585              , VID: V02, SN: JMX15527050

Name: "power supply 0", DESCR: "ASA 5585-X AC Power Supply"
PID: ASA5585-PWR-AC      , VID: V03, SN: POG153700UC

Name: "power supply 1", DESCR: "ASA 5585-X AC Power Supply"
PID: ASA5585-PWR-AC      , VID: V03, SN: POG153700SY

Name: "RegexAccelerator/0", DESCR: "LCPX5110 (LCPX5110)"
PID: LCPX5110             , VID: 335, SN: SL14200225

Name: "RegexAccelerator/1", DESCR: "LCPX5110 (LCPX5110)"
PID: LCPX5110             , VID: 335, SN: SL14200242

Name: "TenGigabitEthernet0/0", DESCR: "10G Based-SR"
PID: SFP-10G-SR          , VID: V03, SN: AGD152740NV

Name: "TenGigabitEthernet0/1", DESCR: "10G Based-SR"
PID: SFP-10G-SR          , VID: V03, SN: AGD152741JT

Name: "TenGigabitEthernet0/2", DESCR: "10G Based-CX-1-5 Passive"
PID: SFP-H10GB-CU5M      , VID: V02, SN: MOC15210458

Name: "TenGigabitEthernet0/3", DESCR: "10G Based-CX-1-5 Passive"
PID: SFP-H10GB-CU5M      , VID: V02, SN: MOC15210458

sensor# show inventory

Name: "Module", DESCR: "IPS 4510- 6 Gig E, 4 10 Gig E SFP+"
PID: IPS-4510-INC-K9      , VID: V01, SN: JAF1546CECE

Name: "Chassis", DESCR: "ASA 5585-X"
PID: ASA5585              , VID: V02, SN: JMX1552705F

Name: "power supply 0", DESCR: "ASA 5585-X AC Power Supply"
PID: ASA5585-PWR-AC      , VID: V03, SN: POG1540001Z

Name: "power supply 1", DESCR: "ASA 5585-X AC Power Supply"
PID: ASA5585-PWR-AC      , VID: V03, SN: POG1540000B

Name: "RegexAccelerator/0", DESCR: "LCPX5110 (LCPX5110)"
PID: LCPX5110             , VID: 335, SN: SL14200223

Name: "TenGigabitEthernet0/0", DESCR: "10G Based-SR"
PID: SFP-10G-SR          , VID: V03, SN: AGD152740KZ

Name: "TenGigabitEthernet0/1", DESCR: "10G Based-SR"
PID: SFP-10G-SR          , VID: V03, SN: AGD15264272

Name: "TenGigabitEthernet0/2", DESCR: "1000Based-SX"
PID: FTLF8519P2BCL-CS    , VID: 000, SN: FNS110210C1

sensor# show inventory

Name: "Chassis", DESCR: "IPS 4360 with SW, 8 GE Data + 1 GE Mgmt"

```

```

PID: IPS-4360          , VID: V01 , SN: FGL162740J6

Name: "RegexAccelerator/0", DESCR: "LCPX8640 (humphrey)"
PID: FCH162077NK      , VID: 33554537, SN: LXXXXXXYYY

Name: "power supply 1", DESCR: "IPS4360 AC Power Supply "
PID: IPS-4360-PWR-AC   , VID: 0700A, SN: 25Y1Y8

Name: "power supply 2", DESCR: "IPS4360 AC Power Supply "
PID: IPS-4360-PWR-AC   , VID: 0700A, SN: 25Y1Y9

```

Tracing the Route of an IP Packet



Caution

There is no command interrupt available for this command. It must run to completion.

Use the **trace ip_address count** command to display the route an IP packet takes to a destination. The *ip_address* option is the address of the system to trace the route to. The *count* option lets you define how many hops you want to take. The default is 4. The valid values are 1 to 256. To trace the route of an IP packet, follow these steps:

Step 1 Log in to the CLI.

Step 2 Display the route of IP packet you are interested in.

```

sensor# trace 10.0.0.1
traceroute to 10.0.0.1 (10.0.0.1), 4 hops max, 40 byte packets
 1 192.0.2.2 (192.0.2.2) 0.267 ms 0.262 ms 0.236 ms
 2 192.0.2.12 (192.0.2.12) 0.24 ms * 0.399 ms
 3 * 192.0.2.12 (192.0.2.12) 0.424 ms *
 4 192.0.2.12 (192.0.2.12) 0.408 ms * 0.406 ms
sensor#

```

Step 3 To configure the route to take more hops than the default of 4, use the *count* option.

```

sensor# trace 10.0.0.1 8
traceroute to 10.0.0.1 (10.0.0.1), 8 hops max, 40 byte packets
 1 192.0.2.2 (192.0.2.2) 0.35 ms 0.261 ms 0.238 ms
 2 192.0.2.12 (192.0.2.12) 0.36 ms * 0.344 ms
 3 * 192.0.2.12 (192.0.2.12) 0.465 ms *
 4 192.0.2.12 (192.0.2.12) 0.319 ms * 0.442 ms
 5 * 192.0.2.12 (192.0.2.12) 0.304 ms *
 6 192.0.2.12 (192.0.2.12) 0.527 ms * 0.402 ms
 7 * 192.0.2.12 (192.0.2.12) 0.39 ms *
 8 192.0.2.12 (192.0.2.12) 0.37 ms * 0.486 ms
sensor#

```

Displaying Submode Settings

Use the **show settings [terse]** command in any submode to view the contents of the current configuration.

To display the current configuration settings for a submode, follow these steps:

-
- Step 1** Log in to the CLI.
- Step 2** Show the current configuration for ARC submode.

```

sensor# configure terminal
sensor (config)# service network-access
sensor (config-net)# show settings
    general
    -----
    log-all-block-events-and-errors: true <defaulted>
    enable-nvram-write: false <defaulted>
    enable-acl-logging: false <defaulted>
    allow-sensor-block: false <defaulted>
    block-enable: true <defaulted>
    block-max-entries: 250 <defaulted>
    max-interfaces: 250 default: 250
    master-blocking-sensors (min: 0, max: 100, current: 0)
    -----
    never-block-hosts (min: 0, max: 250, current: 0)
    -----
    never-block-networks (min: 0, max: 250, current: 0)
    -----
    block-hosts (min: 0, max: 250, current: 0)
    -----
    block-networks (min: 0, max: 250, current: 0)
    -----
    -----
    user-profiles (min: 0, max: 250, current: 11)
    -----
    profile-name: 2admin
    -----
    enable-password: <hidden>
    password: <hidden>
    username: pix default:
    -----
    profile-name: r7200
    -----
    enable-password: <hidden>
    password: <hidden>
    username: netrangr default:
    -----
    profile-name: insidePix
    -----
    enable-password: <hidden>
    password: <hidden>
    username: <defaulted>
    -----
    profile-name: qatest
    -----
    enable-password: <hidden>
  
```

```

password: <hidden>
username: <defaulted>
-----
profile-name: fwsm
-----
enable-password: <hidden>
password: <hidden>
username: pix default:
-----
profile-name: outsidePix
-----
enable-password: <hidden>
password: <hidden>
username: pix default:
-----
profile-name: cat
-----
enable-password: <hidden>
password: <hidden>
username: <defaulted>
-----
profile-name: rcat
-----
enable-password: <hidden>
password: <hidden>
username: cisco default:
-----
profile-name: nopass
-----
enable-password: <hidden>
password: <hidden>
username: <defaulted>
-----
profile-name: test
-----
enable-password: <hidden>
password: <hidden>
username: pix default:
-----
profile-name: sshswitch
-----
enable-password: <hidden>
password: <hidden>
username: cisco default:
-----
-----
cat6k-devices (min: 0, max: 250, current: 1)
-----
ip-address: 192.0.2.12
-----
communication: telnet default: ssh-3des
nat-address: 0.0.0.0 <defaulted>
profile-name: cat
block-vlans (min: 0, max: 100, current: 1)
-----
vlan: 1
-----
pre-vacl-name: <defaulted>
post-vacl-name: <defaulted>
-----
-----
router-devices (min: 0, max: 250, current: 1)

```

```

-----
ip-address: 192.0.2.25
-----
communication: telnet default: ssh-3des
nat-address: 0.0.0.0 <defaulted>
profile-name: r7200
block-interfaces (min: 0, max: 100, current: 1)
-----
interface-name: fa0/0
direction: in
-----
pre-acl-name: <defaulted>
post-acl-name: <defaulted>
-----
-----
firewall-devices (min: 0, max: 250, current: 2)
-----
ip-address: 192.0.2.30
-----
communication: telnet default: ssh-3des
nat-address: 0.0.0.0 <defaulted>
profile-name: insidePix
-----
ip-address: 192.0.2.3
-----
communication: ssh-3des <defaulted>
nat-address: 0.0.0.0 <defaulted>
profile-name: f1
-----
-----
sensor (config-net)#

```

Step 3 Show the ARC settings in terse mode.

```

sensor(config-net)# show settings terse
general
-----
log-all-block-events-and-errors: true <defaulted>
enable-nvram-write: false <defaulted>
enable-acl-logging: false <defaulted>
allow-sensor-block: false <defaulted>
block-enable: true <defaulted>
block-max-entries: 250 <defaulted>
max-interfaces: 250 default: 250
master-blocking-sensors (min: 0, max: 100, current: 0)
-----
never-block-hosts (min: 0, max: 250, current: 0)
-----
never-block-networks (min: 0, max: 250, current: 0)
-----
block-hosts (min: 0, max: 250, current: 0)
-----
block-networks (min: 0, max: 250, current: 0)
-----
-----
user-profiles (min: 0, max: 250, current: 11)
-----

```



```

profile-name: 2admin
profile-name: r7200
profile-name: insidePix
profile-name: gatest
profile-name: fwsm
profile-name: outsidePix
profile-name: cat
profile-name: rcat
profile-name: nopass
profile-name: test
profile-name: sshswitch
-----
cat6k-devices (min: 0, max: 250, current: 1)
-----
ip-address: 192.0.2.12
-----
router-devices (min: 0, max: 250, current: 1)
-----
ip-address: 192.0.2.25
-----
firewall-devices (min: 0, max: 250, current: 2)
-----
ip-address: 192.0.2.30
ip-address: 192.0.2.3
-----
sensor(config-net)#

```

Step 4 You can use the **include** keyword to show settings in a filtered output, for example, to show only profile names and IP addresses in the ARC configuration.

```

sensor(config-net)# show settings | include profile-name|ip-address
profile-name: 2admin
profile-name: r7200
profile-name: insidePix
profile-name: gatest
profile-name: fwsm
profile-name: outsidePix
profile-name: cat
profile-name: rcat
profile-name: nopass
profile-name: test
profile-name: sshswitch
ip-address: 192.0.2.12
profile-name: cat
ip-address: 192.0.2.25
profile-name: r7200
ip-address: 192.0.2.30
profile-name: insidePix
ip-address: 192.0.2.3
profile-name: test
sensor(config-net)#

```




Configuring the ASA 5500 AIP SSM

This chapter contains procedures that are specific to configuring the ASA 5500 AIP SSM. It contains the following sections:

- [ASA 5500 AIP SSM Notes and Caveats, page 18-1](#)
- [ASA 5500 AIP SSM Configuration Sequence, page 18-2](#)
- [Verifying ASA 5500 AIP SSM Initialization, page 18-3](#)
- [Creating Virtual Sensors for the ASA 5500 AIP SSM, page 18-4](#)
- [Sending Traffic to the ASA 5500 AIP SSM, page 18-10](#)
- [The Adaptive Security Appliance, ASA 5500 AIP SSM, and Bypass Mode, page 18-12](#)
- [The ASA 5500 AIP SSM and the Normalizer Engine, page 18-13](#)
- [ASA 5500 AIP SSM Failover Scenarios, page 18-13](#)
- [The ASA 5500 AIP SSM and the Data Plane, page 18-15](#)
- [The ASA 5500 AIP SSM and Jumbo Packets, page 18-15](#)
- [Reloading, Shutting Down, Resetting, and Recovering the ASA 5500 AIP SSM, page 18-15](#)
- [New and Modified Commands, page 18-16](#)

ASA 5500 AIP SSM Notes and Caveats

The following notes and caveats apply to configuring the ASA 5500 AIP SSM:

- All IPS platforms allow ten concurrent CLI sessions.
- Cisco Adaptive Security Appliance Software 7.2.3 or later supports virtualization.
- The **allocate-ips** command does not apply to single mode. In this mode, the adaptive security appliance accepts any virtual sensor named in a **policy-map** command.
- Anomaly detection is disabled by default in IPS 7.1(2)E4 and later. You must enable it to configure or apply an anomaly detection policy. Enabling anomaly detection results in a decrease in performance.
- You cannot allocate the same virtual sensor twice in a context.
- You can only configure one default virtual sensor per context. You must turn off the default flag of an existing default virtual sensor before you can designate another virtual sensor as the default.

- IPS appliances reset both the attacker and victim when the Reset TCP Connection is selected and they reset the victim when Deny Connection Inline is selected. For the ASA IPS modules, TCP resets are sent by the ASA. The ASA resets the server, which in some cases is the attacker and in others the victim. The ASA does not always reset the client. The TCP RST packet, which is automatically generated with a reset action, should be sent to both the target and the attacker. However, when the ASA IPS modules are in inline mode, and when signature 6251/0 is triggered, the RST packet generated by Reset TCP Connection is sent to the attacker only.

TCP Reset Differences Between IPS Appliances and ASA IPS Modules

The IPS appliance sends TCP reset packets to both the attacker and victim when reset-tcp-connection is selected. The IPS appliance sends a TCP reset packet only to the victim under the following circumstances:

- When a deny-packet-inline or deny-connection-inline is selected
- When TCP-based signatures and reset-tcp-connection have NOT been selected

In the case of the ASA 5500 AIP SSM, the TCP reset request is sent to the ASA, and then the ASA sends the TCP reset packets. The ASA sends TCP reset packets to both the attacker and victim when the reset-tcp-connection is selected. When deny-packet-inline or deny-connection-inline is selected, the ASA sends the TCP reset packet to either the attacker or victim depending on the configuration of the signature. Signatures configured to swap the attacker and victim when reporting the alert can cause the ASA to send the TCP reset packet to the attacker.

Reloading IPS Messages

The following messages generated during some IPS signature and global correlation updates for IPS 7.1 and later on the ASA 5500 AIP SSM can cause confusion since the IPS is not reloading:

```
ASA5585-SSP-IPS20 Module in slot 1, application up "IPS", version "7.1(1)E4" Normal
Operation
ASA5585-SSP-IPS20 Module in slot 1, application reloading "IPS", version "7.1(1)E4" Config
Change
```

These messages are generated during some, but not all, of the global correlation updates that are attempted every five minutes. This is expected behavior. There is a global correlation check every five minutes, but there may not be an update available, thus the message appears every hour or so. When a global correlation update actually takes place, a message is sent from the IPS to the ASA indicating that a configuration change is taking place.

ASA 5500 AIP SSM Configuration Sequence

Perform the following tasks to configure the ASA 5500 AIP SSM:

1. Obtain and install the current IPS software if your software is not up to date.
2. Obtain and install the license key.
3. Log (session) in to the ASA 5500 AIP SSM.
4. Run the **setup** command to initialize the ASA 5500 AIP SSM.
5. Verify initialization for the ASA 5500 AIP SSM.
6. (Optional) If you have Cisco Adaptive Security Appliance Software 7.2.3 or later, configure multiple virtual sensors.
7. Configure the adaptive security appliance to send IPS traffic to the ASA 5500 AIP SSM.
8. Perform other initial tasks, such as adding users, trusted hosts, and so forth.

9. Configure intrusion prevention.
10. Configure global correlation.
11. Configure global correlation.
12. Perform miscellaneous tasks to keep your ASA 5500 AIP SSM running smoothly.
13. Upgrade the IPS software with new signature updates and service packs as they become available.
14. Reimage the ASA 5500 AIP SSM when needed.

For More Information

- For the procedure for logging in to the ASA 5500 AIP SSM, see [Chapter 2, “Logging In to the Sensor.”](#)
- For the procedure for running the **setup** command, see [Advanced Setup for the ASA 5500 AIP SSM, page 3-14.](#)
- For the procedure for verifying ASA 5500 AIP SSM initialization, see [Verifying ASA 5500 AIP SSM Initialization, page 18-3.](#)
- For the procedure for creating virtual sensors, see [Creating Virtual Sensors for the ASA 5500 AIP SSM, page 18-4.](#)
- For the procedure for configuring ASA to send traffic to the ASA 5500 AIP SSM, see [Sending Traffic to the ASA 5500 AIP SSM, page 18-10.](#)
- For the procedures for setting up the sensor, see [Chapter 4, “Setting Up the Sensor.”](#)
- For the procedures for configuring intrusion prevention, see [Chapter 7, “Configuring Event Action Rules,”](#) [Chapter 8, “Defining Signatures,”](#) [Chapter 9, “Configuring Anomaly Detection,”](#) and [Chapter 14, “Configuring Attack Response Controller for Blocking and Rate Limiting.”](#)
- For the procedures for configuring global correlation, see [Chapter 10, “Configuring Global Correlation.”](#)
- For the procedures for keeping your ASA 5500 AIP SSM running smoothly, see [Chapter 17, “Administrative Tasks for the Sensor.”](#)
- For more information on how to obtain Cisco IPS software, see [Chapter 21, “Obtaining Software.”](#)
- For the procedure for reimaging the ASA 5500 AIP SSM, see [Installing the System Image for the ASA 5500 AIP SSM, page 22-28.](#)

Verifying ASA 5500 AIP SSM Initialization

You can use the **show module slot details** command to verify that you have initialized the ASA 5500 AIP SSM and to verify that you have the correct software version.

To verify initialization, follow these steps:

-
- Step 1** Log in to the adaptive security appliance.
- Step 2** Obtain the details about the ASA 5500 AIP SSM.

```
asa# show module 1 details
ASA 5500 Series Security Services Module-10
Model: ASA-SSM-10
Hardware version: 1.0
Serial Number: JAB09370212
Firmware version: 1.0(10)0
```

```

Software version: 7.0(1)E3
MAC Address Range: 0012.d948.fe73 to 0012.d948.fe73
App. name: IPS
App. Status: Up
App. Status Desc:
App. version: 6.2(1)E3
Data plane Status: Up
Status: Up
Mgmt IP addr: 171.69.36.171
Mgmt web ports: 443
Mgmt TLS enabled: true
asa#

```

Step 3 Confirm the information.

Creating Virtual Sensors for the ASA 5500 AIP SSM



Note

Cisco Adaptive Security Appliance Software 7.2.3 or later supports virtualization.

This section describes how to create virtual sensors on the ASA 5500 AIP SSM, and contains the following topics:

- [ASA 5500 AIP SSM and Virtualization, page 18-4](#)
- [ASA 5500 AIP SSM Virtual Sensor Configuration Sequence, page 18-5](#)
- [Creating Virtual Sensors, page 18-5](#)
- [Assigning Virtual Sensors to Adaptive Security Appliance Contexts, page 18-7](#)

ASA 5500 AIP SSM and Virtualization

The ASA 5500 AIP SSM has one sensing interface, GigabitEthernet 0/1. When you create multiple virtual sensors, you must assign this interface to only one virtual sensor. For the other virtual sensors you do not need to designate an interface.

After you create virtual sensors, you must map them to a security context on the adaptive security appliance using the **allocate-ips** command. You can map many security contexts to many virtual sensors.



Note

The **allocate-ips** command does not apply to single mode. In this mode, the adaptive security appliance accepts any virtual sensor named in a **policy-map** command.

The **allocate-ips** command adds a new entry to the security context database. A warning is issued if the specified virtual sensor does not exist; however, the configuration is allowed. The configuration is checked again when the **service-policy** command is processed. If the virtual sensor is not valid, the **fail-open** policy is enforced.

ASA 5500 AIP SSM Virtual Sensor Configuration Sequence

Follow this sequence to create virtual sensors on the ASA 5500 AIP SSM, and to assign them to adaptive security appliance contexts:

1. Configure up to four virtual sensors.
2. Assign the ASA 5500 AIP SSM sensing interface (GigabitEthernet 0/1) to one of the virtual sensors.
3. (Optional) Assign virtual sensors to different contexts on the adaptive security appliance.
4. Use MPF to direct traffic to the targeted virtual sensor.

Creating Virtual Sensors



Note

You can create four virtual sensors.

Use the **virtual-sensor** *name* command in service analysis engine submode to create virtual sensors on the ASA 5500 AIP SSM. You assign policies (anomaly detection, event action rules, and signature definition) to the virtual sensor. You can use the default policies, *ad0*, *rules0*, or *sig0*, or you can create new policies. Then you assign the sensing interface, GigabitEthernet 0/1 for the ASA 5500 AIP SSM to one virtual sensor.

The following options apply:

- **anomaly-detection**—Specifies the anomaly detection parameters:
 - **anomaly-detection-name** *name*—Specifies the name of the anomaly detection policy.
 - **operational-mode**—Specifies the anomaly detection mode (**inactive**, **learn**, **detect**).



Note

Anomaly detection is disabled by default in IPS 7.1(2)E4 and later. You must enable it to configure or apply an anomaly detection policy. Enabling anomaly detection results in a decrease in performance.

- **description**—Provides a description of the virtual sensor.
- **event-action-rules**—Specifies the name of the event action rules policy.
- **signature-definition**—Specifies the name of the signature definition policy.
- **physical-interfaces**—Specifies the name of the physical interface.
- **no**—Removes an entry or selection.

Creating Virtual Sensors

To create a virtual sensor on the ASA 5500 AIP SSM, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter service analysis mode.

```
sensor# configure terminal
sensor(config)# service analysis-engine
sensor(config-ana)#
```

Step 3 Add a virtual sensor.

```
sensor(config-ana)# virtual-sensor vs1
sensor(config-ana-vir)#
```

Step 4 Add a description for this virtual sensor.

```
sensor(config-ana-vir)# description virtual sensor 1
```

Step 5 Assign an anomaly detection policy and operational mode to this virtual sensor if you have enabled anomaly detection. If you do not want to use the default anomaly detection policy, ad0, you must create a new one using the **service anomaly-detection** *name* command, for example, ad1.

```
sensor(config-ana-vir)# anomaly-detection
sensor(config-ana-vir-ano)# anomaly-detection-name ad0
sensor(config-ana-vir-ano)# operational-mode learn
```

Step 6 Assign an event action rules policy to this virtual sensor. If you do not want to use the default event action rules policy, rules0, you must create a new one using the **service event-action-rules** *name* command, for example, rules1

```
sensor(config-ana-vir-ano)# exit
sensor(config-ana-vir)# event-action-rules rules0
```

Step 7 Assign a signature definition policy to this virtual sensor. If you do not want to use the default signature definition policy, sig0, you must create a new one using the **service signature-definition** *name* command, for example sig1.

```
sensor(config-ana-vir)# signature-definition sig0
```

Step 8 Assign the interface to one virtual sensor. By default the sensing interface is already assigned to the default virtual sensor, vs0. You must remove it from the default virtual sensor to assign it to another virtual sensor that you create.

```
sensor(config-ana-vir)# physical-interface GigabitEthernet0/1
```

Step 9 Verify the virtual sensor settings.

```
sensor(config-ana-vir)# show settings
name: vs1
-----
description: virtual sensor 1 default:
signature-definition: sig1 default: sig0
event-action-rules: rules1 default: rules0
anomaly-detection
-----
anomaly-detection-name: ad1 default: ad0
operational-mode: learn default: detect
-----
physical-interface (min: 0, max: 999999999, current: 2)
-----
name: GigabitEthernet0/1
subinterface-number: 0 <defaulted>
-----
logical-interface (min: 0, max: 999999999, current: 0)
-----
-----
sensor(config-ana-vir)#
```

Step 10 Exit analysis engine mode.

```
sensor(config-ana-vir)# exit
```



```
sensor(config-ana)# exit
Apply Changes:[yes]:
sensor(config)#
```

Step 11 Press **Enter** to apply the changes or enter **no** to discard them.

For More Information

- For the procedures for creating and configuring anomaly detection policies, see [Working With Anomaly Detection Policies, page 9-9](#).
- For the procedure for creating and configuring event action rules policies, see [Working With Event Action Rules Policies, page 7-8](#).
- For the procedure for creating and configuring signature definitions, [Working With Signature Definition Policies, page 8-2](#).

Assigning Virtual Sensors to Adaptive Security Appliance Contexts

After you create virtual sensors on the ASA 5500 AIP SSM, you must assign the virtual sensors to a security context on the adaptive security appliance.

The following options apply:

- **[no] allocate-ips sensor_name [mapped_name] [default]**—Allocates a virtual sensor to a security context. Supported modes are multiple mode, system context, and context submode.



Note You cannot allocate the same virtual sensor twice in a context.

- *sensor_name*—Specifies the name of the virtual sensor configured on the ASA 5500 AIP SSM. You receive a warning message if the name is not valid.
- *mapped_name*—Specifies the name by which the security context knows the virtual sensor.



Note The mapped name is used to hide the real name of the virtual sensor from the context, usually done for reasons of security or convenience to make the context configuration more generic. If no mapped name is used, the real virtual sensor name is used. You cannot reuse a mapped name for two different virtual sensors in a context.

- **no**—De-allocates the sensor, looks through the policy map configurations, and deletes any IPS subcommand that refers to it.
- **default**—Specifies this virtual sensor as the default. All legacy IPS configurations that do not specify a virtual sensor are mapped to this virtual sensor.



Caution

You can only configure one default virtual sensor per context. You must turn off the default flag of an existing default virtual sensor before you can designate another virtual sensor as the default.

- **clear configure allocate-ips**—Removes the configuration.
- **allocate-ips?**—Displays the list of configured virtual sensors.

- **show context [detail]**—Updated to display information about virtual sensors. In user context mode, a new line is added to show the mapped names of all virtual sensors that have been allocated to this context. In system mode, two new lines are added to show the real and mapped names of virtual sensors allocated to this context.

You can assign multiple virtual sensors to a context. Multiple contexts can share one virtual sensor, and when sharing, the contexts can have different mapped names (aliases) for the same virtual sensor. The following procedure demonstrates how to add three security contexts in multiple mode and how to assign virtual sensors to these security contexts.

Assigning Virtual Sensors to Contexts

To assign virtual sensors to adaptive security appliance contexts in multiple mode for the ASA 5500 AIP SSM, follow these steps:

Step 1 Log in to the adaptive security appliance.

Step 2 Display the list of available virtual sensors.

```
asa# show ips
Sensor Name      Sensor ID
-----
vs0              1
vs1              2
asa#
```

Step 3 Enter configuration mode.

```
asa# configure terminal
asa(config)#
```

Step 4 Enter multiple mode.

```
asa(config)# mode multiple
WARNING: This command will change the behavior of the device
WARNING: This command will initiate a Reboot
Proceed with change mode? [confirm] yes
asa(config)#
```

Step 5 Add three context modes to multiple mode.

```
asa(config)# admin-context admin
Creating context 'admin'... Done. (13)
asa(config)# context admin
asa(config-ctx)# allocate-interface GigabitEthernet0/0.101
asa(config-ctx)# allocate-interface GigabitEthernet0/1.102
asa(config-ctx)# allocate-interface Management0/0
asa(config-ctx)# config-url disk0:/admin.cfg
Cryptochecksum (changed): 0c34dc67 f413ad74 e297464a db211681
INFO: Context admin was created with URL disk0:/admin.cfg
INFO: Admin context will take some time to come up .... please wait.
asa(config-ctx)#
asa(config-ctx)# context c2
Creating context 'c2'... Done. (14)
asa(config-ctx)# allocate-interface GigabitEthernet0/0.103
asa(config-ctx)# allocate-interface GigabitEthernet0/1.104
asa(config-ctx)# config-url disk0:/c2.cfg

WARNING: Could not fetch the URL disk0:/c2.cfg
INFO: Creating context with default config
asa(config-ctx)#
asa(config-ctx)# context c3
Creating context 'c3'... Done. (15)
```

```
asa(config-ctx)# all
asa(config-ctx)# allocate-in
asa(config-ctx)# allocate-interface g0/2
asa(config-ctx)# allocate-interface g0/3
asa(config-ctx)# config-url disk0:/c3.cfg

WARNING: Could not fetch the URL disk0:/c3.cfg
INFO: Creating context with default config
asa(config-ctx)#
```

Step 6 Assign virtual sensors to the security contexts.

```
asa(config)# context admin
asa(config-ctx)# allocate-ips vs0 adminvs0
asa(config-ctx)# exit
asa(config)# context c2
asa(config-ctx)# allocate-ips vs1 c2vs1
asa(config)# context c3
asa(config-ctx)# allocate-ips vs0 c3vs0
asa(config-ctx)# allocate-ips vs1 c3vs1
asa(config-ctx)#
```

Step 7 Configure MPF for each context.



Note The following example shows context 3 (c3).

```
asa(config)# context c3
asa/c3(config)# class-map any
asa/c3(config-cmap)# match access-list any
asa/c3(config-cmap)# exit
asa/c3(config)# policy-map ips_out
asa/c3(config-pmap)# class any
asa/c3(config-pmap-c)# ips promiscuous fail-close sensor c3vs1
asa/c3(config-pmap-c)# policy-map ips_in
asa/c3(config-pmap)# class any
asa/c3(config-pmap-c)# ips inline fail-open sensor c3vs0
asa/c3(config-pmap-c)# service-policy ips_out interface outside
asa/c3(config)# service-policy ips_in interface inside
asa/c3(config)#
```

Step 8 Confirm the configuration.

```
asa/c3(config)# exit
asa(config)# show ips detail
```

Sensor Name	Sensor ID	Allocated To	Mapped Name
-----	-----	-----	-----
vs0	1	admin	adminvs0
		c3	c3vs0
vs1	2	c2	c2vs1
		c3	c3vs1

```
asa(config)#
```

Sending Traffic to the ASA 5500 AIP SSM

**Note**

This section applies to Cisco Adaptive Security Appliance Software 7.2 or earlier for ASA 5500 AIP SSM.

This section describes how to configure ASA 5500 AIP SSM to receive IPS traffic from the adaptive security appliance (inline or promiscuous mode) if it is running Cisco Adaptive Security Appliance Software 7.2 or earlier. It contains the following topics:

- [Adaptive Security Appliance and the ASA 5500 AIP SSM, page 18-10](#)
- [Configuring the Adaptive Security Appliance to Send IPS Traffic to the ASA 5500 AIP SSM, page 18-10](#)

Adaptive Security Appliance and the ASA 5500 AIP SSM

The adaptive security appliance diverts packets to ASA 5500 AIP SSM just before the packet exits the egress interface (or before VPN encryption occurs, if configured) and after other firewall policies are applied. For example, packets that are blocked by an access list are not forwarded to ASA 5500 AIP SSM.

You can configure ASA 5500 AIP SSM to inspect traffic in inline or promiscuous mode and in fail-open or fail-over mode. You can use the adaptive security appliance CLI or ASDM to configure IPS traffic inspection.

Perform these steps on the adaptive security appliance to identify traffic to be diverted to and inspected by ASA 5500 AIP SSM:

1. Create or use an existing ACL.
2. Use the **class-map** command to define the IPS traffic class.
3. Use the **policy-map** command to create an IPS policy map by associating the traffic class with one or more actions.
4. Use the **service-policy** command to create an IPS security policy by associating the policy map with one or more interfaces.

Configuring the Adaptive Security Appliance to Send IPS Traffic to the ASA 5500 AIP SSM

To send traffic from the adaptive security appliance to ASA 5500 AIP SSM for the IPS to inspect, follow these steps:

Step 1 Log in to the adaptive security appliance.

Step 2 Enter configuration mode.

```
asa# configure terminal
```

Step 3 Create an IPS access list.

```
asa(config)# access-list IPS permit ip any any
```

- Step 4** Define an IPS class map to identify the traffic you want to send to ASA 5500 AIP SSM.

```
asa(config)# class-map class_map_name
```

Example

```
asa(config)# class-map ips_class
```



Note You can create multiple traffic class maps to send multiple traffic classes to ASA 5500 AIP SSM.

- Step 5** Specify the traffic in the class map.

```
asa(config-cmap)# match parameter
```

Example

```
asa(config-cmap)# match [access-list | any]
```

- Step 6** Add an IPS policy map that sets the actions to take with the class map traffic.

```
asa(config-cmap)# policy-map policy_map_name
```

Example

```
asa(config-cmap)# policy-map ips_policy
```

- Step 7** Identify the class map you created in Step 4.

```
asa(config-pmap)# class class_map_name
```

Example

```
asa(config-pmap)# class ips_class
```

- Step 8** Assign traffic to ASA 5500 AIP SSM.

```
asa(config-pmap-c)# ips {inline | promiscuous} [fail-close | fail-open]
```

Example

```
asa(config-pmap-c)# ips promiscuous fail-close
```

- Step 9** (Optional) If you created multiple traffic class maps for IPS traffic, you can specify another class.

```
asa(config-pmap)# class class_map_name_2
```

Example

```
asa(config-pmap)# class ips_class_2
```

- Step 10** (Optional) Specify the second class of traffic to send to ASA 5500 AIP SSM.

```
asa(config-pmap-c)# ips {inline | promiscuous} [fail-close | fail-open]
```

Example

```
asa(config-pmap-c)# ips promiscuous fail-close
```

- Step 11** Activate the IPS service policy map on one or more interfaces.

```
asa(config)# service-policy polycymap_name {global | interface interface_name}
```

Example

```
asa(config)# service-policy tcp_bypass_policy outside
```

Step 12 Verify the settings.

```
asa# show running-config
```

Step 13 Exit and save the configuration.

For More Information

For more information on bypass mode, see [The Adaptive Security Appliance, ASA 5500 AIP SSM, and Bypass Mode, page 18-12](#).

The Adaptive Security Appliance, ASA 5500 AIP SSM, and Bypass Mode

The following conditions apply to bypass mode configuration, the adaptive security appliance, and the ASA 5500 AIP SSM.

The SensorApp Fails OR a Configuration Update is Taking Place

The following occurs when bypass is set to Auto or Off on the ASA IPS module:

- Bypass Auto—Traffic passes without inspection.
- Bypass Off—If the adaptive security appliance is configured for failover, then the adaptive security appliance fails over.

If the adaptive security appliance is not configured for failover or failover is not possible:

- If set to fail-open, the adaptive security appliance passes traffic without sending it to the ASA IPS module.
- If set to fail-close, the adaptive security appliance stops passing traffic until the ASA IPS module is restarted or completes reconfiguration.



Note

When bypass is set to On, traffic passes without inspection regardless of the state of the SensorApp.

The ASA 5500 AIP SSM Is Rebooted or Not Responding

The following occurs according to how the adaptive security appliance is configured for failover:

- If the adaptive security appliance is configured for failover, then the adaptive security appliance fails over.
- If the adaptive security appliance is not configured for failover or failover is not possible:
 - If set to fail-open, the adaptive security appliance passes traffic without sending it to the ASA IPS module.
 - If set to fail-close, the adaptive security appliance stops passing traffic until the ASA IPS module is restarted.

For More Information

For more information on bypass mode, see [Configuring Inline Bypass Mode, page 5-38](#).

The ASA 5500 AIP SSM and the Normalizer Engine

The majority of the features in the Normalizer engine are not used on the ASA 5500 AIP SSM, because the ASA itself handles the normalization. Packets on the ASA IPS modules go through a special path in the Normalizer that only reassembles fragments and puts packets in the right order for the TCP stream. The Normalizer does not do any of the normalization that is done on an inline IPS appliance, because that causes problems in the way the ASA handles the packets.

The following Normalizer engine signatures are not supported:

- 1300.0
- 1304.0
- 1305.0
- 1307.0
- 1308.0
- 1309.0
- 1311.0
- 1315.0
- 1316.0
- 1317.0
- 1330.0
- 1330.1
- 1330.2
- 1330.9
- 1330.10
- 1330.12
- 1330.14
- 1330.15
- 1330.16
- 1330.17
- 1330.18

For More Information

For detailed information about the Normalizer engine, see [Normalizer Engine, page B-37](#).

ASA 5500 AIP SSM Failover Scenarios

The following failover scenarios apply to the ASA in the event of configuration changes, signature/signature engine updates, service packs, and SensorApp crashes on the ASA 5500 AIP SSM.

Single ASA in Fail-Open Mode

- If the ASA is configured in fail-open mode for the ASA 5500 AIP SSM, and the ASA 5500 AIP SSM experiences a configuration change or signature/signature engine update, traffic is passed through the ASA without being inspected.
- If the ASA is configured in fail-open mode for the ASA 5500 AIP SSM, and the ASA 5500 AIP SSM experiences a SensorApp crash or a service pack upgrade, traffic is passed through the ASA without being inspected.

Single ASA in Fail-Close Mode

- If the ASA is configured in fail-close mode for the ASA 5500 AIP SSM, and the ASA 5500 AIP SSM experiences a configuration change or a signature/signature engine update, traffic is stopped from passing through the ASA.
- If the ASA is configured in fail-close mode for the ASA 5500 AIP SSM, and the ASA 5500 AIP SSM experiences a SensorApp crash or a service pack upgrade, traffic is stopped from passing through the ASA.

Two ASAs in Fail-Open Mode

- If the ASAs are configured in fail-open mode and if the ASA 5500 AIP SSM on the active ASA experiences a configuration change or a signature/signature engine update, traffic is still passed through the active ASA without being inspected. Failover is not triggered.
- If the ASAs are configured in fail-open mode, and if the ASA 5500 AIP SSM on the active ASA experiences a SensorApp crash or a service pack upgrade, failover is triggered and traffic passes through the ASA 5500 AIP SSM that was previously the standby module.

Two ASAs in Fail-Close Mode

- If the ASAs are configured in fail-close mode, and if the ASA 5500 AIP SSM on the active ASA experiences a configuration change or a signature/signature engine update, traffic is stopped from passing through the active ASA. No failover is triggered.
- If the ASAs are configured in fail-close mode, and if the ASA 5500 AIP SSM on the active ASA experiences a SensorApp crash or a service pack upgrade, failover is triggered and traffic passes through the module that was previously the standby for the ASA 5500 AIP SSM.

Configuration Examples

Use the following configuration for the primary ASA:

```
interface GigabitEthernet0/7
  description LAN Failover Interface

failover
failover lan unit primary
failover lan interface folink GigabitEthernet0/7
failover interface ip folink 172.27.48.1 255.255.255.0 standby 172.27.48.2
```

Use the following configuration for the secondary ASA:

```
interface GigabitEthernet0/7
  description LAN Failover Interface

failover
failover lan unit secondary
failover lan interface folink GigabitEthernet0/7
failover interface ip folink 172.27.48.1 255.255.255.0 standby 172.27.48.2
```


The ASA 5500 AIP SSM and the Data Plane

Symptom The ASA 5500 AIP SSM data plane is kept in the Up state while applying signature updates. You can check the ASA 5500 AIP SSM data plane status by using the **show module** command during signature updates.

Possible Cause Bypass mode is set to off. The issue is seen when updating signatures, and when you use either CSM or IDM to apply signature updates. This issue is not seen when upgrading IPS system software.

The ASA 5500 AIP SSM and Jumbo Packets

The jumbo packet count in the **show interface** command output from the lines `Total Jumbo Packets Received` and `Total Jumbo Packets Transmitted` for ASA IPS modules may be larger than expected due to some packets that were almost jumbo size on the wire being counted as jumbo size by the IPS. This miscount is a result of header bytes added to the packet by the ASA before the packet is transmitted to the IPS. For IPv4, 58 bytes of header data are added. For IPv6, 78 bytes of header data are added. The ASA removes the added IPS header before the packet leaves the ASA.

Reloading, Shutting Down, Resetting, and Recovering the ASA 5500 AIP SSM



Note

You can enter the **hw-module** commands from privileged EXEC mode or from global configuration mode. You can enter the commands in single routed mode and single transparent mode. For adaptive security appliances operating in multi-mode (routed or transparent multi-mode) you can only execute the **hw-module** commands from the system context (not from administrator or user contexts).

Use the following commands to reload, shut down, reset, recover the password, and recover the ASA 5500 AIP SSM directly from the adaptive security appliance:

- **hw-module module slot_number reload**—This command reloads the software on the ASA 5500 AIP SSM without doing a hardware reset. It is effective only when the module is in the Up state.
- **hw-module module slot_number shutdown**—This command shuts down the software on the ASA 5500 AIP SSM. It is effective only when the module is in Up state.
- **hw-module module slot_number reset**—This command performs a hardware reset of the ASA 5500 AIP SSM. It is applicable when the module is in the Up/Down/Unresponsive/Recover states.
- **hw-module module slot_number password-reset**—This command restores the cisco CLI account password on the ASA 5500 AIP SSM to the default **cisco**.

- **hw-module module slot_number recover [boot | stop | configure]**—The **recover** command displays a set of interactive options for setting or changing the recovery parameters. To change the parameter or keep the existing setting, press **Enter**.
 - **hw-module module slot_number recover boot**—This command initiates recovery of the ASA 5500 AIP SSM. It is applicable only when the module is in the Up state.
 - **hw-module module slot_number recover stop**—This command stops recovery of the ASA 5500 AIP SSM. It is applicable only when the module is in the Recover state.

**Caution**

If the ASA 5500 AIP SSM recovery needs to be stopped, you must issue the **hw-module module 1 recover stop** command within 30 to 45 seconds after starting the recovery. Waiting any longer can lead to unexpected consequences. For example, the module may come up in the Unresponsive state.

- **hw-module module 1 recover configure**—Use this command to configure parameters for the ASA 5500 AIP SSM recovery. The essential parameters are the IP address and recovery image TFTP URL location.

Example

```
aip-ssm# hardware-module module 1 recover configure
Image URL [tftp://10.89.146.1/IPS-SSM-K9-sys-1.1-a-7.1-1-E4.img]:
Port IP Address [10.89.149.226]:
VLAN ID [0]:
Gateway IP Address [10.89.149.254]:
```

For More Information

For the procedure for recovering the ASA 5500 AIP SSM system image, see [Installing the System Image for the ASA 5500 AIP SSM, page 22-28](#).

New and Modified Commands

This section describes the new and modified Cisco ASA commands that support the ASA 5500 AIP SSM and are used to configure the ASA 5500 AIP SSM.

**Note**

All other Cisco ASA CLI commands are documented in the *Cisco Security Appliance Command Reference* on Cisco.com at http://www.cisco.com/en/US/products/ps6120/prod_command_reference_list.html.

This section contains the following topic:

- [allocate-ips, page 18-16](#)

allocate-ips

To allocate an IPS virtual sensor to a security context if you have the ASA 5500 AIP SSM installed, use the **allocate-ips** command in context configuration mode. To remove a virtual sensor from a context, use the **no** form of this command.

allocate-ips sensor_name [mapped_name] [default]

no allocate-ips sensor_name [mapped_name] [default]

Syntax Description

default	(Optional) Sets one sensor per context as the default sensor; if the context configuration does not specify a sensor name, the context uses this default sensor. You can only configure one default sensor per context. If you want to change the default sensor, enter the no allocate-ips sensor_name command to remove the current default sensor before you allocate a new default sensor. If you do not specify a sensor as the default, and the context configuration does not include a sensor name, then traffic uses the default sensor on the ASA 5500 AIP SSM.
<i>mapped_name</i>	(Optional) Sets a mapped name as an alias for the sensor name that can be used within the context instead of the actual sensor name. If you do not specify a mapped name, the sensor name is used within the context. For security purposes, you might not want the context administrator to know which sensors are being used by the context. Or you might want to genericize the context configuration. For example, if you want all contexts to use sensors called “sensor1” and “sensor2,” then you can map the “highsec” and “lowsec” sensors to sensor1 and sensor2 in context A, but map the “medsec” and “lowsec” sensors to sensor1 and sensor2 in context B.
<i>sensor_name</i>	Sets the sensor name configured on the ASA 5500 AIP SSM. To view the sensors that are configured on the ASA 5500 AIP SSM, enter allocate-ips ? . All available sensors are listed. You can also enter the show ips command. In the system execution space, the show ips command lists all available sensors; if you enter it in the context, it shows the sensors you already assigned to the context. If you specify a sensor name that does not yet exist on the ASA 5500 AIP SSM, you get an error, but the allocate-ips command is entered as is. Until you create a sensor of that name on the ASA 5500 AIP SSM, the context assumes the sensor is down.

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple	
				Context	System
Context configuration	•	•	—	—	•

Command History

Release	Modification
8.0(2)	This command was introduced.

Usage Guidelines

You can assign one or more IPS virtual sensors to each context. Then, when you configure the context to send traffic to the ASA 5500 AIP SSM using the **ips** command, you can specify a sensor that is assigned to the context; you cannot specify a sensor that you did not assign to the context. If you do not assign any sensors to a context, then the default sensor configured on the ASA 5500 AIP SSM is used. You can assign the same sensor to multiple contexts.



Note

You do not need to be in multiple context mode to use virtual sensors; you can be in single mode and use different sensors for different traffic flows.

Examples

The following example assigns sensor1 and sensor2 to context A, and sensor1 and sensor3 to context B. Both contexts map the sensor names to “ips1” and “ips2.” In context A, sensor1 is set as the default sensor, but in context B, no default is set so the default that is configured on the ASA 5500 AIP SSM is used.

```
hostname(config-ctx)# context A
hostname(config-ctx)# allocate-interface gigabitethernet0/0.100 int1
hostname(config-ctx)# allocate-interface gigabitethernet0/0.102 int2
hostname(config-ctx)# allocate-interface gigabitethernet0/0.110-gigabitethernet0/0.115
int3-int8
hostname(config-ctx)# allocate-ips sensor1 ips1 default
hostname(config-ctx)# allocate-ips sensor2 ips2
hostname(config-ctx)# config-url ftp://user1:passw0rd@10.1.1.1/configlets/test.cfg
hostname(config-ctx)# member gold

hostname(config-ctx)# context sample
hostname(config-ctx)# allocate-interface gigabitethernet0/1.200 int1
hostname(config-ctx)# allocate-interface gigabitethernet0/1.212 int2
hostname(config-ctx)# allocate-interface gigabitethernet0/1.230-gigabitethernet0/1.235
int3-int8
hostname(config-ctx)# allocate-ips sensor1 ips1
hostname(config-ctx)# allocate-ips sensor3 ips2
hostname(config-ctx)# config-url ftp://user1:passw0rd@10.1.1.1/configlets/sample.cfg
hostname(config-ctx)# member silver
```

Related Commands

Command	Description
context	Creates a security context in the system configuration and enters context configuration mode.
ips	Diverts traffic to the ASA 5500 AIP SSM for inspection.
show context	Shows a list of contexts (system execution space) or information about the current context.
show ips	Shows the virtual sensors configured on the ASA 5500 AIP SSM.



Configuring the ASA 5500-X IPS SSP

This chapter contains procedures that are specific to configuring the ASA 5500-X IPS SSP. It contains the following sections:

- [Notes and Caveats for ASA 5500-X IPS SSP, page 19-1](#)
- [Configuration Sequence for the ASA 5500-X IPS SSP, page 19-2](#)
- [Verifying Initialization for the ASA 5500-X IPS SSP, page 19-3](#)
- [Creating Virtual Sensors for the ASA 5500-X IPS SSP, page 19-3](#)
- [TCP Reset Differences Between IPS Appliances and ASA IPS Modules, page 19-9](#)
- [Reloading IPS Messages, page 19-9](#)
- [ASA 5500-X IPS SSP Default Gateway, page 19-10](#)
- [Promiscuous Mode and Under Runs, page 19-10](#)
- [The ASA 5500-X IPS SSP and Bypass Mode, page 19-10](#)
- [The ASA 5500-X IPS SSP and the Normalizer Engine, page 19-11](#)
- [The ASA 5500-X IPS SSP and Memory Usage, page 19-12](#)
- [The ASA 5500-X IPS SSP and Jumbo Packets, page 19-12](#)
- [Reloading, Shutting Down, Resetting, and Recovering the ASA 5500-X IPS SSP, page 19-12](#)
- [Health and Status Information, page 19-13](#)
- [ASA 5500-X IPS SSP Failover Scenarios, page 19-15](#)
- [New and Modified Commands, page 19-16](#)

Notes and Caveats for ASA 5500-X IPS SSP

The following notes and caveats apply to configuring the ASA 5500-X IPS SSP:

- The ASA 5500-X IPS SSP is supported in ASA 8.6.1 and later.
- For the ASA 5500-X IPS SSP, normalization is performed by the adaptive security appliance and not the IPS.
- The ASA 5500-X IPS SSP does not support the inline TCP session tracking mode.
- The ASA 5500-X IPS SSP does not support CDP mode.
- Anomaly detection is disabled by default.

- All IPS platforms allow ten concurrent CLI sessions.
- The ASA 5500-X IPS SSP does not support bypass mode. The adaptive security appliance will either fail open, fail close, or fail over depending on the configuration of the adaptive security appliance and the type of activity being done on the IPS.
- The ASA 5500-X IPS SSP (except the ASA 5512-X IPS SSP and the ASA 5515-X IPS SSP) support the String ICMP XL, String TCP XL, and String UDP XL engines. These engines provide optimized operation for these platforms.

Configuration Sequence for the ASA 5500-X IPS SSP

Perform the following tasks to configure the ASA 5500-X IPS SSP:

1. Obtain and install the current IPS software if your software is not up to date.
2. Obtain and install the license key.
3. Log (session) in to the ASA 5500-X IPS SSP.
4. Run the **setup** command to initialize the ASA 5500-X IPS SSP.
5. Verify initialization for the ASA 5500-X IPS SSP.
6. Configure the adaptive security appliance to send IPS traffic to the ASA 5500-X IPS SSP.
7. Perform other initial tasks, such as adding users, trusted hosts, and so forth.
8. Configure intrusion prevention.
9. Configure global correlation.
10. Configure global correlation.
11. Perform miscellaneous tasks to keep your ASA 5500-X IPS SSP running smoothly.
12. Upgrade the IPS software with new signature updates and service packs as they become available.
13. Reimage the ASA 5500-X IPS SSP when needed.

For More Information

- For the procedure for logging in to the ASA 5500-X IPS SSP, see [Chapter 2, “Logging In to the Sensor.”](#)
- For the procedure for running the **setup** command, see [Advanced Setup for the ASA 5500-X IPS SSP, page 3-18.](#)
- For the procedure for verifying initialization for the ASA 5500-X IPS SSP, see [Verifying Initialization for the ASA 5500-X IPS SSP, page 19-3.](#)
- For the procedure for creating virtual sensors, see [Creating Virtual Sensors for the ASA 5500-X IPS SSP, page 19-3.](#)
- For the procedures for setting up the ASA 5500-X IPS SSP, see [Chapter 4, “Setting Up the Sensor.”](#)
- For the procedures for configuring intrusion prevention, see [Chapter 7, “Configuring Event Action Rules,”](#) [Chapter 8, “Defining Signatures,”](#) [Chapter 9, “Configuring Anomaly Detection,”](#) and [Chapter 14, “Configuring Attack Response Controller for Blocking and Rate Limiting.”](#)
- For the procedures for configuring global correlation, see [Chapter 10, “Configuring Global Correlation.”](#)
- For the procedures for keeping your ASA 5500-X IPS SSP running smoothly, see [Chapter 17, “Administrative Tasks for the Sensor.”](#)

- For more information on how to obtain Cisco IPS software, see [Chapter 21, “Obtaining Software.”](#)
- For the procedure for reimaging the ASA 5500-X IPS SSP, see [Installing the System Image for the ASA 5500-X IPS SSP, page 22-31.](#)

Verifying Initialization for the ASA 5500-X IPS SSP

You can use the **show module slot details** command to verify that you have initialized the ASA 5500-X IPS SSP and to verify that you have the correct software version.

To verify initialization, follow these steps:

-
- Step 1** Log in to the adaptive security appliance.
- Step 2** Obtain the details about the ASA 5500-X IPS SSP.

```
asa# show module ips details
Getting details from the Service Module, please wait...

Card Type:          ASA 5555-X IPS Security Services Processor
Model:              ASA5555-IPS
Hardware version:   N/A
Serial Number:      FCH151070GW
Firmware version:   N/A
Software version:   7.1(3)E4
MAC Address Range:  503d.e59c.7ca0 to 503d.e59c.7ca0
App. name:          IPS
App. Status:        Up
App. Status Desc:   Normal Operation
App. version:       7.1(3)E4
Data Plane Status:  Up
Status:             Up
License:            IPS Module Enabled perpetual
Mgmt IP addr:       192.0.2.2
Mgmt Network mask:  255.255.255.0
Mgmt Gateway:       192.0.2.254
Mgmt Access List:   0.0.0.0/0
Mgmt web ports:     443
Mgmt TLS enabled:   true
asa#
```

- Step 3** Confirm the information.
-

Creating Virtual Sensors for the ASA 5500-X IPS SSP

This section describes how to create virtual sensors on the ASA 5500-X IPS SSP, and contains the following topics:

- [The ASA 5500-X IPS SSP and Virtualization, page 19-4](#)
- [Virtual Sensor Configuration Sequence for ASA 5500-X IPS SSP, page 19-4](#)
- [Creating Virtual Sensors, page 19-4](#)
- [Assigning Virtual Sensors to Adaptive Security Appliance Contexts, page 19-6](#)

The ASA 5500-X IPS SSP and Virtualization

The ASA 5500-X IPS SSP has one sensing interface, PortChannel 0/0. When you create multiple virtual sensors, you must assign this interface to only one virtual sensor. For the other virtual sensors you do not need to designate an interface.

After you create virtual sensors, you must map them to a security context on the adaptive security appliance using the **allocate-ips** command. You can map many security contexts to many virtual sensors.



Note

The **allocate-ips** command does not apply to single mode. In this mode, the adaptive security appliance accepts any virtual sensor named in a **policy-map** command.

The **allocate-ips** command adds a new entry to the security context database. A warning is issued if the specified virtual sensor does not exist; however, the configuration is allowed. The configuration is checked again when the **service-policy** command is processed. If the virtual sensor is not valid, the **fail-open** policy is enforced.

Virtual Sensor Configuration Sequence for ASA 5500-X IPS SSP

Follow this sequence to create virtual sensors on the ASA 5500-X IPS SSP, and to assign them to adaptive security appliance contexts:

1. Configure up to four virtual sensors.
2. Assign the ASA 5500-X IPS SSP sensing interface (PortChannel 0/0) to one of the virtual sensors.
3. (Optional) Assign virtual sensors to different contexts on the adaptive security appliance.
4. Use MPF to direct traffic to the targeted virtual sensor.

Creating Virtual Sensors



Note

You can create four virtual sensors.

Use the **virtual-sensor** *name* command in service analysis engine submode to create virtual sensors on the ASA 5500-X IPS SSP. You assign policies (anomaly detection, event action rules, and signature definition) to the virtual sensor. You can use the default policies, *ad0*, *rules0*, or *sig0*, or you can create new policies. Then you assign the sensing interface, PortChannel 0/0 for the ASA 5500-X IPS SSP to one virtual sensor.

The following options apply:

- **anomaly-detection**—Specifies the anomaly detection parameters:
 - **anomaly-detection-name** *name*—Specifies the name of the anomaly detection policy.
 - **operational-mode**—Specifies the anomaly detection mode (**inactive**, **learn**, **detect**).



Note

Anomaly detection is disabled by default in IPS 7.1(2)E4 and later. You must enable it to configure or apply an anomaly detection policy. Enabling anomaly detection results in a decrease in performance.

- **description**—Provides a description of the virtual sensor.
- **event-action-rules**—Specifies the name of the event action rules policy.
- **signature-definition**—Specifies the name of the signature definition policy.
- **physical-interfaces**—Specifies the name of the physical interface.
- **no**—Removes an entry or selection.

Creating Virtual Sensors

To create a virtual sensor on the ASA 5500-X IPS SSP, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter service analysis mode.
- ```
sensor# configure terminal
sensor(config)# service analysis-engine
sensor(config-ana)#
```
- Step 3** Add a virtual sensor.
- ```
sensor(config-ana)# virtual-sensor vs1
sensor(config-ana-vir)#
```
- Step 4** Add a description for this virtual sensor.
- ```
sensor(config-ana-vir)# description virtual sensor 1
```
- Step 5** Assign an anomaly detection policy and operational mode to this virtual sensor if you have enabled anomaly detection. If you do not want to use the default anomaly detection policy, ad0, you must create a new one using the **service anomaly-detection name** command, for example, ad1.
- ```
sensor(config-ana-vir)# anomaly-detection
sensor(config-ana-vir-ano)# anomaly-detection-name ad0
sensor(config-ana-vir-ano)# operational-mode learn
```
- Step 6** Assign an event action rules policy to this virtual sensor. If you do not want to use the default event action rules policy, rules0, you must create a new one using the **service event-action-rules name** command, for example, rules1
- ```
sensor(config-ana-vir-ano)# exit
sensor(config-ana-vir)# event-action-rules rules0
```
- Step 7** Assign a signature definition policy to this virtual sensor. If you do not want to use the default signature definition policy, sig0, you must create a new one using the **service signature-definition name** command, for example sig1.
- ```
sensor(config-ana-vir)# signature-definition sig0
```
- Step 8** Assign the interface to one virtual sensor. By default the sensing interface is already assigned to the default virtual sensor, vs0. You must remove it from the default virtual sensor to assign it to another virtual sensor that you create.
- ```
sensor(config-ana-vir)# physical-interface PortChannel10/0
```
- Step 9** Verify the virtual sensor settings.
- ```
sensor(config-ana-vir)# show settings
<protected entry>
name: vs1
-----
description: virtual sensor 1 default:
```

```

signature-definition: sig0 <protected>
event-action-rules: rules0 <protected>
anomaly-detection
-----
anomaly-detection-name: ad0 <protected>
operational-mode: inactive <defaulted>
-----
physical-interface (min: 0, max: 999999999, current: 1)
-----
name: PortChannel0/0
-----
inline-TCP-evasion-protection-mode: strict <defaulted>
-----
sensor(config-ana-vir)#

```

Step 10 Exit analysis engine mode.

```

sensor(config-ana-vir)# exit
sensor(config-ana)# exit
Apply Changes:[yes]:
sensor(config)#

```

Step 11 Press **Enter** to apply the changes or enter **no** to discard them.

For More Information

- For the procedure for enabling anomaly detection, see [Enabling Anomaly Detection, page 9-8](#).
- For the procedures for creating and configuring anomaly detection policies, see [Working With Anomaly Detection Policies, page 9-9](#).
- For the procedure for creating and configuring event action rules policies, see [Working With Event Action Rules Policies, page 7-8](#).
- For the procedure for creating and configuring signature definitions, [Working With Signature Definition Policies, page 8-2](#).

Assigning Virtual Sensors to Adaptive Security Appliance Contexts

After you create virtual sensors on the ASA 5500-X IPS SSP, you must assign the virtual sensors to a security context on the adaptive security appliance.

The following options apply:

- **[no] allocate-ips *sensor_name* [*mapped_name*] [default]**—Allocates a virtual sensor to a security context. Supported modes are multiple mode, system context, and context submode.



Note

You cannot allocate the same virtual sensor twice in a context.

- *sensor_name*—Specifies the name of the virtual sensor configured on the ASA 5500-X IPS SSP. You receive a warning message if the name is not valid.
- *mapped_name*—Specifies the name by which the security context knows the virtual sensor.

**Note**

The mapped name is used to hide the real name of the virtual sensor from the context, usually done for reasons of security or convenience to make the context configuration more generic. If no mapped name is used, the real virtual sensor name is used. You cannot reuse a mapped name for two different virtual sensors in a context.

- **no**—De-allocates the sensor, looks through the policy map configurations, and deletes any IPS subcommand that refers to it.
- **default**—Specifies this virtual sensor as the default. All legacy IPS configurations that do not specify a virtual sensor are mapped to this virtual sensor.

**Caution**

You can only configure one default virtual sensor per context. You must turn off the default flag of an existing default virtual sensor before you can designate another virtual sensor as the default.

- **clear configure allocate-ips**—Removes the configuration.
- **allocate-ips?**—Displays the list of configured virtual sensors.
- **show context [detail]**—Updated to display information about virtual sensors. In user context mode, a new line is added to show the mapped names of all virtual sensors that have been allocated to this context. In system mode, two new lines are added to show the real and mapped names of virtual sensors allocated to this context.

You can assign multiple virtual sensors to a context. Multiple contexts can share one virtual sensor, and when sharing, the contexts can have different mapped names (aliases) for the same virtual sensor. The following procedure demonstrates how to add three security contexts in multiple mode and how to assign virtual sensors to these security contexts.

Assigning Virtual Sensors to Contexts

To assign virtual sensors to adaptive security appliance contexts in multiple mode for the ASA 5500-X IPS SSP, follow these steps:

Step 1 Log in to the adaptive security appliance.

Step 2 Display the list of available virtual sensors.

```
asa# show ips
Sensor Name      Sensor ID
-----
vs0              1
vs1              2
asa#
```

Step 3 Enter configuration mode.

```
asa# configure terminal
asa(config)#
```

Step 4 Enter multiple mode.

```
asa(config)# mode multiple
WARNING: This command will change the behavior of the device
WARNING: This command will initiate a Reboot
Proceed with change mode? [confirm] yes
asa(config)#
```

Step 5 Add three context modes to multiple mode.

```
asa(config)# admin-context admin
Creating context 'admin'... Done. (13)
asa(config)# context admin
asa(config-ctx)# allocate-interface GigabitEthernet0/0.101
asa(config-ctx)# allocate-interface GigabitEthernet0/1.102
asa(config-ctx)# allocate-interface Management0/0
asa(config-ctx)# config-url disk0:/admin.cfg
Cryptochecksum (changed): 0c34dc67 f413ad74 e297464a db211681
INFO: Context admin was created with URL disk0:/admin.cfg
INFO: Admin context will take some time to come up .... please wait.
asa(config-ctx)#
asa(config-ctx)# context c2
Creating context 'c2'... Done. (14)
asa(config-ctx)# allocate-interface GigabitEthernet0/0.103
asa(config-ctx)# allocate-interface GigabitEthernet0/1.104
asa(config-ctx)# config-url disk0:/c2.cfg

WARNING: Could not fetch the URL disk0:/c2.cfg
INFO: Creating context with default config
asa(config-ctx)#
asa(config-ctx)# context c3
Creating context 'c3'... Done. (15)
asa(config-ctx)# all
asa(config-ctx)# allocate-in
asa(config-ctx)# allocate-interface g0/2
asa(config-ctx)# allocate-interface g0/3
asa(config-ctx)# config-url disk0:/c3.cfg

WARNING: Could not fetch the URL disk0:/c3.cfg
INFO: Creating context with default config
asa(config-ctx)#
```

Step 6 Assign virtual sensors to the security contexts.

```
asa(config)# context admin
asa(config-ctx)# allocate-ips vs0 adminvs0
asa(config-ctx)# exit
asa(config)# context c2
asa(config-ctx)# allocate-ips vs1 c2vs1
asa(config)# context c3
asa(config-ctx)# allocate-ips vs0 c3vs0
asa(config-ctx)# allocate-ips vs1 c3vs1
asa(config-ctx)#
```

Step 7 Configure MPF for each context.

Note The following example shows context 3 (c3).

```
asa(config)# context c3
asa/c3(config)# class-map any
asa/c3(config-cmap)# match access-list any
asa/c3(config-cmap)# exit
asa/c3(config)# policy-map ips_out
asa/c3(config-pmap)# class any
asa/c3(config-pmap-c)# ips promiscuous fail-close sensor c3vs1
asa/c3(config-pmap-c)# policy-map ips_in
asa/c3(config-pmap)# class any
asa/c3(config-pmap-c)# ips inline fail-open sensor c3vs0
asa/c3(config-pmap-c)# service-policy ips_out interface outside
asa/c3(config)# service-policy ips_in interface inside
```

```
asa/c3(config)#
```

Step 8 Confirm the configuration.

```
asa/c3(config)# exit
asa(config)# show ips detail
```

Sensor Name	Sensor ID	Allocated To	Mapped Name
-----	-----	-----	-----
vs0	1	admin	adminvs0
		c3	c3vs0
vs1	2	c2	c2vs1
		c3	c3vs1

```
asa(config)#
```

TCP Reset Differences Between IPS Appliances and ASA IPS Modules

The IPS appliance sends TCP reset packets to both the attacker and victim when reset-tcp-connection is selected. The IPS appliance sends a TCP reset packet only to the victim under the following circumstances:

- When a deny-packet-inline or deny-connection-inline is selected
- When TCP-based signatures and reset-tcp-connection have NOT been selected

In the case of the ASA 5500-X IPS SSP, the TCP reset request is sent to the ASA, and then the ASA sends the TCP reset packets. The ASA sends TCP reset packets to both the attacker and victim when the reset-tcp-connection is selected. When deny-packet-inline or deny-connection-inline is selected, the ASA sends the TCP reset packet to either the attacker or victim depending on the configuration of the signature. Signatures configured to swap the attacker and victim when reporting the alert can cause the ASA to send the TCP reset packet to the attacker.

Reloading IPS Messages

The following messages generated during some IPS signature and global correlation updates for IPS 7.1 and later on the ASA 5500-X IPS SSP can cause confusion since the IPS is not reloading:

```
ASA5585-SSP-IPS20 Module in slot 1, application up "IPS", version "7.1(1)E4" Normal
Operation
ASA5585-SSP-IPS20 Module in slot 1, application reloading "IPS", version "7.1(1)E4" Config
Change
```

These messages are generated during some, but not all, of the global correlation updates that are attempted every five minutes. This is expected behavior. There is a global correlation check every five minutes, but there may not be an update available, thus the message appears every hour or so. When a global correlation update actually takes place, a message is sent from the IPS to the ASA indicating that a configuration change is taking place.

ASA 5500-X IPS SSP Default Gateway

To access the Internet from the ASA 5500-X IPS SSP and to manage it from hosts behind other interfaces on the ASA 5500-X, connect the Management 0/0 interface on the ASA 5500-X to a Layer 3 device. Configure the default gateway on the sensor as the Layer 3 device. The appropriate static route on the ASA 5500-X is required so that the return traffic reaches the ASA 5500-X IPS SSP through this Layer 3 device.



Note

The Management 0/0 interface on the ASA 5500-X has no through traffic support. If the sensor is configured to use the IP address of the management interface of the ASA as the default gateway, the sensor cannot access the Internet and the sensor cannot be managed or accessed from the hosts behind the other interfaces on the ASA 5500-X.

Promiscuous Mode and Under Runs

The ASA 5500-X can exhibit under runs on the internal data interface going to the ASA 5500-X IPS SSP when it is configured in promiscuous mode.

The under runs for promiscuous mode inspection are expected behavior if you inspect a lot of traffic or have spikes in traffic rates, because the ASA does not wait for the ASA 5500-X IPS SSP to finish inspection before forwarding traffic. It is also possible to have under runs if the ASA 5500-X IPS SSP inspects long flows, such as file downloads. If you have a lot of long flows, you can limit IPS inspection with the **specify-flow-depth** setting under **service analysis-engine global-settings**. Limiting inspection to 800,000 bytes per stream reduces the number of under runs. You can check for symptoms of long flows by looking at the per CPU processing load percentage statistics in **show statistics analysis-engine**. If any of the threads are running at 100%, this may be triggered by a long flow.

For More Information

- For the procedure for specifying flow depth, see [Configuring Global Variables, page 6-12](#).
- For the procedure for checking the load percentage statistics, see [Displaying Statistics, page 17-31](#).

The ASA 5500-X IPS SSP and Bypass Mode

The ASA 5500-X IPS SSP does not support bypass mode. The adaptive security appliance will either fail open, fail close, or fail over depending on the configuration of the adaptive security appliance and the type of activity being done on the ASA 5500-X IPS SSP.

The SensorApp Fails

The following occurs when the SensorApp fails:

- If the adaptive security appliance is configured for failover, then the adaptive security appliance fails over.
- If the adaptive security appliance is not configured for failover or failover is not possible:
 - If set to fail-open, the adaptive security appliance passes traffic without sending it to the ASA IPS module.
 - If set to fail-close, the adaptive security appliance stops passing traffic until the ASA IPS module is restarted.

The SensorApp is Reconfigured

The following occurs when the SensorApp is reconfigured:

- If set to fail-open, the adaptive security appliance passes traffic without sending it to the ASA IPS module.
- If set to fail-close, the adaptive security appliance stops passing traffic until the ASA IPS module is restarted.

**Note**

The adaptive security appliance does not failover unless the reconfiguration is not completed.

The ASA 5500-X IPS SSP and the Normalizer Engine

The majority of the features in the Normalizer engine are not used on the ASA 5500-X IPS SSP, because the ASA itself handles the normalization. Packets on the ASA IPS modules go through a special path in the Normalizer that only reassembles fragments and puts packets in the right order for the TCP stream. The Normalizer does not do any of the normalization that is done on an inline IPS appliance, because that causes problems in the way the ASA handles the packets.

The following Normalizer engine signatures are not supported:

- 1300.0
- 1304.0
- 1305.0
- 1307.0
- 1308.0
- 1309.0
- 1311.0
- 1315.0
- 1316.0
- 1317.0
- 1330.0
- 1330.1
- 1330.2
- 1330.9
- 1330.10
- 1330.12
- 1330.14
- 1330.15
- 1330.16
- 1330.17
- 1330.18

For More Information

For detailed information about the Normalizer engine, see [Normalizer Engine, page B-37](#).

The ASA 5500-X IPS SSP and Memory Usage

For the ASA 5500-X IPS SSP, the memory usage is 93%. The default health thresholds for the sensor are 80% for yellow and 91% for red, so the sensor health will be shown as red on these platforms even for normal operating conditions. You can tune the threshold percentage for memory usage so that it reads more accurately for these platforms by configuring the **memory-usage-policy** option in the sensor health metrics.



Note

Make sure you have the **memory-usage-policy** option in the sensor health metrics enabled.

[Table 19-1](#) lists the yellow-threshold and the red-threshold health values.

Table 19-1 ASA 5500-X IPS SSP Memory Usage Values

Platform	Yellow	Red	Memory Used
ASA 5512-X IPS SSP	85%	91%	28%
ASA 5515-X IPS SSP	88%	92%	14%
ASA 5525-X IPS SSP	88%	92%	14%
ASA 5545-X IPS SSP	93%	96%	13%
ASA 5555-X IPS SSP	95%	98%	17%

The ASA 5500-X IPS SSP and Jumbo Packets

The jumbo packet count in the **show interface** command output from the lines `Total Jumbo Packets Received` and `Total Jumbo Packets Transmitted` for ASA IPS modules may be larger than expected due to some packets that were almost jumbo size on the wire being counted as jumbo size by the IPS. This miscount is a result of header bytes added to the packet by the ASA before the packet is transmitted to the IPS. For IPv4, 58 bytes of header data are added. For IPv6, 78 bytes of header data are added. The ASA removes the added IPS header before the packet leaves the ASA.

Reloading, Shutting Down, Resetting, and Recovering the ASA 5500-X IPS SSP



Note

You can enter the **sw-module** commands from privileged EXEC mode or from global configuration mode. You can enter the commands in single routed mode and single transparent mode. For adaptive security appliances operating in multi-mode (routed or transparent multi-mode) you can only execute the **sw-module** commands from the system context (not from administrator or user contexts).

Use the following commands to reload, shut down, reset, recover the password, and recover the ASA 5500-X IPS SSP directly from the adaptive security appliance:

- **sw-module module ips reload**—This command reloads the software on the ASA 5500-X IPS SSP without doing a hardware reset. It is effective only when the module is in the Up state.
- **sw-module module ips shutdown**—This command shuts down the software on the ASA 5500-X IPS SSP. It is effective only when the module is in Up state.
- **sw-module module ips reset**—This command performs a hardware reset of the ASA 5500-X IPS SSP. It is applicable when the module is in the Up/Down/Unresponsive/Recover states.
- **sw-module module ips password-reset**—This command restores the cisco CLI account password on the ASA 5500-X IPS SSP to the default **cisco**.
- **sw-module module ips recover image disk0:/image name**—This command starts the reimage process by setting the image location and name. You must first copy the IPS image to the ASA to disk0:/.
- **sw-module module ips recover boot**—This command reimages the ASA 5500-X IPS SSP. It is applicable only when the module is in the Up state.
- **sw-module module ips recover stop**—This command stops the reimage of the ASA 5500-X IPS SSP. It is applicable only when the module is in the Recover state.



Caution

If the ASA 5500-X IPS SSP recovery needs to be stopped, you must issue the **sw-module module ips recover stop** command within 30 to 45 seconds after starting the recovery. Waiting any longer can lead to unexpected consequences. For example, the module may come up in the Unresponsive state.

- **sw-module module ips recover configure**—Use this command to configure parameters for the ASA 5500-X IPS SSP recovery. The essential parameters are the IP address and recovery image TFTP URL location.

Example

```
asa-ips# sw-module module ips recover configure image
disk0:/IPS-SSP_5555-K9-sys-1.1-a-7.1-3-E4.aip
Image URL [tftp://192.0.2.1/IPS-5545-K9-sys-1.1-a-7.1-3-E4.aip]:
Port IP Address [192.0.2.226]:
VLAN ID [0]:
Gateway IP Address [192.0.2.254]:
```

For More Information

For the procedure for recovering the ASA 5500-X IPS SSP system image, see [Installing the System Image for the ASA 5500-X IPS SSP](#), page 22-31.

Health and Status Information

To see the general health of the ASA 5500-X IPS SSP, use the **show module ips details** command.

```
asa# show module ips details
Getting details from the Service Module, please wait...

Card Type:           IPS 5555 Intrusion Prevention System
Model:               IPS5555
Hardware version:    N/A
Serial Number:       FCH1504V0CW
```

```

Firmware version:    N/A
Software version:    7.1(3)E4
MAC Address Range:   503d.e59c.7ca0 to 503d.e59c.7ca0
App. name:           IPS
App. Status:         Up
App. Status Desc:    Normal Operation
App. version:        7.1(3)E4
Data Plane Status:   Up
Status:              Up
License:             IPS Module Enabled perpetual
Mgmt IP addr:        192.168.1.2
Mgmt Network mask:   255.255.255.0
Mgmt Gateway:        192.168.1.1
Mgmt web ports:      443
Mgmt TLS enabled:    true
asa#

```

The output shows that the ASA 5500-X IPS SSP is up. If the status reads *Down*, you can reset it using the **sw-module module 1 reset** command.

If you have problems with reimaging the ASA 5500-X IPS SSP, use the **debug module-boot** command to see the output as it boots. Make sure you have the correct IP address for the TFTP server and you have the correct file on the TFTP server. Then use the **sw-module module ips recover** command again to reimage the module.

```

asa-ips# sw-module module ips recover configure image
disk0:/IPS-SSP_5555-K9-sys-1.1-a-7.1-3-E4.aip
Image URL [tftp://192.0.2.1/IPS-5545-K9-sys-1.1-a-7.1-3-E4.aip]:
Port IP Address [192.0.2.226]:
VLAN ID [0]:
Gateway IP Address [192.0.2.254]:

asa-ips# debug module-boot
debug module-boot enabled at level 1
asa-ips# sw-module module ips reload

Reload module ips? [confirm]
Reload issued for module ips.
asa-ips# Mod-ips 228> ***
Mod-ips 229> *** EVENT: The module is reloading.
Mod-ips 230> *** TIME: 08:07:36 CST Jan 17 2012
Mod-ips 231> ***
Mod-ips 232> Mod-ips 233> The system is going down NOW!
Mod-ips 234> Sending SIGTERM to all processes
Mod-ips 235> Sending SIGKILL to all processes
Mod-ips 236> Requesting system reboot
Mod-ips 237> e1000 0000:00:07.0: PCI INT A disabled
Mod-ips 238> e1000 0000:00:06.0: PCI INT A disabled
Mod-ips 239> e1000 0000:00:05.0: PCI INT A disabled
Mod-ips 240> Restarting system.
Mod-ips 241> machine restart
Mod-ips 242> IVSHMEM: addr = 4093640704 size = 67108864
Mod-ips 243> Booting 'Cisco IPS'
-MORE-

```

ASA 5500-X IPS SSP Failover Scenarios

The following failover scenarios apply to the ASA 5500-X series in the event of configuration changes, signature/signature engine updates, service packs, and SensorApp crashes on the ASA 5500-X IPS SSP.

Single ASA in Fail-Open Mode

- If the ASA is configured in fail-open mode for the ASA 5500-X IPS SSP, and the ASA 5500-X IPS SSP experiences a configuration change or signature/signature engine update, traffic is passed through the ASA without being inspected.
- If the ASA is configured in fail-open mode for the ASA 5500-X IPS SSP, and the ASA 5500-X IPS SSP experiences a SensorApp crash or a service pack upgrade, traffic is passed through the ASA without being inspected.

Single ASA in Fail-Close Mode

- If the ASA is configured in fail-close mode for the ASA 5500-X IPS SSP, and the ASA 5500-X IPS SSP experiences a configuration change or a signature/signature engine update, traffic is stopped from passing through the ASA.
- If the ASA is configured in fail-close mode for the ASA 5500-X IPS SSP, and the ASA 5500-X IPS SSP experiences a SensorApp crash or a service pack upgrade, traffic is stopped from passing through the ASA.

Two ASAs in Fail-Open Mode

- If the ASAs are configured in fail-open mode and if the ASA 5500-X IPS SSP on the active ASA experiences a configuration change or a signature/signature engine update, traffic is still passed through the active ASA without being inspected. Failover is not triggered.
- If the ASAs are configured in fail-open mode, and if the ASA 5500-X IPS SSP on the active ASA experiences a SensorApp crash or a service pack upgrade, failover is triggered and traffic passes through the ASA 5500-X IPS SSP that was previously the standby ASA 5500-X IPS SSP.

Two ASAs in Fail-Close Mode

- If the ASAs are configured in fail-close mode, and if the ASA 5500-X IPS SSP on the active ASA experiences a configuration change or a signature/signature engine update, traffic is stopped from passing through the active ASA. No failover is triggered.
- If the ASAs are configured in fail-close mode, and if the ASA 5500-X IPS SSP on the active ASA experiences a SensorApp crash or a service pack upgrade, failover is triggered and traffic passes through the ASA 5500-X IPS SSP that was previously the standby for the ASA 5500-X IPS SSP.

Configuration Examples

Use the following configuration for the primary ASA:

```
interface GigabitEthernet0/7
  description LAN Failover Interface

failover
failover lan unit primary
failover lan interface folink GigabitEthernet0/7
failover interface ip folink 172.27.48.1 255.255.255.0 standby 172.27.48.2
```

Use the following configuration for the secondary ASA:

```
interface GigabitEthernet0/7
  description LAN Failover Interface
```

```
failover
failover lan unit secondary
failover lan interface folink GigabitEthernet0/7
failover interface ip folink 172.27.48.1 255.255.255.0 standby 172.27.48.2
```

New and Modified Commands

This section describes the new and modified Cisco ASA commands that support the ASA 5500-X IPS SSP and are used to configure the ASA 5500-X IPS SSP.



Note

All other Cisco ASA CLI commands are documented in the *Cisco Security Appliance Command Reference* on Cisco.com at http://www.cisco.com/en/US/products/ps6120/prod_command_reference_list.html.

This section contains the following topic:

- [allocate-ips, page 19-16](#)

allocate-ips

To allocate an IPS virtual sensor to a security context if you have the ASA 5500-X IPS SSP installed, use the **allocate-ips** command in context configuration mode. To remove a virtual sensor from a context, use the **no** form of this command.

allocate-ips *sensor_name* [*mapped_name*] [**default**]

no allocate-ips *sensor_name* [*mapped_name*] [**default**]

Syntax Description

default	(Optional) Sets one sensor per context as the default sensor; if the context configuration does not specify a sensor name, the context uses this default sensor. You can only configure one default sensor per context. If you want to change the default sensor, enter the no allocate-ips sensor_name command to remove the current default sensor before you allocate a new default sensor. If you do not specify a sensor as the default, and the context configuration does not include a sensor name, then traffic uses the default sensor on the ASA 5500-X IPS SSP.
----------------	--

<i>mapped_name</i>	(Optional) Sets a mapped name as an alias for the sensor name that can be used within the context instead of the actual sensor name. If you do not specify a mapped name, the sensor name is used within the context. For security purposes, you might not want the context administrator to know which sensors are being used by the context. Or you might want to genericize the context configuration. For example, if you want all contexts to use sensors called “sensor1” and “sensor2,” then you can map the “highsec” and “lowsec” sensors to sensor1 and sensor2 in context A, but map the “medsec” and “lowsec” sensors to sensor1 and sensor2 in context B.
<i>sensor_name</i>	Sets the sensor name configured on the ASA 5500-X IPS SSP. To view the sensors that are configured on the ASA 5500-X IPS SSP, enter allocate-ips ? . All available sensors are listed. You can also enter the show ips command. In the system execution space, the show ips command lists all available sensors; if you enter it in the context, it shows the sensors you already assigned to the context. If you specify a sensor name that does not yet exist on the ASA 5500-X IPS SSP, you get an error, but the allocate-ips command is entered as is. Until you create a sensor of that name on the ASA 5500-X IPS SSP, the context assumes the sensor is down.

Defaults

No default behavior or values.

Command Modes

The following table shows the modes in which you can enter the command:

Command Mode	Firewall Mode		Security Context		
	Routed	Transparent	Single	Multiple Context	System
Context configuration	•	•	—	—	•

Command History

Release	Modification
8.0(2)	This command was introduced.

Usage Guidelines

You can assign one or more IPS virtual sensors to each context. Then, when you configure the context to send traffic to the ASA 5500-X IPS SSP using the **ips** command, you can specify a sensor that is assigned to the context; you cannot specify a sensor that you did not assign to the context. If you do not assign any sensors to a context, then the default sensor configured on the ASA 5500-X IPS SSP is used. You can assign the same sensor to multiple contexts.

**Note**

You do not need to be in multiple context mode to use virtual sensors; you can be in single mode and use different sensors for different traffic flows.

Examples

The following example assigns sensor1 and sensor2 to context A, and sensor1 and sensor3 to context B. Both contexts map the sensor names to “ips1” and “ips2.” In context A, sensor1 is set as the default sensor, but in context B, no default is set so the default that is configured on the ASA 5500-X IPS SSP is used.

```
hostname(config-ctx)# context A
hostname(config-ctx)# allocate-interface gigabitethernet0/0.100 int1
hostname(config-ctx)# allocate-interface gigabitethernet0/0.102 int2
hostname(config-ctx)# allocate-interface gigabitethernet0/0.110-gigabitethernet0/0.115
int3-int8
hostname(config-ctx)# allocate-ips sensor1 ips1 default
hostname(config-ctx)# allocate-ips sensor2 ips2
hostname(config-ctx)# config-url ftp://user1:passw0rd@10.1.1.1/configlets/test.cfg
hostname(config-ctx)# member gold

hostname(config-ctx)# context sample
hostname(config-ctx)# allocate-interface gigabitethernet0/1.200 int1
hostname(config-ctx)# allocate-interface gigabitethernet0/1.212 int2
hostname(config-ctx)# allocate-interface gigabitethernet0/1.230-gigabitethernet0/1.235
int3-int8
hostname(config-ctx)# allocate-ips sensor1 ips1
hostname(config-ctx)# allocate-ips sensor3 ips2
hostname(config-ctx)# config-url ftp://user1:passw0rd@10.1.1.1/configlets/sample.cfg
hostname(config-ctx)# member silver
```

Related Commands

Command	Description
context	Creates a security context in the system configuration and enters context configuration mode.
ips	Diverts traffic to the ASA 5500-X IPS SSP for inspection.
show context	Shows a list of contexts (system execution space) or information about the current context.
show ips	Shows the virtual sensors configured on the ASA 5500-X IPS SSP.



Configuring the ASA 5585-X IPS SSP

This chapter contains procedures that are specific to configuring the ASA 5585-X IPS SSP. It contains the following sections:

- [ASA 5585-X IPS SSP Notes and Caveats, page 20-1](#)
- [Configuration Sequence for the ASA 5585-X IPS SSP, page 20-2](#)
- [Verifying Initialization for the ASA 5585-X IPS SSP, page 20-3](#)
- [Creating Virtual Sensors for the ASA 5585-X IPS SSP, page 20-4](#)
- [The ASA 5585-X IPS SSP and the Normalizer Engine, page 20-10](#)
- [The ASA 5585-X IPS SSP and Bypass Mode](#)
- [The ASA 5585-X IPS SSP and Jumbo Packets, page 20-11](#)
- [Reloading, Shutting Down, Resetting, and Recovering the ASA 5585-X IPS SSP, page 20-12](#)
- [Health and Status Information, page 20-13](#)
- [Traffic Flow Stopped on IPS Switchports, page 20-16](#)
- [Failover Scenarios, page 20-16](#)

ASA 5585-X IPS SSP Notes and Caveats

The following notes and caveats apply to configuring the ASA 5585-X IPS SSP:

- The ASA 5585-X IPS SSP is supported in ASA 8.2(4.4) and later as well as ASA 8.4(2) and later. It is not supported in ASA 8.3(x).
- All IPS platforms allow ten concurrent CLI sessions.
- Anomaly detection is disabled by default.
- The ASA 5585-X IPS SSP do not support CDP mode.
- The ASA 5585-X IPS SSP does not support the inline TCP session tracking mode.
- For the ASA 5585-X IPS SSP, normalization is performed by the adaptive security appliance and not the IPS.
- The ASA 5585-X IPS SSP does not support bypass mode. The adaptive security appliance will either fail open, fail close, or fail over depending on the configuration of the adaptive security appliance and the type of activity being done on the IPS.
- The ASA 5585-X IPS SSP supports the String ICMP XL, String TCP XL, and String UDP XL engines. These engines provide optimized operation for these platforms.

- The ASA 5585-X IPS SSP has four types of ports (console, management, GigabitEthernet, and 10GE). The console and management ports (on the right front panel of the ASA 5585-X IPS SSP) are configured and controlled by IPS software. The GigabitEthernet and 10GE ports (on the left front panel of the ASA 5585-X IPS SSP) are configured and controlled by ASA software rather than IPS software. However, when you reset or shut down the ASA 5585-X IPS SSP, the GigabitEthernet and 10GE ports will also link down. You should reset or shut down the ASA 5585-X IPS SSP during scheduled maintenance windows to minimize the effect of the link down on these ports.

TCP Reset Differences Between IPS Appliances and ASA IPS Modules

The IPS appliance sends TCP reset packets to both the attacker and victim when reset-tcp-connection is selected. The IPS appliance sends a TCP reset packet only to the victim under the following circumstances:

- When a deny-packet-inline or deny-connection-inline is selected
- When TCP-based signatures and reset-tcp-connection have NOT been selected

In the case of the ASA 5585-X IPS SSP, the TCP reset request is sent to the ASA, and then the ASA sends the TCP reset packets. The ASA sends TCP reset packets to both the attacker and victim when the reset-tcp-connection is selected. When deny-packet-inline or deny-connection-inline is selected, the ASA sends the TCP reset packet to either the attacker or victim depending on the configuration of the signature. Signatures configured to swap the attacker and victim when reporting the alert can cause the ASA to send the TCP reset packet to the attacker.

Reloading IPS Messages

The following messages generated during some IPS signature and global correlation updates for IPS 7.1 and later on the ASA 5585-X IPS SSP can cause confusion since the IPS is not reloading:

```
ASA5585-SSP-IPS20 Module in slot 1, application up "IPS", version "7.1(1)E4" Normal
Operation
ASA5585-SSP-IPS20 Module in slot 1, application reloading "IPS", version "7.1(1)E4" Config
Change
```

These messages are generated during some, but not all, of the global correlation updates that are attempted every five minutes. This is expected behavior. There is a global correlation check every five minutes, but there may not be an update available, thus the message appears every hour or so. When a global correlation update actually takes place, a message is sent from the IPS to the ASA indicating that a configuration change is taking place.

Configuration Sequence for the ASA 5585-X IPS SSP

Perform the following tasks to configure the ASA 5585-X IPS SSP:

1. Obtain and install the current IPS software if your software is not up to date.
2. Obtain and install the license key.
3. Log (session) in to the ASA 5585-X IPS SSP.
4. Run the **setup** command to initialize the ASA 5585-X IPS SSP.
5. Verify initialization for the ASA 5585-X IPS SSP.
6. Configure the adaptive security appliance to send IPS traffic to the ASA 5585-X IPS SSP.
7. Perform other initial tasks, such as adding users, trusted hosts, and so forth.
8. Configure intrusion prevention.

9. Configure global correlation.
10. Perform miscellaneous tasks to keep your ASA 5585-X IPS SSP running smoothly.
11. Upgrade the IPS software with new signature updates and service packs as they become available.
12. Reimage the ASA 5585-X IPS SSP when needed.

For More Information

- For the procedure for logging in to the ASA 5585-X IPS SSP, see [Chapter 2, “Logging In to the Sensor.”](#)
- For the procedure for running the **setup** command, see [Advanced Setup for the ASA 5585-X IPS SSP, page 3-21.](#)
- For the procedure for verifying ASA 5585-X IPS SSP initialization, see [Verifying Initialization for the ASA 5585-X IPS SSP, page 20-3.](#)
- For the procedure for creating virtual sensors, see [Creating Virtual Sensors for the ASA 5585-X IPS SSP, page 20-4.](#)
- For the procedures for setting up the ASA 5585-X IPS SSP, see [Chapter 4, “Setting Up the Sensor.”](#)
- For the procedures for configuring intrusion prevention, see [Chapter 7, “Configuring Event Action Rules,”](#) [Chapter 8, “Defining Signatures,”](#) [Chapter 9, “Configuring Anomaly Detection,”](#) and [Chapter 14, “Configuring Attack Response Controller for Blocking and Rate Limiting.”](#)
- For the procedures for configuring global correlation, see [Chapter 10, “Configuring Global Correlation.”](#)
- For the procedures for keeping your ASA 5585-X IPS SSP running smoothly, see [Chapter 17, “Administrative Tasks for the Sensor.”](#)
- For more information on how to obtain Cisco IPS software, see [Chapter 21, “Obtaining Software.”](#)
- For the procedure for reimaging the ASA 5585-X IPS SSP, see [Installing the System Image for the ASA 5585-X IPS SSP, page 22-32.](#)

Verifying Initialization for the ASA 5585-X IPS SSP

You can use the **show module slot details** command to verify that you have initialized the ASA 5585-X IPS SSP and to verify that you have the correct software version.

To verify initialization, follow these steps:

-
- Step 1** Log in to the adaptive security appliance.
 - Step 2** Obtain the details about the ASA 5585-X IPS SSP.

```
asa# show module 1 details
Getting details from the Service Module, please wait...
ASA 5585-X IPS Security Services Processor-10 with 8GE
Model:                ASA5585-SSP-IPS10
Hardware version:     1.0
Serial Number:        JAF1350ABSL
Firmware version:     2.0(1)3
Software version:     7.1(2)E4
MAC Address Range:    8843.e12f.5414 to 8843.e12f.541f
App. name:            IPS
App. Status:          Up
```

```

App. Status Desc:   Normal Operation
App. version:       7.1(2)E4
Data plane Status:  Up
Status:             Up
Mgmt IP addr:       192.0.2.3
Mgmt Network mask:  255.255.255.0
Mgmt Gateway:       192.0.2.254
Mgmt Access List:   10.0.0.0/8
Mgmt Access List:   64.0.0.0/8
Mgmt web ports:     443
Mgmt TLS enabled    true
asa

```

Step 3 Confirm the information.

Creating Virtual Sensors for the ASA 5585-X IPS SSP

This section describes how to create virtual sensors on the ASA 5585-X IPS SSP, and contains the following topics:

- [The ASA 5585-X IPS SSP and Virtualization, page 20-4](#)
- [The ASA 5585-X IPS SSP Virtual Sensor Configuration Sequence, page 20-5](#)
- [Creating Virtual Sensors, page 20-5](#)
- [Assigning Virtual Sensors to Adaptive Security Appliance Contexts, page 20-7](#)

The ASA 5585-X IPS SSP and Virtualization

The ASA 5585-X IPS SSP has two interfaces, the management interface (command and control) and the sensing interface. The command and control interface has an IP address and is used for configuring the ASA 5585-X IPS SSP. It is used by the ASA 5585-X IPS SSP to transmit security and status events to the IDM or IME. The ASA 5585-X IPS SSP command and control interface is named Management 0/0.



Caution

The ASA 5585-X IPS SSP has four types of ports (console, management, GigabitEthernet, and 10GE). The console and management ports (on the right front panel of the ASA 5585-X IPS SSP) are configured and controlled by IPS software. The GigabitEthernet and 10GE ports (on the left front panel of the ASA 5585-X IPS SSP) are configured and controlled by ASA software rather than IPS software. However, when you reset or shut down the ASA 5585-X IPS SSP, the GigabitEthernet and 10GE ports will also link down. You should reset or shut down the ASA 5585-X IPS SSP during scheduled maintenance windows to minimize the effect of the link down on these ports.

The command and control interface is permanently enabled. It is permanently mapped to a specific physical interface. You cannot use the command and control interface as either a sensing or alternate TCP reset interface.

Sensing interfaces are used to analyze traffic for security violations. There is only one sensing interface on the ASA 5585-X IPS SSP. It is named PortChannel 0/0 and is a backplane interface. All backplane interfaces have fixed speed, duplex, and state settings. These settings are protected in the default configuration on all backplane interfaces. You configure the ASA 5585-X IPS SSP interface by security context on the adaptive security appliance. The sensing interface is permanently enabled.

The ASA 5585-X IPS SSP has one sensing interface, PortChannel 0/0. When you create multiple virtual sensors, you must assign this interface to only one virtual sensor. For the other virtual sensors you do not need to designate an interface.

After you create virtual sensors, you must map them to a security context on the adaptive security appliance using the **allocate-ips** command. You can map many security contexts to many virtual sensors.

**Note**

The **allocate-ips** command does not apply to single mode. In this mode, the adaptive security appliance accepts any virtual sensor named in a **policy-map** command.

The **allocate-ips** command adds a new entry to the security context database. A warning is issued if the specified virtual sensor does not exist; however, the configuration is allowed. The configuration is checked again when the **service-policy** command is processed. If the virtual sensor is not valid, the **fail-open** policy is enforced.

The ASA 5585-X IPS SSP Virtual Sensor Configuration Sequence

Follow this sequence to create virtual sensors on the ASA 5585-X IPS SSP, and to assign them to adaptive security appliance contexts:

1. Configure up to four virtual sensors.
2. Assign the ASA 5585-X IPS SSP sensing interface (PortChannel 0/0), to one of the virtual sensors.
3. (Optional) Assign virtual sensors to different contexts on the adaptive security appliance.
4. Use MPF to direct traffic to the targeted virtual sensor.

Creating Virtual Sensors

**Note**

You can create four virtual sensors.

Use the **virtual-sensor** *name* command in service analysis engine submode to create virtual sensors on the ASA 5585-X IPS SSP. You assign policies (anomaly detection, event action rules, and signature definition) to the virtual sensor. You can use the default policies, *ad0*, *rules0*, or *sig0*, or you can create new policies. Then you assign the sensing interface, PortChannel 0/0 for the ASA 5500-X IPS SSP, to one virtual sensor.

The following options apply:

- **anomaly-detection**—Specifies the anomaly detection parameters:
 - **anomaly-detection-name** *name*—Specifies the name of the anomaly detection policy.
 - **operational-mode**—Specifies the anomaly detection mode (**inactive**, **learn**, **detect**).

**Note**

Anomaly detection is disabled by default in IPS 7.1(2)E4 and later. You must enable it to configure or apply an anomaly detection policy. Enabling anomaly detection results in a decrease in performance.

- **description**—Provides a description of the virtual sensor.
- **event-action-rules**—Specifies the name of the event action rules policy.

- **signature-definition**—Specifies the name of the signature definition policy.
- **physical-interfaces**—Specifies the name of the physical interface.
- **no**—Removes an entry or selection.

Creating Virtual Sensors

To create a virtual sensor on the ASA 5585-X IPS SSP, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Enter service analysis mode.
- ```
sensor# configure terminal
sensor(config)# service analysis-engine
sensor(config-ana)#
```
- Step 3** Add a virtual sensor.
- ```
sensor(config-ana)# virtual-sensor vs1
sensor(config-ana-vir)#
```
- Step 4** Add a description for this virtual sensor.
- ```
sensor(config-ana-vir)# description virtual sensor 1
```
- Step 5** Assign an anomaly detection policy and operational mode to this virtual sensor if you have enabled anomaly detection. If you do not want to use the default anomaly detection policy, ad0, you must create a new one using the **service anomaly-detection name** command, for example, ad1.
- ```
sensor(config-ana-vir)# anomaly-detection
sensor(config-ana-vir-ano)# anomaly-detection-name ad0
sensor(config-ana-vir-ano)# operational-mode learn
```
- Step 6** Assign an event action rules policy to this virtual sensor. If you do not want to use the default event action rules policy, rules0, you must create a new one using the **service event-action-rules name** command, for example, rules1
- ```
sensor(config-ana-vir-ano)# exit
sensor(config-ana-vir)# event-action-rules rules0
```
- Step 7** Assign a signature definition policy to this virtual sensor. If you do not want to use the default signature definition policy, sig0, you must create a new one using the **service signature-definition name** command, for example sig1.
- ```
sensor(config-ana-vir)# signature-definition sig0
```
- Step 8** Assign the interface to one virtual sensor. By default the sensing interface is already assigned to the default virtual sensor, vs0. You must remove it from the default virtual sensor to assign it to another virtual sensor that you create.
- ```
sensor(config-ana-vir)# physical-interface PortChannel10/0
```
- Step 9** Verify the virtual sensor settings.
- ```
sensor(config-ana-vir)# show settings
name: vs1
-----
description: virtual sensor 1 default:
signature-definition: sig1 default: sig0
event-action-rules: rules1 default: rules0
anomaly-detection
-----
```

```

anomaly-detection-name: ad1 default: ad0
operational-mode: learn default: detect
-----
physical-interface (min: 0, max: 999999999, current: 2)
-----
name: PortChannel0/0
subinterface-number: 0 <defaulted>
-----
-----
logical-interface (min: 0, max: 999999999, current: 0)
-----
-----
-----
sensor(config-ana-vir)#

```

Step 10 Exit analysis engine mode.

```

sensor(config-ana-vir)# exit
sensor(config-ana)# exit
Apply Changes?[yes]:
sensor(config)#

```

Step 11 Press **Enter** to apply the changes or enter **no** to discard them.

For More Information

- For the procedures for creating and configuring anomaly detection policies, see [Working With Anomaly Detection Policies, page 9-9](#).
- For the procedure for creating and configuring event action rules policies, see [Working With Event Action Rules Policies, page 7-8](#).
- For the procedure for creating and configuring signature definitions, [Working With Signature Definition Policies, page 8-2](#).
- For the procedure for enabling anomaly detection, see [Enabling Anomaly Detection, page 9-8](#).

Assigning Virtual Sensors to Adaptive Security Appliance Contexts

After you create virtual sensors on the ASA 5585-X IPS SSP, you must assign the virtual sensors to a security context on the adaptive security appliance.

The following options apply:

- **[no] allocate-ips sensor_name [mapped_name] [default]**—Allocates a virtual sensor to a security context. Supported modes are multiple mode, system context, and context submode.



Note You cannot allocate the same virtual sensor twice in a context.

- *sensor_name*—Specifies the name of the virtual sensor configured on the ASA 5585-X IPS SSP. You receive a warning message if the name is not valid.
- *mapped_name*—Specifies the name by which the security context knows the virtual sensor.

**Note**

The mapped name is used to hide the real name of the virtual sensor from the context, usually done for reasons of security or convenience to make the context configuration more generic. If no mapped name is used, the real virtual sensor name is used. You cannot reuse a mapped name for two different virtual sensors in a context.

- **no**—De-allocates the sensor, looks through the policy map configurations, and deletes any IPS subcommand that refers to it.
- **default**—Specifies this virtual sensor as the default. All legacy IPS configurations that do not specify a virtual sensor are mapped to this virtual sensor.

**Caution**

You can only configure one default virtual sensor per context. You must turn off the default flag of an existing default virtual sensor before you can designate another virtual sensor as the default.

- **clear configure allocate-ips**—Removes the configuration.
- **allocate-ips?**—Displays the list of configured virtual sensors.
- **show context [detail]**—Updated to display information about virtual sensors. In user context mode, a new line is added to show the mapped names of all virtual sensors that have been allocated to this context. In system mode, two new lines are added to show the real and mapped names of virtual sensors allocated to this context.

You can assign multiple virtual sensors to a context. Multiple contexts can share one virtual sensor, and when sharing, the contexts can have different mapped names (aliases) for the same virtual sensor. The following procedure demonstrates how to add three security contexts in multiple mode and how to assign virtual sensors to these security contexts.

Assigning Virtual Sensors to Contexts

To assign virtual sensors to adaptive security appliance contexts in multiple mode for the ASA 5585-X IPS SSP, follow these steps:

Step 1 Log in to the adaptive security appliance.

Step 2 Display the list of available virtual sensors.

```
asa# show ips
Sensor Name      Sensor ID
-----
vs0              1
vs1              2
asa#
```

Step 3 Enter configuration mode.

```
asa# configure terminal
asa(config)#
```

Step 4 Enter multiple mode.

```
asa(config)# mode multiple
WARNING: This command will change the behavior of the device
WARNING: This command will initiate a Reboot
Proceed with change mode? [confirm] yes
asa(config)#
```

Step 5 Add three context modes to multiple mode.

```
asa(config)# admin-context admin
Creating context 'admin'... Done. (13)
asa(config)# context admin
asa(config-ctx)# allocate-interface GigabitEthernet0/0.101
asa(config-ctx)# allocate-interface GigabitEthernet0/1.102
asa(config-ctx)# allocate-interface Management0/0
asa(config-ctx)# config-url disk0:/admin.cfg
Cryptochecksum (changed): 0c34dc67 f413ad74 e297464a db211681
INFO: Context admin was created with URL disk0:/admin.cfg
INFO: Admin context will take some time to come up .... please wait.
asa(config-ctx)#
asa(config-ctx)# context c2
Creating context 'c2'... Done. (14)
asa(config-ctx)# allocate-interface GigabitEthernet0/0.103
asa(config-ctx)# allocate-interface GigabitEthernet0/1.104
asa(config-ctx)# config-url disk0:/c2.cfg

WARNING: Could not fetch the URL disk0:/c2.cfg
INFO: Creating context with default config
asa(config-ctx)#
asa(config-ctx)# context c3
Creating context 'c3'... Done. (15)
asa(config-ctx)# all
asa(config-ctx)# allocate-in
asa(config-ctx)# allocate-interface g0/2
asa(config-ctx)# allocate-interface g0/3
asa(config-ctx)# config-url disk0:/c3.cfg

WARNING: Could not fetch the URL disk0:/c3.cfg
INFO: Creating context with default config
asa(config-ctx)#
```

Step 6 Assign virtual sensors to the security contexts.

```
asa(config)# context admin
asa(config-ctx)# allocate-ips vs0 adminvs0
asa(config-ctx)# exit
asa(config)# context c2
asa(config-ctx)# allocate-ips vs1 c2vs1
asa(config)# context c3
asa(config-ctx)# allocate-ips vs0 c3vs0
asa(config-ctx)# allocate-ips vs1 c3vs1
asa(config-ctx)#
```

Step 7 Configure MPF for each context.

Note The following example shows context 3 (c3).

```
asa(config)# context c3
asa/c3(config)# class-map any
asa/c3(config-cmap)# match access-list any
asa/c3(config-cmap)# exit
asa/c3(config)# policy-map ips_out
asa/c3(config-pmap)# class any
asa/c3(config-pmap-c)# ips promiscuous fail-close sensor c3vs1
asa/c3(config-pmap-c)# policy-map ips_in
asa/c3(config-pmap)# class any
asa/c3(config-pmap-c)# ips inline fail-open sensor c3vs0
asa/c3(config-pmap-c)# service-policy ips_out interface outside
asa/c3(config)# service-policy ips_in interface inside
```

```
asa/c3(config)#
```

Step 8 Confirm the configuration.

```
asa/c3(config)# exit
```

```
asa(config)# show ips detail
```

Sensor Name	Sensor ID	Allocated To	Mapped Name
-----	-----	-----	-----
vs0	1	admin	adminvs0
		c3	c3vs0
vs1	2	c2	c2vs1
		c3	c3vs1

```
asa(config)#
```

The ASA 5585-X IPS SSP and the Normalizer Engine

The majority of the features in the Normalizer engine are not used on the ASA 5585-X IPS SSP, because the ASA itself handles the normalization. Packets on the ASA IPS modules go through a special path in the Normalizer that only reassembles fragments and puts packets in the right order for the TCP stream. The Normalizer does not do any of the normalization that is done on an inline IPS appliance, because that causes problems in the way the ASA handles the packets.

The following Normalizer engine signatures are not supported:

- 1300.0
- 1304.0
- 1305.0
- 1307.0
- 1308.0
- 1309.0
- 1311.0
- 1315.0
- 1316.0
- 1317.0
- 1330.0
- 1330.1
- 1330.2
- 1330.9
- 1330.10
- 1330.12
- 1330.14
- 1330.15
- 1330.16
- 1330.17

- 1330.18

For More Information

For detailed information about the Normalizer engine, see [Normalizer Engine](#), page B-37.

The ASA 5585-X IPS SSP and Bypass Mode

The ASA 5585-X IPS SSP does not support bypass mode. The adaptive security appliance will either fail open, fail close, or fail over depending on the configuration of the adaptive security appliance and the type of activity being done on the ASA 5585-X IPS SSP.

The SensorApp Fails

The following occurs when the SensorApp fails:

- If the adaptive security appliance is configured for failover, then the adaptive security appliance fails over.
- If the adaptive security appliance is not configured for failover or failover is not possible:
 - If set to fail-open, the adaptive security appliance passes traffic without sending it to the ASA IPS module.
 - If set to fail-close, the adaptive security appliance stops passing traffic until the ASA IPS module is restarted.

The SensorApp is Reconfigured

The following occurs when the SensorApp is reconfigured:

- If set to fail-open, the adaptive security appliance passes traffic without sending it to the ASA IPS module.
- If set to fail-close, the adaptive security appliance stops passing traffic until the ASA IPS module is restarted.



Note

The adaptive security appliance does not failover unless the reconfiguration is not completed.

The ASA 5585-X IPS SSP and Jumbo Packets

The jumbo packet count in the **show interface** command output from the lines `Total Jumbo Packets Received` and `Total Jumbo Packets Transmitted` for ASA IPS modules may be larger than expected due to some packets that were almost jumbo size on the wire being counted as jumbo size by the IPS. This miscount is a result of header bytes added to the packet by the ASA before the packet is transmitted to the IPS. For IPv4, 58 bytes of header data are added. For IPv6, 78 bytes of header data are added. The ASA removes the added IPS header before the packet leaves the ASA.

Reloading, Shutting Down, Resetting, and Recovering the ASA 5585-X IPS SSP



Note

You can enter the **hw-module** commands from privileged EXEC mode or from global configuration mode. You can enter the commands in single routed mode and single transparent mode. For adaptive security appliances operating in multi-mode (routed or transparent multi-mode) you can only execute the **hw-module** commands from the system context (not from administrator or user contexts).

Use the following commands to reload, shut down, reset, recover the password, and recover the ASA 5585-X IPS SSP directly from the adaptive security appliance:

- **hw-module module slot_number reload**—This command reloads the software on the ASA 5585-X IPS SSP without doing a hardware reset. It is effective only when the module is in the Up state.
- **hw-module module slot_number shutdown**—This command shuts down the software on the ASA 5585-X IPS SSP. It is effective only when the module is in Up state.
- **hw-module module slot_number reset**—This command performs a hardware reset of the ASA 5585-X IPS SSP. It is applicable when the module is in the Up/Down/Unresponsive/Recover states.
- **hw-module module slot_number password-reset**—This command restores the cisco CLI account password on the ASA 5585-X IPS SSP to the default **cisco**.
- **hw-module module slot_number recover [boot | stop | configure]**—The **recover** command displays a set of interactive options for setting or changing the recovery parameters. To change the parameter or keep the existing setting, press **Enter**.
 - **hw-module module slot_number recover boot**—This command initiates recovery of the ASA 5585-X IPS SSP. It is applicable only when the module is in the Up state.
 - **hw-module module slot_number recover stop**—This command stops recovery of the ASA 5585-X IPS SSP. It is applicable only when the module is in the Recover state.



Caution

If the ASA 5585-X IPS SSP recovery needs to be stopped, you must issue the **hw-module module 1 recover stop** command within 30 to 45 seconds after starting the recovery. Waiting any longer can lead to unexpected consequences. For example, the module may come up in the Unresponsive state.

- **hw-module module 1 recover configure**—Use this command to configure parameters for the ASA 5585-X IPS SSP recovery. The essential parameters are the IP address and recovery image TFTP URL location.

Example

```
ips-ssp# hardware-module module 1 recover configure
Image URL [tftp://10.89.146.1/IPS-SSP_10-K9-sys-1.1-a-7.1-1-E4.img]:
Port IP Address [10.89.149.226]:
VLAN ID [0]:
Gateway IP Address [10.89.149.254]:
```

For More Information

For the procedure for recovering the ASA 5585-X IPS SSP system image, see [Installing the System Image for the ASA 5585-X IPS SSP, page 22-32](#).

Health and Status Information

To see the general health of the ASA 5585-X IPS SSP, use the **show module 1 details** command.

```
asa# show module 1 details
Getting details from the Service Module, please wait...
ASA 5585-X IPS Security Services Processor-20 with 8GE
Model:                ASA5585-SSP-IPS20
Hardware version:     1.0
Serial Number:        ABC1234DEFG
Firmware version:     2.0(1)3
Software version:     7.1(1)E4
MAC Address Range:    8843.e12f.5414 to 8843.e12f.541f
App. name:            IPS
App. Status:          Up
App. Status Desc:     Normal Operation
App. version:         7.1(1)E4
Data plane Status:    Up
Status:               Up
Mgmt IP addr:         192.0.2.3
Mgmt Network mask:    255.255.255.0
Mgmt Gateway:         192.0.2.254
Mgmt Access List:     10.0.0.0/8
Mgmt Access List:     64.0.0.0/8
Mgmt web ports:       443
Mgmt TLS enabled      true
asa
```

The output shows that the ASA 5585-X IPS SSP is up. If the status reads `Down`, you can reset it using the **hw-module module 1 reset** command.

```
asa# hw-module module 1 reset
The module in slot 1 should be shut down before
resetting it or loss of configuration may occur.
Reset module in slot 1? [confirm]
Reset issued for module in slot 1
asa# show module 1 details
Getting details from the Service Module, please wait...
Unable to read details from slot 1
ASA 5585-X IPS Security Services Processor-20 with 8GE
Model:                ASA5585-SSP-IPS20
Hardware version:     1.0
Serial Number:        ABC1234DEFG
Firmware version:     2.0(7)0
Software version:     7.1(1)E4
MAC Address Range:    5475.d029.7f9c to 5475.d029.7fa7
App. name:            IPS
App. Status:          Not Applicable
App. Status Desc:     Not Applicable
App. version:         7.1(1)E4
Data plane Status:    Not Applicable
Status:               Shutting Down
asa# show module 1 details
Getting details from the Service Module, please wait...
Unable to read details from slot 1
ASA 5585-X IPS Security Services Processor-20 with 8GE
Model:                ASA5585-SSP-IPS20
Hardware version:     1.0
Serial Number:        ABC1234DEFG
Firmware version:     2.0(7)0
Software version:     7.1(1)E4
MAC Address Range:    5475.d029.7f9c to 5475.d029.7fa7
App. name:            IPS
```

```

App. Status:      Not Applicable
App. Status Desc: Not Applicable
App. version:     7.1(1)E4
Data plane Status: Not Applicable
Status:           Down
asa# show module 1 details
Getting details from the Service Module, please wait...
Unable to read details from slot 1
ASA 5585-X IPS Security Services Processor-20 with 8GE
Model:            ASA5585-SSP-IPS20
Hardware version: 1.0
Serial Number:    ABC1234DEFG
Firmware version: 2.0(7)0
Software version: 7.1(1)E4
MAC Address Range: 5475.d029.7f9c to 5475.d029.7fa7
App. name:        IPS
App. Status:      Not Applicable
App. Status Desc: Not Applicable
App. version:     7.1(1)E4
Data plane Status: Not Applicable
Status:           Init
asa# show module 1 details
Getting details from the Service Module, please wait...
ASA 5585-X IPS Security Services Processor-20 with 8GE
Model:            ASA5585-SSP-IPS20
Hardware version: 1.0
Serial Number:    ABC1234DEFG
Firmware version: 2.0(7)0
Software version: 7.1(1)E4
MAC Address Range: 5475.d029.7f9c to 5475.d029.7fa7
App. name:        IPS
App. Status:      Reload
App. Status Desc: Starting up
App. version:     7.1(1)E4
Data plane Status: Down
Status:           Up
Mgmt IP addr:     192.0.2.3
Mgmt Network mask: 255.255.255.0
Mgmt Gateway:     192.0.2.254
Mgmt Access List: 0.0.0.0/0
Mgmt web ports:   443
Mgmt TLS enabled: true
asa# show module 1 details
Getting details from the Service Module, please wait...
ASA 5585-X IPS Security Services Processor-20 with 8GE
Model:            ASA5585-SSP-IPS20
Hardware version: 1.0
Serial Number:    ABC1234DEFG
Firmware version: 2.0(7)0
Software version: 7.1(1)E4
MAC Address Range: 5475.d029.7f9c to 5475.d029.7fa7
App. name:        IPS
App. Status:      Up
App. Status Desc: Normal Operation
App. version:     7.1(1)E4
Data plane Status: Up
Status:           Up
Mgmt IP addr:     192.0.2.3
Mgmt Network mask: 255.255.255.0
Mgmt Gateway:     192.0.2.254
Mgmt Access List: 0.0.0.0/0
Mgmt web ports:   443
Mgmt TLS enabled: true
asa#

```

If you have problems with reimaging the ASA 5585-X IPS SSP, use the **debug module-boot** command to see the output as it boots. Make sure you have the correct IP address for the TFTP server and you have the correct file on the TFTP server. Then use the **hw-module module 1 recover** command again to reimage the module.

```
ips-ssp# hw-module module 1 recover configure
Image URL [tftp://0.0.0.0/]: tftp://10.10.10.10//IPS-SSP_20-K9-sys-1.1-a-7.1-1-E4.img
Port IP Address [0.0.0.0]: 10.10.10.11
VLAN ID [0]:
Gateway IP Address [0.0.0.0]: 10.10.10.254

asa(config)# debug module-boot
debug module-boot enabled at level 1
asa(config)# hw-module module 1 recover boot
The module in slot 1 will be recovered. This may erase all configuration and all data on
that device and attempt to download a new image for it.
Recover module in slot 1? [confirm]
Recover issued for module in slot 1
asa(config)# Slot-1 140> Cisco Systems ROMMON Version (1.0(10)0) #0: Fri Mar 25 23:02:10
PST 2010
Slot-1 141> Platform ASA5585-SSP-IPS20
Slot-1 142> GigabitEthernet0/0
Slot-1 143> Link is UP
Slot-1 144> MAC Address: 000b.fcf8.0176
Slot-1 145> ROMMON Variable Settings:
Slot-1 146> ADDRESS=192.0.2.3
Slot-1 147> SERVER=192.0.2.15
Slot-1 148> GATEWAY=192.0.2.254
Slot-1 149> PORT=GigabitEthernet0/0
Slot-1 150> VLAN=untagged
Slot-1 151> IMAGE=IPS-SSP-K9-sys-1.1-a-7.1-0.1.img
Slot-1 152> CONFIG=
Slot-1 153> LINKTIMEOUT=20
Slot-1 154> PKTTIMEOUT=4
Slot-1 155> RETRY=20
Slot-1 156> tftp IPS-SSP_10-K9-sys-1.1-a-7.1-0.1.img@192.0.2.15 via 192.0.2.254
Slot-1 157> TFTP failure: Packet verify failed after 20 retries
Slot-1 158> Rebooting due to Autoboot error ...
Slot-1 159> Rebooting....
Slot-1 160> Cisco Systems ROMMON Version (1.0(10)0) #0: Fri Mar 25 23:02:10 PST 2010
Slot-1 161> Platform ASA5585-SSP-IPS20
Slot-1 162> GigabitEthernet0/0
Slot-1 163> Link is UP
Slot-1 164> MAC Address: 000b.fcf8.0176
Slot-1 165> ROMMON Variable Settings:
Slot-1 166> ADDRESS=192.0.2.3
Slot-1 167> SERVER=192.0.2.15
Slot-1 168> GATEWAY=192.0.2.254
Slot-1 169> PORT=GigabitEthernet0/0
Slot-1 170> VLAN=untagged
Slot-1 171> IMAGE=IPS-SSP_10-K9-sys-1.1-a-7.1-0.1.img
Slot-1 172> CONFIG=
Slot-1 173> LINKTIMEOUT=20
Slot-1 174> PKTTIMEOUT=4
Slot-1 175> RETRY=20
Slot-1 176> tftp IPS-SSP_10-K9-sys-1.1-a-7.1-0.1.img@192.0.2.15 via 192.0.2.254
```

Traffic Flow Stopped on IPS Switchports

Problem Traffic on any port located on the ASA 5585-X IPS SSP (1/x) no longer passes through the adaptive security appliance when the ASA 5585-X IPS SSP is reset or shut down. This affects all traffic through these ports regardless of whether or not the traffic would have been monitored by the IPS. The link on the ports will link down when the ASA 5585-X IPS SSP is reset or shut down.

Possible Cause Using the ports located on the ASA 5585-X IPS SSP (1/x), and resetting or shutting it down via any mechanism.

Solution Use the ports on the adaptive security appliance (0/x) instead because those ports do not lose their link when the ASA 5585-X IPS SSP is reset or shut down.

Failover Scenarios

The following failover scenarios apply to the ASA 5585-X in the event of configuration changes, signature/signature engine updates, service packs, and SensorApp crashes on the ASA 5585-X IPS SSP.

Single ASA 5585-X in Fail-Open Mode

- If the ASA is configured in fail-open mode for the ASA 5585-X IPS SSP, and the ASA 5585-X IPS SSP experiences a configuration change or signature/signature engine update, traffic is passed through the ASA without being inspected.
- If the ASA is configured in fail-open mode for the ASA 5585-X IPS SSP, and the ASA 5585-X IPS SSP experiences a SensorApp crash or a service pack upgrade, traffic is passed through the ASA without being inspected.

Single ASA 5585-X in Fail-Close Mode

- If the ASA is configured in fail-close mode for the ASA 5585-X IPS SSP, and the ASA 5585-X IPS SSP experiences a configuration change or a signature/signature engine update, traffic is stopped from passing through the ASA.
- If the ASA is configured in fail-close mode for the ASA 5585-X IPS SSP, and the ASA 5585-X IPS SSP experiences a SensorApp crash or a service pack upgrade, traffic is stopped from passing through the ASA.

Two ASA 5585-Xs in Fail-Open Mode

- If the ASAs are configured in fail-open mode and if the ASA 5585-X IPS SSP on the active ASA experiences a configuration change or a signature/signature engine update, traffic is still passed through the active ASA without being inspected. Failover is not triggered.
- If the ASAs are configured in fail-open mode, and if the ASA 5585-X IPS SSP on the active ASA experiences a SensorApp crash or a service pack upgrade, failover is triggered and traffic passes through the ASA 5585-X IPS SSP that was previously the standby ASA 5585-X IPS SSP.

Two ASA 5585-Xs in Fail-Close Mode

- If the ASAs are configured in fail-close mode, and if the ASA 5585-X IPS SSP on the active ASA experiences a configuration change or a signature/signature engine update, traffic is stopped from passing through the active ASA. No failover is triggered.

- If the ASAs are configured in fail-close mode, and if the ASA 5585-X IPS SSP on the active ASA experiences a SensorApp crash or a service pack upgrade, failover is triggered and traffic passes through the ASA 5585-X IPS SSP that was previously the standby for the ASA 5585-X IPS SSP.

Configuration Examples

Use the following configuration for the primary ASA:

```
interface GigabitEthernet0/7
  description LAN Failover Interface

failover
failover lan unit primary
failover lan interface folink GigabitEthernet0/7
failover interface ip folink 172.27.48.1 255.255.255.0 standby 172.27.48.2
```

Use the following configuration for the secondary ASA:

```
interface GigabitEthernet0/7
  description LAN Failover Interface

failover
failover lan unit secondary
failover lan interface folink GigabitEthernet0/7
failover interface ip folink 172.27.48.1 255.255.255.0 standby 172.27.48.2
```




Obtaining Software

This chapter provides information on obtaining the latest Cisco IPS software. It contains the following sections:

- [IPS 7.1 File List, page 21-1](#)
- [Obtaining Cisco IPS Software, page 21-1](#)
- [IPS Software Versioning, page 21-3](#)
- [Accessing IPS Documentation, page 21-7](#)
- [Cisco Security Intelligence Operations, page 21-7](#)

IPS 7.1 File List

The currently supported IPS 7.1(x) versions are 7.1(1)E4, 7.1(2)E4, 7.1(3)E4, and 7.1(4)E4, 7.1(5)E4, 7.1(6)E4, 7.1(7)E4, IPS 7.1(8)E4, and IPS 7.1(9)E4. All IPS sensors are not supported in each 7.1(x) version.

For a list of the specific IPS filenames and the IPS versions that each sensor supports, refer to the Release Notes for your IPS version found at this URL:

http://www.cisco.com/en/US/products/hw/vpndevc/ps4077/prod_release_notes_list.html

Obtaining Cisco IPS Software

You can find major and minor updates, service packs, signature and signature engine updates, system and recovery files, firmware upgrades, and Readmes on the Download Software site on Cisco.com. Signature updates are posted to Cisco.com approximately every week, more often if needed. Service packs are posted to Cisco.com in a release train format, a new release every three months. Major and minor updates are also posted periodically. Check Cisco.com regularly for the latest IPS software.

You must have an account with cryptographic access before you can download software. You set this account up the first time you download IPS software from the Download Software site.



Note

You must be logged in to Cisco.com to download software. You must have an active IPS maintenance contract and a Cisco.com password to download software. You must have a sensor license to apply signature updates.

Downloading Cisco IPS Software

To download software on Cisco.com, follow these steps:

-
- Step 1** Log in to [Cisco.com](https://www.cisco.com).
 - Step 2** From the Support drop-down menu, choose **Download Software**.
 - Step 3** Under Select a Software Product Category, choose **Security Software**.
 - Step 4** Choose **Intrusion Prevention System (IPS)**.
 - Step 5** Enter your username and password.
 - Step 6** In the Download Software window, choose **IPS Appliances > Cisco Intrusion Prevention System** and then click the version you want to download.



Note You must have an IPS subscription service license to download software.

- Step 7** Click the type of software file you need. The available files appear in a list in the right side of the window. You can sort by file name, file size, memory, and release date. And you can access the Release Notes and other product documentation.
 - Step 8** Click the file you want to download. The file details appear.
 - Step 9** Verify that it is the correct file, and click **Download**.
 - Step 10** Click **Agree** to accept the software download rules. The File Download dialog box appears. The first time you download a file from Cisco.com, you must fill in the Encryption Software Export Distribution Authorization form before you can download the software.
 - a.** Fill out the form and click **Submit**. The Cisco Systems Inc. Encryption Software Usage Handling and Distribution Policy appears.
 - b.** Read the policy and click **I Accept**. The Encryption Software Export/Distribution Form appears.If you previously filled out the Encryption Software Export Distribution Authorization form, and read and accepted the Cisco Systems Inc. Encryption Software Usage Handling and Distribution Policy, these forms are not displayed again.
 - Step 11** Open the file or save it to your computer.
 - Step 12** Follow the instructions in the Readme or the Release Notes to install the update.
-

For More Information

For an explanation of the IPS file versioning scheme, see [IPS Software Versioning](#), page 21-3.

IPS Software Versioning

When you download IPS software images from Cisco.com, you should understand the versioning scheme so that you know which files are base files, which are cumulative, and which are incremental.

Major Update

A major update contains new functionality or an architectural change in the product. For example, the Cisco IPS 7.1 base version includes everything (except deprecated features) since the previous major release (the minor update features, service pack fixes, and signature updates) plus any new changes. Major update 7.1(1) requires 5.1(6) and later. With each major update there are corresponding system and recovery packages.



Note

The 7.1(1) major update is used to upgrade 5.1(6) and later sensors to 7.1(1). If you are reinstalling 7.1(1) on a sensor that already has 7.1(1) installed, use the system image or recovery procedures rather than the major update.

Minor Update

A minor update is incremental to the major version. Minor updates are also base versions for service packs. The first minor update for 7.1 is 7.2. Minor updates are released for minor enhancements to the product. Minor updates contain all previous minor features (except deprecated features), service pack fixes, signature updates since the last major version, and the new minor features being released. You can install the minor updates on the previous major or minor version (and often even on earlier versions). The minimum supported version needed to upgrade to the newest minor version is listed in the Readme that accompanies the minor update. With each minor update there are corresponding system and recovery packages.

Service Pack

A service pack is cumulative following a base version release (minor or major). Service packs are released in a train release format with several new features per train. Service packs contain all service pack fixes since the last base version (minor or major) and the new features and defect fixes being released. Service packs require the minor version. The minimum supported version needed to upgrade to the newest service pack is listed in the Readme that accompanies the service pack. Service packs also include the latest engine update. For example, if service pack 7.1(3) is released, and E4 is the latest engine level, the service pack is released as 7.1(3)E4.

Patch Release

A patch release is used to address defects that are identified in the upgrade binaries after a software release. Rather than waiting until the next major or minor update, or service pack to address these defects, a patch can be posted. Patches include all prior patch releases within the associated service pack level. The patches roll into the next official major or minor update, or service pack.

Before you can install a patch release, the most recent major or minor update, or service pack must be installed. For example, patch release 7.1(1p1) requires 7.1(1).




Note

Upgrading to a newer patch does not require you to uninstall the old patch. For example, you can upgrade from patch 7.1(1p1) to 7.1(1p2) without first uninstalling 7.1(1p1).

Figure 21-1 illustrates what each part of the IPS software file represents for major and minor updates, service packs, and patch releases.

Figure 21-1 *IPS Software File Name for Major and Minor Updates, Service Packs, and Patch Releases*




Signature Update and Signature Engine Update

A signature update is a package file containing a set of rules designed to recognize malicious network activities. Signature updates are released independently from other software updates. Each time a major or minor update is released, you can install signature updates on the new version and the next oldest version for a period of at least six months. Signature updates are dependent on a required signature engine version. Because of this, a *req* designator lists the signature engine required to support a particular signature update.

The signature engine update is contained in the signature updates.

Figure 21-2 illustrates what each part of the IPS software file represents for signature updates and signature engine updates.

Figure 21-2 *IPS Software File Name for Signature Updates and Signature Engine Updates*




Recovery and System Image Files

Recovery and system image files contain separate versions for the installer and the underlying application. The installer version contains a major and minor version field. The major version is incremented by one of any major changes to the image installer, for example, switching from .tar to rpm or changing kernels. The minor version can be incremented by any one of the following:

- Minor change to the installer, for example, a user prompt added.
- Repackages require the installer minor version to be incremented by one if the image file must be repackaged to address a defect or problem with the installer.

Figure 21-3 illustrates what each part of the IPS software file represents for recovery and system image filenames.

Figure 21-3 IPS Software File Name for Recovery and System Image Files



IPS Software Release Examples

Table 21-1 lists the Cisco IPS software release examples.

Table 21-1 Release Examples

Release	Target Frequency	Identifier	Example Version	Example Filename
Signature update and signature engine update ¹	Weekly for signature updates, as needed for signature engine updates	sig	S552 E4	IPS- <i>identifier</i> -sig-S552-req-E4.pkg
Service packs ²	Every three months	—	7.1(2)	IPS- <i>identifier</i> -K9-7.1-2-E4.pkg
Minor version update ³	Annually	—	7.1(1)	IPS- <i>identifier</i> -K9-7.1-2-E4.pkg
Major version update ⁴	Annually	—	8.0(1)	IPS- <i>identifier</i> -K9-8.0-1-E4.pkg
Patch release ⁵	As needed	patch	7.2(1p1)	IPS- <i>identifier</i> -K9-patch-7.2-1pl-E4.pkg
Recovery package ⁶	Annually or as needed	r	1.1-7.2(1)	IPS- <i>identifier</i> -K9-r-1.1-a-7.2-1-E4.pkg
System image ⁷	Annually	sys	Separate file per sensor platform	IPS-SSP_60-K9-sys-1.1-a-7.1-2-E4.img IPS-4345-K9-sys-1.1-a-7.1-2-E4.img IPS-SSP_5545-K9-sys-1.1-a-7.1-2-E4.aip IPS-4510-K9-sys-1.1-a-7.1-4-E4.img

1. Signature updates include the latest cumulative IPS signatures. Signature engine updates add new engines or engine parameters that are used by new signatures in later signature updates.
2. Service packs include new features and defect fixes.
3. Minor versions include new minor version features and/or minor version functionality.
4. Major versions include new major version functionality or new architecture.
5. Patch releases are for interim fixes.
6. The r 1.1 can be revised to r 1.2 if it is necessary to release a new recovery package that contains the same underlying application image. If there are defect fixes for the installer, for example, the underlying application version may still be 7.1(3), but the recovery partition image will be r 1.2.
7. The system image includes the combined recovery and application image used to reimage an entire sensor.

Table 21-3 describes the platform identifiers used in platform-specific names.

Table 21-3 Platform Identifiers

Sensor Family	Identifier
ASA 5500 series	SSM_10 SSM_20 SSM_40
ASA 5500-X series	SSP_5512 SSP_5515 SSP_5525 SSP_5545 SSP_5555
ASA 5585-X series	SSP_10 SSP_20 SSP_40 SSP_60
IPS 4240 series	4240
IPS 4255 series	4255
IPS 4260 series	4260
IPS 4270-20 series	4270_20
IPS 4345 series	4345
IPS 4360 series	4360
IPS 4510 series	4510
IPS 4520 series	4520

For More Information

For instructions on how to access these files on Cisco.com, see [Obtaining Cisco IPS Software, page 21-1](#).

Accessing IPS Documentation

You can find IPS documentation at this URL:

http://www.cisco.com/en/US/products/hw/vpndevc/ps4077/tsd_products_support_series_home.html

Or to access IPS documentation from Cisco.com, follow these steps:

-
- Step 1** Log in to [Cisco.com](http://www.cisco.com).
- Step 2** Click **Support**.
- Step 3** Under Support at the bottom of the page, click **Documentation**.
- Step 4** Choose **Products > Security > Intrusion Prevention System (IPS) > IPS Appliances > Cisco IPS 4200 Series Sensors**. The Cisco IPS 4200 Series Sensors page appears. All of the most up-to-date IPS documentation is on this page.



Note Although you will see references to other IPS documentation sites on Cisco.com, this is the site with the most complete and up-to-date IPS documentation.

- Step 5** Click one of the following categories to access Cisco IPS documentation:

- **Download Software**—Takes you to the Download Software site.



Note You must be logged into Cisco.com to access the software download site.

- **Release and General Information**—Contains documentation roadmaps and release notes.
 - **Reference Guides**—Contains command references and technical references.
 - **Design**—Contains design guide and design tech notes.
 - **Install and Upgrade**—Contains hardware installation and regulatory guides.
 - **Configure**—Contains configuration guides for IPS CLI, IDM, and IME.
 - **Troubleshoot and Alerts**—Contains TAC tech notes and field notices.
-

Cisco Security Intelligence Operations

The Cisco Security Intelligence Operations site on Cisco.com provides intelligence reports about current vulnerabilities and security threats. It also has reports on other security topics that help you protect your network and deploy your security systems to reduce organizational risk.

You should be aware of the most recent security threats so that you can most effectively secure and manage your network. Cisco Security Intelligence Operations contains the top ten intelligence reports listed by date, severity, urgency, and whether there is a new signature available to deal with the threat.

Cisco Security Intelligence Operations contains a Security News section that lists security articles of interest. There are related security tools and links.

You can access Cisco Security Intelligence Operations at this URL:

<http://tools.cisco.com/security/center/home.x>

Cisco Security Intelligence Operations is also a repository of information for individual signatures, including signature ID, type, structure, and description.

You can search for security alerts and signatures at this URL:

<http://tools.cisco.com/security/center/search.x>



Upgrading, Downgrading, and Installing System Images

This chapter describes how to upgrade, downgrade, and install system images. It contains the following sections:

- [Upgrade Notes and Caveats, page 22-1](#)
- [Upgrades, Downgrades, and System Images, page 22-2](#)
- [Supported FTP and HTTP/HTTPS Servers, page 22-3](#)
- [Upgrading the Sensor, page 22-4](#)
- [Configuring Automatic Upgrades, page 22-8](#)
- [Downgrading the Sensor, page 22-11](#)
- [Recovering the Application Partition, page 22-12](#)
- [Installing System Images, page 22-13](#)

Upgrade Notes and Caveats

Pay attention to the following upgrade notes and caveats when upgrading your sensor:

- Anomaly detection has been disabled by default in IPS 7.1(2)E4 and later. If you did not configure the operation mode manually before the upgrade, it defaults to inactive after you upgrade to IPS 7.1(2)E4 or later. If you configured the operation mode to detect, learn, or inactive, the tuned value is preserved after the upgrade.
- You must have a valid maintenance contract per sensor to download software upgrades from Cisco.com.
- This service pack automatically reboots the sensor to apply the changes. During reboot, inline network traffic is disrupted.
- You cannot uninstall IPS 7.1(x)E4. To revert to a previous version, you must reimage the sensor using the appropriate system image file.
- You cannot use the **downgrade** command to revert to a previous major or minor version, for example, from Cisco IPS 7.1 to 7.0. You can only use the **downgrade** command to downgrade from the latest signature update or signature engine update. To revert to 7.0, you must reimage the sensor.
- You cannot downgrade the sensor using the recovery partition. To downgrade to an earlier version, you must install the appropriate system image file (.img file).

- During a signature upgrade all signature configurations are retained, both the signature tunings as well as the custom signatures. During a signature downgrade the current signature configuration is replaced with the old signature configuration. So if the last signature set had custom signatures and/or signature tunings, these are restored during the downgrade.
- All user configuration settings are lost when you install the system image. Before trying to recover the sensor by installing the system image, try to recover by using the **recover application-partition** command or by selecting the recovery partition during sensor bootup.

For More Information

- For the procedure for accessing downloads on Cisco.com, see [Obtaining Cisco IPS Software](#), page 21-1.
- For the procedure for using the **upgrade** command to upgrade the sensor, see [Upgrading the Sensor](#), page 22-4.
- For the procedure for configuring automatic upgrades on the sensor, see [Configuring Automatic Upgrades](#), page 22-8.
- For the procedure for using the **recover** command, see [Recovering the Application Partition](#), page 22-12.
- For the procedure for installing the IPS 4240 and IPS 4255 system image, see [Installing the System Images for the IPS-4240 and IPS-4255](#), page 22-15.
- For the procedure for installing the IPS 4260 system image, see [Installing the System Image for the IPS 4260](#), page 22-18.
- For the procedure for installing the IPS 4270-20 system image, see [Installing the System Image for the IPS 4270-20](#), page 22-20.
- For the procedure for installing the IPS 4345 and IPS 4360 system image, see [Installing the System Image for the IPS 4345 and IPS 4360](#), page 22-22.
- For the procedure for installing the IPS 4510 and IPS 4520 system image, see [Installing the System Image for the IPS 4510 and IPS 4520](#), page 22-26.
- For the procedure for installing the ASA 5500 AIP SSM system image, see [Installing the System Image for the ASA 5500 AIP SSM](#), page 22-28.
- For the procedure for installing the ASA 5500-X IPS SSP system image, see [Installing the System Image for the ASA 5500-X IPS SSP](#), page 22-31.
- For the procedure for installing the ASA 5585-X IPS SSP system image, see [Installing the System Image for the ASA 5585-X IPS SSP](#), page 22-32.

Upgrades, Downgrades, and System Images



Caution

You cannot use the **downgrade** command to revert to a previous major or minor version, for example, from Cisco IPS 7.1 to 7.0. You can only use the **downgrade** command to downgrade from the latest signature update or signature engine update. To revert to 7.0, you must reimagine the sensor.



Note

You cannot downgrade the sensor using the recovery partition. To downgrade to an earlier version, you must install the appropriate system image file (.img file).

**Note**

During a signature upgrade all signature configurations are retained, both the signature tunings as well as the custom signatures. During a signature downgrade the current signature configuration is replaced with the old signature configuration. So if the last signature set had custom signatures and/or signature tunings, these are restored during the downgrade.

You can upgrade and downgrade the software on the sensor. Upgrading applies a service pack, signature update, signature engine update, minor version, major version, or recovery partition file. Downgrading removes the last applied service pack or signature update from the sensor.

You can recover the application partition image on your sensor if it becomes unusable. Using the **recover** command lets you retain your host settings while other settings revert to the factory defaults.

To install a new system image on the sensor, use ROMMON, the bootloader file, or the maintenance partition depending on which platform you have. When you install a new system image on your sensor, all accounts are removed and the default cisco account is reset to use the default password **cisco**. After installing the system image, you must initialize the sensor again.

After you reimage and initialize your sensor, upgrade your sensor with the most recent service pack, signature update, signature engine update, minor update, major update, and recovery partition files.

For More Information

- For the procedure for initializing the sensor, see [Basic Sensor Setup, page 3-5](#).
- For the procedure for locating software on Cisco.com, see [Obtaining Cisco IPS Software, page 21-1](#).

Supported FTP and HTTP/HTTPS Servers

The following FTP servers are supported for IPS software updates:

- WU-FTPD 2.6.2 (Linux)
- Solaris 2.8
- Sambar 6.0 (Windows 2000)
- Serv-U 5.0 (Windows 2000)
- MS IIS 5.0 (Windows 2000)

The following HTTP/HTTPS servers are supported for IPS software updates:

- CSM - Apache Server (Tomcat)
- CSM - Apache Server (JRun)

For More Information

- For the procedure for downloading IPS software updates from Cisco.com, see [Obtaining Cisco IPS Software, page 21-1](#).
- For the procedure for configuring automatic updates, see [Configuring Automatic Upgrades, page 22-8](#).

Upgrading the Sensor

This section explains how to use the **upgrade** command to upgrade the software on the sensor. It contains the following topics:

- [IPS 7.1 Upgrade Files, page 22-4](#)
- [Upgrade Notes and Caveats, page 22-4](#)
- [Manually Upgrading the Sensor, page 22-4](#)
- [Upgrading the Sensor, page 22-5](#)
- [Upgrading the Recovery Partition, page 22-7](#)

IPS 7.1 Upgrade Files

The currently supported IPS 7.1(x) versions are 7.1(1)E4, 7.1(2)E4, 7.1(3)E4, and 7.1(4)E4, 7.1(5)E4, and 7.1(6)E4. All IPS sensors are not supported in each 7.1(x) version.

For a list of the specific IPS filenames and the IPS versions that each sensor supports, refer to the Release Notes for your IPS version found at this URL:

http://www.cisco.com/en/US/products/hw/vpndevc/ps4077/prod_release_notes_list.html

For More Information

For the procedure for obtaining these files on Cisco.com, see [Obtaining Cisco IPS Software, page 21-1](#).

Upgrade Notes and Caveats

For a list of the upgrade notes and caveats for each IPS version, refer to the Release Notes for your IPS version found at this URL:

http://www.cisco.com/en/US/products/hw/vpndevc/ps4077/prod_release_notes_list.html

Manually Upgrading the Sensor



Note

During a signature upgrade all signature configurations are retained, both the signature tunings as well as the custom signatures. During a signature downgrade the current signature configuration is replaced with the old signature configuration. So if the last signature set had custom signatures and/or signature tunings, these are restored during the downgrade.



Caution

You must log in to Cisco.com using an account with cryptographic privileges to download software. The first time you download software on Cisco.com, you receive instructions for setting up an account with cryptographic privileges.



Note

Do not change the filename. You must preserve the original filename for the sensor to accept the update.

Use the **upgrade** *source-url* command to apply service pack, signature update, engine update, minor version, major version, or recovery partition file upgrades. The following options apply:

- *source-url*—Specifies the location of the source file to be copied:
 - **ftp:**—Source URL for an FTP network server. The syntax for this prefix is:
`ftp://[[username@]location][relativeDirectory]/filename`
`ftp://[[username@]location][absoluteDirectory]/filename`



Note You are prompted for a password.

- **scp:**—Source URL for the SCP network server. The syntax for this prefix is:
`scp://[[username@]location][relativeDirectory]/filename`
`scp://[[username@]location][absoluteDirectory]/filename`



Note You are prompted for a password. You must add the remote host to the SSH known hosts list.

- **http:**—Source URL for the web server. The syntax for this prefix is:
`http://[[username@]location][directory]/filename`



Note The directory specification should be an absolute path to the desired file.

- **https:**—Source URL for the web server. The syntax for this prefix is:
`https://[[username@]location][directory]/filename`



Note The directory specification should be an absolute path to the desired file. The remote host must be a TLS trusted host.

Upgrading the Sensor



Note The CLI output is an example of what your configuration may look like. It will not match exactly due to the optional setup choices, sensor model, and IPS 7.1 version you have installed.

To upgrade the sensor, follow these steps:

- Step 1** Download the appropriate file to an FTP, SCP, HTTP, or HTTPS server that is accessible from your sensor.
- Step 2** Log in to the CLI using an account with administrator privileges.
- Step 3** Enter configuration mode.

```
sensor# configure terminal
```
- Step 4** Upgrade the sensor.

```
sensor(config)# upgrade url/IPS-SSP_10-K9-7.1-3-E4.pkg
```

The URL points to where the update file is located, for example, to retrieve the update using FTP, enter the following:

```
sensor(config)# upgrade ftp://username@ip_address//directory/IPS-SSP_10-K9-7.1-3-E4.pkg
```

Step 5 Enter the password when prompted.

```
Enter password: *****
```

Step 6 Enter **yes** to complete the upgrade.



Note Major updates, minor updates, and service packs may force a restart of the IPS processes or even force a reboot of the sensor to complete installation.



Note The operating system is reimaged and all files that have been placed on the sensor through the service account are removed.

Step 7 Verify your new sensor version.

```
sensor# show version
Application Partition:
```

```
Cisco Intrusion Prevention System, Version 7.1(3)E4
```

```
Host:
```

```
    Realm Keys          key1.0
Signature Definition:
    Signature Update    S605.0          2011-10-25
OS Version:            2.6.29.1
Platform:              ASA5585-SSP-IPS10
Serial Number:         123456789AB
```

```
No license present
```

```
Sensor up-time is 11 days.
```

```
Using 4395M out of 5839M bytes of available memory (75% usage)
system is using 26.2M out of 160.0M bytes of available disk space (16% usage)
application-data is using 69.6M out of 171.6M bytes of available disk space (43% usage)
boot is using 57.3M out of 70.5M bytes of available disk space (86% usage)
application-log is using 494.0M out of 513.0M bytes of available disk space (96% usage)
```

```
MainApp          S-2011_NOV_16_00_20_7_1_3_46   (Release)  2011-11-16T00:23:0 6-0600
Running
AnalysisEngine   S-2011_NOV_16_00_20_7_1_3_46   (Release)  2011-11-16T00:23:0 6-0600
Running
CollaborationApp S-2011_NOV_16_00_20_7_1_3_46   (Release)  2011-11-16T00:23:0 6-0600
Running
CLI              S-2011_NOV_16_00_20_7_1_3_46   (Release)  2011-11-16T00:23:0 6-0600
```

```
Upgrade History:
```

```
IPS-K9-7.1-3-E4   00:30:07 UTC Wed Nov 16 2011
```

```
Recovery Partition Version 1.1 - 7.1(3)E4
```

```
Host Certificate Valid from: 16-Nov-2011 to 16-Nov-2013
sensor#
```

For More Information

- For a list of supported FTP and HTTP/HTTPS servers, see [Supported FTP and HTTP/HTTPS Servers](#), page 22-3.
- For a list of the specific upgrade files, see [IPS 7.1 Upgrade Files](#), page 22-4.
- For the procedure for locating software on Cisco and obtaining an account with cryptographic privileges, see [Obtaining Cisco IPS Software](#), page 21-1.
- For the IDM procedure for upgrading the sensor, refer to [Manually Updating the Sensor](#). For the IME procedure, refer to [Manually Updating the Sensor](#).

Upgrading the Recovery Partition

**Note**

Recovery partition images are generated for major and minor updates and only in rare situations for service packs or signature updates.

**Note**

You cannot downgrade the sensor using the recovery partition. To downgrade to an earlier version, you must install the appropriate system image file (.img file).

Use the **upgrade** command to upgrade the recovery partition with the most recent version so that it is ready if you need to recover the application partition on your sensor. Recovery partition images are generated for major and minor updates and only in rare situations for service packs or signature updates.

To upgrade the recovery partition on your sensor, follow these steps:

- Step 1** Download the appropriate recovery partition image file to an FTP, SCP, HTTP, or HTTPS server that is accessible from your sensor.

**Caution**

Some browsers add an extension to the filename. The filename of the saved file must match what is displayed on the download page or you cannot use it to upgrade the recovery partition.

- Step 2** Log in to the CLI using an account with administrator privileges.

- Step 3** Enter configuration mode.

```
sensor# configure terminal
```

- Step 4** Upgrade the recovery partition.

```
sensor(config)#
```

```
upgrade scp://user@server_ipaddress//upgrade_path/IPS-SSP_10-K9-r-1.1-a-7.1-3-E4.pkg
```

```
sensor(config)#
```

```
upgrade ftp://user@server_ipaddress//upgrade_path/IPS-SSP_10-K9-r-1.1-a-7.1-3-E4.pkg
```

- Step 5** Enter the server password. The upgrade process begins.

**Note**

This procedure only reimages the recovery partition. The application partition is not modified by this upgrade. To reimage the application partition after the recovery partition, use the **recover application-partition** command.

For More Information

- For a list of supported FTP and HTTP/HTTPS servers, see [Supported FTP and HTTP/HTTPS Servers](#), page 22-3.
- For a list of the specific recovery filenames, see [IPS 7.1 Upgrade Files](#), page 22-4.
- For the procedure for locating software on Cisco.com, see [Obtaining Cisco IPS Software](#), page 21-1.
- For the procedure for using the **recover** command, see [Recovering the Application Partition Image](#), page 22-12.

Configuring Automatic Upgrades

**Note**

For the IDM procedure for automatically upgrading the sensor, refer to [Configuring Automatic Update](#). For the IME procedure, refer to [Configuring Automatic Update](#).

**Caution**

In IPS 7.1(5)E4 and later the default value of the Cisco server IP address has been changed from 198.133.219.25 to 72.163.4.161 in the Auto Update URL configuration. If you have automatic update configured on your sensor, you may need to update firewall rules to allow the sensor to connect to this new IP address.

You can configure the sensor to look for new upgrade files in your upgrade directory automatically. For example, several sensors can point to the same remote FTP server directory with different update schedules, such as every 24 hours, or Monday, Wednesday, and Friday at 11:00 pm.

You specify the following information to schedule automatic upgrades:

- Server IP address
- Path of the directory on the file server where the sensor checks for upgrade files
- File copy protocol (SCP or FTP)
- Username and password
- Upgrade schedule

You must download the software upgrade from Cisco.com and copy it to the upgrade directory before the sensor can poll for automatic upgrades.

Use the **auto-upgrade-option enabled** command in the service host submode to configure automatic upgrades. The following options apply:

- **cisco-server**—Enables automatic signature and engine updates from Cisco.com.
- **cisco-url**—Specifies the Cisco server locator service. You do not need to change this unless the www.cisco.com IP address changes.

- **default**— Sets the value back to the system default setting.
- **directory**— Specifies the directory where upgrade files are located on the file server. A leading '/' indicates an absolute path.
- **file-copy-protocol**— Specifies the file copy protocol used to download files from the file server. The valid values are **ftp** or **scp**.



Note If you use SCP, you must use the **ssh host-key** command to add the server to the SSH known hosts list so the sensor can communicate with it through SSH.

- **ip-address**—Specifies the IP address of the file server.
- **password**—Specifies the user password for Cisco server authentication.
- **schedule-option**—Specifies the schedules for when Cisco server automatic upgrades occur. Calendar scheduling starts upgrades at specific times on specific days. Periodic scheduling starts upgrades at specific periodic intervals.
 - **calendar-schedule**—Configures the days of the week and times of day that automatic upgrades will be performed.
 - **days-of-week**—Specifies the days of the week on which auto-upgrades will be performed. You can select multiple days: *sunday* through *saturday* are the valid values.
 - **no**—Removes an entry or selection setting.
 - **times-of-day**—Specifies the times of day at which auto-upgrades will begin. You can select multiple times. The valid value is *hh:mm[:ss]*.
 - **periodic-schedule**—Specifies the time that the first automatic upgrade should occur, and how long to wait between automatic upgrades.
 - **interval**—Specifies the number of hours to wait between automatic upgrades. Valid values are 0 to 8760.
 - **start-time**—Specifies the time of day to start the first automatic upgrade. The valid value is *hh:mm[:ss]*.
- **user-name**—Specifies the username for server authentication.
- **user-server**—Enables automatic upgrades from a user-defined server.

Configuring Automatic Upgrades

If you get an unauthorized error message while configuring an automatic update, make sure you have the correct ports open on any firewalls between the sensor and Cisco.com. For example, you need port 443 for the initial automatic update connection to www.cisco.com, and you need port 80 to download the chosen package from a Cisco file server. The IP address may change for the Cisco file server, but you can find it in the lastDownloadAttempt section in the output of the **show statistics host** command.



Note

To check the status of the last automatic update or the next scheduled automatic update, run the **show statistics host** command and check the Auto Update Statistics section.

**Caution**

In IPS 7.1(5)E4 and later the default value of the Cisco server IP address has been changed from 198.133.219.25 to 72.163.4.161 in the Auto Update URL configuration. If you have automatic update configured on your sensor, you may need to update firewall rules to allow the sensor to connect to this new IP address.

To schedule automatic upgrades, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter automatic upgrade submode.

```
sensor# configure terminal
sensor(config)# service host
sensor(config-hos)# auto-upgrade
sensor(config-hos-aut)#
```

Step 3 Configure the sensor to automatically look for new upgrades either on Cisco.com or on your file server:

a. On Cisco.com. Continue with Step 4.

```
sensor(config-hos-aut)# cisco-server enabled
```

b. From your server.

```
sensor(config-hos-aut)# user-server enabled
```

c. Specify the IP address of the file server.

```
sensor(config-hos-ena)# ip-address 10.1.1.1
```

d. Specify the directory where the upgrade files are located on the file server.

```
sensor(config-hos-ena)# directory /tftpboot/sensor_updates
```

e. Specify the file server protocol.

```
sensor(config-hos-ena)# file-copy-protocol ftp
```

**Note**

If you use SCP, you must use the **ssh host-key** command to add the server to the SSH known hosts list so the sensor can communicate with it through SSH.

Step 4 Specify the username for authentication.

```
sensor(config-hos-ena)# user-name tester
```

Step 5 Specify the password of the user.

```
sensor(config-hos-ena)# password
Enter password[]: *****
Re-enter password: *****
```

Step 6 Specify the scheduling:

a. For calendar scheduling (starts upgrades at specific times on specific day):

```
sensor(config-hos-ena)# schedule-option calendar-schedule
sensor(config-hos-ena-cal)# days-of-week sunday
sensor(config-hos-ena-cal)# times-of-day 12:00:00
```

- b. For periodic scheduling (starts upgrades at specific periodic intervals):

```
sensor(config-hos-ena) # schedule-option periodic-schedule
sensor(config-hos-ena-per) # interval 24
sensor(config-hos-ena-per) # start-time 13:00:00
```

Step 7 Verify the settings.

```
sensor(config-hos-ena) # show settings
enabled
-----
schedule-option
-----
periodic-schedule
-----
start-time: 13:00:00
interval: 24 hours
-----
-----
ip-address: 10.1.1.1
directory: /tftpboot/update/6.1_dummy_updates
user-name: tester
password: <hidden>
file-copy-protocol: ftp default: scp
-----
sensor(config-hos-ena) #
```

Step 8 Exit automatic upgrade submode.

```
sensor(config-hos-ena) # exit
sensor(config-hos) # exit
Apply Changes?[yes]:
```

Step 9 Press **Enter** to apply the changes or type **no** to discard them.

For More Information

- For a list of supported FTP and HTTP/HTTPS servers, see [Supported FTP and HTTP/HTTPS Servers, page 22-3](#).
- For the CLI procedure for adding the SCP server to the SSH known hosts list, see [Adding Hosts to the SSH Known Hosts List, page 4-45](#).
- For the output of the **show statistics host** command, see [Displaying Statistics, page 17-31](#).
- For the IDM procedure for automatically upgrading the sensor, refer to [Configuring Automatic Update](#). For the IME procedure, refer to [Configuring Automatic Update](#).

Downgrading the Sensor



Caution

You cannot use the **downgrade** command to revert to a previous major or minor version, for example, from Cisco IPS 7.1 to 7.0. You can only use the **downgrade** command to downgrade from the latest signature update or signature engine update. To revert to 7.0, you must reimaging the sensor.

**Note**

You cannot downgrade the sensor using the recovery partition. To downgrade to an earlier version, you must install the appropriate system image file (.img file).

Use the **downgrade** command to remove the last applied signature upgrade or signature engine upgrade from the sensor. To remove the last applied signature update or signature engine update from the sensor, follow these steps:

Step 1 Log in to the sensor using an account with administrator privileges.

Step 2 Enter global configuration mode.

```
sensor# configure terminal
```

Step 3 If there is no recently applied service pack or signature update, the **downgrade** command is not available.

```
sensor(config)# downgrade
No downgrade available.
sensor(config)#
```

Recovering the Application Partition

You can recover the application partition image for the sensor if it becomes unusable. Some network configuration information is retained when you use this method, which lets you have network access after the recovery is performed. Use the **recover application-partition** command to boot to the recovery partition, which automatically recovers the application partition on your sensor. If you have upgraded your recovery partition to the most recent version before you recover the application partition image, you can install the most up-to-date software image.

Because you can execute the **recover application-partition** command through a Telnet or SSH connection, we recommend using this command to recover sensors that are installed at remote locations.

**Note**

When you reconnect to the sensor after recovery, you must log in with the default username and password **cisco**.

Recovering the Application Partition Image

To recover the application partition image, follow these steps:

Step 1 Download the recovery partition image file to an FTP, HTTP, or HTTPS server that is accessible from your sensor.

Step 2 Log in to the CLI using an account with administrator privileges.

Step 3 Enter configuration mode.

```
sensor# configure terminal
```

Step 4 Recover the application partition image.

```
sensor(config)# recover application-partition
```

```
Warning: Executing this command will stop all applications and re-image the node to
version 7.1(x)E4. All configuration changes except for network settings will be reset to
default.
Continue with recovery? []:
```

- Step 5** Enter **yes** to continue. Shutdown begins immediately after you execute the **recover** command. Shutdown can take a while, and you will still have access to the CLI, but access will be terminated without warning.
- The application partition is reimaged using the image stored on the recovery partition. You must now initialize the sensor with the **setup** command. The IP address, netmask, access lists, time zone, and offset are saved and applied to the reimaged application partition. If you executed the **recover application-partition** command remotely, you can SSH to the sensor with the default username and password (**cisco/cisco**) and then initialize the sensor again with the **setup** command. You cannot use Telnet until you initialize the sensor because Telnet is disabled by default.

For More Information

- For more information about TFTP servers, see [TFTP Servers, page 22-14](#).
- For the procedure for locating software on Cisco.com, see [Obtaining Cisco IPS Software, page 21-1](#).
- For the procedure for using the **setup** command to initialize the sensor, see [Basic Sensor Setup, page 3-5](#).
- For the procedure for upgrading the recovery partition to the most recent version, see [Upgrading the Recovery Partition, page 22-7](#).

Installing System Images



Caution

All user configuration settings are lost when you install the system image. Before trying to recover the sensor by installing the system image, try to recover by using the **recover application-partition** command or by selecting the recovery partition during sensor bootup.

This section contains the procedures for installing system images on the appliances and modules. It contains the following topics:

- [ROMMON, page 22-14](#)
- [TFTP Servers, page 22-14](#)
- [Connecting an Appliance to a Terminal Server, page 22-14](#)
- [Installing the System Images for the IPS-4240 and IPS-4255, page 22-15](#)
- [Installing the System Image for the IPS 4260, page 22-18](#)
- [Installing the System Image for the IPS 4270-20, page 22-20](#)
- [Installing the System Image for the IPS 4345 and IPS 4360, page 22-22](#)
- [Installing the System Image for the IPS 4510 and IPS 4520, page 22-26](#)
- [Installing the System Image for the ASA 5500 AIP SSM, page 22-28](#)
- [Installing the System Image for the ASA 5500-X IPS SSP, page 22-31](#)
- [Installing the System Image for the ASA 5585-X IPS SSP, page 22-32](#)

ROMMON

Some Cisco sensors include a preboot CLI called ROMMON, which lets you boot images on sensors where the image on the primary device is missing, corrupt, or otherwise unable to boot the normal application. ROMMON is particularly useful for recovering remote sensors as long as the serial console port is available.

Access to ROMMON is available only through the serial console port, a Cisco-standard asynchronous RS-232C DTE available in an RJ-45F connector on the sensor chassis. The serial port is configured for 9600 baud, 8 data bits, 1 stop bit, no parity, and no flow control.

For More Information

For the procedure for using a terminal server, see [Connecting an Appliance to a Terminal Server, page 22-14](#).

TFTP Servers

ROMMON uses TFTP to download an image and launch it. TFTP does not address network issues such as latency or error recovery. It does implement a limited packet integrity check so that packets arriving in sequence with the correct integrity value have an extremely low probability of error. But TFTP does not offer pipelining so the total transfer time is equal to the number of packets to be transferred times the network average RTT. Because of this limitation, we recommend that the TFTP server be located on the same LAN segment as the sensor. Any network with an RTT less than a 100 milliseconds should provide reliable delivery of the image. Be aware that some TFTP servers limit the maximum file size that can be transferred to ~32 MB.

Connecting an Appliance to a Terminal Server

A terminal server is a router with multiple, low speed, asynchronous ports that are connected to other serial devices. You can use terminal servers to remotely manage network equipment, including appliances. To set up a Cisco terminal server with RJ-45 or hydra cable assembly connections, follow these steps:

-
- Step 1** Connect to a terminal server using one of the following methods:
- For terminal servers with RJ-45 connections, connect a rollover cable from the console port on the appliance to a port on the terminal server.
 - For hydra cable assemblies, connect a straight-through patch cable from the console port on the appliance to a port on the terminal server.
- Step 2** Configure the line and port on the terminal server. In enable mode, enter the following configuration, where # is the line number of the port to be configured.

```
config t
line #
login
transport input all
stopbits 1
flowcontrol hardware
speed 9600
exit
exit
wr mem
```

- Step 3** Be sure to properly close a terminal session to avoid unauthorized access to the appliance. If a terminal session is not stopped properly, that is, if it does not receive an exit(0) signal from the application that initiated the session, the terminal session can remain open. When terminal sessions are not stopped properly, authentication is not performed on the next session that is opened on the serial port.

**Caution**

Always exit your session and return to a login prompt before terminating the application used to establish the connection.

**Caution**

If a connection is dropped or terminated by accident, you should reestablish the connection and exit normally to prevent unauthorized access to the appliance.

Installing the System Images for the IPS-4240 and IPS-4255

**Note**

This procedure is for the IPS 4240, but is also applicable to the IPS 4255. The system image for the IPS 4255 has “4255” in the filename.

You can install the IPS 4240 and IPS 4255 system image by using the ROMMON on the appliance to TFTP the system image onto the compact flash device. To install the IPS 4240 and IPS 4255 system image, follow these steps:

- Step 1** Download the IPS 4240 system image file to the tftp root directory of a TFTP server that is accessible from your IPS 4240.

**Note**

Make sure you can access the TFTP server location from the network connected to the Ethernet port of your IPS 4240.

- Step 2** Boot the IPS 4240.

Booting system, please wait...

CISCO SYSTEMS
Embedded BIOS Version 1.0(5)0 09/14/04 12:23:35.90

Low Memory: 631 KB
High Memory: 2048 MB
PCI Device Table.

Bus	Dev	Func	VendID	DevID	Class	Irq
00	00	00	8086	2578	Host Bridge	
00	01	00	8086	2579	PCI-to-PCI Bridge	
00	03	00	8086	257B	PCI-to-PCI Bridge	
00	1C	00	8086	25AE	PCI-to-PCI Bridge	
00	1D	00	8086	25A9	Serial Bus	11
00	1D	01	8086	25AA	Serial Bus	10
00	1D	04	8086	25AB	System	
00	1D	05	8086	25AC	IRQ Controller	
00	1D	07	8086	25AD	Serial Bus	9

```

00 1E 00 8086 244E PCI-to-PCI Bridge
00 1F 00 8086 25A1 ISA Bridge
00 1F 02 8086 25A3 IDE Controller      11
00 1F 03 8086 25A4 Serial Bus         5
00 1F 05 8086 25A6 Audio               5
02 01 00 8086 1075 Ethernet           11
03 01 00 177D 0003 Encrypt/Decrypt    9
03 02 00 8086 1079 Ethernet           9
03 02 01 8086 1079 Ethernet           9
03 03 00 8086 1079 Ethernet           9
03 03 01 8086 1079 Ethernet           9
04 02 00 8086 1209 Ethernet           11
04 03 00 8086 1209 Ethernet           5

```

```

Evaluating BIOS Options ...
Launch BIOS Extension to setup ROMMON

```

```
Cisco Systems ROMMON Version (1.0(5)0) #1: Tue Sep 14 12:20:30 PDT 2004
```

```

Platform IPS-4240-K9
Management0/0

```

```
MAC Address: 0000.c0ff.ee01
```

Step 3 Press **Break** or **Esc** at the following prompt while the system is booting to interrupt boot. Press the spacebar to begin boot immediately.



Note You have ten seconds to press **Break** or **Esc**.

```

Use BREAK or ESC to interrupt boot.
Use SPACE to begin boot immediately.

```

The system enters ROMMON mode. The `rommon>` prompt appears.

Step 4 Check the current network settings.

```
rommon> set
```

```

ROMMON Variable Settings:
  ADDRESS=0.0.0.0
  SERVER=0.0.0.0
  GATEWAY=0.0.0.0
  PORT=Management0/0
  VLAN=untagged
  IMAGE=
  CONFIG=

```

The variables have the following definitions:

- Address—Local IP address of the IPS 4240
- Server—TFTP server IP address where the application image is stored
- Gateway—Gateway IP address used by the IPS 4240
- Port—Ethernet interface used for the IPS 4240 management
- VLAN—VLAN ID number (leave as untagged)
- Image—System image file/path name
- Config—Unused by these platforms

**Note**

Not all values are required to establish network connectivity. The address, server, gateway, and image values are required. If you are not sure of the settings needed for your local environment, contact your system administrator.

Step 5 If necessary, change the interface used for the TFTP download.

**Note**

The default interface used for TFTP downloads is Management 0/0, which corresponds to the MGMT interface of the IPS 4240.

```
rommon> PORT=interface_name
```

Step 6 If necessary, assign an IP address for the local port on the IPS 4240.

```
rommon> ADDRESS=ip_address
```

**Note**

Use the same IP address that is assigned to the IPS 4240.

Step 7 If necessary, assign the TFTP server IP address.

```
rommon> SERVER=ip_address
```

Step 8 If necessary, assign the gateway IP address.

```
rommon> GATEWAY=ip_address
```

Step 9 Verify that you have access to the TFTP server by pinging it from your local Ethernet port with one of the following commands.

```
rommon> ping server_ip_address
rommon> ping server
```

Step 10 If necessary define the path and filename on the TFTP file server from which you are downloading the image.

```
rommon> IMAGE=path/file_name
```

**Caution**

Make sure that you enter the **IMAGE** command in all uppercase. You can enter the other ROMMON commands in either lower case or upper case, but the **IMAGE** command specifically must be all uppercase.

UNIX Example

```
rommon> IMAGE=/system_images/IPS-4240-K9-sys-1.1-a-7.0-4-E4.img
```

**Note**

The path is relative to the default tftpboot directory of the UNIX TFTP server. Images located in the default tftpboot directory do not have any directory names or slashes in the IMAGE specification.

Windows Example

```
rommon> IMAGE=\\system_images\\IPS-4240-K9-sys-1.1-a-7.0-4-E4.img
```

Step 11 Enter **set** and press **Enter** to verify the network settings.



Note You can use the **sync** command to store these settings in NVRAM so they are maintained across boots. Otherwise, you must enter this information each time you want to boot an image from ROMMON.

Step 12 Download and install the system image.

```
rommon> tftp
```



Caution

To avoid corrupting the system image, do not remove power from the IPS 4240 while the system image is being installed.



Note If the network settings are correct, the system downloads and boots the specified image on the IPS 4240. Be sure to use the IPS 4240 image.

For More Information

- For more information about TFTP servers, see [TFTP Servers, page 22-14](#).
- For a list of the specific system image files, see [IPS 7.1 Upgrade Files, page 22-4](#).
- For the procedure for locating software on Cisco.com, see [Obtaining Cisco IPS Software, page 21-1](#).

Installing the System Image for the IPS 4260

You can install the IPS 4260 system image by using the ROMMON on the appliance to TFTP the system image onto the flash device. To install the IPS 4260 system image, follow these steps:

Step 1 Download the IPS 4260 system image file to the tftp root directory of a TFTP server that is accessible from your IPS 4260.

Make sure you can access the TFTP server location from the network connected to your IPS 4260 Ethernet port.

Step 2 Boot the IPS 4260.

Step 3 Press **Ctrl-R** at the following prompt while the system is booting.

```
Evaluating Run Options...
```



Note You have five seconds to press **Ctrl-R**.

```
Assuming IPS-4260-K9 Platform
 2 Ethernet Interfaces detected
```

```
Cisco Systems ROMMON Version (1.0(11)1c) #26: Mon Mar 13 18:05:54 CST 2006
```

```
Platform IPS-4260-K9
Management0/0
```

```
Link is UP
MAC Address: 0004.23cc.6047
```

```
Use ? for help.
rommon #0>
```

Step 4 If necessary, change the port used for the TFTP download.

```
rommon #1> interface name
```

The port in use is listed just after the platform identification. In the example, port Management 0/0 is being used.



Note The default port used for TFTP downloads is Management 0/0, which corresponds with the command and control (MGMT) interface of the IPS 4260.



Note Ports Management 0/0 (MGMT) and GigabitEthernet 0/1 (GE 0/1) are labeled on the back of the chassis.

Step 5 Specify an IP address for the local port on the IPS 4260.

```
rommon> address ip_address
```



Note Use the same IP address that is assigned to the IPS 4260.

Step 6 Specify the TFTP server IP address.

```
rommon> server ip_address
```

Step 7 Specify the gateway IP address.

```
rommon> gateway ip_address
```

Step 8 Verify that you have access to the TFTP server by pinging it from the local Ethernet port.

```
rommon> ping server_ip_address
rommon> ping server
```

Step 9 Specify the path and filename on the TFTP file server from which you are downloading the image.

```
rommon> file path/filename
```

UNIX Example

```
rommon> file /system_images/IPS-4260-K9-sys-1.1-a-7.0-4-E4.img
```



Note The path is relative to the default tftpboot directory of the UNIX TFTP server. Images located in the default tftpboot directory do not have any directory names or slashes in the file location.

Windows Example

```
rommon> file <tftpboot_directory>IPS-4260-K9-sys-1.1-a-7.0-4-E4.img
```

Step 10 Download and install the system image.

```
rommon> tftp
```



Note The IPS 4260 reboots once during the reimaging process. Do not remove power from the IPS 4260 during the update process or the upgrade can become corrupted.

For More Information

- For more information about TFTP servers, see [TFTP Servers, page 22-14](#).
- For a list of the specific system image files, see [IPS 7.1 Upgrade Files, page 22-4](#).
- For the procedure for locating software on Cisco.com, see [Obtaining Cisco IPS Software, page 21-1](#).

Installing the System Image for the IPS 4270-20

You can install the IPS 4270-20 system image by using the ROMMON on the appliance to TFTP the system image onto the compact flash device. To install the IPS 4270-20 system image, follow these steps:

Step 1 Download the IPS 4270-20 system image file to the tftp root directory of a TFTP server that is accessible from your IPS 4270-20.



Note Make sure you can access the TFTP server location from the network connected to the Ethernet port of your IPS 4270-20.

Step 2 Boot the IPS 4270-20.

```
Booting system, please wait...
Cisco Systems ROMMON Version (1.0(12)10) #7: Thu Jun 21 13:50:04 CDT 2007

ft_id_update: Invalid ID-PROM Controller Type (0x5df)

ft_id_update: Defaulting to Controller Type (0x5c2)
```



Note The controller type errors are a known issue and can be disregarded.

Step 3 Press **Break** or **Esc** at the following prompt while the system is booting to interrupt boot. Press the spacebar to begin boot immediately.



Note You have ten seconds to press **Break** or **Esc**.

```
Use BREAK or ESC to interrupt boot.
Use SPACE to begin boot immediately.
```

The system enters ROMMON mode. The `rommon>` prompt appears.

Step 4 Check the current network settings.

```
rommon> set
```

```
ROMMON Variable Settings:
ADDRESS=0.0.0.0
SERVER=0.0.0.0
GATEWAY=0.0.0.0
PORT=Management0/0
VLAN=untagged
IMAGE=
CONFIG=
LINKTIMEOUT=20
PKTTIMEOUT=2
RETRY=20
```

The variables have the following definitions:

- Address—Specifies the local IP address of the IPS 4270-20.
- Server—Specifies the TFTP server IP address where the application image is stored.
- Gateway—Specifies the gateway IP address used by the IPS 4270-20.
- Port—Specifies the Ethernet interface used for IPS 4270-20 management.
- VLAN—Specifies the VLAN ID number (leave as untagged).
- Image—Specifies the system image file/path name.
- Config—Unused by these platforms.

**Note**

Not all values are required to establish network connectivity. The address, server, gateway, and image values are required. If you are not sure of the settings needed for your local environment, contact your system administrator.

Step 5 If necessary, assign an IP address for the local port on the IPS 4270-20.

```
rommon> ADDRESS=ip_address
```

**Note**

Use the same IP address that is assigned to the IPS 4270-20.

Step 6 If necessary, assign the TFTP server IP address.

```
rommon> SERVER=ip_address
```

Step 7 If necessary, assign the gateway IP address.

```
rommon> GATEWAY=ip_address
```

Step 8 Verify that you have access to the TFTP server by pinging it from your local Ethernet port with one of the following commands:

```
rommon> ping server_ip_address
rommon> ping server
```

Step 9 If necessary define the path and filename on the TFTP file server from which you are downloading the image.

```
rommon> IMAGE=path/file_name
```

UNIX Example

```
rommon> IMAGE=/system_images/IPS-4270_20-K9-sys-1.1-a-7.1-3-E4.img
```



Note The path is relative to the UNIX TFTP server default tftpboot directory. Images located in the default tftpboot directory do not have any directory names or slashes in the IMAGE specification.

Windows Example

```
rommon> IMAGE=\system_images\IPS-4270_20-K9-sys-1.1-a-7.1-3-E4.img
```

Step 10 Enter **set** and press **Enter** to verify the network settings.



Note You can use the **sync** command to store these settings in NVRAM so they are maintained across boots. Otherwise, you must enter this information each time you want to boot an image from ROMMON.

Step 11 Download and install the system image.

```
rommon> tftp
```



Caution To avoid corrupting the system image, do not remove power from the IPS 4270-20 while the system image is being installed.



Note If the network settings are correct, the system downloads and boots the specified image on the IPS 4270-20. Be sure to use the IPS 4270-20 image.

For More Information

- For more information about TFTP servers, see [TFTP Servers, page 22-14](#).
- For a list of the specific system image files, see [IPS 7.1 Upgrade Files, page 22-4](#).
- For the procedure for locating software on Cisco.com, see [Obtaining Cisco IPS Software, page 21-1](#).

Installing the System Image for the IPS 4345 and IPS 4360



Note This procedure is for IPS 4345, but is also applicable to IPS 4360. The system image for IPS 4360 has “4360” in the filename.

You can install the IPS 4345 and IPS 4360 system image by using the ROMMON on the appliance to TFTP the system image on to the compact flash device. To install the IPS 4345 and IPS 4360 system image, follow these steps:

- Step 1** Download the IPS 4345 system image file to the tftp root directory of a TFTP server that is accessible from your IPS 4345.



Note Make sure you can access the TFTP server location from the network connected to the Ethernet port of your IPS 4345.

- Step 2** Boot the IPS 4345.

Booting system, please wait...

CISCO SYSTEMS
Embedded BIOS Version 1.0(5)0 09/14/04 12:23:35.90

Low Memory: 631 KB
High Memory: 2048 MB

PCI Device Table.

Bus	Dev	Func	VendID	DevID	Class	Irq
00	00	00	8086	2578	Host Bridge	
00	01	00	8086	2579	PCI-to-PCI Bridge	
00	03	00	8086	257B	PCI-to-PCI Bridge	
00	1C	00	8086	25AE	PCI-to-PCI Bridge	
00	1D	00	8086	25A9	Serial Bus	11
00	1D	01	8086	25AA	Serial Bus	10
00	1D	04	8086	25AB	System	
00	1D	05	8086	25AC	IRQ Controller	
00	1D	07	8086	25AD	Serial Bus	9
00	1E	00	8086	244E	PCI-to-PCI Bridge	
00	1F	00	8086	25A1	ISA Bridge	
00	1F	02	8086	25A3	IDE Controller	11
00	1F	03	8086	25A4	Serial Bus	5
00	1F	05	8086	25A6	Audio	5
02	01	00	8086	1075	Ethernet	11
03	01	00	177D	0003	Encrypt/Decrypt	9
03	02	00	8086	1079	Ethernet	9
03	02	01	8086	1079	Ethernet	9
03	03	00	8086	1079	Ethernet	9
03	03	01	8086	1079	Ethernet	9
04	02	00	8086	1209	Ethernet	11
04	03	00	8086	1209	Ethernet	5

Evaluating BIOS Options ...
Launch BIOS Extension to setup ROMMON

Cisco Systems ROMMON Version (1.0(5)0) #1: Tue Sep 14 12:20:30 PDT 2004

Platform IPS-4345-K9
Management0/0

MAC Address: 0000.c0ff.ee01

- Step 3** Press **Break** or **Esc** at the following prompt while the system is booting to interrupt boot. Press the spacebar to begin boot immediately.



Note You have ten seconds to press **Break** or **Esc**.

Use BREAK or ESC to interrupt boot.
Use SPACE to begin boot immediately.

The system enters ROMMON mode. The `rommon>` prompt appears.

Step 4 Check the current network settings.

```
rommon> set
```

```
ROMMON Variable Settings:
  ADDRESS=0.0.0.0
  SERVER=0.0.0.0
  GATEWAY=0.0.0.0
  PORT=Management0/0
  VLAN=untagged
  IMAGE=
  CONFIG=
```

The variables have the following definitions:

- Address—Local IP address of the IPS 4345.
- Server—TFTP server IP address where the application image is stored.
- Gateway—Gateway IP address used by the IPS 4345.
- Port—Ethernet interface used for the IPS 4345 management.
- VLAN—VLAN ID number (leave as untagged).
- Image—System image file/path name.
- Config—Unused by these platforms.



Note

Not all values are required to establish network connectivity. The address, server, gateway, and image values are required. If you are not sure of the settings needed for your local environment, contact your system administrator.

Step 5 If necessary, change the interface used for the TFTP download.



Note

The default interface used for TFTP downloads is Management 0/0, which corresponds to the MGMT interface of the IPS 4345.

```
rommon> PORT=interface_name
```

Step 6 If necessary, assign an IP address for the local port on the IPS 4345.

```
rommon> ADDRESS=ip_address
```



Note

Use the same IP address that is assigned to the IPS 4345.

Step 7 Assign the TFTP server IP address.

```
rommon> SERVER=ip_address
```

Step 8 If necessary, assign the gateway IP address.

```
rommon> GATEWAY=ip_address
```


- Step 9** Verify that you have access to the TFTP server by pinging it from your local Ethernet port with one of the following commands:

```
rommon> ping server_ip_address
rommon> ping server
```

- Step 10** If necessary define the path and filename on the TFTP file server from which you are downloading the image.

```
rommon> IMAGE=path file_name
```



Caution

Make sure that you enter the **IMAGE** command in all uppercase. You can enter the other ROMMON commands in either lower case or upper case, but the **IMAGE** command specifically must be all uppercase.

UNIX Example

```
rommon> IMAGE=system_images/IPS-4345-K9-sys-1.1-a-7.1-3-E4.img
```



Note

The path is relative to the default tftpboot directory of the UNIX TFTP server. Images located in the default tftpboot directory do not have any directory names or slashes in the IMAGE specification.

Windows Example

```
rommon> IMAGE=system_images/IPS-4345-K9-sys-1.1-a-7.1-3-E4.img
```

- Step 11** Enter **set** and press **Enter** to verify the network settings.



Note

You can use the **sync** command to store these settings in NVRAM so they are maintained across boots. Otherwise, you must enter this information each time you want to boot an image from ROMMON.

- Step 12** Download and install the system image.

```
rommon> tftp
```



Caution

To avoid corrupting the system image, do not remove power from the IPS 4345 while the system image is being installed.



Note

If the network settings are correct, the system downloads and boots the specified image on the IPS 4345. Be sure to use the IPS 4345 image.

For More Information

- For more information about TFTP servers, see [TFTP Servers](#), page 22-14.
- For a list of the specific system image files, see [IPS 7.1 Upgrade Files](#), page 22-4.
- For the procedure for locating software on Cisco.com, see [Obtaining Cisco IPS Software](#), page 21-1.

Installing the System Image for the IPS 4510 and IPS 4520

**Note**

The following procedure references the IPS 4510 but it also refers to the IPS 4520.

You can install the IPS 4510 and IPS 4520 system image by using the ROMMON on the appliance to TFTP the system image onto the compact flash device. To install the IPS 4510 system image, follow these steps:

- Step 1** Download the IPS 4510 system image file to the tftp root directory of a TFTP server that is accessible from your IPS 4510.

**Note**

Make sure you can access the TFTP server location from the network connected to the Management port of your IPS 4510.

- Step 2** Boot the IPS 4510.

- Step 3** Press **Break** or **Esc** at the following prompt while the system is booting to interrupt boot. Press the spacebar to begin boot immediately.

**Note**

You have ten seconds to press **Break** or **Esc**.

Use BREAK or ESC to interrupt boot.
Use SPACE to begin boot immediately.

The system enters ROMMON mode. The `rommon>` prompt appears.

- Step 4** Check the current network settings.

```
rommon> set
```

```
ROMMON Variable Settings:
ADDRESS=0.0.0.0
SERVER=0.0.0.0
GATEWAY=0.0.0.0
PORT=Management0/0
VLAN=untagged
IMAGE=
CONFIG=
LINKTIMEOUT=20
PKTTIMEOUT=2
RETRY=20
```

The variables have the following definitions:

- Address—Specifies the local IP address of the IPS 4510.
- Server—Specifies the TFTP server IP address where the application image is stored.
- Gateway—Specifies the gateway IP address used by the IPS 4510.
- Port—Specifies the Ethernet interface used for IPS 4510 management.
- VLAN—Specifies the VLAN ID number (leave as untagged).
- Image—Specifies the system image file/path name.
- Config—Unused by these platforms.

**Note**

Not all values are required to establish network connectivity. The address, server, gateway, and image values are required. If you are not sure of the settings needed for your local environment, contact your system administrator.

- Step 5** If necessary, assign an IP address for the Management port on the IPS 4510.

```
rommon> ADDRESS=ip_address
```

**Note**

Use the same IP address that is assigned to the IPS 4510.

- Step 6** If necessary, assign the TFTP server IP address.

```
rommon> SERVER=ip_address
```

- Step 7** If necessary, assign the gateway IP address.

```
rommon> GATEWAY=ip_address
```

- Step 8** Verify that you have access to the TFTP server by pinging it from your local Ethernet port with one of the following commands:

```
rommon> ping server_ip_address
rommon> ping server
```

- Step 9** If necessary define the path and filename on the TFTP file server from which you are downloading the image.

```
rommon> IMAGE=path/file_name
```

UNIX Example

```
rommon> IMAGE=/system_images/IPS-4510-K9-sys-1.1-a-7.1-4-E4.img
```

**Note**

The path is relative to the UNIX TFTP server default tftpboot directory. Images located in the default tftpboot directory do not have any directory names or slashes in the IMAGE specification.

Windows Example

```
rommon> IMAGE=\system_images\IPS-4510-K9-sys-1.1-a-7.1-4-E4.img
```

- Step 10** Enter **set** and press **Enter** to verify the network settings.

**Note**

You can use the **sync** command to store these settings in NVRAM so they are maintained across boots. Otherwise, you must enter this information each time you want to boot an image from ROMMON.

- Step 11** Download and install the system image.

```
rommon> tftp
```

**Caution**

To avoid corrupting the system image, do not remove power from the IPS 4510 while the system image is being installed.

**Note**

If the network settings are correct, the system downloads and boots the specified image on the IPS 4510. Be sure to use the IPS 4510 image.

For More Information

- For more information about TFTP servers, see [TFTP Servers, page 22-14](#).
- For a list of the specific system image files, see [IPS 7.1 Upgrade Files, page 22-4](#).
- For the procedure for locating software on Cisco.com, see [Obtaining Cisco IPS Software, page 21-1](#).

Installing the System Image for the ASA 5500 AIP SSM

This section describes how to install the ASA 5500 AIP SSM system image, and contains the following topics:

- [Reimaging the ASA 5500 AIP SSM, page 22-28](#)
- [Reimaging the ASA 5500 AIP SSM Using the recover configure/boot Command, page 22-28](#)

Reimaging the ASA 5500 AIP SSM

You can reimage the ASA 5500 AIP SSM in one of the following ways:

- From the adaptive security appliance using the **hw-module module 1 recover configure/boot** command.
- Recovering the application image from the sensor CLI using the **recover application-partition** command.
- Upgrading the recovery image from the sensor CLI using the **upgrade** command.

For More Information

- For the procedure for using the **hw-module module 1 recover configure/boot** command, see [Reimaging the ASA 5500 AIP SSM Using the recover configure/boot Command, page 22-28](#).
- For the procedure for recovering the application partition, see [Recovering the Application Partition, page 22-12](#).
- For the procedure for upgrading the recovery image, see [Upgrading the Recovery Partition, page 22-7](#).

Reimaging the ASA 5500 AIP SSM Using the recover configure/boot Command

**Note**

Be sure the TFTP server that you specify can transfer files up to 60 MB in size.

**Note**

This process can take approximately 15 minutes to complete, depending on your network and the size of the image.

If the ASA 5500 AIP SSM suffers a failure and the module application image cannot run, you can transfer application images from a TFTP server to the module using the adaptive security appliance CLI. The adaptive security appliance can communicate with the module ROMMON application to transfer the image.

To install the system image of the ASA 5500 AIP SSM, follow these steps:

- Step 1** Download the system image file to the tftp root directory of a TFTP server that is accessible from your adaptive security appliance.



Note Make sure you can access the TFTP server location from the network connected to the Ethernet port of the adaptive security appliance.

- Step 2** Log in to the adaptive security appliance.

- Step 3** Enter enable mode.

```
asa# enable
```

- Step 4** Configure the recovery settings for the ASA 5500 AIP SSM.

```
asa (enable)# hw-module module 1 recover configure
```



Note If you make an error in the recovery configuration, use the **hw-module module 1 recover stop** command to stop the system reimaging and then you can correct the configuration.

- Step 5** Specify the TFTP URL for the system image.

```
Image URL [tftp://0.0.0.0/]:
```

Example

```
Image URL [tftp://0.0.0.0/]: tftp://192.0.2.0/IPS-SSP-K9-sys-1.1-a-7.1-2-E4.img
```

- Step 6** Specify the command and control interface of the ASA 5500 AIP SSM.



Note The port IP address is the management IP address of the ASA 5500 AIP SSM.

```
Port IP Address [0.0.0.0]:
```

Example

```
Port IP Address [0.0.0.0]: 10.89.149.231
```

- Step 7** Leave the VLAN ID at 0.

```
VLAN ID [0]:
```

- Step 8** Specify the default gateway of the ASA 5500 AIP SSM.

```
Gateway IP Address [0.0.0.0]:
```

Example

```
Gateway IP Address [0.0.0.0]: 10.89.149.254
```

Step 9 Execute the recovery.

```
asa# hw-module module 1 recover boot
```

This transfers the image from the TFTP server to the ASA 5500 AIP SSM.

Step 10 Periodically check the recovery until it is complete.



Note The status reads `Recovery` during recovery and reads `Up` when reimaging is complete.

```
asa# show module 1
```

Mod	Card Type	Model	Serial No.
0	ASA 5540 Adaptive Security Appliance	ASA5540	P2B00000019
1	ASA 5500 Series Security Services Module-20	ASA-SSM-20	P1D000004F4

Mod	MAC Address Range	Hw Version	Fw Version	Sw Version
0	000b.fcf8.7b1c to 000b.fcf8.7b20	0.2	1.0(7)2	7.1(1)82
1	000b.fcf8.011e to 000b.fcf8.011e	0.1	1.0(7)2	5.0(0.22)S129.0

```
Mod Status
```

```
---
0 Up Sys
1 Up
```

```
asa#
```



Note The Status field in the output indicates the operational status of the ASA 5500 AIP SSM. An ASA 5500 AIP SSM operating normally shows a status of “Up.” While the adaptive security appliance transfers an application image to the ASA 5500 AIP SSM, the Status field in the output reads “Recover.” When the adaptive security appliance completes the image transfer and restarts the ASA 5500 AIP SSM, the newly transferred image is running.



Note To debug any errors that may happen in the recovery process, use the **debug module-boot** command to enable debugging of the system reimaging process.

Step 11 Session to the ASA 5500 AIP SSM and initialize it with the **setup** command.

For More Information

- For more information about TFTP servers, see [TFTP Servers, page 22-14](#).
- For a list of the specific system image files, see [IPS 7.1 Upgrade Files, page 22-4](#).
- For the procedure for initializing the ASA 5500 AIP SSM, see [Advanced Setup for the ASA 5500 AIP SSM, page 3-14](#).

Installing the System Image for the ASA 5500-X IPS SSP

**Note**

Be sure the TFTP server that you specify can transfer files up to 60 MB in size.

**Note**

The CLI output is an example of what your configuration may look like. It will not match exactly due to the optional setup choices, sensor model, and IPS 7.1 version you have installed.

To install the system image on the ASA 5500-X IPS SSP, follow these steps:

- Step 1** Download the IPS system image file corresponding to your ASA platform to the tftp root directory of a TFTP server that is accessible from your adaptive security appliance.

**Note**

Make sure you can access the TFTP server location from the network connected to the Ethernet port of the adaptive security appliance.

- Step 2** Log in to the adaptive security appliance.

- Step 3** Enter enable mode.

```
asa> enable
```

- Step 4** Copy the IPS image to the disk0 flash of the adaptive security appliance.

```
asa# copy tftp://192.0.2.0/directory/IPS-5545-K9-sys-1.1-a-7.1-3-E4.aip disk0:
```

- Step 5** Image the ASA 5500-X IPS SSP.

```
asa# sw-module module ips recover configure image
disk0:/IPS-SSP_5545-K9-sys-1.1-a-7.1-3-E4.aip
```

- Step 6** Execute the recovery. This transfers the image from the TFTP server to the ASA 5500-X IPS SSP and restarts it.

```
asa# sw-module module ips recover boot
```

- Step 7** Periodically check the recovery until it is complete.

```
asa# show module
```

Mod	Card	Type	Model	Serial No.
0		Cisco ASA 5545 Appliance with 8 GE ports, 1	ASA5545	ABC1234D56E
1		IPS 5545 Intrusion Protection System	IPS5545	ABC1234D56E

Mod	MAC Address Range	Hw Version	Fw Version	Sw Version
0	503d.e59c.6dc1 to 503d.e59c.6dca	1.0		8.6.1
ips	503d.e59c.6dcb to 503d.e59c.6dcb	N/A	N/A	7.1(3)E4

Mod	SSM Application Name	Status	SSM Application Version
1	IPS	Up	7.1(3)E4

Mod	Status	Data Plane Status	Compatibility
0	Up Sys	Not Applicable	

```

1 Up
asa#

```



Note The Status field in the output indicates the operational status of the ASA 5500-X IPS SSP. An ASA 5500-X IPS SSP operating normally shows a status of “Up.” While the adaptive security appliance transfers an application image to the ASA 5500-X IPS SSP, the Status field in the output reads “Recover.” When the adaptive security appliance completes the image transfer and restarts the ASA 5500-X IPS SSP, the newly transferred image is running.



Note To debug any errors that may happen in the recovery process, use the **debug module-boot** command to enable debugging of the system reimaging process.

Step 8 Session to the ASA 5500-X IPS SSP and initialize it with the **setup** command.

For More Information

- For more information about TFTP servers, see [TFTP Servers, page 22-14](#).
- For a list of the specific system image files, see [IPS 7.1 Upgrade Files, page 22-4](#).
- For the procedure for initializing the ASA 5500-X IPS SSP, see [Advanced Setup for the ASA 5500-X IPS SSP, page 3-18](#).

Installing the System Image for the ASA 5585-X IPS SSP

This section describes how to install the ASA 5585-X IPS SSP system image using the **hw-module** command or ROMMON, and contains the following topics:

- [Installing the ASA 5585-X IPS SSP System Image Using the hw-module Command, page 22-32](#)
- [Installing the ASA 5585-X IPS SSP System Image Using ROMMON, page 22-35](#)

Installing the ASA 5585-X IPS SSP System Image Using the hw-module Command



Note Be sure the TFTP server that you specify can transfer files up to 60 MB in size.



Note This process can take approximately 15 minutes to complete, depending on your network and the size of the image.



Note The CLI output is an example of what your configuration may look like. It will not match exactly due to the optional setup choices, sensor model, and IPS 7.1 version you have installed.

To install the system image, transfer the software image from a TFTP server to the ASA 5585-X IPS SSP using the adaptive security appliance CLI. The adaptive security appliance can communicate with the ROMMON application of the ASA 5585-X IPS SSP to transfer the image. To install the ASA 5585-X IPS SSP software image, follow these steps:

- Step 1** Download the ASA 5585-X IPS SSP system image file to the tftp root directory of a TFTP server that is accessible from your adaptive security appliance.



Note Make sure you can access the TFTP server location from the network connected to the Ethernet port of your adaptive security appliance.

- Step 2** Log in to the adaptive security appliance.

- Step 3** Enter enable mode.

```
asa# enable
```

- Step 4** Configure the recovery settings for the ASA 5585-X IPS SSP.

```
asa (enable)# hw-module module 1 recover configure
```



Note If you make an error in the recovery configuration, use the **hw-module module 1 recover stop** command to stop the system reimaging and then you can correct the configuration.

- Step 5** Specify the TFTP URL for the software image.

```
Image URL [tftp://0.0.0.0/]:
```

Example

```
Image URL [tftp://0.0.0.0/]: tftp://192.0.2.0/IPS-SSP_40-K9-sys-1.1-a-7.1-3-E4.img
```

- Step 6** Specify the command and control interface of the ASA 5585-X IPS SSP.



Note The port IP address is the management IP address of the ASA 5585-X IPS SSP.

```
Port IP Address [0.0.0.0]:
```

Example

```
Port IP Address [0.0.0.0]: 10.89.149.231
```

- Step 7** Leave the VLAN ID at 0.

```
VLAN ID [0]:
```

- Step 8** Specify the default gateway of the ASA 5585-X IPS SSP.

```
Gateway IP Address [0.0.0.0]:
```

Example

```
Gateway IP Address [0.0.0.0]: 10.89.149.254
```

- Step 9** Execute the recovery. This transfers the software image from the TFTP server to the ASA 5585-X IPS SSP and restarts it.

```
asa# hw-module module 1 recover boot
```

Step 10 Periodically check the recovery until it is complete.



Note The status reads `Recovery` during recovery and reads `Up` when installation is complete.

```
asa# show module 1 details
Getting details from the Service Module, please wait...
ASA 5585-X IPS Security Services Processor-10 with 8GE
Model:                ASA5585-SSP-IPS40
Hardware version:     1.0
Serial Number:        JAF1350ABSL
Firmware version:     2.0(1)3
Software version:     7.1(3)E4
MAC Address Range:    8843.e12f.5414 to 8843.e12f.541f
App. name:            IPS
App. Status:          Up
App. Status Desc:     Normal Operation
App. version:         7.1(3)E4
Data plane Status:    Up
Status:               Up
Mgmt IP addr:         192.0.2.0
Mgmt Network mask:    255.255.255.0
Mgmt Gateway:         10.89.148.254
Mgmt Access List:     10.0.0.0/8
Mgmt Access List:     64.0.0.0/8
Mgmt web ports:       443
Mgmt TLS enabled      true
asa#
```



Note The Status field in the output indicates the operational status of the ASA 5585-X IPS SSP. An ASA 5585-X IPS SSP operating normally shows a status of “Up.” While the adaptive security appliance transfers the software image to the ASA 5585-X IPS SSP, the Status field in the output reads “Recover.” When the adaptive security appliance completes the software image transfer and restarts the ASA 5585-X IPS SSP, the newly transferred image is running.



Note To debug any errors that may happen during this process, use the **debug module-boot** command to enable debugging of the software installation process.

Step 11 Session to the ASA 5585-X IPS SSP.

Step 12 Enter **cisco** three times and your new password twice.

Step 13 Initialize the ASA 5585-X IPS SSP with the **setup** command.

For More Information

- For more information about TFTP servers, see [TFTP Servers, page 22-14](#).
- For a list of the specific system image files, see [IPS 7.1 Upgrade Files, page 22-4](#).
- For the procedure for initializing the ASA 5585-X IPS SSP, see [Advanced Setup for the ASA 5585-X IPS SSP, page 3-21](#).

Installing the ASA 5585-X IPS SSP System Image Using ROMMON

You can install the ASA 5585-X IPS SSP system image by using the ROMMON on the adaptive security appliance to TFTP the system image onto the ASA 5585-X IPS SSP.

To install the ASA 5585-X IPS SSP system image, follow these steps:

- Step 1** Download the ASA 5585-X IPS SSP system image file to the tftp root directory of a TFTP server that is accessible from your adaptive security appliance.



Note Make sure you can access the TFTP server location from the network connected to the Ethernet port of your adaptive security appliance.

- Step 2** Boot the ASA 5585-X IPS SSP.

Booting system, please wait...

```
CISCO SYSTEMS
Embedded BIOS Version 0.0(2)10 11:16:38 04/15/10
Com KbdBuf SMM UsbHid Msg0 Prompt Pmrt Cache1 LowM ExtM HugeM Cache2 Flg Siz0 Amrt PMM
PnpDsp Smbios Lpt0 Npx1 Apm Lp1 Acpi Typ Dbg Enb Mp MemReduce MemSync1 CallRoms MemSync2
DriveInit
```

```
Total memory : 12 GB
Total number of CPU cores : 8
Com Lp1 Admgr2 Brd10 Plx2 OEM0=7EFF5C74
Cisco Systems ROMMON Version (1.0(12)10) #0: Thu Apr 8 00:12:33 CDT 2010
```

```
Use BREAK or ESC to interrupt boot.
Use SPACE to begin boot immediately.
Boot interrupted.
```

```
Management0/0
Link is UP
MAC Address: 5475.d029.7fa9
```

- Step 3** Press **Break** or **Esc** at the following prompt while the system is booting to interrupt boot. Press the spacebar to begin boot immediately.



Note You have ten seconds to press **Break** or **Esc**.

```
Use BREAK or ESC to interrupt boot.
Use SPACE to begin boot immediately.
```

The system enters ROMMON mode. The `rommon>` prompt appears.

- Step 4** Check the current network settings.

```
rommon #0> set
ROMMON Variable Settings:
ADDRESS=0.0.0.0
SERVER=0.0.0.0
GATEWAY=0.0.0.0
PORT=Management0/0
VLAN=untagged
IMAGE=
CONFIG=
```

```

LINKTIMEOUT=20
PKTTIMEOUT=4
RETRY=20

```

The variables have the following definitions:

- Address—Specifies the local IP address of the ASA 5585-X IPS SSP.
- Server—Specifies the TFTP server IP address where the application image is stored.
- Gateway—Specifies the gateway IP address used by the ASA 5585-X IPS SSP.
- Port—Specifies the ethernet interface used for the ASA 5585-X IPS SSP management.
- VLAN—Specifies the VLAN ID number (leave as untagged).
- Image—Specifies the system image file/path name.
- Config—Specifies the unused by these platforms.



Note

Not all values are required to establish network connectivity. The address, server, gateway, and image values are required. If you are not sure of the settings needed for your local environment, contact your system administrator.

Step 5 If necessary, change the interface used for the TFTP download.



Note

The default interface used for TFTP downloads is Management 0/0, which corresponds to the management interface of the ASA 5585-X IPS SSP.

```
rommon> PORT=interface_name
```

Step 6 If necessary, assign an IP address for the local port on the ASA 5585-X IPS SSP.

```
rommon> ADDRESS=ip_address
```



Note

Use the same IP address that is assigned to the ASA 5585-X IPS SSP.

Step 7 If necessary, assign the TFTP server IP address.

```
rommon> SERVER=ip_address
```

Step 8 If necessary, assign the gateway IP address.

```
rommon> GATEWAY=ip_address
```

Step 9 Verify that you have access to the TFTP server by pinging it from your local Ethernet port with one of the following commands.

```
rommon> ping server_ip_address
rommon> ping server
```

Step 10 If necessary define the path and filename on the TFTP file server from which you are downloading the image.

```
rommon> IMAGE=path/file_name
```

**Caution**

Make sure that you enter the **IMAGE** command in all uppercase. You can enter the other ROMMON commands in either lower case or upper case, but the **IMAGE** command specifically must be all uppercase.

UNIX Example

```
rommon> IMAGE=/system_images/IPS-SSP_10-K9-sys-1.1-a-7.1-3-E4.img
```

**Note**

The path is relative to the default tftpboot directory of the UNIX TFTP server. Images located in the default tftpboot directory do not have any directory names or slashes in the IMAGE specification.

Windows Example

```
rommon> IMAGE=\system_images\IPS-SSP_10-K9-sys-1.1-a-7.1-3-E4.img
```

Step 11 Enter **set** and press **Enter** to verify the network settings.

**Note**

You can use the **sync** command to store these settings in NVRAM so they are maintained across boots. Otherwise, you must enter this information each time you want to boot an image from ROMMON.

Step 12 Download and install the system image.

```
rommon> tftp
```

**Note**

If the network settings are correct, the system downloads and boots the specified image on the ASA 5585-X IPS SSP. Be sure to use the ASA 5585-X IPS SSP image.

**Caution**

To avoid corrupting the system image, do not remove power from the ASA 5585-X IPS SSP while the system image is being installed.

For More Information

- For more information about TFTP servers, see [TFTP Servers, page 22-14](#).
- For a list of the specific system image files, see [IPS 7.1 Upgrade Files, page 22-4](#).
- For the procedure for initializing ASA 5585-X IPS SSP, see [Advanced Setup for the ASA 5585-X IPS SSP, page 3-21](#).



System Architecture

This appendix describes the IPS system architecture, and contains the following sections:

- [IPS System Design, page A-1](#)
- [System Applications, page A-3](#)
- [User Interaction, page A-5](#)
- [Security Features, page A-5](#)
- [MainApp, page A-6](#)
- [SensorApp, page A-23](#)
- [CollaborationApp, page A-28](#)
- [SwitchApp, page A-30](#)
- [CLI, page A-30](#)
- [Communications, page A-32](#)
- [Cisco IPS File Structure, page A-35](#)
- [Summary of Cisco IPS Applications, page A-36](#)

Understanding the IPS System Architecture

The purpose of the Cisco IPS is to detect and prevent malicious network activity. You can install the Cisco IPS software on two platforms: appliances and the modules. The Cisco IPS contains a management application and a monitoring application. The IDM is a network management JAVA application that you can use to manage and monitor the IPS. The IME is an IPS network monitoring JAVA application that you can use to view IPS events. The IME also contains the IDM configuration component. The IDM and the IME communicate with the IPS using HTTP or HTTPS and are hosted on your computer.

IPS System Design

The Cisco IPS software runs on the Linux operating system. We have hardened the Linux OS by removing unnecessary packages from the OS, disabling unused services, restricting network access, and removing access to the shell.

Figure A-1 illustrates the system design for IPS software.

Figure A-1 System Design





Figure A-1 illustrates the system design for IPS software for the IPS 4500 series sensors.

Figure A-2 System Design for IPS 4500 Series Sensors



For More Information

- For detailed information about the MainApp, see [MainApp, page A-6](#).
- For detailed information about the SensorApp, see [SensorApp, page A-23](#).
- For detailed information about the CollaborationApp, see [CollaborationApp, page A-28](#).
- For detailed information about the CLI, see [CLI, page A-30](#).
- For detailed information about the SwitchApp, see [SwitchApp, page A-30](#).

System Applications



Note

Each application has its own configuration file in XML format.

The Cisco IPS software includes the following applications:

- **MainApp**—Initializes the system, starts and stops the other applications, configures the OS, and performs upgrades. It contains the following components:
 - **ctlTransSource** (Control Transaction server)—Allows sensors to send control transactions. This is used to enable the master blocking sensor capability of Attack Response Controller (formerly known as Network Access Controller).
 - **Event Store**—An indexed store used to store IPS events (error, status, and alert system messages) that is accessible through the CLI, IDM, IME, ASDM, or SDEE.



Note The Event Store has a fixed size of 30 MB for all platforms.

- **InterfaceApp**—Handles bypass and physical settings and defines paired interfaces. Physical settings are speed, duplex, and administrative state.
 - **Logger**—Writes all the log messages of the application to the log file and the error messages of the application to the Event Store.
 - **Attack Response Controller** (formerly known as Network Access Controller) —Manages remote network devices (firewalls, routers, and switches) to provide blocking capabilities when an alert event has occurred. The ARC creates and applies ACLs on the controlled network device or uses the **shun** command (firewalls).
 - **NotificationApp**—Sends SNMP traps when triggered by alert, status, and error events. The NotificationApp uses the public domain SNMP agent. SNMP GETs provide information about the general health of the sensor.
 - **Web server** (HTTP SDEE server)—Provides a web interface and communication with the other IPS devices through the SDEE protocol using several servlets to provide the IPS services.
 - **AuthenticationApp**—Verifies that users are authorized to perform CLI, IDM, IME, ASDM, or SDEE actions.
- **SensorApp** (Analysis Engine)—Performs packet capture and analysis.
 - **CollaborationApp**—Interfaces with the MainApp and the SensorApp using various interprocess communication technologies including IDAPI control transactions, semaphores, shared memory, and file exchange.
 - **CLI**—The interface that is run when you successfully log in to the sensor through Telnet or SSH. All accounts created through the CLI will use the CLI as their shell (except the service account—only one service account is allowed). Allowed CLI commands depend on the privilege of the user.

All Cisco IPS applications communicate with each other through a common API called the IDAPI. Remote applications (other sensors, management applications, and third-party software) communicate with sensors through the SDEE protocol.

The sensor has the following partitions:

- **Application partition**—A full IPS system image.
- **Recovery partition**—A special purpose image used for recovery of the sensor. Booting into the recovery partition enables you to completely reimage the application partition. Network settings are preserved, but all other configuration is lost.

User Interaction

You interact with the Cisco IPS in the following ways:

- Configure device parameters

You generate the initial configuration for the system and its features. This is an infrequent task, usually done only once. The system has reasonable default values to minimize the number of modifications you must make. You can configure Cisco IPS through the CLI, IDM, IME, CSM, ASDM, or through another application using SDEE.

- Tune

You make minor modifications to the configuration, primarily to Analysis Engine, which is the portion of the application that monitors network traffic. You can tune the system frequently after initially installing it on the network until it is operating efficiently and only producing information you find useful. You can create custom signatures, enable features, or apply a service pack or signature update. You can tune Cisco IPS through the CLI, IDM, IME, CSM, ASDM, or through another application using SDEE.

- Update

You can schedule automatic updates or apply updates immediately to the applications and signature data files. You can update Cisco IPS through the CLI, IDM, IME, CSM, ASDM, or through another application using SDEE.

- Retrieve information

You can retrieve data (status messages, errors, and alerts) from the system through the CLI, IDM, IME, CSM, ASDM, CS MARS or another application using SDEE.

For More Information

For detailed information about SDEE, see [SDEE, page A-34](#).

Security Features

Cisco IPS has the following security features:

- Network access is restricted to hosts who are specifically allowed access.
- All remote hosts who attempt to connect through the web server, SSH and SCP or Telnet will be authenticated.
- By default Telnet access is disabled. You can choose to enable Telnet.
- By default SSH access is enabled.
- An FTP server does not run on the sensor. You can use SCP to remotely copy files.
- By default the web server uses TLS or SSL. You can choose to disable TLS and SSL.
- Unnecessary services are disabled.
- Only the SNMP set required by the Cisco MIB Police is allowed within the CISCO-CIDS-MIB. OIDs implemented by the public domain SNMP agent will be writeable when specified by the MIB.

For More Information

For detailed information about SNMP and Cisco MIBs, see [Chapter 15, “Configuring SNMP.”](#)

MainApp

This section describes the MainApp, and contains the following topics:

- [Understanding the MainApp, page A-6](#)
- [MainApp Responsibilities, page A-6](#)
- [Event Store, page A-7](#)
- [NotificationApp, page A-9](#)
- [CtlTransSource, page A-11](#)
- [Attack Response Controller, page A-12](#)
- [Logger, page A-19](#)
- [InterfaceApp, page A-20](#)
- [AuthenticationApp, page A-20](#)
- [Web Server, page A-23](#)

Understanding the MainApp

The MainApp includes all IPS components except SensorApp and the CLI. It is loaded by the operating system at startup and loads SensorApp. The MainApp then brings the following subsystem components up:

- Authentication
- Logger
- ARC
- Web Server
- Notification (SNMP)
- External Product Interface
- Interface manager
- Event Store
- Health and security monitoring

MainApp Responsibilities

The MainApp has the following responsibilities:

- Validate the Cisco-supported hardware platform
- Report software version and PEP information
- Start, stop, and report the version of the IPS components
- Configure the host system settings
- Manage the system clock
- Manage the Event Store
- Install and uninstall software upgrades

**Note**

In the Cisco IPS, the MainApp can automatically download signature and signature engine updates from Cisco.com.

- Shut down or reboot the operating system

The MainApp responds to the **show version** command by displaying the following information:

- Sensor build version
- MainApp version
- Version of each running application
- Version and timestamp of each installed upgrade
- Next downgrade version of each installed upgrade
- Platform version
- Version of sensor build on the other partition

The MainApp also gathers the host statistics and reports the health and security monitoring status.

Event Store

This section describes the Event Store, and contains the following topics:

- [Understanding the Event Store, page A-7](#)
- [Event Data Structures, page A-8](#)
- [IPS Events, page A-9](#)

Understanding the Event Store

**Note**

The Event Store has a fixed size of 30 MB for all platforms.

Each IPS event is stored in the Event Store with a time stamp and a unique, monotonic, ascending ID. This time stamp is the primary key used to index the event into the fixed-size, indexed Event Store. When the circular Event Store has reached its configured size, the oldest event or events are overwritten by the new event being stored. The SensorApp is the only application that writes alert events into the Event Store. All applications write log, status, and error events into the Event Store.

The fixed-sized, indexed Event Store allows simple event queries based on the time, type, priority, and a limited number of user-defined attributes. If each event is assigned a priority of low, medium, or high, a single event query can specify a list of desired event types, intrusion event priorities, and a time range.

Table A-1 shows some examples:

Table A-1 *IPS Event Examples*

IPS Event Type	Intrusion Event Priority	Start Time Stamp Value	Stop Time Stamp Value	Meaning
status	—	0	Maximum value	Get all status events that are stored.
error status	—	0	65743	Get all error and status events that were stored before time 65743.
status	—	65743	Maximum value	Get status events that were stored at or after time 65743.
intrusion attack response	low	0	Maximum value	Get all intrusion and attack response events with low priority that are stored.
attack response error status intrusion	medium high	4123000000	4123987256	Get attack response, error, status, and intrusion events with medium or high priority that were stored between time 4123000000 and 4123987256.

The size of the Event Store allows sufficient buffering of the IPS events when the sensor is not connected to an IPS event consumer. Sufficient buffering depends on your requirements and the capabilities of the nodes in use. The oldest events in the circular buffer are replaced by the newest events.

Event Data Structures

The various functional units communicate the following seven types of data:

- Intrusion events—Produced by the SensorApp. The sensor detects intrusion events.
- Error events—Caused by hardware or software malfunctions.
- Status events—Reports of a change in the status of the application, for example, that its configuration has been updated.
- Control transaction log events—The sensor logs the result of a control transaction.
- Attack response events—Actions for the ARC, for example, a block request.
- Debug events—Highly detailed reports of a change in the status of the application used for debugging.
- Control transaction data—Data associated with control transactions, for example, diagnostic data from an application, session logs, and configuration data to or from an application.

All seven types of data are referred to collectively as *IPS data*. The six event types—intrusion, error, status, control transaction log, network access, and debug—have similar characteristics and are referred to collectively as *IPS events*. IPS events are produced by the several different applications that make up the IPS and are subscribed to by other IPS applications. IPS events have the following characteristics:

- They are spontaneously generated by the application instances configured to do so. There is no request from another application instance to generate a particular event.
- They have no specific destination. They are stored and then retrieved by one or more application instances.

Control transactions involve the following types of requests:

- Request to update the configuration data of an application instance
- Request for the diagnostic data of an application instance
- Request to reset the diagnostic data of an application instance
- Request to restart an application instance
- Request for ARC, such as a block request

Control transactions have the following characteristics:

- They always consist of a request followed by a response.

The request and response may have an arbitrary amount of data associated with them. The response always includes at least a positive or negative acknowledgment.

- They are point-to-point transactions.

Control transactions are sent by one application instance (the initiator) to another application instance (the responder).

IPS data is represented in XML format as an XML document. The system stores user-configurable parameters in several XML files.

IPS Events

IPS applications generate IPS events to report the occurrence of some stimulus. The events are the data, such as the alerts generated by SensorApp or errors generated by any application. Events are stored in a local database known as the Event Store.

There are five types of events:

- evAlert—Alert event messages that report when a signature is triggered by network activity.
- evStatus—Status event messages that report the status and actions of the IPS applications.
- evError—Error event messages that report errors that occurred while attempting response actions.
- evLogTransaction—Log transaction messages that report the control transactions processed by each sensor application.
- evShunRqst—Block request messages that report when ARC issues a block request.

You can view the status and error messages using the CLI, IME, and ASDM. The SensorApp and ARC log response actions (TCP resets, IP logging start and stop, blocking start and stop, trigger packet) as status messages.

NotificationApp

The NotificationApp allows the sensor to send alerts and system error messages as SNMP traps. It subscribes to events in the Event Store and translates them into SNMP MIBs and sends them to destinations through a public-domain SNMP agent. The NotificationApp supports sending sets and gets. The SNMP GETs provide information about basic sensor health.

The NotificationApp sends the following information from the evAlert event in sparse mode:

- Originator information
- Event ID
- Event severity

- Time (UTC and local time)
- Signature name
- Signature ID
- Subsignature ID
- Participant information
- Alarm traits

The NotificationApp sends the following information from the evAlert event in detail mode:

- Originator information
- Event ID
- Event severity
- Time (UTC and local time)
- Signature name
- Signature ID
- Subsignature ID
- Version
- Summary
- Interface group
- VLAN
- Participant information
- Actions
- Alarm traits
- Signature
- IP log IDs

The NotificationApp determines which evError events to send as a trap according to the filter that you define. You can filter based on error severity (error, fatal, and warning). The NotificationApp sends the following information from the evError event:

- Originator information
- Event ID
- Event severity
- Time (UTC and local time)
- Error message

The NotificationApp supports GETs for the following general health and system information from the sensor:

- Packet loss
- Packet denies
- Alarms generated
- Fragments in FRP
- Datagrams in FRP

- TCP streams in embryonic state
- TCP streams in established state
- TCP streams in closing state
- TCP streams in system
- TCP packets queued for reassembly
- Total nodes active
- TCP nodes keyed on both IP addresses and both ports
- UDP nodes keyed on both IP addresses and both ports
- IP nodes keyed on both IP addresses
- Sensor memory critical stage
- Interface status
- Command and control packet statistics
- Fail-over state
- System uptime
- CPU usage
- Memory usage for the system
- PEP



Note Not all IPS platforms support PEP.

The NotificationApp provides the following statistics:

- Number of error traps
- Number of event action traps
- Number of SNMP GET requests
- Number of SNMP SET requests

CtlTransSource


The CtlTransSource is an application that forwards locally initiated remote control transactions to their remote destinations using HTTP protocol. The CtlTransSource initiates either TLS or non-TLS connections and communicates remote control transactions to HTTP servers over these connections.

The CtlTransSource must establish sufficient credentials on the remote HTTP server to execute a remote control transaction. It establishes its credentials by presenting an identity to the HTTP server on the remote node in the form of a username and password (basic authentication). When the authentication is successful, the requestor is assigned a cookie containing a user authentication that must be presented with each request on that connection.

The transactionHandlerLoop method in the CtlTransSource serves as a proxy for remote control transaction. When a local application initiates a remote control transaction, IDAPI initially directs the transaction to the CtlTransSource. The transactionHandlerLoop method is a loop that waits on remote control transactions that are directed to the CtlTransSource.

Figure A-3 shows the transactionHandlerLoop method in the CtlTransSource.

Figure A-3 CtlTransSource



When the transactionHandlerLoop receives a remotely addressed transaction, it tries to forward the remote control transaction to its remote destination. The transactionHandlerLoop formats the transaction into a control transaction message. The transactionHandlerLoop uses the HttpClient classes to issue the control transaction request to the HTTP server on the remote node. The remote HTTP server handles the remote control transaction and returns the appropriate response message in an HTTP response. If the remote HTTP server is an IPS web server, the web server uses the CtlTransSource servlet to process the remote control transactions.

The transactionHandlerLoop returns either the response or a failure response as the response of the control transaction to the initiator of the remote control transaction. If the HTTP server returns an unauthorized status response (indicating the HTTP client has insufficient credentials on the HTTP server), the transactionHandlerLoop reissues the transaction request using the designated username and password of the CtlTransSource to authenticate the identity of the requestor. The transactionHandlerLoop continues to loop until it receives a control transaction that directs it to exit or until its exit event is signaled.

Attack Response Controller

This section describes the ARC, which is the IPS application that starts and stops blocking on routers, switches, and firewalls, and rate limits traffic on routers running Cisco IOS 12.3. A *block* is an entry in the configuration or ACL of a device to block incoming and outgoing traffic for a specific host IP address or network address. This section contains the following topics:


- [Understanding the ARC, page A-13](#)
- [ARC Features, page A-14](#)
- [Supported Blocking Devices, page A-15](#)
- [ACLs and VACLs, page A-16](#)
- [Maintaining State Across Restarts, page A-16](#)
- [Connection-Based and Unconditional Blocking, page A-17](#)
- [Blocking with Cisco Firewalls, page A-18](#)
- [Blocking with Catalyst Switches, page A-19](#)

Understanding the ARC

The main responsibility of the ARC is to block events. When it responds to a block, it either interacts with the devices it is managing directly to enable the block or it sends a block request through the Control Transaction Server to a master blocking sensor. The web server on the master blocking sensor receives the control transaction and passes it to the Control Transaction Server, which passes it to the ARC. The ARC on the master blocking sensor then interacts with the devices it is managing to enable the block.

Figure A-4 illustrates the ARC.

Figure A-4 **ARC**



Note

An ARC instance can control 0, 1, or many network devices. The ARC does not share control of any network device with other ARC applications, IPS management software, other network management software, or system administrators. Only one ARC instance is allowed to run on a given sensor.

The ARC initiates a block in response to one of the following:

- An alert event generated from a signature that is configured with a block action
- A block configured manually through the CLI, IDM, IME, or ASDM
- A block configured permanently against a host or network address

When you configure the ARC to block a device, it initiates either a Telnet or SSH connection with the device. The ARC maintains the connection with each device. After the block is initiated, the ARC pushes a new set of configurations or ACLs (one for each interface direction) to each controlled device. When a block is completed, all configurations or ACLs are updated to remove the block.

ARC Features

The ARC has the following features:

- Communication through Telnet and SSH 1.5 with 3DES (the default) or DES encryption

Only the protocol specified in the ARC configuration for that device is attempted. If the connection fails for any reason, the ARC attempts to reestablish it.

- Preexisting ACLs on routers and VACLs on switches

If a preexisting ACL exists on a router interface or direction that is controlled by the ARC, you can specify that this ACL be merged into the ARC-generated configuration, either before any blocks by specifying a preblock ACL or after any blocks by specifying a postblock ACL. The Catalyst 6000 VACL device types can have a preblock and postblock VACL specified for each interface that the ARC controls. The firewall device types use a different API to perform blocks and the ARC does not have any effect on preexisting ACLs on the firewalls.

**Note**

Catalyst 5000 RSM and Catalyst 6000 MSFC2 network devices are supported in the same way as Cisco routers.

- Forwarding blocks to a list of remote sensors

The ARC can forward blocks to a list of remote sensors, so that multiple sensors can in effect collectively control a single network device. Such remote sensors are referred to as master blocking sensors.

- Specifying blocking interfaces on a network device

You can specify the interface and direction where blocking is performed in the ARC configuration for routers. You can specify the interface where blocking is performed in the VACL configuration. The ARC can simultaneously control up to 250 interfaces.

**Note**

Cisco firewalls do not block based on interface or direction, so this configuration is never specified for them.

- Blocking hosts or networks for a specified time

The ARC can block a host or network for a specified number of minutes or indefinitely. The ARC determines when a block has expired and unblocks the host or network at that time.

- Logging important events

The ARC writes a confirmation event when block or unblock actions are completed successfully or if any errors occur. The ARC also logs important events such as loss and recovery of a network device communication session, configuration errors, and errors reported by the network device.

- Maintaining the blocking state across ARC restarts

The ARC reapplies blocks that have not expired when a shutdown or restart occurs. The ARC removes blocks that have expired while it was shut down.

**Note**

The ARC can only maintain the blocking state successfully if no one changes the system time while the application is shut down.

- Maintaining blocking state across network device restarts

The ARC reapplies blocks and removes expired blocks as needed whenever a network device is shut down and restarted. The ARC is not affected by simultaneous or overlapping shutdowns and restarts of the ARC.

- Authentication and authorization

The ARC can establish a communications session with a network device that uses AAA authentication and authorization including the use of remote TACACS+ servers.

- Two types of blocking

The ARC supports host blocks and network blocks. Host blocks are connection based or unconditional. Network blocks are always unconditional.

- NAT addressing

The ARC can control network devices that use a NAT address for the sensor. If you specify a NAT address when you configure a network device, that address is used instead of the local IP address when the sensor address is filtered from blocks on that device.

- Single point of control

The ARC does not share control of network devices with administrators or other software. If you must update a configuration, shut down ARC until the change is complete. You can enable or disable the ARC through the CLI or any Cisco IPS manager. When the ARC is reenabled, it completely reinitializes itself, including rereading the current configuration for each controlled network device.



Note We recommend that you disable the ARC from blocking when you are configuring any network device, including firewalls.

- Maintains up to 250 active blocks at any given time

The ARC can maintain up to 250 active blocks at a time. Although the ARC can support up to 65535 blocks, we recommend that you allow no more than 250 at a time.



Note The number of blocks is not the same as the number of interface and directions.

Supported Blocking Devices

The ARC can control the following devices:

- Cisco routers running Cisco IOS 11.2 or later



Note To perform rate limiting, the routers must be running Cisco IOS 12.3 or later.

- Catalyst 5000 series switches with Supervisor Engine software 5.3(1) or later running on the supervisor engine, and IOS 11.2(9)P or later running on the RSM.



Note You must have the RSM because blocking is performed on the RSM.

- Catalyst 6000 series switches with PFC installed running Catalyst software 5.3 or later

- Catalyst 6000 MSFC2 with Catalyst software 5.4(3) or later and Cisco IOS 12.1(2)E or later on the MSFC2
- Cisco ASA 5500 series models: ASA 5510, ASA 5520, and ASA 5540
- FWSM



Note The FWSM cannot block in multi-mode admin context.

ACLs and VACLs

If you want to filter packets on an interface or direction that the ARC controls, you can configure the ARC to apply an ACL before any blocks (preblock ACL) and to apply an ACL after any blocks (postblock ACL). These ACLs are configured on the network device as inactive ACLs. You can define preblock and postblock ACLs for each interface and direction. The ARC retrieves and caches the lists and merges them with the blocking ACEs whenever it updates the active ACL on the network device. In most cases, you will want to specify a preexisting ACL as the postblock ACL so that it does not prevent any blocks from taking effect. ACLs work by matching a packet to the first ACE found. If this first ACE permits the packet, a subsequent deny statement will not be found.

You can specify different preblock and postblock ACLs for each interface and direction, or you can reuse the same ACLs for multiple interfaces and directions. If you do not want to maintain a preblock list, you can use the never block option and always block hosts and networks by using existing configuration statements. A forever block is a normal block with a timeout value of -1.

The ARC only modifies ACLs that it owns. It does not modify ACLs that you have defined. The ACLs maintained by ARC have a specific format that should not be used for user-defined ACLs. The naming convention is **IPS_<interface_name>_[in | out]_[0 | 1]**. <interface_name> corresponds to the name of the blocking interface as given in the ARC configuration.

For Catalyst switches, it is a blocking interface VLAN number. Do not use these names for preblock and postblock ACLs. For Catalyst 6000 VACLs, you can specify a preblock and postblock VACL and only the interface is specified (direction is not used in VLANs). For firewalls, you cannot use preblock or postblock ACLs because the firewall uses a different API for blocking. Instead you must create ACLs directly on the firewalls.

Maintaining State Across Restarts

When the sensor shuts down, the ARC writes all blocks and rate limits (with starting timestamps) to a local file (nac.shun.txt) that is maintained by the ARC. When the ARC starts, this file is used to determine if any block updates should occur at the controlled network devices. Any unexpired blocks found in the file are applied to the network devices at startup. When the ARC shuts down, no special actions on the ACLs are taken even if outstanding blocks are in effect. The nac.shun.txt file is accurate only if the system time is not changed while the ARC is not running.



Caution

Do not make manual changes to the nac.shun.txt file.

The following scenarios demonstrate how the ARC maintains state across restarts.

Scenario 1

There are two blocks in effect when the ARC stops and one of them expires before the ARC restarts. When the ARC restarts, it first reads the `nac.shun.txt` file. It then reads the preblock and postblock ACLs or VACLs. The active ACL or VACL is built in the following order:

1. The **allow** *sensor_ip_address* command (unless the **allow sensor shun** command has been configured)
2. Preblock ACL
3. The **always block** command entries from the configuration
4. Unexpired blocks from `nac.shun.txt`
5. Postblock ACL

When a host is specified as never block in the ARC configuration, it does not get translated into permit statements in the ACL. Instead, it is cached by the ARC and used to filter incoming `addShunEvent` events and `addShunEntry` control transactions.

Scenario 2

There are no preblock or postblock ACLs specified, but there is an existing active ACL. The new ACL is built in the following order:

1. The **allow** *sensor_ip_address* command (unless the **allow sensor shun** command has been configured)
2. The **always block** command entries from the configuration
3. Unexpired blocks from `nac.shun.txt`
4. The **permit IP any any** command

Connection-Based and Unconditional Blocking

The ARC supports two types of blocking for hosts and one type of blocking for networks. Host blocks are connection-based or unconditional. Network blocks are always unconditional.

When a host block is received, the ARC checks for the `connectionShun` attribute on the host block. If `connectionShun` is set to true, the ARC performs connection blocking. Any host block can contain optional parameters, such as destination IP address, source port, destination port, and protocol. For a connection block to take place, at least the source and destination IP address must be present. If the source port is present on a connection block, it is ignored and not included in the block.

Under the following conditions, the ARC forces the block to be unconditional, converting the block from connection type if necessary:

- A block of any type is active for a specified source IP address
- A new block of any type is received for that source IP address
- The new block differs in any of its optional parameters (except the source port) from the old block

When a block is updated (for example, when a new block arrives while an existing block for that source IP address or network is already in effect), the remaining minutes of the existing block are determined. If the time for the new block is less than or equal to the remaining minutes, no action is taken. Otherwise, the new block timeout replaces the existing block timeout.

**Caution**

Cisco firewalls do not support connection blocking of hosts. When a connection block is applied, the firewall treats it like an unconditional block. Cisco firewalls also do not support network blocking. ARC never tries to apply a network block to a Cisco firewall.

Blocking with Cisco Firewalls

The ARC performs blocks on firewalls using the **shun** command. The **shun** command has the following formats:

- To block an IP address:
`shun srcip [destination_ip_address source_port destination_port [port]]`
- To unblock an IP address:
`no shun ip`
- To clear all blocks:
`clear shun`
- To show active blocks or to show the global address that was actually blocked:
`show shun [ip_address]`

The ARC uses the response to the **show shun** command to determine whether the block was performed. The **shun** command does not replace existing ACLs, conduits, or outbound commands, so there is no need to cache the existing firewall configuration, nor to merge blocks into the firewall configuration.

**Caution**

Do not perform manual blocks or modify the existing firewall configuration while ARC is running.

If the **block** command specifies only the source IP address, existing active TCP connections are not broken, but all incoming packets from the blocked host are dropped.

When the ARC first starts up, the active blocks in the firewall are compared to an internal blocking list. Any blocks that do not have a corresponding internal list entry are removed.

The ARC supports authentication on a firewall using local usernames or a TACACS+ server. If you configure the firewall to authenticate using AAA but without the TACACS+ server, the ARC uses the reserved username *pix* for communications with the firewall.

If the firewall uses a TACACS+ server for authentication, you use a TACACS+ username. In some firewall configurations that use AAA logins, you are presented with three password prompts: the initial firewall password, the AAA password, and the enable password. The ARC requires that the initial firewall password and the AAA password be the same.

When you configure a firewall to use NAT or PAT and the sensor is checking packets on the firewall outside network, if you detect a host attack that originates on the firewall inside network, the sensor tries to block the translated address provided by the firewall. If you are using dynamic NAT addressing, the block can be ineffective or cause innocent hosts to be blocked. If you are using PAT addressing, the firewall could block the entire inside network. To avoid these situations, position your sensor on the inside interface or do not configure the sensor to block.

Blocking with Catalyst Switches

Catalyst switches with a PFC filter packets using VACLs. VACLs filter all packets between VLANs and within a VLAN. MSFC router ACLs are supported when WAN cards are installed and you want the sensor to control the interfaces through the MSFC2.



Note

An MSFC2 card is not a required part of a Catalyst switch configuration for blocking with VACLs.



Caution

When you configure the ARC for the Catalyst switch, do not specify a direction with the controlled interface. The interface name is a VLAN number. Preblock and postblock lists should be VACLs.

The following commands apply to the Catalyst VACLs:

- To view an existing VACL:
`show security acl info acl_name`
- To block an address (*address_spec* is the same as used by router ACLs):
`set security acl ip acl_name deny address_spec`
- To activate VACLs after building the lists:
`commit security acl all`
- To clear a single VACL:
`clear security acl map acl_name`
- To clear all VACLs:
`clear security acl map all`
- To map a VACL to a VLAN:
`set sec acl acl_name vlans`

Logger

The sensor logs all events (alert, error, status, and debug messages) in a persistent, circular buffer. The sensor also generates IP logs. The messages and IP logs are accessible through the CLI, IDM, and ASDM.

The IPS applications use the Logger to log messages. The Logger sends log messages at any of five levels of severity: debug, timing, warning, error, and fatal. The Logger writes the log messages to `/usr/cids/idsRoot/log/main.log`, which is a circular text file. New messages overwrite older messages when the file reaches its maximum size; therefore the last message written may not appear at the end of the `main.log`. Search for the string “= END OF FILE =” to locate the last line written to the `main.log`.

The `main.log` is included in the **show tech-support** command output. If the message is logged at warning level or above (error or fatal), the Logger converts the message to an `evError` event (with the corresponding error severity) and inserts it in the Event Store.

The Logger receives all syslog messages, except cron messages, that are at the level of informational and above (`*.info;cron.none`), and inserts them in to the Event Store as `evErrors` with the error severity set to Warning. The Logger and application logging are controlled through the service logger commands.

The Logger can control what log messages are generated by each application by controlling the logging severity for different logging zones. You would only access the individual-zone-control of the logger service at the request and supervision of a TAC engineer or developer. For troubleshooting purposes, TAC might request that you turn on debug logging.

InterfaceApp

The InterfaceApp is a subsystem of the MainApp, which is used for configuring and managing the Ethernet interfaces on the IPS device. There are two types of interfaces—management interfaces and sensing interfaces. The management interface is used for managing the IPS device using management applications, such as the IDM, IME, CSM, or CLI. The sensing interfaces represent the packet interfaces, which are used for directing the traffic meant for inspection. In addition to configuration, the InterfaceApp also provides packet statistics for the interfaces.

The InterfaceApp interacts with other applications on the IPS device such as the SensorApp, through control transactions. It also communicates with NIC drivers on each platform to set the interface properties such as speed, duplex, and so forth. The current interface configuration is stored by the InterfaceApp and used when the IPS device is started.

NIC drivers on each platform send asynchronous events called notifications that are related to the state of the Ethernet interfaces, for example, link up and link down notification, to the InterfaceApp. The InterfaceApp collects these notifications and sends the appropriate events.

The InterfaceApp provides a unified view of Ethernet interfaces on different platforms with varied hardware configuration, so that the same set of commands can be used for configuring and managing them.

AuthenticationApp

This section describes the AuthenticationApp, and contains the following topics:

- [Understanding the AuthenticationApp, page A-20](#)
- [Authenticating Users, page A-20](#)
- [Configuring Authentication on the Sensor, page A-21](#)
- [Managing TLS and SSH Trust Relationships, page A-21](#)

Understanding the AuthenticationApp

The AuthenticationApp has the following responsibilities:

- To authenticate the identity of a user
- To administer the accounts, privileges, keys, and certificates of the user
- To configure which authentication methods are used by the AuthenticationApp and other access services on the sensor

Authenticating Users

You must configure authentication on the sensor to establish appropriate security for user access. When you install a sensor, an initial cisco account with an expired password is created. A user with administrative access to the sensor accesses the sensor through the CLI or an IPS manager, such as the

IDM or the ASDM, by logging in to the sensor using the default administrative account (**cisco**). In the CLI, the administrator is prompted to change the password. IPS managers initiate a `setEnableAuthenticationTokenStatus` control transaction to change the password of an account.

Through the CLI or an IPS manager, the administrator configures which authentication method is used, such as username and password or an SSH authorized key. The application servicing the administrator initiates a `setAuthenticationConfig` control transaction to establish the authentication configuration.

The authentication configuration includes a login attempt limit value that is used to specify how account locking is handled. Account locking is invoked when the number of consecutive failed login attempts for a given account exceeds the login attempt limit value. After an account is locked, all further attempts to log in to that account are rejected. The account is unlocked by resetting the authentication token of the account using the `setEnableAuthenticationTokenStatus` control transaction. The account locking feature is disabled when the login attempt limit value is set to zero.

The administrator can add additional user accounts either through the CLI or an IPS manager.

Configuring Authentication on the Sensor

When a user tries to access the sensor through a service such as web server or the CLI, the identity of the user must be authenticated and the privileges of the user must be established. The service that is providing access to the user initiates an `execAuthenticateUser` control transaction request to the `AuthenticationApp` to authenticate the identity of the user. The control transaction request typically includes the username and a password, or the identity of the user can be authenticated using an SSH authorized key.

The `AuthenticationApp` responds to the `execAuthenticateUser` control transaction request by attempting to authenticate the identity of the user. The `AuthenticationApp` returns a control transaction response that contains the authentication status and privileges of the user. If the identity of the user cannot be authenticated, the `AuthenticationApp` returns an unauthenticated status and anonymous user privileges in the control transaction response. The control transaction response also indicates if the account password has expired. User interface applications that authenticate users by initiating an `execAuthenticateUser` control transaction prompt the user to change the password.

The `AuthenticationApp` uses the underlying operating system to confirm the identity of a user. All the IPS applications send control transactions to the `AuthenticationApp`, which then uses the operating system to form its responses.

Remote shell services, Telnet and SSH, are not IPS applications. They call the operating system directly. If the user is authenticated, it launches the IPS CLI. In this case, the CLI sends a special form of the `execAuthenticateUser` control transaction to determine the privilege level of the logged-in user. The CLI then tailors the commands it makes available based on this privilege level.

Managing TLS and SSH Trust Relationships

Encrypted communications over IP networks provide data privacy by making it impossible for a passive attacker to discover from the packets exchanged alone the secret key needed to decrypt the data in the packets.

However, an equally dangerous attack vector is for an imposter to pretend to be the server end of the connection. All encryption protocols provide a means for clients to defend themselves from these attacks. IPS supports two encryption protocols, SSH and TLS, and the `AuthenticationApp` helps manage trust when the sensor plays either the client or server role in encrypted communications.

The IPS web server and SSH server are server endpoints of encrypted communications. They protect their identities with a private key and offer a public key to clients that connect to them. For TLS this public key is included inside an X.509 certificate, which includes other information. Remote systems that connect to the sensor should verify that the public key received during connection establishment is the key they expect.

Clients must maintain a list of trusted public keys to protect themselves from man-in-the-middle attacks. The exact procedure by which this trust is established varies depending on the protocol and client software. In general, the client displays a fingerprint of 16 or 20 bytes. The human operator who is configuring the client to establish trust should use an out-of-band method to learn the key fingerprints of the server before attempting to establish trust. If the fingerprints match, the trust relationship is established and henceforth the client can automatically connect with that server and be confident that the remote server is not an imposter.

You can use the **show ssh server-key** and **show tls fingerprint** to display the key fingerprints of the sensor. By recording the output of these commands when directly connected to the sensor console, you can reliably use this information to confirm the identity of the sensor over the network later when establishing trust relationships.

For example, when you initially connect to a sensor through the Microsoft Internet Explorer web browser, a security warning dialog box indicates that the certificate is not trusted. Using the user interface of Internet Explorer, you can inspect the certificate thumbprint, a value that should exactly match the SHA1 fingerprint displayed by the **show tls fingerprint** command. After verifying this, add this certificate to the list of trusted CAs of the browser to establish permanent trust.

Each TLS client has different procedures for establishing this trust. The sensor itself includes a TLS client that is used to send control transactions to other sensors and download upgrades and configuration files from other TLS web servers. Use the **tls trusted-host** command to establish trust of the TLS servers with which the sensor communicates.

Similarly, the sensor includes an SSH client that is used to communicate with managed network devices, download upgrades, and copy configurations and support files to remote hosts. Use the **ssh host-key** command to establish trust relationships with the SSH servers the sensor will contact.

You can manage the list of TLS trusted certificates and SSH known hosts through the commands **service trusted-certificates** and **service ssh-known-hosts**.

X.509 certificates include additional information that can increase the security of the trust relationship; however, these can lead to confusion. For example, an X.509 certificate includes a validity period during which the certificate can be trusted. Typically this period is a number of years starting at the moment the certificate is created. To ensure that an X.509 certificate is valid at the moment it is being used requires that the client system maintain an accurate clock.

X.509 certificates are also tied to a particular network address. Sensors fill this field with the IP address of the command and control interface of the sensor. Consequently, if you change the command and control IP address of the sensor, the X.509 certificate of the server is regenerated. You must reconfigure all clients on the network that trusted the old certificate to locate the sensor at its new IP address and trust the new certificate.

By using the SSH known hosts and TLS trusted certificates services in the AuthenticationApp, you can operate sensors at a high level of security.

Web Server

The web server provides SDEE support, which enables the sensor to report security events, receive IDIOM transactions, and serve IP logs. The web server supports HTTP 1.0 and 1.1. Communications with the web server often include sensitive information, such as passwords, that would severely compromise the security of the system if an attacker were able to eavesdrop. For this reason, sensors ship with TLS enabled. The TLS protocol is an encryption protocol that is compatible with SSL.

**Note**

We deprecated the RDEP event sever service in IPS 6.1, and deleted it from the IPS 7.0(1) system architecture. The web server now uses the SDEE event server.

SensorApp

This section describes the SensorApp, and contains the following topics:

- [Understanding the SensorApp, page A-23](#)
- [Inline, Normalization, and Event Risk Rating Features, page A-24](#)
- [SensorApp New Features, page A-25](#)
- [Packet Flow, page A-26](#)
- [Signature Event Action Processor, page A-26](#)

Understanding the SensorApp

The SensorApp performs packet capture and analysis. Policy violations are detected through signatures in the SensorApp and the information about the violations is forwarded to the Event Store in the form of an alert. Packets flow through a pipeline of processors fed by a producer designed to collect packets from the network interfaces on the sensor. Event actions can be associated with an event risk rating threshold that must be surpassed for the actions to take place. Some of the processors call inspectors to perform signature analysis. All inspectors can call the alarm channel to produce alerts as needed.

The SensorApp supports the following processors:

- **Time Processor**—This processor processes events stored in a time-slice calendar. Its primary task is to make stale database entries expire and to calculate time-dependent statistics.
- **Deny Filters Processor**—This processor handles the deny attacker functions. It maintains a list of denied source IP addresses. Each entry in the list expires based on the global deny timer, which you can configure in the virtual sensor configuration.
- **Signature Event Action Processor**—This processor processes event actions. Event actions can be associated with an event risk rating threshold that must be surpassed for the actions to take place. It supports the following event actions:
 - Reset TCP flow
 - IP log
 - Deny packets
 - Deny flow
 - Deny attacker

- Alert
 - Block host
 - Block connection
 - Generate SNMP trap
 - Capture trigger packet
- Statistics Processor—This processor keeps track of system statistics such as packet counts and packet arrival rates.
- Layer 2 Processor—This processor processes layer 2-related events. It also identifies malformed packets and removes them from the processing path. You can configure actionable events for detecting malformed packets such as alert, capture packet, and deny packet. The layer 2 processor updates statistics about packets that have been denied because of the policy you have configured.
- Database Processor—This processor maintains the signature state and flow databases.
- Fragment Reassembly Processor—This processor reassembles fragmented IP datagrams. It is also responsible for normalization of IP fragments when the sensor is in inline mode.
- Stream Reassembly Processor—This processor reorders TCP streams to ensure the arrival order of the packets at the various stream-based inspectors. It is also responsible for normalization of the TCP stream. The normalizer engine lets you enable or disable alert and deny actions.

The TCP Stream Reassembly Processor normalizer has a hold-down timer, which lets the stream state rebuild after a reconfiguration event. You cannot configure the timer. During the hold-down interval, the system synchronizes stream state on the first packet in a stream that passes through the system. When the hold down has expired, sensorApp enforces your configured policy. If this policy calls for a denial of streams that have not been opened with a 3-way handshake, established streams that were quiescent during the hold-down period will not be forwarded and will be allowed to timeout. Those streams that were synchronized during the hold-down period are allowed to continue.

- Signature Analysis Processor—This processor dispatches packets to the inspectors that are not stream-based and that are configured for interest in the packet in process.
- Slave Dispatch Processor—A process found only on dual CPU systems.

The SensorApp also supports the following units:

- Analysis Engine—The analysis Engine handles sensor configuration. It maps the interfaces and also the signature and alarm channel policy to the configured interfaces.
- Alarm Channel—The Alarm Channel processes all signature events generated by the inspectors. Its primary function is to generate alerts for each event it is passed.

Inline, Normalization, and Event Risk Rating Features

The SensorApp contains the following inline, normalization, and event risk rating features:

- Processing packets inline

When the sensor is processing packets in the data path, all packets are forwarded without any modifications unless explicitly denied by policy configuration. Because of TCP normalization it is possible that some packets will be delayed to ensure proper coverage. When policy violations are encountered, the SensorApp allows for the configuration of actions. Additional actions are available in inline mode, such as deny packet, deny flow, and deny attacker.

All packets that are unknown or of no interest to the IPS are forwarded to the paired interface with no analysis. All bridging and routing protocols are forwarded with no participation other than a possible deny due to policy violations. There is no IP stack associated with any interface used for inline (or promiscuous) data processing. The current support for 802.1q packets in promiscuous mode is extended to inline mode.

- IP normalization

Intentional or unintentional fragmentation of IP datagrams can serve to hide exploits making them difficult or impossible to detect. Fragmentation can also be used to circumvent access control policies like those found on firewalls and routers. And different operating systems use different methods to queue and dispatch fragmented datagrams. If the sensor has to check for all possible ways that the end host will reassemble the datagrams, it makes the sensor vulnerable to denial of service attacks. Reassembling all fragmented datagrams inline and only forwarding completed datagrams, refragmenting the datagram if necessary, is the solution to this problem. The IP Fragmentation Normalization unit performs this function.

- TCP normalization

Through intentional or natural TCP session segmentation, some classes of attacks can be hidden. To make sure policy enforcement can occur with no false positives and false negatives, the state of the two TCP endpoints must be tracked and only the data that is actually processed by the real host endpoints should be passed on. Overlaps in a TCP stream can occur, but are extremely rare except for TCP segment retransmits. Overwrites in the TCP session should not occur. If overwrites do occur, someone is intentionally trying to elude the security policy or the TCP stack implementation is broken. Maintaining full information about the state of both endpoints is not possible unless the sensor acts as a TCP proxy. Instead of the sensor acting as a TCP proxy, the segments will be ordered properly and the normalizer will look for any abnormal packets associated with evasion and attacks.

- Event risk rating

Event risk rating helps reduce false positives from the system and gives you more control over what causes an alarm. The event risk rating incorporates the following additional information beyond the detection of a potentially malicious action:

- Severity of the attack if it were to succeed
- Fidelity of the signature
- Relevance of the potential attack with respect to the target host
- Overall value of the target host

SensorApp New Features

The SensorApp contains the following new features:

- Policy table—Provides a list of risk category settings (high, medium, and low).
- Evasion protection—Lets an inline interface mode sensor switch from strict mode to asymmetric mode for the Normalizer.
- Sensor health meter—Provides sensor-wide health statistics.
- Top services—Provides the top ten instances of the TCP, UDP, ICMP, and IP protocols.
- Security meter—Profiles alerts into threat categories and reports this information in red, yellow, and green buckets. You can configure the transition points for these buckets.

- Clear Flow state—Lets you clear the database, which causes the sensor to start fresh just as in a restart.
- Restart status—Reports periodically the current start and restart stages of the sensor.

Packet Flow

Packets are received by the NIC and placed in the kernel user-mapped memory space by the IPS-shared driver. The packet is prepended by the IPS header. Each packet also has a field that indicates whether to pass or deny the packet when it reaches Signature Event Action Processor.

The producer pulls packets from the shared-kernel user-mapped packet buffer and calls the process function that implements the processor appropriate to the sensor model. The following orders occur:

- Single processor execution
Time Processor --> Layer 2 Processor --> Deny Filters Processor --> Fragment Reassembly Processor --> Statistics Processor --> Database Processor --> Signature Analysis Processor --> Stream Reassembly Processor --> Signature Event Action Processor
- Dual processor execution
Execution Thread 1 Time Processor --> Layer 2 Processor --> Deny Filters Processor --> Fragment Reassembly Processor --> Statistics Processor --> Database Processor --> Signature Analysis Processor --> Slave Dispatch Processor --> | Execution Thread 2 Database Processor --> Stream Reassembly Processor --> Signature Event Action Processor

Signature Event Action Processor

The Signature Event Action Processor coordinates the data flow from the signature event in the Alarm Channel to processing through the Signature Event Action Override, the Signature Event Action Filter, and the Signature Event Action Handler. It consists of the following components:

- Alarm Channel—The unit that represents the area to communicate signature events from the SensorApp inspection path to signature event handling.
- Signature Event Action Override—Adds actions based on the risk rating value. Signature Event Action Override applies to all signatures that fall in the range of the configured risk rating threshold. Each Signature Event Action Override is independent and has a separate configuration value for each action type.
- Signature Event Action Filter—Subtracts actions based on the signature ID, addresses, and risk rating of the signature event. The input to the Signature Event Action Filter is the signature event with actions possibly added by the Signature Event Action Override.



Note

The Signature Event Action Filter can only subtract actions, it cannot add new actions.


The following parameters apply to the Signature Event Action Filter:

- Signature ID
- Subsignature ID
- Attacker address
- Attacker port
- Victim address

- Victim port
- Risk rating threshold range
- Actions to subtract
- Sequence identifier (optional)
- Stop-or-continue bit
- Enable action filter line bit
- Victim OS relevance or OS relevance
- Signature Event Action Handler—Performs the requested actions. The output from the Signature Event Action Handler is the actions being performed and possibly an evIdsAlert written to the Event Store.

Figure A-5 illustrates the logical flow of the signature event through the Signature Event Action Processor and the operations performed on the action for this event. It starts with the signature event with configured action received in the Alarm Channel and flows top to bottom as the signature event passes through the functional components of the Signature Event Action Processor.

Figure A-5 Signature Event Through Signature Event Action Processor



132188

CollaborationApp

This section describes the CollaborationApp, and contains the following sections:

- [Understanding the CollaborationApp, page A-28](#)
- [Update Components, page A-28](#)
- [Error Events, page A-29](#)

Understanding the CollaborationApp

The CollaborationApp is a peer of the MainApp and the SensorApp. It interfaces with them using various interprocess communication technologies, such as IDAPI control transactions, semaphores, shared memory, and file exchange.

Reputation updates are exchanged between the Global Correlation server and the CollaborationApp. The CollaborationApp communicates with the sensors using four update components:

- Set of rules score weight values
- Set of IP addresses and address ranges, which together with the rules and alerts provide the information needed to calculate reputation scores
- List of IP addresses and address ranges for which traffic should always be denied
- Network participation configuration, which allows the server to control the rate at which sensors send telemetry data to the server

The sensor sends collaboration information to the Network Participation server. The sensor queries the Global Correlation server for a list of what collaboration updates are available and from which Global Correlation server to download the update files.

**Note**

The SensorApp starts before the CollaborationApp, but they initialize asynchronously. Therefore, it is possible that the Reputation Update server may download and attempt to apply one or more global correlation updates before the SensorApp is ready to accept the update. The update server may download and partially process the update, but it must wait until the SensorApp is ready before it can commit the update.

For More Information

For detailed information on global correlation and how to configure it, see [Chapter 10, “Configuring Global Correlation.”](#)

Update Components

The Global Correlation Update client exchanges manifests with the Global Correlation Update server. It parses the server manifest to determine what new updates are available for download and where they reside, and then builds a list of updates to be installed. If all updates are applied successfully, then the Global Correlation Update client commits the applied updates for each component, notifies SensorApp that new updates are available, and updates the client manifest to reflect the latest committed updates for each component.

The client manifest contains the UDI of the sensor, which includes the serial number of the sensor, and an encrypted shared secret that the server uses to verify the sensor is an authentic Cisco IPS sensor. The server manifest contains a list of update files available for each component. For each update file in the list, the server manifest contains data, such as the update version, type, order, location, file transfer protocol, and so forth.

There are two types of updates files: a full update file that replaces any existing data in the database of the component, and an incremental update that modifies the existing reputation data by adding, deleting, or replacing information. When all update files have been applied for all components, the temporary databases are committed by replacing the working databases.

Authentication and authorization are achieved through the secret encryption mechanism and decryption key management. The Global Correlation Update server authenticates the sensor using the shared secret encryption mechanism contained in the client manifest. The Global Correlation Update client authorizes sensors using decryption key management. Sensors that have been authenticated by the Global Correlation Update server are sent valid keys in the server manifest so that they can decrypt the update files.

**Caution**

You receive a warning message if you have enabled global correlation, but you have not configured a DNS or HTTP proxy server. This warning is a reminder to either disable global correlation or add a DNS or HTTP proxy server.

For More Information

For the procedure for adding a DNS or proxy server to support global correlation, see [Changing Network Settings, page 4-2](#).

Error Events

Whenever a global correlation update fails, an evError event is generated. The error message is included in sensor statistics. The following conditions result in a status message with the severity of Error:

- The sensor is unlicensed
- No DNS or HTTP proxy server is configured
- The manifest exchange failed
- An update file download failed
- Applying or committing the update failed

An evError event is generated with the severity level of Warning if you edit and save either the host or global correlation configurations so that global correlation is enabled, but no DNS or HTTP proxy servers are configured.

For More Information

For the procedure for displaying sensor statistics, see [Displaying Statistics, page 17-31](#).

SwitchApp

The 4500 series sensors have a built in switch that provides the external monitoring interfaces of the sensor. The SwitchApp is part of the IPS 4500 series design that enables the InterfaceApp and sensor initialization scripts to communicate and control the switch. Any application that needs to get or set information on the switch must communicate with the SwitchApp. Additionally the SwitchApp implements the following:

- Detects bypass—When the SensorApp is not monitoring, the SwitchApp places the switch in bypass mode and then back to inspection mode once the SensorApp is up and running normally.
- Collects port statistics—The SwitchApp monitors the switch and collects statistics on the external interfaces of the switch for reporting by InterfaceApp.
- Handles the external interface configuration—When you update the interface configuration, the configuration is sent to the InterfaceApp, which updates the interface configuration for SwitchApp, which then forwards that configuration on to the switch.

CLI

The CLI provides the sensor user interface for all direct node access such as Telnet, SSH, and serial interface. You configure the sensor applications with the CLI. Direct access to the underlying OS is allowed through the service role. This section describes the IPS CLI, and contains the following topics:

- [User Roles, page A-30](#)
- [Service Account, page A-31](#)

User Roles



Caution

You should carefully consider whether you want to create a service account. The service account provides shell access to the system, which makes the system vulnerable. However, you can use the service account to create a password if the administrator password is lost. Analyze your situation to decide if you want a service account existing on the system.

There are four user roles:

- Viewer—Can view configuration and events, but cannot modify any configuration data except their user passwords.
- Operator—Can view everything and can modify the following options:
 - Signature tuning (priority, disable or enable)
 - Virtual sensor definition
 - Managed routers
 - Their user passwords
- Administrator—Can view everything and can modify all options that operators can modify in addition to the following:
 - Sensor addressing configuration
 - List of hosts allowed to connect as configuration or viewing agents

- Assignment of physical sensing interfaces
- Enable or disable control of physical interfaces
- Add and delete users and passwords
- Generate new SSH host keys and server certificates
- Service—Only one user with service privileges can exist on a sensor. The service user cannot log in to the IDM or the IME. The service user logs in to a bash shell rather than the CLI.

The service role is a special role that allows you to bypass the CLI if needed. Only one service account is allowed. You should only create an account with the service role for troubleshooting purposes. Only a user with administrator privileges can edit the service account.

When you log in to the service account, you receive the following warning:

```
***** WARNING *****
UNAUTHORIZED ACCESS TO THIS NETWORK DEVICE IS PROHIBITED.
This account is intended to be used for support and troubleshooting purposes only.
Unauthorized modifications are not supported and will require this device to be
re-imaged to guarantee proper operation.
*****
```



Note

For IPS 5.0 and later, you can no longer remove the **cisco** account. You can disable it using the **no password cisco** command, but you cannot remove it. To use the **no password cisco** command, there must be another administrator account on the sensor. Removing the **cisco** account through the service account is not supported. If you remove the **cisco** account through the service account, the sensor most likely will not boot up, so to recover the sensor you must reinstall the sensor system image.

Service Account

The service account is a support and troubleshooting tool that enables the TAC to log in to a native operating system shell rather than the CLI shell. It does not exist on the sensor by default. You must create it so that it is available for the TAC to use for troubleshooting your sensor.

Only one service account is allowed per sensor and only one account is allowed a service role. When the password of the service account is set or reset, the password of the root account is set to the same password. This allows the service account user to su to root using the same password. When the service account is removed, the password of the root account is locked.

The service account is not intended to be used for configuration purposes. Only modifications made to the sensor through the service account under the direction of the TAC are supported. Cisco Systems does not support the addition and/or running of an additional service to the operating system through the service account, because it affects proper performance and proper functioning of the other IPS services. The TAC does not support a sensor on which additional services have been added.

You can track logins to the service account by checking the log file `/var/log/.tac`, which is updated with a record of service account logins.



Note

The Cisco IPS incorporates several troubleshooting features that are available through the CLI, IDM, or IME. The service account is not necessary for most troubleshooting situations. You may need to create the service account at the direction of TAC to troubleshoot a very unique problem. The service account lets you bypass the protections built into the CLI and allows root privilege access to the sensor, which is otherwise disabled. We recommend that you do not create a service account unless it is needed for a specific reason. You should remove the service account when it is no longer needed.

Communications

This section describes the communications protocols used by the Cisco IPS. It contains the following topics:

- [IDAPI, page A-32](#)
- [IDIOM, page A-33](#)
- [IDCONF, page A-33](#)
- [SDEE, page A-34](#)
- [CIDEE, page A-34](#)

IDAPI

IPS applications use an interprocess communication API called the IDAPI to handle internal communications. The IDAPI reads and writes event data and provides a mechanism for control transactions. The IDAPI is the interface through which all the applications communicate.

The SensorApp captures and analyzes the network traffic on its interfaces. When a signature is matched, the SensorApp generates an alert, which is stored in the Event Store. If the signature is configured to perform the blocking response action, the SensorApp generates a block event, which is also stored in the Event Store.

Figure A-6 illustrates the IDAPI interface.

Figure A-6 IDAPI



Each application registers to the IDAPI to send and receive events and control transactions. The IDAPI provides the following services:

- Control transactions
 - Initiates the control transaction.
 - Waits for the inbound control transaction.
 - Responds to the control transaction.
- IPS events
 - Subscribes to remote IPS events, which are stored in the Event Store when received.
 - Reads IPS events from the Event Store.
 - Writes IPS events to the Event Store.

The IDAPI provides the necessary synchronization mechanisms to guarantee atomic data accesses.

IDIOM

IDIOM is a data format standard that defines the event messages that are reported by the IPS as well as the operational messages that are used to configure and control intrusion detection systems. These messages consist of XML documents that conform to the IDIOM XML schema.

IDIOM supports two types of interactions: event and control transaction. Event interactions are used to exchange IPS events such as alerts. IDIOM uses two types of messages for event interactions: event and error messages. Control transactions provide a means for one host to initiate an action in, change the state of, or read the state of another host. Control transactions utilize four types of IDIOM messages: request, response, configuration, and error messages. Events and control transactions that are communicated between application instances within a host are known as local events or local control transactions, or collectively, local IDIOM messages. Events and control transactions that are communicated between different hosts are known as remote events and remote control transactions, or collectively, remote IDIOM messages.



Note

IDIOM for the most part has been superseded by IDCONF, SDEE, and CIDEE.

IDCONF

The Cisco IPS manages its configuration using XML documents. IDCONF specifies the XML schema including the Cisco IPS control transactions. The IDCONF schema does not specify the contents of the configuration documents, but rather the framework and building blocks from which the configuration documents are developed. It provides mechanisms that let the IPS managers and CLI ignore features that are not configurable by certain platforms or functions through the use of the feature-supported attribute.

IDCONF messages are wrapped inside IDIOM request and response messages.

The following is an IDCONF example:

```
<?xml version="1.0" encoding="UTF-8" standalone="yes"?>
<request xmlns="http://www.cisco.com/cids/idiom" schemaVersion="2.00">
  <editConfigDelta xmlns="http://www.cisco.com/cids/idconf">
    <component name="userAccount">
      <config typedefsVersion="2004-03-01" xmlns="http://www.cisco.com/cids/idconf">
        <struct>
          <map name="user-accounts" editOp="merge">
            <mapEntry>
              <key>
                <var name="name">cisco</var>
              </key>
              <struct>
                <struct name="credentials">
                  <var name="role">administrator</var>
                </struct>
              </struct>
            </mapEntry>
          </map>
        </struct>
      </config>
    </component>
  </editDefaultConfig>
</request>
```

SDEE

The Cisco IPS produces various types of events including intrusion alerts and status events. The IPS communicates events to clients such as management applications using the proprietary IPS-industry leading protocol, SDEE, which is a product-independent standard for communicating security device events. SDEE adds extensibility features that are needed for communicating events generated by various types of security devices.

Systems that use SDEE to communicate events to clients are referred to as SDEE providers. SDEE specifies that events can be transported using the HTTP or HTTP over SSL and TLS protocols. When HTTP or HTTPS is used, SDEE providers act as HTTP servers, while SDEE clients are the initiators of HTTP requests.

The IPS includes the web server, which processes HTTP or HTTPS requests. The web server uses run-time loadable servlets to process the different types of HTTP requests. Each servlet handles HTTP requests that are directed to the URL associated with the servlet. The SDEE server is implemented as a web server servlet.

The SDEE server only processes authorized requests. A request is authorized if it originates from a web server to authenticate the identity of the client and determine the privilege level of the client.

CIDEE

CIDEE specifies the extensions to SDEE that are used by the Cisco IPS. The CIDEE standard specifies all possible extensions that are supported by the Cisco IPS. Specific systems may implement a subset of CIDEE extensions. However, any extension that is designated as being required **MUST** be supported by all systems. CIDEE specifies the Cisco IPS-specific security device events and the IPS extensions to the SDEE `evIdsAlert` element.

CIDEE supports the following events:

- **evError—Error event**
Generated by the CIDEE provider when the provider detects an error or warning condition. The `evError` event contains error code and textual description of the error.
- **evStatus—Status message event**
Generated by CIDEE providers to indicate that something of potential interest occurred on the host. Different types of status messages can be reported in the status event—one message per event. Each type of status message contains a set of data elements that are specific to the type of occurrence that the status message is describing. The information in many of the status messages are useful for audit purposes. Errors and warnings are not considered status information and are reported using `evError` rather than `evStatus`.
- **evShunRqst—Block request event**
Generated to indicate that a block action is to be initiated by the service that handles network blocking.

The following is a CIDEE extended event example:

```
<sd:events xmlns:cid="http://www.cisco.com/cids/2004/04/cidee"
xmlns:sd="http://example.org/2003/08/sdee">
  <sd:evIdsAlert eventId="1042648730045587005" vendor="Cisco" severity="medium">
    <sd:originator>
      <sd:hostId>Beta4Sensor1</sd:hostId>
      <cid:appName>sensorApp</cid:appName>
      <cid:appInstanceId>8971</cid:appInstanceId>
    </sd:originator>
```



```
<sd:time offset="0" timeZone="UTC">1043238671706378000</sd:time>
<sd:signature description="IOS Udp Bomb" id="4600" cid:version="S37">
  <cid:subsigId>0</cid:subsigId>
</sd:signature> ...
```

Cisco IPS File Structure

The Cisco IPS has the following directory structure:

- /usr/cids/idsRoot—Main installation directory.
- /usr/cids/idsRoot/shared—Stores files used during system recovery.
- /usr/cids/idsRoot/var—Stores files created dynamically while the sensor is running.
- /usr/cids/idsRoot/var/updates—Stores files and logs for update installations.
- /usr/cids/idsRoot/var/virtualSensor—Stores files used by SensorApp to analyze regular expressions.
- /usr/cids/idsRoot/var/eventStore—Contains the Event Store application.
- /usr/cids/idsRoot/var/core—Stores core files that are created during system crashes.
- /usr/cids/idsRoot/var/iplogs—Stores iplog file data.
- /usr/cids/idsRoot/bin—Contains the binary executables.
- /usr/cids/idsRoot/bin/authentication—Contains the authentication application.
- /usr/cids/idsRoot/bin/cidDump—Contains the script that gathers data for tech support.
- /usr/cids/idsRoot/bin/cidwebserver—Contains the web server application.
- /usr/cids/idsRoot/bin/cidcli—Contains the CLI application.
- /usr/cids/idsRoot/bin/nac—Contains the ARC application.
- /usr/cids/idsRoot/bin/logApp—Contains the logger application.
- /usr/cids/idsRoot/bin/mainApp—Contains the main application.
- /usr/cids/idsRoot/bin/sensorApp—Contains the sensor application.
- /usr/cids/idsRoot/bin/collaborationApp—Contains the collaboration application.
- /usr/cids/idsRoot/bin/switchApp—Contains the switch application.
- /usr/cids/idsRoot/bin/falcondump—Contains the application for getting packet dumps on the sensing ports of IDSM-2.
- /usr/cids/idsRoot/etc—Stores sensor configuration files.
- /usr/cids/idsRoot/htdocs—Contains the IDM files for the web server.
- /usr/cids/idsRoot/lib—Contains the library files for the sensor applications.
- /usr/cids/idsRoot/log—Contains the log files for debugging.
- /usr/cids/idsRoot/tmp—Stores the temporary files created during run time of the sensor.

Summary of Cisco IPS Applications

Table A-2 gives a summary of the applications that make up the IPS.

Table A-2 **Summary of Applications**

Application	Description
AuthenticationApp	Authorizes and authenticates users based on IP address, password, and digital certificates.
Attack Response Controller	An ARC is run on every sensor. Each ARC subscribes to network access events from its local Event Store. The ARC configuration contains a list of sensors and the network access devices that its local ARC controls. If an ARC is configured to send network access events to a master blocking sensor, it initiates a network access control transaction to the remote ARC that controls the device. These network access action control transactions are also used by IPS managers to issue occasional network access actions.
CLI	Accepts command line input and modifies the local configuration using the IDAPI.
CollaborationApp	Shares information with other devices through a global correlation database to improve the combined efficacy of all the devices.
Control Transaction Server ¹	Accepts control transactions from a remote client, initiates a local control transaction, and returns the response to the remote client.
Control Transaction Source ²	Waits for control transactions directed to remote applications, forwards the control transactions to the remote node, and returns the response to the initiator.
IDM	The Java applet that provides an HTML IPS management interface.
IME	The Java applet that provides an interface for viewing and archiving events.
InterfaceApp	Handles bypass and physical settings and defines paired interfaces. Physical settings are speed, duplex, and administrative state.
Logger	Writes all the log messages of the application to the log file and the error messages of the application to the Event Store.
MainApp	Reads the configuration and starts applications, handles starting and stopping of applications and node reboots, handles software upgrades.
NotificationApp	Sends SNMP traps when triggered by alert, status, and error events. NotificationApp uses the public domain SNMP agent. SNMP GETs provide information about the general health of the sensor.
SDEE Server ³	Accepts requests for events from remote clients.
SensorApp	Captures and analyzes traffic on the monitored network and generates intrusion and network access events. Responds to IP logging control transactions that turn logging on and off and that send and delete IP log files.

Table A-2 **Summary of Applications (continued)**

Application	Description
SwitchApp	Part of the IPS 4500 series design that enables the InterfaceApp and sensor initialization scripts to communicate with and control the built-in switch. Any application that needs to get or set information on the switch must communicate with the SwitchApp.
Web Server	Waits for remote HTTP client requests and calls the appropriate servlet application.

1. This is a web server servlet.
2. This is a remote control transaction proxy.
3. This is a web server servlet.



Signature Engines

This appendix describes the IPS signature engines, and contains the following sections:

- [Understanding Signature Engines, page B-1](#)
- [Master Engine, page B-4](#)
- [Regular Expression Syntax, page B-9](#)
- [AIC Engine, page B-10](#)
- [Atomic Engine, page B-14](#)
- [Fixed Engine, page B-30](#)
- [Flood Engine, page B-32](#)
- [Meta Engine, page B-33](#)
- [Multi String Engine, page B-36](#)
- [Normalizer Engine, page B-37](#)
- [Service Engines, page B-40](#)
- [State Engine, page B-61](#)
- [String Engines, page B-63](#)
- [String XL Engines, page B-66](#)
- [Sweep Engines, page B-69](#)
- [Traffic Anomaly Engine, page B-72](#)
- [Traffic ICMP Engine, page B-74](#)
- [Trojan Engines, page B-75](#)

Understanding Signature Engines

A signature engine is a component of the Cisco IPS that is designed to support many signatures in a certain category. An engine is composed of a parser and an inspector. Each engine has a set of parameters that have allowable ranges or sets of values.



Note

The Cisco IPS engines support a standardized Regex.

Cisco IPS contains the following signature engines:

- **AIC**—Provides thorough analysis of web traffic. The AIC engine provides granular control over HTTP sessions to prevent abuse of the HTTP protocol. It allows administrative control over applications, such as instant messaging and gotomypc, that try to tunnel over specified ports. You can also use AIC to inspect FTP traffic and control the commands being issued. There are two AIC engines: AIC FTP and AIC HTTP.
- **Atomic**—The Atomic engines are combined into four engines with multi-level selections. You can combine Layer 3 and Layer 4 attributes within one signature, for example IP + TCP. The Atomic engine uses the standardized Regex support. The Atomic engines consist of the following types:
 - **Atomic ARP**—Inspects Layer 2 ARP protocol. The Atomic ARP engine is different because most engines are based on Layer 3 IP protocol.
 - **Atomic IP Advanced**—Inspects IPv6 Layer 3 and ICMPv6 Layer 4 traffic.
 - **Atomic IP**—Inspects IP protocol packets and associated Layer 4 transport protocols. This engine lets you specify values to match for fields in the IP and Layer 4 headers, and lets you use Regex to inspect Layer 4 payloads.



Note All IP packets are inspected by the Atomic IP engine. This engine replaces the 4.x Atomic ICMP, Atomic IP Options, Atomic L3 IP, Atomic TCP, and Atomic UDP engines.

- **Atomic IPv6**—Detects two IOS vulnerabilities that are stimulated by malformed IPv6 traffic.
- **Fixed**—Performs parallel regular expression matches up to a fixed depth, then stops inspection using a single regular expression table. There are three Fixed engines: ICMP, TCP, and UDP.
- **Flood**—Detects ICMP and UDP floods directed at hosts and networks. There are two Flood engines: Flood Host and Flood Net.
- **Meta**—Defines events that occur in a related manner within a sliding time interval. This engine processes events rather than packets.
- **Multi String**—Inspects Layer 4 transport protocols and payloads by matching several strings for one signature. This engine inspects stream-based TCP and single UDP and ICMP packets.
- **Normalizer**—Configures how the IP and TCP Normalizer functions and provides configuration for signature events related to the IP and TCP Normalizer. Allows you to enforce RFC compliance.
- **Service**—Deals with specific protocols. The Service engines are divided in to the following protocol types:
 - **DNS**—Inspects DNS (TCP and UDP) traffic.
 - **FTP**—Inspects FTP traffic.
 - **FTP V2**—Supports IOS IPS. This signature engine provides a protocol decode engine tuned for IOS IPS. If you try to use this engine, you receive an error message.
 - **Generic**—Decodes custom service and payload, and generically analyzes network protocols.
 - **H225**—Inspects VoIP traffic. Helps the network administrator make sure the SETUP message coming in to the VoIP network is valid and within the bounds that the policies describe. Is also helps make sure the addresses and Q.931 string fields such as url-ids, email-ids, and display information adhere to specific lengths and do not contain possible attack patterns.
 - **HTTP**—Inspects HTTP traffic. The WEBPORTS variable defines inspection port for HTTP traffic.

- HTTP V2—Supports IOS IPS. This signature engine provides a protocol decode engine tuned for IOS IPS. If you try to use this engine, you receive an error message.
- IDENT—Inspects IDENT (client and server) traffic.
- MSRPC—Inspects MSRPC traffic.
- MSSQL—Inspects Microsoft SQL traffic.
- NTP—Inspects NTP traffic.
- P2P—Inspects P2P traffic.
- RPC—Inspects RPC traffic.
- SMB Advanced—Processes Microsoft SMB and Microsoft DCE/RPC (MSRPC) over SMB packets.

**Note**

The SMB engine has been replaced by the SMB Advanced engine. Even though the SMB engine is still visible in IDM, IME, and the CLI, its signatures have been obsoleted; that is, the new signatures have the obsoletes parameter set with the IDs of their corresponding old signatures. Use the new SMB Advanced engine to rewrite any custom signature that were in the SMB engine.

- SMTP V1—Supports IOS IPS.
This signature engine provides a protocol decode engine tuned for IOS IPS. If you try to use this engine, you receive an error message.
- SNMP—Inspects SNMP traffic.
- SSH—Inspects SSH traffic.
- TNS—Inspects TNS traffic.
- State—Conducts stateful searches of strings in protocols such as SMTP. The state engine has a hidden configuration file that is used to define the state transitions so new state definitions can be delivered in a signature update.
- String—Searches on Regex strings based on ICMP, TCP, or UDP protocol. There are three String engines: String ICMP, String TCP, and String UDP.
- String XL—Searches on Regex strings based on ICMP, TCP, or UDP protocol. The String XL engines provide optimized operation for the Regex accelerator card. There are three String engines: String ICMP XL, String TCP XL, and String UDP XL.

**Note**

The IPS 4345, IPS 4360, IPS 4510, IPS 4520, ASA 5525-X IPS SSP, ASA 5545-X IPS SSP, ASA 5555-X IPS SSP, and ASA 5585-X IPS SSP support the String XL engines and the Regex accelerator card.

**Note**

The Regex accelerator card is used for both the standard String engines and the String XL engines. Most standard String engine signatures can be compiled and analyzed by the Regex accelerator card without modification. However, there are special circumstances in which the standard String engine signatures cannot be compiled for the Regex accelerator card. In these situations a new signature is written in a String XL engine using the specific parameters in the String XL engine that do compile on the Regex accelerator card. The new signature in the String XL engine obsoletes the original signature in the standard String engine.

- Sweep—Analyzes sweeps from a single host (ICMP and TCP), from destination ports (TCP and UDP), and multiple ports with RPC requests between two nodes. There are two Sweep engines: Sweep and Sweep Other TCP.
- Traffic Anomaly—Inspects TCP, UDP, and other traffic for worms.
- Traffic ICMP—Analyzes nonstandard protocols, such as TFN2K, LOKI, and DDOS. There are only two signatures with configurable parameters.
- Trojan—Analyzes traffic from nonstandard protocols, such as BO2K and TFN2K. There are three Trojan engines: Bo2k, Tfn2k, and UDP. There are no user-configurable parameters in these engines.

For More Information

For a list of the signature regular expression syntax, see [Regular Expression Syntax, page B-9](#).

Master Engine

The Master engine provides structures and methods to the other engines and handles input from configuration and alert output. This section describes the Master engine, and contains the following topics:

- [General Parameters, page B-4](#)
- [Alert Frequency, page B-7](#)
- [Event Actions, page B-8](#)

General Parameters

The following parameters are part of the Master engine and apply to all signatures (if it makes sense for that signature engine). [Table B-1](#) lists the general master engine parameters.

Table B-1 **Master Engine Parameters**

Parameter	Description	Value
signature-id	Specifies the ID of this signature.	<i>number</i>
sub-signature-id	Specifies the sub ID of this signature	<i>number</i>

Table B-1 Master Engine Parameters (continued)

Parameter	Description	Value
alert-severity	Specifies the severity of the alert: <ul style="list-style-type: none"> Dangerous alert Medium-level alert Low-level alert Informational alert 	high medium low informational (default)
sig-fidelity-rating	Specifies the rating of the fidelity of this signature.	0 to 100 (default = 100)
promisc-delta	Specifies the delta value used to determine the seriousness of the alert.	0 to 30 (default = 5)
sig-name	Specifies the name of the signature.	<i>sig-name</i>
alert-notes	Provides additional information about this signature that will be included in the alert message.	<i>alert-notes</i>
user-comments	Provides comments about this signature.	<i>comments</i>
alert-traits	Specifies traits you want to document about this signature.	0 to 65335
release	Provides the release in which the signature was most recently updated.	<i>release</i>
signature-creation-date	Specifies the date the signature was created.	—
signature-type	Specifies the signature category.	anomaly component exploit other vulnerability
engine	Specifies the engine to which the signature belongs. Note The engine-specific parameters appear under the engine category.	—
event-count	Specifies the number of times an event must occur before an alert is generated.	1 to 65535 (default = 1)
event-count-key	Specifies the storage type on which to count events for this signature: <ul style="list-style-type: none"> Attacker address Attacker and victim addresses Attacker address and victim port Victim address Attacker and victim addresses and ports 	Axxx AxBx Axxb xxBx AaBb

Table B-1 Master Engine Parameters (continued)

Parameter	Description	Value
specify-alert-interval {yes no}	Enables the alert interval: <ul style="list-style-type: none"> alert-interval—Specifies the time in seconds before the event count is reset. 	2 to 1000
status	Specifies whether the signature is enabled or disabled, active or retired.	enabled retired {yes no}
obsoletes	Indicates that a newer signature has disabled an older signature.	—
vulnerable-os-list	When combined with passive OS fingerprinting, it allows the IPS to determine if it is likely a given attack is relevant to the target system.	aix bsd general-os hp-ux ios irix linus mac-os netware other solaris unix windows windows-ut windows-nt-2k-xp
mars-category {yes no}	Maps signatures to a MARS attack category. ¹	—

1. This is a static information category that you can set in the configuration and view in the alerts. Refer to the MARS documentation for more information.

Promiscuous Delta

The promiscuous delta lowers the risk rating of certain alerts in promiscuous mode. Because the sensor does not know the attributes of the target system and in promiscuous mode cannot deny packets, it is useful to lower the prioritization of promiscuous alerts (based on the lower risk rating) so the administrator can focus on investigating higher risk rating alerts. In inline mode, the sensor can deny the offending packets so that they never reach the target host, so it does not matter if the target was vulnerable. Because the attack was not allowed on the network, the IPS does not subtract from the risk rating value. Signatures that are not service, OS, or application-specific have 0 for the promiscuous delta. If the signature is specific to an OS, service, or application, it has a promiscuous delta of 5, 10, or 15 calculated from 5 points for each category.



Caution

We recommend that you do NOT change the promisc-delta setting for a signature.

Obsoletes

The Cisco signature team uses the obsoletes field to indicate obsoleted, older signatures that have been replaced by newer, better signatures, and to indicate disabled signatures in an engine when a better instance of that engine is available. For example, some String XL hardware-accelerated signatures now replace equivalent signatures that were defined in the String engine.

Vulnerable OS List

When you combine the vulnerable OS setting of a signature with passive OS fingerprinting, the IPS can determine if it is likely that a given attack is relevant to the target system. If the attack is found to be relevant, the risk rating value of the resulting alert receives a boost. If the relevancy is unknown, usually because there is no entry in the passive OS fingerprinting list, then no change is made to the risk rating. If there is a passive OS fingerprinting entry and it does not match the vulnerable OS setting of a signature, the risk rating value is decreased. The default value by which to increase or decrease the risk rating is +/- 10 points.

For More Information

- For more information about promiscuous mode, see [Understanding Promiscuous Mode, page 5-19](#).
- For more information about passive OS fingerprinting, see [Configuring OS Identifications, page 7-26](#).

Alert Frequency

The purpose of the alert frequency parameter is to reduce the volume of the alerts written to the Event Store to counter IDS DoS tools, such as stick. There are four modes: fire-all, fire-once, summarize, and global-summarize. The summary mode is changed dynamically to adapt to the current alert volume. For example, you can configure the signature to fire-all, but after a certain threshold is reached, it starts summarizing. [Table B-2](#) lists the alert frequency parameters.

Table B-2 Master Engine Alert Frequency Parameters

Parameter	Description	Value
summary-mode	Specifies the mode used for summarization: <ul style="list-style-type: none"> • fire-all—Fires an alert on all events. • fire-once—Fires an alert only once. • global-summarize—Summarizes an alert so that it only fires once regardless of how many attackers or victims. • summarize—Summarizes alerts. 	fire-all fire-once global-summarize summarize
specify-summary-threshold {yes no}	Enables summary threshold mode: <ul style="list-style-type: none"> • summary-threshold—Specifies the threshold number of alerts to send a signature into summary mode. • summary-interval—Specifies the time in seconds used in each summary alert. 	0 to 65535 1 to 1000

Table B-2 Master Engine Alert Frequency Parameters (continued)

Parameter	Description	Value
specify-global-summary-threshold {yes no}	Enables global summary threshold mode: <ul style="list-style-type: none"> global-summary-threshold—Specifies the threshold number of events to take alerts into global summary. 	1 to 65535
summary-key	Specifies the storage type on which to summarize this signature: <ul style="list-style-type: none"> Attacker address Attacker and victim addresses Attacker address and victim port Victim address Attacker and victim addresses and ports 	Axxx AxBx Axxb xxBx AaBb

Event Actions

The Cisco IPS supports the following event actions. Most of the event actions belong to each signature engine unless they are not appropriate for that particular engine.

Alert and Log Actions

- produce-alert—Writes an evIdsAlert to Event Store.
- produce-verbose-alert—Includes an encoded dump (possibly truncated) of the offending packet in the evIdsAlert.
- log-attacker-packets—Starts IP logging of packets containing the attacker address and sends an alert.
- log-victim-packets—Starts IP logging of packets containing the victim address and sends an alert.
- log-pair-packets (inline mode only)—Starts IP logging of packets containing the attacker/victim address pair.
- request-snmp-trap—Sends request to the NotificationApp to perform SNMP notification.

Deny Actions

- deny-packet-inline (inline mode only)—Does not transmit this packet.



Note

You cannot delete the event action override for deny-packet-inline because it is protected. If you do not want to use that override, set the override-item-status to disabled for that entry.

- deny-connection-inline (inline mode only)—Does not transmit this packet and future packets on the TCP Flow.
- deny-attacker-victim-pair-inline (inline mode only)—Does not transmit this packet and future packets on the attacker/victim address pair for a specified period of time.
- deny-attacker-service-pair-inline (inline mode only)—Does not transmit this packet and future packets on the attacker address victim port pair for a specified period of time.

- deny-attacker-inline (inline mode only)—Does not transmit this packet and future packets from the attacker address for a specified period of time.

**Note**

This is the most severe of the deny actions. It denies the current and future packets from a single attacker address. Each deny address times out for *X* seconds from the first event that caused the deny to start, where *X* is the amount of seconds that you configured. You can clear all denied attacker entries with the **clear denied-attackers** command, which permits the addresses back on the network.

- modify-packet-inline (inline mode only)—Modifies packet data to remove ambiguity about what the end point might do with the packet.

**Note**

The event action modify-packet-inline is part of the Normalizer engine. It scrubs the packet and corrects irregular issues such as bad checksum, out of range values, and other RFC violations.

Other Actions**Note**

IPv6 does not support the following event actions: request-block-host, request-block-connection, or request-rate-limit.

- request-block-connection—Requests the ARC to block this connection.
- request-block-host—Requests the ARC to block this attacker host.
- request-rate-limit—Requests the ARC to perform rate limiting.
- reset-tcp-connection—Sends TCP resets to hijack and terminate the TCP flow.

Regular Expression Syntax

Regular expressions (Regex) are a powerful and flexible notational language that allow you to describe text. In the context of pattern matching, regular expressions allow a succinct description of any arbitrary pattern. [Table B-3](#) lists the IPS signature Regex syntax.

Table B-3 Signature Regular Expression Syntax

Metacharacter	Name	Description
?	Question mark	Repeat 0 or 1 times.
*	Star, asterisk	Repeat 0 or more times.
+	Plus	Repeat 1 or more times.
{x}	Quantifier	Repeat exactly <i>X</i> times.
{x,}	Minimum quantifier	Repeat at least <i>X</i> times.
.	Dot	Any one character except new line (0x0A).
[abc]	Character class	Any character listed.
[^abc]	Negated character class	Any character not listed.

Table B-3 Signature Regular Expression Syntax (continued)

Metacharacter	Name	Description
[a-z]	Character range class	Any character listed inclusively in the range.
()	Parenthesis	Used to limit the scope of other metacharacters.
	Alternation, or	Matches either expression it separates.
^	caret	The beginning of the line.
\char	Escaped character	When <i>char</i> is a metacharacter or not, matches the literal <i>char</i> .
char	Character	When <i>char</i> is not a metacharacter, matches the literal <i>char</i> .
\r	Carriage return	Matches the carriage return character (0x0D).
\n	New line	Matches the new line character (0x0A).
\t	Tab	Matches the tab character (0x09).
\f	Form feed	Matches the form feed character (0x0C).
\xNN	Escaped hexadecimal character	Matches character with the hexadecimal code 0xNN (0<=N<=F).
\NNN	Escaped octal character	Matches the character with the octal code NNN (0<=N<=8).

All repetition operators will match the shortest possible string as opposed to other operators that consume as much of the string as possible thus giving the longest string match.

[Table B-4](#) lists examples of Regex patterns.

Table B-4 Regex Patterns

To Match	Regular Expression
Hacker	Hacker
Hacker or hacker	[Hh]acker
Variations of bananas, banananas, banananananas	ba(na)+s
foo and bar on the same line with anything except a new line between them	foo.*bar
Either foo or bar	foolbar
Either moon or soon	(mls)oon

AIC Engine

The Application Inspection and Control (AIC) engine inspects HTTP web traffic and enforces FTP commands. This section describes the AIC engine and its parameters, and contains the following topics:

- [Understanding the AIC Engine, page B-11](#)
- [AIC Engine and Sensor Performance, page B-11](#)
- [AIC Engine Parameters, page B-11](#)

Understanding the AIC Engine

AIC provides thorough analysis of web traffic. It provides granular control over HTTP sessions to prevent abuse of the HTTP protocol. It allows administrative control over applications, such as instant messaging and gotomypc, that try to tunnel over specified ports. Inspection and policy checks for P2P and instant messaging are possible if these applications are running over HTTP. AIC also provides a way to inspect FTP traffic and control the commands being issued. You can enable or disable the predefined signatures or you can create policies through custom signatures.

**Note**

The AIC engines run when HTTP traffic is received on AIC web ports. If traffic is web traffic, but not received on the AIC web ports, the Service HTTP engine is executed. AIC inspection can be on any port if it is configured as an AIC web port and the traffic to be inspected is HTTP traffic.

AIC Engine and Sensor Performance

Application policy enforcement is a unique sensor feature. Rather than being based on traditional IPS technologies that inspect for exploits, vulnerabilities, and anomalies, AIC policy enforcement is designed to enforce HTTP and FTP service policies. The inspection work required for this policy enforcement is extreme compared with traditional IPS inspection work. A large performance penalty is associated with using this feature. When AIC is enabled, the overall bandwidth capacity of the sensor is reduced.

AIC policy enforcement is disabled in the IPS default configuration. If you want to activate AIC policy enforcement, we highly recommend that you carefully choose the exact policies of interest and disable those you do not need. Also, if your sensor is near its maximum inspection load capacity, we recommend that you not use this feature since it can oversubscribe the sensor. We recommend that you use the adaptive security appliance firewall to handle this type of policy enforcement.

AIC Engine Parameters

The AIC engines define signatures for deep inspection of web traffic. They also define signatures that authorize and enforce FTP commands. There are two AIC engines: AIC HTTP and AIC FTP. The AIC engines have the following features:

- Web traffic:
 - RFC compliance enforcement
 - HTTP request method authorization and enforcement
 - Response message validation
 - MIME type enforcement
 - Transfer encoding type validation
 - Content control based on message content and type of data being transferred
 - URI length enforcement
 - Message size enforcement according to policy configured and the header
 - Tunneling, P2P and instant messaging enforcement.

This enforcement is done using regular expressions. There are predefined signature but you can expand the list.

- FTP traffic:
 - FTP command authorization and enforcement

Table B-5 lists the parameters that are specific to the AIC HTTP engine.

Table B-5 AIC HTTP Engine Parameters

Parameter	Description	
signature-type	Specifies the type of AIC signature.	<ul style="list-style-type: none"> • content-types • define-web-traffic-policy • max-outstanding-requests-overrun • max-outstanding-requests-overrun • msg-body-pattern • request-methods • transfer-encodings •
content-types	Specifies the AIC signature that deals with MIME types: <ul style="list-style-type: none"> • define-content-type—Associates actions such as denying a specific MIME type (image/gif), defining a message-size violation, and determining that the MIME-type mentioned in the header and body do not match. • define-recognized-content-types—Lists the content types recognized by the sensor. 	—
define-web-traffic-policy	Specifies the action to take when noncompliant HTTP traffic is seen. The alarm-on-non-http-traffic {true false} command enables the signature. This signature is disabled by default.	—
max-outstanding-requests-overrun	Specifies the maximum allowed HTTP requests per connection.	1 - 16
msg-body-pattern	Uses Regex to define signatures that look for specific patterns in the message body: <ul style="list-style-type: none"> • regex-list— • regex-list-in-order— 	—

Table B-5 AIC HTTP Engine Parameters (continued)

Parameter	Description	
request-methods	Specifies an AIC signature that allows actions to be associated with HTTP request methods: <ul style="list-style-type: none"> define-request-method—Specifies get, put, and so forth. recognized-request-methods—Lists methods recognized by the sensor. 	—
transfer-encodings	Specifies an AIC signature that deals with transfer encodings: <ul style="list-style-type: none"> define-transfer-encoding—Associates an action with each method, such as compress, chunked, and so forth. recognized-transfer-encodings—Lists methods recognized by the sensor. chunked-transfer-encoding—Error specifies actions to be taken when a chunked encoding error is seen. 	—

Table B-6 lists the parameters that are specific to the AIC FTP engine.

Table B-6 AIC FTP Engine Parameters

Parameter	Description	Value
signature-type	Specifies the type of AIC signature.	<ul style="list-style-type: none"> ftp-commands unrecognized-ftp-command
ftp-commands	Associates an action with an FTP command: <ul style="list-style-type: none"> ftp-command—Lets you choose the FTP command you want to inspect. 	<ul style="list-style-type: none"> help, noop, stat, syst, user, abort, acct, allo, appe, cdup, cwd, dele, list, mkd, mode, nlst, pass, pasv, port, pass, quit, rein, rest, retr, rmd, rnfr, rnto, site, smnt, stor, stou, stru, type
unrecognized-ftp-command	Inspects unrecognized FTP commands.	

For More Information

- For the procedures for configuring AIC engine signatures, see [Configuring AIC Signatures, page 8-17](#).
- For an example of a custom AIC signature, see [Creating an AIC Signature, page 8-26](#).
- For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Atomic Engine

The Atomic engine contains signatures for simple, single packet conditions that cause alerts to be fired. This section describes the Atomic engine, and contains the following topics:

- [Atomic ARP Engine, page B-14](#)
- [Atomic IP Advanced Engine, page B-15](#)
- [Atomic IP Engine, page B-25](#)
- [Atomic IPv6 Engine, page B-29](#)

Atomic ARP Engine

The Atomic ARP engine defines basic Layer 2 ARP signatures and provides more advanced detection of the ARP spoof tools dsniff and ettercap. [Table B-7](#) lists the parameters that are specific to the Atomic ARP engine.

Table B-7 Atomic ARP Engine Parameters

Parameter	Description	Value
specify-arp-operation {yes no}	(Optional) Enables ARP operation: <ul style="list-style-type: none">• arp-operation—Specifies the type of ARP operation to inspect.	0 to 65535
specify-mac-flip {yes no}	(Optional) Enables MAC address flip times: <ul style="list-style-type: none">• mac-flip—Specifies how many times to flip the MAC address in the alert.	0 to 65535
specify-request-inbalance {yes no}	(Optional) Enables request inbalance: <ul style="list-style-type: none">• request-inbalance—Specifies the value for firing an alert when there are this many more requests than replies on the IP address.	0 to 65535

Table B-7 Atomic ARP Engine Parameters (continued)

Parameter	Description	Value
specify-type-of-arp-sig {yes no}	(Optional) Enables the ARP signature type: <ul style="list-style-type: none"> type-of-arp-sig—Specifies the type of ARP signatures you want to fire on: <ul style="list-style-type: none"> Destination Broadcast—Fires an alert for this signature when it sees an ARP destination address of 255.255.255.255. Same Source and Destination—Fires an alert for this signature when it sees an ARP destination address with the same source and destination MAC address Source Broadcast (default)—Fires an alert for this signature when it sees an ARP source address of 255.255.255.255. Source Multicast—Fires an alert for this signature when it sees an ARP source MAC address of 01:00:5e:(00-7f). 	dst-broadcast same-src-dst src-broadcast src-multicast
storage-key	Specifies the type of address key used to store persistent data: <ul style="list-style-type: none"> Attacker address Attacker and victim addresses Victim address Global 	Axxx AxBx xxBx xxxx

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Atomic IP Advanced Engine

The Atomic IP Advanced engine parses and interprets the IPv6 header and its extensions, the IPv4 header and its options, ICMP, ICMPv6, TCP, and UDP, and seeks out anomalies that indicate unusual activity.

Atomic IP Advanced engine signatures do the following:

- Inspect for anomalies in IP addresses, for example, spoofed addresses.
- Inspect for bad information in the length fields of the packet.
- Fire informational alerts about the packet.
- Fire higher severity alerts for the limited set of known vulnerabilities.
- Duplicate any IPv6-specific signatures in Engine Atomic IP that can also apply to IPv6.
- Provide default signatures for identifying tunneled traffic based on IP address, port, protocol, and limited information from the packet data.

Only the outermost IP tunnel is identified. When an IPv6 tunnel or IPv6 traffic inside of an IPv4 tunnel is detected, a signature fires an alert. All of the other IPv6 traffic in embedded tunnels is not inspected. The following tunneling methods are supported, but not individually detected. For example, ISATAP, 6to4, and manual IPv6 RFC 4213 tunnels all appear as IPv6 in IPv4, which is detected by signature 1007:

- ISATAP
- 6to4 (RFC 3056)
- Manually configured tunnels (RFC 4213)
- IPv6 over GRE
- Teredo (IPv6) inside UDP
- MPLS (unencrypted)
- IPv6 over IPv6

IPv6 supports the following:

- Denying by source IP address, destination IP address, or IP address pair
- Alerts
- Resetting the TCP connection
- Logging

Atomic IP Advanced Engine Restrictions

The Atomic IP Advanced engine contains the following restrictions:

- Cannot detect the Layer 4 field of the packets if the packets are fragmented so that the Layer 4 identifier does not appear in the first packet.
- Cannot detect Layer 4 attacks in flows with packets that are fragmented by IPv6 because there is no fragment reassembly.
- Cannot detect attacks with tunneled flows.
- Limited checks are provided for the fragmentation header.
- There is no support for IPv6 on the management (command and control) interface. With ASA 8.2(1), the ASA 5500 AIP SSM support IPv6 features.
- If there are illegal duplicate headers, a signature fires, but the individual headers cannot be separately inspected.
- Anomaly detection does not support IPv6 traffic; only IPv4 traffic is directed to the anomaly detection processor.
- Rate limiting and blocking are not supported for IPv6 traffic. If a signature is configured with a block or rate limit event action and is triggered by IPv6 traffic, an alert is generated but the action is not carried out.

Table B-8 lists the parameters that are specific to the Atomic IP Advanced engine.

**Note**

The second number in the ranges must be greater than or equal to the first number.

Table B-8 Atomic IP Advanced Engine Parameters

Parameter	Description	Value
Global		
fragment-status	Specifies whether or not fragments are wanted.	any no-fragments want-fragments
specify-encapsulation {yes no}	(Optional) Enables any encapsulation before the start of Layer 3 for the packet: ¹ <ul style="list-style-type: none"> encapsulation—Specifies the type of encapsulation to inspect. 	none mpls gre ipv4-in-ipv6 ipipl any
specify-ip-version {yes no}	(Optional) Enables the IP protocol version: <ul style="list-style-type: none"> version—Specifies IPv4 or IPv6. 	ipv4 ipv6
swap-attacker-victim	Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.	true false (default)
Regex		
specify-regex-inspection	(Optional) Enables Regex inspection.	yes no
regex-scope	Specifies the start and end points for the regular expression search.	ipv6-doh-only ipv6-doh-plus ipv6-hoh-only ipv6-hoh-plus ipv6-rh-only ipv6-rh-plus layer3-only layer3-plus layer4
regex-string	Specifies the regular expression to search for in a single TCP packet.	<i>string</i>
specify-exact-match-offset {yes no}	Enables exact match offset: <ul style="list-style-type: none"> exact-match-offset—Specifies the exact stream offset the regex-string must report for a match to be valid. 	0 to 65535
specify-min-match-length {yes no}	Enables minimum match length: <ul style="list-style-type: none"> min-match-length—Specifies the minimum number of bytes the regex-string must match. 	0 to 65535

Table B-8 Atomic IP Advanced Engine Parameters (continued)

Parameter	Description	Value
specify-min-match-offset {yes no}	Enables minimum match offset: <ul style="list-style-type: none"> min-match-offset—Specifies the minimum stream offset the regex-string must report for a match to be valid. 	0 to 65535
specify-max-match-offset {yes no}	Enables maximum match offset: <ul style="list-style-type: none"> max-match-offset—Specifies the maximum stream offset the regex-string must report for a match to be valid. 	0 to 65535
IPv6		
specify-authentication-header {yes no}	(Optional) Enables inspection of the authentication header: <ul style="list-style-type: none"> ah-present—Inspects the authentication header: <ul style="list-style-type: none"> ah-length—Specifies the length of the authentication header to inspect. ah-next-header—Specifies the value of the authentication header to inspect. 	<ul style="list-style-type: none"> have-ah no-ah 0 to 1028 0 to 255
specify-dest-options-header {yes no}	(Optional) Enables inspection of the destination options header: <ul style="list-style-type: none"> doh-present—Inspects the destination options header: <ul style="list-style-type: none"> doh-count—Specifies the number of destination options headers to inspect. doh-length—Specifies the length of destination options headers to inspect. doh-next-header—Specifies the number of next destination options headers to inspect. doh-option-type—Specifies the type of destination options headers to inspect. doh-option-length—Specifies the length of destination options headers to inspect. 	<ul style="list-style-type: none"> have-doh no-doh 0 to 2 8 to 2048 0 to 255 0 to 255 0 to 255
specify-esp-header {yes no}	(Optional) Enables inspection of the ESP header: <ul style="list-style-type: none"> esp-present —Inspects the ESP header. 	have-esp no-esp

Table B-8 Atomic IP Advanced Engine Parameters (continued)

Parameter	Description	Value
specify-first-next-header {yes no}	(Optional) Enables inspection of the first next header: <ul style="list-style-type: none"> first-next-header—Specifies the value of the first next header to inspect. 	0 to 255
specify-flow-label {yes no}	(Optional) Enables inspection of the flow label: <ul style="list-style-type: none"> flow-label—Specifies the value of the flow label to inspect. 	0 to 1048575
specify-headers-out-of-order {yes no}	(Optional) Enables inspection of out-of-order headers: <ul style="list-style-type: none"> headers-out-of-order—Inspects headers that are out of order. 	true false
specify-headers-repeated {yes no}	(Optional) Enables inspection of repeated headers: <ul style="list-style-type: none"> headers-repeated—Inspects repeated headers. 	{yes no}
specify-hop-limit {yes no}	(Optional) Enables hop limit: <ul style="list-style-type: none"> hop-limit—Specifies the value of the hop limit to inspect. 	0 to 255
specify-hop-options-header {yes no}	(Optional) Enables inspection of the hop-by-hop options header: <ul style="list-style-type: none"> hoh-present—Inspects the hop-by-hop options header. 	have-hoh no-hoh

Table B-8 Atomic IP Advanced Engine Parameters (continued)

Parameter	Description	Value
specify-ipv6-addr-options {yes no}	(Optional) Enables the IPv6 address options: <ul style="list-style-type: none"> • <code>ipv6-addr-options</code>—Specifies the IPv6 address options: <ul style="list-style-type: none"> – <code>address-with-localhost</code>—IP address with ::1. – <code>documentation-address</code>—IP address with 2001:db8::/32 prefix. – <code>ipv6-addr</code>—IP address. – <code>link-local-address</code>—Inspects for an IPv6 link local address. – <code>multicast-dst</code>—Inspects for a destination multicast address. – <code>multicast-src</code>—Inspects for a source multicast address. – <code>not-link-local-address</code>—Inspects for an address that is not link-local. – <code>not-valid-address</code>—Inspects for an address that is not reserved for link-local, global, or multicast. – <code>src-ip-eq-dst-ip</code>—Source and destination addresses are the same. 	true false
specify-ipv6-data-length {yes no}	(Optional) Enables inspection of IPv6 data length: <ul style="list-style-type: none"> • <code>ipv6-data-length</code>—Specifies the IPv6 data length to inspect. 	0 to 65535
specify-ipv6-header-length {yes no}	(Optional) Enables inspection of IPv6 header length: <ul style="list-style-type: none"> • <code>ipv6-header-length</code>—Specifies the length of the IPv6 header to inspect. 	0 to 65535
specify-ipv6-total-length {yes no}	(Optional) Enables inspection of IPv6 total length: <ul style="list-style-type: none"> • <code>ipv6-total-length</code>—Specifies the IPv6 total length to inspect. 	0 to 65535
specify-ipv6-payload-length {yes no}	(Optional) Enables inspection of IPv6 payload length: <ul style="list-style-type: none"> • <code>ipv6-payload-length</code>—Specifies the IPv6 payload length to inspect. 	0 to 65535
specify-routing-header {yes no}	(Optional) Enables inspection of the routing header: <ul style="list-style-type: none"> • <code>rh-present</code>—Inspects the routing header. 	have-rh no-rh

Table B-8 Atomic IP Advanced Engine Parameters (continued)

Parameter	Description	Value
specify-traffic-class {yes no}	(Optional) Enables inspection of the traffic class: <ul style="list-style-type: none"> traffic-class—Specifies the value of the traffic class to inspect. 	0 to 255
IPV4		
specify-ip-addr-options {yes no}	(Optional) Enables IP address options: <ul style="list-style-type: none"> ip-addr-options—Specifies the IP address options. 	address-with-localhost ip-addr ² rfc-1918-address src-ip-eq-dst-ip
specify-ip-header-length {yes no}	(Optional) Enables inspection of the IP header length: <ul style="list-style-type: none"> ip-header-length—Specifies the length of the IP header to inspect. 	0 to 16
specify-ip-id {yes no}	(Optional) Enables inspection of the IP identifier: <ul style="list-style-type: none"> ip-id—Specifies the IP ID to inspect. 	0 to 255
specify-ip-option-inspection {yes no}	(Optional) Enables inspection of the IP options: <ul style="list-style-type: none"> ip-option-inspection—Specifies the value of the IP option: <ul style="list-style-type: none"> ip-option—IP OPTION code to match. ip-option-abnormal—The list of options is malformed. 	0 to 65535
specify-ip-payload-length {yes no}	(Optional) Enables inspection of the IP payload length: <ul style="list-style-type: none"> ip-payload-length—Specifies the length of the IP payload to inspect. 	0 to 65535
specify-ip-tos {yes no}	(Optional) Enables inspection of the IP type of service: <ul style="list-style-type: none"> ip-tos—Specifies the IP type of service to inspect. 	0 to 255
specify-ip-total-length {yes no}	(Optional) Enables inspection of the IP total length: <ul style="list-style-type: none"> ip-total-length—Specifies the total length of the IP packet to inspect. 	0 to 65535
specify-ip-ttl {yes no}	(Optional) Enables inspection of the IP time-to-live: <ul style="list-style-type: none"> ip-ttl—Specifies the value of the IP TTL to inspect. 	0 to 255

Table B-8 Atomic IP Advanced Engine Parameters (continued)

Parameter	Description	Value
specify-ip-version {yes no}	(Optional) Enables inspection of the IP version: <ul style="list-style-type: none"> ip-version—Specifies which IP version to inspect. 	0 to 16
L4 Protocol		
specify-l4-protocol {yes no}	(Optional) Enables inspection of Layer 4 protocol: <ul style="list-style-type: none"> l4-protocol—Specifies which Layer 4 protocol to inspect. 	icmp icmpv6 tcp udp other
L4 Protocol Other		
specify-other-ip-protocol-id	(Optional) Enables inspection of other Layer 4 protocols: <ul style="list-style-type: none"> other-ip-protocol-id—Specifies which single IP protocol ID or single range of IP protocol IDs for which to send alerts. 	0 to 255
L4 Protocol ICMP		
specify-icmp-code {yes no}	(Optional) Enables inspection of Layer 4 ICMP code: <ul style="list-style-type: none"> icmp-code—Specifies the value of the ICMP header CODE. 	0 to 65535
specify-icmp-id {yes no}	(Optional) Enables inspection of Layer 4 ICMP ID: <ul style="list-style-type: none"> icmp-id—Specifies the value of the ICMP header IDENTIFIER. 	0 to 65535
specify-icmp-seq {yes no}	(Optional) Enables inspection of Layer 4 ICMP sequence: <ul style="list-style-type: none"> icmp-seq—Specifies the ICMP sequence for which to look. 	0 to 65535
specify-icmp-type {yes no}	(Optional) Enables inspection of the Layer 4 ICMP header type: <ul style="list-style-type: none"> icmp-type—Specifies the value of the ICMP header TYPE. 	0 to 65535
L4 Protocol ICMPv6		
specify-icmpv6-code {yes no}	(Optional) Enables inspection of the Layer 4 ICMPv6 code: <ul style="list-style-type: none"> icmpv6-code—Specifies the value of the ICMPv6 header CODE. 	0 to 255

Table B-8 Atomic IP Advanced Engine Parameters (continued)

Parameter	Description	Value
specify-icmpv6-id {yes no}	(Optional) Enables inspection of the Layer 4 ICMPv6 identifier: <ul style="list-style-type: none"> icmpv6-id—Specifies the value of the ICMPv6 header IDENTIFIER. 	0 to 65535
specify-icmpv6-length {yes no}	(Optional) Enables inspection of the Layer 4 ICMPv6 length: <ul style="list-style-type: none"> icmpv6-length—Specifies the value of the ICMPv6 header LENGTH. 	0 to 65535
specify-icmpv6-mtu-field {yes no}	(Optional) Enables inspection of the Layer 4 ICMPv6 MTU field: <ul style="list-style-type: none"> icmpv6-mtu-field—Specifies the value of the ICMPv6 header MTU field. 	4,294,967,295
specify-icmpv6-option-type {yes no}	(Optional) Enables inspection of the Layer 4 ICMPv6 type: <ul style="list-style-type: none"> icmpv6-option-type—Specifies the ICMPv6 option type to inspect. 	0 to 255
specify-icmpv6-option-length {yes no}	(Optional) Enables inspection of the Layer 4 ICMPv6 option length: <ul style="list-style-type: none"> icmpv6-option-length—Specifies the ICMPv6 option length to inspect. 	0 to 255
specify-icmpv6-seq {yes no}	(Optional) Enables inspection of the Layer 4 ICMPv6 sequence: <ul style="list-style-type: none"> icmpv6-seq—Specifies the value of the ICMPv6 header SEQUENCE. 	0 to 65535
specify-icmpv6-type {yes no}	(Optional) Enables inspection of the Layer 4 ICMPv6 type: <ul style="list-style-type: none"> icmpv6-type—Specifies the value of the ICMPv6 header TYPE. 	0 to 255
L4 Protocol TCP and UDP		
specify-dst-port {yes no}	(Optional) Enables the destination port for use: <ul style="list-style-type: none"> dst-port—Specifies the destination port of interest for this signature. 	0 to 65535
specify-src-port {yes no}	(Optional) Enables source port for use: <ul style="list-style-type: none"> src-port—Specifies the source port of interest for this signature. 	0 to 65535

Table B-8 Atomic IP Advanced Engine Parameters (continued)

Parameter	Description	Value
specify-tcp-mask {yes no}	(Optional) Enables the TCP mask for use: <ul style="list-style-type: none"> tcp-mask—Specifies the mask used in TCP flags comparison: <ul style="list-style-type: none"> URG bit ACK bit PSH bit RST bit SYN bit FIN bit 	urg ack psh rst syn fin
specify-tcp-flags {yes no}	(Optional) Enables TCP flags for use: <ul style="list-style-type: none"> tcp-flags—Specifies the TCP flags to match when masked by mask: <ul style="list-style-type: none"> URG bit ACK bit PSH bit RST bit SYN bit FIN bit 	urg ack psh rst syn fin
specify-tcp-reserved {yes no}	(Optional) Enables TCP reserved for use: <ul style="list-style-type: none"> tcp-reserved—Specifies the value of TCP reserved. 	0 to 63
specify-tcp-header-length {yes no}	(Optional) Enables inspection of the Layer 4 TCP header length: <ul style="list-style-type: none"> tcp-header-length—Specifies the length of the TCP header used in inspection. 	0 to 60
specify-tcp-payload-length {yes no}	(Optional) Enables inspection of the Layer 4 TCP payload length: <ul style="list-style-type: none"> tcp-payload-length—Specifies the length of the TCP payload. 	0 to 65535
specify-tcp-urg-pointer {yes no}	(Optional) Enables inspection of the Layer 4 TCP URG pointer: <ul style="list-style-type: none"> tcp-urg-pointer—Specifies the value of the TCP URG flag inspection. 	0 to 65535
specify-tcp-window-size {yes no}	(Optional) Enables inspection of the Layer 4 TCP window size: <ul style="list-style-type: none"> tcp-window-size—Specifies the window size of the TCP packet. 	0 to 65535

Table B-8 Atomic IP Advanced Engine Parameters (continued)

Parameter	Description	Value
specify-udp-valid-length {yes no}	(Optional) Enables inspection of the Layer 4 UDP valid length: <ul style="list-style-type: none"> udp-valid-length—Specifies the UDP packet lengths that are considered valid and should not be inspected. 	0 to 65535
specify-udp-length-mismatch {yes no}	(Optional) Enables inspection of the Layer 4 UDP length mismatch: <ul style="list-style-type: none"> udp-length-mismatch—Fires an alert when IP Data length is less than the UDP Header length. 	0 to 65535

1. When a packet is GRE, IPIP, IPv4inIPv6, or MPL the sensor skips the Layer 3 encapsulation header and the encapsulation header, and all inspection is done starting from the second Layer 3. The encapsulation enumerator allows the engine to look backward to see if there is an encapsulation header before the Layer 3 in question.
2. Use the following syntax: x.x.x.x-z.z.z.z, for example, 10.10.10.1-10.10.10.254.

For More Information

- For an example custom IPv6 signature, see [Example IPv6 Engine Signature, page 8-51](#).
- For a list of the signature regular expression syntax, see [Regular Expression Syntax, page B-9](#).
- For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Atomic IP Engine

The Atomic IP engine defines signatures that inspect IP protocol headers and associated Layer 4 transport protocols (TCP, UDP, and ICMP) and payloads. The Atomic engines do not store persistent data across packets. Instead they can fire an alert from the analysis of a single packet.

[Table B-9](#) lists the parameters that are specific to the Atomic IP engine.

Table B-9 Atomic IP Engine Parameters

Parameter	Description	Value
specify-ip-addr-options {yes no}	(Optional) Enables IP address options: <ul style="list-style-type: none"> ip-addr-options—Specifies the IP address options. 	address-with-localhost ip-addr ¹ rfc-1918-address src-ip-eq-dst-ip
specify-ip-header-length {yes no}	(Optional) Enables inspection of the IP header length: <ul style="list-style-type: none"> ip-header-length—Specifies the length of the IP header to inspect. 	0 to 16

Table B-9 Atomic IP Engine Parameters (continued)

Parameter	Description	Value
specify-ip-id {yes no}	(Optional) Enables inspection of the IP identifier: <ul style="list-style-type: none"> ip-id—Specifies the IP ID to inspect. 	0 to 255
specify-ip-option-inspection {yes no}	(Optional) Enables inspection of the IP options: <ul style="list-style-type: none"> ip-option-inspection—Specifies the value of the IP option: <ul style="list-style-type: none"> ip-option—Specifies the IP OPTION code to match. ip-option-abnormal—Specifies the list of options is malformed. 	0 to 65535
specify-ip-payload-length {yes no}	(Optional) Enables inspection of the IP payload length: <ul style="list-style-type: none"> ip-payload-length—Specifies the length of IP payload to inspect. 	0 to 65535
specify-ip-tos {yes no}	(Optional) Specifies the IP type of service: <ul style="list-style-type: none"> ip-tos—Specifies the IP type of service to inspect. 	0 to 6 255
specify-ip-total-length {yes no}	(Optional) Enables inspection of the IP total length: <ul style="list-style-type: none"> ip-total-length—Specifies the total length of IP packet to inspect. 	0 to 65535
specify-ip-ttl {yes no}	(Optional) Enables inspection of IP time-to-live: <ul style="list-style-type: none"> ip-ttl—Specifies the value of the IP TTL to inspect. 	0 to 255
specify-ip-version {yes no}	(Optional) Enables inspection of the IP version: <ul style="list-style-type: none"> ip-version—Specifies which IP version to inspect. 	0 to 16
specify-l4-protocol {yes no}	(Optional) Enables inspection of the Layer 4 protocol: <ul style="list-style-type: none"> l4-protocol—Specifies which Layer 4 protocol to inspect. 	icmp tcp udp other-protocol
specify-icmp-code {yes no}	(Optional) Enables inspection of the Layer 4 ICMP code: <ul style="list-style-type: none"> icmp-code—Specifies the value of the ICMP header CODE. 	0 to 65535

Table B-9 Atomic IP Engine Parameters (continued)

Parameter	Description	Value
specify-icmp-id {yes no}	(Optional) Enables inspection of the Layer 4 ICMP ID: <ul style="list-style-type: none"> icmp-id—Specifies the value of the ICMP header IDENTIFIER. 	0 to 65535
specify-icmp-seq {yes no}	(Optional) Enables inspection of the Layer 4 ICMP sequence: <ul style="list-style-type: none"> icmp-seq—Specifies the ICMP sequence to inspect. 	0 to 65535
specify-icmp-type {yes no}	(Optional) Enables inspection of the ICMP header type: <ul style="list-style-type: none"> icmp-type—Specifies the value of the ICMP header TYPE. 	0 to 65535
specify-icmp-total-length {yes no}	(Optional) Enables inspection of the Layer 4 ICMP total header length: <ul style="list-style-type: none"> icmp-total-length—Specifies the value of the ICMP total length to inspect. 	0 to 65535
specify-other-ip-protocol-id {yes no}	(Optional) Enables inspection of the other Layer 4 protocols: <ul style="list-style-type: none"> other-ip-protocol-id—Specifies which single IP protocol ID or single range of IP protocol IDs for which to send alerts. 	0 to 255
specify-dst-port {yes no}	(Optional) Enables the destination port for use: <ul style="list-style-type: none"> dst-port—Specifies the destination port of interest for this signature. 	0 to 65535
specify-src-port {yes no}	(Optional) Enables source port for use: <ul style="list-style-type: none"> src-port—Specifies the source port of interest for this signature. 	0 to 65535
specify-tcp-mask {yes no}	(Optional) Enables the TCP mask for use: <ul style="list-style-type: none"> tcp-mask—Specifies the mask used in TCP flags comparison: <ul style="list-style-type: none"> URG bit ACK bit PSH bit RST bit SYN bit FIN bit 	urg ack psh rst syn fin

Table B-9 Atomic IP Engine Parameters (continued)

Parameter	Description	Value
specify-tcp-flags {yes no}	(Optional) Enables TCP flags for use: <ul style="list-style-type: none"> tcp-flags—Specifies the TCP flags to match when masked by mask: <ul style="list-style-type: none"> URG bit ACK bit PSH bit RST bit SYN bit FIN bit 	urg ack psh rst syn fin
specify-tcp-reserved {yes no}	(Optional) Enables TCP reserved for use: <ul style="list-style-type: none"> tcp-reserved—Specifies the value of TCP reserved. 	0 to 63
specify-tcp-header-length {yes no}	(Optional) Enables inspection of the Layer 4 TCP header length: <ul style="list-style-type: none"> tcp-header-length—Specifies the length of the TCP header used in inspection. 	0 to 60
specify-tcp-payload-length {yes no}	(Optional) Enables inspection of the Layer 4 TCP payload length: <ul style="list-style-type: none"> tcp-payload-length—Specifies the length of the TCP payload. 	0 to 65535
specify-tcp-urg-pointer {yes no}	(Optional) Enables inspection of the L4 TCP URG pointer: <ul style="list-style-type: none"> tcp-urg-pointer—Specifies the value of the TCP URG flag to inspect. 	0 to 65535
specify-tcp-window-size {yes no}	(Optional) Enables inspection of the Layer 4 TCP window size: <ul style="list-style-type: none"> tcp-window-size—Specifies the window size of the TCP packet. 	0 to 65535
specify-udp-length {yes no}	(Optional) Enables inspection of the Layer 4 UDP length: <ul style="list-style-type: none"> udp-length—Fires an alert when the IP Data length is less than the UDP Header length. 	0 to 65535

Table B-9 Atomic IP Engine Parameters (continued)

Parameter	Description	Value
specify-udp-valid-length {yes no}	(Optional) Enables inspection of the Layer 4 UDP valid length: <ul style="list-style-type: none"> udp-valid-length—Specifies UDP packet lengths that are considered valid and should not be inspected. 	0 to 65535
specify-udp-length-mismatch {yes no}	(Optional) Enables inspection of the Layer 4 UDP length mismatch: <ul style="list-style-type: none"> udp-length-mismatch—Fires an alert when the IP Data length is less than the UDP Header length. 	0 to 65535

1. Use the following syntax: x.x.x.x-z.z.z.z, for example, 10.10.10.1-10.10.10.254.

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Atomic IPv6 Engine

The Atomic IPv6 engine detects two IOS vulnerabilities that are stimulated by malformed IPv6 traffic. These vulnerabilities can lead to router crashes and other security issues. One IOS vulnerability deals with multiple first fragments, which cause a buffer overflow. The other one deals with malformed ICMPv6 Neighborhood Discovery options, which also cause a buffer overflow.

**Note**

IPv6 increases the IP address size from 32 bits to 128 bits, which supports more levels of addressing hierarchy, a much greater number of addressable nodes, and autoconfiguration of addresses.

Atomic IPv6 Signatures

There are eight Atomic IPv6 signatures. The Atomic IPv6 inspects Neighborhood Discovery protocol of the following types:

- Type 133—Router Solicitation
- Type 134—Router Advertisement
- Type 135—Neighbor Solicitation
- Type 136—Neighbor Advertisement
- Type 137—Redirect

**Note**

Hosts and routers use Neighborhood Discovery to determine the link-layer addresses for neighbors known to reside on attached links and to quickly purge cached values that become invalid. Hosts also use Neighborhood Discovery to find neighboring routers that will forward packets on their behalf.

Each Neighborhood Discovery type can have one or more Neighborhood Discovery options. The Atomic IPv6 engine inspects the length of each option for compliance with the legal values stated in RFC 2461. Violations of the length of an option results in an alert corresponding to the option type where the malformed length was encountered (signatures 1601 to 1605).

**Note**

The Atomic IPv6 signatures do not have any specific parameters to configure.

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Fixed Engine

The Fixed engines combine multiple regular expression patterns in to a single pattern matching table that allows a single search through the data. It supports ICMP, TCP, and UDP protocols. After a minimum inspection depth is reached (1 to 100 bytes), inspection stops. There are three Fixed engines: Fixed ICMP, Fixed TCP, and Fixed UDP.

**Note**

The Fixed TCP and Fixed UDP engines use the service-ports parameter as exclusion ports. The Fixed ICMP engine uses the service-ports parameter as excluded ICMP types.

[Table B-10](#) lists the parameters specific to the Fixed ICMP engine.

Table B-10 Fixed ICMP Engine Parameters

Parameter	Description	Value
direction	Specifies the direction of traffic: <ul style="list-style-type: none"> Traffic from service port destined to client port. Traffic from client port destined to service port. 	from-service to-service
max-payload-inspect-length	Specifies the maximum inspection depth for the signature.	1 to 250
regex-string	Specifies the regular expression to search for in a single packet.	<i>string</i>
specify-exact-match-offset {yes no}	(Optional) Enables exact match offset: <ul style="list-style-type: none"> exact-match-offset—Specifies the exact stream offset the regex-string must report for a match to be valid. 	0 to 65535
specify-min-match-length {yes no}	(Optional) Enables minimum match length: <ul style="list-style-type: none"> min-match-length—Specifies the minimum number of bytes the regex-string must match. 	0 to 65535

Table B-10 Fixed ICMP Engine Parameters (continued)

Parameter	Description	Value
specify-icmp-type {yes no}	(Optional) Enables inspection of the Layer 4 ICMP header type: <ul style="list-style-type: none"> icmp-type—Specifies the value of the ICMP header TYPE. 	0 to 65535
swap-attacker-victim	Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.	false true (default)

Table B-11 lists the parameters specific to the Fixed TCP engine.

Table B-11 Fixed TCP Engine Parameters

Parameter	Description	Value
direction	Specifies the direction of traffic: <ul style="list-style-type: none"> Traffic from service port destined to client port. Traffic from client port destined to service port. 	from-service to-service
max-payload-inspect-length	Specifies the maximum inspection depth for the signature.	1 to 250
regex-string	Specifies the regular expression to search for in a single packet.	string
specify-exact-match-offset {yes no}	(Optional) Enables exact match offset: <ul style="list-style-type: none"> exact-match-offset—Specifies the exact stream offset the regex-string must report for a match to be valid. 	0 to 65535
specify-min-match-length {yes no}	(Optional) Enables minimum match length: <ul style="list-style-type: none"> min-match-length—Specifies the minimum number of bytes the regex-string must match. 	0 to 65535
exclude-service-ports {yes no}	Enables service ports for use: <ul style="list-style-type: none"> excluded-service-ports—Specifies a comma-separated list of ports or port ranges to exclude. 	0 to 65535 ¹ a-b[,c-d]
swap-attacker-victim	Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.	false true(default)

1. The second number in the range must be greater than or equal to the first number.

Table B-12 lists the parameters specific to the Fixed UDP engine.

Table B-12 Fixed UDP Engine Parameters

Parameter	Description	Value
direction	Specifies the direction of traffic: <ul style="list-style-type: none"> Traffic from service port destined to client port. Traffic from client port destined to service port 	from-service to-service
max-payload-inspect-length	Specifies the maximum inspection depth for the signature.	1 to 250
regex-string	Specifies the regular expression to search for in a single packet.	<i>string</i>
specify-exact-match-offset {yes no}	(Optional) Enables exact match offset: <ul style="list-style-type: none"> exact-match-offset—Specifies the exact stream offset the regex-string must report for a match to be valid. 	0 to 65535
specify-min-match-length {yes no}	(Optional) Enables minimum match length: <ul style="list-style-type: none"> min-match-length—Specifies the minimum number of bytes the regex-string must match. 	0 to 65535
exclude-service-ports {yes no}	Enables service ports for use: <ul style="list-style-type: none"> excluded-service-ports—Specifies a comma-separated list of ports or port ranges to exclude. 	0 to 65535 ¹ a-b[,c-d]
swap-attacker-victim	Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.	false true(default)

1. The second number in the range must be greater than or equal to the first number.

For More Information

- For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).
- For a list of the signature regular expression syntax, see [Regular Expression Syntax, page B-9](#).

Flood Engine

The Flood engines define signatures that watch for any host or network sending multiple packets to a single host or network. For example, you can create a signature that fires when 150 or more packets per second (of the specific type) are found going to the victim host. There are two Flood engines: Flood Host and Flood Net.

Table B-13 lists the parameters specific to the Flood Host engine.

Table B-13 Flood Host Engine Parameters

Parameter	Description	Value
protocol	Specifies which kind of traffic to inspect.	ICMP UDP
rate	Specifies the threshold number of packets per second.	0 to 65535 ¹
icmp-type	Specifies the value for the ICMP header type.	0 to 65535
dst-ports	Specifies the destination ports when you choose UDP protocol.	0 to 65535 ² a-b[,c-d]
src-ports	Specifies the source ports when you choose UDP protocol.	0 to 65535 ² a-b[,c-d]

1. An alert fires when the rate is greater than the packets per second.
2. The second number in the range must be greater than or equal to the first number.

Table B-14 lists the parameters specific to the Flood Net engine.

Table B-14 Flood Net Engine Parameters

Parameter	Description	Value
gap	Specifies the gap of time allowed (in seconds) for a flood signature.	0 to 65535
peaks	Specifies the number of allowed peaks of flood traffic.	0 to 65535
protocol	Specifies which kind of traffic to inspect.	ICMP TCP UDP
rate	Specifies the threshold number of packets per second.	0 to 65535 ¹
sampling-interval	Specifies the interval used for sampling traffic.	1 to 3600
icmp-type	Specifies the value for the ICMP header type.	0 to 65535

1. An alert fires when the rate is greater than the packets per second.

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Meta Engine



Caution

A large number of Meta engine signatures could adversely affect overall sensor performance.

The Meta engine defines events that occur in a related manner within a sliding time interval. This engine processes events rather than packets. As signature events are generated, the Meta engine inspects them to determine if they match any or several Meta definitions. The Meta engine generates a signature event after all requirements for the event are met.

All signature events are handed off to the Meta engine by the Signature Event Action Processor. The Signature Event Action Processor hands off the event after processing the minimum hits option. Summarization and event action are processed after the Meta engine has processed the component events.

Component Signatures and the Meta Engine

Component signatures are not independent signatures, they are pieces of a Meta signature. The **sig-type** option is marked as **component**. Since these signatures are not independent signatures, the risk rating when triggered is automatically set to 0. The risk rating is applicable to the Meta signature rather than the component signatures. This prevents the component signatures from causing denial of packets by either event action overrides or global correlation. Event action overrides and global correlation are applied against the Meta signature rather than the component signature.



Note

Some component signatures in the Meta signatures are valuable as both independent signatures and component signatures. These signatures are not marked as **sig-type component** and instead are marked with the **sig-type** set to either **vulnerability**, **exploit**, **anomaly**, or **other**. The risk rating for these signatures is calculated and is not set to 0.

Meta Signature Engine Enhancement

The purpose of the Meta engine is to detect a specified payload from an attacker and a corresponding payload from the victim. It is also used to inspect streams at different offsets. The Meta engine supports the AND and OR logical operators. ANDNOT capability has been added to the Meta engine. This clause is a negative clause used to complement the existing positive clause-based signatures. The previous signature format had the following form:

IF (A and B and C) then Alarm; alternatively, IF (A or B or C) then Alarm is also supported; where A, B, and C are meta component signatures.

The addition of the negative clause allows for the following logic:

IF (A and/or B) AND NOT (C and/or D) then Alarm.

The (C and/or D) is the negative clause and is satisfied if (C and D) [alternatively (C or D)] do not occur before the Meta Reset Interval time expires.

A component of the positive clause must occur before the negative clause(s) to establish the Meta tracking state. The Meta engine cannot track the lack of past behavior. The state of the negative clause is evaluated when the Meta Reset Interval time expires.

Table B-15 lists the parameters specific to the Meta engine.

Table B-15 Meta Engine Parameters

Parameter	Description	Value
component-list	Specifies the Meta engine component: <ul style="list-style-type: none">• edit—Edits an existing entry.• insert—Inserts a new entry into the list:<ul style="list-style-type: none">– begin—Places the entry at the beginning of the active list.– end—Places the entry at the end of the active list.– inactive—Places the entry into the inactive list.– before—Places the entry before the specified entry.– after—Places the entry after the specified entry.• move—Moves an entry in the list.• component-count—Specifies the number of times component must fire before this component is satisfied• component-sig-id—Specifies the signature ID of the signature to match this component on.• component-subsig-id—Specifies the subsignature ID of the signature to match this component on.• is-not-component—Specifies that the component is a NOT component.	<i>name1</i> true false
component-list-in-order	Specifies to fire the component list in order.	true false
all-components-required	Specifies to use all components.	true false
all-not-components-required	Specifies to use all of the NOT components.	true false
swap-attacker-victim	Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.	true false (default)
meta-reset-interval	Specifies the time in seconds to reset the Meta signature.	0 to 3600
meta-key	Specifies the storage type for the Meta signature: <ul style="list-style-type: none">• Attacker address• Attacker and victim addresses• Attacker and victim addresses and ports• Victim address	<ul style="list-style-type: none">• Axxx• AxBx• AaBb• xxBx
unique-victim-ports	Specifies the number of unique victims ports required per Meta signature.	1 to 256

For More Information

- For an example of a custom Meta engine signature, see [Example Meta Engine Signature](#), page 8-47.
- For more information on the parameters common to all signature engines, see [Master Engine](#), page B-4.
- For more information on Signature Event Action Processor, see [Signature Event Action Processor](#), page 7-3.

Multi String Engine

**Caution**

The Multi String engine can have a significant impact on memory usage.

The Multi String engine lets you define signatures that inspect Layer 4 transport protocol (ICMP, TCP, and UDP) payloads using multiple string matches for one signature. You can specify a series of regular expression patterns that must be matched to fire the signature. For example, you can define a signature that looks for regex 1 followed by regex 2 on a UDP service. For UDP and TCP you can specify port numbers and direction. You can specify a single source port, a single destination port, or both ports. The string matching takes place in both directions.

Use the Multi String engine when you need to specify more than one Regex pattern. Otherwise, you can use the String ICMP, String TCP, or String UDP engine to specify a single Regex pattern for one of those protocols.

[Table B-16](#) lists the parameters specific to the Multi String Engine.

Table B-16 **Multi String Engine Parameters**

Parameter	Description	Value
inspect-length	Specifies the length of the stream or packet that must contain all offending strings for the signature to fire.	0 to 4294967295
protocol	Specifies the Layer 4 protocol selection.	icmp tcp udp
regex-component	Specifies the list of Regex components: <ul style="list-style-type: none"> • regex-string—Specifies the string to search for. • spacing-type—Specifies the type of spacing required from the match before or from the beginning of the stream/packet if it is the first entry in the list. 	list (1 to 16 items) exact minimum

Table B-16 Multi String Engine Parameters (continued)

Parameter	Description	Value
port-selection	Specifies the type of TCP or UDP port to inspect: <ul style="list-style-type: none"> both-ports—Specifies both source and destination port. dest-ports—Specifies a range of destination ports. source-ports—Specifies a range of source ports.¹ 	0 to 65535 ²
exact-spacing	Specifies the exact number of bytes that must be between this Regex string and the one before, or from the beginning of the stream/packet if it is the first entry in the list.	0 to 4294967296
min-spacing	Specifies the minimum number of bytes that must be between this Regex string and the one before, or from the beginning of the stream/packet if it is the first entry in the list.	0 to 4294967296
swap-attacker-victim	Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.	true false (default)

1. Port matching is performed bidirectionally for both the client-to-server and server-to-client traffic flow directions. For example, if the source-ports value is 80, in a client-to-server traffic flow direction, inspection occurs if the client port is 80. In a server-to-client traffic flow direction, inspection occurs if the server port is port 80.
2. A valid value is a comma-separated list of integer ranges a-b[,c-d] within 0 to 65535. The second number in the range must be greater than or equal to the first number.

For More Information

- For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).
- For a list of the signature regular expression syntax, see [Regular Expression Syntax, page B-9](#).

Normalizer Engine

**Note**

You cannot add custom signatures to the Normalizer engine. You can tune the existing ones.

The Normalizer engine deals with IP fragment reassembly and TCP stream reassembly. With the Normalizer engine you can set limits on system resource usage, for example, the maximum number of fragments the sensor tries to track at the same time. Sensors in promiscuous mode report alerts on violations. Sensors in inline mode perform the action specified in the event action parameter, such as produce-alert, deny-packet-inline, and modify-packet-inline.



Caution

For signature 3050 Half Open SYN Attack, if you choose modify-packet-inline as the action, you can see as much as 20 to 30% performance degradation while the protection is active. The protection is only active during an actual SYN flood.

IP Fragmentation Normalization

Intentional or unintentional fragmentation of IP datagrams can hide exploits making them difficult or impossible to detect. Fragmentation can also be used to circumvent access control policies like those found on firewalls and routers. And different operating systems use different methods to queue and dispatch fragmented datagrams. If the sensor has to check for all possible ways that the end host can reassemble the datagrams, the sensor becomes vulnerable to DoS attacks. Reassembling all fragmented datagrams inline and only forwarding completed datagrams and refragmenting the datagram if necessary, prevents this. The IP Fragmentation Normalization unit performs this function.

TCP Normalization

Through intentional or natural TCP session segmentation, some classes of attacks can be hidden. To make sure policy enforcement can occur with no false positives and false negatives, the state of the two TCP endpoints must be tracked and only the data that is actually processed by the real host endpoints should be passed on. Overlaps in a TCP stream can occur, but are extremely rare except for TCP segment retransmits. Overwrites in the TCP session should not occur. If overwrites do occur, someone is intentionally trying to elude the security policy or the TCP stack implementation is broken. Maintaining full information about the state of both endpoints is not possible unless the sensor acts as a TCP proxy. Instead of the sensor acting as a TCP proxy, the segments are ordered properly and the Normalizer engine looks for any abnormal packets associated with evasion and attacks.

IPv6 Fragments

The Normalizer engine can reassemble IPv6 fragments and forward the reassembled buffer for inspection and actions by other engines and processors. The following differences exist between IPv4 and IPv6:

- modify-packet-inline for Normalizer engine signatures has no effect on IPv6 datagrams.
- Signature 1206 (IP Fragment Too Small) does not fire for IPv6 datagrams. Signature 1741 in the Atomic IP Advanced engine fires for IPv6 fragments that are too small.
- Signature 1202 allows 48 additional bytes beyond the max-datagram-size for IPv6 because of the longer IPv6 header fields.

TCP Normalizer Signature Warning

You receive the following warning if you disable a default-enabled TCP Normalizer signature or remove a default-enabled modify packet inline, deny packet inline, or deny connection inline action:

Use caution when disabling, retiring, or changing the event action settings of a <Sig ID> TCP Normalizer signature for a sensor operating in IPS mode. The TCP Normalizer signature default values are essential for proper operation of the sensor.

If the sensor is seeing duplicate packets, consider assigning the traffic to multiple virtual sensors. If you are having problems with asymmetric or out-of-order TCP packets, consider changing the normalizer mode from strict evasion protection to asymmetric mode protection. Contact Cisco TAC if you require further assistance.

ASA IPS Modules and the Normalizer Engine

The majority of the features in the Normalizer engine are not used on the ASA 5500 AIP SSM, ASA 5500-X IPS SSP, or ASA 5585-X IPS SSP, because the ASA itself handles the normalization. Packets on the ASA IPS modules go through a special path in the Normalizer that only reassembles

fragments and puts packets in the right order for the TCP stream. The Normalizer does not do any of the normalization that is done on an inline IPS appliance, because that causes problems in the way the ASA handles the packets.

The following Normalizer engine signatures are not supported:

- 1300.0
- 1304.0
- 1305.0
- 1307.0
- 1308.0
- 1309.0
- 1311.0
- 1315.0
- 1316.0
- 1317.0
- 1330.0
- 1330.1
- 1330.2
- 1330.9
- 1330.10
- 1330.12
- 1330.14
- 1330.15
- 1330.16
- 1330.17
- 1330.18

[Table B-17](#) lists the parameters that are specific to the Normalizer engine.

Table B-17 **Normalizer Engine Parameters**

Parameter	Description
edit-default-sigs-only	Editable signatures.
specify-fragment-reassembly-timeout	(Optional) Enables fragment reassembly timeout.
specify-hijack-max-old-ack	(Optional) Enables hijack-max-old-ack.
specify-max-dgram-size	(Optional) Enables maximum datagram size.
specify-max-fragments	(Optional) Enables maximum fragments: <ul style="list-style-type: none"> • max-fragments—Lets you specify the number of maximum fragments.
specify-max-fragments-per-dgram	(Optional) Enables maximum fragments per datagram.
specify-max-last-fragments	(Optional) Enables maximum last fragments.
specify-max-partial-dgrams	(Optional) Enables maximum partial datagrams.

Table B-17 **Normalizer Engine Parameters (continued)**

Parameter	Description
specify-max-small-fragss	(Optional) Enables maximum small fragments.
specify-min-fragment-size	(Optional) Enables minimum fragment size.
specify-service-ports	(Optional) Enables service ports.
specify-syn-flood-max-embryonic	(Optional) Enables SYN flood maximum embryonic.
specify-tcp-closed-timeout	(Optional) Enables TCP closed timeout.
specify-tcp-embryonic-timeout	(Optional) Enables TCP embryonic timeout.
specify-tcp-idle-timeout	(Optional) Enables TCP idle timeout: <ul style="list-style-type: none"> tcp-idle-timeout—Lets you specify the TCP idle timeout time.
specify-tcp-max-mss	(Optional) Enables TCP maximum mss.
specify-tcp-max-queue	(Optional) Enables TCP maximum queue.
specify-tcp-min-mss	(Optional) Enables TCP minimum mss.
specify-tcp-option-number	(Optional) Enables TCP option number.

For More Information

- For the procedure for configuring IP fragment reassembly signatures in the Normalizer engine, see [Configuring IP Fragment Reassembly, page 8-28](#).
- For the procedure for configuring TCP stream reassembly signatures in the Normalizer engine, see [Configuring TCP Stream Reassembly, page 8-31](#).
- For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Service Engines

This section describes the Service engines, and contains the following topics:

- [Understanding the Service Engines, page B-41](#)
- [Service DNS Engine, page B-41](#)
- [Service FTP Engine, page B-42](#)
- [Service Generic Engine, page B-43](#)
- [Service H225 Engine, page B-45](#)
- [Service HTTP Engine, page B-47](#)
- [Service IDENT Engine, page B-49](#)
- [Service MSRPC Engine, page B-50](#)
- [Service MSSQL Engine, page B-52](#)
- [Service NTP Engine, page B-53](#)
- [Service P2P Engine, page B-54](#)
- [Service RPC Engine, page B-54](#)

- [Service SMB Advanced Engine, page B-56](#)
- [Service SNMP Engine, page B-58](#)
- [Service SSH Engine, page B-59](#)
- [Service TNS Engine, page B-60](#)

Understanding the Service Engines

The Service engines analyze Layer 5+ traffic between two hosts. These are one-to-one signatures that track persistent data. The engines analyze the Layer 5+ payload in a manner similar to the live service.

The Service engines have common characteristics but each engine has specific knowledge of the service that it is inspecting. The Service engines supplement the capabilities of the generic string engine specializing in algorithms where using the string engine is inadequate or undesirable.

Service DNS Engine

The Service DNS engine specializes in advanced DNS decode, which includes anti-evasive techniques, such as following multiple jumps. It has many parameters, such as lengths, opcodes, strings, and so forth. The Service DNS engine is a biprotocol inspector operating on both TCP and UDP port 53. It uses the stream for TCP and the quad for UDP.

[Table B-18](#) lists the parameters specific to the Service DNS engine.

Table B-18 **Service DNS Engine Parameters**

Parameter	Description	Value
protocol	Specifies the protocol of interest for this inspector.	tcp udp
specify-query-chaos-string {yes no}	(Optional) Enables the DNS Query Class Chaos String: <ul style="list-style-type: none"> query-chaos-string—Specifies the query chaos string to search on. 	<i>query-chaos-string</i>
specify-query-class {yes no}	(Optional) Enables the query class: <ul style="list-style-type: none"> query-class—Specifies the DNS Query Class 2 Byte Value. 	0 to 65535
specify-query-invalid-domain-name {yes no}	(Optional) Enables the query invalid domain name: <ul style="list-style-type: none"> query-invalid-domain-name—Specifies the DNS Query Length greater than 255. 	no yes
specify-query-jump-count-exceeded {yes no}	(Optional) Enables query jump count exceeded: <ul style="list-style-type: none"> query-jump-count-exceeded—DNS compression counter. 	no yes

Table B-18 **Service DNS Engine Parameters (continued)**

Parameter	Description	Value
specify-query-opcode {yes no}	(Optional) Enables query opcode: <ul style="list-style-type: none"> query-opcode—Specifies the DNS Query Opcode 1 byte Value. 	0 to 65535
specify-query-record-data-invalid {yes no}	(Optional) Enables query record data invalid: <ul style="list-style-type: none"> query-record-data-invalid—Specifies the DNS Record Data incomplete. 	no yes
specify-query-record-data-len {yes no}	(Optional) Enables the query record data length: <ul style="list-style-type: none"> query-record-data-len—Specifies the DNS Response Record Data Length. 	0 to 65535
specify-query-src-port-53 {yes no}	(Optional) Enables the query source port 53: <ul style="list-style-type: none"> query-src-port-53—Specifies the DNS packet source port 53. 	no yes
specify-query-stream-len {yes no}	(Optional) Enables the query stream length: <ul style="list-style-type: none"> query-stream-len—Specifies the DNS Packet Length. 	0 to 65535
specify-query-type {yes no}	(Optional) Enables the query type: <ul style="list-style-type: none"> query-type—Specifies the DNS Query Type 2 Byte Value. 	0 to 65535
specify-query-value {yes no}	(Optional) Enables the query value: <ul style="list-style-type: none"> query-value—Specifies the Query 0 Response 1. 	no yes

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Service FTP Engine

The Service FTP engine specializes in FTP port command decode, trapping invalid **port** commands and the PASV port spoof. It fills in the gaps when the String engine is not appropriate for detection. The parameters are Boolean and map to the various error trap conditions in the **port** command decode. The Service FTP engine runs on TCP ports 20 and 21. Port 20 is for data and the Service FTP engine does not do any inspection on this. It inspects the control transactions on port 21.

Table B-19 lists the parameters that are specific to the Service FTP engine.

Table B-19 Service FTP Engine Parameters

Parameter	Description	Value
direction	Specifies the direction of traffic: <ul style="list-style-type: none"> Traffic from service port destined to client port. Traffic from client port destined to service port. 	from-service to-service
ftp-inspection-type	Specifies the type of inspection to perform: <ul style="list-style-type: none"> Looks for an invalid address in the FTP port command. Looks for an invalid port in the FTP port command. Looks for the PASV port spoof. 	bad-port-cmd-address bad-port-cmd-port pasv
service-ports	Specifies a comma-separated list of ports or port ranges where the target service resides.	0 to 65535 ¹ a-b[,c-d]
swap-attacker-victim	Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.	true false (default)

1. The second number in the range must be greater than or equal to the first number.

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Service Generic Engine

The Service Generic engine allows programmatic signatures to be issued in a config-file-only signature update. It has a simple machine and assembly language that is defined in the configuration file. It runs the machine code (distilled from the assembly language) through its virtual machine, which processes the instructions and pulls the important pieces of information out of the packet and runs them through the comparisons and operations specified in the machine code. It is intended as a rapid signature response engine to supplement the String and State engines.

New functionality adds the Regex parameter to the Service Generic engine and enhanced instructions. The Service Generic engine can analyze traffic based on the mini-programs that are written to parse the packets. These mini-programs are composed of commands, which dissect the packet and look for certain conditions.



Note

You cannot use the Service Generic engine to create custom signatures.



Caution

Due to the proprietary nature of this complex language, we do not recommend that you edit the Service Generic engine signature parameters other than severity and event action.

Table B-20 lists the parameters specific to the Service Generic engine.

Table B-20 Service Generic Engine Parameters

Parameter	Description	Value
specify-dst-port {yes no}	(Optional) Enables the destination port: <ul style="list-style-type: none"> dst-port—Specifies the destination port of interest for this signature. 	0 to 65535
specify-ip-protocol {yes no}	(Optional) Enables IP protocol: <ul style="list-style-type: none"> ip-protocol—Specifies the IP protocol this inspector should examine. 	0 to 255
specify-payload-source {yes no}	(Optional) Enables payload source inspection: <ul style="list-style-type: none"> payload-source—Specifies the payload source inspection for the following types: <ul style="list-style-type: none"> Inspects ICMP data Inspects Layer 2 headers Inspects Layer 3 headers Inspects Layer 4 headers Inspects TCP data Inspects UDP data 	icmp-data l2-header l3-header l4-header tcp-data udp-data
specify-src-port {yes no}	(Optional) Enables the source port: <ul style="list-style-type: none"> src-port—Specifies the source port of interest for this signature. 	0 to 65535
specify-regex-string {yes no}	Specifies the regular expression to look for when the policy type is Regex: <ul style="list-style-type: none"> regex-string—Specifies a regular expression to search for in a single TCP packet. (Optional) specify-min-match-length—Enables minimum match length for use: <ul style="list-style-type: none"> min-match-length—Specifies the minimum length of the Regex match required to constitute a match. 	string 0 to 65535
swap-attacker-victim	Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.	true false (default)

For More Information

- For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).
- For a list of the signature regular expression syntax, see [Regular Expression Syntax, page B-9](#).

Service H225 Engine

The Service H225 engine analyzes H225.0 protocol, which consists of many subprotocols and is part of the H.323 suite. H.323 is a collection of protocols and other standards that together enable conferencing over packet-based networks.

H.225.0 call signaling and status messages are part of the H.323 call setup. Various H.323 entities in a network, such as the gatekeeper and endpoint terminals, run implementations of the H.225.0 protocol stack. The Service H225 engine analyzes H225.0 protocol for attacks on multiple H.323 gatekeepers, VoIP gateways, and endpoint terminals. It provides deep packet inspection for call signaling messages that are exchanged over TCP PDUs. The Service H225 engine analyzes the H.225.0 protocol for invalid H.255.0 messages, and misuse and overflow attacks on various protocol fields in these messages.

H.225.0 call signaling messages are based on Q.931 protocol. The calling endpoint sends a Q.931 setup message to the endpoint that it wants to call, the address of which it procures from the admissions procedure or some lookup means. The called endpoint either accepts the connection by transmitting a Q.931 connect message or rejects the connection. When the H.225.0 connection is established, either the caller or the called endpoint provides an H.245 address, which is used to establish the control protocol (H.245) channel.

Especially important is the SETUP call signaling message because this is the first message exchanged between H.323 entities as part of the call setup. The SETUP message uses many of the commonly found fields in the call signaling messages, and implementations that are exposed to probable attacks will mostly also fail the security checks for the SETUP messages. Therefore, it is highly important to check the H.225.0 SETUP message for validity and enforce checks on the perimeter of the network.

The Service H225 engine has built-in signatures for TPKT validation, Q.931 protocol validation, and ASN.1PER validations for the H225 SETUP message. ASN.1 is a notation for describing data structures. PER uses a different style of encoding. It specializes the encoding based on the data type to generate much more compact representations.

You can tune the Q.931 and TPKT length signatures and you can add and apply granular signatures on specific H.225 protocol fields and apply multiple pattern search signatures of a single field in Q.931 or H.225 protocol.

The Service H225 engine supports the following features:

- TPKT validation and length check
- Q.931 information element validation
- Regular expression signatures on text fields in Q.931 information elements
- Length checking on Q.931 information elements
- SETUP message validation
- ASN.1 PER encode error checks
- Configuration signatures for fields like ULR-ID, E-mail-ID, h323-id, and so forth for both regular expression and length.

There is a fixed number of TPKT and ASN.1 signatures. You cannot create custom signatures for these types. For TPKT signatures, you should only change the value-range for length signatures. You should not change any parameters for ASN.1. For Q.931 signatures, you can add new regular expression signatures for text fields. For SETUP signatures, you can add signatures for length and regular expression checks on various SETUP message fields.

Table B-21 lists parameters specific to the Service H225 engine.

Table B-21 **Service H.225 Engine Parameters**

Parameter	Description	Value
message-type	Specifies the type of H225 message to which the signature applies: <ul style="list-style-type: none"> • SETUP • ASN.1-PER • Q.931 • TPKT 	asn.1-per q.931 setup tpkt
policy-type	Specifies the type of H225 policy to which the signature applies: <ul style="list-style-type: none"> • Inspects field length. • Inspects presence. If certain fields are present in the message, an alert is sent. • Inspects regular expressions. • Inspects field validations. • Inspects values. Note Regex and presence are not valid for TPKT signatures.	length presence regex validate value
specify-field-name {yes no}	(Optional) Enables field name for use. Gives a dotted representation of the field name to which this signature applies. <ul style="list-style-type: none"> • field-name—Specifies the field name to inspect. Note Only valid for SETUP and Q.931 message types.	1 to 512
specify-invalid-packet-index {yes no}	(Optional) Enables invalid packet index for use for specific errors in ASN, TPKT, and other errors that have fixed mapping. <ul style="list-style-type: none"> • invalid-packet-index—Specifies the inspection for invalid packet index. 	0 to 255

Table B-21 Service H.225 Engine Parameters (continued)

Parameter	Description	Value
specify-regex-string {yes no}	<p>Specifies the regular expression to look for when the policy type is Regex:</p> <ul style="list-style-type: none"> regex-string—Specifies a regular expression to search for in a single TCP packet. (Optional) specify-min-match-length—Enables minimum match length for use: <ul style="list-style-type: none"> min-match-length—Specifies the minimum length of the Regex match required to constitute a match. <p>Note This is never set for TPKT signatures.</p>	<p>string</p> <p>0 to 65535</p>
specify-value-range {yes no}	<p>Enables value range for use:</p> <ul style="list-style-type: none"> value-range—Specifies the range of values. <p>Note Valid for the length or value policy types (0x00 to 6535). Not valid for other policy types.</p>	<p>0 to 65535¹</p> <p>a-b</p>
swap-attacker-victim	Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.	true false (default)

1. The second number in the range must be greater than or equal to the first number.

For More Information

- For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).
- For a list of the signature regular expression syntax, see [Regular Expression Syntax, page B-9](#).

Service HTTP Engine

The Service HTTP engine is a service-specific string-based pattern-matching inspection engine. The HTTP protocol is one of the most commonly used in networks of today. In addition, it requires the most amount of preprocessing time and has the most number of signatures requiring inspection making it critical to the overall performance of the system.

The Service HTTP engine uses a Regex library that can combine multiple patterns into a single pattern-matching table allowing a single search through the data. This engine searches traffic directed only to web services, or HTTP requests. You cannot inspect return traffic with this engine. You can specify separate web ports of interest in each signature in this engine.

HTTP deobfuscation is the process of decoding an HTTP message by normalizing encoded characters to ASCII equivalent characters. It is also known as ASCII normalization.

Before an HTTP packet can be inspected, the data must be deobfuscated or normalized to the same representation that the target system sees when it processes the data. It is ideal to have a customized decoding technique for each host target type, which involves knowing what operating system and web server version is running on the target. The Service HTTP engine has default deobfuscation behavior for the Microsoft IIS web server.

Table B-22 lists the parameters specific the Service HTTP engine.

Table B-22 *Service HTTP Engine Parameters*

Parameter	Description	Value
de-obfuscate	Applies anti-evasive deobfuscation before searching.	true false
max-field-sizes	Enables maximum field sizes grouping.	—
specify-max-arg-field-length {yes no}	(Optional) Enables maximum argument field length: <ul style="list-style-type: none"> max-arg-field-length—Specifies the maximum length of the arguments field. 	0 to 65535
specify-max-header-field-length {yes no}	(Optional) Enables maximum header field length: <ul style="list-style-type: none"> max-header-field-length—Specifies the maximum length of the header field. 	0 to 65535
specify-max-request-length {yes no}	(Optional) Enables maximum request field length: <ul style="list-style-type: none"> max-request-length—Specifies the maximum length of the request field. 	0 to 65535
specify-max-uri-field-length {yes no}	(Optional) Enables the maximum URI field length: <ul style="list-style-type: none"> max-uri-field-length—Specifies the maximum length of the URI field. 	0 to 65535
regex	Enables regular expression grouping.	—
specify-arg-name-regex {yes no}	(Optional) Enables searching the Arguments field for a specific regular expression: <ul style="list-style-type: none"> arg-name-regex—Specifies the regular expression to search for in the HTTP Arguments field (after the ? and in the Entity body as defined by Content-Length). 	—
specify-header-regex {yes no}	(Optional) Enables searching the Header field for a specific regular expression: <ul style="list-style-type: none"> header-regex—Specifies the regular expression to search in the HTTP Header field. <p>Note The Header is defined after the first CRLF and continues until CRLF CRLF.</p>	—

Table B-22 Service HTTP Engine Parameters (continued)

Table B-23 lists the parameters specific to the Service IDENT engine.

Table B-23 Service IDENT Engine Parameters

Parameter	Description	Value
inspection-type	Specifies the type of inspection to perform.	has-newline has-bad-port size
has-newline	Inspects payload for a nonterminating new line character.	—
has-bad-port	Inspects payload for a bad port.	—
size	Inspects for payload length longer than this: <ul style="list-style-type: none"> max-bytes—Specifies the maximum bytes for the payload length. 	0 to 65535
service-ports	Specifies a comma-separated list of ports or port ranges where the target service resides.	0 to 65535 ¹ a-b[,c-d]
direction	Specifies the direction of the traffic: <ul style="list-style-type: none"> Traffic from service port destined to client port. Traffic from client port destined to service port. 	from-service to-service

1. The second number in the range must be greater than or equal to the first number.

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Service MSRPC Engine

The Service MSRPC engine processes MSRPC packets. MSRPC allows for cooperative processing between multiple computers and their application software in a networked environment. It is a transaction-based protocol, implying that there is a sequence of communications that establishes the channel and passes processing requests and replies.

MSRPC is an ISO Layer 5-6 protocol and is layered on top of other transport protocols such as UDP, TCP, and SMB. The MSRPC engine contains facilities to allow for fragmentation and reassembly of the MSRPC PDUs.

This communication channel is the source of recent Windows NT, Windows 2000, and Window XP security vulnerabilities. The Service MSRPC engine only decodes the DCE and RPC protocol for the most common transaction types.

Table B-24 lists the parameters specific to the Service MSRPC engine.

Table B-24 Service MSRPC Engine Parameters

Parameter	Description	Value
protocol	Enables the protocol of interest for this inspector: <ul style="list-style-type: none"> type—Specifies UDP or TCP. 	tcp udp
specify-flags {yes no}	Enables the flags to set: <ul style="list-style-type: none"> msrpc-flags—Specifies MSRPC TCP flags. msrpc-tcp-flags-mask—Specifies the MSRPC TCP flags mask. 	concurrent-execution did-not-execute first-fragment last-fragment maybe-semantics object-uuid reserved
specify-operation {yes no}	(Optional) Enables using MSRPC operation: <ul style="list-style-type: none"> operation—Specifies the MSRPC operation requested. <p>Note Required for SMB_COM_TRANSACTION commands. Exact match.</p>	0 to 65535
swap-attacker-victim	Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.	true false (default)

Table B-24 Service MSRPC Engine Parameters (continued)

Parameter	Description	Value
specify-regex-string {yes no}	(Optional) Enables using a regular expression string: <ul style="list-style-type: none"> specify-exact-match-offset—Enables the exact match offset: <ul style="list-style-type: none"> exact-match-offset—Specifies the exact stream offset the regular expression string must report for a match to be valid. specify-min-match-length—Enables the minimum match length: <ul style="list-style-type: none"> min-match-length—Specifies the minimum number of bytes the regular expression string must match. specify-min-match-offset—Enables the minimum match length: <ul style="list-style-type: none"> min-match-offset—Specifies the minimum stream offset the regular expression string must report for a match to be valid. specify-max-match-offset—Enables the maximum match offset: <ul style="list-style-type: none"> max-match-offset—Specifies the maximum stream offset the regular expression string must report for a match to be valid. 	0 to 65535
specify-uuid {yes no}	(Optional) Enables UUID: <ul style="list-style-type: none"> uuid—Specifies the MSRPC UUID field. 	000001a000000000c0000000000046

For More Information

- For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).
- For a list of the signature regular expression syntax, see [Regular Expression Syntax, page B-9](#).

Service MSSQL Engine

The Service MSSQL engine inspects the protocol used by the Microsoft SQL server. There is one MSSQL signature. It fires an alert when it detects an attempt to log in to an MSSQL server with the default sa account. You can add custom signatures based on MSSQL protocol values, such as login username and whether a password was used.

Table B-25 lists the parameters specific to the Service MSSQL engine.

Table B-25 Service MSSQL Engine Parameters

Parameter	Description	Value
password-present	Specifies whether or not a password was used in an MS SQL login.	true false
specify-sql-username	(Optional) Enables using an SQL username: <ul style="list-style-type: none"> sql-username—Specifies the username (exact match) of user logging in to MS SQL service. 	sa

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Service NTP Engine

The Service NTP engine inspects NTP protocol. There is one NTP signature, the NTP readvar overflow signature, which fires an alert if a readvar command is seen with NTP data that is too large for the NTP service to capture. You can tune this signature and create custom signatures based on NTP protocol values, such as mode and size of control packets.

Table B-26 lists the parameters specific to the Service NTP engine.

Table B-26 Service NTP Engine Parameters

Parameter	Description	Value
inspection-type	Specifies the type of inspection to perform.	inspect-ntp-packets is-invalid-data-packet is-non-ntp-traffic
inspect-ntp-packets	Enables inspection of NTP packets: <ul style="list-style-type: none"> control-opcode—Specifies the opcode number of an NTP control packet according to RFC1305, Appendix B. max-control-data-size—Specifies the maximum allowed amount of data sent in a control packet. mode—Specifies the mode of operation of the NTP packet per RFC 1305. 	0 to 65535
is-invalid-data-packet	Enables inspection of invalid NTP data packets and checks the structure of the NTP data packet to make sure it is the correct size.	—
is-non-ntp-traffic	Enables the inspection of nonNTP packets on an NTP port.	—

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Service P2P Engine

P2P networks use nodes that can simultaneously function as both client and server for the purpose of file sharing. P2P networks often contain copyrighted material and their use on a corporate network can violate company policy. The Service P2P engine monitors such networks and provides optimized TCP and UDP P2P protocol identification. The Service P2P engine has the following characteristics:

- Listens on all TCP and UDP ports.
- Increased performance through the use of hard-coded signatures rather than regular expressions.
- Ignores traffic once P2P protocol is identified or after seeing 10 packets without a P2P protocol being identified.

**Note**

Because the P2P signatures are hard coded, the only parameters that you can edit are the Master engine parameters.

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Service RPC Engine

The Service RPC engine specializes in RPC protocol and has full decode as an anti-evasive strategy. It can handle fragmented messages (one message in several packets) and batch messages (several messages in a single packet).

The RPC portmapper operates on port 111. Regular RPC messages can be on any port greater than 550. RPC sweeps are like TCP port sweeps, except that they only count unique ports when a valid RPC message is sent. RPC also runs on UDP.

[Table B-27](#) lists the parameters specific to the Service RPC engine.

Table B-27 *Service RPC Engine Parameters*

Parameter	Description	Value
direction	Specifies the direction of traffic: <ul style="list-style-type: none"> • Traffic from service port destined to client port. • Traffic from client port destined to service port. 	from-service to-service
protocol	Specifies the protocol of interest.	tcp udp
service-ports	Specifies a comma-separated list of ports or port ranges where the target service resides.	0 to 65535 ¹ a-b[,c-d]

Table B-27 Service RPC Engine Parameters (continued)

Parameter	Description	Value
specify-regex-string {yes no}	(Optional) Enables using a regular expression string: <ul style="list-style-type: none"> specify-exact-match-offset—Enables the exact match offset: <ul style="list-style-type: none"> exact-match-offset—Specifies the exact stream offset the regular expression string must report for a match to be valid. specify-min-match-length—Enables the minimum match length: <ul style="list-style-type: none"> min-match-length—Specifies the minimum number of bytes the regular expression string must match. 	0 to 65535
specify-is-spoof-src {yes no}	(Optional) Enables the spoof source address: <ul style="list-style-type: none"> is-spoof-src—Fires an alert when the source address is 127.0.0.1. 	true false
specify-port-map-program {yes no}	(Optional) Enables the portmapper program: <ul style="list-style-type: none"> port-map-program—Specifies the program number sent to the portmapper for this signature. 	0 to 999999999
specify-rpc-max-length {yes no}	(Optional) Enables RPC maximum length: <ul style="list-style-type: none"> rpc-max-length—Specifies the maximum allowed length of the entire RPC message. <p>Note Lengths longer than what you specify fire an alert.</p>	0 to 65535
specify-rpc-procedure {yes no}	(Optional) Enables RPC procedure: <ul style="list-style-type: none"> rpc-procedure—Specifies the RPC procedure number for this signature. 	0 to 1000000
specify-rpc-program {yes no}	(Optional) Enables RPC program: <ul style="list-style-type: none"> rpc-program—Specifies the RPC program number for this signature. 	0 to 1000000
swap-attacker-victim	Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.	true false (default)

1. The second number in the range must be greater than or equal to the first number.

For More Information

- For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).
- For a list of the signature regular expression syntax, see [Regular Expression Syntax, page B-9](#).

Service SMB Advanced Engine


Note

The SMB engine has been replaced by the SMB Advanced engine. Even though the SMB engine is still visible in IDM, IME, and the CLI, its signatures have been obsoleted; that is, the new signatures have the obsoletes parameter set with the IDs of their corresponding old signatures. Use the new SMB Advanced engine to rewrite any custom signature that were in the SMB engine.

The Service SMB Advanced engine processes Microsoft SMB and Microsoft RPC over SMB packets. The Service SMB Advanced engine uses the same decoding method for connection-oriented MSRPC as the MSRPC engine with the requirement that the MSRPC packet must be over the SMB protocol. The Service SMB Advanced engine supports MSRPC over SMB on TCP ports 139 and 445. It uses a copy of the connection-oriented DCS/RPC code from the MSRPC engine.

[Table B-28](#) lists the parameters specific to the Service SMB Advanced engine.

Table B-28 *Service SMB Advanced Engine Parameters*

Parameter	Description	Value
service-ports	Specifies a comma-separated list of ports or port ranges where the target service resides.	0 to 65535 a-b[,c-d] ¹
specify-smb-command {yes no}	(Optional) Enables SMB commands: <ul style="list-style-type: none"> smb-command—Specifies the SMB command value. Note Exact match required; defines the SMB packet type. ²	0 to 255
specify-direction {yes no}	(Optional) Enables traffic direction: <ul style="list-style-type: none"> direction—Specifies the direction of traffic: <ul style="list-style-type: none"> from service—Traffic from service port destined to client port. to service—Traffic from client port destined to service port. 	from service to service
specify-msrpc-over-smb-operation {yes no}	(Optional) Enables MSRPC over SMB: <ul style="list-style-type: none"> msrpc-over-smb-operation—Specifies MSRPC over SMB. Note Required for SMB_COM_TRANSACTION commands, exact match required.	0 to 65535
specify-regex-string {yes no}	(Optional) Enables searching for Regex strings: <ul style="list-style-type: none"> regex-string—Specifies a regular expression to search for in a single TCP packet. 	<i>string</i>

Table B-28 Service SMB Advanced Engine Parameters (continued)

Parameter	Description	Value
specify-exact-match-offset {yes no}	(Optional) Enables exact match offset: <ul style="list-style-type: none"> exact-match-offset—Specifies the exact stream offset the Regex string must report for a match to be valid. 	0 to 65535
specify-min-match-length {yes no}	(Optional) Enables minimum match length: <ul style="list-style-type: none"> min-match-length—Specifies the minimum number of bytes the Regex string must match. 	0 to 65535
specify-regex-payload-source {yes no}	(Optional) Enables payload source inspection: <ul style="list-style-type: none"> payload-source—Specifies the kind of payload source inspection.³ 	resource smb-data tcp-data
specify-scan-interval {yes no}	(Optional) Enables scan interval: <ul style="list-style-type: none"> scan-interval—Specifies the interval in seconds used to calculate alert rates. 	1 to 131071
specify-tcp-flags {yes no}	(Optional) Enables TCP flags: <ul style="list-style-type: none"> msrpc-tcp-flags—Specifies the MSRPC TCP flags. msrpc-tcp-flags-mask—Specifies the MSRPC flags mask. 	concurrent-execution did-not-execute first-fragment last fragment maybe-semantics object-uuid pending-cancel reserved
specify-msrpc-over-smb-pdu-type	(Optional) Enables MSRPC PDU type over the SMB packet: <ul style="list-style-type: none"> msrpc-over-smb-pdu-type—Specifies the PDU type of MSRPC over the SMB packet. 	0 = Request 2 = Response 11 = Bind 12 = Bind Ack
specify-msrpc-over-smb-uuid {yes no}	(Optional) Enables MSRPC over UUID: <ul style="list-style-type: none"> msrpc-over-smb-uuid—Specifies the MSRPC UUID. 	32-character string composed of hexadecimal characters 0-9, a-f, A-F.
swap-attacker-victim	Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.	true false (default)

1. The second number in the range must be greater than or equal to the first number.

2. Currently supporting 37 (0x25) SMB_COM_TRANSACTION command & 162 (0xA2) SMB_COM_NT_CREATE_ANDX command.

3. TCP_Data performs Regex over entire packet, SMB_Data performs Regex on SMB payload only, Resource_DATA performs Regex on SMB_Resource.

For More Information

- For more information on the parameters common to all signature engines, see [Master Engine](#), page B-4.
- For a list of the signature regular expression syntax, see [Regular Expression Syntax](#), page B-9.

Service SNMP Engine

The Service SNMP engine inspects all SNMP packets destined for port 161. You can tune SNMP signatures and create custom SNMP signatures based on specific community names and object identifiers.

Instead of using string comparison or regular expression operations to match the community name and object identifier, all comparisons are made using the integers to speed up the protocol decode and reduce storage requirements.

[Table B-29](#) lists the parameters specific to the Service SNMP engine.

Table B-29 **Service SNMP Engine Parameters**

Parameter	Description	Value
inspection-type	Enables the SNMP inspection type.	brute-force-inspection (default) invalid-packet-inspection non-snmp-traffic-inspection snmp-inspection
brute-force-inspection	Enables brute force inspection: <ul style="list-style-type: none">• brute-force-count—Specifies the number of unique SNMP community names that constitute a brute force attempt.	0 to 65535
invalid-packet-inspection	Inspects for SNMP protocol violations.	—

Table B-29 Service SNMP Engine Parameters (continued)

Parameter	Description	Value
non-snmp-traffic-inspection	Inspects for non-SNMP traffic destined for UDP port 161.	—
snmp-inspection {yes no}	Enables inspection of SNMP traffic: <ul style="list-style-type: none"> • specify-object-id—Enables inspection of the SNMP Object identifier: <ul style="list-style-type: none"> – object-id—Specifies to search for the SNMP object identifier. • specify-community-name—Enables inspection of the SNMP community name: <ul style="list-style-type: none"> – community-name—Specifies to search for the SNMP community name (SNMP password). 	<i>object-id</i> <i>community-name</i>

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Service SSH Engine

The Service SSH engine specializes in port 22 SSH traffic. Because all but the setup of an SSH session is encrypted, the Service SSH engine only looks at the fields in the setup. There are two default signatures for SSH. You can tune these signatures, but you cannot create custom signatures.

[Table B-30](#) lists the parameters specific to the Service SSH engine.

Table B-30 Service SSH Engine Parameters

Parameter	Description	Value
length-type	Inspects for one of the following SSH length types: <ul style="list-style-type: none"> • key-length—Enables inspection of the length of the SSH key: <ul style="list-style-type: none"> – length—Specifies that keys larger than this fire the RSAREF overflow. • user-length—Enables user length SSH inspection: <ul style="list-style-type: none"> – length—Specifies that keys larger than this fire the RSAREF overflow. 	0 to 65535
service-ports	Specifies a comma-separated list of ports or port ranges where the target service resides.	0 to 65535 ¹ a-b[,c-d]
specify-packet-depth {yes no}	(Optional) Enables packet depth: <ul style="list-style-type: none"> • packet-depth—Specifies the number of packets to watch before determining the session key was missed. 	0 to 65535

1. The second number in the range must be greater than or equal to the first number.

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Service TNS Engine

The Service TNS engine inspects TNS protocol. TNS provides database applications with a single common interface to all industry-standard network protocols. With TNS, applications can connect to other database applications across networks with different protocols. The default TNS listener port is TCP 1521. TNS also supports REDIRECT frames that redirect the client to another host and/or another TCP port. To support REDIRECT packets, the TNS engine listens on all TCP ports and has a quick TNS frame header validation routine to ignore non-TNS streams.

[Table B-31](#) lists the parameters specific to the Service TNS engine

Table B-31 Service TNS Engine Parameters

Parameter	Description	Value
direction	Specifies the direction of traffic: <ul style="list-style-type: none"> • Traffic from service port destined to client port. • Traffic from client port destined to service port. 	from-service to-service
specify-regex-string {yes no}	(Optional) Enables using a regular expression string: <ul style="list-style-type: none"> • regex-string—Specifies the regular expression to search for. 	<i>string</i>
specify-exact-match-offset {yes no}	Enables the exact match offset: <ul style="list-style-type: none"> • exact-match-offset—Specifies the exact stream offset the regex-string must report for a match to be valid. 	0 to 65535
specify-max-match-offset {yes no}	Enables maximum match offset: <ul style="list-style-type: none"> • max-match-offset—Specifies the maximum stream offset the regex-string must report for a match to be valid. 	0 to 65535
specify-min-match-offset {yes no}	Enables minimum match offset: <ul style="list-style-type: none"> • min-match-offset—Specifies the minimum stream offset the regex-string must report for a match to be valid. 	0 to 65535
specify-min-match-length {yes no}	Enables the minimum match length: <ul style="list-style-type: none"> – min-match-length—Specifies the minimum number of bytes the regex-string must match. 	0 to 65535

Table B-31 Service TNS Engine Parameters (continued)

Parameter	Description	Value
specify-regex-payload-src {yes no}	Enables the inspection of TCP or TNS protocol: <ul style="list-style-type: none"> payload-src—Specifies which protocol to inspect: <ul style="list-style-type: none"> tcp-data—Performs Regex over the data portion of the TCP packet. tns-data—Performs Regex only over the TNS data (with all white space removed). 	tcp data tns data
type	Specifies the TNS frame value type: <ul style="list-style-type: none"> 1—Connect 2—Accept 4—Refuse 5—Redirect 6—Data 11—Resend 12—Marker 	1 2 4 5 6 11 12

For More Information

- For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).
- For a list of the signature regular expression syntax, see [Regular Expression Syntax, page B-9](#).

State Engine

The State engine provides state-based regular expression-based pattern inspection of TCP streams. A state engine is a device that stores the state of an event and at a given time can operate on input to transition from one state to another and/or cause an action or output to take place. State machines are used to describe a specific event that causes an output or alarm. There are three state machines in the State engine: SMTP, Cisco Login, and LPR Format String.

Table B-32 lists the parameters specific to the State engine.

Table B-32 State Engine Parameters

Parameter	Description	Value
state-machine	Specifies the state machine grouping.	cisco-login lpr-format-string smtp
cisco-login	Specifies the state machine for Cisco login: <ul style="list-style-type: none"> state-name—Name of the state required before the signature fires an alert: <ul style="list-style-type: none"> Cisco device state Control-C state Password prompt state Start state 	cisco-device control-c pass-prompt start
lpr-format-string	Specifies the state machine to inspect for the LPR format string vulnerability: <ul style="list-style-type: none"> state-name—Name of the state required before the signature fires an alert: <ul style="list-style-type: none"> Abort state to end LPR Format String inspection Format character state State state 	abort format-char start
smtp	Specifies the state machine for the SMTP protocol: <ul style="list-style-type: none"> state-name—Name of the state required before the signature fires an alert: <ul style="list-style-type: none"> Abort state to end LPR Format String inspection Mail body state Mail header state SMTP commands state Start state 	abort mail-body mail-header smtp-commands start
specify-min-match-length {yes no}	(Optional) Enables minimum match length: <ul style="list-style-type: none"> min-match-length—Specifies the minimum number of bytes the regular expression string must match. 	0 to 65535
regex-string	Specifies the regular expression to search for. Note This parameter is protected; you cannot edit it.	<i>string</i>

Table B-32 State Engine Parameters (continued)

Parameter	Description	Value
direction	Specifies the direction of the traffic: <ul style="list-style-type: none"> Traffic from service port destined to client port. Traffic from client port destined to service port. 	from-service to-service
service-ports	Specifies a comma-separated list of ports or port ranges where the target service resides.	0 to 65535 ¹ a-b[,c-d]
swap-attacker-victim	Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.	true false (default)
specify-exact-match-offset {yes no}	(Optional) Enables exact match offset: <ul style="list-style-type: none"> exact-match-offset—Specifies the exact stream offset the regular expression string must report for a match to be valid. 	0 to 65535
specify-max-match-offset {yes no}	(Optional) Enables maximum match offset: <ul style="list-style-type: none"> max-match-offset—Specifies the maximum stream offset the regular expression string must report for a match to be valid. 	0 to 65535
specify-min-match-offset {yes no}	(Optional) Enables minimum match offset: <ul style="list-style-type: none"> min-match-offset—Specifies the minimum stream offset the regular expression string must report for a match to be valid. 	0 to 65535

1. The second number in the range must be greater than or equal to the first number.

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

String Engines

The String engine is a generic-based pattern-matching inspection engine for ICMP, TCP, and UDP protocols. The String engine uses a regular expression engine that can combine multiple patterns into a single pattern-matching table allowing for a single search through the data. There are three String engines: String ICMP, String TCP, and String UDP.

Table B-33 lists the parameters specific to the String ICMP engine.

Table B-33 String ICMP Engine Parameters

Parameter	Description	Value
direction	Specifies the direction of the traffic: <ul style="list-style-type: none"> Traffic from service port destined to client port. Traffic from client port destined to service port. 	from-service to-service
icmp-type	Specifies the value of the ICMP header TYPE.	0 to 18 ¹ a-b[,c-d]
regex-string	The Regex pattern to use in the search.	string
specify-exact-match-offset {yes no}	(Optional) Enables exact match offset: <ul style="list-style-type: none"> exact-match-offset—Specifies the exact stream offset the regular expression string must report for a match to be valid. 	0 to 65535
specify-min-match-length {yes no}	(Optional) Enables minimum match length: <ul style="list-style-type: none"> min-match-length—Specifies the minimum number of bytes the regular expression string must match. 	0 to 65535
swap-attacker-victim	Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.	true false (default)

1. The second number in the range must be greater than or equal to the first number.

Table B-34 lists the parameters specific to the String TCP engine.

Table B-34 String TCP Engine

Parameter	Description	Value
direction	Specifies the direction of the traffic: <ul style="list-style-type: none"> Traffic from service port destined to client port. Traffic from client port destined to service port. 	from-service to-service
regex-string	The Regex pattern to use in the search.	string
service-ports	Specifies a comma-separated list of ports or port ranges where the target service resides.	0 to 65535 ¹ a-b[,c-d]
specify-exact-match-offset {yes no}	(Optional) Enables exact match offset: <ul style="list-style-type: none"> exact-match-offset—Specifies the exact stream offset the regular expression string must report for a match to be valid. 	0 to 65535

Table B-34 String TCP Engine (continued)

Parameter	Description	Value
specify-min-match-length {yes no}	(Optional) Enables minimum match length: <ul style="list-style-type: none"> min-match-length—Specifies the minimum number of bytes the regular expression string must match. 	0 to 65535
strip-telnet-options	Strips the Telnet option characters from the data before the pattern is searched. ²	true false
swap-attacker-victim	Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.	true false (default)

1. The second number in the range must be greater than or equal to the first number.

2. This parameter is primarily used as an IPS anti-evasion tool.

Table B-35 lists the parameters specific to the String UDP engine.

Table B-35 String UDP Engine

Parameter	Description	Value
direction	Specifies the direction of the traffic: <ul style="list-style-type: none"> Traffic from service port destined to client port. Traffic from client port destined to service port. 	<ul style="list-style-type: none"> from-service to-service
regex-string	The Regex pattern to use in the search.	<i>string</i>
service-ports	Specifies a comma-separated list of ports or port ranges where the target service resides.	0 to 65535 ¹ a-b[,c-d]
specify-exact-match-offset {yes no}	(Optional) Enables exact match offset: <ul style="list-style-type: none"> exact-match-offset—Specifies the exact stream offset the regular expression string must report for a match to be valid. 	0 to 65535
specify-min-match-length {yes no}	(Optional) Enables minimum match length: <ul style="list-style-type: none"> min-match-length—Specifies the minimum number of bytes the regular expression string must match. 	0 to 65535
swap-attacker-victim	Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.	true false

1. The second number in the range must be greater than or equal to the first number.

For More Information

- For an example custom String engine signature, see [Example String TCP Engine Signature, page 8-41](#).
- For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

String XL Engines

**Note**

The IPS 4345, IPS 4360, IPS 4510, IPS 4520, ASA 5525-X IPS SSP, ASA 5545-X IPS SSP, ASA 5555-X IPS SSP, and ASA 5585-X IPS SSP support the String XL engines and the Regex accelerator card.

The String XL engines do the same thing as the other String engines—provide a matching capability of one string per signature—but they use a different Regex syntax. The String TCP XL engine is stream-based and uses cross-packet inspection (XPI). The packets must be in order. UDP and ICMP are both stateless, thus the String UDP XL and String ICMP XL signature engines require no session state to be allocated and so each packet is a separate search.

The Regex accelerator card is used for both the standard String engines and the String XL engines. Most standard String engine signatures can be compiled and analyzed by the Regex accelerator card without modification. However, there are special circumstances in which the standard String engine signatures cannot be compiled for the Regex accelerator card. In these situations a new signature is written in a String XL engine using the specific parameters in the String XL engine that do compile on the Regex accelerator card. The new signature in the String XL engine obsoletes the original signature in the standard String engine.

Although you can use regular expression syntax or raw expression syntax, raw expression syntax is for expert users only. When configuring String XL signatures, the regex-string parameter is required unless you are using raw expression syntax.

**Note**

Raw Regex is regular expression syntax used for raw mode processing. It is expert mode only and targeted for use by the Cisco IPS signature development team or only those who are under supervision by the Cisco IPS signature development team. You can configure a String XL signature in either regular Regex or raw Regex.

Table B-36 lists the parameters specific to the String XL engines (TCP, ICMP, and UDP).

Table B-36 String XL Engine Parameters

Parameter	Description	Value
direction	(Required) Direction of the traffic to inspect: <ul style="list-style-type: none"> Traffic from service port destined to client port. Traffic from client port destined to service port. 	from-service to-service
dot-all	If set to true, matches [\x00-\xFF] including \n; if set to false, matches anything in the range [\x00-\xFF] except \n.	true false (default)
end-optional	Specifies that at the end of a packet, if all other conditions are satisfied but the end is not seen, a match is reported if the minimum is exceeded.	true false (default)
icmp-type	Specifies the ICMP message type. Required if the signature engine is string-icmp.	0 to 18 ¹ a-b[,c-d]
no-case	Specifies to treat all alphabetic characters in the expression as case insensitive.	true false (default)
raw-regex	If set to true, min-match-length, max-match-length, min-whole-length, max-whole-length, dot-all, utf8, no-case, stingy, and end-optional are not used to reformat the regular expression string. Note raw-regex lets you enter a regular expression string in Raw syntax without being translated.	true false (default)
regex-string	(Required) Specifies the Regex pattern to use in the search. Note This parameter is required unless max-stream-length is set. Do not set the regex-string if max-stream-length is set.	string
service-ports	(Required) Specifies a comma-separated list of ports or port ranges where the target service resides. Note This parameter is required for the String XL TCP and String XL UDP signature engines. It cannot be used for the String XL ICMP signature engine.	0 to 65535 ¹ a-b[,c-d]
specify-exact-match-offset {yes No}	Enables exact match offset: <ul style="list-style-type: none"> exact-match-offset—Specifies the exact stream offset in bytes the regular expression string must report for a match to be valid. 	0 to 65535

Table B-36 String XL Engine Parameters (continued) (continued)

Parameter	Description	Value
specify-max-match-offset {yes No}	Enables maximum match offset: <ul style="list-style-type: none"> maximum-match-offset—Specifies the maximum stream offset in bytes the regular expression string must report for a match to be valid. 	0 to 65535
specify-min-match-offset {yes No}	Enables minimum match offset: <ul style="list-style-type: none"> min-match-offset—Specifies the minimum stream offset in bytes the regular expression string must report for a match to be valid. 	0 to 65535
specify-max-match-length {yes No}	Enables maximum match length: <ul style="list-style-type: none"> max-match-length—Specifies the maximum number of bytes the regular expression string must match for the pattern to be considered a hit. 	0 to 65535
specify-min-match-length {yes No}	Enables minimum match length: <ul style="list-style-type: none"> min-match-length—Specifies the minimum number of bytes the regular expression string must match for the pattern to be considered a hit. 	0 to 65535
specify-max-stream-length {yes No}	Enables maximum stream length: <ul style="list-style-type: none"> max-stream-length—Limits the search to the first configured number of bytes. The length of the stream is checked again this value. If the stream contains more bytes than this value, an alert is triggered. <p>Note When you specify this parameter, you cannot configure raw-regex or regex-string.</p>	yes no 0 to 65535
specify-max-whole-length {yes No}	Enables maximum whole length: <ul style="list-style-type: none"> max-whole-length—Specifies the maximum length for the pattern that will not be fragmented. 	yes no 0 to 65535
specify-min-whole-length {yes No}	Enables minimum whole length: <ul style="list-style-type: none"> min-whole-length—Specifies the minimum length for the pattern that will not be fragmented. 	yes no 0 to 65535
stingy	Specifies to stop looking for larger matches after the first completed match. <p>Note stingy can only be used with min-match-length; otherwise, it is ignored.</p>	true false (default)

Table B-36 String XL Engine Parameters (continued) (continued)

Parameter	Description	Value
strip-telnet-options	Strips the Telnet option characters from the data before the pattern is searched. ²	true false (default)
swap-attacker-victim	True if address (and ports) source and destination are swapped in the alert message. False for no swap (default).	true false (default)
utf8	Treats all legal UTF-8 byte sequences in the expression as a single character.	true false (default)

1. The second number in the range must be greater than or equal to the first number.
2. This parameter is primarily used as an IPS anti-evasion tool.

Unsupported String XL Parameters

Although you see the end-optional and specify-max-stream-length parameters in the String XL engine, they are disabled in IPS 7.1(1)E4. You receive an error message if you try to configure them. For example, here is the error message you receive after you create a signature using specify-max-stream-length and then try to save it:

```
Apply Changes?[yes]: yes
Error: string-xl-tcp 60003.0 : Maximum Stream Length is currently not supported.
Please don't use this option.
```

```
The configuration changes failed validation, no changes were applied.
Would you like to return to edit mode to correct the errors? [yes]:
```

For More Information

- For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#)
- For example String XL engine signatures, see [Example String XL TCP Engine Match Offset Signature, page 8-52](#) and [Example String XL TCP Engine Minimum Match Length Signature, page 8-55](#).

Sweep Engines

This section describes the Sweep engines, and contains the following topics:

- [Sweep Engine, page B-69](#)
- [Sweep Other TCP Engine, page B-72](#)

Sweep Engine

The Sweep engine analyzes traffic between two hosts or from one host to many hosts. You can tune the existing signatures or create custom signatures. The Sweep engine has protocol-specific parameters for ICMP, UDP, and TCP.

The alert conditions of the Sweep engine ultimately depend on the count of the unique parameter. The unique parameter is the threshold number of distinct hosts or ports depending on the type of sweep. The unique parameter triggers the alert when more than the unique number of ports or hosts is seen on the address set within the time period. The processing of unique port and host tracking is called counting.

**Caution**

Event action filters based on source and destination IP addresses do not function for the Sweep engine, because they do not filter as regular signatures. To filter source and destination IP addresses in sweep alerts, use the source and destination IP address filter parameters in the Sweep engine signatures.

A unique parameter must be specified for all signatures in the Sweep engine. A limit of 2 through 40 (inclusive) is enforced on the sweeps. 2 is the absolute minimum for a sweep, otherwise, it is not a sweep (of one host or port). 40 is a practical maximum that must be enforced so that the sweep does not consume excess memory. More realistic values for unique range between 5 and 15.

TCP sweeps must have a TCP flag and mask specified to determine which sweep inspector slot in which to count the distinct connections. ICMP sweeps must have an ICMP type specified to discriminate among the various types of ICMP packets.

Data Nodes

When an activity related to Sweep engine signatures is seen, the IPS uses a data node to determine when it should stop monitoring for a particular host. The data node contains various persistent counters and variables needed for cross-packet reassembly of streams and for tracking the inspection state on a per-stream/per-source/per-destination basis. The data node containing the sweep determines when the sweep should expire. The data node stops a sweep when the data node has not seen any traffic for x number of seconds (depending on the protocol).

There are several adaptive timeouts for the data nodes. The data node expires after 30 seconds of idle time on the address set after all of the contained objects have been removed. Each contained object has various timeouts, for example, TCP Stream has a one-hour timeout for established connections. Most other objects have a much shorter expiration time, such as 5 or 60 seconds.

[Table B-37](#) lists the parameters specific to the Sweep engine.

Table B-37 **Sweep Engine Parameters**

Parameter	Description	Value
dst-addr-filter	Specifies the destination IP address to exclude from the sweep counting algorithm.	<A.B.C.D>- <A.B.C.D> [,<A.B.C.D>- <A.B.C.D>]
src-addr-filter	Specifies the source IP address to exclude from the sweep counting algorithm.	<A.B.C.D>- <A.B.C.D> [,<A.B.C.D>- <A.B.C.D>]
protocol	Specifies the protocol of interest for this inspector.	icmp udp tcp

Table B-37 Sweep Engine Parameters (continued)

Parameter	Description	Value
specify-icmp-type {yes no}	(Optional) Enables the ICMP header type: <ul style="list-style-type: none"> icmp-type—Specifies the value of the ICMP header TYPE. 	0 to 255
specify-port-range {yes no}	(Optional) Enables using a port range for inspection: <ul style="list-style-type: none"> port-range—Specifies the UDP port range used in inspection. 	0 to 65535 a-b[,c-d]
fragment-status	Specifies whether fragments are wanted or not: <ul style="list-style-type: none"> Any fragment status Do not inspect fragments Inspect fragments 	any no-fragments want-fragments
inverted-sweep	Uses source port instead of destination port for unique counting.	true false
mask	Specifies the mask used in TCP flags comparison: <ul style="list-style-type: none"> URG bit ACK bit PSH bit RST bit SYN bit FIN bit 	urg ack psh rst syn fin
storage-key	Specifies the type of address key used to store persistent data: <ul style="list-style-type: none"> Attacker address Attacker and victim addresses Attacker address and victim port 	Axxx AxBx Axxb
suppress-reverse	Does not fire when a sweep has fired in the reverse direction on this address set.	true false
swap-attacker-victim	Swaps the attacker and victim addresses and ports (source and destination) in the alert message and in any actions taken.	true false (default)
tcp-flags	Specifies the TCP flags to match when masked by mask: <ul style="list-style-type: none"> URG bit ACK bit PSH bit RST bit SYN bit FIN bit 	urg ack psh rst syn fin
unique	Specifies the threshold number of unique port connections between the two hosts.	0 to 65535

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Sweep Other TCP Engine

The Sweep Other TCP engine analyzes traffic between two hosts looking for abnormal packets typically used to fingerprint a victim. You can tune the existing signatures or create custom signatures. TCP sweeps must have a TCP flag and mask specified. You can specify multiple entries in the set of TCP flags. And you can specify an optional port range to filter out certain packets. [Table B-38](#) lists the parameters specific to the Sweep Other TCP engine.

Table B-38 Sweep Other TCP Engine Parameters

Parameter	Description	Value
specify-port-range {yes no}	(Optional) Enables using a port range for inspection: <ul style="list-style-type: none"> port-range—Specifies the UDP port range used in inspection. 	0 to 65535 a-b[,c-d]
set-tcp-flags	Lets you set TCP flags to match. <ul style="list-style-type: none"> tcp-flags—Specifies the TCP flags used in this inspection: <ul style="list-style-type: none"> URG bit ACK bit PSH bit RST bit SYN bit FIN bit 	urg ack psh rst syn fin

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Traffic Anomaly Engine

**Note**

You can edit or tune anomaly detection signatures but you cannot create custom anomaly detection signatures.

The Traffic Anomaly engine contains nine anomaly detection signatures covering the three protocols (TCP, UDP, and other). Each signature has two subsignatures, one for the scanner and the other for the worm-infected host (or a scanner under worm attack). When anomaly detection discovers an anomaly, it triggers an alert for these signatures. All anomaly detection signatures are enabled by default and the alert severity for each one is set to high.

When a scanner is detected but no histogram anomaly occurred, the scanner signature fires for that attacker (scanner) IP address. If the histogram signature is triggered, the attacker addresses that are doing the scanning each trigger the worm signature (instead of the scanner signature). The alert details state which threshold is being used for the worm detection now that the histogram has been triggered. From that point on, all scanners are detected as worm-infected hosts.

The following anomaly detection event actions are possible:

- produce-alert—Writes the event to the Event Store.
- deny-attacker-inline—Does not transmit this packet and future packets originating from the attacker address for a specified period of time.
- log-attacker-packets—Starts IP logging for packets that contain the attacker address.
- log-pair-packets—Starts IP logging for packets that contain the attacker and victim address pair.
- deny-attacker-service-pair-inline—Blocks the source IP address and the destination port.
- request-snmp-trap—Sends a request to NotificationApp to perform SNMP notification.
- request-block-host—Sends a request to ARC to block this host (the attacker).

Table B-39 lists the anomaly detection worm signatures.

Table B-39 Anomaly Detection Worm Signatures

Signature ID	Subsignature ID	Name	Description
13000	0	Internal TCP Scanner	Identified a single scanner over a TCP protocol in the internal zone.
13000	1	Internal TCP Scanner	Identified a worm attack over a TCP protocol in the internal zone; the TCP histogram threshold was crossed and a scanner over a TCP protocol was identified.
13001	0	Internal UDP Scanner	Identified a single scanner over a UDP protocol in the internal zone.
13001	1	Internal UDP Scanner	Identified a worm attack over a UDP protocol in the internal zone; the UDP histogram threshold was crossed and a scanner over a UDP protocol was identified.
13002	0	Internal Other Scanner	Identified a single scanner over an Other protocol in the internal zone.
13002	1	Internal Other Scanner	Identified a worm attack over an Other protocol in the internal zone; the Other histogram threshold was crossed and a scanner over an Other protocol was identified.
13003	0	External TCP Scanner	Identified a single scanner over a TCP protocol in the external zone.
13003	1	External TCP Scanner	Identified a worm attack over a TCP protocol in the external zone; the TCP histogram threshold was crossed and a scanner over a TCP protocol was identified.
13004	0	External UDP Scanner	Identified a single scanner over a UDP protocol in the external zone.

Table B-39 *Anomaly Detection Worm Signatures (continued)*

Signature ID	Subsignature ID	Name	Description
13004	1	External UDP Scanner	Identified a worm attack over a UDP protocol in the external zone; the UDP histogram threshold was crossed and a scanner over a UDP protocol was identified.
13005	0	External Other Scanner	Identified a single scanner over an Other protocol in the external zone.
13005	1	External Other Scanner	Identified a worm attack over an Other protocol in the external zone; the Other histogram threshold was crossed and a scanner over an Other protocol was identified.
13006	0	Illegal TCP Scanner	Identified a single scanner over a TCP protocol in the illegal zone.
13006	1	Illegal TCP Scanner	Identified a worm attack over a TCP protocol in the illegal zone; the TCP histogram threshold was crossed and a scanner over a TCP protocol was identified.
13007	0	Illegal UDP Scanner	Identified a single scanner over a UDP protocol in the illegal zone.
13007	1	Illegal UDP Scanner	Identified a worm attack over a UDP protocol in the illegal zone; the UDP histogram threshold was crossed and a scanner over a UDP protocol was identified.
13008	0	Illegal Other Scanner	Identified a single scanner over an Other protocol in the illegal zone.
13008	1	Illegal Other Scanner	Identified a worm attack over an Other protocol in the illegal zone; the Other histogram threshold was crossed and a scanner over an Other protocol was identified.

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Traffic ICMP Engine

The Traffic ICMP engine analyzes nonstandard protocols, such as TFN2K, LOKI, and DDoS. There are only two signatures (based on the LOKI protocol) with user-configurable parameters.

TFN2K is the newer version of the TFN. It is a DDoS agent that is used to control coordinated attacks by infected computers (zombies) to target a single computer (or domain) with bogus traffic floods from hundreds or thousands of unknown attacking hosts. TFN2K sends randomized packet header information, but it has two discriminators that can be used to define signatures. One is whether the L3 checksum is incorrect and the other is whether the character 64 'A' is found at the end of the payload. TFN2K can run on any port and can communicate with ICMP, TCP, UDP, or a combination of these protocols.

LOKI is a type of back door Trojan. When the computer is infected, the malicious code creates an ICMP Tunnel that can be used to send small payload in ICMP replies (which may go straight through a firewall if it is not configured to block ICMP.) The LOKI signatures look for an imbalance of ICMP echo requests to replies and simple ICMP code and payload discriminators.

The DDoS category (excluding TFN2K) targets ICMP-based DDoS agents. The main tools used here are TFN and Stacheldraht. They are similar in operation to TFN2K, but rely on ICMP only and have fixed commands: integers and strings.

Table B-40 lists the parameters specific to the Traffic ICMP engine.

Table B-40 Traffic ICMP Engine Parameters

Parameter	Description	Value
parameter-tunable-sig	Specifies the whether this signature has configurable parameters.	yes no
inspection-type	Specifies the type of inspection to perform: <ul style="list-style-type: none"> Inspects for original LOKI traffic Inspects for modified LOKI traffic 	is-loki is-mod-lok
reply-ratio	Specifies the imbalance of replies to requests. The alert fires when there are this many more replies than requests.	0 to 65535
want-request	Requires an ECHO REQUEST be seen before firing the alert.	true false

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).

Trojan Engines

The Trojan engines analyze nonstandard protocols, such as BO2K and TFN2K. There are three Trojan engines: Trojan BO2K, TrojanTFN2K, and Trojan UDP.

BO was the original Windows back door Trojan that ran over UDP only. It was soon superseded by BO2K. BO2K supported UDP and TCP both with basic XOR encryption. They have plain BO headers that have certain cross-packet characteristics.

BO2K also has a stealthy TCP module that was designed to encrypt the BO header and make the cross-packet patterns nearly unrecognizable. The UDP modes of BO and BO2K are handled by the Trojan UDP engine. The TCP modes are handled by the Trojan BO2K engine.



Note

There are no specific parameters to the Trojan engines, except for swap-attacker-victim in the Trojan UDP engine.

For More Information

For more information on the parameters common to all signature engines, see [Master Engine, page B-4](#).



Troubleshooting

This appendix contains troubleshooting tips and procedures for sensors and software. It contains the following sections:

- [Cisco Bug Search, page C-1](#)
- [Preventive Maintenance, page C-2](#)
- [Disaster Recovery, page C-6](#)
- [Password Recovery, page C-7](#)
- [Time Sources and the Sensor, page C-17](#)
- [Advantages and Restrictions of Virtualization, page C-19](#)
- [Supported MIBs, page C-20](#)
- [Troubleshooting RADIUS Authentication, page C-21](#)
- [Troubleshooting Global Correlation, page C-21](#)
- [When to Disable Anomaly Detection, page C-21](#)
- [Analysis Engine Not Responding, page C-22](#)
- [Troubleshooting External Product Interfaces, page C-23](#)
- [Troubleshooting the Appliance, page C-24](#)
- [Troubleshooting the IDM, page C-57](#)
- [Troubleshooting the IME, page C-59](#)
- [Troubleshooting the ASA 5500 AIP SSM, page C-61](#)
- [Troubleshooting the ASA 5500-X IPS SSP, page C-66](#)
- [Troubleshooting the ASA 5585-X IPS SSP, page C-78](#)
- [Gathering Information, page C-85](#)

Cisco Bug Search

Bug Search Tool (BST), the online successor to Bug Toolkit, is designed to improve your effectiveness in network risk management and device troubleshooting.

BST allows partners and customers to search for software bugs based on product, release, and keyword, and aggregates key data such as bug details, product, and version. The service has provision to filter bugs based on credentials to provide external and internal bug views for the search input.

Check out Bug Search Tools & Resources on Cisco.com. For more details on the tool overview and functionalities, check out the help page, located at <http://www.cisco.com/web/applicat/cbsshelp/help.html>

Preventive Maintenance

This section describes how to perform preventive maintenance for your sensor, and contains the following topics:

- [Understanding Preventive Maintenance, page C-2](#)
- [Creating and Using a Backup Configuration File, page C-2](#)
- [Backing Up and Restoring the Configuration File Using a Remote Server, page C-3](#)
- [Creating the Service Account, page C-5](#)

Understanding Preventive Maintenance

The following actions will help you maintain your sensor:

- Back up a good configuration. If your current configuration becomes unusable, you can replace it with the backup version.
- Save your backup configuration to a remote system.
- Always back up your configuration before you do a manual upgrade. If you have auto upgrades configured, make sure you do periodic backups.
- Create a service account. A service account is needed for special debug situations directed by TAC.



Caution

You should carefully consider whether you want to create a service account. The service account provides shell access to the system, which makes the system vulnerable. Analyze your situation to decide if you want a service account existing on the system.

For More Information

- For the procedure for backing up a configuration file, see [Creating and Using a Backup Configuration File, page C-2](#).
- For the procedure for using a remote server to copy and restore the a configuration file, see [Backing Up and Restoring the Configuration File Using a Remote Server, page C-3](#).
- For more information about the service account, see [Creating the Service Account, page C-5](#).

Creating and Using a Backup Configuration File

To protect your configuration, you can back up the current configuration and then display it to confirm that is the configuration you want to save. If you need to restore this configuration, you can merge the backup configuration file with the current configuration or overwrite the current configuration file with the backup configuration file.

To back up your current configuration, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** Save the current configuration. The current configuration is saved in a backup file.
- ```
sensor# copy current-config backup-config
```
- Step 3** Display the backup configuration file. The backup configuration file is displayed.
- ```
sensor# more backup-config
```
- Step 4** You can either merge the backup configuration with the current configuration, or you can overwrite the current configuration:
- Merge the backup configuration into the current configuration.
- ```
sensor# copy backup-config current-config
```
- Overwrite the current configuration with the backup configuration.
- ```
sensor# copy /erase backup-config current-config
```
-

Backing Up and Restoring the Configuration File Using a Remote Server



Note

We recommend copying the current configuration file to a remote server before upgrading.

Use the **copy [/erase] source_url destination_url keyword** command to copy the configuration file to a remote server. You can then restore the current configuration from the remote server. You are prompted to back up the current configuration first. The following options apply:

- **/erase**—Erases the destination file before copying.
This keyword only applies to the current-config; the backup-config is always overwritten. If this keyword is specified for destination current-config, the source configuration is applied to the system default configuration. If it is not specified for the destination current-config, the source configuration is merged with the current-config.
- **source_url**—The location of the source file to be copied. It can be a URL or keyword.
- **destination_url**—The location of the destination file to be copied. It can be a URL or a keyword.
- **current-config**—The current running configuration. The configuration becomes persistent as the commands are entered.
- **backup-config**—The storage location for the configuration backup.

The exact format of the source and destination URLs varies according to the file. Here are the valid types:

- **ftp**—Source or destination URL for an FTP network server. The syntax for this prefix is:
ftp://[[username@] location]/relativeDirectory]/filename
ftp://[[username@]location]//absoluteDirectory]/filename
- **scp**—Source or destination URL for the SCP network server. The syntax for this prefix is:
scp://[[username@] location]/relativeDirectory]/filename

```
scp://[username@] location[/absoluteDirectory]/filename
```



Note If you use FTP or SCP protocol, you are prompted for a password. If you use SCP protocol, you must also add the remote host to the SSH known hosts list.

- **http:**—Source URL for the web server. The syntax for this prefix is:
http://[username@]location[/directory]/filename
- **https:**—Source URL for the web server. The syntax for this prefix is:
https://[username@]location[/directory]/filename



Note HTTP and HTTPS prompt for a password if a username is required to access the website. If you use HTTPS protocol, the remote host must be a TLS trusted host.



Caution

Copying a configuration file from another sensor may result in errors if the sensing interfaces and virtual sensors are not configured the same.

Backing Up the Current Configuration to a Remote Server

To back up your current configuration to a remote server, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Back up the current configuration to the remote server.

```
sensor# copy current-config scp://user@192.0.2.0//configuration/cfg current-config
Password: *****
Warning: Copying over the current configuration may leave the box in an unstable state.
Would you like to copy current-config to backup-config before proceeding? [yes]:
```

Step 3 Enter **yes** to copy the current configuration to a backup configuration.

```
cfg          100% | ***** | 36124          00:00
```

Restoring the Current Configuration From a Backup File

To restore your current configuration from a backup file, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Back up the current configuration to the remote server.

```
sensor# copy scp://user@192.0.2.0//configuration/cfg current-config
Password: *****
Warning: Copying over the current configuration may leave the box in an unstable state.
Would you like to copy current-config to backup-config before proceeding? [yes]:
```

Step 3 Enter **yes** to copy the current configuration to a backup configuration.

```
cfg          100% | ***** | 36124          00:00
```

Warning: Replacing existing network-settings may leave the box in an unstable state.

```
Would you like to replace existing network settings
(host-ipaddress/netmask/gateway/access-list) on sensor before proceeding? [no]:
sensor#
```

- Step 4** Enter **no** to retain the currently configured hostname, IP address, subnet mask, management interface, and access list. We recommend you retain this information to preserve access to your sensor after the rest of the configuration has been restored.

For More Information

For a list of supported HTTP/HTTPS servers, see [Supported FTP and HTTP/HTTPS Servers, page 22-3](#).

Creating the Service Account

You can create a service account for the TAC to use during troubleshooting. Although more than one user can have access to the sensor, only one user can have service privileges on a sensor. The service account is for support purposes only.

The root user password is synchronized to the service account password when the service account is created. To gain root access you must log in with the service account and switch to user root with the **su - root** command.



Caution

Do not make modifications to the sensor through the service account except under the direction of the TAC. If you use the service account to configure the sensor, your configuration is not supported by the TAC. Adding services to the operating system through the service account affects proper performance and functioning of the other IPS services. The TAC does not support a sensor on which additional services have been added.



Caution

You should carefully consider whether you want to create a service account. The service account provides shell access to the system, which makes the system vulnerable. However, you can use the service account to create a password if the administrator password is lost. Analyze your situation to decide if you want a service account existing on the system.



Note

For IPS 5.0 and later, you can no longer remove the **cisco** account. You can disable it using the **no password cisco** command, but you cannot remove it. To use the **no password cisco** command, there must be another administrator account on the sensor. Removing the **cisco** account through the service account is not supported. If you remove the **cisco** account through the service account, the sensor most likely will not boot up, so to recover the sensor you must reinstall the sensor system image.

To create the service account, follow these steps:

-
- Step 1** Log in to the CLI using an account with administrator privileges.

- Step 2** Enter configuration mode.

```
sensor# configure terminal
```

- Step 3** Specify the parameters for the service account. The username follows the pattern `^[A-Za-z0-9()+:;_-]+$`, which means the username must start with a letter or number, and can include any letter A to Z (capital or small), any number 0 to 9, - and `_`, and can contain 1 to 64 characters.

```
sensor(config)# user username privilege service
```

- Step 4** Specify a password when prompted. A valid password is 8 to 32 characters long. All characters except space are allowed. If a service account already exists for this sensor, the following error is displayed and no service account is created.

```
Error: Only one service account may exist
```

- Step 5** Exit configuration mode.

```
sensor(config)# exit
sensor#
```

When you use the service account to log in to the CLI, you receive this warning.

```
***** WARNING *****
UNAUTHORIZED ACCESS TO THIS NETWORK DEVICE IS PROHIBITED. This account is intended to be
used for support and troubleshooting purposes only. Unauthorized modifications are not
supported and will require this device to be reimaged to guarantee proper operation.
*****
```

Disaster Recovery

Follow these recommendations so that you are ready in case of a disaster:

- If you are using the CLI, IDM, or IME for configuration, copy the current configuration from the sensor to an FTP or SCP server any time a change has been made.
- You should note the specific software version for that configuration. You can apply the copied configuration only to a sensor of the same version.
- You also need the list of user IDs that have been used on that sensor. The list of user IDs and passwords are not saved in the configuration.

When a disaster happens and you need to recover the sensor, try the following:

1. Reimage the sensor.
2. Log in to the sensor with the default user ID and password—**cisco**.



Note You are prompted to change the **cisco** password.

3. Initialize the sensor.
4. Upgrade the sensor to the IPS software version it had when the configuration was last saved and copied.



Warning

Trying to copy the saved configuration without getting the sensor back to the same IPS software version it had before the disaster can cause configuration errors.

5. Copy the last saved configuration to the sensor.

6. Update clients to use the new key and certificate of the sensor. Reimaging changes the sensor SSH keys and HTTPS certificate, so you must add the hosts back to the SSN known hosts list.
7. Create previous users.

For More Information

- For the procedure for backing up a configuration file, see [Creating and Using a Backup Configuration File, page C-2](#).
- For the procedure for obtaining a list of the current users on the sensor, see [Showing User Status, page 4-30](#).
- For the procedures for reimage a sensor, see [Chapter 22, “Upgrading, Downgrading, and Installing System Images.”](#)
- For the procedure for using the **setup** command to initialize the sensor, see [Chapter 3, “Initializing the Sensor.”](#)
- For more information on obtaining IPS software and how to install it, see [Obtaining Cisco IPS Software, page 21-1](#).
- For the procedure for using a remote server to copy and restore the a configuration file, see [Backing Up and Restoring the Configuration File Using a Remote Server, page C-3](#).
- For the procedure for adding hosts to the SSH known hosts list, see [Adding Hosts to the SSH Known Hosts List, page 4-45](#).
- For the procedure for adding users, see [Adding and Removing Users, page 4-16](#).

Password Recovery

For most IPS platforms, you can now recover the password on the sensor rather than using the service account or reimaging the sensor. This section describes how to recover the password for the various IPS platforms. It contains the following topics:

- [Understanding Password Recovery, page C-7](#)
- [Recovering the Password for the Appliance, page C-8](#)
- [Recovering the Password for the ASA 5500 AIP SSM, page C-10](#)
- [Recovering the Password for the ASA 5500-X IPS SSP, page C-12](#)
- [Recovering the Password for the ASA 5585-X IPS SSP, page C-14](#)
- [Disabling Password Recovery, page C-15](#)
- [Verifying the State of Password Recovery, page C-16](#)
- [Troubleshooting Password Recovery, page C-17](#)

Understanding Password Recovery



Note

Administrators may need to disable the password recovery feature for security reasons.

Password recovery implementations vary according to IPS platform requirements. Password recovery is implemented only for the cisco administrative account and is enabled by default. The IPS administrator can then recover user passwords for other accounts using the CLI. The cisco user password reverts to **cisco** and must be changed after the next login.

[Table C-1](#) lists the password recovery methods according to platform.

Table C-1 Password Recovery Methods According to Platform

Platform	Description	Recovery Method
4200 series sensors 4300 series sensors 4500 series sensors	Standalone IPS appliances	GRUB prompt or ROMMON
ASA 5500 AIP SSM ASA 5500-X IPS SSP ASA 5585-X IPS SSP	ASA 5500 series adaptive security appliance IPS modules	Adaptive security appliance CLI command

Recovering the Password for the Appliance

This section describes the two ways to recover the password for appliances. It contains the following topics:

- [Using the GRUB Menu, page C-8](#)
- [Using ROMMON, page C-9](#)

Using the GRUB Menu



Note

You must have a terminal server or direct serial connection to the appliance to use the GRUB menu to recover the password.

For the IPS 4270-20, IPS 4355, IPS 4360, IPS 4510, and IPS 4520 appliances, the password recovery is found in the GRUB menu, which appears during bootup. When the GRUB menu appears, press any key to pause the boot process.

To recover the password on appliances, follow these steps:

Step 1 Reboot the appliance to see the GRUB menu.

```
GNU GRUB version 0.94 (632K lower / 523264K upper memory)
```

```
-----
0: Cisco IPS
1: Cisco IPS Recovery
2: Cisco IPS Clear Password (cisco)
-----
```

Use the ^ and v keys to select which entry is highlighted.
Press enter to boot the selected OS, 'e' to edit the
Commands before booting, or 'c' for a command-line.

Highlighted entry is 0:

Step 2 Press any key to pause the boot process.

- Step 3** Choose **2: Cisco IPS Clear Password (cisco)**. The password is reset to **cisco**. Log in to the CLI with username **cisco** and password **cisco**. You can then change the password.

Using ROMMON

For the IPS 4240, IPS 4255, IPS 4345, IPS 4360, IPS 4510, and IPS 4520, you can use the ROMMON to recover the password. To access the ROMMON CLI, reboot the sensor from a terminal server or direct connection and interrupt the boot process.



Note

After recovering the password, you must reset the confreg to **0**, otherwise, when you try to upgrade the sensor, the upgrade fails because when the sensor reboots, it goes to password recovery (**confreg 0x7**) rather than to the upgrade option.

To recover the password using the ROMMON CLI, follow these steps:

- Step 1** Reboot the appliance.
- Step 2** To interrupt the boot process, press **ESC** or **Control-R** (terminal server) or send a **BREAK** command (direct connection). The boot code either pauses for 10 seconds or displays something similar to one of the following:

- Evaluating boot options
- Use **BREAK** or **ESC** to interrupt boot

- Step 3** Enter the following commands to reset the password:

```
confreg 0x7
boot
```

Sample ROMMON session:

```
Booting system, please wait...
CISCO SYSTEMS
Embedded BIOS Version 1.0(11)2 01/25/06 13:21:26.17
...
Evaluating BIOS Options...
Launch BIOS Extension to setup ROMMON
Cisco Systems ROMMON Version (1.0(11)2) #0: Thu Jan 26 10:43:08 PST 2006
Platform IPS-4360-K9
Use BREAK or ESC to interrupt boot.
Use SPACE to begin boot immediately.
Boot interrupted.
Management0/0
Link is UP
MAC Address:000b.fcfa.d155
Use ? for help.
rommon #0> confreg 0x7
Update Config Register (0x7) in NVRAM...
rommon #1> boot
```

- Step 4** Enter the following command to reset the confreg value to 0:

```
confreg 0
```

Recovering the Password for the ASA 5500 AIP SSM



Note

To reset the password, you must have ASA 7.2.2 or later.

You can reset the password to the default (**cisco**) for the ASA 5500 AIP SSM using the CLI or the ASDM. Resetting the password causes it to reboot. IPS services are not available during a reboot.

Use the **hw-module module slot_number password-reset** command to reset the password to the default **cisco**. If the module in the specified slot has an IPS version that does not support password recovery, the following error message is displayed:

```
ERROR: the module in slot <n> does not support password recovery.
```

Resetting the Password Using the CLI

To reset the password on the ASA 5500 AIP SSM, follow these steps:

- Step 1** Log into the adaptive security appliance and enter the following command to verify the module slot number:

```
asa# show module
```

Mod	Card Type	Model	Serial No.
0	ASA 5510 Adaptive Security Appliance	ASA5510	JMX1135L097
1	ASA 5500 Series Security Services Module-40	ASA-SSM-40	JAF1214AMRL

Mod	MAC Address Range	Hw Version	Fw Version	Sw Version
0	001b.d5e8.e0c8 to 001b.d5e8.e0cc	2.0	1.0(11)2	8.4(3)
1	001e.f737.205f to 001e.f737.205f	1.0	1.0(14)5	7.0(7)E4

Mod	SSM Application Name	Status	SSM Application Version
1	IPS	Up	7.0(7)E4

Mod	Status	Data Plane Status	Compatibility
0	Up Sys	Not Applicable	
1	Up	Up	

- Step 2** Reset the password for module 1.

```
asa# hw-module module 1 password-reset
Reset the password on module in slot 1? [confirm]
```

- Step 3** Press **Enter** to confirm.

```
Password-Reset issued for slot 1.
```

- Step 4** Verify the status of the module. Once the status reads Up, you can session to the ASA 5500 AIP SSM.

```
asa# show module 1
```

Mod	Card Type	Model	Serial No.
1	ASA 5500 Series Security Services Module-40	ASA-SSM-40	JAF1214AMRL

Mod	MAC Address Range	Hw Version	Fw Version	Sw Version
1	001e.f737.205f to 001e.f737.205f	1.0	1.0(14)5	7.0(7)E4

Mod	SSM Application Name	Status	SSM Application Version
1	IPS	Up	7.0(7)E4

```

-----
1 IPS                               Up                               7.0(7)E4

Mod Status                        Data Plane Status      Compatibility
-----
1 Up                               Up

```

Step 5 Session to the ASA 5500 AIP SSM.

```
asa# session 1
Opening command session with slot 1.
Connected to slot 1. Escape character sequence is 'CTRL-^X'.
```

Step 6 Enter the default username (**cisco**) and password (**cisco**) at the login prompt.

```
login: cisco
Password: cisco
```

```
You are required to change your password immediately (password aged)
Changing password for cisco.
(current) password: cisco
```

Step 7 Enter your new password twice.

```
New password: new password
Retype new password: new password
```

```
***NOTICE***
```

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at:
<http://www.cisco.com/wwl/export/crypto/tool/stqrg.html>

If you require further assistance please contact us by sending email to export@cisco.com.

```
***LICENSE NOTICE***
```

There is no license key installed on this IPS platform. The system will continue to operate with the currently installed signature set. A valid license must be obtained in order to apply signature updates. Please go to <http://www.cisco.com/go/license> to obtain a new license or install a license.

```
aip_ssm#
```

Using the ASDM

To reset the password in the ASDM, follow these steps:

Step 1 From the ASDM menu bar, choose **Tools > IPS Password Reset**.



Note This option does not appear in the menu if there is no IPS present.

- Step 2** In the IPS Password Reset confirmation dialog box, click **OK** to reset the password to the default (**cisco**). A dialog box displays the success or failure of the password reset. If the reset fails, make sure you have the correct ASA and IPS software versions.
- Step 3** Click **Close** to close the dialog box. The sensor reboots.

Recovering the Password for the ASA 5500-X IPS SSP

You can reset the password to the default (**cisco**) for the ASA 5500-X IPS SSP using the CLI or the ASDM. Resetting the password causes it to reboot. IPS services are not available during a reboot.



Note

To reset the password, you must have ASA 8.6.1 or later.

Use the **sw-module module ips password-reset** command to reset the password to the default **cisco**. If the module in the specified slot has an IPS version that does not support password recovery, the following error message is displayed:

```
ERROR: the module in slot <n> does not support password recovery.
```

To reset the password on the ASA 5500-X IPS SSP, follow these steps:

- Step 1** Log into the adaptive security appliance and enter the following command:
- ```
asa# sw-module module ips password-reset
Reset the password on module ips? [confirm]
```
- Step 2** Press **Enter** to confirm.
- ```
Password-Reset issued for module ips.
```
- Step 3** Verify the status of the module. Once the status reads **Up**, you can session to the ASA 5500-X IPS SSP.

```
asa# show module ips
Mod Card Type                               Model                Serial No.
---
ips ASA 5555-X IPS Security Services Processor  ASA5555-IPS          FCH151070GR

Mod MAC Address Range                       Hw Version           Fw Version           Sw Version
---
ips 503d.e59c.7c4c to 503d.e59c.7c4c         N/A                   N/A                   7.1(4)E4

Mod SSM Application Name                     Status                SSM Application Version
---
ips IPS                                       Up                    7.1(4)E4

Mod Status           Data Plane Status     Compatibility
---
ips Up               Up                     -----

Mod License Name      License Status         Time Remaining
---
ips IPS Module        Enabled                210 days
```

- Step 4** Session to the ASA 5500-X IPS SSP.

```
asa# session ips
Opening command session with module ips.
```

Connected to module ips. Escape character sequence is 'CTRL-^X'.

- Step 5** Enter the default username (**cisco**) and password (**cisco**) at the login prompt.

```
login: cisco
Password: cisco
```

```
You are required to change your password immediately (password aged)
Changing password for cisco.
(current) password: cisco
```

- Step 6** Enter your new password twice.

```
New password: new password
Retype new password: new password
```

NOTICE

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at:
<http://www.cisco.com/wwl/export/crypto/tool/stqrg.html>

If you require further assistance please contact us by sending email to export@cisco.com.

LICENSE NOTICE

There is no license key installed on this IPS platform. The system will continue to operate with the currently installed signature set. A valid license must be obtained in order to apply signature updates. Please go to <http://www.cisco.com/go/license> to obtain a new license or install a license.

```
asa-ssp#
```

Using the ASDM

To reset the password in the ASDM, follow these steps:

- Step 1** From the ASDM menu bar, choose **Tools > IPS Password Reset**.



Note This option does not appear in the menu if there is no IPS present.

- Step 2** In the IPS Password Reset confirmation dialog box, click **OK** to reset the password to the default (**cisco**). A dialog box displays the success or failure of the password reset. If the reset fails, make sure you have the correct ASA and IPS software versions.

- Step 3** Click **Close** to close the dialog box. The sensor reboots.

Recovering the Password for the ASA 5585-X IPS SSP



Note

To reset the password, you must have ASA 8.2.(4.4) or later or ASA 8.4.2 or later. The ASA 5585-X IPS SSP is not supported in ASA 8.3(x).

You can reset the password to the default (**cisco**) for the ASA 5585-X IPS SSP using the CLI or the ASDM. Resetting the password causes it to reboot. IPS services are not available during a reboot.

Use the **hw-module module slot_number password-reset** command to reset the password to the default **cisco**. If the module in the specified slot has an IPS version that does not support password recovery, the following error message is displayed:

```
ERROR: the module in slot <n> does not support password recovery.
```

To reset the password on the ASA 5585-X IPS SSP, follow these steps:

Step 1 Log into the adaptive security appliance and enter the following command:

```
asa# hw-module module 1 password-reset
Reset the password on module in slot 1? [confirm]
```

Step 2 Press **Enter** to confirm.

```
Password-Reset issued for slot 1.
```

Step 3 Verify the status of the module. Once the status reads **Up**, you can session to the ASA 5585-X IPS SSP.

```
asa# show module 1
```

Mod Card Type	Model	Serial No.
1 ASA 5585-X IPS Security Services Processor-4	ASA5585-SSP-IPS40	JAF1436ABSG

Mod MAC Address Range	Hw Version	Fw Version	Sw Version
1 5475.d029.8c74 to 5475.d029.8c7f	0.1	2.0(12)3	7.1(4)E4

Mod SSM Application Name	Status	SSM Application Version
1 IPS	Up	7.1(4)E4

Mod Status	Data Plane Status	Compatibility
1 Up	Up	

Step 4 Session to the ASA 5585-X IPS SSP.

```
asa# session 1
Opening command session with slot 1.
Connected to slot 1. Escape character sequence is 'CTRL-^X'.
```

Step 5 Enter the default username (**cisco**) and password (**cisco**) at the login prompt.

```
login: cisco
Password: cisco
```

```
You are required to change your password immediately (password aged)
Changing password for cisco.
(current) password: cisco
```

Step 6 Enter your new password twice.

New password: **new password**
 Retype new password: **new password**

NOTICE

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at:
<http://www.cisco.com/wwl/export/crypto/tool/stqrg.html>

If you require further assistance please contact us by sending email to export@cisco.com.

LICENSE NOTICE

There is no license key installed on this IPS platform. The system will continue to operate with the currently installed signature set. A valid license must be obtained in order to apply signature updates. Please go to <http://www.cisco.com/go/license> to obtain a new license or install a license.
 ips_ssp#

Using the ASDM

To reset the password in the ASDM, follow these steps:

Step 1 From the ASDM menu bar, choose **Tools > IPS Password Reset**.

Note This option does not appear in the menu if there is no IPS present.

Step 2 In the IPS Password Reset confirmation dialog box, click **OK** to reset the password to the default (**cisco**). A dialog box displays the success or failure of the password reset. If the reset fails, make sure you have the correct ASA and IPS software versions.**Step 3** Click **Close** to close the dialog box. The sensor reboots.

Disabling Password Recovery

**Caution**

If you try to recover the password on a sensor on which password recovery is disabled, the process proceeds with no errors or warnings; however, the password is not reset. If you cannot log in to the sensor because you have forgotten the password, and password recovery is set to disabled, you must reimagine your sensor.

Password recovery is enabled by default. You can disable password recovery through the CLI, IDM, or IME.

Disabling Password Recovery Using the CLI

To disable password recovery in the CLI, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter global configuration mode.

```
sensor# configure terminal
```

Step 3 Enter host mode.

```
sensor(config)# service host
```

Step 4 Disable password recovery.

```
sensor(config-hos)# password-recovery disallowed
```

Disabling Password Recovery Using the IDM or IME

To disable password recovery in the IDM or IME, follow these steps:

Step 1 Log in to the IDM or IME using an account with administrator privileges.

Step 2 Choose **Configuration > sensor_name > Sensor Setup > Network**.

Step 3 To disable password recovery, uncheck the **Allow Password Recovery** check box.

Verifying the State of Password Recovery

Use the **show settings | include password** command to verify whether password recovery is enabled. To verify whether password recovery is enabled, follow these steps:

Step 1 Log in to the CLI.

Step 2 Enter service host submode.

```
sensor# configure terminal
sensor (config)# service host
sensor (config-hos)#
```

Step 3 Verify the state of password recovery by using the **include** keyword to show settings in a filtered output.

```
sensor(config-hos)# show settings | include password
password-recovery: allowed <defaulted>
sensor(config-hos)#
```

Troubleshooting Password Recovery

When you troubleshoot password recovery, pay attention to the following:

- You cannot determine whether password recovery has been disabled in the sensor configuration from the ROMMON prompt, GRUB menu, switch CLI, or router CLI. If you attempt password recovery, it always appears to succeed. If it has been disabled, the password is not reset to **cisco**. The only option is to reimage the sensor.
- You can disable password recovery in the host configuration. For the platforms that use external mechanisms, such as ROMMON, although you can run commands to clear the password, if password recovery is disabled in the IPS, the IPS detects that password recovery is not allowed and rejects the external request.
- To check the state of password recovery, use the **show settings | include password** command.

Time Sources and the Sensor

This section describes how to maintain accurate time on the sensor, and contains the following topics:

- [Time Sources and the Sensor, page C-17](#)
- [Synchronizing IPS Clocks with Parent Device Clocks, page C-18](#)
- [Verifying the Sensor is Synchronized with the NTP Server, page C-18](#)
- [Correcting Time on the Sensor, page C-19](#)

Time Sources and the Sensor



Note

We recommend that you use an NTP server to regulate time on your sensor. You can use authenticated or unauthenticated NTP. For authenticated NTP, you must obtain the NTP server IP address, NTP server key ID, and the key value from the NTP server. You can set up NTP during initialization or you can configure NTP through the CLI, IDM, IME, or ASDM.

The sensor requires a reliable time source. All events (alerts) must have the correct UTC and local time stamp, otherwise, you cannot correctly analyze the logs after an attack. When you initialize the sensor, you set up the time zones and summertime settings. This section provides a summary of the various ways to set the time on sensors.

The IPS Standalone Appliances

- Use the **clock set** command to set the time. This is the default.
- Configure the appliance to get its time from an NTP time synchronization source.



Note

The currently supported Cisco IPS appliances are the IPS 4240, IPS 4255, and IPS 4260 [IPS 7.1(5) and later], IPS 4270-20 [IPS 7.1(3) and later], IPS 4345 and IPS 4360 [IPS 7.1(3) and later], and IPS 4510 and IPS 4520 [IPS 7.1(4) and later].

The ASA IPS Modules

- The ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP automatically synchronize their clocks with the clock in the adaptive security appliance in which they are installed. This is the default.
- Configure them to get their time from an NTP time synchronization source, such as a Cisco router other than the parent router.

For More Information

For the procedure for configuring NTP, see [Configuring NTP, page 4-41](#).

Synchronizing IPS Clocks with Parent Device Clocks

The ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP) synchronize their clocks to the parent chassis clock (switch, router, or adaptive security appliance) each time the IPS boots up and any time the parent chassis clock is set. The IPS clock and parent chassis clock tend to drift apart over time. The difference can be as much as several seconds per day. To avoid this problem, make sure that both the IPS clock and the parent clock are synchronized to an external NTP server. If only the IPS clock or only the parent chassis clock is synchronized to an NTP server, the time drift occurs.

Verifying the Sensor is Synchronized with the NTP Server

In IPS, you cannot apply an incorrect NTP configuration, such as an invalid NTP key value or ID, to the sensor. If you try to apply an incorrect configuration, you receive an error message. To verify the NTP configuration, use the **show statistics host** command to gather sensor statistics. The NTP statistics section provides NTP statistics including feedback on sensor synchronization with the NTP server.

To verify the NTP configuration, follow these steps:

Step 1 Log in to the sensor.

Step 2 Generate the host statistics.

```
sensor# show statistics host
...
NTP Statistics
      remote      refid      st t when poll reach  delay  offset  jitter
11.22.33.44    CHU_AUDIO(1)    8 u  36   64    1   0.536   0.069   0.001
LOCAL(0)      73.78.73.84     5 l  35   64    1   0.000   0.000   0.001
ind assID status  conf reach auth condition last_event cnt
  1 10372 f014   yes  yes  ok    reject  reachable  1
  2 10373 9014   yes  yes  none  reject  reachable  1
status = Not Synchronized
```

Step 3 Generate the hosts statistics again after a few minutes.

```
sensor# show statistics host
...
NTP Statistics
      remote      refid      st t when poll reach  delay  offset  jitter
*11.22.33.44    CHU_AUDIO(1)    8 u  22   64   377   0.518  37.975  33.465
LOCAL(0)      73.78.73.84     5 l  22   64   377   0.000   0.000   0.001
ind assID status  conf reach auth condition last_event cnt
  1 10372 f624   yes  yes  ok    sys.peer reachable  2
  2 10373 9024   yes  yes  none  reject  reachable  2
```

```
status = Synchronized
```

- Step 4** If the status continues to read `Not Synchronized`, check with the NTP server administrator to make sure the NTP server is configured correctly.
-

Correcting Time on the Sensor

If you set the time incorrectly, your stored events will have the incorrect time because they are stamped with the time the event was created. The Event Store time stamp is always based on UTC time. If during the original sensor setup, you set the time incorrectly by specifying 8:00 p.m. rather than 8:00 a.m., when you do correct the error, the corrected time will be set backwards. New events might have times older than old events.

For example, if during the initial setup, you configure the sensor as central time with daylight saving time enabled and the local time is 8:04 p.m., the time is displayed as 20:04:37 CDT and has an offset from UTC of -5 hours (01:04:37 UTC, the next day). A week later at 9:00 a.m., you discover the error: the clock shows 21:00:23 CDT. You then change the time to 9:00 a.m. and now the clock shows 09:01:33 CDT. Because the offset from UTC has not changed, it requires that the UTC time now be 14:01:33 UTC, which creates the time stamp problem.

To ensure the integrity of the time stamp on the event records, you must clear the event archive of the older events by using the **clear events** command.

**Note**

You cannot remove individual events.

For More Information

For the procedure for clearing events, see [Clearing Events, page C-111](#).

Advantages and Restrictions of Virtualization

To avoid configuration problems on your sensor, make sure you understand the advantages and restrictions of virtualization on your sensor.

Virtualization has the following advantages:

- You can apply different configurations to different sets of traffic.
- You can monitor two networks with overlapping IP spaces with one sensor.
- You can monitor both inside and outside of a firewall or NAT device.

Virtualization has the following restrictions:

- You must assign both sides of asymmetric traffic to the same virtual sensor.
- Using VACL capture or SPAN (promiscuous monitoring) is inconsistent with regard to VLAN tagging, which causes problems with VLAN groups.
 - When using Cisco IOS software, a VACL capture port or a SPAN target does not always receive tagged packets even if it is configured for trunking.
 - When using the MSFC, fast path switching of learned routes changes the behavior of VACL captures and SPAN.

- Persistent store is limited.

Virtualization has the following traffic capture requirements:

- The virtual sensor must receive traffic that has 802.1q headers (other than traffic on the native VLAN of the capture port).
- The sensor must see both directions of traffic in the same VLAN group in the same virtual sensor for any given sensor.

The following sensors support virtualization:

- ASA 5500 AIP SSM
- ASA 5500-X IPS SSP
- ASA 5585-X IPS SSP
- IPS 4240
- IPS 4255
- IPS 4260
- IPS 4270-20
- IPS 4345
- IPS 4360
- IPS 4510
- IPS 4520

Supported MIBs

To avoid problems with configuring SNMP, be aware of the MIBs that are supported on the sensor.

The following private MIBs are supported on the sensor:

- CISCO-CIDS-MIB

The CISCO-CIDS-MIB has been updated to include SNMP health data in IPS 7.1(3)E4 and later.

- CISCO-ENHANCED-MEMPOOL-MIB
- CISCO-ENTITY-ALARM-MIB

You can obtain these private Cisco MIBs under the heading SNMP v2 MIBs at this URL:

<http://www.cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml>



Note

MIB II is available on the sensor, but we do not support it. We know that some elements are not correct (for example, the packet counts from the IF MIB on the sensing interfaces). While you can use elements from MIB II, we do not guarantee that they all provide correct information. We fully support the other listed MIBs and their output is correct.



Note

CISCO-PROCESS-MIB is available on the sensor, but we do not support it. We know that some elements are not available. While you can use elements from CISCO-PROCESS-MIB, we do not guarantee that they all provide correct information. We fully support the other listed MIBs and their output is correct.

Troubleshooting RADIUS Authentication

Symptom Attempt limit configured on the IPS sensor may not be enforced for a RADIUS user.

Conditions Applicable for RADIUS users only. The RADIUS user must have logged in to the sensor at least once after RADIUS authentication is enabled or after the sensor is reset or rebooted.

Workaround Log in to the sensor with the correct credentials and from that time on the attempt limit is enforced for that RADIUS user.

For More Information

For detailed information about RADIUS authentication, see [Configuring Authentication and User Parameters, page 4-16](#).

Troubleshooting Global Correlation

Make sure you observe the following when configuring global correlation:

- Because global correlation updates occur through the sensor management interface, firewalls must allow port 443/80 traffic.
- You must have an HTTP proxy server or a DNS server configured to allow global correlation features to function.
- For detailed information about HTTP proxy server configuration, see You must have a valid IPS license to allow global correlation features to function.
- Global correlation features only contain external IP addresses, so if you position a sensor in an internal lab, you may never receive global correlation information.
- Make sure your sensor supports the global correlation features.
- Make sure your IPS version supports the global correlation features.

For More Information

For detailed information about global correlation, see [Chapter 10, “Configuring Global Correlation.”](#)

When to Disable Anomaly Detection

If you have anomaly detection enabled and you have your sensor configured to see only one direction of traffic, you should disable anomaly detection. Otherwise, you will receive many alerts, because anomaly detection sees asymmetric traffic as having incomplete connections, that is, like worm scanners, and fires alerts.

To disable anomaly detection, follow these steps:

Step 1 Log in to the CLI using an account with administrator privileges.

Step 2 Enter analysis engine submode.

```
sensor# configure terminal
sensor(config)# service analysis-engine
```

```
sensor(config-ana)#
```

Step 3 Enter the virtual sensor name that contains the anomaly detection policy you want to disable.

```
sensor(config-ana)# virtual-sensor vs0
sensor(config-ana-vir)#
```

Step 4 Disable anomaly detection operational mode.

```
sensor(config-ana-vir)# anomaly-detection
sensor(config-ana-vir-ano)# operational-mode inactive
sensor(config-ana-vir-ano)#
```

Step 5 Exit analysis engine submode.

```
sensor(config-ana-vir-ano)# exit
sensor(config-ana-vir)# exit
sensor(config-ana)# exit
Apply Changes:[yes]:
```

Step 6 Press **Enter** to apply your changes or enter **no** to discard them.

For More Information

To learn more about Worms, see [Understanding Worms, page 9-2](#).

Analysis Engine Not Responding

Error Message Output from show statistics analysis-engine
 Error: getAnalysisEngineStatistics : ct-sensorApp.424 not responding, please check system processes - The connect to the specified Io::ClientPipe failed.

Error Message Output from show statistics anomaly-detection
 Error: getAnomalyDetectionStatistics : ct-sensorApp.424 not responding, please check system processes - The connect to the specified Io::ClientPipe failed.

Error Message Output from show statistics denied-attackers
 Error: getDeniedAttackersStatistics : ct-sensorApp.424 not responding, please check system processes - The connect to the specified Io::ClientPipe failed.

Possible Cause These error messages appear when you run the **show tech support** command and the Analysis Engine is not running.

Recommended Action Verify the Analysis Engine is running and monitor it to see if the issue is resolved.

To verify the Analysis Engine is running and to monitor the issue, follow these steps:

Step 1 Log in to the sensor.

Step 2 Verify that the Analysis Engine is not running. Check to see if the Analysis Engine reads **Not Running**.

```
sensor# show version
```

```

-----
MainApp N-2007_JUN_19_16_45 (Release) 2007-06-19T17:10:20-0500 Running
AnalysisEngine N-2007_JUN_19_16_45 (Release) 2007-06-19T17:10:20-0500 Not Running
CLI N-2007_JUN_19_16_45 (Release) 2007-06-19T17:10:20-0500

```

- Step 3** Enter **show tech-support** and save the output.
- Step 4** Reboot the sensor.
- Step 5** Enter **show version** after the sensor has stabilized to see if the issue is resolved.
- Step 6** If the Analysis Engine still reads `Not Running`, contact TAC with the original **show tech support** command output.

Troubleshooting External Product Interfaces

This section lists issues that can occur with external product interfaces and provides troubleshooting tips. For more information on external product interfaces, see [Chapter 11, “Configuring External Product Interfaces.”](#) This section contains the following topics:

- [External Product Interfaces Issues, page C-23](#)
- [External Product Interfaces Troubleshooting Tips, page C-24](#)

External Product Interfaces Issues

When the external product interface receives host posture and quarantine events, the following issues can arise:

- The sensor can store only a certain number of host records:
 - If the number of records exceeds 10,000, subsequent records are dropped.
 - If the 10,000 limit is reached and then it drops to below 9900, new records are no longer dropped.
- Hosts can change an IP address or appear to use another host IP address, for example, because of DHCP lease expiration or movement in a wireless network. In the case of an IP address conflict, the sensor presumes the most recent host posture event to be the most accurate.
- A network can include overlapping IP address ranges in different VLANs, but host postures do not include VLAN ID information. You can configure the sensor to ignore specified address ranges.
- A host can be unreachable from the CSA MC because it is behind a firewall. You can exclude unreachable hosts.
- The CSA MC event server allows up to ten open subscriptions by default. You can change this value. You must have an administrative account and password to open subscriptions.
- CSA data is not virtualized; it is treated globally by the sensor.
- Host posture OS and IP addresses are integrated into passive OS fingerprinting storage. You can view them as imported OS profiles.
- You cannot see the quarantined hosts.
- The sensor must recognize each CSA MC host X.509 certificate. You must add them as a trusted host.

- You can configure a maximum of two external product devices.

For More Information

- For more information on working with OS maps and identifications, see [Adding, Editing, Deleting, and Moving Configured OS Maps, page 7-28](#) and [Displaying and Clearing OS Identifications, page 7-32](#).
- For the procedure for adding trusted hosts, see [Adding TLS Trusted Hosts, page 4-51](#).

External Product Interfaces Troubleshooting Tips

To troubleshoot external product interfaces, check the following:

- Make sure the interface is active by checking the output from the **show statistics external-product-interface** command in the CLI, or choose **Monitoring > Sensor Monitoring > Support Information > Statistics** in the IDM and check the Interface state line in the response, or choose **Configuration > sensor_name > Sensor Monitoring > Support Information > Statistics** in the IME, and check the Interface state line in the response.
- Make sure you have added the CSA MC IP address to the trusted hosts. If you forgot to add it, add it, wait a few minutes and then check again.
- Confirm subscription login information by opening and closing a subscription on the CSA MC using the browser.
- Check the Event Store for the CSA MC subscription errors.

For More Information

- For the procedure for adding trusted hosts, see [Adding TLS Trusted Hosts, page 4-51](#).
- For the procedure for displaying events, see [Displaying Events, page C-108](#).

Troubleshooting the Appliance

This section contains information to troubleshoot the appliance. It contains the following topics:

- [The Appliance and Jumbo Packet Frame Size, page C-25](#)
- [Troubleshooting Loose Connections, page C-25](#)
- [The Analysis Engine is Busy, page C-25](#)
- [Connecting the IPS 4240 to a Cisco 7200 Series Router, page C-26](#)
- [Communication Problems, page C-26](#)
- [The SensorApp and Alerting, page C-31](#)
- [Blocking, page C-38](#)
- [Logging, page C-47](#)
- [TCP Reset Not Occurring for a Signature, page C-52](#)
- [Software Upgrades, page C-54](#)

**Tip**

Before troubleshooting the appliance, check the Caveats section of the Readme for the software version you have installed on your sensor to see if you are dealing with a known issue.

The Appliance and Jumbo Packet Frame Size

For IPS standalone appliances with 1 G and 10 G fixed or add-on interfaces, the maximum jumbo frame size is 9216 bytes.

**Note**

A jumbo frame is an Ethernet packet that is larger than the standard maximum of 1518 bytes (including Layer 2 header and FCS).

Troubleshooting Loose Connections

Perform the following actions to troubleshoot loose connections on sensors:

- Make sure all power cords are securely connected.
- Make sure all cables are properly aligned and securely connected for all external and internal components.
- Remove and check all data and power cables for damage. Make sure no cables have bent pins or damaged connectors.
- Make sure each device is properly seated.
- If a device has latches, make sure they are completely closed and locked.
- Check any interlock or interconnect indicators that indicate a component is not connected properly.
- If problems continue, remove and reinstall each device, checking the connectors and sockets for bent pins or other damage.

The Analysis Engine is Busy

After you reimage a sensor, the Analysis Engine is busy rebuilding Regex tables and does not respond to new configurations. You can check whether the Analysis Engine is busy by using the **show statistics virtual-sensor** command. You receive the following error message if the Analysis Engine is busy:

```
sensor# show statistics virtual-sensor
Error: getVirtualSensorStatistics : Analysis Engine is busy rebuilding regex tables. This
may take a while.
sensor#
```

When the Analysis Engine is busy rebuilding Regex tables, you receive an error message if you try to update a configuration, for example, enabling or retiring a signature:

```
sensor# configure terminal
sensor(config)# service sig sig0
sensor(config-sig)# sig 2000 0
sensor(config-sig-sig)# status enabled
sensor(config-sig-sig)# status
sensor(config-sig-sig-sta)# enabled true
sensor(config-sig-sig-sta)# retired false
```

```
sensor(config-sig-sig-sta)# exit
sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes?[yes]:
Error: editConfigDeltaSignatureDefinition : Analysis Engine is busy rebuilding regex
tables. This may take a while.
The configuration changes failed validation, no changes were applied.
Would you like to return to edit mode to correct the errors? [yes]: no
No changes were made to the configuration.
sensor(config)#
```

If you try to get the virtual sensor statistics immediately after you boot a sensor, you receive an error message. Although the sensor has rebuilt the cache files, the virtual sensor is not finished initializing.

```
sensor# show statistics virtual-sensor
Error: getVirtualSensorStatistics : Analysis Engine is busy.
sensor#
```

When you receive the errors that the Analysis Engine is busy, wait a while before trying to make configuration changes. Use the **show statistics virtual-sensor** command to find out when the Analysis Engine is available again.

Connecting the IPS 4240 to a Cisco 7200 Series Router

When an IPS 4240 is connected directly to a 7200 series router and both the IPS 4240 and the router interfaces are hard-coded to a speed of 100 with the duplex set to Full, the connection does not work. If you set both the IPS 4240 speed and duplex to Auto, it connects to the router but only at a speed of 100 and a duplex of Half.

To connect correctly at a speed of 100 and a duplex of Full, configure the interfaces of both the IPS 4240 and the router with the speed and duplex both set to Auto. Also, if either interface is hard-coded, you must make the connection using a crossover cable.

Communication Problems

This section helps you troubleshoot communication problems with the 4200 series sensor. It contains the following topics:

- [Cannot Access the Sensor CLI Through Telnet or SSH, page C-26](#)
- [Correcting a Misconfigured Access List, page C-29](#)
- [Duplicate IP Address Shuts Interface Down, page C-29](#)

Cannot Access the Sensor CLI Through Telnet or SSH

If you cannot access the sensor CLI through Telnet (if you already have it enabled) or SSH, follow these steps:

-
- Step 1** Log in to the sensor CLI through a console, terminal, or module session.
 - Step 2** Make sure that the sensor management interface is enabled. The management interface is the interface in the list with the status line `Media Type = TX`. If the Link Status is `Down`, go to Step 3. If the Link Status is `Up`, go to Step 5.

```
sensor# show interfaces
```

```

Interface Statistics
  Total Packets Received = 0
  Total Bytes Received = 0
  Missed Packet Percentage = 0
  Current Bypass Mode = Auto_off
MAC statistics from interface GigabitEthernet0/1
  Media Type = backplane
  Missed Packet Percentage = 0
  Inline Mode = Unpaired
  Pair Status = N/A
  Link Status = Up
  Link Speed = Auto_1000
  Link Duplex = Auto_Full
  Total Packets Received = 0
  Total Bytes Received = 0
  Total Multicast Packets Received = 0
  Total Broadcast Packets Received = 0
  Total Jumbo Packets Received = 0
  Total Undersize Packets Received = 0
  Total Receive Errors = 0
  Total Receive FIFO Overruns = 0
  Total Packets Transmitted = 0
  Total Bytes Transmitted = 0
  Total Multicast Packets Transmitted = 0
  Total Broadcast Packets Transmitted = 0
  Total Jumbo Packets Transmitted = 0
  Total Undersize Packets Transmitted = 0
  Total Transmit Errors = 0
  Total Transmit FIFO Overruns = 0
MAC statistics from interface GigabitEthernet0/0
  Media Type = TX
  Link Status = Up
  Link Speed = Auto_100
  Link Duplex = Auto_Full
  Total Packets Received = 944333
  Total Bytes Received = 83118358
  Total Multicast Packets Received = 0
  Total Receive Errors = 0
  Total Receive FIFO Overruns = 0
  Total Packets Transmitted = 397633
  Total Bytes Transmitted = 435730956
  Total Transmit Errors = 0
  Total Transmit FIFO Overruns = 0
sensor#

```

- Step 3** Make sure the sensor IP address is unique. If the management interface detects that another device on the network has the same IP address, it does not come up.

```

sensor# setup
--- System Configuration Dialog ---

```

At any point you may enter a question mark '?' for help.
 User ctrl-c to abort configuration dialog at any prompt.
 Default settings are in square brackets '[]'.

Current Configuration:

```

service host
network-settings
host-ip 192.168.1.2/24,192.168.1.1
host-name sensor
telnet-option enabled

```

```
access-list 0.0.0.0/0
ftp-timeout 300
no login-banner-text
exit
--MORE--
```

- Step 4** Make sure the management port is connected to an active network connection. If the management port is not connected to an active network connection, the management interface does not come up.
- Step 5** Make sure the IP address of the workstation that is trying to connect to the sensor is permitted in the sensor access list. If the workstation network address is permitted in the sensor access list, go to Step 6.

```
sensor# setup
--- System Configuration Dialog ---
```

At any point you may enter a question mark '?' for help.
 User ctrl-c to abort configuration dialog at any prompt.
 Default settings are in square brackets '[]'.

Current Configuration:

```
service host
network-settings
host-ip 192.168.1.2/24,192.168.1.1
host-name sensor
telnet-option enabled
access-list 0.0.0.0/0
ftp-timeout 300
no login-banner-text
exit
--MORE--
```

- Step 6** Add a permit entry for the workstation network address, save the configuration, and try to connect again.
- Step 7** Make sure the network configuration allows the workstation to connect to the sensor. If the sensor is protected behind a firewall and the workstation is in front of the firewall, make sure the firewall is configured to allow the workstation to access the sensor. Or if the workstation is behind a firewall that is performing network address translation on the workstation IP address, and the sensor is in front of the firewall, make sure that the sensor access list contains a permit entry for the workstation translated address.

For More Information

- For the procedure for enabling and disabling Telnet on the sensor, see [Enabling and Disabling Telnet, page 4-5](#).
- For the various ways to open a CLI session directly on the sensor, see [Chapter 2, “Logging In to the Sensor.”](#)
- For the procedure for changing the IP address, see [Changing the IP Address, Netmask, and Gateway, page 4-4](#).
- For the procedure for changing the access list, see [Correcting a Misconfigured Access List, page C-29](#).

Correcting a Misconfigured Access List

To correct a misconfigured access list, follow these steps:

Step 1 Log in to the CLI.

Step 2 View your configuration to see the access list.

```
sensor# show configuration | include access-list
access-list 10.0.0.0/8
access-list 64.0.0.0/8
sensor#
```

Step 3 Verify that the client IP address is listed in the allowed networks. If it is not, add it.

```
sensor# configure terminal
sensor(config)# service host
sensor(config-hos)# network-settings
sensor(config-hos-net)# access-list 171.69.70.0/24
```

Step 4 Verify the settings.

```
sensor(config-hos-net)# show settings
network-settings
-----
host-ip: 192.168.1.2/24,192.168.1.1 default: 10.1.9.201/24,10.1.9.1
host-name: sensor-238 default: sensor
telnet-option: enabled default: disabled
access-list (min: 0, max: 512, current: 3)
-----
network-address: 10.0.0.0/8
-----
network-address: 64.0.0.0/8
-----
network-address: 171.69.70.0/24
-----
ftp-timeout: 300 seconds <defaulted>
login-banner-text: <defaulted>
-----
sensor(config-hos-net)#
```

Duplicate IP Address Shuts Interface Down

If you have two newly imaged sensors with the same IP address that come up on the same network at the same time, the interface shuts down. Linux prevents the command and control interface from activating if it detects an address conflict with another host.

To verify that the sensor in question does not have an IP address conflict with another host on the network, follow these steps:

Step 1 Log in to the CLI.

Step 2 Determine whether the interface is up. If the output says the command and control interface link status is down, there is a hardware issue or an IP address conflict.

```
sensor# show interfaces
Interface Statistics
Total Packets Received = 0
```

```

Total Bytes Received = 0
Missed Packet Percentage = 0
Current Bypass Mode = Auto_off
MAC statistics from interface GigabitEthernet0/1
Media Type = backplane
Missed Packet Percentage = 0
Inline Mode = Unpaired
Pair Status = N/A
Link Status = Up
Link Speed = Auto_1000
Link Duplex = Auto_Full
Total Packets Received = 0
Total Bytes Received = 0
Total Multicast Packets Received = 0
Total Broadcast Packets Received = 0
Total Jumbo Packets Received = 0
Total Undersize Packets Received = 0
Total Receive Errors = 0
Total Receive FIFO Overruns = 0
Total Packets Transmitted = 0
Total Bytes Transmitted = 0
Total Multicast Packets Transmitted = 0
Total Broadcast Packets Transmitted = 0
Total Jumbo Packets Transmitted = 0
Total Undersize Packets Transmitted = 0
Total Transmit Errors = 0
Total Transmit FIFO Overruns = 0
MAC statistics from interface GigabitEthernet0/0
Media Type = TX
Link Status = Up
Link Speed = Auto_100
Link Duplex = Auto_Full
Total Packets Received = 1822323
Total Bytes Received = 131098876
Total Multicast Packets Received = 20
Total Receive Errors = 0
Total Receive FIFO Overruns = 0
Total Packets Transmitted = 219260
Total Bytes Transmitted = 103668610
Total Transmit Errors = 0
Total Transmit FIFO Overruns = 0
sensor#

```

Step 3 Make sure the sensor cabling is correct.

Step 4 Make sure the IP address is correct.

For More Information

- To make sure the sensor cabling is correct, refer to the chapter for your sensor in [Cisco Intrusion Prevention System Appliances and Modules Installation Guide for IPS 7.1](#).
- For the procedure for making sure the IP address is correct, see [Changing Network Settings, page 4-2](#).

The SensorApp and Alerting

This section helps you troubleshoot issues with the SensorApp and alerting. It contains the following topics:

- [The SensorApp is Not Running, page C-31](#)
- [Physical Connectivity, SPAN, or VACL Port Issue, page C-32](#)
- [Unable to See Alerts, page C-34](#)
- [Sensor Not Seeing Packets, page C-35](#)
- [Cleaning Up a Corrupted SensorApp Configuration, page C-37](#)

The SensorApp is Not Running

The sensing process, SensorApp, should always be running. If it is not, you do not receive any alerts. The SensorApp is part of the Analysis Engine, so you must make sure the Analysis Engine is running.

To make sure the Analysis Engine is running, follow these steps:

Step 1 Log in to the CLI.

Step 2 Determine the status of the Analysis Engine service and whether you have the latest software updates.

```

sensor# show version
Application Partition:

Cisco Intrusion Prevention System, Version 7.1(3)E4

Host:
  Realm Keys          key1.0
Signature Definition:
  Signature Update     S605.0          2011-10-25
OS Version:           2.6.29.1
Platform:             ASA5585-SSP-IPS10
Serial Number:        123456789AB
No license present
Sensor up-time is 13 days.
Using 4395M out of 5839M bytes of available memory (75% usage)
system is using 26.2M out of 160.0M bytes of available disk space (16% usage)
application-data is using 69.7M out of 171.6M bytes of available disk space (43%
usage)
boot is using 57.3M out of 70.5M bytes of available disk space (86% usage)
application-log is using 494.0M out of 513.0M bytes of available disk space (96%
usage)

MainApp              S-2011_NOV_16_00_20_7_1_3_46  (Release)  2011-11-16T00:23:0
6-0600  Running
AnalysisEngine       S-2011_NOV_16_00_20_7_1_3_46  (Release)  2011-11-16T00:23:0
6-0600  Running
CollaborationApp     S-2011_NOV_16_00_20_7_1_3_46  (Release)  2011-11-16T00:23:0
6-0600  Running
CLI                  S-2011_NOV_16_00_20_7_1_3_46  (Release)  2011-11-16T00:23:0
6-0600

Upgrade History:

IPS-K9-7.1-3-E4    00:30:07 UTC Wed Nov 16 2011

```

Recovery Partition Version 1.1 - 7.1(3)E4

Host Certificate Valid from: 16-Nov-2011 to 16-Nov-2013
sensor#

Step 3 If the Analysis Engine is not running, look for any errors connected to it.

```
sensor# show events error fatal past 13:00:00 | include AnalysisEngine
evError: eventId=1077219258696330005 severity=warning

originator:
hostId: sensor
appName: sensorApp
appInstanceId: 1045
time: 2004/02/19 19:34:20 2004/02/19 19:34:20 UTC
errorMessage: name=errUnclassified Generating new Analysis Engine configuration file.
```



Note The date and time of the last restart is listed. In this example, the last restart was on 2-19-2004 at 7:34.

- Step 4** If you do not have the latest software updates, download them from Cisco.com. Read the Readme that accompanies the software upgrade for any known DDTs for the SensorApp or the Analysis Engine.
- Step 5** If the Analysis Engine is still not running, enter **show tech-support** and save the output.
- Step 6** Reboot the sensor.
- Step 7** Enter **show version** after the sensor has stabilized to see if the issue is resolved.
- Step 8** If the Analysis Engine still reads `Not Running`, contact the TAC with the original **show tech support** command output.

For More Information

- For more information on IPS system architecture, see [Chapter A, “System Architecture.”](#)
- For the procedure for obtaining the latest Cisco IPS software, see [Obtaining Cisco IPS Software, page 21-1.](#)

Physical Connectivity, SPAN, or VACL Port Issue

If the sensor is not connected properly, you do not receive any alerts.

To make sure the sensor is connected properly, follow these steps:

- Step 1** Log in to the CLI.
- Step 2** Make sure the interfaces are up and that the packet count is increasing.

```
sensor# show interfaces
Interface Statistics
  Total Packets Received = 0
  Total Bytes Received = 0
  Missed Packet Percentage = 0
  Current Bypass Mode = Auto_off
MAC statistics from interface GigabitEthernet0/1
  Media Type = backplane
  Missed Packet Percentage = 0
```



```

Inline Mode = Unpaired
Pair Status = N/A
Link Status = Up
Link Speed = Auto_1000
Link Duplex = Auto_Full
Total Packets Received = 0
Total Bytes Received = 0
Total Multicast Packets Received = 0
Total Broadcast Packets Received = 0
Total Jumbo Packets Received = 0
Total Undersize Packets Received = 0
Total Receive Errors = 0
Total Receive FIFO Overruns = 0
Total Packets Transmitted = 0
Total Bytes Transmitted = 0
Total Multicast Packets Transmitted = 0
Total Broadcast Packets Transmitted = 0
Total Jumbo Packets Transmitted = 0
Total Undersize Packets Transmitted = 0
Total Transmit Errors = 0
Total Transmit FIFO Overruns = 0
MAC statistics from interface GigabitEthernet0/0
Media Type = TX
Link Status = Up
Link Speed = Auto_100
Link Duplex = Auto_Full
Total Packets Received = 1830137
Total Bytes Received = 131624465
Total Multicast Packets Received = 20
Total Receive Errors = 0
Total Receive FIFO Overruns = 0
Total Packets Transmitted = 220052
Total Bytes Transmitted = 103796666
Total Transmit Errors = 0
Total Transmit FIFO Overruns = 0
sensor#

```

Step 3 If the Link Status is down, make sure the sensing port is connected properly:

- Make sure the sensing port is connected properly on the appliance.

Step 4 Verify the interface configuration:

- Make sure you have the interfaces configured properly.
- Verify the SPAN and VACL capture port configuration on the Cisco switch.

Refer to your switch documentation for the procedure.

Step 5 Verify again that the interfaces are up and that the packet count is increasing.

```
sensor# show interfaces
```

For More Information

- For the procedure for properly installing the sensing interface on your sensor, refer to the chapter on your appliance in [Cisco Intrusion Prevention System Appliances and Modules Installation Guide for IPS 7.1](#).
- For the procedures for configuring interfaces on your sensor, see [Chapter 5, “Configuring Interfaces.”](#)

Unable to See Alerts

If you are not seeing alerts, try the following:

- Make sure the signature is enabled
- Make sure the signature is not retired
- Make sure that you have Produce Alert configured as an action



Note

If you choose Produce Alert, but come back later and add another event action and do not add Produce Alert to the new configuration, alerts are not sent to the Event Store. Every time you configure a signature, the new configuration overwrites the old one, so make sure you have configured all the event actions you want for each signature.

- Make sure the sensor is seeing packets
- Make sure that alerts are being generated
- Make sure the sensing interface is in a virtual sensor

To make sure you can see alerts, follow these steps:

Step 1 Log in to the CLI.

Step 2 Make sure the signature is enabled.

```
sensor# configure terminal
sensor(config)# service signature-definition sig0
sensor(config-sig)# signatures 1300 0
sensor(config-sig-sig)# status
sensor(config-sig-sig-sta)# show settings
status
-----
enabled: true <defaulted>
retired: false <defaulted>
-----
sensor(config-sig-sig-sta)#
```

Step 3 Make sure you have Produce Alert configured.

```
sensor# configure terminal
sensor(config)# service signature-definition sig0
sensor(config-sig)# signatures 1300 0
sensor(config-sig-sig)# engine ?
normalizer      Signature engine
sensor(config-sig-sig)# engine normalizer
sensor(config-sig-sig-nor)# event-action produce-alert
sensor(config-sig-sig-nor)# show settings
normalizer
-----
event-action: produce-alert default: produce-alert|deny-connection-inline
edit-default-sigs-only
-----
sensor#
```

Step 4 Make sure the sensor is seeing packets.

```
sensor# show interfaces FastEthernet0/1
MAC statistics from interface FastEthernet0/1
Media Type = backplane
Missed Packet Percentage = 0
```

```

Inline Mode = Unpaired
Pair Status = N/A
Link Status = Up
Link Speed = Auto_100
Link Duplex = Auto_Full
Total Packets Received = 267581
Total Bytes Received = 24886471
Total Multicast Packets Received = 0
Total Broadcast Packets Received = 0
Total Jumbo Packets Received = 0
Total Undersize Packets Received = 0
Total Receive Errors = 0
Total Receive FIFO Overruns = 0
Total Packets Transmitted = 57301
Total Bytes Transmitted = 3441000
Total Multicast Packets Transmitted = 0
Total Broadcast Packets Transmitted = 0
Total Jumbo Packets Transmitted = 0
Total Undersize Packets Transmitted = 0
Total Transmit Errors = 1
Total Transmit FIFO Overruns = 0
sensor#

```

Step 5 Check for alerts.

```

sensor# show statistics virtual-sensor
SigEvent Preliminary Stage Statistics
  Number of Alerts received = 0
  Number of Alerts Consumed by AlertInterval = 0
  Number of Alerts Consumed by Event Count = 0
  Number of FireOnce First Alerts = 0
  Number of FireOnce Intermediate Alerts = 0
  Number of Summary First Alerts = 0
  Number of Summary Intermediate Alerts = 0
  Number of Regular Summary Final Alerts = 0
  Number of Global Summary Final Alerts = 0
  Number of Alerts Output for further processing = 0alertDetails: Traffic Source: int0 ;

```

Sensor Not Seeing Packets

If the sensor is not seeing any packets on the network, you could have the interfaces set up incorrectly.

If the sensor is not seeing packets, follow these steps:

Step 1 Log in to the CLI.

Step 2 Make sure the interfaces are up and receiving packets.

```

sensor# show interfaces GigabitEthernet0/1
MAC statistics from interface GigabitEthernet0/1
  Media Type = backplane
  Missed Packet Percentage = 0
  Inline Mode = Unpaired
  Pair Status = N/A
  Link Status = Down
  Link Speed = Auto_1000
  Link Duplex = Auto_Full
  Total Packets Received = 0
  Total Bytes Received = 0
  Total Multicast Packets Received = 0

```

```
Total Broadcast Packets Received = 0
Total Jumbo Packets Received = 0
Total Undersize Packets Received = 0
Total Receive Errors = 0
Total Receive FIFO Overruns = 0
Total Packets Transmitted = 0
Total Bytes Transmitted = 0
Total Multicast Packets Transmitted = 0
Total Broadcast Packets Transmitted = 0
Total Jumbo Packets Transmitted = 0
Total Undersize Packets Transmitted = 0
Total Transmit Errors = 0
Total Transmit FIFO Overruns = 0
sensor#
```

Step 3 If the interfaces are not up, do the following:

- Check the cabling.
- Enable the interface.

```
sensor# configure terminal
sensor(config)# service interface
sensor(config-int)# physical-interfaces GigabitEthernet0/1
sensor(config-int-phy)# admin-state enabled
sensor(config-int-phy)# show settings
<protected entry>
name: GigabitEthernet0/1
-----
media-type: tx <protected>
description: <defaulted>
admin-state: enabled default: disabled
duplex: auto <defaulted>
speed: auto <defaulted>
alt-tcp-reset-interface
-----
none
-----
-----
-----
sensor(config-int-phy)#
```

Step 4 Check to see that the interface is up and receiving packets.

```
sensor# show interfaces
MAC statistics from interface GigabitEthernet0/1
Media Type = TX
Missed Packet Percentage = 0
Inline Mode = Unpaired
Pair Status = N/A
Link Status = Up
Link Speed = Auto_100
Link Duplex = Auto_Full
Total Packets Received = 3
Total Bytes Received = 900
Total Multicast Packets Received = 3
Total Broadcast Packets Received = 0
Total Jumbo Packets Received = 0
Total Undersize Packets Received = 0
Total Receive Errors = 0
Total Receive FIFO Overruns = 0
Total Packets Transmitted = 0
Total Bytes Transmitted = 0
Total Multicast Packets Transmitted = 0
```

```
Total Broadcast Packets Transmitted = 0
Total Jumbo Packets Transmitted = 0
Total Undersize Packets Transmitted = 0
Total Transmit Errors = 0
Total Transmit FIFO Overruns = 0 ...
```

For More Information

For the procedure for installing the sensor properly, refer to your sensor chapter in [Cisco Intrusion Prevention System Appliances and Modules Installation Guide for IPS 7.1](#).

Cleaning Up a Corrupted SensorApp Configuration

If the SensorApp configuration has become corrupted and the SensorApp cannot run, you must delete it entirely and restart the SensorApp.

To delete the SensorApp configuration, follow these steps:

-
- Step 1** Log in to the service account.
 - Step 2** Su to root.
 - Step 3** Stop the IPS applications.
`/etc/init.d/cids stop`
 - Step 4** Replace the virtual sensor file.
`cp /usr/cids/idsRoot/etc/defVirtualSensorConfig.xml
/usr/cids/idsRoot/etc/VS-Config/virtualSensor.xml`
 - Step 5** Remove the cache files.
`rm /usr/cids/idsRoot/var/virtualSensor/*.pmz`
 - Step 6** Exit the service account.
 - Step 7** Log in to the sensor CLI.
 - Step 8** Start the IPS services.
`sensor# cids start`
 - Step 9** Log in to an account with administrator privileges.
 - Step 10** Reboot the sensor.
`sensor# reset`
Warning: Executing this command will stop all applications and reboot the node.
Continue with reset? [yes]:**yes**
Request Succeeded.
`sensor#`
-

For More Information

To learn more about IPS system architecture, see [Appendix A, “System Architecture.”](#)

Blocking

This section provides troubleshooting help for blocking and the ARC service. It contains the following topics.

- [Troubleshooting Blocking, page C-38](#)
- [Verifying the ARC is Running, page C-39](#)
- [Verifying ARC Connections are Active, page C-40](#)
- [Device Access Issues, page C-41](#)
- [Verifying the Interfaces and Directions on the Network Device, page C-43](#)
- [Enabling SSH Connections to the Network Device, page C-44](#)
- [Blocking Not Occurring for a Signature, page C-44](#)
- [Verifying the Master Blocking Sensor Configuration, page C-45](#)

Troubleshooting Blocking

After you have configured the ARC, you can verify if it is running properly by using the **show version** command. To verify that the ARC is connecting to the network devices, use the **show statistics network-access** command.



Note

The ARC was formerly known as Network Access Controller. Although the name has been changed since IPS 5.1, it still appears in IDM, IME, and the CLI as Network Access Controller, **nac**, and **network-access**.

To troubleshoot the ARC, follow these steps:

1. Verify that the ARC is running.
2. Verify that the ARC is connecting to the network devices.
3. Verify that the Event Action is set to Block Host for specific signatures.
4. Verify that the master blocking sensor is properly configured.

For More Information

- For the procedure to verify that the ARC is running, see [Verifying the ARC is Running, page C-39](#).
- For the procedure to verify that the ARC is connecting, see [Verifying ARC Connections are Active, page C-40](#).
- For the procedure to verify that the Event Action is set to Block Host, see [Blocking Not Occurring for a Signature, page C-44](#).
- For the procedure to verify that the master blocking sensor is properly configured, see [Verifying the Master Blocking Sensor Configuration, page C-45](#).
- For a discussion of ARC architecture, see [Attack Response Controller, page A-12](#).

Verifying the ARC is Running

To verify that the ARC is running, use the **show version** command. If the MainApp is not running, the ARC cannot run. The ARC is part of the MainApp.

To verify that the ARC is running, follow these steps:

Step 1 Log in to the CLI.

Step 2 Verify that the MainApp is running.

```

sensor# show version
Application Partition:

Cisco Intrusion Prevention System, Version 7.1(3)E4

Host:
  Realm Keys          key1.0
Signature Definition:
  Signature Update    S605.0          2011-10-25
OS Version:          2.6.29.1
Platform:            ASA5585-SSP-IPS10
Serial Number:       123456789AB
No license present
Sensor up-time is 13 days.
Using 4395M out of 5839M bytes of available memory (75% usage)
system is using 26.2M out of 160.0M bytes of available disk space (16% usage)
application-data is using 69.7M out of 171.6M bytes of available disk space (43%
usage)
boot is using 57.3M out of 70.5M bytes of available disk space (86% usage)
application-log is using 494.0M out of 513.0M bytes of available disk space (96%
usage)

MainApp              S-2011_NOV_16_00_20_7_1_3_46  (Release)  2011-11-16T00:23:0
6-0600  Running
AnalysisEngine       S-2011_NOV_16_00_20_7_1_3_46  (Release)  2011-11-16T00:23:0
6-0600  Running
CollaborationApp     S-2011_NOV_16_00_20_7_1_3_46  (Release)  2011-11-16T00:23:0
6-0600  Running
CLI                  S-2011_NOV_16_00_20_7_1_3_46  (Release)  2011-11-16T00:23:0
6-0600

Upgrade History:

  IPS-K9-7.1-3-E4    00:30:07 UTC Wed Nov 16 2011

Recovery Partition Version 1.1 - 7.1(3)E4

Host Certificate Valid from: 16-Nov-2011 to 16-Nov-2013

sensor#

```

Step 3 If the MainApp displays Not Running, the ARC has failed. Contact the TAC.

For More Information

To learn more about IPS system architecture, see [Appendix A, “System Architecture.”](#)

Verifying ARC Connections are Active

If the State is not `Active` in the ARC statistics, there is a problem.

To verify that the State is `Active` in the statistics, follow these steps:

Step 1 Log in to the CLI.

Step 2 Verify that the ARC is connecting. Check the State section of the output to verify that all devices are connecting.

```
sensor# show statistics network-access
Current Configuration
  LogAllBlockEventsAndSensors = true
  EnableNvramWrite = false
  EnableAclLogging = false
  AllowSensorBlock = false
  BlockMaxEntries = 250
  MaxDeviceInterfaces = 250
  NetDevice
    Type = Cisco
    IP = 10.89.147.54
    NATAddr = 0.0.0.0
    Communications = telnet
    BlockInterface
      InterfaceName = fa0/0
      InterfaceDirection = in
  State
    BlockEnable = true
    NetDevice
      IP = 10.89.147.54
      AclSupport = uses Named ACLs
      Version = 12.2
      State = Active
sensor#
```

Step 3 If the ARC is not connecting, look for recurring errors.

```
sensor# show events error hh:mm:ss month day year | include : nac
```

Example

```
sensor# show events error 00:00:00 Apr 01 2011 | include : nac
```

Step 4 Make sure you have the latest software updates.

```
sensor# show version
Application Partition:

Cisco Intrusion Prevention System, Version 7.1(3)E4

Host:
  Realm Keys          key1.0
Signature Definition:
  Signature Update     S605.0          2011-10-25
OS Version:           2.6.29.1
Platform:             ASA5585-SSP-IPS10
Serial Number:         123456789AB
No license present
Sensor up-time is 13 days.
Using 4395M out of 5839M bytes of available memory (75% usage)
system is using 26.2M out of 160.0M bytes of available disk space (16% usage)
application-data is using 69.7M out of 171.6M bytes of available disk space (43% usage)
```



```
boot is using 57.3M out of 70.5M bytes of available disk space (86% usage)
application-log is using 494.0M out of 513.0M bytes of available disk space (96%
usage)
```

```
MainApp          S-2011_NOV_16_00_20_7_1_3_46  (Release)  2011-11-16T00:23:0
6-0600  Running
AnalysisEngine   S-2011_NOV_16_00_20_7_1_3_46  (Release)  2011-11-16T00:23:0
6-0600  Running
CollaborationApp S-2011_NOV_16_00_20_7_1_3_46  (Release)  2011-11-16T00:23:0
6-0600  Running
CLI              S-2011_NOV_16_00_20_7_1_3_46  (Release)  2011-11-16T00:23:0
6-0600
```

Upgrade History:

```
IPS-K9-7.1-3-E4   00:30:07 UTC Wed Nov 16 2011
```

Recovery Partition Version 1.1 - 7.1(3)E4

Host Certificate Valid from: 16-Nov-2011 to 16-Nov-2013

sensor#



Note If you do not have the latest software updates, download them from Cisco.com. Read the Readme that accompanies the software upgrade for any known DDTs for the ARC.

- Step 5** Make sure the configuration settings for each device are correct (the username, password, and IP address).
- Step 6** Make sure the interface and directions for each network device are correct.
- Step 7** If the network device is using SSH-3DES, make sure that you have enabled SSH connections to the device.
- Step 8** Verify that each interface and direction on each controlled device is correct.

For More Information

- For the procedure for obtaining the latest Cisco IPS software, see [Obtaining Cisco IPS Software, page 21-1](#).
- For more information about configuring devices, see [Device Access Issues, page C-41](#).
- For the procedure for verifying the interfaces and directions for each network device, see [Verifying the Interfaces and Directions on the Network Device, page C-43](#).
- For the procedure for enabling SSH, see [Enabling SSH Connections to the Network Device, page C-44](#).

Device Access Issues

The ARC may not be able to access the devices it is managing. Make sure the you have the correct IP address and username and password for the managed devices and the correct interface and direction configured.



Note

SSH devices must support SSH 1.5. The sensor does not support SSH 2.0.

To troubleshoot device access issues, follow these steps:

Step 1 Log in to the CLI.

Step 2 Verify the IP address for the managed devices.

```
sensor# configure terminal
sensor (config)# service network-access
sensor(config-net)# show settings
general
-----
log-all-block-events-and-errors: true <defaulted>
enable-nvram-write: false <defaulted>
enable-acl-logging: false <defaulted>
allow-sensor-block: false <defaulted>
block-enable: true <defaulted>
block-max-entries: 250 <defaulted>
max-interfaces: 250 <defaulted>
master-blocking-sensors (min: 0, max: 100, current: 0)
-----
never-block-hosts (min: 0, max: 250, current: 0)
-----
never-block-networks (min: 0, max: 250, current: 0)
-----
block-hosts (min: 0, max: 250, current: 0)
-----
block-networks (min: 0, max: 250, current: 0)
-----
user-profiles (min: 0, max: 250, current: 1)
-----
profile-name: r7200
-----
enable-password: <hidden>
password: <hidden>
username: netrangr default:
-----
cat6k-devices (min: 0, max: 250, current: 0)
-----
router-devices (min: 0, max: 250, current: 1)
-----
ip-address: 10.89.147.54
-----
communication: telnet default: ssh-3des
nat-address: 0.0.0.0 <defaulted>
profile-name: r7200
block-interfaces (min: 0, max: 100, current: 1)
-----
interface-name: fa0/0
direction: in
-----
pre-acl-name: <defaulted>
```

```

        post-acl-name: <defaulted>
        -----
        -----
        -----
        firewall-devices (min: 0, max: 250, current: 0)
        -----
        -----
sensor(config-net)#

```

- Step 3** Manually connect to the device to make sure you have used the correct username, password, and enable password, and to ensure that the device is reachable from the sensor:
- Log in to the service account.
 - Telnet or SSH to the network device to verify the configuration.
 - Make sure you can reach the device.
 - Verify the username and password.
- Step 4** Verify that each interface and direction on each network device is correct.

For More Information

For the procedure for verifying the interfaces and directions for each network device, see [Verifying the Interfaces and Directions on the Network Device, page C-43](#).

Verifying the Interfaces and Directions on the Network Device

To verify that each interface and direction on each controlled device is correct, you can send a manual block to a bogus host and then check to see if deny entries exist for the blocked addresses in the ACL of the router.



Note

To perform a manual block using IDM, choose **Monitoring > Sensor Monitoring > Time-Based Actions > Host Blocks**. To perform a manual block using IME, choose **Configuration > sensor_name > Sensor Monitoring > Time-Based Actions > Host Blocks**.

To initiate a manual block to a bogus host, follow these steps:

- Step 1** Enter ARC general submode.
- ```

sensor# configure terminal
sensor(config)# service network-access
sensor(config-net)# general

```
- Step 2** Start the manual block of the bogus host IP address.
- ```

sensor(config-net-gen)# block-hosts 10.16.0.0

```
- Step 3** Exit general submode.
- ```

sensor(config-net-gen)# exit
sensor(config-net)# exit
Apply Changes:? [yes]:

```
- Step 4** Press **Enter** to apply the changes or type **no** to discard them.

- Step 5** Telnet to the router and verify that a deny entry for the blocked address exists in the router ACL. Refer to the router documentation for the procedure.
- Step 6** Remove the manual block by repeating Steps 1 through 4 except in Step 2 place **no** in front of the command.

```
sensor(config-net-gen)# no block-hosts 10.16.0.0
```

## Enabling SSH Connections to the Network Device

If you are using SSH-3DES as the communication protocol for the network device, you must make sure you have enabled it on the device.

To enable SSH-3DES connections to the network device, follow these steps:

- Step 1** Log in to the CLI.
- Step 2** Enter configuration mode.
- ```
sensor# configure terminal
```
- Step 3** Enable SSH-3DES.
- ```
sensor(config)# ssh-3des host blocking_device_ip_address
```
- Step 4** Type **yes** when prompted to accept the device.

## Blocking Not Occurring for a Signature

If blocking is not occurring for a specific signature, check that the event action is set to block the host.

To make sure blocking is occurring for a specific signature, follow these steps:

- Step 1** Log in to the CLI.
- Step 2** Enter signature definition submode.
- ```
sensor# configure terminal
sensor(config)# service signature-definition sig0
sensor(config-sig)#
```

- Step 3** Make sure the event action is set to block the host.



Note If you want to receive alerts, you must always add **produce-alert** any time you configure the event actions.

```
sensor(config-sig)# signatures 1300 0
sensor(config-sig-sig)# engine normalizer
sensor(config-sig-sig-nor)# event-action produce-alert|request-block-host
sensor(config-sig-sig-nor)# show settings
normalizer
-----
event-action: produce-alert|request-block-host default: produce-alert|deny
-connection-inline
```

```

edit-default-sigs-only
-----
default-signatures-only
-----
specify-service-ports
-----
no
-----
-----
specify-tcp-max-mss
-----
no
-----
-----
specify-tcp-min-mss
-----
no
-----
-----
--MORE--

```

Step 4 Exit signature definition submode.

```

sensor(config-sig-sig-nor)# exit
sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:

```

Step 5 Press **Enter** to apply the changes or type **no** to discard them.

Verifying the Master Blocking Sensor Configuration

To verify that a master blocking sensor is set up properly or to troubleshoot a master blocking sensor that is not set up properly, you can use the **show statistics network-access** command. Make sure that the forwarding sensor is set up as TLS trusted host if the remote master blocking sensor is using TLS for web access.

To verify a master blocking sensor configuration, follow these steps:

Step 1 Log in to the CLI.

Step 2 View the ARC statistics and verify that the master blocking sensor entries are in the statistics.

```

sensor# show statistics network-access
Current Configuration
  AllowSensorShun = false
  ShunMaxEntries = 250
  MasterBlockingSensor
    SensorIp = 10.89.149.46
    SensorPort = 443
    UseTls = 1
State
  ShunEnable = true
  ShunnedAddr
    Host
      IP = 122.122.122.44
      ShunMinutes = 60
      MinutesRemaining = 59

```

Step 3 If the master blocking sensor does not show up in the statistics, you need to add it.

Step 4 Initiate a manual block to a bogus host IP address to make sure the master blocking sensor is initiating blocks.

```
sensor# configure terminal
sensor(config)# service network-access
sensor(config-net)# general
sensor(config-net-gen)# block-hosts 10.16.0.0
```

Step 5 Exit network access general submode.

```
sensor(config-net-gen)# exit
sensor(config-net)# exit
Apply Changes?: [yes]:
```

Step 6 Press **Enter** to apply the changes or type **no** to discard them.

Step 7 Verify that the block shows up in the ARC statistics.

```
sensor# show statistics network-access
Current Configuration
  AllowSensorShun = false
  ShunMaxEntries = 100
State
  ShunEnable = true
  ShunnedAddr
    Host
      IP = 10.16.0.0
      ShunMinutes =
```

Step 8 Log in to the CLI of the master blocking sensor host, and using the **show statistics network-access** command, verify that the block also shows up in the master blocking sensor ARC statistics.

```
sensor# show statistics network-access
Current Configuration
  AllowSensorShun = false
  ShunMaxEntries = 250
  MasterBlockingSensor
    SensorIp = 10.89.149.46
    SensorPort = 443
    UseTls = 1
State
  ShunEnable = true
  ShunnedAddr
    Host
      IP = 10.16.0.0
      ShunMinutes = 60
      MinutesRemaining = 59
```

Step 9 If the remote master blocking sensor is using TLS for web access, make sure the forwarding sensor is configured as a TLS host.

```
sensor# configure terminal
sensor(config)# tls trust ip master_blocking_sensor_ip_address
```

For More Information

For the procedure to configure the sensor to be a master blocking sensor, see [Configuring the Sensor to be a Master Blocking Sensor, page 14-28](#).

Logging

TAC may suggest that you turn on debug logging for troubleshooting purposes. Logger controls what log messages are generated by each application by controlling the logging severity for different logging zones. By default, debug logging is not turned on. If you enable individual zone control, each zone uses the level of logging that it is configured for. Otherwise, the same logging level is used for all zones. This section contains the following topics:

- [Enabling Debug Logging, page C-47](#)
- [Zone Names, page C-51](#)
- [Directing cidLog Messages to SysLog, page C-51](#)

Enabling Debug Logging



Caution

Enabling debug logging seriously affects performance and should only be done when instructed by the TAC.

To enable debug logging, follow these steps:

-
- Step 1** Log in to the service account.
- Step 2** Edit the log.conf file to increase the size of the log to accommodate the additional log statements.
- ```
vi /usr/cids/idsRoot/etc/log.conf
```
- Step 3** Change `fileMaxSizeInK=500` to `fileMaxSizeInK=5000`.
- Step 4** Locate the zone and CID section of the file and set the severity to debug.
- ```
severity=debug
```
- Step 5** Save the file, exit the vi editor, and exit the service account.
- Step 6** Log in to the CLI as administrator.
- Step 7** Enter master control submode.
- ```
sensor# configure terminal
sensor(config)# service logger
sensor(config-log)# master-control
```
- Step 8** Enable debug logging for all zones.
- ```
sensor(config-log-mas)# enable-debug true
sensor(config-log-mas)# show settings
master-control
-----
enable-debug: true default: false
individual-zone-control: false <defaulted>
-----
sensor(config-log-mas)#
```
- Step 9** Turn on individual zone control.
- ```
sensor(config-log-mas)# individual-zone-control true
sensor(config-log-mas)# show settings
master-control

```

```

enable-debug: true default: false
individual-zone-control: true default: false

sensor(config-log-mas)#

```

**Step 10** Exit master zone control.

```
sensor(config-log-mas)# exit
```

**Step 11** View the zone names.

```

sensor(config-log)# show settings
master-control

enable-debug: false <defaulted>
individual-zone-control: true default: false

zone-control (min: 0, max: 999999999, current: 14)

<protected entry>
zone-name: AuthenticationApp
severity: warning <defaulted>
<protected entry>
zone-name: Cid
severity: debug <defaulted>
<protected entry>
zone-name: Cli
severity: warning <defaulted>
<protected entry>
zone-name: IdapiCtlTrans
severity: warning <defaulted>
<protected entry>
zone-name: IdsEventStore
severity: warning <defaulted>
<protected entry>
zone-name: MpInstaller
severity: warning <defaulted>
<protected entry>
zone-name: cmgr
severity: warning <defaulted>
<protected entry>
zone-name: cplane
severity: warning <defaulted>
<protected entry>
zone-name: csi
severity: warning <defaulted>
<protected entry>
zone-name: ctlTransSource
severity: warning <defaulted>
<protected entry>
zone-name: intf
severity: warning <defaulted>
<protected entry>
zone-name: nac
severity: warning <defaulted>
<protected entry>
zone-name: sensorApp
severity: warning <defaulted>
<protected entry>
zone-name: tls
severity: warning <defaulted>

sensor(config-log)#

```



**Step 12** Change the severity level (debug, timing, warning, or error) for a particular zone.

```

sensor(config-log)# zone-control IdsEventStore severity error
sensor(config-log)# show settings
master-control

enable-debug: true default: false
individual-zone-control: true default: false

zone-control (min: 0, max: 999999999, current: 14)

<protected entry>
zone-name: AuthenticationApp
severity: warning <defaulted>
<protected entry>
zone-name: Cid
severity: debug <defaulted>
<protected entry>
zone-name: Cli
severity: warning <defaulted>
<protected entry>
zone-name: IdapiCtlTrans
severity: warning <defaulted>
<protected entry>
zone-name: IdsEventStore
severity: error default: warning
<protected entry>
zone-name: MpInstaller
severity: warning <defaulted>
<protected entry>
zone-name: cmgr
severity: warning <defaulted>
<protected entry>
zone-name: cplane
severity: warning <defaulted>
<protected entry>
zone-name: csi
severity: warning <defaulted>
<protected entry>
zone-name: ctlTransSource
severity: warning <defaulted>
<protected entry>
zone-name: intfci
severity: warning <defaulted>
<protected entry>
zone-name: nac
severity: warning <defaulted>
<protected entry>
zone-name: sensorApp
severity: warning <defaulted>
<protected entry>
zone-name: tls
severity: warning <defaulted>

sensor(config-log)#

```

**Step 13** Turn on debugging for a particular zone.

```

sensor(config-log)# zone-control nac severity debug
sensor(config-log)# show settings
master-control

enable-debug: true default: false
individual-zone-control: true default: false

```

```

zone-control (min: 0, max: 999999999, current: 14)

<protected entry>
zone-name: AuthenticationApp
severity: warning <defaulted>
<protected entry>
zone-name: Cid
severity: debug <defaulted>
<protected entry>
zone-name: Cli
severity: warning <defaulted>
<protected entry>
zone-name: IdapiCtlTrans
severity: warning <defaulted>
<protected entry>
zone-name: IdsEventStore
severity: error default: warning
<protected entry>
zone-name: MpInstaller
severity: warning <defaulted>
<protected entry>
zone-name: cmgr
severity: warning <defaulted>
<protected entry>
zone-name: cplane
severity: warning <defaulted>
<protected entry>
zone-name: csi
severity: warning <defaulted>
<protected entry>
zone-name: ctlTransSource
severity: warning <defaulted>
<protected entry>
zone-name: intf
severity: warning <defaulted>
<protected entry>
zone-name: nac
severity: debug default: warning
<protected entry>
zone-name: sensorApp
severity: warning <defaulted>
<protected entry>
zone-name: tls
severity: warning <defaulted>

sensor(config-log)#

```

**Step 14** Exit the logger submenu.

```

sensor(config-log)# exit
Apply Changes:[yes]:

```

**Step 15** Press **Enter** to apply changes or type **no** to discard them:

---

### For More Information

For a list of what each zone name refers to, see [Zone Names](#), page C-51.

## Zone Names

Table C-2 lists the debug logger zone names:

**Table C-2**      **Debug Logger Zone Names**

| Zone Name         | Description                            |
|-------------------|----------------------------------------|
| AD                | Anomaly Detection zone                 |
| AuthenticationApp | Authentication zone                    |
| Cid               | General logging zone                   |
| Cli               | CLI zone                               |
| IdapiCtlTrans     | All control transactions zone          |
| IdsEventStore     | Event Store zone                       |
| MpInstaller       | IDS-2 master partition installer zone  |
| cmgr              | Card Manager service zone <sup>1</sup> |
| cplane            | Control Plane zone <sup>2</sup>        |
| csi               | CIDS Servlet Interface <sup>3</sup>    |
| ctlTransSource    | Outbound control transactions zone     |
| intfc             | Interface zone                         |
| nac               | ARC zone                               |
| rep               | Reputation zone                        |
| sched             | Automatic update scheduler zone        |
| sensorApp         | AnalysisEngine zone                    |
| tls               | SSL and TLS zone                       |

1. The Card Manager service is used on the AIP SSM to exchange control and state information between modules in the chassis.
2. The Control Plane is the transport communications layer used by Card Manager on the AIP SSM.
3. The CIDS servlet interface is the interface layer between the CIDS web server and the servlets.

### For More Information

To learn more about the IPS Logger service, see [Logger, page A-19](#).

## Directing cidLog Messages to SysLog

It might be useful to direct cidLog messages to syslog.

To direct cidLog messages to syslog, follow these steps:

---

**Step 1**      Go to the idsRoot/etc/log.conf file.

**Step 2**      Make the following changes:

- a. Set [logApp] enabled=false

Comment out the enabled=true because enabled=false is the default.

**b. Set [drain/main] type=syslog**

The following example shows the logging configuration file:

```
timemode=local
;timemode=utc

[logApp]
;enabled=true
;----- FIFO parameters -----
fifoName=logAppFifo
fifoSizeInK=240
;----- logApp zone and drain parameters -----
zoneAndDrainName=logApp
fileName=main.log
fileMaxSizeInK=500

[zone/Cid]
severity=warning
drain=main

[zone/IdsEventStore]
severity=debug
drain=main

[drain/main]
type=syslog
```

The syslog output is sent to the syslog facility local6 with the following correspondence to syslog message priorities:

```
LOG_DEBUG, // debug
LOG_INFO, // timing
LOG_WARNING, // warning
LOG_ERR, // error
LOG_CRIT // fatal
```



**Note** Make sure that your /etc/syslog.conf has that facility enabled at the proper priority.



**Caution**

The syslog is much slower than logApp (about 50 messages per second as opposed to 1000 or so). We recommend that you enable debug severity on one zone at a time.

## TCP Reset Not Occurring for a Signature



**Note**

There is only one sensing interface on the ASA IPS modules (ASA 5500 AIP SSM, ASA 5500-X IPS SSP, and ASA 5585-X IPS SSP), so you cannot designate an alternate TCP reset interface.

If you do not have the event action set to reset, the TCP reset does not occur for a specific signature.

**Note**

TCP Resets are not supported over MPLS links or the following tunnels: GRE, IPv4 in IPv4, IPv6 in IPv4, or IPv4 in IPv6.

To troubleshoot a reset not occurring for a specific signature, follow these steps:

**Step 1** Log in to the CLI.

**Step 2** Make sure the event action is set to TCP reset.

```
sensor# configure terminal
sensor(config)# service signature-definition sig0
sensor(config-sig)# signatures 1000 0
sensor(config-sig-sig)# engine atomic-ip
sensor(config-sig-sig-ato)# event-action reset-tcp-connection|produc-alert
sensor(config-sig-sig-ato)# show settings
 atomic-ip

 event-action: produce-alert|reset-tcp-connection default: produce-alert
 fragment-status: any <defaulted>
 specify-l4-protocol

 no

 specify-ip-payload-length

 no

 specify-ip-header-length

 no

 specify-ip-tos

--MORE--
```

**Step 3** Exit signature definition submenu.

```
sensor(config-sig-sig-ato)# exit
sensor(config-sig-sig)# exit
sensor(config-sig)# exit
Apply Changes:[yes]:
```

**Step 4** Press **Enter** to apply the changes or type **no** to discard them.

**Step 5** Make sure the correct alarms are being generated.

```
sensor# show events alert
evAlert: eventId=1047575239898467370 severity=medium
originator:
hostId: sj_4250_40
appName: sensorApp
appInstanceId: 1004
signature: sigId=20000 sigName=STRING.TCP subSigId=0 version=Unknown
addr: locality=OUT 172.16.171.19
```

```
port: 32771
victim:
addr: locality=OUT 172.16.171.13 port: 23
actions:
tcpResetSent: true
```

**Step 6** Make sure the switch is allowing incoming TCP reset packet from the sensor. Refer to your switch documentation for more information.

**Step 7** Make sure the resets are being sent.

```
root# ./tcpdump -i eth0 src host 172.16.171.19
tcpdump: WARNING: eth0: no IPv4 address assigned
tcpdump: listening on eth0
13:58:03.823929 172.16.171.19.32770 > 172.16.171.13.telnet: R 79:79(0) ack 62 win 0
13:58:03.823930 172.16.171.19.32770 > 172.16.171.13.telnet: R 80:80(0) ack 62 win 0
13:58:03.823930 172.16.171.19.32770 > 172.16.171.13.telnet: R 80:80(0) ack 62 win 0
13:58:03.823930 172.16.171.19.32770 > 172.16.171.13.telnet: R 80:80(0) ack 62 win 0
```

## Software Upgrades

This section helps in troubleshooting software upgrades. It contains the following topics:

- [Upgrading Error, page C-54](#)
- [Which Updates to Apply and Their Prerequisites, page C-55](#)
- [Issues With Automatic Update, page C-55](#)
- [Updating a Sensor with the Update Stored on the Sensor, page C-56](#)

## Upgrading Error

When you upgrade an IPS sensor, you may receive an error that the Analysis Engine is not running:

```
sensor# upgrade scp://user@10.1.1.1/updates/IPS-K9-7.1-2-E4.pkg
Password: *****
Warning: Executing this command will apply a major version upgrade to the application
partition. The system may be rebooted to complete the upgrade.
Continue with upgrade?: yes
Error: AnalysisEngine is not running. Please reset box and attempt upgrade again.
```

If you receive this error, you must get the Analysis Engine running before trying to upgrade again. This error is often caused by a defect in the currently running version. Try rebooting the sensor, and after reboot, run the **setup** command and remove the interfaces from the virtual sensor vs0. When it is not monitoring traffic, Analysis Engine usually stays up and running. You can upgrade at this time. After the upgrade, add the interfaces back to the virtual sensor vs0 using the **setup** command.

Or you can use the system image file to reimage the sensor directly to the version you want. You can reimage a sensor and avoid the error because the reimage process does not check to see if the Analysis Engine is running.



**Caution**

Reimaging using the system image file restores all configuration defaults.

**For More Information**

- For more information on running the **setup** command, see [Chapter 3, “Initializing the Sensor.”](#)
- For more information on reimaging your sensor, see [Chapter 22, “Upgrading, Downgrading, and Installing System Images.”](#)

## Which Updates to Apply and Their Prerequisites

You must have the correct service pack and minor and major version of the software. If you are having trouble with applying new software, make sure that you are applying the proper updates with the proper prerequisites:

- Signature updates require the minimum version and engine version listed in the filename.
- Engine updates require the major or minor version in the engine update filename. Service packs require the correct minor version.
- Minor versions require the correct major version.
- Major versions require the previous major version.

**For More Information**

To understand how to interpret the IPS software filenames, see [IPS Software Versioning, page 21-3](#).

## Issues With Automatic Update

**Caution**

In IPS 7.1(5)E4 and later the default value of the Cisco server IP address has been changed from 198.133.219.25 to 72.163.4.161 in the Auto Update URL configuration. If you have automatic update configured on your sensor, you may need to update firewall rules to allow the sensor to connect to this new IP address.

The following list provides suggestions for troubleshooting automatic updates:

- Run TCPDUMP:
  - Create a service account. **Su** to root and run TCPDUMP on the command and control interface to capture packets between the sensor and the FTP server.
  - Use the **upgrade** command to manually upgrade the sensor.
  - Look at the TCPDUMP output for errors coming back from the FTP server.
- Make sure the sensor is in the correct directory. The directory must be specified correctly. This has caused issues with Windows FTP servers. Sometimes an extra “/” or even two “/” are needed in front of the directory name. To verify this, use the same FTP commands you see in the TCPDUMP output through your own FTP connection.
- You must use the Windows FTP server setup option to emulate UNIX file structure and not MS-DOS file structure.
- If you are using SCP, make sure you have added the SSH host key to the known hosts list.
- If you get an unauthorized error message while configuring an automatic update, make sure you have the correct ports open on any firewalls between the sensor and Cisco.com. For example, you need port 443 for the initial automatic update connection to www.cisco.com, and you need port 80

to download the chosen package from a Cisco file server. The IP address may change for the Cisco file server, but you can find it in the lastDownloadAttempt section in the output of the **show statistics host** command.

Try the manual **upgrade** command before attempting the automatic update. If it works with the **upgrade** command and does not work with the automatic update, try the following:

- Determine which IPS software version your sensor has.
- Make sure the passwords are configured for automatic update. Make sure they match the same passwords used for manual update.
- Make sure that the filenames in the FTP server are exactly what you see on Downloads on Cisco.com. This includes capitalization. Some Windows FTP servers allow access to the file with the incorrect capitalization but the sensor ultimately rejects the file because the name has changed.
- If necessary, run TCPDUMP on automatic update. You can compare the successful manual update with the unsuccessful automatic update and troubleshoot from there.

#### For More Information

- For the procedure for creating the service account, see [Creating the Service Account, page 4-26](#).
- For the procedure for reimaging your sensor, see [Chapter 22, “Upgrading, Downgrading, and Installing System Images.”](#)
- For the procedure for adding hosts to the SSH known hosts list, see [Adding Hosts to the SSH Known Hosts List, page 4-45](#).
- For the procedure for determining the software version, see [Displaying Version Information, page C-91](#).

## Updating a Sensor with the Update Stored on the Sensor

You can store the update package in the /var directory on the sensor and update the sensor from there if you need to.

To update the sensor with an update stored on the sensor, follow these steps:

- 
- Step 1** Log in to the service account.
  - Step 2** Obtain the update package file from Cisco.com.
  - Step 3** FTP or SCP the update file to the sensor /usr/cids/idsRoot/var directory.
  - Step 4** Set the file permissions:
 

```
chmod 644 ips_package_file_name
```
  - Step 5** Exit the service account.
  - Step 6** Log in to the sensor using an account with administrator privileges.
  - Step 7** Store the sensor host key.

```
sensor# configure terminal
sensor(config)# service ssh
sensor(config-ssh)# rsa1-keys sensor_ip_address
```



**Step 8** Upgrade the sensor.

```

sensor(config)# upgrade scp://service@sensor_ip_address/upgrade/ips_package_file_name
Enter password: *****
Re-enter password: *****

```

**For More Information**

For the procedure for obtaining Cisco IPS software, see [Obtaining Cisco IPS Software, page 21-1](#).

## Troubleshooting the IDM

This section contains troubleshooting procedures for the IDM. It contains the following topics:

- [Cannot Launch the IDM - Loading Java Applet Failed, page C-57](#)
- [Cannot Launch the IDM-The Analysis Engine Busy, page C-58](#)
- [The IDM, Remote Manager, or Sensing Interfaces Cannot Access Sensor, page C-58](#)
- [Signatures Not Producing Alerts, page C-59](#)

**Note**

These procedures also apply to the IPS section of the ASDM.

**Note**

After you upgrade any IPS software on your sensor, you must restart the IDM to see the latest software features.

## Cannot Launch the IDM - Loading Java Applet Failed

**Symptom** The browser displays Loading Cisco IDM. Please wait ... At the bottom left corner of the window, Loading Java Applet Failed is displayed.

**Possible Cause** This condition can occur if multiple Java Plug-ins are installed on the machine on which you are launching the IDM.

**Recommended Action** Clear the Java cache and remove temp files and clear history in the browser you are using. The result is that neither of these plug-ins will be used by default and each applet should use the correct plug-in.

To clear the cache, follow these steps:

**Step 1** Close all browser windows.

**Step 2** If you have Java Plug-in 1.3.x installed:

- Click **Start > Settings > Control Panel > Java Plug-in 1.3.x**.
- Click the **Advanced** tab.
- Under Java Runtime Environment, select **JRE 1.3.x** from the drop-down menu.

d. Click the **Cache** tab.

e. Click **Clear**.

**Step 3** If you have Java Plug-in 1.4.x installed:

a. Click **Start > Settings > Control Panel > Java Plug-in 1.4.x**.

b. Click the **Advanced** tab.

c. Under Java Runtime Environment, select **JRE 1.3.x** from the drop-down menu.

d. Click the **Cache** tab.

e. Click the **Browser** tab.

f. Deselect all browser check boxes.

g. Click **Clear Cache**.

**Step 4** Delete the temp files and clear the history in the browser.

---

## Cannot Launch the IDM-The Analysis Engine Busy

**Error Message** Error connecting to sensor. Failed to load sensor-errNotAvailable-Analysis Engine is busy. Exiting IDM.

**Possible Cause** This condition can occur if the Analysis Engine in the sensor is busy getting ready to perform a task and so does not respond to the IDM.

**Recommended Action** Wait for a while and try again to connect.

## The IDM, Remote Manager, or Sensing Interfaces Cannot Access Sensor

If the IDM, a remote manager, or sensing interfaces cannot access the sensor, but you can access the sensor CLI using SSH or Telnet (if enabled), follow these steps:

**Step 1** Make sure the network configuration allows access to the web server port that is configured on the sensor:

```
sensor# setup
```

```
--- System Configuration Dialog ---
```

```
At any point you may enter a question mark '?' for help.
User ctrl-c to abort configuration dialog at any prompt.
Default settings are in square brackets '[]'.
```

```
Current Configuration:
```

```
service host
network-settings
host-ip 192.168.1.2/24,192.168.1.1
host-name sensor
```

```
telnet-option enabled
access-list 0.0.0.0/0
ftp-timeout 300
no login-banner-text
exit
time-zone-settings
offset 0
standard-time-zone-name UTC
exit
summertime-option disabled
ntp-option disabled
exit
service web-server
port 443
exit
```

- Step 2** If network devices, such as routers, switches, or firewalls, are between the sensor and the workstation, make sure these devices are configured to allow the workstation to access the sensor web server port. All remote management communication is performed by the sensor web server.
- 

#### For More Information

- For the procedure for enabling and disabling Telnet on the sensor, see [Enabling and Disabling Telnet, page 4-5](#).
- For the procedure for configuring the web server, see [Changing Web Server Settings, page 4-14](#).

## Signatures Not Producing Alerts



#### Caution

You cannot add other actions each time you configure the event actions. You are actually replacing the list of event actions every time you configure it, so make sure you choose Produce Alert every time you configure event actions.

---

If you are not seeing any alerts when signatures are firing, make sure that you have configured Produce Alert as an event action. For example, if you choose Produce Alert, but later add another event action and do not add Produce Alert to the new configuration, alerts are not sent to the Event Store. To make sure you are getting alerts, check the statistics for the virtual sensor and the Event Store.

#### For More Information

- For more information about event actions, see [Event Actions, page 7-5](#).
- For the procedure for configuring event actions, see [Assigning Actions to Signatures, page 8-15](#).
- For the procedure for obtaining statistics about the virtual sensor and Event Store, see [Displaying Statistics, page 17-31](#).

## Troubleshooting the IME

This section describes troubleshooting tools for the IME, and contains the following sections:

- [Time Synchronization on the IME and the Sensor, page C-60](#)
- [Not Supported Error Message, page C-60](#)

- [Installation Error, page C-60](#)

## Time Synchronization on the IME and the Sensor

**Symptom** The IME displays `No Data Available` on the Events dashboard. A historical query does not return any events; however, events are coming in to the IME and they appear in the real-time event viewer.

**Possible Cause** The time is not synchronized between the sensor and the IME local server. The IME dashboards use a time relative to the IME local time. If these times are not synchronized, the query does not return any results. When you add a sensor to the IME, it checks for the time synchronization and warns you to correct it if it is in wrong. The IME also displays a clock warning in Home > Devices > Device List to warn you about problems with synchronization.

**Recommended Action** Change the time settings on the sensor or the IME local server. In most cases, the time change is required for the sensor because it is configured with the incorrect or default time.

### For More Information

- For more information on time and the sensor, see [Time Sources and the Sensor, page C-17](#).
- For the procedure for changing the time on the sensor, see [Correcting Time on the Sensor, page C-19](#).

## Not Supported Error Message

**Symptom** The IME displays `Not Supported` in the device list table and in some gadgets, and no data is included.

**Possible Cause** Click **Details** to see an explanation for this message. The IME needs IPS 6.1 or later to obtain certain information. The IME still operates with event monitoring and reporting for IPS 5.0 and later and specific IOS IPS versions, but some functions, such as health information and integrated configuration, are not available.

**Recommended Action** Upgrade to IPS 6.1 or later.

## Installation Error

**Symptom** IME 7.1.1 installation is failing with the following error message: `Unhandled Exception. Error Number: 0x80004005, Description: Unspecified Error. Setup will now terminate.`

**Conditions** You are trying to install the IME over an RDP connection, which has 8-bit color depth or 256 colors. This is an InstallShield error.

**Workaround** Increase the color depth of the RDP connection to at least 16 bits.

# Troubleshooting the ASA 5500 AIP SSM



Tip

Before troubleshooting the ASA 5500 AIP SSM, check the Caveats section of the Readme for the software version you have installed on your sensor to see if you are dealing with a known issue.

The following section contains commands that are specific for troubleshooting the ASA 5500 AIP SSM:

- [Health and Status Information, page C-61](#)
- [Failover Scenarios, page C-63](#)
- [The ASA 5500 AIP SSM and the Data Plane, page C-64](#)
- [The ASA 5500 AIP SSM and the Normalizer Engine, page C-64](#)
- [The ASA 5500 AIP SSM and Jumbo Packet Frame Size, page C-65](#)
- [The ASA 5500 AIP SSM and Jumbo Packets, page C-65](#)
- [TCP Reset Differences Between IPS Appliances and ASA IPS Modules, page C-65](#)
- [IPS Reloading Messages, page C-66](#)

## Health and Status Information

To see the general health of the ASA 5500 AIP SSM, use the **show module 1 details** command:

```
asa# show module 1 details
Getting details from the Service Module, please wait...
ASA 5500 Series Security Services Module-20
Model: ASA-SSM-20
Hardware version: 0.2
Serial Number: P2B000005D0
Firmware version: 1.0(10)0
Software version: 5.1(0.1)S153.0
Status: Up
Mgmt IP addr: 192.0.2.0
Mgmt web ports: 443
Mgmt TLS enabled: true
asa#
```

The output shows that the ASA 5500 AIP SSM is up. If the status reads **Down**, you can reset the module using the **hw-module module 1 reset** command:

```
asa# hw-module module 1 reset
The module in slot 1 should be shut down before
resetting it or loss of configuration may occur.
Reset module in slot 1? [confirm]
Reset issued for module in slot 1
asa(config)# show module
```

| Mod | Card     | Type                               | Model      | Serial No.  |
|-----|----------|------------------------------------|------------|-------------|
| 0   | ASA 5520 | Adaptive Security Appliance        | ASA5520    | P2A00000014 |
| 1   | ASA 5500 | Series Security Services Module-10 | ASA-SSM-10 | P2A0000067U |

| Mod | MAC            | Address Range     | Hw Version | Fw Version | Sw Version     |
|-----|----------------|-------------------|------------|------------|----------------|
| 0   | 000b.fcf8.7bdc | to 000b.fcf8.7be0 | 0.2        | 1.0(10)0   | 7.0(4)         |
| 1   | 000b.fcf8.0176 | to 000b.fcf8.0176 | 0.2        | 1.0(10)0   | 5.1(0.1)S153.0 |

```

Mod Status

 0 Up Sys
 1 Shutting Down

asa(config)# show module

Mod Card Type Model Serial No.

 0 ASA 5520 Adaptive Security Appliance ASA5520 P2A00000014
 1 ASA 5500 Series Security Services Module-10 ASA-SSM-10 P2A0000067U

Mod MAC Address Range Hw Version Fw Version Sw Version

 0 000b.fcf8.7bdc to 000b.fcf8.7be0 0.2 1.0(10)0 7.0(4)
 1 000b.fcf8.0176 to 000b.fcf8.0176 0.2 1.0(10)0 5.1(0.1)S153.0

Mod Status

 0 Up Sys
 1 Up
asa(config)#

```

If you have problems with reimaging the ASA 5500 AIP SSM, use the **debug module-boot** command to see the output as the module boots. Make sure you have the correct IP address for the TFTP server and you have the correct file on the TFTP server. Then use the **hw-module module 1 recover** command again to reimaging the module:

```

asa(config)# hw-module module 1 recover configure
Image URL [tftp://0.0.0.0/]: tftp://192.0.2.0/IPS-SSM-K9-sys-1.1-a-5.1-0.1.i$
Port IP Address [0.0.0.0]: 10.89.150.227
VLAN ID [0]:
Gateway IP Address [0.0.0.0]: 10.89.149.254
asa(config)# debug module-boot
debug module-boot enabled at level 1
asa(config)# hw-module module 1 recover boot
The module in slot 1 will be recovered. This may erase all configuration and all data on
that device and attempt to download a new image for it.
Recover module in slot 1? [confirm]
Recover issued for module in slot 1
asa(config)# Slot-1 140> Cisco Systems ROMMON Version (1.0(10)0) #0: Fri Mar 25 23:02:10
PST 2005
Slot-1 141> Platform ASA-SSM-10
Slot-1 142> GigabitEthernet0/0
Slot-1 143> Link is UP
Slot-1 144> MAC Address: 000b.fcf8.0176
Slot-1 145> ROMMON Variable Settings:
Slot-1 146> ADDRESS=10.89.150.227
Slot-1 147> SERVER=10.89.146.1
Slot-1 148> GATEWAY=10.89.149.254
Slot-1 149> PORT=GigabitEthernet0/0
Slot-1 150> VLAN=untagged
Slot-1 151> IMAGE=IPS-SSM-K9-sys-1.1-a-5.1-0.1.img
Slot-1 152> CONFIG=
Slot-1 153> LINKTIMEOUT=20
Slot-1 154> PKTTIMEOUT=4
Slot-1 155> RETRY=20
Slot-1 156> tftp IPS-SSM-K9-sys-1.1-a-5.1-0.1.img@10.89.146.1 via 10.89.149.254
Slot-1 157> TFTP failure: Packet verify failed after 20 retries
Slot-1 158> Rebooting due to Autoboot error ...
Slot-1 159> Rebooting...
Slot-1 160> Cisco Systems ROMMON Version (1.0(10)0) #0: Fri Mar 25 23:02:10 PST 2005

```

```
Slot-1 161> Platform ASA-SSM-10
Slot-1 162> GigabitEthernet0/0
Slot-1 163> Link is UP
Slot-1 164> MAC Address: 000b.fcf8.0176
Slot-1 165> ROMMON Variable Settings:
Slot-1 166> ADDRESS=10.89.150.227
Slot-1 167> SERVER=10.89.146.1
Slot-1 168> GATEWAY=10.89.149.254
Slot-1 169> PORT=GigabitEthernet0/0
Slot-1 170> VLAN=untagged
Slot-1 171> IMAGE=IPS-SSM-K9-sys-1.1-a-5.1-0.1.img
Slot-1 172> CONFIG=
Slot-1 173> LINKTIMEOUT=20
Slot-1 174> PKTTIMEOUT=4
Slot-1 175> RETRY=20
Slot-1 176> tftp IPS-SSM-K9-sys-1.1-a-5.1-0.1.img@10.89.146.1 via 10.89.149.254
```

## Failover Scenarios

The following failover scenarios apply to the ASA in the event of configuration changes, signature/signature engine updates, service packs, and SensorApp crashes on the ASA 5500 AIP SSM.

### Single ASA in Fail-Open Mode

- If the ASA is configured in fail-open mode for the ASA 5500 AIP SSM, and the ASA 5500 AIP SSM experiences a configuration change or signature/signature engine update, traffic is passed through the ASA without being inspected.
- If the ASA is configured in fail-open mode for the ASA 5500 AIP SSM, and the ASA 5500 AIP SSM experiences a SensorApp crash or a service pack upgrade, traffic is passed through the ASA without being inspected.

### Single ASA in Fail-Close Mode

- If the ASA is configured in fail-close mode for the ASA 5500 AIP SSM, and the ASA 5500 AIP SSM experiences a configuration change or a signature/signature engine update, traffic is stopped from passing through the ASA.
- If the ASA is configured in fail-close mode for the ASA 5500 AIP SSM, and the ASA 5500 AIP SSM experiences a SensorApp crash or a service pack upgrade, traffic is stopped from passing through the ASA.

### Two ASAs in Fail-Open Mode

- If the ASAs are configured in fail-open mode and if the ASA 5500 AIP SSM on the active ASA experiences a configuration change or a signature/signature engine update, traffic is still passed through the active ASA without being inspected. Failover is not triggered.
- If the ASAs are configured in fail-open mode, and if the ASA 5500 AIP SSM on the active ASA experiences a SensorApp crash or a service pack upgrade, failover is triggered and traffic passes through the ASA 5500 AIP SSM that was previously the standby module.

### Two ASAs in Fail-Close Mode

- If the ASAs are configured in fail-close mode, and if the ASA 5500 AIP SSM on the active ASA experiences a configuration change or a signature/signature engine update, traffic is stopped from passing through the active ASA. No failover is triggered.

- If the ASAs are configured in fail-close mode, and if the ASA 5500 AIP SSM on the active ASA experiences a SensorApp crash or a service pack upgrade, failover is triggered and traffic passes through the module that was previously the standby for the ASA 5500 AIP SSM.

### Configuration Examples

Use the following configuration for the primary ASA:

```
interface GigabitEthernet0/7
 description LAN Failover Interface

failover
failover lan unit primary
failover lan interface folink GigabitEthernet0/7
failover interface ip folink 172.27.48.1 255.255.255.0 standby 172.27.48.2
```

Use the following configuration for the secondary ASA:

```
interface GigabitEthernet0/7
 description LAN Failover Interface

failover
failover lan unit secondary
failover lan interface folink GigabitEthernet0/7
failover interface ip folink 172.27.48.1 255.255.255.0 standby 172.27.48.2
```

## The ASA 5500 AIP SSM and the Data Plane

**Symptom** The ASA 5500 AIP SSM data plane is kept in the Up state while applying signature updates. You can check the ASA 5500 AIP SSM data plane status by using the **show module** command during signature updates.

**Possible Cause** Bypass mode is set to off. The issue is seen when updating signatures, and when you use either CSM or IDM to apply signature updates. This issue is not seen when upgrading IPS system software.

## The ASA 5500 AIP SSM and the Normalizer Engine

The majority of the features in the Normalizer engine are not used on the ASA 5500 AIP SSM, because the ASA itself handles the normalization. Packets on the ASA IPS modules go through a special path in the Normalizer that only reassembles fragments and puts packets in the right order for the TCP stream. The Normalizer does not do any of the normalization that is done on an inline IPS appliance, because that causes problems in the way the ASA handles the packets.

The following Normalizer engine signatures are not supported:

- 1300.0
- 1304.0
- 1305.0
- 1307.0
- 1308.0
- 1309.0



- 1311.0
- 1315.0
- 1316.0
- 1317.0
- 1330.0
- 1330.1
- 1330.2
- 1330.9
- 1330.10
- 1330.12
- 1330.14
- 1330.15
- 1330.16
- 1330.17
- 1330.18

## The ASA 5500 AIP SSM and Jumbo Packet Frame Size

Refer to the following URL for information about the ASA 5500 AIP SSM jumbo packet frame size:

[http://www.cisco.com/en/US/docs/security/asa/asa84/configuration/guide/interface\\_start.html#wp1328869](http://www.cisco.com/en/US/docs/security/asa/asa84/configuration/guide/interface_start.html#wp1328869)

**Note**

A jumbo frame is an Ethernet packet that is larger than the standard maximum of 1518 bytes (including Layer 2 header and FCS).

## The ASA 5500 AIP SSM and Jumbo Packets

The jumbo packet count in the **show interface** command output from the lines `Total Jumbo Packets Received` and `Total Jumbo Packets Transmitted` for ASA IPS modules may be larger than expected due to some packets that were almost jumbo size on the wire being counted as jumbo size by the IPS. This miscount is a result of header bytes added to the packet by the ASA before the packet is transmitted to the IPS. For IPv4, 58 bytes of header data are added. For IPv6, 78 bytes of header data are added. The ASA removes the added IPS header before the packet leaves the ASA.

## TCP Reset Differences Between IPS Appliances and ASA IPS Modules

The IPS appliance sends TCP reset packets to both the attacker and victim when `reset-tcp-connection` or `Reset TCP Connection` is selected. The IPS appliance sends a TCP reset packet only to the victim under the following circumstances:

- When a `deny-packet-inline` or `Deny Packet Inline` or `deny-connection-inline` or `Deny Connection Inline` is selected

- When TCP-based signatures and reset-tcp-connectionReset TCP Connection have NOT been selected

In the case of the ASA IPS module, the TCP reset request is sent to the ASA, and the ASA then sends the TCP reset packets. The ASA sends TCP reset packets to both the attacker and victim when the reset-tcp-connectionReset TCP Connection is selected. When deny-packet-inlineDeny Packet Inline or deny-connection-inlineDeny Connection Inline is selected, the ASA sends the TCP reset packet to either the attacker or victim depending on the configuration of the signature. Signatures configured to swap the attacker and victim when reporting the alert can cause the ASA to send the TCP reset packet to the attacker.

#### For More Information

For a detailed description of all the event actions, see [Event Actions, page 7-5](#).

## IPS Reloading Messages

**Symptom** ASA syslog messages similar to the following are observed and the root cause of the message is not clear:

```
%ASA-1-505013: ASA-SSM-10 Module in slot 1, application reloading "IPS", version
"7.1(6)E4" Config Change
%ASA-1-505013: ASA5585-SSP-IPS10 Module in slot 1, application reloading "IPS", version
"7.1(1)E4" Config Change
```

These messages occur once an hour for sensors not actively being configured or more often for sensors being configured.

**Conditions** ASA adaptive appliances running an affected software version with an ASA IPS module (ASA 5500 AIP SSMASA 5500-X IPS SSPASA 5585-X IPS SSP) installed that is running IPS 7.1 or later. The common cause for these messages is global correlation and/or signature updates occurring on the ASA IPS module that results in these messages being generated for some, but not necessarily all of the updates, which are attempted every five minutes.

**Workaround** None. The cause of these messages can be confirmed on the sensor module by reviewing the **show events status past** command output and identifying a status event that corresponds to the ASA syslog message that matches the date and time. The sensor's status event should provide further details about what operation occurred that resulted in the ASA syslog message.

## Troubleshooting the ASA 5500-X IPS SSP



#### Tip

Before troubleshooting the ASA 5500-X IPS SSP, check the Caveats section of the Readme for the software version installed on your sensor to see if you are dealing with a known issue.

This section contains troubleshooting information specific to the ASA 5500-X IPS SSP, and contains the following topics:

- [Health and Status Information, page C-67](#)
- [Failover Scenarios, page C-74](#)

- [The ASA 5500-X IPS SSP and the Normalizer Engine, page C-75](#)
- [The ASA 5500-X IPS SSP and Memory Usage, page C-76](#)
- [The ASA 5500-X IPS SSP and Jumbo Packet Frame Size, page C-77](#)
- [The ASA 5500-X IPS SSP and Jumbo Packets, page C-77](#)
- [TCP Reset Differences Between IPS Appliances and ASA IPS Modules, page C-77](#)
- [IPS Reloading Messages, page C-78](#)
- [IPS Not Loading, page C-78](#)

## Health and Status Information

To see the general health of the ASA 5500-X IPS SSP, use the **show module ips details** command.

```
asa# show module ips details
Getting details from the Service Module, please wait...

Card Type: IPS 5555 Intrusion Prevention System
Model: IPS5555
Hardware version: N/A
Serial Number: FCH1504V0CW
Firmware version: N/A
Software version: 7.1(3)E4
MAC Address Range: 503d.e59c.7ca0 to 503d.e59c.7ca0
App. name: IPS
App. Status: Up
App. Status Desc: Normal Operation
App. version: 7.1(3)E4
Data Plane Status: Up
Status: Up
License: IPS Module Enabled perpetual
Mgmt IP addr: 192.168.1.2
Mgmt Network mask: 255.255.255.0
Mgmt Gateway: 192.168.1.1
Mgmt web ports: 443
Mgmt TLS enabled: true
asa#
```

The output shows that the ASA 5500-X IPS SSP is up. If the status reads **Down**, you can reset it using the **sw-module module 1 reset** command.

If you have problems with reimaging the ASA 5500-X IPS SSP, use the **debug module-boot** command to see the output as it boots. Make sure you have the correct IP address for the TFTP server and you have the correct file on the TFTP server. Then use the **sw-module module ips recover** command again to reimage the module.

```
asa-ips# sw-module module ips recover configure image
disk0:/IPS-SSP_5555-K9-sys-1.1-a-7.1-3-E4.aip
Image URL [tftp://192.0.2.1/IPS-5545-K9-sys-1.1-a-7.1-3-E4.aip]:
Port IP Address [192.0.2.226]:
VLAN ID [0]:
Gateway IP Address [192.0.2.254]:

asa-ips# debug module-boot
debug module-boot enabled at level 1
asa-ips# sw-module module ips reload

Reload module ips? [confirm]
Reload issued for module ips.
```

```

asa-ips# Mod-ips 228> ***
Mod-ips 229> *** EVENT: The module is reloading.
Mod-ips 230> *** TIME: 08:07:36 CST Jan 17 2012
Mod-ips 231> ***
Mod-ips 232> Mod-ips 233> The system is going down NOW!
Mod-ips 234> Sending SIGTERM to all processes
Mod-ips 235> Sending SIGKILL to all processes
Mod-ips 236> Requesting system reboot
Mod-ips 237> e1000 0000:00:07.0: PCI INT A disabled
Mod-ips 238> e1000 0000:00:06.0: PCI INT A disabled
Mod-ips 239> e1000 0000:00:05.0: PCI INT A disabled
Mod-ips 240> Restarting system.
Mod-ips 241> machine restart
Mod-ips 242> IVSHMEM: addr = 4093640704 size = 67108864
Mod-ips 243> Booting 'Cisco IPS'
Mod-ips 244> root (hd0,0)
Mod-ips 245> Filesystem type is ext2fs, partition type 0x83
Mod-ips 246> kernel /ips-2.6.1d ro initfsDev=/dev/hda1 init=loader.run rootrw=/dev/hda2
init
Mod-ips 247> fs=runtime-image.cpio.bz2 hda=nodma console=ttyS0 plat=saleen htlblow=1
hugepag
Mod-ips 248> es=3223
Mod-ips 249> [Linux-bzImage, setup=0x2c00, size=0x2bad80]
Mod-ips 250> Linux version 2.6.29.1 (ipsbuild@seti-teambuilder-a) (gcc version 4.3.2
(crosstool
Mod-ips 251> -NG-1.4.1)) #56 SMP Tue Dec 6 00:46:11 CST 2011
Mod-ips 252> Command line: ro initfsDev=/dev/hda1 init=loader.run rootrw=/dev/hda2
initfs=runti
Mod-ips 253> me-image.cpio.bz2 hda=nodma console=ttyS0 plat=saleen htlblow=1
hugepages=3223
Mod-ips 254> KERNEL supported cpus:
Mod-ips 255> Intel GenuineIntel
Mod-ips 256> AMD AuthenticAMD
Mod-ips 257> Centaur CentaurHauls
Mod-ips 258> BIOS-provided physical RAM map:
Mod-ips 259> BIOS-e820: 0000000000000000 - 000000000009f400 (usable)
Mod-ips 260> BIOS-e820: 000000000009f400 - 00000000000a0000 (reserved)
Mod-ips 261> BIOS-e820: 00000000000f0000 - 0000000000100000 (reserved)
Mod-ips 262> BIOS-e820: 0000000000100000 - 00000000dffffd000 (usable)
Mod-ips 263> BIOS-e820: 00000000dffffd000 - 00000000e0000000 (reserved)
Mod-ips 264> BIOS-e820: 00000000fffb0000 - 0000000100000000 (reserved)
Mod-ips 265> BIOS-e820: 0000000100000000 - 0000000201400000 (usable)
Mod-ips 266> DMI 2.4 present.
Mod-ips 267> last_pfn = 0x201400 max_arch_pfn = 0x100000000
Mod-ips 268> last_pfn = 0xdffffd max_arch_pfn = 0x100000000
Mod-ips 269> init_memory_mapping: 0000000000000000-00000000dffffd000
Mod-ips 270> last_map_addr: dffffd000 end: dffffd000
Mod-ips 271> init_memory_mapping: 0000000100000000-0000000201400000
Mod-ips 272> last_map_addr: 201400000 end: 201400000
Mod-ips 273> ACPI: RSDP 000F88D0, 0014 (r0 BOCHS)
Mod-ips 274> ACPI: RSDT DFFFDD00, 0034 (r1 BOCHS BXPCRSDT 1 BXPC 1)
Mod-ips 275> ACPI: FACP DFFFDD90, 0074 (r1 BOCHS BXPCFACP 1 BXPC 1)
Mod-ips 276> FADT: X_PM1a_EVT_BLK.bit_width (16) does not match PM1_EVT_LEN (4)
Mod-ips 277> ACPI: DSDT DFFFDF10, 1E22 (r1 BXPC BXDSDT 1 INTL 20090123)
Mod-ips 278> ACPI: FACS DFFFDD40, 0040
Mod-ips 279> ACPI: SSDT DFFFDE90, 0079 (r1 BOCHS BXPCSSDT 1 BXPC 1)
Mod-ips 280> ACPI: APIC DFFFDD80, 0090 (r1 BOCHS BXPCAPIC 1 BXPC 1)
Mod-ips 281> ACPI: HPET DFFFDD40, 0038 (r1 BOCHS BXPCHPET 1 BXPC 1)
Mod-ips 282> No NUMA configuration found
Mod-ips 283> Faking a node at 0000000000000000-0000000201400000
Mod-ips 284> Bootmem setup node 0 0000000000000000-0000000201400000
Mod-ips 285> NODE_DATA [000000000000011000 - 000000000001ffff]
Mod-ips 286> bootmap [0000000000020000 - 000000000006027f] pages 41
Mod-ips 287> (6 early reservations) ==> bootmem [0000000000 - 0201400000]

```

```

Mod-ips 288> #0 [0000000000 - 0000001000] BIOS data page ==> [0000000000 - 0000001000]
Mod-ips 289> #1 [0000006000 - 0000008000] TRAMPOLINE ==> [0000006000 - 0000008000]
Mod-ips 290> #2 [0000200000 - 0000d55754] TEXT DATA BSS ==> [0000200000 - 0000d55754]
Mod-ips 291> #3 [000009f400 - 0000100000] BIOS reserved ==> [000009f400 - 0000100000]
Mod-ips 292> #4 [0000008000 - 000000c000] PGTABLE ==> [0000008000 - 000000c000]
Mod-ips 293> #5 [000000c000 - 0000011000] PGTABLE ==> [000000c000 - 0000011000]
Mod-ips 294> found SMP MP-table at [ffff8800000f8920] 000f8920
Mod-ips 295> Zone PFN ranges:
Mod-ips 296> DMA 0x00000000 -> 0x000001000
Mod-ips 297> DMA32 0x000001000 -> 0x001000000
Mod-ips 298> Normal 0x00100000 -> 0x00201400
Mod-ips 299> Movable zone start PFN for each node
Mod-ips 300> early_node_map[3] active PFN ranges
Mod-ips 301> 0: 0x00000000 -> 0x00000009f
Mod-ips 302> 0: 0x000000100 -> 0x000dffffd
Mod-ips 303> 0: 0x00100000 -> 0x00201400
Mod-ips 304> ACPI: PM-Timer IO Port: 0xb008
Mod-ips 305> ACPI: LAPIC (acpi_id[0x00] lapic_id[0x00] enabled)
Mod-ips 306> ACPI: LAPIC (acpi_id[0x01] lapic_id[0x01] enabled)
Mod-ips 307> ACPI: LAPIC (acpi_id[0x02] lapic_id[0x02] enabled)
Mod-ips 308> ACPI: LAPIC (acpi_id[0x03] lapic_id[0x03] enabled)
Mod-ips 309> ACPI: LAPIC (acpi_id[0x04] lapic_id[0x04] enabled)
Mod-ips 310> ACPI: LAPIC (acpi_id[0x05] lapic_id[0x05] enabled)
Mod-ips 311> ACPI: IOAPIC (id[0x06] address[0xfec00000] gsi_base[0])
Mod-ips 312> IOAPIC[0]: apic_id 6, version 0, address 0xfec00000, GSI 0-23
Mod-ips 313> ACPI: INT_SRC_OVR (bus 0 bus_irq 5 global_irq 5 high level)
Mod-ips 314> ACPI: INT_SRC_OVR (bus 0 bus_irq 9 global_irq 9 high level)
Mod-ips 315> ACPI: INT_SRC_OVR (bus 0 bus_irq 10 global_irq 10 high level)
Mod-ips 316> ACPI: INT_SRC_OVR (bus 0 bus_irq 11 global_irq 11 high level)
Mod-ips 317> Using ACPI (MADT) for SMP configuration information
Mod-ips 318> ACPI: HPET id: 0x8086a201 base: 0xfed00000
Mod-ips 319> SMP: Allowing 6 CPUs, 0 hotplug CPUs
Mod-ips 320> Allocating PCI resources starting at e2000000 (gap: e0000000:1ffbc000)
Mod-ips 321> NR_CPUS:32 nr_cpumask_bits:32 nr_cpu_ids:6 nr_node_ids:1
Mod-ips 322> PERCPU: Allocating 49152 bytes of per cpu data
Mod-ips 323> Built 1 zonelists in Zone order, mobility grouping on. Total pages: 1939347
Mod-ips 324> Policy zone: Normal
Mod-ips 325> Kernel command line: ro initfsDev=/dev/hda1 init=loader.run rootrw=/dev/hda2
initf
Mod-ips 326> s=runtime-image.cpio.bz2 hda=nodma console=ttyS0 plat=saleen htlblow=1
hugepages=3
Mod-ips 327> 223
Mod-ips 328> hugetlb_lowmem_setup: Allocated 2097152 huge pages (size=0x200000) from
lowmem are
Mod-ips 329> a at 0xffff88002ee00000 phys addr 0x000000002ee00000
Mod-ips 330> Initializing CPU#0
Mod-ips 331> PID hash table entries: 4096 (order: 12, 32768 bytes)
Mod-ips 332> Fast TSC calibration using PIT
Mod-ips 333> Detected 2792.965 MHz processor.
Mod-ips 334> Console: colour VGA+ 80x25
Mod-ips 335> console [ttyS0] enabled
Mod-ips 336> Checking aperture...
Mod-ips 337> No AGP bridge found
Mod-ips 338> PCI-DMA: Using software bounce buffering for IO (SWIOTLB)
Mod-ips 339> Placing 64MB software IO TLB between ffff880020000000 - ffff880024000000
Mod-ips 340> software IO TLB at phys 0x20000000 - 0x24000000
Mod-ips 341> Memory: 7693472k/8409088k available (3164k kernel code, 524688k absent,
190928k re
Mod-ips 342> served, 1511k data, 1032k init)
Mod-ips 343> Calibrating delay loop (skipped), value calculated using timer frequency..
5585.93
Mod-ips 344> BogoMIPS (lpj=2792965)
Mod-ips 345> Dentry cache hash table entries: 1048576 (order: 11, 8388608 bytes)
Mod-ips 346> Inode-cache hash table entries: 524288 (order: 10, 4194304 bytes)

```

```

Mod-ips 347> Mount-cache hash table entries: 256
Mod-ips 348> CPU: L1 I cache: 32K, L1 D cache: 32K
Mod-ips 349> CPU: L2 cache: 4096K
Mod-ips 350> CPU 0/0x0 -> Node 0
Mod-ips 351> Freeing SMP alternatives: 29k freed
Mod-ips 352> ACPI: Core revision 20081204
Mod-ips 353> Setting APIC routing to flat
Mod-ips 354> ..TIMER: vector=0x30 apic1=0 pin1=0 apic2=-1 pin2=-1
Mod-ips 355> CPU0: Intel QEMU Virtual CPU version 0.12.5 stepping 03
Mod-ips 356> Booting processor 1 APIC 0x1 ip 0x6000
Mod-ips 357> Initializing CPU#1
Mod-ips 358> Calibrating delay using timer specific routine.. 5585.16 BogoMIPS
(lpj=2792581)
Mod-ips 359> CPU: L1 I cache: 32K, L1 D cache: 32K
Mod-ips 360> CPU: L2 cache: 4096K
Mod-ips 361> CPU 1/0x1 -> Node 0
Mod-ips 362> CPU1: Intel QEMU Virtual CPU version 0.12.5 stepping 03
Mod-ips 363> checking TSC synchronization [CPU#0 -> CPU#1]:
Mod-ips 364> Measured 1453783140569731 cycles TSC warp between CPUs, turning off TSC
clock.
Mod-ips 365> Marking TSC unstable due to check_tsc_sync_source failed
Mod-ips 366> Booting processor 2 APIC 0x2 ip 0x6000
Mod-ips 367> Initializing CPU#2
Mod-ips 368> Calibrating delay using timer specific routine.. 5580.51 BogoMIPS
(lpj=2790259)
Mod-ips 369> CPU: L1 I cache: 32K, L1 D cache: 32K
Mod-ips 370> CPU: L2 cache: 4096K
Mod-ips 371> CPU 2/0x2 -> Node 0
Mod-ips 372> CPU2: Intel QEMU Virtual CPU version 0.12.5 stepping 03
Mod-ips 373> Booting processor 3 APIC 0x3 ip 0x6000
Mod-ips 374> Initializing CPU#3
Mod-ips 375> Calibrating delay using timer specific routine.. 5585.18 BogoMIPS
(lpj=2792594)
Mod-ips 376> CPU: L1 I cache: 32K, L1 D cache: 32K
Mod-ips 377> CPU: L2 cache: 4096K
Mod-ips 378> CPU 3/0x3 -> Node 0
Mod-ips 379> CPU3: Intel QEMU Virtual CPU version 0.12.5 stepping 03
Mod-ips 380> Booting processor 4 APIC 0x4 ip 0x6000
Mod-ips 381> Initializing CPU#4
Mod-ips 382> Calibrating delay using timer specific routine.. 5585.15 BogoMIPS
(lpj=2792579)
Mod-ips 383> CPU: L1 I cache: 32K, L1 D cache: 32K
Mod-ips 384> CPU: L2 cache: 4096K
Mod-ips 385> CPU 4/0x4 -> Node 0
Mod-ips 386> CPU4: Intel QEMU Virtual CPU version 0.12.5 stepping 03
Mod-ips 387> Booting processor 5 APIC 0x5 ip 0x6000
Mod-ips 388> Initializing CPU#5
Mod-ips 389> Calibrating delay using timer specific routine.. 5585.21 BogoMIPS
(lpj=2792609)
Mod-ips 390> CPU: L1 I cache: 32K, L1 D cache: 32K
Mod-ips 391> CPU: L2 cache: 4096K
Mod-ips 392> CPU 5/0x5 -> Node 0
Mod-ips 393> CPU5: Intel QEMU Virtual CPU version 0.12.5 stepping 03
Mod-ips 394> Brought up 6 CPUs
Mod-ips 395> Total of 6 processors activated (33507.17 BogoMIPS).
Mod-ips 396> net_namespace: 1312 bytes
Mod-ips 397> Booting paravirtualized kernel on bare hardware
Mod-ips 398> NET: Registered protocol family 16
Mod-ips 399> ACPI: bus type pci registered
Mod-ips 400> dca service started, version 1.8
Mod-ips 401> PCI: Using configuration type 1 for base access
Mod-ips 402> mtrr: your CPUs had inconsistent variable MTRR settings
Mod-ips 403> mtrr: your CPUs had inconsistent MTRRdefType settings
Mod-ips 404> mtrr: probably your BIOS does not setup all CPUs.

```

```
Mod-ips 405> mtrr: corrected configuration.
Mod-ips 406> bio: create slab <bio-0> at 0
Mod-ips 407> ACPI: Interpreter enabled
Mod-ips 408> ACPI: (supports S0 S5)
Mod-ips 409> ACPI: Using IOAPIC for interrupt routing
Mod-ips 410> ACPI: No dock devices found.
Mod-ips 411> ACPI: PCI Root Bridge [PCI0] (0000:00)
Mod-ips 412> pci 0000:00:01.3: quirk: region b000-b03f claimed by PIIX4 ACPI
Mod-ips 413> pci 0000:00:01.3: quirk: region b100-b10f claimed by PIIX4 SMB
Mod-ips 414> IVSHMEM: addr = 4093640704 size = 67108864
Mod-ips 415> ACPI: PCI Interrupt Link [LNKA] (IRQs 5 *10 11)
Mod-ips 416> ACPI: PCI Interrupt Link [LNKB] (IRQs 5 *10 11)
Mod-ips 417> ACPI: PCI Interrupt Link [LNKC] (IRQs 5 10 *11)
Mod-ips 418> ACPI: PCI Interrupt Link [LNKD] (IRQs 5 10 *11)
Mod-ips 419> SCSI subsystem initialized
Mod-ips 420> usbcore: registered new interface driver usbfs
Mod-ips 421> usbcore: registered new interface driver hub
Mod-ips 422> usbcore: registered new device driver usb
Mod-ips 423> PCI: Using ACPI for IRQ routing
Mod-ips 424> pnp: PnP ACPI init
Mod-ips 425> ACPI: bus type pnp registered
Mod-ips 426> pnp: PnP ACPI: found 9 devices
Mod-ips 427> ACPI: ACPI bus type pnp unregistered
Mod-ips 428> NET: Registered protocol family 2
Mod-ips 429> IP route cache hash table entries: 262144 (order: 9, 2097152 bytes)
Mod-ips 430> TCP established hash table entries: 524288 (order: 11, 8388608 bytes)
Mod-ips 431> TCP bind hash table entries: 65536 (order: 8, 1048576 bytes)
Mod-ips 432> TCP: Hash tables configured (established 524288 bind 65536)
Mod-ips 433> TCP reno registered
Mod-ips 434> NET: Registered protocol family 1
Mod-ips 435> Adding htlb page ffff88002ee00000 phys 000000002ee00000 page ffffe20000a41000
Mod-ips 436> HugeTLB registered 2 MB page size, pre-allocated 3223 pages
Mod-ips 437> report_hugepages: Using 1 pages from low memory at ffff88002ee00000 HugeTLB
FS
Mod-ips 438> msgmni has been set to 15026
Mod-ips 439> alg: No test for stdrng (krng)
Mod-ips 440> io scheduler noop registered
Mod-ips 441> io scheduler anticipatory registered
Mod-ips 442> io scheduler deadline registered
Mod-ips 443> io scheduler cfq registered (default)
Mod-ips 444> pci 0000:00:00.0: Limiting direct PCI/PCI transfers
Mod-ips 445> pci 0000:00:01.0: PIIX3: Enabling Passive Release
Mod-ips 446> pci 0000:00:01.0: Activating ISA DMA hang workarounds
Mod-ips 447> pci_hotplug: PCI Hot Plug PCI Core version: 0.5
Mod-ips 448> pciehp: PCI Express Hot Plug Controller Driver version: 0.4
Mod-ips 449> acpiphp: ACPI Hot Plug PCI Controller Driver version: 0.5
Mod-ips 450> acpiphp_glue: can't get bus number, assuming 0
Mod-ips 451> decode_hpp: Could not get hotplug parameters. Use defaults
Mod-ips 452> acpiphp: Slot [1] registered
Mod-ips 453> acpiphp: Slot [2] registered
Mod-ips 454> acpiphp: Slot [3] registered
Mod-ips 455> acpiphp: Slot [4] registered
Mod-ips 456> acpiphp: Slot [5] registered
Mod-ips 457> acpiphp: Slot [6] registered
Mod-ips 458> acpiphp: Slot [7] registered
Mod-ips 459> acpiphp: Slot [8] registered
Mod-ips 460> acpiphp: Slot [9] registered
Mod-ips 461> acpiphp: Slot [10] registered
Mod-ips 462> acpiphp: Slot [11] registered
Mod-ips 463> acpiphp: Slot [12] registered
Mod-ips 464> acpiphp: Slot [13] registered
Mod-ips 465> acpiphp: Slot [14] registered
Mod-ips 466> acpiphp: Slot [15] registered
Mod-ips 467> acpiphp: Slot [16] registered
```

```

Mod-ips 468> acpiphp: Slot [17] registered
Mod-ips 469> acpiphp: Slot [18] registered
Mod-ips 470> acpiphp: Slot [19] registered
Mod-ips 471> acpiphp: Slot [20] registered
Mod-ips 472> acpiphp: Slot [21] registered
Mod-ips 473> acpiphp: Slot [22] registered
Mod-ips 474> acpiphp: Slot [23] registered
Mod-ips 475> acpiphp: Slot [24] registered
Mod-ips 476> acpiphp: Slot [25] registered
Mod-ips 477> acpiphp: Slot [26] registered
Mod-ips 478> acpiphp: Slot [27] registered
Mod-ips 479> acpiphp: Slot [28] registered
Mod-ips 480> acpiphp: Slot [29] registered
Mod-ips 481> acpiphp: Slot [30] registered
Mod-ips 482> acpiphp: Slot [31] registered
Mod-ips 483> shpchp: Standard Hot Plug PCI Controller Driver version: 0.4
Mod-ips 484> fakephp: Fake PCI Hot Plug Controller Driver
Mod-ips 485> fakephp: pci_hp_register failed with error -16
Mod-ips 486> fakephp: pci_hp_register failed with error -16
Mod-ips 487> fakephp: pci_hp_register failed with error -16
Mod-ips 488> fakephp: pci_hp_register failed with error -16
Mod-ips 489> fakephp: pci_hp_register failed with error -16
Mod-ips 490> fakephp: pci_hp_register failed with error -16
Mod-ips 491> fakephp: pci_hp_register failed with error -16
Mod-ips 492> processor ACPI_CPU:00: registered as cooling_device0
Mod-ips 493> processor ACPI_CPU:01: registered as cooling_device1
Mod-ips 494> processor ACPI_CPU:02: registered as cooling_device2
Mod-ips 495> processor ACPI_CPU:03: registered as cooling_device3
Mod-ips 496> processor ACPI_CPU:04: registered as cooling_device4
Mod-ips 497> processor ACPI_CPU:05: registered as cooling_device5
Mod-ips 498> hpet_acpi_add: no address or irqs in _CRS
Mod-ips 499> Non-volatile memory driver v1.3
Mod-ips 500> Linux agpgart interface v0.103
Mod-ips 501> ipmi message handler version 39.2
Mod-ips 502> ipmi device interface
Mod-ips 503> IPMI System Interface driver.
Mod-ips 504> ipmi_si: Unable to find any System Interface(s)
Mod-ips 505> IPMI SMB Interface driver
Mod-ips 506> IPMI Watchdog: driver initialized
Mod-ips 507> Copyright (C) 2004 MontaVista Software - IPMI Powerdown via sys_reboot.
Mod-ips 508> Serial: 8250/16550 driver, 4 ports, IRQ sharing enabled
Mod-ips 509> ?serial8250: ttyS0 at I/O 0x3f8 (irq = 4) is a 16550A
Mod-ips 510> serial8250: ttyS1 at I/O 0x2f8 (irq = 3) is a 16550A
Mod-ips 511> 00:06: ttyS0 at I/O 0x3f8 (irq = 4) is a 16550A
Mod-ips 512> 00:07: ttyS1 at I/O 0x2f8 (irq = 3) is a 16550A
Mod-ips 513> brd: module loaded
Mod-ips 514> loop: module loaded
Mod-ips 515> lpc: version 0.1 (Nov 10 2011)
Mod-ips 516> tun: Universal TUN/TAP device driver, 1.6
Mod-ips 517> tun: (C) 1999-2004 Max Krasnyansky <maxk@qualcomm.com>
Mod-ips 518> Uniform Multi-Platform E-IDE driver
Mod-ips 519> piix 0000:00:01.1: IDE controller (0x8086:0x7010 rev 0x00)
Mod-ips 520> piix 0000:00:01.1: not 100native mode: will probe irqs later
Mod-ips 521> ide0: BM-DMA at 0xc000-0xc007
Mod-ips 522> ide1: BM-DMA at 0xc008-0xc00f
Mod-ips 523> hda: QEMU HARDDISK, ATA DISK drive
Mod-ips 524> Clocksource tsc unstable (delta = 2851415955127 ns)
Mod-ips 525> hda: MWDMA2 mode selected
Mod-ips 526> hdc: QEMU DVD-ROM, ATAPI CD/DVD-ROM drive
Mod-ips 527> hdc: MWDMA2 mode selected
Mod-ips 528> ide0 at 0x1f0-0x1f7,0x3f6 on irq 14
Mod-ips 529> ide1 at 0x170-0x177,0x376 on irq 15
Mod-ips 530> ide_generic: please use "probe_mask=0x3f" module parameter for probing all
legacy

```



```
Mod-ips 531> ISA IDE ports
Mod-ips 532> ide-gd driver 1.18
Mod-ips 533> hda: max request size: 512KiB
Mod-ips 534> hda: 7815168 sectors (4001 MB) w/256KiB Cache, CHS=7753/255/63
Mod-ips 535> hda: cache flushes supported
Mod-ips 536> hda: hda1 hda2 hda3 hda4
Mod-ips 537> Driver 'sd' needs updating - please use bus_type methods
Mod-ips 538> Driver 'sr' needs updating - please use bus_type methods
Mod-ips 539> ehci_hcd: USB 2.0 'Enhanced' Host Controller (EHCI) Driver
Mod-ips 540> ohci_hcd: USB 1.1 'Open' Host Controller (OHCI) Driver
Mod-ips 541> uhci_hcd: USB Universal Host Controller Interface driver
Mod-ips 542> Initializing USB Mass Storage driver...
Mod-ips 543> usbcore: registered new interface driver usb-storage
Mod-ips 544> USB Mass Storage support registered.
Mod-ips 545> PNP: PS/2 Controller [PNP0303:KBD,PNP0f13:MOU] at 0x60,0x64 irq 1,12
Mod-ips 546> serio: i8042 KBD port at 0x60,0x64 irq 1
Mod-ips 547> serio: i8042 AUX port at 0x60,0x64 irq 12
Mod-ips 548> mice: PS/2 mouse device common for all mice
Mod-ips 549> rtc_cmos 00:01: rtc core: registered rtc_cmos as rtc0
Mod-ips 550> rtc0: alarms up to one day, 114 bytes nvram
Mod-ips 551> input: AT Translated Set 2 keyboard as /class/input/input0
Mod-ips 552> i2c /dev entries driver
Mod-ips 553> piix4_smbus 0000:00:01.3: SMBus Host Controller at 0xb100, revision 0
Mod-ips 554> device-mapper: ioctl: 4.14.0-ioctl (2008-04-23) initialised:
dm-devel@redhat.com
Mod-ips 555> cpuidle: using governor ladder
Mod-ips 556> usbcore: registered new interface driver usbbhid
Mod-ips 557> usbbhid: v2.6:USB HID core driver
Mod-ips 558> TCP cubic registered
Mod-ips 559> IPv6: Loaded, but is disabled by default. IPv6 may be enabled on individual
interf
Mod-ips 560> aces.
Mod-ips 561> NET: Registered protocol family 10
Mod-ips 562> NET: Registered protocol family 17
Mod-ips 563> NET: Registered protocol family 5
Mod-ips 564> rtc_cmos 00:01: setting system clock to 2012-01-17 14:06:34 UTC (1326809194)
Mod-ips 565> Freeing unused kernel memory: 1032k freed
Mod-ips 566> Write protecting the kernel read-only data: 4272k
Mod-ips 567> Loader init started...
Mod-ips 568> kjournald starting. Commit interval 5 seconds
Mod-ips 569> EXT3-fs: mounted filesystem with ordered data mode.
Mod-ips 570> input: ImExPS/2 Generic Explorer Mouse as /class/input/input1
Mod-ips 571> 51216 blocks
Mod-ips 572> Checking rootrw fs: corrected filesystem
Mod-ips 573> kjournald starting. Commit interval 5 seconds
Mod-ips 574> EXT3 FS on hda2, internal journal
Mod-ips 575> EXT3-fs: mounted filesystem with ordered data mode.
Mod-ips 576> mkdir: cannot create directory '/lib/modules': File exists
Mod-ips 577> init started: BusyBox v1.13.1 (2011-11-01 07:21:34 CDT)
Mod-ips 578> starting pid 678, tty '': '/etc/init.d/rc.init'
Mod-ips 579> Checking system fs: no errors
Mod-ips 580> kjournald starting. Commit interval 5 seconds
Mod-ips 581> EXT3-fs: mounted filesystem with ordered data mode.
Mod-ips 582> /etc/init.d/rc.init: line 102: /proc/sys/vm/bdflush: No such file or
directory
Mod-ips 583> starting pid 728, tty '': '/etc/init.d/rcS'
Mod-ips 584> Initializing random number generator... done.
Mod-ips 585> Starting network... ifconfig lo 127.0.0.1 netmask 255.255.255.255 up
Mod-ips 586> starting inetd
Mod-ips 587> done
Mod-ips 588> Starting sshd:
Mod-ips 589> Starting nsd:
Mod-ips 590> Set Irq Affinity ... cpus:
Mod-ips 591> Checking kernel allocated memory: EXT3 FS on hda1, internal journal
```

```

Mod-ips 592> [OK]
Mod-ips 593> Unloading REGEX-CP drivers ...
Mod-ips 594> Loading REGEX-CP drivers ...
Mod-ips 595> ACPI: PCI Interrupt Link [LNKD] enabled at IRQ 11
Mod-ips 596> cpp_user_kvm 0000:00:04.0: PCI INT A -> Link[LNKD] -> GSI 11 (level, high) ->
IRQ
Mod-ips 597> 11
Mod-ips 598> Detected cpp_user_kvm device with 33554432 bytes of shared memory
Mod-ips 599> Device 0: model=LCPX8640, cpc=T2005, cpe0=None, cpe1=None
Mod-ips 600> Load cidmodcap:
Mod-ips 601> Create node:
Mod-ips 602> ln: /etc/modprobe.conf: File exists
Mod-ips 603> Shutting down network... ifconfig lo down
Mod-ips 604> ifconfig lo down
Mod-ips 605> done
Mod-ips 606> Load ihm:
Mod-ips 607> Create node:
Mod-ips 608> Load kvm_ivshmem: IVSHMEM: writing 0x0 to 0xc86cf8
Mod-ips 609> IVSHMEM: IntrMask write(w) val = 0xffff
Mod-ips 610> Create node:
Mod-ips 611> Create node:
Mod-ips 612> Create node:
Mod-ips 613> Set Irq Affinity ... cpus: 6
Mod-ips 614> Starting network... ifconfig lo 127.0.0.1 netmask 255.255.255.255 up
Mod-ips 615> done
Mod-ips 616> Creating boot.info[OK]
Mod-ips 617> Checking for system modifications since last boot[OK]
Mod-ips 618> Checking model identification[OK]
Mod-ips 619> Model: ASA-5555
Mod-ips 620> Model=ASA-5555
Mod-ips 621> Unable to set speed and duplex for user mode interfaces
Mod-ips 622> interface type 0x8086:0x100e at pci address 0:6.0(0) is currently named eth1
Mod-ips 623> Renaming eth1 --> ma0_0
Mod-ips 624> interface type 0x8086:0x100e at pci address 0:7.0(0) is currently named po0_0
Mod-ips 625> interface type 0x8086:0x100e at pci address 0:5.0(0) is currently named eth0
Mod-ips 626> Renaming eth0 --> sy0_0
Mod-ips 627> Initializing access list
Mod-ips 628> MGMT_INTFC_CIDS_NAME Management0/0
Mod-ips 629> MGMT_INTFC_OS_NAME ma0_0
Mod-ips 630> SYSTEM_PCI_IDS 0x0030,0x0028
Mod-ips 631> Load rebootkom:
Mod-ips 632> root: Starting SSM controlplane
Mod-ips 633> Starting CIDS:
Mod-ips 634> starting pid 1718, tty '/dev/ttyS0': '/sbin/getty -L ttyS0 9600 vt100'

```

## Failover Scenarios

The following failover scenarios apply to the ASA 5500-X series in the event of configuration changes, signature/signature engine updates, service packs, and SensorApp crashes on the ASA 5500-X IPS SSP.

### Single ASA in Fail-Open Mode

- If the ASA is configured in fail-open mode for the ASA 5500-X IPS SSP, and the ASA 5500-X IPS SSP experiences a configuration change or signature/signature engine update, traffic is passed through the ASA without being inspected.
- If the ASA is configured in fail-open mode for the ASA 5500-X IPS SSP, and the ASA 5500-X IPS SSP experiences a SensorApp crash or a service pack upgrade, traffic is passed through the ASA without being inspected.

### Single ASA in Fail-Close Mode

- If the ASA is configured in fail-close mode for the ASA 5500-X IPS SSP, and the ASA 5500-X IPS SSP experiences a configuration change or a signature/signature engine update, traffic is stopped from passing through the ASA.
- If the ASA is configured in fail-close mode for the ASA 5500-X IPS SSP, and the ASA 5500-X IPS SSP experiences a SensorApp crash or a service pack upgrade, traffic is stopped from passing through the ASA.

### Two ASAs in Fail-Open Mode

- If the ASAs are configured in fail-open mode and if the ASA 5500-X IPS SSP on the active ASA experiences a configuration change or a signature/signature engine update, traffic is still passed through the active ASA without being inspected. Failover is not triggered.
- If the ASAs are configured in fail-open mode, and if the ASA 5500-X IPS SSP on the active ASA experiences a SensorApp crash or a service pack upgrade, failover is triggered and traffic passes through the ASA 5500-X IPS SSP that was previously the standby ASA 5500-X IPS SSP.

### Two ASAs in Fail-Close Mode

- If the ASAs are configured in fail-close mode, and if the ASA 5500-X IPS SSP on the active ASA experiences a configuration change or a signature/signature engine update, traffic is stopped from passing through the active ASA. No failover is triggered.
- If the ASAs are configured in fail-close mode, and if the ASA 5500-X IPS SSP on the active ASA experiences a SensorApp crash or a service pack upgrade, failover is triggered and traffic passes through the ASA 5500-X IPS SSP that was previously the standby for the ASA 5500-X IPS SSP.

### Configuration Examples

Use the following configuration for the primary ASA:

```
interface GigabitEthernet0/7
 description LAN Failover Interface

failover
failover lan unit primary
failover lan interface folink GigabitEthernet0/7
failover interface ip folink 172.27.48.1 255.255.255.0 standby 172.27.48.2
```

Use the following configuration for the secondary ASA:

```
interface GigabitEthernet0/7
 description LAN Failover Interface

failover
failover lan unit secondary
failover lan interface folink GigabitEthernet0/7
failover interface ip folink 172.27.48.1 255.255.255.0 standby 172.27.48.2
```

## The ASA 5500-X IPS SSP and the Normalizer Engine

The majority of the features in the Normalizer engine are not used on the ASA 5500-X IPS SSP, because the ASA itself handles the normalization. Packets on the ASA IPS modules go through a special path in the Normalizer that only reassembles fragments and puts packets in the right order for the TCP stream. The Normalizer does not do any of the normalization that is done on an inline IPS appliance, because that causes problems in the way the ASA handles the packets.

The following Normalizer engine signatures are not supported:

- 1300.0
- 1304.0
- 1305.0
- 1307.0
- 1308.0
- 1309.0
- 1311.0
- 1315.0
- 1316.0
- 1317.0
- 1330.0
- 1330.1
- 1330.2
- 1330.9
- 1330.10
- 1330.12
- 1330.14
- 1330.15
- 1330.16
- 1330.17
- 1330.18

## The ASA 5500-X IPS SSP and Memory Usage

For the ASA 5500-X IPS SSP, the memory usage is 93%. The default health thresholds for the sensor are 80% for yellow and 91% for red, so the sensor health will be shown as red on these platforms even for normal operating conditions. You can tune the threshold percentage for memory usage so that it reads more accurately for these platforms by configuring the **memory-usage-policy** option in the sensor health metrics.



### Note

Make sure you have the **memory-usage-policy** option in the sensor health metrics enabled.

Table C-3 lists the yellow-threshold and the red-threshold health values.

**Table C-3 ASA 5500-X IPS SSP Memory Usage Values**

| Platform           | Yellow | Red | Memory Used |
|--------------------|--------|-----|-------------|
| ASA 5512-X IPS SSP | 85%    | 91% | 28%         |
| ASA 5515-X IPS SSP | 88%    | 92% | 14%         |
| ASA 5525-X IPS SSP | 88%    | 92% | 14%         |

**Table C-3 ASA 5500-X IPS SSP Memory Usage Values**

| Platform           | Yellow | Red | Memory Used |
|--------------------|--------|-----|-------------|
| ASA 5545-X IPS SSP | 93%    | 96% | 13%         |
| ASA 5555-X IPS SSP | 95%    | 98% | 17%         |

## The ASA 5500-X IPS SSP and Jumbo Packet Frame Size

Refer to the following URL for information about the ASA 5500-X IPS SSP jumbo packet frame size:

[http://www.cisco.com/en/US/docs/security/asa/asa84/configuration/guide/interface\\_start.html#wp1328869](http://www.cisco.com/en/US/docs/security/asa/asa84/configuration/guide/interface_start.html#wp1328869)



### Note

A jumbo frame is an Ethernet packet that is larger than the standard maximum of 1518 bytes (including Layer 2 header and FCS).

## The ASA 5500-X IPS SSP and Jumbo Packets

The jumbo packet count in the **show interface** command output from the lines `Total Jumbo Packets Received` and `Total Jumbo Packets Transmitted` for ASA IPS modules may be larger than expected due to some packets that were almost jumbo size on the wire being counted as jumbo size by the IPS. This miscount is a result of header bytes added to the packet by the ASA before the packet is transmitted to the IPS. For IPv4, 58 bytes of header data are added. For IPv6, 78 bytes of header data are added. The ASA removes the added IPS header before the packet leaves the ASA.

## TCP Reset Differences Between IPS Appliances and ASA IPS Modules

The IPS appliance sends TCP reset packets to both the attacker and victim when `reset-tcp-connectionReset TCP Connection` is selected. The IPS appliance sends a TCP reset packet only to the victim under the following circumstances:

- When a `deny-packet-inlineDeny Packet Inline` or `deny-connection-inlineDeny Connection Inline` is selected
- When TCP-based signatures and `reset-tcp-connectionReset TCP Connection` have NOT been selected

In the case of the ASA IPS module, the TCP reset request is sent to the ASA, and the ASA then sends the TCP reset packets. The ASA sends TCP reset packets to both the attacker and victim when the `reset-tcp-connectionReset TCP Connection` is selected. When `deny-packet-inlineDeny Packet Inline` or `deny-connection-inlineDeny Connection Inline` is selected, the ASA sends the TCP reset packet to either the attacker or victim depending on the configuration of the signature. Signatures configured to swap the attacker and victim when reporting the alert can cause the ASA to send the TCP reset packet to the attacker.

### For More Information

For a detailed description of all the event actions, see [Event Actions, page 7-5](#).

## IPS Reloading Messages

**Symptom** ASA syslog messages similar to the following are observed and the root cause of the message is not clear:

```
%ASA-1-505013: ASA-SSM-10 Module in slot 1, application reloading "IPS", version
"7.1(6)E4" Config Change
%ASA-1-505013: ASA5585-SSP-IPS10 Module in slot 1, application reloading "IPS", version
"7.1(1)E4" Config Change
```

These messages occur once an hour for sensors not actively being configured or more often for sensors being configured.

**Conditions** ASA adaptive appliances running an affected software version with an ASA IPS module (ASA 5500 AIP SSMASA 5500-X IPS SSPASA 5585-X IPS SSP) installed that is running IPS 7.1 or later. The common cause for these messages is global correlation and/or signature updates occurring on the ASA IPS module that results in these messages being generated for some, but not necessarily all of the updates, which are attempted every five minutes.

**Workaround** None. The cause of these messages can be confirmed on the sensor module by reviewing the **show events status past** command output and identifying a status event that corresponds to the ASA syslog message that matches the date and time. The sensor's status event should provide further details about what operation occurred that resulted in the ASA syslog message.

## IPS Not Loading

**Symptom** For a failing unit, the Mod Card Type shows `ips Unknown`:

CMGR PLAT: In sw\_mod\_idprom\_resp\_handler Failed to find idp resp udi pdesc for slot 1  
messages are seen on the ASA console.

The mac address contains either `da` or `cb` (hex values).

**Conditions** Loading the IPS image on ASA 5500-X platforms.

**Workaround** The IPS 7.1(8) p1E4 patch fixes this problem.

## Troubleshooting the ASA 5585-X IPS SSP



**Tip**

Before troubleshooting the ASA 5585-X IPS SSP, check the Caveats section of the Readme for the software version installed on your sensor to see if you are dealing with a known issue.

This section contains troubleshooting information specific to the ASA 5585-X IPS SSP, and contains the following topics:

- [Health and Status Information, page C-79](#)
- [Failover Scenarios, page C-82](#)
- [Traffic Flow Stopped on IPS Switchports, page C-83](#)

- [The ASA 5585-X IPS SSP and the Normalizer Engine, page C-83](#)
- [The ASA 5585-X IPS SSP and Jumbo Packet Frame Size, page C-84](#)
- [The ASA 5585-X IPS SSP and Jumbo Packets, page C-84](#)
- [TCP Reset Differences Between IPS Appliances and ASA IPS Modules, page C-84](#)
- [IPS Reloading Messages, page C-85](#)

## Health and Status Information

To see the general health of the ASA 5585-X IPS SSP, use the **show module 1 details** command.

```
asa# show module 1 details
Getting details from the Service Module, please wait...
ASA 5585-X IPS Security Services Processor-20 with 8GE
Model: ASA5585-SSP-IPS20
Hardware version: 1.0
Serial Number: ABC1234DEFG
Firmware version: 2.0(1)3
Software version: 7.1(1)E4
MAC Address Range: 8843.e12f.5414 to 8843.e12f.541f
App. name: IPS
App. Status: Up
App. Status Desc: Normal Operation
App. version: 7.1(1)E4
Data plane Status: Up
Status: Up
Mgmt IP addr: 192.0.2.3
Mgmt Network mask: 255.255.255.0
Mgmt Gateway: 192.0.2.254
Mgmt Access List: 10.0.0.0/8
Mgmt Access List: 64.0.0.0/8
Mgmt web ports: 443
Mgmt TLS enabled true
asa
```

The output shows that the ASA 5585-X IPS SSP is up. If the status reads `Down`, you can reset it using the **hw-module module 1 reset** command.

```
asa# hw-module module 1 reset
The module in slot 1 should be shut down before
resetting it or loss of configuration may occur.
Reset module in slot 1? [confirm]
Reset issued for module in slot 1
asa# show module 1 details
Getting details from the Service Module, please wait...
Unable to read details from slot 1
ASA 5585-X IPS Security Services Processor-20 with 8GE
Model: ASA5585-SSP-IPS20
Hardware version: 1.0
Serial Number: ABC1234DEFG
Firmware version: 2.0(7)0
Software version: 7.1(1)E4
MAC Address Range: 5475.d029.7f9c to 5475.d029.7fa7
App. name: IPS
App. Status: Not Applicable
App. Status Desc: Not Applicable
App. version: 7.1(1)E4
Data plane Status: Not Applicable
Status: Shutting Down
asa# show module 1 details
```

```

Getting details from the Service Module, please wait...
Unable to read details from slot 1
ASA 5585-X IPS Security Services Processor-20 with 8GE
Model: ASA5585-SSP-IPS20
Hardware version: 1.0
Serial Number: ABC1234DEFG
Firmware version: 2.0(7)0
Software version: 7.1(1)E4
MAC Address Range: 5475.d029.7f9c to 5475.d029.7fa7
App. name: IPS
App. Status: Not Applicable
App. Status Desc: Not Applicable
App. version: 7.1(1)E4
Data plane Status: Not Applicable
Status: Down
asa# show module 1 details
Getting details from the Service Module, please wait...
Unable to read details from slot 1
ASA 5585-X IPS Security Services Processor-20 with 8GE
Model: ASA5585-SSP-IPS20
Hardware version: 1.0
Serial Number: ABC1234DEFG
Firmware version: 2.0(7)0
Software version: 7.1(1)E4
MAC Address Range: 5475.d029.7f9c to 5475.d029.7fa7
App. name: IPS
App. Status: Not Applicable
App. Status Desc: Not Applicable
App. version: 7.1(1)E4
Data plane Status: Not Applicable
Status: Init
asa# show module 1 details
Getting details from the Service Module, please wait...
ASA 5585-X IPS Security Services Processor-20 with 8GE
Model: ASA5585-SSP-IPS20
Hardware version: 1.0
Serial Number: ABC1234DEFG
Firmware version: 2.0(7)0
Software version: 7.1(1)E4
MAC Address Range: 5475.d029.7f9c to 5475.d029.7fa7
App. name: IPS
App. Status: Reload
App. Status Desc: Starting up
App. version: 7.1(1)E4
Data plane Status: Down
Status: Up
Mgmt IP addr: 192.0.2.3
Mgmt Network mask: 255.255.255.0
Mgmt Gateway: 192.0.2.254
Mgmt Access List: 0.0.0.0/0
Mgmt web ports: 443
Mgmt TLS enabled: true
asa# show module 1 details
Getting details from the Service Module, please wait...
ASA 5585-X IPS Security Services Processor-20 with 8GE
Model: ASA5585-SSP-IPS20
Hardware version: 1.0
Serial Number: ABC1234DEFG
Firmware version: 2.0(7)0
Software version: 7.1(1)E4
MAC Address Range: 5475.d029.7f9c to 5475.d029.7fa7
App. name: IPS
App. Status: Up
App. Status Desc: Normal Operation

```



```

App. version: 7.1(1)E4
Data plane Status: Up
Status: Up
Mgmt IP addr: 192.0.2.3
Mgmt Network mask: 255.255.255.0
Mgmt Gateway: 192.0.2.254
Mgmt Access List: 0.0.0.0/0
Mgmt web ports: 443
Mgmt TLS enabled: true
asa#

```

If you have problems with reimaging the ASA 5585-X IPS SSP, use the **debug module-boot** command to see the output as it boots. Make sure you have the correct IP address for the TFTP server and you have the correct file on the TFTP server. Then use the **hw-module module 1 recover** command again to reimage the module.

```

ips-ssp# hw-module module 1 recover configure
Image URL [tftp://0.0.0.0/]: tftp://10.10.10.10//IPS-SSP_20-K9-sys-1.1-a-7.1-1-E4.img
Port IP Address [0.0.0.0]: 10.10.10.11
VLAN ID [0]:
Gateway IP Address [0.0.0.0]: 10.10.10.254

asa(config)# debug module-boot
debug module-boot enabled at level 1
asa(config)# hw-module module 1 recover boot
The module in slot 1 will be recovered. This may erase all configuration and all data on
that device and attempt to download a new image for it.
Recover module in slot 1? [confirm]
Recover issued for module in slot 1
asa(config)# Slot-1 140> Cisco Systems ROMMON Version (1.0(10)0) #0: Fri Mar 25 23:02:10
PST 2010
Slot-1 141> Platform ASA5585-SSP-IPS20
Slot-1 142> GigabitEthernet0/0
Slot-1 143> Link is UP
Slot-1 144> MAC Address: 000b.fcf8.0176
Slot-1 145> ROMMON Variable Settings:
Slot-1 146> ADDRESS=192.0.2.3
Slot-1 147> SERVER=192.0.2.15
Slot-1 148> GATEWAY=192.0.2.254
Slot-1 149> PORT=GigabitEthernet0/0
Slot-1 150> VLAN=untagged
Slot-1 151> IMAGE=IPS-SSP-K9-sys-1.1-a-7.1-0.1.img
Slot-1 152> CONFIG=
Slot-1 153> LINKTIMEOUT=20
Slot-1 154> PKTTIMEOUT=4
Slot-1 155> RETRY=20
Slot-1 156> tftp IPS-SSP_10-K9-sys-1.1-a-7.1-0.1.img@192.0.2.15 via 192.0.2.254
Slot-1 157> TFTP failure: Packet verify failed after 20 retries
Slot-1 158> Rebooting due to Autoboot error ...
Slot-1 159> Rebooting....
Slot-1 160> Cisco Systems ROMMON Version (1.0(10)0) #0: Fri Mar 25 23:02:10 PST 2010
Slot-1 161> Platform ASA5585-SSP-IPS20
Slot-1 162> GigabitEthernet0/0
Slot-1 163> Link is UP
Slot-1 164> MAC Address: 000b.fcf8.0176
Slot-1 165> ROMMON Variable Settings:
Slot-1 166> ADDRESS=192.0.2.3
Slot-1 167> SERVER=192.0.2.15
Slot-1 168> GATEWAY=192.0.2.254
Slot-1 169> PORT=GigabitEthernet0/0
Slot-1 170> VLAN=untagged
Slot-1 171> IMAGE=IPS-SSP_10-K9-sys-1.1-a-7.1-0.1.img
Slot-1 172> CONFIG=

```

```
Slot-1 173> LINKTIMEOUT=20
Slot-1 174> PKTTIMEOUT=4
Slot-1 175> RETRY=20
Slot-1 176> tftp IPS-SSP_10-K9-sys-1.1-a-7.1-0.1.img@192.0.2.15 via 192.0.2.254
```

## Failover Scenarios

The following failover scenarios apply to the ASA 5585-X in the event of configuration changes, signature/signature engine updates, service packs, and SensorApp crashes on the ASA 5585-X IPS SSP.

### Single ASA 5585-X in Fail-Open Mode

- If the ASA is configured in fail-open mode for the ASA 5585-X IPS SSP, and the ASA 5585-X IPS SSP experiences a configuration change or signature/signature engine update, traffic is passed through the ASA without being inspected.
- If the ASA is configured in fail-open mode for the ASA 5585-X IPS SSP, and the ASA 5585-X IPS SSP experiences a SensorApp crash or a service pack upgrade, traffic is passed through the ASA without being inspected.

### Single ASA 5585-X in Fail-Close Mode

- If the ASA is configured in fail-close mode for the ASA 5585-X IPS SSP, and the ASA 5585-X IPS SSP experiences a configuration change or a signature/signature engine update, traffic is stopped from passing through the ASA.
- If the ASA is configured in fail-close mode for the ASA 5585-X IPS SSP, and the ASA 5585-X IPS SSP experiences a SensorApp crash or a service pack upgrade, traffic is stopped from passing through the ASA.

### Two ASA 5585-Xs in Fail-Open Mode

- If the ASAs are configured in fail-open mode and if the ASA 5585-X IPS SSP on the active ASA experiences a configuration change or a signature/signature engine update, traffic is still passed through the active ASA without being inspected. Failover is not triggered.
- If the ASAs are configured in fail-open mode, and if the ASA 5585-X IPS SSP on the active ASA experiences a SensorApp crash or a service pack upgrade, failover is triggered and traffic passes through the ASA 5585-X IPS SSP that was previously the standby ASA 5585-X IPS SSP.

### Two ASA 5585-Xs in Fail-Close Mode

- If the ASAs are configured in fail-close mode, and if the ASA 5585-X IPS SSP on the active ASA experiences a configuration change or a signature/signature engine update, traffic is stopped from passing through the active ASA. No failover is triggered.
- If the ASAs are configured in fail-close mode, and if the ASA 5585-X IPS SSP on the active ASA experiences a SensorApp crash or a service pack upgrade, failover is triggered and traffic passes through the ASA 5585-X IPS SSP that was previously the standby for the ASA 5585-X IPS SSP.

### Configuration Examples

Use the following configuration for the primary ASA:

```
interface GigabitEthernet0/7
 description LAN Failover Interface

failover
failover lan unit primary
failover lan interface folink GigabitEthernet0/7
```

```
failover interface ip folink 172.27.48.1 255.255.255.0 standby 172.27.48.2
```

Use the following configuration for the secondary ASA:

```
interface GigabitEthernet0/7
 description LAN Failover Interface

failover
failover lan unit secondary
failover lan interface folink GigabitEthernet0/7
failover interface ip folink 172.27.48.1 255.255.255.0 standby 172.27.48.2
```

## Traffic Flow Stopped on IPS Switchports

**Problem** Traffic on any port located on the ASA 5585-X IPS SSP (1/x) no longer passes through the adaptive security appliance when the ASA 5585-X IPS SSP is reset or shut down. This affects all traffic through these ports regardless of whether or not the traffic would have been monitored by the IPS. The link on the ports will link down when the ASA 5585-X IPS SSP is reset or shut down.

**Possible Cause** Using the ports located on the ASA 5585-X IPS SSP (1/x), and resetting or shutting it down via any mechanism.

**Solution** Use the ports on the adaptive security appliance (0/x) instead because those ports do not lose their link when the ASA 5585-X IPS SSP is reset or shut down.

## The ASA 5585-X IPS SSP and the Normalizer Engine

The majority of the features in the Normalizer engine are not used on the ASA 5585-X IPS SSP, because the ASA itself handles the normalization. Packets on the ASA IPS modules go through a special path in the Normalizer that only reassembles fragments and puts packets in the right order for the TCP stream. The Normalizer does not do any of the normalization that is done on an inline IPS appliance, because that causes problems in the way the ASA handles the packets.

The following Normalizer engine signatures are not supported:

- 1300.0
- 1304.0
- 1305.0
- 1307.0
- 1308.0
- 1309.0
- 1311.0
- 1315.0
- 1316.0
- 1317.0
- 1330.0
- 1330.1
- 1330.2

- 1330.9
- 1330.10
- 1330.12
- 1330.14
- 1330.15
- 1330.16
- 1330.17
- 1330.18

## The ASA 5585-X IPS SSP and Jumbo Packet Frame Size

Refer to the following URL for information about the ASA 5585-X IPS SSP jumbo packet frame size:

[http://www.cisco.com/en/US/docs/security/asa/asa84/configuration/guide/interface\\_start.html#wp1328869](http://www.cisco.com/en/US/docs/security/asa/asa84/configuration/guide/interface_start.html#wp1328869)



### Note

A jumbo frame is an Ethernet packet that is larger than the standard maximum of 1518 bytes (including Layer 2 header and FCS).

## The ASA 5585-X IPS SSP and Jumbo Packets

The jumbo packet count in the **show interface** command output from the lines `Total Jumbo Packets Received` and `Total Jumbo Packets Transmitted` for ASA IPS modules may be larger than expected due to some packets that were almost jumbo size on the wire being counted as jumbo size by the IPS. This miscount is a result of header bytes added to the packet by the ASA before the packet is transmitted to the IPS. For IPv4, 58 bytes of header data are added. For IPv6, 78 bytes of header data are added. The ASA removes the added IPS header before the packet leaves the ASA.

## TCP Reset Differences Between IPS Appliances and ASA IPS Modules

The IPS appliance sends TCP reset packets to both the attacker and victim when `reset-tcp-connectionReset TCP Connection` is selected. The IPS appliance sends a TCP reset packet only to the victim under the following circumstances:

- When a `deny-packet-inlineDeny Packet Inline` or `deny-connection-inlineDeny Connection Inline` is selected
- When TCP-based signatures and `reset-tcp-connectionReset TCP Connection` have NOT been selected

In the case of the ASA IPS module, the TCP reset request is sent to the ASA, and the ASA then sends the TCP reset packets. The ASA sends TCP reset packets to both the attacker and victim when the `reset-tcp-connectionReset TCP Connection` is selected. When `deny-packet-inlineDeny Packet Inline` or `deny-connection-inlineDeny Connection Inline` is selected, the ASA sends the TCP reset packet to either the attacker or victim depending on the configuration of the signature. Signatures configured to swap the attacker and victim when reporting the alert can cause the ASA to send the TCP reset packet to the attacker.

**For More Information**

For a detailed description of all the event actions, see [Event Actions, page 7-5](#).

## IPS Reloading Messages

**Symptom** ASA syslog messages similar to the following are observed and the root cause of the message is not clear:

```
%ASA-1-505013: ASA-SSM-10 Module in slot 1, application reloading "IPS", version
"7.1(6)E4" Config Change
%ASA-1-505013: ASA5585-SSP-IPS10 Module in slot 1, application reloading "IPS", version
"7.1(1)E4" Config Change
```

These messages occur once an hour for sensors not actively being configured or more often for sensors being configured.

**Conditions** ASA adaptive appliances running an affected software version with an ASA IPS module (ASA 5500 AIP SSMASA 5500-X IPS SSPASA 5585-X IPS SSP) installed that is running IPS 7.1 or later. The common cause for these messages is global correlation and/or signature updates occurring on the ASA IPS module that results in these messages being generated for some, but not necessarily all of the updates, which are attempted every five minutes.

**Workaround** None. The cause of these messages can be confirmed on the sensor module by reviewing the **show events status past** command output and identifying a status event that corresponds to the ASA syslog message that matches the date and time. The sensor's status event should provide further details about what operation occurred that resulted in the ASA syslog message.

## Gathering Information

You can use the following CLI commands and scripts to gather information and diagnose the state of the sensor when problems occur. You can use the **show tech-support** command to gather all the information of the sensor, or you can use the other individual commands listed in this section for specific information. This section contains the following topics:

- [Health and Network Security Information, page C-86](#)
- [Tech Support Information, page C-86](#)
- [Version Information, page C-90](#)
- [Statistics Information, page C-93](#)
- [Interfaces Information, page C-106](#)
- [Events Information, page C-107](#)
- [cidDump Script, page C-111](#)
- [Uploading and Accessing Files on the Cisco FTP Site, page C-112](#)

## Health and Network Security Information



### Caution

When the sensor is first starting, it is normal for certain health metric statuses to be red until the sensor is fully up and running.



### Note

The ASA 5500-X IPS SSP and the ASA 5585-X IPS SSP do not support bypass mode. The adaptive security appliance will either fail open, fail close, or fail over depending on the configuration of the adaptive security appliance and the type of activity being done on the IPS.

Use the **show health** command in privileged EXEC mode to display the overall health status information of the sensor. The health status categories are rated by red and green with red being critical. To display the overall health status of the sensor, follow these steps:

**Step 1** Log in to the CLI.

**Step 2** Show the health and security status of the sensor.

```
sensor# show health
Overall Health Status Red
Health Status for Failed Applications Green
Health Status for Signature Updates Green
Health Status for License Key Expiration Red
Health Status for Running in Bypass Mode Green
Health Status for Interfaces Being Down Red
Health Status for the Inspection Load Green
Health Status for the Time Since Last Event Retrieval Green
Health Status for the Number of Missed Packets Green
Health Status for the Memory Usage Not Enabled
Health Status for Global Correlation Red
Health Status for Network Participation Not Enabled

Security Status for Virtual Sensor vs0 Green
sensor#
```

## Tech Support Information

The **show tech-support** command is useful for capturing all sensor status and configuration information. This section describes the **show tech-support** command, and contains the following topics:

- [Understanding the show tech-support Command, page C-86](#)
- [Displaying Tech Support Information, page C-87](#)
- [Tech Support Command Output, page C-88](#)

## Understanding the show tech-support Command

The **show tech-support** command captures all status and configuration information on the sensor and includes the current configuration, version information, and cidDump information. The output can be large, over 1 MB. You can transfer the output to a remote system. For the procedure for copying the output to a remote system, see [Displaying Tech Support Information, page C-87](#).



### Note

Always run the **show tech-support** command before contacting TAC.

## Displaying Tech Support Information



### Note

The **show tech-support** command now displays historical interface data for each interface for the past 72 hours.

Use the **show tech-support [page] [destination-url destination\_url]** command to display system information on the screen or have it sent to a specific URL. You can use the information as a troubleshooting tool with the TAC.

The following parameters are optional:

- **page**—Displays the output, one page of information at a time. Press **Enter** to display the next line of output or use the spacebar to display the next page of information.
- **destination-url**—Indicates the information should be formatted as HTML and sent to the destination that follows this command. If you use this keyword, the output is not displayed on the screen.
- **destination\_url**—Indicates the information should be formatted as HTML. The URL specifies where the information should be sent. If you do not use this keyword, the information is displayed on the screen.
- You can specify the following destination types:
  - **ftp**—Destination URL for FTP network server. The syntax for this prefix is:  
`ftp://[[username@location]/relativeDirectory]/filename` or  
`ftp://[[username@location]//absoluteDirectory]/filename`
  - **scp**—Destination URL for the SCP network server. The syntax for this prefix is:  
`scp://[[username@]location]/relativeDirectory]/filename` or  
`scp://[[username@]location]//absoluteDirectory]/filename`

### Varlog Files

The `/var/log/messages` file has the latest logs. A new softlink called `varlog` has been created under the `/usr/cids/idsRoot/log` folder that points to the `/var/log/messages` file. Old logs are stored in `varlog.1` and `varlog.2` files. The maximum size of these `varlog` files is 200 KB. Once they cross the size limit the content is rotated. The content of `varlog`, `varlog.1`, and `varlog.2` is displayed in the output of the **show tech-support** command.

### Displaying Tech Support Information

To display tech support information, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator privileges.
- Step 2** View the output on the screen. The system information appears on the screen, one page at a time. Press the spacebar to view the next page or press **Ctrl-C** to return to the prompt

```
sensor# show tech-support page
```

- Step 3** To send the output (in HTML format) to a file:

- a. Enter the following command, followed by a valid destination. The `password:` prompt appears.

```
sensor# show tech-support destination-url destination_url
```

Example

To send the tech support output to the file `/absolute/reports/sensor1Report.html`:

```
sensor# show tech support dest
ftp://csidsuser@10.2.1.2//absolute/reports/sensor1Report.html
```

- b. Enter the password for this user account. The `Generating report:` message is displayed.
- 

## Tech Support Command Output

The following is an example of the `show tech-support` command output:



### Note

This output example shows the first part of the command and lists the information for the interfaces, authentication, and the Analysis Engine.

---

```
sensor# show tech-support page
System Status Report
This Report was generated on Wed Nov 30 23:40:09 2011.
Output from show version
Application Partition:

Cisco Intrusion Prevention System, Version 7.1(3)E4

Host:
 Realm Keys key1.0
Signature Definition:
 Signature Update S605.0 2011-10-25
OS Version: 2.6.29.1
Platform: ASA5585-SSP-IPS10
Serial Number: 123456789AB
No license present
Sensor up-time is 13 days.
Using 4395M out of 5839M bytes of available memory (75% usage)
system is using 26.2M out of 160.0M bytes of available disk space (16% usage)
application-data is using 69.7M out of 171.6M bytes of available disk space (43%
usage)
boot is using 57.3M out of 70.5M bytes of available disk space (86% usage)
application-log is using 494.0M out of 513.0M bytes of available disk space (96%
usage)
```



```

MainApp S-2011_NOV_16_00_20_7_1_3_46 (Release) 2011-11-16T00:23:0
6-0600 Running
AnalysisEngine S-2011_NOV_16_00_20_7_1_3_46 (Release) 2011-11-16T00:23:0
6-0600 Running
CollaborationApp S-2011_NOV_16_00_20_7_1_3_46 (Release) 2011-11-16T00:23:0
6-0600 Running
CLI S-2011_NOV_16_00_20_7_1_3_46 (Release) 2011-11-16T00:23:0
6-0600

```

#### Upgrade History:

```
IPS-K9-7.1-3-E4 00:30:07 UTC Wed Nov 16 2011
```

Recovery Partition Version 1.1 - 7.1(3)E4

Host Certificate Valid from: 16-Nov-2011 to 16-Nov-2013

#### Output from show interfaces

##### Interface Statistics

```

Total Packets Received = 4285610
Total Bytes Received = 548558080
Missed Packet Percentage = 0

```

##### MAC statistics from interface Management0/0

```

Interface function = Command-control interface
Description =
Media Type = TX
Default Vlan = 0
Link Status = Up
Link Speed = Auto_100
Link Duplex = Auto_Full
Total Packets Received = 9584350
Total Bytes Received = 986355666
Total Multicast Packets Received = 0
Total Receive Errors = 0
Total Receive FIFO Overruns = 0
Total Packets Transmitted = 7205444
Total Bytes Transmitted = 1376470584
Total Transmit Errors = 0
Total Transmit FIFO Overruns = 0

```

##### MAC statistics from interface PortChannel0/0

```

Interface function = Sensing interface
Description =
Media Type = backplane
Default Vlan = 0
InlineMode = Unpaired
Pair Status = N/A
Hardware Bypass Capable = No
Hardware Bypass Paired = N/A
Link Status = Up
Admin Enabled Status = Enabled
Link Speed = Auto_10000
Link Duplex = Auto_Full
Missed Packet Percentage = 0
Total Packets Received = 4285610
Total Bytes Received = 548558080
Total Multicast Packets Received = 0
Total Broadcast Packets Received = 0
Total Jumbo Packets Received = 0
Total Undersize Packets Received = 0
Total Receive Errors = 0
Total Receive FIFO Overruns = 0
Total requests for buffer when none available = 0
Total Packets Transmitted = 4285610

```

```

Total Bytes Transmitted = 548558080
Total Multicast Packets Transmitted = 0
Total Broadcast Packets Transmitted = 0
Total Jumbo Packets Transmitted = 0
Total Undersize Packets Transmitted = 0
Total Transmit Errors = 0
Total Transmit FIFO Overruns = 0
MAC statistics from interface Management0/1
 Interface function = Reserved for future use

Output from show statistics authentication
General
 totalAuthenticationAttempts = 237
 failedAuthenticationAttempts = 14

Output from show statistics analysis-engine
Analysis Engine Statistics
 Number of seconds since service started = 1150851
 Processing Load Percentage
 Thread 5 sec 1 min 5 min
 0 1 1 1
 1 1 1 1
 2 1 1 1
 Average 1 1 1

The rate of TCP connections tracked per second = 0
The rate of packets per second = 0
The rate of bytes per second = 0
Receiver Statistics
 Total number of packets processed since reset = 0
 Total number of IP packets processed since reset = 0
Transmitter Statistics
 Total number of packets transmitted = 4285631
 Total number of packets denied = 0
 Total number of packets reset = 0
Fragment Reassembly Unit Statistics
 Number of fragments currently in FRU = 0
 Number of datagrams currently in FRU = 0
TCP Stream Reassembly Unit Statistics
 TCP streams currently in the embryonic state = 0
 TCP streams currently in the established state = 0
 TCP streams currently in the closing state = 0
 TCP streams currently in the system = 0
 TCP Packets currently queued for reassembly = 0
The Signature Database Statistics.
 Total nodes active = 0
 TCP nodes keyed on both IP addresses and both ports = 0
 UDP nodes keyed on both IP addresses and both ports = 0
 IP nodes keyed on both IP addresses = 0
Statistics for Signature Events
 Number of SigEvents since reset = 0
Statistics for Actions executed on a SigEvent
 Number of Alerts written to the IdsEventStore = 0
Inspection Stats

--MORE--

```

## Version Information

The **show version** command is useful for obtaining sensor information. This section describes the **show version** command, and contains the following topics:

- [Understanding the show version Command, page C-91](#)
- [Displaying Version Information, page C-91](#)

### Understanding the show version Command

The **show version** command shows the basic sensor information and can indicate where a failure is occurring. It gives the following information:

- Which applications are running
- Versions of the applications
- Disk and memory usage
- Upgrade history of the applications



#### Note

To get the same information from IDM, choose **Monitoring > Sensor Monitoring > Support Information > Diagnostics Report**. To get the same information from IME, choose **Configuration > sensor\_name > Sensor Monitoring > Support Information > Diagnostics Report**.

### Displaying Version Information

Use the **show version** command to display version information for all installed operating system packages, signature packages, and IPS processes running on the system. To view the configuration for the entire system, use the **more current-config** command.



#### Note

The CLI output is an example of what your configuration may look like. It will not match exactly due to the optional setup choices, sensor model, and IPS 7.1 version you have installed.



#### Note

For the IPS 4500 series sensors, the **show version** command output contains an extra application called the SwitchApp.

To display the version and configuration, follow these steps:

**Step 1** Log in to the CLI.

**Step 2** View version information.

```
sensor# show version
Application Partition:

Cisco Intrusion Prevention System, Version 7.1(3)E4

Host:
 Realm Keys key1.0
Signature Definition:
 Signature Update S605.0 2011-10-25
```

```

OS Version: 2.6.29.1
Platform: ASA5585-SSP-IPS10
Serial Number: 123456789AB
No license present
Sensor up-time is 13 days.
Using 4395M out of 5839M bytes of available memory (75% usage)
system is using 26.2M out of 160.0M bytes of available disk space (16% usage)
application-data is using 69.7M out of 171.6M bytes of available disk space (43%
usage)
boot is using 57.3M out of 70.5M bytes of available disk space (86% usage)
application-log is using 494.0M out of 513.0M bytes of available disk space (96%
usage)

```

```

MainApp S-2011_NOV_16_00_20_7_1_3_46 (Release) 2011-11-16T00:23:0
6-0600 Running
AnalysisEngine S-2011_NOV_16_00_20_7_1_3_46 (Release) 2011-11-16T00:23:0
6-0600 Running
CollaborationApp S-2011_NOV_16_00_20_7_1_3_46 (Release) 2011-11-16T00:23:0
6-0600 Running
CLI S-2011_NOV_16_00_20_7_1_3_46 (Release) 2011-11-16T00:23:0
6-0600

```

Upgrade History:

```
IPS-K9-7.1-3-E4 00:30:07 UTC Wed Nov 16 2011
```

Recovery Partition Version 1.1 - 7.1(3)E4

Host Certificate Valid from: 16-Nov-2011 to 16-Nov-2013

sensor#




---

**Note** If the `--MORE--` prompt is displayed, press the spacebar to see more information or **Ctrl-C** to cancel the output and get back to the CLI prompt.

---

### Step 3 View configuration information.




---

**Note** You can use the **more current-config** or **show configuration** commands.

---

```

sensor# more current-config
! -----
! Current configuration last modified Tue Nov 22 16:11:35 2011
! -----
! Version 7.1(3)
! Host:
! Realm Keys key1.0
! Signature Definition:
! Signature Update S605.0 2011-10-25
! -----
service interface
exit
! -----
service authentication
exit
! -----
service event-action-rules rules0
exit
! -----
service host

```

```
network-settings
host-ip 192.168.1.2/24, 192.168.1.1
host-name sensor
telnet-option enabled
access-list 0.0.0.0/0
dns-primary-server disabled
exit
exit
! -----
service logger
exit
! -----
service network-access
exit
! -----
service notification
exit
! -----
service signature-definition sig0
exit
! -----
service ssh-known-hosts
exit
! -----
service trusted-certificates
exit
! -----
service web-server
exit
! -----
service anomaly-detection ad0
exit
! -----
service external-product-interface
exit
! -----
service health-monitor
exit
! -----
service global-correlation
exit
! -----
service aaa
exit
! -----
service analysis-engine
sensor#
```

---

## Statistics Information

The **show statistics** command is useful for examining the state of the sensor services. This section describes the **show statistics** command, and contains the following topics:

- [Understanding the show statistics Command, page C-93](#)
- [Displaying Statistics, page C-94](#)

## Understanding the show statistics Command

The **show statistics** command provides a snapshot of the state of the sensor services. The following services provide statistics:

- AnalysisEngine
- Authentication
- Denied Attackers
- Event Server
- Event Store
- Host
- Logger
- Attack Response (formerly known as Network Access)
- Notification
- SDEE Server
- Transaction Server
- Transaction Source
- Virtual Sensor
- Web Server

**Note**

To get the same information from IDM, choose **Monitoring > Sensor Monitoring > Support Information > Statistics**. To get the same information from IME, choose **Configuration > sensor\_name > Sensor Monitoring > Support Information > Statistics**.

## Displaying Statistics

Use the **show statistics** [**analysis-engine** | **anomaly-detection** | **authentication** | **denied-attackers** | **event-server** | **event-store** | **external-product-interface** | **global-correlation** | **host** | **logger** | **network-access** | **notification** | **os-identification** | **sdee-server** | **transaction-server** | **virtual-sensor** | **web-server**] [**clear**] command to display statistics for each sensor application.

Use the **show statistics** {**anomaly-detection** | **denied-attackers** | **os-identification** | **virtual-sensor**} [**name** | **clear**] command to display statistics for these components for all virtual sensors. If you provide the virtual sensor name, the statistics for that virtual sensor only are displayed.

**Note**

The **clear** option is not available for the analysis engine, anomaly detection, host, network access, or OS identification applications.

For the IPS 4510 and IPS 4520, at the end of the command output, there are extra details for the Ethernet controller statistics, such as the total number of packets received at the Ethernet controller, the total number of packets dropped at the Ethernet controller under high load conditions, and the total packets transmitted including the customer traffic packets and the internal keepalive packet count.

**Note**

The Ethernet controller statistics are polled at an interval of 5 seconds from the hardware side. The keepalives are sent or updated at an interval of 10 ms. Because of this, there may be a disparity in the actual count reflected in the total packets transmitted. At times, it is even possible that the total packets transmitted may be less than the keepalive packets transmitted.

To display statistics for the sensor, follow these steps:

**Step 1** Log in to the CLI.

**Step 2** Display the statistics for the Analysis Engine.

```

sensor# show statistics analysis-engine
Analysis Engine Statistics
 Number of seconds since service started = 431157
 Processing Load Percentage
 Thread 5 sec 1 min 5 min
 0 1 1 1
 1 1 1 1
 2 1 1 1
 3 1 1 1
 4 1 1 1
 5 1 1 1
 6 1 1 1
 Average 1 1 1

 The rate of TCP connections tracked per second = 0
 The rate of packets per second = 0
 The rate of bytes per second = 0
 Receiver Statistics
 Total number of packets processed since reset = 0
 Total number of IP packets processed since reset = 0
 Transmitter Statistics
 Total number of packets transmitted = 133698
 Total number of packets denied = 203
 Total number of packets reset = 3
 Fragment Reassembly Unit Statistics
 Number of fragments currently in FRU = 0
 Number of datagrams currently in FRU = 0
 TCP Stream Reassembly Unit Statistics
 TCP streams currently in the embryonic state = 0
 TCP streams currently in the established state = 0
 TCP streams currently in the closing state = 0
 TCP streams currently in the system = 0
 TCP Packets currently queued for reassembly = 0
 The Signature Database Statistics.
 Total nodes active = 0
 TCP nodes keyed on both IP addresses and both ports = 0
 UDP nodes keyed on both IP addresses and both ports = 0
 IP nodes keyed on both IP addresses = 0
 Statistics for Signature Events
 Number of SigEvents since reset = 0
 Statistics for Actions executed on a SigEvent
 Number of Alerts written to the IdsEventStore = 0
 Inspection Stats
 Inspector active call create delete loadPct
 AtomicAdvanced 0 2312 4 4 33
 Fixed 0 1659 1606 1606 1
 MSRPC_TCP 0 20 4 4 0
 MSRPC_UDP 0 1808 1575 1575 0
 MultiString 0 145 10 10 2

```

|                    |   |      |      |      |    |
|--------------------|---|------|------|------|----|
| ServiceDnsUdp      | 0 | 1841 | 3    | 3    | 0  |
| ServiceGeneric     | 0 | 2016 | 14   | 14   | 1  |
| ServiceHttp        | 0 | 2    | 2    | 2    | 51 |
| ServiceNtp         | 0 | 3682 | 3176 | 3176 | 0  |
| ServiceP2PTCP      | 0 | 21   | 9    | 9    | 0  |
| ServiceRpcUDP      | 0 | 1841 | 3    | 3    | 0  |
| ServiceRpcTCP      | 0 | 130  | 9    | 9    | 0  |
| ServiceSMBAdvanced | 0 | 139  | 3    | 3    | 0  |
| ServiceSnmp        | 0 | 1841 | 3    | 3    | 0  |
| ServiceTNS         | 0 | 18   | 14   | 14   | 0  |
| String             | 0 | 225  | 16   | 16   | 0  |
| SweepUDP           | 0 | 1808 | 1555 | 1555 | 6  |
| SweepTCP           | 0 | 576  | 17   | 17   | 0  |
| SweepOtherTcp      | 0 | 288  | 6    | 6    | 0  |
| TrojanBO2K         | 0 | 261  | 11   | 11   | 0  |
| TrojanUdp          | 0 | 1808 | 1555 | 1555 | 0  |

```

GlobalCorrelationStats
SwVersion = 7.1(4.70)E4
SigVersion = 645.0
DatabaseRecordCount = 0
DatabaseVersion = 0
RuleVersion = 0
ReputationFilterVersion = 0
AlertsWithHit = 0
AlertsWithMiss = 0
AlertsWithModifiedRiskRating = 0
AlertsWithGlobalCorrelationDenyAttacker = 0
AlertsWithGlobalCorrelationDenyPacket = 0
AlertsWithGlobalCorrelationOtherAction = 0
AlertsWithAuditRepDenies = 0
ReputationForcedAlerts = 0
EventStoreInsertTotal = 0
EventStoreInsertWithHit = 0
EventStoreInsertWithMiss = 0
EventStoreDenyFromGlobalCorrelation = 0
EventStoreDenyFromOverride = 0
EventStoreDenyFromOverlap = 0
EventStoreDenyFromOther = 0
ReputationFilterDataSize = 0
ReputationFilterPacketsInput = 0
ReputationFilterRuleMatch = 0
DenyFilterHitsNormal = 0
DenyFilterHitsGlobalCorrelation = 0
SimulatedReputationFilterPacketsInput = 0
SimulatedReputationFilterRuleMatch = 0
SimulatedDenyFilterInsert = 0
SimulatedDenyFilterPacketsInput = 0
SimulatedDenyFilterRuleMatch = 0
TcpDeniesDueToGlobalCorrelation = 0
TcpDeniesDueToOverride = 0
TcpDeniesDueToOverlap = 0
TcpDeniesDueToOther = 0
SimulatedTcpDeniesDueToGlobalCorrelation = 0
SimulatedTcpDeniesDueToOverride = 0
SimulatedTcpDeniesDueToOverlap = 0
SimulatedTcpDeniesDueToOther = 0
LateStageDenyDueToGlobalCorrelation = 0
LateStageDenyDueToOverride = 0
LateStageDenyDueToOverlap = 0
LateStageDenyDueToOther = 0
SimulatedLateStageDenyDueToGlobalCorrelation = 0
SimulatedLateStageDenyDueToOverride = 0
SimulatedLateStageDenyDueToOverlap = 0

```



```

SimulatedLateStageDenyDueToOther = 0
AlertHistogram
RiskHistogramEarlyStage
RiskHistogramLateStage
ConfigAggressiveMode = 0
ConfigAuditMode = 0
RegexAccelerationStats
Status = Enabled
DriverVersion = 6.2.1
Devices = 1
Agents = 12
Flows = 7
Channels = 0
SubmittedJobs = 4968
CompletedJobs = 4968
SubmittedBytes = 72258005
CompletedBytes = 168
TCPFlowsWithoutLCB = 0
UDPFlowsWithoutLCB = 0
TCPMissedPacketsDueToUpdate = 0
UDPMissedPacketsDueToUpdate = 0
MemorySize = 1073741824
HostDirectMemSize = 0
MaliciousSiteDenyHitCounts
MaliciousSiteDenyHitCountsAUDIT
Ethernet Controller Statistics
Total Packets Received = 0
Total Received Packets Dropped = 0
Total Packets Transmitted = 13643"
sensor#

```

### Step 3 Display the statistics for anomaly detection.

```

sensor# show statistics anomaly-detection
Statistics for Virtual Sensor vs0
No attack
Detection - ON
Learning - ON
Next KB rotation at 10:00:01 UTC Sat Jan 18 2008
Internal Zone
TCP Protocol
UDP Protocol
Other Protocol
External Zone
TCP Protocol
UDP Protocol
Other Protocol
Illegal Zone
TCP Protocol
UDP Protocol
Other Protocol
Statistics for Virtual Sensor vs1
No attack
Detection - ON
Learning - ON
Next KB rotation at 10:00:00 UTC Sat Jan 18 2008
Internal Zone
TCP Protocol
UDP Protocol
Other Protocol
External Zone
TCP Protocol
UDP Protocol
Other Protocol

```

```

Illegal Zone
TCP Protocol
UDP Protocol
Other Protocol
sensor#

```

**Step 4** Display the statistics for authentication.

```

sensor# show statistics authentication
General
 totalAuthenticationAttempts = 128
 failedAuthenticationAttempts = 0
sensor#

```

**Step 5** Display the statistics for the denied attackers in the system.

```

sensor# show statistics denied-attackers
Denied Attackers and hit count for each.
Denied Attackers and hit count for each.
Statistics for Virtual Sensor vs0
 Denied Attackers with percent denied and hit count for each.

 Denied Attackers with percent denied and hit count for each.

Statistics for Virtual Sensor vs1
 Denied Attackers with percent denied and hit count for each.

 Denied Attackers with percent denied and hit count for each.

sensor#

```

**Step 6** Display the statistics for the Event Server.

```

sensor# show statistics event-server
General
 openSubscriptions = 0
 blockedSubscriptions = 0
Subscriptions
sensor#

```

**Step 7** Display the statistics for the Event Store.

```

sensor# show statistics event-store
Event store statistics
 General information about the event store
 The current number of open subscriptions = 2
 The number of events lost by subscriptions and queries = 0
 The number of filtered events not written to the event store = 850763
 The number of queries issued = 0
 The number of times the event store circular buffer has wrapped = 0
 Number of events of each type currently stored
 Status events = 4257
 Shun request events = 0
 Error events, warning = 669
 Error events, error = 8
 Error events, fatal = 0
 Alert events, informational = 0
 Alert events, low = 0
 Alert events, medium = 0
 Alert events, high = 0
 Alert events, threat rating 0-20 = 0

```

```

Alert events, threat rating 21-40 = 0
Alert events, threat rating 41-60 = 0
Alert events, threat rating 61-80 = 0
Alert events, threat rating 81-100 = 0
Cumulative number of each type of event
Status events = 4257
Shun request events = 0
Error events, warning = 669
Error events, error = 8
Error events, fatal = 0
Alert events, informational = 0
Alert events, low = 0
Alert events, medium = 0
Alert events, high = 0
Alert events, threat rating 0-20 = 0
Alert events, threat rating 21-40 = 0
Alert events, threat rating 41-60 = 0
Alert events, threat rating 61-80 = 0
Alert events, threat rating 81-100 = 0
sensor#

```

### Step 8 Display the statistics for global correlation.

```

sensor# show statistics global-correlation
Network Participation:
 Counters:
 Total Connection Attempts = 0
 Total Connection Failures = 0
 Connection Failures Since Last Success = 0
 Connection History:
Updates:
 Status Of Last Update Attempt = Disabled
 Time Since Last Successful Update = never
 Counters:
 Update Failures Since Last Success = 0
 Total Update Attempts = 0
 Total Update Failures = 0
 Update Interval In Seconds = 300
 Update Server = update-manifests.ironport.com
 Update Server Address = Unknown
 Current Versions:
Warnings:
 Unlicensed = Global correlation inspection and reputation filtering have been
disabled because the sensor is unlicensed.
 Action Required = Obtain a new license from http://www.cisco.com/go/license.
sensor#

```

### Step 9 Display the statistics for the host.

```

sensor# show statistics host
General Statistics
 Last Change To Host Config (UTC) = 25-Jan-2012 02:59:18
 Command Control Port Device = Management0/0
Network Statistics
 = ma0_0 Link encap:Ethernet HWaddr 00:04:23:D5:A1:8D
 = inet addr:10.89.130.98 Bcast:10.89.131.255 Mask:255.255.254.0
 = UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1
 = RX packets:1688325 errors:0 dropped:0 overruns:0 frame:0
 = TX packets:38546 errors:0 dropped:0 overruns:0 carrier:0
 = collisions:0 txqueuelen:1000
 = RX bytes:133194316 (127.0 MiB) TX bytes:5515034 (5.2 MiB)
 = Base address:0xcc80 Memory:fcee0000-fcf00000
NTP Statistics
 status = Not applicable

```

```

Memory Usage
 usedBytes = 1889357824
 freeBytes = 2210988032
 totalBytes = 4100345856
CPU Statistics
 Note: CPU Usage statistics are not a good indication of the sensor processin load. The
 Inspection Load Percentage in the output of 'show inspection-load' should be used instead.
 Usage over last 5 seconds = 0
 Usage over last minute = 2
 Usage over last 5 minutes = 2
 Usage over last 5 seconds = 0
 Usage over last minute = 1
 Usage over last 5 minutes = 1
Memory Statistics
 Memory usage (bytes) = 1889357824
 Memory free (bytes) = 2210988032
Auto Update Statistics
 lastDirectoryReadAttempt = N/A
 lastDownloadAttempt = N/A
 lastInstallAttempt = N/A
 nextAttempt = N/A
Auxilliary Processors Installed
sensor#

```

**Step 10** Display the statistics for the logging application.

```

sensor# show statistics logger
The number of Log interprocessor FIFO overruns = 0
The number of syslog messages received = 11
The number of <evError> events written to the event store by severity
 Fatal Severity = 0
 Error Severity = 64
 Warning Severity = 35
 TOTAL = 99
The number of log messages written to the message log by severity
 Fatal Severity = 0
 Error Severity = 64
 Warning Severity = 24
 Timing Severity = 311
 Debug Severity = 31522
 Unknown Severity = 7
 TOTAL = 31928
sensor#

```

**Step 11** Display the statistics for the ARC.

```

sensor# show statistics network-access
Current Configuration
 LogAllBlockEventsAndSensors = true
 EnableNvramWrite = false
 EnableAclLogging = false
 AllowSensorBlock = false
 BlockMaxEntries = 11
 MaxDeviceInterfaces = 250
NetDevice
 Type = PIX
 IP = 10.89.150.171
 NATAddr = 0.0.0.0
 Communications = ssh-3des
NetDevice
 Type = PIX
 IP = 192.0.2.4
 NATAddr = 0.0.0.0
 Communications = ssh-3des

```

```

NetDevice
 Type = PIX
 IP = 192.0.2.5
 NATAddr = 0.0.0.0
 Communications = telnet
NetDevice
 Type = Cisco
 IP = 192.0.2.6
 NATAddr = 0.0.0.0
 Communications = telnet
 BlockInterface
 InterfaceName = ethernet0/1
 InterfaceDirection = out
 InterfacePostBlock = Post_Acl_Test
 BlockInterface
 InterfaceName = ethernet0/1
 InterfaceDirection = in
 InterfacePreBlock = Pre_Acl_Test
 InterfacePostBlock = Post_Acl_Test
NetDevice
 Type = CAT6000_VACL
 IP = 192.0.2.1
 NATAddr = 0.0.0.0
 Communications = telnet
 BlockInterface
 InterfaceName = 502
 InterfacePreBlock = Pre_Acl_Test
 BlockInterface
 InterfaceName = 507
 InterfacePostBlock = Post_Acl_Test
State
 BlockEnable = true
NetDevice
 IP = 192.0.2.3
 AclSupport = Does not use ACLs
 Version = 6.3
 State = Active
 Firewall-type = PIX
NetDevice
 IP = 192.0.2.7
 AclSupport = Does not use ACLs
 Version = 7.0
 State = Active
 Firewall-type = ASA
NetDevice
 IP = 102.0.2.8
 AclSupport = Does not use ACLs
 Version = 2.2
 State = Active
 Firewall-type = FWSM
NetDevice
 IP = 192.0.2.9
 AclSupport = uses Named ACLs
 Version = 12.2
 State = Active
NetDevice
 IP = 192.0.2.10
 AclSupport = Uses VACLs
 Version = 8.4
 State = Active
BlockedAddr
 Host
 IP = 203.0.113.1
 Vlan =

```

```

 ActualIp =
 BlockMinutes =
 Host
 IP = 203.0.113.2
 Vlan =
 ActualIp =
 BlockMinutes =
 Host
 IP = 203.0.113.4
 Vlan =
 ActualIp =
 BlockMinutes = 60
 MinutesRemaining = 24
 Network
 IP = 203.0.113.9
 Mask = 255.255.0.0
 BlockMinutes =
sensor#

```

**Step 12** Display the statistics for the notification application.

```

sensor# show statistics notification
General
 Number of SNMP set requests = 0
 Number of SNMP get requests = 0
 Number of error traps sent = 0
 Number of alert traps sent = 0
sensor#

```

**Step 13** Display the statistics for OS identification.

```

sensor# show statistics os-identification
Statistics for Virtual Sensor vs0
 OS Identification
 Configured
 Imported
 Learned
sensor#

```

**Step 14** Display the statistics for the SDEE server.

```

sensor# show statistics sdee-server
General
 Open Subscriptions = 1
 Blocked Subscriptions = 1
 Maximum Available Subscriptions = 5
 Maximum Events Per Retrieval = 500
Subscriptions
 sub-4-d074914f
 State = Read Pending
 Last Read Time = 23:54:16 UTC Wed Nov 30 2011
 Last Read Time (nanoseconds) = 1322697256078549000
sensor#

```

**Step 15** Display the statistics for the transaction server.

```

sensor# show statistics transaction-server
General
 totalControlTransactions = 35
 failedControlTransactions = 0
sensor#

```

**Step 16** Display the statistics for a virtual sensor.

```

sensor# show statistics virtual-sensor vs0

```

```

Statistics for Virtual Sensor vs0
 Name of current Signature-Definition instance = sig0
 Name of current Event-Action-Rules instance = rules0
 List of interfaces monitored by this virtual sensor =
 General Statistics for this Virtual Sensor
 Number of seconds since a reset of the statistics = 1151770
 MemoryAlloPercent = 23
 MemoryUsedPercent = 22
 MemoryMaxCapacity = 3500000
 MemoryMaxHighUsed = 4193330
 MemoryCurrentAllo = 805452
 MemoryCurrentUsed = 789047
 Processing Load Percentage = 1
 Total packets processed since reset = 0
 Total IP packets processed since reset = 0
 Total IPv4 packets processed since reset = 0
 Total IPv6 packets processed since reset = 0
 Total IPv6 AH packets processed since reset = 0
 Total IPv6 ESP packets processed since reset = 0
 Total IPv6 Fragment packets processed since reset = 0
 Total IPv6 Routing Header packets processed since reset = 0
 Total IPv6 ICMP packets processed since reset = 0
 Total packets that were not IP processed since reset = 0
 Total TCP packets processed since reset = 0
 Total UDP packets processed since reset = 0
 Total ICMP packets processed since reset = 0
 Total packets that were not TCP, UDP, or ICMP processed since reset = 0
 Total ARP packets processed since reset = 0
 Total ISL encapsulated packets processed since reset = 0
 Total 802.1q encapsulated packets processed since reset = 0
 Total GRE Packets processed since reset = 0
 Total GRE Fragment Packets processed since reset = 0
 Total GRE Packets skipped since reset = 0
 Total GRE Packets with Bad Header skipped since reset = 0
 Total IpIp Packets with Bad Header skipped since reset = 0
 Total Encapsulated Tunnel Packets with Bad Header skipped since reset = 0
 Total packets with bad IP checksums processed since reset = 0
 Total packets with bad layer 4 checksums processed since reset = 0
 Total cross queue TCP packets processed since reset = 0
 Total cross queue UDP packets processed since reset = 0
 Packets dropped due to regex resources unavailable since reset = 0
 Total number of bytes processed since reset = 0
 The rate of packets per second since reset = 0
 The rate of bytes per second since reset = 0
 The average bytes per packet since reset = 0
 Denied Address Information
 Number of Active Denied Attackers = 0
 Number of Denied Attackers Inserted = 0
 Number of Denied Attacker Victim Pairs Inserted = 0
 Number of Denied Attacker Service Pairs Inserted = 0
 Number of Denied Attackers Total Hits = 0
 Number of times max-denied-attackers limited creation of new entry = 0
 Number of exec Clear commands during uptime = 0
 Denied Attackers and hit count for each.
 Denied Attackers with percent denied and hit count for each.

The Signature Database Statistics.
 The Number of each type of node active in the system
 Total nodes active = 0
 TCP nodes keyed on both IP addresses and both ports = 0
 UDP nodes keyed on both IP addresses and both ports = 0
 IP nodes keyed on both IP addresses = 0
 The number of each type of node inserted since reset

```

```

Total nodes inserted = 0
TCP nodes keyed on both IP addresses and both ports = 0
UDP nodes keyed on both IP addresses and both ports = 0
IP nodes keyed on both IP addresses = 0
The rate of nodes per second for each time since reset
Nodes per second = 0
TCP nodes keyed on both IP addresses and both ports per second = 0
UDP nodes keyed on both IP addresses and both ports per second = 0
IP nodes keyed on both IP addresses per second = 0
The number of root nodes forced to expire because of memory constraints
TCP nodes keyed on both IP addresses and both ports = 0
Packets dropped because they would exceed Database insertion rate limit s = 0
Fragment Reassembly Unit Statistics for this Virtual Sensor
Number of fragments currently in FRU = 0
Number of datagrams currently in FRU = 0
Number of fragments received since reset = 0
Number of fragments forwarded since reset = 0
Number of fragments dropped since last reset = 0
Number of fragments modified since last reset = 0
Number of complete datagrams reassembled since last reset = 0
Fragments hitting too many fragments condition since last reset = 0
Number of overlapping fragments since last reset = 0
Number of Datagrams too big since last reset = 0
Number of overwriting fragments since last reset = 0
Number of Initial fragment missing since last reset = 0
Fragments hitting the max partial dgrams limit since last reset = 0
Fragments too small since last reset = 0
Too many fragments per dgram limit since last reset = 0
Number of datagram reassembly timeout since last reset = 0
Too many fragments claiming to be the last since last reset = 0
Fragments with bad fragment flags since last reset = 0
TCP Normalizer stage statistics
Packets Input = 0
Packets Modified = 0
Dropped packets from queue = 0
Dropped packets due to deny-connection = 0
Duplicate Packets = 0
Current Streams = 0
Current Streams Closed = 0
Current Streams Closing = 0
Current Streams Embryonic = 0
Current Streams Established = 0
Current Streams Denied = 0
Total SendAck Limited Packets = 0
Total SendAck Limited Streams = 0
Total SendAck Packets Sent = 0
Statistics for the TCP Stream Reassembly Unit
Current Statistics for the TCP Stream Reassembly Unit
TCP streams currently in the embryonic state = 0
TCP streams currently in the established state = 0
TCP streams currently in the closing state = 0
TCP streams currently in the system = 0
TCP Packets currently queued for reassembly = 0
Cumulative Statistics for the TCP Stream Reassembly Unit since reset
TCP streams that have been tracked since last reset = 0
TCP streams that had a gap in the sequence jumped = 0
TCP streams that was abandoned due to a gap in the sequence = 0
TCP packets that arrived out of sequence order for their stream = 0
TCP packets that arrived out of state order for their stream = 0
The rate of TCP connections tracked per second since reset = 0
SigEvent Preliminary Stage Statistics
Number of Alerts received = 0
Number of Alerts Consumed by AlertInterval = 0
Number of Alerts Consumed by Event Count = 0

```



```

Number of FireOnce First Alerts = 0
Number of FireOnce Intermediate Alerts = 0
Number of Summary First Alerts = 0
Number of Summary Intermediate Alerts = 0
Number of Regular Summary Final Alerts = 0
Number of Global Summary Final Alerts = 0
Number of Active SigEventDataNodes = 0
Number of Alerts Output for further processing = 0
--MORE--

```

**Step 17** Display the statistics for the web server.

```

sensor# show statistics web-server
listener-443
 session-11
 remote host = 64.101.182.167
 session is persistent = no
 number of requests serviced on current connection = 1
 last status code = 200
 last request method = GET
 last request URI = cgi-bin/sdee-server
 last protocol version = HTTP/1.1
 session state = processingGetServlet
 number of server session requests handled = 957134
 number of server session requests rejected = 0
 total HTTP requests handled = 365871
 maximum number of session objects allowed = 40
 number of idle allocated session objects = 12
 number of busy allocated session objects = 1
 summarized log messages
 number of TCP socket failure messages logged = 0
 number of TLS socket failure messages logged = 0
 number of TLS protocol failure messages logged = 0
 number of TLS connection failure messages logged = 595015
 number of TLS crypto warning messages logged = 0
 number of TLS expired certificate warning messages logged = 0
 number of receipt of TLS fatal alert message messages logged = 594969
 crypto library version = 6.2.1.0
sensor#

```

**Step 18** Clear the statistics for an application, for example, the logging application. The statistics are retrieved and cleared.

```

sensor# show statistics logger clear
The number of Log interprocessor FIFO overruns = 0
The number of syslog messages received = 141
The number of <evError> events written to the event store by severity
 Fatal Severity = 0
 Error Severity = 14
 Warning Severity = 142
 TOTAL = 156
The number of log messages written to the message log by severity
 Fatal Severity = 0
 Error Severity = 14
 Warning Severity = 1
 Timing Severity = 0
 Debug Severity = 0
 Unknown Severity = 28
 TOTAL = 43

```

**Step 19** Verify that the statistics have been cleared. The statistics now all begin from 0.

```

sensor# show statistics logger
The number of Log interprocessor FIFO overruns = 0

```

```

The number of syslog messages received = 0
The number of <evError> events written to the event store by severity
 Fatal Severity = 0
 Error Severity = 0
 Warning Severity = 0
 TOTAL = 0
The number of log messages written to the message log by severity
 Fatal Severity = 0
 Error Severity = 0
 Warning Severity = 0
 Timing Severity = 0
 Debug Severity = 0
 Unknown Severity = 0
 TOTAL = 0
sensor#

```

---

## Interfaces Information

The **show interfaces** command is useful for gathering information on the sensing and command and control interfaces. This section describes the **show interfaces** command, and contains the following topics:

- [Understanding the show interfaces Command, page C-106](#)
- [Interfaces Command Output, page C-106](#)

## Understanding the show interfaces Command

You can learn the following information from the **show interfaces** command:

- Whether the interface is up or down
- Whether or not packets are being seen, and on which interfaces
- Whether or not packets are being dropped by SensorApp
- Whether or not there are errors being reported by the interfaces that can result in packet drops

The **show interfaces** command displays statistics for all system interfaces. Or you can use the individual commands to display statistics for the command and control interface (**show interfaces command\_control\_interface\_name**), the sensing interface (**show interfaces interface\_name**).

## Interfaces Command Output

The following example shows the output from the **show interfaces** command:

```

sensor# show interfaces
Interface Statistics
 Total Packets Received = 0
 Total Bytes Received = 0
 Missed Packet Percentage = 0
 Current Bypass Mode = Auto_off
MAC statistics from interface GigabitEthernet0/1
 Media Type = backplane
 Missed Packet Percentage = 0
 Inline Mode = Unpaired
 Pair Status = N/A
 Link Status = Up

```

```

Link Speed = Auto_1000
Link Duplex = Auto_Full
Total Packets Received = 0
Total Bytes Received = 0
Total Multicast Packets Received = 0
Total Broadcast Packets Received = 0
Total Jumbo Packets Received = 0
Total Undersize Packets Received = 0
Total Receive Errors = 0
Total Receive FIFO Overruns = 0
Total Packets Transmitted = 0
Total Bytes Transmitted = 0
Total Multicast Packets Transmitted = 0
Total Broadcast Packets Transmitted = 0
Total Jumbo Packets Transmitted = 0
Total Undersize Packets Transmitted = 0
Total Transmit Errors = 0
Total Transmit FIFO Overruns = 0
MAC statistics from interface GigabitEthernet0/0
Media Type = TX
Link Status = Up
Link Speed = Auto_100
Link Duplex = Auto_Full
Total Packets Received = 2211296
Total Bytes Received = 157577635
Total Multicast Packets Received = 20
Total Receive Errors = 0
Total Receive FIFO Overruns = 0
Total Packets Transmitted = 239723
Total Bytes Transmitted = 107213390
Total Transmit Errors = 0
Total Transmit FIFO Overruns = 0
sensor#

```

## Events Information

You can use the **show events** command to view the alerts generated by SensorApp and errors generated by an application. This section describes the **show events** command, and contains the following topics:

- [Sensor Events, page C-107](#)
- [Understanding the show events Command, page C-107](#)
- [Displaying Events, page C-108](#)
- [Clearing Events, page C-111](#)

## Sensor Events

There are five types of events:

- **evAlert**—Intrusion detection alerts
- **evError**—Application errors
- **evStatus**—Status changes, such as an IP log being created
- **evLogTransaction**—Record of control transactions processed by each sensor application
- **evShunRqst**—Block requests

Events remain in the Event Store until they are overwritten by newer events.

## Understanding the show events Command



### Note

The Event Store has a fixed size of 30 MB for all platforms.

The **show events** command is useful for troubleshooting event capture issues in which you are not seeing events in Event Viewer or Security Monitor. You can use the **show events** command to determine which events are being generated on the sensor to make sure events are being generated and that the fault lies with the monitoring side.

You can clear all events from Event Store by using the **clear events** command.

Here are the parameters for the **show events** command:

```
sensor# show events
<cr>
alert Display local system alerts.
error Display error events.
hh:mm[:ss] Display start time.
log Display log events.
nac Display NAC shun events.
past Display events starting in the past specified time.
status Display status events.
| Output modifiers.
```

## Displaying Events



### Note

The Event Store has a fixed size of 30 MB for all platforms.



### Note

Events are displayed as a live feed. To cancel the request, press **Ctrl-C**.

Use the **show events** [{**alert** [informational] [low] [medium] [high] [**include-traits** *traits*] [**exclude-traits** *traits*] [**min-threat-rating** *min-rr*] [**max-threat-rating** *max-rr*] | **error** [warning] [error] [fatal] | **NAC** | **status**}] [*hh:mm:ss* [*month day* [*year*]]] | **past** *hh:mm:ss*] command to display events from Event Store. Events are displayed beginning at the start time. If you do not specify a start time, events are displayed beginning at the current time. If you do not specify an event type, all events are displayed. The following options apply:

- **alert**—Displays alerts. Provides notification of some suspicious activity that may indicate an attack is in process or has been attempted. Alert events are generated by the Analysis Engine whenever a signature is triggered by network activity. If no level is selected (informational, low, medium, or high), all alert events are displayed.
- **include-traits**—Displays alerts that have the specified traits.
- **exclude-traits**—Does not display alerts that have the specified traits.
- **traits**—Specifies the trait bit position in decimal (0 to 15).
- **min-threat-rating**—Displays events with a threat rating above or equal to this value. The default is 0. The valid range is 0 to 100.
- **max-threat-rating**—Displays events with a threat rating below or equal to this value. The default is 100. The valid range is 0 to 100.

- **error**—Displays error events. Error events are generated by services when error conditions are encountered. If no level is selected (warning, error, or fatal), all error events are displayed.
- **NAC**—Displays the ARC (block) requests.



**Note** The ARC is formerly known as NAC. This name change has not been completely implemented throughout the IDM, the IME, and the CLI for Cisco IPS 7.1.

- **status**—Displays status events.
- **past**—Displays events starting in the past for the specified hours, minutes, and seconds.
- *hh:mm:ss*—Specifies the hours, minutes, and seconds in the past to begin the display.



**Note**

The **show events** command continues to display events until a specified event is available. To exit, press **Ctrl-C**.

### Displaying Events

To display events from the Event Store, follow these steps:

**Step 1** Log in to the CLI.

**Step 2** Display all events starting now. The feed continues showing all events until you press **Ctrl-C**.

```
sensor# show events
evError: eventId=1041472274774840147 severity=warning vendor=Cisco
 originator:
 hostId: sensor2
 appName: cidwebserver
 appInstanceId: 12075
 time: 2011/01/07 04:41:45 2011/01/07 04:41:45 UTC
 errorMessage: name=errWarning received fatal alert: certificate_unknown

evError: eventId=1041472274774840148 severity=error vendor=Cisco
 originator:
 hostId: sensor2
 appName: cidwebserver
 appInstanceId: 351
 time: 2011/01/07 04:41:45 2011/01/07 04:41:45 UTC
 errorMessage: name=errTransport WebSession::sessionTask(6) TLS connection exception: handshake incomplete.
```

**Step 3** Display the block requests beginning at 10:00 a.m. on February 9, 2011.

```
sensor# show events NAC 10:00:00 Feb 9 2011
evShunRgst: eventId=1106837332219222281 vendor=Cisco
 originator:
 deviceName: Sensor1
 appName: NetworkAccessControllerApp
 appInstance: 654
 time: 2011/02/09 10:33:31 2011/08/09 13:13:31
 shunInfo:
 host: connectionShun=false
 srcAddr: 11.0.0.1
 destAddr:
 srcPort:
 destPort:
 protocol: numericType=0 other
 timeoutMinutes: 40
```

```
evAlertRef: hostId=esendHost 123456789012345678
sensor#
```

**Step 4** Display errors with the warning level starting at 10:00 a.m. on February 9, 2011.

```
sensor# show events error warning 10:00:00 Feb 9 2011
evError: eventId=1041472274774840197 severity=warning vendor=Cisco
originator:
 hostId: sensor
 appName: cidwebserver
 appInstanceId: 12160
time: 2011/01/07 04:49:25 2011/01/07 04:49:25 UTC
errorMessage: name=errWarning received fatal alert: certificate_unknown
```

**Step 5** Display alerts from the past 45 seconds.

```
sensor# show events alert past 00:00:45

evIdsAlert: eventId=1109695939102805307 severity=medium vendor=Cisco
originator:
 hostId: sensor
 appName: sensorApp
 appInstanceId: 367
time: 2011/03/02 14:15:59 2011/03/02 14:15:59 UTC
signature: description=Nachi Worm ICMP Echo Request id=2156 version=S54
 subsigId: 0
 sigDetails: Nachi ICMP
interfaceGroup:
vlan: 0
participants:
 attacker:
 addr: locality=OUT 10.89.228.202
 target:
 addr: locality=OUT 10.89.150.185
riskRatingValue: 70
interface: fe0_1
protocol: icmp
```

```
evIdsAlert: eventId=1109695939102805308 severity=medium vendor=Cisco
originator:
--MORE--
```

**Step 6** Display events that began 30 seconds in the past.

```
sensor# show events past 00:00:30
evStatus: eventId=1041526834774829055 vendor=Cisco
originator:
 hostId: sensor
 appName: mainApp
 appInstanceId: 2215
time: 2011/01/08 02:41:00 2011/01/08 02:41:00 UTC
controlTransaction: command=getVersion successful=true
 description: Control transaction response.
 requestor:
 user: cids
 application:
 hostId: 64.101.182.101
 appName: -cidcli
 appInstanceId: 2316

evStatus: eventId=1041526834774829056 vendor=Cisco
originator:
 hostId: sensor
```

```

 appName: login(pam_unix)
 appInstanceId: 2315
 time: 2011/01/08 02:41:00 2011/01/08 02:41:00 UTC
 syslogMessage:
 description: session opened for user cisco by cisco(uid=0)

```

---

## Clearing Events

Use the **clear events** command to clear the Event Store.

To clear events from the Event Store, follow these steps:

- 
- Step 1** Log in to the CLI using an account with administrator privileges.
  - Step 2** Clear the Event Store.  

```

sensor# clear events
Warning: Executing this command will remove all events currently stored in the event
store.
Continue with clear? []:

```
  - Step 3** Enter **yes** to clear the events.
- 

## cidDump Script

If you do not have access to the IDM, the IME, or the CLI, you can run the underlying script `cidDump` from the service account by logging in as root and running `/usr/cids/idsRoot/bin/cidDump`. The path of the `cidDump` file is `/usr/cids/idsRoot/htdocs/private/cidDump.html`. `cidDump` is a script that captures a large amount of information including the IPS processes list, log files, OS information, directory listings, package information, and configuration files.

To run the `cidDump` script, follow these steps:

- 
- Step 1** Log in to the sensor service account.
  - Step 2** **su** to **root** using the service account password.
  - Step 3** Enter the following command.  

```

/usr/cids/idsRoot/bin/cidDump

```
  - Step 4** Enter the following command to compress the resulting `/usr/cids/idsRoot/log/cidDump.html` file.  

```

gzip /usr/cids/idsRoot/log/cidDump.html

```
  - Step 5** Send the resulting HTML file to the TAC or the IPS developers in case of a problem.
- 

### For More Information

For the procedure for putting a file on the Cisco FTP site, see [Uploading and Accessing Files on the Cisco FTP Site](#), page C-112.

## Uploading and Accessing Files on the Cisco FTP Site

You can upload large files, for example, cidDump.html, the **show tech-support** command output, and cores, to the ftp-sj server.

To upload and access files on the Cisco FTP site, follow these steps:

- 
- |               |                                                                                            |
|---------------|--------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Log in to ftp-sj.cisco.com as anonymous.                                                   |
| <b>Step 2</b> | Change to the /incoming directory.                                                         |
| <b>Step 3</b> | Use the <b>put</b> command to upload the files. Make sure to use the binary transfer type. |
| <b>Step 4</b> | To access uploaded files, log in to an ECS-supported host.                                 |
| <b>Step 5</b> | Change to the /auto/ftp/incoming directory.                                                |
-





# CLI Error Messages

This appendix lists the CLI error messages and CLI validation error messages. It contains the following sections:

- [CLI Error Messages, page D-1](#)
- [CLI Validation Error Messages, page D-5](#)

## CLI Error Messages

[Table D-1](#) describes CLI error messages.

**Table D-1** CLI Error Messages

| Error Message                                                                                                             | Reason                                                                                     | Command                                 |
|---------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|-----------------------------------------|
| <code>getVirtualSensorStatistics : Analysis Engine is busy</code>                                                         | Analysis Engine is busy because the virtual sensor has not finished initializing.          | <b>show statistics virtual-sensor</b>   |
| <code>getVirtualSensorStatistics : Analysis Engine is busy rebuilding regex tables. This may take a while.</code>         | Analysis Engine is busy building cache files immediately after the sensor has been imaged. | <b>show statistics virtual-sensor</b>   |
| <code>editConfigDeltaSignatureDefinition : Analysis Engine is busy rebuilding regex tables. This may take a while.</code> | Analysis Engine is busy building cache files immediately after the sensor has been imaged. | <b>service signature-definition</b>     |
| <code>Invalid command received.</code>                                                                                    | The .conf file and code are out of synchronization, which should never occur in the field. | All commands                            |
| <code>Invalid port number was entered.</code>                                                                             | An out-of-range port number was entered in URI.                                            | <b>copy, upgrade, show tech-support</b> |
| <code>Invalid scheme was entered.</code>                                                                                  | Internal tables are out of synchronization, which should never occur in the field.         | <b>copy, upgrade, show tech-support</b> |
| <code>Unknown scheme was entered.</code>                                                                                  | An invalid scheme was entered in URI.                                                      | <b>copy, upgrade, show tech-support</b> |

**Table D-1** CLI Error Messages (continued)

| Error Message                                                                                               | Reason                                                                                                   | Command                             |
|-------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|-------------------------------------|
| The filename <file> is not a valid upgrade file type.                                                       | Attempt to install the wrong file for your platform and version.                                         | <b>upgrade</b>                      |
| idsPackageMgr: digital signature of the update was not valid                                                | The signature update or service pack is corrupt. Contact TAC.                                            | <b>upgrade</b>                      |
| Cannot create a new event-action-rules configuration. "rules0" is currently the only configuration allowed. | An invalid logical instance name was entered for service event action rules. <sup>1</sup>                | <b>service event-action-rules</b>   |
| Cannot create a new signature-definition configuration. "sig0" is currently the only configuration allowed. | An invalid logical instance name was entered for service signature definition. <sup>2</sup>              | <b>service signature-definition</b> |
| Cannot create a new anomaly-detection configuration. "ad0" is currently the only configuration allowed.     | An invalid logical instance name was entered for service anomaly detection. <sup>3</sup>                 | <b>service anomaly-detection</b>    |
| User does not exist.                                                                                        | The Administrator is attempting to change the password for a username that does not exist in the system. | <b>password</b>                     |
| Incorrect password for user account.                                                                        | The user entered an invalid password while attempting to change the password.                            | <b>password</b>                     |
| Empty user list.                                                                                            | The curUserAccountList.xml file does not contain any entries, which should never occur in the field.     | <b>username</b>                     |
| User already exists.                                                                                        | An attempt to create a user that already exists in the system was made.                                  | <b>username</b>                     |
| Cannot communicate with system processes. Please contact your system administrator.                         | One or more required applications is not responding to control transactions.                             | All commands                        |
| Source and Destination are the same.                                                                        | —                                                                                                        | <b>copy</b>                         |
| Backup config was missing.                                                                                  | The user attempted to copy or erase the backup config file but no backup config file has been generated. | <b>copy</b><br><b>erase</b>         |
| Could not load CLI configuration files, can not complete request.                                           | The .conf files could not be located, which should never occur in the field.                             | <b>copy</b>                         |
| Error writing to <URL>.                                                                                     | The URL specified in the destination could not be written.                                               | <b>copy</b>                         |
| Error reading from <URL>.                                                                                   | The URL specified in the source could not be read.                                                       | <b>copy</b>                         |

**Table D-1** CLI Error Messages (continued)

| Error Message                                                                                                                          | Reason                                                                                                                                                                    | Command                                          |
|----------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------|
| Packet-file does not exist.                                                                                                            | The user attempted to copy or erase the packet-file but no packet-file has been captured.                                                                                 | <b>copy</b><br><b>erase</b>                      |
| No downgrade available.                                                                                                                | The user attempted to downgrade a system that has not been upgraded.                                                                                                      | <b>downgrade</b>                                 |
| No packet-file available.                                                                                                              | The user attempted to display the file-info or the packet-file but no packet-file exists.                                                                                 | <b>packet</b>                                    |
| Another user is currently capturing into the packet-file. Please try again later.                                                      | —                                                                                                                                                                         | <b>packet capture</b>                            |
| Another CLI client is currently displaying packets from the interface.                                                                 | The user must wait for the other CLI session to terminate display before this will be available. Multiple users may display the command control interface simultaneously. | <b>packet display</b>                            |
| Log does not exist.                                                                                                                    | The user attempted to copy or display an iplog that does not exist.                                                                                                       | <b>copy iplog</b><br><b>packet display iplog</b> |
| The requested IPLOG is not complete. Please try again after the IPLOG status is 'completed.'                                           | The user attempted to copy or display an iplog that is not complete.                                                                                                      | <b>copy iplog</b>                                |
| Error: Log file exists but an error occurred during read. The log file might have been overwritten.                                    | The user was displaying or copying an iplog file that was overwritten. The partial file contents should still be viewable.                                                | <b>copy iplog</b>                                |
| Error: Iplog transfer failed. The copied log file is incomplete.                                                                       | Iplog transfer has failed. There may or may not be any partial copied file at remote server.                                                                              | <b>copy iplog</b>                                |
| Could not create pipe /usr/cids/idsRoot/tmp/pipe_cliPacket.<pid>.tmp                                                                   | Could not open pipe for sending iplog file. This indicates a space or resource limitation, which should not occur in the field.                                           | <b>copy iplog</b>                                |
| Error: The log file might have been overwritten while the copy was in progress. The copied log file may be viewable but is incomplete. | The iplog was overwritten while it was being copied off the sensor.                                                                                                       | <b>copy iplog</b>                                |
| Could not read license file.                                                                                                           | The license file was copied but cannot be opened.                                                                                                                         | <b>copy license-key</b>                          |
| Could not write the temporary license file location used to copy the file off the box.                                                 | Could not open the temporary storage location /usr/cids/idsRoot/tmp/ips.lic. This indicates a space issue, which should not occur in the field.                           | <b>copy license-key</b>                          |

**Table D-1** CLI Error Messages (continued)

| Error Message                                                                                              | Reason                                                                                                                                                                                                                | Command                                         |
|------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------|
| Virtual sensor name does not exist.                                                                        | The user attempted to start or stop an iplog on a non-existent virtual sensor.                                                                                                                                        | <b>iplog</b>                                    |
| You do not have permission to terminate the requested CLI session.                                         | An operator or viewer user attempted to terminate a CLI session belonging to another user.                                                                                                                            | <b>clear line</b>                               |
| Invalid CLI ID specified, use the 'show users all' command to view the valid CLI session IDs.              | The user attempted to cancel a CLI session that does not exist.                                                                                                                                                       | <b>clear line</b>                               |
| The maximum allowed CLI sessions are currently open, please try again later.                               | Operator or viewer user attempted to log in when the maximum number of CLI sessions were already open.                                                                                                                | initial login                                   |
| The maximum allowed CLI sessions are currently open, would you like to terminate one of the open sessions? | Administrator user attempted to log in when the maximum number of CLI sessions were already open.                                                                                                                     | initial login                                   |
| Can not communicate with system processes. Please contact your system administrator.                       | The CLI cannot contact the applications on the sensor to retrieve start-up information. This is a fatal error that should never happen. The user has to log in to the service account and manually reboot the sensor. | initial login                                   |
| The instance cannot be removed. Instance assigned to virtual sensor name.                                  | The user attempted to remove a configuration instance that is currently assigned to a virtual sensor. Use the <b>default service</b> command to reset the configuration setting to default.                           | <b>no service component instance</b>            |
| Insufficient disk space to complete request.                                                               | Not enough disk space is available to create a new instance of a configuration file.                                                                                                                                  | <b>copy instance service component instance</b> |

1. This error only occurs on platforms that do not support virtual policies.
2. This error only occurs on platforms that do not support virtual policies.
3. This error only occurs on platforms that do not support virtual policies.

# CLI Validation Error Messages

Table D-2 describes the validation error messages.

**Table D-2** Validation Error Messages

| Error Message                                                                                                                                           | Reason/Location                                                                                                                                                                                                  |
|---------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Interface 'name' has not been subdivided.                                                                                                               | The physical interface or inline interface <i>name</i> subinterface type is none (service interface submode).                                                                                                    |
| Interface 'name' subinterface 'num' does not exist.                                                                                                     | The physical interface <i>name</i> has been subdivided into inline VLAN pairs, but the specified subinterface number does not exist (service interface submode).                                                 |
| Interface 'name' is the command-control interface.                                                                                                      | The physical interface <i>name</i> is the command and control interface (service interface submode).                                                                                                             |
| Interface 'name' has been subdivided.                                                                                                                   | The physical interface <i>name</i> subinterface type is inline VLAN pair or VLAN group. Or the inline interface <i>name</i> subinterface type is VLAN group (service interface submode).                         |
| Interface 'name' is assigned to inline-interfaces 'inlinename.'                                                                                         | The physical interface <i>name</i> is assigned to an inline interface entry's interface1 or interface2 (service interface submode).                                                                              |
| Vlan 'vlannum' is assigned to subinterface 'subnum.'                                                                                                    | The VLAN <i>vlannum</i> is already assigned to a different subinterface <i>subnum</i> entry's vlan1 or vlan2 (service interface submode).                                                                        |
| Vlan range 'vlanrange' overlaps with vlans assigned to subinterface 'subnum.'                                                                           | The VLAN range <i>vlanrange</i> contains values that are already used in a different subinterface <i>subnum</i> entry's vlans range (service interface submode).                                                 |
| Unassigned vlans already assigned to subinterface 'subnum.'                                                                                             | Unassigned VLANs have already been selected in a different subinterface <i>subnum</i> entry.                                                                                                                     |
| Inline-interface 'inlinename' does not exist.                                                                                                           | The inline interface <i>inlinename</i> does not exist (service interface submode).                                                                                                                               |
| The default-vlans for the selected interfaces do not match. interface1, 'name' default-vlan is 'vlannum,' interface2, 'name' default-vlan is 'vlannum.' | The user is trying to change the subinterface type of an inline interface to VLAN group, but the default VLANs for the two interfaces assigned to the inline interface do not match (service interface submode). |
| interface1 and interface2 must be set before the logical interface can be divided into subinterfaces.                                                   | The user is trying to change the subinterface type of an inline interface to VLAN group, but has not set both interface1 and interface2 (service interface submode).                                             |
| Interface 'name' has not been subdivided into inline-vlan-pairs.                                                                                        | The physical interface <i>name</i> subinterface type is not inline VLAN pair (service interface submode).                                                                                                        |

**Table D-2**      **Validation Error Messages (continued)**

| Error Message                                                                 | Reason/Location                                                                                                                                                             |
|-------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Interface already assigned to virtual sensor 'vsname.'                        | The interface and optional sub-interface being added to the virtual sensor entry physical interface set has already been assigned to another virtual sensor entry.          |
| The instance cannot be removed. Instance assigned to virtual sensor 'vsname.' | The user is trying to remove a signature definition, event action rules, or anomaly detection configuration file that is currently in use by virtual sensor <i>vsname</i> . |



# Open Source License Files Used In Cisco IPS 7.1

---

**Published: November 12, 2010**

**Revised: September 23, 2011**

This document contains the licenses and notices for open source software used in Cisco IPS 7.1(x). With respect to the free/open source software listed in this document, if you have any questions or wish to receive a copy of the source code to which you are entitled under the applicable free/open source license(s) (such as the GNU Lesser/General Public License), please contact us at [external-opensource-requests@cisco.com](mailto:external-opensource-requests@cisco.com).

## Contents

This appendix lists the open source software used in Cisco IPS 7.1, and contains the following sections:

- [bash 3.2, page E-2](#)
- [busybox 1.13.1, page E-7](#)
- [cracklib 2.8.12, page E-13](#)
- [curl 7.18.2 1, page E-18](#)
- [diffutils 2.8.1, page E-19](#)
- [e2fsprogs 1.39, page E-23](#)
- [Expat XML parser 2.0.1, page E-28](#)
- [expect 5.4.3, page E-29](#)
- [freeradius-server 2.1.8, page E-29](#)
- [freeradius-server-src-lib 2.1.8, page E-34](#)
- [glibc 2.9, page E-40](#)
- [gnupg 1.4.5, page E-44](#)
- [hotplug 2004\\_03\\_29, page E-49](#)
- [i2c-tools 3.0.2, page E-53](#)
- [ipmiutil 2.3.3, page E-58](#)
- [iptables 1.4.1, page E-59](#)
- [kernel 2.6.29.1, page E-63](#)

- KVM inter-VM shared memory module, page E-73
- libpcap 0.9.8, page E-77
- libtecla 1.6.1, page E-78
- Linux-Pam 1.0.1, page E-78
- lm\_sensors 3.0.2, page E-79
- module-init-tools 3.2.2 1.0.0.0900084, page E-84
- Ncurses 5.6, page E-88
- net-snmp 5.4.1, page E-89
- NTP 4.2.4p5, page E-93
- openssh 5.1p1, page E-96
- openssl 0.9.8j, page E-102
- pciutils 3.0.1, page E-105
- procps 3.2.7, page E-111
- sysfsutils 2.1.0, page E-115
- sysstat 8.1.3, page E-116
- tcl 8.4.9, page E-120
- tcpdump 3.9.8 1.0.1.0801182, page E-121
- tipc 1.7.6-bundle, page E-121
- util-linux 2.12r, page E-123
- zlib 1.2.3, page E-124

## bash 3.2

Available under license:

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.



To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

## GNU GENERAL PUBLIC LICENSE

### TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

## NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

## END OF TERMS AND CONDITIONS

## How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the program's name and a brief idea of what it does.>

Copyright (C) <year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type 'show w'.

This is free software, and you are welcome to redistribute it under certain conditions; type 'show c' for details.

The hypothetical commands ‘show w’ and ‘show c’ should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than ‘show w’ and ‘show c’; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a “copyright disclaimer” for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program

‘Gnomovision’ (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon>, 1 April 1989

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

## busybox 1.13.1

Available under license:

A note on GPL versions

BusyBox is distributed under version 2 of the General Public License (included in its entirety, below). Version 2 is the only version of this license which this version of BusyBox (or modified versions derived from this one) may be distributed under.

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation’s software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights.

These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software. Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

## GNU GENERAL PUBLIC LICENSE

### TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the

user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances. It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS



TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

#### END OF TERMS AND CONDITIONS

#### How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the “copyright” line and a pointer to where the full notice is found.

<one line to give the program’s name and a brief idea of what it does. Copyright (C) <year

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA  
Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type ‘show w’.

This is free software, and you are welcome to redistribute it under certain conditions; type ‘show c’ for details.

The hypothetical commands ‘show w’ and ‘show c’ should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than ‘show w’ and ‘show c’; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a “copyright disclaimer” for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program ‘Gnomovision’ (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

The code and graphics on this website (and it's mirror sites, if any) are

Copyright (c) 1999-2004 by Erik Andersen. All rights reserved.

Copyright (c) 2005-2006 Rob Landley.

Documents on this Web site including their graphical elements, design, and layout are protected by trade dress and other laws and MAY BE COPIED OR IMITATED IN WHOLE OR IN PART. THIS WEBSITE IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE WEBSITE TO THE EXTENT PERMITTED BY APPLICABLE LAW.

SHOULD THIS WEBSITE PROVE DEFECTIVE, YOU MAY ASSUME THAT SOMEONE MIGHT GET AROUND TO SERVICING, REPAIRING OR CORRECTING IT SOMETIME WHEN THEY HAVE NOTHING BETTER TO DO. REGARDLESS, YOU GET TO KEEP BOTH PIECES.

IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THIS WEBSITE AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THIS WEBSITE (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR LOSS OF HAIR, LOSS OF LIFE, LOSS OF MEMORY, LOSS OF YOUR CARKEYS, MISPLACEMENT OF YOUR PAYCHECK, OR COMMANDER DATA BEING RENDERED UNABLE TO ASSIST THE STARFLEET OFFICERS ABOARD THE STARSHIP ENTERPRISE TO RECALIBRATE THE MAIN DEFLECTOR ARRAY, LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE WEBSITE TO OPERATE WITH YOUR WEBBROWSER), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

You have been warned.

You can contact the webmaster at <rob@landley.net of problem with this.

bzip2 applet in busybox is based on lightly-modified source of bzip2 version 1.0.4. bzip2 source is distributed under the following conditions (copied verbatim from LICENSE file).

This program, "bzip2", the associated library "libbzip2", and all documentation, are copyright (C) 1996-2006 Julian R Seward. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
3. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
4. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESSOR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO

EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Julian Seward, Cambridge, UK.

[jseward@bzip.org](mailto:jseward@bzip.org)

bzip2/libbzip2 version 1.0.4 of 20 December 2006

## cracklib 2.8.12

Available under license:

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

## GNU GENERAL PUBLIC LICENSE

### TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program).

Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License

and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES

SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

## END OF TERMS AND CONDITIONS

### How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the “copyright” line and a pointer to where the full notice is found.

<one line to give the program’s name and a brief idea of what it does. Copyright (C) <year

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type ‘show w’.

This is free software, and you are welcome to redistribute it under certain conditions; type ‘show c’ for details.

The hypothetical commands ‘show w’ and ‘show c’ should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than ‘show w’ and ‘show c’; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a “copyright disclaimer” for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program

‘Gnomovision’ (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

# curl 7.18.2 1

Available under license:

## COPYRIGHT AND PERMISSION NOTICE

Copyright (c) 1996 - 2008, Daniel Stenberg, <daniel@haxx.se>

All rights reserved.

Permission to use, copy, modify, and distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies.

THE SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OF THIRD PARTY RIGHTS. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Except as contained in this notice, the name of a copyright holder shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization of the copyright holder.

Copyright (c) 1995, 1996, 1997, 1998, 1999 Kungliga Tekniska Hogskolan

(Royal Institute of Technology, Stockholm, Sweden).

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the Institute nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE INSTITUTE AND CONTRIBUTORS “AS IS” AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE INSTITUTE OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.



## diffutils 2.8.1

Available under license:

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

### Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

### GNU GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

#### END OF TERMS AND CONDITIONS

##### How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the “copyright” line and a pointer to where the full notice is found.

<one line to give the program’s name and a brief idea of what it does.

Copyright (C) <year

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type 'show w'.

This is free software, and you are welcome to redistribute it under certain conditions; type 'show c' for details.

The hypothetical commands 'show w' and 'show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than 'show w' and 'show c'; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program

'Gnomovision' (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

## e2fsprogs 1.39

Available under license:

This package, the EXT2 filesystem utilities, are made available under the GNU Public License, with the exception of the lib/uuid directory which is made available under a BSD-style license. Please see lib/uuid/COPYING for more details for the license for the files comprising the libuuid library.

However, I request that if the version string in the file version.h contains the string "pre-", or "WIP" that this version of e2fsprogs be distributed in source form only. Please feel free to give a copy of the e2fsck binary to help a friend recover his or her filesystem, as the need arises. However, "pre" or "WIP" indicates that this release is under development, and available for ALPHA testing. So for your protection as much as mine, I'd prefer that it not appear in a some distribution --- especially not a CD-ROM distribution!

The most recent officially distributed version can be found at <http://e2fsprogs.sourceforge.net>. If you need to make a distribution, that's the one you should use. If there is some reason why you'd like a more recent version that is still in ALPHA testing for your distribution, please contact me (tytso@mit.edu), and we will very likely be able to work out something that will work for all concerned.

The release schedules for this package are flexible, if you give me enough lead time.

Theodore Ts'o

15-Mar-2003

## GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

### Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

### GNU GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License.

However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.



8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

#### END OF TERMS AND CONDITIONS

#### How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the “copyright” line and a pointer to where the full notice is found.

<one line to give the program’s name and a brief idea of what it does.

Copyright (C) <year

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type 'show w'.

This is free software, and you are welcome to redistribute it under certain conditions; type 'show c' for details.

The hypothetical commands 'show w' and 'show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than 'show w' and 'show c'; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program

'Gnomovision' (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

## Expat XML parser 2.0.1

Available under license:

Copyright (c) 1998, 1999, 2000 Thai Open Source Software Center Ltd.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR

OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

## expect 5.4.3

Available under license:

Written by: Don Libes, NIST, 2/6/90

Design and implementation of this program was paid for by U.S. tax dollars. Therefore it is public domain. However, the author and NIST would appreciate credit if this program or parts of it are used.

## freeradius-server 2.1.8

Available under license:

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

51 Franklin St, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

## GNU GENERAL PUBLIC LICENSE

### TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to his License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License

and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES

SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

## END OF TERMS AND CONDITIONS

### How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms. To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the “copyright” line and a pointer to where the full notice is found.

<one line to give the program's name and a brief idea of what it does.>

Copyright (C) <year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin St, Fifth Floor, Boston, MA 02110-1301 USA

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type ‘show w’.

This is free software, and you are welcome to redistribute it under certain conditions; type ‘show c’ for details.

The hypothetical commands ‘show w’ and ‘show c’ should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than ‘show w’ and ‘show c’; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a “copyright disclaimer” for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program

‘Gnomovision’ (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon>, 1 April 1989

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

## freeradius-server-src-lib 2.1.8

Available under license:

GNU LESSER GENERAL PUBLIC LICENSE

Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc.

51 Franklin St, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages--typically libraries--of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you want it; that you can change the software and use pieces of it in new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.



Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the “Lesser” General Public License because it does Less to protect the user’s freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users’ freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a “work based on the library” and a “work that uses the library”. The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

## GNU LESSER GENERAL PUBLIC LICENSE

### TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called “this License”). Each licensee is addressed as “you”.

A “library” means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The “Library”, below, refers to any such software library or work which has been distributed under these terms. A “work based on the Library” means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term “modification”).

“Source code” for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) The modified work must itself be a software library.
- b) You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.
- c) You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.
- d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful.

(For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a “work that uses the Library”. Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a “work that uses the Library” with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a “work that uses the library”. The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a “work that uses the Library” uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a “work that uses the Library” with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer’s own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

a) Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable “work that uses the Library”, as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)

b) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.

- c) Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.
- d) If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.
- e) Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the “work that uses the Library” must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

- a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.
- b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients’ exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

#### END OF TERMS AND CONDITIONS

### How to Apply These Terms to Your New Libraries

If you develop a new library, and you want it to be of the greatest possible use to the public, we recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

To apply these terms, attach the following notices to the library. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the “copyright” line and a pointer to where the full notice is found.

<one line to give the library's name and a brief idea of what it does.>

Copyright (C) <year> <name of author>

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details.

You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 51 Franklin St, Fifth Floor, Boston, MA 02110-1301 USA

Also add information on how to contact you by electronic and paper mail.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a “copyright disclaimer” for the library, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the library ‘Frob’ (a library for tweaking knobs) written by James Random Hacker.

<signature of Ty Coon>, 1 April 1990

Ty Coon, President of Vice

That’s all there is to it!

## glibc 2.9

Available under license:

### GNU GENERAL PUBLIC LICENSE

This file contains the copying permission notices for various files in the GNU C Library distribution that have copyright owners other than the Free Software Foundation. These notices all require that a copy of the notice be included in the accompanying documentation and be distributed with binary distributions of the code, so be sure to include this file along with any binary distributions derived from the GNU C Library.

All code incorporated from 4.4 BSD is distributed under the following license:

Copyright (C) 1991 Regents of the University of California.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. [This condition was removed.]
4. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The DNS resolver code, taken from BIND 4.9.5, is copyrighted both by UC Berkeley and by Digital Equipment Corporation. The DEC portions are under the following license:

Portions Copyright (C) 1993 by Digital Equipment Corporation.

Permission to use, copy, modify, and distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies, and that the name of Digital Equipment Corporation not be used in advertising or publicity pertaining to distribution of the document or software without specific, written prior permission.

THE SOFTWARE IS PROVIDED "AS IS" AND DIGITAL EQUIPMENT CORP. DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL DIGITAL EQUIPMENT CORPORATION BE LIABLE FOR ANY SPECIAL, DIRECT, INDIRECT, OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

The Sun RPC support (from rpcsrc-4.0) is covered by the following license:

Copyright (C) 1984, Sun Microsystems, Inc.

Sun RPC is a product of Sun Microsystems, Inc. and is provided for unrestricted use provided that this legend is included on all tape media and as a part of the software program in whole or part. Users may copy or modify Sun RPC without charge, but are not authorized to license or distribute it to anyone else except as part of a product or program developed by the user.

SUN RPC IS PROVIDED AS IS WITH NO WARRANTIES OF ANY KIND INCLUDING THE WARRANTIES OF DESIGN, MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, OR ARISING FROM A COURSE OF DEALING, USAGE OR TRADE PRACTICE.

Sun RPC is provided with no support and without any obligation on the part of Sun Microsystems, Inc. to assist in its use, correction, modification or enhancement.

SUN MICROSYSTEMS, INC. SHALL HAVE NO LIABILITY WITH RESPECT TO THE INFRINGEMENT OF COPYRIGHTS, TRADE SECRETS OR ANY PATENTS BY SUN RPC OR ANY PART THEREOF.

In no event will Sun Microsystems, Inc. be liable for any lost revenue or profits or other special, indirect and consequential damages, even if Sun has been advised of the possibility of such damages.

The following CMU license covers some of the support code for Mach, derived from Mach 3.0:

Mach Operating System

Copyright (C) 1991,1990,1989 Carnegie Mellon University

All Rights Reserved.

Permission to use, copy, modify and distribute this software and its documentation is hereby granted, provided that both the copyright notice and this permission notice appear in all copies of the software, derivative works or modified versions, and any portions thereof, and that both notices appear in supporting documentation.

CARNEGIE MELLON ALLOWS FREE USE OF THIS SOFTWARE IN ITS "AS IS" CONDITION. CARNEGIE MELLON DISCLAIMS ANY LIABILITY OF ANY KIND FOR ANY DAMAGES WHATSOEVER RESULTING FROM THE USE OF THIS SOFTWARE.

Carnegie Mellon requests users of this software to return to

Software Distribution Coordinator

School of Computer Science

Carnegie Mellon University

Pittsburgh PA 15213-3890

or Software.Distribution@CS.CMU.EDU any improvements or extensions that they make and grant Carnegie Mellon the rights to redistribute these changes.

The file if\_ppp.h is under the following CMU license:

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY CARNEGIE MELLON UNIVERSITY AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE UNIVERSITY OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.



The following license covers the files from Intel's "Highly Optimized Mathematical Functions for Itanium" collection:

Intel License Agreement

Copyright (c) 2000, Intel Corporation

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- The name of Intel Corporation may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL INTEL OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The files `inet/getnameinfo.c` and `sysdeps/posix/getaddrinfo.c` are copyright (C) by Craig Metz and are distributed under the following license:

The Inner Net License, Version 2.00

The author(s) grant permission for redistribution and use in source and binary forms, with or without modification, of the software and documentation provided that the following conditions are met:

0. If you receive a version of the software that is specifically labelled as not being for redistribution (check the version message and/or README), you are not permitted to redistribute that version of the software in any way or form.
1. All terms of the all other applicable copyrights and licenses must be followed.
2. Redistributions of source code must retain the authors' copyright notice(s), this list of conditions, and the following disclaimer.
3. Redistributions in binary form must reproduce the authors' copyright notice(s), this list of conditions, and the following disclaimer in the documentation and/or other materials provided with the distribution.
4. [The copyright holder has authorized the removal of this clause.]
5. Neither the name(s) of the author(s) nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY ITS AUTHORS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHORS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL

DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

If these license terms cause you a real problem, contact the author. /

GNU LESSER GENERAL PUBLIC LICENSE

Copyright 1992, 1993, 1994, 1997 Henry Spencer. All rights reserved.

## gnupg 1.4.5

Available under license:

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

51 Franklin St., Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights.

These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

#### GNU GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License.

However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License

and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program. If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES

SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

#### END OF TERMS AND CONDITIONS

#### How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the “copyright” line and a pointer to where the full notice is found.

<one line to give the program’s name and a brief idea of what it does.

Copyright (C) <year

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin St., Fifth Floor, Boston, MA 02110-1301 USA  
Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type ‘show w’.

This is free software, and you are welcome to redistribute it under certain conditions; type ‘show c’ for details.

The hypothetical commands ‘show w’ and ‘show c’ should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than ‘show w’ and ‘show c’; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a “copyright disclaimer” for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program

‘Gnomovision’ (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

# hotplug 2004\_03\_29

Available under license:

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,



c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

#### END OF TERMS AND CONDITIONS

#### How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least

the “copyright” line and a pointer to where the full notice is found.

<one line to give the program's name and a brief idea of what it does.>

Copyright (C) <year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type 'show w'.

This is free software, and you are welcome to redistribute it under certain conditions; type 'show' c for details.

The hypothetical commands 'show w' and 'show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than 'show w' and 'show c'; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program 'Gnomovision' (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon>, 1 April 1989

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

## i2c-tools 3.0.2

Available under license:

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all. The precise terms and conditions for copying, distribution and modification follow.

#### GNU GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License.

However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

## NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

## END OF TERMS AND CONDITIONS

### How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the “copyright” line and a pointer to where the full notice is found.

<one line to give the program’s name and a brief idea of what it does.

Copyright (C) <year

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type ‘show w’.

This is free software, and you are welcome to redistribute it under certain conditions; type ‘show c’ for details.

The hypothetical commands ‘show w’ and ‘show c’ should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than ‘show w’ and ‘show c’; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a “copyright disclaimer” for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program

‘Gnomovision’ (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

## ipmiutil 2.3.3

Available under license:

The BSD 2.0 License

Copyright (c) 2002-2008, Intel Corporation

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- a. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- b. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- c. Neither the name of Intel Corporation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS “AS IS” AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.



# iptables 1.4.1

Available under license:

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

675 Mass Ave, Cambridge, MA 02139, USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

## Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

## GNU GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License.

However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances. It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice. This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

#### END OF TERMS AND CONDITIONS

##### Appendix: How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the “copyright” line and a pointer to where the full notice is found.

<one line to give the program’s name and a brief idea of what it does.

Copyright (C) 19yy <name of author

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 675 Mass Ave, Cambridge, MA 02139, USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) 19yy name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type 'show w'.

This is free software, and you are welcome to redistribute it under certain conditions; type 'show c' for details.

The hypothetical commands 'show w' and 'show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than 'show w' and 'show c'; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program

'Gnomovision' (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

## kernel 2.6.29.1

Available under license:

NOTE! This copyright does *\*not\** cover user programs that use kernel services by normal system calls - this is merely considered normal use of the kernel, and does *\*not\** fall under the heading of "derived work". Also note that the GPL below is copyrighted by the Free Software Foundation, but the instance of code that it refers to (the Linux kernel) is copyrighted by me and others who actually wrote it.

Also note that the only valid version of the GPL as far as the kernel is concerned is *\_this\_* particular version of the license (i.e. v2, not v2.2 or v3.x or whatever), unless explicitly otherwise stated.

Linus Torvalds

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

51 Franklin St, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

#### Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

#### GNU GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that

is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License.

However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.



Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

#### END OF TERMS AND CONDITIONS

##### How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the “copyright” line and a pointer to where the full notice is found.

<one line to give the program’s name and a brief idea of what it does.

Copyright (C) <year>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin St, Fifth Floor, Boston, MA 02110-1301 USA

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type 'show w'.

This is free software, and you are welcome to redistribute it under certain conditions; type 'show c' for details.

The hypothetical commands 'show w' and 'show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than 'show w' and 'show c'; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program

'Gnomovision' (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

Copyright (c) 2003-2006 QLogic Corporation

QLogic Linux Networking HBA Driver

This program includes a device driver for Linux 2.6 that may be distributed with QLogic hardware specific firmware binary file.

You may modify and redistribute the device driver code under the GNU General Public License as published by the Free Software Foundation (version 2 or a later version).

You may redistribute the hardware specific firmware binary file under the following terms:

1. Redistribution of source code (only if applicable), must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistribution in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The name of QLogic Corporation may not be used to endorse or promote products derived from this software without specific prior written permission

REGARDLESS OF WHAT LICENSING MECHANISM IS USED OR APPLICABLE, THIS PROGRAM IS PROVIDED BY QLOGIC CORPORATION "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

USER ACKNOWLEDGES AND AGREES THAT USE OF THIS PROGRAM WILL NOT CREATE OR GIVE GROUNDS FOR A LICENSE BY IMPLICATION, ESTOPPEL, OR OTHERWISE IN ANY INTELLECTUAL PROPERTY RIGHTS (PATENT, COPYRIGHT, TRADE SECRET, MASK WORK, OR OTHER PROPRIETARY RIGHT) EMBODIED IN ANY OTHER QLOGIC HARDWARE OR SOFTWARE EITHER SOLELY OR IN COMBINATION WITH THIS PROGRAM.

Copyright (c) 2003-2008 QLogic Corporation

QLogic Linux Networking HBA Driver

This program includes a device driver for Linux 2.6 that may be distributed with QLogic hardware specific firmware binary file.

You may modify and redistribute the device driver code under the GNU General Public License as published by the Free Software Foundation (version 2 or a later version).

You may redistribute the hardware specific firmware binary file under the following terms:

1. Redistribution of source code (only if applicable), must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistribution in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The name of QLogic Corporation may not be used to endorse or promote products derived from this software without specific prior written permission

REGARDLESS OF WHAT LICENSING MECHANISM IS USED OR APPLICABLE, THIS PROGRAM IS PROVIDED BY QLOGIC CORPORATION "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

USER ACKNOWLEDGES AND AGREES THAT USE OF THIS PROGRAM WILL NOT CREATE OR GIVE GROUNDS FOR A LICENSE BY IMPLICATION, ESTOPPEL, OR OTHERWISE IN ANY INTELLECTUAL PROPERTY RIGHTS (PATENT, COPYRIGHT, TRADE SECRET, MASK WORK, OR OTHER PROPRIETARY RIGHT) EMBODIED IN ANY OTHER QLOGIC HARDWARE OR SOFTWARE EITHER SOLELY OR IN COMBINATION WITH THIS PROGRAM.

FlashPoint Driver Developer's Kit

Version 1.0

Copyright 1995-1996 by Mylex Corporation

All Rights Reserved

This program is free software; you may redistribute and/or modify it under the terms of either:

a) the GNU General Public License as published by the Free Software Foundation; either version 2, or (at your option) any later version,

or

b) the "BSD-style License" included below.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY, without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See either the GNU General Public License or the BSD-style License below for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 675 Mass Ave, Cambridge, MA 02139, USA.

The BSD-style License is as follows:

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain this LICENSE.FlashPoint file, without modification, this list of conditions, and the following disclaimer. The following copyright notice must appear immediately at the beginning of all source files:

Copyright 1995-1996 by Mylex Corporation. All Rights Reserved

This file is available under both the GNU General Public License and a BSD-style copyright; see LICENSE.FlashPoint for details.

2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

3. The name of Mylex Corporation may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY MYLEX CORP. "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (c) 2003-2005 QLogic Corporation

QLogic Linux Fibre Channel HBA Driver

This program includes a device driver for Linux 2.6 that may be distributed with QLogic hardware specific firmware binary file.

You may modify and redistribute the device driver code under the GNU General Public License as published by the Free Software Foundation (version 2 or a later version).

You may redistribute the hardware specific firmware binary file under the following terms:

1. Redistribution of source code (only if applicable), must retain the above copyright notice, this list of conditions and the following disclaimer.

2. Redistribution in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

3. The name of QLogic Corporation may not be used to endorse or promote products derived from this software without specific prior written permission

REGARDLESS OF WHAT LICENSING MECHANISM IS USED OR APPLICABLE, THIS PROGRAM IS PROVIDED BY QLOGIC CORPORATION "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN

NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

USER ACKNOWLEDGES AND AGREES THAT USE OF THIS PROGRAM WILL NOT CREATE OR GIVE GROUNDS FOR A LICENSE BY IMPLICATION, ESTOPPEL, OR OTHERWISE IN ANY INTELLECTUAL PROPERTY RIGHTS (PATENT, COPYRIGHT, TRADE SECRET, MASK WORK, OR OTHER PROPRIETARY RIGHT) EMBODIED IN ANY OTHER QLOGIC HARDWARE OR SOFTWARE EITHER SOLELY OR IN COMBINATION WITH THIS PROGRAM.

#### GNU LIBRARY GENERAL PUBLIC LICENSE

nicstar.c v0.22 Jawaid Bazyar (bazyar@hypermall.com)

nicstar.c, M. Welsh (matt.welsh@cl.cam.ac.uk)

Hacked October, 1997 by Jawaid Bazyar, Interlink Advertising Services Inc.

<http://www.hypermall.com/>

10/1/97 - commented out CFG\_PHYIE bit - we don't care when the PHY interrupts us (except possibly for removal/insertion of the cable?)

10/4/97 - began heavy inline documentation of the code. Corrected typos and spelling mistakes.

10/5/97 - added code to handle PHY interrupts, disable PHY on loss of link, and correctly re-enable PHY when link is re-established. (put back CFG\_PHYIE)

Modified to work with the IDT7721 nicstar -- AAL5 (tested) only.

R. D. Rechenmacher <ron@fnal.gov>

Linux driver for the IDT77201 NICStAR PCI ATM controller.

PHY component is expected to be 155 Mbps S/UNI-Lite or IDT 77155; see init\_nicstar() for PHY initialization to change this. This driver expects the Linux ATM stack to support scatter-gather lists (skb-Implementing minimal-copy of received data:

IDT always receives data into a small buffer, then large buffers as needed. This means that data must always be copied to create the linear buffer needed by most non-ATM protocol stacks (e.g. IP)

Fix is simple: make large buffers large enough to hold entire SDU, and leave <small\_buffer\_data copy small buffer contents to head of large buffer.

Trick is to avoid fragmenting Linux, due to need for a lot of large buffers. This is done by 2 things:

- 1) skb-combined, allow nicstar\_free\_rx\_skb to be called to recycle large data buffers
- 2) skb\_clone of received buffers

See nicstar\_free\_rx\_skb and linearize\_buffer for implementation details.

Copyright (c) 1996 University of Cambridge Computer Laboratory

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 675 Mass Ave, Cambridge, MA 02139, USA. M. Welsh, 6 July 1996

linux-2.6.29.1/drivers/net/LICENSE.SRC

Code in this directory written at the IDA Supercomputing Research Center carries the following copyright and license.

Copyright 1993 United States Government as represented by the Director, National Security Agency. This software may be used and distributed according to the terms of the GNU General Public License, incorporated herein by reference.

In addition to the disclaimers in the GPL, SRC expressly disclaims any and all warranties, expressed or implied, concerning the enclosed software.

This software was developed at SRC for use in internal research, and the intent in sharing this software is to promote the productive interchange of ideas throughout the research community. All software is furnished on an "as-is" basis. No further updates to this software should be expected. Although updates may occur, no commitment exists.

linux-2.6.29.1/drivers/net/wireless/libertas/LICENSE

Copyright (c) 2003-2006, Marvell International Ltd.

All Rights Reserved

This program is free software; you can redistribute it and/or modify it under the terms of version 2 of the GNU General Public License as published by the Free Software Foundation.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place - Suite 330, Boston, MA 02111-1307, USA.

The files in this directory and elsewhere which refer to this LICENCE file are part of JFFS2, the Journalling Flash File System v2.

Copyright © 2001-2007 Red Hat, Inc. and others

JFFS2 is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 or (at your option) any later version.

JFFS2 is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with JFFS2; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA.

As a special exception, if other files instantiate templates or use macros or inline functions from these files, or you compile these files and link them with other works to produce a work based on these files, these files do not by themselves cause the resulting work to be covered by the GNU General Public License. However the source code for these files must still be made available in accordance with section (3) of the GNU General Public License.

This exception does not invalidate any other reasons why a work based on this file might be covered by the GNU General Public License.

# KVM inter-VM shared memory module

Available under license:

Nahanni/ivshmem guest-code

(C) Cam Macdonell 2009-2011

This code is released under the GNU Public License V2 a copy of which is included below

-----

## GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

51 Franklin St, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

### Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

## GNU GENERAL PUBLIC LICENSE

### TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The “Program”, below, refers to any such program or work, and a “work based on the Program” means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term “modification”.) Each licensee is addressed as “you”.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program’s source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.



3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

#### END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the “copyright” line and a pointer to where the full notice is found.

<one line to give the program’s name and a brief idea of what it does.>

Copyright (C) <year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin St, Fifth Floor, Boston, MA 02110-1301 USA

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type ‘show w’. This is free software, and you are welcome to redistribute it under certain conditions; type ‘show c’ for details.

The hypothetical commands ‘show w’ and ‘show c’ should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than ‘show w’ and ‘show c’; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a “copyright disclaimer” for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program

‘Gnomovision’ (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon>, 1 April 1989

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

## libpcap 0.9.8

Available under license:

License: BSD

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The names of the authors may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

## libtecla 1.6.1

Available under license:

### LICENSE TERMS

Copyright (c) 2000, 2001, 2002, 2003, 2004 by Martin C. Shepherd.

All rights reserved.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the “Software”), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, provided that the above copyright notice(s) and this permission notice appear in all copies of the Software and that both the above copyright notice(s) and this permission notice appear in supporting documentation.

THE SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OF THIRD PARTY RIGHTS. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR HOLDERS INCLUDED IN THIS NOTICE BE LIABLE FOR ANY CLAIM, OR ANY SPECIAL INDIRECT OR CONSEQUENTIAL DAMAGES, OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

Except as contained in this notice, the name of a copyright holder shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization of the copyright holder.

## Linux-Pam 1.0.1

Available under license:

Unless otherwise \*explicitly\* stated the following text describes the licensed conditions under which the contents of this libpamc release may be distributed:

Redistribution and use in source and binary forms of libpamc, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain any existing copyright notice, and this entire permission notice in its entirety, including the disclaimer of warranties.
2. Redistributions in binary form must reproduce all prior and current copyright notices, this list of conditions, and the following disclaimer in the documentation and/or other materials provided with the distribution.

3. The name of any author may not be used to endorse or promote products derived from this software without their specific prior written permission.

ALTERNATIVELY, this product may be distributed under the terms of the GNU Library General Public License (LGPL), in which case the provisions of the GNU LGPL are required INSTEAD OF the above restrictions. (This clause is necessary due to a potential conflict between the GNU LGPL and the restrictions contained in a BSD-style copyright.)

THIS SOFTWARE IS PROVIDED "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR(S) BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

## Im\_sensors 3.0.2

Available under license:

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.,

51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

#### GNU GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as

separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License.

However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.



12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

## END OF TERMS AND CONDITIONS

### How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the “copyright” line and a pointer to where the full notice is found.

<one line to give the program’s name and a brief idea of what it does.

Copyright (C) <year>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type ‘show w’.

This is free software, and you are welcome to redistribute it under certain conditions; type ‘show c’ for details.

The hypothetical commands ‘show w’ and ‘show c’ should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than ‘show w’ and ‘show c’; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a “copyright disclaimer” for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program

‘Gnomovision’ (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

## module-init-tools 3.2.2 1.0.0.0900084

Available under license:

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights.

These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE

## TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The “Program”, below, refers to any such program or work, and a “work based on the Program” means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term “modification”.) Each licensee is addressed as “you”.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program’s source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License.

However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

#### END OF TERMS AND CONDITIONS

### How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the “copyright” line and a pointer to where the full notice is found.

<one line to give the program’s name and a brief idea of what it does.

Copyright (C) <year

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w`.

This is free software, and you are welcome to redistribute it under certain conditions; type `show c` for details.

The hypothetical commands `show w` and `show c` should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w` and `show c`; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a “copyright disclaimer” for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program

‘Gnomovision’ (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

## Ncurses 5.6

Available under license:

Copyright (c) 1998-2004,2006 Free Software Foundation, Inc.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, distribute with modifications, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE ABOVE COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Except as contained in this notice, the name(s) of the above copyright holders shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization.

## net-snmp 5.4.1

Available under license:

Various copyrights apply to this package, listed in various separate parts below. Please make sure that you read all the parts.

Part 1: CMU/UCD copyright notice: (BSD like)

Copyright 1989, 1991, 1992 by Carnegie Mellon University

Derivative Work - 1996, 1998-2000

Copyright 1996, 1998-2000 The Regents of the University of California

All Rights Reserved

Permission to use, copy, modify and distribute this software and its documentation for any purpose and without fee is hereby granted, provided that the above copyright notice appears in all copies and that both that copyright notice and this permission notice appear in supporting documentation, and that the name of CMU and The Regents of the University of California not be used in advertising or publicity pertaining to distribution of the software without specific written permission.

CMU AND THE REGENTS OF THE UNIVERSITY OF CALIFORNIA DISCLAIM ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL CMU OR THE REGENTS OF THE UNIVERSITY OF CALIFORNIA BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM THE LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

Part 2: Networks Associates Technology, Inc. copyright notice (BSD)

Copyright (c) 2001-2003, Networks Associates Technology, Inc.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the Networks Associates Technology, Inc. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS “AS IS” AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Part 3: Cambridge Broadband Ltd. copyright notice (BSD)

Portions of this code are copyright (c) 2001-2003, Cambridge Broadband Ltd.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- The name of Cambridge Broadband Ltd. may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDER “AS IS” AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Part 4: Sun Microsystems, Inc. copyright notice (BSD)

Copyright 2003 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A.  
All rights reserved.

Use is subject to license terms below.



This distribution may include materials developed by third parties.

Sun, Sun Microsystems, the Sun logo and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the Sun Microsystems, Inc. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Part 5: Sparta, Inc. copyright notice (BSD)

Copyright (c) 2003-2006, Sparta, Inc.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of Sparta, Inc. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Part 6: Cisco/BUPTNIC copyright notice (BSD)

Copyright (c) 2004, Cisco, Inc. and Information Network

Center of Beijing University of Posts and Telecommunications.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of Cisco, Inc., Beijing University of Posts and Telecommunications, nor the names of their contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS “AS IS” AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Part 7: Fabasoft R&D Software GmbH & Co KG copyright notice (BSD)

Copyright (c) Fabasoft R&D Software GmbH & Co KG, 2003

oss@fabasoft.com

Author: Bernhard Penz <bernhard.penz@fabasoft.com>

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- The name of Fabasoft R&D Software GmbH & Co KG or any of its subsidiaries, brand or product names may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDER “AS IS” AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

## NTP 4.2.4p5

Available under license:

This file is automatically generated from `html/copyright.html`

Copyright Notice

jpg “Clone me,” says Dolly sheepishly

Last update: 20:31 UTC Saturday, January 06, 2007

The following copyright notice applies to all files collectively called the Network Time Protocol Version 4 Distribution. Unless specifically declared otherwise in an individual file, this notice applies as if the text was explicitly included in the file.

Copyright (c) David L. Mills 1992-2008

Permission to use, copy, modify, and distribute this software and its documentation for any purpose with or without fee is hereby granted, provided that the above copyright notice appears in all copies and that both the copyright notice and this permission notice appear in supporting documentation, and that the name University of Delaware not be used in advertising or publicity pertaining to distribution of the software without specific, written prior permission. The University of Delaware makes no representations about the suitability this software for any purpose. It is provided “as is” without express or implied warranty.

The following individuals contributed in part to the Network Time Protocol Distribution Version 4 and are acknowledged as authors of this work.

1. Mark Andrews <mark\_andrews@isc.org> controller
2. Bernd Altmeier <altmeier@atlsoft.de> line and PCI-bus devices
3. Viraj Bais <vbais@mailman1.intel.com> <kirkwood@striderfm.intel.com>
4. Michael Barone <michael.barone@lmco.com>
5. Jean-Francois Boudreault <Jean-Francois.Boudreault@viagenie.qc.ca>
6. Karl Berry <karl@owl.HQ.ileaf.com>
7. Greg Brackley <greg.brackley@bigfoot.com> Clean up recvbuf and iosignal code into separate modules.
8. Marc Brett <Marc.Brett@westgeo.com>
9. Piete Brooks <Piete.Brooks@cl.cam.ac.uk> Trimble PARSE support
10. Reg Clemens <reg@dwf.com>
11. Steve Clift <clift@ml.csiro.au>
12. Casey Crellin <casey@csc.co.za> help with target configuration
13. Sven Dietrich <sven\_dietrich@trimble.com> clock driver, NT adj. residuals, integrated Greg’s Winnt port.
14. John A. Dundas III <dundas@salt.jpl.nasa.gov>
15. Torsten Duwe <duwe@immd4.informatik.uni-erlangen.de> port
16. Dennis Ferguson <dennis@mrbill.canet.ca> NTP Version 2 as specified in RFC-1119
17. John Hay <jhay@icomtek.csir.co.za>
18. Glenn Hollinger <glenn@herald.usask.ca>
19. Mike Iglesias <iglesias@uci.edu>

20. Jim Jagielski <jim@jagubox.gsfc.nasa.gov
21. Jeff Johnson <jbj@chatham.usdesign.com overhaul
22. Hans Lambermont <Hans.Lambermont@nl.origin-it.com <H.Lambermont@chello.nl
23. Poul-Henning Kamp <phk@FreeBSD.ORG author)
24. Frank Kardel [27]<kardel (at) ntp (dot) org driver (scripts, syslog cleanup, dynamic interface handling
25. William L. Jones <jones@hermes.chpc.utexas.edu modifications, HPUX modifications
26. Dave Katz <dkatz@cisco.com
27. Craig Leres <leres@ee.lbl.gov GPS clock driver
28. George Lindholm <lindholm@ucs.ubc.ca
29. Louis A. Mamakos <louie@ni.umd.edu
30. Lars H. Mathiesen <thorinn@diku.dk code for Version 3 as specified in RFC-1305
31. Danny Mayer <mayer@ntp.org Maintenance
32. David L. Mills <mills@udel.edu discipline, authentication, precision kernel; clock drivers: Spectracom, Austron, Arbiter, Heath, ATOM, ACTS, KSI/Odetics; audio clock drivers: CHU, WWV/H, IRIG
33. Wolfgang Moeller <moeller@gwdgv1.dnet.gwdg.de
34. Jeffrey Mogul <mogul@pa.dec.com
35. Tom Moore <tmoore@fivel.daytonoh.ncr.com
36. Kamal A Mostafa <kamal@whence.com
37. Derek Mulcahy <derek@toybox.demon.co.uk Hart-Davis <d@hd.org
38. Rainer Pruy <Rainer.Pruy@informatik.uni-erlangen.de monitoring/trap scripts, statistics file handling
39. Dirce Richards <dirce@zk3.dec.com
40. Wilfredo Sanchez <wsanchez@apple.com NetInfo
41. Nick Sayer <mrapple@quack.kfu.com
42. Jack Sasportas <jack@innovativeinternet.com space on the stuff in the html/pic/ subdirectory
43. Ray Schnitzler <schnitz@unipress.com
44. Michael Shields <shields@tembel.org
45. Jeff Steinman <jss@pebbles.jpl.nasa.gov driver
46. Harlan Stenn <harlan@pfcs.com makeover, various other bits (see the ChangeLog)
47. Kenneth Stone <ken@sdd.hp.com
48. Ajit Thyagarajan <ajit@ee.udel.edu support
49. Tomoaki TSURUOKA <tsuruoka@nc.fukuoka-u.ac.jp driver
50. Paul A Vixie <vixie@vix.com TrueTime clock driver
51. Ulrich Windl <Ulrich.Windl@rz.uni-regensburg.de validated HTML documents according to the HTML DTD

#### References

1. [mailto:mark\\_andrews@isc.org](mailto:mark_andrews@isc.org)

2. <mailto:altmeier@atlsoft.de>
3. <mailto:vbais@mailman1.intel.co>
4. <mailto:kirkwood@striderfm.intel.com>
5. <mailto:michael.barone@lmco.com>
6. <mailto:Jean-Francois.Boudreault@viagenie.qc.ca>
7. <mailto:karl@owl.HQ.ileaf.com>
8. <mailto:greg.brackley@bigfoot.com>
9. <mailto:Marc.Brett@westgeo.com>
10. <mailto:Piete.Brooks@cl.cam.ac.uk>
11. <mailto:reg@dwf.com>
12. <mailto:clift@ml.csiro.au>
13. <mailto:casey@csc.co.za>
14. [mailto:Sven\\_Dietrich@trimble.COM](mailto:Sven_Dietrich@trimble.COM)
15. <mailto:dundas@salt.jpl.nasa.gov>
16. <mailto:duwe@immd4.informatik.uni-erlangen.de>
17. <mailto:dennis@mrbill.canet.ca>
18. <mailto:jhay@icomtek.csir.co.za>
19. <mailto:glenn@herald.usask.ca>
20. <mailto:iglesias@uci.edu>
21. <mailto:jagubox.gsfc.nasa.gov>
22. <mailto:jbj@chatham.usdesign.com>
23. <mailto:Hans.Lambermont@nl.origin-it.com>
24. <mailto:H.Lambermont@chello.nl>
25. <mailto:phk@FreeBSD.ORG>
26. <http://www4.informatik.uni-erlangen.de/%7ekardel>
27. [mailto:kardel\(at\)ntp\(dot\)org](mailto:kardel(at)ntp(dot)org)
28. <mailto:jones@hermes.chpc.utexas.edu>
29. <mailto:dkatz@cisco.com>
30. <mailto:leres@ee.lbl.gov>
31. <mailto:lindholm@ucs.ubc.ca>
32. <mailto:louie@ni.umd.edu>
33. <mailto:thorinn@diku.dk>
34. <mailto:mayer@ntp.org>
35. <mailto:mills@udel.edu>
36. <mailto:moeller@gwdgv1.dnet.gwdg.de>
37. <mailto:mogul@pa.dec.com>
38. <mailto:tmoore@fieval.daytonoh.ncr.com>
39. <mailto:kamal@whence.com>

- 40. mailto:derek@toybox.demon.co.uk
- 41. mailto:d@hd.org
- 42. mailto:Rainer.Pruy@informatik.uni-erlangen.de
- 43. mailto:dirce@zk3.dec.com
- 44. mailto:wsanchez@apple.com
- 45. mailto:mrapple@quack.kfu.com
- 46. mailto:jack@innovativeinternet.com
- 47. mailto:schnitz@unipress.com
- 48. mailto:shields@tembel.org
- 49. mailto:pebbles.jpl.nasa.gov
- 50. mailto:harlan@pfcs.com
- 51. mailto:ken@sdd.hp.com
- 52. mailto:ajit@ee.udel.edu
- 53. mailto:tsuruoka@nc.fukuoka-u.ac.jp
- 54. mailto:vixie@vix.com
- 55. mailto:Ulrich.Windl@rz.uni-regensburg.de

GNU LESSER GENERAL PUBLIC LICENSE

Redistribution and use in source and binary forms, with or without

GNU GENERAL PUBLIC LICENSE

General Public Licence for the software known as MSNTP

## openssh 5.1p1

Available under license:

This file is part of the OpenSSH software.

The licences which components of this software fall under are as follows. First, we will summarize and say that all components are under a BSD licence, or a licence more free than that.

1)

OpenSSH contains no GPL code.

Copyright (c) 1995 Tatu Ylonen <ylo@cs.hut.fi>

All rights reserved

As far as I am concerned, the code I have written for this software can be used freely for any purpose. Any derived versions of this software must be clearly marked as such, and if the derived work is incompatible with the protocol description in the RFC file, it must be called by a name other than “ssh” or “Secure Shell”.

[Tatu continues]

However, I am not implying to give any licenses to any patents or copyrights held by third parties, and the software includes parts that are not under my direct control. As far as I know, all included source code is used in accordance with the relevant license agreements and can be used freely for any purpose (the GNU license being the most restrictive); see below for details.

[However, none of that term is relevant at this point in time. All of these restrictively licensed software components which he talks about have been removed from OpenSSH, i.e.,

- RSA is no longer included, found in the OpenSSL library
- IDEA is no longer included, its use is deprecated
- DES is now external, in the OpenSSL library
- GMP is no longer used, and instead we call BN code from OpenSSL
- Zlib is now external, in a library
- The make-ssh-known-hosts script is no longer included
- TSS has been removed
- MD5 is now external, in the OpenSSL library
- RC4 support has been replaced with ARC4 support from OpenSSL
- Blowfish is now external, in the OpenSSL library

[The licence continues]

Note that any information and cryptographic algorithms used in this software are publicly available on the Internet and at any major bookstore, scientific library, and patent office worldwide. More information can be found e.g. at "<http://www.cs.hut.fi/crypto>".

The legal status of this program is some combination of all these permissions and restrictions. Use only at your own responsibility.

You will be responsible for any legal consequences yourself; I am not making any claims whether possessing or using this is legal or not in your country, and I am not taking any responsibility on your behalf.

#### NO WARRANTY

BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

2)

The 32-bit CRC compensation attack detector in deattack.c was contributed by CORE SDI S.A. under a BSD-style license.

Cryptographic attack detector for ssh - source code

Copyright (c) 1998 CORE SDI S.A., Buenos Aires, Argentina.

All rights reserved. Redistribution and use in source and binary forms, with or without modification, are permitted provided that this copyright notice is retained.

THIS SOFTWARE IS PROVIDED "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES ARE DISCLAIMED. IN NO EVENT SHALL CORE SDI S.A. BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OR MISUSE OF THIS SOFTWARE.

Ariel Futoransky <futo@core-sdi.com

<<http://www.core-sdi.com>

3)

ssh-keyscan was contributed by David Mazieres under a BSD-style license.

Copyright 1995, 1996 by David Mazieres <dm@lcs.mit.edu>

Modification and redistribution in source and binary forms is permitted provided that due credit is given to the author and the OpenBSD project by leaving this copyright notice intact.

4)

The Rijndael implementation by Vincent Rijmen, Antoon Bosselaers and Paulo Barreto is in the public domain and distributed with the following license:

version 3.0 (December 2000)

Optimised ANSI C code for the Rijndael cipher (now AES)

author Vincent Rijmen <vincent.rijmen@esat.kuleuven.ac.be>

author Antoon Bosselaers <antoon.bosselaers@esat.kuleuven.ac.be>

author Paulo Barreto <paulo.barreto@terra.com.br>

This code is hereby placed in the public domain.

THIS SOFTWARE IS PROVIDED BY THE AUTHORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHORS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

5)

One component of the ssh source code is under a 3-clause BSD license, held by the University of California, since we pulled these parts from original Berkeley code.

Copyright (c) 1983, 1990, 1992, 1993, 1995

The Regents of the University of California. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.



2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

3. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

6)

Remaining components of the software are provided under a standard 2-term BSD licence with the following names as copyright holders:

Markus Friedl

Theo de Raadt

Niels Provos

Dug Song

Aaron Campbell

Damien Miller

Kevin Steves

Daniel Kouril

Wesley Griffin

Per Allansson

Nils Nordman

Simon Wilkinson

Portable OpenSSH additionally includes code from the following copyright holders, also under the 2-term BSD license:

Ben Lindstrom

Tim Rice

Andre Lucas

Chris Adams

Corinna Vinschen

Cray Inc.

Denis Parker

Gert Doering

Jakob Schlyter

Jason Downs

Juha Yrjölä

Michael Stone

Networks Associates Technology, Inc.

Solar Designer

Todd C. Miller

Wayne Schroeder

William Jones

Darren Tucker

Sun Microsystems

The SCO Group

Daniel Walsh

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

8)

Portable OpenSSH contains the following additional licenses:

a) md5crypt.c, md5crypt.h

"THE BEER-WARE LICENSE" (Revision 42):

<phk@login.dknet.dk

notice you can do whatever you want with this stuff. If we meet some day, and you think this stuff is worth it, you can buy me a beer in return. Poul-Henning Kamp

b) snprintf replacement

Copyright Patrick Powell 1995

his code is based on code written by Patrick Powell

papowell@astart.com) It may be used for any purpose as long as this notice remains intact on all source code distributions

c) Compatibility code (openbsd-compat)

Apart from the previously mentioned licenses, various pieces of code in the openbsd-compat/ subdirectory are licensed as follows:

Some code is licensed under a 3-term BSD license, to the following copyright holders:

Todd C. Miller

Theo de Raadt

Damien Miller

Eric P. Allman

The Regents of the University of California

Constantin S. Svintsoff

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Some code is licensed under an ISC-style license, to the following copyright holders:

Internet Software Consortium.

Todd C. Miller

Reyk Floeter

Chad Mynhier

Permission to use, copy, modify, and distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies.

THE SOFTWARE IS PROVIDED "AS IS" AND TODD C. MILLER DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL TODD C. MILLER BE LIABLE FOR ANY SPECIAL, DIRECT, INDIRECT, OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

Some code is licensed under a MIT-style license to the following copyright holders:

Free Software Foundation, Inc.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the “Software”), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, distribute with modifications, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED “AS IS”, WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE ABOVE COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Except as contained in this notice, the name(s) of the above copyright holders shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization.

## openssl 0.9.8j

Notifications:

This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>)

This product includes cryptographic software written by Eric Young ([ey@cryptsoft.com](mailto:ey@cryptsoft.com)).

This product includes software written by Tim Hudson ([tjh@cryptsoft.com](mailto:tjh@cryptsoft.com)).

Available under license:

### LICENSE ISSUES

The OpenSSL toolkit stays under a dual license, i.e. both the conditions of the OpenSSL License and the original SSLeay license apply to the toolkit.

See below for the actual license texts. Actually both licenses are BSD-style Open Source licenses. In case of any license issues related to OpenSSL please contact [openssl-core@openssl.org](mailto:openssl-core@openssl.org).

### OpenSSL License

Copyright (c) 1998-2008 The OpenSSL Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgment:

“This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (<http://www.openssl.org/>)”

4. The names “OpenSSL Toolkit” and “OpenSSL Project” must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact [openssl-core@openssl.org](mailto:openssl-core@openssl.org).
5. Products derived from this software may not be called “OpenSSL” nor may “OpenSSL” appear in their names without prior written permission of the OpenSSL Project.
6. Redistributions of any form whatsoever must retain the following acknowledgment:

“This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>)”

THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT “AS IS” AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes cryptographic software written by Eric Young ([ey@cryptsoft.com](mailto:ey@cryptsoft.com)). This product includes software written by Tim Hudson ([tjh@cryptsoft.com](mailto:tjh@cryptsoft.com)).

Original SSLeay License

Copyright (C) 1995-1998 Eric Young ([ey@cryptsoft.com](mailto:ey@cryptsoft.com))

All rights reserved.

This package is an SSL implementation written by Eric Young ([ey@cryptsoft.com](mailto:ey@cryptsoft.com)). The implementation was written so as to conform with Netscapes SSL.

This library is free for commercial and non-commercial use as long as the following conditions are adhered to. The following conditions apply to all code found in this distribution, be it the RC4, RSA, lhash, DES, etc., code; not just the SSL code. The SSL documentation included with this distribution is covered by the same copyright terms except that the holder is Tim Hudson ([tjh@cryptsoft.com](mailto:tjh@cryptsoft.com)).

Copyright remains Eric Young’s, and as such any Copyright notices in the code are not to be removed.

If this package is used in a product, Eric Young should be given attribution as the author of the parts of the library used. This can be in the form of a textual message at program startup or in documentation (online or textual) provided with the package.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement: “This product includes cryptographic software written by Eric Young ([ey@cryptsoft.com](mailto:ey@cryptsoft.com))”

The word ‘cryptographic’ can be left out if the routines from the library being used are not cryptographic related :-).

4. If you include any Windows specific code (or a derivative thereof) from the apps directory (application code) you must include an acknowledgement: “This product includes software written by Tim Hudson (tjh@cryptsoft.com)”

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG “AS IS” AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The licence and distribution terms for any publicly available version or derivative of this code cannot be changed, i.e. this code cannot simply be copied and put under another distribution licence [including the GNU Public Licence.]

Copyright (C) 1995-1997 Eric Young (eay@cryptsoft.com)

All rights reserved.

This package is an Blowfish implementation written by Eric Young (eay@cryptsoft.com).

This library is free for commercial and non-commercial use as long as the following conditions are adhered to. The following conditions apply to all code found in this distribution.

Copyright remains Eric Young’s, and as such any Copyright notices in the code are not to be removed.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement: This product includes software developed by Eric Young (eay@cryptsoft.com).

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG “AS IS” AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The license and distribution terms for any publicly available version or derivative of this code cannot be changed, i.e. this code cannot simply be copied and put under another distribution license [including the GNU Public License.]

The reason behind this being stated in this direct manner is past experience in code simply being copied and the attribution removed from it and then being distributed as part of other packages. This implementation was a non-trivial and unpaid effort.

Copyright (C) 1995-1997 Eric Young (eay@cryptsoft.com)

All rights reserved.

This package is an DES implementation written by Eric Young (eay@cryptsoft.com).

The implementation was written so as to conform with MIT's libdes.

This library is free for commercial and non-commercial use as long as the following conditions are adhered to. The following conditions apply to all code found in this distribution.

Copyright remains Eric Young's, and as such any Copyright notices in the code are not to be removed.

If this package is used in a product, Eric Young should be given attribution as the author of that the SSL library. This can be in the form of a textual message at program startup or in documentation (online or textual) provided with the package.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement: This product includes software developed by Eric Young (eay@cryptsoft.com)

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The license and distribution terms for any publicly available version or derivative of this code cannot be changed, i.e. this code cannot simply be copied and put under another distribution license [including the GNU Public License.]

The reason behind this being stated in this direct manner is past experience in code simply being copied and the attribution removed from it and then being distributed as part of other packages. This implementation was a non-trivial and unpaid effort.

## pciutils 3.0.1

Available under license:

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

## Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

## GNU GENERAL PUBLIC LICENSE

### TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.



You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that

is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

#### END OF TERMS AND CONDITIONS

##### How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the “copyright” line and a pointer to where the full notice is found.

<one line to give the program’s name and a brief idea of what it does.

Copyright (C) <year>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type 'show w'.

This is free software, and you are welcome to redistribute it under certain conditions; type 'show c' for details.

The hypothetical commands 'show w' and 'show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than 'show w' and 'show c'; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program

'Gnomovision' (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

Copyright (c) 1997--2008 Martin Mares <mj@ucw.cz

All files in this package can be freely distributed and used according to the terms of the GNU General Public License, either version 2 or (at your opinion) any newer version. See <http://www.gnu.org/> for details.

List of PCI ID's

Maintained by Martin Mares <mj@ucw.cz

Linux PCI ID's Project at <http://pciids.sf.net/>.

New data are always welcome, especially if accurate. If you have anything to contribute, please follow the instructions at the web site or send a diff -u against the most recent pci.ids to [pci-ids@ucw.cz](mailto:pci-ids@ucw.cz).

This file can be distributed under either the GNU General Public License (version 2 or higher) or the 3-clause BSD License.

Daily snapshot on Thu 2008-09-11 01:05:01

License: BSD

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The names of the authors may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

## procps 3.2.7

Available under license:

### GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc. 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

#### Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

### GNU GENERAL PUBLIC LICENSE

#### TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

#### END OF TERMS AND CONDITIONS

#### How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the “copyright” line and a pointer to where the full notice is found.

<one line to give the program’s name and a brief idea of what it does.



Copyright (C) <year

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type 'show w'.

This is free software, and you are welcome to redistribute it under certain conditions; type 'show c' for details.

The hypothetical commands 'show w' and 'show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than 'show w' and 'show c'; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program

'Gnomovision' (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

## sysfsutils 2.1.0

Available under license:

The commands and utilities under the "test" directory are licensed under the GNU General Public License (GPL) Version 2, June 1991. The full text of the GPL is located at:

sysfsutils/cmd/GPL

The sysfs library is licensed under the GNU Lesser Public License (LGPL) Version 2.1, February 1999. The full text of the LGPL is located at:

sysfsutils/lib/LGPL

The GNU General Public License (GPL)

GNU Lesser Public License

## sysstat 8.1.3

Available under license:

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.

675 Mass Ave, Cambridge, MA 02139, USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

### Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE

### TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of

it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term “modification”.) Each licensee is addressed as “you”.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program’s source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and “any later version”, you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

#### END OF TERMS AND CONDITIONS

#### Appendix: How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the “copyright” line and a pointer to where the full notice is found.

<one line to give the program’s name and a brief idea of what it does.

Copyright (C) 19yy <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 675 Mass Ave, Cambridge, MA 02139, USA.

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) 19yy name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type 'show w'.

This is free software, and you are welcome to redistribute it under certain conditions; type 'show c' for details.

The hypothetical commands 'show w' and 'show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than 'show w' and 'show c'; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program

'Gnomovision' (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon>

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

## tcl 8.4.9

Available under license:

This software is copyrighted by the Regents of the University of California, Sun Microsystems, Inc., Scriptics Corporation, ActiveState Corporation and other parties. The following terms apply to all files associated with the software unless explicitly disclaimed in individual files.

The authors hereby grant permission to use, copy, modify, distribute, and license this software and its documentation for any purpose, provided that existing copyright notices are retained in all copies and that this notice is included verbatim in any distributions. No written agreement, license, or royalty fee is required for any of the authorized uses.

Modifications to this software may be copyrighted by their authors and need not follow the licensing terms described here, provided that the new terms are clearly indicated on the first page of each file where they apply.

IN NO EVENT SHALL THE AUTHORS OR DISTRIBUTORS BE LIABLE TO ANY PARTY FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF THIS SOFTWARE, ITS DOCUMENTATION, OR ANY DERIVATIVES THEREOF, EVEN IF THE AUTHORS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

THE AUTHORS AND DISTRIBUTORS SPECIFICALLY DISCLAIM ANY WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT. THIS SOFTWARE IS PROVIDED ON AN "AS IS" BASIS, AND THE AUTHORS AND DISTRIBUTORS HAVE NO OBLIGATION TO PROVIDE MAINTENANCE, SUPPORT, UPDATES, ENHANCEMENTS, OR MODIFICATIONS.

GOVERNMENT USE: If you are acquiring this software on behalf of the U.S. government, the Government shall have only "Restricted Rights" in the software and related documentation as defined in the Federal Acquisition Regulations (FARs) in Clause 52.227.19 (c) (2). If you are acquiring the software on behalf of the Department of Defense, the software shall be classified as "Commercial Computer Software" and the Government shall have only "Restricted Rights" as defined in Clause 252.227-7013 (c) (1) of DFARs. Notwithstanding the foregoing, the authors grant the U.S. Government and others acting in its behalf permission to use and distribute the software in accordance with the terms specified in this license.

## tcpdump 3.9.8 1.0.1.0801182

Available under license:

License: BSD

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The names of the authors may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

## tipc 1.7.6-bundle

Available under license:

net/tipc/tipc\_user\_reg.c: TIPC user registry code

Copyright (c) 2000-2006, Ericsson AB

Copyright (c) 2004-2006, Wind River Systems

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the names of the copyright holders nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

\* Alternatively, this software may be distributed under the terms of the GNU General Public License (“GPL”) version 2 as published by the Free Software Foundation.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS “AS IS” AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

client\_tipc.c

Short description: TIPC benchmark demo (client side)

Copyright (c) 2001-2005, Ericsson Research Canada

Copyright (c) 2004-2006, Wind River Systems

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the names of the copyright holders nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS “AS IS” AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.



## util-linux 2.12r

Available under license:

### GNU GENERAL PUBLIC LICENSE

Copyright (c) 1989 The Regents of the University of California.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement:

This product includes software developed by the University of California, Berkeley and its contributors.

4. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (c) 2000-2001 Gunnar Ritter. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. [deleted]
4. Neither the name of Gunnar Ritter nor the names of his contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY GUNNAR RITTER AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL GUNNAR RITTER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS

INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

## zlib 1.2.3

Available under license:

License attached

zlib.h -- interface of the 'zlib' general purpose compression library version 1.2.3, July 18th, 2005

Copyright (C) 1995-2005 Jean-loup Gailly and Mark Adler

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

1. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
2. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
3. This notice may not be removed or altered from any source distribution.

Jean-loup Gailly      Mark Adler

jloup@gzip.org      madler@alumni.caltech.edu

The data format used by the zlib library is described by RFCs (Request for Comments) 1950 to 1952 in the files <http://www.ietf.org/rfc/rfc1950.txt> (zlib format), [rfc1951.txt](http://www.ietf.org/rfc/rfc1951.txt) (deflate format) and [rfc1952.txt](http://www.ietf.org/rfc/rfc1952.txt) (gzip format).

---

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)



Revised: September 1, 2014

---

## Numerals

- 3DES** Triple Data Encryption Standard. A stronger version of DES, which is the default encryption method for SSH version 1.5. Used when establishing an SSH session with the sensor. It can be used when the sensor is managing a device.
- 802.x** A set of IEEE standards for the definition of LAN protocols.

---

## A

- AAA** authentication, authorization, and accounting. Pronounced “triple a.” The primary and recommended method for access control in Cisco devices.
- ACE** Access Control Entry. An entry in the ACL that describes what action should be taken for a specified address or protocol. The sensor adds/removes ACE to block hosts.
- ACK** acknowledgment. Notification sent from one network device to another to acknowledge that some event occurred (for example, the receipt of a message).
- ACL** Access Control List. A list of ACEs that control the flow of data through a router. There are two ACLs per router interface for inbound data and outbound data. Only one ACL per direction can be active at a time. ACLs are identified by number or by name. ACLs can be standard, enhanced, or extended. You can configure the sensor to manage ACLs.
- ACS server** Cisco Access Control Server. A RADIUS security server that is the centralized control point for managing network users, network administrators, and network infrastructure resources.
- action** The response of the sensor to an event. An action only happens if the event is not filtered. Examples include TCP reset, block host, block connection, IP logging, and capturing the alert trigger packet.
- active ACL** The ACL created and maintained by ARC and applied to the router block interfaces.
- adaptive security appliance** ASA. Combines firewall, VPN concentrator, and intrusion prevention software functionality into one software image. You can configure the adaptive security appliance in single mode or multi-mode.
- AIC engine** Application Inspection and Control engine. Provides deep analysis of web traffic. It provides granular control over HTTP sessions to prevent abuse of the HTTP protocol. It allows administrative control over applications that try to tunnel over specified ports, such as instant messaging, and tunneling applications, such as gotomypc. It can also inspect FTP traffic and control the commands being issued.

|                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>ASA 5500 AIP SSM</b>      | Advanced Inspection and Prevention Security Services Module. The IPS plug-in module in the Cisco ASA 5500 series adaptive security appliance. The ASA 5500 AIP SSM is an IPS services module that monitors and performs real-time analysis of network traffic by looking for anomalies and misuse based on an extensive, embedded signature library. When the ASA 5500 AIP SSM detects unauthorized activity, it can terminate the specific connection, permanently block the attacking host, log the incident, and send an alert to the device manager. See also adaptive security appliance.                                                              |
| <b>ASA 5500-X IPS SSP</b>    | Intrusion Prevention System Security Services Processor. The IPS is running as a service and ASA controls sending and receiving traffic to and from the IPS. The IPS services processor monitors and performs real-time analysis of network traffic by looking for anomalies and misuse based on an extensive, embedded signature library. When the ASA 5500-X IPS SSP detects unauthorized activity, it can terminate the specific connection, permanently block the attacking host, log the incident, and send an alert to the device manager. See also adaptive security appliance.                                                                      |
| <b>ASA 5585-X IPS SSP</b>    | Intrusion Prevention System Security Services Processor. The IPS plug-in module in the Cisco ASA 5585-X adaptive security appliance. The ASA 5585-X IPS SSP is an IPS services processor that monitors and performs real-time analysis of network traffic by looking for anomalies and misuse based on an extensive, embedded signature library. When the ASA 5585-X IPS SSP detects unauthorized activity, it can terminate the specific connection, permanently block the attacking host, log the incident, and send an alert to the device manager. See also adaptive security appliance.                                                                |
| <b>Alarm Channel</b>         | The IPS software module that processes all signature events generated by the inspectors. Its primary function is to generate alerts for each event it receives.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>alert</b>                 | Specifically, an IPS event type; it is written to the Event Store as an evidsAlert. In general, an alert is an IPS message that indicates a network exploit in progress or a potential security problem occurrence. Also known as an alarm.                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Analysis Engine</b>       | The IPS software module that handles sensor configuration. It maps the interfaces and also the signature and alarm channel policy to the configured interfaces. It performs packet analysis and alert detection. The Analysis Engine functionality is provided by the SensorApp process.                                                                                                                                                                                                                                                                                                                                                                    |
| <b>anomaly detection</b>     | AD. The sensor component that creates a baseline of normal network traffic and then uses this baseline to detect worm-infected hosts.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>API</b>                   | Application Programming Interface. The means by which an application program talks to communications software. Standardized APIs allow application programs to be developed independently of the underlying method of communication. Computer application programs run a set of standard software interrupts, calls, and data formats to initiate contact with other devices (for example, network services, mainframe communications programs, or other program-to-program communications). Typically, APIs make it easier for software developers to create links that an application needs to communicate with the operating system or with the network. |
| <b>application</b>           | Any program (process) designed to run in the Cisco IPS environment.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>application image</b>     | Full IPS image stored on a permanent storage device used for operating the sensor.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>application instance</b>  | A specific application running on a specific piece of hardware in the IPS environment. An application instance is addressable by its name and the IP address of its host computer.                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>application partition</b> | The bootable disk or compact-flash partition that contains the IPS software image.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>ARC</b>                   | Attack Response Controller. Formerly known as Network Access Controller (NAC). A component of the IPS. A software module that provides block and unblock functionality where applicable.                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

|                                |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|--------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>architecture</b>            | The overall structure of a computer or communication system. The architecture influences the capabilities and limitations of the system.                                                                                                                                                                                                                                                                                               |
| <b>ARP</b>                     | Address Resolution Protocol. Internet protocol used to map an IP address to a MAC address. Defined in RFC 826.                                                                                                                                                                                                                                                                                                                         |
| <b>ASDM</b>                    | Adaptive Security Device Manager. A web-based application that lets you configure and manage your adaptive security device.                                                                                                                                                                                                                                                                                                            |
| <b>ASN.1</b>                   | Abstract Syntax Notation 1. Standard for data presentation.                                                                                                                                                                                                                                                                                                                                                                            |
| <b>aspect version</b>          | Version information associated with a group of IDIOM default configuration settings. For example, Cisco Systems publishes the standard set of attack signatures as a collection of default settings with the S aspect. The S-aspect version number is displayed after the S in the signature update package file name. Other aspects include the Virus signature definitions in the V-aspect and IDIOM signing keys in the key-aspect. |
| <b>atomic attack</b>           | Represents exploits contained within a single packet. For example, the “ping of death” attack is a single, abnormally large ICMP packet.                                                                                                                                                                                                                                                                                               |
| <b>Atomic engine</b>           | There are two Atomic engines: Atomic IP inspects IP protocol packets and associated Layer-4 transport protocols, and Atomic ARP inspects Layer-2 ARP protocol.                                                                                                                                                                                                                                                                         |
| <b>attack</b>                  | An assault on system security that derives from an intelligent threat, that is, an intelligent act that is a deliberate attempt (especially in the sense of method or technique) to evade security services and violate the security policy of a system.                                                                                                                                                                               |
| <b>attack relevance rating</b> | ARR. A weight associated with the relevancy of the targeted OS. The attack relevance rating is a derived value (relevant, unknown, or not relevant), which is determined at alert time. The relevant OSes are configured per signature.                                                                                                                                                                                                |
| <b>attack severity rating</b>  | ASR. A weight associated with the severity of a successful exploit of the vulnerability. The attack severity rating is derived from the alert severity parameter (informational, low, medium, or high) of the signature. The attack severity rating is configured per signature and indicates how dangerous the event detected is.                                                                                                     |
| <b>authentication</b>          | Process of verifying that a user has permission to use the system, usually by means of a password key or certificate.                                                                                                                                                                                                                                                                                                                  |
| <b>AuthenticationApp</b>       | A component of the IPS. Authorizes and authenticates users based on IP address, password, and digital certificates.                                                                                                                                                                                                                                                                                                                    |
| <b>autostate</b>               | In normal autostate mode, the Layer 3 interfaces remain up if at least one port in the VLAN remains up. If you have appliances, such as load balancers or firewall servers that are connected to the ports in the VLAN, you can configure these ports to be excluded from the autostate feature to make sure that the forwarding SVI does not go down if these ports become inactive.                                                  |
| <b>AV</b>                      | Anti-Virus.                                                                                                                                                                                                                                                                                                                                                                                                                            |

---

**B**

|                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>backplane</b>       | The physical connection between an interface processor or card and the data buses and the power distribution buses inside a chassis.                                                                                                                                                                                                                                                                                                                                    |
| <b>base version</b>    | A software release that must be installed before a follow-up release, such as a service pack or signature update, can be installed. Major and minor updates are base version releases.                                                                                                                                                                                                                                                                                  |
| <b>benign trigger</b>  | A situation in which a signature is fired correctly, but the source of the traffic is nonmalicious.                                                                                                                                                                                                                                                                                                                                                                     |
| <b>BIOS</b>            | Basic Input/Output System. The program that starts the sensor and communicates between the devices in the sensor and the system.                                                                                                                                                                                                                                                                                                                                        |
| <b>blackhole</b>       | Routing term for an area of the internetwork where packets enter, but do not emerge, due to adverse conditions or poor system configuration within a portion of the network.                                                                                                                                                                                                                                                                                            |
| <b>block</b>           | The ability of the sensor to direct a network device to deny entry to all packets from a specified network host or network.                                                                                                                                                                                                                                                                                                                                             |
| <b>block interface</b> | The interface on the network device that the sensor manages.                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>BO</b>              | BackOrifice. The original Windows back door Trojan that ran over UDP only.                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>BO2K</b>            | BackOrifice 2000. A Windows back door Trojan that runs over TCP and UDP.                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>bootloader</b>      | A small set of system software that runs when the system first powers up. It loads the operating system (from the disk, network, external compact flash, or external USB flash), which loads and runs the IPS application.                                                                                                                                                                                                                                              |
| <b>Botnets</b>         | A collection of software robots, or bots, that run autonomously and automatically. The term is often associated with malicious software but it can also refer to the network of computers using distributed computing software. The term Botnet is used to refer to a collection of compromised computers (called Zombie computers) running software, usually installed through worms, Trojan horses, or back doors, under a common command-and-control infrastructure. |
| <b>Bpdu</b>            | Bridge Protocol Data Unit. Spanning-Tree Protocol hello packet that is sent out at configurable intervals to exchange information among bridges in the network.                                                                                                                                                                                                                                                                                                         |
| <b>bypass mode</b>     | Mode that lets packets continue to flow through the sensor even if the sensor fails. Bypass mode is only applicable to inline-paired interfaces.                                                                                                                                                                                                                                                                                                                        |

---

**C**

|                       |                                                                                                                                                                                                                                                                                                   |
|-----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>CA</b>             | certification authority. Entity that issues digital certificates (especially X.509 certificates) and vouches for the binding between the data items in a certificate. Sensors use self-signed certificates.                                                                                       |
| <b>CA certificate</b> | Certificate for one CA issued by another CA.                                                                                                                                                                                                                                                      |
| <b>CEF</b>            | Cisco Express Forwarding. CEF is advanced, Layer 3 IP switching technology. CEF optimizes network performance and scalability for networks with large and dynamic traffic patterns, such as the Internet, on networks characterized by intensive Web-based applications, or interactive sessions. |

|                                      |                                                                                                                                                                                                                                                                                                                             |
|--------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>certificate</b>                   | Digital representation of user or device attributes, including a public key, that is signed with an authoritative private key.                                                                                                                                                                                              |
| <b>cidDump</b>                       | A script that captures a large amount of information including the IPS processes list, log files, OS information, directory listings, package information, and configuration files.                                                                                                                                         |
| <b>CIDEE</b>                         | Cisco Intrusion Detection Event Exchange. Specifies the extensions to SDEE that are used by Cisco IPS systems. The CIDEE standard specifies all possible extensions that may be supported by Cisco IPS systems.                                                                                                             |
| <b>CIDS header</b>                   | The header that is attached to each packet in the IPS system. It contains packet classification, packet length, checksum results, timestamp, and the receive interface.                                                                                                                                                     |
| <b>cipher key</b>                    | The secret binary data used to convert between clear text and cipher text. When the same cipher key is used for both encryption and decryption, it is called symmetric. When it is used for either encryption or decryption (but not both), it is called asymmetric.                                                        |
| <b>Cisco IOS</b>                     | Cisco system software that provides common functionality, scalability, and security for all products under the CiscoFusion architecture. Cisco IOS allows centralized, integrated, and automated installation and management of internetworks while supporting a wide variety of protocols, media, services, and platforms. |
| <b>CLI</b>                           | command-line interface. A shell provided with the sensor used for configuring and controlling the sensor applications.                                                                                                                                                                                                      |
| <b>CollaborationApp</b>              | A component of the IPS. Shares information with other devices through a global correlation database to improve the combined efficacy of all the devices.                                                                                                                                                                    |
| <b>command and control interface</b> | The interface on the sensor that communicates with the IPS manager and other network devices. This interface has an assigned IP address.                                                                                                                                                                                    |
| <b>community</b>                     | In SNMP, a logical group of managed devices and NMSs in the same administrative domain.                                                                                                                                                                                                                                     |
| <b>composite attack</b>              | Spans multiple packets in a single session. Examples include most conversation attacks such as FTP, Telnet, and most Regex-based attacks.                                                                                                                                                                                   |
| <b>connection block</b>              | ARC blocks traffic from a given source IP address to a given destination IP address and destination port.                                                                                                                                                                                                                   |
| <b>console</b>                       | A terminal or laptop computer used to monitor and control the sensor.                                                                                                                                                                                                                                                       |
| <b>console port</b>                  | An RJ45 or DB9 serial port on the sensor that is used to connect to a console device.                                                                                                                                                                                                                                       |
| <b>control interface</b>             | When ARC opens a Telnet or SSH session with a network device, it uses one of the routing interfaces of the device as the remote IP address. This is the control interface.                                                                                                                                                  |
| <b>control transaction</b>           | CT. An IPS message containing a command addressed to a specific application instance. Control transactions can be sent between a management application and an IPS sensor, or between applications on the same IPS sensor. Example control transactions include <i>start</i> , <i>stop</i> , <i>getConfig</i> .             |
| <b>Control Transaction Server</b>    | A component of the IPS. Accepts control transactions from a remote client, initiates a local control transaction, and returns the response to the remote client.                                                                                                                                                            |
| <b>Control Transaction Source</b>    | A component of the IPS. Waits for control transactions directed to remote applications, forwards the control transactions to the remote node, and returns the response to the initiator.                                                                                                                                    |

|                                 |                                                                                                                                                                                                                                                                                                    |
|---------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>cookie</b>                   | A piece of information sent by a web server to a web browser that the browser is expected to save and send back to the web server whenever the browser makes additional requests of the web server.                                                                                                |
| <b>CSA MC</b>                   | Cisco Security Agent Management Center. CSA MC receives host posture information from the CSA agents it manages. It also maintains a watch list of IP addresses that it has determined should be quarantined from the network.                                                                     |
| <b>CSM</b>                      | Cisco Security Manager, the provisioning component of the Cisco Self-Defending Networks solution. CS-Manager is fully integrated with CS-MARS.                                                                                                                                                     |
| <b>CS-MARS</b>                  | Cisco Security Monitoring, Analysis and Reporting System. The monitoring component of the Cisco Self-Defending Networks solution. CS-MARS is fully integrated with CS-Manager                                                                                                                      |
| <b>cut-through architecture</b> | Cut-through architecture is one method of design for packet-switching systems. When a packet arrives at a switch, the switch starts forwarding the packet almost immediately, reading only the first few bytes in the packet to learn the destination address. This technique improves performance |
| <b>CVE</b>                      | Common Vulnerabilities and Exposures. A list of standardized names for vulnerabilities and other information security exposures maintained at <a href="http://cve.mitre.org/">http://cve.mitre.org/</a> .                                                                                          |

---

**D**

|                               |                                                                                                                                                                                                                                                                                                                                                                                                       |
|-------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>darknets</b>               | A virtual private network where users connect only to people they trust. In its most general meaning, a darknet can be any type of closed, private group of people communicating, but the name is most often used specifically for file-sharing networks. Darknet can be used to refer collectively to all covert communication networks.                                                             |
| <b>Database Processor</b>     | A processor in the IPS. Maintains the signature state and flow databases.                                                                                                                                                                                                                                                                                                                             |
| <b>datagram</b>               | Logical grouping of information sent as a network layer unit over a transmission medium without prior establishment of a virtual circuit. IP datagrams are the primary information units in the Internet. The terms cell, frame, message, packet, and segment also are used to describe logical information groupings at various layers of the OSI reference model and in various technology circles. |
| <b>DCE</b>                    | data circuit-terminating equipment (ITU-T expansion). Devices and connections of a communications network that comprise the network end of the user-to-network interface. The DCE provides a physical connection to the network, forwards traffic, and provides a clocking signal used to synchronize data transmission between DCE and DTE devices. Modems and interface cards are examples of DCE.  |
| <b>DCOM</b>                   | Distributed Component Object Model. Protocol that enables software components to communicate directly over a network. Developed by Microsoft and previously called Network OLE, DCOM is designed for use across multiple network transports, including such Internet protocols as HTTP.                                                                                                               |
| <b>DDoS</b>                   | Distributed Denial of Service. An attack in which a multitude of compromised systems attack a single target, thereby causing denial of service for users of the targeted system. The flood of incoming messages to the target system essentially forces it to shut down, thereby denying service to the system to legitimate users.                                                                   |
| <b>Deny Filters Processor</b> | A processor in the IPS. Handles the deny attacker functions. It maintains a list of denied source IP addresses.                                                                                                                                                                                                                                                                                       |



|                            |                                                                                                                                                                                                                                                                                     |
|----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>DES</b>                 | Data Encryption Standard. A strong encryption method where the strength lies in a 56-bit key rather than an algorithm.                                                                                                                                                              |
| <b>destination address</b> | Address of a network device that is receiving data.                                                                                                                                                                                                                                 |
| <b>DIMM</b>                | Dual In-line Memory Modules.                                                                                                                                                                                                                                                        |
| <b>DMZ</b>                 | demilitarized zone. A separate network located in the neutral zone between a private (inside) network and a public (outside) network.                                                                                                                                               |
| <b>DNS</b>                 | Domain Name System. An Internet-wide hostname to IP address mapping. DNS enables you to convert human-readable names into the IP addresses needed for network packets.                                                                                                              |
| <b>DoS</b>                 | Denial of Service. An attack whose goal is just to disrupt the operation of a specific system or network.                                                                                                                                                                           |
| <b>DRAM</b>                | dynamic random-access memory. RAM that stores information in capacitors that must be refreshed periodically. Delays can occur because DRAMs are inaccessible to the processor when refreshing their contents. However, DRAMs are less complex and have greater capacity than SRAMs. |
| <b>DTE</b>                 | Data Terminal Equipment. Refers to the role of a device on an RS-232C connection. A DTE writes data to the transmit line and reads data from the receive line.                                                                                                                      |
| <b>DTP</b>                 | Dynamic Trunking Protocol. A Cisco proprietary protocol in the VLAN group used for negotiating trunking on a link between two devices and for negotiating the type of trunking encapsulation (ISL or 802.1q) to be used.                                                            |

---

**E**

|                           |                                                                                                                                                                                                                                                                           |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>ECLB</b>               | Ether Channel Load Balancing. Lets a Catalyst switch split traffic flows over different physical paths.                                                                                                                                                                   |
| <b>egress</b>             | Traffic leaving the network.                                                                                                                                                                                                                                              |
| <b>encryption</b>         | Application of a specific algorithm to data to alter the appearance of the data making it incomprehensible to those who are not authorized to see the information.                                                                                                        |
| <b>engine</b>             | A component of the sensor designed to support many signatures in a certain category. Each engine has parameters that can be used to create signatures or tune existing signatures.                                                                                        |
| <b>enterprise network</b> | Large and diverse network connecting most major points in a company or other organization. Differs from a WAN in that it is privately owned and maintained.                                                                                                               |
| <b>escaped expression</b> | Used in regular expression. A character can be represented as its hexadecimal value, for example, \x61 equals 'a,' so \x61 is an escaped expression representing the character 'a.'                                                                                       |
| <b>ESD</b>                | electrostatic discharge. Electrostatic discharge is the rapid movement of a charge from one object to another object, which produces several thousand volts of electrical charge that can cause severe damage to electronic components or entire circuit card assemblies. |
| <b>event</b>              | An IPS message that contains an alert, a block request, a status message, or an error message.                                                                                                                                                                            |
| <b>Event Store</b>        | One of the components of the IPS. A fixed-size, indexed store (30 MB) used to store IPS events.                                                                                                                                                                           |
| <b>evldsAlert</b>         | The XML entity written to the Event Store that represents an alert.                                                                                                                                                                                                       |

---

**F**

|                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|--------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>fail closed</b>                   | Blocks traffic on the device after a hardware failure.                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>fail open</b>                     | Lets traffic pass through the device after a hardware failure.                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>false negative</b>                | A signature is not fired when offending traffic is detected.                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>false positive</b>                | Normal traffic or a benign action causes a signature to fire.                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Fast Ethernet</b>                 | Any of a number of 100-Mbps Ethernet specifications. Fast Ethernet offers a speed increase 10 times that of the 10BaseT Ethernet specification while preserving such qualities as frame format, MAC mechanisms, and MTU. Such similarities allow the use of existing 10BaseT applications and network management tools on Fast Ethernet networks. Based on an extension to the IEEE 802.3 specification.                                                                              |
| <b>Fast flux</b>                     | Fast flux is a DNS technique used by Botnets to hide phishing and malware delivery sites behind an ever-changing network of compromised hosts acting as proxies. It can also refer to the combination of peer-to-peer networking, distributed command and control, web-based load balancing and proxy redirection used to make malware networks more resistant to discovery and counter-measures. The Storm Worm is one of the recent malware variants to make use of this technique. |
| <b>firewall</b>                      | Router or access server, or several routers or access servers, designated as a buffer between any connected public networks and a private network. A firewall router uses access lists and other methods to ensure the security of the private network.                                                                                                                                                                                                                               |
| <b>Flood engine</b>                  | Detects ICMP and UDP floods directed at hosts and networks.                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>flooding</b>                      | Traffic passing technique used by switches and bridges in which traffic received on an interface is sent out all the interfaces of that device except the interface on which the information was received originally.                                                                                                                                                                                                                                                                 |
| <b>forwarding</b>                    | Process of sending a frame toward its ultimate destination by way of an internetworking device.                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>fragment</b>                      | Piece of a larger packet that has been broken down to smaller units.                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>fragmentation</b>                 | Process of breaking a packet into smaller units when transmitting over a network medium that cannot support the original size of the packet.                                                                                                                                                                                                                                                                                                                                          |
| <b>Fragment Reassembly Processor</b> | A processor in the IPS. Reassembles fragmented IP datagrams. It is also responsible for normalization of IP fragments when the sensor is in inline mode.                                                                                                                                                                                                                                                                                                                              |
| <b>FTP</b>                           | File Transfer Protocol. Application protocol, part of the TCP/IP protocol stack, used for transferring files between network nodes. FTP is defined in RFC 959.                                                                                                                                                                                                                                                                                                                        |
| <b>FTP server</b>                    | File Transfer Protocol server. A server that uses the FTP protocol for transferring files between network nodes.                                                                                                                                                                                                                                                                                                                                                                      |
| <b>full duplex</b>                   | Capability for simultaneous data transmission between a sending station and a receiving station.                                                                                                                                                                                                                                                                                                                                                                                      |

|             |                                                                                                                                                                                                                                                                                                    |
|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>FQDN</b> | Fully Qualified Domain Name. A domain name that specifies its exact location in the tree hierarchy of the DNS. It specifies all domain levels, including the top-level domain, relative to the root domain. A fully qualified domain name is distinguished by this absoluteness in the name space. |
| <b>FWSM</b> | Firewall Security Module. A module that can be installed in a Catalyst 6500 series switch. It uses the <b>shun</b> command to block. You can configure the FWSM in either single mode or multi-mode.                                                                                               |

---

## G

|                                    |                                                                                                                                                                                                                                                                                                               |
|------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>GBIC</b>                        | GigaBit Interface Converter. Often refers to a fiber optic transceiver that adapts optical cabling to fiber interfaces. Fiber-ready switches and NICs generally provide GBIC and/or SFP slots. For more information, refer to the <a href="#">Catalyst Switch Cable, Connector, and AC Power Cord Guide</a> . |
| <b>Gigabit Ethernet</b>            | Standard for a high-speed Ethernet, approved by the IEEE (Institute of Electrical and Electronics Engineers) 802.3z standards committee in 1996.                                                                                                                                                              |
| <b>global correlation</b>          | The IPS sensor shares information with other devices through a global correlation database to improve the combined efficacy of all devices.                                                                                                                                                                   |
| <b>global correlation client</b>   | The software component of CollaborationApp that obtains and installs updates to the local global correlation databases.                                                                                                                                                                                       |
| <b>global correlation database</b> | The collective information obtained from and shared with collaborative devices such as IPS sensors.                                                                                                                                                                                                           |
| <b>GMT</b>                         | Greenwich Mean Time. Time zone at zero degrees longitude. Now called Coordinated Universal Time (UTC).                                                                                                                                                                                                        |
| <b>GRUB</b>                        | Grand Unified Bootloader. Boot loader is the first software program that runs when a computer starts. It is responsible for loading and transferring control to the operating system kernel software. The kernel, in turn, initializes the rest of the operating system.                                      |

---

## H

|                    |                                                                                                                                                                                                                                       |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>H.225.0</b>     | An ITU standard that governs H.225.0 session establishment and packetization. H.225.0 actually describes several different protocols: RAS, use of Q.931, and use of RTP.                                                              |
| <b>H.245</b>       | An ITU standard that governs H.245 endpoint control.                                                                                                                                                                                  |
| <b>H.323</b>       | Allows dissimilar communication devices to communicate with each other by using a standardized communication protocol. H.323 defines a common set of CODECs, call setup and negotiating procedures, and basic data transport methods. |
| <b>half duplex</b> | Capability for data transmission in only one direction at a time between a sending station and a receiving station. BSC is an example of a half-duplex protocol.                                                                      |
| <b>handshake</b>   | Sequence of messages exchanged between two or more network devices to ensure transmission synchronization.                                                                                                                            |

|                        |                                                                                                                                                                                                                                                                                                                               |
|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>hardware bypass</b> | A specialized interface card that pairs physical interfaces so that when a software error is detected, a bypass mechanism is engaged that directly connects the physical interfaces and allows traffic to flow through the pair. Hardware bypass passes traffic at the network interface, does not pass it to the IPS system. |
| <b>host block</b>      | ARC blocks all traffic from a given IP address.                                                                                                                                                                                                                                                                               |
| <b>HTTP</b>            | Hypertext Transfer Protocol. The stateless request/response media transfer protocol used in the IPS architecture for remote data exchange.                                                                                                                                                                                    |
| <b>HTTPS</b>           | An extension to the standard HTTP protocol that provides confidentiality by encrypting the traffic from the website. By default this protocol uses TCP port 443.                                                                                                                                                              |

---

**I**

|                         |                                                                                                                                                                                                                                                                   |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>ICMP</b>             | Internet Control Message Protocol. Network layer Internet protocol that reports errors and provides other information relevant to IP packet processing. Documented in RFC 792.                                                                                    |
| <b>ICMP flood</b>       | Denial of Service attack that sends a host more ICMP echo request (“ping”) packets than the protocol implementation can handle.                                                                                                                                   |
| <b>IDAPI</b>            | Intrusion Detection Application Programming Interface. Provides a simple interface between IPS architecture applications. IDAPI reads and writes event data and provides a mechanism for control transactions.                                                    |
| <b>IDCONF</b>           | Intrusion Detection Configuration. A data format standard that defines operational messages that are used to configure intrusion detection and prevention systems.                                                                                                |
| <b>IDENT</b>            | Ident protocol, specified in RFC 1413, is an Internet protocol that helps identify the user of a particular TCP connection.                                                                                                                                       |
| <b>IDIOM</b>            | Intrusion Detection Interchange and Operations Messages. A data format standard that defines the event messages that are reported by intrusion detection systems and the operational messages that are used to configure and control intrusion detection systems. |
| <b>IDM</b>              | IPS Device Manager. A web-based application that lets you configure and manage your sensor. The web server for IDM resides on the sensor. You can access it through Internet Explorer or Firefox web browsers.                                                    |
| <b>IDMEF</b>            | Intrusion Detection Message Exchange Format. The IETF Intrusion Detection Working Group draft standard.                                                                                                                                                           |
| <b>IDS MC</b>           | Management Center for IDS Sensors. A web-based IDS manager that can manage configurations for up to 300 sensors.                                                                                                                                                  |
| <b>IME</b>              | IPS Manager Express. A network management application that provides system health monitoring, events monitoring, reporting, and configuration for up to ten sensors.                                                                                              |
| <b>inline mode</b>      | All packets entering or leaving the network must pass through the sensor.                                                                                                                                                                                         |
| <b>inline interface</b> | A pair of physical interfaces configured so that the sensor forwards all traffic received on one interface out to the other interface in the pair.                                                                                                                |

|                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>InterfaceApp</b>               | A component of the IPS. Handles bypass and physical settings and defines paired interfaces. Physical settings are speed, duplex, and administrative state.                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>intrusion detection system</b> | IDS. A security service that monitors and analyzes system events to find and provide real-time or near real-time warning of attempts to access system resources in an unauthorized manner.                                                                                                                                                                                                                                                                                                                                                  |
| <b>IP address</b>                 | 32-bit address assigned to hosts using TCP/IP. An IP address belongs to one of five classes (A, B, C, D, or E) and is written as 4 octets separated by periods (dotted decimal format). Each address consists of a network number, an optional subnetwork number, and a host number. The network and subnetwork numbers together are used for routing, and the host number is used to address an individual host within the network or subnetwork. A subnet mask is used to extract network and subnetwork information from the IP address. |
| <b>IPS</b>                        | Intrusion Prevention System. A system that alerts the user to the presence of an intrusion on the network through network traffic analysis techniques.                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>IPS data or message</b>        | Describes the messages transferred over the command and control interface between IPS applications.                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>iplog</b>                      | A log of the binary packets to and from a designated address. Iplogs are created when the log Event Action is selected for a signature. Iplogs are stored in a libpcap format, which can be read by WireShark and TCPDUMP.                                                                                                                                                                                                                                                                                                                  |
| <b>IP spoofing</b>                | IP spoofing attack occurs when an attacker outside your network pretends to be a trusted user either by using an IP address that is within the range of IP addresses for your network or by using an authorized external IP address that you trust and to which you want to provide access to specified resources on your network. Should an attacker get access to your IPSec security parameters, that attacker can masquerade as the remote user authorized to connect to the corporate network.                                         |
| <b>IPv6</b>                       | IP version 6. Replacement for the current version of IP (version 4). IPv6 includes support for flow ID in the packet header, which can be used to identify flows. Formerly called IPng (next generation).                                                                                                                                                                                                                                                                                                                                   |
| <b>ISL</b>                        | Inter-Switch Link. Cisco-proprietary protocol that maintains VLAN information as traffic flows between switches and routers.                                                                                                                                                                                                                                                                                                                                                                                                                |

---

**J**

|                       |                                                                                                                                                                                                                                                                                                                                            |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Java Web Start</b> | Java Web Start provides a platform-independent, secure, and robust deployment technology. It enables developers to deploy full-featured applications to you by making the applications available on a standard web server. With any web browser, you can launch the applications and be confident you always have the most-recent version. |
| <b>JNLP</b>           | Java Network Launching Protocol. Defined in an XML file format specifying how Java Web Start applications are launched. JNLP consists of a set of rules defining how exactly the launching mechanism should be implemented.                                                                                                                |

---

**K**

|                       |                                                                                                        |
|-----------------------|--------------------------------------------------------------------------------------------------------|
| <b>KB</b>             | Knowledge Base. The sets of thresholds learned by Anomaly Detection and used for worm virus detection. |
| <b>Knowledge Base</b> | See KB.                                                                                                |

---

**L**

|                          |                                                                                                                                                                                                                               |
|--------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>LACP</b>              | Link Aggregation Control Protocol. LACP aids in the automatic creation of EtherChannel links by exchanging LACP packets between LAN ports. This protocol is defined in IEEE 802.3ad.                                          |
| <b>LAN</b>               | Local Area Network. Refers to the Layer 2 network domain local to a given host. Packets exchanged between two hosts on the same LAN do not require Layer 3 routing.                                                           |
| <b>Layer 2 Processor</b> | A processor in the IPS. Processes layer 2-related events. It also identifies malformed packets and removes them from the processing path.                                                                                     |
| <b>Logger</b>            | A component of the IPS. Writes all the log messages of the application to the log file and the error messages of the application to the Event Store.                                                                          |
| <b>logging</b>           | Gathers actions that have occurred in a log file. Logging of security information is performed on two levels: logging of events (such as IPS commands, errors, and alerts), and logging of individual IP session information. |
| <b>LOKI</b>              | Remote access, back door Trojan, ICMP tunneling software. When the computer is infected, the malicious code creates an ICMP tunnel that can be used to send small payload ICMP replies.                                       |

---

**M**

|                                    |                                                                                                                                                                                                                                                                  |
|------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>MainApp</b>                     | The main application in the IPS. The first application to start on the sensor after the operating system has booted. Reads the configuration and starts applications, handles starting and stopping of applications and node reboots, handles software upgrades. |
| <b>maintenance partition</b>       | The bootable disk partition on IDSM2, from which an IPS image can be installed on the application partition. No IPS capability is available while the IDSM2 is booted into the maintenance partition.                                                            |
| <b>maintenance partition image</b> | The bootable software image installed on the maintenance partition on an IDSM2. You can install the maintenance partition image only while booted into the application partition.                                                                                |
| <b>major update</b>                | A base version that contains major new functionality or a major architectural change in the product.                                                                                                                                                             |
| <b>Malware</b>                     | Malicious software that is installed on an unknowing host.                                                                                                                                                                                                       |
| <b>manufacturing image</b>         | Full IPS system image used by manufacturing to image sensors.                                                                                                                                                                                                    |
| <b>master blocking sensor</b>      | A remote sensor that controls one or more devices. Blocking forwarding sensors send blocking requests to the master blocking sensor and the master blocking sensor executes the blocking requests.                                                               |

|                             |                                                                                                                                                                                                                                                                                                                                                                                                                               |
|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>MD5</b>                  | Message Digest 5. A one-way hashing algorithm that produces a 128-bit hash. Both MD5 and Secure Hash Algorithm (SHA) are variations on MD4 and strengthen the security of the MD4 hashing algorithm. Cisco uses hashes for authentication within the IPSec framework. Also used for message authentication in SNMP v.2. MD5 verifies the integrity of the communication, authenticates the origin, and checks for timeliness. |
| <b>Meta engine</b>          | Defines events that occur in a related manner within a sliding time interval. This engine processes events rather than packets.                                                                                                                                                                                                                                                                                               |
| <b>MIB</b>                  | Management Information Base. Database of network management information that is used and maintained by a network management protocol, such as SNMP or CMIP. The value of a MIB object can be changed or retrieved using SNMP or CMIP commands, usually through a GUI network management system. MIB objects are organized in a tree structure that includes public (standard) and private (proprietary) branches.             |
| <b>MIME</b>                 | Multipurpose Internet Mail Extension. Standard for transmitting nontext data (or data that cannot be represented in plain ASCII code) in Internet mail, such as binary, foreign language text (such as Russian or Chinese), audio, or video data. MIME is defined in RFC 2045.                                                                                                                                                |
| <b>minor update</b>         | A minor version that contains minor enhancements to the product line. Minor updates are incremental to the major version, and are also base versions for service packs.                                                                                                                                                                                                                                                       |
| <b>module</b>               | A removable card in a switch, router, or security appliance chassis. The ASA 5500 AIP SSM and the ASA 5585-X IPS SSP are IPS modules.                                                                                                                                                                                                                                                                                         |
| <b>monitoring interface</b> | See sensing interface.                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>MPF</b>                  | Modular Policy Framework. A means of configuring security appliance features in a manner similar to Cisco IOS software Modular QoS CLI.                                                                                                                                                                                                                                                                                       |
| <b>MSFC, MSFC2</b>          | Multilayer Switch Feature Card. An optional card on a Catalyst 6000 supervisor engine that performs L3 routing for the switch.                                                                                                                                                                                                                                                                                                |
| <b>MSRPC</b>                | Microsoft Remote Procedure Call. MSRPC is the Microsoft implementation of the DCE RPC mechanism. Microsoft added support for Unicode strings, implicit handles, inheritance of interfaces (which are extensively used in DCOM), and complex calculations in the variable-length string and structure paradigms already present in DCE/RPC.                                                                                    |
| <b>MySDN</b>                | My Self-Defending Network. A part of the signature definition section of IDM and IME. It provides detailed information about signatures.                                                                                                                                                                                                                                                                                      |

---

## N

|               |                                                                                                                                                        |
|---------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>NAC</b>    | Network Access Controller. See ARC.                                                                                                                    |
| <b>NAS-ID</b> | Network Access ID. An identifier that clients send to servers to communicate the type of service they are attempting to authenticate.                  |
| <b>NAT</b>    | Native Address Translation. A network device can present an IP address to the outside networks that is different from the actual IP address of a host. |

|                                     |                                                                                                                                                                                                                                                                                                                    |
|-------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>NBD</b>                          | Next Business Day. The arrival of replacement hardware according to Cisco service contracts.                                                                                                                                                                                                                       |
| <b>Neighborhood Discovery</b>       | Protocol for IPv6. IPv6 nodes on the same link use Neighbor Discovery to discover each other's presence, to determine each other's link-layer addresses, to find routers, and to maintain reachability information about the paths to active neighbors.                                                            |
| <b>Network Access ID</b>            | See NAS-ID.                                                                                                                                                                                                                                                                                                        |
| <b>network device</b>               | A device that controls IP traffic on a network and can block an attacking host. An example of a network device is a Cisco router or PIX Firewall.                                                                                                                                                                  |
| <b>network participation</b>        | Networks contributing learned information to the global correlation database.                                                                                                                                                                                                                                      |
| <b>network participation client</b> | The software component of CollaborationApp that sends data to the SensorBase Network.                                                                                                                                                                                                                              |
| <b>never block address</b>          | Hosts and networks you have identified that should never be blocked.                                                                                                                                                                                                                                               |
| <b>never shun address</b>           | See never block address.                                                                                                                                                                                                                                                                                           |
| <b>NIC</b>                          | Network Interface Card. Board that provides network communication capabilities to and from a computer system.                                                                                                                                                                                                      |
| <b>NMS</b>                          | network management system. System responsible for managing at least part of a network. An NMS is generally a reasonably powerful and well-equipped computer, such as an engineering workstation. NMSs communicate with agents to help keep track of network statistics and resources.                              |
| <b>node</b>                         | A physical communicating element on the command and control network. For example, an appliance or a router.                                                                                                                                                                                                        |
| <b>Normalizer engine</b>            | Configures how the IP and TCP normalizer functions and provides configuration for signature events related to the IP and TCP normalizer.                                                                                                                                                                           |
| <b>NOS</b>                          | network operating system. Generic term used to refer to distributed file systems. Examples include LAN Manager, NetWare, NFS, and VINES.                                                                                                                                                                           |
| <b>NotificationApp</b>              | A component of the IPS. Sends SNMP traps when triggered by alert, status, and error events. NotificationApp uses the public domain SNMP agent. SNMP GETs provide information about the general health of the sensor.                                                                                               |
| <b>NTP</b>                          | Network Timing Protocol. Protocol built on top of TCP that ensures accurate local time-keeping with reference to radio and atomic clocks located on the Internet. This protocol is capable of synchronizing distributed clocks within milliseconds over long time periods.                                         |
| <b>NTP server</b>                   | Network Timing Protocol server. A server that uses NTP. NTP is a protocol built on top of TCP that ensures accurate local time-keeping with reference to radio and atomic clocks located on the Internet. This protocol is capable of synchronizing distributed clocks within milliseconds over long time periods. |
| <b>NVRAM</b>                        | Non-Volatile Read/Write Memory. RAM that retains its contents when a unit is powered off.                                                                                                                                                                                                                          |



---

**O**

|            |                                                                                                                                                                                                                |
|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>OIR</b> | online insertion and removal. Feature that permits you to add, replace, or remove cards without interrupting the system power, entering console commands, or causing other software or interfaces to shutdown. |
| <b>OPS</b> | Outbreak Prevention Service.                                                                                                                                                                                   |

---

**P**

|                                  |                                                                                                                                                                                                                                                                                                                                                                             |
|----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>P2P</b>                       | Peer-to-Peer. P2P networks use nodes that can simultaneously function as both client and server for the purpose of file sharing.                                                                                                                                                                                                                                            |
| <b>packet</b>                    | Logical grouping of information that includes a header containing control information and (usually) user data. Packets most often are used to refer to network layer units of data. The terms datagram, frame, message, and segment also are used to describe logical information groupings at various layers of the OSI reference model and in various technology circles. |
| <b>PAgP</b>                      | Port Aggregation Control Protocol. PAgP aids in the automatic creation of EtherChannel links by exchanging PAgP packets between LAN ports. It is a Cisco-proprietary protocol.                                                                                                                                                                                              |
| <b>PAM</b>                       | Software module that provides AAA functionality to applications.                                                                                                                                                                                                                                                                                                            |
| <b>PAP</b>                       | Password Authentication Protocol. Most commonly used RADIUS messaging protocol.                                                                                                                                                                                                                                                                                             |
| <b>passive fingerprinting</b>    | Act of determining the OS or services available on a system from passive observation of network interactions.                                                                                                                                                                                                                                                               |
| <b>Passive OS Fingerprinting</b> | The sensor determines host operating systems by inspecting characteristics of the packets exchanged on the network.                                                                                                                                                                                                                                                         |
| <b>PASV Port Spoof</b>           | An attempt to open connections through a firewall to a protected FTP server to a non-FTP port. This happens when the firewall incorrectly interprets an FTP 227 <b>passive</b> command by opening an unauthorized connection.                                                                                                                                               |
| <b>PAT</b>                       | Port Address Translation. A more restricted translation scheme than NAT in which a single IP address and different ports are used to represent the hosts of a network.                                                                                                                                                                                                      |
| <b>patch release</b>             | Release that addresses defects identified in the update (minor, major, or service pack) binaries after a software release (service pack, minor, or major update) has been released.                                                                                                                                                                                         |
| <b>PAWS</b>                      | Protection Against Wrapped Sequence. Protection against wrapped sequence numbers in high performance TCP networks. See <a href="#">RFC 1323</a> .                                                                                                                                                                                                                           |
| <b>PCI</b>                       | Peripheral Component Interface. The most common peripheral expansion bus used on Intel-based computers.                                                                                                                                                                                                                                                                     |
| <b>PDU</b>                       | protocol data unit. OSI term for packet. See also BPDU and packet.                                                                                                                                                                                                                                                                                                          |
| <b>PEP</b>                       | Cisco Product Evolution Program. PEP is the UDI information that consists of the PID, the VID, and the SN of your sensor. PEP provides hardware version and serial number visibility through electronic query, product labels, and shipping items.                                                                                                                          |

|                                         |                                                                                                                                                                                                                 |
|-----------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>PER</b>                              | packed encoding rules. Instead of using a generic style of encoding that encodes all types in a uniform way, PER specializes the encoding based on the data type to generate much more compact representations. |
| <b>PFC</b>                              | Policy Feature Card. An optional card on a Catalyst 6000 supervisor engine that supports VACL packet filtering.                                                                                                 |
| <b>PID</b>                              | Product Identifier. The orderable product identifier that is one of the three parts of the UDI. The UDI is part of the PEP policy.                                                                              |
| <b>ping</b>                             | packet internet groper. Often used in IP networks to test the reachability of a network device. It works by sending ICMP echo request packets to the target host and listening for echo response replies.       |
| <b>PIX Firewall</b>                     | Private Internet Exchange Firewall. A Cisco network security device that can be programmed to block/enable addresses and ports between networks.                                                                |
| <b>PKI</b>                              | Public Key Infrastructure. Authentication of HTTP clients using the clients X.509 certificates.                                                                                                                 |
| <b>Pluggable Authentication Modules</b> | See PAM.                                                                                                                                                                                                        |
| <b>POST</b>                             | Power-On Self Test. Set of hardware diagnostics that runs on a hardware device when that device is powered up.                                                                                                  |
| <b>Post-ACL</b>                         | Designates an ACL from which ARC should read the ACL entries, and where it places entries after all deny entries for the addresses being blocked.                                                               |
| <b>Pre-ACL</b>                          | Designates an ACL from which ARC should read the ACL entries, and where it places entries before any deny entries for the addresses being blocked.                                                              |
| <b>promiscuous delta</b>                | PD. A weight in the range of 0 to 30 configured per signature. This weight can be subtracted from the overall risk rating in promiscuous mode.                                                                  |
| <b>promiscuous mode</b>                 | A passive interface for monitoring packets of the network segment. The sensing interface does not have an IP address assigned to it and is therefore invisible to attackers.                                    |

---

## Q

|              |                                                                                                                                       |
|--------------|---------------------------------------------------------------------------------------------------------------------------------------|
| <b>Q.931</b> | ITU-T specification for signaling to establish, maintain, and clear ISDN network connections.                                         |
| <b>QoS</b>   | quality of service. Measure of performance for a transmission system that reflects its transmission quality and service availability. |

---

## R

|                      |                                                                                                                                                                 |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>rack mounting</b> | Refers to mounting a sensor in an equipment rack.                                                                                                               |
| <b>RADIUS</b>        | Remote Authentication Dial In User Service. A networking protocol that provides centralized AAA functionality for systems to connect and use a network service. |

|                                                   |                                                                                                                                                                                                                                                                                                                                                                                     |
|---------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>RAM</b>                                        | random-access memory. Volatile memory that can be read and written by a microprocessor.                                                                                                                                                                                                                                                                                             |
| <b>RAS</b>                                        | Registration, Admission, and Status Protocol. Protocol that is used between endpoints and the gatekeeper to perform management functions. RAS signaling function performs registration, admissions, bandwidth changes, status, and disengage procedures between the VoIP gateway and the gatekeeper.                                                                                |
| <b>RBCP</b>                                       | Router Blade Control Protocol. RBCP is based on SCP, but modified specifically for the router application. It is designed to run over Ethernet interfaces and uses 802.2 SNAP encapsulation for messages.                                                                                                                                                                           |
| <b>reassembly</b>                                 | The putting back together of an IP datagram at the destination after it has been fragmented either at the source or at an intermediate node.                                                                                                                                                                                                                                        |
| <b>recovery package</b>                           | An IPS package file that includes the full application image and installer used for recovery on sensors.                                                                                                                                                                                                                                                                            |
| <b>regex</b>                                      | See regular expression.                                                                                                                                                                                                                                                                                                                                                             |
| <b>regular expression</b>                         | A mechanism by which you can define how to search for a specified sequence of characters in a data stream or file. Regular expressions are a powerful and flexible notation almost like a mini-programming language that allow you to describe text. In the context of pattern matching, regular expressions allow a succinct description of any arbitrary pattern.                 |
| <b>Remote Authentication Dial In User Service</b> | See RADIUS.                                                                                                                                                                                                                                                                                                                                                                         |
| <b>repackage release</b>                          | A release that addresses defects in the packaging or the installer.                                                                                                                                                                                                                                                                                                                 |
| <b>reputation</b>                                 | Similar to human social interaction, reputation is an opinion toward a device on the Internet. It enables the installed base of IPS sensors in the field to collaborate using the existing network infrastructure. A network device with reputation is most probably malicious or infected.                                                                                         |
| <b>risk rating</b>                                | RR. A risk rating is a value between 0 and 100 that represents a numerical quantification of the risk associated with a particular event on the network. The risk of the attack accounts for the severity, fidelity, relevance, and asset value of the attack, but not any response or mitigation actions. This risk is higher when more damage could be inflicted on your network. |
| <b>RMA</b>                                        | Return Materials Authorization. The Cisco program for returning faulty hardware and obtaining a replacement.                                                                                                                                                                                                                                                                        |
| <b>ROMMON</b>                                     | Read-Only-Memory Monitor. ROMMON lets you TFTP system images onto the sensor for recovery purposes.                                                                                                                                                                                                                                                                                 |
| <b>round-trip time</b>                            | See RTT.                                                                                                                                                                                                                                                                                                                                                                            |
| <b>RPC</b>                                        | remote-procedure call. Technological foundation of client/server computing. RPCs are procedure calls that are built or specified by clients and are executed on servers, with the results returned over the network to the clients.                                                                                                                                                 |
| <b>RSM</b>                                        | Router Switch Module. A router module that is installed in a Catalyst 5000 switch. It functions exactly like a standalone router.                                                                                                                                                                                                                                                   |

|            |                                                                                                                                                                                                                                                                                                                                                                                                                     |
|------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>RTP</b> | Real-Time Transport Protocol. Commonly used with IP networks. RTP is designed to provide end-to-end network transport functions for applications transmitting real-time data, such as audio, video, or simulation data, over multicast or unicast network services. RTP provides such services as payload type identification, sequence numbering, timestamping, and delivery monitoring to real-time applications. |
| <b>RTT</b> | round-trip time. A measure of the time delay imposed by a network on a host from the sending of a packet until acknowledgment of the receipt.                                                                                                                                                                                                                                                                       |
| <b>RU</b>  | rack unit. A rack is measured in rack units. An RU is equal to 44 mm or 1.75 inches.                                                                                                                                                                                                                                                                                                                                |

---

**S**

|                              |                                                                                                                                                                                                                                                                                                                                                                                                                     |
|------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>SCP</b>                   | Switch Configuration Protocol. Cisco control protocol that runs directly over the Ethernet.                                                                                                                                                                                                                                                                                                                         |
| <b>SCEP</b>                  | Simple Certificate Enrollment Protocol. The Cisco Systems PKI communication protocol that leverages existing technology by using PKCS#7 and PKCS#10. SCEP is the evolution of the enrollment protocol.                                                                                                                                                                                                              |
| <b>SDEE</b>                  | Security Device Event Exchange. A product-independent standard for communicating security device events. It adds extensibility features that are needed for communicating events generated by various types of security devices.                                                                                                                                                                                    |
| <b>SDEE Server</b>           | Accepts requests for events from remote clients.                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Secure Shell Protocol</b> | Protocol that provides a secure remote connection to a router through a Transmission Control Protocol (TCP) application.                                                                                                                                                                                                                                                                                            |
| <b>security context</b>      | You can partition a single adaptive security appliance into multiple virtual devices, known as security contexts. Each context is an independent device, with its own security policy, interfaces, and administrators. Multiple contexts are similar to having multiple standalone devices. Many features are supported in multiple context mode, including routing tables, firewall features, IPS, and management. |
| <b>Security Monitor</b>      | Monitoring Center for Security. Provides event collection, viewing, and reporting capability for network devices. Used with the IDS MC.                                                                                                                                                                                                                                                                             |
| <b>sensing interface</b>     | The interface on the sensor that monitors the desired network segment. The sensing interface is in promiscuous mode; it has no IP address and is not visible on the monitored segment.                                                                                                                                                                                                                              |
| <b>sensor</b>                | The sensor is the intrusion detection engine. It analyzes network traffic searching for signs of unauthorized activity.                                                                                                                                                                                                                                                                                             |
| <b>SensorApp</b>             | A component of the IPS. Performs packet capture and analysis. SensorApp analyzes network traffic for malicious content. Packets flow through a pipeline of processors fed by a producer designed to collect packets from the network interfaces on the sensor. SensorApp is the standalone executable that runs Analysis Engine.                                                                                    |
| <b>Service engine</b>        | Deals with specific protocols, such as DNS, FTP, H255, HTTP, IDENT, MS RPC, MS SQL, NTP, P2P, RPC, SMB, SNMP, SSH, and TNS.                                                                                                                                                                                                                                                                                         |
| <b>service pack</b>          | Used for the release of defect fixes and for the support of new signature engines. Service packs contain all of the defect fixes since the last base version (minor or major) and any new defects fixes.                                                                                                                                                                                                            |

|                                         |                                                                                                                                                                                                                                                                                           |
|-----------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>session command</b>                  | Command used on routers and switches to provide either Telnet or console access to a module in the router or switch.                                                                                                                                                                      |
| <b>SFP</b>                              | Small Form-factor Pluggable. Often refers to a fiber optic transceiver that adapts optical cabling to fiber interfaces. See GBIC for more information.                                                                                                                                    |
| <b>shared secret</b>                    | A piece of data known only to the parties involved in a secure communication. The shared secret can be a password, a passphrase, a big number, or an array of randomly chosen bytes.                                                                                                      |
| <b>shun command</b>                     | Enables a dynamic response to an attacking host by preventing new connections and disallowing packets from any existing connection. It is used by ARC when blocking with a PIX Firewall.                                                                                                  |
| <b>Signature Analysis Processor</b>     | A processor in the IPS. Dispatches packets to the inspectors that are not stream-based and that are configured for interest in the packet in process.                                                                                                                                     |
| <b>signature</b>                        | A signature distills network information and compares it against a rule set that indicates typical intrusion activity.                                                                                                                                                                    |
| <b>signature engine</b>                 | A component of the sensor that supports many signatures in a certain category. An engine is composed of a parser and an inspector. Each engine has a set of legal parameters that have allowable ranges or sets of values.                                                                |
| <b>signature engine update</b>          | Executable file with its own versioning scheme that contains binary code to support new signature updates.                                                                                                                                                                                |
| <b>Signature Event Action Filter</b>    | Subtracts actions based on the signature event signature ID, addresses, and risk rating. The input to the Signature Event Action Filter is the signature event with actions possibly added by the Signature Event Action Override.                                                        |
| <b>Signature Event Action Handler</b>   | Performs the requested actions. The output from Signature Event Action Handler is the actions being performed and possibly an evIdsAlert written to the Event Store.                                                                                                                      |
| <b>Signature Event Action Override</b>  | Adds actions based on the risk rating value. Signature Event Action Override applies to all signatures that fall into the range of the configured risk rating threshold. Each Signature Event Action Override is independent and has a separate configuration value for each action type. |
| <b>Signature Event Action Processor</b> | Processes event actions. Event actions can be associated with an event risk rating threshold that must be surpassed for the actions to take place.                                                                                                                                        |
| <b>signature fidelity rating</b>        | SFR. A weight associated with how well a signature might perform in the absence of specific knowledge of the target. The signature fidelity rating is configured per signature and indicates how accurately the signature detects the event or condition it describes.                    |
| <b>signature update</b>                 | Executable file that contains a set of rules designed to recognize malicious network activities, such as worms, DDOS, viruses, and so forth. Signature updates are released independently, are dependent on a required signature engine version, and have their own versioning scheme.    |
| <b>Slave Dispatch Processor</b>         | A processor in the IPS. Process found on dual CPU systems.                                                                                                                                                                                                                                |
| <b>SMB</b>                              | Server Message Block. File-system protocol used in LAN manager and similar NOSs to package data and exchange information with other systems.                                                                                                                                              |
| <b>SMTP</b>                             | Simple Mail Transfer Protocol. Internet protocol providing e-mail services.                                                                                                                                                                                                               |

|                                    |                                                                                                                                                                                                                                                                                                                                                                                                                           |
|------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>SN</b>                          | Serial Number. Part of the UDI. The SN is the serial number of your Cisco product.                                                                                                                                                                                                                                                                                                                                        |
| <b>SNAP</b>                        | Subnetwork Access Protocol. Internet protocol that operates between a network entity in the subnetwork and a network entity in the end system. SNAP specifies a standard method of encapsulating IP datagrams and ARP messages on IEEE networks. The SNAP entity in the end system makes use of the services of the subnetwork and performs three key functions: data transfer, connection management, and QoS selection. |
| <b>sniffing interface</b>          | See sensing interface.                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>SNMP</b>                        | Simple Network Management Protocol. Network management protocol used almost exclusively in TCP/IP networks. SNMP provides a means to monitor and control network devices, and to manage configurations, statistics collection, performance, and security.                                                                                                                                                                 |
| <b>SNMP2</b>                       | SNMP Version 2. Version 2 of the network management protocol. SNMP2 supports centralized and distributed network management strategies, and includes improvements in the SMI, protocol operations, management architecture, and security.                                                                                                                                                                                 |
| <b>software bypass</b>             | Passes traffic through the IPS system without inspection.                                                                                                                                                                                                                                                                                                                                                                 |
| <b>source address</b>              | Address of a network device that is sending data.                                                                                                                                                                                                                                                                                                                                                                         |
| <b>SPAN</b>                        | Switched Port Analyzer. Feature of the Catalyst 5000 switch that extends the monitoring abilities of existing network analyzers into a switched Ethernet environment. SPAN mirrors the traffic at one switched segment onto a predefined SPAN port. A network analyzer attached to the SPAN port can monitor traffic from any other Catalyst switched port.                                                               |
| <b>spanning tree</b>               | Loop-free subset of a network topology.                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>SQL</b>                         | Structured Query Language. International standard language for defining and accessing relational databases.                                                                                                                                                                                                                                                                                                               |
| <b>SRAM</b>                        | Type of RAM that retains its contents for as long as power is supplied. SRAM does not require constant refreshing, like DRAM.                                                                                                                                                                                                                                                                                             |
| <b>SSH</b>                         | Secure Shell. A utility that uses strong authentication and secure communications to log in to another computer over a network.                                                                                                                                                                                                                                                                                           |
| <b>SSL</b>                         | Secure Socket Layer. Encryption technology for the Internet used to provide secure transactions, such as the transmission of credit card numbers for e-commerce.                                                                                                                                                                                                                                                          |
| <b>Stacheldraht</b>                | A DDoS tool that relies on the ICMP protocol.                                                                                                                                                                                                                                                                                                                                                                             |
| <b>State engine</b>                | Stateful searches of HTTP strings.                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Statistics Processor</b>        | A processor in the IPS. Keeps track of system statistics such as packet counts and packet arrival rates.                                                                                                                                                                                                                                                                                                                  |
| <b>Stream Reassembly Processor</b> | A processor in the IPS. Reorders TCP streams to ensure the arrival order of the packets at the various stream-based inspectors. It is also responsible for normalization of the TCP stream. The normalizer engine lets you enable or disable alert and deny actions.                                                                                                                                                      |
| <b>String engine</b>               | A signature engine that provides regular expression-based pattern inspection and alert functionality for multiple transport protocols, including TCP, UDP, and ICMP.                                                                                                                                                                                                                                                      |

|                         |                                                                                                                                                                                                                                               |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>subsignature</b>     | A more granular representation of a general signature. It typically further defines a broad scope signature.                                                                                                                                  |
| <b>surface mounting</b> | Refers to attaching rubber feet to the bottom of a sensor when it is installed on a flat surface. The rubber feet allow proper airflow around the sensor and they also absorb vibration so that the hard-disk drive is less impacted.         |
| <b>switch</b>           | Network device that filters, forwards, and floods frames based on the destination address of each frame. The switch operates at the data link layer of the OSI model.                                                                         |
| <b>SwitchApp</b>        | A component of the IPS. The IPS 4500 series sensors have a built in switch that provides external monitoring interfaces. The SwitchApp enables the InterfaceApp and sensor initialization scripts to communicate with and control the switch. |
| <b>SYN flood</b>        | Denial of Service attack that sends a host more TCP SYN packets (request to synchronize sequence numbers, used when opening a connection) than the protocol implementation can handle.                                                        |
| <b>system image</b>     | The full IPS application and recovery image used for reimaging an entire sensor.                                                                                                                                                              |

---

**T**

|                            |                                                                                                                                                                                                                                                                                                                                                |
|----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>TAC</b>                 | A Cisco Technical Assistance Center. There are four TACs worldwide.                                                                                                                                                                                                                                                                            |
| <b>TACACS+</b>             | Terminal Access Controller Access Control System Plus. Proprietary Cisco enhancement to Terminal Access Controller Access Control System (TACACS). Provides additional support for authentication, authorization, and accounting.                                                                                                              |
| <b>target value rating</b> | TVR. A weight associated with the perceived value of the target. Target value rating is a user-configurable value (zero, low, medium, high, or mission critical) that identifies the importance of a network asset (through its IP address).                                                                                                   |
| <b>TCP</b>                 | Transmission Control Protocol. Connection-oriented transport layer protocol that provides reliable full-duplex data transmission. TCP is part of the TCP/IP protocol stack.                                                                                                                                                                    |
| <b>TCPDUMP</b>             | The TCPDUMP utility is a free network protocol analyzer for UNIX and Windows. It lets you examine data from a live network or from a capture file on disk. You can use different options for viewing summary and detail information for each packet. For more information, see <a href="http://www.tcpdump.org/">http://www.tcpdump.org/</a> . |
| <b>Telnet</b>              | Standard terminal emulation protocol in the TCP/IP protocol stack. Telnet is used for remote terminal connection, enabling users to log in to remote systems and use resources as if they were connected to a local system. Telnet is defined in RFC 854.                                                                                      |
| <b>terminal server</b>     | A router with multiple, low speed, asynchronous ports that are connected to other serial devices. Terminal servers can be used to remotely manage network equipment, including sensors.                                                                                                                                                        |
| <b>TFN</b>                 | Tribe Flood Network. A common type of DoS attack that can take advantage of forged or rapidly changing source IP addresses to allow attackers to thwart efforts to locate or filter the attacks.                                                                                                                                               |
| <b>TFN2K</b>               | Tribe Flood Network 2000. A common type of DoS attack that can take advantage of forged or rapidly changing source IP addresses to allow attackers to thwart efforts to locate or filter the attacks.                                                                                                                                          |

|                            |                                                                                                                                                                                                                                                                                                                |
|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>TFTP</b>                | Trivial File Transfer Protocol. Simplified version of FTP that lets files be transferred from one computer to another over a network, usually without the use of client authentication (for example, username and password).                                                                                   |
| <b>threat rating</b>       | TR. A threat rating is a value between 0 and 100 that represents a numerical decrease of the risk rating of an attack based on the response action that depicts the threat of an alert on the monitored network.                                                                                               |
| <b>three-way handshake</b> | Process whereby two protocol entities synchronize during connection establishment.                                                                                                                                                                                                                             |
| <b>threshold</b>           | A value, either upper- or lower-bound that defines the maximum/minimum allowable condition before an alarm is sent.                                                                                                                                                                                            |
| <b>Time Processor</b>      | A processor in the IPS. Processes events stored in a time-slice calendar. Its primary task is to make stale database entries expire and to calculate time-dependent statistics.                                                                                                                                |
| <b>TLS</b>                 | Transport Layer Security. The protocol used over stream transports to negotiate the identity of peers and establish encrypted communications.                                                                                                                                                                  |
| <b>TNS</b>                 | Transparent Network Substrate. Provides database applications with a single common interface to all industry-standard network protocols. With TNS, database applications can connect to other database applications across networks with different protocols.                                                  |
| <b>topology</b>            | Physical arrangement of network nodes and media within an enterprise networking structure.                                                                                                                                                                                                                     |
| <b>TPKT</b>                | Transport Packet. RFC 1006-defined method of demarking messages in a packet. The protocol uses ISO transport services on top of TCP.                                                                                                                                                                           |
| <b>traceroute</b>          | Program available on many systems that traces the path a packet takes to a destination. It is used mostly to debug routing problems between hosts. A traceroute protocol is also defined in RFC 1393.                                                                                                          |
| <b>traffic analysis</b>    | Inference of information from observable characteristics of data flow(s), even when the data is encrypted or otherwise not directly available. Such characteristics include the identities and locations of the source(s) and destination(s), and the presence, amount, frequency, and duration of occurrence. |
| <b>Traffic ICMP engine</b> | Analyzes traffic from nonstandard protocols, such as TFN2K, LOKI, and DDOS.                                                                                                                                                                                                                                    |
| <b>trap</b>                | Message sent by an SNMP agent to an NMS, a console, or a terminal to indicate the occurrence of a significant event, such as a specifically defined condition or a threshold that was reached.                                                                                                                 |
| <b>Trojan engine</b>       | Analyzes traffic from nonstandard protocols, such as BO2K and TFN2K.                                                                                                                                                                                                                                           |
| <b>trunk</b>               | Physical and logical connection between two switches across which network traffic travels. A backbone is composed of a number of trunks.                                                                                                                                                                       |
| <b>trusted certificate</b> | Certificate upon which a certificate user relies as being valid without the need for validation testing; especially a public-key certificate that is used to provide the first public key in a certification path.                                                                                             |
| <b>trusted key</b>         | Public key upon which a user relies; especially a public key that can be used as the first public key in a certification path.                                                                                                                                                                                 |
| <b>tune</b>                | Adjusting signature parameters to modify an existing signature.                                                                                                                                                                                                                                                |



---

**U**

|                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|----------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>UDI</b>                             | Unique Device Identifier. Provides a unique identity for every Cisco product. The UDI is composed of the PID, VID, and SN. The UDI is stored in the Cisco IPS ID PROM.                                                                                                                                                                                                                                                                                              |
| <b>UDLD</b>                            | UniDirectional Link Detection. Cisco proprietary protocol that allows devices connected through fiber-optic or copper Ethernet cables connected to LAN ports to monitor the physical configuration of the cables and detect when a unidirectional link exists. When a unidirectional link is detected, UDLD shuts down the affected LAN port and sends an alert, since unidirectional links can cause a variety of problems, such as, spanning tree topology loops. |
| <b>UDP</b>                             | User Datagram Protocol. Connectionless transport layer protocol in the TCP/IP protocol stack. UDP is a simple protocol that exchanges datagrams without acknowledgments or guaranteed delivery, requiring that error processing and retransmission be handled by other protocols. UDP is defined in RFC 768.                                                                                                                                                        |
| <b>unblock</b>                         | To direct a router to remove a previously applied block.                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>UniDirectional Link Detection</b>   | See UDLD.                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>unvirtualized sensing interface</b> | An unvirtualized sensing interface has not been divided into subinterfaces and the entire interfaces can be associated with at most one virtual sensor.                                                                                                                                                                                                                                                                                                             |
| <b>UPS</b>                             | Uninterruptable Power Source.                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>UTC</b>                             | Coordinated Universal Time. Time zone at zero degrees longitude. Formerly called Greenwich Mean Time (GMT) and Zulu time.                                                                                                                                                                                                                                                                                                                                           |
| <b>UTF-8</b>                           | 8-bit Unicode Transformation Format. A variable-length character encoding for Unicode. UTF-8 can represent every character in the Unicode character set and is backwards-compatible with ASCII.                                                                                                                                                                                                                                                                     |

---

**V**

|                                      |                                                                                                                                                                                                                                                                                                                           |
|--------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>VACL</b>                          | VLAN ACL. An ACL that filters all packets (both within a VLAN and between VLANs) that pass through a switch. Also known as security ACLs.                                                                                                                                                                                 |
| <b>VID</b>                           | Version identifier. Part of the UDI.                                                                                                                                                                                                                                                                                      |
| <b>VIP</b>                           | Versatile Interface Processor. Interface card used in Cisco 7000 and Cisco 7500 series routers. The VIP provides multilayer switching and runs Cisco IOS. The most recent version of the VIP is VIP2.                                                                                                                     |
| <b>virtual sensor</b>                | A logical grouping of sensing interfaces and the configuration policy for the signature engines and alarm filters to apply to them. In other words, multiple virtual sensors running on the same appliance, each configured with different signature behavior and traffic feeds.                                          |
| <b>virtualized sensing interface</b> | A virtualized interface has been divided into subinterfaces each of which consists of a group of VLANs. You can associate a virtual sensor with one or more subinterfaces so that different intrusion prevention policies can be assigned to those subinterfaces. You can virtualize both physical and inline interfaces. |

|                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>virus</b>         | Hidden, self-replicating section of computer software, usually malicious logic, that propagates by infecting—that is, inserting a copy of itself into and becoming part of—another program. A virus cannot run by itself; it requires that its host program be run to make the virus active.                                                                                                                                                                                                  |
| <b>virus update</b>  | A signature update specifically addressing viruses.                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>VLAN</b>          | Virtual Local Area Network. Group of devices on one or more LANs that are configured (using management software) so that they can communicate as if they were attached to the same wire, when in fact they are located on a number of different LAN segments. Because VLANs are based on logical instead of physical connections, they are extremely flexible.                                                                                                                                |
| <b>VTP</b>           | VLAN Trunking Protocol. Cisco Layer 2 messaging protocol that manages the addition, deletion, and renaming of VLANs on a network-wide basis.                                                                                                                                                                                                                                                                                                                                                  |
| <b>VMS</b>           | CiscoWorks VPN/Security Management Solution. A suite of network security applications that combines web-based tools for configuring, monitoring, and troubleshooting enterprise VPN, firewalls, network intrusion detection systems and host-based intrusion prevention systems.                                                                                                                                                                                                              |
| <b>VoIP</b>          | Voice over IP. The capability to carry normal telephony-style voice over an IP-based Internet with POTS-like functionality, reliability, and voice quality. VoIP enables a router to carry voice traffic (for example, telephone calls and faxes) over an IP network. In VoIP, the DSP segments the voice signal into frames, which then are coupled in groups of two and stored in voice packets. These voice packets are transported using IP in compliance with ITU-T specification H.323. |
| <b>VPN</b>           | Virtual Private Network(ing). Enables IP traffic to travel securely over a public TCP/IP network by encrypting all traffic from one network to another. A VPN uses “tunneling” to encrypt all information at the IP level.                                                                                                                                                                                                                                                                    |
| <b>VTP</b>           | VLAN Trunking Protocol. A Cisco Layer 2 messaging protocol that manages the addition, deletion, and renaming of VLANs on a network-wide basis.                                                                                                                                                                                                                                                                                                                                                |
| <b>vulnerability</b> | One or more attributes of a computer or a network that permit a subject to initiate patterns of misuse on that computer or network.                                                                                                                                                                                                                                                                                                                                                           |

---

## W

|                          |                                                                                                                                                                                                                    |
|--------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>WAN</b>               | wide-area network. Data communications network that serves users across a broad geographic area and often uses transmission devices provided by common carriers. Frame Relay, SMDS, and X.25 are examples of WANs. |
| <b>watch list rating</b> | WLR. A weight associated with the CSA MC watch list in the range of 0 to 100 (CSA MC only uses the range 0 to 35).                                                                                                 |
| <b>Web Server</b>        | A component of the IPS. Waits for remote HTTP client requests and calls the appropriate servlet application.                                                                                                       |
| <b>WHOIS</b>             | A TCP-based query/response protocol used for querying an official database to determine the owner of a domain name or an IP address.                                                                               |

|                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Wireshark</b> | Wireshark is a free network protocol analyzer for UNIX and Windows. It lets you examine data from a live network or from a capture file on disk. You can interactively browse the capture data, viewing summary and detail information for each packet. Wireshark has several powerful features, including a rich display filter language and the ability to view the reconstructed stream of a TCP session. For more information, see <a href="http://www.wireshark.org">http://www.wireshark.org</a> . |
| <b>worm</b>      | A computer program that can run independently, can propagate a complete working version of itself onto other hosts on a network, and can consume computer resources destructively.                                                                                                                                                                                                                                                                                                                       |
| <hr/>            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>X</b>         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>X.509</b>     | Standard that defines information contained in a certificate.                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>XML</b>       | eXtensible Markup Language. Textual file format used for data interchange between heterogeneous hosts.                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>XPI</b>       | Cross Packet Inspection. Technology used by TCP that allows searches across packets to achieve packet and payload reassembly.                                                                                                                                                                                                                                                                                                                                                                            |
| <hr/>            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Z</b>         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>zone</b>      | A set of destination IP addresses sorted into an internal, illegal, or external zone used by Anomaly Detection.                                                                                                                                                                                                                                                                                                                                                                                          |





---

## Numerics

- 4GE bypass interface card
  - configuration restrictions [7-10](#)
  - described [7-10](#)
- 802.1q encapsulation for VLAN groups [7-17](#)

---

## A

### AAA RADIUS

- functionality [6-19](#)
- limitations [6-19](#)

### accessing

- IPS software [26-2](#)
- service account [6-18, C-5](#)

### access list misconfiguration [C-29](#)

### access lists

- necessary hosts [5-3](#)
- Startup Wizard [5-3](#)

### account locking

- configuring [6-25](#)
- security [6-25](#)

### account unlocking configuring [6-26](#)

### ACLs

- adding [5-5](#)
- described [16-3](#)
- Post-Block [16-17, 16-18](#)
- Pre-Block [16-17, 16-18](#)

### ad0 pane

- default [13-10](#)
- described [13-10](#)
- tabs [13-10](#)

### Add/Update Trusted Root Certificate dialog box

- field descriptions [15-15](#)

### Add ACL Entry dialog box field descriptions [5-3](#)

### Add Allowed Host dialog box

- field descriptions [6-6](#)
- user roles [6-5](#)

### Add Authorized RSA1 Key dialog box

- field descriptions [15-5](#)
- user roles [15-4](#)

### Add Authorized RSA Key dialog box

- field descriptions [15-3](#)
- user roles [15-2](#)

### Add Blocking Device dialog box

- field descriptions [16-15](#)
- user roles [16-14](#)

### Add Cat 6K Blocking Device Interface dialog box

- field descriptions [16-22](#)
- user roles [16-21](#)

### Add Configured OS Map dialog box

- field descriptions [8-32, 12-26](#)
- user roles [8-31, 12-23](#)

### Add Destination Port dialog box

- field descriptions [13-17, 13-23, 13-30](#)
- user roles [13-15](#)

### Add Device dialog box field descriptions [2-3](#)

### Add Device Login Profile dialog box

- field descriptions [16-12](#)
- user roles [16-12](#)

### Add Event Action Filter dialog box

- field descriptions [8-22, 12-16](#)
- user roles [12-15](#)

### Add Event Action Override dialog box

- field descriptions [8-12, 12-13](#)

- user roles [8-12, 12-13](#)
- Add Event Variable dialog box
  - field descriptions [8-35, 12-29](#)
  - user roles [8-34, 12-28](#)
- Add External Product Interface dialog box
  - field descriptions [19-6](#)
  - user roles [19-4](#)
- Add Filter dialog box field descriptions [3-19, 22-3](#)
- Add Histogram dialog box
  - field descriptions [13-17, 13-24, 13-30](#)
  - user roles [13-15](#)
- Add Host Block dialog box field descriptions [18-4](#)
- adding
  - ACLs [5-5](#)
  - a host never to be blocked [16-11](#)
  - anomaly detection policies [13-10](#)
  - blocking devices [16-15](#)
  - CSA MC interfaces [19-7](#)
  - denied attackers [18-2](#)
  - event action filters [8-23, 12-17](#)
  - event action overrides [12-14](#)
  - event action rules policies [12-12](#)
  - event variables [8-36, 12-29](#)
  - external product interfaces [19-7](#)
  - host blocks [18-4](#)
  - IPv4 target value ratings [8-26, 12-20](#)
  - IPv6 target value ratings [8-28, 12-22](#)
  - network blocks [18-7](#)
  - OS maps [8-33, 12-27](#)
  - rate limiting devices [16-15](#)
  - rate limits [18-9](#)
  - risk categories [8-38, 12-32](#)
  - signature definition policies [10-8](#)
  - signatures [10-17](#)
  - signature variables [10-37](#)
  - trusted root certificates [15-15](#)
  - virtual sensors [5-13, 8-13](#)
  - virtual sensors (ASA 5500 AIP SSM) [8-16](#)
  - virtual sensors (ASA 5500-X IPS SSP) [8-16](#)
- virtual sensors (ASA 5585-X IPS SSP) [8-16](#)
- Add Inline VLAN Pair dialog box
  - field descriptions [7-24](#)
  - user roles [7-23](#)
- Add Inline VLAN Pair Entry dialog box field descriptions [5-10](#)
- Add Interface Pair dialog box
  - field descriptions [7-22](#)
  - user roles [7-22](#)
- Add IP Logging dialog box field descriptions [18-11](#)
- Add Known Host RSA1 Key dialog box
  - field descriptions [15-9](#)
  - user roles [15-8](#)
- Add Known Host RSA Key dialog box
  - field descriptions [15-7](#)
  - user roles [15-6](#)
- Add Master Blocking Sensor dialog box
  - field descriptions [16-25](#)
  - user roles [16-24](#)
- Add Network Block dialog box field descriptions [18-6](#)
- Add Never Block Address dialog box
  - field descriptions [16-10](#)
  - user roles [16-7](#)
- Add Policy dialog box
  - field descriptions [9-2, 10-8, 12-12, 13-9](#)
  - user roles [10-7, 12-11, 13-9](#)
- Add Posture ACL dialog box field descriptions [19-7](#)
- Add Protocol Number dialog box field descriptions [13-18, 13-25, 13-32](#)
- Add Rate Limit dialog box
  - field descriptions [18-8](#)
  - user role [18-7](#)
- Address Resolution Protocol. See ARP.
- Add Risk Level dialog box
  - field descriptions [8-38, 12-31](#)
  - user roles [8-37, 12-31](#)
- Add Router Blocking Device Interface dialog box
  - field descriptions [16-19](#)
  - user roles [16-17](#)

- Add Signature dialog box field descriptions [10-12](#)
- Add Signature Variable dialog box
  - field descriptions [10-36](#)
  - user roles [10-36](#)
- Add SNMP Trap Destination dialog box
  - field descriptions [17-5](#)
  - user roles [17-4](#)
- Add Start Time dialog box
  - field descriptions [13-14](#)
  - user roles [13-12](#)
- Add Target Value Rating dialog box
  - field descriptions [8-26, 8-28](#)
  - user roles [8-26, 8-27](#)
- Add Trusted Host dialog box
  - field descriptions [15-13](#)
  - user roles [15-13](#)
- Add User dialog box
  - field descriptions [6-22](#)
  - user roles [6-19, 6-22](#)
- Add Virtual Sensor dialog box
  - described [5-12, 8-10](#)
  - field descriptions [5-13, 8-10](#)
  - user roles [8-10](#)
- Add VLAN Group dialog box
  - field descriptions [7-27](#)
  - user roles [7-26](#)
- Advanced Alert Behavior Wizard
  - Alert Dynamic Response Fire All window field descriptions [11-27](#)
  - Alert Dynamic Response Fire Once window field descriptions [11-28](#)
  - Alert Dynamic Response Summary window field descriptions [11-28](#)
  - Alert Summarization window field descriptions [11-27](#)
  - Event Count and Interval window field descriptions [11-26](#)
  - Global Summarization window field descriptions [11-29](#)
- aggregation
  - alert frequency [8-7, 12-5](#)
  - operating modes [8-7, 12-5](#)
- AIC
  - policy [10-48](#)
  - signatures (example) [10-48](#)
- AIC engine
  - AIC FTP [B-11](#)
  - AIC FTP engine parameters (table) [B-12](#)
  - AIC HTTP [B-11](#)
  - AIC HTTP engine parameters (table) [B-12](#)
  - described [B-11](#)
  - features [B-11](#)
  - signature categories [10-40](#)
- AIC policy enforcement
  - default configuration [10-41, B-11](#)
  - described [10-41, B-11](#)
  - sensor oversubscription [10-41, B-11](#)
- Alarm Channel
  - described [12-6, A-26](#)
  - risk rating [14-5](#)
- alert and log actions (list) [10-2, 10-14, 12-8](#)
- alert behavior
  - Custom Signature Wizard [11-26](#)
  - normal [11-26](#)
- alert frequency
  - aggregation [10-23](#)
  - configuring [10-23](#)
  - controlling [10-23](#)
  - modes [B-7](#)
- allocate-ips command [8-15](#)
- Allowed Hosts/Networks pane
  - configuring [6-6](#)
  - described [6-5](#)
  - field descriptions [6-6](#)
- alternate TCP reset interface
  - configuration restrictions [7-12](#)
  - designating [7-9](#)
  - restrictions [7-2](#)
- Analysis Engine
  - described [8-2](#)

- error messages [C-26](#)
- errors [C-55](#)
- IDM exits [C-59](#)
- sensing interfaces [7-3](#)
- verify it is running [C-22](#)
- virtual sensors [8-2](#)
- anomaly detection
  - asymmetric traffic [13-2](#)
  - caution [13-2](#)
  - configuration sequence [13-5](#)
  - default anomaly detection configuration [13-4](#)
  - default configuration (example) [13-4](#)
  - described [13-2](#)
  - detect mode [13-4](#)
  - enabling [13-4](#)
  - event actions [13-7, B-70](#)
  - inactive mode [13-4](#)
  - learning accept mode [13-3](#)
  - learning process [13-3](#)
  - limiting false positives [13-13, 21-8](#)
  - operation settings [13-11](#)
  - protocols [13-3](#)
  - signatures (table) [13-7, B-70](#)
  - signatures described [13-7](#)
  - worms
    - attacks [13-13, 21-8](#)
    - described [13-3](#)
  - zones [13-5](#)
- anomaly detection disabling [13-35, C-21](#)
- Anomaly Detection pane
  - button functions [21-8](#)
  - described [21-7](#)
  - field descriptions [21-8](#)
  - user roles [21-7](#)
- anomaly detection policies
  - ad0 [13-9](#)
  - adding [13-10](#)
  - cloning [13-10](#)
  - default policy [13-9](#)
  - deleting [13-10](#)
- Anomaly Detections pane
  - described [13-9](#)
  - field descriptions [13-9](#)
  - user roles [13-9](#)
- appliances
  - GRUB menu [20-5, C-8](#)
  - initializing [25-8](#)
  - logging in [24-2](#)
  - password recovery [20-5, C-8](#)
  - setting system clock [6-16](#)
  - terminal servers
    - described [24-3, 27-13](#)
    - setting up [24-3, 27-13](#)
  - time sources [6-10, C-17](#)
  - upgrading recovery partition [27-6](#)
- Application Inspection and Control. See AIC.
- application partition
  - described [A-4](#)
  - image recovery [27-11](#)
- application policy enforcement described [10-41, B-11](#)
- applications in XML format [A-4](#)
- applying signature threat profiles [5-15](#)
- applying software updates [C-55](#)
- ARC
  - ACLs [16-18, A-14](#)
  - authentication [A-15](#)
  - blocking
    - connection-based [A-17](#)
    - response [A-13](#)
    - unconditional blocking [A-17](#)
  - blocking application [16-2](#)
  - blocking not occurring for signature [C-45](#)
  - Catalyst switches
    - VACL commands [A-19](#)
    - VACLs [A-16, A-19](#)
    - VLANs [A-16](#)
  - checking status [16-3, 16-4](#)
  - described [A-4](#)



- design [16-2](#)
- device access issues [C-42](#)
- enabling SSH [C-44](#)
- features [A-14](#)
- firewalls
  - AAA [A-18](#)
  - connection blocking [A-18](#)
  - NAT [A-18](#)
  - network blocking [A-18](#)
  - postblock ACL [A-16](#)
  - preblock ACL [A-16](#)
  - shun command [A-18](#)
  - TACACS+ [A-18](#)
- formerly Network Access Controller [16-1](#)
- functions [16-2](#)
- illustration [A-13](#)
- inactive state [C-40](#)
- interfaces [A-14](#)
- maintaining states [A-16](#)
- managed devices [16-7](#)
- master blocking sensors [A-14](#)
- maximum blocks [16-2](#)
- misconfigured master blocking sensor [C-46](#)
- nac.shun.txt file [A-16](#)
- NAT addressing [A-15](#)
- number of blocks [A-15](#)
- postblock ACL [A-16](#)
- preblock ACL [A-16](#)
- prerequisites [16-5](#)
- rate limiting [16-4](#)
- responsibilities [A-13](#)
- single point of control [A-15](#)
- SSH [A-14](#)
- supported devices [16-5, A-15](#)
- Telnet [A-14](#)
- troubleshooting [C-38](#)
- VACLs [A-14](#)
- verifying device interfaces [C-43](#)
- verifying status [C-39](#)
- ARP
  - Layer 2 signatures [B-13](#)
  - protocol [B-13](#)
- ARP spoof tools
  - dsniff [B-13](#)
  - ettercap [B-13](#)
- ASA 5500 AIP SSM
  - assigning virtual sensors [8-18](#)
  - bypass mode [7-30](#)
  - creating virtual sensors [8-16](#)
  - initializing [25-13](#)
  - installing system image [27-27](#)
  - logging in [24-4](#)
  - Normalizer engine [B-37, C-65](#)
  - password recovery [20-7, 20-11, C-10](#)
  - recovering [C-64](#)
  - resetting [C-64](#)
  - resetting the password [20-7, 20-11, C-10](#)
  - sensing interface [8-15](#)
  - session command [24-4](#)
  - sessioning in [24-4](#)
  - setup command [25-13](#)
  - time sources [6-11, C-18](#)
  - virtual sensors
    - assigning the interface [8-16](#)
    - sequence [8-15](#)
- ASA 5500-X IPS SSP
  - assigning virtual sensors [8-18](#)
  - creating virtual sensors [8-16](#)
  - initializing [25-17](#)
  - IPS reloading messages [C-67, C-72, C-80](#)
  - logging in [24-5](#)
  - memory usage [20-20, C-71](#)
  - memory usage values (table) [20-20, C-71](#)
  - no CDP mode support [7-31](#)
  - Normalizer engine [B-37, C-70](#)
  - password recovery [20-9, C-12](#)
  - resetting the password [20-9, C-12](#)
  - sensing interface [8-15](#)

- session command [24-5](#)
- sessioning in [24-5](#)
- setup command [25-17](#)
- time sources [6-11, C-18](#)
- virtual sensors
  - assigning policies [8-16](#)
  - assigning the interface [8-16](#)
  - virtual sensor sequence [8-15](#)
- ASA 5585-X IPS SSP
  - assigning virtual sensors [8-18](#)
  - creating virtual sensors [8-16](#)
  - initializing [25-21](#)
  - installing system image [27-31](#)
  - IPS reloading messages [C-67, C-72, C-80](#)
  - logging in [24-6](#)
  - no CDP mode support [7-31](#)
  - Normalizer engine [B-37, C-78](#)
  - password recovery [C-14](#)
  - resetting the password [C-14](#)
  - sensing interface [8-15](#)
  - session command [24-6](#)
  - sessioning in [24-6](#)
  - setup command [25-21](#)
  - time sources [6-11, C-18](#)
  - virtual sensors
    - assigning policies [8-16](#)
    - assigning the interface [8-16](#)
    - sequence [8-15](#)
- ASA IPS modules
  - jumbo packet count [C-66, C-72, C-79](#)
- ASDM
  - resetting passwords [20-9, 20-10, 20-13, C-12, C-13, C-15](#)
- assigning
  - interfaces to virtual sensors (ASA 5500 AIP SSM) [8-16](#)
  - interfaces to virtual sensors (ASA 5500-X IPS SSP) [8-16](#)
  - interfaces to virtual sensors (ASA 5585-X IPS SSP) [8-16](#)
  - policies to virtual sensors (ASA 5500 AIP SSM) [8-16](#)
  - policies to virtual sensors (ASA 5500-X IPS SSP) [8-16](#)
  - policies to virtual sensors (ASA 5585-X IPS SSP) [8-16](#)
- assigning actions to signatures [10-21](#)
- asymmetric mode
  - described [8-4](#)
  - normalization [8-4](#)
- asymmetric traffic
  - anomaly detection [13-2](#)
  - caution [13-2](#)
- asymmetric traffic and disabling anomaly detection [13-35, C-21](#)
- Atomic ARP engine
  - described [B-13](#)
  - parameters (table) [B-13](#)
- Atomic IP Advanced engine
  - described [B-14](#)
  - parameters (table) [B-16](#)
  - restrictions [B-15](#)
- Atomic IP engine
  - described [11-13, B-24](#)
  - parameters (table) [B-24](#)
- Atomic IPv6 engine
  - described [B-27](#)
  - Neighborhood Discovery protocol [B-28](#)
  - signatures [B-28](#)
- attack relevance rating
  - calculating risk rating [8-6, 12-3](#)
  - described [8-6, 8-30, 12-3, 12-24](#)
- Attack Response Controller
  - described [A-4](#)
  - formerly known as Network Access Controller [A-4](#)
- Attack Response Controller. See ARC.
- attack severity rating
  - calculating risk rating [8-6, 12-3](#)
  - described [8-6, 12-3](#)
- Attacks Over Time gadgets
  - configuring [3-13](#)
  - described [3-13](#)

Attacks Over Time Reports described [1-18, 23-2](#)

attempt limit

RADIUS [C-23](#)

attemptLimit command [6-25](#)

audit mode

described [14-8](#)

testing global correlation [14-8](#)

authenticated NTP [6-10, 6-14, C-17](#)

authentication

local [6-19](#)

RADIUS [6-19](#)

AuthenticationApp

authenticating users [A-21](#)

described [A-4](#)

login attempt limit [A-21](#)

method [A-21](#)

responsibilities [A-20](#)

secure communications [A-21](#)

sensor configuration [A-20](#)

Authentication pane

configuring [6-22](#)

described [6-19](#)

field descriptions [6-20](#)

user roles [6-17, A-30](#)

Authorized RSA1 Keys pane

configuring [15-5](#)

described [15-4](#)

field descriptions [15-4](#)

RSA authentication [15-4](#)

RSA key generation tool [15-5](#)

Authorized RSA Keys pane

configuring [15-3](#)

described [15-2](#)

field descriptions [15-2](#)

RSA authentication [15-2](#)

RSA key generation tool [15-3](#)

Auto/Cisco.com Update pane

configuring [20-25](#)

described [5-16, 20-22](#)

field descriptions [20-24](#)

UNIX-style directory listings [20-23](#)

user roles [20-22](#)

automatic reporting configuring (IME) [1-19](#)

automatic setup [25-2](#)

automatic updates

Cisco.com [5-16, 20-22](#)

configuring [5-17, 20-25](#)

cryptographic account [5-16, 20-22](#)

FTP servers [20-22](#)

SCP servers [5-16, 20-22](#)

automatic upgrade

information required [27-7](#)

troubleshooting [C-56](#)

autonegotiation for hardware bypass [7-11](#)

Auto Update window field descriptions [5-16](#)

auto-upgrade-option command [27-7](#)

## B

backing up

configuration [C-2](#)

current configuration [C-4](#)

BackOrifice. See BO.

BackOrifice 2000. See BO2K.

basic setup [25-4](#)

blocking

described [16-2](#)

disabling [16-8](#)

master blocking sensor [16-24](#)

necessary information [16-3](#)

prerequisites [16-5](#)

supported devices [16-5](#)

types [16-2](#)

blocking devices

adding [16-15](#)

deleting [16-15](#)

editing [16-15](#)

## Blocking Devices pane

- configuring [16-15](#)
- described [16-14](#)
- field descriptions [16-14](#)
- ssh host-key command [16-15](#)

blocking not occurring for signature [C-45](#)

## Blocking Properties pane

- adding a host never to be blocked [16-11](#)
- configuring [16-9](#)
- described [16-7](#)
- field descriptions [16-8](#)

## BO

- described [B-72](#)
- Trojans [B-72](#)

## BO2K

- described [B-72](#)
- Trojans [B-72](#)

## bypass mode

- ASA 5500 AIP SSM [7-30](#)
- described [7-29](#)
- signature updates [20-24](#)

## Bypass pane

- field descriptions [7-29](#)
- user roles [7-28](#)

---

**C**

## calculating risk rating

- attack relevance rating [8-6, 12-3](#)
- attack severity rating [8-6, 12-3](#)
- promiscuous delta [8-6, 12-3](#)
- signature fidelity rating [8-5, 12-3](#)
- target value rating [8-6, 12-3](#)
- watch list rating [8-6, 12-3](#)

cannot access sensor [C-27](#)

## Cat 6K Blocking Device Interfaces pane

- configuring [16-23](#)
- described [16-21](#)
- field descriptions [16-22](#)

## CDP mode

- ASA 5500-X IPS SSP [7-31](#)
- ASA 5585-X IPS SSP [7-31](#)
- described [7-31](#)
- interfaces [7-31](#)

## CDP Mode pane

- configuring [7-32](#)
- field descriptions [7-31](#)
- user roles [7-31](#)

## certificates

- displaying [15-16](#)
- generating [15-16](#)

certificates (IDM) [15-11](#)changing Microsoft IIS to UNIX-style directory listings [20-23](#)cidDump obtaining information [C-105](#)

## CIDE

- defined [A-34](#)
- example [A-34](#)
- IPS extensions [A-34](#)
- protocol [A-34](#)
- supported IPS events [A-34](#)

## cisco

- default password [24-2](#)
- default username [24-2](#)

## Cisco.com

- accessing software [26-2](#)
- downloading software [26-1](#)
- software downloads [26-1](#)

## Cisco Discovery Protocol. See CDP.

Cisco IOS rate limiting [16-4](#)

## Cisco Security Intelligence Operations

- described [26-7](#)
- URL [26-8](#)

## Cisco Services for IPS

- service contract [20-16](#)
- supported products [20-16](#)

clear events command [6-12, 6-16, 21-4, C-19, C-105](#)

- Clear Flow States pane
  - described [21-18](#)
  - field descriptions [21-19](#)
- clearing
  - denied attackers [18-2](#)
  - events [6-16, 21-4, C-105](#)
  - flow states [21-19](#)
  - statistics [C-89](#)
- CLI
  - described [A-4, A-30](#)
  - password recovery [20-13, C-16](#)
- client manifest described [A-29](#)
- clock set command [6-16](#)
- Clone Policy dialog box
  - field descriptions [10-8, 12-12, 13-9](#)
  - user roles [10-7, 12-11, 13-9](#)
- Clone Signature dialog box field descriptions [10-12](#)
- cloning
  - anomaly detection policies [13-10](#)
  - event action rules policies [12-12](#)
  - signature definition policies [10-8](#)
  - signatures [10-19](#)
- CollaborationApp described [A-4, A-28](#)
- color rules
  - described [22-2](#)
  - events (IME) [22-2](#)
- Color Rules tab
  - described [22-2](#)
  - filters [22-2](#)
- command and control interface
  - described [7-2](#)
  - list [7-2](#)
- commands
  - allocate-ips [8-15](#)
  - attemptLimit [6-25](#)
  - auto-upgrade-option [27-7](#)
  - clear events [6-12, 6-16, 21-4, C-19, C-105](#)
  - clock set [6-16](#)
  - copy backup-config [C-3](#)
  - copy current-config [C-3](#)
  - debug module-boot [C-64](#)
  - downgrade [27-10](#)
  - erase license-key [20-19](#)
  - hw-module module 1 reset [C-64](#)
  - hw-module module slot\_number password-reset [20-7, 20-11, C-10, C-14](#)
  - setup [6-1, 25-1, 25-4, 25-8, 25-13, 25-17, 25-21](#)
  - show events [C-102](#)
  - show health [C-81](#)
  - show module 1 details [C-63, C-69, C-75](#)
  - show settings [20-14, C-16](#)
  - show statistics [C-89](#)
  - show statistics virtual-sensor [C-26, C-89](#)
  - show tech-support [C-82](#)
  - show version [C-86](#)
  - sw-module module slot\_number password-reset [20-9, C-12](#)
  - unlock user username [6-26](#)
  - upgrade [27-3, 27-6](#)
  - virtual-sensor name [8-16](#)
- Compare Knowledge Bases dialog box field descriptions [21-11](#)
- comparing KBs [21-11, 21-12](#)
- component signatures
  - risk rating [B-32](#)
- configuration files
  - backing up [C-2](#)
  - merging [C-2](#)
- configuration restrictions
  - alternate TCP reset interface [7-12](#)
  - inline interface pairs [7-12](#)
  - inline VLAN pairs [7-12](#)
  - interfaces [7-11](#)
  - physical interfaces [7-11](#)
  - VLAN groups [7-13](#)
- Configure Summertime dialog box field descriptions [5-4, 6-8](#)
- configuring
  - account locking [6-25](#)

- account unlocking [6-26](#)
- AIC policy parameters [10-48](#)
- allowed hosts [6-6](#)
- allowed networks [6-6](#)
- anomaly detection operation settings [13-11](#)
- application policy signatures [10-48](#)
- Attacks Over Time gadgets [3-13](#)
- authorized keys [15-5](#)
- authorized RSA keys [15-3](#)
- automatic updates [5-17, 20-25](#)
- automatic upgrades [27-9](#)
- blocking devices [16-15](#)
- blocking properties [16-9](#)
- Cat 6K blocking device interfaces [16-23](#)
- CDP mode [7-32](#)
- CPU, Memory, & Load gadget [3-11](#)
- CSA MC IPS interfaces [19-3](#)
- device login profiles [16-13](#)
- event action filters [8-23, 12-17](#)
- events [21-3](#)
- event variables [8-36, 12-29](#)
- external zone [13-32](#)
- general settings [8-41, 12-34](#)
- Global Correlation Health gadget [3-8](#)
- Global Correlation Reports gadget [3-6](#)
- host blocks [18-4](#)
- illegal zone [13-25](#)
- inline VLAN pairs [5-10](#)
- inspection/reputation [14-9](#)
- inspection load statistics display [21-5](#)
- interface pairs [7-23](#)
- interfaces [7-20](#)
- interface statistics display [21-6](#)
- Interface Status gadget [3-6](#)
- internal zone [13-19](#)
- IP fragment reassembly signatures [10-52](#)
- IP logging [18-12](#)
- IPv4 target value ratings [8-26, 12-20](#)
- IPv6 target value ratings [8-28, 12-22](#)
- known host keys [15-9](#)
- known host RSA keys [15-7](#)
- learning accept mode [13-14](#)
- Licensing gadget [3-5](#)
- local authentication [6-23](#)
- master blocking sensor [16-25](#)
- network blocks [18-7](#)
- network participation [14-11](#)
- Network Security gadget [3-9](#)
- network settings [6-3](#)
- NTP servers [6-13](#)
- OS maps [8-33, 12-27](#)
- RADIUS authentication [6-23](#)
- rate limiting [18-9](#)
- rate limiting device interfaces [16-20](#)
- risk categories [8-38, 12-32](#)
- router blocking device interfaces [16-20](#)
- RSS Feed gadgets [3-11](#)
- RSS feeds [4-2](#)
- Sensor Health gadget [3-4](#)
- Sensor Information gadget [3-3](#)
- Sensor Setup window [5-4](#)
- sensor to use NTP [6-14](#)
- signature variables [10-37](#)
- SNMP [17-3](#)
- SNMP traps [17-5](#)
- time [6-9](#)
- Top Applications gadget [3-9](#)
- Top Attackers gadgets [3-12](#)
- Top Signatures gadgets [3-13](#)
- Top Victims gadgets [3-12](#)
- traffic flow notifications [7-31](#)
- trusted hosts [15-13](#)
- upgrades [27-4](#)
- users [6-22](#)
- VLAN groups [7-27](#)
- VLAN pairs [7-25](#)
- control transactions
  - characteristics [A-9](#)

- request types [A-9](#)
- copy backup-config command [C-3](#)
- copy current-config command [C-3](#)
- correcting time on the sensor [6-12, C-19](#)
- CPU, Memory, & Load gadget
  - configuring [3-11](#)
- creating
  - Atomic IP Advanced engine signature [10-29, 11-14](#)
  - custom signatures
    - not using signature engines [11-4](#)
    - Service HTTP [11-17](#)
    - String TCP [11-22](#)
    - using signature engines [11-1](#)
  - event views [22-4](#)
  - IPv6 signatures [10-29, 11-14](#)
  - Meta signatures [10-26](#)
  - Post-Block VACLs [16-21](#)
  - Pre-Block VACLs [16-21](#)
  - reports (IME) [23-3](#)
  - String TCP XL signatures [10-34](#)
- creating the service account [C-5](#)
- cryptographic account
  - automatic updates [5-16, 20-22](#)
  - Encryption Software Export Distribution Authorization from [26-2](#)
  - obtaining [26-2](#)
- cryptographic features (IME) [1-2](#)
- CSA MC
  - adding interfaces [19-7](#)
  - configuring IPS interfaces [19-3](#)
  - host posture events [19-1, 19-3](#)
  - quarantined IP address events [19-1](#)
  - supported IPS interfaces [19-3](#)
- CtlTransSource
  - described [A-4, A-11](#)
  - illustration [A-12](#)
- current configuration back up [C-2](#)
- current KB setting [21-13](#)
- custom signatures
  - Custom Signature Wizard [11-5](#)
  - described [10-2](#)
  - IPv6 signature [10-29, 11-14](#)
  - Meta signature [10-26](#)
  - sensor performance [11-4](#)
  - String TCP XL [10-31, 10-34](#)
- Custom Signature Wizard
  - alert behavior [11-26](#)
  - Alert Response window field descriptions [11-26](#)
  - Atomic IP Engine Parameters window field descriptions [11-13](#)
  - described [11-1](#)
  - ICMP Traffic Type window field descriptions [11-12](#)
  - Inspect Data window field descriptions [11-12](#)
  - MSRPC Engine Parameters window field descriptions [11-11](#)
  - no signature engine sequence [11-4](#)
  - Protocol Type window field descriptions [11-10](#)
  - Service HTTP Engine Parameters window field descriptions [11-16](#)
  - Service RPC Engine Parameters window field descriptions [11-19](#)
  - Service Type window field descriptions [11-13](#)
  - signature engine sequence [11-1](#)
  - Signature Identification window field descriptions [11-11](#)
  - State Engine Parameters window field descriptions [11-20](#)
  - String ICMP Engine Parameters window field descriptions [11-21](#)
  - String TCP Engine Parameters window field descriptions [11-21](#)
  - String UDP Engine Parameters window field descriptions [11-24](#)
  - supported signature engines [11-2](#)
  - Sweep Engine Parameters window field descriptions [11-25](#)
  - TCP Sweep Type window field descriptions [11-13](#)
  - TCP Traffic Type window field descriptions [11-12](#)
  - UDP Sweep Type window field descriptions [11-12](#)
  - UDP Traffic Type window field descriptions [11-12](#)

using [11-5](#)  
 Welcome window field descriptions [11-10](#)

## D

### dashboards

adding [3-1](#)  
 deleting [3-1](#)

### Data Archive dialog box

configuring [1-13](#)  
 described [1-12](#)  
 field descriptions [1-12](#)

### data archiving configuring [1-13](#)

### data nodes [11-25, B-67](#)

### data structures (examples) [A-8](#)

### DDoS

protocols [B-72](#)  
 Stacheldraht [B-72](#)  
 TFN [B-72](#)

### debug logging enable [C-47](#)

### debug-module-boot command [C-64](#)

### default policies

ad0 [13-9](#)  
 rules0 [12-2, 12-11](#)  
 sig0 [10-7](#)

### defaults

KB filename [13-12](#)  
 password [24-2](#)  
 restoring [20-29](#)  
 username [24-2](#)  
 virtual sensor vs0 [8-2](#)

### deleting

anomaly detection policies [13-10](#)  
 blocking devices [16-15](#)  
 denied attackers [18-2](#)  
 event action filters [8-23, 12-17](#)  
 event action overrides [12-14](#)  
 event action rules policies [12-12](#)  
 event variables [8-36, 12-29](#)

### host blocks [18-4](#)

### imported OS values [21-18](#)

### IPv4 target value ratings [8-26, 12-20](#)

### IPv6 target value ratings [8-28, 12-22](#)

### KBs [21-14](#)

### learned OS values [21-17](#)

### network blocks [18-7](#)

### OS maps [8-33, 12-27](#)

### rate limiting devices [16-15](#)

### rate limits [18-9](#)

### risk categories [8-38, 12-32](#)

### signature definition policies [10-8](#)

### signature variables [10-37](#)

### virtual sensors [8-13](#)

### Demo mode (IME) [1-7](#)

### demo reports described [23-1](#)

### Denial of Service. See DoS.

### denied attackers

adding [18-2](#)  
 clearing [18-2](#)  
 deleting [18-2](#)  
 hit count [18-1](#)  
 resetting hit counts [18-2](#)  
 viewing hit counts [18-2](#)  
 viewing list [18-2](#)

### Denied Attackers pane

described [18-1](#)  
 field descriptions [18-2](#)  
 user roles [18-1](#)  
 using [18-2](#)

### deny actions (list) [10-3, 10-15, 12-8](#)

### Deny Packet Inline described [12-10](#)

### detect mode (anomaly detection) [13-4](#)

### device access issues [C-42](#)

### Device Details pane described [2-1](#)

### Device List pane

described [2-1](#)  
 field descriptions [2-2](#)



## Device Login Profiles pane

- configuring [16-13](#)
- described [16-12](#)
- field descriptions [16-12](#)

## devices

- adding [2-4](#)
- deleting [2-4](#)
- editing [2-4](#)

## device tools

- DNS lookup [2-6](#)
- ping [2-6](#)
- traceroute [2-6](#)
- whois [2-6](#)

## Diagnostics Report pane

- button functions [21-21](#)
- described [21-21](#)
- user roles [21-20](#)
- using [21-21](#)

diagnostics reports [21-21](#)

Differences between knowledge bases KB\_Name and KB\_Name window field descriptions [21-11](#)

## disabling

- anomaly detection [13-35, C-21](#)
- blocking [16-8](#)
- event action filters [8-23, 12-17](#)
- global correlation [14-12](#)
- interfaces [7-20](#)
- password recovery [20-13, C-16](#)
- signatures [10-17](#)

disaster recovery [C-6](#)

## displaying

- events [21-3, C-103](#)
- health status [C-81](#)
- imported OS maps [21-17](#)
- inspection load statistics [21-5](#)
- interface statistics [21-6](#)
- learned OS maps [21-16](#)
- password recovery setting [20-14, C-16](#)
- sensor statistics [21-22](#)

statistics [C-89](#)

tech support information [C-82](#)

version [C-86](#)

Distributed Denial of Service. See DDoS.

DNS lookup device tool (IME) [1-4, 2-6, 3-15, 3-16, 22-6](#)

## DoS tools

- Stacheldraht [B-72](#)
- stick [B-7](#)
- TFN [B-72](#)

downgrade command [27-10](#)

downgrading sensors [27-10](#)

## downloading

- Cisco software [26-1](#)
- KBs [21-15](#)

Download Knowledge Base From Sensor dialog box

- described [21-15](#)
- field descriptions [21-15](#)

duplicate IP addresses [C-30](#)

---

**E**

Edit ACL Entry dialog box field descriptions [5-3](#)

Edit Allowed Host dialog box

- field descriptions [6-6](#)
- user roles [6-5](#)

Edit Authorized RSA1 Key dialog box

- field descriptions [15-5](#)
- user roles [15-4](#)

Edit Authorized RSA Key dialog box

- field descriptions [15-3](#)
- user roles [15-2](#)

Edit Blocking Device dialog box

- field descriptions [16-15](#)
- user roles [16-14](#)

Edit Cat 6K Blocking Device Interface dialog box

- field descriptions [16-22](#)
- user roles [16-21](#)

Edit Configured OS Map dialog box

- field descriptions [8-32, 12-26](#)

- user roles [8-31, 12-23](#)
- Edit Destination Port dialog box
  - field descriptions [13-17, 13-23, 13-30](#)
  - user roles [13-15](#)
- Edit Device dialog box field descriptions [2-3](#)
- Edit Device Login Profile dialog box
  - field descriptions [16-12](#)
  - user roles [16-12](#)
- Edit Event Action Filter dialog box
  - field descriptions [8-22, 12-16](#)
  - user roles [12-15](#)
- Edit Event Action Override dialog box
  - field descriptions [8-12, 12-13](#)
  - user roles [8-12, 12-13](#)
- Edit Event Variable dialog box
  - field descriptions [8-35, 12-29](#)
  - user roles [8-34, 12-28](#)
- Edit External Product Interface dialog box
  - field descriptions [19-6](#)
  - user roles [19-4](#)
- Edit Filter dialog box field descriptions [3-19](#)
- Edit Histogram dialog box
  - field descriptions [13-17, 13-24, 13-30](#)
  - user roles [13-15](#)
- editing
  - blocking devices [16-15](#)
  - event action filters [8-23, 12-17](#)
  - event action overrides [12-14](#)
  - event variables [8-36, 12-29](#)
  - interfaces [7-21](#)
  - IPv4 target value ratings [8-26, 12-20](#)
  - IPv6 target value ratings [8-28, 12-22](#)
  - OS maps [8-33, 12-27](#)
  - rate limiting devices [16-15](#)
  - risk categories [8-38, 12-32](#)
  - signatures [10-20](#)
  - signature variables [10-37](#)
  - virtual sensors [8-13](#)
- Edit Inline VLAN Pair dialog box
  - field descriptions [7-24](#)
  - user roles [7-23](#)
- Edit Inline VLAN Pair Entry dialog box field descriptions [5-10](#)
- Edit Interface dialog box
  - field descriptions [7-20](#)
  - user roles [7-18](#)
- Edit Interface Pair dialog box
  - field descriptions [7-22](#)
  - user roles [7-22](#)
- Edit IP Logging dialog box field descriptions [18-11](#)
- Edit Known Host RSA1 Key dialog box
  - field descriptions [15-9](#)
  - user roles [15-8](#)
- Edit Known Host RSA Key dialog box
  - field descriptions [15-7](#)
  - user roles [15-6](#)
- Edit Master Blocking Sensor dialog box
  - field descriptions [16-25](#)
  - user roles [16-24](#)
- Edit Never Block Address dialog box
  - field descriptions [16-10](#)
  - user roles [16-7](#)
- Edit Posture ACL dialog box field descriptions [19-7](#)
- Edit Protocol Number dialog box field descriptions [13-18, 13-25, 13-32](#)
- Edit Risk Level dialog box
  - field descriptions [8-38, 12-31](#)
  - user roles [8-37, 12-31](#)
- Edit Router Blocking Device Interface dialog box
  - field descriptions [16-19](#)
  - user roles [16-17](#)
- Edit Signature dialog box field descriptions [10-12](#)
- Edit Signature Variable dialog box
  - field descriptions [10-36](#)
  - user roles [10-36](#)
- Edit SNMP Trap Destination dialog box
  - field descriptions [17-5](#)

- user roles [17-4](#)
- Edit Start Time dialog box
  - field descriptions [13-14](#)
  - user roles [13-12](#)
- Edit Target Value Rating dialog box
  - field descriptions [8-26, 8-28](#)
  - user roles [8-26, 8-27](#)
- Edit User dialog box
  - field descriptions [6-22](#)
  - user roles [6-19, 6-22](#)
- Edit Virtual Sensor dialog box
  - field descriptions [8-10](#)
  - user roles [8-10](#)
- Edit VLAN Group dialog box
  - field descriptions [7-27](#)
  - user roles [7-26](#)
- efficacy
  - described [14-4](#)
  - measurements [14-4](#)
- email notification
  - configuring (IME) [1-16](#)
  - example (IME) [1-15](#)
- email setup (IME) [1-14](#)
- Email Setup dialog box
  - configuring [1-14](#)
  - described [1-14](#)
  - field descriptions [1-14](#)
- enabling
  - anomaly detection [13-4](#)
  - event action filters [8-23, 12-17](#)
  - event action overrides [12-14](#)
  - interfaces [7-20](#)
  - packet logging [20-3](#)
  - signatures [10-17](#)
- enabling debug logging [C-47](#)
- Encryption Software Export Distribution Authorization form
  - cryptographic account [26-2](#)
  - described [26-2](#)
- engines
  - AIC [B-10](#)
  - AIC FTP [B-11](#)
  - AIC HTTP [B-11](#)
  - Atomic ARP [B-13](#)
  - Atomic IP [11-13, B-24](#)
  - Atomic IP Advanced [B-14](#)
  - Atomic IPv6 [B-27](#)
  - Fixed [B-28](#)
  - Fixed ICMP [B-28](#)
  - Fixed TCP [B-28](#)
  - Fixed UDP [B-28](#)
  - Flood [B-31](#)
  - Flood Host [B-31](#)
  - Flood Net [B-31](#)
  - Master [B-4](#)
  - Meta [10-25, B-32](#)
  - Multi String [B-34](#)
  - Normalizer [B-36](#)
  - Service [B-39](#)
  - Service DNS [B-39](#)
  - Service FTP [B-41](#)
  - Service Generic [B-42](#)
  - Service H225 [B-43](#)
  - Service HTTP [11-16, B-46](#)
  - Service IDENT [B-48](#)
  - Service MSRPC [11-11, B-48](#)
  - Service MSSQL [B-50](#)
  - Service NTP [B-51](#)
  - Service P2P [B-52](#)
  - Service RPC [11-19, B-52](#)
  - Service SMB Advanced [B-54](#)
  - Service SNMP [B-56](#)
  - Service SSH [B-57](#)
  - Service TNS [B-57](#)
  - State [11-20, B-59](#)
  - String [11-21, 11-24, B-61](#)
  - String ICMP [11-21, 11-24, B-61](#)
  - String TCP [11-21, 11-24, B-61](#)

- String UDP [11-21, 11-24, B-61](#)
- Sweep [11-24, B-66](#)
- Sweep Other TCP [B-69](#)
- Traffic Anomaly [B-69](#)
- Traffic ICMP [B-72](#)
- Trojan [B-72](#)
- EPS
  - described [1-3](#)
  - IME Home pane [1-3](#)
- erase license-key command [20-19](#)
- errors (Analysis Engine) [C-55](#)
- evAlert [A-9](#)
- event action filters
  - adding [8-23, 12-17](#)
  - configuring [8-23, 12-17](#)
  - deleting [8-23, 12-17](#)
  - described [8-20, 12-4](#)
  - disabling [8-23, 12-17](#)
  - editing [8-23, 12-17](#)
  - enabling [8-23, 12-17](#)
  - moving [8-23, 12-17](#)
- Event Action Filters tab
  - configuring [8-23, 12-17](#)
  - described [8-21, 12-15](#)
  - field descriptions [8-21, 12-15](#)
- event action overrides
  - adding [12-14](#)
  - deleting [12-14](#)
  - described [8-5, 12-4](#)
  - editing [12-14](#)
  - enabling [12-14](#)
  - risk rating range [8-5, 12-4](#)
- Event Action Overrides tab
  - described [12-13](#)
  - field descriptions [12-13](#)
- Event Action Rules (rules0) pane described [12-13](#)
- Event Action Rules pane
  - described [12-2, 12-11](#)
  - field descriptions [12-12](#)
  - user roles [12-11](#)
- event action rules policies
  - adding [12-12](#)
  - cloning [12-12](#)
  - deleting [12-12](#)
- event action rules variables [8-21, 12-15](#)
- event actions
  - risk ratings [8-6, 12-4](#)
  - threat ratings [8-6, 12-4](#)
- event connection status
  - displaying [2-5](#)
  - starting [2-5](#)
  - stopping [2-5](#)
- Event Monitoring pane
  - described [22-1](#)
  - filters [22-2](#)
- events
  - clearing [6-16, 21-4, C-105](#)
  - color rules [22-2](#)
  - displaying [C-103](#)
  - grouping [22-2](#)
  - host posture [19-2](#)
  - quarantined IP address [19-2](#)
- Events pane
  - configuring [21-3](#)
  - described [21-1](#)
  - field descriptions [21-2](#)
- events per second. See EPS.
- Event Store
  - clearing [6-16, 21-4, C-105](#)
  - clearing events [6-12, C-19](#)
  - data structures [A-8](#)
  - described [A-4](#)
  - examples [A-8](#)
  - no alerts [C-34](#)
  - responsibilities [A-7](#)
  - time stamp [6-12, C-19](#)
  - timestamp [A-7](#)
- event types [C-102](#)

## event variables

- adding [8-36, 12-29](#)
- configuring [8-36, 12-29](#)
- deleting [8-36, 12-29](#)
- described [8-34, 12-28](#)
- editing [8-36, 12-29](#)
- example [8-35, 12-29](#)

## Event Variables tab

- configuring [8-36, 12-29](#)
- field descriptions [8-35, 12-29](#)

## Event Viewer pane

- displaying events [21-3](#)
- field descriptions [21-3](#)

## event views

- creating [22-4](#)
- using [22-4](#)

evError [A-9](#)evLogTransaction [A-9](#)evShunRqst [A-9](#)evStatus [A-9](#)

## example custom signatures

- Atomic IP Advanced [10-29, 11-14](#)
- Meta [10-26](#)
- Service HTTP [11-17](#)
- String TCP [11-22](#)
- String TCP XL [10-31](#)

## examples

- AIC engine signature [10-48](#)
- ASA failover configuration [C-63, C-69, C-74](#)
- Atomic IP Advanced engine signature [10-29, 11-14](#)
- automatic update [20-25](#)
- configured OS maps [8-31, 12-24](#)
- default anomaly detection configuration [13-4](#)
- email notification (IME) [1-15](#)
- email notifications (IME) [1-17](#)
- IP Fragment Reassembly signature [10-52](#)
- IPv6 attacker address [8-22, 12-16](#)
- IPV6 victim address [8-22, 12-16](#)
- KB histogram [13-13, 21-8](#)

Meta engine signature [10-26](#)Service HTTP engine signature [11-17](#)SPAN configuration for IPv6 support [7-15](#)String TCP engine signature [11-22](#)String TCP XL engine signature [10-31, 10-34](#)System Configuration Dialog [25-2](#)TCP Stream Reassembly signature [10-59](#)

## external product interfaces

- adding [19-7](#)
- described [19-1](#)
- issues [19-3, C-24](#)
- troubleshooting [19-10, C-24](#)
- trusted hosts [19-4](#)

## External Product Interfaces pane

- described [19-4](#)
- field descriptions [19-5](#)

## external zone

- configuring [13-32](#)
- protocols [13-29](#)

## External Zone tab

- described [13-29](#)
- tabs [13-29](#)
- user roles [13-29](#)

---

**F**
fail-over testing [7-10](#)false positives described [10-2](#)Fields tab described [22-2](#)files Cisco IPS (list) [26-1](#)Filtered Events vs All Events Reports described [1-19, 23-2](#)filtering described [22-2](#)Filter pane field descriptions [22-3](#)

## filters

- configuring [3-16, 22-6](#)
- creating reports [23-3](#)

Fixed engine described [B-28](#)Fixed ICMP engine parameters (table) [B-29](#)Fixed TCP engine parameters (table) [B-29](#)

Fixed UDP engine parameters (table) [B-30](#)

Flood engine described [B-31](#)

Flood Host engine parameters (table) [B-31](#)

Flood Net engine parameters (table) [B-32](#)

flow states clearing [21-19](#)

FTP servers

automatic updates [20-22](#)

signature updates [20-27](#)

FTP servers and software updates [20-23, 27-2](#)

## G

gadgets

adding [3-1](#)

Attacks Over Time [3-13](#)

deleting [3-1](#)

Global Correlation Health [3-7](#)

Global Correlation Reports [3-6](#)

Interface Status [3-5](#)

Licensing [3-5](#)

Network Security [3-8](#)

RSS Feed [3-11](#)

Sensor Health [3-3](#)

Sensor Information [3-2](#)

Top Applications [3-9](#)

Top Attackers [3-11](#)

Top Signatures [3-13](#)

Top Victims [3-12](#)

General dialog box

configuring [1-11](#)

described [1-11](#)

field descriptions [1-11](#)

user roles [1-11](#)

general settings

configuring [8-41, 12-34](#)

described [8-40, 12-33](#)

General tab

configuring [8-41, 12-34](#)

described [8-40, 12-33, 13-16, 13-23](#)

described (IME) [22-2](#)

enabling zones [13-16, 13-23](#)

field descriptions [8-41, 12-34, 13-16, 13-23](#)

user roles [8-40, 12-33](#)

generating diagnostics reports [21-21](#)

global correlation [23-2](#)

described [1-2, 14-1, 14-2](#)

disabling [14-12](#)

disabling about [14-12](#)

DNS server [14-6](#)

error messages [A-29](#)

features [14-5](#)

goals [14-5](#)

health metrics [14-7](#)

health status [14-7](#)

HTTP proxy server [14-6](#)

license [6-3, 14-6, 14-8, 25-1, 25-5](#)

no IPv6 support [8-23, 8-28, 8-36, 14-6](#)

Produce Alert [10-2, 10-14, 12-8](#)

requirements [14-6](#)

risk rating [14-5](#)

shared policies [9-1](#)

troubleshooting [14-11, C-23](#)

update client (illustration) [14-8](#)

global correlation connection status

displaying [2-5](#)

starting [2-5](#)

stopping [2-5](#)

Global Correlation Health gadget

configuring [3-8](#)

described [3-7](#)

Global Correlation Reports described [23-2](#)

Global Correlation Reports gadget

configuring [3-6](#)

described [3-6](#)

Global Correlation Update

client described [A-28](#)

server described [A-28](#)

Group By tab described [22-2](#)

grouping events [22-2](#)  
 GRUB menu password recovery [20-5, C-8](#)

## H

H.225.0 protocol [B-43](#)  
 H.323 protocol [B-43](#)  
 hardware bypass  
     autonegotiation [7-11](#)  
     configuration restrictions [7-10](#)  
     fail-over [7-10](#)  
     IPS 4260 [7-10](#)  
     IPS 4270-20 [7-10](#)  
     reimage [7-11](#)  
     supported configurations [7-10](#)  
     with software bypass [7-10](#)  
 health connection status  
     displaying [2-5](#)  
     starting [2-5](#)  
     stopping [2-5](#)  
 health status  
     global correlation [14-7](#)  
     metrics [3-4](#)  
     sensor [3-3](#)  
 health status display [C-81](#)  
 host blocks  
     adding [18-4](#)  
     deleting [18-4](#)  
     managing [18-4](#)  
 Host Blocks pane  
     configuring [18-4](#)  
     described [18-3](#)  
     field descriptions [18-3](#)  
     user roles [18-3](#)  
 host posture events  
     CSA MC [19-3](#)  
     described [19-2](#)  
 HTTP/HTTPS servers supported [20-23, 27-2](#)

HTTP advanced decoding  
     described [8-4](#)  
     platform support [8-5](#)  
     restrictions [8-4](#)  
 HTTP deobfuscation  
     ASCII normalization [11-16, B-46](#)  
     described [11-16, B-46](#)  
 hw-module module 1 reset command [C-64](#)  
 hw-module module slot\_number password-reset  
 command [20-7, 20-11, C-10, C-14](#)

## IDAPI

communications [A-4, A-32](#)  
 described [A-4](#)  
 functions [A-32](#)  
 illustration [A-32](#)  
 responsibilities [A-32](#)

## IDCONF

described [A-33](#)  
 example [A-33](#)  
 RDEP2 [A-33](#)  
 XML [A-33](#)

## IDIOM

defined [A-33](#)  
 messages [A-33](#)

## IDM

Analysis Engine is busy [C-59](#)  
 certificates [15-11](#)  
 Custom Signature Wizard supported signature  
 engines [11-2](#)  
 TLS [15-11](#)  
 will not load [C-58](#)  
 illegal zone configuring [13-25](#)  
 Illegal Zone tab  
     described [13-22](#)  
     user roles [13-22](#)

## IME

- color rules [22-2](#)
  - Color Rules tab [22-2](#)
  - configuring
    - automatic reporting [1-19](#)
    - email notification [1-16](#)
    - filters [3-16, 22-6](#)
    - RSS feeds [4-2](#)
    - views [3-16, 22-6](#)
  - cryptographic features [1-2](#)
  - dashboards
    - adding [3-1](#)
    - deleting [3-1](#)
  - Demo mode [1-7](#)
  - described [1-1](#)
  - devices
    - adding [2-4](#)
    - deleting [2-4](#)
    - editing [2-4](#)
  - email notification example [1-17](#)
  - EPS [1-3](#)
  - event connection status
    - displaying [2-5](#)
    - starting [2-5](#)
    - stopping [2-5](#)
  - Event Monitoring pane [22-1](#)
  - Fields tab [22-2](#)
  - filtering [22-2](#)
  - gadgets
    - adding [3-1](#)
    - deleting [3-1](#)
  - General tab [22-2](#)
  - global correlation connection status
    - displaying [2-5](#)
    - starting [2-5](#)
    - stopping [2-5](#)
  - Group By tab [22-2](#)
  - grouping events [22-2](#)
  - health connection status
    - displaying [2-5](#)
    - starting [2-5](#)
    - stopping [2-5](#)
  - installation error [1-20, C-61](#)
  - installation notes and caveats [1-8](#)
  - installing [1-8](#)
  - IPS versions [1-6](#)
  - known host key retrieval [15-6, 15-7, 15-8, 15-9](#)
  - menu features [1-4](#)
  - MySQL database [1-8](#)
  - password recovery [20-13, C-16](#)
  - password requirements [1-10](#)
  - reports
    - configuring [23-3](#)
    - described [23-1](#)
    - generating [23-3](#)
  - report types [23-1](#)
  - supported platforms [1-5](#)
  - system requirements [1-4](#)
  - using event views [22-4](#)
  - video help [1-3](#)
  - working with
    - top attacker IP addresses [3-14](#)
    - top signatures [3-15](#)
    - top victim IP addresses [3-14](#)
- IME Home pane
- described [1-3](#)
  - EPS [1-3](#)
  - features [1-3](#)
- IME time synchronization problems [C-61](#)
- Imported OS pane
- clearing [21-18](#)
  - described [21-17](#)
  - field descriptions [21-18](#)
- imported OS values
- clearing [21-18](#)
  - deleting [21-18](#)
- inactive mode (anomaly detection) [13-4](#)



- initializing
  - appliances [25-8](#)
  - ASA 5500 AIP SSM [25-13](#)
  - ASA 5500-X IPS SSP [25-17](#)
  - ASA 5585-X IPS SSP [25-21](#)
  - sensors [6-1, 25-1, 25-4](#)
  - verifying [25-24](#)
- inline interface pair mode
  - configuration restrictions [7-12](#)
  - described [7-15](#)
  - illustration [7-16](#)
- Inline Interface Pair window
  - described [5-9](#)
  - Startup Wizard [5-9](#)
- inline mode
  - interface cards [7-3](#)
  - normalization [8-4](#)
  - pairing interfaces [7-3](#)
- inline TCP session tracking modes described [8-4](#)
- inline VLAN pair mode
  - configuration restrictions [7-12](#)
  - configuring [5-10](#)
  - described [7-16](#)
  - illustration [7-17](#)
  - supported sensors [7-16](#)
- Inline VLAN Pairs window
  - described [5-9](#)
  - field descriptions [5-10](#)
  - Startup Wizard [5-9](#)
- Inspection/Reputation pane
  - configuring [14-9](#)
  - described [14-8](#)
  - field descriptions [14-9](#)
- Inspection Load Statistics pane
  - configuring [21-5](#)
  - described [21-4](#)
  - field descriptions [21-4](#)
  - user roles [21-4](#)
- installer major version [26-5](#)
- installer minor version [26-5](#)
- installing
  - IME [1-8](#)
  - sensor license [20-17](#)
  - system image
    - ASA 5500 AIP SSM [27-27](#)
    - ASA 5500-X IPS SSP [27-29](#)
    - ASA 5585-X IPS SSP [27-31](#)
    - IPS 4240 [27-14](#)
    - IPS 4255 [27-14](#)
    - IPS 4260 [27-17](#)
    - IPS 4270-20 [27-19](#)
    - IPS 4345 [27-22](#)
    - IPS 4360 [27-22](#)
    - IPS 4510 [27-25](#)
    - IPS 4520 [27-25](#)
- IntelliShield
  - alerts [10-10](#)
  - MySDN [10-10](#)
- InterfaceApp
  - described [A-20](#)
  - interactions [A-20](#)
  - NIC drivers [A-20](#)
- InterfaceApp described [A-4](#)
- interface pairs
  - configuring [7-23](#)
  - described [7-22](#)
- Interface Pairs pane
  - configuring [7-23](#)
  - described [7-22](#)
  - field descriptions [7-22](#)
  - user roles [7-22](#)
- interfaces
  - alternate TCP reset [7-2](#)
  - command and control [7-2](#)
  - configuration restrictions [7-11](#)
  - configuring [7-20](#)
  - described [5-7, 7-1](#)
  - disabling [7-20](#)

- editing [7-21](#)
  - enabling [7-20](#)
  - logical [5-7](#)
  - physical [5-7](#)
  - port numbers [7-1](#)
  - sensing [7-2, 7-3](#)
  - slot numbers [7-1](#)
  - support (table) [7-4](#)
  - TCP reset [7-8](#)
- Interface Selection window
  - described [5-9](#)
  - Startup Wizard [5-9](#)
- Interfaces pane
  - configuring [7-20](#)
  - described [7-19](#)
  - field descriptions [7-19](#)
  - user roles [7-18](#)
- Interface Statistics pane
  - configuring [21-6](#)
  - described [21-5](#)
  - field descriptions [21-6](#)
- Interface Status gadget
  - configuring [3-6](#)
  - described [3-5](#)
- Interface Summary window
  - described [5-7](#)
  - field descriptions [5-8](#)
- internal zone configuring [13-19](#)
- Internal Zone tab
  - described [13-15](#)
  - user roles [13-15](#)
- IP fragmentation described [B-36](#)
- IP fragment reassembly
  - configuring [10-51](#)
  - described [10-49](#)
  - mode [10-51](#)
  - parameters (table) [10-50](#)
  - signatures [10-52](#)
  - signatures (example) [10-52](#)
  - signatures (table) [10-50](#)
- IP logging
  - described [10-60, 18-10](#)
  - event actions [18-11](#)
  - system performance [18-10, 18-11](#)
- IP Logging pane
  - configuring [18-12](#)
  - described [18-11](#)
  - field descriptions [18-11](#)
  - user roles [18-11](#)
- IP Logging Variables pane
  - described [20-21](#)
  - field description [20-22](#)
  - user roles [20-21](#)
- IP logs
  - circular buffer [18-10](#)
  - states [18-10](#)
  - TCPDUMP [18-10](#)
  - viewing [18-12](#)
  - WireShark [18-10](#)
- IPS 4240
  - 7200 series router [C-26](#)
  - installing system image [27-14](#)
  - password recovery [20-6, C-9](#)
  - reimaging [27-14](#)
- IPS 4255
  - installing system image [27-14](#)
  - password recovery [20-6, C-9](#)
  - reimaging [27-14](#)
- IPS 4260
  - hardware bypass [7-10](#)
  - installing system image [27-17](#)
  - password recovery [C-8](#)
  - reimaging [27-17](#)
- IPS 4270-20
  - hardware bypass [7-10](#)
  - installing system image [27-19](#)
  - password recovery [20-5, C-8](#)
  - reimaging [27-19](#)

- IPS 4345
  - installing system image [27-22](#)
  - password recovery [20-5, 20-6, C-8, C-9](#)
  - reimaging [27-21](#)
- IPS 4360
  - installing system image [27-22](#)
  - password recovery [20-5, C-8, C-9](#)
  - reimaging [27-21](#)
- IPS 4510
  - installing system image [27-25](#)
  - password recovery [20-5, 20-6, C-8, C-9](#)
  - reimaging [27-25](#)
  - SwitchApp [A-30](#)
- IPS 4520
  - installing system image [27-25](#)
  - password recovery [20-5, 20-6, C-8, C-9](#)
  - reimaging [27-25](#)
  - SwitchApp [A-30](#)
- IPS applications
  - summary [A-36](#)
  - table [A-36](#)
  - XML format [A-4](#)
- IPS clock synchronization [6-11, C-18](#)
- IPS data
  - types [A-8](#)
  - XML document [A-9](#)
- IPS events
  - evAlert [A-9](#)
  - evError [A-9](#)
  - evLogTransaction [A-9](#)
  - evShunRqst [A-9](#)
  - evStatus [A-9](#)
  - list [A-9](#)
  - types [A-9](#)
- IPS internal communications [A-32](#)
- IPS Manager Express described [1-1](#)
- IPS Policies pane
  - described [8-8](#)
  - Event Action Rules [8-9](#)
  - field descriptions [8-9](#)
- IPS software
  - application list [A-4](#)
  - available files [26-1](#)
  - configuring device parameters [A-5](#)
  - directory structure [A-35](#)
  - Linux OS [A-1](#)
  - obtaining [26-1](#)
  - retrieving data [A-5](#)
  - security features [A-5](#)
  - tuning signatures [A-5](#)
  - updating [A-5](#)
  - user interaction [A-5](#)
  - versioning scheme [26-3](#)
- IPS software file names
  - major updates (illustration) [26-4](#)
  - minor updates (illustration) [26-4](#)
  - patch releases (illustration) [26-4](#)
  - service packs (illustration) [26-4](#)
- IPS versions supported (IME) [1-6](#)
- IPv4
  - address format [8-34, 12-28](#)
  - event variables [8-34, 12-28](#)
- IPv4 Add Target Value Rating dialog box
  - field descriptions [12-20](#)
  - user roles [12-20](#)
- IPv4 Edit Target Value Rating dialog box
  - field descriptions [12-20](#)
  - user roles [12-20](#)
- IPv4 target value ratings
  - adding [8-26, 12-20](#)
  - deleting [8-26, 12-20](#)
  - editing [8-26, 12-20](#)
- IPv4 Target Value Rating tab
  - configuring [8-26, 12-20](#)
  - field descriptions [8-26, 12-20](#)
- IPv6
  - address format [8-35, 12-28](#)
  - described [B-28](#)

event variables [8-35, 12-28](#)

SPAN ports [7-14](#)

switches [7-14](#)

IPv6 Add Target Value Rating dialog box

field descriptions [12-22](#)

user roles [12-21](#)

IPv6 Edit Target Value Rating dialog box

field descriptions [12-22](#)

user roles [12-21](#)

IPv6 target value ratings

adding [8-28, 12-22](#)

configuring [8-28, 12-22](#)

deleting [8-28, 12-22](#)

editing [8-28, 12-22](#)

IPv6 Target Value Rating tab

configuring [8-28, 12-22](#)

field descriptions [8-27, 12-21](#)

## K

KBs

comparing [21-12](#)

default filename [13-12](#)

deleting [21-14](#)

described [13-3](#)

downloading [21-15](#)

histogram [13-12, 21-8](#)

initial baseline [13-3](#)

learning accept mode [13-12](#)

loading [21-13](#)

monitoring [21-10](#)

renaming [21-14](#)

saving [21-13](#)

scanner threshold [13-12, 21-8](#)

tree structure [13-12, 21-8](#)

uploading [21-16](#)

Knowledge Base. See KB.

Known Host RSA1 Keys pane

configuring [15-9](#)

described [15-8](#)

field descriptions [15-9](#)

Known Host RSA Keys pane

configuring [15-7](#)

described [15-6](#)

field descriptions [15-7](#)

## L

Learned OS pane

clearing [21-17](#)

described [21-16](#)

field descriptions [21-17](#)

learned OS values

clearing [21-17](#)

deleting [21-17](#)

learning accept mode

anomaly detection [13-3](#)

configuring [13-14](#)

Learning Accept Mode tab

described [13-12](#)

field descriptions [13-14](#)

user roles [13-12](#)

license key

obtaining [20-15](#)

trial [20-15](#)

uninstalling [20-19](#)

viewing status of [20-15](#)

licensing

described [20-15](#)

IPS device serial number [20-15](#)

Licensing gadget

configuring [3-5](#)

described [3-5](#)

Licensing pane

configuring [20-17](#)

described [20-15](#)

field descriptions [20-16](#)

user roles [20-15](#)

limitations for concurrent CLI sessions [24-1](#)

listings UNIX-style [20-23](#)

loading KBs [21-13](#)

local authentication configuring [6-23](#)

Logger

described [A-4, A-19](#)

functions [A-19](#)

syslog messages [A-19](#)

logging in

appliances [24-2](#)

ASA 5500 AIP SSM [24-4](#)

ASA 5500-X IPS SSP [24-5](#)

ASA 5585-X IPS SSP [24-6](#)

sensors

SSH [24-7](#)

Telnet [24-7](#)

service role [24-2](#)

terminal servers [24-3, 27-13](#)

user role [24-1](#)

LOKI

described [B-72](#)

protocol [B-72](#)

loose connections on sensors [C-25](#)

## M

MainApp

components [A-6](#)

described [A-4, A-6](#)

host statistics [A-6](#)

responsibilities [A-6](#)

show version command [A-6](#)

major updates described [26-3](#)

Manage Filter Rules dialog box field descriptions [3-18](#)

managing

host blocks [18-4](#)

network blocks [18-7](#)

rate limiting [18-9](#)

manifests

client [A-29](#)

server [A-29](#)

manually updating sensor [20-27](#)

master blocking sensor

described [16-24](#)

not set up properly [C-46](#)

verifying configuration [C-46](#)

Master Blocking Sensor pane

configuring [16-25](#)

described [16-24](#)

field descriptions [16-25](#)

Master engine

alert frequency [B-7](#)

alert frequency parameters (table) [B-7](#)

described [B-4](#)

event actions [12-8, B-8](#)

general parameters (table) [B-4](#)

universal parameters [B-4](#)

master engine parameters

obsoletes [B-6](#)

promiscuous delta [B-6](#)

vulnerable OSES [B-6](#)

merging configuration files [C-2](#)

Meta engine

described [10-25, B-32](#)

parameters (table) [B-33](#)

Signature Event Action Processor [10-25, B-32](#)

Meta Event Generator described [8-40, 12-33](#)

Meta signature

component signatures [B-32](#)

metrics for sensor health [20-20](#)

MIBs supported [17-6, C-20](#)

minor updates described [26-3](#)

Miscellaneous tab

application policy parameters [10-38](#)

configuring

application policy [10-48](#)

IP fragment reassembly mode [10-51](#)

- IP logging [10-60](#)
  - TCP stream reassembly mode [10-58](#)
- described [10-38](#)
- field descriptions [10-39](#)
- IP fragment reassembly options [10-38](#)
- IP logging options [10-39](#)
- TCP stream reassembly [10-38](#)
- user roles [10-38](#)
- modes
  - anomaly detection detect [13-4](#)
  - anomaly detection learning accept [13-3](#)
  - asymmetric [8-4](#)
  - bypass [7-29](#)
  - inactive (anomaly detection) [13-4](#)
  - inline interface pair [7-15](#)
  - inline TCP tracking [8-4](#)
  - inline VLAN pair [7-16](#)
  - Normalizer [8-4](#)
  - promiscuous [7-14](#)
  - VLAN groups [7-17](#)
- monitoring
  - displaying statistics [21-6](#)
  - events [21-3](#)
  - inspection load statistics [21-4, 21-5](#)
  - KBs [21-10](#)
- moving
  - event action filters [8-23, 12-17](#)
  - OS maps [8-33, 12-27](#)
- Multi String engine
  - described [B-34](#)
  - parameters (table) [B-35](#)
  - Regex [B-34](#)
- MySDN
  - described [10-10](#)
  - IntelliShield [10-11](#)
- MySQL database
  - coexisting with IME [1-8](#)
  - installing IME [1-8](#)

## N

- NAS-ID
  - described [6-23](#)
  - RADIUS authentication [6-23](#)
- Neighborhood Discovery
  - options [B-28](#)
  - types [B-28](#)
- network blocks
  - adding [18-7](#)
  - deleting [18-7](#)
  - managing [18-7](#)
- Network Blocks pane
  - configuring [18-7](#)
  - described [18-6](#)
  - field descriptions [18-6](#)
  - user roles [18-6](#)
- Network pane
  - configuring [6-3](#)
  - described [6-2](#)
  - field descriptions [6-2](#)
  - TLS/SSL [6-4](#)
  - user roles [6-2](#)
- network participation
  - data gathered [14-3](#)
  - data use (table) [1-3, 14-2](#)
  - described [14-3](#)
  - health metrics [14-7](#)
  - modes [14-4](#)
  - requirements [14-3](#)
  - SensorBase Network [14-4](#)
  - statistics [14-4](#)
- network participation data
  - improving signature fidelity [14-4](#)
  - understanding sensor deployment [14-4](#)
- Network Participation pane
  - configuring [14-11](#)
  - described [14-10](#)
  - field descriptions [14-10](#)

## Network Security gadget

configuring [3-9](#)

described [3-8](#)

## never block

hosts [16-7](#)

networks [16-7](#)

normalization described [8-4](#)

## Normalizer engine

ASA 5500 AIP SSM [B-37](#)

ASA 5500-X IPS SSP [B-37](#)

ASA 5585-X IPS SSP [B-37](#)

described [B-36](#)

IP fragment reassembly [B-36](#)

IPv6 fragments [B-36](#)

modify packets inline [8-4](#)

parameters (table) [B-38](#)

TCP stream reassembly [B-36](#)

## NotificationApp

alert information [A-9](#)

described [A-4](#)

functions [A-9](#)

SNMP gets [A-9](#)

SNMP traps [A-9](#)

statistics [A-11](#)

system health information [A-10](#)

## Notifications dialog box

configuring [1-16](#)

field descriptions [1-15](#)

## NTP

authenticated [6-10, 6-14, C-17](#)

configuring servers [6-13](#)

described [6-11, C-17](#)

incorrect configuration [6-11, C-18](#)

sensor time source [6-13, 6-14](#)

time synchronization [6-11, C-17](#)

unauthenticated [6-10, 6-14, C-17](#)

verifying configuration [6-11](#)

## O

Obfuscated Traffic/Attacks reports described [23-2](#)

obsoletes field described [B-6](#)

## obtaining

cryptographic account [26-2](#)

IPS software [26-1](#)

license key [20-15](#)

sensor license [20-17](#)

one-way TCP reset described [8-40, 12-34](#)

## Operation Settings tab

described [13-11](#)

field descriptions [13-11](#)

user roles [13-11](#)

## OS Identifications tab

described [8-31, 12-23](#)

field descriptions [8-32, 12-25](#)

OS information sources [8-30, 12-24](#)

## OS maps

adding [8-33, 12-27](#)

configuring [8-33, 12-27](#)

deleting [8-33, 12-27](#)

editing [8-33, 12-27](#)

moving [8-33, 12-27](#)

other actions (list) [10-4, 10-16, 12-9](#)

## Other Protocols tab

described [13-18, 13-25, 13-31](#)

enabling other protocols [13-18](#)

external zone [13-31](#)

field descriptions [13-18, 13-31](#)

illegal zone [13-25](#)

## P

P2P networks described [B-52](#)

## Packet Logging pane

described [20-3](#)

field descriptions [20-3](#)

## partitions

- application [A-4](#)
- recovery [A-5](#)

## passive OS fingerprinting

- components [8-30, 12-24](#)
- configuring [8-31, 12-25](#)
- described [8-30, 12-24](#)
- enabled (default) [8-31, 12-25](#)

password policy caution [20-2, 20-3](#)

## password recovery

- appliances [20-5, C-8](#)
- ASA 5500 AIP SSM [20-7, 20-11, C-10](#)
- ASA 5500-X IPS SSP [20-9, C-12](#)
- ASA 5585-X IPS SSP [C-14](#)
- CLI [20-13, C-16](#)
- described [20-4, C-8](#)
- disabling [20-13, C-16](#)
- displaying setting [20-14, C-16](#)
- GRUB menu [20-5, C-8](#)
- IME [20-13, C-16](#)
- IPS 4240 [20-6, C-9](#)
- IPS 4255 [20-6, C-9](#)
- IPS 4260 [C-8](#)
- IPS 4270-20 [20-5, C-8](#)
- IPS 4345 [20-5, 20-6, C-8, C-9](#)
- IPS 4360 [20-5, C-8, C-9](#)
- IPS 4510 [20-5, 20-6, C-8, C-9](#)
- IPS 4520 [20-5, 20-6, C-8, C-9](#)
- platforms [20-4, C-8](#)
- ROMMON [20-6, C-9](#)
- troubleshooting [20-14, C-17](#)
- verifying [20-14, C-16](#)

password requirements configuring [20-2](#)

## Passwords pane

- configuring [20-2](#)
- described [20-1](#)
- field descriptions [20-2](#)

patch releases described [26-3](#)peacetime learning (anomaly detection) [13-3](#)

## Peer-to-Peer. See P2P.

physical connectivity issues [C-33](#)physical interfaces configuration restrictions [7-11](#)ping device tool (IME) [1-4, 2-6, 3-15, 3-16, 22-6](#)platforms concurrent CLI sessions [24-1](#)

## policy groups

- described [9-4](#)
- managing [9-4](#)

Post-Block ACLs [16-17, 16-18](#)Pre-Block ACLs [16-17, 16-18](#)prerequisites for blocking [16-5](#)

## promiscuous delta

- calculating risk rating [8-6, 12-3](#)
- described [8-6, 12-3](#)

promiscuous delta described [B-6](#)

## promiscuous mode

- atomic attacks [7-14](#)
- described [7-14](#)
- illustration [7-14](#)
- packet flow [7-14](#)
- SPAN ports [7-14](#)
- TCP reset interfaces [7-8](#)
- VACL capture [7-14](#)

## protocols

- ARP [B-13](#)
- CDP [7-31](#)
- CIDEE [A-34](#)
- DCE [11-11, B-48](#)
- DDoS [B-72](#)
- H.323 [B-43](#)
- H225.0 [B-43](#)
- ICMPv6 [B-14](#)
- IDAPI [A-32](#)
- IDCONF [A-33](#)
- IDIOM [A-33](#)
- IPv6 [B-28](#)
- LOKI [B-72](#)
- MSSQL [B-50](#)
- Neighborhood Discovery [B-28](#)



Q.931 [B-43](#)  
 RPC [11-11, B-48](#)  
 SDEE [A-34](#)  
 Signature Wizard [11-10](#)

## Q

Q.931 protocol  
     described [B-43](#)  
     SETUP messages [B-43](#)  
 quarantined IP address events described [19-2](#)

## R

### RADIUS

    attempt limit [C-23](#)  
     multiple cisco av-pairs [6-21, 6-24](#)

### RADIUS authentication

    configuring [6-23](#)  
     described [6-19](#)  
     NAS-ID [6-23](#)  
     service account [6-18](#)  
     shared secret [6-24](#)

### rate limiting

    ACLs [16-5](#)  
     configuring [18-9](#)  
     described [16-4](#)  
     managing [18-9](#)  
     percentages [18-8](#)  
     routers [16-4](#)  
     service policies [16-5](#)  
     supported signatures [16-4](#)

### rate limiting devices

    adding [16-15](#)  
     deleting [16-15](#)  
     editing [16-15](#)

### rate limits

    adding [18-9](#)

    deleting [18-9](#)

### Rate Limits pane

    configuring [18-9](#)  
     described [18-7](#)  
     field descriptions [18-8](#)

### raw expression syntax

    described [B-63](#)  
     expert mode [B-63](#)

### Raw Regex

    described [10-32, 10-35, B-63](#)  
     expert mode [10-32, 10-35, B-63](#)

### rebooting the sensor [20-30](#)

### Reboot Sensor pane

    configuring [20-30](#)  
     described [20-30](#)  
     user roles [20-29](#)

### receiving RSS feeds (IME) [4-1](#)

### recover command [27-11](#)

### recovering

    application partition image [27-11](#)  
     ASA 5500 AIP SSM [C-64](#)

### recovery partition

    described [A-5](#)  
     upgrade [27-6](#)

### Regex

    Multi String engine [B-34](#)  
     standardized [10-5, B-1](#)

### Regular Expression. See also Regex.

### regular expression syntax

    raw Regex [10-32, 10-35, B-63](#)  
     signatures [B-9](#)

### reimaging

    ASA 5500-X IPS SSP [27-29](#)  
     described [27-1](#)  
     hardware bypass [7-11](#)  
     IPS 4240 [27-14](#)  
     IPS 4255 [27-14](#)  
     IPS 4260 [27-17](#)  
     IPS 4270-20 [27-19](#)

- IPS 4345 [27-21](#)
- IPS 4360 [27-21](#)
- IPS 4510 [27-25](#)
- IPS 4520 [27-25](#)
- sensors [27-1, 27-11](#)
- removing
  - last applied
    - service pack [27-10](#)
    - signature update [27-10](#)
- Rename Knowledge Base dialog box field descriptions [21-14](#)
- renaming KBs [21-14](#)
- reports
  - configuring [23-3](#)
  - customizing [23-3](#)
  - described [23-1](#)
  - generating [23-3](#)
  - using filters [23-3](#)
- Reports dialog box
  - configuring [1-19](#)
  - field descriptions [1-18](#)
- report types [23-2](#)
  - attacks over time [1-18, 23-2](#)
  - demo [23-1](#)
  - filtered events vs all events [1-19, 23-2](#)
  - obfuscated traffic/attacks [23-2](#)
  - top attackers [1-18, 23-1](#)
  - top signatures [1-18, 23-2](#)
  - top victim [1-18, 23-2](#)
  - user-defined [23-1](#)
- reputation
  - described [14-2](#)
  - illustration [14-3](#)
  - servers [14-3](#)
- requirements passwords (IME) [1-10](#)
- Reset Network Security Health pane
  - described [21-20](#)
  - field descriptions [21-20](#)
  - resetting data [21-20](#)
  - user roles [21-20](#)
- reset not occurring for a signature [C-53](#)
- resetting
  - ASA 5500 AIP SSM [C-64](#)
  - hit counts for denied attackers [18-2](#)
  - network security health data [21-20](#)
  - passwords
    - ASDM [20-9, 20-10, 20-13, C-12, C-13, C-15](#)
    - hw-module command [20-7, 20-11, C-10, C-14](#)
    - sw-module command [20-9, C-12](#)
- resetting the password
  - ASA 5500 AIP SSM [20-7, 20-11, C-10](#)
  - ASA 5500-X IPS SSP [20-9, C-12](#)
  - ASA 5585-X IPS SSP [C-14](#)
- Restore Default Interface dialog box field descriptions [5-8](#)
- Restore Defaults pane
  - configuring [20-29](#)
  - described [20-29](#)
  - user roles [20-29](#)
- restoring
  - current configuration [C-4](#)
  - defaults [20-29](#)
- retiring signatures [10-17](#)
- risk categories
  - adding [8-38, 12-32](#)
  - configuring [8-38, 12-32](#)
  - deleting [8-38, 12-32](#)
  - editing [8-38, 12-32](#)
- Risk Category tab
  - configuring [8-38, 12-32](#)
  - described [8-37, 12-31](#)
  - field descriptions [8-38, 12-31](#)
- risk rating
  - Alarm Channel [14-5](#)
  - calculating [8-5, 12-2](#)
  - component signatures [B-32](#)
  - described [8-30, 12-24](#)
  - global correlation [14-5](#)

- reputation score [14-5](#)
  - ROMMON
    - ASA 5585-X IPS SSP [27-33](#)
    - described [27-13](#)
    - IPS 4240 [20-6, 27-14, C-9](#)
    - IPS 4255 [20-6, 27-14, C-9](#)
    - IPS 4260 [27-17](#)
    - IPS 4270-20 [27-19](#)
    - IPS 4345 [20-6, 27-22, C-9](#)
    - IPS 4360 [27-22, C-9](#)
    - IPS 4510 [20-6, 27-25, C-9](#)
    - IPS 4520 [20-6, 27-25, C-9](#)
    - password recovery [20-6, C-9](#)
    - remote sensors [27-13](#)
    - serial console port [27-13](#)
    - TFTP [27-13](#)
  - round-trip time. See RTT.
  - Router Blocking Device Interfaces pane
    - configuring [16-20](#)
    - described [16-17](#)
    - field descriptions [16-19](#)
  - RPC portmapper [11-19, B-52](#)
  - RSS Feed gadgets
    - configuring [3-11](#)
    - described [3-11](#)
  - RSS feeds
    - channels [4-1](#)
    - configuring [4-2](#)
    - described [4-1](#)
    - formats [4-1](#)
    - receiving [4-1](#)
  - RTT
    - described [27-13](#)
    - TFTP limitation [27-13](#)
  - field descriptions [21-13](#)
  - saving KBs [21-13](#)
  - scheduling automatic upgrades [27-9](#)
  - SDEE
    - described [A-34](#)
    - HTTP [A-34](#)
    - protocol [A-34](#)
    - server requests [A-34](#)
  - security
    - account locking [6-25](#)
    - information on Cisco Security Intelligence Operations [26-7](#)
    - information on MySDN [10-10](#)
    - SSH [15-1](#)
  - security policies described [8-1, 10-1, 12-1, 13-1](#)
  - sensing interface
    - ASA 5500 AIP SSM [8-15](#)
    - ASA 5500-X IPS SSP [8-15](#)
    - ASA 5585-X IPS SSP [8-15](#)
  - sensing interfaces
    - Analysis Engine [7-3](#)
    - described [7-3](#)
    - interface cards [7-3](#)
    - modes [7-3](#)
  - SensorApp
    - Alarm Channel [A-24](#)
    - Analysis Engine [A-24](#)
    - described [A-4](#)
    - event action filtering [A-25](#)
    - inline packet processing [A-24](#)
    - IP normalization [A-25](#)
    - packet flow [A-26](#)
    - processors [A-23](#)
    - responsibilities [A-23](#)
    - risk rating [A-25](#)
    - Signature Event Action Processor [A-23](#)
    - signature updates [20-23](#)
    - TCP normalization [A-25](#)
- 
- ## S
- Save Knowledge Base dialog box
    - described [21-13](#)

- SensorBase Network
  - described [1-2, 14-1, 14-2](#)
  - network participation [14-4](#)
  - participation [1-2, 14-2](#)
  - servers [1-2, 14-2](#)
- sensor health
  - critical settings [20-20](#)
  - metrics [20-20](#)
- Sensor Health gadget
  - configuring [3-4](#)
  - described [3-3](#)
  - metrics [3-4](#)
  - status [3-4](#)
- Sensor Health pane
  - described [20-20](#)
  - field descriptions [20-21](#)
  - user roles [20-20](#)
- Sensor Information gadget
  - configuring [3-3](#)
  - described [3-2](#)
- Sensor Key pane
  - button functions [15-11](#)
  - described [15-11](#)
  - field descriptions [15-11](#)
  - sensor SSH host key
    - displaying [15-11](#)
    - generating [15-11](#)
  - user roles [15-10](#)
- sensor license
  - installing [20-17](#)
  - obtaining [20-17](#)
- sensors
  - access problems [C-27](#)
  - application partition image [27-11](#)
  - asymmetric traffic and disabling anomaly detection [13-35, C-21](#)
  - blocking self [16-8](#)
  - command and control interfaces (list) [7-2](#)
  - configuring to use NTP [6-14](#)
  - corrupted SensorApp configuration [C-37](#)
  - diagnostics reports [21-21](#)
  - disaster recovery [C-6](#)
  - downgrading [27-10](#)
  - incorrect NTP configuration [6-11, C-18](#)
  - initializing [6-1, 25-1, 25-4](#)
  - interface support [7-4](#)
  - IP address conflicts [C-30](#)
  - logging in
    - SSH [24-7](#)
    - Telnet [24-7](#)
  - loose connections [C-25](#)
  - misconfigured access lists [C-29](#)
  - no alerts [C-34, C-60](#)
  - not seeing packets [C-36](#)
  - NTP time source [6-14](#)
  - NTP time synchronization [6-11, C-17](#)
  - partitions [A-4](#)
  - physical connectivity [C-33](#)
  - preventive maintenance [C-2](#)
  - rebooting [20-30](#)
  - reimaging [27-1](#)
  - restoring defaults [20-29](#)
  - sensing process not running [C-31](#)
  - setup command [6-1, 25-1, 25-4, 25-8](#)
  - shutting down [20-30](#)
  - statistics [21-22](#)
  - system information [21-23](#)
  - time sources [6-10, C-17](#)
  - troubleshooting software upgrades [C-57](#)
  - updating [20-27](#)
  - upgrading [27-4](#)
  - using NTP time source [6-13](#)
- Sensor Setup window
  - described [5-2](#)
  - Startup Wizard [5-2](#)
- Server Certificate pane
  - button functions [15-16](#)

- certificate
  - displaying [15-16](#)
  - generating [15-16](#)
- described [15-16](#)
- field descriptions [15-16](#)
- user roles [15-16](#)
- server manifest described [A-29](#)
- service account
  - accessing [6-18, C-5](#)
  - cautions [6-18, C-5](#)
  - creating [C-5](#)
  - described [6-18, A-31, C-5](#)
  - RADIUS authentication [6-18](#)
  - TAC [A-31](#)
  - troubleshooting [A-31](#)
- Service DNS engine
  - described [B-40](#)
  - parameters (table) [B-40](#)
- Service engine
  - described [B-39](#)
  - Layer 5 traffic [B-39](#)
- Service FTP engine
  - described [B-41](#)
  - parameters (table) [B-41](#)
  - PASV port spoof [B-41](#)
- Service Generic engine
  - described [B-42](#)
  - no custom signatures [B-42](#)
  - parameters (table) [B-42](#)
- Service H225 engine
  - ASN.1PER validation [B-44](#)
  - described [B-43](#)
  - features [B-44](#)
  - parameters (table) [B-44](#)
  - TPKT validation [B-44](#)
- Service HTTP engine
  - custom signature [11-17](#)
  - described [11-16, B-46](#)
  - example signature [11-17](#)
  - parameters (table) [B-46](#)
- Service IDENT engine
  - described [B-48](#)
  - parameters (table) [B-48](#)
- Service MSRPC engine
  - DCS/RPC protocol [11-11, B-48](#)
  - described [11-11, B-48](#)
  - parameters (table) [B-49](#)
- Service MSSQL engine
  - described [B-50](#)
  - MSSQL protocol [B-50](#)
  - parameters (table) [B-51](#)
- Service NTP engine
  - described [B-51](#)
  - parameters (table) [B-51](#)
- Service P2P engine described [B-52](#)
- service packs described [26-3](#)
- service role [6-17, 24-2, A-31](#)
- Service RPC engine
  - described [11-19, B-52](#)
  - parameters (table) [B-52](#)
  - RPC portmapper [11-19, B-52](#)
- Service SMB Advanced engine
  - described [B-54](#)
  - parameters (table) [B-54](#)
- Service SNMP engine
  - described [B-56](#)
  - parameters (table) [B-56](#)
- Service SSH engine
  - described [B-57](#)
  - parameters (table) [B-57](#)
- Service TNS engine
  - described [B-57](#)
  - parameters (table) [B-58](#)
- session command
  - ASA 5500 AIP SSM [24-4](#)
  - ASA 5500-X IPS SSP [24-5](#)
  - ASA 5585-X IPS SSP [24-6](#)

- sessioning in
  - ASA 5500 AIP SSM [24-4](#)
  - ASA 5500-X IPS SSP [24-5](#)
  - ASA 5585-X IPS SSP [24-6](#)
- setting
  - current KB [21-13](#)
  - system clock [6-16](#)
- setting up
  - IME email notification [1-14](#)
  - terminal servers [24-3, 27-13](#)
- setup
  - automatic [25-2](#)
  - command [6-1, 25-1, 25-4, 25-8, 25-13, 25-17, 25-21](#)
  - simplified mode [25-2](#)
- shared policies
  - adding [9-3](#)
  - deleting [9-3](#)
  - deploying [9-3](#)
  - described [9-1](#)
  - restrictions [9-2](#)
- shared secret
  - described [6-24](#)
  - RADIUS authentication [6-24](#)
- show events command [C-102](#)
- show health command [C-81](#)
- show interfaces command [C-100](#)
- show module 1 details command [C-63, C-69, C-75](#)
- show settings command [20-14, C-16](#)
- show statistics command [C-88, C-89](#)
- show statistics virtual-sensor command [C-26, C-89](#)
- show tech-support command [C-81, C-82](#)
- show version command [C-85, C-86](#)
- Shut Down Sensor pane
  - configuring [20-30](#)
  - described [20-30](#)
  - user roles [20-30](#)
- shutting down the sensor [20-30](#)
- sig0 pane
  - column heads [10-9](#)
  - configuration buttons [10-10](#)
  - default [10-9](#)
  - described [10-9](#)
  - field descriptions [10-11](#)
  - signatures
    - assigning actions [10-21](#)
    - cloning [10-19](#)
    - tuning [10-20](#)
  - tabs [10-9](#)
- signature definition policies
  - adding [10-8](#)
  - cloning [10-8](#)
  - default policy [10-7](#)
  - deleting [10-8](#)
  - sig0 [10-7](#)
- Signature Definitions pane
  - described [10-7](#)
  - field descriptions [10-8](#)
- signature engines
  - AIC [B-10](#)
  - Atomic [B-13](#)
  - Atomic ARP [B-13](#)
  - Atomic IP [11-13, B-24](#)
  - Atomic IP Advanced [B-14](#)
  - Atomic IPv6 [B-27](#)
  - creating custom signatures [11-1](#)
  - described [10-4, B-1](#)
  - Fixed [B-28](#)
  - Flood [B-31](#)
  - Flood Host [B-31](#)
  - Flood Net [B-32](#)
  - list [10-5, B-2](#)
  - Master [B-4](#)
  - Meta [10-25, B-32](#)
  - Multi String [B-34](#)
  - Normalizer [B-36](#)
  - Regex
    - patterns [B-10](#)
    - syntax [B-9](#)

- Service [B-39](#)
- Service DNS [B-40](#)
- Service FTP [B-41](#)
- Service Generic [B-42](#)
- Service H225 [B-43](#)
- Service HTTP [11-16, B-46](#)
- Service IDENT [B-48](#)
- Service MSRPC [11-11, B-48](#)
- Service MSSQL [B-50](#)
- Service NTP [B-51](#)
- Service P2P [B-52](#)
- Service RPC [11-19, B-52](#)
- Service SMB Advanced [B-54](#)
- Service SNMP [B-56](#)
- Service SSH engine [B-57](#)
- Service TNS [B-57](#)
- State [11-20, B-59](#)
- String [11-21, 11-24, B-61](#)
- supported by IDM [11-2](#)
- Sweep [11-24, B-66](#)
- Sweep Other TCP [B-69](#)
- Traffic Anomaly [B-69](#)
- Traffic ICMP [B-72](#)
- Trojan [B-72](#)
- Signature Event Action Filter
  - described [12-6, A-26](#)
  - parameters [12-6, A-26](#)
- Signature Event Action Handler described [12-6, A-27](#)
- Signature Event Action Override described [12-6, A-26](#)
- Signature Event Action Processor
  - Alarm Channel [12-6, A-26](#)
  - components [12-6, A-26](#)
  - described [12-6, A-23, A-26](#)
- signature fidelity rating
  - calculating risk rating [8-5, 12-3](#)
  - described [8-5, 12-2](#)
- signatures
  - adding [10-17](#)
  - alert frequency [10-23](#)
  - assigning actions [10-21](#)
  - cloning [10-19](#)
  - custom [10-2](#)
  - default [10-2](#)
  - described [10-1](#)
  - disabling [10-17](#)
  - editing [10-20](#)
  - enabling [10-17](#)
  - false positives [10-2](#)
  - rate limits [16-4](#)
  - retiring [10-17](#)
  - String TCP XL [10-34](#)
  - subsignatures [10-2](#)
  - TCP reset [C-53](#)
  - tuned [10-2](#)
  - tuning [10-20](#)
- Signatures window
  - field descriptions [5-15](#)
  - user roles [5-14](#)
- Signatures window described [5-14](#)
- signature threat profiles
  - applying [5-15](#)
  - platform support [5-14](#)
- signature updates
  - bypass mode [20-24](#)
  - files [26-4](#)
  - FTP server [20-27](#)
  - installation time [20-23](#)
  - SensorApp [20-23](#)
- signature variables
  - adding [10-37](#)
  - configuring [10-37](#)
  - deleting [10-37](#)
  - described [10-36](#)
  - editing [10-37](#)
- Signature Variables tab
  - configuring [10-37](#)
  - field descriptions [10-36](#)

- Signature Wizard
  - protocols [11-10](#)
  - signature identification [11-11](#)
- SNMP
  - configuring [17-3](#)
  - described [17-1](#)
  - General Configuration pane
    - field descriptions [17-2](#)
    - user roles [17-2](#)
  - Get [17-1](#)
  - GetNext [17-1](#)
  - Set [17-1](#)
  - supported MIBs [17-6, C-20](#)
  - Trap [17-1](#)
  - Traps Configuration pane
    - field descriptions [17-4](#)
    - user roles [17-4](#)
- SNMP General Configuration pane
  - configuring [17-3](#)
  - described [17-2](#)
- SNMP traps
  - configuring [17-5](#)
  - described [17-1](#)
- software architecture
  - ARC (illustration) [A-13](#)
  - IDAPI (illustration) [A-32](#)
- software bypass
  - supported configurations [7-10](#)
  - with hardware bypass [7-10](#)
- software downloads Cisco.com [26-1](#)
- software file names
  - recovery (illustration) [26-5](#)
  - signature/virus updates (illustration) [26-4](#)
  - system image (illustration) [26-5](#)
- software release examples
  - platform identifiers [26-6](#)
  - platform-independent [26-5](#)
- software updates
  - supported FTP servers [20-23, 27-2](#)
  - supported HTTP/HTTPS servers [20-23, 27-2](#)
- SPAN port issues [C-33](#)
- specialized [23-2](#)
- Specialized Reports described [23-2](#)
- SSH
  - described [15-1](#)
  - security [15-1](#)
- SSH Server
  - private keys [A-22](#)
  - public keys [A-22](#)
- standards
  - CIDEE [A-34](#)
  - IDCONF [A-33](#)
  - IDIOM [A-33](#)
  - SDEE [A-34](#)
- Startup Wizard
  - access lists [5-3](#)
  - adding ACLs [5-5](#)
  - adding virtual sensors [5-13](#)
  - Add Virtual Sensor dialog box [5-12](#)
  - Auto Update configuring [5-17](#)
  - described [5-1](#)
  - Inline Interface Pair window
    - described [5-9](#)
    - field descriptions [5-9](#)
  - Inline VLAN Pairs window configuring [5-10](#)
  - Interface Selection window [5-9](#)
  - Interface Summary window [5-7](#)
  - Sensor Setup window
    - configuring [5-4](#)
    - described [5-2](#)
    - field descriptions [5-2](#)
  - Signatures window described [5-14](#)
  - Traffic Inspection Mode window [5-8](#)
  - Virtual Sensors window
    - field descriptions [5-11](#)
  - Virtual Sensors window described [5-11](#)
  - VLAN groups unsupported [5-1, 5-7](#)



## State engine

Cisco Login [11-20, B-59](#)described [11-20, B-59](#)LPR Format String [11-20, B-59](#)parameters (table) [B-59](#)SMTP [11-20, B-59](#)statistic display [C-89](#)

## Statistics pane

button functions [21-22, 21-23](#)categories [21-21](#)described [21-21](#)using [21-22](#)statistics viewing [21-22](#)String engine described [11-21, 11-24, B-61](#)String ICMP engine parameters (table) [B-61](#)

## String TCP engine

custom signature [11-22](#)example signature [11-22](#)parameters (table) [B-61](#)String TCP XL signature (example) [10-31, 10-34](#)String UDP engine parameters (table) [B-62](#)

## String XL engine

description [B-63](#)hardware support [10-6, 11-3, B-3, B-63](#)parameters (table) [B-64](#)unsupported parameters [B-66](#)subinterface 0 described [7-17](#)subsignatures described [10-2](#)

## summarization

described [8-7, 12-5](#)Fire All [8-7, 12-5](#)Fire Once [8-8, 12-5](#)Global Summarization [8-8, 12-5](#)Meta engine [8-7, 12-5](#)Summary [8-8, 12-5](#)Summarizer described [8-40, 12-33](#)

## Summary pane

described [7-18](#)field descriptions [7-18](#)

## supported

FTP servers [20-23, 27-2](#)HTTP/HTTPS servers [20-23, 27-2](#)IPS interfaces for CSA MC [19-3](#)platforms for IME [1-5](#)supported sensors for signature threat profiles [5-14](#)Sweep engine [11-25, B-67](#)described [11-24, B-66](#)parameters (table) [B-67](#)

Sweep Other TCP engine

described [B-69](#)parameters (table) [B-69](#)SwitchApp described [A-30](#)switches and TCP reset interfaces [7-9](#)sw-module module slot\_number password-reset  
command [20-9, C-12](#)

## system architecture

directory structure [A-35](#)supported platforms [A-1](#)system clock setting [6-16](#)system components IDAPI [A-32](#)

## System Configuration Dialog

described [25-2](#)example [25-2](#)system design (illustration) [A-2](#)

## system image

## installing

ASA 5500 AIP SSM [27-27](#)ASA 5500-X IPS SSP [27-29](#)IPS 4240 [27-14](#)IPS 4255 [27-14](#)IPS 4260 [27-17](#)IPS 4270-20 [27-19](#)IPS 4345 [27-22](#)IPS 4360 [27-22](#)

## system images

## installing

IPS 4510 [27-25](#)IPS 4520 [27-25](#)

## System Information pane

described [21-22](#)using [21-23](#)system information viewing [21-23](#)system requirements for IME [1-4](#)**T**

## TAC

contact information [21-22](#)service account [6-18, A-31, C-5](#)show tech-support command [C-82](#)troubleshooting [A-31](#)

## target value rating

calculating risk rating [8-6, 12-3](#)described [8-6, 8-26, 8-27, 12-3, 12-20, 12-21](#)TCP fragmentation described [B-36](#)

## TCP Protocol tab

described [13-16, 13-23, 13-29](#)enabling TCP [13-16](#)external zone [13-29](#)field descriptions [13-16, 13-23, 13-30](#)illegal zone [13-23](#)

## TCP reset interfaces

conditions [7-9](#)described [7-8](#)list [7-8](#)promiscuous mode [7-8](#)switches [7-9](#)TCP resets not occurring [C-53](#)

## TCP stream reassembly

described [10-52](#)mode [10-58](#)parameters (table) [10-53](#)signatures (table) [10-53](#)tech support information display [C-82](#)terminal server setup [24-3, 27-13](#)testing fail-over [7-10](#)

## TFN2K

described [B-72](#)Trojans [B-72](#)

## TFTP servers

maximum file size limitation [27-13](#)RTT [27-13](#)

## Threat Category tab

described [8-39, 12-32](#)field descriptions [8-39, 12-33](#)

## threat rating

described [8-6, 12-4](#)risk rating [8-6, 12-4](#)

## Thresholds for KB Name window

described [21-9](#)field descriptions [21-10](#)filtering information [21-10](#)

## time

correction on the sensor [6-12, C-19](#)sensors [6-10, C-17](#)synchronizing IPS clocks [6-11, C-18](#)

## Time pane

configuring [6-9](#)described [6-7](#)field descriptions [6-7](#)user roles [6-7](#)

## time sources

appliances [6-10, C-17](#)ASA 5500 AIP SSM [6-11, C-18](#)ASA 5500-X IPS SSP [6-11, C-18](#)ASA 5585-X IPS SSP [6-11, C-18](#)

## TLS

described [6-4](#)handshaking [15-12](#)IDM [15-11](#)web server [15-11](#)

## Top Applications gadget

configuring [3-9](#)described [3-9](#)Top Attacker Reports described [1-18, 23-1](#)

- Top Attackers gadgets
  - configuring [3-12](#)
  - described [3-11](#)
- Top Signature Reports described [1-18, 23-2](#)
- Top Signatures gadgets
  - configuring [3-13](#)
  - described [3-13](#)
- Top Victim Reports described [1-18, 23-2](#)
- Top Victims gadgets
  - configuring [3-12](#)
  - described [3-12](#)
- traceroute device tool (IME) [1-4, 2-6, 3-15, 3-16, 22-6](#)
- Traffic Anomaly engine
  - described [B-69](#)
  - protocols [B-69](#)
  - signatures [B-69](#)
- traffic flow notifications
  - configuring [7-31](#)
  - described [7-30](#)
- Traffic Flow Notifications pane
  - configuring [7-31](#)
  - field descriptions [7-30](#)
  - user roles [7-30](#)
- Traffic ICMP engine
  - DDoS [B-72](#)
  - described [B-72](#)
  - LOKI [B-72](#)
  - parameters (table) [B-72](#)
  - TFN2K [B-72](#)
- Traffic Inspection Mode window described [5-8](#)
- Traps Configuration pane
  - configuring [17-5](#)
  - described [17-4](#)
- trial license key [20-15](#)
- Tribe Flood Network. See TFN.
- Tribe Flood Network 2000. See TFN2K.
- Trojan engine
  - BO2K [B-72](#)
  - described [B-72](#)
  - TFN2K [B-72](#)
- Trojans
  - BO [B-72](#)
  - BO2K [B-72](#)
  - LOKI [B-72](#)
  - TFN2K [B-72](#)
- troubleshooting
  - Analysis Engine busy [C-59](#)
  - applying software updates [C-55](#)
  - ARC
    - blocking not occurring for signature [C-45](#)
    - device access issues [C-42](#)
    - enabling SSH [C-44](#)
    - inactive state [C-40](#)
    - misconfigured master blocking sensor [C-46](#)
    - verifying device interfaces [C-43](#)
  - ASA 5500 AIP SSM
    - commands [C-63](#)
    - debugging [C-64](#)
    - failover scenarios [C-62](#)
    - recovering [C-64](#)
    - reset [C-64](#)
  - ASA 5500-X IPS SSP
    - commands [C-69](#)
    - failover scenarios [C-68](#)
  - ASA 5585-X IPS SSP
    - commands [C-75](#)
    - failover scenarios [C-73](#)
    - traffic flow stopped [C-75](#)
  - automatic updates [C-56](#)
  - cannot access sensor [C-27](#)
  - cidDump [C-105](#)
  - cidLog messages to syslog [C-52](#)
  - communication [C-27](#)
  - corrupted SensorApp configuration [C-37](#)
  - debug logger zone names (table) [C-51](#)
  - debug logging [C-47](#)
  - disaster recovery [C-6](#)
  - duplicate sensor IP addresses [C-30](#)

- enabling debug logging [C-47](#)
- external product interfaces [19-10, C-24](#)
- gathering information [C-80](#)
- global correlation [14-11, C-23](#)
- IDM
  - cannot access sensor [C-59](#)
  - will not load [C-58](#)
- IME
  - installation error [1-20, C-61](#)
- IME time synchronization [C-61](#)
- IPS clock time drift [6-11, C-18](#)
- misconfigured access list [C-29](#)
- no alerts [C-34, C-60](#)
- password recovery [20-14, C-17](#)
- physical connectivity issues [C-33](#)
- preventive maintenance [C-2](#)
- RADIUS
  - attempt limit [C-23](#)
- reset not occurring for a signature [C-53](#)
- sensing process not running [C-31](#)
- sensor events [C-102](#)
- sensor loose connections [C-25](#)
- sensor not seeing packets [C-36](#)
- sensor software upgrade [C-57](#)
- service account [6-18, C-5](#)
- show events command [C-102](#)
- show interfaces command [C-100](#)
- show tech-support command [C-81, C-83](#)
- show version command [C-85](#)
- software upgrades [C-55](#)
- SPAN port issue [C-33](#)
- upgrading [C-55](#)
- verifying Analysis Engine is running [C-22](#)
- verifying ARC status [C-39](#)

Trusted Hosts pane

- configuring [15-13](#)
- described [15-13](#)
- field descriptions [15-13](#)

Trusted Root Certificates pane

- configuring [15-15](#)
- described [15-14](#)
- field descriptions [15-15](#)

tuned signatures described [10-2](#)

tuning

- AIC signatures [10-48](#)
- IP fragment reassembly signatures [10-52](#)
- signatures [10-20](#)
- TCP fragment reassembly signatures [10-59](#)

---

## U

UDP Protocol tab

- described [13-17, 13-24, 13-31](#)
- enabling UDP [13-17](#)
- external zone [13-31](#)
- field descriptions [13-17, 13-31](#)
- illegal zone [13-24](#)

unassigned VLAN groups described [7-17](#)

unauthenticated NTP [6-10, 6-14, C-17](#)

uninstalling the license key [20-19](#)

UNIX-style directory listings [20-23](#)

unlocking accounts [6-26](#)

unlock user username command [6-26](#)

Update Sensor pane

- configuring [20-27](#)
- described [20-27](#)
- field descriptions [20-27](#)
- user roles [20-26](#)

updating

- trusted root certificates [15-15](#)

updating sensors [20-27](#)

upgrade command [27-3, 27-6](#)

upgrading

- application partition [27-11](#)
- latest version [C-55](#)
- recovery partition [27-6](#)
- sensors [27-4](#)

uploading KBs

FTP [21-15](#)

SCP [21-15](#)

Upload Knowledge Base to Sensor dialog box

described [21-15](#)

field descriptions [21-15](#)

URLs for Cisco Security Intelligence Operations [26-8](#)

user-defined reports described [23-1](#)

user roles authentication [6-19](#)

users configuring [6-22](#)

using

debug logging [C-47](#)

TCP reset interfaces [7-9](#)

## V

VACLs

described [16-3](#)

Post-Block [16-21](#)

Pre-Block [16-21](#)

verifying

NTP configuration [6-11](#)

password recovery [20-14, C-16](#)

sensor initialization [25-24](#)

sensor setup [25-24](#)

version display [C-86](#)

video help described [1-3](#)

viewing

denied attacker hit counts [18-2](#)

denied attackers list [18-2](#)

IP logs [18-12](#)

license key status [20-15](#)

statistics [21-22](#)

system information [21-23](#)

virtualization

advantages [8-3, C-19](#)

restrictions [8-3, C-19](#)

supported sensors [8-3, C-20](#)

traffic capture requirements [8-3, C-20](#)

virtual-sensor name command [8-16](#)

virtual sensors

adding [5-13, 8-13](#)

adding (ASA 5500 AIP SSM) [8-16](#)

adding (ASA 5500-X IPS SSP) [8-16](#)

adding (ASA 5585-X IPS SSP) [8-16](#)

ASA 5500 AIP SSM [8-18](#)

ASA 5500-X IPS SSP [8-18](#)

ASA 5585-X IPS SSP [8-18](#)

creating (ASA 5500 AIP SSM) [8-16](#)

creating (ASA 5500-X IPS SSP) [8-16](#)

creating (ASA 5585-X IPS SSP) [8-16](#)

default virtual sensor [8-2, 8-8](#)

deleting [8-13](#)

described [8-2, 8-8](#)

editing [8-13](#)

options [8-16](#)

Virtual Sensors window

described [5-11](#)

VLAN groups

802.1q encapsulation [7-17](#)

configuration restrictions [7-13](#)

configuring [7-27](#)

deploying [7-26](#)

switches [7-26](#)

VLAN IDs [7-26](#)

VLAN groups mode

described [7-17](#)

VLAN Groups pane

configuring [7-27](#)

described [7-26](#)

field descriptions [7-27](#)

user roles [7-26](#)

VLAN Pairs pane

configuring [7-25](#)

described [7-24](#)

field descriptions [7-24](#)

user roles [7-23](#)

vulnerable OSES field described [B-6](#)

---

## W

### watch list rating

calculating risk rating [8-6, 12-3](#)

described [8-6, 12-3](#)

### web server

described [A-4, A-23](#)

HTTP 1.0 and 1.1 support [A-23](#)

private keys [A-22](#)

public keys [A-22](#)

SDEE support [A-23](#)

TLS [15-11](#)

whois device tool (IME) [1-4, 2-6, 3-15, 3-16, 22-6](#)

### worms

Blaster [13-2](#)

Code Red [13-2](#)

histograms [13-13, 21-8](#)

Nimda [13-2](#)

protocols [13-3](#)

Sasser [13-2](#)

scanners [13-3](#)

Slammer [13-2](#)

SQL Slammer [13-2](#)

---

## Z

### zones

external [13-5](#)

illegal [13-5](#)

internal [13-5](#)