

Numerics

10BaseT cable pinouts appliance F-1802.1q encapsulation for VLAN groups 1-15

A

access control list. See ACL. accessing IPS software C-1 service account **E-5** access list misconfiguration E-26 actions ACL changes 1-2 IP logs 1-3 multiple packet drop 1-3 TCP reset 1-2 adaptive security appliance ASA 5585-X IPS SSP 5-2 models 5-2 alternate TCP reset interface configuration restrictions 1-11 designating 1-9 restrictions 1-5 Analysis Engine error messages E-23 errors **E-52** IDM exits E-55 sensing interfaces 1-6 verify it is running **E-20** anomaly detection disabling E-19

appliance cable pinouts (10BaseT) F-1 cable pinouts(10BaseT) F-1 appliances ACLs 1-2 described 1-18 GRUB menu E-8 initializing **B-8** logging in A-2 managers 1-18 models 1-18 password recovery **E-8** preparing for installation 2-1 restrictions 1-18 SPAN 1-18 TCP reset 1-2 terminal servers described 1-19, A-3, D-13 setting up 1-19, A-3, D-13 time sources 1-20, E-15 upgrading recovery partition **D-6** application partition image recovery **D-12** applying software updates E-52 ARC blocking not occurring for signature E-42 device access issues **E-39** enabling SSH E-41 inactive state **E-37** misconfigured master blocking sensor **E-43** troubleshooting E-36 verifying device interfaces **E-41** verifying status **E-36**

ASA 5500-X IPS SSP initializing **B-13** logging in A-4 memory usage **E-68** memory usage values (table) E-68 Normalizer engine E-67 password recovery E-10 resetting the password **E-10** session command A-4 sessioning in A-4 setup command **B-13** time soruces 1-20, E-16 ASA 5585-X slide rail kit hardware installation 4-20 ASA 5585-X IPS SSP adaptive security appliance **5-2** described 5-2 front panel indicators described 5-7 illustration 5-6 initializing **B-17** installing 5-10 installing system image D-22 interfaces 5-2, 5-3 introducing 5-2 logging in A-5 memory requirements **5-9** Normalizer engine E-74 password recovery E-12 reimaging D-21 removing 5-10, 5-14 requirements 5-4 resetting the password **E-12** session command A-5 sessioning in A-5 setup command **B-17** show module 1 command 5-13 slot 1 5-10 specifications 5-3

time sources 1-20, E-16 verifying status 5-14 ASA 5585-X SSP-10 with IPS SSP-10 described **5-2** memory requirements 5-9 ASA 5585-X SSP-20 with IPS SSP-20 described **5-3** memory requirements 5-9 ASA 5585-X SSP-40 with IPS SSP-40 described **5-3** memory requirements 5-9 ASA 5585-X SSP-60 with IPS SSP-60 described **5-3** memory requirements 5-9 ASA IPS modules jumbo packet count E-68, E-75 ASDM resetting passwords E-11, E-13 asymmetric traffic and disabling anomaly detection **E-18** attack responses for TCP resets 1-2 attempt limit RADIUS E-21 authenticated NTP 1-20, E-15 automatic setup **B-2** automatic upgrade information required **D-7** troubleshooting E-52 auto-upgrade-option command D-7

В

backing up configuration E-3 current configuration E-4 back panel features IPS 4345 3-7 IPS 4360 3-8 IPS 4510 4-6 IPS 4520 4-6 basic setup B-4

Cisco Intrusion Prevention System Appliance and Module Installation Guide for IPS 7.2

blocking not occurring for signature E-42 BST

described E-2

URL E-2

Bug Search Tool. See BST.

С

cable pinouts RJ-45 to DB-9 F-3 cannot access sensor E-24 cidDump obtaining information **E-101** circuit breaker warning 3-21 cisco default password A-2 default username A-2 Cisco.com accessing software C-1 downloading software C-1 software downloads C-1 Cisco ASA 5585-X described 5-2 installing ASA 5585-X IPS SSP 5-14 models 5-2 removing ASA 5585-X IPS SSP 5-14 Cisco Bug Search Tool described E-2 **Cisco Security Intelligence Operations** described C-8 URL C-8 Cisco Services for IPS service contract **C-9** supported products C-9 clear events command 1-21, E-17, E-101 clearing events E-101 statistics **E-85** CLI password recovery E-14 command and control interface

described 1-5 Ethernet 1-2 list 1-5 commands auto-upgrade-option D-7 clear events 1-21, E-17, E-101 copy backup-config E-3 copy current-config E-3 copy license-key **C-11** downgrade D-11 erase license-key C-14 hw-module module slot_number password-reset E-12 setup B-1, B-4, B-8, B-13, B-17 show events **E-98** show health E-76 show module 1 details E-59, E-71 show settings E-14 show statistics **E-84** show statistics virtual-sensor E-23, E-84 show tech-support E-77 show version **E-81** sw-module module slot_number password-reset E-10 upgrade D-4, D-6 configuration files backing up E-3 merging E-3 configuration restrictions alternate TCP reset interface 1-11 inline interface pairs 1-10 inline VLAN pairs 1-10 interfaces 1-10 physical interfaces 1-10 VLAN groups 1-11 configuring automatic upgrades D-9 upgrades D-5 connecting SFP/SFP+ modules 5-13 copy backup-config command E-3 copy current-config command E-3

copy license-key command C-11 correcting time on the sensor 1-21, E-17 creating the service account E-6 cryptographic account Encryption Software Export Distribution Authorization from C-2 obtaining C-2 current configuration back up E-3

D

DC power supply connecting (IPS 4360) 3-23 debug logging enable E-44 defaults password A-2 username A-2 device access issues **E-39** disabling anomaly detection **E-19** password recovery E-14 disaster recovery **E-6** displaying events **E-99** health status **E-76** password recovery setting E-14 statistics **E-85** tech support information **E-78** version **E-81** downgrade command **D-11** downgrading sensors D-11 downloading Cisco software C-1 duplicate IP addresses E-27

Е

electrical safety guidelines 2-3 enabling debug logging E-44 Encryption Software Export Distribution Authorization form cryptographic account C-2 described C-2 erase license-key command C-14 errors (Analysis Engine) E-52 ESD environment working in 2-4 events clearing E-101 displaying E-99 types E-97 Event Store clearing E-101 clearing events 1-21, E-17 no alerts E-31 time stamp 1-21, E-17 examples ASA failover configuration E-59, E-70 SPAN configuration for IPv6 support 1-13 System Configuration Dialog B-2 external product interfaces issues E-21 troubleshooting E-22

F

false positives filtering 1-4 tuning IPS 1-3 files Cisco IPS (list) C-1 front panel features IPS 4510 4-3 IPS 4520 4-3 front panel indicators ASA 5585-X IPS SSP 5-6 IPS 4345 3-6 IPS 4360 3-6 FTP servers and software updates D-3

G

global correlation license **B-5** troubleshooting **E-19** GRUB menu password recovery **E-8** guidelines electrical safety **2-3** power supplies **2-6**

Η

health status display E-76 HTTP/HTTPS servers supported D-3 hw-module module slot_number password-reset command E-12

IDM Analysis Engine is busy **E-55** described 4-2, 5-2 web browsers 4-2, 5-2 will not load **E-54** IME 10 devices 4-3, 5-2 described **4-3**, **5-2** password recovery **E-14** time synchronization problems **E-57** initializing appliances **B-8** ASA 5500-X IPS SSP **B-13** ASA 5585-X IPS SSP B-17 sensors **B-1**, **B-4** user roles **B-1** verifying **B-21** inline interface pair mode configuration restrictions 1-10 described 1-13

illustration 1-14 inline mode interface cards 1-6 pairing interfaces 1-6 inline VLAN pair mode configuration restrictions 1-10 described 1-14 illustration 1-15 supported sensors 1-14 installation preparation 2-1 installer major version C-5 installer minor version C-5 installing DC power supply (IPS 4360) 3-26 IPS 4345 3-12 IPS 4360 3-12 IPS 4510 4-11 IPS 4520 4-11 license key C-12 sensor license **C-10** SFP/SFP+ modules 5-13 system image ASA 5500-X IPS SSP **D-20** ASA 5585-X IPS SSP D-22 IPS 4345 D-14 IPS 4360 D-14 IPS 4510 D-18 IPS 4520 D-18 interfaces alternate TCP reset 1-5 command and control 1-5 configuration restrictions 1-10 described 1-4 port numbers 1-4 sensing 1-5, 1-6 slot numbers 1-4 support (table) 1-6 TCP reset 1-9

introducing ASA 5585-X IPS SSP 5-2 IPS 4345 3-2 IPS 4360 3-2 IPS 4510 4-2 IPS 4520 4-2 IPS appliances 1-18 Intrusion Prevention System Device Manager. See IDM. 4-2, 5-2 Intrusion Prevention System Manager Express. See IME. 5-2 Intrusion Prevention System Manager Express. See IME. 4-3 IPS restrictions 1-18 supported appliances 1-16 modules 1-16 tuning 1-3 **IPS 4345** AC power supply (V01) 3-15 back panel features 3-7 back panel features (illustration) 3-7 described 3-2 front panel (llustration) 3-5 front panel indicators described **3-6** indicators 3-6 installation 3-12 installing system image **D-14** packing box contents 3-4 password recovery E-8, E-9 power supplies 3-16 power supplies (illustration) 3-17 power supply indicator 3-17 rack mounting 3-10 reimaging **D-14** specifications 3-2 V01 power supply limitations 3-15

IPS 4360 AC power supply installing 3-19 removing 3-19 AC power supply (V02) 3-15 back panel features 3-8 back panel features (illustration) 3-8 connecting DC power supplies 3-23 described 3-2 front panel (illustration) 3-5 front panel indicators described 3-6 indicators 3-6 installation 3-12 installing DC power supplies 3-26 installing system image D-14 packing box contents 3-4 password recovery E-8, E-9 power supplies 3-16 power supplies(illustration) 3-17 power supply indicator 3-17 reimaging D-14 removing DC power supplies 3-26 specifications 3-2 V01 power supply limitations 3-15 IPS 4510 back panel features 4-6 back panel features (illustration) 4-6 cable management brackets described 4-33 installing 4-33 chassis features 4-3 connecting cables 4-11 described 4-2 Ethernet port indicators 4-7 fan modules hot-pluggable 4-18 installing 4-19 OIR **4-18** removing 4-19

front panel indicators described 4-5 illustration 4-4 front panel view 4-3 installing core IPS SSP 4-14 SFP/SFP+ modules 4-12 slide rail kit hardware 4-20 installing system image **D-18** Management 0/0 4-11 management port described 4-11 memory requirements 4-10 OIR fan supply modules 4-2 not supported 4-2 power supply modules 4-2 SFP/SFP+ 4-2 packing box contents 4-9 password recovery E-8, E-9 power module indicators described 4-7 illustration 4-6 power supply modules installing 4-17 removing 4-17 requirements 4-10 rack mounting 4-30 reimaging **D-18** removing core IPS SSP 4-14 SFP ports 4-12 slide rail kit hardware installation 4-20 specifications 4-8 supported SFP+ modules 4-11, 5-10 supported SFP modules 4-11, 5-10 SwitchApp 4-35 **IPS 4520** back panel features 4-6 back panel features (illustration) 4-6

cable management brackets described 4-33 installing 4-33 chassis features 4-3 connecting cables 4-11 described 4-2 Ethernet port indicators 4-7 fan modules hot-pluggable 4-18 installing 4-19 OIR **4-18** removing 4-19 front panel indicators described 4-5 illustration 4-4 front panel view 4-3 installing core IPS SSP 4-14 SFP/SFP+ modules 4-12 slide rail kit hardware 4-20 installing system image **D-18** Management 0/0 4-11 management port described 4-11 memory requirements 4-10 OIR fan supply modules 4-2 not supported 4-2 power supply modules 4-2 SFP/SFP+ 4-2 packing box contents 4-9 password recovery E-8, E-9 power module indicators described 4-7 illustration 4-6 power supply modules installing 4-17 removing 4-17 requirements 4-10 rack mounting 4-30

reimaging **D-18** removing core IPS SSP 4-14 SFP ports 4-12 slide rail kit hardware installation 4-20 specifications 4-8 supported SFP+ modules 4-11, 5-10 supported SFP modules 4-11, 5-10 SwitchApp 4-35 two power supply modules 4-16, 4-18 **IPS** software available files C-1 obtaining C-1 IPS software file names major updates (illustration) **C-4** minor updates (illustration) C-4 patch releases (illustration) C-4 service packs (illustration) C-4 IPS SSP-10 front panel features (illustration) 5-4 IPS SSP-20 front panel features (illustration) 5-4 IPS SSP-40 front panel features (illustration) 5-5 IPS SSP-60 front panel features (illustration) 5-5 IPS SSP in the ASA 5585-X 5-2 IPS SSPs (core) slot 0 4-14 IPv6 SPAN ports 1-13 switches 1-13

L

license key installing C-12 obtaining C-9 trial C-9 uninstalling C-14 viewing status of C-9 licensing described C-9 IPS device serial number C-9 Licensing pane configuring C-10 described C-9 logging in appliances A-2 ASA 5500-X IPS SSP A-4 ASA 5585-X IPS SSP A-5 sensors SSH A-6 Telnet A-6 service role A-1 terminal servers 1-19, A-3, D-13 user role A-1 loose connections on sensors 4-34, E-23

Μ

major updates described C-3 Management 0/0 port described 4-11 Management 0/1 described 4-11 manual block to bogus host **E-41** master blocking sensor not set up properly E-43 verifying configuration **E-43** merging configuration files **E-3** MIBs supported **E-18** minor updates described C-3 modes IDS 1-1 inline interface pair 1-13 inline VLAN pair 1-14 IPS 1-1 promiscuous 1-12 VLAN groups 1-15 modules ASA 5585-X IPS SSP 5-2

Ν

NTP

authenticated 1-20, E-15 described 1-20, E-15 incorrect configuration 1-20, E-16 time synchronization 1-20, E-15 unauthenticated 1-20, E-15 verifying configuration 1-21

0

obtaining cryptographic account C-2 IPS software C-1 license key C-9 sensor license C-10 OIR not supported for modules 4-2 supported fan modules 4-2 power supply modules 4-2 SFP/SFP+ 4-2 online insertion and removal. See OIR. 5-2

Ρ

password recovery appliances E-8 ASA 5500-X IPS SSP E-10 ASA 5585-X IPS SSP E-12 CLI E-14 described E-8 disabling E-14 displaying setting E-14 GRUB menu E-8 IME E-14 IPS 4345 E-8, E-9 IPS 4360 E-8, E-9

IPS 4510 E-8, E-9 IPS 4520 E-8, E-9 platforms E-8 ROMMON E-9 troubleshooting E-15 verifying E-14 patch releases described **C-3** physical connectivity issues E-30 physical interfaces configuration restrictions 1-10 ports Management 0/0 4-11 Management 0/1 4-11 SFP 4-12 SFP/SFP+ 5-13 power supplies described (IPS 4345) **3-16** describes (IPS 4360) 3-16 illustration (IPS 4345) 3-17 illustration (IPS 4560) 3-17 power supply guidelines 2-6 power supply indicator IPS 4345 3-17 IPS 4360 3-17 power supply indicators IPS 4510 4-6 IPS 4520 4-6 power supply modules hot-pluggable 4-16 installing (IPS 4510) 4-17 installing (IPS 4520) 4-17 OIR 4-16 redundant configuration 4-16 removing (IPS 4510) 4-17 removing (IPS 4520) 4-17 preparing for appliance installation 2-1 promiscuous mode atomic attacks 1-12 described 1-12 illustration 1-12

packet flow 1-12 SPAN ports 1-13 TCP reset interfaces 1-9 VACL capture 1-13

R

rack mounting IPX 4345 3-10 rack-mounting IPS 4510 4-30 IPS 4520 4-30 RADIUS attempt limit E-21 recover command **D-11** recovering the application partition image **D-12** recovery partition upgrade D-6 reimaging ASA 5500-X IPS SSP D-20 ASA 5585-X IPS SSP **D-21** described **D-2** IPS 4345 D-14 IPS 4360 D-14 IPS 4510 D-18 IPS 4520 D-18 sensors D-2, D-11 removing ASA 5585-X IPS SSP 5-14 DC power supply (IPS 4360) 3-26 last applied service pack **D-11** signature update **D-11** requirements ASA 5585-X IPS SSP 5-4 reset not occurring for a signature **E-50** resetting passwords ASDM E-11, E-13 hw-module command E-12

sw-module command **E-10** resetting the password ASA 5500-X IPS SSP E-10 ASA 5585-X IPS SSP E-12 restoring the current configuration **E-5** RJ-45 to DB-9 cable pinouts **F-3** ROMMON ASA 5585-X IPS SSP D-24 described **D-13** IPS 4345 D-14, E-9 IPS 4360 D-14, E-9 IPS 4510 D-18, E-9 IPS 4520 D-18, E-9 password recovery E-9 remote sensors **D-13** serial console port **D-13** TFTP D-13 round-trip time. See RTT. RTT described **D-13** TFTP limitation **D-13**

S

scheduling automatic upgrades D-9 security information on Cisco Security Intelligence Operations C-8 sensing interfaces Analysis Engine 1-6 described 1-6 interface cards 1-6 modes 1-6 sensor license installing C-10 obtaining C-10 sensors access problems E-24 application partition image D-12

Cisco Intrusion Prevention System Appliance and Module Installation Guide for IPS 7.2

asymmetric traffic and disabling anomaly detection E-18 capturing traffic 1-1 command and control interfaces (list) 1-5 comprehensive deployment 1-1 **Comprehensive Deployment Solutions** (illustration) 1-1 corrupted SensorApp configuration **E-35** disaster recovery **E-6** downgrading **D-11** electrical guidelines 2-3 IDS mode 1-1 incorrect NTP configuration 1-20, E-16 initializing **B-1**, **B-4** interface support 1-6 IP address conflicts E-27 IPS mode 1-1 IPS tuning tips 1-3 logging in SSH A-6 Telnet A-6 loose connections 4-34, E-23 misconfigured access lists E-26 models 1-16 network topology 1-3 no alerts E-31, E-57 not seeing packets E-33 NTP time synchronization 1-20, E-15 physical connectivity **E-30** power supply guidelines **2-6** preventive maintenance E-2 reimaging D-2 sensing process not running **E-28** setup command B-1, B-4, B-8 site guidelines 2-5 supported 1-16 TCP reset 1-2 time sources 1-20, E-15 troubleshooting software upgrades **E-53**

upgrading D-5 service account accessing E-5 cautions **E-5** creating **E-6** described E-5 service packs described C-3 service role A-1 session command ASA 5500-X IPS SSP A-4 ASA 5585-X IPS SSP A-5 sessioning in ASA 5500-X IPS SSP A-4 ASA 5585-X IPS SSP A-5 setting up terminal servers 1-19, A-3, D-13 setup automatic **B-2** command **B-1, B-4, B-8, B-13, B-17** simplified mode **B-2** SFP+ modules described 4-10, 5-9 supported (table) 4-11, 5-10 SFP+ modules described 5-4 SFP/SFP+ port (illustration) 5-13 SFP modules described 4-10, 5-4, 5-9 supported (table) 4-11, 5-10 SFP port (illustration) 4-12 show events command E-97, E-98 show health command **E-76** show interfaces command **E-96** show module 1 details command E-59, E-71 show settings command E-14 show statistics command **E-84** show statistics virtual-sensor command E-23, E-84 show tech-support command E-77 show version command **E-81** signature engine update files described **C-5**

Γ

signatures TCP reset **E-50** update files C-4 site guidelines for sensor installation 2-5 SNMP supported MIBs E-18 software downloads Cisco.com C-1 software file names recovery (illustration) C-5 signature/virus updates (illustration) C-4 signature engine updates (illustration) C-5 system image (illustration) C-5 software release examples platform identifiers C-7 platform-independent C-6 software updates supported FTP servers **D-3** supported HTTP/HTTPS servers D-3 SPAN appliances 1-18 port issues **E-30** specifications IPS 4345 **3-2** IPS 4360 3-2 IPS 4510 4-8 IPS 4520 4-8 **SSP-10** components 5-2 described 5-2 **SSP-20** components 5-3 described 5-3 **SSP-40** components 5-3 described 5-3 **SSP-60** components 5-3 described 5-3 SSP in slot 2 5-10 statistic display **E-85**

```
subinterface 0 described 1-15
supported
    FTP servers D-3
    HTTP/HTTPS servers D-3
SwitchApp described 4-35
Switched Port Analyzer. See SPAN.
switches and TCP reset interfaces 1-9
sw-module module slot_number password-reset
command E-10
System Configuration Dialog
    described B-2
    example B-2
system images
   installing
       ASA 5500-X IPS SSP
                             D-20
       ASA 5585-X IPS SSP
                             D-21
       IPS 4345 D-14
       IPS 4360 D-14
       IPS 4510 D-18
       IPS 4520 D-18
```

Т

TAC service account E-5 show tech-support command E-77 TCP reset interfaces conditions 1-9 described 1-9 list 1-9 promiscuous mode 1-9 switches 1-9 TCP resets not occurring E-50 signature actions 1-2 tech support information display E-78 terminal server setup 1-19, A-3, D-13

TFTP servers recommended UNIX D-13 Windows D-13 RTT D-13 time correction on the sensor 1-21, E-17 sensors 1-20, E-15 time sources appliances 1-20, E-15 ASA 5500-X IPS SSP 1-20, E-16 ASA 5585-X IPS SSP 1-20, E-16 trial license key **C-9** troubleshooting E-1 Analysis Engine busy **E-55** applying software updates E-52 ARC blocking not occurring for signature E-42 device access issues **E-39** enabling SSH E-41 inactive state **E-37** misconfigured master blocking sensor E-43 verifying device interfaces E-41 ASA 5500-X IPS SSP commands **E-59** failover scenarios **E-58** ASA 5585-X IPS SSP commands E-71 failover scenarios **E-70** traffic flow stopped E-71 automatic updates **E-52** cannot access sensor E-24 cidDump E-101 cidLog messages to syslog E-49 communication E-24 corrupted SensorApp configuration E-35 debug logger zone names (table) E-48 debug logging E-44 disaster recovery **E-6**

duplicate sensor IP addresses E-27 enabling debug logging E-44 external product interfaces E-22 gathering information E-76 global correlation E-19 IDM cannot access sensor **E-56** will not load **E-54** IME time synchronization **E-57** IPS clock time drift 1-20, E-16 manual block to bogus host E-41 misconfigured access list E-26 no alerts E-31, E-57 NTP **E-50** password recovery E-15 physical connectivity issues E-30 preventive maintenance **E-2** RADIUS attempt limit **E-21** reset not occurring for a signature **E-50** sensing process not running **E-28** sensor events **E-97** sensor loose connections 4-34, E-23 sensor not seeing packets E-33 sensor software upgrade E-53 service account **E-5** show events command **E-97** show interfaces command **E-96** show statistics command **E-84** show tech-support command E-77, E-78 show version command **E-81** software upgrades E-51 **SPAN** port issue **E-30** upgrading E-52 verifying Analysis Engine is running E-20 verifying ARC status E-36 tuning IPS 1-3

Cisco Intrusion Prevention System Appliance and Module Installation Guide for IPS 7.2

tips 1-3

U

unassigned VLAN groups described 1-15 unauthenticated NTP 1-20, E-15 uninstalling the license key C-14 upgrade command D-4, D-6 upgrade notes and caveatsu(pgrading IPS software) D-1 upgrading application partition D-11 latest version E-52 recovery partition D-6 sensors D-5 upgrading IPS software (upgrade notes and caveats) D-1 URLs for Cisco Security Intelligence Operations C-8 using debug logging E-44 TCP reset interfaces 1-9

V

verifying ASA 5585-X IPS SSP installation 5-14 NTP configuration 1-21 password recovery E-14 sensor initialization **B-21** sensor setup **B-21** version display **E-81** viewing license key status C-9 virtualization advantages E-17 restrictions E-17 supported sensors **E-18** traffic capture requirements **E-18** VLAN groups 802.1q encapsulation 1-15

configuration restrictions 1-11 deploying 1-16 described 1-15 switches 1-16

W

warning circuit breaker 3-21 exposed DC wire 3-23