



## New and Changed Information xvii

### Preface xix

|  |       |
|--|-------|
| Audience   | xix   |
| Organization   | xix   |
| Document Conventions   | xx    |
| Related Documentation  | xxi   |
| Release Notes  | xxi   |
| Regulatory Compliance and Safety Information                 | xxi   |
| Compatibility Information                                    | xxi   |
| Hardware Installation  | xxi   |
| Software Installation and Upgrade                            | xxii  |
| Cisco NX-OS  | xxii  |
| Cisco DCNM-SAN   | xxii  |
| Command-Line Interface                                       | xxii  |
| Intelligent Storage Networking Services Configuration Guides | xxii  |
| Troubleshooting and Reference                                | xxiii |
| Obtaining Documentation and Submitting a Service Request     | xxiii |

### System Management Overview 1-1

|                             |     |
|-----------------------------|-----|
| Cisco Fabric Services       | 1-1 |
| System Messages             | 1-1 |
| Call Home                   | 1-2 |
| Scheduler                   | 1-2 |
| System Processes and Logs   | 1-2 |
| Embedded Event Manager      | 1-2 |
| SNMP                        | 1-3 |
| RMON                        | 1-3 |
| Domain Parameters           | 1-3 |
| SPAN                        | 1-3 |
| Fabric Configuration Server | 1-3 |

### Using the CFS Infrastructure 2-1

|                       |     |
|-----------------------|-----|
| Information About CFS | 2-1 |
|-----------------------|-----|

|  |             |
|--|-------------|
| Cisco MDS NX-OS Features Using CFS                           | <b>2-2</b>  |
| CFS Features   | <b>2-2</b>  |
| Enabling CFS for an Application                              | <b>2-3</b>  |
| CFS Protocol   | <b>2-3</b>  |
| CFS Distribution Scopes                                      | <b>2-3</b>  |
| CFS Distribution Modes                                       | <b>2-4</b>  |
| Uncoordinated Distribution                                   | <b>2-4</b>  |
| Coordinated Distribution                                     | <b>2-4</b>  |
| Unrestricted Uncoordinated Distributions                     | <b>2-4</b>  |
| CFS Connectivity in a Mixed Fabric                           | <b>2-4</b>  |
| Locking the Fabric   | <b>2-5</b>  |
| Committing Changes   | <b>2-5</b>  |
| CFS Merge Support  | <b>2-6</b>  |
| CFS Distribution over IP                                     | <b>2-6</b>  |
| Static IP Peers for CFS over IP                              | <b>2-7</b>  |
| About CFS Regions  | <b>2-8</b>  |
| Guidelines and Limitations                                   | <b>2-9</b>  |
| Default Settings   | <b>2-9</b>  |
| Configuring CFS  | <b>2-9</b>  |
| Disabling CFS Distribution on a Switch                       | <b>2-10</b> |
| Committing Changes   | <b>2-10</b> |
| Discarding Changes   | <b>2-10</b> |
| Saving the Configuration                                     | <b>2-10</b> |
| Clearing a Locked Session                                    | <b>2-11</b> |
| Enabling CFS over IP   | <b>2-11</b> |
| Configuring IP Multicast Address for CFS over IP             | <b>2-12</b> |
| Configuring Static IP Peers for CFS over IP                  | <b>2-13</b> |
| Configuring CFS Regions                                      | <b>2-14</b> |
| Creating CFS Regions   | <b>2-14</b> |
| Assigning Applications to CFS Regions                        | <b>2-15</b> |
| Moving an Application to a Different CFS Region              | <b>2-15</b> |
| Removing an Application from a Region                        | <b>2-15</b> |
| Deleting CFS Regions   | <b>2-16</b> |
| Verifying CFS Configurations                                 | <b>2-16</b> |
| Verifying CFS Distribution Status                            | <b>2-17</b> |
| Verifying Application Registration Status                    | <b>2-17</b> |
| Verifying CFS Lock Status                                    | <b>2-18</b> |
| Verifying the CFS over IP Configuration                      | <b>2-18</b> |
| Verifying IP Multicast Address Configuration for CFS over IP | <b>2-19</b> |

|   |             |
|---|-------------|
| Verifying Static IP Peer Configuration            | <b>2-19</b> |
| Verifying CFS Regions                             | <b>2-19</b> |
| Additional References                             | <b>2-19</b> |
| MIBs  | <b>2-20</b> |
| Feature History for CFS                           | <b>2-20</b> |
| <b>Configuring System Message Logging</b>         | <b>3-1</b>  |
| Information About System Message Logging          | <b>3-1</b>  |
| System Message Logging                            | <b>3-3</b>  |
| SFP Diagnostics                                   | <b>3-4</b>  |
| Outgoing System Message Logging Server Facilities | <b>3-4</b>  |
| System Message Logging Configuration Distribution | <b>3-5</b>  |
| Fabric Lock Override                              | <b>3-5</b>  |
| Guidelines and Limitations                        | <b>3-5</b>  |
| Default Settings                                  | <b>3-6</b>  |
| Configuring System Message Logging                | <b>3-6</b>  |
| Task Flow for Configuring System Message Logging  | <b>3-7</b>  |
| Enabling or Disabling Message Logging             | <b>3-7</b>  |
| Configuring Console Severity Level                | <b>3-7</b>  |
| Configuring Monitor Severity Level                | <b>3-8</b>  |
| Configuring Module Logging                        | <b>3-8</b>  |
| Configuring Facility Severity Levels              | <b>3-9</b>  |
| Sending Log Files                                 | <b>3-9</b>  |
| Configuring System Message Logging Servers        | <b>3-10</b> |
| Configuring System Message Logging Distribution   | <b>3-11</b> |
| Fabric Lock Override                              | <b>3-12</b> |
| Displaying System Message Logging Information     | <b>3-12</b> |
| Additional References                             | <b>3-17</b> |
| MIBs  | <b>3-17</b> |
| <b>Configuring Call Home</b>                      | <b>4-1</b>  |
| Information About Call Home                       | <b>4-1</b>  |
| Call Home Features                                | <b>4-2</b>  |
| About Smart Call Home                             | <b>4-3</b>  |
| Obtaining Smart Call Home                         | <b>4-5</b>  |
| Call Home Destination Profiles                    | <b>4-5</b>  |
| Call Home Alert Groups                            | <b>4-5</b>  |
| Customized Alert Group Messages                   | <b>4-6</b>  |
| Call Home Message Level Feature                   | <b>4-6</b>  |
| Syslog-Based Alerts                               | <b>4-6</b>  |

|  |      |
|--|------|
| RMON-Based Alerts                          | 4-7  |
| General E-Mail Options Using HTTPS Support | 4-7  |
| Multiple SMTP Server Support               | 4-7  |
| Periodic Inventory Notification            | 4-8  |
| Duplicate Message Throttle                 | 4-8  |
| Call Home Configuration Distribution       | 4-8  |
| Fabric Lock Override                       | 4-8  |
| Clearing Call Home Name Server Database    | 4-9  |
| EMC E-mail Home Delayed Traps              | 4-9  |
| Event Triggers                             | 4-10 |
| Call Home Message Levels                   | 4-12 |
| Message Contents                           | 4-14 |
| Guidelines and Limitations                 | 4-21 |
| Default Settings                           | 4-22 |
| Configuring Call Home                      | 4-22 |
| Task Flow for Configuring Call Home        | 4-23 |
| Configuring Contact Information            | 4-23 |
| Enabling Call Home Function                | 4-24 |
| Configuring Destination Profiles           | 4-24 |
| Associating an Alert Group                 | 4-26 |
| Customizing Alert Group Messages           | 4-28 |
| Setting the Call Home Message Levels       | 4-29 |
| Configuring the Syslog-Based Alerts        | 4-29 |
| Configuring RMON Alerts                    | 4-30 |
| Configuring Event Trap Notifications       | 4-30 |
| Configuring General E-Mail Options         | 4-30 |
| Configuring HTTPS Support                  | 4-31 |
| Enable or Disable Transport Method         | 4-31 |
| Configuring an HTTP Proxy Server           | 4-32 |
| Configuring SMTP Server and Ports          | 4-34 |
| Configuring Multiple SMTP Server Support   | 4-34 |
| Enabling Periodic Inventory Notifications  | 4-35 |
| Configuring Duplicate Message Throttle     | 4-35 |
| Enabling Call Home Fabric Distribution     | 4-36 |
| Fabric Lock Override                       | 4-37 |
| Call Home Communications Test              | 4-37 |
| Configuring Delayed Traps                  | 4-37 |
| Verifying Call Home Configuration          | 4-38 |
| Displaying Call Home Information           | 4-38 |

|  |             |
|--|-------------|
| Displaying Delayed Trap Information                  | <b>4-40</b> |
| Verifying Alert Group Customization                  | <b>4-40</b> |
| Verifying Event Notification Trap                    | <b>4-40</b> |
| Verifying Call Home Transport                        | <b>4-41</b> |
| Verifying the Number of Name Server Database Entries | <b>4-41</b> |
| Monitoring Call Home                                 | <b>4-41</b> |
| Sample Syslog Alert Notification in Full-txt Format  | <b>4-42</b> |
| Sample Syslog Alert Notification in XML Format       | <b>4-42</b> |
| Sample RMON Notification in XML Format               | <b>4-45</b> |
| Additional References                                | <b>4-46</b> |
| MIBs   | <b>4-47</b> |
| Feature History for Call Home                        | <b>4-47</b> |
| <b>Scheduling Maintenance Jobs</b>                   | <b>5-1</b>  |
| Information About the Command Scheduler              | <b>5-1</b>  |
| Scheduler Terminology                                | <b>5-1</b>  |
| Licensing Requirements for Command Scheduler         | <b>5-2</b>  |
| Guidelines and Limitations                           | <b>5-2</b>  |
| Default Settings                                     | <b>5-2</b>  |
| Configuring the Command Scheduler                    | <b>5-3</b>  |
| Task Flow for Configuring the Command Scheduler      | <b>5-3</b>  |
| Enabling the Command Scheduler                       | <b>5-3</b>  |
| Configuring Remote User Authentication               | <b>5-4</b>  |
| Defining a Job                                       | <b>5-4</b>  |
| Deleting a Job                                       | <b>5-6</b>  |
| Specifying a Schedule                                | <b>5-6</b>  |
| Specifying a One-Time Schedule                       | <b>5-7</b>  |
| Deleting a Schedule                                  | <b>5-8</b>  |
| Removing an Assigned Job                             | <b>5-8</b>  |
| Deleting a Schedule Time                             | <b>5-8</b>  |
| Configuring Execution Logs                           | <b>5-8</b>  |
| Clearing the Execution Log File Contents             | <b>5-9</b>  |
| Verifying Scheduler Configuration                    | <b>5-9</b>  |
| Verifying the Command Scheduler Configuration        | <b>5-9</b>  |
| Verifying the Command Scheduler Execution Status     | <b>5-10</b> |
| Verifying the Job Definition                         | <b>5-10</b> |
| Displaying Execution Log File Contents               | <b>5-10</b> |
| Clearing the Execution Log File Contents             | <b>5-11</b> |

## Configuring the Embedded Event Manager 6-1

|   |
|---|
| Information About EEM 6-1                           |
| EEM Overview 6-2                                    |
| Policies 6-2  |
| Event Statements 6-3                                |
| Action Statements 6-4                               |
| VSH Script Policies 6-4                             |
| Environment Variables 6-5                           |
| High Availability 6-5                               |
| Licensing Requirements for EEM 6-5                  |
| Prerequisites for EEM 6-5                           |
| Guidelines and Limitations 6-5                      |
| Default Settings 6-6                                |
| Configuring EEM 6-6                                 |
| Defining a User Policy Using the CLI 6-6            |
| Configuring Event Statements 6-7                    |
| Configuring Action Statements 6-9                   |
| Defining a Policy Using a VSH Script 6-10           |
| Registering and Activating a VSH Script Policy 6-11 |
| Overriding a Policy 6-11                            |
| Defining an Environment Variable 6-12               |
| Verifying the EEM Configuration 6-12                |
| Configuration Examples for EEM 6-13                 |
| Additional References 6-13                          |
| MIBs 6-13   |
| Feature History for EEM 6-13                        |

## Monitoring System Processes and Logs 7-1

|   |
|---|
| Information About System Processes and Logs 7-1 |
| Saving Cores 7-2                                |
| Saving the Last Core to Bootflash 7-2           |
| First and Last Core 7-2                         |
| Online System Health Management 7-2             |
| Loopback Test Configuration Frequency 7-3       |
| Loopback Test Configuration Frame Length 7-3    |
| Hardware Failure Action 7-4                     |
| Performing Test Run Requirements 7-4            |
| Tests for a Specified Module 7-4                |
| Clearing Previous Error Reports 7-5             |

|  |            |
|--|------------|
| Interpreting the Current Status                      | 7-5        |
| On-Board Failure Logging                             | 7-6        |
| Default Settings                                     | 7-7        |
| Core and Log Files                                   | 7-7        |
| Saving Cores   | 7-7        |
| Clearing the Core Directory                          | 7-8        |
| Configuring System Health                            | 7-8        |
| Task Flow for Configuring System Health              | 7-9        |
| Enabling System Health Initiation                    | 7-9        |
| Configuring Loopback Test Configuration Frequency    | 7-10       |
| Configuring Loopback Test Configuration Frame Length | 7-10       |
| Configuring Hardware Failure Action                  | 7-10       |
| Performing Test Run Requirements                     | 7-11       |
| Clearing Previous Error Reports                      | 7-11       |
| Performing Internal Loopback Tests                   | 7-11       |
| Performing External Loopback Tests                   | 7-12       |
| Performing Serdes Loopbacks                          | 7-13       |
| Configuring On-Board Failure Logging                 | 7-14       |
| Configuring OBFL for the Switch                      | 7-14       |
| Configuring OBFL for a Module                        | 7-15       |
| Clearing the Module Counters                         | 7-15       |
| Verifying System Processes and Logs Configuration    | 7-17       |
| Displaying System Processes                          | 7-17       |
| Displaying System Status                             | 7-20       |
| Displaying Core Status                               | 7-22       |
| Verifying First and Last Core Status                 | 7-23       |
| Displaying System Health                             | 7-23       |
| Verifying Loopback Test Configuration Frame Length   | 7-26       |
| Displaying OBFL for the Switch                       | 7-26       |
| Displaying the OBFL for a Module                     | 7-26       |
| Displaying OBFL Logs                                 | 7-27       |
| Displaying the Module Counters Information           | 7-27       |
| Additional References                                | 7-28       |
| MIBs   | 7-28       |
| Feature History for System Processes and Logs        | 7-28       |
| <b>Configuring RMON</b>                              | <b>8-1</b> |
| Information About RMON                               | 8-1        |
| RMON Configuration Information                       | 8-2        |

|   |             |
|---|-------------|
| RMON Configuration Using Threshold Manager        | 8-2         |
| RMON Alarm Configuration Information              | 8-2         |
| Default Settings                                  | 8-3         |
| Configuring RMON                                  | 8-3         |
| Configuring the RMON Traps in SNMP                | 8-3         |
| Configuring the RMON Alarm                        | 8-4         |
| Configuring the RMON Event                        | 8-4         |
| Verifying the RMON Configuration                  | 8-5         |
| Additional References                             | 8-6         |
| MIBs  | 8-6         |
| Feature History for RMON                          | 8-6         |
| <b>Configuring Online Diagnostics</b>             | <b>9-1</b>  |
| Information About Online Diagnostics              | 9-1         |
| Online Diagnostic Overview                        | 9-2         |
| Bootup Diagnostics                                | 9-2         |
| Runtime or Health Monitoring Diagnostics          | 9-3         |
| On-Demand Diagnostics                             | 9-5         |
| High Availability                                 | 9-5         |
| Licensing Requirements for Online Diagnostics     | 9-5         |
| Guidelines and Limitations                        | 9-5         |
| Default Settings                                  | 9-5         |
| Configuring Online Diagnostics                    | 9-6         |
| Setting the Bootup Diagnostic Level               | 9-6         |
| Activating a Diagnostic Test                      | 9-6         |
| Setting a Diagnostic Test as Inactive             | 9-8         |
| Starting or Stopping an On-Demand Diagnostic Test | 9-8         |
| Clearing Diagnostic Results                       | 9-9         |
| Simulating Diagnostic Results                     | 9-9         |
| Verifying the Online Diagnostics Configuration    | 9-10        |
| Configuration Examples for Online Diagnostics     | 9-10        |
| Additional References                             | 9-10        |
| Related Documents                                 | 9-11        |
| Feature History for Online Diagnostics            | 9-11        |
| <b>Configuring SNMP</b>                           | <b>10-1</b> |
| Information About SNMP Security                   | 10-1        |
| SNMP Version 1 and Version 2c                     | 10-2        |
| SNMP Version 3                                    | 10-2        |

|  |              |
|--|--------------|
| SNMPv3 CLI User Management and AAA Integration           | <b>10-3</b>  |
| CLI and SNMP User Synchronization                        | <b>10-3</b>  |
| Restricting Switch Access                                | <b>10-3</b>  |
| Group-Based SNMP Access                                  | <b>10-4</b>  |
| Creating and Modifying Users                             | <b>10-4</b>  |
| AES Encryption-Based Privacy                             | <b>10-4</b>  |
| Enabling SNMP Notifications                              | <b>10-5</b>  |
| LinkUp/LinkDown Notifications for Switches               | <b>10-5</b>  |
| Scope of LinkUp and LinkDown Trap Settings               | <b>10-5</b>  |
| Default Settings   | <b>10-6</b>  |
| Configuring SNMP   | <b>10-6</b>  |
| Assigning SNMP Switch Contact and Location Information   | <b>10-6</b>  |
| Configuring SNMP Users from the CLI                      | <b>10-7</b>  |
| Enforcing SNMPv3 Message Encryption                      | <b>10-8</b>  |
| Assigning SNMPv3 Users to Multiple Roles                 | <b>10-9</b>  |
| Adding Communities                                       | <b>10-9</b>  |
| Configuring SNMP Trap and Inform Notifications           | <b>10-9</b>  |
| Configuring SNMPv2c Notifications                        | <b>10-10</b> |
| Configuring SNMPv3 Notifications                         | <b>10-11</b> |
| Enabling SNMP Notifications                              | <b>10-12</b> |
| Configuring the Notification Target User                 | <b>10-13</b> |
| Configuring LinkUp/LinkDown Notifications for Switches   | <b>10-14</b> |
| Configuring Up/Down SNMP Link-State Traps for Interfaces | <b>10-15</b> |
| Configuring Entity (FRU) Traps                           | <b>10-16</b> |
| Verifying SNMP Configuration                             | <b>10-17</b> |
| Viewing the Up/Down SNMP Link-State Traps for Interfaces | <b>10-17</b> |
| Displaying SNMP Traps                                    | <b>10-18</b> |
| Displaying SNMP Security Information                     | <b>10-19</b> |
| Additional References                                    | <b>10-21</b> |
| MIBs   | <b>10-21</b> |
| Feature History for SNMP                                 | <b>10-22</b> |

## **Configuring Domain Parameters** **11-1**

|   |             |
|---|-------------|
| Information About Fibre Channel Domains | <b>11-1</b> |
| Domain Restart                          | <b>11-3</b> |
| Domain Manager Fast Restart             | <b>11-3</b> |
| Switch Priority                         | <b>11-4</b> |
| fcdomain Initiation                     | <b>11-4</b> |
| Incoming RCFs                           | <b>11-4</b> |

|   |       |
|---|-------|
| Autoreconfiguring Merged Fabrics            | 11-4  |
| Domain IDs                                  | 11-4  |
| Specifying Static or Preferred Domain IDs   | 11-6  |
| Allowed Domain ID Lists                     | 11-6  |
| CFS Distribution of Allowed Domain ID Lists | 11-7  |
| Contiguous Domain ID Assignments            | 11-7  |
| Locking the Fabric                          | 11-7  |
| Committing Changes                          | 11-7  |
| Clearing a Fabric Lock                      | 11-7  |
| FC IDs                                      | 11-8  |
| Persistent FC IDs                           | 11-8  |
| Persistent FC ID Configuration              | 11-8  |
| About Unique Area FC IDs for HBAs           | 11-9  |
| Persistent FC ID Selective Purging          | 11-9  |
| Guidelines and Limitations                  | 11-9  |
| Default Settings                            | 11-9  |
| Configuring Fibre Channel Domains           | 11-11 |
| Restarting a Domain                         | 11-11 |
| Enabling Domain Manager Fast Restart        | 11-12 |
| Configuring Switch Priority                 | 11-12 |
| Enabling or Disabling fcdomains             | 11-12 |
| Configuring Fabric Names                    | 11-13 |
| Rejecting Incoming RCFs                     | 11-13 |
| Enabling Autoreconfiguration                | 11-14 |
| Configuring Domain IDs                      | 11-14 |
| Specifying Static or Preferred Domain IDs   | 11-14 |
| Configuring Allowed Domain ID Lists         | 11-15 |
| Enabling Allowed Domain ID Distribution     | 11-16 |
| Committing Changes                          | 11-16 |
| Discarding Changes                          | 11-16 |
| Enabling Contiguous Domain ID Assignments   | 11-17 |
| Configuring FC IDs                          | 11-17 |
| Enabling the Persistent FC ID Feature       | 11-17 |
| Configuring Persistent FC IDs               | 11-18 |
| Configuring Unique Area FC IDs for an HBA   | 11-19 |
| Purging Persistent FC IDs                   | 11-20 |
| Clearing a Fabric Lock                      | 11-20 |
| Verifying FC Domain Configuration           | 11-20 |
| Displaying CFS Distribution Status          | 11-21 |

|                                       |              |
|---------------------------------------|--------------|
| Displaying Pending Changes            | <b>11-21</b> |
| Displaying Session Status             | <b>11-22</b> |
| Displaying fcdomain Information       | <b>11-22</b> |
| Feature History for Domain Parameters | <b>11-25</b> |
|                                       | <b>11-25</b> |

## **Monitoring Network Traffic Using SPAN** **12-1**

|  |              |
|--|--------------|
| Information About SPAN   | <b>12-1</b>  |
| <span style="color: #0000ff;">SPAN Sources</span>                                      | <b>12-3</b>  |
| <span style="color: #0000ff;">IPS Source Ports</span>                                  | <b>12-3</b>  |
| <span style="color: #0000ff;">Allowed Source Interface Types</span>                    | <b>12-4</b>  |
| <span style="color: #0000ff;">VSAN as a Source</span>                                  | <b>12-4</b>  |
| <span style="color: #0000ff;">SPAN Sessions</span>                                     | <b>12-4</b>  |
| <span style="color: #0000ff;">Specifying Filters</span>                                | <b>12-5</b>  |
| <span style="color: #0000ff;">SD Port Characteristics</span>                           | <b>12-5</b>  |
| <span style="color: #0000ff;">SPAN Conversion Behavior</span>                          | <b>12-5</b>  |
| <span style="color: #0000ff;">Monitoring Traffic Using Fibre Channel Analyzers</span>  | <b>12-6</b>  |
| <span style="color: #0000ff;">Monitoring Without SPAN</span>                           | <b>12-7</b>  |
| <span style="color: #0000ff;">Monitoring with SPAN</span>                              | <b>12-7</b>  |
| <span style="color: #0000ff;">Single SD Port to Monitor Traffic</span>                 | <b>12-8</b>  |
| <span style="color: #0000ff;">SD Port Configuration</span>                             | <b>12-9</b>  |
| <span style="color: #0000ff;">Mapping the FC Tunnel</span>                             | <b>12-9</b>  |
| <span style="color: #0000ff;">Creating VSAN Interfaces</span>                          | <b>12-10</b> |
| <span style="color: #0000ff;">Remote SPAN</span>                                       | <b>12-10</b> |
| <span style="color: #0000ff;">Advantages of Using RSPAN</span>                         | <b>12-11</b> |
| <span style="color: #0000ff;">FC and RSPAN Tunnels</span>                              | <b>12-11</b> |
| <span style="color: #0000ff;">ST Port Configuration</span>                             | <b>12-12</b> |
| <span style="color: #0000ff;">ST Port Characteristics</span>                           | <b>12-12</b> |
| <span style="color: #0000ff;">Creating Explicit Paths</span>                           | <b>12-13</b> |
| <span style="color: #0000ff;">Guidelines and Limitations</span>                        | <b>12-13</b> |
| <span style="color: #0000ff;">Default SPAN and RSPAN Settings</span>                   | <b>12-15</b> |
| <span style="color: #0000ff;">Configuring SPAN</span>                                  | <b>12-15</b> |
| <span style="color: #0000ff;">Configuring SD Ports for SPAN</span>                     | <b>12-16</b> |
| <span style="color: #0000ff;">Configuring SPAN max-queued-packets</span>               | <b>12-17</b> |
| <span style="color: #0000ff;">Configuring SPAN for Generation 2 Fabric Switches</span> | <b>12-18</b> |
| <span style="color: #0000ff;">Suspending and Reactivating SPAN Sessions</span>         | <b>12-19</b> |
| <span style="color: #0000ff;">Encapsulating Frames</span>                              | <b>12-20</b> |
| <span style="color: #0000ff;">Configuring Fibre Channel Analyzers Using SPAN</span>    | <b>12-20</b> |
| <span style="color: #0000ff;">Configuring Single SD Port to Monitor Traffic</span>     | <b>12-21</b> |

|  |              |
|--|--------------|
| Configuring the Source Switch                  | <b>12-22</b> |
| Creating VSAN Interfaces                       | <b>12-22</b> |
| Enabling FC Tunnels                            | <b>12-22</b> |
| Initiating the FC Tunnel                       | <b>12-23</b> |
| Configuring the ST Port                        | <b>12-23</b> |
| Configuring an RSPAN Session                   | <b>12-23</b> |
| Configuring All Intermediate Switches          | <b>12-24</b> |
| Configuring VSAN Interfaces                    | <b>12-24</b> |
| Enabling IP Routing                            | <b>12-24</b> |
| Configuring the Destination Switch             | <b>12-24</b> |
| Configuring VSAN Interfaces                    | <b>12-25</b> |
| Configuring the SD Port                        | <b>12-25</b> |
| Mapping the FC Tunnel                          | <b>12-25</b> |
| Creating Explicit Paths                        | <b>12-26</b> |
| Monitoring RSPAN Traffic                       | <b>12-27</b> |
| Verifying SPAN Configuration                   | <b>12-27</b> |
| Displaying SPAN Information                    | <b>12-28</b> |
| Displaying RSPAN Information                   | <b>12-29</b> |
| Configuration Examples for RSPAN               | <b>12-31</b> |
| Single Source with One RSPAN Tunnel            | <b>12-32</b> |
| Single Source with Multiple RSPAN Tunnels      | <b>12-32</b> |
| Multiple Sources with Multiple RSPAN Tunnels   | <b>12-32</b> |
| <b>Configuring Fabric Configuration Server</b> | <b>13-1</b>  |
| Information About FCS                          | <b>13-1</b>  |
| Significance of FCS                            | <b>13-2</b>  |
| Default Settings                               | <b>13-3</b>  |
| Configuring FCS                                | <b>13-3</b>  |
| Specifying a FCS Name                          | <b>13-3</b>  |
| Verifying FCS Configuration                    | <b>13-4</b>  |
| Displaying FCS Elements                        | <b>13-5</b>  |
| Additional References                          | <b>13-8</b>  |
| MIBs   | <b>13-8</b>  |