



## L Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter L.

### limit-resource erspan-flow-id minimum

To configure the range of allowed ERSPAN flow IDs, use the **limit-resource erspan-flow-id minimum** command. To remove the configuration, use the **no** form of this command.

**limit-resource erspan-flow-id minimum** *min-val* **maximum** *max-val*

**no limit-resource erspan-flow-id**

<b>Syntax Description</b>	<i>min-val</i>	Minimum ERSPAN flow ID number allowed.
	<b>maximum</b>	Configures the maximum range value for ERSPAN flow IDs.
	<i>max-val</i>	Maximum ERSPAN flow ID number allowed.

<b>Defaults</b>	None
-----------------	------

<b>Command Modes</b>	Global configuration (config)
----------------------	-------------------------------

<b>Supported User Roles</b>	network-admin
-----------------------------	---------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	4.0(4)SV1(2)	This command was introduced.

<b>Examples</b>	This example shows how to restrict the range of allowed ERSPAN flow IDs to the range, 1-80:
	<code>n1000v(config)# <b>limit-resource erspan-flow-id minimum 1 maximum 80</b></code>

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

This example shows how to restore the default range of ERSPAN flow IDs:

```
n1000v(config)# no limit-resource erspan-flow-id
```

Related Commands	Command	Description
	<b>erspan-id</b>	Adds an ERSPAN ID (1-1023) to the session configuration and saves it in the running configuration.
	<b>show monitor session</b>	Displays the ERSPAN session configuration as it exists in the running configuration.
	<b>monitor session</b>	Creates an ERSPAN session.

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

# line console

To enter console configuration mode, use the **line console** command. To exit console configuration mode, use the **no** form of this command.

**line console**

**no line console**

**Syntax Description** This command has no arguments or keywords.

**Defaults** None

**Command Modes** Global configuration (config)

**SupportedUserRoles** network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

**Examples** This example shows how to enter console configuration mode:

```
n1000v# configure terminal
n1000v(config)# line console
n1000v(config-console)#
```

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

# line vty

To enter line configuration mode, use the **line vty** command. To exit line configuration mode, use the **no** form of this command.

```
line vty
no line vty
```

**Syntax Description** This command has no arguments or keywords.

**Defaults** None

**Command Modes** Global configuration (config)

**SupportedUserRoles** network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

**Examples** This example shows how to enter line configuration mode:

```
n1000v# configure terminal
n1000v(config)# line vty
n1000v(config-line)#
```

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

# logging console

Use the **logging console** command to enable logging messages to the console session.

To disable logging messages to the console session, use the **no** form of this command.

**logging console** [*severity-level*]

**no logging console**

## Syntax Description

*severity-level*

The severity level at which you want messages to be logged. When you set a severity level, for example 4, then messages at that severity level and higher (0 through 4) are logged.

Severity levels are as follows:

Level	Designation	Definition
0	Emergency	System unusable <b>*the highest level*</b>
1	Alert	Immediate action needed
2	Critical	Critical condition—default level
3	Error	Error condition
4	Warning	Warning condition
5	Notification	Normal but significant condition
6	Informational	Informational message only
7	Debugging	Appears during debugging only

## Defaults

None

## Command Modes

Global configuration (config)

## Supported User Roles

network-admin

## Command History

**Release**

**Modification**

4.0(4)SV1(1)

This command was introduced.

## Examples

This example shows how to enable logging messages with a severity level of 4 (warning) or higher to the console session:

```
n1000v# configure terminal
n1000v(config)# logging console 4
n1000v(config)#
```

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

**Related Commands**

Command	Description
show logging console	Displays the console logging configuration.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## logging event

Use the **logging event** command to log interface events.

**logging event** {link-status | trunk-status} {enable | default}

**no logging event** {link-status | trunk-status} {enable | default}

Syntax Description	<b>link-status</b>	Log all up/down and change status messages.
	<b>trunk-status</b>	Log all trunk status messages.
	<b>default</b>	The default logging configuration is used.
	<b>enable</b>	Enables interface logging to override the port level logging configuration.

Defaults	None
----------	------

Command Modes	Global configuration (config)
---------------	-------------------------------

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Examples	<p>This example shows how to log interface events:</p> <pre>n1000v# configure terminal n1000v(config)# logging event link-status default n1000v(config)#</pre>
----------	--

Related Commands	Command	Description
	<b>show logging</b>	Displays the logging configuration and contents of logfile.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

## logging level

Use the **logging level** command to enable the logging of messages as follows:

- from a named facility (such as license or aaa)
- of a specified severity level or higher

To disable the logging of messages, use the **no** form of this command.

**logging level** *facility severity-level*

**no logging level** *facility severity-level*

### Syntax Description

*facility* Names the *facility*.

*severity-level* The severity level at which you want messages to be logged. When you set a severity level, for example 4, then messages at that severity level and higher (0 through 4) are logged.

Severity levels are as follows:

Level	Designation	Definition
0	Emergency	System unusable <b>*the highest level*</b>
1	Alert	Immediate action needed
2	Critical	Critical condition—default level
3	Error	Error condition
4	Warning	Warning condition
5	Notification	Normal but significant condition
6	Informational	Informational message only
7	Debugging	Appears during debugging only

### Defaults

None

### Command Modes

Global configuration (config)

### Supported User Roles

network-admin

### Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

### Usage Guidelines

To apply the same severity level to all facilities, use the following command:

- **logging level all** *level\_number*

To list the available facilities for which messages can be logged, use the following command:

- **logging level ?**

### Examples

This example shows how to enable logging messages from the AAA facility that have a severity level of 0 through 2:

```
n1000v# configure terminal
n1000v(config)# logging level aaa 2
n1000v(config)#
```

This example shows how to enable logging messages from the license facility with a severity level of 0 through 4; and then display the license logging configuration:

```
n1000v# configure terminal
n1000v(config)# logging level license 4
n1000v(config)# show logging level license
Facility          Default Severity    Current Session Severity
-----
licmgr              6                      4

0(emergencies)      1(alerts)            2(critical)
3(errors)           4(warnings)          5(notifications)
6(information)      7(debugging)
```

n1000v(config)#

### Related Commands

Command	Description
<b>show logging level</b>	Displays the facility logging level configuration.
<b>logging level ?</b>	Lists the available facilities for which messages can be logged.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

# logging logfile

Use the **logging logfile** command to configure the log file used to store system messages.

To remove a configuration, use the **no** form of this command.

**logging logfile** *logfile-name severity-level* [**size bytes**]

**no logging logfile** [*logfile-name severity-level* [**size bytes**]]

## Syntax Description

<i>logfile-name</i>	Specifies the name of the log file that stores system messages.																											
<i>severity-level</i>	<p>The severity level at which you want messages to be logged. When you set a severity level, for example 4, then messages at that severity level and higher (0 through 4) are logged.</p> <p>Severity levels are as follows:</p> <table><tr><th>Level</th><th>Designation</th><th>Definition</th></tr><tr><td>0</td><td>Emergency</td><td>System unusable <b>*the highest level*</b></td></tr><tr><td>1</td><td>Alert</td><td>Immediate action needed</td></tr><tr><td>2</td><td>Critical</td><td>Critical condition—default level</td></tr><tr><td>3</td><td>Error</td><td>Error condition</td></tr><tr><td>4</td><td>Warning</td><td>Warning condition</td></tr><tr><td>5</td><td>Notification</td><td>Normal but significant condition</td></tr><tr><td>6</td><td>Informational</td><td>Informational message only</td></tr><tr><td>7</td><td>Debugging</td><td>Appears during debugging only</td></tr></table>	Level	Designation	Definition	0	Emergency	System unusable <b>*the highest level*</b>	1	Alert	Immediate action needed	2	Critical	Critical condition—default level	3	Error	Error condition	4	Warning	Warning condition	5	Notification	Normal but significant condition	6	Informational	Informational message only	7	Debugging	Appears during debugging only
Level	Designation	Definition																										
0	Emergency	System unusable <b>*the highest level*</b>																										
1	Alert	Immediate action needed																										
2	Critical	Critical condition—default level																										
3	Error	Error condition																										
4	Warning	Warning condition																										
5	Notification	Normal but significant condition																										
6	Informational	Informational message only																										
7	Debugging	Appears during debugging only																										
<i>size bytes</i>	<p>(Optional) Specifies the log file size in bytes, from 4096 to 10485760 bytes.</p> <p>The default file size is 10485760 bytes.</p>																											

## Defaults

None

## Command Modes

Global configuration (config)

## Supported User Roles

network-admin

## Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

## Examples

This example shows how to configure a log file named LogFile to store system messages and set its severity level to 4:

```
n1000v# config t
n1000v(config)# logging logfile LogFile 4
```

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

```
n1000v(config)#
```

**Related Commands**

Command	Description
<b>show logging logfile</b>	Displays the contents of the log file.

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

# logging module

To start logging of module messages to the log file, use the **logging module** command. To stop module log messages, use the **no logging module** form of this command.

**logging module** [*severity*]

**no logging module** [*severity*]

## Syntax Description

*severity-level*

The severity level at which you want messages to be logged. If you do not specify a severity level, the default is used. When you set a severity level, for example 4, then messages at that severity level and higher (0 through 4) are logged.

Severity levels are as follows:

Level	Designation	Definition
0	Emergency	System unusable <b>*the highest level*</b>
1	Alert	Immediate action needed
2	Critical	Critical condition—default level
3	Error	Error condition
4	Warning	Warning condition
5	Notification	Normal but significant condition (the default)
6	Informational	Informational message only
7	Debugging	Appears during debugging only

## Defaults

Disabled

If you start logging of module messages, and do not specify a severity, then the default is used, Notification (5).

## Command Modes

Global configuration (config)

## Supported User Roles

network-admin

## Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

## Examples

This example shows how to start logging of module messages to the log file at the default severity level (severity 4):

```
n1000v# configure terminal
n1000v(config)# logging module
n1000v(config)#
```

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

This example shows how to stop the logging of module messages to the log file:

```
n1000v# configure terminal
n1000v(config)# no logging module
n1000v#
```

#### Related Commands

Command	Description
<b>show logging module</b>	Displays the current configuration for logging module messages to the log file.

**Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).**

# logging monitor

Use the **logging monitor** command to enable the logging of messages to the monitor (terminal line). This configuration applies to telnet and Secure Shell (SSH) sessions.

To disable monitor logging, use the **no** form of this command.

**logging monitor** [*severity-level*]

**no logging monitor**

## Syntax Description

*severity-level*

The severity level at which you want messages to be logged. If you do not specify a severity level, the default is used. When you set a severity level, for example 4, then messages at that severity level and higher (0 through 4) are logged.

Severity levels are as follows:

Level	Designation	Definition
0	Emergency	System unusable <b>*the highest level*</b>
1	Alert	Immediate action needed
2	Critical	Critical condition—default level
3	Error	Error condition
4	Warning	Warning condition
5	Notification	Normal but significant condition (the default)
6	Informational	Informational message only
7	Debugging	Appears during debugging only

## Defaults

None

## Command Modes

Global configuration (config)

## Supported User Roles

Network-admin

## Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

## Examples

This example shows how to enable monitor log messages:

```
n1000v# configure terminal
n1000v(config)# logging monitor
n1000v(config)#
```

***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

**Related Commands**

Command	Description
<b>show logging monitor</b>	Displays the monitor logging configuration.

[Send document comments to nexus1k-docfeedback@cisco.com.](mailto:nexus1k-docfeedback@cisco.com)

## logging server

Use the **logging server** command to designate and configure a remote server for logging system messages. Use the **no** form of this command to remove or change the configuration,

```
logging server host0 [i1 [use-vrf s0 [facility {auth | authpriv | cron | daemon | ftp | kernel | local0 | local1 | local2 | local3 | local4 | local5 | local6 | local7 | lpr | mail | news | syslog | user | uucp}]]]
```

```
no logging server host0 [i1 [use-vrf s0 [facility {auth | authpriv | cron | daemon | ftp | kernel | local0 | local1 | local2 | local3 | local4 | local5 | local6 | local7 | lpr | mail | news | syslog | user | uucp}]]]
```

Syntax Description	
<i>host0</i>	Hostname/IPv4/IPv6 address of the Remote Syslog Server.
<i>i1</i>	(Optional) 0-emerg;1-alert;2-crit;3-err;4-warn;5-notif;6-inform;7-debug.
<b>use-vrf</b> <i>s0</i>	(Optional) Enter VRF name, default is management + VRF name,default management.
<b>facility</b>	(Optional) Facility to use when forwarding to server.
<b>auth</b>	Use auth facility.
<b>authpriv</b>	Use authpriv facility.
<b>cron</b>	Use Cron/at facility.
<b>daemon</b>	Use daemon facility.
<b>ftp</b>	Use file transfer system facility.
<b>kernel</b>	Use kernel facility.
<b>local0</b>	Use local0 facility.
<b>local1</b>	Use local1 facility.
<b>local2</b>	Use local2 facility.
<b>local3</b>	Use local3 facility.
<b>local4</b>	Use local4 facility.
<b>local5</b>	Use local5 facility.
<b>local6</b>	Use local6 facility.
<b>local7</b>	Use local7 facility.
<b>lpr</b>	Use lpr facility.
<b>mail</b>	Use mail facility.
<b>news</b>	Use USENET news facility.
<b>syslog</b>	Use syslog facility.
<b>user</b>	Use user facility.
<b>uucp</b>	Use Unix-to-Unix copy system facility.

**Defaults** None

**Command Modes** Global configuration (config)



***Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).***

**SupportedUserRoles** network-admin

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

## Examples

This example shows how to configure a remote syslog server at a specified IPv4 address, using the default outgoing facility:

```
n1000v# configure terminal
n1000v(config)# logging server 172.28.254.253
n1000v(config)#
```

This example shows how to configure a remote syslog server at a specified host name, with severity level 5 or higher:

```
n1000v# configure terminal
n1000v(config)# logging server syslogA 5
n1000v(config)#
```

Related Commands	Command	Description
	<b>show logging server</b>	Displays the current server configuration for logging system messages.

*Send document comments to [nexus1k-docfeedback@cisco.com](mailto:nexus1k-docfeedback@cisco.com).*

# logging timestamp

To set the unit of measure for the system messages timestamp, use the **logging timestamp** command. To restore the default unit of measure, use the **no** form of this command.

**logging timestamp** {microseconds | milliseconds | seconds}

**no logging timestamp** {microseconds | milliseconds | seconds}

## Syntax Description

<b>microseconds</b>	Timestamp in micro-seconds.
<b>milliseconds</b>	Timestamp in milli-seconds.
<b>seconds</b>	Timestamp in seconds (Default).

## Defaults

Seconds

## Command Modes

Global configuration (config)

## Supported User Roles

network-admin

## Command History

Release	Modification
4.0(4)SV1(1)	This command was introduced.

## Examples

This example shows how to set microseconds as the unit of measure for the system messages timestamp:

```
n1000v# configure terminal
n1000v(config)# logging timestamp microseconds
n1000v(config)#
```

## Related Commands

Command	Description
<b>show logging timestamp</b>	Displays the logging timestamp configuration.