

Send comments to nexus5k-docfeedback@cisco.com



I Commands

This chapter describes the basic Cisco NX-OS system commands that begin with I.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

install all

To install the kickstart and system images on a Cisco Nexus 5000 Series switch, use the **install all** command.

```
install all [kickstart kickstart-url] [system system-url]
```

Syntax Description

kickstart	(Optional) Specifies the kickstart image file.
<i>kickstart-url</i>	Full address of the kickstart image file. The name is case sensitive.
system	(Optional) Specifies the system image file.
<i>system-url</i>	Full address of the system image file. The name is case sensitive.

Command Default

If you do not enter any parameters, the boot variable values are used.

Command Modes

EXEC mode

Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.
5.0(3)N1(1)	Support for Layer 3 interfaces was added.

Usage Guidelines

The format of the kickstart and system URLs varies according to the file system, directory, and file location.

The following tables list URL prefix keywords by the file system type. If you do not specify a URL prefix keyword, the switch looks for a file in the current directory.

[Table 1](#) lists URL prefix keywords for local writable storage file systems. [Table 2](#) lists the URL prefix keywords for remote file systems. For remote file systems, if it is not otherwise specified, the path is the default for the user on the remote server.

Table 1 URL Prefix Keywords for Local Writable Storage File Systems

Keyword	Source or Destination
bootflash: <i>[//server]</i>	Source URL for boot flash memory. The <i>server</i> argument value is module-1 , sup-1 , sup-active , or sup-local .
modflash: <i>[//server]</i>	Source URL of an external flash file system. The <i>server</i> argument value is module-1 , sup-1 , sup-active , or sup-local .
volatile: <i>[//server]</i>	Source URL of the default internal file system. Any files or directories stored in this file system are erased when the switch reboots. The <i>server</i> argument value is module-1 , sup-1 , sup-active , or sup-local .

Send comments to nexus5k-docfeedback@cisco.com

Table 2 URL Prefix Keywords for Remote File Systems

Keyword	Source or Destination
ftp:	Source URL for a FTP network server. The syntax for this alias is as follows: ftp://server[/path]/filename
scp:	Source URL for a network server that supports Secure Shell (SSH) and uses the secure copy protocol (scp). The syntax is as follows: scp://[username@]server[/path]/filename
sftp:	Source URL for an SSH FTP (SFTP) network server. The syntax is as follows: sftp://[username@]server[/path]/filename
tftp:	Source URL for a TFTP network server. The syntax is as follows: tftp://server[:port][/path]/filename

If you do not enter the information about the server or username when downloading and installing the image files from a remote server, you are prompted for the information.

This command sets the kickstart and system boot variables and copies the image files to the redundant supervisor module.

The **install all** command upgrades the switch software and also upgrades the Fabric Extender software of all attached chassis. The Fabric Extender remains online passing traffic while the software is copied. Once the software images have successfully been installed, the parent switch and the Fabric Extender chassis are rebooted automatically to maintain the software version compatibility between the parent switch and the Fabric Extender.

You can use the **install all** command to downgrade the Cisco NX-OS software on the switch. To determine if the downgrade software is compatible with the current configuration on the switch, use the **show incompatibility system** command and resolve any configuration incompatibilities.

In Cisco NX-OS Release 5.0(3)N1(1), a software upgrade on the Cisco Nexus 5548 switch and the Cisco Nexus 5596 switch that has the Layer 3 features enabled is disruptive. You must reload the switch and the Cisco Nexus 2000 Series Fabric Extender.

Examples

This example shows how to install the Cisco NX-OS software from the bootflash: directory:

```
switch# install all kickstart bootflash:nx-os_kick.bin system bootflash:nx-os_sys.bin
```

This example shows how to install the Cisco NX-OS software using the values configured in the kickstart and system boot variables:

```
switch# configure terminal
switch(config)# boot kickstart bootflash:nx-os_kick.bin
switch(config)# boot system bootflash:nx-os_sys.bin
switch(config)# exit
switch# copy running-config startup-config
switch# install all
```

This example shows how to install the Cisco NX-OS software from an SCP server:

```
switch# install all kickstart scp://adminuser@192.168.1.1/nx-os_kick.bin system
bootflash:scp://adminuser@192.168.1.1/nx-os_sys.bin
```

Send comments to nexus5k-docfeedback@cisco.com

Related Commands	Command	Description
	reload	Reloads the device with new Cisco NX-OS software.
	show incompatibility system	Displays configuration incompatibilities between Cisco NX-OS system software images.
	show install all	Displays information related to the install operation.
	show version	Displays information about the software version.

Send comments to nexus5k-docfeedback@cisco.com

install license

To install a license, use the **install license** command.

install license [*filesystem:*] [*//server/*] [*directory*] *src-filename* [*target-filename*]

Syntax Description	
<i>filesystem:</i>	(Optional) Name of the file system. Valid values are bootflash or volatile .
<i>//server/</i>	(Optional) Name of the server. Valid values are <i>///</i> , //module-1/ , //sup-1/ , //sup-active/ , or //sup-local/ . The double slash (//) is required.
<i>directory</i>	(Optional) Name of a directory. The directory name is case sensitive.
<i>src-filename</i>	Name of the source license file.
<i>target-filename</i>	(Optional) Name of the target license file.



Note

There can be no spaces in the *filesystem://server/directory/filename* string. Individual elements of this string are separated by colons (:) and slashes (/).

Command Default	
	All licenses for the Cisco Nexus 5000 Series switches are factory installed. Manual installation is not required.

Command Modes	
	EXEC mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.

Usage Guidelines	
	If a target filename is provided after the source location, the license file is installed with that name. Otherwise, the filename in the source URL is used. This command also verifies the license file before installing it.

Examples	
	This example shows how to install a file named license-file that resides in the bootflash: directory: <pre>switch# install license bootflash:license-file</pre>

Related Commands	Command	Description
	show license	Displays license information.
	show license host-id	Displays the serial number of the chassis to use for licensing.
	show license usage	Displays license usage information.

Send comments to nexus5k-docfeedback@cisco.com