



Unsupported Commands in Cisco IOS Release 12.2(18)SE

This appendix lists some of the command-line interface (CLI) commands that appear when you enter the question mark (?) at the Catalyst 3750 switch prompt but are not supported in this release, either because they are not tested or because of Catalyst 3750 hardware limitations. This is not a complete list. The unsupported commands are listed by software feature and command mode.

Access Control Lists

Unsupported Privileged EXEC Commands

access-enable [host] [timeout *minutes*]

access-template [*access-list-number* | *name*] [*dynamic-name*] [*source*] [*destination*] [timeout *minutes*]

clear access-template [*access-list-number* | *name*] [*dynamic-name*] [*source*] [*destination*].

Unsupported Global Configuration Commands

access-list rate-limit *acl-index* {*precedence* | **mask** *prec-mask*}

access-list dynamic extended

ARP Commands

Unsupported Global Configuration Commands

```
arp ip-address hardware-address smds
arp ip-address hardware-address srp-a
arp ip-address hardware-address srp-b
```

Unsupported Interface Configuration Commands

```
arp probe
ip probe proxy
```

FallBack Bridging

Unsupported Privileged EXEC Commands

```
clear bridge [bridge-group] multicast [router-ports | groups | counts] [group-address] [interface-unit]
[counts]
clear vlan statistics
show bridge [bridge-group] circuit-group [circuit-group] [src-mac-address] [dst-mac-address]
show bridge [bridge-group] multicast [router-ports | groups] [group-address]
show bridge vlan
show interfaces crb
show interfaces { ethernet | fastethernet } [interface | slot/port] irb
show subscriber-policy range
```

Unsupported Global Configuration Commands

```
bridge bridge-group acquire
bridge bridge-group address mac-address {forward | discard} [interface-id]
bridge bridge-group aging-time seconds
bridge bridge-group bitswap_13_addresses
bridge bridge-group bridge ip
bridge bridge-group circuit-group circuit-group pause milliseconds
bridge bridge-group circuit-group circuit-group source-based
bridge cmf
bridge crb
```

bridge *bridge-group domain domain-name*
bridge **irb**
bridge *bridge-group mac-address-table limit number*
bridge *bridge-group multicast-source*
bridge *bridge-group protocol dec*
bridge *bridge-group route protocol*
bridge *bridge-group subscriber policy policy*
subscriber-policy *policy [[no | default] packet [permit | deny]]*

Unsupported Interface Configuration Commands

bridge-group *bridge-group cbus-bridging*
bridge-group *bridge-group circuit-group circuit-number*
bridge-group *bridge-group input-address-list access-list-number*
bridge-group *bridge-group input-lat-service-deny group-list*
bridge-group *bridge-group input-lat-service-permit group-list*
bridge-group *bridge-group input-lsap-list access-list-number*
bridge-group *bridge-group input-pattern-list access-list-number*
bridge-group *bridge-group input-type-list access-list-number*
bridge-group *bridge-group lat-compression*
bridge-group *bridge-group output-address-list access-list-number*
bridge-group *bridge-group output-lat-service-deny group-list*
bridge-group *bridge-group output-lat-service-permit group-list*
bridge-group *bridge-group output-lsap-list access-list-number*
bridge-group *bridge-group output-pattern-list access-list-number*
bridge-group *bridge-group output-type-list access-list-number*
bridge-group *bridge-group sse*
bridge-group *bridge-group subscriber-loop-control*
bridge-group *bridge-group subscriber-trunk*
bridge *bridge-group lat-service-filtering*
frame-relay **map** **bridge** *dldci broadcast*
interface **bvi** *bridge-group*
x25 **map** **bridge** *x.121-address broadcast [options-keywords]*

HSRP

Unsupported Global Configuration Commands

interface Async
interface BVI
interface Dialer
interface Group-Async
interface Lex
interface Multilink
interface Virtual-Template
interface Virtual-Tokenring

Unsupported Interface Configuration Commands

mtu
standby mac-refresh *seconds*
standby use-bia

IGMP Snooping Commands

Unsupported Global Configuration Commands

ip igmp snooping source-only-learning
ip igmp snooping tcn

Interface Commands

Unsupported Privileged EXEC Commands

show interfaces [*interface-id* | *vlan vlan-id*] [crb** | **fair-queue** | **irb** | **mac-accounting** | **precedence** | **irb** | **random-detect** | **rate-limit** | **shape**]**

Unsupported Global Configuration Commands

interface tunnel

Unsupported Interface Configuration Commands

switchport broadcast *level*

switchport multicast *level*

switchport unicast *level*



Note

These commands have been replaced by the **storm-control** { **broadcast** | **multicast** | **unicast** } **level** *level* [*.level*] interface configuration command.

IP Multicast Routing

Unsupported Privileged EXEC Commands

clear ip rtp header-compression [*type number*]

The **debug ip packet** command displays packets received by the switch CPU. It does not display packets that are hardware-switched.

The **debug ip mcache** command affects packets received by the switch CPU. It does not display packets that are hardware-switched.

The **debug ip mpacket** [**detail**] [*access-list-number* [*group-name-or-address*]] command affects only packets received by the switch CPU. Because most multicast packets are hardware-switched, use this command only when you know that the route will forward the packet to the CPU.

debug ip pim atm

show frame-relay ip rtp header-compression [**interface** *type number*]

The **show ip mcache** command displays entries in the cache for those packets that are sent to the switch CPU. Because most multicast packets are switched in hardware without CPU involvement, you can use this command, but multicast packet information is not displayed.

The **show ip mpacket** commands are supported but are only useful for packets received at the switch CPU. If the route is hardware-switched, the command has no effect because the CPU does not receive the packet and cannot display it.

show ip pim vc [*group-address* | *name*] [*type number*]

show ip rtp header-compression [*type number*] [**detail**]

Unsupported Global Configuration Commands

ip pim accept-rp { *address* | **auto-rp** } [*group-access-list-number*]

ip pim message-interval *seconds*

Unsupported Interface Configuration Commands

frame-relay ip rtp header-compression [**active** | **passive**]
frame-relay map ip *ip-address* *dlci* [**broadcast**] **compress**
frame-relay map ip *ip-address* *dlci* **rtp header-compression** [**active** | **passive**]
ip igmp helper-address *ip-address*
ip multicast helper-map {*group-address* | **broadcast**} {*broadcast-address* | *multicast-address*}
extended-access-list-number
ip multicast rate-limit {**in** | **out**} [**video** | **whiteboard**] [**group-list** *access-list*] [**source-list** *access-list*]
kbps
ip multicast ttl-threshold *ttl-value* (instead, use the **ip multicast boundary** *access-list-number*
interface configuration command)
ip multicast use-functional
ip pim minimum-vc-rate *pps*
ip pim multipoint-signalling
ip pim nbma-mode
ip pim vc-count *number*
ip rtp compression-connections *number*
ip rtp header-compression [**passive**]

IP Unicast Routing

Unsupported Privileged EXEC or User EXEC Commands

clear ip accounting [**checkpoint**]
clear ip bgp *address* **flap-statistics**
clear ip bgp prefix-list
show cef [**drop** | **not-cef-switched**]
show ip accounting [**checkpoint**] [**output-packets** | **access-violations**]
show ip bgp dampened-paths
show ip bgp inconsistent-as
show ip bgp regexp *regular expression*
show ip prefix-list *regular expression*

Unsupported Global Configuration Commands

ip accounting-list *ip-address wildcard*
ip as-path access-list
ip accounting-transits *count*
ip cef accounting [**per-prefix**] [**non-recursive**]
ip cef traffic-statistics [**load-interval** *seconds*] [**update-rate** *seconds*]
ip flow-aggregation
ip flow-cache
ip flow-export
ip gratuitous-arps
ip local
ip prefix-list
ip reflexive-list
router **egp**
router **isis**
router **iso-igrp**
router **mobile**
router **odr**
router **static**

Unsupported Interface Configuration Commands

ip **accounting**
ip **load-sharing** [**per-packet**]
ip **mtu** *bytes*
ip **route-cache**
ip **verify**
ip **unnumbered** *type number*
All **ip security** commands

Unsupported BGP Router Configuration Commands

address-family vpv4
default-information originate
neighbor advertise-map
neighbor allowas-in
neighbor default-originate
neighbor description
network backdoor
table-map

Unsupported VPN Configuration Commands

All

Unsupported Route Map Commands

match route-type
set as-path {tag | prepend *as-path-string*}
set automatic-tag
set dampening *half-life reuse suppress max-suppress-time*
set default interface *interface-id [interface-id.....]*
set interface *interface-id [interface-id.....]*
set ip default next-hop *ip-address [ip-address.....]*
set ip destination *ip-address mask*
set ip precedence *value*
set ip qos-group
set metric-type internal
set origin
set metric-type internal
set tag *tag-value*

MSDP

Unsupported Privileged EXEC Commands

```
show access-expression
show exception
show location
show pm LINE
show smf [interface-id]
show subscriber-policy [policy-number]
show template [template-name]
```

Unsupported Global Configuration Commands

```
ip msdp default-peer ip-address | name [prefix-list list] (Because BGP/MBGP is not supported, use the
ip msdp peer command instead of this command.)
```

Network Address Translation (NAT) Commands

Unsupported User EXEC Commands

```
clear ip nat translation
show ip nat statistics
show ip nat translations
```

Unsupported Global Configuration Commands

```
ip nat inside destination
ip nat inside source
ip nat outside source
ip nat pool
```

Unsupported Interface Configuration Commands

```
ip nat
```

RADIUS

Unsupported Global Configuration Commands

`aaa nas port extended`
`radius-server attribute nas-port`
`radius-server configure`
`radius-server extended-portnames`

SNMP

Unsupported Global Configuration Commands

`snmp-server enable informs`
`snmp-server enable traps flash insertion`
`snmp-server enable traps flash removal`
`snmp-server ifindex persist`

Spanning Tree

Unsupported Global Configuration Command

`spanning-tree pathcost method {long | short}`

Unsupported Interface Configuration Command

`spanning-tree stack-port`

VLAN

Unsupported vlan-config Command

`private-vlan`

Unsupported User EXEC Commands

```
show running-config vlan
show vlan ifindex
show vlan private-vlan
```

VTP

Unsupported Privileged EXEC Commands

```
vtp {password password | pruning | version number}private-vlan
```



Note

This command has been replaced by the **vtp** global configuration command.

Miscellaneous

Unsupported Global Configuration Commands

```
errdisable detect cause dhcp-rate-limit
errdisable recovery cause dhcp-rate-limit
errdisable recovery cause unicast flood
service compress-config
```

Miscellaneous