



Configuring Traffic Test Loops

- [Configuring Traffic Test Loops, page 1](#)
- [Traffic Test Loop Function, page 1](#)
- [EVC Domain Latching Loop Overview, page 3](#)
- [Configuration Examples, page 5](#)
- [User Interface Reference, page 9](#)

Configuring Traffic Test Loops

This chapter describes the Traffic Test Loop feature and how to use it.

A traffic test loop can be used to return selected Ethernet frames in the direction from which they came. This feature is intended for Service Activation Testing (SAT) and troubleshooting for point-to-point and multipoint services across multiple Carrier Ethernet Networks (CENs).

Traffic Test Loop Function

Loop Instances

A single system can contain several loop instances. Only four instances can however be active at any given point in time.

Loop Modes

The system supports two different loop modes:

- Static Loopback
- Latching Loopback (as specified in MEF 46)

The Static Loopback mode is fully configured and controlled by management actions. Once configured and activated the loop will operate until explicitly changed or deactivated by another management operation.

The Latching Loopback mode combines management operations and OAM frame exchange to enable operational control of the loop from a remote system without management interface access. The loop must be initially provisioned by the management interface but it can be activated and deactivated using a standard Y.1731 OAM frame sequence.

The Latching Loopback mode conforms to the MEF 46 specification with the exceptions listed in the MEF 46 Non-Conformance Statement section.

Both modes are configured in a similar way. Since the static loops were added first the latching loop function has been implemented as an "add-on" function to the existing loop function.

Loop Domain

A loop instance must be created within one of the following domains. The domain determines which frames to loop.

Domain	Frames to Loop
Port	All ingress or egress frames on the selected port.
VLAN	All ingress or egress frames on the selected port with the configured VLAN.
EVC	All ingress or egress frames classified as belonging to the EVC.
EVC Subscriber	All ingress or egress frames classified as belonging to the EVC and located in the subscriber domain of the EVC and tagged with an optional Subscriber VID.

Loop Type

The loop type determines which type of frames to loop and the action performed on the looped frames.

Domain	Frames to Loop
MAC Loop	All frames in the flow are looped. The source MAC (SMAC) address and destination MAC (DMAC) addresses are swapped.
OAM Loop	Only Y.1731 OAM Loopback Messages (LBM) and Delay Measurement Messages (DMM) frames are looped. LBM frames are converted to LBR frames and DMM frames are converted to DMR frames. Note The OAM loop type is only supported for static loops and not for latching loops.

Loop Direction

The loop can be configured with two different directions.

Direction	Description
Facility	This loop is pointing out to the port. Looping is done from ingress to egress.
Terminal	This loop is pointing into the forwarding plane. Looping is done from egress to ingress.

Loop Residence Port

Any loop instance must be configured with a residence port regardless of the domain and direction settings. The residence port indicates the point in the system where frames that would otherwise have been forwarded is returned to the sender.

The valid choices of residence port depend on the domain and direction settings.

Warning Ignore

When enabling a Port domain facility loop all frames on the port will be looped including any management IP frames - management access will be lost on this port. To ensure that the user is aware of these consequences a warning is printed and the loop is not enabled. To enable the loop, the user must append the ICLI command with the keyword 'warning-ignore'.

EVC Domain Latching Loop Overview


The Port and VLAN loop domains are rather simple to understand and setup. But the EVC and EVC Subscriber domains are a bit more complex, especially when used in conjunction with the Latching Loopback mode.

The figure below shows a generalized view of a switch, together with the various possible locations for a latching loop instance in the EVC and EVC Subscriber domains.

The vertical ellipsis in the middle represents the actual layer-2 MAC/VLAN switch function. The small rectangles at the edge of the larger box represents ports on the switch. In case of an EVC the ports are marked with their role (NNI or UNI/ENNI).

The tag notation is explained in the figure below:

Figure 1: EVC Domain Latching Loops



Tag notation:

- TagA is the first tag on NNI.
- TagB is the second tag on NNI.
- TagC and TagD are first tag on UNI/ENNI.

MEP/MIP notation:

- MP1 is an EVC Down-MEP on NNI and the LLFS is TagA.
- MP5 is a Down-MEP on UNI/ENNI and the LLFS is TagC.
- MP4 is a Down-MIP on UNI/ENNI and the LLFS is TagD.
- MP7 is a Down-MIP on UNI/ENNI and the LLFS is Untagged.
- MP2 is an Up-MEP on UNI and the LLFS is TagA.
- MP3 is an Up-MIP on UNI and the LLFS is TagA+TagB.
- MP6 is an Up-MIP on UNI and the LLFS is TagA+Untagged.

Valid Feature Combinations

This table shows the supported loop parameters combinations.

Domain	Static Loop		Latching Loop	
	Facility	Terminal	Facility	Terminal
Port	Supported	Not Applicable	Not Applicable	Not Applicable

Domain	Static Loop		Latching Loop	
	Supported	Not Applicable	Supported	Not Applicable
VLAN	Supported	Not Applicable	Supported	Not Applicable
EVC Subscriber	Supported	Supported	Supported	Supported

Valid Residence Port Types

This table shows the type of EVC ports that can be used as a residence port depending on the other settings.



Note

The table is relevant only for EVC domain loops.

Domain	Direction	Valid Port Types
EVC	Facility	NNI ports
	Terminal	UNI ports
EVC Subscriber	Facility	UNI ports
	Terminal	UNI ports

MEF 46 Non-Conformance Statement

The system provides a Latching Loopback function which is fully MEF 46 conformant with the following exceptions:

- On a Serval-1 system a Terminal loop will loop the whole residence port due to limitations in the system hardware. This means that other flows using the same port will be affected when the loop is activated.
- A single latching loopback instance can only reference a single Maintenance Point (MEP or MIP).

Configuration Examples

The following sections describe various ICLI configuration examples based on the feature description section.

It is recommended to perform a restore to default operation before starting to configure any of the examples in the following sections.

```
# reload defaults
#
```

Note the following points with respect to the syntax:

- Lines that starts with an exclamation mark denotes an explanatory comment. You do not have to enter these in the ICLI console.

- Text in bold denote user input. These are the commands you need to type.
- Other text denotes command response from the system.
- Blank lines are occasionally inserted to increase readability.
- Wrapped CLI command lines (i.e. user input) will be shown with a '>' marker at the start of the wrapped text.
- Truncated CLI output lines will be shown with a '<...>' marker at the end of the line.

Static Loopback

This section contains examples of how to set up a static loop.

Port Facility Loop

This example describes how to create a simple static loop for port 1/1. The loop has type = MAC-Loop. The direction is set to facility, which means that all frames received by the port are looped back out on the port. The loop instance is given instance number '1'.

```

! Enter configuration mode
# configure terminal

! Create the loop
(config)# traffic-test-loop 1 type mac-loop interface GigabitEthernet 1/1 direction facility
> domain port admin-state disabled

! Give the loop a name
(config)# traffic-test-loop 1 name MyLoop

! The loop instance is now created but not active.
! Activate the loop
(config)# traffic-test-loop 1 admin-state enabled warning-ignore

! The loop instance is now active and will loop frames. Without 'warning-ignore' a warning
is given and the loop is not active.

! Leave configuration mode and view the loop state
(config)# exit
# show traffic-test-loop 1

Traffic Test Loop:
inst  name      type  opctrl  direction  domain  flow  port <...>
   1  MyLoop  mac-loop  static  facility   port    -    GigabitEthernet 1/1 <...>

! Enter configuration mode again
# configure terminal

! Deactivate the loop
(config)# traffic-test-loop 1 admin-state disabled

! Remove the loop instance
(config)# no traffic-test-loop 1

```

EVC Terminal Loop

This example shows how to create a static terminal loop of type MAC-Loop in the EVC domain.

The example assumes that an EVC has already been created with EVC ID = 1, and with port 1/2 as a UNI port.

```
! Enter configuration mode
# configure terminal

! Create the loop
(config)# traffic-test-loop 1 type mac-loop interface GigabitEthernet 1/2 direction terminal
domain evc 1 admin-state disabled

! Give the loop a name
(config)# traffic-test-loop 1 name MyEVCLoop

! Activate the loop
(config)# traffic-test-loop 1 admin-state enabled

! The loop instance is now active and will loop frames.

! Leave configuration mode and view the loop state
(config)# exit
# show traffic-test-loop 1

Traffic Test Loop:
  inst  name                type  opctrl  direction  domain  flow  port <...>
-----
      1  TRAFFIC_<...>  mac-loop  static  terminal    evc     1  GigabitEthernet 1/2 <...>

! Enter configuration mode again
# configure terminal

! Remove the loop instance (not strictly necessary to deactivate first)
(config)# no traffic-test-loop 1
```

Latching Loop

This section contains examples of how to set up a latching loop.



Note

When setting up a latching loop instance it is very important that the instance is initially created with `admin-state = disabled` and that the `admin-state` is not set to `enabled` until the latching loop function has been configured for the instance. Otherwise the loop will behave as a static loop and will immediately start to loop frames!

VLAN Facility Loop

This example shows how to create a latching loop for VLAN 200 on port 1/1. The loop will have `type = MAC-Loop`. The direction will be set to `facility`. The latching loop OAM frame handling will be enabled using a MEP with instance ID = 1 and will be provisioned with a source MAC (SMAC) filter = 00:11:22:33:44:55. Refer to [AN1105] for details on how to create MEPs.

With this configuration, only frames arriving on port 1/1 with VLAN tag 200 and with the specified SMAC address will be looped.

The example also shows how to inspect the state of an actively looping instance.

```
! Enter configuration mode
# configure terminal

! Create the MEP used for handling the latching loop OAM frames
(config)# mep 1 down domain vlan flow 200 level 0 interface GigabitEthernet 1/1
```

```

! Create the loop
(config)# traffic-test-loop 1 type mac-loop interface GigabitEthernet 1/1 direction facility
> domain vlan 200 admin-state disabled

! Give the loop a name
(config)# traffic-test-loop 1 name MyLlVlanLoop

! Setup the Latching Loop function
(config)# traffic-test-loop 1 ll mep 1 smac 00:11:22:33:44:55

! Enable the loop
(config)# traffic-test-loop 1 admin-state enabled

! The loop instance is now enabled but not active, i.e. it will not start to loop
! until it receives a valid Latching Loop LLM "Activate" OAM frame.

! Leave configuration mode and view the basic loop state
(config)# exit
# show traffic-test-loop 1

Traffic Test Loop:
  inst      name          type  opctrl  direction  domain  flow  port <...>
-----
    1  MyLlVlanLoop  mac-loop  latch-1  facility   vlan    200  GigabitEthernet 1/1 <...>

! show the specific latching loop state
# show traffic-test-loop 1 ll

Traffic Test Latching Loop:
  inst  mep      smac      admin      oper      timer
    1    1  00-11-22-33-44-55  enabled    inactive  0s

! Note that the "oper" state is 'inactive' and that the "timer" value is 0s which
! indicate that the loop is not active and it not looping traffic.

! Ensure that the latching loop is activated using an LLM OAM packet exchange
! using a remote system. Set the expiry timer to e.g. 30 seconds.

! show the specific latching loop state
# show traffic-test-loop 1 ll

Traffic Test Latching Loop:
  inst  mep      smac      admin      oper      timer
    1    1  00-11-22-33-44-55  enabled    up        27s

! Wait for at least 30 seconds and check the state again.
# show traffic-test-loop 1 ll

Traffic Test Latching Loop:
  inst  mep      smac      admin      oper      timer
    1    1  00-11-22-33-44-55  enabled    inactive  0s

! Remove the loop instance
(config)# no traffic-test-loop 1

```

EVC Subscriber Facility Loop

This example shows how to create a latching loop in the subscriber domain of an EVC using C-VID = 10. The example assumes that an EVC has already been created with EVC ID = 1, and with port 1/2 as a UNI port. Please refer to [AN1142] for details on how to create an EVC.

The latching loop OAM frame handling will be enabled using a MIP with instance ID = 1 and will be provisioned with a source MAC (SMAC) filter = 00:11:22:33:44:55. Refer to [AN1105] for details on how to create MEPs.

With this configuration, only frames arriving on port 1/2 with C-VID = 10 and with the specified SMAC address will be looped.

```
! Enter configuration mode
# configure terminal

! Create the MIP used for handling the latching loop OAM frames
(config)# mip 1 mip down domain evc vid 10 flow 1 level 4 interface GigabitEthernet 1/2

! Create the loop
(config)# traffic-test-loop 1 type mac-loop interface GigabitEthernet 1/1 direction facility

> domain evc 1 subscriber vid 10 admin-state disabled

! Setup the Latching Loop function
(config)# traffic-test-loop 1 ll mip 1 smac 00:11:22:33:44:55

! Enable the loop
(config)# traffic-test-loop 1 admin-state enabled

! The loop instance is now enabled but not active, i.e. it will not start to loop
! until it receives a valid Latching Loop LLM "Activate" OAM frame.
```

User Interface Reference

This section describes all configurable and viewable parameters for the Traffic Test Loop function.

The content of this section applies to both static and latching loopback modes.

iCLI Interface

All Traffic Test Loop operations use the traffic-test-loop command name.

Show Command

The command syntax for viewing settings and status is as follows:

```
show traffic-test-loop [ <inst> ] [ ll ]
```

Argument	Explanation
<inst>	This optional argument is the 1-offset identifier number assigned to the loop instance. If this is omitted, all instances will be shown.
ll	This optional argument will display special configuration and state for a Latching Loopback loop. If this is omitted only the common configuration and state will be shown, regardless of the mode of the loop.

Main Configuration Command

The main command syntax for configuring loops is as follows:

```
traffic-test-loop <inst>
type { mac-loop | { oam-loop [ level <level> ] } }
interface <port_type> <port>
direction { terminal | facility }
domain {
  port |
  { evc <evc_id> [ subscriber { all | untagged | { vid <sub_vid> } } ] } |
  { vlan <vlan_vid> }
}
[ admin-state { enabled | disabled } ]
[ warning-ignore ]
```

Argument	Description
<inst>	This argument is the 1-offset identifier number assigned by the user to the loop instance when it is created.
type	Selects the type of the loop as explained in section 2.1.4. If the type is set to "OAM Loop" then a MEG level value must also be provided.
interface	Selects the residence port for the loop.
direction	Selects the direction of the loop.
domain	Selects the domain for the loop.
evc_id	The ID of the EVC if the domain is set to "EVC". The EVC must exist when activating the loop.
subscriber	Optional EVC Subscriber settings if the domain is set to "EVC".
all	All frames in the EVC subscriber domain will be looped.
untagged	Only untagged frames in the EVC subscriber domain will be looped.
vid <sub_vid>	Only frames tagged with subscriber VID <sub_vid> in the EVC subscriber domain will be looped.
vlan_vid	The VLAN VID to use if the domain is set to "VLAN".
admin-state	Controls the administrative state of the loop. The default value is "disabled".
warning-ignore	Ignore the warning when enabling a Port Domain facility loop. The loop is enabled.

Naming Loop Instance

This sub-command can be used to change the display name of an existing loop instance.

```
traffic-test-loop <inst> name <name>
```

Argument	Description
<inst>	This argument is the 1-offset identifier number assigned by the user to the loop instance when it is created.
name	A display name to help the user identify the loop instance. The name can at most contain 32 characters and may not contain spaces.

Controlling Subscriber Domain Settings

The EVC subscriber settings can also be (re-)configured using a separate command.

```
traffic-test-loop <inst> subscriber [ all | untagged | { vid <vlan_id> } ]
```

Controlling Latching Loopback Mode

A loop instance is by default created as a static loop but the latching loop mode can be enabled after initial creation with this separate command.

```
traffic-test-loop <inst> ll mep <mep_id> smac <mac_address>
```

Argument	Description
<inst>	This argument is the 1-offset identifier number assigned by the user to the loop instance when it is created.
ll	Indicate that the remaining command arguments are related to the latching loop mode.
mep <mep_id>	Indicate the MEP or MIP instance which shall be responsible for processing Latching Loopback OAM frames (LLM/LLR) for the loop. This MEP/MIP must be created on the residence port defined for the loop. It must also be assigned to a similar domain as the loop. Note MEP instances must be used for Port and VLAN domain loop and also for main EVC domain loops. MIP instances can be used for EVC Subscriber domain loops.

Argument	Description
smac <mac_address>	The Source MAC (SMAC) filter to use for the loop. This is used to select frames to include in the loop but LLM OAM frames sent to the loop must also use this SMAC address.

Controlling Administrative State

The loop administrative state can be set in the main configuration command, but it can also be controlled for an existing loop instance with this separate command.

```
traffic-test-loop <inst> admin-state { enabled | disabled }
```



Note

When setting up a latching loop instance it is very important that the instance is initially created with admin-state = disabled (the default value) and that the admin-state is not set to enabled until the latching loop function has been enabled for the instance. Otherwise, the loop immediately starts to loop frames!

Web Interface

The web interface provides the same configuration options for the Traffic Test Loop function as the ICLI interface described in section . Please refer to this section for a detailed description of the various parameters.

The Traffic Test Loop function can be reached in the web interface using the menu on the left as follows:

- Expand the Top-most Configuration level
- Expand the Traffic Test level (located near the bottom)
- Select the Loop menu entry (see the screenshot to the right).

The main overview page is then shown.

Viewing Existing Loop Instances

The main overview page displays all configured loop instances together with their main configuration and current state.

Figure 2: Main Loop Overview

Traffic Test Loop

Delete	Instance	Name	Domain	Flow	Type	Direction	Residence Port	Operational State	OpS
<input type="checkbox"/>	<u>1</u>	MyLoop	Vlan	200	Mac-Loop	Facility	1	Down	
<input type="checkbox"/>	<u>2</u>	My2ndLoop	Port		Mac-Loop	Facility	2	Up	
<input type="checkbox"/>	<u>3</u>	MyEvcLoop	Evc	1	Mac-Loop	Terminal	1	Inactive	

Add New TT-LOOP Save Reset

Creating a New Loop

To create a new loop instance:

- 1 Click **Add New TT-LOOP**. A new row is inserted in the overview table.

Figure 3: Creating a New Loop

Delete	4	Port	1	Mac-Loop	Facility	1
--------	---	------	---	----------	----------	---

Add New TT-LOOP Save Reset

- 2 Fill in the parameters for the loop and click **Save**.
- 3 To cancel the loop creation, click **Reset**. Alternatively, click **Delete** in the first column.

Deleting a Loop Instance

To delete one or more existing loop instances, select the checkbox in the first column of the loop row(s) you want to delete and click **Save**.

Figure 4: Deleting a Loop Instance

Traffic Test Loop

Delete	Instance	Name	Domain	Flow	Type
<input type="checkbox"/>	<u>1</u>	MyLoop	Vlan	200	Mac-Loop
<input type="checkbox"/>	<u>2</u>	My2ndLoop	Port		Mac-Loop
<input checked="" type="checkbox"/>	<u>3</u>	MyEvcLoop	Evc	1	Mac-Loop

Add New TT-LOOP Save Reset


Modifying a Loop Instance

To change the settings of an existing loop instance, click the hyperlinked instance number in the Instance column.

Figure 5: Modifying a Loop Instance

Traffic Test Loop

Delete	Instance	Name	Domain	Flow	Type	Direction
<input type="checkbox"/>	1	MyLoop	Vlan	200	Mac-Loop	Facility
<input type="checkbox"/>	2	My2ndLoop	Port		Mac-Loop	Facility
<input type="checkbox"/>	3	MyEvcLoop	Evc	1	Mac-Loop	Terminal

367139 

The following loop parameters cannot be changed after they are created in the Web interface:

- Instance number
- Domain
- Flow association
- Type
- Direction
- Residence port

Figure 6: Loop Parameters

Traffic Test Loop Configuration

Instance Data

Instance	Domain	Flow	Type	Direction	Residence Port	Oper State
3	Evc	1	Mac-Loop	Terminal	1	Inactive

Instance Configuration

Name	Subscriber	VID	Admin State
MyEvcLoop	None ▼	0	Enable ▼

Latching Loopback Configuration

Enabled	MEP Instance	SMAC Address
<input checked="" type="checkbox"/>	1	00-00-00-00-00-01

367140 