



Viewing Server Properties

This chapter includes the following sections:

- [Viewing Server Properties, on page 1](#)
- [Viewing System Information, on page 2](#)
- [Viewing a Server Utilization, on page 2](#)
- [Viewing Cisco IMC Properties, on page 3](#)
- [Viewing CPU Properties, on page 4](#)
- [Viewing Memory Properties, on page 4](#)
- [Viewing Power Supply Properties, on page 6](#)
- [Viewing Storage Properties, on page 6](#)
- [Viewing PCI Adapter Properties, on page 12](#)
- [Viewing Network Related Properties, on page 13](#)
- [Viewing TPM Properties, on page 14](#)
- [Enabling 6G or 12G Mixed Mode Speed on SAS Expanders, on page 14](#)

Viewing Server Properties

Procedure

	Command or Action	Purpose
Step 1	Server# show chassis [detail]	Displays server properties.

Example

This example displays server properties:

```
Server# show chassis detail
Chassis:
  Power: on
  Serial Number: QCI140205ZG
  Product Name: UCS C210 M2
  PID : R210-2121605W
  UUID: FFFFFFFF-FFFF-FFFF-FFFFFFFFFFFFFF
  Locator LED: off
  Description: This shows the chassis details.
```

```
Server#
```

This example displays server properties for C3160 servers:

```
Server# show chassis detail
Chassis:
  Power: on
  Serial Number: FCH1821JAVL
  Product Name: UCS C3160
  PID : UCSC-C3X60-SVRNB
  UUID: 84312F76-75F0-4BD1-9167-28B74EBB444C
  Locator LED: off
  Front Panel Locator LED: off
  Description: This shows the chassis details
Server#
```

Viewing System Information

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # show sku-details	Displays the system information.

Example

This example shows how to view system details:

```
Server# scope chassis
Server /chassis # show sku-details
  SAS Expander: Not-Present
  HDD: 10-SFF_drive_back_plane
  Riser1: (1 Slot x16)
  Riser2: (1 Slot x16)
  M.2 SATA/NVMe: Not-Present
  M.2 SD Card Controller: Not-Present
  CPU1 PKG-ID: Non-MCP
  CPU2 PKG-ID: Non-MCP
  Intrusion Sensor: Not-Equipped
Server /chassis #
```

Viewing a Server Utilization

You can view a server utilization only on some UCS C-Series servers.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.

	Command or Action	Purpose
Step 2	Server /chassis # show cups-utilization	Displays the server utilization value on all the available CPUs. Note These utilization values are reported as a percentage of the total hardware bandwidth. These values may not match with the values being displayed by the host based resource monitoring software.

Example

This example shows how to view the server utilization value:

```
Server# scope chassis
Server /chassis # show cups-utilization

CPU Utilization (%)   Memory Utilization (%)   I/O Utilization (%)   Overall Utilization (%)
-----
100                   69                       0                     86

Server /chassis #
```

Viewing Cisco IMC Properties



Note Cisco IMC gets the current date and time from the server BIOS. To change this information, reboot the server and press **F2** when prompted to access the BIOS configuration menu. Then change the date or time using the options on the main BIOS configuration tab.

Procedure

	Command or Action	Purpose
Step 1	Server# show cimc [detail]	Displays Cisco IMC properties.

Example

This example displays Cisco IMC properties:

```
Server# show cimc detail
Cisco IMC:
  Firmware Version: 2.0(8.122)
  Current Time: Wed Dec 9 23:14:28 2015
  Boot-loader Version: 2.0(8.122).36
  Local Time: Wed Dec 9 23:14:28 2015 UTC +0000
  Timezone: UTC
  Reset Reason: graceful-reboot (This provides the last Cisco IMC reboot reason.)
```

```
Server#
```

Viewing CPU Properties

Before you begin

The server must be powered on, or the properties will not display.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters chassis command mode.
Step 2	Server /chassis # show cpu [detail]	Displays CPU properties.

Example

This example displays CPU properties:

```
Server# scope chassis
Server /chassis # show cpu
Name          Cores    Version
-----
CPU1          4        Intel(R) Xeon(R) CPU           E5520 @ 2.27GHz
CPU2          4        Intel(R) Xeon(R) CPU           E5520 @ 2.27GHz

Server /chassis #
```

Viewing Memory Properties

Before you begin

The server must be powered on, or the properties will not display.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters chassis command mode.
Step 2	Server /chassis # show dimm [detail]	Displays memory properties.
Step 3	Server /chassis # show dimm-summary	Displays DIMM summary information.

Example

This example displays memory properties:

```
Server# scope chassis
Server /chassis # show dimm
Name                Capacity          Channel Speed (MHz) Channel Type
-----
DIMM_A1             2048 MB           1067              Other
DIMM_A2             2048 MB           1067              Other
DIMM_B1             2048 MB           1067              Other
DIMM_B2             2048 MB           1067              Other
DIMM_C1             Not Installed     Unknown           Other
DIMM_C2             Not Installed     Unknown           Other
DIMM_D1             2048 MB           1067              Other
DIMM_D2             2048 MB           1067              Other
DIMM_E1             2048 MB           1067              Other
DIMM_E2             2048 MB           1067              Other
DIMM_F1             Not Installed     Unknown           Other
DIMM_F2             Not Installed     Unknown           Other
```

```
Server /chassis #
```

This example displays detailed information about memory properties:

```
Server# scope chassis
Server /chassis # show dimm detail
Name DIMM_A1:
  Capacity: 2048 MB
  Channel Speed (MHz): 1067
  Channel Type: Other
  Memory Type Detail: Synchronous
  Bank Locator: NODE 0 CHANNEL 0 DIMM 0
  Visibility: Yes
  Operability: Operable
  Manufacturer: 0x802C
  Part Number: 18JSF25672PY-1G1D1
  Serial Number: 0xDA415F3F
  Asset Tag: Unknown
  Data Width: 64 bits
Name DIMM_A2:
  Capacity: 2048 MB
--More--
```

```
Server /chassis #
```

This example displays DIMM summary information:

```
Server# scope chassis
Server /chassis # show dimm-summary
DIMM Summary:
  Memory Speed: 1067 MHz
  Total Memory: 16384 MB
  Effective Memory: 16384 MB
  Redundant Memory: 0 MB
  Failed Memory: 0 MB
  Ignored Memory: 0 MB
  Number of Ignored Dimms: 0
  Number of Failed Dimms: 0
  Memory RAS possible: Memory configuration can support mirroring
  Memory Configuration: Maximum Performance
```

```
Server /chassis #
```

Viewing Power Supply Properties

Before you begin

The server must be powered on, or the properties will not display.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters chassis command mode.
Step 2	Server /chassis # show psu [detail]	Displays power supply properties.

Example

This example displays power supply properties:

```
Server# scope chassis
Server /chassis # show psu
Name          In. Power (Watts)  Out. Power (Watts)  Firmware  Status
-----
PSU1          74                 650                 R0E       Present
PSU2          83                 650                 R0E       Present

Server /chassis #
```



Note **Input Power** and **Maximum Output Power** options are available only for some C-Series servers.

Viewing Storage Properties

Viewing Storage Adapter Properties

Before you begin

The server must be powered on, or the properties will not display.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # show storageadapter [slot] [detail]	Displays installed storage cards.

	Command or Action	Purpose
		Note This command displays all MegaRAID controllers on the server that can be managed through Cisco IMC. If an installed controller or storage device is not displayed, then it cannot be managed through Cisco IMC.
Step 3	Server /chassis # scope storageadapter slot	Enters command mode for an installed storage card.
Step 4	Server /chassis/storageadapter # show bbu [detail]	Displays battery backup unit information for the storage card.
Step 5	Server /chassis/storageadapter # show capabilities [detail]	Displays RAID levels supported by the storage card.
Step 6	Server /chassis/storageadapter # show error-counters [detail]	Displays number of errors seen by the storage card.
Step 7	Server /chassis/storageadapter # show firmware-versions [detail]	Displays firmware version information for the storage card.
Step 8	Server /chassis/storageadapter # show hw-config [detail]	Displays hardware information for the storage card.
Step 9	Server /chassis/storageadapter # show mfg-data [detail]	Displays manufacturer data for the storage card.
Step 10	Server /chassis/storageadapter # show pci-info [detail]	Displays adapter PCI information for the storage card.
Step 11	Server /chassis/storageadapter # show running-firmware-images [detail]	Displays running firmware information for the storage card.
Step 12	Server /chassis/storageadapter # show settings [detail]	Displays adapter firmware settings for the storage card.
Step 13	Server /chassis/storageadapter # show startup-firmware-images [detail]	Displays firmware images to be activated on startup for the storage card.

Example

This example displays storage properties:

```
Server# scope chassis
Server /chassis # show storageadapter
PCI Slot Product Name Serial Number Firmware Package Build
-----
SAS LSI MegaRAID SAS 9260-8i SV93404392 12.12.0-0038
```

```

      Product ID      Battery Status Cache Memory Size
-----
      LSI Logic      fully charged  0 MB

```

```
Server /chassis #
```

This example displays battery backup unit information for the storage card named SAS:

```

Server# scope chassis
Server /chassis # scope storageadapter SAS
Server /chassis/storageadapter # show bbu
Controller Battery Type Battery Present Voltage      Current      Charge Charging State
-----
SAS          iBBU          true          4.051 V      0.000 A      100%  fully charged

Server /chassis/storageadapter #

```

Viewing the Flexible Flash Controller Properties

Before you begin

- Cisco Flexible Flash must be supported by your platform.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Required: Server /chassis # show flexflash [detail]	(Optional) Displays the available Cisco Flexible Flash controllers.
Step 3	Required: Server /chassis # scope flexflash index	Enters the Cisco Flexible Flash controller command mode for the specified controller. At this time, the only permissible <i>index</i> value is FlexFlash-0 .
Step 4	Server /chassis/flexflash # show operational-profile [detail]	Displays the operational profile properties.

Example

This example displays the properties of the flash controller:

```

Server# scope chassis
Server /chassis # show flexflash
Controller  Product Name      Has Error  Firmware Version  Vendor      Internal State
-----
FlexFlash-0 Cisco FlexFlash No          1.2 build 247    Cypress    Connected

Server /chassis # scope flexflash FlexFlash-0
Server /chassis # show operational-profile
Primary Member Slot  I/O Error Threshold  Host Accessible VDs
-----
slot1                100                  SCU Drivers

```



```
Server /chassis/flexflash #
```

Viewing Physical Drive Properties

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope storageadapter slot	Enters command mode for an installed storage card.
Step 3	Server /chassis/storageadapter # show physical-drive [drive-number] [detail]	Displays physical drive information for the storage card.
Step 4	Server /chassis/storageadapter # show physical-drive-count [detail]	Displays the number of physical drives on the storage card.
Step 5	Server /chassis/storageadapter # scope physical-drive drive-number	Enters command mode for the specified physical drive.
Step 6	Server /chassis/storageadapter/physical-drive # show general [detail]	Displays general information about the specified physical drive.
Step 7	Server /chassis/storageadapter/physical-drive # show inquiry-data [detail]	Displays inquiry data about the specified physical drive.
Step 8	Server /chassis/storageadapter/physical-drive # show status [detail]	Displays status information about the specified physical drive.

Example

This example displays general information about physical drive number 1 on the storage card named SAS:

```
Server# scope chassis
Server /chassis # scope storageadapter SAS
Server /chassis/storageadapter # scope physical-drive 1
Server /chassis/storageadapter/physical-drive # show general
Slot Number 1:
  Controller: SAS
  Enclosure Device ID: 27
  Device ID: 34
  Sequence Number: 2
  Media Error Count: 0
  Other Error Count: 0
  Predictive Failure Count: 0
  Link Speed: 6.0 Gb/s
  Interface Type: SAS
  Media Type: HDD
  Block Size: 512
  Block Count: 585937500
  Raw Size: 286102 MB
```

```

Non Coerced Size: 285590 MB
Coerced Size: 285568 MB
SAS Address 0: 500000e112693fa2
SAS Address 1:
Connected Port 0:
Connected Port 1:
Connected Port 2:
Connected Port 3:
Connected Port 4:
Connected Port 5:
Connected Port 6:
Connected Port 7:
Power State: powersave

```

```
Server /chassis/storageadapter/physical-drive #
```

This example displays inquiry data about physical drive number 1 on the storage card named SAS:

```

Server# scope chassis
Server /chassis # scope storageadapter SAS
Server /chassis/storageadapter # scope physical-drive 1
Server /chassis/storageadapter/physical-drive # show inquiry-data
Slot Number 1:
  Controller: SAS
  Product ID: MBD2300RC
  Drive Firmware: 5701
  Drive Serial Number: D010P9A0016D

```

```
Server /chassis/storageadapter/physical-drive #
```

This example displays status information about physical drive number 1 on the storage card named SAS:

```

Server# scope chassis
Server /chassis # scope storageadapter SAS
Server /chassis/storageadapter # scope physical-drive 1
Server /chassis/storageadapter/physical-drive # show inquiry-data
Slot Number 1:
  Controller: SAS
  State: online
  Online: true
  Fault: false

```

```
Server /chassis/storageadapter/physical-drive #
```

Viewing Virtual Drive Properties

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope storageadapter slot	Enters command mode for an installed storage card.
Step 3	Server /chassis/storageadapter # show virtual-drive [drive-number] [detail]	Displays virtual drive information for the storage card.

	Command or Action	Purpose
Step 4	Server /chassis/storageadapter # show virtual-drive-count [detail]	Displays the number of virtual drives configured on the storage card.
Step 5	Server /chassis/storageadapter # scope virtual-drive drive-number	Enters command mode for the specified virtual drive.
Step 6	Server /chassis/storageadapter/virtual-drive # show physical-drive [detail]	Displays physical drive information about the specified virtual drive.

Example

This example displays information about virtual drives on the storage card named SAS:

```
Server# scope chassis
Server /chassis # scope storageadapter SAS
Server /chassis/storageadapter # show virtual-drive
Virtual Drive  Status      Name                Size      RAID Level
-----
0              Optimal      SLES1SP1beta5      30720 MB  RAID 0
1              Optimal      RHEL5.5             30720 MB  RAID 0
2              Optimal      W2K8R2_DC           30720 MB  RAID 0
3              Optimal      VD_3                 30720 MB  RAID 0
4              Optimal      ESX4.0u2            30720 MB  RAID 0
5              Optimal      VMs                  285568 MB RAID 0
6              Optimal      RHEL6-35GB          35840 MB  RAID 0
7              Optimal      OS_Ins_Test_DR      158720 MB RAID 0
8              Optimal
```

```
Server /chassis/storageadapter #
```

This example displays physical drive information about virtual drive number 1 on the storage card named SAS:

```
Server# scope chassis
Server /chassis # scope storageadapter SAS
Server /chassis/storageadapter # scope virtual-drive 1
Server /chassis/storageadapter/virtual-drive # show physical-drive
Span  Physical Drive Status      Starting Block Number Of Blocks
-----
0     12              online      62914560    62914560
```

```
Server /chassis/storageadapter/virtual-drive #
```

Viewing Nvidia GPU Card Information

These commands are not available on all UCS C-series servers.

Before you begin

The server must be powered on to view information on the Nvidia GPU cards.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # show gpu	Displays the available Nvidia GPU cards on the system.
Step 3	Server /chassis # scope gpu <i>slot-number</i>	Enters the GPU card command mode. Specify the slot number of the GPU card.
Step 4	Server /chassis/gpu # show gpu-list	Displays temperature information on the GPU cards.

Example

This example shows how to view the temperature information of the available GPU cards on the system:

```
Server # scope chassis
Server /chassis # show gpu

Slot          Product Name          Num of GPUs
-----
5             Nvidia GRID K2 @ BD      2

Server /chassis # scope gpu 5
Server /chassis/gpu # show gpu-list

GPU ID        Temperature
-----
0             32
1             33

Server /chassis/gpu #
```

Viewing PCI Adapter Properties

Before you begin

The server must be powered on, or the properties will not display.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # show pci-adapter [detail]	Displays PCI adapter properties.

Example

This example displays PCI adapter properties:

```

Server# scope chassis
Server /chassis # show pci-adapter
Slot Vendor ID Device ID SubVendor ID SubDevice ID Firmware Version Product Name
-----
L 0x8086 0x1521 0x1137 0x008b 0x8000AA5... Intel(R) I350 1 Gbps N...
1 0x19a2 0x0710 0x10df 0xe702 4.6.142.10 Emulex OCell1102-FX 2 p...
3 0x10de 0x118f 0x10de 0x097f N/A Nvidia TESLA K10 P2055...
4 0x14e4 0x1639 0x14e4 0x1639 N/A Broadcom 5709 1 Gbps 2...
5 0x10de 0x0ff2 0x10de 0x1012 N/A Nvidia GRID K1 P2401-502
M 0x1000 0x0073 0x1137 0x00b1 N/A Cisco UCSC RAID SAS 20...

Option ROM Status
-----
Loaded
Not-Loaded
Not-Loaded
Loaded

Server /chassis #

```



Note Option ROM Status is applicable only for legacy boot mode and not for UEFI boot mode.

Viewing Network Related Properties

Viewing LOM Properties

You can view the MAC addresses of the LAN On Motherboard (LOM) Ethernet ports.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope network-adapter slot ID	Enters the specific network adapter command mode.
Step 3	Server /chassis/network-adapter # show mac-list [detail]	Displays the MAC addresses of the LOM ports.

Example

This example shows how to display the MAC addresses of the LOM ports:

```

Server# scope chassis
Server /chassis # scope network-adapter L
Server /chassis/network-adapter # show mac-list
Interface ID      MAC Address

```

```

-----
eth0          010000002000
eth1          010000002000

Server /chassis/network-adapter #

```

Viewing TPM Properties

Before you begin

The server must be powered on, or the properties will not display.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # show tpm-inventory	Displays the TPM properties.

Example

This example displays the TPM properties:

```

Server# scope chassis
Server /chassis # show tpm-inventory

Version Presence Enabled-Status Active-Status Ownership Revision Model
Vendor      Serial
-----
-----
A      equipped disabled      deactivated unowned      1      UCSX-TPMX-00X ABC
Inc    FCHXXXXXXXXX

Server /chassis #

```

Enabling 6G or 12G Mixed Mode Speed on SAS Expanders

Cisco IMC supports mixed mode speeds of 6 gigabytes or 12 gigabytes for SAS expanders. This support is added because 6 gigabyte solid state drives (SSDs) are now giving way to 12 gigabyte SSDs. Using this feature you can select a SAS expander in the Dynamic Storage tab and enable either modes based on your requirements.

Enabling 6G or 12G Mixed Mode on a SAS Expander

This action is available only on some servers.

Before you begin

You must log in with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope sas-expander sas-expander ID	Enters the SAS expander command mode.
Step 3	Server /chassis/sas-expander # scope 6G-12G-Mixed-Mode-status	Enters the 6G or 12G mixed mode command mode.
Step 4	Server /chassis/sas-expander/6G-12G-Mixed-Mode-status # set set-6G-12G-mixed-mode Enabled	Enables the 6G or 12G mixed mode on the SAS expander.
Step 5	Server /chassis/sas-expander/6G-12G-Mixed-Mode-status * # commit	Enter y at the confirmation prompt. Commits the transaction to the system configuration.
Step 6	(Optional) Server /chassis/sas-expander/6G-12G-Mixed-Mode-status # show detail	Displays the 6G or 12G mixed mode status.

Example

This example shows how to enable the 6G or 12G mixed mode on the SAS expander:

```

Server# scope chassis
Server /chassis # scope sas-expander 1
Server /chassis/sas-expander # scope 6G-12G-Mixed-Mode-status
Server /chassis/sas-expander/6G-12G-Mixed-Mode-status # set set-6G-12G-mixed-mode Enabled
Server /chassis/sas-expander/6G-12G-Mixed-Mode-status *# commit
Are you sure you want to change the enable-mixed-mode setting to Enable mode?[y|N]y
Setting enable-mixed-mode setting to Enable ..
Successfully set enable-6G-12G-mixed-mode to Enable..
Server /chassis/sas-expander/6G-12G-Mixed-Mode-status # show detail
6G/12G Mixed Mode Settings:
Mixed 6G/12G Drive Support: Enabled
Server /chassis/sas-expander/6G-12G-Mixed-Mode-status #

```

