



Configuring Communication Services

This chapter includes the following sections:

- [Configuring HTTP, on page 1](#)
- [Configuring SSH, on page 3](#)
- [Configuring XML API, on page 4](#)
- [Enabling Redfish, on page 4](#)
- [Configuring IPMI, on page 5](#)
- [Configuring SNMP, on page 7](#)
- [Configuring a Server to Send Email Alerts Using SMTP, on page 13](#)

Configuring HTTP

Beginning with release 4.1(2b), Cisco IMC supports separate HTTPS and HTTP communication services. You can disable only HTTP services using this functionality.

This functionality is supported only on the following servers:

- Cisco UCS C220 M5
- Cisco UCS C240 M5
- Cisco UCS C480 M5
- Cisco UCS C480 ML M5
- Cisco UCS C240 SD M5
- Cisco UCS C125 M5
- Cisco UCS S3260 M4/M5



Note If **Redirect HTTP to HTTPS Enabled** was disabled in any release earlier than 4.1(2b), then after upgrading to release 4.1(2b) or later, **HTTP Enabled** value is set to **Disabled** by the system.

Before you begin

You must log in as a user with admin privileges to configure HTTP.

Procedure

	Command or Action	Purpose
Step 1	Server# scope http	Enters the HTTP command mode.
Step 2	Server /http # set enabled {yes no}	Enables or disables HTTP and HTTPS service on the Cisco IMC.
Step 3	Server /http # set http-enabled {yes no}	Enables or disables HTTP services on the Cisco IMC.
Step 4	Server /http # set http-port number	Sets the port to use for HTTP communication. The default is 80.
Step 5	Server /http # set https-port number	Sets the port to use for HTTPS communication. The default is 443.
Step 6	Server /http # set http-redirect {yes no}	Enables or disables the redirection of an HTTP request to HTTPS.
Step 7	Server /http # set timeout seconds	Sets the number of seconds to wait between HTTP requests before the Cisco IMC times out and terminates the session. Enter an integer between 60 and 10,800. The default is 1,800 seconds.
Step 8	Server /http # commit	Commits the transaction to the system configuration.

Example

This example configures HTTP for the Cisco IMC:

```

Server# scope http
Server /http # set enabled yes
Server /http *# set http-port 80
Server /http *# set https-port 443
Server /http *# set http-redirect yes
Server /http *# set timeout 1800
Server /http *# commit
Server /http # show
HTTP Port  HTTPS Port  Timeout  Active Sessions  Enabled  HTTP Redirected
-----
80          443          1800    0                 yes     yes
Server /http #

```

Configuring SSH

Before you begin

You must log in as a user with admin privileges to configure SSH.

Procedure

	Command or Action	Purpose
Step 1	Server# scope ssh	Enters the SSH command mode.
Step 2	Server /ssh # set enabled {yes no}	Enables or disables SSH on the Cisco IMC.
Step 3	Server /ssh # set ssh-port number	Sets the port to use for secure shell access. The default is 22.
Step 4	Server /ssh # set timeout seconds	Sets the number of seconds to wait before the system considers an SSH request to have timed out. Enter an integer between 60 and 10,800. The default is 300 seconds.
Step 5	Server /ssh # commit	Commits the transaction to the system configuration.
Step 6	Server /ssh # show [detail]	(Optional) Displays the SSH configuration.

Example

This example configures SSH for the Cisco IMC:

```
Server# scope ssh
Server /ssh # set enabled yes
Server /ssh *# set ssh-port 22
Server /ssh *# set timeout 600
Server /ssh *# commit
Server /ssh # show
SSH Port   Timeout  Active Sessions  Enabled
-----
22         600     1                yes

Server /ssh #
```

Configuring XML API

XML API for Cisco IMC

The Cisco IMC XML application programming interface (API) is a programmatic interface to Cisco IMC for a C-Series Rack-Mount Server. The API accepts XML documents through HTTP or HTTPS.

For detailed information about the XML API, see *Cisco UCS Rack-Mount Servers Cisco IMC XML API Programmer's Guide*.

Enabling XML API

Before you begin

You must log in as a user with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server# scope xmlapi	Enters XML API command mode.
Step 2	Server /xmlapi # set enabled {yes no}	Enables or disables XML API control of Cisco IMC.
Step 3	Server /xmlapi # commit	Commits the transaction to the system configuration.

Example

This example enables XML API control of Cisco IMC and commits the transaction:

```
Server# scope xmlapi
Server /xmlapi # set enabled yes
Server /xmlapi *# commit
Server /xmlapi # show detail
XMLAPI Settings:
  Enabled: yes
  Active Sessions: 0
  Max Sessions: 4

Server /xmlapi #
```

Enabling Redfish

Before you begin

You must log in as a user with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server# scope redfish	Enters redfish command mode.
Step 2	Server /redfish # set enabled {yes no}	Enables or disables redfish control of Cisco IMC.
Step 3	Server /redfish* # commit	Commits the transaction to the system configuration.

Example

This example enables redfish control of Cisco IMC and commits the transaction:

```
Server# scope redfish
Server /redfish # set enabled yes
Server /redfish *# commit
Server /redfish # show detail
REDFISH Settings:
  Enabled: yes
  Active Sessions: 0
  Max Sessions: 4

Server /redfish #
```

Configuring IPMI

IPMI Over LAN

Intelligent Platform Management Interface (IPMI) defines the protocols for interfacing with a service processor embedded in a server platform. This service processor is called a Baseboard Management Controller (BMC) and resides on the server motherboard. The BMC links to a main processor and other on-board elements using a simple serial bus.

During normal operations, IPMI lets a server operating system obtain information about system health and control system hardware. For example, IPMI enables the monitoring of sensors, such as temperature, fan speeds and voltages, for proactive problem detection. If server temperature rises above specified levels, the server operating system can direct the BMC to increase fan speed or reduce processor speed to address the problem.

Configuring IPMI over LAN

Configure IPMI over LAN when you want to manage the Cisco IMC with IPMI messages.

Before you begin

You must log in with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server# scope ipmi	Enters the IPMI command mode.
Step 2	Server /ipmi # set enabled {yes no}	Enables or disables IPMI access on this server.
Step 3	Server /ipmi # set privilege-level {readonly user admin}	<p>Specifies the highest privilege level that can be assigned to an IPMI session on this server. This can be:</p> <ul style="list-style-type: none"> • readonly — IPMI users can view information but cannot make any changes. If you select this option, IPMI users with the "Administrator", "Operator", or "User" user roles can only create read-only IPMI sessions, regardless of their other IPMI privileges. • user — IPMI users can perform some functions but cannot perform administrative tasks. If you select this option, IPMI users with the "Administrator" or "Operator" user role can create user and read-only sessions on this server. • admin — IPMI users can perform all available actions. If you select this option, IPMI users with the "Administrator" user role can create admin, user, and read-only sessions on this server.
Step 4	Server /ipmi # set encryption-key key	Sets the IPMI encryption key to use for IPMI communications. The key value must be 40 hexadecimal numbers.
Step 5	Server /ipmi # commit	Commits the transaction to the system configuration.
Step 6	Server /ipmi # randomise-key	<p>Sets the IPMI encryption key to a random value.</p> <p>Note You can perform the Step 6 action instead of Steps 4 and 5.</p>
Step 7	At the prompt, enter y to randomize the encryption key.	Sets the IPMI encryption key to a random value.

Example

This example configures IPMI over LAN for the Cisco IMC:

```

Server# scope ipmi
Server /ipmi # set enabled yes
Server /ipmi *# set privilege-level admin
Server /ipmi *# set encryption-key abcdef01234567890abcdef01234567890abcdef
Server /ipmi *# commit
Server /ipmi *# show
Enabled Encryption Key                               Privilege Level Limit
-----
yes          ABCDEF01234567890ABCDEF01234567890ABCDEF admin

Server /ipmi # randomise-key
This operation will change the IPMI Encryption Key to a random value
Continue?[y|N]y
Setting IPMI Encryption Key to a random value...

Server /ipmi # show
Enabled Encryption Key                               Privilege Level Limit
-----
yes          abcdef01234567890abcdef01234567890abcdef admin

Server /ipmi #

```

Configuring SNMP

SNMP

The Cisco UCS C-Series Rack-Mount Servers support the Simple Network Management Protocol (SNMP) for viewing server configuration and status and for sending fault and alert information by SNMP traps. For information on Management Information Base (MIB) files supported by Cisco IMC, see the *MIB Quick Reference for Cisco UCS* at this URL: http://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/sw/mib/b-series/b_UCS_MIBRef.html.

Configuring SNMP Properties

Before you begin

You must log in as a user with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server# scope snmp	Enters SNMP command mode.
Step 2	Server /snmp # set enabled {yes no}	Enables or disables SNMP. Note SNMP must be enabled and saved before additional SNMP configuration commands are accepted.

	Command or Action	Purpose
Step 3	Server /snmp # commit	Commits the transaction to the system configuration.
Step 4	Server /snmp # set enable-serial-num {yes no}	Prefixes the traps with the serial number of the server.
Step 5	Server /snmp # set snmp-port <i>port number</i>	Sets the port number on which the SNMP agent runs. You can choose a number within the range 1 to 65535. The default port number is 161. Note The port numbers that are reserved for system calls, such as 22,23,80,123,443,623,389,636,3268,3269 and 2068, cannot be used as an SNMP port.
Step 6	Server /snmp # set community-str <i>community</i>	Specifies the default SNMP v1 or v2c community name that Cisco IMC includes on any trap messages it sends to the SNMP host. The name can be up to 18 characters.
Step 7	Server /snmp # set community-access	This can be one of the following : Disabled, Limited, or Full.
Step 8	Server /snmp # set trap-community-str	Specifies the SNMP community group to which trap information should be sent. The name can be up to 18 characters
Step 9	Server /snmp # set sys-contact <i>contact</i>	Specifies the system contact person responsible for the SNMP implementation. The contact information can be up to 254 characters, such as an email address or a name and telephone number. To enter a value that contains spaces, you must enclose the entry with quotation marks.
Step 10	Server /snmp # set sys-location <i>location</i>	Specifies the location of the host on which the SNMP agent (server) runs. The location information can be up to 254 characters. To enter a value that contains spaces, you must enclose the entry with quotation marks.
Step 11	Server /snmp # commit	Commits the transaction to the system configuration.

Example

This example configures the SNMP properties and commits the transaction:


```

Server# scope snmp
Server /snmp # set enabled yes
Server /snmp *# commit
Server /snmp *# set enable-serial-num yes
Server /snmp *# set snmp-port 20000
Server /snmp *# set community-str cimcpbublic
Server /snmp *# set community-access Full
Server /snmp *# set trap-community-str public
Server /snmp *# set sys-contact "User Name <username@example.com> +1-408-555-1212"
Server /snmp *# set sys-location "San Jose, California"
Server /snmp *# commit
Server /snmp # show detail
SNMP Settings:
  SNMP Port: 20000
  System Contact: User Name <username@example.com> +1-408-555-1212
  System Location: San Jose, California
  SNMP Community: cimcpbublic
  SNMP Trap Community: public
  SNMP Community access: Full
  Enabled: yes
  Serial Number Enabled: yes

Server /snmp #

```

What to do next

Configure SNMP trap settings as described in [Configuring SNMP Trap Settings, on page 9](#).

Configuring SNMP Trap Settings

Before you begin

- You must log in with admin privileges to perform this task.
- SNMP must be enabled and saved before trap settings can be configured.

Procedure

	Command or Action	Purpose
Step 1	Server# scope snmp	Enters the SNMP command mode.
Step 2	Server /snmp # scope trap-destinations <i>number</i>	Enters the SNMP trap destination command mode for the specified destination. Four SNMP trap destinations are available. The destination <i>number</i> is an integer between 1 and 15.
Step 3	Server /snmp/trap-destinations # set enabled {yes no}	Enables or disables the SNMP trap destination.
Step 4	Server /snmp/trap-destinations # set version { 2 3 }	Specify the desired SNMP version of the trap message.

	Command or Action	Purpose
		Note SNMPv3 traps will be delivered only to locations where the SNMPv3 user and key values are configured correctly.
Step 5	Server /snmp/trap-destinations # set type { trap inform }	Specifies whether SNMP notification messages are sent as simple traps or as inform requests requiring acknowledgment by the receiver. Note The inform option can be chosen only for V2 users.
Step 6	Server /snmp/trap-destinations # set user <i>user</i>	
Step 7	Server /snmp/trap-destination # set trap-addr <i>trap destination address</i>	Specifies the trap destination address to which the trap information is sent. You can set an IPv4 or IPv6 address or a domain name as the trap destination. Note When IPv6 is enabled, the SNMP Trap destination source address can either be the SLAAC IPv6 address (if available) or a user assigned IPv6 address. Both these are valid SNMP IPv6 destination addresses that uniquely identify the server.
Step 8	Server /snmp/trap-destinations # set trap-port <i>trap destination port</i>	Sets the port number the server uses to communicate with the trap destination. You can choose a number within the range 1 to 65535.
Step 9	Server /snmp/trap-destination # commit	Commits the transaction to the system configuration.

Example

This example configures general SNMP trap settings and trap destination number 1 and commits the transaction:

```
Server# scope snmp
Server /snmp # Scope trap-destinations 1
Server /snmp/trap-destination *# set enabled yes
Server /snmp/trap-destination *# set version 2
Server /snmp/trap-destination *# set type inform
Server /snmp/trap-destination *# set user user1
Server /snmp/trap-destination *# set trap-addr www.cisco.com
Server /snmp/trap-destination *# set trap-port 10000
Server /snmp/trap-destination *# commit
Server /snmp/trap-destination # show detail
Trap Destination 1:
  Enabled: yes
  SNMP version: 2
  Trap type: inform
```

```

SNMP user: user1
Trap Address: www.cisco.com
Trap Port: 10000
Delete Trap: no
Server /snmp/trap-destination #

```

Sending a Test SNMP Trap Message

Before you begin

You must log in with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server# scope snmp	Enters the SNMP command mode.
Step 2	Server /snmp # send-test-trap	Sends an SNMP test trap to the configured SNMP trap destination that are enabled. Note The trap must be configured and enabled in order to send a test message.

Example

This example sends a test message to all the enabled SNMP trap destinations:

```

Server# scope snmp
Server /snmp # send-test-trap
SNMP Test Trap sent to the destination.
Server /snmp #

```

Configuring SNMPv3 Users

Before you begin

- You must log in as a user with admin privileges to perform this task.
- SNMP must be enabled and saved before these configuration commands are accepted.

Procedure

	Command or Action	Purpose
Step 1	Server# scope snmp	Enters the SNMP command mode.
Step 2	Server /snmp # scope v3users number	Enters the SNMPv3 users command mode for the specified user number.

	Command or Action	Purpose
Step 3	Server /snmp/v3users # set v3add {yes no}	<p>Adds or deletes an SNMPv3 user. This can be one of the following:</p> <ul style="list-style-type: none"> • yes—This user is enabled as an SNMPv3 user and is allowed to access the SNMP OID tree. <p>Note The security name and security level must also be configured at this time or the user addition will fail.</p> <ul style="list-style-type: none"> • no—This user configuration is deleted.
Step 4	Server /snmp/v3users # set v3security-name <i>security-name</i>	Enter an SNMP username for this user.
Step 5	Server /snmp/v3users # set v3security-level {noauthnopriv authnopriv authpriv}	<p>Select a security level for this user. This can be one of the following:</p> <ul style="list-style-type: none"> • noauthnopriv—The user does not require an authorization or privacy password. • authnopriv—The user requires an authorization password but not a privacy password. If you select this option, you must configure an authentication key. • authpriv—The user requires both an authorization password and a privacy password. If you select this option, you must configure an authentication key and a private encryption key. <p>Note For a v3 version, only authnopriv and authpriv security levels are available.</p>
Step 6	Server /snmp/v3users # set v3proto {MD5 SHA}	Select an authentication protocol for this user.
Step 7	Server /snmp/v3users # set v3auth-key <i>auth-key</i>	Enter an authorization password for this user.
Step 8	Server /snmp/v3users # set v3priv-PROTO {DES AES}	Select an encryption protocol for this user.
Step 9	Server /snmp/v3users # set v3priv-auth-key <i>priv-auth-key</i>	Enter a private encryption key (privacy password) for this user.
Step 10	Server /snmp/v3users # commit	Commits the transaction to the system configuration.

Example

This example configures SNMPv3 user number 2 and commits the transaction:

```

Server# scope snmp
Server /snmp # scope v3users 2
Server /snmp/v3users # set v3add yes
Server /snmp/v3users *# set v3security-name ucsSNMPV3user
Server /snmp/v3users *# set v3security-level authpriv
Server /snmp/v3users *# set v3proto SHA
Server /snmp/v3users *# set v3auth-key
Please enter v3auth-key:ex4mplek3y
Please confirm v3auth-key:ex4mplek3y
Server /snmp/v3users *# set v3priv-proto AES
Server /snmp/v3users *# set v3priv-auth-key
Please enter v3priv-auth-key:!1@2#3$4%5^6&7*8
Please confirm v3priv-auth-key:!1@2#3$4%5^6&7*8
Server /snmp/v3users *# commit
Settings are being applied ... allow a few minutes for the process to complete
Server /snmp/v3users # show detail
User 2:
  Add User: yes
  Security Name: ucsSNMPV3user
  Security Level: authpriv
  Auth Type: SHA
  Auth Key: *****
  Encryption: AES
  Private Key: *****

Server /snmp/v3users #

```

Configuring a Server to Send Email Alerts Using SMTP

The Cisco IMC supports email-based notification of server faults to recipients without relying on the SNMP. The system uses the Simple Mail Transfer Protocol (SMTP) to send server faults as email alerts to the configured SMTP server.

A maximum of four recipients is supported.

Configuring SMTP Servers for Receiving E-Mail Alerts

Before you begin

You must log in as a user with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server# scope smtp	Enters the SMTP command mode.
Step 2	Server /smtp # set enabled {yes no}	Enables or disables the SMTP feature.
Step 3	Server /smtp * # set server-addr IP_Address	Assigns the SMTP server IP address.

	Command or Action	Purpose
Step 4	Server /smtp * # set fault-severity {critical major minor warning condition}	Assigns the fault severity to the mail alerts.
Step 5	Server /smtp * # set port <i>port_number</i>	Sets the port number for the SMTP server.
Step 6	Server /smtp * # commit	Commits the transaction to the system configuration.
Step 7	Server /smtp # send-test-mail recipient1	Sends a test mail alert to the email address assigned to the chosen recipient.

Example

This example shows how to configure SMTP for receiving mail alerts:

```

Server # scope smtp
Server /smtp # set enabled yes
Server /smtp *# set server-addr 10.10.10.10
Server /smtp *# set fault-severity major
Server /smtp *# set port 25
Server /smtp # set-mail-addr recipient1 test@cisco.com
There is no change in the configured port number.
Please verify if you wish to choose a different one before commit.
Server /smtp *# commit
Server /smtp # show detail
SMTP Setting:
  Enabled: yes
  Port Number: 25
  Server Address: 10.104.10.10
  Minimum Severity to Report: critical
  Recipient1:
    Name      : test@cisco.com
    Reachable: na
  Recipient2:
    Name      :
    Reachable: na
  Recipient3:
    Name      :
    Reachable: na
  Recipient4:
    Name      :
    Reachable: na

Server /smtp # send-test-mail recipient1
Test mail sent Successful.
Server /smtp # show detail
SMTP Setting:
  Enabled: yes
  Port Number: 25
  Server Address: 10.10.10.10
  Minimum Severity to Report: critical
  Recipient1:
    Name      : test@cisco.com
    Reachable: yes
  Recipient2:
    Name      :

```

```
    Reachable: na
Recipient3:
    Name      :
    Reachable: na
Recipient4:
    Name      :
    Reachable: na

Server /smtp #
```

