



Managing the Server

This chapter includes the following sections:

- [Toggling the Server Locator LED, on page 1](#)
- [Toggling the Locator LED for a Hard Drive, on page 2](#)
- [Clearing Personality Configuration, on page 3](#)
- [Managing the Server Boot Order, on page 3](#)
- [Managing Server Power, on page 6](#)
- [Resetting the Server, on page 20](#)
- [Shutting Down the Server , on page 21](#)
- [Configuring DIMM Black Listing, on page 22](#)
- [Configuring BIOS Settings, on page 23](#)
- [Viewing Product ID \(PID\) Catalog Details, on page 32](#)
- [Uploading and Activating PID Catalog, on page 33](#)
- [Deleting PID Catalog, on page 35](#)
- [Persistent Memory Module, on page 36](#)

Toggling the Server Locator LED

Before you begin

You must log in with user or admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server # scope server server ID	Enters server command mode.
Step 2	Server /server # set locator-led {on off}	Enables or disables the server locator LED.
Step 3	Server /server # commit	Commits the transaction to the system configuration.

Example

This example disables the server locator LED and commits the transaction:

```
Server# scope server 1
Server /server # set locator-led off
Server /server *# commit

Server /server #
```

Toggling the Locator LED for a Hard Drive

Before you begin

You must log in with user or admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 2	Server /server # scope sensor	Enters sensor command.
Step 3	Server /server/sensor # scope hdd	Enters hard disk drive (HDD) command mode.
Step 4	Server /server/sensor/hdd # set locateHDD <i>drivenum</i> {1 2}	Where <i>drivenum</i> is the number of the hard drive whose locator LED you want to set. A value of 1 turns the LED on while a value of 2 turns the LED off.

Example

This example turns on the locator LED on HDD 2:

```
Server# scope server 1
Server /server # scope sensor
Server /server/sensor # scope hdd
Server /server/sensor/hdd # locateHDD 2 1
HDD Locate LED Status changed to 1
Server /server/sensor/hdd # show
Name                Status                LocateLEDStatus
-----
HDD1_STATUS         present               TurnOFF
HDD2_STATUS         present               TurnON
HDD3_STATUS         absent                TurnOFF
HDD4_STATUS         absent                TurnOFF

Server /server/sensor/hdd #
```

Clearing Personality Configuration

Before you begin

You must log in with admin privileges to perform this task.

Procedure

- Step 1** Server # **scope chassis**
Enters chassis command mode.
- Step 2** Server chassis # **clear-personality**
Clears the personality configuration.
-

Managing the Server Boot Order

Server Boot Order

Using Cisco IMC, you can configure the order in which the server attempts to boot from available boot device types. In the legacy boot order configuration, Cisco IMC allows you to reorder the device types but not the devices within the device types. With the precision boot order configuration, you can have a linear ordering of the devices. In the web UI or CLI you can change the boot order and boot mode, add multiple devices under each device types, rearrange the boot order, set parameters for each device type.

When you change the boot order configuration, Cisco IMC sends the configured boot order to BIOS the next time that server is rebooted. To implement the new boot order, reboot the server after you make the configuration change. The new boot order takes effect on any subsequent reboot. The configured boot order remains until the configuration is changed again in Cisco IMC or in the BIOS setup.



- Note** The actual boot order differs from the configured boot order if either of the following conditions occur:
- BIOS encounters issues while trying to boot using the configured boot order.
 - A user changes the boot order directly through BIOS.
-

Viewing the Actual Server Boot Order

The actual server boot order is the boot order actually used by the BIOS when the server last booted. The actual boot order can differ from the boot order configured in .

Procedure

	Command or Action	Purpose
Step 1	Server # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 2	Server /server# scope bios	Enters BIOS command mode.
Step 3	Server /server/bios # show actual-boot-order [detail]	Displays the boot order actually used by the BIOS when the server last booted.

Example

This example displays the actual boot order of the legacy boot order from the last boot:

```
Server# scope server 1
Server /server # scope bios
Server /server/bios # show actual-boot-order
```

Boot Order	Boot Device	Device Type	Boot Policy
1	Cisco CIMC-Mapped vDVD1.22	VMEDIA	NIHUUCIMCDVD
2	Cisco vKVM-Mapped vDVD1.22	VMEDIA	dvd
3	Cisco vKVM-Mapped vHDD1.22	VMEDIA	dvd2
4	Cisco CIMC-Mapped vHDD1.22	VMEDIA	dvd3
5	(Bus 14 Dev 00) PCI RAID Adapter	HDD	NonPolicyTarget
6	"P1: INTEL SSDSC2BB120G4 "	PCHSTORAGE	NonPolicyTarget
7	"UEFI: Built-in EFI Shell "	EFI	NonPolicyTarget
8	"P0: INTEL SSDSC2BB120G4 "	PCHSTORAGE	NonPolicyTarget
9	Cisco vKVM-Mapped vFDD1.22	VMEDIA	NonPolicyTarge

```
Server /server/bios #
```

Configuring a Server to Boot With a One-Time Boot Device

You can configure a server to boot from a particular device only for the next server boot, without disrupting the currently configured boot order. Once the server boots from the one time boot device, all its future reboots occur from the previously configured boot order.

Before you begin

You must log in with user or admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server# scope bios	Enters the BIOS command mode.
Step 2	Server# /bios show boot-device	Displays the list of available boot drives.
Step 3	Server# /bios set one-time-boot-device <i>device-order</i>	Sets the boot order.

	Command or Action	Purpose
		Note The host boots to the one time boot device even when configured with a disabled advanced boot device.
Step 4	Server# /bios * commit	Commits the transaction.
Step 5	(Optional) Server# /bios show detail	Displays the BIOS details.

Example

This example shows how to configure a server to boot with a one-time boot device:

```
Server scope bios
Server /bios # show boot-device
Boot Device                Device Type  Device State  Device Order
-----
KVMDVD                    VMEDIA      Enabled       1
vkvm                      VMEDIA      Enabled       2

Server /bios # set one-time-boot-device KVMDVD
Server /bios *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N]n
Changes will be applied on next reboot.
Server /bios # show detail
BIOS:
  BIOS Version: "C240M3.3.0.0.9 (Build Date: 10/02/16)"
  Boot Order: (none)
  FW Update/Recovery Status: None, OK
  UEFI Secure Boot: disabled
  Configured Boot Mode: Legacy
  Actual Boot Mode: Legacy
  Last Configured Boot Order Source: CIMC
  One time boot device: KVMDVD
Server /bios #
```

Assigning User-defined Server Description and Asset Tag

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters chassis command mode.
Step 2	Server /chassis # set description <Server Description>	Enters the server description.
Step 3	Server /chassis* # set asset-tag <Asset Tag>	Enters the asset tag.
Step 4	Server /chassis* # commit	Commits the transaction.
Step 5	(Optional) Server /chassis # show detail	Displays the server details.

Example

This example shows how to assign user-defined server description and asset tag:

```
Server# scope chassis
Server/chassis # set description DN1-server
Server/chassis* # set asset-tag powerpolicy
Server /chassis* # commit
Server /chassis # show detail
Chassis:
  Power: on
  Serial Number: FCH1834V23X
  Product Name: UCS C220 M4S
  PID : UCSC-C220-M4S
  UUID: 414949AC-22D6-4D0D-B0C0-F7950E9217C1
  Locator LED: off
  Description: DN1-server
  Asset Tag: powerpolicy
Server /chassis #
```

Managing Server Power

Powering On the Server



Note If the server was powered off other than through the , the server will not become active immediately when powered on. In this case, the server will enter standby mode until the completes initialization.



Important If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

Before you begin

You must log in with user or admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 3	Server /chassis/server # power on	Powers on the server.
Step 4	At the prompt, enter y to confirm.	Power on the server.

Example

This example shows how to power on the server:

```
Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power on
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID
-----
-----
1 On FCH1848794D UCS S3260M4 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#
```

Powering Off the Server



Important If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

Before you begin

You must log in with user or admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope server 1	Enters the server command mode.
Step 3	Server /chassis/server # power off	Powers off the server.
Step 4	At the prompt, enter y to confirm.	Power off the server.

Example

This example shows how to power off the server:

```
Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power off
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID
```

```

-----
1          Off  FCH1848794D  UCS S3260      UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#

```

Powering Cycling the Server



Important If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

Before you begin

You must log in with user or admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope server 1	Enters the server command mode.
Step 3	Server /chassis/server # power cycle	Power off and then powers on the server.
Step 4	At the prompt, enter y to confirm.	Power off and then powers on the server.

Example

This example shows how to power cycle the server:

```

Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power cycle
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name  PID                UUID
-----
1          On  FCH1848794D  UCS S3260      UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#

```

Configuring the Power Restore Policy

The power restore policy determines how power is restored to the server after a chassis power loss.

Before you begin

You must log in with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server /server # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 2	server /server # scope bmc	Enters bmc command mode.
Step 3	Server /server/bmc # scope power-restore-policy	Enters the power restore policy command mode.
Step 4	Server /server/bmc/power-restore-policy # set policy { power-off power-on restore-last-state }	<p>Specifies the action to be taken when chassis power is restored. Select one of the following:</p> <ul style="list-style-type: none"> • power-off—Server power will remain off until manually turned on. This is the default action. • power-on—Server power will be turned on when chassis power is restored. • restore-last-state—Server power will return to the state before chassis power was lost. <p>When the selected action is power-on, you can select a delay in the restoration of power to the server.</p>
Step 5	(Optional) Server /server/bmc/power-restore-policy # set delay { fixed random }	Specifies whether server power will be restored after a fixed or random time. The default is fixed . This command is accepted only if the power restore action is power-on .
Step 6	(Optional) Server /server/bmc/power-restore-policy # set delay-value <i>delay</i>	Specifies the delay time in seconds. The range is 0 to 240; the default is 0.
Step 7	Server /CIMC/power-restore-policy # commit	Commits the transaction to the system configuration.

Example

This example sets the power restore policy to power-on with a fixed delay of 180 seconds (3 minutes) and commits the transaction:

```
Server# scope server 1
Server /server # scope bmc
Server /server/bmc # Scope power-restore-policy
Server /server/bmc/power-restore-policy # set policy power-on
Server /server/bmc/power-restore-policy *# commit
Server /server/bmc/power-restore-policy # set delay fixed
```

```
Server /server/bmc/power-restore-policy *# set delay-value 180
Server /server/bmc/power-restore-policy *# commit
Server /server/bmc/power-restore-policy # show detail
Power Restore Policy:
  Power Restore Policy: power-on
  Power Delay Type: fixed
  Power Delay Value(sec): 180

Server /server/bmc/power-restore-policy #
```

Power Characterization

The chassis power characterization range is calculated and derived from individual server node power characterization status, and from the power requirements of all the unmanageable components of the chassis.

This range varies for each configuration, so you need to run the power characterization every time a configuration changes.

To help you use the power characterization range appropriately for the different power profiles, the system represents the chassis' minimum power as auto profile minimum and custom profile minimum. However, custom power profile minimum is the actual minimum power requirement of the current chassis configuration. For more information see the section Run Power Characterization.

Power Profiles

Power capping determines how server power consumption is actively managed. When you enable power capping option, the system monitors power consumption and maintains the power below the allocated power limit. If the server cannot maintain the power limit or cannot bring the platform power back to the specified power limit within the correction time, power capping performs actions that you specify in the Action field under the Power Profile area.

You can configure multiple profiles with the following combinations: automatic and thermal profiles; and custom and thermal profiles. These profiles are configured by using either the web user interface, command line interface, or XML API. In the web UI, the profiles are listed under the Power Capping area. In the CLI, the profiles are configured when you enter the **power-cap-config** command. You can configure the following power profiles for power capping feature:

- Automatic Power Limiting Profile
- Custom Power Limiting Profile
- Thermal Power Limiting Profile

Automatic power limiting profile sets the power limit of the individual server boards based on server priority selected by you, or as detected by the system, based on the server utilization sensor (which is known as manual or dynamic priority selection). The limiting values are calculated within the manageable chassis power budget and applied to the individual server, and the priority server is allocated with its maximum power limiting value, while the other server with the remaining of the manageable power budget. Power limiting occurs at each server board platform level that affects the overall chassis power consumption.

Custom power limiting profile allows you to set an individual server board's power limit from the Web UI or command line interface within the chassis power budget. In this scenario you can specify an individual server power limit.

Thermal power profile allows you to enable thermal failure power capping, which means you can set a specific platform temperature threshold and it sets P (min-x) as the power limit to be applied on the temperature threshold.

Enabling Chassis Global Power Capping

Before you begin

You must log in as a user with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope power-cap-config	Enters power cap configuration command mode.
Step 3	Server /chassis/power-cap-config # set pow-cap-enable {yes no}	Enables or disables the power configuration.
Step 4	Server /chassis/power-cap-config *# set chassis-budget <i>power limit</i>	Sets the chassis power limit.
Step 5	Server /chassis/power-cap-config *# commit	Commits the transaction to the system.
Step 6	(Optional) Server /chassis/power-cap-config # show detail	Displays the chassis power configuration details.

Example

The following example shows how to enable chassis global power capping:

```
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # set pow-cap-enable yes
Server /chassis/power-cap-config *# set chassis-budget 1000
Server /chassis/power-cap-config *# commit
Server /chassis/power-cap-config # show detail
Chassis :
    Power Capping: yes
    Power Characterization Status: Completed
    Chassis Minimum (W): 756
    Chassis Maximum (W): 1089
    Chassis Budget (W): 1000
    Chassis Manageable Power Budget (W): 530
    Auto Balance Minimum Power Budget (W) : 966
Server 1 :
    Power Characterization Status: Completed
    Platform Minimum (W): 163
    Platform Maximum (W): 362
    Memory Minimum (W): 1
    Memory Maximum (W): 0
    CPU Minimum (W): 95
    CPU Maximum (W): 241
Server 2 :
    Power Characterization Status: Completed
```

```

Platform Minimum (W): 136
Platform Maximum (W): 253
Memory Minimum (W): 1
Memory Maximum (W): 0
CPU Minimum (W): 57
CPU Maximum (W): 139
Server /chassis/power-cap-config #

```

Enabling Auto Balance Profile

Before you begin

You must log in as a user with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters chassis command mode.
Step 2	Server /chassis # scope power-cap-config	Enters power cap configuration command mode.
Step 3	Server /chassis/power-cap-config # scope power-profile auto_balance	Enters auto balance power profile command mode.
Step 4	Server /chassis/power-cap-config/power-profile # set enabled {yes no}	Enables or disables the power profile.
Step 5	Server /chassis/power-cap-config/power-profile *# set priority-selection {dynamic manual}	Sets the priority type to the chosen value.
Step 6	Server /chassis/power-cap-config/power-profile *# set priority-server-id {1 2}	Assigns priority to the chosen server.
Step 7	Server /chassis/power-cap-config/power-profile *# set corr-time Value	Sets the correction time in which the platform power should be brought back to the specified power limit before taking the action specified in the Action mode. The range is from 1 and 600 seconds. The default is 1 seconds.
Step 8	Server /chassis/power-cap-config/power-profile *# set allow-throttle {yes no}	Enables or disables the system to maintain the power limit by forcing the processor to use the throttling state (T-state) and memory throttle.
Step 9	Server /chassis /power-cap-config# set susp-pd {h:m-h:m /ll,Mo,Tu,We,Th,Fr,Sa,Su.}	Specifies the time period that the power capping profile will not be active.

	Command or Action	Purpose
Step 10	Server /chassis/power-cap-config/power-profile *# commit	Commits the transaction to the system configuration.
Step 11	(Optional) Server /chassis/power-cap-config/power-profile # show detail	Displays the auto balance power profile details.

Example

The following example shows how to enable auto balance profile and setting the priority selection:

Setting Priority Using Dynamic Option

```
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile auto_balance
Server /chassis/power-cap-config/power-profile # set enabled yes
Server /chassis/power-cap-config/power-profile *# set priority-selection dynamic
Server /chassis/power-cap-config/power-profile *# set corr-time 1
Server /chassis/power-cap-config/power-profile *# set allow-throttle yes
Server /chassis/power-cap-config/power-profile *# set susp-pd "2:0-4:30|All"
Server /chassis/power-cap-config/power-profile *# commit
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : auto_balance
    Enabled: yes
    Priority Selection: dynamic
    Priority Server: 2
    Server1 Power Limit: 362
    Server2 Power Limit: 253
    Suspend Period: 2:0-4:30|All
    Exception Action: alert
    Correction Time: 1
    Throttling: no
Server /chassis/power-cap-config/power-profile #
```

Setting Priority Using the Manual Option

```
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile auto_balance
Server /chassis/power-cap-config/power-profile # set enabled yes
Server /chassis/power-cap-config/power-profile *# set priority-selection manual
Server /chassis/power-cap-config/power-profile *# set priority-server-id 1
Server /chassis/power-cap-config/power-profile *# set corr-time 1
Server /chassis/power-cap-config/power-profile *# set allow-throttle yes
Server /chassis/power-cap-config/power-profile *# set susp-pd "2:0-4:30|All"
Server /chassis/power-cap-config/power-profile *# commit
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : auto_balance
    Enabled: yes
    Priority Selection: manual
    Priority Server: 1
    Server1 Power Limit: 362
    Server2 Power Limit: 253
    Suspend Period: 2:0-4:30|All
    Exception Action: alert
    Correction Time: 1
    Throttling: no
Server /chassis/power-cap-config/power-profile #
```

Disabling Auto Balance Power Profile

Procedure

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope power-cap-config	Enters the power cap configuration mode.
Step 3	Server /chassis/power-cap-config # scope power-profile auto_balance	Enters the auto balance power profile mode.
Step 4	Server /chassis/power-cap-config/power-profile # set enabled no	Disables the auto balance power profile.
Step 5	Server /chassis/power-cap-config/power-profile # commit	Commits the transaction to the system configuration.

Example

This example shows how to disable the auto balance profile:

```
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile auto_balance
Server /chassis/power-cap-config/power-profile # set enabled no
Server /chassis/power-cap-config/power-profile *# commit
```

Enabling Custom Profile on Server

Procedure

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope power-cap-config	Enters the power cap configuration mode.
Step 3	Server /chassis/power-cap-config # scope power-profile custom	Enters the custom power profile mode.
Step 4	Server /chassis/power-cap-config/power-profile # set enabled yes	Enables the custom power profile.
Step 5	Server /chassis/power-cap-config/power-profile *# set power-limit value	Specifies the power limit. Enter a value within the specified range.

	Command or Action	Purpose
Step 6	Server /chassis/power-cap-config/power-profile *# set corr-time <i>value</i>	Sets the correction time in which the platform power should be brought back to the specified power limit before taking the action specified in the Action mode. The range is from 1 and 600 seconds. The default is 1 seconds
Step 7	Server /chassis/power-cap-config/power-profile *# set allow-throttle yes	Enables the system to maintain the power limit by forcing the processor to use the throttling state (T-state) and memory throttle.
Step 8	Server /chassis/power-cap-config/power-profile *# commit	Commits the transaction to the system configuration.
Step 9	At the prompt, enter the server ID for which you want to apply the custom power profile.	
Step 10	Server /chassis/power-cap-config/power-profile # show detail	Displays the power profile details.

Example

This example shows how to enable the custom profile on any server node:

```
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile custom
Server /chassis/power-cap-config/power-profile # set enabled yes
Server /chassis/power-cap-config/power-profile *# set power-limit 253
Server /chassis/power-cap-config/power-profile *# set corr-time 1
Server /chassis/power-cap-config/power-profile *# set allow-throttle no
Server /chassis/power-cap-config/power-profile *# commit
Please enter server Id for which 'custom' power profile setting needs to be done
[1|2]?2
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : custom
Server Id 1:
    Enabled: no
    Power Limit: N/A
    Suspend Period:
    Exception Action: alert
    Correction Time: 1
    Throttling: no
Server Id 2:
    Enabled: yes
    Power Limit: 253
    Suspend Period:
    Exception Action: alert
    Correction Time: 1
    Throttling: yes
```

Disabling Custom Profile on Server

Procedure

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope power-cap-config	Enters the power cap configuration mode.
Step 3	Server /chassis/power-cap-config # scope power-profile custom	Enters the custom power profile mode.
Step 4	Server /chassis/power-cap-config/power-profile # set enabled no	Disables the custom power profile.
Step 5	Server /chassis/power-cap-config/power-profile *# commit	Commits the transaction to the system configuration.
Step 6	At the prompt, enter the server ID for which you want to disable the custom power profile.	
Step 7	Server /chassis/power-cap-config/power-profile # show detail	Displays the power profile details.

Example

This example shows how to disable the custom profile on any server node:

```

Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile custom
Server /chassis/power-cap-config/power-profile # set enabled no
Server /chassis/power-cap-config/power-profile *# commit
Please enter server Id for which 'custom' power profile setting needs to be done
[1|2]?2
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : custom
Server Id 1:
  Enabled: no
  Power Limit: N/A
  Suspend Period:
  Exception Action: alert
  Correction Time: 1
  Throttling: no
Server Id 2:
  Enabled: no
  Power Limit: 253
  Suspend Period:
  Exception Action: alert
  Correction Time: 1
  Throttling: yes

```

Enabling Thermal Profile on Server

Procedure

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope power-cap-config	Enters the power cap configuration mode.
Step 3	Server /chassis/power-cap-config # scope power-profile thermal	Enters the thermal power profile mode.
Step 4	Server /chassis/power-cap-config/power-profile # set enabled yes	Enables or disables the thermal power profile.
Step 5	Server /chassis/power-cap-config/power-profile *# set temperature value	Enter power in watts within the range specified. Enter the temperature in Celsius.
Step 6	Server /chassis/power-cap-config/power-profile *# commit	Commits the transaction to the system configuration.
Step 7	At the prompt, enter the server ID for which you want to enable the thermal power profile.	
Step 8	Server /chassis/power-cap-config/power-profile # show detail	Displays the power profile details.

Example

This example shows how to enable the thermal profile on any server node:

```
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile thermal
Server /chassis/power-cap-config/power-profile # set enabled yes
Server /chassis/power-cap-config/power-profile *# set temperature 26
Server /chassis/power-cap-config/power-profile *# commit
Please enter server Id for which 'thermal' power profile setting needs to be done
[1|2]?1
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : thermal
Server Id 1:
    Enabled: yes
    Temperature Threshold (deg C): 26
    Power Limit: 163
```

Disabling Thermal Profile on Server

Procedure

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters the chassis command mode.

	Command or Action	Purpose
Step 2	Server /chassis # scope power-cap-config	Enters the power cap configuration mode.
Step 3	Server /chassis/power-cap-config # scope power-profile thermal	Enters the thermal power profile mode.
Step 4	Server /chassis/power-cap-config/power-profile # set enabled no	Disables the thermal power profile.
Step 5	Server /chassis/power-cap-config/power-profile *# commit	Commits the transaction to the system configuration.
Step 6	At the prompt, enter the server ID for which you want to disable the thermal power profile.	
Step 7	Server /chassis/power-cap-config/power-profile # show detail	Displays the power profile details.

Example

This example shows how to disable the thermal profile on any server node:

```

Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile thermal
Server /chassis/power-cap-config/power-profile # set enabled no
Server /chassis/power-cap-config/power-profile *# commit
Please enter server Id for which 'thermal' power profile setting needs to be done
[1|2]?1
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : thermal
Server Id 1:
    Enabled: no
    Temperature Threshold (deg C): 26
    Power Limit: 163
Server Id 2:
    Enabled: no
    Temperature Threshold (deg C): 0
    Power Limit: N/A
Server /chassis/power-cap-config/power-profile #

```

Viewing Power Cap Configuration Details

Procedure

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope power-cap-config	Enters the power cap configuration mode.

	Command or Action	Purpose
Step 3	Server /chassis/power-cap-config # show detail	Displays the power characterization status of the chassis and servers.

Example

This example shows how to view power cap configuration details:

```
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # show detail
Chassis :
    Power Capping: yes
    Power Characterization Status: Completed
    Chassis Minimum (W): 756
    Chassis Maximum (W): 1089
    Chassis Budget (W): 1000
    Chassis Manageable Power Budget (W): 530
    Auto Balance Minimum Power Budget (W) : 966
    Auto Balance Efficient Budget (W): 1901
Server 1 :
    Power Characterization Status: Completed
    Platform Minimum (W): 163
    Platform Efficient (W): 396
    Platform Maximum (W): 362
    Memory Minimum (W): 1
    Memory Maximum (W): 0
    CPU Minimum (W): 95
    CPU Maximum (W): 241
Server 2 :
    Power Characterization Status: Completed
    Platform Minimum (W): 136
    Platform Efficient (W): 584
    Platform Maximum (W): 253
    Memory Minimum (W): 1
    Memory Maximum (W): 0
    CPU Minimum (W): 57
    CPU Maximum (W): 139
Server /chassis/power-cap-config #
```

Viewing Power Monitoring Details

Procedure

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # show power-monitoring	Displays the power monitoring details.

Example

This example shows how to view power monitoring details:

```

Server # scope chassis
Server /chassis # show power-monitoring
Chassis :
Current (W)  Minimum (W)  Maximum (W)  Average (W)  Period
-----
408          311          471          392          0days 9:5...
Server 1 :
Domain       Current (W)  Minimum (W)  Maximum (W)  Average (W)  Period
-----
Platform    68           61           178          68           0days 21:...
CPU         30           28           133          30           0days 21:...
Memory      1            0            1            1            0days 21:...
Server 2 :
Domain       Current (W)  Minimum (W)  Maximum (W)  Average (W)  Period
-----
Platform    97           62           200          100          1days 7:1:2
CPU         46           16           140          48           1days 7:1:2
Memory      1            0            1            1            1days 7:1:2
Server /chassis/server/pid-catalog #

```

Viewing CUPS Utilization Details

Procedure

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # show cups-utilization	Displays the server utilization value on all the available CPUs.

Example

This example shows how to view CUPS utilization details:

```

Server # scope chassis
Server /chassis # show cups-utilization
Server 1 :
CPU Utilization (%)  Memory Utilization (%)  I/O Utilization (%)  Overall Utilization (%)
-----
0                    0                        0                    0
Server 2 :
CPU Utilization (%)  Memory Utilization (%)  I/O Utilization (%)  Overall Utilization (%)
-----
7                    0                        0                    8

```

Resetting the Server



Important If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

Before you begin

You must log in with user or admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope server 1	Enters the server command mode.
Step 3	Server /chassis/server # power hard-reset	Reset the server, this is equivalent to pressing the reset button on the front panel or IPMI reset.
Step 4	At the prompt, enter y to confirm.	Reset the server, this is equivalent to pressing the reset button on the front panel or IPMI reset.

Example

This example shows how to power hard reset the server:

```
Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power hard-reset
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID
-----
-----
1 Off FCH1848794D UCS S3260 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#
```

Shutting Down the Server



Important If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

Before you begin

You must log in with user or admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.

	Command or Action	Purpose
Step 2	Server /chassis # scope server 1	Enters the server command mode.
Step 3	Server /chassis/server # power shutdown	Shuts down the host OS and powers off the server.
Step 4	At the prompt, enter y to confirm.	Shuts down the host OS and powers off the server.

Example

This example shows how to shutdown the server:

```
Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power shutdown
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID
-----
-----
1 Off FCH1848794D UCS S3260 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#
```

Configuring DIMM Black Listing

DIMM Black Listing

In Cisco IMC, the state of the Dual In-line Memory Module (DIMM) is based on SEL event records. A DIMM is marked bad if the BIOS encounters a non-correctable memory error or correctable memory error with 16000 error counts during memory test execution during BIOS post. If a DIMM is marked bad, it is considered a non-functional device.

If you enable DIMM blacklisting, Cisco IMC monitors the memory test execution messages and blacklists any DIMM that encounters memory errors at any given point of time in the DIMM SPD data. This allows the host to map out those DIMMs.

DIMMs are mapped out or blacklisted only when Uncorrectable errors occur. When a DIMM gets blacklisted, other DIMMs in the same channel are ignored or disabled, which means that the DIMM is no longer considered bad.



Note DIMMs do not get mapped out or blacklisted for 16000 Correctable errors.

Enabling DIMM Black Listing

Before you begin

You must be logged in as an administrator.

Procedure

	Command or Action	Purpose
Step 1	Server # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 2	Server /server # scope dimm-blacklisting /	Enters the DIMM blacklisting mode.
Step 3	Server /server/dimm-blacklisting # set enabled {yes no}	Enables or disables DIMM blacklisting.
Step 4	Server /server/dimm-blacklisting* # commit	Commits the transaction to the system configuration.

Example

The following example shows how to enable DIMM blacklisting:

```
Server # scope server 1
Server /server # scope dimm-blacklisting
Server /server/dimm-blacklisting # set enabled yes
Server /server/dimm-blacklisting* # commit
Server /server/dimm-blacklisting #
Server /server/dimm-blacklisting # show detail

DIMM Blacklisting:
  Enabled: yes
Server /server/dimm-blacklisting #
```

Configuring BIOS Settings

Viewing BIOS Status

Procedure

	Command or Action	Purpose
Step 1	Server # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 2	Server /server # scope bios	Enters the BIOS command mode.
Step 3	Server /server/bios # show detail	Displays details of the BIOS status.

The BIOS status information contains the following fields:

Name	Description
BIOS Version	The version string of the running BIOS.
Backup BIOS Version	The backup version string of the BIOS.
Boot Order	The legacy boot order of bootable target types that the server will attempt to use.
Boot Override Priority	This can be None, or HV.
FW Update/Recovery Status	The status of any pending firmware update or recovery action.
UEFI Secure Boot	Enables or Disables UEFI secure boot.
Configured Boot Mode	The boot mode in which h BIOS will try to boot the devices.
Actual Boot Mode	The actual boot mode in which BIOS booted the devices.
Last Configured Boot Order Source	The last configured boot order source by BIOS.

Example

This example displays the BIOS status:

```
Server# scope server 1
Server /sever # scope bios
Server /sever/bios # show detail
Server /sever/bios # show detail
BIOS:
  BIOS Version: server-name.2.0.7c.0.071620151216
  Backup BIOS Version: server-name.2.0.7c.0.071620151216
  Boot Order: (none)
  Boot Override Priority:
  FW Update/Recovery Status: None, OK
  UEFI Secure Boot: disabled
  Configured Boot Mode: Legacy
  Actual Boot Mode: Legacy
  Last Configured Boot Order Source: CIMC
Server /sever/bios #
```

Configuring Main BIOS Settings

Before you begin

You must log in with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server # <code>scope server {1 2}</code>	Enters server command mode of server 1 or 2.

	Command or Action	Purpose
Step 2	Server /server # scope bios	Enters the BIOS command mode.
Step 3	Server /server /bios # scope main	Enters the main BIOS settings command mode.
Step 4	Server /server /bios # set TPMAdminCtrl { Disbaled Enabled }	Enables or disables TPM support.
Step 5	Server /server /bios/main # commit	Commits the transaction to the system configuration. Changes are applied on the next server reboot. If server power is on, you are prompted to choose whether to reboot now.

Example

This example configures the main BIOS parameter and commits the transaction:

```
Server /server # scope server 1
Server/server # scope bios
Server /server/bios # scope main
Server /server/bios/main # set TPMAdminCtrl Enabled
Server /server/bios/main *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N] n
Changes will be applied on next reboot.
Server /server/bios/main #
```

Configuring Advanced BIOS Settings

Before you begin

You must log in with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server # scope server { 1 2 }	Enters server command mode of server 1 or 2.
Step 2	Server /sever # scope bios	Enters the BIOS command mode.
Step 3	Server /sever/bios # scope advanced	Enters the advanced BIOS settings command mode.
Step 4	Configure the BIOS settings.	BIOS Parameters by Server Model
Step 5	Server /sever/bios/advanced # commit	Commits the transaction to the system configuration.

	Command or Action	Purpose
		Changes are applied on the next server reboot. If server power is on, you are prompted to choose whether to reboot now.

Example

This example enables all the USB drives and commits the transaction:

```
Server# scope server 1
Server/sever # scope bios
Server /sever/bios # scope advanced
Server /sever/bios/advanced # set AllUsbDevices Enabled
Server /sever/bios/advanced *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N] n
Changes will be applied on next reboot.
Server /sever/bios/advanced #
```

Configuring Server Management BIOS Settings

Before you begin

You must log in with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 2	Server /sever # scope bios	Enters the BIOS command mode.
Step 3	Server /sever/bios # scope server-management	Enters the server management BIOS settings command mode.
Step 4	Configure the BIOS settings.	BIOS Parameters by Server Model
Step 5	Server /sever/bios/server-management # commit	Commits the transaction to the system configuration. Changes are applied on the next server reboot. If server power is on, you are prompted to choose whether to reboot now.

Example

This example enables the OS watchdog timer and commits the transaction:

```
Server# scope bios
Server /sever # scope bios
Server /sever/bios # scope server-management
```

```

Server /sever/bios/server-management # set OSBootWatchdogTimer Enabled
Server /sever/bios/server-management *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N] n
Changes will be applied on next reboot.
Server /sever/bios/server-management #

```

Restoring BIOS Defaults

Before you begin

You must log in as a user with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 2	Server /sever # scope bios	Enters the BIOS command mode.
Step 3	Server /sever/bios # bios-setup-default	Restores BIOS default settings. This command initiates a reboot.

Example

This example restores BIOS default settings:

```

Server# scope bios
Server/sever # scope bios
Server /sever/bios # bios-setup-default
This operation will reset the BIOS set-up tokens to factory defaults.
All your configuration will be lost.
Changes to BIOS set-up parameters will initiate a reboot.
Continue?[y|N]y

```

Entering BIOS Setup

Before you begin

- The server must be powered on.
- You must log in as a user with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 2	Server /sever # scope bios	Enters the BIOS command mode.

	Command or Action	Purpose
Step 3	Server /sever/bios # enter-bios-setup	Enters BIOS setup on reboot.

Example

This example enables you to enter BIOS setup:

```
Server# scope server 1
Server /sever # scope bios
Server /sever/bios # enter-bios-setup
This operation will enable Enter BIOS Setup option.
Host must be rebooted for this option to be enabled.
Continue?[y|N]y
```

Restoring BIOS Manufacturing Custom Defaults

In instances where the components of the BIOS no longer function as desired, you can restore the BIOS set up tokens to the manufacturing default values.

Before you begin

- You must log in with admin privileges to perform this task.
- The server must be powered off.

Procedure

	Command or Action	Purpose
Step 1	Server # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 2	Server /sever # scope bios	Enters the BIOS command mode.
Step 3	Server /sever/bios # restore-mfg-defaults	Restores the set up tokens to the manufacturing default values.

Example

This example shows how to restore the BIOS set up tokens to the manufacturing default values:

```
Server # scope bios
Server /sever/bios # restore-mfg-defaults
This operation will reset the BIOS set-up tokens to manufacturing defaults.
The system will be powered on.
Continue? [y|n] y
Server /sever/bios #
```

BIOS Profiles

On the Cisco UCS server, default token files are available for every S3260 server platform, and you can configure the value of these tokens using the Graphic User Interface (GUI), CLI interface, and the XML API interface. To optimize server performance, these token values must be configured in a specific combination.

Configuring a BIOS profile helps you to utilize pre-configured token files with the right combination of the token values. Some of the pre-configured profiles that are available are virtualization, high-performance, low power, and so on. You can download the various options of these pre-configured token files from the Cisco website and apply it on the servers through the BMC.

You can edit the downloaded profile to change the value of the tokens or add new tokens. This allows you to customize the profile to your requirements without having to wait for turnaround time.

Activating a BIOS Profile

Before you begin

You must log in with user or admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server# scope bios	Enters the BIOS command mode.
Step 2	Server# /bios scope bios-profile	Enters the BIOS profile command mode.
Step 3	Server# /bios/bios-profile activate virtualization	You are prompted to back up the BIOS configuration. Enter y .
Step 4	You are prompted to reboot the system to apply the changes to the BIOS set-up parameters. Enter y .	Initiates the system reboot.

Example

This example activates the specified BIOS profile:

```
Server # scope bios
Server /bios # scope bios-profile
Server /bios/bios-profile # activate virtualization
It is recommended to take a backup before activating a profile.
Do you want to take backup of BIOS configuration?[y/n] y
backup-bios-profile succeeded.
bios profile "virtualization" deleted
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N]y
A system reboot has been initiated.
Server /bios/bios-profile #
```

Taking a Back-Up of a BIOS Profile

Before you begin

You must log in with user or admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server# scope bios	Enters the BIOS command mode.
Step 2	Server# /bios scope bios-profile	Enters the BIOS profile command mode.
Step 3	Server# /bios/bios-profile backup	Displays a message that the backup of the BIOS profile was successful.

Example

This example backs up a BIOS profile:

```
Server # scope bios
Server /bios # scope bios-profile
Server /bios/bios-profile # backup
backup-bios-profile succeeded.
Server /bios #
```

Deleting a BIOS Profile

Before you begin

You must log in with user or admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server# scope bios	Enters the BIOS command mode.
Step 2	Server# /bios scope bios-profile	Enters the BIOS profile command mode.
Step 3	Server# /bios/bios-profile delete BIOS profile	Deletes the specified BIOS profile.

Example

This example deletes the specified BIOS profile:

```
Server # scope bios
Server /bios # scope bios-profile
Server /bios/bios-profile # delete performance
Server /bios/bios-profile #
```

Displaying BIOS Profiles

Procedure

	Command or Action	Purpose
Step 1	Server# scope bios	Enters the BIOS command mode.
Step 2	Server# /bios show bios-profile	Displays all the BIOS profiles.

Example

This example displays all the BIOS profiles:

```
Server # scope bios
Server /bios # show bios-profile
ID      Name                Active
-----
1       performance           yes
2       virtualization          no
3       none                    no
4       cisco_backup             no
Server /bios #scope bios-profile
Server /bios #
```

Displaying Information of a BIOS Profile

Procedure

	Command or Action	Purpose
Step 1	Server# scope bios	Enters the BIOS command mode.
Step 2	Server# /bios scope bios-profile	Displays all the BIOS profiles.
Step 3	Server# /bios/bios-profile info performance	Displays information of the BIOS profile such as token name, profile value, and active value.

Example

This example displays information of the specified BIOS profile:

```
Server # scope bios
Server /bios # scope bios-profile
Server /bios/bios-profile # info performance

TOKEN NAME                PROFILE VALUE    ACTUAL VALUE
=====
TPMAdminCtrl              Enabled          Enabled
ASEPMSupport              Disabled         Disabled
Server /bios/bios-profile #
```

Displaying details of the BIOS Profile

Procedure

	Command or Action	Purpose
Step 1	Server# scope bios	Enters the BIOS command mode.
Step 2	Server# /bios scope bios-profile	Enters the BIOS profile command mode.
Step 3	Server# /bios/bios-profile show detail	Displays the details of BIOS profile.

Example

This example displays the details of the BIOS profile:

```
Server # scope bios
Server /bios # scope bios-profile
Server /bios/bios-profile # show detail
Active Profile: Virtualization
Install Status: bios profile install done
Server /bios/bios-profile #
```

Viewing Product ID (PID) Catalog Details

Procedure

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters chassis command mode.
Step 2	Server /chassis # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 3	Server /chassis/server # show cpu-pid	Displays the CPU PID details.
Step 4	Server /chassis/server # show dimm-pid	Displays the memory PID details.
Step 5	Server /chassis/server # show pciadapter-pid	Displays the PCI adapters PID details.
Step 6	Server /chassis/server # show hdd-pid	Displays the HDD PID details.

Example

This example shows how to create view PID details

```
Server # scope chassis
Server /chassis # scope server 1
Viewing CPU PID details
Server /chassis/server # show cpu-pid
Socket Product ID Model
-----
CPU1 UCS-CPU-E52660B Intel(R) Xeon(R) CPU E5-2660 v2 @ 2.2...
```

```

CPU2 UCS-CPU-E52660B Intel(R) Xeon(R) CPU E5-2660 v2 @ 2.2...
    
```

Viewing memory PID details

```

Server /chassis/server # show dimm-pid
    
```

Name	Product ID	Vendor ID	Capacity	Speed
DIMM_A1	UNKNOWN	NA	Failed	NA
DIMM_A2	UNKNOWN	NA	Ignore...	NA
DIMM_B1	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_B2	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_C1	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_C2	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_D1	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_D2	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_E1	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_E2	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_F1	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_F2	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_G1	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_G2	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_H1	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866
DIMM_H2	UCS-MR-1X162RZ-A	0xCE00	16384 MB	1866

Viewing PCI adapters PID details

```

Server /chassis/server # show pciadapter-pid
    
```

Slot	Product ID	Vendor ID	Device ID	SubVendor ID	SubDevice ID
1	UCSC-MLOM-CSC-02	0x1137	0x0042	0x1137	0x012e

Viewing HDD PID details

```

Server /chassis/server # show hdd-pid
    
```

Disk	Controller	Product ID	Vendor	Model
1	SBMezz1	UCSC-C3X60-HD6TB	SEAGATE	ST6000NM0014
2	SBMezz1	UCSC-C3X60-HD6TB	SEAGATE	ST6000NM0014
3	SBMezz1	UCSC-C3X60-HD6TB	SEAGATE	ST6000NM0014
4	SBMezz1	UCSC-C3X60-HD6TB	SEAGATE	ST6000NM0014
5	SBMezz1	UCSC-C3X60-HD6TB	SEAGATE	ST6000NM0014
6	SBMezz1	UCSC-C3X60-HD6TB	SEAGATE	ST6000NM0014
7	SBMezz1	UCSC-C3X60-HD6TB	SEAGATE	ST6000NM0014
8	SBMezz1	UCSC-C3X60-HD6TB	SEAGATE	ST6000NM0014
9	SBMezz1	UCSC-C3X60-HD6TB	SEAGATE	ST6000NM0014
10	SBMezz1	UCSC-C3X60-HD6TB	SEAGATE	ST6000NM0014
11	SBMezz1	UCSC-C3X60-HD6TB	SEAGATE	ST6000NM0014
12	SBMezz1	UCSC-C3X60-HD6TB	SEAGATE	ST6000NM0014
13	SBMezz1	UCSC-C3X60-HD6TB	SEAGATE	ST6000NM0014
14	SBMezz1	UCSC-C3X60-HD6TB	SEAGATE	ST6000NM0014
201	SBMezz1	UCSC-C3X60-12SSD	ATA	INTEL SSD...
202	SBMezz1	UCSC-C3X60-12SSD	ATA	INTEL SSD...

```

Server /chassis/server #
    
```

Uploading and Activating PID Catalog



Caution BMC reboots automatically once a PID catalog is activated.

You must reboot the server after activating a PID catalog.

Before you begin

You must log in as a user with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope pid-catalog	Enters the server PID catalog command mode.
Step 3	Server /chassis/pid-catalog # upload-pid-catalog <i>remote-protocol IP address</i> <i>PID Catalog file</i>	<p>Specifies the protocol to connect to the remote server. It can be one of the following types:</p> <ul style="list-style-type: none"> • TFTP • FTP • SFTP • SCP • HTTP <p>Note The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is <server_finger_print_ID> Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p>Initiates the upload of the PID catalog.</p>
Step 4	(Optional) Server /chassis/pid-catalog # show detail	Displays the status of the upload.
Step 5	Server /chassis/pid-catalog # exit	Returns to the chassis command mode.
Step 6	Server /chassis # scope server {1 2}	Enters server command mode of server 1 or 2.

	Command or Action	Purpose
Step 7	Server /chassis/server # scope pid-catalog	Enters server PID catalog command mode.
Step 8	Server /chassis/server/pid-catalog # activate	Activates the uploaded PID catalog.
Step 9	(Optional) Server /chassis/server/pid-catalog # show detail	Displays the status of the activation.

Example

This example shows how to upload and activate PID catalog:

```
Server # scope chassis
Server /chassis # scope pid-catalog
Uploading PID catalog
Server /chassis/pid-catalog # upload-pid-catalog tftp 10.10.10.10
pid-ctlg-2_0_12_78_01.tar.gz
upload-pid-catalog initialized.
Please check the status using "show detail".
Server /chassis/pid-catalog # show detail
    Upload Status: Upload Successful
Activating the uploaded PID catalog
Server /chassis/pid-catalog # exit
Server /chassis # scope server 2
Server /chassis/server # scope pid-catalog
Server /chassis/server/pid-catalog # activate
Successfully activated PID catalog
Server /chassis/server/pid-catalog # show detail
    Upload Status:
    Activation Status: Activation Successful
    Current Activated Version: 2.0(12.78).01
Server /chassis/server/pid-catalog #
```

Deleting PID Catalog



Caution BMC reboots automatically once a PID catalog is deleted.

You must reboot the server after deleting a PID catalog.

Before you begin

You must log in as a user with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope server {1 2}	Enters server command mode of server 1 or 2.

	Command or Action	Purpose
Step 3	Server /chassis/server # scope pid-catalog	Enters server PID catalog command mode.
Step 4	Server /chassis/server/pid-catalog # delete	Enter y at the confirmation prompt to delete the uploaded PID catalog. Note You can delete a PID catalog only if it has been previously updated and activated.
Step 5	(Optional) Server /chassis/server/pid-catalog # show detail	Displays the PID catalog status.

Example

This example shows how to upload and activate PID catalog:

```
Server # scope chassis
Server /chassis # scope server 2
Server /chassis/server # scope pid-catalog
Server /chassis/server/pid-catalog # delete
CIMC will be automatically rebooted after successful deletion of the uploaded catalog file.
Once this is complete, a host reboot will be required for the catalog changes to be reflected
in
the BIOS and host Operating System Continue?[y|N]y
Server /chassis/server/pid-catalog # show detail
PID Catalog:
  Upload Status: N/A
  Activation Status: N/A
  Current Activated Version: 4.1(0.41)
Server /chassis/server/pid-catalog #
```

Persistent Memory Module

Persistent Memory Modules

Cisco UCS S-Series Release 4.0(4) introduces support for the Intel® Optane™ Data Center persistent memory modules on the UCS M5 servers that are based on the Second Generation Intel® Xeon® Scalable processors. These persistent memory modules can be used only with the Second Generation Intel® Xeon® Scalable processors.

Persistent memory modules are non-volatile memory modules that bring together the low latency of memory and the persistence of storage. Data stored in persistent memory modules can be accessed quickly compared to other storage devices, and is retained across power cycles.

For detailed information about configuring persistent memory modules, see the [Cisco UCS: Configuring and Managing Intel® Optane™ Data Center Persistent Memory Modules Guide](#).