



Cisco UCS Integrated Management Controller CLI Configuration Guide for S3260 Storage Servers, Release 4.3

First Published: 2023-03-03

Last Modified: 2023-08-16

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883



CONTENTS

PREFACE

Preface	xvii
Audience	xvii
Conventions	xvii
Related Cisco UCS Documentation	xix

CHAPTER 1

Overview	1
Overview of the Cisco UCS S-Series Rack-Mount Server S3260	1
Overview of the Server Software	2
Server Ports	2
Cisco Integrated Management Controller	3
CLI	4
Command Modes	5
Command Mode Table	5
Complete a Command	8
Command History	9
Committing, Discarding, and Viewing Pending Commands	9
Command Output Formats	9
Online Help for the CLI	10
Logging In to	10

CHAPTER 2

Installing the Server OS	13
OS Installation Methods	13
Virtual KVM Console	13
Installing an OS Using the KVM Console	14
PXE Installation Servers	14
Installing an OS Using a PXE Installation Server	15

Booting an Operating System from a USB Port 15

CHAPTER 3**Managing Chassis 17**

Viewing Chassis Properties 17

Viewing Chassis Summary 17

Viewing CMC Firmware Versions 18

Viewing LED Details 18

Viewing the Details of the Servers on the Chassis 19

Viewing Physical Drive Properties 19

Viewing Cisco VIC Adapter Properties 21

Viewing Power Supply Properties 23

Chassis Management Tasks 24

 Toggling the Front Locator LED for the Chassis 24

 Updating Firmware on Server Components 25

 Time Zone 26

 Selecting a Time Zone 26

 Setting a Time Zone 26

 Single Server Dual SIOC Connectivity 29

 Configuring Single Server Dual SIOC Connectivity 29

Managing Dynamic Storage 31

 Dynamic Storage Support 31

 Viewing SAS Expander Properties 31

 Viewing Dynamic Storage and Physical Drive Details 33

 Enabling 6G or 12G Mixed Mode Speed on SAS Expanders 35

 Enabling Dual Enclosure ID 36

 Managing Physical Drives 37

 Assigning Physical Drives to Servers 37

 Unassigning Physical Drives to Servers 38

 Assigning Physical Drives as Chassis Wide Hot Spare 38

 Sharing Physical Drives with Servers 39

CHAPTER 4**Managing the Server 41**

 Toggling the Server Locator LED 41

 Toggling the Locator LED for a Hard Drive 42

Clearing Personality Configuration	43
Managing the Server Boot Order	43
Server Boot Order	43
Viewing the Actual Server Boot Order	44
Configuring a Server to Boot With a One-Time Boot Device	44
Assigning User-defined Server Description and Asset Tag	46
Managing Server Power	46
Powering On the Server	46
Powering Off the Server	47
Powering Cycling the Server	48
Configuring the Power Restore Policy	49
Power Characterization	51
Power Profiles	51
Enabling Chassis Global Power Capping	51
Enabling Auto Balance Profile	53
Disabling Auto Balance Power Profile	55
Enabling Custom Profile on Server	55
Disabling Custom Profile on Server	57
Enabling Thermal Profile on Server	58
Disabling Thermal Profile on Server	59
Viewing Power Cap Configuration Details	60
Viewing Power Monitoring Details	61
Viewing CUPS Utilization Details	62
Resetting the Server	63
Shutting Down the Server	64
Configuring DIMM Black Listing	65
DIMM Block Listing	65
Enabling DIMM Black Listing	65
Configuring BIOS Settings	66
Viewing BIOS Status	66
Configuring Main BIOS Settings	67
Configuring Advanced BIOS Settings	68
Configuring Server Management BIOS Settings	69
Restoring BIOS Defaults	70

- Entering BIOS Setup 71
- Restoring BIOS Manufacturing Custom Defaults 71
- BIOS Profiles 72
 - Activating a BIOS Profile 72
 - Taking a Back-Up of a BIOS Profile 73
 - Deleting a BIOS Profile 74
 - Displaying BIOS Profiles 74
 - Displaying Information of a BIOS Profile 75
 - Displaying details of the BIOS Profile 76
- Viewing Product ID (PID) Catalog Details 76
- Uploading and Activating PID Catalog 78
- Deleting PID Catalog 80
- Persistent Memory Module 81
 - Persistent Memory Modules 81

CHAPTER 5

- Viewing Server Properties 83**
 - Viewing Server Properties 83
 - Viewing CMC Properties 84
 - Viewing Server CPU Details 84
 - Viewing Memory Properties 85
 - Viewing PCI Adapter Properties for a Server 87
 - Viewing HDD Details for a Server 88
 - Viewing Storage Adapter Properties for a Server 89
 - Viewing TPM Properties 89

CHAPTER 6

- Viewing Sensors 91**
 - Viewing Chassis Sensors 91
 - Viewing Power Supply Sensors 91
 - Viewing Fan Sensors 92
 - Viewing Current Sensors 93
 - Viewing Voltage Sensors 94
 - Viewing Temperature Sensors 95
 - Viewing LED Sensor 97
 - Viewing Server Sensors 97

Viewing Storage Sensors	97
Viewing Current Sensors	98
Viewing LED Sensors	99
Viewing Temperature Sensors	100
Viewing Voltage Sensors	101

CHAPTER 7**Managing Remote Presence 103**

Managing the Virtual KVM	103
Virtual KVM Console	103
Enabling the Virtual KVM	104
Disabling the Virtual KVM	105
Configuring the Virtual KVM	106
Configuring Virtual Media	107
Configuring a Cisco IMC-Mapped vMedia Volume	109
Viewing Cisco IMC-Mapped vMedia Volume Properties	110
Remapping an Existing Cisco IMC vMedia Image	110
Deleting a Cisco IMC vMedia Image	111
Managing Serial over LAN	112
Serial Over LAN	112
Guidelines and Restrictions for Serial Over LAN	112
Configuring Serial Over LAN	112

CHAPTER 8**Managing User Accounts 115**

Configuring Local Users for Cisco UCS C-Series M7 and Later Servers	115
Managing SSH Keys for User Accounts	118
Configuring SSH Keys	118
Adding SSH Keys	118
Modifying SSH Keys	120
Deleting SSH Keys	122
Non-IPMI User Mode	123
Switching User Mode from IPMI to Non-IPMI	123
Switching User Mode from Non-IPMI to IPMI	124
Disabling Strong Password	125
Password Expiry	126

Configuring User Authentication Precedence	126
Resetting the User Password	127
Configuring Password Expiry for Users	128
LDAP Servers	129
Configuring the LDAP Server	130
Configuring LDAP in	131
Configuring LDAP Groups in	135
Configuring Nested Group Search Depth in LDAP Groups	136
TACACS+ Authentication	137
TACACS+ Server Configuration	137
Enabling TACACS+ Authentication	138
Configuring TACACS+ Remote Server Settings	139
LDAP Certificates Overview	140
Exporting LDAP CA Certificate	140
Testing LDAP Binding	141
Deleting LDAP CA Certificate	142
Viewing User Sessions	143
Terminating a User Session	144

CHAPTER 9

Configuring Network-Related Settings	147
Server NIC Configuration	147
Server NICs	147
Configuring NICs	149
Common Properties Configuration	150
Overview to Common Properties Configuration	150
Configuring Common Properties	150
Configuring Single IP Properties	152
Configuring IPv4	153
Configuring IPv6	156
Configuring ICMP	160
Configuring VLAN	161
Connecting to a Port Profile	163
Configuring Interface Properties	165
Network Security Configuration	166

Network Security	166
Configuring Network Security	166
Network Time Protocol Configuration	168
Configuring Network Time Protocol Settings	168
Pinging an IP address	169

CHAPTER 10**Managing Network Adapters 171**

Overview of the Cisco UCS C-Series Network Adapters	171
Viewing Network Adapter Properties	173
Configuring Network Adapter Properties	174
Managing vHBAs	177
Guidelines for Managing vHBAs	177
Viewing vHBA Properties	177
Modifying vHBA Properties	178
Creating a vHBA	184
Deleting a vHBA	186
vHBA Boot Table	186
Viewing the Boot Table	187
Creating a Boot Table Entry	187
Deleting a Boot Table Entry	188
vHBA Persistent Binding	190
Enabling Persistent Binding	190
Disabling Persistent Binding	191
Rebuilding Persistent Binding	191
Managing vNICs	192
Guidelines for Managing vNICs	192
Viewing vNIC Properties	193
Modifying vNIC Properties	195
Setting Admin Link Training on External Ethernet Interfaces	204
Setting Admin FEC Mode on External Ethernet Interfaces	206
Creating a vNIC	207
Deleting a vNIC	208
Creating Cisco usNIC Using the CLI	209
Modifying a Cisco usNIC value using the CLI	212

Viewing usNIC Properties	214
Deleting Cisco usNIC from a vNIC	214
Configuring iSCSI Boot Capability	215
Configuring iSCSI Boot Capability for vNICs	215
Configuring iSCSI Boot Capability on a vNIC	216
Deleting an iSCSI Boot Configuration for a vNIC	217
Backing Up and Restoring the Adapter Configuration	218
Exporting the Adapter Configuration	218
Importing the Adapter Configuration	220
Restoring Adapter Defaults	221
Managing Adapter Firmware	221
Adapter Firmware	221
Installing Adapter Firmware	222
Activating Adapter Firmware	223
<hr/>	
CHAPTER 11	Managing Storage Adapters 225
Creating Virtual Drives from Unused Physical Drives	225
Creating Virtual Drive from an Existing Drive Group	228
Importing Foreign Configuration	230
Clearing Foreign Configuration	231
Retrieving Storage Firmware Logs for a Controller	232
Self Encrypting Drives (Full Disk Encryption)	233
Enabling Security on a Controller	234
Disabling Security on a Controller	235
Modifying Controller Security Settings	236
Verifying the Security Key Authenticity	237
Switching Controller Security From Remote to Local Key Management	238
Switching Controller Security From Local to Remote Key Management	239
Deleting a Virtual Drive	240
Initializing a Virtual Drive	241
Set as Boot Drive	242
Modifying Attributes of a Virtual Drive	243
Making a Dedicated Hot Spare	244
Making a Global Hot Spare	245

Preparing a Drive for Removal	246
Removing a Drive from Hot Spare Pools	247
Undo Preparing a Drive for Removal	248
Enabling Auto Learn Cycles for the Battery Backup Unit	249
Disabling Auto Learn Cycles for the Battery Backup Unit	249
Starting a Learn Cycle for a Battery Backup Unit	250
Toggling the Locator LED for a Physical Drive	251
Clearing Controller Configuration	252
Restoring Storage Controller to Factory Defaults	253
Viewing Storage Controller Logs	254
Viewing Physical Drive Details	254
Viewing SIOC NVMe Drive Details	256

CHAPTER 12

Configuring Communication Services	259
Enabling or Disabling TLS v1.2	259
Enabling TLS Static Key Cipher	261
Configuring HTTP	262
Configuring SSH	264
Configuring XML API	265
XML API for	265
Enabling XML API	265
Enabling Redfish	266
Configuring IPMI	266
IPMI Over LAN	266
Configuring IPMI over LAN for Cisco IMC	267
Configuring IPMI over LAN for CMCs	268
Configuring SNMP	270
SNMP	270
Configuring SNMP Properties	270
Configuring SNMP Trap Settings	272
Sending a Test SNMP Trap Message	273
Configuring SNMPv3 Users	273
Configuring a Server to Send Email Alerts Using SMTP	275
Configuring SMTP Servers for Receiving E-Mail Alerts	276

CHAPTER 13	Managing Certificates and Server Security	277
	Managing the Server Certificate	277
	Managing the Server Certificate	277
	Generating a Certificate Signing Request	278
	Creating an Untrusted CA-Signed Certificate	280
	Uploading a Server Certificate	282
	Managing the External Certificate	283
	Uploading an External Certificate	283
	Uploading an External Private Key	285
	Activating the External Certificate	287
	Key Management Interoperability Protocol	287
	Enabling or Disabling KMIP	288
	Creating a Client Private Key and Client Certificate for KMIP Configuration	288
	Downloading a KMIP Client Certificate	289
	Exporting a KMIP Client Certificate	291
	Deleting a KMIP Client Certificate	293
	Downloading a KMIP Root CA Certificate	294
	Exporting a KMIP Root CA Certificate	296
	Deleting a KMIP Root CA Certificate	297
	Downloading a KMIP Client Private Key	298
	Exporting KMIP Client Private Key	300
	Deleting a KMIP Client Private Key	302
	Configuring KMIP Server Login Credentials	302
	Configuring KMIP Server Properties	304
	KMIP	305
	Key Management Interoperability Protocol	305
	Enabling or Disabling KMIP	305
	Configuring KMIP Server Login Credentials	306
	Creating a Client Private Key and Client Certificate for KMIP Configuration	307
	Testing the KMIP Server Connection	308
	Configuring KMIP Server Properties	309
	Downloading a KMIP Client Certificate	310
	Exporting a KMIP Client Certificate	312

Deleting a KMIP Client Certificate	314
Downloading a KMIP Client Private Key	315
Exporting KMIP Client Private Key	317
Deleting a KMIP Client Private Key	319
Downloading a KMIP Root CA Certificate	319
Exporting a KMIP Root CA Certificate	322
Deleting a KMIP Root CA Certificate	324
FIPS 140-2 Compliance in Cisco IMC	324
Enabling Security Configuration	325

CHAPTER 14 **Configuring Platform Event Filters** 329

Platform Event Filters	329
Configuring Platform Event Filters	329

CHAPTER 15 **Cisco IMC Firmware Management** 331

Overview of Firmware	331
Obtaining Firmware from Cisco	332
Installing Cisco IMC Firmware from a Remote Server	334
Activating Installed Firmware	336
Installing BIOS Firmware from a Remote Server	338
Activating Installed BIOS Firmware	339
Canceling a Pending BIOS Activation	341
Installing CMC Firmware from a Remote Server	342
Activating Installed CMC Firmware	343
Managing SAS Expander and HDD Firmware	344
Updating and Activating SAS Expander Firmware	344
Updating HDD Firmware	346

CHAPTER 16 **Viewing Faults and Logs** 349

Fault Summary	349
Viewing the Faults and Logs Summary	349
Cisco IMC Log	350
Viewing Cisco IMC Log	350
Clearing Trace Logs	351

Configuring the Cisco IMC Log Threshold	351
Sending the Cisco IMC Log to a Remote Server	353
System Event Log	354
Viewing the System Event Log	354
Viewing the System Event Log for Servers	355
Clearing the System Event Log	356
Logging Controls	357
Configuring the Cisco IMC Log Threshold	357
Sending the Cisco IMC Log to a Remote Server	359
Sending a Test Cisco IMC Log to a Remote Server	360
Uploading Remote Syslog Certificate	360
Deleting Remote Syslog Certificate	363

CHAPTER 17**Server Utilities 365**

Exporting Technical Support Data	365
Rebooting the Cisco IMC	368
Clearing the BIOS CMOS	369
Resetting the BMC to factory Defaults	369
Resetting to Factory Defaults	370
Resetting to Factory Defaults	372
Exporting and Importing the Cisco IMC and BMC Configuration	374
Importing a CMC Configuration	374
Importing BMC Configuration	375
Exporting the BMC Configuration	376
Exporting the CMC Configuration	378
Exporting VIC Adapter Configuration	380
Importing VIC Adapter Configuration	381
Generating Non-Maskable Interrupts to the Host	382
Adding Cisco IMC Banner	383
Downloading and Viewing Inventory Details	384

APPENDIX A**BIOS Parameters by Server Model 387**

S3260 M3 Servers	387
Main BIOS Parameters	387

Advance BIOS Parameters	388
Server Management BIOS Parameters	406
S3260 M4 Servers	407
Main BIOS Parameters	407
Advance BIOS Parameters	408
Server Management BIOS Parameters	431
S3260 M5 Servers	432
I/O Tab	432
Server Management Tab	439
Security Tab	443
Processor Tab	445
Memory Tab	455
Power/Performance Tab	461

APPENDIX B

BIOS Token Name Comparison for Multiple Interfaces	463
BIOS Token Name Comparison for Multiple Interfaces	463



Preface

- [Audience, on page xvii](#)
- [Conventions, on page xvii](#)
- [Related Cisco UCS Documentation, on page xix](#)

Audience

This guide is intended primarily for data center administrators with responsibilities and expertise in one or more of the following:

- Server administration
- Storage administration
- Network administration
- Network security

Conventions

Text Type	Indication
GUI elements	GUI elements such as tab titles, area names, and field labels appear in this font . Main titles such as window, dialog box, and wizard titles appear in this font .
Document titles	Document titles appear in <i>this font</i> .
TUI elements	In a Text-based User Interface, text the system displays appears in <i>this font</i> .
System output	Terminal sessions and information that the system displays appear in <i>this font</i> .
CLI commands	CLI command keywords appear in this font . Variables in a CLI command appear in <i>this font</i> .
[]	Elements in square brackets are optional.

Text Type	Indication
{x y z}	Required alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
<>	Nonprinting characters such as passwords are in angle brackets.
[]	Default responses to system prompts are in square brackets.
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.



Note Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the document.



Tip Means *the following information will help you solve a problem*. The tips information might not be troubleshooting or even an action, but could be useful information, similar to a Timesaver.



Timesaver Means *the described action saves time*. You can save time by performing the action described in the paragraph.



Caution Means *reader be careful*. In this situation, you might perform an action that could result in equipment damage or loss of data.



Warning IMPORTANT SAFETY INSTRUCTIONS

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. Use the statement number provided at the end of each warning to locate its translation in the translated safety warnings that accompanied this device.

SAVE THESE INSTRUCTIONS

Related Cisco UCS Documentation

Documentation Roadmaps

For a complete list of all B-Series documentation, see the *Cisco UCS B-Series Servers Documentation Roadmap* available at the following URL: https://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/overview/guide/UCS_roadmap.html

For a complete list of all C-Series documentation, see the *Cisco UCS C-Series Servers Documentation Roadmap* available at the following URL: https://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/overview/guide/ucs_rack_roadmap.html.

For information on supported firmware versions and supported UCS Manager versions for the rack servers that are integrated with the UCS Manager for management, refer to [Release Bundle Contents for Cisco UCS Software](#).



CHAPTER 1

Overview

This chapter includes the following sections:

- [Overview of the Cisco UCS S-Series Rack-Mount Server S3260, on page 1](#)
- [Overview of the Server Software, on page 2](#)
- [Server Ports, on page 2](#)
- [Cisco Integrated Management Controller, on page 3](#)
- [CLI, on page 4](#)

Overview of the Cisco UCS S-Series Rack-Mount Server S3260

The Cisco UCS S3260 is a modular, dense storage server with dual M3, M4 or M5 server nodes, optimized for large datasets used in environments such as big data, cloud, object storage, and content delivery.

The UCS S3260 chassis is a modular architecture consisting of the following modules:

- **Base chassis:** contains four redundant, hot-pluggable power supplies, eight redundant, hot-pluggable fans, and a rail kit.
- **Server Node:** one or two M3, M4 or M5 server nodes, each with two CPUs, 64, 128, 256, or 512 GB of DIMM memory, and a pass-through controller or a RAID card with a 1 GB or 4 GB cache.
- **System I/O Controller (SIOC):** one or two System I/O Controllers, each of which includes an integrated 1300-series or 1400-series virtual interface capability.
- **Optional Drive Expansion Node:** Large Form Factor (LFF) 3.5-inch drives in a choice of capacities.
- **Solid State Drives:** Up to 14 solid-state disks (SSDs) of 400GB, 800 GB, 1.6TB, and 3.2 TB capacities. These replace the previously supported top-loading LFF HDDs.
- **Solid-State Boot Drives:** up to two SSDs per M3, M4, or M5 server node. On the M4 server node, boot drives support hardware RAID connected to the RAID controller on the server node.
- **I/O Expander:** provides one storage mezz slot with two PCIe expansion slots and up to two NVMe SSDs.

The enterprise-class UCS S3260 storage server extends the capabilities of Cisco's Unified Computing System portfolio in a 4U form factor that delivers the best combination of performance, flexibility, and efficiency gains.



Note An M3 Server Node has Intel E5-2600 V2 CPUs and DDR-3 DIMMs. An M4 Server Node has Intel E5-2600 v4 CPUs and DDR-4 DIMMs

Overview of the Server Software

The Cisco UCS C-Series Rack-Mount Server ships with the `firmware`.

Firmware

is a separate management module built into the motherboard. A dedicated ARM-based processor, separate from the main server CPU, runs the `firmware`. The system ships with a running version of the `firmware`. You can update the `firmware`, but no initial installation is needed.

Server OS

The Cisco UCS C-Series rack servers support operating systems such as Windows, Linux, Oracle and so on. For more information on supported operating systems, see the *Hardware and Software Interoperability for Standalone C-series servers* at http://www.cisco.com/en/US/products/ps10477/prod_technical_reference_list.html. You can use `to` to install an OS on the server using the KVM console and vMedia.

Server Ports

Following is a list of server ports and their default port numbers:

Table 1: Server Ports

Port Name	Port Number
LDAP Port 1	389
LDAP Port 2	389
LDAP Port 3	389
LDAP Port 4	3268
LDAP Port 5	3268
LDAP Port 6	3268
SSH Port	22
HTTP Port	80
HTTPS Port	443
SMTP Port	25

Port Name	Port Number
KVM Port	2068
Intersight Management Port	8889
Intersight Cloud Port	8888
SOL SSH Port	2400
SNMP Port	161
SNMP Traps	162
External Syslog	514

Cisco Integrated Management Controller

The is the management service for the C-Series servers. runs within the server.



Note The management service is used only when the server is operating in Standalone Mode. If your C-Series server is integrated into a UCS system, you must manage it using UCS Manager. For information about using UCS Manager, see the configuration guides listed in the *Cisco UCS B-Series Servers Documentation Roadmap* at <http://www.cisco.com/go/unifiedcomputing/b-series-doc>.

Management Interfaces

You can use a web-based GUI or SSH-based CLI or an XML-based API to access, configure, administer, and monitor the server. Almost all tasks can be performed in either interface, and the results of tasks performed in one interface are displayed in another. However, you cannot do the following:

- Use GUI to invoke CLI
- View a command that has been invoked through CLI in GUI
- Generate CLI output from GUI

Tasks You Can Perform in

You can use to perform the following server management tasks:

- Power on, power off, power cycle, reset and shut down the server
- Toggle the locator LED
- Configuring BIOS settings
- Configure the server boot order
- View server properties and sensors
- Manage remote presence

- Create and manage local user accounts, and enable remote user authentication through Active Directory
- Configure network-related settings, including NIC properties, IPv4, VLANs, and network security
- Configure communication services, including HTTP, SSH, IPMI Over LAN, and SNMP.
- Manage certificates
- Configure platform event filters
- Update firmware
- Monitor faults, alarms, and server status
- Set time zone and view local time
- Install and activate firmware
- Install and activate BIOS firmware
- Install and activate CMC firmware

No Operating System or Application Provisioning or Management

provisions servers, and as a result, exists below the operating system on a server. Therefore, you cannot use it to provision or manage operating systems or applications on servers. For example, you cannot do the following:

- Deploy an OS, such as Windows or Linux
- Deploy patches for software, such as an OS or an application
- Install base software components, such as anti-virus software, monitoring agents, or backup clients
- Install software applications, such as databases, application server software, or web servers
- Perform operator actions, including restarting an Oracle database, restarting printer queues, or handling non- user accounts
- Configure or manage external storage on the SAN or NAS storage

CLI

The CLI is a command-line management interface for Cisco UCS C-Series servers. You can launch the CLI and manage the server over the network by SSH or Telnet.

A user of the CLI will be one of three roles: admin, user (can control, cannot configure), and read-only.



Note To recover from a lost admin password, see the Cisco UCS C-Series server installation and service guide for your platform.

Command Modes

The CLI is organized into a hierarchy of command modes, with the EXEC mode being the highest-level mode of the hierarchy. Higher-level modes branch into lower-level modes. You use the **scope** command to move from higher-level modes to modes in the next lower level, and the **exit** command to move up one level in the mode hierarchy. The **top** command returns to the EXEC mode.



Note Most command modes are associated with managed objects. The **scope** command does not create managed objects and can only access modes for which managed objects already exist.

Each mode contains a set of commands that can be entered in that mode. Most of the commands available in each mode pertain to the associated managed object. Depending on your assigned role, you may have access to only a subset of the commands available in a mode; commands to which you do not have access are hidden.

The CLI prompt for each mode shows the full path down the mode hierarchy to the current mode. This helps you to determine where you are in the command mode hierarchy and can be an invaluable tool when you need to navigate through the hierarchy.

Command Mode Table

The following table lists the first four levels of command modes, the commands used to access each mode, and the CLI prompt associated with each mode.

Mode Name	Command to Access	Mode Prompt
EXEC	top command from any mode	#
server	scope server <i>index</i> command from EXEC mode	/server #
bios	scope bios command from server mode	/server/bios #
advanced	scope advanced command from bios mode	/server/bios/advanced #
main	scope main command from bios mode	/server/bios/main #
server-management	scope server-management command from bios mode	/server/bios/server-management #
bmc	scope bmc command from server mode	/server/bmc #
firmware	scope firmware command from bmc mode	/server/bios/bmc #
import-export	scope import-export command from bmc mode	/server/bios/import-export #

Mode Name	Command to Access	Mode Prompt
network	scope network command from bmc mode	/server/bios/network #
power-restore-policy	scope power-restore-policy command from bmc mode	/server/bios/power-restore-policy #
kvm	scope kvm command from server mode	/server/kvm #
ipmi	scope ipmi command from server mode	/server/ipmi #
dim-blacklisting	scope dim-blacklisting command from server mode	/server/dimm-blacklisting #
reset-ecc	scope reset-ecc command from server mode	/server/reset-ecc #
sel	scope sel command from server mode	/server/sel #
sol	scope sol command from server mode	/server/sol #
vmedia	scope vmedia command from server mode	/server/vmedia #
certificate	scope certificate command from EXEC mode	/certificate #
fault	scope fault command from EXEC mode	/fault #
http	scope http command from EXEC mode	/http #
ldap	scope ldap command from EXEC mode	/ldap #
binding	scope binding command from ldap mode	/ldap/binding #
dns-search	scope dns-search command from ldap mode	/ldap/dns-search #
ldap-group-rule	scope ldap-group-rule command from ldap mode	/ldap/ldap-group-rule #
ldap-server	scope ldap-server command from ldap mode	/ldap/ldap-server #
role-group	scope role-group command from ldap mode	/ldap/role-group #

Mode Name	Command to Access	Mode Prompt
network	scope network command from EXEC mode	/network #
ipblocking	scope ipblocking command from network mode	/network/ipblocking #
chassis	scope chassis command from EXEC mode	/chassis #
adapter	scope adapter <i>index</i> command from chassis mode	/chassis/adapter #
host-eth-if	scope host-eth-if command from adapter mode	/chassis/adapter/host-eth-if #
host-fc-if	scope host-fc-if command from adapter mode	/chassis/adapter/host-fc-if #
port-profiles	scope port-profiles command from adapter mode	/chassis/adapter/port-profiles #
vmfex	scope vmfex <i>index</i> command from adapter mode	/chassis/adapter/vmfex #
cmc	scope cmc <i>index</i> command from chassis mode	/chassis/cmc #
ipmi	scope ipmi command from cmc mode	/chassis/cmc/ipmi #
network	scope network command from cmc mode	/chassis/cmc/network #
firmware	scope firmware command from chassis mode	/chassis/firmware #
import-export	scope import-export command from chassis mode	/chassis/import-export #
log	scope log command from chassis mode	/chassis/log #
server	scope server command from log mode	/chassis/log/server #
sas-expander	scope sas-expander <i>index</i> command from chassis mode	/chassis/sas-expander #
phy-stats	scope phy-stats command from sas-expander mode	/chassis/sas-expander/phy-stats #
server	scope server <i>index</i> command from chassis mode	/chassis/server #

Mode Name	Command to Access	Mode Prompt
storageadapter	scope storageadapter command from server mode	/chassis/server/storageadapter #
dimmm-summary	scope dimm-summary command from server mode	/chassis/server/dimm-summary #
tech-support	scope tech-support command from chassis mode	/chassis/tech-support #
sensor	scope sensor command from EXEC mode	/sensor #
snmp	scope snmp command from EXEC mode	/snmp #
trap-destinations	scope trap-destinations command from snmp mode	/snmp/trap-destinations #
v3users	scope v3users command from snmp mode	/snmp/v3users #
ssh	scope ssh command from EXEC mode	/ssh #
time	scope time command from EXEC mode	/time #
ntp	scope ntp command from time mode	/time/ntp #
user	scope user <i>user-number</i> command from EXEC mode	/user #
user-policy	scope user-policy command from EXEC mode	/user-policy #
user-session	scope user-session <i>session-number</i> command from EXEC mode	/user-session #
xmlapi	scope xmlapi command from EXEC mode	/xmlapi #

Complete a Command

You can use the **Tab** key in any mode to complete a command. Partially typing a command name and pressing **Tab** causes the command to be displayed in full or to the point where another keyword must be chosen or an argument value must be entered.

Command History

The CLI stores all commands used in the current session. You can step through the previously used commands by using the **Up Arrow** or **Down Arrow** keys. The **Up Arrow** key steps to the previous command in the history, and the **Down Arrow** key steps to the next command in the history. If you get to the end of the history, pressing the **Down Arrow** key does nothing.

All commands in the history can be entered again by simply stepping through the history to recall the desired command and pressing **Enter**. The command is entered as if you had manually typed it. You can also recall a command and change it before you press **Enter**.

Committing, Discarding, and Viewing Pending Commands

When you enter a configuration command in the CLI, the command is not applied until you enter the **commit** command. Until committed, a configuration command is pending and can be discarded by entering a **discard** command. When any command is pending, an asterisk (*) appears before the command prompt. The asterisk disappears when you enter the **commit** command, as shown in this example:

```
Server# scope chassis
Server /chassis # set locator-led off
Server /chassis *# commit
Server /chassis #
```

You can accumulate pending changes in multiple command modes and apply them together with a single **commit** command. You can view the pending commands by entering the **show configuration pending** command in any command mode.



Note Committing multiple commands together is not an atomic operation. If any command fails, the successful commands are applied despite the failure. Failed commands are reported in an error message.

Command Output Formats

Most CLI **show** commands accept an optional **detail** keyword that causes the output information to be displayed as a list rather than a table. You can configure either of two presentation formats for displaying the output information when the **detail** keyword is used. The format choices are as follows:

- **Default**—For easy viewing, the command output is presented in a compact list.

This example shows command output in the default format:

```
Server /chassis # set cli output default
Server /chassis # show hdd detail
Name HDD_01_STATUS:
  Status : present
Name HDD_02_STATUS:
  Status : present
Name HDD_03_STATUS:
  Status : present
Name HDD_04_STATUS:
  Status : present

Server /chassis #
```

- **YAML**—For easy parsing by scripts, the command output is presented in the YAML (YAML Ain't Markup Language) data serialization language, delimited by defined character strings.

This example shows command output in the YAML format:

```
Server /chassis # set cli output yaml
Server /chassis # show hdd detail
---
  name: HDD_01_STATUS
  hdd-status: present
---
  name: HDD_02_STATUS
  hdd-status: present
---
  name: HDD_03_STATUS
  hdd-status: present
---
  name: HDD_04_STATUS
  hdd-status: present
...
Server /chassis #
```

For detailed information about YAML, see <http://www.yaml.org/about.html>.

In most CLI command modes, you can enter **set cli output default** to configure the default format, or **set cli output yaml** to configure the YAML format.

Online Help for the CLI

At any time, you can type the **?** character to display the options available at the current state of the command syntax.

If you have not typed anything at the prompt, typing **?** lists all available commands for the mode you are in. If you have partially typed a command, typing **?** lists all available keywords and arguments available at your current position in the command syntax.

Logging In to

Step 1 Connect to the console port.

Step 2 When logging in to an unconfigured system for the first time, use **admin** as the username and **password** as the password.

The following situations occur when you login to the CLI for the first time:

- You cannot perform any operation until you change default admin credentials on the web UI or CLI.

Note After an upgrade from version 1.5(x) or 2.0(1) to the latest version, or when you do a factory reset, during first login prompts for a password change. You cannot choose the word 'password' as your new password. If this creates problems for any scripts you may be running, you could change it to password by logging back into the user management options, but this is ENTIRELY at your own risk. It is not recommended by Cisco.

Example

The following example shows how to login in to first time:

```
Login as # admin
admin10.101.255.255's password # password

*****WARNING*****
Default credentials were used for login.
Administration passwords needs to be changed for security purpose.
*****

Enter current password # abcxyz
Re-enter new password # abcxyz
Updating password...
Password updated successfully.
Server #
```




CHAPTER 2

Installing the Server OS

This chapter includes the following sections:

- [OS Installation Methods, on page 13](#)
- [Virtual KVM Console, on page 13](#)
- [PXE Installation Servers, on page 14](#)
- [Booting an Operating System from a USB Port, on page 15](#)

OS Installation Methods

C-Series servers support several operating systems. Regardless of the OS being installed, you can install it on your server using one of the following tools:

- KVM console
- PXE installation server

For more information on Cisco UCS Server Configuration Utility, see [Cisco UCS Server Configuration Utility Quick Start Guide](#).

Virtual KVM Console

The vKVM console is an interface accessible from that emulates a direct keyboard, video, and mouse (vKVM) connection to the server. The vKVM console allows you to connect to the server from a remote location.

Here are a few major advantages of using Cisco KVM Console:

- The Cisco KVM console provides connection to KVM, SOL, and vMedia whereas the Avocent KVM provides connection only to KVM and vMedia.
- In the KVM Console, the vMedia connection is established at the KVM Launch Manager and is available for all users.
- The KVM console offers you an advanced character replacement options for the unsupported characters while pasting text from the guest to the host.
- The KVM console provides you an ability to store the vMedia mappings on CIMC.

Instead of using CD/DVD or floppy drives physically connected to the server, the vKVM console uses virtual media, which are actual disk drives or disk image files that are mapped to virtual CD/DVD or floppy drives. You can map any of the following to a virtual drive:

- CD/DVD or floppy drive on your computer
- Disk image files (ISO or IMG files) on your computer
- USB flash drive on your computer
- CD/DVD or floppy drive on the network
- Disk image files (ISO or IMG files) on the network
- USB flash drive on the network

You can use the vKVM console to install an OS on the server.



Note To configure the vKVM console successfully for the S3260 Storage Server, you need to configure IP addresses for the Cisco IMC, CMC, and BMC components. You can configure the IP addresses for these components using the CLI interface or Web UI. For the CLI, use the command **scope network**, or view the setting using **scope <chassis/server1/2><cmc/bmc><network>**.

To configure IP addresses for network components on the web interface, see the steps described in the section **Configuring Network-Related Settings**.



Note The vKVM Console is operated only through the GUI. To launch the vKVM Console, see the instructions in the *Cisco UCS C-Series Servers Integrated Management Controller GUI Configuration Guide*.

Installing an OS Using the KVM Console

Because the KVM console is operated only through the GUI, you cannot install a server OS using the CLI. To install an OS using the KVM console, follow the instructions in the "Installing an OS Using the KVM Console" section of the *Cisco UCS C-Series Servers Integrated Management Controller GUI Configuration Guide*.



Note Detailed guides for installing Linux, VMware, and Windows can be found at this URL: http://www.cisco.com/en/US/products/ps10493/products_installation_and_configuration_guides_list.html.

PXE Installation Servers

A Preboot Execution Environment (PXE) installation server allows a client to boot and install an OS from a remote location. To use this method, a PXE environment must be configured and available on your VLAN, typically a dedicated provisioning VLAN. Additionally, the server must be set to boot from the network.

When the server boots, it sends a PXE request across the network. The PXE installation server acknowledges the request, and starts a sequence of events that installs the OS on the server.

PXE servers can use installation disks, disk images, or scripts to install an OS. Proprietary disk images can also be used to install an OS, additional components, or applications.



Note PXE installation is an efficient method for installing an OS on a large number of servers. However, considering that this method requires setting up a PXE environment, it might be easier to use another installation method.

Installing an OS Using a PXE Installation Server

Before you begin

- Verify that the server can be reached over a VLAN.
- You must log in as a user with admin privileges to install an OS.

Step 1 Set the boot order to **PXE** first.

Step 2 Reboot the server.

If a PXE install server is available on the VLAN, the installation process begins when the server reboots. PXE installations are typically automated and require no additional user input. Refer to the installation guide for the OS being installed to guide you through the rest of the installation process.

What to do next

After the OS installation is complete, reset the LAN boot order to its original setting. Always follow your OS vendors recommended configuration, including software interoperability and driver compatibility. For more information on driver recommendations and installation, follow the Cisco UCS Hardware Compatibility list here:

<https://ucshcltool.cloudapps.cisco.com/public/>

Booting an Operating System from a USB Port

All Cisco UCS C-series servers support booting an operating system from any USB port on the server. However, there are a few guidelines that you must keep in mind, prior to booting an OS from a USB port.

- To maintain the boot order configuration, it is recommended that you use an internal USB port for booting an OS.
- The USB port must be enabled prior to booting an OS from it.

By default, the USB ports are enabled. If you have disabled a USB port, you must enable it prior to booting an OS from it. For information on enabling a disabled USB ports, see topic *Enabling or Disabling the Internal USB Port* in the server-specific installation and service guide available at the following link:

http://www.cisco.com/en/US/products/ps10493/prod_installation_guides_list.html.

- After you boot the OS from the USB port, you must set the second-level boot order so that the server boots from that USB source every time.



CHAPTER 3

Managing Chassis

This chapter includes the following sections:

- [Viewing Chassis Properties, on page 17](#)
- [Chassis Management Tasks, on page 24](#)
- [Managing Dynamic Storage, on page 31](#)

Viewing Chassis Properties

Viewing Chassis Summary

SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **show detail**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters chassis command mode.
Step 2	Server /chassis # show detail	Displays the chassis' properties.

Example

This example displays the chassis' properties:

```
Server# scope chassis
Server /chassis # show detail
Chassis:
  Serial Number: FOX1843G9EM
  Product Name: UCS S3260
  PID : UCSC-C3X60-BASE
  Front Panel Locator LED: on
  Description:
  CMC-1 State: Active
  CMC-2 State: Standby
```

```
Server /chassis #
```

Viewing CMC Firmware Versions

SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **show cmc**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters chassis command mode.
Step 2	Server /chassis # show cmc	Displays the CMC firmware versions.

Example

This example displays the CMC firmware versions.:

```
Server# scope chassis
Server /chassis # show cmc
ID      Name      Serial Number  Update Stage  Update Progress  Current FW Version
-----
1       CMC1                NONE          100           2.0 (6.79)
2       CMC2                NONE          100           2.0 (6.79)

Server /chassis #
```

Viewing LED Details

SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **show led**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters chassis command mode.
Step 2	Server /chassis # show led	Displays the LED details at the chassis level.

Example

This example the LED details at the chassis level:

```

Server# scope chassis
Server /chassis # show led
LED Name                LED State  LED Color
-----
CHS_FP_LED_ID           FAST BLINK BLUE
LED_HLTH_STATUS         ON         GREEN
LED_PSU_STATUS          ON         GREEN
LED_TEMP_STATUS         ON         GREEN
LED_FAN_STATUS          ON         GREEN
SERVER1_FP_ID_LED       OFF        BLUE
SERVER2_FP_ID_LED       OFF        BLUE
OVERALL_DIMM_STATUS     ON         GREEN

Server /chassis #
    
```

Viewing the Details of the Servers on the Chassis

SUMMARY STEPS

1. Server # scope chassis
2. Server /chassis # show server

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters chassis command mode.
Step 2	Server /chassis # show server	Displays the high level details of the servers on the chassis.

Example

This example displays the high level details of the servers on the chassis:

```

Server# scope chassis
Server /chassis # show server
Server ID Power Serial Number Product Name PID          UUID
-----
1          on   FCH1848794D   UCS C3160   UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06
2          on   FCH183978RD   UCS C3160   UCSC-C3X60-SVRNB
207BD0D4-C589-40C1-A73E-EF6E7F773198

Server /chassis #
    
```

Viewing Physical Drive Properties

SUMMARY STEPS

1. Server # scope chassis
2. Server /chassis # scope dynamic-storage

3. Server /chassis/dynamic-storage # **scope physical-drive drive number**
4. Server /chassis/dynamic-storage/physical-drive # **show detail**
5. Server /chassis/dynamic-storage/physical-drive # **exit**
6. Server /chassis/dynamic-storage # **scope physical-drive-fw drive number**
7. Server /chassis/dynamic-storage/physical-drive-fw # **show detail**
8. Server /chassis/dynamic-storage/physical-drive-fw # **exit**
9. Server /chassis/dynamic-storage # **scope physical-drive-link drive number**
10. Server /chassis/dynamic-storage/physical-drive-link # **show detail**
11. Server /chassis/dynamic-storage/physical-drive-link # **exit**
12. Server /chassis/dynamic-storage # **scope physical-slot-owner drive number**
13. Server /chassis/dynamic-storage/physical-slot-owner # **show detail**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters chassis command mode.
Step 2	Server /chassis # scope dynamic-storage	Enters the dynamic storage command mode.
Step 3	Server /chassis/dynamic-storage # scope physical-drive drive number	Enters the physical drive command mode.
Step 4	Server /chassis/dynamic-storage/physical-drive # show detail	Displays the details of the physical drive.
Step 5	Server /chassis/dynamic-storage/physical-drive # exit	Exits to the dynamic storage command mode.
Step 6	Server /chassis/dynamic-storage # scope physical-drive-fw drive number	Enters the physical drive firmware command mode.
Step 7	Server /chassis/dynamic-storage/physical-drive-fw # show detail	Displays the firmware details of the physical drive.
Step 8	Server /chassis/dynamic-storage/physical-drive-fw # exit	Exits to the dynamic storage command mode.
Step 9	Server /chassis/dynamic-storage # scope physical-drive-link drive number	Enters the physical drive link command mode.
Step 10	Server /chassis/dynamic-storage/physical-drive-link # show detail	Displays the link details of the physical drive.
Step 11	Server /chassis/dynamic-storage/physical-drive-link # exit	Exits to the dynamic storage command mode.
Step 12	Server /chassis/dynamic-storage # scope physical-slot-owner drive number	Enters the physical slot ownership command mode.
Step 13	Server /chassis/dynamic-storage/physical-slot-owner # show detail	Displays details about which server the physical drive is assigned to.

Example

This example displays the physical drive properties:

Viewing Physical Drive Properties

```

Server# scope chassis
Server /chassis # scope dynamic-storage
Server /chassis/dynamic-storage # scope physical-drive 1
Server /chassis/dynamic-storage/physical-drive # show detail
Slot 1:
  Ownership: server1
  Health: good
  Vendor: TOSHIBA
  Product ID: MG03SCA400
  Product Rev Level: 5702
  Size: 3.63 TB
  Serial Number: 94E0A0T9FVU4
svbu-huu-sanity-col2-1-vcmc /chassis/dynamic-storage/physical-drive #

```

Viewing Firmware Details

```

Server /chassis/dynamic-storage/physical-drive # exit
Server /chassis/dynamic-storage # scope physical-drive-fw 1
Server /chassis/dynamic-storage/physical-drive-fw # show detail

```

Slot 1:

```

  Vendor: TOSHIBA
  Product ID: MG03SCA400
  Current_FW: 5702
  Update Stage: NONE
  Update Progress: 0

```

```

Server /chassis/dynamic-storage/physical-drive-fw #

```

Viewing Link Details

```

Server /chassis/dynamic-storage/physical-drive # exit
Server /chassis/dynamic-storage # scope physical-drive-link 1
Server /chassis/dynamic-storage/physical-drive-link # show detail

```

Slot 1:

```

  Ownership: server1
  EX1 Link: 6.0 Gb
  EX2 Link: 6.0 Gb
  SAS Address 1: 50000395c8d2a1fe
  SAS Address 2: 50000395c8d2a1ff

```

```

Server /chassis/dynamic-storage/physical-drive-link #

```

Viewing the slot ownership

```

Server /chassis/dynamic-storage/physical-drive-link # exit
Server /chassis/dynamic-storage # scope physical-slot-owner 1
Server /chassis/dynamic-storage/physical-drive-link # show detailSlot 1:
  Ownership: server1

```

```

Server /chassis/dynamic-storage/physical-slot-owner #

```

Viewing Cisco VIC Adapter Properties

SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **show adapter**
3. Server /chassis # **show adapter detail**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters chassis command mode.
Step 2	Server /chassis # show adapter	Displays the high level details of the servers on the chassis.
Step 3	Server /chassis # show adapter detail	Displays the high level details of the servers on the chassis.

Example

This example displays the high level details of the Cisco Virtual Interface Card properties:

```

Server# scope chassis
Server /chassis # show adapter
Server ID Power Serial Number Product Name PID UUID
-----
-----
1 on FCH1848794D UCS S3260M4 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06
2 on FCH183978RD UCS S3260M4 UCSC-C3X60-SVRNB
207BD0D4-C589-40C1-A73E-EF6E7F773198
Server /chassis # show adapter detail
SIOC Slot 1:
  Product Name: UCSS-S3260-SIOC
  Serial Number: FCH18467P0U
  Product ID: UCSC-C3260-SIOC
  Adapter Hardware Revision:
  Current FW Version: 4.0(300.76)
  VNTAG: Disabled
  FIP: Enabled
  LLDP: Enabled
  Configuration Pending: no
  Cisco IMC Management Enabled: yes
  VID: V00
  Vendor: Cisco Systems Inc
  Description:
  Bootloader Version: 4.0(300.76)
  FW Image 1 Version: 4.0(300.76)
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: 4.0(300.71)
  FW Image 2 State: BACKUP INACTIVATED
  FW Update Status: Idle
  FW Update Error: No error
  FW Update Stage: No operation (0%)
  FW Update Overall Progress: 0%
SIOC Slot 2:
  Product Name: UCSS-S3260-SIOC
  Serial Number: FCH18467P16
  Product ID: UCSC-C3260-SIOC
  Adapter Hardware Revision:
  Current FW Version: 4.0(300.61)
  VNTAG: Disabled
  FIP: Enabled
  LLDP: Enabled
  Configuration Pending: no
  Cisco IMC Management Enabled: yes
  VID: V00
  Vendor: Cisco Systems Inc

```

```

Description:
Bootloader Version: 4.0(300.61)
FW Image 1 Version: 4.0(300.61)
FW Image 1 State: RUNNING ACTIVATED
FW Image 2 Version: 4.0(300.51)
FW Image 2 State: BACKUP INACTIVATED
FW Update Status: Idle
FW Update Error: No error
FW Update Stage: No operation (0%)
FW Update Overall Progress: 0%
Server /chassis #

```

Viewing Power Supply Properties

SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **show psu**
3. Server /chassis # **show psu detail**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters chassis command mode.
Step 2	Server /chassis # show psu	Displays the properties of each power supply on the chassis.
Step 3	Server /chassis # show psu detail	Displays the properties of each power supply on the chassis.

Example

This example displays the properties of each power supply on the chassis:

```

Server# scope chassis
Server /chassis # show psu
Name          In. Power (Watts)  Out. Power (Watts)  Firmware  Status  Product ID
-----
PSU1          101                79                  10062012 Present  UCSC-PSU1-1050W
PSU2          89                 73                  10062012 Present  UCSC-PSU1-1050W
PSU3          96                 79                  10062012 Present  UCSC-PSU1-1050W
PSU4          92                 82                  10062012 Present  UCSC-PSU1-1050W
Server /chassis # show psu detail
Name PSU1:
  In. Power (Watts): 100
  Out. Power (Watts): 77
  Firmware : 10062012
  Status : Present
  Product ID : UCSC-PSU1-1050W
Name PSU2:
  In. Power (Watts): 89
  Out. Power (Watts): 75
  Firmware : 10062012
  Status : Present
  Product ID : UCSC-PSU1-1050W

```

```

Name PSU3:
  In. Power (Watts): 96
  Out. Power (Watts): 81
  Firmware : 10062012
  Status : Present
  Product ID : UCSC-PSU1-1050W
Name PSU4:
  In. Power (Watts): 91
  Out. Power (Watts): 77
  Firmware : 10062012
  Status : Present
  Product ID : UCSC-PSU1-1050W

Server /chassis #

```

Chassis Management Tasks

Toggling the Front Locator LED for the Chassis

Before you begin

You must log in with user or admin privileges to perform this task.

SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **set front-locator-led {on | off}**
3. Server /chassis # **commit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters chassis command mode.
Step 2	Server /chassis # set front-locator-led {on off}	Enables or disables the chassis locator LED.
Step 3	Server /chassis # commit	Commits the transaction to the system configuration.

Example

This example disables the chassis locator LED and commits the transaction:

```

Server# scope chassis
Server /chassis # set front-locator-led off
Server /chassis *# commit

Server /chassis #

```

Updating Firmware on Server Components



Important If any firmware or BIOS updates are in progress, do not reset the server until those tasks are complete.

Before you begin

You must log in with user or admin privileges to perform this task.

Server must be powered off.

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope firmware**
3. Server /chassis/firmware # **show detail**
4. Server /chassis/firmware # **update-all**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters chassis command mode.
Step 2	Server /chassis # scope firmware	Enters firmware command mode.
Step 3	Server /chassis/firmware # show detail	Displays the firmware update required on some components message.
Step 4	Server /chassis/firmware # update-all	Updates the firmware on the server components.

Example

This example resets the server:

```
Server# scope chassis
Server /chassis # scope firmware
Server /chassis / firmware # show detail
```

```
Firmware update required on some components,
please run update-all (under chassis/firmware scope).
```

```
Server /chassis / firmware # update-all
```

Time Zone

Selecting a Time Zone

Selecting a time zone helps you choose a local time zone so that you can view the local time rather than the default machine time. Web UI and the CLI provide you options to choose and set a time zone of your choice.

Setting the time zone to your local time will apply the time zone variable to all the services that utilize the system timing. This impacts the logging information and is utilized in the following applications of the :

- Fault summary and fault history logs
- log
- rsyslog

When you set a local time, the timestamp on the applications that you can view are updated with the local time that you have chosen.

Setting a Time Zone

Before you begin

You must log in with user or admin privileges to perform this task.

SUMMARY STEPS

1. Server # **scope time**
2. Server /time # **timezone-select**
3. Enter the number corresponding to your continent or ocean.
4. Enter the number corresponding to the country or region that you want to set as your time zone.
5. Enter the number corresponding to time zone.
6. Enter **1**.
7. Enter **y** if you want to set the chosen time zone.

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server # scope time	Enters time command mode.
Step 2	Server /time # timezone-select	Displays a list of continents and oceans.
Step 3	Enter the number corresponding to your continent or ocean.	A list of all the countries or regions of the chosen continent or ocean displays.
Step 4	Enter the number corresponding to the country or region that you want to set as your time zone.	If a country or a region has more than one time zones, a list of time zones in that country or region displays.
Step 5	Enter the number corresponding to time zone.	Is the above information OK? message appears.
Step 6	Enter 1 .	Continue?[y N]: prompt appears.
Step 7	Enter y if you want to set the chosen time zone.	The chosen time zone is set as the time zone for your server.

Example

This example sets the time zone:

```
Server# scope time
Server /time # timezone-select
```

```
Please identify a location so that time zone rules can be set correctly.
Please select a continent or ocean.
```

- 1) Africa
 - 2) Americas
 - 3) Antarctica
 - 4) Arctic Ocean
 - 5) Asia
 - 6) Atlantic Ocean
 - 7) Australia
 - 8) Europe
 - 9) Indian Ocean
 - 10) Pacific Ocean
- ```
#? 2
```

```
Please select a country whose clocks agree with yours.
```

- 1) Anguilla
- 2) Antigua & Barbuda
- 3) Argentina
- 4) Aruba
- 5) Bahamas
- 6) Barbados
- 7) Belize
- 8) Bolivia
- 9) Brazil
- 10) Canada
- 11) Caribbean Netherlands
- 12) Cayman Islands
- 13) Chile
- 14) Colombia
- 15) Costa Rica
- 16) Cuba
- 17) Curacao
- 18) Dominica
- 19) Dominican Republic
- 20) Ecuador
- 21) El Salvador
- 22) French Guiana
- 23) Greenland
- 24) Grenada
- 25) Guadeloupe
- 26) Guatemala
- 27) Guyana
- 28) Haiti
- 29) Honduras
- 30) Jamaica
- 31) Martinique
- 32) Mexico
- 33) Montserrat
- 34) Nicaragua
- 35) Panama
- 36) Paraguay
- 37) Peru
- 38) Puerto Rico
- 39) St Barthelemy
- 40) St Kitts & Nevis
- 41) St Lucia
- 42) St Maarten (Dutch part)

- 43) St Martin (French part)
  - 44) St Pierre & Miquelon
  - 45) St Vincent
  - 46) Suriname
  - 47) Trinidad & Tobago
  - 48) Turks & Caicos Is
  - 49) United States
  - 50) Uruguay
  - 51) Venezuela
  - 52) Virgin Islands (UK)
  - 53) Virgin Islands (US)
- #? 49

Please select one of the following time zone regions.

- 1) Eastern Time
  - 2) Eastern Time - Michigan - most locations
  - 3) Eastern Time - Kentucky - Louisville area
  - 4) Eastern Time - Kentucky - Wayne County
  - 5) Eastern Time - Indiana - most locations
  - 6) Eastern Time - Indiana - Daviess, Dubois, Knox & Martin Counties
  - 7) Eastern Time - Indiana - Pulaski County
  - 8) Eastern Time - Indiana - Crawford County
  - 9) Eastern Time - Indiana - Pike County
  - 10) Eastern Time - Indiana - Switzerland County
  - 11) Central Time
  - 12) Central Time - Indiana - Perry County
  - 13) Central Time - Indiana - Starke County
  - 14) Central Time - Michigan - Dickinson, Gogebic, Iron & Menominee Counties
  - 15) Central Time - North Dakota - Oliver County
  - 16) Central Time - North Dakota - Morton County (except Mandan area)
  - 17) Central Time - North Dakota - Mercer County
  - 18) Mountain Time
  - 19) Mountain Time - south Idaho & east Oregon
  - 20) Mountain Standard Time - Arizona (except Navajo)
  - 21) Pacific Time
  - 22) Alaska Time
  - 23) Alaska Time - Alaska panhandle
  - 24) Alaska Time - southeast Alaska panhandle
  - 25) Alaska Time - Alaska panhandle neck
  - 26) Alaska Time - west Alaska
  - 27) Aleutian Islands
  - 28) Metlakatla Time - Annette Island
  - 29) Hawaii
- #? 8

The following information has been given:

```

United States
Eastern Time - Indiana - Crawford County

```

Is the above information OK?

- 1) Yes
  - 2) No
- #? 1

You have chosen to set timezone settings to:

```

America/Indiana/Marengo

```

Continue?[y|N]: y

Timezone has been updated.

The local time now is: Wed Jul 1 02:21:15 2015 EST

Server /time #



## Single Server Dual SIOC Connectivity

The S3260 Storage Server operates either in Single Server Single SIOC mode or Single Server Dual SIOC mode. In single server single SIOC mode, the data path from the second SIOC is unused. The second SIOC is used for management redundancy only, if a VIC installed in the second SIOC.

In single server dual SIOC mode, the data path from both SIOCs is provided to the single server. This allows users to use dual VICs or third party adapters (NIC or HBA) for data, or a combination of both. Only the VIC or dedicated management port can provide server management. When third party adapters are used, they are for the host data path only. In this mode:

Effective with this release, the S3260 storage server supports a single server with dual connectivity, which is based on these two factors:

- The PCIe between the server board and the SIOC card is connected using BIOS.
- The CMC controls the correct association of the server ID with the virtual network interfaces it creates.

This feature allows you to configure a new single server dual VIC chassis property on the Cisco IMC by enabling it or disabling it using the web UI or command line interface.

When using a VIC in the SIOC, a specific PCI connectivity is enabled on the VIC. The CMC uses the single server dual VIC property along with the current chassis hardware configuration to identify the server ID property to be specified when you create a virtual network interface in either of the dual SIOC VICs. The VIC configuration page on the web UI displays the read-only attribute of the Server ID to which the VIC is PCIe linked, and this is used by the host server for the virtual network interface traffic.

## Configuring Single Server Dual SIOC Connectivity

### Before you begin

- You must log in with admin privileges to perform this task.
- The chassis must have a single server and two VIC adapters (SIOC).

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **server-sioc-connectivity**
3. Server /chassis # **show detail**

### DETAILED STEPS

|        | Command or Action                                 | Purpose                                                                                                                                                                                                                                                 |
|--------|---------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Server # <b>scope chassis</b>                     | Enters chassis command mode.                                                                                                                                                                                                                            |
| Step 2 | Server /chassis # <b>server-sioc-connectivity</b> | Enter <b>y</b> at the confirmation prompt. Configures the server SIOC Connectivity of the chassis to single server dual SIOC.<br><br><b>Note</b> This operation will reset the VIC adapter 2 to factory default configuration as part of these changes. |

|               | Command or Action                    | Purpose                                                                    |
|---------------|--------------------------------------|----------------------------------------------------------------------------|
| <b>Step 3</b> | Server /chassis # <b>show detail</b> | Displays the chassis details that has the server SIOC connectivity status. |

### Example

The following example shows how to configuring single server dual SIOC connectivity:

```
Server # scope chassis
Server /chassis # server-sioc-connectivity
Do you want to configure Server SIOC Connectivity of the chassis to Single Server Dual
SIOC?[y|N]y

This operation will reset the VIC Adapter-2 to factory default configuration as part of
these changes.
Please take backup of VIC Adapter-2 configuration before proceeding with the operation.
All your VIC Adapter-2 configuration will be lost.
Continue?[y|N]y
The VIC Adapter-2 factory default has been successfully restored. Please reboot the Server-1
Host.
The Chassis Server SIOC Connectivity successfully configured to Single Server Dual SIOC.
Server /chassis # show detail
Chassis:
 Serial Number: FCH1819JUVM
 Product Name: UCS S3260
 PID : UCSS-S3260-BASE
 Front Panel Locator LED: off
 Description: Test Label22
 Asset Tag: TESTTAG11
 CMC-1 State: Active
 CMC-2 State: Standby
 Server SIOC Connectivity: Single_Server_Dual_SIOC
```

**When the server connectivity is set as Single Server Dual SIOC and if you want to change that to single server single SIOC:**

```
Server /chassis # server-sioc-connectivity
The Server SIOC Connectivity of the chassis is currently configured as Single Server Dual
SIOC.
Do you want to configure Server SIOC Connectivity of the chassis to Single Server Single
SIOC?[y|N]y

This operation will reset the VIC Adapter-2 to factory default configuration as part of
these changes.
Please take backup of VIC Adapter-2 configuration before proceeding with the operation.
All your VIC Adapter-2 configuration will be lost.
Continue?[y|N]y
The VIC Adapter-2 factory default has been successfully restored. Please reboot the Server-1
Host.
The Chassis Server SIOC Connectivity successfully configured to Single Server Single SIOC.
Server /chassis # show detail
Chassis:
 Serial Number: FCH1819JUVM
 Product Name: UCS S3260
 PID : UCSS-S3260-BASE
 Front Panel Locator LED: off
 Description: Test Label22
 Asset Tag: TESTTAG11
 CMC-1 State: Active
 CMC-2 State: Standby
```

```
Server SIOC Connectivity: Single_Server_Single_SIOC
```

```
Server /chassis #
```

# Managing Dynamic Storage

## Dynamic Storage Support

Effective with this release, The Cisco UCS C-Series rack-mount servers support dynamic storage of Serial Attached SCSI (SAS) drives in the Cisco Management Controller (CMC). This dynamic storage support is provided by the SAS fabric manager located in the CMC.

The fabric manager interacts with the PMC SAS expanders over an Out-of-Band ethernet connection. SAS Expanders allow you to maximize the storage capability of an SAS controller card. Using these expanders, you can employ SAS controllers support up to 60 hard drives. In CMC, an active SIOC configures the expander zoning, where you can assign the drives to the server nodes through the Web UI, command line interface or Cisco UCS Manager. The standby CMC is updated with the current state, so during a CMC fail-over standby, the CMC can take over the zoning responsibilities. Once the drives are visible to a particular server node, you can manage these using RAID controller.



---

**Note** The SAS controller support 56 hard disk drives (HDD) by default. There is also a provision to to replace Server node 2 with an additional four HDDs on Server 2. In that case the total number of HDDs shown in the Zoning page is 60. However, CMC would not support zoning for the additional HDDs 57, 58, 59, 60.

---

The SAS fabric manager provides an API library for other processes to configure and monitor the expanders and drives. Configuration of the fabric involves zoning the drives, updating the firmware for expanders and drives.

Dynamic Storage supports the following options:

- Assigning physical disks to server 1 and server 2
- Chassis Wide Hot Spare (supported only on RAID controllers)
- Shared mode (supported only in HBAs)
- Unassigning physical disks

## Viewing SAS Expander Properties

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **show sas-expander**
3. Server /chassis # **show sas-expander detail**
4. Server /chassis # **scope sas-expander sas expander ID**
5. Server /chassis/sas-expander # **show detail**

## DETAILED STEPS

|               | Command or Action                                           | Purpose                                             |
|---------------|-------------------------------------------------------------|-----------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                               | Enters chassis command mode.                        |
| <b>Step 2</b> | Server /chassis # <b>show sas-expander</b>                  | Displays the SAS expander properties.               |
| <b>Step 3</b> | Server /chassis # <b>show sas-expander detail</b>           | Displays detailed SAS expander properties.          |
| <b>Step 4</b> | Server /chassis # <b>scope sas-expander sas expander ID</b> | Enters SAS expander mode.                           |
| <b>Step 5</b> | Server /chassis/sas-expander # <b>show detail</b>           | Displays the properties of the chosen SAS expander. |

## Example

This example displays the SAS expander properties:

```
Server# scope chassis
Server /chassis # show sas-expander
ID Name Update Stage Update Progress Current FW Version

1 SASEXP1 NONE 100 04.08.01_B055
2 SASEXP2 NONE 100 04.08.01_B055
```

```
Server /chassis # show sas-expander detail
```

```
Firmware Image Information:
ID: 1
Name: SASEXP1
Update Stage: NONE
Update Progress: 100
Current FW Version: 04.08.01_B056
FW Image 1 Version: 04.08.01_B056
FW Image 1 State: RUNNING ACTIVATED
FW Image 2 Version: 04.08.01_B056
FW Image 2 State: BACKUP INACTIVATED
```

```
Firmware Image Information:
ID: 2
Name: SASEXP2
Update Stage: NONE
Update Progress: 100
Current FW Version: 04.08.01_B056
FW Image 1 Version: 04.08.01_B056
FW Image 1 State: RUNNING ACTIVATED
FW Image 2 Version: 04.08.01_B056
FW Image 2 State: BACKUP INACTIVATED
```

```
Server /chassis # scope sas-expander 1
```

```
Server /chassis/sas-expander # show detail
```

```
Firmware Image Information:
ID: 1
Name: SASEXP1
Update Stage: NONE
Update Progress: 100
Current FW Version: 04.08.01_B056
FW Image 1 Version: 04.08.01_B056
FW Image 1 State: RUNNING ACTIVATED
FW Image 2 Version: 04.08.01_B056
FW Image 2 State: BACKUP INACTIVATED
```

```
Server /chassis/sas-expander #
```

## Viewing Dynamic Storage and Physical Drive Details

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **show dynamic-storage**
3. Server /chassis/dynamic-storage # **scope dynamic-storage**
4. Server /chassis/dynamic-storage # **show physical-drive**
5. Server /chassis/dynamic-storage # **show physical-drive-fw**
6. Server /chassis/dynamic-storage # **show physical-drive-link**
7. Server /chassis/dynamic-storage # **show physical-slot-owner**

### DETAILED STEPS

|               | Command or Action                                                 | Purpose                                                            |
|---------------|-------------------------------------------------------------------|--------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                     | Enters chassis command mode.                                       |
| <b>Step 2</b> | Server /chassis # <b>show dynamic-storage</b>                     | Displays the physical drives and the servers they are assigned to. |
| <b>Step 3</b> | Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>    | Enters dynamic storage command mode.                               |
| <b>Step 4</b> | Server /chassis/dynamic-storage # <b>show physical-drive</b>      | Displays the physical drive properties.                            |
| <b>Step 5</b> | Server /chassis/dynamic-storage # <b>show physical-drive-fw</b>   | Displays the firmware of the physical drives.                      |
| <b>Step 6</b> | Server /chassis/dynamic-storage # <b>show physical-drive-link</b> | Displays the links of the physical drives.                         |
| <b>Step 7</b> | Server /chassis/dynamic-storage # <b>show physical-slot-owner</b> | Displays the physical drives association with the servers.         |

### Example

This example displays the dynamic storage properties:

```
Server# scope chassis
Server /chassis # show dynamic-storage
Slot Ownership
----- -
1 server1
2 server1
3 server1
4 server1
5 server1
6 server1
7 server1
8 server1
9 server1
.
.
.
Server /chassis # scope dynamic-storage
Server /chassis/dynamic-storage # show detail
Slot 1:
```

## Viewing Dynamic Storage and Physical Drive Details

```

Ownership: server1
Slot 2:
Ownership: server1
Slot 3:
Ownership: server1
Slot 4:
Ownership: server1
Slot 5:
Ownership: server1
Slot 6:
Ownership: server1
Slot 7:
Ownership: server1
Slot 8:
.
.
.

```

```
Server /chassis/dynamic-storage # show physical-drive
```

| Slot | Ownership | Health | Vendor  | Product ID | Size    | Serial Number |
|------|-----------|--------|---------|------------|---------|---------------|
| 1    | server1   | good   | TOSHIBA | MG03SCA400 | 3.63 TB | 94E0A0T9FVU4  |
| 2    | server1   | good   | TOSHIBA | MG03SCA400 | 3.63 TB | 94D0A0F7FVU4  |
| 3    | server1   | good   | TOSHIBA | MG03SCA400 | 3.63 TB | 94B0A12YFVU4  |
| 4    | server1   | good   | TOSHIBA | MG03SCA400 | 3.63 TB | 94B0A131FVU4  |
| 5    | server1   | good   | TOSHIBA | MG03SCA400 | 3.63 TB | 94C0A0I9FVU4  |
| 6    | server1   | good   | TOSHIBA | MG03SCA400 | 3.63 TB | 94B0A12ZFVU4  |
| 7    | server1   | good   | TOSHIBA | MG03SCA400 | 3.63 TB | 94B0A02AFVU4  |
| 8    | server1   | good   | TOSHIBA | MG03SCA400 | 3.63 TB | 94B0A00LFVU4  |
| 9    | server1   | good   | TOSHIBA | MG03SCA400 | 3.63 TB | 94B0A00WFVU4  |
| 10   | server1   | good   | TOSHIBA | MG03SCA400 | 3.63 TB | 94B0A00QFVU4  |
| 11   | server1   | good   | TOSHIBA | MG03SCA400 | 3.63 TB | 94B0A00MFVU4  |
| 12   | server1   | good   | TOSHIBA | MG03SCA400 | 3.63 TB | 94B0A00NFVU4  |
| 13   | server1   | good   | TOSHIBA | MG03SCA400 | 3.63 TB | 94B0A130FVU4  |
| 14   | server1   | good   | TOSHIBA | MG03SCA400 | 3.63 TB | 94B0A000FVU4  |

```
Server /chassis/dynamic-storage # show physical-drive-fw
```

| Slot | Vendor  | Product ID | Current_FW | Update Stage | Update Progress |
|------|---------|------------|------------|--------------|-----------------|
| 1    | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 2    | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 3    | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 4    | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 5    | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 6    | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 7    | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 8    | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 9    | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 10   | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 11   | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 12   | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 13   | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 14   | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |

```
Server /chassis/dynamic-storage show physical-drive-link
```

| Slot | Ownership | EX1 Link | EX2 Link | SAS Address 1    | SAS Address 2    |
|------|-----------|----------|----------|------------------|------------------|
| 1    | server1   | 6.0 Gb   | 6.0 Gb   | 50000395c8d2a1fe | 50000395c8d2a1ff |
| 2    | server1   | 6.0 Gb   | 6.0 Gb   | 50000395c8d1f6de | 50000395c8d1f6df |
| 3    | server1   | 6.0 Gb   | 6.0 Gb   | 50000395c8d0e93a | 50000395c8d0e93b |
| 4    | server1   | 6.0 Gb   | 6.0 Gb   | 50000395c8d0e946 | 50000395c8d0e947 |
| 5    | server1   | 6.0 Gb   | 6.0 Gb   | 50000395c8d17d2e | 50000395c8d17d2f |
| 6    | server1   | 6.0 Gb   | 6.0 Gb   | 50000395c8d0e93e | 50000395c8d0e93f |

```

7 server1 6.0 Gb 6.0 Gb 50000395c8d09ace 50000395c8d09acf
8 server1 6.0 Gb 6.0 Gb 50000395c8d099ce 50000395c8d099cf
9 server1 6.0 Gb 6.0 Gb 50000395c8d099fa 50000395c8d099fb
10 server1 6.0 Gb 6.0 Gb 50000395c8d099e2 50000395c8d099e3
11 server1 6.0 Gb 6.0 Gb 50000395c8d099d2 50000395c8d099d3
12 server1 6.0 Gb 6.0 Gb 50000395c8d099d6 50000395c8d099d7
13 server1 6.0 Gb 6.0 Gb 50000395c8d0e942 50000395c8d0e943
14 server1 6.0 Gb 6.0 Gb 50000395c8d099da 50000395c8d099db

```

```

Server /chassis/dynamic-storage show physical-slot-owner
Slot Ownership

1 server1
2 server1
3 server1
4 server1
5 hotspare
6 server1
7 server1
8 server1
9 server1
10 server1
.
.
.
Server /chassis/dynamic-storage #

```

## Enabling 6G or 12G Mixed Mode Speed on SAS Expanders

Cisco IMC supports mixed mode speeds of 6 gigabytes or 12 gigabytes for SAS expanders. This support is added because 6 gigabyte solid state drives (SSDs) are now giving way to 12 gigabyte SSDs. Using this feature you can select a SAS expander in the Dynamic Storage tab and enable either modes based on your requirements.

### Enabling 6G or 12G Mixed Mode on a SAS Expander

This action is available only on some servers.

#### Before you begin

You must log in with admin privileges to perform this task.

#### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope sas-expander sas-expander ID**
3. Server /chassis/sas-expander # **scope 6G-12G-Mixed-Mode-status**
4. Server /chassis/sas-expander/6G-12G-Mixed-Mode-status # **set set-6G-12G-mixed-mode Enabled**
5. Server /chassis/sas-expander/6G-12G-Mixed-Mode-status \* # **commit**
6. (Optional) Server /chassis/sas-expander/6G-12G-Mixed-Mode-status # **show detail**

#### DETAILED STEPS

|        | Command or Action             | Purpose                          |
|--------|-------------------------------|----------------------------------|
| Step 1 | Server # <b>scope chassis</b> | Enters the chassis command mode. |

|               | Command or Action                                                                                | Purpose                                                                                         |
|---------------|--------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|
| <b>Step 2</b> | Server /chassis # <b>scope sas-expander sas-expander ID</b>                                      | Enters the SAS expander command mode.                                                           |
| <b>Step 3</b> | Server /chassis/sas-expander # <b>scope 6G-12G-Mixed-Mode-status</b>                             | Enters the 6G or 12G mixed mode command mode.                                                   |
| <b>Step 4</b> | Server /chassis/sas-expander/6G-12G-Mixed-Mode-status # <b>set set-6G-12G-mixed-mode Enabled</b> | Enables the 6G or 12G mixed mode on the SAS expander.                                           |
| <b>Step 5</b> | Server /chassis/sas-expander/6G-12G-Mixed-Mode-status * # <b>commit</b>                          | Enter <b>y</b> at the confirmation prompt. Commits the transaction to the system configuration. |
| <b>Step 6</b> | (Optional) Server /chassis/sas-expander/6G-12G-Mixed-Mode-status # <b>show detail</b>            | Displays the 6G or 12G mixed mode status.                                                       |

**Example**

This example shows how to enable the 6G or 12G mixed mode on the SAS expander:

```

Server# scope chassis
Server /chassis # scope sas-expander 1
Server /chassis/sas-expander # scope 6G-12G-Mixed-Mode-status
Server /chassis/sas-expander/6G-12G-Mixed-Mode-status # set set-6G-12G-mixed-mode Enabled
Server /chassis/sas-expander/6G-12G-Mixed-Mode-status *# commit
Are you sure you want to change the enable-mixed-mode setting to Enable mode?[y|N]y
Setting enable-mixed-mode setting to Enable ..
Successfully set enable-6G-12G-mixed-mode to Enable..
Server /chassis/sas-expander/6G-12G-Mixed-Mode-status # show detail
6G/12G Mixed Mode Settings:
 Mixed 6G/12G Drive Support: Enabled
Server /chassis/sas-expander/6G-12G-Mixed-Mode-status #

```

**Enabling Dual Enclosure ID**

This action is available only on some servers.

**Before you begin**

You must log in with admin privileges to perform this task.

**SUMMARY STEPS**

1. Server # **scope chassis**
2. Server /chassis # **scope dynamic-storage**
3. Server /chassis/sas-expander # **set-dual-enclosure**
4. Enter **Yes** again and press **Enter** to confirm.

**DETAILED STEPS**

|               | Command or Action             | Purpose                          |
|---------------|-------------------------------|----------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b> | Enters the chassis command mode. |



|               | Command or Action                                         | Purpose                                             |
|---------------|-----------------------------------------------------------|-----------------------------------------------------|
| <b>Step 2</b> | Server /chassis # <b>scope dynamic-storage</b>            | Enters the dynamic storage command mode.            |
| <b>Step 3</b> | Server /chassis/sas-expander # <b>set-dual-enclosure</b>  | Enter <b>Yes</b> and press <b>Enter</b> to confirm. |
| <b>Step 4</b> | Enter <b>Yes</b> again and press <b>Enter</b> to confirm. |                                                     |

### Example

```

Server# scope chassis
server /chassis# scope dynamic-storage
server /chassis/dynamic-storage # set-dual-enclosure
Do you want to set different enclosure id to SAS Expanders?
Enter 'yes' --> to set different enclosure id
Enter 'no' --> to set same enclosure id
Enter your option 'yes/no' to continue-->yes
This dual enclosure feature should be applied only when the server nodes has UCS-S3260-DHBA
adaptor and single path is zoned for each drives.
make sure both server blades are powered off.
Do you want to continue? Enter 'yes' to continue-->yes
set-dual-enclosure operation success
server /chassis/dynamic-storage #

```

## Managing Physical Drives

### Assigning Physical Drives to Servers

#### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis/dynamic-storage # **scope dynamic-storage**
3. Server /chassis/dynamic-storage # **assign-drive** <server1 | server2 | shared | hotspare> [SBMezz1 | IOEMezz1 | SBMezz2] [PATH\_BOTH | PATH\_0 | PATH\_1] <drive-slotid-list>

#### DETAILED STEPS

|               | Command or Action                                                                                                                                                              | Purpose                                                                                            |
|---------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                                                                                                                                  | Enters chassis command mode.                                                                       |
| <b>Step 2</b> | Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>                                                                                                                 | Enters dynamic storage command mode.                                                               |
| <b>Step 3</b> | Server /chassis/dynamic-storage # <b>assign-drive</b> <server1   server2   shared   hotspare> [SBMezz1   IOEMezz1   SBMezz2] [PATH_BOTH   PATH_0   PATH_1] <drive-slotid-list> | Enter <b>yes</b> at the confirmation prompt, this assigns the chosen physical drive to the server. |

### Example

Example for assigning a physical drive to the servers:

```

Server# scope chassis
Server /chassis # scope dynamic-storage
Server /chassis/dynamic-storage # assign-drive server2 SBMezz1 PATH_0 15
Are you sure you want to assign drives 15 to server1-SBMezz1 using PATH_0?
Enter 'yes' to confirm -> yes
assign-drive operation successful.
Server /chassis/dynamic-storage #

```

## Unassigning Physical Drives to Servers

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **show dynamic-storage**
3. Server /chassis/dynamic-storage # **scope dynamic-storage**
4. Server /chassis/dynamic-storage # **unassign-drive <drive-slotid-list>**

### DETAILED STEPS

|               | Command or Action                                                                 | Purpose                                                                    |
|---------------|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                                     | Enters chassis command mode.                                               |
| <b>Step 2</b> | Server /chassis # <b>show dynamic-storage</b>                                     | Displays the physical drives and the servers they are assigned to servers. |
| <b>Step 3</b> | Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>                    | Enters dynamic storage command mode.                                       |
| <b>Step 4</b> | Server /chassis/dynamic-storage # <b>unassign-drive &lt;drive-slotid-list&gt;</b> | Unassign the chosen physical drive.                                        |

### Example

This example unassigning a physical drive:

```

Server# scope chassis
Server /chassis # scope dynamic-storage
Server /chassis/dynamic-storage # unassign-drive 27
Are you sure you want to unassign drives 27
Host will loose access to drive(s). Enter 'yes' to confirm -> yes
unassign-drive operation successful.

Server /chassis/dynamic-storage #

```

## Assigning Physical Drives as Chassis Wide Hot Spare

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis/dynamic-storage # **scope dynamic-storage**
3. Server /chassis/dynamic-storage # **assign-drive hotspare <drive-slotid-list>**

## DETAILED STEPS

|        | Command or Action                                                                  | Purpose                                                               |
|--------|------------------------------------------------------------------------------------|-----------------------------------------------------------------------|
| Step 1 | Server # <b>scope chassis</b>                                                      | Enters chassis command mode.                                          |
| Step 2 | Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>                     | Enters dynamic storage command mode.                                  |
| Step 3 | Server /chassis/dynamic-storage # <b>assign-drive hotspare</b> <drive-slotid-list> | Assigns the physical drive as a global hotspare at the chassis level. |

## Example

Example for assigning a physical drive as a global hotspare at the chassis level:

```
Server# scope chassis
Server /chassis # scope dynamic-storage
Server /chassis/dynamic-storage # assign-drive hotspare 5
Are you sure you want to assign drives 5 as hotspare
Enter 'yes' to confirm -> yes
assign-drive operation successful.

Server /chassis/dynamic-storage #
```

## Sharing Physical Drives with Servers

## SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis/dynamic-storage # **scope dynamic-storage**
3. Server /chassis/dynamic-storage # **assign-drive shared** <drive-slotid-list>

## DETAILED STEPS

|        | Command or Action                                                                | Purpose                                                 |
|--------|----------------------------------------------------------------------------------|---------------------------------------------------------|
| Step 1 | Server # <b>scope chassis</b>                                                    | Enters chassis command mode.                            |
| Step 2 | Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>                   | Enters dynamic storage command mode.                    |
| Step 3 | Server /chassis/dynamic-storage # <b>assign-drive shared</b> <drive-slotid-list> | Assigns the chosen physical drive for both the servers. |

## Example

Example for assigning the same physical drive for both the servers:

```
Server# scope chassis
Server /chassis # scope dynamic-storage
svbu-huu-sanity-col2-1-vcmc /chassis/dynamic-storage # assign-drive shared 4
Are you sure you want to assign drives 4 as shared
Enter 'yes' to confirm -> yes
assign-drive operation successful.
```

```
Server /chassis/dynamic-storage #
```



## CHAPTER 4

# Managing the Server

This chapter includes the following sections:

- [Toggling the Server Locator LED, on page 41](#)
- [Toggling the Locator LED for a Hard Drive, on page 42](#)
- [Clearing Personality Configuration, on page 43](#)
- [Managing the Server Boot Order, on page 43](#)
- [Managing Server Power, on page 46](#)
- [Resetting the Server, on page 63](#)
- [Shutting Down the Server , on page 64](#)
- [Configuring DIMM Black Listing, on page 65](#)
- [Configuring BIOS Settings, on page 66](#)
- [Viewing Product ID \(PID\) Catalog Details, on page 76](#)
- [Uploading and Activating PID Catalog, on page 78](#)
- [Deleting PID Catalog, on page 80](#)
- [Persistent Memory Module, on page 81](#)

## Toggling the Server Locator LED

### Before you begin

You must log in with user or admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope server server ID**
2. Server /server # **set locator-led {on | off}**
3. Server /server # **commit**

### DETAILED STEPS

|               | Command or Action                                  | Purpose                                     |
|---------------|----------------------------------------------------|---------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server server ID</b>             | Enters server command mode.                 |
| <b>Step 2</b> | Server /server # <b>set locator-led {on   off}</b> | Enables or disables the server locator LED. |

|               | Command or Action              | Purpose                                              |
|---------------|--------------------------------|------------------------------------------------------|
| <b>Step 3</b> | Server /server # <b>commit</b> | Commits the transaction to the system configuration. |

### Example

This example disables the server locator LED and commits the transaction:

```
Server# scope server 1
Server /server # set locator-led off
Server /server *# commit

Server /server #
```

## Toggling the Locator LED for a Hard Drive

### Before you begin

You must log in with user or admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server # **scope sensor**
3. Server /server/sensor # **scope hdd**
4. Server /server/sensor/hdd # **set locateHDD** *drivenum* {1 | 2}

### DETAILED STEPS

|               | Command or Action                                                        | Purpose                                                                                                                                                      |
|---------------|--------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}                                     | Enters server command mode of server 1 or 2.                                                                                                                 |
| <b>Step 2</b> | Server /server # <b>scope sensor</b>                                     | Enters sensor command.                                                                                                                                       |
| <b>Step 3</b> | Server /server/sensor # <b>scope hdd</b>                                 | Enters hard disk drive (HDD) command mode.                                                                                                                   |
| <b>Step 4</b> | Server /server/sensor/hdd # <b>set locateHDD</b> <i>drivenum</i> {1   2} | Where <i>drivenum</i> is the number of the hard drive whose locator LED you want to set. A value of 1 turns the LED on while a value of 2 turns the LED off. |

### Example

This example turns on the locator LED on HDD 2:

```
Server# scope server 1
Server /server # scope sensor
Server /server/sensor # scope hdd
Server /server/sensor/hdd # locateHDD 2 1
HDD Locate LED Status changed to 1
Server /server/sensor/hdd # show
```

```

Name Status LocateLEDStatus

HDD1_STATUS present TurnOFF
HDD2_STATUS present TurnON
HDD3_STATUS absent TurnOFF
HDD4_STATUS absent TurnOFF

Server /server/sensor/hdd #

```

## Clearing Personality Configuration

### Before you begin

You must log in with admin privileges to perform this task.

- 
- Step 1** Server # **scope chassis**  
Enters chassis command mode.
- Step 2** Server chassis # **clear-personality**  
Clears the personality configuration.
- 

## Managing the Server Boot Order

### Server Boot Order

Using Cisco IMC, you can configure the order in which the server attempts to boot from available boot device types. In the legacy boot order configuration, Cisco IMC allows you to reorder the device types but not the devices within the device types. With the precision boot order configuration, you can have a linear ordering of the devices. In the web UI or CLI you can change the boot order and boot mode, add multiple devices under each device types, rearrange the boot order, set parameters for each device type.

When you change the boot order configuration, Cisco IMC sends the configured boot order to BIOS the next time that server is rebooted. To implement the new boot order, reboot the server after you make the configuration change. The new boot order takes effect on any subsequent reboot. The configured boot order remains until the configuration is changed again in Cisco IMC or in the BIOS setup.



- 
- Note** The actual boot order differs from the configured boot order if either of the following conditions occur:
- BIOS encounters issues while trying to boot using the configured boot order.
  - A user changes the boot order directly through BIOS.
-

## Viewing the Actual Server Boot Order

The actual server boot order is the boot order actually used by the BIOS when the server last booted. The actual boot order can differ from the boot order configured in .

### SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server# **scope bios**
3. Server /server/bios # **show actual-boot-order** [detail]

### DETAILED STEPS

|               | Command or Action                                            | Purpose                                                                        |
|---------------|--------------------------------------------------------------|--------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}                         | Enters server command mode of server 1 or 2.                                   |
| <b>Step 2</b> | Server /server# <b>scope bios</b>                            | Enters BIOS command mode.                                                      |
| <b>Step 3</b> | Server /server/bios # <b>show actual-boot-order</b> [detail] | Displays the boot order actually used by the BIOS when the server last booted. |

### Example

This example displays the actual boot order of the legacy boot order from the last boot:

```
Server# scope server 1
Server /server # scope bios
Server /server/bios # show actual-boot-order

Boot Order Boot Device Device Type Boot Policy

1 Cisco CIMC-Mapped vDVD1.22 VMEDIA NIHUUCIMCDVD
2 Cisco vKVM-Mapped vDVD1.22 VMEDIA dvd
3 Cisco vKVM-Mapped vHDD1.22 VMEDIA dvd2
4 Cisco CIMC-Mapped vHDD1.22 VMEDIA dvd3
5 (Bus 14 Dev 00)PCI RAID Adapter HDD NonPolicyTarget
6 "P1: INTEL SSDSC2BB120G4 " PCHSTORAGE NonPolicyTarget
7 "UEFI: Built-in EFI Shell " EFI NonPolicyTarget
8 "P0: INTEL SSDSC2BB120G4 " PCHSTORAGE NonPolicyTarget
9 Cisco vKVM-Mapped vFDD1.22 VMEDIA NonPolicyTarge

Server /server/bios #
```

## Configuring a Server to Boot With a One-Time Boot Device

You can configure a server to boot from a particular device only for the next server boot, without disrupting the currently configured boot order. Once the server boots from the one time boot device, all its future reboots occur from the previously configured boot order.

### Before you begin

You must log in with user or admin privileges to perform this task.



**SUMMARY STEPS**

1. Server# **scope bios**
2. Server# /bios **show boot-device**
3. Server# /bios **set one-time-boot-device** *device-order*
4. Server# /bios \* **commit**
5. (Optional) Server# /bios **show detail**

**DETAILED STEPS**

|               | <b>Command or Action</b>                                          | <b>Purpose</b>                                                                                                                                |
|---------------|-------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope bios</b>                                         | Enters the BIOS command mode.                                                                                                                 |
| <b>Step 2</b> | Server# /bios <b>show boot-device</b>                             | Displays the list of available boot drives.                                                                                                   |
| <b>Step 3</b> | Server# /bios <b>set one-time-boot-device</b> <i>device-order</i> | Sets the boot order.<br><br><b>Note</b> The host boots to the one time boot device even when configured with a disabled advanced boot device. |
| <b>Step 4</b> | Server# /bios * <b>commit</b>                                     | Commits the transaction.                                                                                                                      |
| <b>Step 5</b> | (Optional) Server# /bios <b>show detail</b>                       | Displays the BIOS details.                                                                                                                    |

**Example**

This example shows how to configure a server to boot with a one-time boot device:

```

Server scope bios
Server /bios # show boot-device
Boot Device Device Type Device State Device Order

KVMDVD VMEDIA Enabled 1
vkvm VMEDIA Enabled 2

Server /bios # set one-time-boot-device KVMDVD
Server /bios *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N]n
Changes will be applied on next reboot.
Server /bios # show detail
BIOS:
 BIOS Version: "C240M3.3.0.0.9 (Build Date: 10/02/16)"
 Boot Order: (none)
 FW Update/Recovery Status: None, OK
 UEFI Secure Boot: disabled
 Configured Boot Mode: Legacy
 Actual Boot Mode: Legacy
 Last Configured Boot Order Source: CIMC
 One time boot device: KVMDVD
Server /bios #

```

## Assigning User-defined Server Description and Asset Tag

### Procedure

|               | Command or Action                                             | Purpose                        |
|---------------|---------------------------------------------------------------|--------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                  | Enters chassis command mode.   |
| <b>Step 2</b> | Server /chassis # <b>set description</b> <Server Description> | Enters the server description. |
| <b>Step 3</b> | Server /chassis* # <b>set asset-tag</b> <Asset Tag>           | Enters the asset tag.          |
| <b>Step 4</b> | Server /chassis* # <b>commit</b>                              | Commits the transaction.       |
| <b>Step 5</b> | (Optional) Server /chassis # <b>show detail</b>               | Displays the server details.   |

### Example

This example shows how to assign user-defined server description and asset tag:

```
Server# scope chassis
Server/chassis # set description DN1-server
Server/chassis* # set asset-tag powerpolicy
Server /chassis* # commit
Server /chassis # show detail
Chassis:
 Power: on
 Serial Number: FCH1834V23X
 Product Name: UCS C220 M4S
 PID : UCSC-C220-M4S
 UUID: 414949AC-22D6-4D0D-B0C0-F7950E9217C1
 Locator LED: off
 Description: DN1-server
 Asset Tag: powerpolicy
Server /chassis #
```

## Managing Server Power

### Powering On the Server



**Note** If the server was powered off other than through the , the server will not become active immediately when powered on. In this case, the server will enter standby mode until the completes initialization.



**Important** If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

**Before you begin**

You must log in with user or admin privileges to perform this task.

**SUMMARY STEPS**

1. Server# **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis/server # **power on**
4. At the prompt, enter **y** to confirm.

**DETAILED STEPS**

|               | Command or Action                             | Purpose                                      |
|---------------|-----------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                  | Enters the chassis command mode.             |
| <b>Step 2</b> | Server /chassis # <b>scope server {1   2}</b> | Enters server command mode of server 1 or 2. |
| <b>Step 3</b> | Server /chassis/server # <b>power on</b>      | Powers on the server.                        |
| <b>Step 4</b> | At the prompt, enter <b>y</b> to confirm.     | Power on the server.                         |

**Example**

This example shows how to power on the server:

```
Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power on
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID

1 On FCH1848794D UCS S3260M4 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#
```

## Powering Off the Server




---

**Important** If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

---

**Before you begin**

You must log in with user or admin privileges to perform this task.

**SUMMARY STEPS**

1. Server# **scope chassis**
2. Serve /chassis # **scope server 1**
3. Server /chassis/server # **power off**
4. At the prompt, enter **y** to confirm.

**DETAILED STEPS**

|               | Command or Action                         | Purpose                          |
|---------------|-------------------------------------------|----------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>              | Enters the chassis command mode. |
| <b>Step 2</b> | Serve /chassis # <b>scope server 1</b>    | Enters the server command mode.  |
| <b>Step 3</b> | Server /chassis/server # <b>power off</b> | Powers off the server.           |
| <b>Step 4</b> | At the prompt, enter <b>y</b> to confirm. | Power off the server.            |

**Example**

This example shows how to power off the server:

```
Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power off
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID

1 Off FCH1848794D UCS S3260 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#
```

## Powering Cycling the Server




---

**Important** If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

---

**Before you begin**

You must log in with user or admin privileges to perform this task.

**SUMMARY STEPS**

1. Server# **scope chassis**
2. Serve /chassis # **scope server 1**

3. Server /chassis/server # **power cycle**
4. At the prompt, enter **y** to confirm.

## DETAILED STEPS

|        | Command or Action                           | Purpose                                  |
|--------|---------------------------------------------|------------------------------------------|
| Step 1 | Server# <b>scope chassis</b>                | Enters the chassis command mode.         |
| Step 2 | Server /chassis # <b>scope server 1</b>     | Enters the server command mode.          |
| Step 3 | Server /chassis/server # <b>power cycle</b> | Power off and then powers on the server. |
| Step 4 | At the prompt, enter <b>y</b> to confirm.   | Power off and then powers on the server. |

### Example

This example shows how to power cycle the server:

```
Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power cycle
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID

1 On FCH1848794D UCS S3260 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#
```

## Configuring the Power Restore Policy

The power restore policy determines how power is restored to the server after a chassis power loss.

### Before you begin

You must log in with admin privileges to perform this task.

## SUMMARY STEPS

1. Server /server # **scope server {1 | 2}**
2. server /server # **scope bmc**
3. Server /server/bmc # **scope power-restore-policy**
4. Server /server/bmc/power-restore-policy # **set policy {power-off | power-on | restore-last-state}**
5. (Optional) Server /server/bmc/power-restore-policy # **set delay {fixed | random}**
6. (Optional) Server /server/bmc/power-restore-policy # **set delay-value delay**
7. Server /CIMC/power-restore-policy # **commit**

## DETAILED STEPS

|               | Command or Action                                                                                                              | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|---------------|--------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server /server # <b>scope server</b> {1   2}                                                                                   | Enters server command mode of server 1 or 2.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Step 2</b> | server /server # <b>scope bmc</b>                                                                                              | Enters bmc command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Step 3</b> | Server /server/bmc # <b>scope power-restore-policy</b>                                                                         | Enters the power restore policy command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Step 4</b> | Server /server/bmc/power-restore-policy # <b>set policy</b> { <b>power-off</b>   <b>power-on</b>   <b>restore-last-state</b> } | <p>Specifies the action to be taken when chassis power is restored. Select one of the following:</p> <ul style="list-style-type: none"> <li>• <b>power-off</b>—Server power will remain off until manually turned on. This is the default action.</li> <li>• <b>power-on</b>—Server power will be turned on when chassis power is restored.</li> <li>• <b>restore-last-state</b>—Server power will return to the state before chassis power was lost.</li> </ul> <p>When the selected action is <b>power-on</b>, you can select a delay in the restoration of power to the server.</p> |
| <b>Step 5</b> | (Optional) Server /server/bmc/power-restore-policy # <b>set delay</b> { <b>fixed</b>   <b>random</b> }                         | Specifies whether server power will be restored after a fixed or random time. The default is <b>fixed</b> . This command is accepted only if the power restore action is <b>power-on</b> .                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Step 6</b> | (Optional) Server /server/bmc/power-restore-policy # <b>set delay-value</b> <i>delay</i>                                       | Specifies the delay time in seconds. The range is 0 to 240; the default is 0.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Step 7</b> | Server /CIMC/power-restore-policy # <b>commit</b>                                                                              | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

**Example**

This example sets the power restore policy to power-on with a fixed delay of 180 seconds (3 minutes) and commits the transaction:

```

Server# scope server 1
Server /server # scope bmc
Server /server/bmc # Scope power-restore-policy
Server /server/bmc/power-restore-policy # set policy power-on
Server /server/bmc/power-restore-policy *# commit
Server /server/bmc/power-restore-policy # set delay fixed
Server /server/bmc/power-restore-policy *# set delay-value 180
Server /server/bmc/power-restore-policy *# commit
Server /server/bmc/power-restore-policy # show detail
Power Restore Policy:
 Power Restore Policy: power-on
 Power Delay Type: fixed
 Power Delay Value(sec): 180

Server /server/bmc/power-restore-policy #

```

## Power Characterization

The chassis power characterization range is calculated and derived from individual server node power characterization status, and from the power requirements of all the unmanageable components of the chassis.

This range varies for each configuration, so you need to run the power characterization every time a configuration changes.

To help you use the power characterization range appropriately for the different power profiles, the system represents the chassis' minimum power as auto profile minimum and custom profile minimum. However, custom power profile minimum is the actual minimum power requirement of the current chassis configuration. For more information see the section Run Power Characterization.

## Power Profiles

Power capping determines how server power consumption is actively managed. When you enable power capping option, the system monitors power consumption and maintains the power below the allocated power limit. If the server cannot maintain the power limit or cannot bring the platform power back to the specified power limit within the correction time, power capping performs actions that you specify in the Action field under the Power Profile area.

You can configure multiple profiles with the following combinations: automatic and thermal profiles; and custom and thermal profiles. These profiles are configured by using either the web user interface, command line interface, or XML API. In the web UI, the profiles are listed under the Power Capping area. In the CLI, the profiles are configured when you enter the **power-cap-config** command. You can configure the following power profiles for power capping feature:

- Automatic Power Limiting Profile
- Custom Power Limiting Profile
- Thermal Power Limiting Profile

Automatic power limiting profile sets the power limit of the individual server boards based on server priority selected by you, or as detected by the system, based on the server utilization sensor (which is known as manual or dynamic priority selection). The limiting values are calculated within the manageable chassis power budget and applied to the individual server, and the priority server is allocated with its maximum power limiting value, while the other server with the remaining of the manageable power budget. Power limiting occurs at each server board platform level that affects the overall chassis power consumption.

Custom power limiting profile allows you to set an individual server board's power limit from the Web UI or command line interface within the chassis power budget. In this scenario you can specify an individual server power limit.

Thermal power profile allows you to enable thermal failure power capping, which means you can set a specific platform temperature threshold and it sets P (min-x) as the power limit to be applied on the temperature threshold.

## Enabling Chassis Global Power Capping

### Before you begin

You must log in as a user with admin privileges to perform this task.

## SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope power-cap-config**
3. Server /chassis/power-cap-config # **set pow-cap-enable {yes | no}**
4. Server /chassis/power-cap-config \*# **set chassis-budget***power limit*
5. Server /chassis/power-cap-config \*# **commit**
6. (Optional) Server /chassis/power-cap-config # **show detail**

## DETAILED STEPS

|               | Command or Action                                                                | Purpose                                           |
|---------------|----------------------------------------------------------------------------------|---------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                                    | Enters the chassis command mode.                  |
| <b>Step 2</b> | Server /chassis # <b>scope power-cap-config</b>                                  | Enters power cap configuration command mode.      |
| <b>Step 3</b> | Server /chassis/power-cap-config # <b>set pow-cap-enable {yes   no}</b>          | Enables or disables the power configuration.      |
| <b>Step 4</b> | Server /chassis/power-cap-config *# <b>set chassis-budget</b> <i>power limit</i> | Sets the chassis power limit.                     |
| <b>Step 5</b> | Server /chassis/power-cap-config *# <b>commit</b>                                | Commits the transaction to the system.            |
| <b>Step 6</b> | (Optional) Server /chassis/power-cap-config # <b>show detail</b>                 | Displays the chassis power configuration details. |

## Example

The following example shows how to enable chassis global power capping:

```

Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # set pow-cap-enable yes
Server /chassis/power-cap-config *# set chassis-budget 1000
Server /chassis/power-cap-config *# commit
Server /chassis/power-cap-config # show detail
Chassis :
 Power Capping: yes
 Power Characterization Status: Completed
 Chassis Minimum (W): 756
 Chassis Maximum (W): 1089
 Chassis Budget (W): 1000
 Chassis Manageable Power Budget (W): 530
 Auto Balance Minimum Power Budget (W) : 966
Server 1 :
 Power Characterization Status: Completed
 Platform Minimum (W): 163
 Platform Maximum (W): 362
 Memory Minimum (W): 1
 Memory Maximum (W): 0
 CPU Minimum (W): 95
 CPU Maximum (W): 241
Server 2 :
 Power Characterization Status: Completed
 Platform Minimum (W): 136
 Platform Maximum (W): 253

```



```

Memory Minimum (W): 1
Memory Maximum (W): 0
CPU Minimum (W): 57
CPU Maximum (W): 139
Server /chassis/power-cap-config #

```

## Enabling Auto Balance Profile

### Before you begin

You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope power-cap-config**
3. Server /chassis/power-cap-config # **scope power-profile auto\_balance**
4. Server /chassis/power-cap-config/power-profile # **set enabled {yes | no}**
5. Server /chassis/power-cap-config/power-profile \*# **set priority-selection {dynamic | manual}**
6. Server /chassis/power-cap-config/power-profile \*# **set priority-server-id {1 | 2}**
7. Server /chassis/power-cap-config/power-profile \*# **set corr-time Value**
8. Server /chassis/power-cap-config/power-profile \*# **set allow-throttle {yes | no}**
9. Server /chassis /power-cap-config# **set susp-pd {h:m-h:m | /ll,Mo,Tu,We,Th,Fr,Sa,Su. }**
10. Server /chassis/power-cap-config/power-profile \*# **commit**
11. (Optional) Server /chassis/power-cap-config/power-profile # **show detail**

### DETAILED STEPS

|               | Command or Action                                                                                  | Purpose                                                                                                                                                                                                                                      |
|---------------|----------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                                                      | Enters chassis command mode.                                                                                                                                                                                                                 |
| <b>Step 2</b> | Server /chassis # <b>scope power-cap-config</b>                                                    | Enters power cap configuration command mode.                                                                                                                                                                                                 |
| <b>Step 3</b> | Server /chassis/power-cap-config # <b>scope power-profile auto_balance</b>                         | Enters auto balance power profile command mode.                                                                                                                                                                                              |
| <b>Step 4</b> | Server /chassis/power-cap-config/power-profile # <b>set enabled {yes   no}</b>                     | Enables or disables the power profile.                                                                                                                                                                                                       |
| <b>Step 5</b> | Server /chassis/power-cap-config/power-profile *# <b>set priority-selection {dynamic   manual}</b> | Sets the priority type to the chosen value.                                                                                                                                                                                                  |
| <b>Step 6</b> | Server /chassis/power-cap-config/power-profile *# <b>set priority-server-id {1   2}</b>            | Assigns priority to the chosen server.                                                                                                                                                                                                       |
| <b>Step 7</b> | Server /chassis/power-cap-config/power-profile *# <b>set corr-time Value</b>                       | Sets the correction time in which the platform power should be brought back to the specified power limit before taking the action specified in the <b>Action</b> mode.<br><br>The range is from 1 and 600 seconds. The default is 1 seconds. |

|                | Command or Action                                                                           | Purpose                                                                                                                                        |
|----------------|---------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 8</b>  | Server /chassis/power-cap-config/power-profile <b>*# set allow-throttle {yes   no}</b>      | Enables or disables the system to maintain the power limit by forcing the processor to use the throttling state (T-state) and memory throttle. |
| <b>Step 9</b>  | Server /chassis /power-cap-config# <b>set susp-pd {h:m-h:m   /ll,Mo,Tu,We,Th,Fr,Sa,Su.}</b> | Specifies the time period that the power capping profile will not be active.                                                                   |
| <b>Step 10</b> | Server /chassis/power-cap-config/power-profile <b>*# commit</b>                             | Commits the transaction to the system configuration.                                                                                           |
| <b>Step 11</b> | (Optional) Server /chassis/power-cap-config/power-profile <b># show detail</b>              | Displays the auto balance power profile details.                                                                                               |

### Example

The following example shows how to enable auto balance profile and setting the priority selection:

#### Setting Priority Using Dynamic Option

```
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile auto_balance
Server /chassis/power-cap-config/power-profile # set enabled yes
Server /chassis/power-cap-config/power-profile *# set priority-selection dynamic
Server /chassis/power-cap-config/power-profile *# set corr-time 1
Server /chassis/power-cap-config/power-profile *# set allow-throttle yes
Server /chassis/power-cap-config/power-profile *# set susp-pd "2:0-4:30|All"
Server /chassis/power-cap-config/power-profile *# commit
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : auto_balance
 Enabled: yes
 Priority Selection: dynamic
 Priority Server: 2
 Server1 Power Limit: 362
 Server2 Power Limit: 253
 Suspend Period: 2:0-4:30|All
 Exception Action: alert
 Correction Time: 1
 Throttling: no
Server /chassis/power-cap-config/power-profile #
```

#### Setting Priority Using the Manual Option

```
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile auto_balance
Server /chassis/power-cap-config/power-profile # set enabled yes
Server /chassis/power-cap-config/power-profile *# set priority-selection manual
Server /chassis/power-cap-config/power-profile *# set priority-server-id 1
Server /chassis/power-cap-config/power-profile *# set corr-time 1
Server /chassis/power-cap-config/power-profile *# set allow-throttle yes
Server /chassis/power-cap-config/power-profile *# set susp-pd "2:0-4:30|All"
Server /chassis/power-cap-config/power-profile *# commit
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : auto_balance
 Enabled: yes
 Priority Selection: manual
 Priority Server: 1
 Server1 Power Limit: 362
 Server2 Power Limit: 253
```

```

Suspend Period: 2:0-4:30|All
Exception Action: alert
Correction Time: 1
Throttling: no
Server /chassis/power-cap-config/power-profile #

```

## Disabling Auto Balance Power Profile

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope power-cap-config**
3. Server /chassis/power-cap-config # **scope power-profile auto\_balance**
4. Server /chassis/power-cap-config/power-profile # **set enabled no**
5. Server /chassis/power-cap-config/power-profile # **commit**

### DETAILED STEPS

|               | Command or Action                                                          | Purpose                                              |
|---------------|----------------------------------------------------------------------------|------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                              | Enters the chassis command mode.                     |
| <b>Step 2</b> | Server /chassis # <b>scope power-cap-config</b>                            | Enters the power cap configuration mode.             |
| <b>Step 3</b> | Server /chassis/power-cap-config # <b>scope power-profile auto_balance</b> | Enters the auto balance power profile mode.          |
| <b>Step 4</b> | Server /chassis/power-cap-config/power-profile # <b>set enabled no</b>     | Disables the auto balance power profile.             |
| <b>Step 5</b> | Server /chassis/power-cap-config/power-profile # <b>commit</b>             | Commits the transaction to the system configuration. |

### Example

This example shows how to disable the auto balance profile:

```

Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile auto_balance
Server /chassis/power-cap-config/power-profile # set enabled no
Server /chassis/power-cap-config/power-profile *# commit

```

## Enabling Custom Profile on Server

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope power-cap-config**
3. Server /chassis/power-cap-config # **scope power-profile custom**

4. Server /chassis/power-cap-config/power-profile # **set enabled yes**
5. Server /chassis/power-cap-config/power-profile \*# **set power-limit** *value*
6. Server /chassis/power-cap-config/power-profile \*# **set corr-time** *value*
7. Server /chassis/power-cap-config/power-profile \*# **set allow-throttle yes**
8. Server /chassis/power-cap-config/power-profile \*# **commit**
9. At the prompt, enter the server ID for which you want to apply the custom power profile.
10. Server /chassis/power-cap-config/power-profile # **show detail**

## DETAILED STEPS

|                | Command or Action                                                                        | Purpose                                                                                                                                                                                                                                     |
|----------------|------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b>  | Server # <b>scope chassis</b>                                                            | Enters the chassis command mode.                                                                                                                                                                                                            |
| <b>Step 2</b>  | Server /chassis # <b>scope power-cap-config</b>                                          | Enters the power cap configuration mode.                                                                                                                                                                                                    |
| <b>Step 3</b>  | Server /chassis/power-cap-config # <b>scope power-profile custom</b>                     | Enters the custom power profile mode.                                                                                                                                                                                                       |
| <b>Step 4</b>  | Server /chassis/power-cap-config/power-profile # <b>set enabled yes</b>                  | Enables the custom power profile.                                                                                                                                                                                                           |
| <b>Step 5</b>  | Server /chassis/power-cap-config/power-profile *# <b>set power-limit</b> <i>value</i>    | Specifies the power limit. Enter a value within the specified range.                                                                                                                                                                        |
| <b>Step 6</b>  | Server /chassis/power-cap-config/power-profile *# <b>set corr-time</b> <i>value</i>      | Sets the correction time in which the platform power should be brought back to the specified power limit before taking the action specified in the <b>Action</b> mode.<br><br>The range is from 1 and 600 seconds. The default is 1 seconds |
| <b>Step 7</b>  | Server /chassis/power-cap-config/power-profile *# <b>set allow-throttle yes</b>          | Enables the system to maintain the power limit by forcing the processor to use the throttling state (T-state) and memory throttle.                                                                                                          |
| <b>Step 8</b>  | Server /chassis/power-cap-config/power-profile *# <b>commit</b>                          | Commits the transaction to the system configuration.                                                                                                                                                                                        |
| <b>Step 9</b>  | At the prompt, enter the server ID for which you want to apply the custom power profile. |                                                                                                                                                                                                                                             |
| <b>Step 10</b> | Server /chassis/power-cap-config/power-profile # <b>show detail</b>                      | Displays the power profile details.                                                                                                                                                                                                         |

### Example

This example shows how to enable the custom profile on any server node:

```
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile custom
Server /chassis/power-cap-config/power-profile # set enabled yes
Server /chassis/power-cap-config/power-profile *# set power-limit 253
Server /chassis/power-cap-config/power-profile *# set corr-time 1
```

```

Server /chassis/power-cap-config/power-profile *# set allow-throttle no
Server /chassis/power-cap-config/power-profile *# commit
Please enter server Id for which 'custom' power profile setting needs to be done
[1|2]?2
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : custom
Server Id 1:
 Enabled: no
 Power Limit: N/A
 Suspend Period:
 Exception Action: alert
 Correction Time: 1
 Throttling: no
Server Id 2:
 Enabled: yes
 Power Limit: 253
 Suspend Period:
 Exception Action: alert
 Correction Time: 1
 Throttling: yes

```

## Disabling Custom Profile on Server

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope power-cap-config**
3. Server /chassis/power-cap-config # **scope power-profile custom**
4. Server /chassis/power-cap-config/power-profile # **set enabled no**
5. Server /chassis/power-cap-config/power-profile \*# **commit**
6. At the prompt, enter the server ID for which you want to disable the custom power profile.
7. Server /chassis/power-cap-config/power-profile # **show detail**

### DETAILED STEPS

|               | Command or Action                                                                          | Purpose                                              |
|---------------|--------------------------------------------------------------------------------------------|------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                                              | Enters the chassis command mode.                     |
| <b>Step 2</b> | Server /chassis # <b>scope power-cap-config</b>                                            | Enters the power cap configuration mode.             |
| <b>Step 3</b> | Server /chassis/power-cap-config # <b>scope power-profile custom</b>                       | Enters the custom power profile mode.                |
| <b>Step 4</b> | Server /chassis/power-cap-config/power-profile # <b>set enabled no</b>                     | Disables the custom power profile.                   |
| <b>Step 5</b> | Server /chassis/power-cap-config/power-profile *# <b>commit</b>                            | Commits the transaction to the system configuration. |
| <b>Step 6</b> | At the prompt, enter the server ID for which you want to disable the custom power profile. |                                                      |
| <b>Step 7</b> | Server /chassis/power-cap-config/power-profile # <b>show detail</b>                        | Displays the power profile details.                  |

## Example

This example shows how to disable the custom profile on any server node:

```
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile custom
Server /chassis/power-cap-config/power-profile # set enabled no
Server /chassis/power-cap-config/power-profile *# commit
Please enter server Id for which 'custom' power profile setting needs to be done
[1|2]?2
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : custom
Server Id 1:
 Enabled: no
 Power Limit: N/A
 Suspend Period:
 Exception Action: alert
 Correction Time: 1
 Throttling: no
Server Id 2:
 Enabled: no
 Power Limit: 253
 Suspend Period:
 Exception Action: alert
 Correction Time: 1
 Throttling: yes
```

## Enabling Thermal Profile on Server

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope power-cap-config**
3. Server /chassis/power-cap-config # **scope power-profile thermal**
4. Server /chassis/power-cap-config/power-profile # **set enabled yes**
5. Server /chassis/power-cap-config/power-profile \*# **set temperature value**
6. Server /chassis/power-cap-config/power-profile \*# **commit**
7. At the prompt, enter the server ID for which you want to enable the thermal power profile.
8. Server /chassis/power-cap-config/power-profile # **show detail**

### DETAILED STEPS

|               | Command or Action                                                     | Purpose                                  |
|---------------|-----------------------------------------------------------------------|------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                         | Enters the chassis command mode.         |
| <b>Step 2</b> | Server /chassis # <b>scope power-cap-config</b>                       | Enters the power cap configuration mode. |
| <b>Step 3</b> | Server /chassis/power-cap-config # <b>scope power-profile thermal</b> | Enters the thermal power profile mode.   |

|        | Command or Action                                                                          | Purpose                                                                            |
|--------|--------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|
| Step 4 | Server /chassis/power-cap-config/power-profile # <b>set enabled yes</b>                    | Enables or disables the thermal power profile.                                     |
| Step 5 | Server /chassis/power-cap-config/power-profile *# <b>set temperature value</b>             | Enter power in watts within the range specified. Enter the temperature in Celsius. |
| Step 6 | Server /chassis/power-cap-config/power-profile *# <b>commit</b>                            | Commits the transaction to the system configuration.                               |
| Step 7 | At the prompt, enter the server ID for which you want to enable the thermal power profile. |                                                                                    |
| Step 8 | Server /chassis/power-cap-config/power-profile # <b>show detail</b>                        | Displays the power profile details.                                                |

### Example

This example shows how to enable the thermal profile on any server node:

```
Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile thermal
Server /chassis/power-cap-config/power-profile # set enabled yes
Server /chassis/power-cap-config/power-profile *# set temperature 26
Server /chassis/power-cap-config/power-profile *# commit
Please enter server Id for which 'thermal' power profile setting needs to be done
[1|2]?1
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : thermal
Server Id 1:
 Enabled: yes
 Temperature Threshold (deg C): 26
 Power Limit: 163
```

## Disabling Thermal Profile on Server

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope power-cap-config**
3. Server /chassis/power-cap-config # **scope power-profile thermal**
4. Server /chassis/power-cap-config/power-profile # **set enabled no**
5. Server /chassis/power-cap-config/power-profile \*# **commit**
6. At the prompt, enter the server ID for which you want to disable the thermal power profile.
7. Server /chassis/power-cap-config/power-profile # **show detail**

### DETAILED STEPS

|        | Command or Action             | Purpose                          |
|--------|-------------------------------|----------------------------------|
| Step 1 | Server # <b>scope chassis</b> | Enters the chassis command mode. |

|               | Command or Action                                                                           | Purpose                                              |
|---------------|---------------------------------------------------------------------------------------------|------------------------------------------------------|
| <b>Step 2</b> | Server /chassis # <b>scope power-cap-config</b>                                             | Enters the power cap configuration mode.             |
| <b>Step 3</b> | Server /chassis/power-cap-config # <b>scope power-profile thermal</b>                       | Enters the thermal power profile mode.               |
| <b>Step 4</b> | Server /chassis/power-cap-config/power-profile # <b>set enabled no</b>                      | Disables the thermal power profile.                  |
| <b>Step 5</b> | Server /chassis/power-cap-config/power-profile *# <b>commit</b>                             | Commits the transaction to the system configuration. |
| <b>Step 6</b> | At the prompt, enter the server ID for which you want to disable the thermal power profile. |                                                      |
| <b>Step 7</b> | Server /chassis/power-cap-config/power-profile # <b>show detail</b>                         | Displays the power profile details.                  |

### Example

This example shows how to disable the thermal profile on any server node:

```

Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # scope power-profile thermal
Server /chassis/power-cap-config/power-profile # set enabled no
Server /chassis/power-cap-config/power-profile *# commit
Please enter server Id for which 'thermal' power profile setting needs to be done
[1|2]?1
Server /chassis/power-cap-config/power-profile # show detail
Profile Name : thermal
Server Id 1:
 Enabled: no
 Temperature Threshold (deg C): 26
 Power Limit: 163
Server Id 2:
 Enabled: no
 Temperature Threshold (deg C): 0
 Power Limit: N/A
Server /chassis/power-cap-config/power-profile #

```

## Viewing Power Cap Configuration Details

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope power-cap-config**
3. Server /chassis/power-cap-config # **show detail**



## DETAILED STEPS

|               | Command or Action                                     | Purpose                                                                |
|---------------|-------------------------------------------------------|------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                         | Enters the chassis command mode.                                       |
| <b>Step 2</b> | Server /chassis # <b>scope power-cap-config</b>       | Enters the power cap configuration mode.                               |
| <b>Step 3</b> | Server /chassis/power-cap-config # <b>show detail</b> | Displays the power characterization status of the chassis and servers. |

## Example

This example shows how to view power cap configuration details:

```

Server # scope chassis
Server /chassis # scope power-cap-config
Server /chassis/power-cap-config # show detail
Chassis :
 Power Capping: yes
 Power Characterization Status: Completed
 Chassis Minimum (W): 756
 Chassis Maximum (W): 1089
 Chassis Budget (W): 1000
 Chassis Manageable Power Budget (W): 530
 Auto Balance Minimum Power Budget (W) : 966
 Auto Balance Efficient Budget (W): 1901
Server 1 :
 Power Characterization Status: Completed
 Platform Minimum (W): 163
 Platform Efficient (W): 396
 Platform Maximum (W): 362
 Memory Minimum (W): 1
 Memory Maximum (W): 0
 CPU Minimum (W): 95
 CPU Maximum (W): 241
Server 2 :
 Power Characterization Status: Completed
 Platform Minimum (W): 136
 Platform Efficient (W): 584
 Platform Maximum (W): 253
 Memory Minimum (W): 1
 Memory Maximum (W): 0
 CPU Minimum (W): 57
 CPU Maximum (W): 139
Server /chassis/power-cap-config #

```

## Viewing Power Monitoring Details

## SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **show power-monitoring**

## DETAILED STEPS

|               | Command or Action                              | Purpose                                |
|---------------|------------------------------------------------|----------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                  | Enters the chassis command mode.       |
| <b>Step 2</b> | Server /chassis # <b>show power-monitoring</b> | Displays the power monitoring details. |

**Example**

This example shows how to view power monitoring details:

```
Server # scope chassis
Server /chassis # show power-monitoring
Chassis :
Current (W) Minimum (W) Maximum (W) Average (W) Period

408 311 471 392 0days 9:5...
Server 1 :
Domain Current (W) Minimum (W) Maximum (W) Average (W) Period

Platform 68 61 178 68 0days 21:...
CPU 30 28 133 30 0days 21:...
Memory 1 0 1 1 0days 21:...
Server 2 :
Domain Current (W) Minimum (W) Maximum (W) Average (W) Period

Platform 97 62 200 100 1days 7:1:2
CPU 46 16 140 48 1days 7:1:2
Memory 1 0 1 1 1days 7:1:2
Server /chassis/server/pid-catalog #
```

## Viewing CUPS Utilization Details

## SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **show cups-utilization**

## DETAILED STEPS

|               | Command or Action                              | Purpose                                                          |
|---------------|------------------------------------------------|------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                  | Enters the chassis command mode.                                 |
| <b>Step 2</b> | Server /chassis # <b>show cups-utilization</b> | Displays the server utilization value on all the available CPUs. |

**Example**

This example shows how to view CUPS utilization details:

```

Server # scope chassis
Server /chassis # show cups-utilization
Server 1 :

CPU Utilization (%) Memory Utilization (%) I/O Utilization (%) Overall Utilization (%)

0 0 0 0
Server 2 :

CPU Utilization (%) Memory Utilization (%) I/O Utilization (%) Overall Utilization (%)

7 0 0 8

```

## Resetting the Server



**Important** If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

### Before you begin

You must log in with user or admin privileges to perform this task.

### SUMMARY STEPS

1. Server# **scope chassis**
2. Serve /chassis # **scope server 1**
3. Server /chassis/server # **power hard-reset**
4. At the prompt, enter **y** to confirm.

### DETAILED STEPS

|               | Command or Action                                | Purpose                                                                                             |
|---------------|--------------------------------------------------|-----------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                     | Enters the chassis command mode.                                                                    |
| <b>Step 2</b> | Server /chassis # <b>scope server 1</b>          | Enters the server command mode.                                                                     |
| <b>Step 3</b> | Server /chassis/server # <b>power hard-reset</b> | Reset the server, this is equivalent to pressing the reset button on the front panel or IPMI reset. |
| <b>Step 4</b> | At the prompt, enter <b>y</b> to confirm.        | Reset the server, this is equivalent to pressing the reset button on the front panel or IPMI reset. |

### Example

This example shows how to power hard reset the server:

```

Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power hard-reset
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

```

```

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID

1 Off FCH1848794D UCS S3260 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#

```

## Shutting Down the Server




---

**Important** If any firmware or BIOS updates are in progress, do not change the server power until those tasks are complete.

---

### Before you begin

You must log in with user or admin privileges to perform this task.

### SUMMARY STEPS

1. Server# **scope chassis**
2. Serve /chassis # **scope server 1**
3. Server /chassis/server # **power shutdown**
4. At the prompt, enter **y** to confirm.

### DETAILED STEPS

|               | Command or Action                              | Purpose                                           |
|---------------|------------------------------------------------|---------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                   | Enters the chassis command mode.                  |
| <b>Step 2</b> | Serve /chassis # <b>scope server 1</b>         | Enters the server command mode.                   |
| <b>Step 3</b> | Server /chassis/server # <b>power shutdown</b> | Shuts down the host OS and powers off the server. |
| <b>Step 4</b> | At the prompt, enter <b>y</b> to confirm.      | Shuts down the host OS and powers off the server. |

### Example

This example shows how to shutdown the server:

```

Server# scope chassis
Server# /chassis scope server 1
Server /chassis/server # power shutdown
This operation will change the server's power state.
Do you want to continue with power control for Server 1 ?[y|N] y

Server /chassis/server # show
Server ID Power Serial Number Product Name PID UUID

```

```

1 Off FCH1848794D UCS S3260 UCSC-C3X60-SVRNB
60974271-A514-484C-BAE3-A5EE4FD16E06

Server /chassis/server#

```

## Configuring DIMM Black Listing

### DIMM Block Listing

In Cisco IMC, the state of the Dual In-line Memory Module (DIMM) is based on SEL event records. A DIMM is marked bad if the BIOS encounters a non-correctable memory error or correctable memory error with 16000 error counts during memory test execution during BIOS post. If a DIMM is marked bad, it is considered a non-functional device.

If you enable DIMM blocklisting, Cisco IMC monitors the memory test execution messages and blocklists any DIMM that encounters memory errors at any given point of time in the DIMM SPD data. This allows the host to map out those DIMMs.

DIMMs are mapped out or blocklisted only when Uncorrectable errors occur. When a DIMM gets blocklisted, other DIMMs in the same channel are ignored or disabled, which means that the DIMM is no longer considered bad.



**Note** DIMMs do not get mapped out or blocklisted for 16000 Correctable errors.

### Enabling DIMM Black Listing

#### Before you begin

You must be logged in as an administrator.

#### SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server # **scope dimm-blacklisting** /
3. Server /server/dimm-blacklisting # **set enabled** {yes | no}
4. Server /server/dimm-blacklisting\* # **commit**

#### DETAILED STEPS

|               | Command or Action                                                | Purpose                                      |
|---------------|------------------------------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}                             | Enters server command mode of server 1 or 2. |
| <b>Step 2</b> | Server /server # <b>scope dimm-blacklisting</b> /                | Enters the DIMM blacklisting mode.           |
| <b>Step 3</b> | Server /server/dimm-blacklisting # <b>set enabled</b> {yes   no} | Enables or disables DIMM blacklisting.       |

|               | Command or Action                                 | Purpose                                              |
|---------------|---------------------------------------------------|------------------------------------------------------|
| <b>Step 4</b> | Server /server/dimm-blacklisting* # <b>commit</b> | Commits the transaction to the system configuration. |

### Example

The following example shows how to enable DIMM blacklisting:

```
Server # scope server 1
Server /server # scope dimm-blacklisting
Server /server/dimm-blacklisting # set enabled yes
Server /server/dimm-blacklisting* # commit
Server /server/dimm-blacklisting #
Server /server/dimm-blacklisting # show detail

DIMM Blacklisting:
 Enabled: yes
Server /server/dimm-blacklisting #
```

## Configuring BIOS Settings

### Viewing BIOS Status

#### SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /sever # **scope bios**
3. Server /sever/bios # **show detail**

#### DETAILED STEPS

|               | Command or Action                       | Purpose                                      |
|---------------|-----------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}    | Enters server command mode of server 1 or 2. |
| <b>Step 2</b> | Server /sever # <b>scope bios</b>       | Enters the BIOS command mode.                |
| <b>Step 3</b> | Server /sever/bios # <b>show detail</b> | Displays details of the BIOS status.         |

The BIOS status information contains the following fields:

| Name                   | Description                                                                         |
|------------------------|-------------------------------------------------------------------------------------|
| BIOS Version           | The version string of the running BIOS.                                             |
| Backup BIOS Version    | The backup version string of the BIOS.                                              |
| Boot Order             | The legacy boot order of bootable target types that the server will attempt to use. |
| Boot Override Priority | This can be None, or HV.                                                            |

| Name                              | Description                                                   |
|-----------------------------------|---------------------------------------------------------------|
| FW Update/Recovery Status         | The status of any pending firmware update or recovery action. |
| UEFI Secure Boot                  | Enables or Disables UEFI secure boot.                         |
| Configured Boot Mode              | The boot mode in which h BIOS will try to boot the devices.   |
| Actual Boot Mode                  | The actual boot mode in which BIOS booted the devices.        |
| Last Configured Boot Order Source | The last configured boot order source by BIOS.                |

### Example

This example displays the BIOS status:

```
Server# scope server 1
Server /server # scope bios
Server /server/bios # show detail
Server /server/bios # show detail
BIOS:
 BIOS Version: server-name.2.0.7c.0.071620151216
 Backup BIOS Version: server-name.2.0.7c.0.071620151216
 Boot Order: (none)
 Boot Override Priority:
 FW Update/Recovery Status: None, OK
 UEFI Secure Boot: disabled
 Configured Boot Mode: Legacy
 Actual Boot Mode: Legacy
 Last Configured Boot Order Source: CIMC
Server /server/bios #
```

## Configuring Main BIOS Settings

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server # **scope bios**
3. Server /server /bios # **scope main**
4. Server /server /bios # **set TPMAdminCtrl** {Disbaled | Enabled}
5. Server /server /bios/main # **commit**

### DETAILED STEPS

|        | Command or Action                    | Purpose                                      |
|--------|--------------------------------------|----------------------------------------------|
| Step 1 | Server # <b>scope server</b> {1   2} | Enters server command mode of server 1 or 2. |

|               | Command or Action                                                   | Purpose                                                                                                                                                                         |
|---------------|---------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 2</b> | Server /server # <b>scope bios</b>                                  | Enters the BIOS command mode.                                                                                                                                                   |
| <b>Step 3</b> | Server /server /bios # <b>scope main</b>                            | Enters the main BIOS settings command mode.                                                                                                                                     |
| <b>Step 4</b> | Server /server /bios # <b>set TPMAdminCtrl {Disbaled   Enabled}</b> | Enables or disables TPM support.                                                                                                                                                |
| <b>Step 5</b> | Server /server /bios/main # <b>commit</b>                           | Commits the transaction to the system configuration.<br>Changes are applied on the next server reboot. If server power is on, you are prompted to choose whether to reboot now. |

### Example

This example configures the main BIOS parameter and commits the transaction:

```
Server /server # scope server 1
Server/server # scope bios
Server /server/bios # scope main
Server /server/bios/main # set TPMAdminCtrl Enabled
Server /server/bios/main *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N] n
Changes will be applied on next reboot.
Server /server/bios/main #
```

## Configuring Advanced BIOS Settings

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope server {1 | 2}**
2. Server /sever # **scope bios**
3. Server /sever/bios # **scope advanced**
4. Configure the BIOS settings.
5. Server /sever/bios/advanced # **commit**

### DETAILED STEPS

|               | Command or Action                          | Purpose                                         |
|---------------|--------------------------------------------|-------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server {1   2}</b>       | Enters server command mode of server 1 or 2.    |
| <b>Step 2</b> | Server /sever # <b>scope bios</b>          | Enters the BIOS command mode.                   |
| <b>Step 3</b> | Server /sever/bios # <b>scope advanced</b> | Enters the advanced BIOS settings command mode. |



|        | Command or Action                           | Purpose                                                                                                                                                                         |
|--------|---------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 4 | Configure the BIOS settings.                | <a href="#">BIOS Parameters by Server Model, on page 387</a>                                                                                                                    |
| Step 5 | Server /sever/bios/advanced # <b>commit</b> | Commits the transaction to the system configuration.<br>Changes are applied on the next server reboot. If server power is on, you are prompted to choose whether to reboot now. |

### Example

This example enables all the USB drives and commits the transaction:

```
Server# scope server 1
Server/sever # scope bios
Server /sever/bios # scope advanced
Server /sever/bios/advanced # set AllUsbDevices Enabled
Server /sever/bios/advanced *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N] n
Changes will be applied on next reboot.
Server /sever/bios/advanced #
```

## Configuring Server Management BIOS Settings

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope server {1 | 2}**
2. Server /sever # **scope bios**
3. Server /sever/bios # **scope server-management**
4. Configure the BIOS settings.
5. Server /sever/bios/server-management # **commit**

### DETAILED STEPS

|        | Command or Action                                    | Purpose                                                      |
|--------|------------------------------------------------------|--------------------------------------------------------------|
| Step 1 | Server # <b>scope server {1   2}</b>                 | Enters server command mode of server 1 or 2.                 |
| Step 2 | Server /sever # <b>scope bios</b>                    | Enters the BIOS command mode.                                |
| Step 3 | Server /sever/bios # <b>scope server-management</b>  | Enters the server management BIOS settings command mode.     |
| Step 4 | Configure the BIOS settings.                         | <a href="#">BIOS Parameters by Server Model, on page 387</a> |
| Step 5 | Server /sever/bios/server-management # <b>commit</b> | Commits the transaction to the system configuration.         |

|  | Command or Action | Purpose                                                                                                                 |
|--|-------------------|-------------------------------------------------------------------------------------------------------------------------|
|  |                   | Changes are applied on the next server reboot. If server power is on, you are prompted to choose whether to reboot now. |

### Example

This example enables the OS watchdog timer and commits the transaction:

```
Server# scope bios
Server /sever # scope bios
Server /sever/bios # scope server-management
Server /sever/bios/server-management # set OSBootWatchdogTimer Enabled
Server /sever/bios/server-management *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N] n
Changes will be applied on next reboot.
Server /sever/bios/server-management #
```

## Restoring BIOS Defaults

### Before you begin

You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope server {1 | 2}**
2. Server /sever # **scope bios**
3. Server /sever/bios # **bios-setup-default**

### DETAILED STEPS

|               | Command or Action                              | Purpose                                                          |
|---------------|------------------------------------------------|------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server {1   2}</b>           | Enters server command mode of server 1 or 2.                     |
| <b>Step 2</b> | Server /sever # <b>scope bios</b>              | Enters the BIOS command mode.                                    |
| <b>Step 3</b> | Server /sever/bios # <b>bios-setup-default</b> | Restores BIOS default settings. This command initiates a reboot. |

### Example

This example restores BIOS default settings:

```
Server# scope bios
Server/sever # scope bios
Server /sever/bios # bios-setup-default
This operation will reset the BIOS set-up tokens to factory defaults.
All your configuration will be lost.
```

```
Changes to BIOS set-up parameters will initiate a reboot.
Continue?[y|N]y
```

## Entering BIOS Setup

### Before you begin

- The server must be powered on.
- You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /sever # **scope bios**
3. Server /sever/bios # **enter-bios-setup**

### DETAILED STEPS

|               | Command or Action                            | Purpose                                      |
|---------------|----------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}         | Enters server command mode of server 1 or 2. |
| <b>Step 2</b> | Server /sever # <b>scope bios</b>            | Enters the BIOS command mode.                |
| <b>Step 3</b> | Server /sever/bios # <b>enter-bios-setup</b> | Enters BIOS setup on reboot.                 |

### Example

This example enables you to enter BIOS setup:

```
Server# scope server 1
Server /sever # scope bios
Server /sever/bios # enter-bios-setup
This operation will enable Enter BIOS Setup option.
Host must be rebooted for this option to be enabled.
Continue?[y|N]y
```

## Restoring BIOS Manufacturing Custom Defaults

In instances where the components of the BIOS no longer function as desired, you can restore the BIOS set up tokens to the manufacturing default values.

### Before you begin

- You must log in with admin privileges to perform this task.
- The server must be powered off.

## SUMMARY STEPS

1. Server # **scope server {1 | 2}**
2. Server /sever # **scope bios**
3. Server /sever/bios # **restore-mfg-defaults**

## DETAILED STEPS

|               | Command or Action                                | Purpose                                                         |
|---------------|--------------------------------------------------|-----------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server {1   2}</b>             | Enters server command mode of server 1 or 2.                    |
| <b>Step 2</b> | Server /sever # <b>scope bios</b>                | Enters the BIOS command mode.                                   |
| <b>Step 3</b> | Server /sever/bios # <b>restore-mfg-defaults</b> | Restores the set up tokens to the manufacturing default values. |

### Example

This example shows how to restore the BIOS set up tokens to the manufacturing default values:

```
Server # scope bios
Server /sever/bios # restore-mfg-defaults
This operation will reset the BIOS set-up tokens to manufacturing defaults.
The system will be powered on.
Continue? [y|n] y
Server /sever/bios #
```

## BIOS Profiles

On the Cisco UCS server, default token files are available for every S3260 server platform, and you can configure the value of these tokens using the Graphic User Interface (GUI), CLI interface, and the XML API interface. To optimize server performance, these token values must be configured in a specific combination.

Configuring a BIOS profile helps you to utilize pre-configured token files with the right combination of the token values. Some of the pre-configured profiles that are available are virtualization, high-performance, low power, and so on. You can download the various options of these pre-configured token files from the Cisco website and apply it on the servers through the BMC.

You can edit the downloaded profile to change the value of the tokens or add new tokens. This allows you to customize the profile to your requirements without having to wait for turnaround time.

## Activating a BIOS Profile

### Before you begin

You must log in with user or admin privileges to perform this task.

## SUMMARY STEPS

1. Server# **scope bios**
2. Server# /bios **scope bios-profile**

3. Server# /bios/bios-profile **activate** *virtualization*
4. You are prompted to reboot the system to apply the changes to the BIOS set-up parameters. Enter **y**.

#### DETAILED STEPS

|        | Command or Action                                                                                          | Purpose                                                              |
|--------|------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------|
| Step 1 | Server# <b>scope bios</b>                                                                                  | Enters the BIOS command mode.                                        |
| Step 2 | Server# /bios <b>scope bios-profile</b>                                                                    | Enters the BIOS profile command mode.                                |
| Step 3 | Server# /bios/bios-profile <b>activate</b> <i>virtualization</i>                                           | You are prompted to back up the BIOS configuration. Enter <b>y</b> . |
| Step 4 | You are prompted to reboot the system to apply the changes to the BIOS set-up parameters. Enter <b>y</b> . | Initiates the system reboot.                                         |

#### Example

This example activates the specified BIOS profile:

```
Server # scope bios
Server /bios # scope bios-profile
Server /bios/bios-profile # activate virtualization
It is recommended to take a backup before activating a profile.
Do you want to take backup of BIOS configuration?[y/n] y
backup-bios-profile succeeded.
bios profile "virtualization" deleted
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N]y
A system reboot has been initiated.
Server /bios/bios-profile #
```

## Taking a Back-Up of a BIOS Profile

#### Before you begin

You must log in with user or admin privileges to perform this task.

#### SUMMARY STEPS

1. Server# **scope bios**
2. Server# /bios **scope bios-profile**
3. Server# /bios/bios-profile **backup**

#### DETAILED STEPS

|        | Command or Action                       | Purpose                               |
|--------|-----------------------------------------|---------------------------------------|
| Step 1 | Server# <b>scope bios</b>               | Enters the BIOS command mode.         |
| Step 2 | Server# /bios <b>scope bios-profile</b> | Enters the BIOS profile command mode. |

|               | Command or Action                        | Purpose                                                                |
|---------------|------------------------------------------|------------------------------------------------------------------------|
| <b>Step 3</b> | Server# /bios/bios-profile <b>backup</b> | Displays a message that the backup of the BIOS profile was successful. |

### Example

This example backs up a BIOS profile:

```
Server # scope bios
Server /bios # scope bios-profile
Server /bios/bios-profile # backup
backup-bios-profile succeeded.
Server /bios #
```

## Deleting a BIOS Profile

### Before you begin

You must log in with user or admin privileges to perform this task.

### SUMMARY STEPS

1. Server# **scope bios**
2. Server# /bios **scope bios-profile**
3. Server# /bios/bios-profile **delete BIOS profile**

### DETAILED STEPS

|               | Command or Action                                     | Purpose                               |
|---------------|-------------------------------------------------------|---------------------------------------|
| <b>Step 1</b> | Server# <b>scope bios</b>                             | Enters the BIOS command mode.         |
| <b>Step 2</b> | Server# /bios <b>scope bios-profile</b>               | Enters the BIOS profile command mode. |
| <b>Step 3</b> | Server# /bios/bios-profile <b>delete BIOS profile</b> | Deletes the specified BIOS profile.   |

### Example

This example deletes the specified BIOS profile:

```
Server # scope bios
Server /bios # scope bios-profile
Server /bios/bios-profile # delete performance
Server /bios/bios-profile #
```

## Displaying BIOS Profiles

### SUMMARY STEPS

1. Server# **scope bios**

## 2. Server# /bios show bios-profile

### DETAILED STEPS

|        | Command or Action                      | Purpose                         |
|--------|----------------------------------------|---------------------------------|
| Step 1 | Server# <b>scope bios</b>              | Enters the BIOS command mode.   |
| Step 2 | Server# /bios <b>show bios-profile</b> | Displays all the BIOS profiles. |

### Example

This example displays all the BIOS profiles:

```
Server # scope bios
Server /bios # show bios-profile
ID Name Active

1 performance yes
2 virtualization no
3 none no
4 cisco_backup no
Server /bios #scope bios-profile
Server /bios #
```

## Displaying Information of a BIOS Profile

### SUMMARY STEPS

1. Server# **scope bios**
2. Server# /bios **scope bios-profile**
3. Server# /bios/bios-profile **info performance**

### DETAILED STEPS

|        | Command or Action                                  | Purpose                                                                                       |
|--------|----------------------------------------------------|-----------------------------------------------------------------------------------------------|
| Step 1 | Server# <b>scope bios</b>                          | Enters the BIOS command mode.                                                                 |
| Step 2 | Server# /bios <b>scope bios-profile</b>            | Displays all the BIOS profiles.                                                               |
| Step 3 | Server# /bios/bios-profile <b>info performance</b> | Displays information of the BIOS profile such as token name, profile value, and active value. |

### Example

This example displays information of the specified BIOS profile:

```
Server # scope bios
Server /bios # scope bios-profile
Server /bios/bios-profile # info performance

TOKEN NAME PROFILE VALUE ACTUAL VALUE
```

```

=====
TPMAdminCtrl Enabled Enabled
ASPMsupport Disabled Disabled
Server /bios/bios-profile #

```

## Displaying details of the BIOS Profile

### SUMMARY STEPS

1. Server# **scope bios**
2. Server# /bios **scope bios-profile**
3. Server# /bios/bios-profile **show detail**

### DETAILED STEPS

|               | Command or Action                             | Purpose                               |
|---------------|-----------------------------------------------|---------------------------------------|
| <b>Step 1</b> | Server# <b>scope bios</b>                     | Enters the BIOS command mode.         |
| <b>Step 2</b> | Server# /bios <b>scope bios-profile</b>       | Enters the BIOS profile command mode. |
| <b>Step 3</b> | Server# /bios/bios-profile <b>show detail</b> | Displays the details of BIOS profile. |

### Example

This example displays the details of the BIOS profile:

```

Server # scope bios
Server /bios # scope bios-profile
Server /bios/bios-profile # show detail
Active Profile: Virtualization
Install Status: bios profile install done
Server /bios/bios-profile #

```

## Viewing Product ID (PID) Catalog Details

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis/server # **show cpu-pid**
4. Server /chassis/server # **show dimm-pid**
5. Server /chassis/server # **show pciadapter-pid**
6. Server /chassis/server # **show hdd-pid**

### DETAILED STEPS

|               | Command or Action             | Purpose                      |
|---------------|-------------------------------|------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b> | Enters chassis command mode. |



|               | Command or Action                                   | Purpose                                      |
|---------------|-----------------------------------------------------|----------------------------------------------|
| <b>Step 2</b> | Server /chassis # <b>scope server {1   2}</b>       | Enters server command mode of server 1 or 2. |
| <b>Step 3</b> | Server /chassis/server # <b>show cpu-pid</b>        | Displays the CPU PID details.                |
| <b>Step 4</b> | Server /chassis/server # <b>show dimm-pid</b>       | Displays the memory PID details.             |
| <b>Step 5</b> | Server /chassis/server # <b>show pciadapter-pid</b> | Displays the PCI adapters PID details.       |
| <b>Step 6</b> | Server /chassis/server # <b>show hdd-pid</b>        | Displays the HDD PID details.                |

### Example

This example shows how to create view PID details

```

Server # scope chassis
Server /chassis # scope server 1
Viewing CPU PID details
Server /chassis/server # show cpu-pid
Socket Product ID Model

CPU1 UCS-CPU-E52660B Intel(R) Xeon(R) CPU E5-2660 v2 @ 2.2...
CPU2 UCS-CPU-E52660B Intel(R) Xeon(R) CPU E5-2660 v2 @ 2.2...
Viewing memory PID details
Server /chassis/server # show dimm-pid
Name Product ID Vendor ID Capacity Speed

DIMM_A1 UNKNOWN NA Failed NA
DIMM_A2 UNKNOWN NA Ignore... NA
DIMM_B1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_B2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_C1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_C2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_D1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_D2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_E1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_E2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_F1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_F2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_G1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_G2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_H1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_H2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
Viewing PCI adapters PID details
Server /chassis/server # show pciadapter-pid
Slot Product ID Vendor ID Device ID SubVendor ID SubDevice ID

1 UCSC-MLOM-CSC-02 0x1137 0x0042 0x1137 0x012e
Viewing HDD PID details
Server /chassis/server # show hdd-pid
Disk Controller Product ID Vendor Model

1 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
2 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
3 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
4 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
5 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
6 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
7 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014

```

```

8 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
9 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
10 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
11 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
12 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
13 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
14 SBMezz1 UCSC-C3X60-HD6TB SEAGATE ST6000NM0014
201 SBMezz1 UCSC-C3X60-12SSD ATA INTEL SSD...
202 SBMezz1 UCSC-C3X60-12SSD ATA INTEL SSD...

```

```
Server /chassis/server #
```

## Uploading and Activating PID Catalog



**Caution** BMC reboots automatically once a PID catalog is activated.

You must reboot the server after activating a PID catalog.

### Before you begin

You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope pid-catalog**
3. Server /chassis/pid-catalog # **upload-pid-catalog** *remote-protocol IP address PID Catalog file*
4. (Optional) Server /chassis/pid-catalog # **show detail**
5. Server /chassis/pid-catalog # **exit**
6. Server /chassis # **scope server** {1 | 2}
7. Server /chassis/server # **scope pid-catalog**
8. Server /chassis/server/pid-catalog # **activate**
9. (Optional) Server /chassis/server/pid-catalog # **show detail**

### DETAILED STEPS

|               | Command or Action                                                                                             | Purpose                                                                                                                                                                               |
|---------------|---------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                                                                 | Enters the chassis command mode.                                                                                                                                                      |
| <b>Step 2</b> | Server /chassis # <b>scope pid-catalog</b>                                                                    | Enters the server PID catalog command mode.                                                                                                                                           |
| <b>Step 3</b> | Server /chassis/pid-catalog # <b>upload-pid-catalog</b><br><i>remote-protocol IP address PID Catalog file</i> | Specifies the protocol to connect to the remote server. It can be one of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> </ul> |

|               | Command or Action                                                  | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|---------------|--------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                                    | <ul style="list-style-type: none"> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p>Initiates the upload of the PID catalog.</p> |
| <b>Step 4</b> | (Optional) Server /chassis/pid-catalog # <b>show detail</b>        | Displays the status of the upload.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Step 5</b> | Server /chassis/pid-catalog # <b>exit</b>                          | Returns to the chassis command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Step 6</b> | Server /chassis # <b>scope server {1   2}</b>                      | Enters server command mode of server 1 or 2.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Step 7</b> | Server /chassis/server # <b>scope pid-catalog</b>                  | Enters server PID catalog command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Step 8</b> | Server /chassis/server/pid-catalog # <b>activate</b>               | Activates the uploaded PID catalog.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Step 9</b> | (Optional) Server /chassis/server/pid-catalog # <b>show detail</b> | Displays the status of the activation.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |

### Example

This example shows how to upload and activate PID catalog:

```

Server # scope chassis
Server /chassis # scope pid-catalog
Uploading PID catalog
Server /chassis/pid-catalog # upload-pid-catalog tftp 10.10.10.10
pid-ctlg-2_0_12_78_01.tar.gz
upload-pid-catalog initialized.
Please check the status using "show detail".
Server /chassis/pid-catalog # show detail
Upload Status: Upload Successful
Activating the uploaded PID catalog
Server /chassis/pid-catalog # exit
Server /chassis # scope server 2
Server /chassis/server # scope pid-catalog
Server /chassis/server/pid-catalog # activate
Successfully activated PID catalog
Server /chassis/server/pid-catalog # show detail

```

```

Upload Status:
Activation Status: Activation Successful
Current Activated Version: 2.0(12.78).01
Server /chassis/server/pid-catalog #

```

## Deleting PID Catalog



**Caution** BMC reboots automatically once a PID catalog is deleted.

You must reboot the server after deleting a PID catalog.

### Before you begin

You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis/server # **scope pid-catalog**
4. Server /chassis/server/pid-catalog # **delete**
5. (Optional) Server /chassis/server/pid-catalog # **show detail**

### DETAILED STEPS

|               | Command or Action                                                  | Purpose                                                                                                                                                                      |
|---------------|--------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                      | Enters the chassis command mode.                                                                                                                                             |
| <b>Step 2</b> | Server /chassis # <b>scope server {1   2}</b>                      | Enters server command mode of server 1 or 2.                                                                                                                                 |
| <b>Step 3</b> | Server /chassis/server # <b>scope pid-catalog</b>                  | Enters server PID catalog command mode.                                                                                                                                      |
| <b>Step 4</b> | Server /chassis/server/pid-catalog # <b>delete</b>                 | Enter y at the confirmation prompt to delete the uploaded PID catalog.<br><br><b>Note</b> You can delete a PID catalog only if it has been previously updated and activated. |
| <b>Step 5</b> | (Optional) Server /chassis/server/pid-catalog # <b>show detail</b> | Displays the PID catalog status.                                                                                                                                             |

### Example

This example shows how to upload and activate PID catalog:

```

Server # scope chassis
Server /chassis # scope server 2
Server /chassis/server # scope pid-catalog

```

```
Server /chassis/server/pid-catalog # delete
CIMC will be automatically rebooted after successful deletion of the uploaded catalog file.
Once this is complete, a host reboot will be required for the catalog changes to be reflected
in
the BIOS and host Operating System Continue?[y|N]y
Server /chassis/server/pid-catalog # show detail
PID Catalog:
 Upload Status: N/A
 Activation Status: N/A
 Current Activated Version: 4.1(0.41)
Server /chassis/server/pid-catalog #
```

# Persistent Memory Module

## Persistent Memory Modules

Cisco UCS S-Series Release 4.0(4) introduces support for the Intel® Optane™ Data Center persistent memory modules on the UCS M5 servers that are based on the Second Generation Intel® Xeon® Scalable processors. These persistent memory modules can be used only with the Second Generation Intel® Xeon® Scalable processors.

Persistent memory modules are non-volatile memory modules that bring together the low latency of memory and the persistence of storage. Data stored in persistent memory modules can be accessed quickly compared to other storage devices, and is retained across power cycles.

For detailed information about configuring persistent memory modules, see the [Cisco UCS: Configuring and Managing Intel® Optane™ Data Center Persistent Memory Modules](#) Guide.





## CHAPTER 5

# Viewing Server Properties

This chapter includes the following sections:

- [Viewing Server Properties](#), on page 83
- [Viewing CMC Properties](#), on page 84
- [Viewing Server CPU Details](#), on page 84
- [Viewing Memory Properties](#), on page 85
- [Viewing PCI Adapter Properties for a Server](#), on page 87
- [Viewing HDD Details for a Server](#), on page 88
- [Viewing Storage Adapter Properties for a Server](#), on page 89
- [Viewing TPM Properties](#), on page 89

## Viewing Server Properties

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis /server # **show detail**

### DETAILED STEPS

|               | Command or Action                             | Purpose                                      |
|---------------|-----------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                 | Enters chassis command mode.                 |
| <b>Step 2</b> | Server /chassis # <b>scope server {1   2}</b> | Enters server command mode of server 1 or 2. |
| <b>Step 3</b> | Server /chassis /server # <b>show detail</b>  | Displays server properties.                  |

### Example

This example displays server properties:

```
Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show
```

```

Server ID Power Serial Number Product Name PID UUID

2 on FCH183978RD UCS S3260 UCSC-C3X60-SVRNB
207BD0D4-C589-40C1-A73E-EF6E7F773198

Server /chassis /Server #show detail
Server ID 1:
 Power: off
 Serial Number: FCH1848794D
 Product Name: UCS S3260
 PID: UCSC-C3X60-SVRNB
 UUID: 60974271-A514-484C-BAE3-A5EE4FD16E06
Server /chassis /Server #

```

## Viewing CMC Properties

### SUMMARY STEPS

1. server # **scope chassis**
2. server /chassis # **scope cmc I|2**
3. server /chassis/cmc # **show detail**

### DETAILED STEPS

|               | Command or Action                        | Purpose                                                  |
|---------------|------------------------------------------|----------------------------------------------------------|
| <b>Step 1</b> | server # <b>scope chassis</b>            | Enters chassis command mode.                             |
| <b>Step 2</b> | server /chassis # <b>scope cmc I 2</b>   | Enters CMC on the chosen SIOC controller command mode.   |
| <b>Step 3</b> | server /chassis/cmc # <b>show detail</b> | Displays the CMC details for the chosen SIOC controller. |

This example shows how to view the CMC details:

## Viewing Server CPU Details

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis /server # **show cpu**
4. Server# **show cpu-pid**



## DETAILED STEPS

|        | Command or Action                             | Purpose                                      |
|--------|-----------------------------------------------|----------------------------------------------|
| Step 1 | Server # <b>scope chassis</b>                 | Enters chassis command mode.                 |
| Step 2 | Server /chassis # <b>scope server {1   2}</b> | Enters server command mode of server 1 or 2. |
| Step 3 | Server /chassis /server # <b>show cpu</b>     | Displays CPU details for the server.         |
| Step 4 | Server# <b>show cpu-pid</b>                   | Displays the CPU product IDs .               |

## Example

This example displays the CPU details for the server:

```

Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show cpu
Name Cores Version

CPU1 6 Intel(R) Xeon(R) CPU E5-2620 v2 @ 2.10GHz
CPU2 6 Intel(R) Xeon(R) CPU E5-2620 v2 @ 2.10GHz

Server /chassis /Server #show cpu-pid
Socket Product ID Model

CPU1 UCS-CPU-E52620B Intel(R) Xeon(R) CPU E5-2620 v2 @ 2.1...
CPU2 UCS-CPU-E52620B Intel(R) Xeon(R) CPU E5-2620 v2 @ 2.1...

Server /chassis /Server #

```

## Viewing Memory Properties

## SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis /server # **show dimm**
4. Server# **show dimm-pid**
5. Server# **show dimm-summary**

## DETAILED STEPS

|        | Command or Action                             | Purpose                                      |
|--------|-----------------------------------------------|----------------------------------------------|
| Step 1 | Server # <b>scope chassis</b>                 | Enters chassis command mode.                 |
| Step 2 | Server /chassis # <b>scope server {1   2}</b> | Enters server command mode of server 1 or 2. |
| Step 3 | Server /chassis /server # <b>show dimm</b>    | Displays DIMM details for the server.        |
| Step 4 | Server# <b>show dimm-pid</b>                  | Displays the DIMM product IDs.               |

|               | Command or Action                | Purpose                                 |
|---------------|----------------------------------|-----------------------------------------|
| <b>Step 5</b> | Server# <b>show dimm-summary</b> | Displays the DIMM summary information . |

### Example

This example displays the DIMM details for the server.:

```

Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show dimm

Name Capacity Channel Speed (MHz) Channel Type

DIMM_A1 16384 MB 1866 DDR3
DIMM_A2 16384 MB 1866 DDR3
DIMM_B1 16384 MB 1866 DDR3
DIMM_B2 16384 MB 1866 DDR3
DIMM_C1 16384 MB 1866 DDR3
DIMM_C2 16384 MB 1866 DDR3
DIMM_D1 16384 MB 1866 DDR3
DIMM_D2 16384 MB 1866 DDR3
DIMM_E1 16384 MB 1866 DDR3
DIMM_E2 16384 MB 1866 DDR3
DIMM_F1 16384 MB 1866 DDR3
DIMM_F2 16384 MB 1866 DDR3
DIMM_G1 16384 MB 1866 DDR3
DIMM_G2 16384 MB 1866 DDR3
DIMM_H1 16384 MB 1866 DDR3
DIMM_H2 16384 MB 1866 DDR3

Server /chassis /Server #show dimm-pid

Name Product ID Vendor ID Capacity Speed

DIMM_A1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_A2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_B1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_B2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_C1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_C2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_D1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_D2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_E1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_E2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_F1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_F2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_G1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_G2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_H1 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866
DIMM_H2 UCS-MR-1X162RZ-A 0xCE00 16384 MB 1866

Server /chassis /Server #show dimm-summary
DIMM Summary:
 Memory Speed: 1600 MHz
 Total Memory: 262144 MB
 Effective Memory: 262144 MB
 Redundant Memory: 0 MB
 Failed Memory: 0 MB
 Ignored Memory: 0 MB
 Number of Ignored Dimms: 0
 Number of Failed Dimms: 0
 Memory RAS possible: Independent Mirroring Lockstep
 Memory Configuration: Independent

```

```
Server /chassis /Server #
```

## Viewing PCI Adapter Properties for a Server

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis /server # **show pci-adapter**
4. Server# **show pciadapter-pid**

### DETAILED STEPS

|               | Command or Action                                 | Purpose                                      |
|---------------|---------------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                     | Enters chassis command mode.                 |
| <b>Step 2</b> | Server /chassis # <b>scope server {1   2}</b>     | Enters server command mode of server 1 or 2. |
| <b>Step 3</b> | Server /chassis /server # <b>show pci-adapter</b> | Displays PCI adapter details for the server. |
| <b>Step 4</b> | Server# <b>show pciadapter-pid</b>                | Displays the PCI adapter product IDs.        |

### Example

This example displays the PCI adapter details for the server.:

```
Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show pci-adapter
```

```
Slot Vendor ID Device ID SubVendor ID SubDevice ID Firmware Version Product Name

L 0x8086 0x1521 0x1137 0x00d5 0x80000E74... Intel(R) I350 1
Gbps N...
1 0x1cc7 0x0200 0x1cc7 0x0200 N/A Radian RMS-200
NVRAM card
MLOM 0x1137 0x0042 0x1137 0x0139 4.1 (3S1) Cisco UCS VIC
1227T MLOM
HBA 0x1000 0x005d 0x1137 0x00db 24.12.1-0107 Cisco 12G SAS
Modular ...
```

```
Option ROM Status
```

```

Loaded
Not-Loaded
Not-Loaded
Loaded
```

```
Server /chassis /Server #show pciadapter-pid
```

```

Slot Product ID Vendor ID Device ID SubVendor ID SubDevice ID

1 UNKNOWN 0x1137 0x0042 0x1137 0x0157
M UCSC-C3X60-RAID 0x1000 0x005d 0x1137 0x012d

```

```
Server /chassis /Server #
```

## Viewing HDD Details for a Server

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis /server # **show hdd-pid**

### DETAILED STEPS

|               | Command or Action                             | Purpose                                      |
|---------------|-----------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                 | Enters chassis command mode.                 |
| <b>Step 2</b> | Server /chassis # <b>scope server {1   2}</b> | Enters server command mode of server 1 or 2. |
| <b>Step 3</b> | Server /chassis /server # <b>show hdd-pid</b> | Displays HDD details for the server.         |

### Example

This example displays the HDD details for the server:

```

Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show hdd-pid
Disk Controller Product ID Vendor Model

1 SLOT-MEZZ UCS-HD4T7KS3-E TOSHIBA MG03SCA400
2 SLOT-MEZZ UCS-HD4T7KS3-E TOSHIBA MG03SCA400
3 SLOT-MEZZ UCS-HD4T7KS3-E TOSHIBA MG03SCA400
4 SLOT-MEZZ UCS-HD4T7KS3-E TOSHIBA MG03SCA400
5 SLOT-MEZZ UCS-HD4T7KS3-E TOSHIBA MG03SCA400
6 SLOT-MEZZ UCS-HD4T7KS3-E TOSHIBA MG03SCA400
7 SLOT-MEZZ UCS-HD4T7KS3-E TOSHIBA MG03SCA400
8 SLOT-MEZZ UCS-HD4T7KS3-E TOSHIBA MG03SCA400
9 SLOT-MEZZ UCS-HD4T7KS3-E TOSHIBA MG03SCA400
10 SLOT-MEZZ UCS-HD4T7KS3-E TOSHIBA MG03SCA400
11 SLOT-MEZZ UCS-HD4T7KS3-E TOSHIBA MG03SCA400
12 SLOT-MEZZ UCS-HD4T7KS3-E TOSHIBA MG03SCA400
13 SLOT-MEZZ UCS-HD4T7KS3-E TOSHIBA MG03SCA400
14 SLOT-MEZZ UCS-HD4T7KS3-E TOSHIBA MG03SCA400

Server /chassis /Server#

```

# Viewing Storage Adapter Properties for a Server

## SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis /server # **show storageadapter**

## DETAILED STEPS

|               | Command or Action                                    | Purpose                                          |
|---------------|------------------------------------------------------|--------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                        | Enters chassis command mode.                     |
| <b>Step 2</b> | Server /chassis # <b>scope server {1   2}</b>        | Enters server command mode of server 1 or 2.     |
| <b>Step 3</b> | Server /chassis /server # <b>show storageadapter</b> | Displays storage adapter details for the server. |

### Example

This example displays the storage adapter details for the server.:

```

Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show storageadapter
PCI Slot Health Controller Status ROC Temperature Product Name

SLOT-MEZZ Good Optimal 48 degrees C RAID controller for UCS S3260
S...

Serial Number Firmware Package Build Product ID D Battery Status Cache Memory Size

FCH184972F5 24.7.3-0006 LSI Logic Optimal 3534 MB

Boot Drive Boot Drive is PD

0 false
Server /chassis /Server #

```

# Viewing TPM Properties

## SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis/server # **show tpm-inventory**

## DETAILED STEPS

|               | Command or Action                                  | Purpose                                      |
|---------------|----------------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                      | Enters chassis command mode.                 |
| <b>Step 2</b> | Server /chassis # <b>scope server {1   2}</b>      | Enters server command mode of server 1 or 2. |
| <b>Step 3</b> | Server /chassis/server # <b>show tpm-inventory</b> | Displays TPM properties for the server.      |

**Example**

This example displays the TPM properties for the server:

```

Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show tpm-inventory
Version Presence Enabled-Status Active-Status Ownership Revision

NA empty unknown unknown unknown NA
Model Vendor Serial

Server chassis /Server#

```



# CHAPTER 6

## Viewing Sensors

This chapter includes the following sections:

- [Viewing Chassis Sensors, on page 91](#)
- [Viewing Server Sensors, on page 97](#)

### Viewing Chassis Sensors

### Viewing Power Supply Sensors

#### SUMMARY STEPS

1. Server# **scope sensor**
2. Server /sensor # **show psu**
3. Server /sensor # **show psu-redundancy**

#### DETAILED STEPS

|               | Command or Action                           | Purpose                                                        |
|---------------|---------------------------------------------|----------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope sensor</b>                 | Enters sensor command mode.                                    |
| <b>Step 2</b> | Server /sensor # <b>show psu</b>            | Displays power supply sensor statistics for the server.        |
| <b>Step 3</b> | Server /sensor # <b>show psu-redundancy</b> | Displays power supply redundancy sensor status for the server. |

#### Example

This example displays power supply sensor statistics:

```
Server# scope sensor
Server /sensor # show psu
Name Sensor Status Reading Units Min. Warning Max. Warning Min. Failure Max.
Failure


```

```

SU1_PIN Normal 102 Watts N/A 882 N/A
 1098
PSU2_PIN Normal 96 Watts N/A 882 N/A
 1098
PSU3_PIN Normal 102 Watts N/A 882 N/A
 1098
PSU4_PIN Normal 96 Watts N/A 882 N/A
 1098
PSU1_POUT Normal 78 Watts N/A 798 N/A
 996
PSU2_POUT Normal 78 Watts N/A 798 N/A
 996
PSU3_POUT Normal 84 Watts N/A 798 N/A
 996
PSU4_POUT Normal 84 Watts N/A 798 N/A
 996
POWER_USAGE Normal 406 Watts N/A N/A N/A
 2674
PSU1_DC_OK Normal good
PSU2_DC_OK Normal good
PSU3_DC_OK Normal good
PSU4_DC_OK Normal good
PSU1_AC_OK Normal good
PSU2_AC_OK Normal good
PSU3_AC_OK Normal good
PSU4_AC_OK Normal good
PSU1_STATUS Normal present
PSU2_STATUS Normal present
PSU3_STATUS Normal present
PSU4_STATUS Normal present

Server /sensor # show psu-redundancy
Name Reading Sensor Status

PS_RDNDNT_MODE full Normal

Server /sensor #

```

## Viewing Fan Sensors

### SUMMARY STEPS

1. Server# **scope sensor**
2. Server /sensor # **show fan [detail]**



## DETAILED STEPS

|        | Command or Action                         | Purpose                                        |
|--------|-------------------------------------------|------------------------------------------------|
| Step 1 | Server# <b>scope sensor</b>               | Enters sensor command mode.                    |
| Step 2 | Server /sensor # <b>show fan [detail]</b> | Displays fan sensor statistics for the server. |

## Example

This example displays fan sensor statistics:

```
Server# scope sensor
Server /sensor # show fan
Name Sensor Status Reading Units Min. Warning Max. Warning Min. Failure
Max. Failure

PSU1_FAN_SPEED Normal 5160 RPM 1118 N/A 946
N/A
PSU2_FAN_SPEED Normal 6106 RPM 1118 N/A 946
N/A
PSU3_FAN_SPEED Normal 5762 RPM 1118 N/A 946
N/A
PSU4_FAN_SPEED Normal 4988 RPM 1118 N/A 946
N/A
FAN1_SPEED Normal 6600 RPM 2040 N/A 1800
N/A
FAN2_SPEED Normal 6660 RPM 2040 N/A 1800
N/A
FAN3_SPEED Normal 6600 RPM 2040 N/A 1800
N/A
FAN4_SPEED Normal 6660 RPM 2040 N/A 1800
N/A
FAN5_SPEED Normal 6660 RPM 2040 N/A 1800
N/A
FAN6_SPEED Normal 6660 RPM 2040 N/A 1800
N/A
FAN7_SPEED Normal 6660 RPM 2040 N/A 1800
N/A
FAN8_SPEED Normal 6660 RPM 2040 N/A 1800
N/A
Server /sensor #
```

## Viewing Current Sensors

## SUMMARY STEPS

1. Server# **scope sensor**
2. Server /sensor # **show current**

## DETAILED STEPS

|        | Command or Action           | Purpose                     |
|--------|-----------------------------|-----------------------------|
| Step 1 | Server# <b>scope sensor</b> | Enters sensor command mode. |

|               | Command or Action                    | Purpose                             |
|---------------|--------------------------------------|-------------------------------------|
| <b>Step 2</b> | Server /sensor # <b>show current</b> | Displays current sensor statistics. |

### Example

This example displays current sensor statistics:

```
Server# scope sensor
Server /sensor # show current
Name Sensor Status Reading Units Min. Warning Max. Warning Min. Failure Max.
Failure

PSU1_IOUT Normal 6.00 AMP N/A 78.00 N/A
87.00
PSU2_IOUT Normal 6.00 AMP N/A 78.00 N/A
87.00
PSU3_IOUT Normal 7.00 AMP N/A 78.00 N/A
87.00
PSU4_IOUT Normal 7.00 AMP N/A 78.00 N/A
87.00

Server /sensor #
```

## Viewing Voltage Sensors

### SUMMARY STEPS

1. Server# **scope sensor**
2. Server /sensor # **show voltage**

### DETAILED STEPS

|               | Command or Action                    | Purpose                             |
|---------------|--------------------------------------|-------------------------------------|
| <b>Step 1</b> | Server# <b>scope sensor</b>          | Enters sensor command mode.         |
| <b>Step 2</b> | Server /sensor # <b>show voltage</b> | Displays voltage sensor statistics. |

### Example

This example displays voltage sensor statistics:

```
Server# scope sensor
Server /sensor # show voltage
Name Sensor Status Reading Units Min. Warning Max. Warning Min. Failure
Max. Failure

SIOC_P1V0 Normal 1.000 V N/A N/A 0.944
1.064
SIOC_P1V2 Normal 1.208 V N/A N/A 1.128
1.272
```

|                          |        |         |   |     |     |        |
|--------------------------|--------|---------|---|-----|-----|--------|
| SIOC_P1V5<br>1.590       | Normal | 1.500   | V | N/A | N/A | 1.410  |
| SIOC_P2V5<br>2.646       | Normal | 2.478   | V | N/A | N/A | 2.338  |
| SIOC_P3V3<br>3.500       | Normal | 3.320   | V | N/A | N/A | 3.100  |
| SIOC_P12V_STBY<br>12.720 | Normal | 12.060  | V | N/A | N/A | 11.280 |
| SIOC_P3V3_STBY<br>3.460  | Normal | 3.360   | V | N/A | N/A | 3.140  |
| PSU1_VIN<br>264.000      | Normal | 228.000 | V | N/A | N/A | N/A    |
| PSU2_VIN<br>264.000      | Normal | 228.000 | V | N/A | N/A | N/A    |
| PSU3_VIN<br>264.000      | Normal | 228.000 | V | N/A | N/A | N/A    |
| PSU4_VIN<br>264.000      | Normal | 228.000 | V | N/A | N/A | N/A    |
| P5V_1<br>5.640           | Normal | 5.010   | V | N/A | N/A | 4.500  |
| P5V_2<br>5.640           | Normal | 5.010   | V | N/A | N/A | 4.500  |
| P5V_3<br>5.640           | Normal | 5.010   | V | N/A | N/A | 4.500  |
| P5V_4<br>5.640           | Normal | 5.010   | V | N/A | N/A | 4.500  |
| P0V9_EXP1_VCORE<br>0.976 | Normal | 0.872   | V | N/A | N/A | 0.836  |
| P0V9_EXP2_VCORE<br>0.976 | Normal | 0.872   | V | N/A | N/A | 0.836  |
| P0V9_EXP1_AVD<br>0.976   | Normal | 0.888   | V | N/A | N/A | 0.836  |
| P0V9_EXP2_AVD<br>0.976   | Normal | 0.904   | V | N/A | N/A | 0.836  |
| PSU1_VOUT<br>12.600      | Normal | 12.000  | V | N/A | N/A | N/A    |
| PSU2_VOUT<br>12.600      | Normal | 12.000  | V | N/A | N/A | N/A    |
| PSU3_VOUT<br>12.600      | Normal | 12.000  | V | N/A | N/A | N/A    |
| PSU4_VOUT                | Normal | 12.000  | V | N/A | N/A | N/A    |

Server /sensor #

## Viewing Temperature Sensors

### SUMMARY STEPS

1. Server# **scope sensor**
2. Server /sensor # **show temperature**

### DETAILED STEPS

|               | Command or Action                        | Purpose                                 |
|---------------|------------------------------------------|-----------------------------------------|
| <b>Step 1</b> | Server# <b>scope sensor</b>              | Enters sensor command mode.             |
| <b>Step 2</b> | Server /sensor # <b>show temperature</b> | Displays temperature sensor statistics. |

**Example**

This example displays temperature sensor statistics:

```

Server# scope sensor
Server /sensor # show temperature
Name Sensor Status Reading Units Min. Warning Max. Warning Min. Failure
Max. Failure

SIOC1_BACK_TEMP Normal 37.0 C N/A 70.0 N/A
 80.0
SIOC1_FRONT_TEMP Normal 42.0 C N/A 70.0 N/A
 80.0
SIOC1_MID_TEMP Normal 41.0 C N/A 70.0 N/A
 80.0
SIOC1_VIC_TEMP Normal 44.0 C N/A 70.0 N/A
 80.0
SIOC2_VIC_TEMP Normal 44.0 C N/A 70.0 N/A
 80.0
MOBO_R_BOT_TEMP Normal 30.0 C N/A 70.0 N/A
 80.0
MOBO_L_BOT_TEMP Normal 31.0 C N/A 70.0 N/A
 80.0
MOBO_R_MID_TEMP Normal 25.0 C N/A 50.0 N/A
 55.0
MOBO_R_IN_TEMP Normal 24.0 C N/A 50.0 N/A
 55.0
MOBO_L_IN_TEMP Normal 26.0 C N/A 50.0 N/A
 55.0
MOBO_L_MID_TEMP Normal 26.0 C N/A 50.0 N/A
 55.0
MOBO_R_OUT_TEMP Normal 29.0 C N/A 47.0 N/A
 52.0
MOBO_L_OUT_TEMP Normal 29.0 C N/A 46.0 N/A
 51.0
PSU1_TEMP Normal 24.0 C N/A 55.0 N/A
 60.0
PSU2_TEMP Normal 27.0 C N/A 55.0 N/A
 60.0
PSU3_TEMP Normal 27.0 C N/A 55.0 N/A
 60.0
PSU4_TEMP Normal 25.0 C N/A 55.0 N/A
 60.0
SIOC1_CMC_TEMP Normal 51.0 C N/A 75.0 N/A
 85.0
MOBO_R_EXP_TEMP Normal 37.0 C N/A 80.0 N/A
 90.0
MOBO_L_EXP_TEMP Normal 40.0 C N/A 80.0 N/A
 90.0
SIOC2_BACK_TEMP Normal 36.0 C N/A 70.0 N/A
 80.0
SIOC2_FRONT_TEMP Normal 36.0 C N/A 70.0 N/A
 80.0
SIOC2_MID_TEMP Normal 36.0 C N/A 70.0 N/A
 80.0
SIOC2_CMC_TEMP Normal 36.0 C N/A 75.0 N/A
 85.0
Server /sensor #

```

## Viewing LED Sensor

### SUMMARY STEPS

1. Server# **scope sensor**
2. Server /sensor # **show led**

### DETAILED STEPS

|               | Command or Action                | Purpose                         |
|---------------|----------------------------------|---------------------------------|
| <b>Step 1</b> | Server# <b>scope sensor</b>      | Enters sensor command mode.     |
| <b>Step 2</b> | Server /sensor # <b>show led</b> | Displays LED sensor statistics. |

### Example

This example displays LED sensor statistics:

```
Server# scope sensor
Server /sensor # show led
LED Name LED State LED Color

LED_FAN12_FAULT OFF AMBER
LED_FAN34_FAULT OFF AMBER
LED_FAN56_FAULT OFF AMBER
LED_FAN78_FAULT OFF AMBER
CHS_FP_LED_ID OFF BLUE
LED_HLTH_STATUS ON GREEN
LED_PSU_STATUS ON GREEN
LED_TEMP_STATUS ON GREEN
LED_FAN_STATUS ON GREEN
SERVER1_FP_ID_LED OFF BLUE
SERVER2_FP_ID_LED OFF BLUE
OVERALL_DIMM_STATUS ON GREEN
Server /sensor #
```

## Viewing Server Sensors

## Viewing Storage Sensors

### SUMMARY STEPS

1. Server # **scope server {1 | 2}**
2. Server /server # **scope sensor**
3. Server /server /sensor # **show hdd**

## DETAILED STEPS

|               | Command or Action                        | Purpose                                      |
|---------------|------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}     | Enters server command mode of server 1 or 2. |
| <b>Step 2</b> | Server /server # <b>scope sensor</b>     | Enters sensor command.                       |
| <b>Step 3</b> | Server /server /sensor # <b>show hdd</b> | Displays the storage sensors for the server. |

**Example**

This example displays the storage sensors for the server:

```
Server# scope server 1
Server /server #scope sensor
Server /server /sensor #show hdd
Name Status

SSD1_PRS inserted
SSD2_PRS inserted

Server server /sensor #
```

## Viewing Current Sensors

## SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server # **scope sensor**
3. Server /server /sensor #**show current**

## DETAILED STEPS

|               | Command or Action                            | Purpose                                      |
|---------------|----------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}         | Enters server command mode of server 1 or 2. |
| <b>Step 2</b> | Server /server # <b>scope sensor</b>         | Enters sensor command.                       |
| <b>Step 3</b> | Server /server /sensor # <b>show current</b> | Displays the current sensors for the server. |

**Example**

This example displays the current sensors for the server:

```
Server# scope server 1
Server /server #scope sensor
Server /server /sensor #show current
Name Sensor Status Reading Units Min. Warning Max. Warning Min. Failure Max.
Failure

```

```
P12V_CUR_SENS Normal 5.84 AMP N/A N/A N/A
56.90
Server server /sensor #
```

## Viewing LED Sensors

### SUMMARY STEPS

1. Server # **scope server {1 | 2}**
2. Server /server # **scope sensor**
3. Server /server /sensor #**show led**

### DETAILED STEPS

|               | Command or Action                        | Purpose                                      |
|---------------|------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server {1   2}</b>     | Enters server command mode of server 1 or 2. |
| <b>Step 2</b> | Server /server # <b>scope sensor</b>     | Enters sensor command.                       |
| <b>Step 3</b> | Server /server /sensor # <b>show led</b> | Displays the LED sensors for the server.     |

### Example

This example displays the LED sensors for the server:

```
Server# scope server 1
Server /server #scope sensor
Server /server /sensor #show led
LED Name LED State LED Color

FP_ID_LED FAST BLINK BLUE
P1_DIMM_A1_LED OFF AMBER
P1_DIMM_A2_LED OFF AMBER
P1_DIMM_B1_LED OFF AMBER
P1_DIMM_B2_LED OFF AMBER
P1_DIMM_C1_LED OFF AMBER
P1_DIMM_C2_LED OFF AMBER
P1_DIMM_D1_LED OFF AMBER
P1_DIMM_D2_LED OFF AMBER
P2_DIMM_E1_LED OFF AMBER
P2_DIMM_E2_LED OFF AMBER
P2_DIMM_F1_LED OFF AMBER
P2_DIMM_F2_LED OFF AMBER
P2_DIMM_G1_LED OFF AMBER
P2_DIMM_G2_LED OFF AMBER
P2_DIMM_H1_LED OFF AMBER
P2_DIMM_H2_LED OFF AMBER
LED_HLTH_STATUS ON GREEN
LED_TEMP_STATUS ON GREEN
OVERALL_DIMM_STATUS ON GREEN

Server server /sensor #
```

# Viewing Temperature Sensors

## SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server # **scope sensor**
3. Server /server /sensor #**show temperature**

## DETAILED STEPS

|               | Command or Action                                | Purpose                                          |
|---------------|--------------------------------------------------|--------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}             | Enters server command mode of server 1 or 2.     |
| <b>Step 2</b> | Server /server # <b>scope sensor</b>             | Enters sensor command.                           |
| <b>Step 3</b> | Server /server /sensor # <b>show temperature</b> | Displays the temperature sensors for the server. |

### Example

This example displays the temperature sensors for the server:

```

Server# scope server 1
Server /server #scope sensor
Server /server /sensor #show temperature
Name Sensor Status Reading Units Min. Warning Max. Warning Min. Failure
Max. Failure

TEMP_SENS_FRONT Normal 24.0 C N/A 60.0 N/A
 70.0
TEMP_SENS_REAR Normal 25.0 C N/A 80.0 N/A
 85.0
P1_TEMP_SENS Normal 21.0 C N/A 74.0 N/A
 79.0
P2_TEMP_SENS Normal 23.5 C N/A 74.0 N/A
 79.0
DDR3_P1_A1_TEMP Normal 23.0 C N/A 65.0 N/A
 85.0
DDR3_P1_A2_TEMP Normal 23.0 C N/A 65.0 N/A
 85.0
DDR3_P1_B1_TEMP Normal 23.0 C N/A 65.0 N/A
 85.0
DDR3_P1_B2_TEMP Normal 23.0 C N/A 65.0 N/A
 85.0
DDR3_P1_C1_TEMP Normal 24.0 C N/A 65.0 N/A
 85.0
DDR3_P1_C2_TEMP Normal 24.0 C N/A 65.0 N/A
 85.0
DDR3_P1_D1_TEMP Normal 24.0 C N/A 65.0 N/A
 85.0
DDR3_P1_D2_TEMP Normal 23.0 C N/A 65.0 N/A
 85.0
DDR3_P2_E1_TEMP Normal 23.0 C N/A 65.0 N/A
 85.0
DDR3_P2_E2_TEMP Normal 23.0 C N/A 65.0 N/A
 85.0
DDR3_P2_F1_TEMP Normal 22.0 C N/A 65.0 N/A

```



85.0

Server server /sensor #

## Viewing Voltage Sensors

### SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server # **scope sensor**
3. Server /server /sensor #**show voltage**

### DETAILED STEPS

|               | Command or Action                            | Purpose                                      |
|---------------|----------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}         | Enters server command mode of server 1 or 2. |
| <b>Step 2</b> | Server /server # <b>scope sensor</b>         | Enters sensor command.                       |
| <b>Step 3</b> | Server /server /sensor # <b>show voltage</b> | Displays the voltage sensors for the server. |

### Example

This example displays the voltage sensors for the server:

```
Server# scope server 1
Server /server #scope sensor
Server /server /sensor #show voltage
Name Sensor Status Reading Units Min. Warning Max. Warning Min. Failure
Max. Failure

P3V_BAT_SCALED Normal 2.973 V N/A N/A 2.154
 3.418
P5V_STBY Normal 4.909 V N/A N/A 4.555
 5.452
P3V3_STBY Normal 3.302 V N/A N/A 3.018
 3.602
P1V1_SSB_STBY Normal 1.088 V N/A N/A 1.000
 1.205
P1V8_STBY Normal 1.784 V N/A N/A 1.627
 1.980
P1V0_STBY Normal 0.990 V N/A N/A 0.911
 1.088
P1V5_STBY Normal 1.490 V N/A N/A 1.372
 1.637
P0V75_STBY Normal 0.725 V N/A N/A 0.686
 0.823
P2V5_STBY Normal 2.484 V N/A N/A 2.279
 2.734
P12V Normal 11.977 V N/A N/A 11.210
 12.803
P5V Normal 5.031 V N/A N/A 4.680
 5.335
P3V3 Normal 3.276 V N/A N/A 3.089
```

## Viewing Voltage Sensors

|          |        |       |   |     |     |       |  |
|----------|--------|-------|---|-----|-----|-------|--|
| 3.526    |        |       |   |     |     |       |  |
| P1V5_SSB | Normal | 1.482 | V | N/A | N/A | 1.412 |  |
| 1.607    |        |       |   |     |     |       |  |
| P1V1_SSB | Normal | 1.084 | V | N/A | N/A | 1.037 |  |
| 1.178    |        |       |   |     |     |       |  |
| PVTT_P1  | Normal | 0.991 | V | N/A | N/A | 0.944 |  |
| 1.061    |        |       |   |     |     |       |  |
| PVTT_P2  | Normal | 0.975 | V | N/A | N/A | 0.944 |  |
| 1.061    |        |       |   |     |     |       |  |
| PVSA_P1  | Normal | 0.959 | V | N/A | N/A | 0.593 |  |
| 1.170    |        |       |   |     |     |       |  |

Server server /sensor #



## CHAPTER 7

# Managing Remote Presence

---

This chapter includes the following sections:

- [Managing the Virtual KVM, on page 103](#)
- [Configuring Virtual Media, on page 107](#)
- [Managing Serial over LAN, on page 112](#)

## Managing the Virtual KVM

### Virtual KVM Console

The vKVM console is an interface accessible from that emulates a direct keyboard, video, and mouse (vKVM) connection to the server. The vKVM console allows you to connect to the server from a remote location.

Here are a few major advantages of using Cisco KVM Console:

- The Cisco KVM console provides connection to KVM, SOL, and vMedia whereas the Avocent KVM provides connection only to KVM and vMedia.
- In the KVM Console, the vMedia connection is established at the KVM Launch Manager and is available for all users.
- The KVM console offers you an advanced character replacement options for the unsupported characters while pasting text from the guest to the host.
- The KVM console provides you an ability to store the vMedia mappings on CIMC.

Instead of using CD/DVD or floppy drives physically connected to the server, the vKVM console uses virtual media, which are actual disk drives or disk image files that are mapped to virtual CD/DVD or floppy drives. You can map any of the following to a virtual drive:

- CD/DVD or floppy drive on your computer
- Disk image files (ISO or IMG files) on your computer
- USB flash drive on your computer
- CD/DVD or floppy drive on the network
- Disk image files (ISO or IMG files) on the network

- USB flash drive on the network

You can use the vKVM console to install an OS on the server.



**Note** To configure the vKVM console successfully for the S3260 Storage Server, you need to configure IP addresses for the Cisco IMC, CMC, and BMC components. You can configure the IP addresses for these components using the CLI interface or Web UI. For the CLI, use the command **scope network**, or view the setting using **scope <chassis/server1/2><cmc/bmc><network>**.

To configure IP addresses for network components on the web interface, see the steps described in the section **Configuring Network-Related Settings**.



**Note** The vKVM Console is operated only through the GUI. To launch the vKVM Console, see the instructions in the *Cisco UCS C-Series Servers Integrated Management Controller GUI Configuration Guide*.

## Enabling the Virtual KVM

### Before you begin

You must log in as a user with admin privileges to enable the virtual KVM.

### SUMMARY STEPS

1. Server # **scope server {1 | 2}**
2. Server /server # **scope kvm**
3. Server /server/kvm # **set enabled yes**
4. Server /server/kvm # **commit**
5. Server /server/kvm # **show [detail]**

### DETAILED STEPS

|               | Command or Action                           | Purpose                                              |
|---------------|---------------------------------------------|------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server {1   2}</b>        | Enters server command mode of server 1 or 2.         |
| <b>Step 2</b> | Server /server # <b>scope kvm</b>           | Enters KVM command mode.                             |
| <b>Step 3</b> | Server /server/kvm # <b>set enabled yes</b> | Enables the virtual KVM.                             |
| <b>Step 4</b> | Server /server/kvm # <b>commit</b>          | Commits the transaction to the system configuration. |
| <b>Step 5</b> | Server /server/kvm # <b>show [detail]</b>   | (Optional) Displays the virtual KVM configuration.   |

### Example

This example enables the virtual KVM:

```

Server# scope server 1
Server /server # scope kvm
Server /server/kvm # set enabled yes
Server /server/kvm *# commit
Server /server/kvm # show detail
KVM Settings:
 Encryption Enabled: yes
 Max Sessions: 4
 Local Video: yes
 Active Sessions: 1
 Enabled: yes
 KVM Port: 2068

Server /server/kvm #

```

## Disabling the Virtual KVM

### Before you begin

You must log in as a user with admin privileges to enable the virtual KVM.

### SUMMARY STEPS

1. Server # **scope server {1 | 2}**
2. Server /server # **scope kvm**
3. Server /server /kvm # **set enabled no**
4. Server /server/kvm # **commit**
5. Server /server/kvm # **show [detail]**

### DETAILED STEPS

|               | Command or Action                           | Purpose                                                                                                                                                                                         |
|---------------|---------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server {1   2}</b>        | Enters server command mode of server 1 or 2.                                                                                                                                                    |
| <b>Step 2</b> | Server /server # <b>scope kvm</b>           | Enters KVM command mode.                                                                                                                                                                        |
| <b>Step 3</b> | Server /server /kvm # <b>set enabled no</b> | Disables the virtual KVM.<br><br><b>Note</b> Disabling the virtual KVM disables access to the virtual media feature, but does not detach the virtual media devices if virtual media is enabled. |
| <b>Step 4</b> | Server /server/kvm # <b>commit</b>          | Commits the transaction to the system configuration.                                                                                                                                            |
| <b>Step 5</b> | Server /server/kvm # <b>show [detail]</b>   | (Optional) Displays the virtual KVM configuration.                                                                                                                                              |

### Example

This example enables the virtual KVM:

```

Server# scope server 1
Server /server # scope kvm
Server /server/kvm # set enabled no
Server /server/kvm *# commit
Server /server/kvm # show detail
KVM Settings:
 Encryption Enabled: yes
 Max Sessions: 4
 Local Video: yes
 Active Sessions: 0
 Enabled: no
 KVM Port: 2068

Server /server/kvm #

```

## Configuring the Virtual KVM

### Before you begin

You must log in as a user with admin privileges to configure the virtual KVM.

### SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server# **scope kvm**
3. Server /server/kvm # **set enabled** {yes | no}
4. Server /server/kvm # **set encrypted** {yes | no}
5. Server /server/kvm # **set kvm-port** *port*
6. Server /server/kvm # **set local-video** {yes | no}
7. Server /server/kvm # **set max-sessions** *sessions*
8. Server /server/kvm # **commit**
9. Server /server/kvm # **show** [detail]

### DETAILED STEPS

|               | Command or Action                                      | Purpose                                                                                                 |
|---------------|--------------------------------------------------------|---------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}                   | Enters server command mode of server 1 or 2.                                                            |
| <b>Step 2</b> | Server /server# <b>scope kvm</b>                       | Enters KVM command mode.                                                                                |
| <b>Step 3</b> | Server /server/kvm # <b>set enabled</b> {yes   no}     | Enables or disables the virtual KVM.                                                                    |
| <b>Step 4</b> | Server /server/kvm # <b>set encrypted</b> {yes   no}   | If encryption is enabled, the server encrypts all video information sent through the KVM.               |
| <b>Step 5</b> | Server /server/kvm # <b>set kvm-port</b> <i>port</i>   | Specifies the port used for KVM communication.                                                          |
| <b>Step 6</b> | Server /server/kvm # <b>set local-video</b> {yes   no} | If local video is <b>yes</b> , the KVM session is also displayed on any monitor attached to the server. |

|        | Command or Action                                            | Purpose                                                                                                                      |
|--------|--------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------|
| Step 7 | Server /server/kvm # <b>set max-sessions</b> <i>sessions</i> | Specifies the maximum number of concurrent KVM sessions allowed. The <i>sessions</i> argument is an integer between 1 and 4. |
| Step 8 | Server /server/kvm # <b>commit</b>                           | Commits the transaction to the system configuration.                                                                         |
| Step 9 | Server /server/kvm # <b>show [detail]</b>                    | (Optional) Displays the virtual KVM configuration.                                                                           |

### Example

This example configures the virtual KVM and displays the configuration:

```
Server# scope server 1
Server /server # scope kvm
Server /server/kvm # set enabled yes
Server /server/kvm *# set encrypted no
Server /server/kvm *# set kvm-port 2068
Server /server/kvm *# set max-sessions 4
Server /server/kvm *# set local-video yes
Server /server/kvm *# commit
Server /server/kvm # show detail
KVM Settings:
 Encryption Enabled: no
 Max Sessions: 4
 Local Video: yes
 Active Sessions: 0
 Enabled: yes
 KVM Port: 2068

Server /server/kvm #
```

### What to do next

Launch the virtual KVM from the GUI.

## Configuring Virtual Media

### Before you begin

You must log in as a user with admin privileges to configure virtual media.

### Procedure

|        | Command or Action                              | Purpose                                                                   |
|--------|------------------------------------------------|---------------------------------------------------------------------------|
| Step 1 | Server# <b>scope vmedia</b>                    | Enters virtual media command mode.                                        |
| Step 2 | Server /vmedia # <b>set enabled</b> {yes   no} | Enables or disables virtual media. By default, virtual media is disabled. |

|               | Command or Action                                            | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------------|--------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                              | <b>Note</b> Disabling virtual media detaches the virtual CD, virtual floppy, and virtual HDD devices from the host.                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Step 3</b> | Server /vmedia # <b>set encryption {yes   no}</b>            | Enables or disables virtual media encryption.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Step 4</b> | Server /vmedia # <b>set low-power-usb-enabled {yes   no}</b> | Enables or disables low power USB.<br><br><b>Note</b> While mapping an ISO to a server which has a UCS VIC P81E card and the NIC is in Cisco Card mode: <ul style="list-style-type: none"> <li>• If the low power USB is enabled, after mapping the ISO and rebooting the host the card resets and ISO mapping is lost. The virtual drives are not visible on the boot selection menu.</li> <li>• If the low power USB is disabled, after mapping the ISO, and rebooting the host and the , the virtual drivers appear on the boot selection menu as expected.</li> </ul> |
| <b>Step 5</b> | Server /vmedia # <b>commit</b>                               | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Step 6</b> | Server /vmedia # <b>show [detail]</b>                        | (Optional) Displays the virtual media configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |

### Example

This example configures virtual media encryption:

```
Server# scope vmedia
Server /vmedia # set enabled yes
Server /vmedia *# set encryption yes
Server /vmedia *# set low-power-use-enabled no
Server /vmedia *# commit
Server /vmedia # show detail
vMedia Settings:
 Encryption Enabled: yes
 Enabled: yes
 Max Sessions: 1
 Active Sessions: 0
 Low Power USB Enabled: no

Server /vmedia #
```

### What to do next

Use the KVM to attach virtual media devices to a host.



## Configuring a Cisco IMC-Mapped vMedia Volume

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

|               | Command or Action                                                                                                                      | Purpose                                                                                                                                                                                                                                                                                                                                                                                             |
|---------------|----------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}                                                                                                   | Enters server command mode of server 1 or 2.                                                                                                                                                                                                                                                                                                                                                        |
| <b>Step 2</b> | Server /server# <b>scope vmedia</b>                                                                                                    | Enters the virtual media command mode.                                                                                                                                                                                                                                                                                                                                                              |
| <b>Step 3</b> | Server /server/vmedia # <b>map-cifs</b> { <b>volume-name</b>   <b>remote-share</b>   <b>remote-file-path</b> [ <i>mount options</i> ]} | Maps a CIFS file for vMedia. You must specify the following: <ul style="list-style-type: none"> <li>• Name of the volume to create</li> <li>• Remote share including IP address and the exported directory</li> <li>• Path of the remote file corresponding to the exported directory.</li> <li>• (Optional) Mapping options</li> <li>• Username and password to connect to the server</li> </ul>   |
| <b>Step 4</b> | Server /server/vmedia # <b>map-nfs</b> { <b>volume-name</b>   <b>remote-share</b>   <b>remote-file-path</b> } [ <i>mount options</i> ] | Maps an NFS file for vMedia. You must specify the following: <ul style="list-style-type: none"> <li>• Name of the volume to create</li> <li>• Remote share including IP address and the exported directory</li> <li>• Path of the remote file corresponding to the exported directory.</li> <li>• (Optional) Mapping options</li> </ul>                                                             |
| <b>Step 5</b> | Server /server/vmedia # <b>map-www</b> { <b>volume-name</b>   <b>remote-share</b>   <b>remote-file-path</b> [ <i>mount options</i> ]}  | Maps an HTTPS file for vMedia. You must specify the following: <ul style="list-style-type: none"> <li>• Name of the volume to create</li> <li>• Remote share including IP address and the exported directory</li> <li>• Path of the remote file corresponding to the exported directory.</li> <li>• (Optional) Mapping options</li> <li>• Username and password to connect to the server</li> </ul> |

**Example**

This example shows how to create a CIFS -mapped vmedia settings:

```
Server # scope server 1
Server /server #scope vmedia
Server /server/vmedia # map-cifs sample-volume //10.10.10.10/project /test/sample
Server username:
Server password: ****
Confirm password: ****

Server /server/vmedia #
```

## Viewing Cisco IMC-Mapped vMedia Volume Properties

**Before you begin**

You must log in with admin privileges to perform this task.

**Procedure**

|               | Command or Action                                   | Purpose                                                             |
|---------------|-----------------------------------------------------|---------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}                | Enters server command mode of server 1 or 2.                        |
| <b>Step 2</b> | Server /server # <b>scope vmedia</b>                | Enters the virtual media command mode.                              |
| <b>Step 3</b> | Server /server/vmedia # <b>show mappings detail</b> | Displays information on all the vmedia mapping that are configured. |

**Example**

This example shows how to view the properties of all the configured vmedia mapping:

```
Server # scope server 1
Server /server/#scope vmedia
Server /server/vmedia # show mappings
```

| Volume | Map-status | Drive-type | remote-share          | remote-file               | mount-type |
|--------|------------|------------|-----------------------|---------------------------|------------|
| Huu    | OK         | removable  | http://10.104.236.99/ | rhel-server-6.1-x86_6.iso | www        |
| Rhel   | OK         | CD         | http://10.104.236.99/ | rhel-server-6.1-x86_6.iso | www        |

```
Server /server/vmedia #
```

## Remapping an Existing Cisco IMC vMedia Image

**Before you begin**

You must log in with user or admin privileges to perform this task.

**Procedure**

|               | <b>Command or Action</b>                         | <b>Purpose</b>                                                                                                            |
|---------------|--------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope vmedia</b>                     | Enters the vMedia command mode.                                                                                           |
| <b>Step 2</b> | Server /vmedia # <b>show saved-mappings</b>      | Displays the available saved mappings.                                                                                    |
| <b>Step 3</b> | Server /vmedia # <b>remap mapping volume</b>     | Remaps the vMedia.<br><br><b>Note</b> You must use the volume name of the saved mapping as the variable for this command. |
| <b>Step 4</b> | (Optional) Server /vmedia # <b>show mappings</b> | Displays the mapped vMedia details.                                                                                       |

**Example**

This example shows how to remap a vMedia image to a saved mapping:

```

Server # scope vmedia
Server/vmedia # remap huu
Server/vmedia # show mappings
Volume Map-Status Drive-Type Remote-Share Remote-File
 Mount-Type

huu OK CD https://10.104.236.99...
ucs-c240-huu-3.0.0.33... www
Server/vmedia # show saved-mappings
Volume Drive-Type Remote-Share Remote-File Mount-Type

huu CD https://10.104.236.99... ucs-c240-huu-3.0.0.33... www
Server/vmedia #

```

## Deleting a Cisco IMC vMedia Image

**Before you begin**

You must log in with user or admin privileges to perform this task.

**Procedure**

|               | <b>Command or Action</b>                      | <b>Purpose</b>                                                          |
|---------------|-----------------------------------------------|-------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope vmedia</b>                  | Enters the vMedia command mode.                                         |
| <b>Step 2</b> | Server /vmedia # <b>delete-saved-mappings</b> | Enter <b>yes</b> in the confirmation prompt. Deletes the saved mapping. |
| <b>Step 3</b> | Server /vmedia # <b>show saved-mappings</b>   | Does not display any saved mapping as it is deleted.                    |

### Example

This example shows how to delete a saved mapping:

```

Server # scope vmedia
Server/vmedia # show saved-mappings
Volume Drive-Type Remote-Share Remote-File Mount-Type

huu CD https://10.104.236.99... ucs-c240-huu-3.0.0.33... www
Server/vmedia # delete-saved-mappings
Purge saved mappings? Enter 'yes' to confirm -> yes
Server/vmedia # show saved-mappings
Server/vmedia #

```

## Managing Serial over LAN

### Serial Over LAN

Serial over LAN (SoL) is a mechanism that enables the input and output of the serial port of a managed system to be redirected via an SSH session over IP. SoL provides a means of reaching the host console via .

### Guidelines and Restrictions for Serial Over LAN

For redirection to SoL, the server console must have the following configuration:

- console redirection to serial port A
- no flow control
- baud rate the same as configured for SoL
- VT-100 terminal type
- legacy OS redirection disabled

The SoL session will display line-oriented information such as boot messages, and character-oriented screen menus such as BIOS setup menus. If the server boots an operating system or application with a bitmap-oriented display, such as Windows, the SoL session will no longer display. If the server boots a command-line-oriented operating system (OS), such as Linux, you may need to perform additional configuration of the OS in order to properly display in an SoL session.

In the SoL session, your keystrokes are transmitted to the console except for the function key F2. To send an F2 to the console, press the Escape key, then press 2.

## Configuring Serial Over LAN

### Before you begin

You must log in as a user with admin privileges to configure serial over LAN (SoL).

## SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server# **scope sol**
3. Server /server/sol # **set enabled** {yes | no}
4. Server /server/sol # **set baud-rate** {9600 | 19200 | 38400 | 57600 | 115200}
5. (Optional) Server /server/sol # **set comport** {com0 | com1}
6. Server /sol # **commit**
7. Server /sol # **show** [detail]

## DETAILED STEPS

|               | Command or Action                                                                 | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|---------------|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}                                              | Enters server command mode of server 1 or 2.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Step 2</b> | Server /server# <b>scope sol</b>                                                  | Enters SoL command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Step 3</b> | Server /server/sol # <b>set enabled</b> {yes   no}                                | Enables or disables SoL on this server.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Step 4</b> | Server /server/sol # <b>set baud-rate</b> {9600   19200   38400   57600   115200} | <p>Sets the serial baud rate the system uses for SoL communication.</p> <p><b>Note</b> The baud rate must match the baud rate configured in the server serial console.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Step 5</b> | (Optional) Server /server/sol # <b>set comport</b> {com0   com1}                  | <p>Sets the serial port through which the system routes SoL communications.</p> <p><b>Note</b> This option is only available on some C-Series servers. If it is not available, the server always uses COM port 0 for SoL communication.</p> <p>You can specify:</p> <ul style="list-style-type: none"> <li>• <b>com0</b>—SoL communication is routed through COM port 0, an externally accessible serial port that supports either a physical RJ45 connection to an external device or a virtual SoL connection to a network device.</li> </ul> <p>If you select this option, the system enables SoL and disables the RJ45 connection, which means that the server can no longer support an external serial device.</p> <ul style="list-style-type: none"> <li>• <b>com1</b>—SoL communication is routed through COM port 1, an internal port accessible only through SoL.</li> </ul> <p>If you select this option, you can use SoL on COM port 1 and the physical RJ45 connection on COM port 0.</p> <p><b>Note</b> Changing the comport setting disconnects any existing SoL sessions.</p> |

|               | Command or Action                  | Purpose                                              |
|---------------|------------------------------------|------------------------------------------------------|
| <b>Step 6</b> | Server /sol # <b>commit</b>        | Commits the transaction to the system configuration. |
| <b>Step 7</b> | Server /sol # <b>show [detail]</b> | (Optional) Displays the SoL settings.                |

### Example

This example configures SoL:

```

Server# scope server 1
Server /server #scope sol
Server /server/sol # set enabled yes
Server /server/sol *# set baud-rate 115200
Server /server/sol *# set comport com1
Server /server/sol *# commit
Server /server/sol # show
Enabled Baud Rate(bps) Com Port

yes 115200 com1
Server /sol # show detail
Serial Over LAN:
 Enabled: yes
 Baud Rate(bps): 115200
 Com Port: com1
Server /server/sol #

```



## CHAPTER 8

# Managing User Accounts

This chapter includes the following sections:

- [Configuring Local Users for Cisco UCS C-Series M7 and Later Servers, on page 115](#)
- [Managing SSH Keys for User Accounts, on page 118](#)
- [Non-IPMI User Mode, on page 123](#)
- [Disabling Strong Password, on page 125](#)
- [Password Expiry, on page 126](#)
- [Configuring User Authentication Precedence, on page 126](#)
- [Resetting the User Password, on page 127](#)
- [Configuring Password Expiry for Users, on page 128](#)
- [LDAP Servers, on page 129](#)
- [Configuring the LDAP Server, on page 130](#)
- [Configuring LDAP in , on page 131](#)
- [Configuring LDAP Groups in , on page 135](#)
- [Configuring Nested Group Search Depth in LDAP Groups, on page 136](#)
- [TACACS+ Authentication, on page 137](#)
- [LDAP Certificates Overview, on page 140](#)
- [Viewing User Sessions, on page 143](#)
- [Terminating a User Session, on page 144](#)

## Configuring Local Users for Cisco UCS C-Series M7 and Later Servers

### Before you begin

You must log in as a user with admin privileges to configure or modify local user accounts.

### Procedure

|               | Command or Action                            | Purpose                                                    |
|---------------|----------------------------------------------|------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope user</b> <i>username</i>    | Enters user command mode for user number <i>username</i> . |
| <b>Step 2</b> | Server /user # <b>set enabled</b> {yes   no} | Enables or disables the user account on the Cisco IMC.     |

|               | Command or Action                                                               | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|---------------|---------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 3</b> | Server /user # <b>set name</b> <i>username</i>                                  | Specifies the username for the user.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Step 4</b> | Server /user # <b>set role</b> { <b>readonly</b>   <b>user</b>   <b>admin</b> } | <p>Specifies the role assigned to the user. The roles are as follows:</p> <ul style="list-style-type: none"> <li>• <b>readonly</b>—This user can view information but cannot make any changes.</li> <li>• <b>user</b>—This user can do the following: <ul style="list-style-type: none"> <li>• View all information</li> <li>• Manage the power control options such as power on, power cycle, and power off</li> <li>• Launch the KVM console and virtual media</li> <li>• Clear all logs</li> <li>• Toggle the locator LED</li> <li>• Set the time zone</li> <li>• Ping an IP address</li> </ul> </li> <li>• <b>admin</b>—This user can perform all actions available through the GUI, CLI, and IPMI.</li> </ul> |
| <b>Step 5</b> | Server /user # <b>set user-type</b> CIMC SNMP IPMI                              | Specifies the user type assigned to the user. You may select one or multiple user-type for a single user.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Step 6</b> | Server /user # <b>set password</b>                                              | You are prompted to enter the password twice.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |



|                | Command or Action                                                                                                    | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|----------------|----------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                |                                                                                                                      | <p><b>Note</b></p> <p>When strong password is enabled, you must follow these guidelines while setting a password:</p> <ul style="list-style-type: none"> <li>• The password must have a minimum of 8 and a maximum of 14 characters.</li> <li>• The password must not contain the User's Name.</li> <li>• The password must contain characters from three of the following four categories: <ul style="list-style-type: none"> <li>• English uppercase characters (A through Z)</li> <li>• English lowercase characters (a through z)</li> <li>• Base 10 digits (0 through 9)</li> <li>• Non-alphabetic characters (!, @, #, \$, %, ^, &amp;, *, -, _, +, =)</li> </ul> </li> </ul> <p>when strong password is disabled, you can set a password using characters of your choice (alphanumeric, special characters, or integers) within the range 1-20.</p> |
| <b>Step 7</b>  | Server /user # <b>set ipmi-password</b> <i>password</i>                                                              | Set the password for IPMI user type.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Step 8</b>  | Server /user # <b>set v3priv-protocol</b> <i>None CFB128_AES128</i>                                                  | Set this value for SNMP user type.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Step 9</b>  | Server /user # <b>set v3proto</b> <i>HMAC128_SHA224 HMAC192_SHA256 HMAC256_SHA384 HMAC384_SHA512 HMAC_SHA96 None</i> | Set this value for SNMP user type.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Step 10</b> | Server /user # <b>set v3priv-auth-key</b> <i>Priv_Auth_key</i>                                                       | Set the key, if required.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Step 11</b> | Server /user # <b>set v3auth-key</b> <i>Auth_key</i>                                                                 | Set the key, if required.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Step 12</b> | Server /user # <b>commit</b>                                                                                         | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

### Example

This example configures user 5 as an admin and all three user type:

```
Server# scope user 5
Server /user # set enabled yes
Server /user *# set name UserName
Server /user *# set role readonly
Server /user *# set user-type CIMC,SNMP,IPMI
```

```

Server /user *# set password
Warning:
Strong Password Policy is enabled!

For CIMC protection your password must meet the following requirements:
 The password must have a minimum of 8 and a maximum of 14 characters.
 The password must not contain the User's Name.
 The password must contain characters from three of the following four categories.
 English uppercase characters (A through Z)
 English lowercase characters (a through z)
 Base 10 digits (0 through 9)
Please enter password:
Please confirm password:
Server /user *# set ipmi-password
Warning:
Strong Password Policy is enabled!

For CIMC protection your password must meet the following requirements:
 The password must have a minimum of 8 and a maximum of 20 characters for IPMI users
 and
 maximum 127 characters for Non IPMI users.
 The password must not contain the User's Name.
 The password must contain characters from three of the following four categories.
 English uppercase characters (A through Z)
 English lowercase characters (a through z)
 Base 10 digits (0 through 9)
 Non-alphabetic characters (!, @, #, $, %, ^, &, *, -, _, +, =)
Please enter ipmi-password:
Server /user *# set v3proto None
Server /user *# set v3priv-prot None
Server /user *# commit

```

## Managing SSH Keys for User Accounts

### Configuring SSH Keys

In the release 4.1.2, Cisco IMC provides SSH RSA key-based authentication in addition to password authentication. SSH keys are a set of public and private RSA key pair, which you can use for authentication. Public key-based authentication provides enhanced security over password-based authentication.

You must log in as a user with admin privileges to configure the SSH keys for all the users. If you are a non-admin user, you can configure the SSH keys to authenticate and login only to your account. You can configure only one SSH RSA key pair, public and private, for your account. The SSH keys must be in .pem or .pub format.

The Cisco IMC sessions authenticated using public keys will be active even if the password has expired. You can also start new sessions using the public SSH key even after the password has expired. **Account lockout** option, available on some C-series servers, does not apply to the accounts that use public key authentication.

### Adding SSH Keys

#### Before you begin

- You must log in as a user with admin privileges to add the SSH keys for all the users.

- If you are a non-admin user, you can add the public key only for your account.

### Procedure

|               | Command or Action                                         | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|---------------|-----------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope user</b> <i>user-number</i>              | Enters the user command mode for a user.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Step 2</b> | Server /user # <b>show-detail</b>                         | Displays the details of the user account. You can view the number of SSH keys configured for a user in the <code>SSH Key Count</code> field.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Step 3</b> | Server /user # <b>scope ssh-keys</b>                      | Enters the SSH keys command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Step 4</b> | Server /user/ssh-keys # <b>add-key 1 remote</b>           | <p>Use this option to add the SSH key from a remote server.</p> <p>Enter the following details:</p> <ol style="list-style-type: none"> <li>Specify the protocol to connect to the remote server. It can be of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> <li>FTP</li> <li>SFTP</li> <li>SCP</li> <li>HTTP</li> </ul> </li> </ol> <p><b>Note</b> If you choose FTP, SCP or SFTP, you will be prompted to enter your username and password.</p> <ol style="list-style-type: none"> <li>Specify the remote server address.</li> <li>Specify the remote file path.</li> <li>Specify your username and password.</li> </ol> |
| <b>Step 5</b> | (Optional) Server /user/ssh-keys # <b>add-key 2 paste</b> | <p>Use this option to add the SSH key by paste method.</p> <p>Launches a dialog for entering the public SSH key. Copy the SSH key text, paste it into the console when prompted, and type CTRL+D.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Step 6</b> | (Optional) Server /user/ssh-keys # <b>show-detail</b>     | Displays the public SSH key that you have added to the account.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |

### Example

- This example adds the SSH key from a remote server.

```
Server# scope user 1
Server /user # scope ssh-keys
```

```

Server /user/ssh-keys # add-key 1 remote
Enter the remote Protocol [tftp | ftp | sftp | scp | http]: scp
Enter the remote Server: 10.10.10.10
Enter the remote file Path: /home/xyz/publickey.pem
Server (RSA) key fingerprint is dd:b5:2b:07:ad:c0:30:b2:d5:6a:6a:78:80:85:93:b0
Do you wish to continue? [y/N]y
Username: xyz
Password:
SSH Public key added successfully
Server /user/ssh-keys #

```

## 2. This example adds the SSH key by paste method.

```

Server# scope user 1
Server /user # scope ssh-keys
Server /user/ssh-keys # add-key 2 paste
Please paste your ssh key here, when finished, press CTRL+D.
ssh-rsa AAAAB3NzaC1yc2EAAAADAQABAAQDFOK17ZYbMMfGcxGrfxlupMqFy11ZNIJohPxASTu41
OkItF9VrrhrfF1ZKOpogJinx3s0OcPfgLMSWEQkUq1zGll8rAESZbi6z36WGFz93amJ3nfxDU7JWD9K
HmINixpX5XbbZeKQJvfSTptanmkjTQ8sq2iSMK0HL+G35i8BXmwIBLuEM+SWIEYjLaDAZ6aLKPxxddTr
FwWTF9QpzJAfQGlXXZSYauYb6OMNUxjggFtB2XCiROZTzcj4n1XQRbzU+56HvHmowcOPh081Btbun+xv
ksTeXbV3e9DVymjQK1qD2yY5h/EJdC0+9wGPyVmaT2bAOu4HbTsz8u4HFkTf
SSH Public key added successfully
Server /user/ssh-keys #

```

### What to do next

Modify or delete the SSH key.

## Modifying SSH Keys

### Before you begin

- You must log in as a user with admin privileges to modify the SSH keys for all the users.
- If you are a non-admin user, you can modify the public key only for your account.

### Procedure

|               | Command or Action                                  | Purpose                                                                                                                                                                                                                                                                                                         |
|---------------|----------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope user</b> <i>user-number</i>       | Enters the user command mode for a user.                                                                                                                                                                                                                                                                        |
| <b>Step 2</b> | Server /user # <b>show-detail</b>                  | Displays the details of the user account. You can view the number of SSH keys configured for a user in the <code>SSH Key Count</code> field.                                                                                                                                                                    |
| <b>Step 3</b> | Server /user # <b>scope ssh-keys</b>               | Enters the SSH keys command mode.                                                                                                                                                                                                                                                                               |
| <b>Step 4</b> | Server /user/ssh-keys # <b>modify-key 1 remote</b> | Use this option to add the modified key from a remote server. Enter the following details: <ol style="list-style-type: none"> <li>a. Specify the protocol to connect to the remote server. It can be of the following types:               <ul style="list-style-type: none"> <li>• TFTP</li> </ul> </li> </ol> |

|               | Command or Action                                            | Purpose                                                                                                                                                                                                                                                                                                            |
|---------------|--------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                              | <p>FTP</p> <p>SFTP</p> <p>SCP</p> <p>HTTP</p> <p><b>Note</b> If you choose FTP, SCP or SFTP, you will be prompted to enter your username and password.</p> <p><b>b.</b> Specify the remote server address.</p> <p><b>c.</b> Specify the remote file path.</p> <p><b>d.</b> Specify your username and password.</p> |
| <b>Step 5</b> | (Optional) Server /user/ssh-keys # <b>modify-key 2 paste</b> | <p>Use this option to add the modified SSH key by paste method.</p> <p>Launches a dialog for entering the updated public SSH key. Copy the SSH key text, paste it into the console when prompted, and type CTRL+D.</p>                                                                                             |
| <b>Step 6</b> | (Optional) Server /user/ssh-keys # <b>show-detail</b>        | Displays the updated public SSH key that you modified in the account.                                                                                                                                                                                                                                              |

**Example**

1. This example adds the modified SSH key from a remote server.

```

Server# scope user 1
Server /user # scope ssh-keys
Server /user/ssh-keys # modify-key 1 remote
Enter the remote Protocol [tftp | ftp | sftp | scp | http]: scp
Enter the remote Server: 10.10.10.10
Enter the remote file Path: /home/xyz/publickey.pem
Server (RSA) key fingerprint is dd:b5:2b:07:ad:c0:30:b2:d5:6a:6a:78:80:85:93:b0
Do you wish to continue? [y/N]y
Username: xyz
Password:
SSH Public key modified successfully
Server /user/ssh-keys #

```

2. This example adds the modified SSH key by paste method.

```

Server# scope user 1
Server /user # scope ssh-keys
Server /user/ssh-keys # modify-key 2 paste
Please paste your ssh key here, when finished, press CTRL+D.
ssh-rsa AAAAB3NzaC1yc2EAAAADAQABAAQDFOK17ZYbMMfGcxGrfxlupMqFyl1ZNIJohPxASTu41
OkItF9VrrhrfF1ZKOpogJinx3s0OcPfGLMSWEQkUq1zG1L8rAESZbi6z36WGFz93amJ3nfxDU7JWD9K
HmINixpX5XbbZeKQJvfSTptanmkjTQ8sq2iSMK0HL+G35i8BXmwIBLuEM+SWIEYjLaDAZ6aLKPxxddTr
FxWTP9QpzJAfQGL1XXZSYauYb6OMNUxjgqFtB2XCiROZTzcj4n1XQRbzU+56HvHmowcOPh081Btbun+xv
ksTeXbV3e9DVymjQK1qD2yY5h/EJdC0+9wGPYVmaT2baOu4HbTsz8u4HFkTf

```

```
SSH Public key modified successfully
Server /user/ssh-keys #
```

### What to do next

Delete the SSH key.

## Deleting SSH Keys

### Before you begin

- You must log in as a user with admin privileges to delete the SSH keys for all the users.
- If you are a non-admin user, you can delete the public key only for your account.

### Procedure

|               | Command or Action                                     | Purpose                                                                                                                                          |
|---------------|-------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope user</b> <i>user-number</i>         | Enters the user command mode for a user.                                                                                                         |
| <b>Step 2</b> | Server /user # <b>show-detail</b>                     | Displays the details of the user account. The field <code>SSH Key Count</code> displays the number of SSH keys that are configured for the user. |
| <b>Step 3</b> | Server /user # <b>scope ssh-keys</b>                  | Enters the SSH keys command mode.                                                                                                                |
| <b>Step 4</b> | Server /user/ssh-keys # <b>delete-key 1</b>           | A prompt with the message <code>Do you wish to continue? [y/N]</code> is displayed.                                                              |
| <b>Step 5</b> | Enter <code>y</code> to confirm the deletion.         |                                                                                                                                                  |
| <b>Step 6</b> | (Optional) Server /user/ssh-keys # <b>show-detail</b> | Displays the updated user details and SSH key count.                                                                                             |

### Example

This example deletes the SSH key.

```
Server# scope user 1
Server /user # scope ssh-keys
Server /user/ssh-keys # delete-key 1
This operation will delete the SSH key -
ssh-rsa AAAAB3NzaC1yc2EAAAADAQABAAQDFOK17ZYbMMfGcxGrfxlupMqFy11ZNIJohPxASTu41
OkItF9VrrhrfF1ZKOpogJinx3s0OcPFLMSWEQkUq1zG1L8rAESZbi6z36WGFz93amJ3nfxDU7JWD9K
HmINixpX5XbbZeKQJvfSTptanmkjTQ8sq2iSMK0HL+G35i8BXmwIBLuEM+SWIEYjLaDAZ6aLKPxxddTr
FkWTP9QpzJafQGlXXZSYauYb6OMNUxjggFtB2XCiROZTzcj4n1XQRbzU+56HvHmowcOPh081Btbun+Xv
ksTeXbV3e9DVymjQK1qD2yY5h/EJdC0+9wGPYvMaT2bAOu4HbTsz8u4HFkTf
Do you wish to continue? [y/N]y
SSH Public key deleted successfully
Server /user/ssh-keys #
```

## Non-IPMI User Mode

Release 4.1 introduces a new user configuration option called **User Mode** that allows you to switch between IPMI and non-IPMI user modes. Introduction of the non-IPMI user mode provides enhanced password security for users and security enhancements to the BMC database that were restricted in earlier releases due to the constraints posed by the IPMI 2.0 standards. Non-IPMI user mode allows you to use 127 characters to set user passwords whereas users in IPMI mode are restricted to a password length of 20 characters. Non-IPMI user mode enables you to set stronger passwords for users configured in this mode.

You must consider the following configuration changes that occur while switching between user modes, when you:

- Switch to the non-IPMI mode, IPMI over LAN will not be supported.
- Switch from the non-IPMI to IPMI mode, deletes all the local users and reverts user credentials to default username and password. On subsequent login, you will be prompted to change the password.  
User data is not affected when you switch from IPMI to non-IPMI mode.
- Downgrade the firmware to a versions lower than 4.1 and if the user mode is non-IPMI, deletes all the local users and reverts user credentials to default username and password. On subsequent login, you will be prompted to change the default password.



**Note** When you reset to factory defaults, the user mode reverts to IPMI mode.

## Switching User Mode from IPMI to Non-IPMI

### Before you begin

You must log in as a user with admin privileges to perform this action.

### SUMMARY STEPS

1. Server# **scope user-policy**
2. Server /user-policy # **scope user-mode**
3. Server /user-policy/user-mode # **set user-mode non-ipmi**
4. Server /user-policy/user-mode \* # **commit**
5. Server /user-policy/user-mode # **show detail**

### DETAILED STEPS

|               | Command or Action                                             | Purpose                                                             |
|---------------|---------------------------------------------------------------|---------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope user-policy</b>                              | Enters user policy command mode.                                    |
| <b>Step 2</b> | Server /user-policy # <b>scope user-mode</b>                  | Enters user mode command mode.                                      |
| <b>Step 3</b> | Server /user-policy/user-mode # <b>set user-mode non-ipmi</b> | Enter y at the confirmation prompt to switch to Non-IPMI user mode. |

|               | Command or Action                                  | Purpose                                              |
|---------------|----------------------------------------------------|------------------------------------------------------|
| <b>Step 4</b> | Server /user-policy/user-mode * # <b>commit</b>    | Commits the transaction to the system configuration. |
| <b>Step 5</b> | Server /user-policy/user-mode # <b>show detail</b> | Displays the user mode.                              |

### Example

This example shows how to disable strong password:

```
Server# scope user-policy
Server /user-policy # scope user-mode
Server /user-policy/user-mode # set user-mode non-ipmi
Server /user-policy/user-mode *# commit
Warning: This will enable NON-IPMI based user mode.
 Converting to Non-IPMI User Mode disables IPMI Services and removes IPMI user
support.
 SSH, KVM, Webserver, XMAPi and Redfish sessions will be disconnected.
Do you wish to continue? [y/N] y
Connection to 10.10.10.10 closed by remote host.
Connection to 10.10.10.10 closed.
Server /user-policy/user-mode # show detail
User Mode:
 User mode for IPMI accessibility: non-ipmi
Server /user-policy/user-mode #
```

## Switching User Mode from Non-IPMI to IPMI

### Before you begin

You must log in as a user with admin privileges to perform this action.

### SUMMARY STEPS

1. Server# **scope user-policy**
2. Server /user-policy # **scope user-mode**
3. Server /user-policy/user-mode # **set user-mode ipmi**
4. Server /user-policy/user-mode \* # **commit**
5. Server /user-policy/user-mode # **show detail**

### DETAILED STEPS

|               | Command or Action                                         | Purpose                                                         |
|---------------|-----------------------------------------------------------|-----------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope user-policy</b>                          | Enters user policy command mode.                                |
| <b>Step 2</b> | Server /user-policy # <b>scope user-mode</b>              | Enters user mode command mode.                                  |
| <b>Step 3</b> | Server /user-policy/user-mode # <b>set user-mode ipmi</b> | Enter y at the confirmation prompt to switch to IPMI user mode. |



|               | Command or Action                                  | Purpose                                                                                                         |
|---------------|----------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|
|               |                                                    | <b>Note</b> Switching to IPMI user mode deletes all the UCS users and reverts to default username and password. |
| <b>Step 4</b> | Server /user-policy/user-mode * # <b>commit</b>    | Commits the transaction to the system configuration.                                                            |
| <b>Step 5</b> | Server /user-policy/user-mode # <b>show detail</b> | Displays the user mode.                                                                                         |

### Example

This example shows how to disable strong password:

```
Server# scope user-policy
Server /user-policy # scope user-mode
Server /user-policy/user-mode # set user-mode ipmi
Server /user-policy/user-mode *# commit
Warning: This will enable IPMI based user mode.
 Converting to IPMI User Mode deletes all UCS users and reverts to default
userid/password.
 SSH, KVM, Webserver, XMAPi and Redfish sessions will be disconnected.
Do you wish to continue? [y/N] y
Connection to 10.10.10.10 closed by remote host.
Connection to 10.10.10.10 closed.
Server /user-policy/user-mode # show detail
User Mode:
 User mode for IPMI accessibility: ipmi
Server /user-policy/user-mode #
```

## Disabling Strong Password

The Cisco IMC now implements a strong password policy wherein you are required to follow guidelines and set a strong password when you first log on to the server for the first time. The Cisco IMC CLI provides you option which allows you to disable the strong password policy and set a password of your choice by ignoring the guidelines. Once you disable the strong password, an Enable Strong Password button is displayed. By default, the strong password policy is enabled.

### Before you begin

You must log in as a user with admin privileges to perform this action.

### SUMMARY STEPS

1. Server# **scope user-policy**
2. Server /user-policy # **set password-policy {enabled | disabled}**
3. Server /user-policy # **commit**

## DETAILED STEPS

|               | Command or Action                                                     | Purpose                                                                                                                                      |
|---------------|-----------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope user-policy</b>                                      | Enters user policy command mode.                                                                                                             |
| <b>Step 2</b> | Server /user-policy # <b>set password-policy {enabled   disabled}</b> | At the confirmation prompt, enter <b>y</b> to complete the action or <b>n</b> to cancel the action. Enables or disables the strong password. |
| <b>Step 3</b> | Server /user-policy # <b>commit</b>                                   | Commits the transaction to the system configuration.                                                                                         |

**Example**

This example shows how to disable strong password:

```
Server# scope user-policy
Server /user-policy # set password-policy disabled
Warning: Strong password policy is being disabled.
Do you wish to continue? [y/N] y
Server /user-policy *# commit
Server /user-policy #
```

## Password Expiry

You can set a shelf life for a password, after which it expires. As an administrator, you can set this time in days. This configuration would be common to all users. Upon password expiry, the user is notified on login and would not be allowed to login unless the password is reset.



**Note** When you downgrade to an older database, existing users are deleted. The database returns to default settings. Previously configured users are cleared and the database is empty, that is, the database has the default username - 'admin' and password - 'password'. Since the server is left with the default user database, the change default credential feature is enabled. This means that when the 'admin' user logs on to the database for the first time after a downgrade, the user must mandatorily change the default credential.

**Password Set Time**

A 'Password set time' is configured for every existing user, to the time when the migration or upgrade occurred. For new users (users created after an upgrade), the Password Set time is configured to the time when the user was created, and the password is set. For users in general (new and existing), the Password Set Time is updated whenever the password is changed.

## Configuring User Authentication Precedence

## SUMMARY STEPS

1. Server # **scope user-policy**

2. Server/user-policy # **set authentication-precedence** *User Database name*
3. Server/user-policy # **commit**

#### DETAILED STEPS

|               | Command or Action                                                                   | Purpose                                      |
|---------------|-------------------------------------------------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope user-policy</b>                                                   | Enters the TACACS+ command mode.             |
| <b>Step 2</b> | Server/user-policy # <b>set authentication-precedence</b> <i>User Database name</i> | Enter comma delimited list of user database. |
| <b>Step 3</b> | Server/user-policy # <b>commit</b>                                                  |                                              |

#### Example

```
Server # scope user-policy
Server /user-policy # set authentication-precedence DB1,DB2
Server /user-policy* # commit
```

## Resetting the User Password

You can use the change password option to change your password.



#### Note

- This option is not available when you login as an admin, you can only change the password of the configured users with read-only user privileges.
- When you change your password you will be logged out of Cisco IMC.

#### SUMMARY STEPS

1. Server # **scope user** *user ID*
2. Server /chassis/user # **set password**
3. Server /chassis/user \* # **commit**

#### DETAILED STEPS

|               | Command or Action                          | Purpose                                                                                                                                      |
|---------------|--------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope user</b> <i>user ID</i>  | Enters the chosen user command mode.                                                                                                         |
| <b>Step 2</b> | Server /chassis/user # <b>set password</b> | Read the password requirements instructions and enter the current password, new password and confirm the password at the respective prompts. |
| <b>Step 3</b> | Server /chassis/user * # <b>commit</b>     | Commits the transaction to the system configuration.                                                                                         |

**Example**

This example shows how to change the password of a configured user:

```
Server # scope user 2
Server /chassis/user # set password
Warning:
Strong Password Policy is enabled!
For CIMC protection your password must meet the following requirements:
 The password must have a minimum of 8 and a maximum of 20 characters.
 The password must not contain the User's Name.
 The password must contain characters from three of the following four categories.
 English uppercase characters (A through Z)
 English lowercase characters (a through z)
 Base 10 digits (0 through 9)
 Non-alphabetic characters (!, @, #, $, %, ^, &, *, -, _, +, =)
Please enter current password:Testabcd1
Please enter password: Testabcd2
Please confirm password: Testabcd2
Server /chassis/user * # commit
Server /chassis/user #
```

# Configuring Password Expiry for Users

**SUMMARY STEPS**

1. Server # **scope user-policy**
2. Server /user-policy # **scope password-expiration**
3. Server /user-policy/password-expiration # **set password-expiry-duration** *integer in the range 0-3650*
4. Server /user-policy/password-expiration \* # **set notification-period** *integer in the range 0-15*
5. Server /user-policy/password-expiration \* # **set grace-period** *integer in the range 0-5*
6. Server /user-policy/password-expiration \* # **set password-history** *integer in the range 0-5*
7. Server /user-policy/password-expiration \*# **commit**
8. (Optional) Server /user-policy/password-expiration # **show detail**
9. (Optional) Server /user-policy/password-expiration # **restore**

**DETAILED STEPS**

|               | Command or Action                                                                                                | Purpose                                                                                                                                                                                                      |
|---------------|------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope user-policy</b>                                                                                | Enters the user policy command mode.                                                                                                                                                                         |
| <b>Step 2</b> | Server /user-policy # <b>scope password-expiration</b>                                                           | Enters the password expiration command mode.                                                                                                                                                                 |
| <b>Step 3</b> | Server /user-policy/password-expiration # <b>set password-expiry-duration</b> <i>integer in the range 0-3650</i> | The time period that you can set for the existing password to expire (from the time you set a new password or modify an existing one). The range is between 0 to 3650 days. Entering 0 disables this option. |
| <b>Step 4</b> | Server /user-policy/password-expiration * # <b>set notification-period</b> <i>integer in the range 0-15</i>      | Notifies the time by when the password expires. Enter a value between 0 to 15 days. Entering 0 disables this option.                                                                                         |

|        | Command or Action                                                                                       | Purpose                                                                                                                                                                   |
|--------|---------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 5 | Server /user-policy/password-expiration * # <b>set grace-period</b> <i>integer in the range 0-5</i>     | Time period till when the existing password can still be used, after it expires. Enter a value between 0 to 5 days. Entering 0 disables this option.                      |
| Step 6 | Server /user-policy/password-expiration * # <b>set password-history</b> <i>integer in the range 0-5</i> | The number of occurrences when a password was entered. When this is enabled, you cannot repeat a password. Enter a value between 0 to 5. Entering 0 disables this option. |
| Step 7 | Server /user-policy/password-expiration *# <b>commit</b>                                                | Commits the transactions.                                                                                                                                                 |
| Step 8 | (Optional) Server /user-policy/password-expiration # <b>show detail</b>                                 | Shows the password expiration details.                                                                                                                                    |
| Step 9 | (Optional) Server /user-policy/password-expiration # <b>restore</b>                                     | At the confirmation prompt, enter <b>yes</b> to restore the password expiry settings to default values.                                                                   |

### Example

This example sets the password expiration and restore the settings to default vales:

```

Server # scope user-policy
Server /user-policy # scope password-expiration
Server /user-policy/password-expiration # set password-expiry-duration 5
Server /user-policy/password-expiration * # set notification-period 2
Server /user-policy/password-expiration *# set grace-period 1
Server /user-policy/password-expiration *# set password-history 4
Server /user-policy/password-expiration *# commit
Server /user-policy/password-expiration # show detail
Password expiration parameters:
 Valid password duration: 5
 Number of stored old passwords: 4
 Notification period: 2
 Grace period: 1
Server /user-policy/password-expiration #
Restoring the password expiry parameters to default values:
Server /user-policy/password-expiration # restoreAre you sure you want to restore
User password expiration parameters to defaults?
Please enter 'yes' to confirm:yes
Server /user-policy/password-expiration #

```

## LDAP Servers

supports directory services that organize information in a directory, and manage access to this information. supports Lightweight Directory Access Protocol (LDAP), which stores and maintains directory information in a network. In addition, supports Microsoft Active Directory (AD). Active Directory is a technology that provides a variety of network services including LDAP-like directory services, Kerberos-based authentication, and DNS-based naming. The utilizes the Kerberos-based authentication service of LDAP.

When LDAP is enabled in the , user authentication and role authorization is performed by the LDAP server for user accounts not found in the local user database. The LDAP user authentication format is `username@domain.com`.

By enabling encryption in the configuration of Active Directory on the server, you can require the server to encrypt data sent to the LDAP server.

## Configuring the LDAP Server

The can be configured to use LDAP for user authentication and authorization. To use LDAP, configure users with an attribute that holds the user role and locale information for the . You can use an existing LDAP attribute that is mapped to the user roles and locales or you can modify the LDAP schema to add a new custom attribute, such as the CiscoAVPair attribute, which has an attribute ID of 1.3.6.1.4.1.9.287247.1.



**Important** For more information about altering the schema, see the article at <http://technet.microsoft.com/en-us/library/bb727064.aspx>.



**Note** This example creates a custom attribute named CiscoAVPair, but you can also use an existing LDAP attribute that is mapped to the user roles and locales.

If you are using Group Authorization on the Cisco IMC LDAP configuration, then you can skip Steps 1-4 and perform the steps listed in the *Configuring LDAP Settings and Group Authorization in Cisco IMC* section.

The following steps must be performed on the LDAP server.

**Step 1** Ensure that the LDAP schema snap-in is installed.

**Step 2** Using the schema snap-in, add a new attribute with the following properties:

| Properties            | Value                         |
|-----------------------|-------------------------------|
| Common Name           | <b>CiscoAVPair</b>            |
| LDAP Display Name     | <b>CiscoAVPair</b>            |
| Unique X500 Object ID | <b>1.3.6.1.4.1.9.287247.1</b> |
| Description           | <b>CiscoAVPair</b>            |
| Syntax                | <b>Case Sensitive String</b>  |

**Step 3** Add the CiscoAVPair attribute to the user class using the snap-in:

- a) Expand the **Classes** node in the left pane and type **U** to select the user class.
- b) Click the **Attributes** tab and click **Add**.
- c) Type **C** to select the CiscoAVPair attribute.
- d) Click **OK**.

**Step 4** Add the following user role values to the CiscoAVPair attribute, for the users that you want to have access to :

| Role      | CiscoAVPair Attribute Value          |
|-----------|--------------------------------------|
| admin     | <code>shell:roles="admin"</code>     |
| user      | <code>shell:roles="user"</code>      |
| read-only | <code>shell:roles="read-only"</code> |

**Note** For more information about adding values to attributes, see the article at <http://technet.microsoft.com/en-us/library/bb727064.aspx>.

### What to do next

Use the `scope ldap` to configure the LDAP server.

## Configuring LDAP in

Configure LDAP in `scope ldap` when you want to use an LDAP server for local user authentication and authorization.

### Before you begin

You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. `Server# scope ldap`
2. `Server /ldap # set enabled {yes | no}`
3. `Server /ldap # set domainLDAP domain name`
4. `Server /ldap # set timeout seconds`
5. `Server /ldap # set base-dn domain-name`
6. `Server /ldap # set attribute name`
7. `Server /ldap # set filter-attribute`
8. `Server /ldap # scope secure`
9. Enable secure LDAP and either download the certificate remotely or paste the certificate.
10. `Server /ldap # commit`
11. `Server /ldap # show [detail]`

### DETAILED STEPS

|               | Command or Action                                  | Purpose                                                                                                                                                                  |
|---------------|----------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | <code>Server# scope ldap</code>                    | Enters the LDAP command mode.                                                                                                                                            |
| <b>Step 2</b> | <code>Server /ldap # set enabled {yes   no}</code> | Enables or disables LDAP security. When enabled, user authentication and role authorization is performed by LDAP for user accounts not found in the local user database. |

|               | Command or Action                                                                         | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|---------------|-------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 3</b> | Server /ldap # <b>set domain</b> <i>LDAP domain name</i>                                  | Specifies an LDAP domain name.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Step 4</b> | Server /ldap # <b>set timeout</b> <i>seconds</i>                                          | Specifies the number of seconds the waits until the LDAP search operation times out. The value must be between 0 and 1800 seconds.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Step 5</b> | Server /ldap # <b>set base-dn</b> <i>domain-name</i>                                      | Specifies the Base DN that is searched on the LDAP server.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Step 6</b> | Server /ldap # <b>set attribute</b> <i>name</i>                                           | <p>Specify an LDAP attribute that contains the role and locale information for the user. This property is always a name-value pair. The system queries the user record for the value that matches this attribute name.</p> <p>You can use an existing LDAP attribute that is mapped to the user roles and locales or you can create a custom attribute, such as the CiscoAVPair attribute, which has the following attribute ID:</p> <p>1.3.6.1.4.1.9.287247.1</p> <p><b>Note</b> If you do not specify this property, user access is denied.</p>                                                                                                             |
| <b>Step 7</b> | Server /ldap # <b>set filter-attribute</b>                                                | Specifies the account name attribute. If Active Directory is used, then specify <b>sAMAccountName</b> for this field.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Step 8</b> | Server /ldap # <b>scope secure</b>                                                        | Enters the secure LDAP mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Step 9</b> | Enable secure LDAP and either download the certificate remotely or paste the certificate. | <p>Perform one of the following:</p> <ol style="list-style-type: none"> <li>Server /ldap # <b>secure-ldap</b> <i>disabled/enabled paste tftp   ftp   sftp   scp   http</i><br/>Prompts you to paste the certificate content.</li> <li>Paste the certificate content and press <b>CTRL+D</b>.<br/>Confirmation prompt appears.</li> <li>At the confirmation prompt, enter <b>y</b>.<br/>This begins the download of the LDAP CA certificate.</li> </ol> <p><b>OR</b></p> <ol style="list-style-type: none"> <li>Server /ldap # <b>secure-ldap</b> <i>disabled/enabled remote tftp   ftp   sftp   scp   http IP Address LDAP CA Certificate file</i></li> </ol> |



|                | Command or Action                   | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|----------------|-------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                |                                     | <p><b>Note</b></p> <p>The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p><b>b.</b> At the confirmation prompt, enter <b>y</b>.</p> <p>This begins the download of the LDAP CA certificate.</p> |
| <b>Step 10</b> | Server /ldap # <b>commit</b>        | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Step 11</b> | Server /ldap # <b>show [detail]</b> | (Optional) Displays the LDAP configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |

**Example**

This example configures LDAP using remote download option:

```

Server# scope ldap
Server /ldap # set enabled yes
Server /ldap *# set domain sample-domain
Server /ldap *# set timeout 60
Server /ldap *# set base-dn example.com
Server /ldap *# set attribute CiscoAVPair
Server /ldap *# set filter-attribute sAMAccountName
Server /ldap *# scope secure
Server /ldap/secure *# secure-ldap enabled remote ftp xx.xx.xx.xx filename
% Total % Received % Xferd Average Speed Time Time Current
 Dload Upload Total Spent Left Speed
100 1282 100 1282 0 0 1247 0 0:00:01 0:00:01 --:--:-- 1635
100 1282 100 1282 0 0 1239 0 0:00:01 0:00:01 --:--:-- 1239
 You are going to overwrite the LDAP CA Certificate.
 Are you sure you want to proceed and overwrite the LDAP CA Certificate? [y|N]y
LDAP CA Certificate is downloaded successfully
Server /ldap/secure *# commit
Server /ldap # exit
Server /ldap # show detail
LDAP Settings:
 Enabled: yes
 Domain: sample-domain
 BaseDN: example.com
 Timeout: 60

```

```

Filter-Attribute: sAMAccountName
Server /ldap #

```

This example configures secure LDAP using paste certificate option:

```

Server# scope ldap
Server /ldap # set enabled yes
Server /ldap *# set domain sample-domain
Server /ldap *# set timeout 60
Server /ldap *# set base-dn example.com
Server /ldap *# set attribute CiscoAVPair
Server /ldap *# set filter-attribute sAMAccountName
Server /ldap *# scope secure
Server /ldap/secure *# secure-ldap enabled ftp paste

```

```

Please paste your certificate here, when finished, press CTRL+D.
-----BEGIN CERTIFICATE-----
MIIDdzCCAl+gAwIBAgIQV06yJcJPAYNO8Cp+FYQtTjANBgkqhkiG9w0BAQsFADBO
MRIwEAYKCCZImiZPyLQBGARYCaW4xGzAZBgoJkiaJk/IsZAEZFgsOT0JKUkEySkhC
UTEbMBkGAlUEAxMSV0lOLTRPQkpSQTJKSEJRLUNBMB4XDTE2MDIyNTE3MDczNloX
DTIxMDIyNTE3MTczM1owTjESMBAGCgmSJomT8ixkARkWAmlMRswGQYKCCZImiZPy
LQBGARYLNE9CSlJBMkpIQlExGzAZBgnVBAMTEldJTi00T0JKUkEySkhCUS1DQTC
ASIwDQYJKoZIhvcNAQEBBQADggEPADCCAQoCggEBAMM2cdgmrPTkZe4K2zi+EbeZ
mfQnjfiUz8OIY97w8lC/2S4qK46T+fnXl3rXe8vvVHAO5wgPDVQTGS4nlF46A6Ba
FK+krKcIgfRQB1gnF74qs/lnlYtKHNBjrvG5KyeWFrA7So6Mi2XEw8w/zMPL0d8T
b+LMLYnhnuXA9G8gVCJ/iUhXfMpB20L8sv30Mek7bw8x2cxJYTuJAViVIrjSwU5j
fO3WktRuyFpeOIi00weklpF0+8D3Z9mBinoTbL2pl0U32am6wTI+8WmtJ+8W68v
jH4Y8YBY/kzMHdpwjpgdZkC5pE9Bcm0rL9xKoTu6X0kSNEssoGnepFyNaH3t8vnMC
AwEAAANRME8wCwYDVR0PBAQDAGGMA8GA1UdEwEB/wQFMAMBAf8wHQYDVR0OBBYE
FBAUulHTAWBT1OBz8IgaEzXsfCsMBAGCSsGAQQBggjCVAQQDAgEAMA0GCSqGSIb3
DQEBEwUAA4IBAQAzUMZr+0r1dWkVfFNbd7lu8tQbAEJf/A7PIKnJGN0Ug8moAGs4
pMndoxdpNGZhYCDWX3GwdeFlHqZHhb38gGQ9ylu0pIK7tgQufZmeCBH6T7Tzq/w
Dq+TMFGIjXF84xW3N665y4ePgUcUI7e/6aBgCgkGeUYodBPtExe28tQyeuYwD4Zj
nLuZKkT+I4PAYyqVCqxDGsvfRHDpGneb3R+GeonOf4ED/0tn5PLSL9khh9qkHu/V
dO3/HmKVzUhl0TDBuAMq/wES2WZAWHGr3hBc4nWQNjZWEMOKDpYZVK/GhBmNF+xi
eRcFqgh64oEmH9qAp0caGS1e7UyYan+LtPRE
-----END CERTIFICATE-----

```

**CTRL+D**

You are going to overwrite the LDAP CA Certificate.

Are you sure you want to proceed and overwrite the LDAP CA Certificate? [y|N]

**y**

```

Server /ldap/secure *# commit
Server /ldap # exit
Server /ldap # show detail
LDAP Settings:
 Enabled: yes
 Domain: sample-domain
 BaseDN: example.com
 Timeout: 60
 Filter-Attribute: sAMAccountName
Server /ldap #

```

### What to do next

If you want to use LDAP groups for group authorization, see *Configuring LDAP Groups in* .

# Configuring LDAP Groups in



**Note** When Active Directory (AD) group authorization is enabled and configured, user authentication is also done on the group level for users that are not found in the local user database or who are not individually authorized to use in the Active Directory.

## Before you begin

- You must log in as a user with admin privileges to perform this task.
- Active Directory (or LDAP) must be enabled and configured.

## SUMMARY STEPS

1. Server# **scope ldap**
2. Server /ldap# **scope ldap-group-rule**
3. Server /ldap/ldap-group-rule # **set group-auth {yes | no}**
4. Server /ldap # **scope role-group index**
5. Server /ldap/role-group # **set name group-name**
6. Server /ldap/role-group # **set domain domain-name**
7. Server /ldap/role-group # **set role {admin | user | readonly}**
8. Server /ldap/role-group # **commit**

## DETAILED STEPS

|               | Command or Action                                                   | Purpose                                                                                                                                                                                                                                                                                       |
|---------------|---------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope ldap</b>                                           | Enters the LDAP command mode for AD configuration.                                                                                                                                                                                                                                            |
| <b>Step 2</b> | Server /ldap# <b>scope ldap-group-rule</b>                          | Enters the LDAP group rules command mode for AD configuration.                                                                                                                                                                                                                                |
| <b>Step 3</b> | Server /ldap/ldap-group-rule # <b>set group-auth {yes   no}</b>     | Enables or disables LDAP group authorization.                                                                                                                                                                                                                                                 |
| <b>Step 4</b> | Server /ldap # <b>scope role-group index</b>                        | Selects one of the available group profiles for configuration, where <i>index</i> is a number between 1 and 28.                                                                                                                                                                               |
| <b>Step 5</b> | Server /ldap/role-group # <b>set name group-name</b>                | Specifies the name of the group in the AD database that is authorized to access the server.                                                                                                                                                                                                   |
| <b>Step 6</b> | Server /ldap/role-group # <b>set domain domain-name</b>             | Specifies the AD domain the group must reside in.                                                                                                                                                                                                                                             |
| <b>Step 7</b> | Server /ldap/role-group # <b>set role {admin   user   readonly}</b> | Specifies the permission level (role) assigned to all users in this AD group. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>admin</b>—The user can perform all actions available.</li> <li>• <b>user</b>—The user can perform the following tasks:</li> </ul> |

|               | Command or Action                       | Purpose                                                                                                                                                                                                                                                                                                                                                                 |
|---------------|-----------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                         | <ul style="list-style-type: none"> <li>• View all information</li> <li>• Manage the power control options such as power on, power cycle, and power off</li> <li>• Launch the KVM console and virtual media</li> <li>• Clear all logs</li> <li>• Toggle the locator LED</li> <li>• <b>readonly</b>—The user can view information but cannot make any changes.</li> </ul> |
| <b>Step 8</b> | Server /ldap/role-group # <b>commit</b> | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                    |

### Example

This example shows how to configure LDAP group authorization:

```
Server# scope ldap
Server /ldap # scope ldap-group-rule
Server /ldap/ldap-group-rule # set group-auth yes
Server /ldap *# scope role-group 5
Server /ldap/role-group # set name Training
Server /ldap/role-group* # set domain example.com
Server /ldap/role-group* # set role readonly
Server /ldap/role-group* # commit
ucs-c250-M2 /ldap # show role-group
Group Group Name Domain Name Assigned Role

1 (n/a) (n/a) admin
2 (n/a) (n/a) user
3 (n/a) (n/a) readonly
4 (n/a) (n/a) (n/a)
5 Training example.com readonly

Server /ldap/role-group #
```

## Configuring Nested Group Search Depth in LDAP Groups

You can search for an LDAP group nested within another defined group in an LDAP group map.

- You must log in as a user with admin privileges to perform this task.
- Active Directory (or LDAP) must be enabled and configured.

### SUMMARY STEPS

1. Server# **scope ldap**
2. Server /ldap# **scope ldap-group-rule**
3. Server /ldap/ldap-group-rule # **set group-search-depth value**

#### 4. Server /ldap/role-group-rule # commit

### DETAILED STEPS

|        | Command or Action                                                  | Purpose                                                        |
|--------|--------------------------------------------------------------------|----------------------------------------------------------------|
| Step 1 | Server# <b>scope ldap</b>                                          | Enters the LDAP command mode for AD configuration.             |
| Step 2 | Server /ldap# <b>scope ldap-group-rule</b>                         | Enters the LDAP group rules command mode for AD configuration. |
| Step 3 | Server /ldap/ldap-group-rule # <b>set group-search-depth value</b> | Enables search for a nested LDAP group.                        |
| Step 4 | Server /ldap/role-group-rule # <b>commit</b>                       | Commits the transaction to the system configuration.           |

### Example

This example shows how to search for run a search for an LDAP group nested within another defined group.

```
Server# scope ldap
Server /ldap # scope ldap-group-rule
Server /ldap/ldap-group-rule # set group-search-depth 10
Server /ldap/role-group-rule* # commit
Server /ldap/role-group-rule # show detail
Group rules for LDAP:
 Group search attribute: memberOf
 Enable Group Authorization: yes
 Nested group search depth: 10
Server/ldap/ldap-group-rule #
```

## TACACS+ Authentication

Beginning with 4.1(3b) release, Cisco IMC supports Terminal Access Controller Access-Control System Plus (TACACS+) user authentication. Cisco IMC supports up to six TACACS+ remote servers. Once a user is successfully authenticated, the username is appended with (TACACS+). This is also displayed in the Cisco IMC interfaces.

Refer [Enabling TACACS+ Authentication, on page 138](#) to enable TACACS+ Authentication. Cisco IMC also supports user authentication precedence in case TACACS+ remote servers are inaccessible. User authentication precedence can be configured using [Configuring User Authentication Precedence, on page 126](#).

## TACACS+ Server Configuration

Privilege level of a user is calculated based on the **cisco-av-pair** value configured for that user. A **cisco-av-pair** should be created on the TACACS+ server. Users cannot use any existing TACACS+ attributes.

Following three syntax are supported for the **cisco-av-pair** attribute:

- For **admin** privilege: **cisco-av-pair=shell:roles="admin"**
- For **user** privilege: **cisco-av-pair=shell:roles="user"**

- For **read-only** privilege: **cisco-av-pair=shell:roles="read-only"**

More roles, if required, can be added by using **comma** as a separator.



**Note** If **cisco-av-pair** is not configured on the TACACS+ server, then a user with that server has **read-only** privilege.

## Enabling TACACS+ Authentication

### Before you begin

Before configuring Terminal Access Controller Access-Control System (TACACS+) based user authentication, ensure that privilege level of a user is configured on TACACS+ server based on the **cisco-av-pair** value.

### SUMMARY STEPS

1. Server# **scope tacacs+**
2. Server/tacacs+ # **set enabled yes/no**
3. Server/tacacs+ # **set fallback-only-on-no-connectivity yes/no**
4. Server/tacacs+ # **set timeout timeout duration in seconds**
5. Server/tacacs+ # **restore**
6. Server/tacacs+ # **commit**

### DETAILED STEPS

|               | Command or Action                                                   | Purpose                                                                                                   |
|---------------|---------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope tacacs+</b>                                        | Enters the TACACS+ command mode.                                                                          |
| <b>Step 2</b> | Server/tacacs+ # <b>set enabled yes/no</b>                          |                                                                                                           |
| <b>Step 3</b> | Server/tacacs+ # <b>set fallback-only-on-no-connectivity yes/no</b> | If you are enabling <b>fallback-only-on-no-connectivity</b> , enter <b>Y</b> to confirm.                  |
| <b>Step 4</b> | Server/tacacs+ # <b>set timeout timeout duration in seconds</b>     | Enter a value between 5 to 30.                                                                            |
| <b>Step 5</b> | Server/tacacs+ # <b>restore</b>                                     | If you wish to restore TACACS+ configuration to default in case of time out, enter <b>yes</b> to confirm. |
| <b>Step 6</b> | Server/tacacs+ # <b>commit</b>                                      | Saves the changes in the system.                                                                          |

### Example

```
Server # scope tacacs+
Server /tacacs+ # set enabled yes
Server /tacacs+ # set fallback-only-on-no-connectivity yes
```

Warning: If TACACS+ and fallback option is enabled, then the fallback to the next precedence database happens only when CIMC is not able to connect to any

```

of the configured TACACS+ servers.
Do you wish to continue? [y/N] y
Server /tacacs+ # set timeout 5
Server /tacacs+ # restore
Are you sure you want to restore TACACS+ configuration to defaults?
Please enter 'yes' to confirm: yes
Restored TACACS+ default configuration.

Server /tacacs+ # commit

```

## Configuring TACACS+ Remote Server Settings

### SUMMARY STEPS

1. Server# **scope tacacs+**
2. Server# **scope tacacs-server** *Server Number*
3. Server/tacacs+/tacacs-server # **set tacacs-port** *Port Number*
4. Server/tacacs+/tacacs-server # **set tacacs-key** *Server Key*
5. Server/tacacs+/tacacs-server # **set tacacs-server** *Server IP Address*
6. Server/tacacs+/tacacs-server # **restore**

### DETAILED STEPS

|               | Command or Action                                                                | Purpose                                                                                                   |
|---------------|----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope tacacs+</b>                                                     | Enters the TACACS+ command mode.                                                                          |
| <b>Step 2</b> | Server# <b>scope tacacs-server</b> <i>Server Number</i>                          | Enters the TACACS server command mode.                                                                    |
| <b>Step 3</b> | Server/tacacs+/tacacs-server # <b>set tacacs-port</b> <i>Port Number</i>         | Enter a value between 1 and 65535.                                                                        |
| <b>Step 4</b> | Server/tacacs+/tacacs-server # <b>set tacacs-key</b> <i>Server Key</i>           | Enter the same key configured on the remote TACACS+ server.                                               |
| <b>Step 5</b> | Server/tacacs+/tacacs-server # <b>set tacacs-server</b> <i>Server IP Address</i> | Enter remote TACACS+ server IP address.                                                                   |
| <b>Step 6</b> | Server/tacacs+/tacacs-server # <b>restore</b>                                    | If you wish to restore TACACS+ configuration to default in case of time out, enter <b>yes</b> to confirm. |

### Example

```

Server # scope tacacs+
Server # scope tacacs-server 1
Server /tacacs+/tacacs-server # set tacacs-port 6
Server /tacacs+/tacacs-server # set tacacs-key xxx
Server /tacacs+/tacacs-server # set tacacs-server xx.xx.xx.xx
Server /tacacs+/tacacs-server # restore
Are you sure you want to restore TACACS+ configuration to defaults?
Please enter 'yes' to confirm: yes
Restored TACACS+ default configuration.

Server /tacacs+/tacacs-server # commit

```

# LDAP Certificates Overview

Cisco S3260 C-series servers allow an LDAP client to validate a directory server certificate against an installed CA certificate or chained CA certificate during an LDAP binding step. This feature is introduced in the event where anyone can duplicate a directory server for user authentication and cause a security breach due to the inability to enter a trusted point or chained certificate into the Cisco IMC for remote user authentication.

An LDAP client needs a new configuration option to validate the directory server certificate during the encrypted TLS/SSL communication.

## Exporting LDAP CA Certificate

### Before you begin

You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. Server# **scope ldap**
2. Server# /ldap **scope binding-certificate**
3. Server /ldap/binding-certificate # **export-ca-certificate** *remote-protocol IP Addresss LDAP CA Certificate file*

### DETAILED STEPS

|               | Command or Action                                                                                                              | Purpose                                                                                                                                                                                                          |
|---------------|--------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope ldap</b>                                                                                                      | Enters the LDAP command mode.                                                                                                                                                                                    |
| <b>Step 2</b> | Server# /ldap <b>scope binding-certificate</b>                                                                                 | Enters the LDAP CA certificate binding command mode.                                                                                                                                                             |
| <b>Step 3</b> | Server /ldap/binding-certificate # <b>export-ca-certificate</b><br><i>remote-protocol IP Addresss LDAP CA Certificate file</i> | Specifies the protocol to connect to the remote server. It can be of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> |



|  | Command or Action | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|--|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  |                   | <p><b>Note</b></p> <p>The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p>Initiates the export of the certificate.</p> |

**Example**

This example exports the LDAP certificate:

```

Server # scope ldap
Server /ldap # scope binding-certificate
Server /ldap/binding-certificate # export-ca-certificate tftp 172.22.141.66 test.csv
Initiating Export
 % Total % Received % Xferd Average Speed Time Time Time Current
 Dload Upload Total Spent Left Speed
100 1262 0 0 100 1262 0 1244 0:00:01 0:00:01 ---:--:-- 1653
100 1262 0 0 100 1262 0 1237 0:00:01 0:00:01 ---:--:-- 1237
LDAP CA Certificate is exported successfully
Server /ldap/binding-certificate #

```

## Testing LDAP Binding

**Before you begin**

You must log in as a user with admin privileges to perform this task.



**Note** If you checked the **Enable Encryption** and the **Enable Binding CA Certificate** check boxes, enter the fully qualified domain name (FQDN) of the LDAP server in the LDAP Server field. To resolve the FQDN of the LDAP server, configure the preferred DNS of Cisco IMC network with the appropriate DNS IP address.

**SUMMARY STEPS**

1. Server# **scope ldap**
2. Server# /ldap **scope binding-certificate**

3. Server /ldap/binding-certificate # **test-ldap-binding** *username*
4. Enter the corresponding password.

#### DETAILED STEPS

|               | Command or Action                                                           | Purpose                                              |
|---------------|-----------------------------------------------------------------------------|------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope ldap</b>                                                   | Enters the LDAP command mode.                        |
| <b>Step 2</b> | Server# /ldap <b>scope binding-certificate</b>                              | Enters the LDAP CA certificate binding command mode. |
| <b>Step 3</b> | Server /ldap/binding-certificate # <b>test-ldap-binding</b> <i>username</i> | Password prompt appears.                             |
| <b>Step 4</b> | Enter the corresponding password.                                           | Authenticates the user.                              |

#### Example

This example tests the LDAP user binding:

```
Server # scope ldap
Server /ldap # scope binding-certificate
Server /ldap/binding-certificate # test-ldap-binding user
Password:
diagldapbinding: Authenticated by LDAP
User user authenticated successfully.
Server /ldap/binding-certificate #
```

## Deleting LDAP CA Certificate

#### Before you begin

You must log in as a user with admin privileges to perform this task.

#### SUMMARY STEPS

1. Server# **scope ldap**
2. Server# /ldap **scope binding-certificate**
3. Server /ldap/binding-certificate # **delete-ca-certificate**
4. At the confirmation prompt, enter **y**.

#### DETAILED STEPS

|               | Command or Action                                               | Purpose                                              |
|---------------|-----------------------------------------------------------------|------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope ldap</b>                                       | Enters the LDAP command mode.                        |
| <b>Step 2</b> | Server# /ldap <b>scope binding-certificate</b>                  | Enters the LDAP CA certificate binding command mode. |
| <b>Step 3</b> | Server /ldap/binding-certificate # <b>delete-ca-certificate</b> | Confirmation prompt appears.                         |
| <b>Step 4</b> | At the confirmation prompt, enter <b>y</b> .                    | This deletes the LDAP CA certificate.                |

**Example**

This example deletes the LDAP certificate:

```
Server # scope ldap
Server /ldap # scope binding-certificate
Server /ldap/binding-certificate # delete-ca-certificate
You are going to delete the LDAP CA Certificate.
Are you sure you want to proceed and delete the LDAP CA Certificate? [y|N]y
LDAP CA Certificate is deleted successfully
Server /ldap/binding-certificate #
```

# Viewing User Sessions

**SUMMARY STEPS**

1. Server# **show user-session**

**DETAILED STEPS**

|               | Command or Action                | Purpose                                           |
|---------------|----------------------------------|---------------------------------------------------|
| <b>Step 1</b> | Server# <b>show user-session</b> | Displays information about current user sessions. |

The command output displays the following information about current user sessions:

| Name                            | Description                                                                                                                                                                                                   |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Terminate Session</b> button | If your user account is assigned the <b>admin</b> user role, this option enables you to force the associated user session to end.<br><br><b>Note</b> You cannot terminate your current session from this tab. |
| <b>Session ID</b> column        | The unique identifier for the session.                                                                                                                                                                        |
| <b>BMC Session ID</b>           | The identifier for the BMC session.                                                                                                                                                                           |
| <b>User Name</b> column         | The username for the user.                                                                                                                                                                                    |
| <b>IP Address</b> column        | The IP address from which the user accessed the server. If this is a serial connection, it displays <b>N/A</b> .                                                                                              |

| Name                | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Session Type column | <p>The type of session the user chose to access the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>webgui</b>— indicates the user is connected to the server using the web UI.</li> <li>• <b>CLI</b>— indicates the user is connected to the server using CLI.</li> <li>• <b>serial</b>— indicates the user is connected to the server using the serial port.</li> <li>• — indicates the user is connected to the server using XML API.</li> <li>• — indicates the user is connected to the server using Redfish API.</li> </ul> |

### Example

This example displays information about current user sessions:

```
Server# show user-session
ID Name IP Address Type Killable

15 admin 10.20.30.138 CLI yes
Server /user #
```

## Terminating a User Session

### Before you begin

You must log in as a user with admin privileges to terminate a user session.

### SUMMARY STEPS

1. Server# **show user-session**
2. Server /user-session # **scope user-session session-number**
3. Server /user-session # **terminate**

### DETAILED STEPS

|               | Command or Action                                               | Purpose                                                                                                                                                            |
|---------------|-----------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>show user-session</b>                                | Displays information about current user sessions. The user session to be terminated must be eligible to be terminated (killable) and must not be your own session. |
| <b>Step 2</b> | Server /user-session # <b>scope user-session session-number</b> | Enters user session command mode for the numbered user session that you want to terminate.                                                                         |
| <b>Step 3</b> | Server /user-session # <b>terminate</b>                         | Terminates the user session.                                                                                                                                       |

### Example

This example shows how the admin at user session 10 terminates user session 15:

```
Server# show user-session
ID Name IP Address Type Killable

10 admin 10.20.41.234 CLI yes
15 admin 10.20.30.138 CLI yes
Server# scope user-session 15
Server /user-session # terminate
User session 15 terminated.

Server /user-session #
```





## CHAPTER 9

# Configuring Network-Related Settings

This chapter includes the following sections:

- [Server NIC Configuration, on page 147](#)
- [Common Properties Configuration, on page 150](#)
- [Configuring Single IP Properties, on page 152](#)
- [Configuring IPv4, on page 153](#)
- [Configuring IPv6, on page 156](#)
- [Configuring ICMP, on page 160](#)
- [Configuring VLAN, on page 161](#)
- [Connecting to a Port Profile, on page 163](#)
- [Configuring Interface Properties, on page 165](#)
- [Network Security Configuration, on page 166](#)
- [Network Time Protocol Configuration, on page 168](#)
- [Pinging an IP address, on page 169](#)

## Server NIC Configuration

### Server NICs

#### NIC Mode

The NIC mode setting determines which ports can reach the Cisco IMC. The following network mode options are available, depending on your platform:

- **Dedicated**—The management port that is used to access the Cisco IMC.
- **Cisco Card**—Any port on the adapter card that can be used to access the Cisco IMC. The Cisco adapter card has to be installed in a slot with Network the Communications Services Interface protocol support (NCSI).
- **Shared LOM**—Any LOM (LAN on Motherboard) port that can be used to access Cisco IMC.
- **Shared LOM Extended**—Any LOM port or adapter card port that can be used to access Cisco IMC. The Cisco adapter card has to be installed in a slot with NCSI support.



---

**Note** **Shared LOM** and **Shared LOM Extended** ports are available only on some C-series servers.

---



---

**Note** For other UCS C-Series M4 and M5 servers, the NIC mode is set to **Shared LOM Extended** by default.

---

#### Default NIC Mode Setting:

- For UCS C-Series C125 M5 servers and S3260 servers, the **NIC Mode** is set to **Cisco Card** by default.

#### NIC Redundancy

The following NIC redundancy options are available, depending on the selected NIC mode and your platform:

- **active-active**—If supported, all ports that are associated with the configured NIC mode operate simultaneously. This feature increases throughput and provides multiple paths to the Cisco IMC.
- **active-standby**—If a port that is associated with the configured NIC mode fails, traffic fails over to one of the other ports associated with the NIC mode.



---

**Note** If you choose this option, make sure that all ports associated with the configured NIC mode are connected to the same subnet to ensure that traffic is secure regardless of which port is used.

---

- **None**—In *Dedicated* mode, NIC redundancy is set to *None*.

The available redundancy modes vary depending on the selected network mode and your platform. For the available modes, see the *Hardware Installation Guide* (HIG) for the type of server you are using. The C-Series HIGs are available at the following URL:

[http://www.cisco.com/en/US/products/ps10493/prod\\_installation\\_guides\\_list.html](http://www.cisco.com/en/US/products/ps10493/prod_installation_guides_list.html)

#### VIC Slots

The VIC slot that can be used for management functions in Cisco card mode.

The following options are available only on some UCS C-Series servers:

- 4
- 5
- 9
- 10





**Note** This option is available only on some UCS C-Series servers.

## Configuring NICs

Configure a server NIC when you want to set the NIC mode and NIC redundancy.

### Before you begin

You must log in as a user with admin privileges to configure the NIC.

### SUMMARY STEPS

1. Server # **scope network**
2. Server /network # **set mode {dedicated | cisco\_card}**
3. Server /network # **set redundancy {none | active-active | active-standby}**
4. Server /network # **commit**

### DETAILED STEPS

|               | Command or Action                                                               | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|---------------|---------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope network</b>                                                   | Enters the network command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Step 2</b> | Server /network # <b>set mode {dedicated   cisco_card}</b>                      | Sets the NIC mode to one of the following: <ul style="list-style-type: none"> <li>• <b>Dedicated</b>—The management Ethernet port is used to access the .</li> <li>• <b>Cisco card</b>—The ports on the adapter card are used to access the .</li> </ul>                                                                                                                                                                                                            |
| <b>Step 3</b> | Server /network # <b>set redundancy {none   active-active   active-standby}</b> | Sets the NIC redundancy mode when the NIC mode is Shared LOM. The redundancy mode can be one of the following: <ul style="list-style-type: none"> <li>• <b>none</b>—The LOM Ethernet ports operate independently and do not fail over if there is a problem.</li> <li>• <b>active-active</b>—If supported, all LOM Ethernet ports are utilized.</li> <li>• <b>active-standby</b>—If one LOM Ethernet port fails, traffic fails over to another LOM port.</li> </ul> |
| <b>Step 4</b> | Server /network # <b>commit</b>                                                 | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                                                                                                                |

|  | Command or Action | Purpose                                                                                                                                                                                                                 |
|--|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  |                   | <p><b>Note</b> The available NIC mode and NIC redundancy mode options may vary depending on your platform. If you select a mode not supported by your server, an error message displays when you save your changes.</p> |

### Example

This example configures the network interface:

## Common Properties Configuration

### Overview to Common Properties Configuration

#### Hostname

The Dynamic Host Configuration Protocol (DHCP) enhancement is available with the addition of the hostname to the DHCP packet, which can either be interpreted or displayed at the DHCP server side. The hostname, which is now added to the options field of the DHCP packet, sent in the DHCP DISCOVER packet that was initially sent to the DHCP server.

The default hostname of the server is changed from ucs-c2XX to CXXX-YYYYYY, where XXX is the model number and YYYYYY is the serial number of the server. This unique string acts as a client identifier, allows you to track and map the IP addresses that are leased out to from the DHCP server. The default serial number is provided by the manufacturer as a sticker or label on the server to help you identify the server.

## Configuring Common Properties

Use common properties to describe your server.

#### Before you begin

You must log in as a user with admin privileges to configure common properties.

#### SUMMARY STEPS

1. Server # **scope network**
2. Server /network # **set hostname-bmc1 hostname-bmc2hostname-cmc1hostname-cmc2host-name**
3. Server /network # **commit**
4. At the prompt, enter **y** to confirm.

## DETAILED STEPS

|               | Command or Action                                                                                       | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|---------------|---------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope network</b>                                                                           | Enters the network command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Step 2</b> | Server /network # <b>set hostname-bmc1<br/>hostname-bmc2hostname-cmc1hostname-cmc2</b> <i>host-name</i> | Specifies the name of the host for the following components: <ul style="list-style-type: none"> <li>• BMC 1</li> <li>• BMC 2</li> <li>• CMC 1</li> <li>• CMC 2</li> </ul> <p>When you modify the hostname, you are prompted to confirm whether you want to create a new self-signed certificate with Common Name (CN) as the new hostname.</p> <p>If you enter <b>y</b> at the prompt, a new self-signed certificate is created with CN as the new hostname.</p> <p>If you enter <b>n</b> at the prompt, only the hostname is changed and no certificate will be generated.</p> |
| <b>Step 3</b> | Server /network # <b>commit</b>                                                                         | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Step 4</b> | At the prompt, enter <b>y</b> to confirm.                                                               | Configures common properties.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

**Example**

This example shows how to configure the common properties:

```
Server # scope network
Server /network # set hostname-cmc1 cmc1
Server /network *# set ddns-enabled
Server /network *# set ddns-update-domain 1.2.3.4
Server /network *# commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network #
```

**What to do next**

Changes to the network are applied immediately. You might lose connectivity to and have to log in again. Because of the new SSH session created, you may be prompted to confirm the host key.

# Configuring Single IP Properties

## Before you begin

You must log in as a user with admin privileges to configure single IP properties.

## SUMMARY STEPS

1. Server # **scope network**
2. Server /network # **set enable-single-ip {yes | no}**
3. Server /network # **set starting-port** *port number*
4. Server /network \* # **commit**
5. Server /network # **show [detail]**

## DETAILED STEPS

|               | Command or Action                                             | Purpose                                                                                                                                                                                                                          |
|---------------|---------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope network</b>                                 | Enters the network command mode.                                                                                                                                                                                                 |
| <b>Step 2</b> | Server /network # <b>set enable-single-ip {yes   no}</b>      | Enables the Single IP feature.                                                                                                                                                                                                   |
| <b>Step 3</b> | Server /network # <b>set starting-port</b> <i>port number</i> | Specifies the starting port number for the single IP configuration. When single IP is enabled ports 9000-9006 are used by Cisco IMC for the starting port configuration. These ports cannot be used for any other configuration. |
| <b>Step 4</b> | Server /network * # <b>commit</b>                             | Choose <b>y</b> at the confirmation prompt, commits the transaction to the system configuration.                                                                                                                                 |
| <b>Step 5</b> | Server /network # <b>show [detail]</b>                        | (Optional) Displays the network settings.                                                                                                                                                                                        |

## Example

This example configures and displays the single IP network settings:

```
Server# scope network
Server /network # set enable-single-ip yes
Server /network * # set starting-port 9000
Server /network * # commit
Server /network # show detail
Chassis Network Setting:
 IPv4 Enabled: yes
 SingleIP Mode: yes
 Starting Port: 10000
 IPv4 Netmask: 255.255.255.0
 IPv4 Gateway: 10.104.236.1
 DHCP Enabled: yes
 DDNS Enabled: yes
 DDNS Update Domain:
 DDNS Refresh Interval(0-8736 Hr): 0
 Obtain DNS Server by DHCP: yes
 Preferred DNS: 10.104.236.99
```

```

Alternate DNS: 0.0.0.0
IPv6 Enabled: yes
IPv6 Prefix: 64
IPv6 Gateway: fe80::3e08:f6ff:fe21:29c0
IPv6 DHCP Enabled: yes
IPv6 Obtain DNS Server by DHCP: yes
IPv6 Preferred DNS: ::
IPv6 Alternate DNS: ::
VLAN Enabled: no
VLAN ID: 1
VLAN Priority: 0
Port Profile:
NIC Mode: cisco_card
NIC Redundancy: active-active
SIOC Slot: 2
Management IPv4 Address: 10.104.236.135
Management IPv6 Address: ::
Management Hostname: S3260-FOX2111P7VD
Auto Negotiate: no
Admin Network Speed: NA
Admin Duplex: NA
Operational Network Speed: NA
Operational Duplex: NA
CMC 1 Network Setting:
IPv6 Address CMC 1: ::
IPv6 Link Local CMC 1: ::
IPv6 SLAAC Address CMC 1: ::
Hostname CMC 1: UCS-C3260-FCH21277KB8-1
MAC Address CMC 1: 96:09:5C:EF:B6:32
CMC 2 Network Setting:
IPv6 Address CMC 2: ::
IPv6 Link Local CMC 2: fe80::522f:a8ff:fed2:34aa
IPv6 SLAAC Address CMC 2: ::
Hostname CMC 2: UCS-C3260-FCH21277KCA-2
MAC Address CMC 2: 50:2F:A8:D2:34:AA
BMC 1 Network Setting:
IPv6 Address BMC 1: ::
IPv6 Link Local BMC 1: fe80::3a90:a5ff:fe7f:a840
IPv6 SLAAC Address BMC 1: ::
Hostname BMC 1: S3X60M5-FCH21187159
MAC Address BMC 1: 38:90:A5:7F:A8:40

Server /network #

```

## Configuring IPv4

### Before you begin

You must log in as a user with admin privileges to configure IPv4 network settings.

### SUMMARY STEPS

1. Server # **scope network**
2. Server /network # **set dhcp-enabled** {yes | no}
3. Server /network # **set v4-addr** *ipv4-address*
4. Server /network # **set v4-netmask** *ipv4-netmask*
5. Server /network # **set v4-gateway** *gateway-ipv4-address*

6. Server /network # **set dns-use-dhcp** {yes | no}
7. Server /network # **set preferred-dns-server** *dns1-ipv4-address*
8. Server /network # **set alternate-dns-server** *dns2-ipv4-address*
9. Server /network # **commit**
10. Server /network # **show** [detail]

## DETAILED STEPS

|                | Command or Action                                                          | Purpose                                                                                                                                                                                                                                                                                                             |
|----------------|----------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b>  | Server # <b>scope network</b>                                              | Enters the network command mode.                                                                                                                                                                                                                                                                                    |
| <b>Step 2</b>  | Server /network # <b>set dhcp-enabled</b> {yes   no}                       | Selects whether the uses DHCP.<br><br><b>Note</b> If DHCP is enabled, we recommend that the DHCP server be configured to reserve a single IP address for the . If the is reachable through multiple ports on the server, the single IP address must be reserved for the full range of MAC addresses of those ports. |
| <b>Step 3</b>  | Server /network # <b>set v4-addr</b> <i>ipv4-address</i>                   | Specifies the IP address for the .                                                                                                                                                                                                                                                                                  |
| <b>Step 4</b>  | Server /network # <b>set v4-netmask</b> <i>ipv4-netmask</i>                | Specifies the subnet mask for the IP address.                                                                                                                                                                                                                                                                       |
| <b>Step 5</b>  | Server /network # <b>set v4-gateway</b> <i>gateway-ipv4-address</i>        | Specifies the gateway for the IP address.                                                                                                                                                                                                                                                                           |
| <b>Step 6</b>  | Server /network # <b>set dns-use-dhcp</b> {yes   no}                       | Selects whether the retrieves the DNS server addresses from DHCP.                                                                                                                                                                                                                                                   |
| <b>Step 7</b>  | Server /network # <b>set preferred-dns-server</b> <i>dns1-ipv4-address</i> | Specifies the IP address of the primary DNS server.                                                                                                                                                                                                                                                                 |
| <b>Step 8</b>  | Server /network # <b>set alternate-dns-server</b> <i>dns2-ipv4-address</i> | Specifies the IP address of the secondary DNS server.                                                                                                                                                                                                                                                               |
| <b>Step 9</b>  | Server /network # <b>commit</b>                                            | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                |
| <b>Step 10</b> | Server /network # <b>show</b> [detail]                                     | (Optional) Displays the IPv4 network settings.                                                                                                                                                                                                                                                                      |

### Example

This example configures and displays the IPv4 network settings:

```
Server # scope network
Server /network # set dhcp-enabled yes
Server /network *# set v4-addr 10.20.30.11
Server /network *# set v4-netmask 255.255.248.0
Server /network *# set v4-gateway 10.20.30.1
Server /network *# set dns-use-dhcp-enabled no
Server /network *# set preferred-dns-server 192.168.30.31
Server /network *# set alternate-dns-server 192.168.30.32
Server /network *# commit

Server /network # show detail
```

```
Network Setting:
 IPv4 Enabled: yes
 IPv4 Netmask: 255.255.248.0
 IPv4 Gateway: 10.20.30.1
 DHCP Enabled: no
 DDNS Enabled: yes
 DDNS Update Domain:
 Obtain DNS Server by DHCP: no
 Preferred DNS: 192.168.30.31
 Alternate DNS: 192.168.30.32
 IPv6 Enabled: no
 IPv6 Prefix: 64
 IPv6 Gateway: ::
 IPV6 DHCP Enabled: no
 IPV6 Obtain DNS Server by DHCP: no
 IPV6 Preferred DNS: ::
 IPV6 Alternate DNS: ::
 VLAN Enabled: no
 VLAN ID: 1
 VLAN Priority: 0
 Port Profile: abcde12345
 NIC Mode: dedicated
 NIC Redundancy: none
 SIOC Slot: 1
 Management IPv4 Address: 10.106.145.202
 Management IPv6 Address: ::
 Management Hostname: S3260-FCH18207WF3
 Network Speed: 100Mbps
 Duplex: full
 Auto Negotiate: yes
 Admin Network Speed: auto
 Admin Duplex: auto
 Operational Network Speed: 1Gbps
 Operational Duplex: full
CMC 1 Network Setting:
 IPv4 Address CMC 1: 10.20.30.11
 IPv6 Address CMC 1: ::
 IPv6 Link Local CMC 1: ::
 IPv6 SLAAC Address CMC 1: ::
 Hostname CMC 1: UCS-S3260-FCH181772ZP-1
 MAC Address CMC 1: F4:CF:E2:77:7F:D2
CMC 2 Network Setting:
 IPv4 Address CMC 2: 10.20.30.11
 IPv6 Address CMC 2: ::
 IPv6 Link Local CMC 2: ::
 IPv6 SLAAC Address CMC 2: ::
 Hostname CMC 2: UCS-S3260--2
 MAC Address CMC 2: F4:CF:E2:77:80:83
BMC 1 Network Setting:
 IPv4 Address BMC 1: 10.20.30.11
 IPv6 Address BMC 1: ::
 IPv6 Link Local BMC 1: ::
 IPv6 SLAAC Address BMC 1: ::
 Hostname BMC 1: S3260-FCH1827K9YT
 MAC Address BMC 1: 7C:0E:CE:5A:EF:26
BMC 2 Network Setting:
 IPv4 Address BMC 2: 10.20.30.11
 IPv6 Address BMC 2: ::
 IPv6 Link Local BMC 2: ::
 IPv6 SLAAC Address BMC 2: ::
 Hostname BMC 2: S3260-FCH18407MYD
 MAC Address BMC 2: A0:EC:F9:85:90:3F
```

```
Server /network #
```

## Configuring IPv6

### Before you begin

You must log in as a user with admin privileges to configure IPv6 network settings.

### SUMMARY STEPS

1. Server # **scope network**
2. Server /network # **set v6-enabled {yes | no}**
3. Server /network # **set v6-dhcp-enabled {yes | no}**
4. Server /network # **set v6-addr-bmc1v6-addr-bmc2v6-addr-cmc1v6-addr-cmc2 v6-addr-mgmtipv6-address**
5. Server /network # **set v6-prefix ipv6-prefix-length**
6. Server /network # **set v6-gateway gateway-ipv6-address**
7. Server /network # **set v6-dns-use-dhcp {yes | no}**
8. Server /network # **set v6-preferred-dns-server dns1-ipv6-address**
9. Server /network # **set v6-alternate-dns-server dns2-ipv6-address**
10. Server /network # **commit**
11. Server /network # **show [detail]**

### DETAILED STEPS

|               | Command or Action                                                                                      | Purpose                                                                                                                                                                                                                                                                                                                        |
|---------------|--------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope network</b>                                                                          | Enters the network command mode.                                                                                                                                                                                                                                                                                               |
| <b>Step 2</b> | Server /network # <b>set v6-enabled {yes   no}</b>                                                     | Enables IPv6.                                                                                                                                                                                                                                                                                                                  |
| <b>Step 3</b> | Server /network # <b>set v6-dhcp-enabled {yes   no}</b>                                                | <p>Selects whether the uses DHCP.</p> <p><b>Note</b> If DHCP is enabled, we recommend that the DHCP server be configured to reserve a single IPv6 address for the . If the is reachable through multiple ports on the server, the single IPv6 address must be reserved for the full range of MAC addresses of those ports.</p> |
| <b>Step 4</b> | Server /network # <b>set v6-addr-bmc1v6-addr-bmc2v6-addr-cmc1v6-addr-cmc2 v6-addr-mgmtipv6-address</b> | <p>Specifies the IP address for the following components:</p> <ul style="list-style-type: none"> <li>• BMC1 IPv6 Address</li> <li>• BMC2 IPv6 Address</li> <li>• CMC1 IPv6 Address</li> <li>• CMC2 IPv6 Address</li> </ul>                                                                                                     |



|                | Command or Action                                                             | Purpose                                                                                                                                     |
|----------------|-------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|
|                |                                                                               | <ul style="list-style-type: none"> <li>• Management IPv6 Address</li> </ul>                                                                 |
| <b>Step 5</b>  | Server /network # <b>set v6-prefix</b> <i>ipv6-prefix-length</i>              | Specifies the prefix length for the IP address.                                                                                             |
| <b>Step 6</b>  | Server /network # <b>set v6-gateway</b> <i>gateway-ipv6-address</i>           | Specifies the gateway for the IP address.                                                                                                   |
| <b>Step 7</b>  | Server /network # <b>set v6-dns-use-dhcp</b> { <b>yes</b>   <b>no</b> }       | <p>Selects whether the retrieves the DNS server addresses from DHCP.</p> <p><b>Note</b> You can use this option only when DHCP enabled.</p> |
| <b>Step 8</b>  | Server /network # <b>set v6-preferred-dns-server</b> <i>dns1-ipv6-address</i> | Specifies the IP address of the primary DNS server.                                                                                         |
| <b>Step 9</b>  | Server /network # <b>set v6-alternate-dns-server</b> <i>dns2-ipv6-address</i> | Specifies the IP address of the secondary DNS server.                                                                                       |
| <b>Step 10</b> | Server /network # <b>commit</b>                                               | Commits the transaction to the system configuration.                                                                                        |
| <b>Step 11</b> | Server /network # <b>show [detail]</b>                                        | (Optional) Displays the IPv6 network settings.                                                                                              |

### Example

This example enables static IPv6 and displays the IPv6 network settings:

```

Server # scope network
Server /network # set v6-enabled yes
Server /network *# set v6-addr-bmcl 2010:201::279
Server /network *# set v6-gateway 2010:201::1
Server /network *# set v6-prefix 64
Server /network *# set v6-dns-use-dhcp no
Server /network *# set v6-preferred-dns-server 2010:201::100
Server /network *# set v6-alternate-dns-server 2010:201::101
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Server /network *# commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network # show detail
Network Setting:
 IPv4 Enabled: yes
 IPv4 Netmask: 255.255.255.0
 IPv4 Gateway: 10.106.145.1
 DHCP Enabled: no
 DDNS Enabled: yes
 DDNS Update Domain:
 Obtain DNS Server by DHCP: no
 Preferred DNS: 171.70.168.183
 Alternate DNS: 0.0.0.0
 IPv6 Enabled: no
 IPv6 Prefix: 64
 IPv6 Gateway: 2010:201::1
 IPV6 DHCP Enabled: no
 IPV6 Obtain DNS Server by DHCP: no
 IPV6 Preferred DNS: 2010:201::100

```

```

IPV6 Alternate DNS: 2010:201::101
VLAN Enabled: no
VLAN ID: 1
VLAN Priority: 0
Port Profile: abcde12345
NIC Mode: dedicated
NIC Redundancy: none
SIOC Slot: 1
Management IPv4 Address: 10.106.145.202
Management IPv6 Address: ::
Management Hostname: S3260-FCH18207WF3
Network Speed: 100Mbps
Duplex: full
Auto Negotiate: yes
Admin Network Speed: auto
Admin Duplex: auto
Operational Network Speed: 1Gbps
Operational Duplex: full
CMC 1 Network Setting:
IPv4 Address CMC 1: 10.106.145.135
IPv6 Address CMC 1: ::
IPv6 Link Local CMC 1: ::
IPv6 SLAAC Address CMC 1: ::
Hostname CMC 1: UCS-S3260-FCH181772ZP-1
MAC Address CMC 1: F4:CF:E2:77:7F:D2
CMC 2 Network Setting:
IPv4 Address CMC 2: 10.106.145.248
IPv6 Address CMC 2: ::
IPv6 Link Local CMC 2: ::
IPv6 SLAAC Address CMC 2: ::
Hostname CMC 2: UCS-S3260--2
MAC Address CMC 2: F4:CF:E2:77:80:83
BMC 1 Network Setting:
IPv4 Address BMC 1: 10.106.145.41
IPv6 Address BMC 1: 2010:201::279
IPv6 Link Local BMC 1: ::
IPv6 SLAAC Address BMC 1: ::
Hostname BMC 1: S3260-FCH1827K9YT
MAC Address BMC 1: 7C:0E:CE:5A:EF:26
BMC 2 Network Setting:
IPv4 Address BMC 2: 10.106.145.39
IPv6 Address BMC 2: ::
IPv6 Link Local BMC 2: ::
IPv6 SLAAC Address BMC 2: ::
Hostname BMC 2: S3260-FCH18407MYD
MAC Address BMC 2: A0:EC:F9:85:90:3F

```

```
Server /network #
```

This example enables DHCP for IPv6 and displays the IPv6 network settings:

```

Server # scope network
Server /network # set v6-enabled yes
Server /network *# set v6-dhcp-enabled yes
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Server /network *# commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network # show detail
Network Setting:
 IPv4 Enabled: yes
 IPv4 Address: 10.106.145.76

```

```
IPv4 Netmask: 255.255.255.0
IPv4 Gateway: 10.106.145.1
DHCP Enabled: yes
DDNS Enabled: yes
DDNS Update Domain: example.com
Obtain DNS Server by DHCP: no
Preferred DNS: 171.70.168.183
Alternate DNS: 0.0.0.0
IPv6 Enabled: yes
IPv6 Address: 2010:201::253
IPv6 Prefix: 64
IPv6 Gateway: fe80::222:df:fec2:8000
IPv6 Link Local: fe80::523d:e5ff:fe9d:395d
IPv6 SLAAC Address: 2010:201::523d:e5ff:fe9d:395d
IPV6 DHCP Enabled: yes
IPV6 Obtain DNS Server by DHCP: no
IPV6 Preferred DNS: ::
IPV6 Alternate DNS: ::
VLAN Enabled: no
VLAN ID: 1
VLAN Priority: 0
Port Profile:
Hostname: CIMC_C220
MAC Address: 50:3D:E5:9D:39:5C
NIC Mode: dedicated
NIC Redundancy: none
Network Speed: 100Mbps
Duplex: full
Auto Negotiate: no
Admin Network Speed: auto
Admin Duplex: auto
Operational Network Speed: 1Gbps
Operational Duplex: full
CMC 1 Network Setting:
IPv4 Address CMC 1: 10.106.145.135
IPv6 Address CMC 1: ::
IPv6 Link Local CMC 1: ::
IPv6 SLAAC Address CMC 1: ::
Hostname CMC 1: UCS-S3260-FCH181772ZP-1
MAC Address CMC 1: F4:CF:E2:77:7F:D2
CMC 2 Network Setting:
IPv4 Address CMC 2: 10.106.145.248
IPv6 Address CMC 2: ::
IPv6 Link Local CMC 2: ::
IPv6 SLAAC Address CMC 2: ::
Hostname CMC 2: UCS-S3260--2
MAC Address CMC 2: F4:CF:E2:77:80:83
BMC 1 Network Setting:
IPv4 Address BMC 1: 10.106.145.41
IPv6 Address BMC 1: ::
IPv6 Link Local BMC 1: ::
IPv6 SLAAC Address BMC 1: ::
Hostname BMC 1: S3260-FCH1827K9YT
MAC Address BMC 1: 7C:0E:CE:5A:EF:26
BMC 2 Network Setting:
IPv4 Address BMC 2: 10.106.145.39
IPv6 Address BMC 2: ::
IPv6 Link Local BMC 2: ::
IPv6 SLAAC Address BMC 2: ::
Hostname BMC 2: S3260-FCH18407MYD
MAC Address BMC 2: A0:EC:F9:85:90:3F

Server /network #
```

# Configuring ICMP

In the release 4.1(3b), Cisco IMC allows you to enable or disable processing of incoming ICMP redirect and destination unreachable packets on BMC.



**Note** This option is available only on Cisco UCS S-series M5 servers.

## Procedure

|               | Command or Action                                                                        | Purpose                                                                   |
|---------------|------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope cimc</b>                                                                | Enters the Cisco IMC command mode.                                        |
| <b>Step 2</b> | Server /cimc # <b>scope network</b>                                                      | Enters the Cisco IMC network command mode.                                |
| <b>Step 3</b> | Server /cimc/network # <b>scope icmp-configuration</b>                                   | Enters the ICMP configuration mode.                                       |
| <b>Step 4</b> | Server /cimc/network/icmp-configuration # <b>show-detail</b>                             | Displays the ICMP configuration settings.                                 |
| <b>Step 5</b> | Server /cimc/network/icmp-configuration # <b>set destination-unreachable-enabled yes</b> | Enables the <b>Destination Unreachable</b> configuration setting in ICMP. |
| <b>Step 6</b> | Server /cimc/network/icmp-configuration # <b>set redirect-enabled yes</b>                | Enables the <b>redirect</b> configuration setting in ICMP.                |
| <b>Step 7</b> | Server /cimc/network/icmp-configuration # <b>commit</b>                                  | Commits the transaction to the system configuration.                      |
| <b>Step 8</b> | Server /cimc/network/icmp-configuration # <b>show-detail</b>                             | Displays the updated ICMP configuration settings.                         |

## Example

This example shows how to configure the ICMP configuration settings:

```

Server# scope cimc
Server /cimc # scope network
Server /cimc/network # scope icmp-configuration
Server /network/icmp-configuration # show detail
ICMP Settings:
 Destination Unreachable Enabled: no
 Redirect Enabled: no
Server /cimc/network/icmp-configuration # set destination-unreachable-enabled yes
Server /cimc/network/icmp-configuration # set redirect yes
Server /cimc/network/icmp-configuration # commit
Server /cimc/network/icmp-configuration # show detail
ICMP Settings:
 Destination Unreachable Enabled: yes
 Redirect Enabled: yes
Server /cimc/network/icmp-configuration #

```

# Configuring VLAN

## Before you begin

You must be logged in as admin to configure the server VLAN.

## SUMMARY STEPS

1. Server # **scope network**
2. Server /network # **set vlan-enabled {yes | no}**
3. Server /network # **set vlan-id id**
4. Server /network # **set vlan-priority priority**
5. Server /network # **commit**
6. Server /network # **show [detail]**

## DETAILED STEPS

|               | Command or Action                                    | Purpose                                              |
|---------------|------------------------------------------------------|------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope network</b>                        | Enters the network command mode.                     |
| <b>Step 2</b> | Server /network # <b>set vlan-enabled {yes   no}</b> | Selects whether the is connected to a VLAN.          |
| <b>Step 3</b> | Server /network # <b>set vlan-id id</b>              | Specifies the VLAN number.                           |
| <b>Step 4</b> | Server /network # <b>set vlan-priority priority</b>  | Specifies the priority of this system on the VLAN.   |
| <b>Step 5</b> | Server /network # <b>commit</b>                      | Commits the transaction to the system configuration. |
| <b>Step 6</b> | Server /network # <b>show [detail]</b>               | (Optional) Displays the network settings.            |

## Example

This example configures the VLAN:

```
Server # scope network
Server /network # set vlan-enabled yes
Server /network *# set vlan-id 5
Server /network *# set vlan-priority 7
Server /network *# commit
```

```
Server /network # show detail
Network Setting:
 IPv4 Enabled: yes
 IPv4 Netmask: 255.255.255.0
 IPv4 Gateway: 10.106.145.1
 DHCP Enabled: no
 DDNS Enabled: yes
 DDNS Update Domain:
 Obtain DNS Server by DHCP: no
 Preferred DNS: 171.70.168.183
 Alternate DNS: 0.0.0.0
```

```

IPv6 Enabled: no
IPv6 Prefix: 64
IPv6 Gateway: ::
IPV6 DHCP Enabled: no
IPV6 Obtain DNS Server by DHCP: no
IPV6 Preferred DNS: ::
IPV6 Alternate DNS: ::
VLAN Enabled: yes
VLAN ID: 2
VLAN Priority: 7
Port Profile: abcde12345
NIC Mode: dedicated
NIC Redundancy: none
SIOC Slot: 1
Management IPv4 Address: 10.106.145.202
Management IPv6 Address: ::
Management Hostname: S3260-FCH18207WF3
Network Speed: 100Mbps
Duplex: full
Auto Negotiate: yes
Admin Network Speed: auto
Admin Duplex: auto
Operational Network Speed: 1Gbps
Operational Duplex: full
CMC 1 Network Setting:
IPv4 Address CMC 1: 10.106.145.135
IPv6 Address CMC 1: ::
IPv6 Link Local CMC 1: ::
IPv6 SLAAC Address CMC 1: ::
Hostname CMC 1: UCS-S3260-FCH181772ZP-1
MAC Address CMC 1: F4:CF:E2:77:7F:D2
CMC 2 Network Setting:
IPv4 Address CMC 2: 10.106.145.248
IPv6 Address CMC 2: ::
IPv6 Link Local CMC 2: ::
IPv6 SLAAC Address CMC 2: ::
Hostname CMC 2: UCS-S3260--2
MAC Address CMC 2: F4:CF:E2:77:80:83
BMC 1 Network Setting:
IPv4 Address BMC 1: 10.106.145.41
IPv6 Address BMC 1: ::
IPv6 Link Local BMC 1: ::
IPv6 SLAAC Address BMC 1: ::
Hostname BMC 1: S3260-FCH1827K9YT
MAC Address BMC 1: 7C:0E:CE:5A:EF:26
BMC 2 Network Setting:
IPv4 Address BMC 2: 10.106.145.39
IPv6 Address BMC 2: ::
IPv6 Link Local BMC 2: ::
IPv6 SLAAC Address BMC 2: ::
Hostname BMC 2: S3260-FCH18407MYD
MAC Address BMC 2: A0:EC:F9:85:90:3F

Server /network #

```

# Connecting to a Port Profile



**Note** You can configure a port profile or a VLAN, but you cannot use both. If you want to use a port profile, make sure the `set vlan-enabled` command is set to `no`.

## Before you begin

You must be logged in as admin to connect to a port profile.

## SUMMARY STEPS

1. Server # `scope network`
2. Server /network # `set port-profile port_profile_name`
3. Server /network # `commit`
4. (Optional) Server /network # `show [detail]`

## DETAILED STEPS

|               | Command or Action                                                 | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|---------------|-------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <code>scope network</code>                               | Enters the <code>network</code> command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Step 2</b> | Server /network # <code>set port-profile port_profile_name</code> | Specifies the port profile should use to configure the management interface, the virtual Ethernet, and the VIF on supported adapter cards such as the Cisco UCS VIC 1225 Virtual Interface Card.<br><br>Enter up to 80 alphanumeric characters. You cannot use spaces or other special characters except for - (hyphen) and _ (underscore). In addition, the port profile name cannot begin with a hyphen.<br><br><b>Note</b> The port profile must be defined on the switch to which this server is connected. |
| <b>Step 3</b> | Server /network # <code>commit</code>                             | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Step 4</b> | (Optional) Server /network # <code>show [detail]</code>           | Displays the network settings.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

## Example

This example connects to port profile abcde12345:

```
Server # scope network
Server /network # set port-profile abcde12345
Server /network *# commit

Server /network # show detail
Network Setting:
```

```

IPv4 Enabled: yes
IPv4 Netmask: 255.255.255.0
IPv4 Gateway: 10.106.145.1
DHCP Enabled: no
DDNS Enabled: yes
DDNS Update Domain:
Obtain DNS Server by DHCP: no
Preferred DNS: 171.70.168.183
Alternate DNS: 0.0.0.0
IPv6 Enabled: no
IPv6 Prefix: 64
IPv6 Gateway: ::
IPV6 DHCP Enabled: no
IPV6 Obtain DNS Server by DHCP: no
IPV6 Preferred DNS: ::
IPV6 Alternate DNS: ::
VLAN Enabled: no
VLAN ID: 1
VLAN Priority: 0
Port Profile: abcde12345
NIC Mode: dedicated
NIC Redundancy: none
SIOC Slot: 1
Management IPv4 Address: 10.106.145.202
Management IPv6 Address: ::
Management Hostname: S3260-FCH18207WF3
Network Speed: 100Mbps
Duplex: full
Auto Negotiate: yes
Admin Network Speed: auto
Admin Duplex: auto
Operational Network Speed: 1Gbps
Operational Duplex: full
CMC 1 Network Setting:
IPv4 Address CMC 1: 10.106.145.135
IPv6 Address CMC 1: ::
IPv6 Link Local CMC 1: ::
IPv6 SLAAC Address CMC 1: ::
Hostname CMC 1: UCS-S3260-FCH181772ZP-1
MAC Address CMC 1: F4:CF:E2:77:7F:D2
CMC 2 Network Setting:
IPv4 Address CMC 2: 10.106.145.248
IPv6 Address CMC 2: ::
IPv6 Link Local CMC 2: ::
IPv6 SLAAC Address CMC 2: ::
Hostname CMC 2: UCS-S3260--2
MAC Address CMC 2: F4:CF:E2:77:80:83
BMC 1 Network Setting:
IPv4 Address BMC 1: 10.106.145.41
IPv6 Address BMC 1: ::
IPv6 Link Local BMC 1: ::
IPv6 SLAAC Address BMC 1: ::
Hostname BMC 1: S3260-FCH1827K9YT
MAC Address BMC 1: 7C:0E:CE:5A:EF:26
BMC 2 Network Setting:
IPv4 Address BMC 2: 10.106.145.39
IPv6 Address BMC 2: ::
IPv6 Link Local BMC 2: ::
IPv6 SLAAC Address BMC 2: ::
Hostname BMC 2: S3260-FCH18407MYD
MAC Address BMC 2: A0:EC:F9:85:90:3F

Server /network #

```



# Configuring Interface Properties

The settings on the switch must match with the settings to avoid any speed or duplex mismatch.

## SUMMARY STEPS

1. Server # **scope network**
2. Server /network\* # **set mode dedicated**
3. Server /network\* # **set auto-negotiate {yes | no}**
4. Server /network\* # **set duplex {full | half}**

## DETAILED STEPS

|               | Command or Action                                       | Purpose                                                                                                                                                                                                                                                                                                                                                                                             |
|---------------|---------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope network</b>                           | Enters the network command mode.                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Step 2</b> | Server /network* # <b>set mode dedicated</b>            | Enters dedicated command mode.                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Step 3</b> | Server /network* # <b>set auto-negotiate {yes   no}</b> | Enables or disables auto negotiation command mode. <ul style="list-style-type: none"> <li>• If you enter <b>yes</b>, the setting for duplex will be ignored by the system. The retains the speed at which the switch is configured.</li> <li>• If you enter <b>no</b>, you can set duplex. Else, a default speed of 100 Mbps will be applied, and duplex will retain its previous value.</li> </ul> |
| <b>Step 4</b> | Server /network* # <b>set duplex {full   half}</b>      | Sets specified duplex mode type. By default, the duplex mode is set to <b>Full</b>                                                                                                                                                                                                                                                                                                                  |

## Example

This example shows how to configure the interface properties and commit the transaction:

```
Server # scope network
Server /network* # set mode dedicated
Server /network* # set auto-negotiate no
Warning: You have chosen to set auto negotiate to no
If speed and duplex are not set then a default speed of 100Mbps will be applied
Duplex will retain its previous value
Server /network* # commit
Server /network # set duplex full
Server /network* # commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Server /network #
```

# Network Security Configuration

## Network Security

The uses IP blocking as network security. IP blocking prevents the connection between a server or website and certain IP addresses or ranges of addresses. IP blocking effectively bans undesired connections from those computers to a website, mail server, or other Internet servers.

IP banning is commonly used to protect against denial of service (DoS) attacks. bans IP addresses by setting up an IP blocking fail count.

## Configuring Network Security

Configure network security if you want to set up an IP blocking fail count.

### Before you begin

You must log in as a user with admin privileges to configure network security.

### SUMMARY STEPS

1. Server # **scope network**
2. Server /network # **scope ipblocking**
3. Server /network/ipblocking # **set enabled {yes | no}**
4. Server /network/ipblocking # **set fail-count fail-count**
5. Server /network/ipblocking # **set fail-window fail-seconds**
6. Server /network/ipblocking # **set penalty-time penalty-seconds**
7. Server /network/ipblocking # **commit**
8. Server /network/ipblocking # **exit**
9. Server /network # **scope ipfiltering**
10. Server /network/ipfiltering # **set enabled {yes | no}**
11. Server /network/ipfiltering # **set filter-1 IPv4 or IPv6 address or a range of IP addresses**
12. Server /network/ipfiltering # **commit**

### DETAILED STEPS

|               | Command or Action                                             | Purpose                                                                                                                                    |
|---------------|---------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope network</b>                                 | Enters the network command mode.                                                                                                           |
| <b>Step 2</b> | Server /network # <b>scope ipblocking</b>                     | Enters the IP blocking command mode.                                                                                                       |
| <b>Step 3</b> | Server /network/ipblocking # <b>set enabled {yes   no}</b>    | Enables or disables IP blocking.                                                                                                           |
| <b>Step 4</b> | Server /network/ipblocking # <b>set fail-count fail-count</b> | Sets the number of times a user can attempt to log in unsuccessfully before the system locks that user out for a specified length of time. |

|                | Command or Action                                                                                        | Purpose                                                                                                                                                                                   |
|----------------|----------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                |                                                                                                          | The number of unsuccessful login attempts must occur within the time frame specified in the IP Blocking Fail Window field.<br><br>Enter an integer between 3 and 10.                      |
| <b>Step 5</b>  | Server /network/ipblocking # <b>set fail-window</b> <i>fail-seconds</i>                                  | Sets the length of time, in seconds, in which the unsuccessful login attempts must occur in order for the user to be locked out.<br><br>Enter an integer between 60 and 120.              |
| <b>Step 6</b>  | Server /network/ipblocking # <b>set penalty-time</b> <i>penalty-seconds</i>                              | Sets the number of seconds the user remains locked out if they exceed the maximum number of login attempts within the specified time window.<br><br>Enter an integer between 300 and 900. |
| <b>Step 7</b>  | Server /network/ipblocking # <b>commit</b>                                                               | Commits the transaction to the system configuration.                                                                                                                                      |
| <b>Step 8</b>  | Server /network/ipblocking # <b>exit</b>                                                                 | Exits the IP blocking to the network command mode.                                                                                                                                        |
| <b>Step 9</b>  | Server /network # <b>scope ipfiltering</b>                                                               | Enters the IP filtering command mode.                                                                                                                                                     |
| <b>Step 10</b> | Server /network/ipfiltering # <b>set enabled</b> {yes   no}                                              | Enables or disables IP filtering. At the prompt enter <b>y</b> to enable IP filtering.                                                                                                    |
| <b>Step 11</b> | Server /network/ipfiltering # <b>set filter-1</b> <i>IPv4 or IPv6 address or a range of IP addresses</i> | You can set four IP filters. You can assign an IPv4 or IPv6 IP address or a range of IP addresses.                                                                                        |
| <b>Step 12</b> | Server /network/ipfiltering # <b>commit</b>                                                              | Commits the transaction to the system configuration.                                                                                                                                      |

### Example

This example configures network security:

```

Server # scope network
Server /network # scope ipblocking
Server /network/ipblocking # set enabled yes
Server /network/ipblocking *# set fail-count 5
Server /network/ipblocking *# set fail-window 90
Server /network/ipblocking *# set penalty-time 600
Server /network/ipblocking *# commit
Server /network/ipblocking # exit
Server /network # scope ipfiltering
Server /network/ipfiltering # set enabled yes
This will enable IP Filtering
Do you wish to continue? [y/N] y
Server /network/ipfiltering *# set filter-1 1.1.1.1-255.255.255.255
 set filter-2 10.10.10.10
 set filter-3 2001:xxx::-2xxx:xx8::0001
 set filter-4
2001:xxx::-2xxx:xx8::0001-2001:xxx::-2xxx:xx8::0020
Server /network/ipfiltering *# commit
Changes to the ipfiltering will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.

```

Do you wish to continue? [y/N] **Y**

# Network Time Protocol Configuration

## Configuring Network Time Protocol Settings

By default, when `is` is reset, it synchronizes the time with the host. With the introduction of the NTP service, you can configure `is` to synchronize the time with an NTP server. The NTP server does not run in `is` by default. You must enable and configure the NTP service by specifying the IP/DNS address of at least one server or a maximum of four servers that function as NTP servers or time source servers. When you enable the NTP service, `is` synchronizes the time with the configured NTP server. The NTP service can be modified only through `is`.



**Note** To enable the NTP service, it is preferable to specify the IP address of a server rather than the DNS address.

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope time**
2. Server /time # **scope ntp**
3. Server /time/ntp # **set enabled yes**
4. Server /time/ntp\* # **commit**
5. Server /time/ntp # **set server-1 10.120.33.44**
6. Server /time/ntp # **set server-2 10.120.34.45**
7. Server /time/ntp # **set server-3 10.120.35.46**
8. Server /time/ntp # **set server-4 10.120.36.48**
9. Server /time/ntp # **commit**
10. Server /time/ntp # **show detail**

### DETAILED STEPS

|               | Command or Action                         | Purpose                                |
|---------------|-------------------------------------------|----------------------------------------|
| <b>Step 1</b> | Server # <b>scope time</b>                | Enters time command mode.              |
| <b>Step 2</b> | Server /time # <b>scope ntp</b>           | Enters NTP service command mode.       |
| <b>Step 3</b> | Server /time/ntp # <b>set enabled yes</b> | Enables the NTP service on the server. |
| <b>Step 4</b> | Server /time/ntp* # <b>commit</b>         | Commits the transaction.               |

|                | Command or Action                                   | Purpose                                                                                                      |
|----------------|-----------------------------------------------------|--------------------------------------------------------------------------------------------------------------|
| <b>Step 5</b>  | Server /time/ntp # <b>set server-1 10.120.33.44</b> | Specifies the IP/DNS address of one of the four servers that act as an NTP server or the time source server. |
| <b>Step 6</b>  | Server /time/ntp # <b>set server-2 10.120.34.45</b> | Specifies the IP/DNS address of one of the four servers that act as an NTP server or the time source server. |
| <b>Step 7</b>  | Server /time/ntp # <b>set server-3 10.120.35.46</b> | Specifies the IP/DNS address of one of the four servers that act as an NTP server or the time source server. |
| <b>Step 8</b>  | Server /time/ntp # <b>set server-4 10.120.36.48</b> | Specifies the IP/DNS address of one of the four servers that act as an NTP server or the time source server. |
| <b>Step 9</b>  | Server /time/ntp # <b>commit</b>                    | Commits the transaction.                                                                                     |
| <b>Step 10</b> | Server /time/ntp # <b>show detail</b>               | Displays the NTP configuration details.                                                                      |

### Example

This example shows how to configure the NTP service:

```

Server # scope time
Server /time # scope ntp
Server /time/ntp # set enabled yes
Warning: IPMI Set SEL Time Command will be
disabled if NTP is enabled.
Do you wish to continue? [y|N]
y
Server /time/ntp* # commit
Server /time/ntp # set server-1 10.120.33.44
Server /time/ntp* # set server-2 10.120.34.45
Server /time/ntp* # set server-3 10.120.35.46
Server /time/ntp* # set server-4 10.120.36.48
Server /time/ntp* # commit
Server /time/ntp # show details
NTP Service Settings:
 NTP Enabled: yes
 NTP Server 1: 10.120.33.44
 NTP Server 2: 10.120.34.45
 NTP Server 3: 10.120.35.46
 NTP Server 4: 10.120.36.48
 Status: NTP service enabled

```

## Pinging an IP address

Ping an IP address when you want to validate network connectivity with the IP address in the Cisco IMC.

### Before you begin

You must log in as a user with administration privileges to ping an IP address.

## SUMMARY STEPS

1. Server # **scope network**
2. Server /network# **ping IP address | retriesnumber | timeoutseconds**
3. Server /network # **commit**

## DETAILED STEPS

|               | Command or Action                                                        | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|---------------|--------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope network</b>                                            | Enters the network command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Step 2</b> | Server /network# <b>ping IP address   retriesnumber   timeoutseconds</b> | <p>Pings the IP address or host name for a specified number of times until timeout.</p> <ul style="list-style-type: none"> <li>• <b>IP address/hostname</b> - The IP address or the host name of the server.</li> <li>• <b>Number of retries</b> - The number of times the system tries to connect to the server. Default value is 3. Valid range is from 1 to 10.</li> <li>• <b>Timeout</b> - The number of seconds the system waits before it stops pinging. Default maximum value is 20 seconds. Valid range is from 1 to 20 seconds.</li> <li>• <b>Component</b> - The controller that you can ping.</li> </ul> |
| <b>Step 3</b> | Server /network # <b>commit</b>                                          | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |

## Example

This example pings an IP address:

```

Server # scope network
Server /network # ping 10.10.10.10
PING 10.10.10.10 (10.10.10.10): 56 data bytes
64 bytes from 10.10.10.10: seq=0 ttl=238 time=146.343 ms
64 bytes from 10.10.10.10: seq=1 ttl=238 time=146.140 ms
64 bytes from 10.10.10.10: seq=2 ttl=238 time=146.238 ms

--- 10.10.10.10 ping statistics ---
3 packets transmitted, 3 packets received, 0% packet loss
round-trip min/avg/max = 146.140/146.240/146.343 ms
Server /cimc/network #

```



## CHAPTER 10

# Managing Network Adapters

---

This chapter includes the following sections:

- [Overview of the Cisco UCS C-Series Network Adapters, on page 171](#)
- [Viewing Network Adapter Properties, on page 173](#)
- [Configuring Network Adapter Properties, on page 174](#)
- [Managing vHBAs, on page 177](#)
- [Managing vNICs, on page 192](#)
- [Backing Up and Restoring the Adapter Configuration, on page 218](#)
- [Managing Adapter Firmware, on page 221](#)

## Overview of the Cisco UCS C-Series Network Adapters



---

**Note** The procedures in this chapter are available only when a Cisco UCS C-Series network adapter is installed in the chassis.

---

A Cisco UCS C-Series network adapter can be installed to provide options for I/O consolidation and virtualization support. The following adapters are available:

- Cisco UCS VIC 15238 Virtual Interface Card
- Cisco UCS VIC 15428 Virtual Interface Card
- Cisco UCS VIC 1497 Virtual Interface Card
- Cisco UCS VIC 1495 Virtual Interface Card
- Cisco UCS VIC 1457 Virtual Interface Card
- Cisco UCS VIC 1455 Virtual Interface Card
- Cisco UCS VIC 1387 Virtual Interface Card
- Cisco UCS VIC 1385 Virtual Interface Card
- Cisco UCS VIC 1227T Virtual Interface Card
- Cisco UCS VIC 1225 Virtual Interface Card



---

**Note** You must have same generation VIC cards on a server. For example, you cannot have a combination of 3rd generation and 4th generation VIC cards on a single server.

---

The interactive *UCS Hardware and Software Interoperability Utility* lets you view the supported components and configurations for a selected server model and software release. The utility is available at the following URL: <http://www.cisco.com/web/techdoc/ucs/interoperability/matrix/matrix.html>

#### **Cisco UCS VIC 1497 Virtual Interface Card**

The Cisco VIC 1497 is a dual-port Small Form-Factor (QSFP28) mLOM card designed for the M5 generation of Cisco UCS C-Series Rack Servers. The card supports 40/100-Gbps Ethernet and FCoE. The card can present PCIe standards-compliant interfaces to the host, and these can be dynamically configured as NICs and HBAs.

#### **Cisco UCS VIC 1495 Virtual Interface Card**

The Cisco UCS VIC 1495 is a dual-port Small Form-Factor (QSFP28) PCIe card designed for the M5 generation of Cisco UCS C-Series Rack Servers. The card supports 40/100-Gbps Ethernet and FCoE. The card can present PCIe standards-compliant interfaces to the host, and these can be dynamically configured as NICs and HBAs.

#### **Cisco UCS VIC 1457 Virtual Interface Card**

The Cisco UCS VIC 1457 is a quad-port Small Form-Factor Pluggable (SFP28) mLOM card designed for M5 generation of Cisco UCS C-Series rack servers. The card supports 10/25-Gbps Ethernet or FCoE. It incorporates Cisco's next-generation CNA technology and offers a comprehensive feature set, providing investment protection for future feature software releases. The card can present PCIe standards-compliant interfaces to the host, and these can be dynamically configured as NICs and HBAs.

#### **Cisco UCS VIC 1455 Virtual Interface Card**

The Cisco UCS VIC 1455 is a quad-port Small Form-Factor Pluggable (SFP28) half-height PCIe card designed for M5 generation of Cisco UCS C-Series rack servers. The card supports 10/25-Gbps Ethernet or FCoE. It incorporates Cisco's next-generation CNA technology and offers a comprehensive feature set, providing investment protection for future feature software releases. The card can present PCIe standards-compliant interfaces to the host, and these can be dynamically configured as NICs and HBAs.

#### **Cisco UCS VIC 1387 Virtual Interface Card**

The Cisco UCS VIC 1387 Virtual Interface Card is a dual-port Enhanced Quad Small Form-Factor Pluggable (QSFP) 40 Gigabit Ethernet and Fibre Channel over Ethernet (FCoE)-capable half-height PCI Express (PCIe) card designed exclusively for Cisco UCS C-Series Rack Servers. It incorporates Cisco's next-generation converged network adapter (CNA) technology, with a comprehensive feature set, providing investment protection for future feature software releases.

#### **Cisco UCS VIC 1385 Virtual Interface Card**

The Cisco UCS VIC 1385 Virtual Interface Card is a dual-port Enhanced Quad Small Form-Factor Pluggable (QSFP) 40 Gigabit Ethernet and Fibre Channel over Ethernet (FCoE)-capable half-height PCI Express (PCIe) card designed exclusively for Cisco UCS C-Series Rack Servers. It incorporates Cisco's next-generation converged network adapter (CNA) technology, with a comprehensive feature set, providing investment protection for future feature software releases.



### Cisco UCS VIC 1227T Virtual Interface Card

The Cisco UCS VIC 1227T Virtual Interface Card is a dual-port 10GBASE-T (RJ-45) 10-Gbps Ethernet and Fibre Channel over Ethernet (FCoE)-capable PCI Express (PCIe) modular LAN-on-motherboard (mLOM) adapter designed exclusively for Cisco UCS C-Series Rack Servers. New to Cisco rack servers, the mLOM slot can be used to install a Cisco VIC without consuming a PCIe slot, which provides greater I/O expandability. It incorporates next-generation converged network adapter (CNA) technology from Cisco, providing Fibre Channel connectivity over low-cost twisted pair cabling with a bit error rate (BER) of 10 to 15 up to 30 meters and investment protection for future feature releases.

### Cisco UCS VIC 1225 Virtual Interface Card

The Cisco UCS VIC 1225 Virtual Interface Card is a high-performance, converged network adapter that provides acceleration for the various new operational modes introduced by server virtualization. It brings superior flexibility, performance, and bandwidth to the new generation of Cisco UCS C-Series Rack-Mount Servers.

## Viewing Network Adapter Properties

### Procedure

|               | Command or Action                                                        | Purpose                                                                                                                               |
|---------------|--------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                             | Enters the chassis command mode.                                                                                                      |
| <b>Step 2</b> | Server /chassis # <b>show adapter</b> [ <i>index</i> ] [ <i>detail</i> ] | Displays adapter properties. To display the properties of a single adapter, specify the PCI slot number as the <i>index</i> argument. |

### Example

- This example displays the properties of adapter:

```
Server# scope chassis
Server /chassis # show adapter
PCI Slot Product Name Serial Number Product ID Vendor

11 UCS VIC 1455 FCH233770S8 UCSC-PCIE-C... Cisco Systems Inc
Server /chassis # show adapter detail
PCI Slot 11:
 Product Name: UCS VIC 1455
 Serial Number: FCH233770S8
 Product ID: UCSC-PCIE-C25Q-04
 Adapter Hardware Revision: 5
 Current FW Version: 5.1(1.64)
 VNTAG: Disabled
 FIP: Enabled
 LLDP: Enabled
 PORT CHANNEL: Enabled
 Configuration Pending: no
 Cisco IMC Management Enabled: no
 VID: V04
 Vendor: Cisco Systems Inc
 Description:
```

```

Bootloader Version: 5.0(3c)
FW Image 1 Version: 5.1(1.64)
FW Image 1 State: RUNNING ACTIVATED
FW Image 2 Version: 5.1(1.59)
FW Image 2 State: BACKUP INACTIVATED
FW Update Status: Fwupdate never issued
FW Update Error: No error
FW Update Stage: No operation (0%)
FW Update Overall Progress: 0%
Server /chassis #

```

## Configuring Network Adapter Properties

### Before you begin

- You must log in with admin privileges to perform this task.
- A supported Virtual Interface Card (VIC) must be installed in the chassis and the server must be powered on.

### Procedure

|               | Command or Action                                                                | Purpose                                                                                                                                                                                                                                                                                                                                     |
|---------------|----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                     | Enters the chassis command mode.                                                                                                                                                                                                                                                                                                            |
| <b>Step 2</b> | Server /chassis # <b>show adapter</b>                                            | (Optional) Displays the available adapter devices.                                                                                                                                                                                                                                                                                          |
| <b>Step 3</b> | Server /chassis # <b>scope adapter</b> <i>index</i>                              | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings.                                                                                                                                            |
| <b>Step 4</b> | Server /chassis/adapter # <b>set fip-mode</b> { <b>disable</b>   <b>enable</b> } | Enables or disables FCoE Initialization Protocol (FIP) on the adapter card. FIP is enabled by default.<br><br><b>Note</b> <ul style="list-style-type: none"> <li>• We recommend that you disable this option only when explicitly directed to do so by a technical support representative.</li> </ul>                                       |
| <b>Step 5</b> | Server /chassis/adapter # <b>set lldp</b> { <b>disable</b>   <b>enable</b> }     | <b>Note</b> For LLDP change to be effective, it is required that you reboot the server.<br><br>In case of S3260 chassis with two nodes, ensure to reboot the secondary node after making LLDP changes in the primary node.<br><br>Enables or disables Link Layer Discovery Protocol (LLDP) on the adapter card. LLDP is enabled by default. |

|               | Command or Action                                                    | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------|----------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                                      | <p><b>Note</b> We recommend that you do not disable LLDP option, as it disables all the Data Center Bridging Capability Exchange protocol (DCBX) functionality.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Step 6</b> | Server /chassis/adapter # <b>set vntag-mode {disabled   enabled}</b> | <p>Enables or disables VNTAG on the adapter card. VNTAG is disabled by default.</p> <p><b>Note</b><br/>If VNTAG mode is enabled:</p> <ul style="list-style-type: none"> <li>• vNICs and vHBAs can be assigned to a specific channel.</li> <li>• vNICs and vHBAs can be associated to a port profile.</li> <li>• vNICs can fail over to another vNIC if there are communication problems.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Step 7</b> | Server /chassis/adapter # <b>set portchannel disabled</b>            | <p>Allows you to enable or disable the port channel. When you disable port channel, four vNICs and vHBAs are available for use on the adapter.</p> <p>When Port channel is enabled:</p> <ul style="list-style-type: none"> <li>• Only two vNICs and vHBAs are available for use.</li> <li>• Port 0 and 1 are bundled as one port channel and Port 2 and 3 are bundled as the other port channel.</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• This option is enabled by default on Cisco UCS VIC 1455 and 1457.</li> <li>• When you change the port channel configuration, all the previously created vNICs and vHBAs will be deleted and the configuration will be restored to factory defaults.</li> <li>• VNTAG mode is supported only in the port-channel mode.</li> </ul> |
| <b>Step 8</b> | Server /chassis/adapter # <b>set physical-nic-mode enabled</b>       | <p>Allows you to enable or disable the physical NIC mode. This option is disabled by default.</p> <p>When Physical NIC Mode is enabled, up-link ports of the VIC are set to pass-through mode. This allows the host to transmit packets without any modification. VIC ASIC does not rewrite the VLAN tag of the packets based on the VLAN and CoS settings for the vNIC.</p>                                                                                                                                                                                                                                                                                                                                                                                                                             |

|               | Command or Action                        | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|---------------|------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                          | <p><b>Note</b></p> <p>This option is available only for Cisco UCS VIC 14xx series and 15xxx series adapters.</p> <p>For the VIC configuration changes to be effective, you must reboot the host.</p> <p>This option cannot be enabled on an adapter that has:</p> <ul style="list-style-type: none"> <li>• <b>Port Channel mode</b> enabled</li> <li>• <b>VNTAG mode</b> enabled</li> <li>• <b>LLDP</b> enabled</li> <li>• <b>FIP mode</b> enabled</li> <li>• <b>Cisco IMC Management Enabled</b> value set to <b>Yes</b></li> <li>• multiple user created vNICs</li> </ul> |
| <b>Step 9</b> | Server /chassis/adapter* # <b>commit</b> | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |

### Example

This example configures the properties of adapter 1:

```

Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # set fip-mode enable
Server /chassis/adapter *# set vntag-mode enabled
Server /chassis/adapter* # set portchannel disabled
Server /chassis/adapter *# commit
Warning: Enabling VNTAG mode
All the vnic configuration will be reset to factory defaults
New vNIC adapter settings will take effect upon the next server reset
Server /chassis/adapter # show detail
PCI Slot 1:
 Product Name: UCS VIC xxxx
 Serial Number: FCHXXXXXZV4
 Product ID: UCSC-PCIE-xxx-04
 Adapter Hardware Revision: 3
 Current FW Version: x.0(0.345)
 VNTAG: Enabled
 FIP: Enabled
 LLDP: Enabled
 PORT CHANNEL: Disabled
 Configuration Pending: no
 Cisco IMC Management Enabled: no
 VID: V00
 Vendor: Cisco Systems Inc
 Description:
 Bootloader Version: xxx
 FW Image 1 Version: x.0(0.345)
 FW Image 1 State: RUNNING ACTIVATED
 FW Image 2 Version: gafskl-dev-170717-1500-orosz-ET

```

```

FW Image 2 State: BACKUP INACTIVATED
FW Update Status: Fwupdate never issued
FW Update Error: No error
FW Update Stage: No operation (0%)
FW Update Overall Progress: 0%
Server /chassis/adapter #

```

# Managing vHBAs

## Guidelines for Managing vHBAs

When managing vHBAs, consider the following guidelines and restrictions:

- The SIOCs with the Cisco UCS Virtual Interface Cards provide two vHBAs and two vNICs by default. You can create up to 14 additional vHBAs or vNICs on these adapter cards.

The Cisco UCS 1455 and 1457 Virtual Interface Cards, in non-port channel mode, provide four vHBAs and four vNICs by default. You can create up to 10 additional vHBAs or vNICs on these adapter cards in VNTAG mode.




---

**Note** If VNTAG mode is enabled for the adapter, you must assign a channel number to a vHBA when you create it.

---

- When using the Cisco UCS Virtual Interface Cards in an FCoE application, you must associate the vHBA with the FCoE VLAN. Follow the instructions in the **Modifying vHBA Properties** section to assign the VLAN.
- After making configuration changes, you must reboot the host for settings to take effect.

## Viewing vHBA Properties

### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter index**
3. Server /chassis/adapter # **show host-fc-if [fc0 | fc1 | name] [detail]**

### DETAILED STEPS

|        | Command or Action                            | Purpose                                                                                                                                                                                          |
|--------|----------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Server# <b>scope chassis</b>                 | Enters the chassis command mode.                                                                                                                                                                 |
| Step 2 | Server /chassis # <b>scope adapter index</b> | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings. |

|               | Command or Action                                                                                               | Purpose                                                           |
|---------------|-----------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------|
| <b>Step 3</b> | Server /chassis/adapter # <b>show host-fc-if</b> [ <b>fc0</b>   <b>fc1</b>   <i>name</i> ]<br>[ <b>detail</b> ] | Displays properties of a single vHBA, if specified, or all vHBAs. |

### Example

This example displays all vHBAs on adapter card 1 and the detailed properties of fc0:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # show host-fc-if
Name World Wide Port Name FC SAN Boot Uplink Port

fc0 20:00:00:22:BD:D6:5C:35 Disabled 0
fc1 20:00:00:22:BD:D6:5C:36 Disabled 1

Server /chassis/adapter # show host-fc-if fc0 detail
Name fc0:
 World Wide Node Name: 10:00:70:0F:6A:C0:97:43
 World Wide Port Name: 20:00:70:0F:6A:C0:97:43
 FC SAN Boot: disabled
 FC Type: fc-initiator
 Persistent LUN Binding: disabled
 Uplink Port: 0
 PCI Link: 0
 MAC Address: 70:0F:6A:C0:97:43
 CoS: 3
 VLAN: NONE
 Rate Limiting: OFF
 PCIe Device Order: 2
 EDTOV: 2000
 RATOV: 10000
 Maximum Data Field Size: 2112
 Channel Number: N/A
 Port Profile: N/A

Server /chassis/adapter #
```

## Modifying vHBA Properties

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **show adapter**
3. Server /chassis # **scope adapter** *index*
4. Server /chassis/adapter # **scope host-fc-if** {**fc0** | **fc1** | *name*}
5. Server /chassis/adapter/host-fc-if # **set wwnn** *wwnn*
6. Server /chassis/adapter/host-fc-if # **set wwpn** *wwpn*
7. Server /chassis/adapter/host-fc-if # **set boot** {**disable** | **enable**}

8. Server /chassis/adapter/host-fc-if # **set persistent-lun-binding** {**disable** | **enable**}
9. Server /chassis/adapter/host-fc-if # **set mac-addr** *mac-addr*
10. Server /chassis/adapter/host-fc-if # **set vlan** {**none** | *vlan-id*}
11. Server /chassis/adapter/host-fc-if # **set cos** *cos-value*
12. Server /chassis/adapter/host-fc-if # **set rate-limit** {**off** | *rate*}
13. Server /chassis/adapter/host-fc-if # **set order** {**any** | *0-99*}
14. Server /chassis/adapter/host-fc-if # **set error-detect-timeout** *msec*
15. Server /chassis/adapter/host-fc-if # **set resource-allocation-timeout** *msec*
16. Server /chassis/adapter/host-fc-if # **set max-data-field-size** *size*
17. Server /chassis/adapter/host-fc-if # **set channel-number** *channel number*
18. Server /chassis/adapter/host-fc-if # **set pci-link** *0/1*
19. Server /chassis/adapter/host-fc-if # **set uplink** *Port number*
20. Server /chassis/adapter/host-fc-if # **set vhba-type** *fc-initiator|fc-target|fc-nvme-initiator|fc-nvme-target*
21. Server /chassis/adapter/host-fc-if # **scope error-recovery**
22. Server /chassis/adapter/host-fc-if/error-recovery # **set fcp-error-recovery** {**disable** | **enable**}
23. Server /chassis/adapter/host-fc-if/error-recovery # **set link-down-timeout** *msec*
24. Server /chassis/adapter/host-fc-if/error-recovery # **set port-down-io-retry-count** *count*
25. Server /chassis/adapter/host-fc-if/error-recovery # **set port-down-timeout** *msec*
26. Server /chassis/adapter/host-fc-if/error-recovery # **exit**
27. Server /chassis/adapter/host-fc-if # **scope interrupt**
28. Server /chassis/adapter/host-fc-if/interrupt # **set interrupt-mode** {**intx** | **msi** | **msix**}
29. Server /chassis/adapter/host-fc-if/interrupt # **exit**
30. Server /chassis/adapter/host-fc-if # **scope port**
31. Server /chassis/adapter/host-fc-if/port # **set outstanding-io-count** *count*
32. Server /chassis/adapter/host-fc-if/port # **set max-target-luns** *count*
33. Server /chassis/adapter/host-fc-if/port # **exit**
34. Server /chassis/adapter/host-fc-if # **scope port-f-logi**
35. Server /chassis/adapter/host-fc-if/port-f-logi # **set flogi-retries** {**infinite** | *count*}
36. Server /chassis/adapter/host-fc-if/port-f-logi # **set flogi-timeout** *msec*
37. Server /chassis/adapter/host-fc-if/port-f-logi # **exit**
38. Server /chassis/adapter/host-fc-if # **scope port-p-logi**
39. Server /chassis/adapter/host-fc-if/port-p-logi # **set plogi-retries** *count*
40. Server /chassis/adapter/host-fc-if/port-p-logi # **set plogi-timeout** *msec*
41. Server /chassis/adapter/host-fc-if/port-p-logi # **exit**
42. Server /chassis/adapter/host-fc-if # **scope scsi-io**
43. Server /chassis/adapter/host-fc-if/scsi-io # **set cdb-wq-count** *count*
44. Server /chassis/adapter/host-fc-if/scsi-io # **set cdb-wq-ring-size** *size*
45. Server /chassis/adapter/host-fc-if/scsi-io # **exit**
46. Server /chassis/adapter/host-fc-if # **scope trans-queue**
47. Server /chassis/adapter/host-fc-if/trans-queue # **set fc-wq-ring-size** *size*
48. Server /chassis/adapter/host-fc-if/trans-queue # **exit**
49. Server /chassis/adapter/host-fc-if # **scope recv-queue**
50. Server /chassis/adapter/host-fc-if/recv-queue # **set fc-rq-ring-size** *size*
- 51.
52. Server /chassis/adapter/host-fc-if/recv-queue # **exit**

53. Server /chassis/adapter/host-fc-if # **commit**

## DETAILED STEPS

|                | Command or Action                                                                                         | Purpose                                                                                                                                                                                                                                                                       |
|----------------|-----------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b>  | Server# <b>scope chassis</b>                                                                              | Enters the chassis command mode.                                                                                                                                                                                                                                              |
| <b>Step 2</b>  | Server /chassis # <b>show adapter</b>                                                                     | (Optional) Displays the available adapter devices.                                                                                                                                                                                                                            |
| <b>Step 3</b>  | Server /chassis # <b>scope adapter</b> <i>index</i>                                                       | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings.                                                                              |
| <b>Step 4</b>  | Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> }               | Enters the host Fibre Channel interface command mode for the specified vHBA.                                                                                                                                                                                                  |
| <b>Step 5</b>  | Server /chassis/adapter/host-fc-if # <b>set wwnn</b> <i>wwnn</i>                                          | Specifies a unique World Wide Node Name (WWNN) for the adapter in the form hh:hh:hh:hh:hh:hh:hh:hh.<br><br>Unless specified by this command, the WWNN is generated automatically by the system.                                                                               |
| <b>Step 6</b>  | Server /chassis/adapter/host-fc-if # <b>set wwpn</b> <i>wwpn</i>                                          | Specifies a unique World Wide Port Name (WWPN) for the adapter in the form hh:hh:hh:hh:hh:hh:hh:hh.<br><br>Unless specified by this command, the WWPN is generated automatically by the system.                                                                               |
| <b>Step 7</b>  | Server /chassis/adapter/host-fc-if # <b>set boot</b> { <b>disable</b>   <b>enable</b> }                   | Enables or disables FC SAN boot. The default is disable.                                                                                                                                                                                                                      |
| <b>Step 8</b>  | Server /chassis/adapter/host-fc-if # <b>set persistent-lun-binding</b> { <b>disable</b>   <b>enable</b> } | Enables or disables persistent LUN binding. The default is disable.                                                                                                                                                                                                           |
| <b>Step 9</b>  | Server /chassis/adapter/host-fc-if # <b>set mac-addr</b> <i>mac-addr</i>                                  | Specifies a MAC address for the vHBA.                                                                                                                                                                                                                                         |
| <b>Step 10</b> | Server /chassis/adapter/host-fc-if # <b>set vlan</b> { <b>none</b>   <i>vlan-id</i> }                     | Specifies the default VLAN for this vHBA. Valid VLAN numbers are 1 to 4094; the default is none.                                                                                                                                                                              |
| <b>Step 11</b> | Server /chassis/adapter/host-fc-if # <b>set cos</b> <i>cos-value</i>                                      | Specifies the class of service (CoS) value to be marked on received packets unless the vHBA is configured to trust host CoS. Valid CoS values are 0 to 6; the default is 0. Higher values indicate more important traffic.<br><br>This setting is not functional in NIV mode. |
| <b>Step 12</b> | Server /chassis/adapter/host-fc-if # <b>set rate-limit</b> { <b>off</b>   <i>rate</i> }                   | Specifies a maximum data rate for the vHBA. The range is 1 to 100000 Mbps; the default is off.<br><br>This setting is not functional in NIV mode.                                                                                                                             |
| <b>Step 13</b> | Server /chassis/adapter/host-fc-if # <b>set order</b> { <b>any</b>   <i>0-99</i> }                        | Specifies the relative order of this device for PCIe bus device number assignment; the default is any.                                                                                                                                                                        |



|         | Command or Action                                                                                                        | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|---------|--------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 14 | Server /chassis/adapter/host-fc-if # <b>set error-detect-timeout</b> <i>msec</i>                                         | Specifies the error detect timeout value (EDTOV), the number of milliseconds to wait before the system assumes that an error has occurred. The range is 1000 to 100000; the default is 2000 milliseconds.                                                                                                                                                                                                                                                                                                                                                            |
| Step 15 | Server /chassis/adapter/host-fc-if # <b>set resource-allocation-timeout</b> <i>msec</i>                                  | Specifies the resource allocation timeout value (RATOV), the number of milliseconds to wait before the system assumes that a resource cannot be properly allocated. The range is 5000 to 100000; the default is 10000 milliseconds.                                                                                                                                                                                                                                                                                                                                  |
| Step 16 | Server /chassis/adapter/host-fc-if # <b>set max-data-field-size</b> <i>size</i>                                          | Specifies the maximum size of the Fibre Channel frame payload (in bytes) that the vHBA supports. The range is 1 to 2112; the default is 2112 bytes.                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Step 17 | Server /chassis/adapter/host-fc-if # <b>set channel-number</b> <i>channel number</i>                                     | The channel number that will be assigned to this vHBA. Enter an integer between 1 and 1,000.<br><br><b>Note</b> VNTAG mode is required for this option.                                                                                                                                                                                                                                                                                                                                                                                                              |
| Step 18 | Server /chassis/adapter/host-fc-if # <b>set pci-link</b> <i>0/1</i>                                                      | The link through which vNICs can be connected. These are the following values: <ul style="list-style-type: none"> <li>• 0 — The first cross-edged link where the vNIC is placed.</li> <li>• 1 — The second cross-edged link where the vNIC is placed.</li> </ul> <b>Note</b> This option is available only on some Cisco UCS C-Series servers.                                                                                                                                                                                                                       |
| Step 19 | Server /chassis/adapter/host-fc-if # <b>set uplink</b> <i>Port number</i>                                                | The uplink port associated with the vHBA.<br><br><b>Note</b> This value cannot be changed for the system-defined vHBAs fc0 and fc1.                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Step 20 | Server /chassis/adapter/host-fc-if # <b>set vhma-type</b> <i>fc-initiator fc-target fc-nvme-initiator fc-nvme-target</i> | The vHBA type used in this policy. vHBAs supporting FC and FC-NVMe can now be created on the same adapter. The vHBA type used in this policy can be one of the following: <ul style="list-style-type: none"> <li>• fc-initiator—Legacy SCSI FC vHBA initiator</li> <li>• fc-target—vHBA that supports SCSI FC target functionality</li> </ul> <b>Note</b> This option is available as a Tech Preview. <ul style="list-style-type: none"> <li>• fc-nvme-initiator—vHBA that is an FC NVME initiator, which discovers FC NVME targets and connects to them.</li> </ul> |

|                | Command or Action                                                                                    | Purpose                                                                                                                                                                                                                                                                                                                                                        |
|----------------|------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                |                                                                                                      | <ul style="list-style-type: none"> <li>• <b>fc-nvme-target</b>—vHBA that acts as an FC NVME target and provides connectivity to the NVME storage.</li> </ul>                                                                                                                                                                                                   |
| <b>Step 21</b> | Server /chassis/adapter/host-fc-if # <b>scope error-recovery</b>                                     | Enters the Fibre Channel error recovery command mode.                                                                                                                                                                                                                                                                                                          |
| <b>Step 22</b> | Server /chassis/adapter/host-fc-if/error-recovery # <b>set fcp-error-recovery {disable   enable}</b> | Enables or disables FCP Error Recovery. The default is disable.                                                                                                                                                                                                                                                                                                |
| <b>Step 23</b> | Server /chassis/adapter/host-fc-if/error-recovery # <b>set link-down-timeout msec</b>                | Specifies the link down timeout value, the number of milliseconds the uplink port should be offline before it informs the system that the uplink port is down and fabric connectivity has been lost. The range is 0 to 240000; the default is 30000 milliseconds.                                                                                              |
| <b>Step 24</b> | Server /chassis/adapter/host-fc-if/error-recovery # <b>set port-down-io-retry-count count</b>        | Specifies the port down I/O retries value, the number of times an I/O request to a port is returned because the port is busy before the system decides the port is unavailable. The range is 0 to 255; the default is 8 retries.                                                                                                                               |
| <b>Step 25</b> | Server /chassis/adapter/host-fc-if/error-recovery # <b>set port-down-timeout msec</b>                | Specifies the port down timeout value, the number of milliseconds a remote Fibre Channel port should be offline before informing the SCSI upper layer that the port is unavailable. The range is 0 to 240000; the default is 10000 milliseconds.                                                                                                               |
| <b>Step 26</b> | Server /chassis/adapter/host-fc-if/error-recovery # <b>exit</b>                                      | Exits to the host Fibre Channel interface command mode.                                                                                                                                                                                                                                                                                                        |
| <b>Step 27</b> | Server /chassis/adapter/host-fc-if # <b>scope interrupt</b>                                          | Enters the interrupt command mode.                                                                                                                                                                                                                                                                                                                             |
| <b>Step 28</b> | Server /chassis/adapter/host-fc-if/interrupt # <b>set interrupt-mode {intx   msi   msix}</b>         | Specifies the Fibre Channel interrupt mode. The modes are as follows: <ul style="list-style-type: none"> <li>• <b>intx</b> —Line-based interrupt (INTx)</li> <li>• <b>msi</b> —Message-Signaled Interrupt (MSI)</li> <li>• <b>msix</b> —Message Signaled Interrupts with the optional extension (MSIX). This is the recommended and default option.</li> </ul> |
| <b>Step 29</b> | Server /chassis/adapter/host-fc-if/interrupt # <b>exit</b>                                           | Exits to the host Fibre Channel interface command mode.                                                                                                                                                                                                                                                                                                        |
| <b>Step 30</b> | Server /chassis/adapter/host-fc-if # <b>scope port</b>                                               | Enters the Fibre Channel port command mode.                                                                                                                                                                                                                                                                                                                    |
| <b>Step 31</b> | Server /chassis/adapter/host-fc-if/port # <b>set outstanding-io-count count</b>                      | Specifies the I/O throttle count, the number of I/O operations that can be pending in the vHBA at one time. The range is 1 to 1024; the default is 512 operations.                                                                                                                                                                                             |
| <b>Step 32</b> | Server /chassis/adapter/host-fc-if/port # <b>set max-target-luns count</b>                           | Specifies the maximum logical unit numbers (LUNs) per target, the maximum number of LUNs that the driver will                                                                                                                                                                                                                                                  |

|                | Command or Action                                                                             | Purpose                                                                                                                                                                                                                                          |
|----------------|-----------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                |                                                                                               | discover. This is usually an operating system platform limitation. The range is 1 to 1024; the default is 256 LUNs.                                                                                                                              |
| <b>Step 33</b> | Server /chassis/adapter/host-fc-if/port # <b>exit</b>                                         | Exits to the host Fibre Channel interface command mode.                                                                                                                                                                                          |
| <b>Step 34</b> | Server /chassis/adapter/host-fc-if # <b>scope port-f-logic</b>                                | Enters the Fibre Channel fabric login command mode.                                                                                                                                                                                              |
| <b>Step 35</b> | Server /chassis/adapter/host-fc-if/port-f-logic # <b>set flogi-retries</b> {infinite   count} | Specifies the fabric login (FLOGI) retries value, the number of times that the system tries to log in to the fabric after the first failure. Enter a number between 0 and 4294967295 or enter <b>infinite</b> ; the default is infinite retries. |
| <b>Step 36</b> | Server /chassis/adapter/host-fc-if/port-f-logic # <b>set flogi-timeout msec</b>               | Specifies the fabric login (FLOGI) timeout value, the number of milliseconds that the system waits before it tries to log in again. The range is 1 to 255000; the default is 2000 milliseconds.                                                  |
| <b>Step 37</b> | Server /chassis/adapter/host-fc-if/port-f-logic # <b>exit</b>                                 | Exits to the host Fibre Channel interface command mode.                                                                                                                                                                                          |
| <b>Step 38</b> | Server /chassis/adapter/host-fc-if # <b>scope port-p-logic</b>                                | Enters the Fibre Channel port login command mode.                                                                                                                                                                                                |
| <b>Step 39</b> | Server /chassis/adapter/host-fc-if/port-p-logic # <b>set plogi-retries count</b>              | Specifies the port login (PLOGI) retries value, the number of times that the system tries to log in to the fabric after the first failure. The range is 0 and 255; the default is 8 retries.                                                     |
| <b>Step 40</b> | Server /chassis/adapter/host-fc-if/port-p-logic # <b>set plogi-timeout msec</b>               | Specifies the port login (PLOGI) timeout value, the number of milliseconds that the system waits before it tries to log in again. The range is 1 to 255000; the default is 2000 milliseconds.                                                    |
| <b>Step 41</b> | Server /chassis/adapter/host-fc-if/port-p-logic # <b>exit</b>                                 | Exits to the host Fibre Channel interface command mode.                                                                                                                                                                                          |
| <b>Step 42</b> | Server /chassis/adapter/host-fc-if # <b>scope scsi-io</b>                                     | Enters the SCSI I/O command mode.                                                                                                                                                                                                                |
| <b>Step 43</b> | Server /chassis/adapter/host-fc-if/scsi-io # <b>set cdb-wq-count count</b>                    | The number of command descriptor block (CDB) transmit queue resources to allocate. For Cisco UCS VIC 14xx series adapters, enter an integer between 1 and 64. For any other VIC adapter, enter an integer between 1 and 245.                     |
| <b>Step 44</b> | Server /chassis/adapter/host-fc-if/scsi-io # <b>set cdb-wq-ring-size size</b>                 | The number of descriptors in the command descriptor block (CDB) transmit queue. The range is 64 to 512; the default is 512.                                                                                                                      |
| <b>Step 45</b> | Server /chassis/adapter/host-fc-if/scsi-io # <b>exit</b>                                      | Exits to the host Fibre Channel interface command mode.                                                                                                                                                                                          |
| <b>Step 46</b> | Server /chassis/adapter/host-fc-if # <b>scope trans-queue</b>                                 | Enters the Fibre Channel transmit queue command mode.                                                                                                                                                                                            |
| <b>Step 47</b> | Server /chassis/adapter/host-fc-if/trans-queue # <b>set fc-wq-ring-size size</b>              | The number of descriptors in the Fibre Channel transmit queue. The range is 64 to 128; the default is 64.                                                                                                                                        |
| <b>Step 48</b> | Server /chassis/adapter/host-fc-if/trans-queue # <b>exit</b>                                  | Exits to the host Fibre Channel interface command mode.                                                                                                                                                                                          |

|                | Command or Action                                                              | Purpose                                                                                                                           |
|----------------|--------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 49</b> | Server /chassis/adapter/host-fc-if # <b>scope rcv-queue</b>                    | Enters the Fibre Channel receive queue command mode.                                                                              |
| <b>Step 50</b> | Server /chassis/adapter/host-fc-if/rcv-queue # <b>set fc-rq-ring-size size</b> | The number of descriptors in the Fibre Channel receive queue. The range is 64 to 128; the default is 64.                          |
| <b>Step 51</b> |                                                                                |                                                                                                                                   |
| <b>Step 52</b> | Server /chassis/adapter/host-fc-if/rcv-queue # <b>exit</b>                     | Exits to the host Fibre Channel interface command mode.                                                                           |
| <b>Step 53</b> | Server /chassis/adapter/host-fc-if # <b>commit</b>                             | Commits the transaction to the system configuration.<br><br><b>Note</b> The changes will take effect upon the next server reboot. |

### Example

This example configures the properties of a vHBA (only few options are shown):

```
Server# scope chassis
Server /chassis # show adapter
PCI Slot Product Name Serial Number Product ID Vendor

1 UCS VIC P81E QCI1417A0QK N2XX-ACPCI01 Cisco Systems Inc

Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-fc-if fcl
Server /chassis/adapter/host-fc-if # set boot enable
Server /chassis/adapter/host-fc-if *# scope scsi-io
Server /chassis/adapter/host-fc-if/scsi-io *# set cdb-wq-count 2
Server /chassis/adapter/host-fc-if/scsi-io *# exit
Server /chassis/adapter/host-fc-if *# commit
Server /chassis/adapter/host-fc-if #
```

### What to do next

Reboot the server to apply the changes.

## Creating a vHBA

The adapter provides two permanent vHBAs. If NIV mode is enabled, you can create up to 16 additional vHBAs.



**Note** Additional vHBAs can be created only in **VNTAG** mode.

### Before you begin

You must log in with admin privileges to perform this task.

## SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **create host-fc-if** *name*
4. Server /chassis/adapter/host-fc-if # **set channel-number** *number*
5. Server /chassis/adapter/host-fc-if # **commit**

## DETAILED STEPS

|               | Command or Action                                                            | Purpose                                                                                                                                                                                          |
|---------------|------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                 | Enters the chassis command mode.                                                                                                                                                                 |
| <b>Step 2</b> | Server /chassis # <b>scope adapter</b> <i>index</i>                          | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings. |
| <b>Step 3</b> | Server /chassis/adapter # <b>create host-fc-if</b> <i>name</i>               | Creates a vHBA and enters the host Fibre Channel interface command mode. The <i>name</i> argument can be up to 32 ASCII characters.                                                              |
| <b>Step 4</b> | Server /chassis/adapter/host-fc-if # <b>set channel-number</b> <i>number</i> | Assign a channel number to this vHBA. The range is 1 to 1000.                                                                                                                                    |
| <b>Step 5</b> | Server /chassis/adapter/host-fc-if # <b>commit</b>                           | Commits the transaction to the system configuration.<br><br><b>Note</b> The changes will take effect upon the next server reboot.                                                                |

## Example

This example creates a vHBA on adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # create host-fc-if Vhba5
Server /chassis/adapter/host-fc-if *# commit
New host-fc-if settings will take effect upon the next server reset
Server /chassis/adapter/host-fc-if #
```

## What to do next

- Reboot the server to create the vHBA.
- If configuration changes are required, configure the new vHBA as described in [Modifying vHBA Properties, on page 178](#).

## Deleting a vHBA

### Before you begin

You cannot delete the default vHBAs.

### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **delete host-fc-if** *name*
4. Server /chassis/adapter # **commit**

### DETAILED STEPS

|               | Command or Action                                              | Purpose                                                                                                                                                                                          |
|---------------|----------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                   | Enters the chassis command mode.                                                                                                                                                                 |
| <b>Step 2</b> | Server /chassis # <b>scope adapter</b> <i>index</i>            | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings. |
| <b>Step 3</b> | Server /chassis/adapter # <b>delete host-fc-if</b> <i>name</i> | Deletes the specified vHBA.<br><br><b>Note</b> You cannot delete either of the two default vHBAs, fc0 or fc1.                                                                                    |
| <b>Step 4</b> | Server /chassis/adapter # <b>commit</b>                        | Commits the transaction to the system configuration.<br><br><b>Note</b> The changes will take effect upon the next server reboot.                                                                |

### Example

This example deletes a vHBA on adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # delete host-fc-if Vhba5
Server /chassis/adapter *# commit
Server /chassis/adapter #
```

## vHBA Boot Table

In the vHBA boot table, you can specify up to four LUNs from which the server can boot.

## Viewing the Boot Table

### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **scope host-fc-if** {**fc0** | **fc1** | *name*}
4. Server /chassis/adapter/host-fc-if # **show boot**

### DETAILED STEPS

|               | Command or Action                                                                           | Purpose                                                                                                                                                                                          |
|---------------|---------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                                | Enters the chassis command mode.                                                                                                                                                                 |
| <b>Step 2</b> | Server /chassis # <b>scope adapter</b> <i>index</i>                                         | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings. |
| <b>Step 3</b> | Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> } | Enters the host Fibre Channel interface command mode for the specified vHBA.                                                                                                                     |
| <b>Step 4</b> | Server /chassis/adapter/host-fc-if # <b>show boot</b>                                       | Displays the boot table of the Fibre Channel interface.                                                                                                                                          |

### Example

This example displays the boot table for a vHBA:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # show boot
Boot Table Entry Boot Target WWPN Boot LUN ID

0 20:00:00:11:22:33:44:55 3
1 20:00:00:11:22:33:44:56 5

Server /chassis/adapter/host-fc-if #
```

## Creating a Boot Table Entry

You can create up to four boot table entries.

### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **scope host-fc-if** {**fc0** | **fc1** | *name*}
4. Server /chassis/adapter/host-fc-if # **create-boot-entry** *wwpn lun-id*

5. Server /chassis/adapter/host-fc-if # **commit**

## DETAILED STEPS

|               | Command or Action                                                                           | Purpose                                                                                                                                                                                                                                                                    |
|---------------|---------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                                | Enters the chassis command mode.                                                                                                                                                                                                                                           |
| <b>Step 2</b> | Server /chassis # <b>scope adapter</b> <i>index</i>                                         | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings.                                                                           |
| <b>Step 3</b> | Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> } | Enters the host Fibre Channel interface command mode for the specified vHBA.                                                                                                                                                                                               |
| <b>Step 4</b> | Server /chassis/adapter/host-fc-if # <b>create-boot-entry</b> <i>wwpn lun-id</i>            | Creates a boot table entry.<br><br><ul style="list-style-type: none"> <li>• <i>wwpn</i> — The World Wide Port Name (WWPN) for the boot target in the form hh:hh:hh:hh:hh:hh:hh:hh.</li> <li>• <i>lun-id</i> —The LUN ID of the boot LUN. The range is 0 to 255.</li> </ul> |
| <b>Step 5</b> | Server /chassis/adapter/host-fc-if # <b>commit</b>                                          | Commits the transaction to the system configuration.<br><br><b>Note</b> The changes will take effect upon the next server reboot.                                                                                                                                          |

**Example**

This example creates a boot table entry for vHBA fc1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # create-boot-entry 20:00:00:11:22:33:44:55 3
Server /chassis/adapter/host-fc-if *# commit
New boot table entry will take effect upon the next server reset
Server /chassis/adapter/host-fc-if #
```

## Deleting a Boot Table Entry

## SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **scope host-fc-if** {**fc0** | **fc1** | *name*}
4. Server /chassis/adapter/host-fc-if # **show boot**
5. Server /chassis/adapter/host-fc-if # **delete boot entry**



6. Server /chassis/adapter/host-fc-if # **commit**

## DETAILED STEPS

|               | Command or Action                                                                           | Purpose                                                                                                                                                                                          |
|---------------|---------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                                | Enters the chassis command mode.                                                                                                                                                                 |
| <b>Step 2</b> | Server /chassis # <b>scope adapter</b> <i>index</i>                                         | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings. |
| <b>Step 3</b> | Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> } | Enters the host Fibre Channel interface command mode for the specified vHBA.                                                                                                                     |
| <b>Step 4</b> | Server /chassis/adapter/host-fc-if # <b>show boot</b>                                       | Displays the boot table. From the Boot Table Entry field, locate the number of the entry to be deleted.                                                                                          |
| <b>Step 5</b> | Server /chassis/adapter/host-fc-if # <b>delete boot</b> <i>entry</i>                        | Deletes the boot table entry at the specified position in the table. The range of <i>entry</i> is 0 to 3. The change will take effect upon the next server reset.                                |
| <b>Step 6</b> | Server /chassis/adapter/host-fc-if # <b>commit</b>                                          | Commits the transaction to the system configuration.<br><br><b>Note</b> The changes will take effect upon the next server reboot.                                                                |

**Example**

This example deletes boot table entry number 1 for the vHBA fc1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # show boot
Boot Table Entry Boot Target WWPN Boot LUN ID

0 20:00:00:11:22:33:44:55 3
1 20:00:00:11:22:33:44:56 5

Server /chassis/adapter/host-fc-if # delete boot 1
Server /chassis/adapter/host-fc-if # commit
New host-fc-if settings will take effect upon the next server reset
Server /chassis/adapter/host-fc-if # show boot
Boot Table Entry Boot Target WWPN Boot LUN ID

0 20:00:00:11:22:33:44:55 3

Server /chassis/adapter/host-fc-if #
```

**What to do next**

Reboot the server to apply the changes.

## vHBA Persistent Binding

Persistent binding ensures that the system-assigned mapping of Fibre Channel targets is maintained after a reboot.

## Enabling Persistent Binding

### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **scope host-fc-if** {**fc0** | **fc1** | *name*}
4. Server /chassis/adapter/host-fc-if # **scope perbi**
5. Server /chassis/adapter/host-fc-if/perbi # **set persistent-lun-binding enable**
6. Server /chassis/adapter/host-fc-if/perbi # **commit**

### DETAILED STEPS

|               | Command or Action                                                                           | Purpose                                                                                                                                                                                          |
|---------------|---------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                                | Enters the chassis command mode.                                                                                                                                                                 |
| <b>Step 2</b> | Server /chassis # <b>scope adapter</b> <i>index</i>                                         | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings. |
| <b>Step 3</b> | Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> } | Enters the host Fibre Channel interface command mode for the specified vHBA.                                                                                                                     |
| <b>Step 4</b> | Server /chassis/adapter/host-fc-if # <b>scope perbi</b>                                     | Enters the persistent binding command mode for the vHBA.                                                                                                                                         |
| <b>Step 5</b> | Server /chassis/adapter/host-fc-if/perbi # <b>set persistent-lun-binding enable</b>         | Enables persistent binding for the vHBA.                                                                                                                                                         |
| <b>Step 6</b> | Server /chassis/adapter/host-fc-if/perbi # <b>commit</b>                                    | Commits the transaction to the system configuration.                                                                                                                                             |

### Example

This example enables persistent binding for a vHBA:

```
Server# scope chassis
Server /chassis # scope adapter 4
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # scope perbi
Server /chassis/adapter/host-fc-if/perbi # set persistent-lun-binding enable
Server /chassis/adapter/host-fc-if/perbi *# commit
Server /chassis/adapter/host-fc-if/perbi #
```

## Disabling Persistent Binding

### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **scope host-fc-if** {**fc0** | **fc1** | *name*}
4. Server /chassis/adapter/host-fc-if # **scope perbi**
5. Server /chassis/adapter/host-fc-if/perbi # **set persistent-lun-binding disable**
6. Server /chassis/adapter/host-fc-if/perbi # **commit**

### DETAILED STEPS

|               | Command or Action                                                                           | Purpose                                                                                                                                                                                          |
|---------------|---------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                                | Enters the chassis command mode.                                                                                                                                                                 |
| <b>Step 2</b> | Server /chassis # <b>scope adapter</b> <i>index</i>                                         | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings. |
| <b>Step 3</b> | Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> } | Enters the host Fibre Channel interface command mode for the specified vHBA.                                                                                                                     |
| <b>Step 4</b> | Server /chassis/adapter/host-fc-if # <b>scope perbi</b>                                     | Enters the persistent binding command mode for the vHBA.                                                                                                                                         |
| <b>Step 5</b> | Server /chassis/adapter/host-fc-if/perbi # <b>set persistent-lun-binding disable</b>        | Disables persistent binding for the vHBA.                                                                                                                                                        |
| <b>Step 6</b> | Server /chassis/adapter/host-fc-if/perbi # <b>commit</b>                                    | Commits the transaction to the system configuration.                                                                                                                                             |

### Example

This example disables persistent binding for a vHBA:

```
Server# scope chassis
Server /chassis # scope adapter 4
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # scope perbi
Server /chassis/adapter/host-fc-if/perbi # set persistent-lun-binding disable
Server /chassis/adapter/host-fc-if/perbi *# commit
Server /chassis/adapter/host-fc-if/perbi #
```

## Rebuilding Persistent Binding

### Before you begin

Persistent binding must be enabled in the vHBA properties.

## SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **scope host-fc-if** {**fc0** | **fc1** | *name*}
4. Server /chassis/adapter/host-fc-if # **scope perbi**
5. Server /chassis/adapter/host-fc-if/perbi # **rebuild**

## DETAILED STEPS

|               | Command or Action                                                                           | Purpose                                                                                                                                                                                          |
|---------------|---------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                                | Enters the chassis command mode.                                                                                                                                                                 |
| <b>Step 2</b> | Server /chassis # <b>scope adapter</b> <i>index</i>                                         | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings. |
| <b>Step 3</b> | Server /chassis/adapter # <b>scope host-fc-if</b> { <b>fc0</b>   <b>fc1</b>   <i>name</i> } | Enters the host Fibre Channel interface command mode for the specified vHBA.                                                                                                                     |
| <b>Step 4</b> | Server /chassis/adapter/host-fc-if # <b>scope perbi</b>                                     | Enters the persistent binding command mode for the vHBA.                                                                                                                                         |
| <b>Step 5</b> | Server /chassis/adapter/host-fc-if/perbi # <b>rebuild</b>                                   | Rebuilds the persistent binding table for the vHBA.                                                                                                                                              |

### Example

This example rebuilds the persistent binding table for a vHBA:

```
Server# scope chassis
Server /chassis # scope adapter 4
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # scope perbi
Server /chassis/adapter/host-fc-if/perbi # rebuild

Server /chassis/adapter/host-fc-if/perbi #
```

# Managing vNICs

## Guidelines for Managing vNICs

When managing vNICs, consider the following guidelines and restrictions:

- The Cisco UCS Virtual Interface Cards provide two vHBAs and two vNICs by default. You can create up to 14 additional vHBAs or vNICs on these adapter cards.

Additional vHBAs can be created using VNTAG mode.

The Cisco UCS 1455 and 1457 Virtual Interface Cards, in non-port channel mode, provide four vHBAs and four vNICs by default. You can create up to 10 additional vHBAs or vNICs on these adapter cards.



**Note** If VNTAG mode is enabled for the adapter, you must assign a channel number to a vNIC when you create it.

- After making configuration changes, you must reboot the host for settings to take effect.

## Viewing vNIC Properties

### Procedure

|               | Command or Action                                                                                               | Purpose                                                                                                                                                                                          |
|---------------|-----------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                                                    | Enters the chassis command mode.                                                                                                                                                                 |
| <b>Step 2</b> | Server /chassis # <b>scope adapter</b> <i>index</i>                                                             | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings. |
| <b>Step 3</b> | Server /chassis/adapter # <b>show host-eth-if</b> [ <b>eth0</b>   <b>eth1</b>   <i>name</i> ] [ <b>detail</b> ] | Displays properties of a single vNIC, if specified, or all vNICs.                                                                                                                                |
| <b>Step 4</b> | Server /chassis/adapter # <b>show ext-eth-if</b> [ <b>detail</b> ]                                              | Displays the external ethernet interfaces' details.                                                                                                                                              |

### Example

Following examples display the brief properties of all vNICs and the detailed properties of eth0 and the external interfaces:



**Note** These examples may show features available only with certain releases.

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # show host-eth-if
Name MTU Uplink Port MAC Address CoS VLAN PXE Boot iSCSI Boot usNIC

eth0 1500 0 74:A2:E6:28:C6:AE N/A N/A disabled disabled 0
eth1 1500 1 74:A2:E6:28:C6:AF N/A N/A disabled disabled 0
srg 1500 0 74:A2:E6:28:C6:B2 N/A N/A disabled disabled 64
hhh 1500 0 74:A2:E6:28:C6:B3 N/A N/A disabled disabled 0

Server /chassis/adapter # show host-eth-if eth0 detail
Name eth0:
MTU: 1500
Uplink Port: 0
MAC Address: B0:8B:CF:4C:ED:FF
```

```

CoS: 0
Trust Host CoS: disabled
PCI Link: 0
PCI Order: 0
VLAN: NONE
VLAN Mode: TRUNK
Rate Limiting: OFF
PXE Boot: disabled
iSCSI Boot: disabled
usNIC: 0
Channel Number: N/A
Port Profile: N/A
Uplink Failover: N/A
Uplink Failback Timeout: N/A
aRFS: disabled
VMQ: disabled
NVGRE: disabled
VXLAN: disabled
CDN Name: VIC-MLOM-eth0
RoCE Version1: disabled
RoCE Version2: disabled
RDMA Queue Pairs: 0
RDMA Memory Regions: 0
RDMA Resource Groups: 0
RDMA COS: 0
Multi Queue: disabled
No of subVnics:
Multi Queue Transmit Queue Count:
Multi Queue Receive Queue Count:
Multi Queue Completion Queue Count:
Multi Queue RoCE Version1:
Multi Queue RoCE Version2:
Multi Queue RDMA Queue Pairs:
Multi Queue RDMA Memory Regions:
Multi Queue RDMA Resource Groups:
Multi Queue RDMA COS:
Advanced Filters: disabled
Geneve Offload: disabled

```

```
Server# scope chassis
```

```
Server /chassis # scope adapter 1
```

```
Server /chassis/adapter # show ext-eth-if
```

| Port      | MAC Address       | Link State | Encap..   | Mode | Admin Speed | Oper..Speed | Link Training |
|-----------|-------------------|------------|-----------|------|-------------|-------------|---------------|
| Connector | Present           | Connector  | Supported |      |             |             |               |
| 0         | 74:A2:E6:28:C6:A2 | Link       | CE        |      | 40Gbps      | 40Gbps      | N/A           |
| Yes       | Yes               |            |           |      |             |             |               |
| 1         | 74:A2:E6:28:C6:A3 | Link       | CE        |      | 40Gbps      | 40Gbps      | N/A           |
| Yes       | Yes               |            |           |      |             |             |               |

```
Server /chassis/adapter # show ext-eth-if detail
```

```
C220-FCH1834V23X /chassis/adapter # show ext-eth-if detail
```

```
Port 0:
```

```

MAC Address: 74:A2:E6:28:C6:A2
Link State: Link
Encapsulation Mode: CE
Admin Speed: 40Gbps
Operating Speed: 40Gbps
Link Training: N/A
Connector Present: Yes
Connector Supported: Yes
Connector Type: QSFP_XCVR_CR4

```

```

Connector Vendor: CISCO
Connector Part Number: 2231254-3
Connector Part Revision: B
Port 1:
MAC Address: 74:A2:E6:28:C6:A3
Link State: Link
Encapsulation Mode: CE
Admin Speed: 40Gbps
Operating Speed: 40Gbps
Link Training: N/A
Connector Present: Yes
Connector Supported: Yes
Connector Type: QSFP_XCVR_CR4
Connector Vendor: CISCO
Connector Part Number: 2231254-3
Connector Part Revision: B

```

```
Server /chassis/adapter #
```

## Modifying vNIC Properties

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

|               | Command or Action                                                                              | Purpose                                                                                                                                                                                          |
|---------------|------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                                   | Enters the chassis command mode.                                                                                                                                                                 |
| <b>Step 2</b> | Server /chassis # <b>show adapter</b>                                                          | (Optional) Displays the available adapter devices.                                                                                                                                               |
| <b>Step 3</b> | Server /chassis # <b>scope adapter</b> <i>index</i>                                            | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings. |
| <b>Step 4</b> | Server /chassis/adapter # <b>scope host-eth-if</b> { <b>eth0</b>   <b>eth1</b>   <i>name</i> } | Enters the host Ethernet interface command mode for the specified vNIC.                                                                                                                          |
| <b>Step 5</b> | Server /chassis/adapter/host-eth-if # <b>set mtu</b> <i>mtu-value</i>                          | Specifies the maximum transmission unit (MTU) or packet size that the vNIC accepts. Valid MTU values are 1500 to 9000 bytes; the default is 1500.                                                |
| <b>Step 6</b> | Server /chassis/adapter/host-eth-if # <b>set uplink</b> { <b>0</b>   <b>1</b> }                | Specifies the uplink port associated with this vNIC. All traffic for this vNIC goes through this uplink port.                                                                                    |
| <b>Step 7</b> | Server /chassis/adapter/host-eth-if # <b>set mac-addr</b> <i>mac-addr</i>                      | Specifies a MAC address for the vNIC in the form hh:hh:hh:hh:hh:hh or hhhh:hhhh:hhhh.                                                                                                            |
| <b>Step 8</b> | Server /chassis/adapter/host-eth-if # <b>set cos</b> <i>cos-value</i>                          | Specifies the class of service (CoS) value to be marked on received packets unless the vNIC is configured to trust                                                                               |

|                | Command or Action                                                                                  | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|----------------|----------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                |                                                                                                    | <p>host CoS. Valid CoS values are 0 to 6; the default is 0. Higher values indicate more important traffic.</p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>You must set the <b>COS</b> value to 5 for the RDMA enabled interfaces.</li> <li>If NIV is enabled, this setting is determined by the switch, and the command is ignored.</li> </ul>                                                                                                                                                                                                                                |
| <b>Step 9</b>  | Server /chassis/adapter/host-eth-if # <b>set trust-host-cos</b> { <b>disable</b>   <b>enable</b> } | <p>Specifies whether the vNIC will trust host CoS or will remark packets. The behavior is as follows:</p> <ul style="list-style-type: none"> <li><b>disable</b> —Received packets are remarked with the configured CoS. This is the default.</li> <li><b>enable</b> —The existing CoS value of received packets (host CoS) is preserved.</li> </ul>                                                                                                                                                                                                                                          |
| <b>Step 10</b> | Server /chassis/adapter/host-eth-if # <b>set order</b> { <b>any</b>   0-99}                        | <p>Specifies the relative order of this device for PCI bus device number assignment; the default is any.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Step 11</b> | Server /chassis/adapter/host-eth-if # <b>set vlan</b> { <b>none</b>   <i>vlan-id</i> }             | <p>Specifies the default VLAN for this vNIC. Valid VLAN numbers are 1 to 4094; the default is none.</p> <p><b>Note</b> If NIV is enabled, this setting is determined by the switch, and the command is ignored.</p>                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Step 12</b> | Server /chassis/adapter/host-eth-if # <b>set vlan-mode</b> { <b>access</b>   <b>trunk</b> }        | <p>Specifies the VLAN mode for the vNIC. The modes are as follows:</p> <ul style="list-style-type: none"> <li><b>access</b> —The vNIC belongs to only one VLAN. When the VLAN is set to access mode, any frame received from the specified default VLAN (1-4094) that is received from the switch with a TAG removes that TAG when it is sent to the host OS through the vNIC.</li> <li><b>trunk</b> —The vNIC can belong to more than one VLAN. This is the default.</li> </ul> <p><b>Note</b> If NIV is enabled, this setting is determined by the switch, and the command is ignored.</p> |
| <b>Step 13</b> | Server /chassis/adapter/host-eth-if # <b>set rate-limit</b> { <b>off</b>   <i>rate</i> }           | <p>Specifies a maximum data rate for the vNIC. The range is 1 to 10000 Mbps; the default is off.</p> <p>For VIC 13xx controllers, you can enter an integer between 1 and 40,000.</p> <p>For VIC 1455 and 1457 controllers:</p>                                                                                                                                                                                                                                                                                                                                                               |



|                | Command or Action                                                                   | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|----------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                |                                                                                     | <ul style="list-style-type: none"> <li>If the adapter is connected to 25 Gbps link on a switch, then you can enter an integer between 1 to 25,000 Mbps.</li> <li>If the adapter is connected to 10 Gbps link on a switch, then you can enter an integer between 1 to 10,000 Mbps.</li> </ul> <p>For VIC 1495 and 1497 controllers:</p> <ul style="list-style-type: none"> <li>If the adapter is connected to 40 Gbps link on a switch, then you can enter an integer between 1 to 40,000 Mbps.</li> <li>If the adapter is connected to 100 Gbps link on a switch, then you can enter an integer between 1 to 100,000 Mbps.</li> </ul> <p><b>Note</b> If NIV is enabled, this setting is determined by the switch, and the command is ignored.</p> |
| <b>Step 14</b> | Server /chassis/adapter/host-eth-if # <b>set boot {disable   enable}</b>            | Specifies whether the vNIC can be used to perform a PXE boot. Default value is set to disable for the default vNICs and user-created vNICs.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Step 15</b> | Server /chassis/adapter/host-eth-if # <b>set channel-number number</b>              | If NIV mode is enabled for the adapter, select the channel number that will be assigned to this vNIC. The range is 1 to 1000.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Step 16</b> | Server /chassis/adapter/host-eth-if # <b>set port-profile name</b>                  | If NIV mode is enabled for the adapter, select the port profile that should be associated with the vNIC.<br><br><b>Note</b> The <i>name</i> must be a port profile defined on the switch to which this server is connected.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Step 17</b> | Server /chassis/adapter/host-eth-if # <b>set uplink-failover {disable   enable}</b> | If NIV mode is enabled for the adapter, enable this setting if traffic on this vNIC should fail over to the secondary interface if there are communication problems.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Step 18</b> | Server /chassis/adapter/host-eth-if # <b>set uplink-failback-timeout seconds</b>    | After a vNIC has started using its secondary interface, this setting controls how long the primary interface must be available before the system resumes using the primary interface for the vNIC.<br><br>Enter a number of <i>seconds</i> between 0 and 600.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Step 19</b> | Server /chassis/adapter/host-eth-if # <b>set multi-queue {disabled   enabled}</b>   | Enables or disables the multi queue option for this adapter and allows you to set the following multi queue parameters: <ul style="list-style-type: none"> <li><b>mq-rq-count</b>—The number of receive queue resources to allocate. Enter an integer between 1 and 1000.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

|                | Command or Action                                                          | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|----------------|----------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                |                                                                            | <ul style="list-style-type: none"> <li>• <b>mq-wq-count</b>—The number of transmit queue resources to allocate. Enter an integer between 1 and 1000.</li> <li>• <b>mq-cq-count</b>—The number of completion queue resources to allocate. In general, the number of completion queue resources you should allocate is equal to the number of transmit queue resources plus the number of receive queue resources. Enter an integer between 1 and 2000.</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• Multi queue is supported only on C-Series servers with 14xx adapters.</li> <li>• VMQ must be in enabled state to enable this option.</li> <li>• When you enable this option on one of the vNICs, configuring only VMQ (without choosing multi-queue) on other vNICs is not supported.</li> <li>• When this option is enabled usNIC configuration will be disabled.</li> </ul>                                                                                   |
| <b>Step 20</b> | Server /chassis/adapter/host-eth-if # <b>set geneve {disable   enable}</b> | <p>Beginning with release 4.1(2a), Cisco IMC supports Generic Network Virtualization Encapsulation (Geneve) Offload feature with Cisco VIC 14xx series adapters in ESX 7.0 (NSX-T 3.0) and ESX 6.7U3(NSX-T 2.5) OS.</p> <p>Geneve is a tunnel encapsulation functionality for network traffic. Enable this feature if you want to enable Geneve Offload encapsulation in Cisco VIC 14xx series adapters.</p> <p>Disable this feature to disable Geneve Offload, in order to prevent non-encapsulated UDP packets whose destination port numbers match with the Geneve destination port from being treated as tunneled packets.</p> <p>If you enable Geneve Offload feature, then Cisco recommends the following settings:</p> <ul style="list-style-type: none"> <li>• Transmit Queue Count—1</li> <li>• Transmit Queue Ring Size—4096</li> <li>• Receive Queue Count—8</li> <li>• Receive Queue Ring Size—4096</li> <li>• Completion Queue Count—9</li> <li>• Interrupt Count—11</li> </ul> |

|                | Command or Action                                                                                                    | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|----------------|----------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                |                                                                                                                      | <p><b>Note</b> You cannot enable the following when Geneve Offload is enabled:</p> <ul style="list-style-type: none"> <li>• RDMA on the same vNIC</li> <li>• usNIC on the same vNIC</li> <li>• Non-Port Channel Mode</li> <li>• aRFS</li> <li>• Advanced Filters</li> <li>• NetQueue</li> </ul> <p>Outer IPV6 is not supported with GENEVE Offload feature.</p> <p><b>Downgrade Limitation</b>—If Geneve Offload is enabled, you cannot downgrade to any release earlier than 4.1(2a).</p> |
| <b>Step 21</b> | Server /chassis/adapter/host-eth-if # <b>scope interrupt</b>                                                         | Enters the interrupt command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Step 22</b> | Server /chassis/adapter/host-eth-if/interrupt # <b>set interrupt-count</b> <i>count</i>                              | Specifies the number of interrupt resources. The range is 1 to 514; the default is 8. In general, you should allocate one interrupt resource for each completion queue.                                                                                                                                                                                                                                                                                                                    |
| <b>Step 23</b> | Server /chassis/adapter/host-eth-if/interrupt # <b>set coalescing-time</b> <i>usec</i>                               | <p>The time to wait between interrupts or the idle period that must be encountered before an interrupt is sent.</p> <p>The range is 1 to 65535 microseconds; the default is 125. To turn off coalescing, enter 0 (zero).</p>                                                                                                                                                                                                                                                               |
| <b>Step 24</b> | Server /chassis/adapter/host-eth-if/interrupt # <b>set coalescing-type</b> { <i>idle</i>   <i>min</i> }              | <p>The coalescing types are as follows:</p> <ul style="list-style-type: none"> <li>• <b>idle</b> —The system does not send an interrupt until there is a period of no activity lasting as long as the time specified in the coalescing time configuration.</li> <li>• <b>min</b> —The system waits for the time specified in the coalescing time configuration before sending another interrupt event. This is the default.</li> </ul>                                                     |
| <b>Step 25</b> | Server /chassis/adapter/host-eth-if/interrupt # <b>set interrupt-mode</b> { <i>intx</i>   <i>msi</i>   <i>msix</i> } | <p>Specifies the Ethernet interrupt mode. The modes are as follows:</p> <ul style="list-style-type: none"> <li>• <b>intx</b> —Line-based interrupt (PCI INTx)</li> <li>• <b>msi</b> —Message-Signaled Interrupt (MSI)</li> <li>• <b>msix</b> —Message Signaled Interrupts with the optional extension (MSI-X). This is the recommended and default option.</li> </ul>                                                                                                                      |

|                | Command or Action                                                              | Purpose                                                                                                                                                                                                                   |
|----------------|--------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 26</b> | Server /chassis/adapter/host-eth-if/interrupt # <b>exit</b>                    | Exits to the host Ethernet interface command mode.                                                                                                                                                                        |
| <b>Step 27</b> | Server /chassis/adapter/host-eth-if # <b>scope rcv-queue</b>                   | Enters receive queue command mode.                                                                                                                                                                                        |
| <b>Step 28</b> | Server /chassis/adapter/host-eth-if/rcv-queue # <b>set rq-count count</b>      | The number of receive queue resources to allocate. The range is 1 to 256; the default is 4.                                                                                                                               |
| <b>Step 29</b> | Server /chassis/adapter/host-eth-if/rcv-queue # <b>set rq-ring-size size</b>   | The number of descriptors in the receive queue. The range is 64 and 16384; the default is 512.<br><br>VIC 14xx Series adapters support a 4K (4096) maximum Ring Size.                                                     |
| <b>Step 30</b> | Server /chassis/adapter/host-eth-if/rcv-queue # <b>exit</b>                    | Exits to the host Ethernet interface command mode.                                                                                                                                                                        |
| <b>Step 31</b> | Server /chassis/adapter/host-eth-if # <b>scope trans-queue</b>                 | Enters transmit queue command mode.                                                                                                                                                                                       |
| <b>Step 32</b> | Server /chassis/adapter/host-eth-if/trans-queue # <b>set wq-count count</b>    | The number of transmit queue resources to allocate. The range is 1 to 256; the default is 1.                                                                                                                              |
| <b>Step 33</b> | Server /chassis/adapter/host-eth-if/trans-queue # <b>set wq-ring-size size</b> | The number of descriptors in the transmit queue. The range is 64 to 16384; the default is 256.<br><br>VIC 14xx Series adapters support a 4K (4096) maximum Ring Size.                                                     |
| <b>Step 34</b> | Server /chassis/adapter/host-eth-if/trans-queue # <b>exit</b>                  | Exits to the host Ethernet interface command mode.                                                                                                                                                                        |
| <b>Step 35</b> | Server /chassis/adapter/host-eth-if # <b>scope comp-queue</b>                  | Enters completion queue command mode.                                                                                                                                                                                     |
| <b>Step 36</b> | Server /chassis/adapter/host-eth-if/comp-queue # <b>set cq-count count</b>     | The number of completion queue resources to allocate. The range is 1 to 512; the default is 5.<br><br>In general, the number of completion queues equals the number of transmit queues plus the number of receive queues. |
| <b>Step 37</b> | Server /chassis/adapter/host-eth-if/comp-queue # <b>exit</b>                   | Exits to the host Ethernet interface command mode.                                                                                                                                                                        |
| <b>Step 38</b> | Server /chassis/adapter/host-eth-if/ # <b>set rdma_mr number</b>               | Sets the number of memory regions to be used per adapter. The values range from 4096 to 524288.                                                                                                                           |
| <b>Step 39</b> | Server /chassis/adapter/host-eth-if/ # <b>set rdma_qp number</b>               | Sets the number of queue pairs to be used per adapter. The values range from 1-8192 queue pairs.                                                                                                                          |
| <b>Step 40</b> | Server /chassis/adapter/host-eth-if/ # <b>set rdma_resgrp number</b>           | Sets the number of resource groups to be used. The values range from 1-128 resource groups.<br><br><b>Note</b> After committing the RoCE details, you are required to reboot the server for the changes to take place.    |
| <b>Step 41</b> | Server /chassis/adapter/host-eth-if # <b>scope offload</b>                     | Enters TCP offload command mode.                                                                                                                                                                                          |

|                | Command or Action                                                                                     | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                             |
|----------------|-------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 42</b> | Server /chassis/adapter/host-eth-if/offload # <b>set tcp-segment-offload {disable   enable}</b>       | <p>Enables or disables TCP Segmentation Offload as follows:</p> <ul style="list-style-type: none"> <li>• <b>disable</b> —The CPU segments large TCP packets.</li> <li>• <b>enable</b> —The CPU sends large TCP packets to the hardware to be segmented. This option may reduce CPU overhead and increase throughput rate. This is the default.</li> </ul> <p><b>Note</b> This option is also known as Large Send Offload (LSO).</p> |
| <b>Step 43</b> | Server /chassis/adapter/host-eth-if/offload # <b>set tcp-rx-checksum-offload {disable   enable}</b>   | <p>Enables or disables TCP Receive Offload Checksum Validation as follows:</p> <ul style="list-style-type: none"> <li>• <b>disable</b> —The CPU validates all packet checksums.</li> <li>• <b>enable</b> —The CPU sends all packet checksums to the hardware for validation. This option may reduce CPU overhead. This is the default.</li> </ul>                                                                                   |
| <b>Step 44</b> | Server /chassis/adapter/host-eth-if/offload # <b>set tcp-tx-checksum-offload {disable   enable}</b>   | <p>Enables or disables TCP Transmit Offload Checksum Validation as follows:</p> <ul style="list-style-type: none"> <li>• <b>disable</b> —The CPU validates all packet checksums.</li> <li>• <b>enable</b> —The CPU sends all packet checksums to the hardware for validation. This option may reduce CPU overhead. This is the default.</li> </ul>                                                                                  |
| <b>Step 45</b> | Server /chassis/adapter/host-eth-if/offload # <b>set tcp-large-receive-offload {disable   enable}</b> | <p>Enables or disables TCP Large Packet Receive Offload as follows:</p> <ul style="list-style-type: none"> <li>• <b>disable</b> —The CPU processes all large packets.</li> <li>• <b>enable</b> —The hardware reassembles all segmented packets before sending them to the CPU. This option may reduce CPU utilization and increase inbound throughput. This is the default.</li> </ul>                                              |
| <b>Step 46</b> | Server /chassis/adapter/host-eth-if/offload # <b>exit</b>                                             | Exits to the host Ethernet interface command mode.                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Step 47</b> | Server /chassis/adapter/host-eth-if # <b>scope rss</b>                                                | Enters Receive-side Scaling (RSS) command mode.                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Step 48</b> | Server /chassis/adapter/host-eth-if/rss # <b>set rss {disable   enable}</b>                           | Enables or disables RSS, which allows the efficient distribution of network receive processing across multiple CPUs in multiprocessor systems. The default is enable for the two default vNICs, and disable for user-created vNICs.                                                                                                                                                                                                 |
| <b>Step 49</b> | Server /chassis/adapter/host-eth-if/rss # <b>set rss-hash-ipv4 {disable   enable}</b>                 | Enables or disables IPv4 RSS. The default is enable.                                                                                                                                                                                                                                                                                                                                                                                |

|                | Command or Action                                                                            | Purpose                                                                                                                                                                                                                                                            |
|----------------|----------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 50</b> | Server /chassis/adapter/host-eth-if/rss # <b>set rss-hash-tcp-ipv4 {disable   enable}</b>    | Enables or disables TCP/IPv4 RSS. The default is enable.                                                                                                                                                                                                           |
| <b>Step 51</b> | Server /chassis/adapter/host-eth-if/rss # <b>set rss-hash-ipv6 {disable   enable}</b>        | Enables or disables IPv6 RSS. The default is enable.                                                                                                                                                                                                               |
| <b>Step 52</b> | Server /chassis/adapter/host-eth-if/rss # <b>set rss-hash-tcp-ipv6 {disable   enable}</b>    | Enables or disables TCP/IPv6 RSS. The default is enable.                                                                                                                                                                                                           |
| <b>Step 53</b> | Server /chassis/adapter/host-eth-if/rss # <b>set rss-hash-ipv6-ex {disable   enable}</b>     | Enables or disables IPv6 Extension RSS. The default is disable.                                                                                                                                                                                                    |
| <b>Step 54</b> | Server /chassis/adapter/host-eth-if/rss # <b>set rss-hash-tcp-ipv6-ex {disable   enable}</b> | Enables or disables TCP/IPv6 Extension RSS. The default is disable.                                                                                                                                                                                                |
| <b>Step 55</b> | Server /chassis/adapter/host-eth-if/rss # <b>exit</b>                                        | Exits to the host Ethernet interface command mode.                                                                                                                                                                                                                 |
| <b>Step 56</b> | Server /chassis/adapter/host-eth-if # <b>commit</b>                                          | Commits the transaction to the system configuration.<br><br><b>Note</b> The changes will take effect upon the next server reboot.                                                                                                                                  |
| <b>Step 57</b> | Server /chassis/adapter/host-eth-if # <b>set vf-count</b> <i>Count</i>                       | Specify number of VFs for each PF.<br>Enter an integer between 1 and 64; the default is zero.                                                                                                                                                                      |
| <b>Step 58</b> | Server /chassis/adapter/host-eth-if* # <b>set vf-intr-count</b> <i>Count</i>                 | Specify number of interrupts for each VF.<br>Enter an integer between 1 and 16                                                                                                                                                                                     |
| <b>Step 59</b> | Server /chassis/adapter/host-eth-if* # <b>set vf-rq-count</b> <i>Count</i>                   | Specify number of Receive queues for each VF.<br>Enter an integer between 1 and 8.                                                                                                                                                                                 |
| <b>Step 60</b> | Server /chassis/adapter/host-eth-if* # <b>set vf-wq-count</b> <i>Count</i>                   | Specify number of Transmit Queues for each VF.<br>Enter an integer between 1 and 8.                                                                                                                                                                                |
| <b>Step 61</b> | Server /chassis/adapter/host-eth-if* # <b>set vf-cq-count</b> <i>Count</i>                   | Specify number of Completion Queues for each VF.<br>Enter an integer between 1 and 16; the default is zero.<br>The value is sum of wq and rq.                                                                                                                      |
| <b>Step 62</b> | Server /chassis/adapter/host-eth-if* # <b>set qinq_vlan</b> <i>4090</i>                      | Specify the QinQ VLAN id for this vNIC.<br>Enter an integer between 2 and 4094.<br><br>Beginning with release 4.3.2.230207, Cisco IMC provides VIC QinQ Tunneling support on Cisco UCS C-series M5, M6 and M7 servers with UCS VIC 14xx and 15xxx series adapters. |

|                | Command or Action                                    | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|----------------|------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                |                                                      | <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• QinQ is not supported on 13xx adapters.</li> <li>• Default vLAN should not be none when QinQ is configured and vLAN mode is trunk.</li> </ul> <p>You cannot enable the following when <b>VIC QinQ Tunneling</b> is enabled in a setup with Cisco VIC 14xx:</p> <ul style="list-style-type: none"> <li>• usNIC on the same vNIC</li> <li>• Geneve offload on the same vNIC</li> <li>• VMMQ on the same vNIC</li> <li>• RDMA v2 on the same vNIC</li> <li>• SR-IOV on the same vNIC</li> </ul> <p>You cannot enable the following when <b>VIC QinQ Tunneling</b> is enabled in a setup with Cisco VIC 15xxx:</p> <ul style="list-style-type: none"> <li>• usNIC on the same vNIC</li> <li>• VMMQ on the same vNIC</li> <li>• RDMA v2 on the same vNIC</li> <li>• SR-IOV on the same vNIC</li> </ul> |
| <b>Step 63</b> | Server /chassis/adapter/host-eth-if* # <b>commit</b> | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

**Example**

The below examples configure the properties of a vNIC.

- The below example enables QinQ tunneling in a vNIC:

```
Server# scope chassis
Server /chassis # show adapter
Server /chassis # scope adapter MLOM
Server /chassis/adapter # scope host-eth-if eth0
Server /chassis/adapter/host-eth-if # set qinq enabled
Server /chassis/adapter/host-eth-if *# set qinq_vlan 4090
Server /chassis/adapter/host-eth-if *# commit
Committed host-eth-if settings will take effect upon the next host power cycle
Server /chassis/adapter/host-eth-if #
```

- The below example configure the properties of a vNIC (VMQ, Multi-queue, SR-IOV)

```
Server# scope chassis
Server /chassis # show adapter
PCI Slot Product Name Serial Number Product ID Vendor

1 UCS VIC P81E QCI1417A0QK N2XX-ACPCI01 Cisco Systems Inc

Server /chassis # scope adapter 1
```

```

Server /chassis/adapter # scope host-eth-if Test1
Server /chassis/adapter/host-eth-if # set uplink 1
Server /chassis/adapter/host-eth-if # set vmq enabled
Server /chassis/adapter/host-eth-if # set multi-queue enabled
Server /chassis/adapter/host-eth-if # enable arfs
Server /chassis/adapter/host-eth-if *# scope offload
Server /chassis/adapter/host-eth-if/offload *# set tcp-segment-offload enable
Server /chassis/adapter/host-eth-if/offload *# exit
Server /chassis/adapter/host-eth-if *# commit
Server /chassis/adapter/host-eth-if # set vf-count 8
Server /chassis/adapter/host-eth-if *# set vf-intr-count 8
Server /chassis/adapter/host-eth-if *# set vf-cq-count 8
Server /chassis/adapter/host-eth-if *# set vf-rq-count 4
Server /chassis/adapter/host-eth-if *# set vf-wq-count 4
Server /chassis/adapter/host-eth-if *# commit
Server /chassis/adapter/host-eth-if #

```

**What to do next**

Reboot the server to apply the changes.

## Setting Admin Link Training on External Ethernet Interfaces

Admin link training for the port profile on the external ethernet interfaces of the specified vNIC can be enabled or disabled.

**Before you begin**

You must log in with admin privileges to perform this task.



**Note** This option is available only on some of the adapters and servers.

**Procedure**

|               | Command or Action                                                                      | Purpose                                                                                                                                                                                          |
|---------------|----------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                           | Enters the chassis command mode.                                                                                                                                                                 |
| <b>Step 2</b> | Server /chassis # <b>show adapter</b>                                                  | (Optional) Displays the available adapter devices.                                                                                                                                               |
| <b>Step 3</b> | Server /chassis # <b>scope adapter</b> <i>index</i>                                    | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings. |
| <b>Step 4</b> | Server /chassis / adapter # <b>scope ext-eth-if 0   1 name</b>                         | Enters the external ethernet interface command mode for the specified vNIC.                                                                                                                      |
| <b>Step 5</b> | Server /chassis / adapter / ext-eth-if # <b>set admin-link-training on   off  auto</b> | Sets the admin link training to the chosen option for the specified vNIC.                                                                                                                        |



|               | Command or Action                                        | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|---------------|----------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                          | <p>Admin Link Training is set to <code>auto</code>, by default.</p> <p>Beginning from 4.2(2a), the below different settings apply only to Cisco UCS VIC 15xxx adapters and Copper cables at speeds 10G/25G/50G only.</p> <ul style="list-style-type: none"> <li>• If <code>admin-link-training</code> is set to <code>auto</code>, then Adapter firmware sets <code>oper-link-training</code> value as <code>on</code> or <code>off</code>, depending upon the transceivers. <ul style="list-style-type: none"> <li>• Auto Negotiate disabled with 25G copper</li> <li>• Auto Negotiate enabled with 50G copper</li> </ul> </li> <li>• If <code>admin-link-training</code> is set to <code>on</code>, then Adapter firmware sets <code>oper-link-training</code> as <code>on</code>. <ul style="list-style-type: none"> <li>• Auto Negotiate enabled with 25G copper</li> <li>• Auto Negotiate enabled with 50G copper</li> </ul> </li> <li>• If <code>admin-link-training</code> is <code>off</code>, then Adapter firmware sets <code>oper-link-training</code> as <code>off</code>. <ul style="list-style-type: none"> <li>• Auto Negotiate disabled with 25G copper</li> <li>• Auto Negotiate disabled for 50G copper</li> </ul> </li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• For all non-passive copper cables, <code>oper-link-training</code> mode is set to <code>off</code>, irrespective of the <code>admin-link-training</code> mode.</li> <li>• Any changes in the <code>admin-link-training</code> settings leads to the reset of the Series for that port, even if the <code>oper-link-training</code> value remains the same.</li> </ul> |
| <b>Step 6</b> | Server /chassis / adapter / ext-eth-if * # <b>commit</b> | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |

### Example

This example shows how to set admin link training to `auto` on the external ethernet interface.

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope ext-eth-if 1
Server /chassis/adapter/ext-eth-if # set admin-link-training auto
Server /chassis/adapter/ext-eth-if* # commit
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
```

```

Port 1:
 MAC Address: 74:A2:E6:28:C6:A3
 Link State: Link
 Encapsulation Mode: CE
 Admin Speed: 40Gbps
 Operating Speed: -
 Admin Link Training: Auto
 Connector Present: Yes
 Connector Supported: Yes
 Connector Type: QSFP_XCVR_CR4
 Connector Vendor: CISCO
 Connector Part Number: 2231254-3
 Connector Part Revision: B
Server /chassis/adapter/ext-eth-if

```

## Setting Admin FEC Mode on External Ethernet Interfaces

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

|               | Command or Action                                                                                            | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|---------------|--------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                                                 | Enters the chassis command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Step 2</b> | Server /chassis # <b>show adapter</b>                                                                        | (Optional) Displays the available adapter devices.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Step 3</b> | Server /chassis # <b>scope adapter index</b>                                                                 | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings.                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Step 4</b> | Server /chassis / adapter # <b>scope ext-eth-if {0   1 name}</b>                                             | Enters the external ethernet interface command mode for the specified vNIC.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Step 5</b> | Server /chassis / adapter / ext-eth-if # <b>set admin-fec-mode {cl108   cl91-cons16   cl91   cl74   off}</b> | Sets the admin FEC mode. The default value is <b>cl91</b> .<br><br><b>Note</b> Admin Forward Error Correction (FEC) mode apply only to Cisco UCS VIC 14xx adapters at speed 25/100G and Cisco UCS VIC 15xxx adapters at speeds 25G/50G.<br><br><b>Operating FEC Mode—</b><br>The value of <b>Operating FEC Mode</b> is the same as <b>Admin FEC mode</b> with these exceptions: <ul style="list-style-type: none"> <li>• The value is Off when the speed is 10 Gbps or 40 Gbps. This is because FEC is not supported.</li> <li>• The value is Off for QSFP-100G-LR4-S transceiver.</li> <li>• The value is Off for QSFP-40/100-SRBD transceiver.</li> </ul> |

|        | Command or Action                                        | Purpose                                                                               |
|--------|----------------------------------------------------------|---------------------------------------------------------------------------------------|
| Step 6 | Server /chassis / adapter / ext-eth-if * # <b>commit</b> | At the prompt, select <b>y</b> . Commits the transaction to the system configuration. |

### Example

This example shows how to set the admin FEC mode on the external ethernet interface.

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope ext-eth-if 1
Server /chassis/adapter/ext-eth-if # set admin-fec-mode cl74
Server /chassis/adapter/ext-eth-if* # commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Port 1:
 MAC Address: 00:5D:73:1C:6C:58
 Link State: LinkDown
 Encapsulation Mode: CE
 Admin Speed: Auto
 Operating Speed: -
 Admin Link Training: N/A
 Admin FEC Mode: cl74
 Operating FEC Mode: Off
 Connector Present: NO
 Connector Supported: N/A
 Connector Type: N/A
 Connector Vendor: N/A
 Connector Part Number: N/A
 Connector Part Revision: N/A
Server /chassis/adapter/ext-eth-if #
```

## Creating a vNIC

The adapter provides two permanent vNICs. You can create up to 16 additional vNICs.

### Before you begin

You must log in with user or admin privileges to perform this task.

### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **create host-eth-if** *name*
4. (Optional) Server /chassis/adapter/host-eth-if # **set channel-number** *number*
5. Server /chassis/adapter/host-eth-if # **commit**

### DETAILED STEPS

|        | Command or Action            | Purpose                          |
|--------|------------------------------|----------------------------------|
| Step 1 | Server# <b>scope chassis</b> | Enters the chassis command mode. |

|               | Command or Action                                                                        | Purpose                                                                                                                                                                                          |
|---------------|------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 2</b> | Server /chassis # <b>scope adapter</b> <i>index</i>                                      | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings. |
| <b>Step 3</b> | Server /chassis/adapter # <b>create host-eth-if</b> <i>name</i>                          | Creates a vNIC and enters the host Ethernet interface command mode. The <i>name</i> argument can be up to 32 ASCII characters.                                                                   |
| <b>Step 4</b> | (Optional) Server /chassis/adapter/host-eth-if # <b>set channel-number</b> <i>number</i> | If NIV mode is enabled for the adapter, you must assign a channel number to this vNIC. The range is 1 to 1000.                                                                                   |
| <b>Step 5</b> | Server /chassis/adapter/host-eth-if # <b>commit</b>                                      | Commits the transaction to the system configuration.<br><br><b>Note</b> The changes will take effect upon the next server reboot.                                                                |

### Example

This example creates a vNIC on adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # create host-eth-if Vnic5
Server /chassis/adapter/host-eth-if *# commit
New host-eth-if settings will take effect upon the next server reset
Server /chassis/adapter/host-eth-if #
```

## Deleting a vNIC

### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **delete host-eth-if** *name*
4. Server /chassis/adapter # **commit**

### DETAILED STEPS

|               | Command or Action                                   | Purpose                                                                                                                                                                                          |
|---------------|-----------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                        | Enters the chassis command mode.                                                                                                                                                                 |
| <b>Step 2</b> | Server /chassis # <b>scope adapter</b> <i>index</i> | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings. |

|        | Command or Action                                               | Purpose                                                                                                                           |
|--------|-----------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| Step 3 | Server /chassis/adapter # <b>delete host-eth-if</b> <i>name</i> | Deletes the specified vNIC.<br><br><b>Note</b> You cannot delete either of the two default vNICs, eth0 or eth1.                   |
| Step 4 | Server /chassis/adapter # <b>commit</b>                         | Commits the transaction to the system configuration.<br><br><b>Note</b> The changes will take effect upon the next server reboot. |

### Example

This example deletes a vNIC on adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # delete host-eth-if Vnic5
Server /chassis/adapter *# commit
Server /chassis/adapter #
```

## Creating Cisco usNIC Using the CLI



**Note** Even though several properties are listed for Cisco usNIC in the usNIC properties dialog box, you must configure only the following properties because the other properties are not currently being used.

- **cq-count**
- **rq-count**
- **tq-count**
- **usnic-count**

### Before you begin

You must log in to the CLI with administrator privileges to perform this task.

### SUMMARY STEPS

1. server# **scope chassis**
2. server/chassis# **scope adapter** *index*
3. server/chassis/adapter# **scope host-eth-if** {eth0 | eth1}
4. server/chassis/adapter/host-eth-if# **create usnic-config** 0
5. server/chassis/adapter/host-eth-if/usnic-config# **set cq-count** *count*
6. server/chassis/adapter/host-eth-if/usnic-config# **set rq-count** *count*
7. server/chassis/adapter/host-eth-if/usnic-config# **set tq-count** *count*
8. server/chassis/adapter/host-eth-if/usnic-config# **set usnic-count** *number of usNICs* .

9. server/chassis/adapter/host-eth-if /usnic-config# **commit**
10. server/chassis/adapter/host-eth-if/usnic-config# **exit**
11. server/chassis/adapter/host-eth-if# **exit**
12. server/chassis/adapter# **exit**
13. server/chassis# **exit**
14. server# **scope bios**
15. server/bios# **scope advanced**
16. server/bios/advanced# **set IntelVTD Enabled**
17. server/bios/advanced# **set ATS Enabled**
18. server/bios/advanced# **set CoherencySupport Enabled**
19. server /bios/advanced# **commit**

## DETAILED STEPS

|               | Command or Action                                                          | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|---------------|----------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | server# <b>scope chassis</b>                                               | Enters chassis command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Step 2</b> | server/chassis# <b>scope adapter index</b>                                 | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> Make sure that the server is powered on before you attempt to view or change adapter settings. To view the index of the adapters configured on your server, use the <b>show adapter</b> command.                                                                                                                                                                                          |
| <b>Step 3</b> | server/chassis/adapter# <b>scope host-eth-if {eth0   eth1}</b>             | Enters the command mode for the vNIC. Specify the Ethernet ID based on the number of vNICs that you have configured in your environment. For example, specify <b>eth0</b> if you configured only one vNIC.                                                                                                                                                                                                                                                                                                   |
| <b>Step 4</b> | server/chassis/adapter/host-eth-if# <b>create usnic-config 0</b>           | Creates a usNIC config and enters its command mode. Make sure that you always set the index value to 0.<br><br><b>Note</b> To create a Cisco usNIC for the first time for a given vNIC using the CLI, you must first create a <b>usnic-config</b> . Subsequently, you only need to scope into the <b>usnic-config</b> and modify the properties for Cisco usNIC. For more information about modifying Cisco usNIC properties, see <a href="#">Modifying a Cisco usNIC value using the CLI, on page 212</a> . |
| <b>Step 5</b> | server/chassis/adapter/host-eth-if/usnic-config# <b>set cq-count count</b> | Specifies the number of completion queue resources to allocate. We recommend that you set this value to 6.<br><br>The number of completion queues equals the number of transmit queues plus the number of receive queues.                                                                                                                                                                                                                                                                                    |
| <b>Step 6</b> | server/chassis/adapter/host-eth-if/usnic-config# <b>set rq-count count</b> | Specifies the number of receive queue resources to allocate. We recommend that you set this value to 6.                                                                                                                                                                                                                                                                                                                                                                                                      |

|         | Command or Action                                                                                 | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------|---------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 7  | server/chassis/adapter/host-eth-if/usnic-config# <b>set tq-count</b> <i>count</i>                 | Specifies the number of transmit queue resources to allocate. We recommend that you set this value to 6.                                                                                                                                                                                                                                                                                                                                                                  |
| Step 8  | server/chassis/adapter/host-eth-if/usnic-config# <b>set usnic-count</b> <i>number of usNICs</i> . | Specifies the number of Cisco usNICs to create. Each MPI process that is running on the server requires a dedicated Cisco usNIC. Therefore, you might need to create up to 64 Cisco usNICs to sustain 64 MPI processes running simultaneously. We recommend that you create at least as many Cisco usNICs, per Cisco usNIC-enabled vNIC, as the number of physical cores on your server. For example, if you have 8 physical cores on your server, create 8 Cisco usNICs. |
| Step 9  | server/chassis/adapter/host-eth-if/usnic-config# <b>commit</b>                                    | Commits the transaction to the system configuration.<br><b>Note</b> The changes take effect when the server is rebooted.                                                                                                                                                                                                                                                                                                                                                  |
| Step 10 | server/chassis/adapter/host-eth-if/usnic-config# <b>exit</b>                                      | Exits to host Ethernet interface command mode.                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Step 11 | server/chassis/adapter/host-eth-if# <b>exit</b>                                                   | Exits to adapter interface command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Step 12 | server/chassis/adapter# <b>exit</b>                                                               | Exits to chassis interface command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Step 13 | server/chassis# <b>exit</b>                                                                       | Exits to server interface command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Step 14 | server# <b>scope bios</b>                                                                         | Enters Bios command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Step 15 | server/bios# <b>scope advanced</b>                                                                | Enters the advanced settings of BIOS command mode.                                                                                                                                                                                                                                                                                                                                                                                                                        |
| Step 16 | server/bios/advanced# <b>set IntelVTD Enabled</b>                                                 | Enables the Intel Virtualization Technology.                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Step 17 | server/bios/advanced# <b>set ATS Enabled</b>                                                      | Enables the Intel VT-d Address Translation Services (ATS) support for the processor.                                                                                                                                                                                                                                                                                                                                                                                      |
| Step 18 | server/bios/advanced# <b>set CoherencySupport Enabled</b>                                         | Enables Intel VT-d coherency support for the processor.                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Step 19 | server /bios/advanced# <b>commit</b>                                                              | Commits the transaction to the system configuration.<br><b>Note</b> The changes take effect when the server is rebooted.                                                                                                                                                                                                                                                                                                                                                  |

### Example

This example shows how to configure Cisco usNIC properties:

```
Server # scope chassis
server /chassis # show adapter
server /chassis # scope adapter 2
server /chassis/adapter # scope host-eth-if eth0
server /chassis/adapter/host-eth-if # create usnic-config 0
server /chassis/adapter/host-eth-if/usnic-config *# set usnic-count 64
```

```

server /chassis/adapter/host-eth-if/usnic-config *# set cq-count 6
server /chassis/adapter/host-eth-if/usnic-config *# set rq-count 6
server /chassis/adapter/host-eth-if/usnic-config *# set tq-count 6
server /chassis/adapter/host-eth-if/usnic-config *# commit
Committed settings will take effect upon the next server reset
server /chassis/adapter/host-eth-if/usnic-config # exit
server /chassis/adapter/host-eth-if # exit
server /chassis/adapter # exit
server /chassis # exit
server # exit
server# scope bios
server /bios # scope advanced
server /bios/advanced # set IntelVTD Enabled
server /bios/advanced *# set ATS Enabled*
server /bios/advanced *# set CoherencySupport Enabled
server /bios/advanced *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N]y
A system reboot has been initiated.

```

## Modifying a Cisco usNIC value using the CLI

### Before you begin

You must log in to the GUI with administrator privileges to perform this task.

### SUMMARY STEPS

1. server# **scope chassis**
2. server/chassis# **scope adapter** *index*
3. server/chassis/adapter# **scope host-eth-if** {eth0 | eth1}
4. server/chassis/adapter/host-eth-if# **scope usnic-config** 0
5. server/chassis/adapter/host-eth-if/usnic-config# **set usnic-count** *number of usNICs* .
6. server /chassis/adapter/host-eth-if /usnic-config# **commit**
7. server/chassis/adapter/host-eth-if/usnic-config# **exit**
8. server/chassis/adapter/host-eth-if# **exit**
9. server/chassis/adapter# **exit**
10. server/chassis# **exit**

### DETAILED STEPS

|        | Command or Action                                 | Purpose                                                                                                                                                                                                                                                                                                            |
|--------|---------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | server# <b>scope chassis</b>                      | Enters chassis command mode.                                                                                                                                                                                                                                                                                       |
| Step 2 | server/chassis# <b>scope adapter</b> <i>index</i> | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> Make sure that the server is powered on before you attempt to view or change adapter settings. To view the index of the adapters configured on you server, use the <b>show adapter</b> command. |



|         | Command or Action                                                                                 | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------|---------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 3  | server/chassis/adapter# <b>scope host-eth-if</b> {eth0   eth1}                                    | Enters the command mode for the vNIC. Specify the Ethernet ID based on the number of vNICs that you have configured in your environment. For example, specify <b>eth0</b> if you configured only one vNIC.                                                                                                                                                                                                                                                |
| Step 4  | server/chassis/adapter/host-eth-if# <b>scope usnic-config 0</b>                                   | Enters the command mode for the usNIC. Make sure that you always set the index value as 0 to configure a Cisco usNIC.                                                                                                                                                                                                                                                                                                                                     |
| Step 5  | server/chassis/adapter/host-eth-if/usnic-config# <b>set usnic-count</b> <i>number of usNICs</i> . | Specifies the number of Cisco usNICs to create. Each MPI process running on the server requires a dedicated Cisco usNIC. Therefore, you might need to create up to 64 Cisco usNIC to sustain 64 MPI processes running simultaneously. We recommend that you create at least as many Cisco usNIC, per Cisco usNIC-enabled vNIC, as the number of physical cores on your server. For example, if you have 8 physical cores on your server, create 8 usNICs. |
| Step 6  | server /chassis/adapter/host-eth-if/usnic-config# <b>commit</b>                                   | Commits the transaction to the system configuration.<br><br><b>Note</b> The changes take effect when the server is rebooted.                                                                                                                                                                                                                                                                                                                              |
| Step 7  | server/chassis/adapter/host-eth-if/usnic-config# <b>exit</b>                                      | Exits to host Ethernet interface command mode.                                                                                                                                                                                                                                                                                                                                                                                                            |
| Step 8  | server/chassis/adapter/host-eth-if# <b>exit</b>                                                   | Exits to adapter interface command mode.                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Step 9  | server/chassis/adapter# <b>exit</b>                                                               | Exits to chassis interface command mode.                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Step 10 | server/chassis# <b>exit</b>                                                                       | Exits to server interface command mode.                                                                                                                                                                                                                                                                                                                                                                                                                   |

### Example

This example shows how to configure Cisco usNIC properties:

```
server # scope chassis
server /chassis # show adapter
server /chassis # scope adapter 2
server /chassis/adapter # scope host-eth-if eth0
server /chassis/adapter/host-eth-if # scope usnic-config 0
server /chassis/adapter/host-eth-if/usnic-config # set usnic-count 32
server /chassis/adapter/host-eth-if/usnic-config # commit
Committed settings will take effect upon the next server reset
server /chassis/adapter/host-eth-if/usnic-config # exit
server /chassis/adapter/host-eth-if # exit
server /chassis/adapter # exit
server /chassis # exit
server # exit
```

## Viewing usNIC Properties

### Before you begin

You must log in with admin privileges to perform this task.

usNIC must be configured on a vNIC.

### Procedure

|               | Command or Action                                                                              | Purpose                                                                                                                                                                                          |
|---------------|------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                                   | Enters the chassis command mode.                                                                                                                                                                 |
| <b>Step 2</b> | Server /chassis # <b>scope adapter</b> <i>index</i>                                            | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings. |
| <b>Step 3</b> | Server /chassis/adapter # <b>scope host-eth-if</b> { <b>eth0</b>   <b>eth1</b>   <i>name</i> } | Enters the host Ethernet interface command mode for the specified vNIC.                                                                                                                          |
| <b>Step 4</b> | Server /chassis/adapter/host-eth-if # <b>show usnic-config</b> <i>index</i>                    | Displays the usNIC properties for a vNIC.                                                                                                                                                        |

### Example

This example displays the usNIC properties for a vNIC:

```
Server # scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-eth-if eth0
Server /chassis/adapter/host-eth-if # show usnic-config 0
Idx usNIC Count TQ Count RQ Count CQ Count TQ Ring Size RQ Ring Size Interrupt Count

0 113 2 2 4 256 512 4
Server /chassis/adapter/host-eth-if #
```

## Deleting Cisco usNIC from a vNIC

### Before you begin

You must log in to CLI with admin privileges to perform this task.

### Procedure

|               | Command or Action            | Purpose                      |
|---------------|------------------------------|------------------------------|
| <b>Step 1</b> | server# <b>scope chassis</b> | Enters chassis command mode. |

|        | Command or Action                                                | Purpose                                                                                                                                                                                                                                                                                                             |
|--------|------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 2 | server/chassis# <b>scope adapter</b> <i>index</i>                | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> Make sure that the server is powered on before you attempt to view or change adapter settings. To view the index of the adapters configured on your server, use the <b>show adapter</b> command. |
| Step 3 | server/chassis/adapter# <b>scope host-eth-if</b> {eth0   eth1}   | Enters the command mode for the vNIC. Specify the Ethernet ID based on the number of vNICs that you have configured in your environment. For example, specify <b>eth0</b> if you configured only one vNIC.                                                                                                          |
| Step 4 | Server/chassis/adapter/host-eth-if# <b>delete usnic-config 0</b> | Deletes the Cisco usNIC configuration for the vNIC.                                                                                                                                                                                                                                                                 |
| Step 5 | Server/chassis/adapter/host-eth-if# <b>commit</b>                | Commits the transaction to the system configuration<br><br><b>Note</b> The changes take effect when the server is rebooted.                                                                                                                                                                                         |

### Example

This example shows how to delete the Cisco usNIC configuration for a vNIC:

```
server # scope chassis
server/chassis # show adapter
server/chassis # scope adapter 1
server/chassis/adapter # scope host-eth-if eth0
server/chassis/adapter/host-eth-if # delete usnic-config 0
server/chassis/host-eth-if/iscsi-boot *# commit
New host-eth-if settings will take effect upon the next adapter reboot

server/chassis/host-eth-if/usnic-config #
```

## Configuring iSCSI Boot Capability

### Configuring iSCSI Boot Capability for vNICs

To configure the iSCSI boot capability on a vNIC:

- You must log in with admin privileges to perform this task.
- To configure a vNIC to boot a server remotely from an iSCSI storage target, you must enable the PXE boot option on the vNIC.



**Note** You can configure a maximum of 2 iSCSI vNICs for each host.

## Configuring iSCSI Boot Capability on a vNIC

You can configure a maximum of 2 iSCSI vNICs for each host.

### Before you begin

- To configure a vNIC to boot a server remotely from an iSCSI storage target, you must enable the PXE boot option on the vNIC.
- You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **scope host-eth-if** {**eth0** | **eth1** | *name*}
4. Server /chassis/adapter/host-eth-if # **create iscsi-boot** *index*
5. Server /chassis/adapter/host-eth-if/iscsi-boot\* # **create iscsi-target** *index*
6. Server /chassis/adapter/host-eth-if/iscsi-boot\* # **set dhcp-net-settings enabled**
7. Server /chassis/adapter/host-eth-if/iscsi-boot\* # **set initiator-name** *string*
8. Server /chassis/adapter/host-eth-if/iscsi-boot\* # **set dhcp-iscsi-settings enabled**
9. Server /chassis/adapter/host-eth-if/iscsi-boot\* # **commit**

### DETAILED STEPS

|               | Command or Action                                                                              | Purpose                                                                                                                                                                                          |
|---------------|------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                                   | Enters the chassis command mode.                                                                                                                                                                 |
| <b>Step 2</b> | Server /chassis # <b>scope adapter</b> <i>index</i>                                            | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings. |
| <b>Step 3</b> | Server /chassis/adapter # <b>scope host-eth-if</b> { <b>eth0</b>   <b>eth1</b>   <i>name</i> } | Enters the host Ethernet interface command mode for the specified vNIC.                                                                                                                          |
| <b>Step 4</b> | Server /chassis/adapter/host-eth-if # <b>create iscsi-boot</b> <i>index</i>                    | Creates the iSCSI boot index for the vNIC. At this moment, only 0 is allowed as the index.                                                                                                       |
| <b>Step 5</b> | Server /chassis/adapter/host-eth-if/iscsi-boot* # <b>create iscsi-target</b> <i>index</i>      | Creates an iSCSI target for the vNIC. The value can either be 0 or 1.                                                                                                                            |
| <b>Step 6</b> | Server /chassis/adapter/host-eth-if/iscsi-boot* # <b>set dhcp-net-settings enabled</b>         | Enables the DHCP network settings for the iSCSI boot.                                                                                                                                            |
| <b>Step 7</b> | Server /chassis/adapter/host-eth-if/iscsi-boot* # <b>set initiator-name</b> <i>string</i>      | Sets the initiator name. It cannot be more than 223 characters.                                                                                                                                  |
| <b>Step 8</b> | Server /chassis/adapter/host-eth-if/iscsi-boot* # <b>set dhcp-iscsi-settings enabled</b>       | Enables the DHCP iSCSI settings.                                                                                                                                                                 |

|        | Command or Action                                               | Purpose                                                                                                                           |
|--------|-----------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|
| Step 9 | Server /chassis/adapter/host-eth-if/iscsi-boot* # <b>commit</b> | Commits the transaction to the system configuration.<br><br><b>Note</b> The changes will take effect upon the next server reboot. |

### Example

This example shows how to configure the iSCSI boot capability for a vNIC:

```
Server # scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-eth-if eth0
Server /chassis/adapter/host-eth-if # create iscsi-boot 0
Server /adapter/host-eth-if/iscsi-boot *# set dhcp-net-settings enabled
Server /adapter/host-eth-if/iscsi-boot *# set initiator-name iqn.2012-01.com.adser:abcde
Server /adapter/host-eth-if/iscsi-boot *# set dhcp-iscsi-settings enabled
Server /adapter/host-eth-if/iscsi-boot *# commit
```

New host-eth-if settings will take effect upon the next server reset  
Server /adapter/host-eth-if/iscsi-boot #

## Deleting an iSCSI Boot Configuration for a vNIC

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **scope host-eth-if** {eth0 | eth1 | *name*}
4. Server /chassis/adapter/host-eth-if # **delete iscsi-boot 0**
5. Server /chassis/adapter/host-eth-if\* # **commit**

### DETAILED STEPS

|        | Command or Action                                                               | Purpose                                                                                                                                                                                          |
|--------|---------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Server# <b>scope chassis</b>                                                    | Enters the chassis command mode.                                                                                                                                                                 |
| Step 2 | Server /chassis # <b>scope adapter</b> <i>index</i>                             | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings. |
| Step 3 | Server /chassis/adapter # <b>scope host-eth-if</b> {eth0   eth1   <i>name</i> } | Enters the host Ethernet interface command mode for the specified vNIC.                                                                                                                          |

|               | Command or Action                                                | Purpose                                                                                                                          |
|---------------|------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 4</b> | Server /chassis/adapter/host-eth-if # <b>delete iscsi-boot 0</b> | Deletes the iSCSI boot capability for the vNIC.                                                                                  |
| <b>Step 5</b> | Server /chassis/adapter/host-eth-if* # <b>commit</b>             | Commits the transaction to the system configuration<br><br><b>Note</b> The changes will take effect upon the next server reboot. |

### Example

This example shows how to delete the iSCSI boot capability for a vNIC:

```
Server # scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-eth-if eth0
Server /chassis/adapter/host-eth-if # delete iscsi-boot 0
Server /adapter/host-eth-if/iscsi-boot *# commit
New host-eth-if settings will take effect upon the next server reset

Server /adapter/host-eth-if/iscsi-boot #
```

## Backing Up and Restoring the Adapter Configuration

### Exporting the Adapter Configuration

The adapter configuration can be exported as an XML file to a TFTP server.




---

**Important** If any firmware or BIOS updates are in progress, do not export the adapter configuration until those tasks are complete.

---

#### Before you begin

A supported Virtual Interface Card (VIC) must be installed in the chassis and the server must be powered on.  
Obtain the TFTP server IP address.

#### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **export-vnic protocol** *remote server IP address*

## DETAILED STEPS

|        | Command or Action                                                                     | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|--------|---------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Server# <b>scope chassis</b>                                                          | Enters the chassis command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Step 2 | Server /chassis # <b>scope adapter</b> <i>index</i>                                   | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Step 3 | Server /chassis/adapter # <b>export-vnic</b> <i>protocol remote server IP address</i> | Starts the export operation. The adapter configuration file will be stored at the specified path and filename on the remote server at the specified IP address. The protocol can be one of the following: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.<br><br>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is <server_finger_print_ID> Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.<br><br>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to. |

**Example**

This example exports the configuration of adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # export-vnic ftp 192.0.20.34 //test/dnld-ucs-k9-bundle.1.0.2h.bin
Server /chassis/adapter #
```

# Importing the Adapter Configuration



**Important** If any firmware or BIOS updates are in progress, do not import the adapter configuration until those tasks are complete.

## Before you begin

You must log in with admin privileges to perform this task.

## SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **import-vnic** *tftp-ip-address path-and-filename*

## DETAILED STEPS

|               | Command or Action                                                                     | Purpose                                                                                                                                                                                                              |
|---------------|---------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                          | Enters the chassis command mode.                                                                                                                                                                                     |
| <b>Step 2</b> | Server /chassis # <b>scope adapter</b> <i>index</i>                                   | Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> .<br><br><b>Note</b> The server must be powered on before you can view or change adapter settings.                     |
| <b>Step 3</b> | Server /chassis/adapter # <b>import-vnic</b> <i>tftp-ip-address path-and-filename</i> | Starts the import operation. The adapter downloads the configuration file from the specified path on the TFTP server at the specified IP address. The configuration will be installed during the next server reboot. |

## Example

This example imports a configuration for the adapter in PCI slot 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # import-vnic 192.0.2.34 /ucs/backups/adapter4.xml
Import succeeded.
New VNIC adapter settings will take effect upon the next server reset.
Server /chassis/adapter #
```

## What to do next

Reboot the server to apply the imported configuration.



## Restoring Adapter Defaults

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **adapter-reset-defaults index**

### DETAILED STEPS

|        | Command or Action                                     | Purpose                                                                                                                                                                                                                                                                                    |
|--------|-------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Server# <b>scope chassis</b>                          | Enters the chassis command mode.                                                                                                                                                                                                                                                           |
| Step 2 | Server /chassis # <b>adapter-reset-defaults index</b> | Restores factory default settings for the adapter at the PCI slot number specified by the <i>index</i> argument.<br><br><b>Note</b> Resetting the adapter to default settings sets the port speed to 4 X 10 Gbps. Choose 40 Gbps as the port speed only if you are using a 40 Gbps switch. |

### Example

This example restores the default configuration of the adapter in PCI slot 1:

```
Server# scope chassis
Server /chassis # adapter-reset-defaults 1
This operation will reset the adapter to factory default.
All your configuration will be lost.
Continue?[y|N] y
Server /chassis #
```

## Managing Adapter Firmware

### Adapter Firmware

A Cisco UCS C-Series network adapter contains the following firmware components:

- Adapter firmware—The main operating firmware, consisting of an active and a backup image, can be installed from the GUI or CLI interface or from the Host Upgrade Utility (HUU). You can upload a firmware image from either a local file system or a TFTP server.
- Bootloader firmware—The bootloader firmware cannot be installed from the . You can install this firmware using the Host Upgrade Utility.

# Installing Adapter Firmware



**Important** If any firmware or BIOS updates are in progress, do not install the adapter firmware until those tasks are complete.

## Before you begin

You must log in with admin privileges to perform this task.

## SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **update-adapter-fw** *tftp-ip-address path-and-filename* {**activate** | **no-activate**} [*pci-slot*]  
[*pci-slot*]
3. (Optional) Server /chassis # **recover-adapter-update** [*pci-slot*] [*pci-slot*]

## DETAILED STEPS

|               | Command or Action                                                                                                                                                       | Purpose                                                                                                                                                                                                                                                                                             |
|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                                                                                                            | Enters the chassis command mode.                                                                                                                                                                                                                                                                    |
| <b>Step 2</b> | Server /chassis # <b>update-adapter-fw</b> <i>tftp-ip-address path-and-filename</i> { <b>activate</b>   <b>no-activate</b> } [ <i>pci-slot</i> ]<br>[ <i>pci-slot</i> ] | Downloads the specified adapter firmware file from the TFTP server, then installs the firmware as the backup image on one or two specified adapters or, if no adapter is specified, on all adapters. If the <b>activate</b> keyword is specified, the new firmware is activated after installation. |
| <b>Step 3</b> | (Optional) Server /chassis # <b>recover-adapter-update</b> [ <i>pci-slot</i> ] [ <i>pci-slot</i> ]                                                                      | Clears an incomplete firmware update condition on one or two specified adapters or, if no adapter is specified, on all adapters.                                                                                                                                                                    |

## Example

This example begins an adapter firmware upgrade on the adapter in PCI slot 1:

```
Server# scope chassis
Server /chassis # update-adapter-fw 192.0.2.34 /ucs/adapters/adapter4.bin activate 1
Server /chassis #
```

## What to do next

To activate the new firmware, see [Activating Adapter Firmware, on page 223](#).

# Activating Adapter Firmware



- Important** While the activation is in progress, do not:
- Reset, power off, or shut down the server.
  - Reboot or reset .
  - Activate any other firmware.
  - Export technical support or configuration data.

## Before you begin

You must log in with admin privileges to perform this task.

## SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **activate-adapter-fw pci-slot {1 | 2}**

## DETAILED STEPS

|               | Command or Action                                             | Purpose                                                                                                                                                               |
|---------------|---------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                  | Enters the chassis command mode.                                                                                                                                      |
| <b>Step 2</b> | Server /chassis # <b>activate-adapter-fw pci-slot {1   2}</b> | <p>Activates adapter firmware image 1 or 2 on the adapter in the specified PCI slot.</p> <p><b>Note</b> The changes will take effect upon the next server reboot.</p> |

## Example

This example activates adapter firmware image 2 on the adapter in PCI slot 1:

```
Server# scope chassis
Server /chassis # activate-adapter-fw 1 2
Firmware image activation succeeded
Please reset the server to run the activated image
Server /chassis #
```

## What to do next

Reboot the server to apply the changes.





## CHAPTER 11

# Managing Storage Adapters

---

This chapter includes the following sections:

- [Creating Virtual Drives from Unused Physical Drives, on page 225](#)
- [Creating Virtual Drive from an Existing Drive Group, on page 228](#)
- [Importing Foreign Configuration, on page 230](#)
- [Clearing Foreign Configuration, on page 231](#)
- [Retrieving Storage Firmware Logs for a Controller , on page 232](#)
- [Self Encrypting Drives \(Full Disk Encryption\), on page 233](#)
- [Deleting a Virtual Drive, on page 240](#)
- [Initializing a Virtual Drive, on page 241](#)
- [Set as Boot Drive, on page 242](#)
- [Modifying Attributes of a Virtual Drive, on page 243](#)
- [Making a Dedicated Hot Spare, on page 244](#)
- [Making a Global Hot Spare, on page 245](#)
- [Preparing a Drive for Removal, on page 246](#)
- [Removing a Drive from Hot Spare Pools, on page 247](#)
- [Undo Preparing a Drive for Removal, on page 248](#)
- [Enabling Auto Learn Cycles for the Battery Backup Unit, on page 249](#)
- [Disabling Auto Learn Cycles for the Battery Backup Unit, on page 249](#)
- [Starting a Learn Cycle for a Battery Backup Unit, on page 250](#)
- [Toggling the Locator LED for a Physical Drive, on page 251](#)
- [Clearing Controller Configuration, on page 252](#)
- [Restoring Storage Controller to Factory Defaults, on page 253](#)
- [Viewing Storage Controller Logs, on page 254](#)
- [Viewing Physical Drive Details, on page 254](#)
- [Viewing SIOC NVMe Drive Details , on page 256](#)

## Creating Virtual Drives from Unused Physical Drives

### Before you begin

You must log in with admin privileges to perform this task.

## SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis/server # **scope storageadapter Slot-ID**
4. Server /chassis/server/storageadapter # **create virtual-drive**
5. Server /chassis/storageadapter # **show virtual-drive**

## DETAILED STEPS

|               | Command or Action                                                   | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|---------------|---------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                       | Enters chassis command mode.                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Step 2</b> | Server /chassis # <b>scope server {1   2}</b>                       | Enters server command mode of server 1 or 2.                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter Slot-ID</b>        | Enters storage adapter command mode.                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Step 4</b> | Server /chassis/server/storageadapter # <b>create virtual-drive</b> | At this point, you are prompted to enter information corresponding to the RAID level, the physical drives to be used, the size and the write policy for the new virtual drive. Enter the appropriate information at each prompt.<br><br>When you have finished specifying the virtual drive information, you are prompted to confirm that the information is correct. Enter <b>y</b> (yes) to confirm, or <b>n</b> (no) to cancel the operation. |
| <b>Step 5</b> | Server /chassis/storageadapter # <b>show virtual-drive</b>          | Displays the existing virtual drives.                                                                                                                                                                                                                                                                                                                                                                                                            |

## Example

This example shows how to create a new virtual drive that spans two unused physical drives.

```

Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # create-virtual-drive
Please enter RAID level
0, 1, 5, 10, 50 --> 1

Please choose from the following 10 unused physical drives:
 ID Size(MB) Model Interface Type
 -- -
 1 571776 SEAGATE SAS HDD
 2 571776 SEAGATE SAS HDD
 4 571776 SEAGATE SAS HDD
 5 428672 SEAGATE SAS HDD
 6 571776 SEAGATE SAS HDD
 7 571776 SEAGATE SAS HDD
 8 571776 SEAGATE SAS HDD
 9 428672 SEAGATE SAS HDD
 10 571776 SEAGATE SAS HDD
 11 953344 SEAGATE SAS HDD

Specify physical disks for span 0:
Enter comma-separated PDs from above list--> 1,2
Please enter Virtual Drive name (15 characters maximum)--> test_v_drive

```

Please enter Virtual Drive size in MB, GB, or TB  
 Example format: '400 GB' --> **10 GB**

Optional attribute:

stripsize: defaults to 64K Bytes

- 0: 8K Bytes
- 1: 16K Bytes
- 2: 32K Bytes
- 3: 64K Bytes
- 4: 128K Bytes
- 5: 256K Bytes
- 6: 512K Bytes
- 7: 1024K Bytes

Choose number from above options or hit return to pick default--> **2**  
 stripsize will be set to 32K Bytes (6 and 'strip-size\:32k')

Disk Cache Policy: defaults to Unchanged

- 0: Unchanged
- 1: Enabled
- 2: Disabled

Choose number from above options or hit return to pick default--> **0**  
 Disk Cache Policy will be set to Unchanged (0 and 'disk-cache-policy\:unchanged')

)

Read Policy: defaults to No Read Ahead

- 0: No Read Ahead
- 1: Always

Choose number from above options or hit return to pick default--> **0**  
 Read Policy will be set to No Read Ahead (0 and 'read-policy\:no-read-ahead')

Write Policy: defaults to Write Through

- 0: Write Through
- 1: Write Back Good BBU
- 2: Always Write Back

Choose number from above options or hit return to pick default--> **0**  
 Write Policy will be set to Write Through (0 and 'write-policy\:write-through')

IO Policy: defaults to Direct I/O

- 0: Direct I/O
- 1: Cached I/O

Choose number from above options or hit return to pick default--> **0**  
 IO Policy will be set to Direct I/O (0 and 'io-policy\:direct-io')

Access Policy: defaults to Read Write

- 0: Read Write
- 1: Read Only
- 2: Blocked

Choose number from above options or hit return to pick default--> **0**  
 Access Policy will be set to Read Write (0 and 'access-policy\:read-write')

New virtual drive will have the following characteristics:

- Spans: '[1.2]'
- RAID level: '1'
- Name: 'test\_v\_drive'
- Size: 10 GB
- stripsize: 32K Bytes

- Disk Cache Policy: Unchanged
- Read Policy: No Read Ahead
- Write Policy: Write Through
- IO Policy: Direct I/O
- Access Policy: Read Write

OK? (y or n)--> **y**

```
Server /chassis/server/storageadapter # show virtual-drive
Virtual Drive Health Status Name Size RAID Level
Boot Drive

0 Good Optimal 150528 MB RAID 0
false
1 Good Optimal 20480 MB RAID 0
true
2 Good Optimal 114140 MB RAID 0
false
3 Good Optimal test_v_drive 10000 MB RAID 1
false
4 Good Optimal new_from_test 500 MB RAID 1
false

Server /chassis/storageadapter #
```

## Creating Virtual Drive from an Existing Drive Group

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis/server # **scope storageadapter Slot-ID**
4. Server /chassis/storageadapter # **carve-virtual-drive**
5. Server /chassis/server/storageadapter # **show virtual-drive**

### DETAILED STEPS

|               | Command or Action                                            | Purpose                                                                                                                                                                                                             |
|---------------|--------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                | Enters chassis command mode.                                                                                                                                                                                        |
| <b>Step 2</b> | Server /chassis # <b>scope server {1   2}</b>                | Enters server command mode of server 1 or 2.                                                                                                                                                                        |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter Slot-ID</b> | Enters storage adapter command mode.                                                                                                                                                                                |
| <b>Step 4</b> | Server /chassis/storageadapter # <b>carve-virtual-drive</b>  | At this point, you are prompted to enter information corresponding to the virtual drives to be used, and the size and the write policy for the new virtual drive. Enter the appropriate information at each prompt. |



|               | Command or Action                                                 | Purpose                                                                                                                                                                                                  |
|---------------|-------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                                   | When you have finished specifying the virtual drive information, you are prompted to confirm that the information is correct. Enter <b>y</b> (yes) to confirm, or <b>n</b> (no) to cancel the operation. |
| <b>Step 5</b> | Server /chassis/server/storageadapter # <b>show virtual-drive</b> | Displays the existing virtual drives.                                                                                                                                                                    |

### Example

This example shows how to carve a new virtual drive out of unused space in an existing RAID 1 drive group:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # carve-virtual-drive
 < Fetching virtual drives...>
```

| ID | Name     | RL | VDSize | MaxPossibleSize | PD(s) |
|----|----------|----|--------|-----------------|-------|
| 0  | RAID0_12 | 0  | 100 MB | Unknown         | 1,2   |

```
Please choose from the above list the virtual drive number
whose space the new virtual drive will share--> 0
New virtual drive will share space with VD 0

Please enter Virtual Drive name (15 characters maximum)--> test_v_drive
Please enter Virtual Drive size in MB, GB, or TB (maximum: Unknown)
 Example format: '400 GB' --> 10 GB

Optional attributes:

 stripsize: defaults to 64K Bytes
 0: 8K Bytes
 1: 16K Bytes
 2: 32K Bytes
 3: 64K Bytes
 4: 128K Bytes
 5: 256K Bytes
 6: 512K Bytes
 7: 1024K Bytes
 Choose number from above options or hit return to pick default--> 0
 stripsize will be set to 8K Bytes (4 and 'strip-size\:8k')

 Disk Cache Policy: defaults to Unchanged
 0: Unchanged
 1: Enabled
 2: Disabled
 Choose number from above options or hit return to pick default--> 0
 Disk Cache Policy will be set to Unchanged (0 and 'disk-cache-policy\:unchanged')

 Read Policy: defaults to No Read Ahead
 0: No Read Ahead
 1: Always
 Choose number from above options or hit return to pick default--> 0
 Read Policy will be set to No Read Ahead (0 and 'read-policy\:no-read-ahead')

 Write Policy: defaults to Write Through
```

```

 0: Write Through
 1: Write Back Good BBU
 2: Always Write Back
 Choose number from above options or hit return to pick default--> 0
Write Policy will be set to Write Through (0 and 'write-policy\:write-through')

 IO Policy: defaults to Direct I/O
 0: Direct I/O
 1: Cached I/O
 Choose number from above options or hit return to pick default--> 0
IO Policy will be set to Direct I/O (0 and 'io-policy\:direct-io')

 Access Policy: defaults to Read Write
 0: Read Write
 1: Read Only
 2: Blocked
 Choose number from above options or hit return to pick default--> 0
Access Policy will be set to Read Write (0 and 'access-policy\:read-write')

New virtual drive will have the following characteristics:
- It will share space with virtual drive 0
- Name: 'amit'
- Size: 10 GB
- stripsize: 8K Bytes
- Disk Cache Policy: Unchanged
- Read Policy: No Read Ahead
- Write Policy: Write Through
- IO Policy: Direct I/O
- Access Policy: Read Write

OK? (y or n)--> y
Server /chassis/storageadapter # show virtual-drive
Virtual Drive Health Status Name Size RAID Level
Boot Drive

0 Good Optimal 150528 MB RAID 0
false
1 Good Optimal 20480 MB RAID 0
true
2 Good Optimal 114140 MB RAID 0
false
3 Good Optimal test_v_drive 10000 MB RAID 1
false
4 Good Optimal new_from_test 500 MB RAID 1
false

Server /chassis/server/storageadapter #

```

## Importing Foreign Configuration

When one or more physical drives that have previously been configured with a different controller are inserted into a server, they are identified as foreign configurations. You can import these foreign configurations to a controller.

### Before you begin

You must log in with admin privileges to perform this task.

**SUMMARY STEPS**

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis/server # **scope storageadapter Slot-ID**
4. Server /chassis/server/storageadapter # **import-foreign-config**

**DETAILED STEPS**

|               | <b>Command or Action</b>                                                | <b>Purpose</b>                                                                                                                                  |
|---------------|-------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                           | Enters chassis command mode.                                                                                                                    |
| <b>Step 2</b> | Server /chassis # <b>scope server {1   2}</b>                           | Enters server command mode of server 1 or 2.                                                                                                    |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter Slot-ID</b>            | Enters storage adapter command mode.                                                                                                            |
| <b>Step 4</b> | Server /chassis/server/storageadapter #<br><b>import-foreign-config</b> | You are prompted to confirm the action. Enter <b>yes</b> to confirm.<br><br><b>Note</b> If you do not enter <b>yes</b> , the action is aborted. |

**Example**

This example shows how to import all foreign configurations on the MegaRAID controller in slot 3:

```
Server# scope chassis
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # import-foreign-config
Are you sure you want to import all foreign configurations on this controller?
Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter #
```

# Clearing Foreign Configuration




---

**Important** This task clears all foreign configuration on the controller. Also, all configuration information from all physical drives hosting foreign configuration is deleted. This action cannot be reverted.

---

**Before you begin**

You must log in with admin privileges to perform this task.

**SUMMARY STEPS**

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis/server # **scope storageadapter Slot-ID**

4. Server /chassis/server/storageadapter # **clear-foreign-config**

## DETAILED STEPS

|               | Command or Action                                                   | Purpose                                                                                                                                         |
|---------------|---------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                       | Enters chassis command mode.                                                                                                                    |
| <b>Step 2</b> | Server /chassis # <b>scope server</b> {1   2}                       | Enters server command mode of server 1 or 2.                                                                                                    |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i> | Enters storage adapter command mode.                                                                                                            |
| <b>Step 4</b> | Server /chassis/server/storageadapter # <b>clear-foreign-config</b> | You are prompted to confirm the action. Enter <b>yes</b> to confirm.<br><br><b>Note</b> If you do not enter <b>yes</b> , the action is aborted. |

**Example**

This example shows how to clear all foreign configurations on the MegaRAID controller in slot 3:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # clear-foreign-config
Are you sure you want to clear all foreign configurations on this controller?
All data on the drive(s) will be lost.
Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter #
```

## Retrieving Storage Firmware Logs for a Controller

This task retrieves the firmware logs for the controller and places it in the `/var/log` location. This ensures that this log data is available when Technical Support Data is requested.

**Before you begin**

You must log in with admin privileges to perform this task

## SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope storageadapter** *slot*
3. Server /chassis/storageadapter # **get-storage-fw-log**
4. At the prompt, enter **yes**.

## DETAILED STEPS

|               | Command or Action             | Purpose                          |
|---------------|-------------------------------|----------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b> | Enters the chassis command mode. |

|               | Command or Action                                          | Purpose                                                              |
|---------------|------------------------------------------------------------|----------------------------------------------------------------------|
| <b>Step 2</b> | Server /chassis # <b>scope storageadapter slot</b>         | Enters the command mode for an installed storage card.               |
| <b>Step 3</b> | Server /chassis/storageadapter # <b>get-storage-fw-log</b> | Retrieves the storage firmware log file to the specified controller. |
| <b>Step 4</b> | At the prompt, enter <b>yes</b> .                          | Begins download of the storage firmware log files.                   |

### Example

This example shows how to view the download status of the retrieved storage firmware log files:

```
Server # scope chassis
Server /chassis # scope storageadapter SLOT-HBA
Server /chassis/storageadapter # get-storage-fw-log
```

You are initiating the retrieval of the storage firmware log to Cisco IMC. This task will take a few minutes to complete. You may monitor the status of the retrieval by running the 'get-storage-fw-log-download-progress' command. When the download is finished, the 'Storage Firmware Log Status' value will be 'Complete', along with the size of the logfile. You may then download the log file using the Technical Support facility, accessible from /cimc/tech-support scope, or the WebUI's Utilities page.

```
Do you want to proceed?
Enter 'yes' to confirm -> yes
Server /chassis/storageadapter # get-storage-fw-log-download-progress
Storage Firmware Log Status: Complete (total size 61906 bytes)
```

## Self Encrypting Drives (Full Disk Encryption)

Cisco IMC supports self encrypting drives (SED). A special hardware in the drives encrypts incoming data and decrypts outgoing data in real-time. This feature is also called Full Disk Encryption (FDE).

The data on the drive is encrypted on its way into the drive and decrypted on its way out. However, if you lock the drive, no security key is required to retrieve the data.

When a drive is locked, an encryption key is created and stored internally. All data stored on this drive is encrypted using that key, and stored in encrypted form. Once you store the data in this manner, a security key is required in order to un-encrypt and fetch the data from the drive. Unlocking a drive deletes that encryption key and renders the stored data unusable. This is called a Secure Erase. The FDE comprises a key ID and a security key.

The FDE feature supports the following operations:

- Enable and disable security on a controller
- Create a secure virtual drive
- Secure a non-secure drive group
- Unlock foreign configuration drives
- Enable security on a physical drive (JBOD)

- Clear secure SED drives
- Clear secure foreign configuration

### Scenarios to consider While Configuring Controller Security in a Dual or Multiple Controllers Environment



**Note** Dual or Multiple controllers connectivity is available only on some servers.

Controller security can be enabled, disabled, or modified independently. However, local and remote key management applies to all the controllers on the server. Therefore security action involving switching the key management modes must be performed with caution. In a scenario where both controllers are secure, and you decide to move one of the controllers to a different mode, you need to perform the same operation on the other controller as well.

Consider the following two scenarios:

- Scenario 1—Key management is set to remote; both controllers are secure and use remote key management. If you now wish to switch to local key management, switch the key management for each controller and disable remote key management.
- Scenario 2—Key management is set to local; both controllers are secure and use local key management. If you now wish to switch to remote key management, enable remote key management and switch the key management for each controller.

If you do not modify the controller security method on any one of the controllers, it renders the secure key management in an unsupported configuration state.

## Enabling Security on a Controller

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *Slot-ID*
4. Server /chassis/server/storageadapter # **enable-controller-security**
5. Server /chassis/server/storageadapter # **show detail**

### DETAILED STEPS

|               | Command or Action                                                   | Purpose                                      |
|---------------|---------------------------------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                       | Enters chassis command mode.                 |
| <b>Step 2</b> | Server /chassis # <b>scope server</b> {1   2}                       | Enters server command mode of server 1 or 2. |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i> | Enters storage adapter command mode.         |

|               | Command or Action                                                            | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|---------------|------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 4</b> | Server /chassis/server/storageadapter #<br><b>enable-controller-security</b> | At this point, you are prompted to enter the key-id and then the security key, you can either enter a key-id or a security key of your choice in the respective prompts or you can use the suggested keys.<br><br>Depending on whether you want to use the suggested key-id and security key, or key-id and security key of your choice, enter <b>y</b> (yes) to use the suggested keys, or <b>n</b> (no) to enter the keys of your choice at the appropriate prompts. |
| <b>Step 5</b> | Server /chassis/server/storageadapter # <b>show detail</b>                   | Displays the storage drive details.                                                                                                                                                                                                                                                                                                                                                                                                                                    |

### Example

The following example shows how to enable security on a controller:

```
Server# scope chassis
Server/chassis # scope server 1
Server /chassis/server # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # enable-controller-security
Use generated key-id 'UCSC-MRAID12G_FHH18250010_1d85dcd3'? (y or n)--> y
Use suggested security-key '6ICsmuX@oVB7e9wXt79qsTgp6ICsmuX@'? (y or n)--> n
Enter security-key --> testSecurityKey
Will use security-key 'testSecurityKey'
Server /chassis/server/storageadapter show detail
PCI Slot SBMezz1:
 <stuff deleted>
 Controller is Secured: 1
Server /chassis/server/storageadapter #
```

## Disabling Security on a Controller

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *Slot-ID*
4. Server /chassis/server/storageadapter # **disable-controller-security**
5. Server /chassis/server/storageadapter # **show detail**

### DETAILED STEPS

|               | Command or Action                             | Purpose                                      |
|---------------|-----------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                 | Enters chassis command mode.                 |
| <b>Step 2</b> | Server /chassis # <b>scope server</b> {1   2} | Enters server command mode of server 1 or 2. |

|               | Command or Action                                                             | Purpose                                                                                                                                                                        |
|---------------|-------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>           | Enters storage adapter command mode.                                                                                                                                           |
| <b>Step 4</b> | Server /chassis/server/storageadapter #<br><b>disable-controller-security</b> | A confirmation prompt appears.<br>At the confirmation prompt, enter <b>yes</b> to confirm, or <b>n</b> (no) to cancel the operation.<br>This disables the controller security. |
| <b>Step 5</b> | Server /chassis/server/storageadapter # <b>show detail</b>                    | Displays the storage drive details.                                                                                                                                            |

### Example

The following example shows how to disable security on a controller:

```
Server# scope chassis
Server/chassis # scope server 2
Server /chassis/server # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # disable-controller-security
Note: this operation will fail if any secured virtual drives or secure JBODs are present.
Are you sure you want to disable security on this controller?
Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter # show detail
PCI Slot SBMezz1:
 <content deleted>
 Controller is Secured: 0
Server /chassis/server/storageadapter #
```

## Modifying Controller Security Settings

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *Slot-ID*
4. Server /chassis/server/storageadapter # **modify-controller-security**

### DETAILED STEPS

|               | Command or Action                                                   | Purpose                                      |
|---------------|---------------------------------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                       | Enters chassis command mode.                 |
| <b>Step 2</b> | Server /chassis # <b>scope server</b> {1   2}                       | Enters server command mode of server 1 or 2. |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i> | Enters storage adapter command mode.         |



|               | Command or Action                                                            | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|---------------|------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 4</b> | Server /chassis/server/storageadapter #<br><b>modify-controller-security</b> | <p>At this point, you are prompted to enter the current security key, option to choose whether you want to reset the key-id and the new security key. Enter the appropriate information.</p> <p><b>Note</b> The modify command allows you to modify the key ID and/or the security key. You are prompted to enter the current security key only if you choose to modify the security key. Modifying the key ID alone does not require specifying the current security key.</p> <p>At the confirmation prompt, enter <b>y</b> (yes) to confirm, or <b>n</b> (no) to cancel the operation.</p> |

### Example

The following example shows how to modify the security settings of a controller:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # modify-controller-security
Please enter current security-key --> testSecurityKey
Keep current key-id 'UCSC-MRAID12G_FHH18250010_1d85dcd3'? (y or n)--> n
Enter new key-id: NewKeyId
Will change key-id to 'NewKeyId'
Keep current security-key? (y or n)--> y

Server /chassis/server/storageadapter #
```

## Verifying the Security Key Authenticity

If you are not sure about the security key, you can use this procedure to verify whether the security key that you provide matches the controller security key.

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis/server # **scope storageadapter Slot-ID**
4. Server /chassis/server/storageadapter # **verify-controller-security-key**

### DETAILED STEPS

|               | Command or Action             | Purpose                      |
|---------------|-------------------------------|------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b> | Enters chassis command mode. |

|               | Command or Action                                                                | Purpose                                                                                                                                                                        |
|---------------|----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 2</b> | Server /chassis # <b>scope server</b> {1   2}                                    | Enters server command mode of server 1 or 2.                                                                                                                                   |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>              | Enters storage adapter command mode.                                                                                                                                           |
| <b>Step 4</b> | Server /chassis/server/storageadapter #<br><b>verify-controller-security-key</b> | At the prompt, enter the security key and press Enter.<br>If you enter a security key that does not match the controller security key, a verification failure message appears. |

### Example

The following example shows how to verify the security key of a controller:

```
Server # scope chassis
Server/chassis # scope server 2
Server /chassis/server # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # verify-controller-security-key
Please enter the security key to verify -> WrongSecurityKey
verify-controller-security-key failed.
Error: "r-type: RAID controller: SBMezz1 command-status: Lock key from backup failed
verification"
Server /chassis/server/storageadapter #
Server /chassis/server/storageadapter # verify-controller-security-key
Please enter the security key to verify -> testSecurityKey
Server /chassis/server/storageadapter #
```

## Switching Controller Security From Remote to Local Key Management

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *Slot-ID*
4. Server /chassis/server/storageadapter # **switch-to-local-key-mgmt**
5. Server /chassis/server/storageadapter # *key id*

### DETAILED STEPS

|               | Command or Action                                                   | Purpose                                      |
|---------------|---------------------------------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                       | Enters chassis command mode.                 |
| <b>Step 2</b> | Server /chassis # <b>scope server</b> {1   2}                       | Enters server command mode of server 1 or 2. |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i> | Enters storage adapter command mode.         |

|        | Command or Action                                                       | Purpose                                                                                                                                                    |
|--------|-------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 4 | Server /chassis/server/storageadapter # <b>switch-to-local-key-mgmt</b> | Enter <b>y</b> at the confirmation prompt.<br><br><b>Note</b> If you have multiple controller you must switch the security on those as well.               |
| Step 5 | Server /chassis/server/storageadapter # <i>key id</i>                   | Enter the new key ID at the prompt. Switches to local key management.<br><br><b>Note</b> Entering the security key is mandatory to perform this operation. |

### Example

The following example shows how to switch controller security from remote to local key management:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # switch-to-local-key-mgmt
Executing this command will require you to disable remote key management once switch is
complete.
Do you want to continue(y or n)?y
Proceeding to switch to local key management.
Enter new security-key: test
Will change security-key to 'test'
Switch to local key management complete on controller in SBMezz1.
Remote key management needs to be disabled
Please disable remote key management.
Server /chassis/server/storageadapter #
```

### What to do next

After you switch from Remote to Local Key Management, ensure that you disable KMIP secure key management.

## Switching Controller Security From Local to Remote Key Management

### Before you begin

- You must log in with admin privileges to perform this task.
- KMIP must be enabled.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *Slot-ID*
4. Server /chassis/server/storageadapter # **switch-to-remote-key-mgmt**
5. Server /chassis/server/storageadapter # *security id*

## DETAILED STEPS

|               | Command or Action                                                           | Purpose                                                                                                                                                       |
|---------------|-----------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                               | Enters chassis command mode.                                                                                                                                  |
| <b>Step 2</b> | Server /chassis # <b>scope server</b> {1   2}                               | Enters server command mode of server 1 or 2.                                                                                                                  |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>         | Enters storage adapter command mode.                                                                                                                          |
| <b>Step 4</b> | Server /chassis/server/storageadapter #<br><b>switch-to-remote-key-mgmt</b> | Enter <b>y</b> at the confirmation prompt.                                                                                                                    |
| <b>Step 5</b> | Server /chassis/server/storageadapter # <i>security id</i>                  | Enter the security key at the prompt. Switches to remote key management.<br><br><b>Note</b> Entering the security key is mandatory to perform this operation. |

## Example

The following example shows how to switch controller security from local to remote key management:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # switch-to-remote-key-mgmt
Changing the security key requires existing security key.
Please enter current security-key --> test
Switch to remote key management complete on controller in SBMezz1.
Server /chassis/server/storageadapter #
```

## Deleting a Virtual Drive



**Important** This task deletes a virtual drive, including the drives that run the booted operating system. So back up any data that you want to retain before you delete a virtual drive.

### Before you begin

You must log in with admin privileges to perform this task.

## SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *Slot-ID*
4. Server /chassis/server/storageadapter # **scope virtual-drive** *drive-number*
5. Server /chassis/server/storageadapter/virtual-drive # **delete-virtual-drive**

## DETAILED STEPS

|               | Command or Action                                                                 | Purpose                                                                                                                                         |
|---------------|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                                     | Enters chassis command mode.                                                                                                                    |
| <b>Step 2</b> | Server /chassis # <b>scope server {1   2}</b>                                     | Enters server command mode of server 1 or 2.                                                                                                    |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter Slot-ID</b>                      | Enters storage adapter command mode.                                                                                                            |
| <b>Step 4</b> | Server /chassis/server/storageadapter # <b>scope virtual-drive drive-number</b>   | Enters command mode for the specified virtual drive.                                                                                            |
| <b>Step 5</b> | Server /chassis/server/storageadapter/virtual-drive # <b>delete-virtual-drive</b> | You are prompted to confirm the action. Enter <b>yes</b> to confirm.<br><br><b>Note</b> If you do not enter <b>yes</b> , the action is aborted. |

**Example**

This example shows how to delete virtual drive 3.

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope virtual-drive 3
Server /chassis/server/storageadapter/virtual-drive # delete-virtual-drive
Are you sure you want to delete virtual drive 3?
All data on the drive will be lost. Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter/virtual-drive #
```

## Initializing a Virtual Drive

All data on a virtual drive is lost when you initialize the drive. Before you run an initialization, back up any data on the virtual drive that you want to save.

**Before you begin**

You must log in with admin privileges to perform this task.

## SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis/server # **scope storageadapter Slot-ID**
4. Server /chassis/server/storageadapter # **scope virtual-drive drive-number**
5. Server /chassis/server/storageadapter/virtual-drive # **start-initialization**
6. Server /chassis/server/storageadapter/virtual-drive # **cancel-initialization**
7. Server /chassis/server/storageadapter/physical-drive # **get-operation-status**

## DETAILED STEPS

|               | Command or Action                                                                      | Purpose                                                               |
|---------------|----------------------------------------------------------------------------------------|-----------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                                          | Enters chassis command mode.                                          |
| <b>Step 2</b> | Server /chassis # <b>scope server</b> {1   2}                                          | Enters server command mode of server 1 or 2.                          |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>                    | Enters storage adapter command mode.                                  |
| <b>Step 4</b> | Server /chassis/server/storageadapter # <b>scope virtual-drive</b> <i>drive-number</i> | Enters command mode for the specified virtual drive.                  |
| <b>Step 5</b> | Server /chassis/server/storageadapter/virtual-drive # <b>start-initialization</b>      | Initializes the specified virtual drive.                              |
| <b>Step 6</b> | Server /chassis/server/storageadapter/virtual-drive # <b>cancel-initialization</b>     | (Optional) Cancels the initialization of the specified virtual drive. |
| <b>Step 7</b> | Server /chassis/server/storageadapter/physical-drive # <b>get-operation-status</b>     | Displays the status of the task that is in progress on the drive.     |

**Example**

This example shows how to initialize virtual drive 3 using fast initialization:

```
Server# scope chassis
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/storageadapter # scope virtual-drive 3
Server /chassis/server/storageadapter/virtual-drive # start-initialization
Are you sure you want to initialize virtual drive 3?
All data on the drive will be lost. Enter 'yes' to confirm -> yes
Fast (0) or full (1) initialization? -> 0
Server /chassis/server/storageadapter/virtual-drive # get-operation-status

progress-percent: 20%
elapsed -seconds: 30
operation-in-progress: initializing virtual drive

Server /chassis/server/storageadapter/virtual-drive #
```

# Set as Boot Drive

**Before you begin**

You must log in with admin privileges to perform this task.

## SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *Slot-ID*
4. Server /chassis/server/storageadapter # **scope virtual-drive** *drive-number*

### 5. Server /chassis/server/storageadapter # **set-boot-drive**

#### DETAILED STEPS

|               | Command or Action                                                                      | Purpose                                                   |
|---------------|----------------------------------------------------------------------------------------|-----------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                                          | Enters chassis command mode.                              |
| <b>Step 2</b> | Server /chassis # <b>scope server</b> {1   2}                                          | Enters server command mode of server 1 or 2.              |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>                    | Enters storage adapter command mode.                      |
| <b>Step 4</b> | Server /chassis/server/storageadapter # <b>scope virtual-drive</b> <i>drive-number</i> | Enters command mode for the specified virtual drive.      |
| <b>Step 5</b> | Server /chassis/server/storageadapter # <b>set-boot-drive</b>                          | Specifies the controller to boot from this virtual drive. |

#### Example

This example shows how to specify the controller to boot from virtual drive 3:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope virtual-drive 3
Server /chassis/server/storageadapter/virtual-drive # set-boot-drive
Are you sure you want to set virtual drive 3 as the boot drive?
Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter/virtual-drive #
```

## Modifying Attributes of a Virtual Drive

#### Before you begin

You must log in with admin privileges to perform this task.

#### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *Slot-ID*
4. Server /chassis/server/storageadapter # **scope virtual-drive** 3
5. Server /chassis/server/storageadapter/virtual-drive # **modify-attributes**

#### DETAILED STEPS

|               | Command or Action                             | Purpose                                      |
|---------------|-----------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                 | Enters chassis command mode.                 |
| <b>Step 2</b> | Server /chassis # <b>scope server</b> {1   2} | Enters server command mode of server 1 or 2. |

|               | Command or Action                                                                 | Purpose                                           |
|---------------|-----------------------------------------------------------------------------------|---------------------------------------------------|
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>               | Enters storage adapter command mode.              |
| <b>Step 4</b> | Server /chassis/server/storageadapter # <b>scope virtual-drive</b><br>3           | Enters the command mode for the virtual drive.    |
| <b>Step 5</b> | Server /chassis/server/storageadapter/virtual-drive #<br><b>modify-attributes</b> | Prompts you to select a different current policy. |

### Example

This example shows how to carve a new virtual drive out of unused space in an existing RAID 1 drive group:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope virtual-drive
Server /chassis/server/storageadapter/virtual-drive # modify-attributes
```

```
Current write policy: Write Back
```

```
0: Write Through
1: Write Back
2: Write Back even if Bad BBU
```

```
Choose number from above options --> 0
```

```
The following attribute will be modified:
```

```
- Write policy: Write Through
```

```
OK? (y or n) --> y
```

```
operation in progress.
```

```
Server /chassis/server/storageadapter/virtual-drive #
```

## Making a Dedicated Hot Spare

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *Slot-ID*
4. Server /chassis/server/storageadapter # **scope physical-drive** *drive-number*
5. Server /chassis/server/storageadapter/physical-drive # **make-dedicated-hot-spare**



## DETAILED STEPS

|               | Command or Action                                                                       | Purpose                                                                                        |
|---------------|-----------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                                           | Enters chassis command mode.                                                                   |
| <b>Step 2</b> | Server /chassis # <b>scope server</b> {1   2}                                           | Enters server command mode of server 1 or 2.                                                   |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>                     | Enters storage adapter command mode.                                                           |
| <b>Step 4</b> | Server /chassis/server/storageadapter # <b>scope physical-drive</b> <i>drive-number</i> | Enters command mode for the specified physical drive.                                          |
| <b>Step 5</b> | Server /chassis/server/storageadapter/physical-drive # <b>make-dedicated-hot-spare</b>  | You are prompted to choose a virtual drive for which the dedicated hot spare is being created. |

## Example

This example shows how to make physical drive 3 a dedicated hot spare for virtual drive 6:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # make-dedicated-hot-spare
 5: VD_OS_1, RAID 0, 102400 MB, physical disks: 1
 6: VD_OS_2, RAID 0, 12288 MB, physical disks: 1
 7: VD_OS_3, RAID 0, 12288 MB, physical disks: 1
 8: VD_DATA_1, RAID 0, 12512 MB, physical disks: 1
 9: RAID1_2358, RAID 1, 40000 MB, physical disks: 2,3,5,8
 11: JFB_RAID1_67, RAID 1, 20000 MB, physical disks: 6,7
 12: JFB_Crv_R1_40, RAID 1, 40000 MB, physical disks: 6,7
 13: JFB_R1_10GB, RAID 1, 10000 MB, physical disks: 6,7

Please choose from the above 8 virtual drives-->6

Server /chassis/server/storageadapter/physical-drive #
```

## Making a Global Hot Spare

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *Slot-ID*
4. Server /chassis/server/storageadapter # **scope physical-drive** *drive-number*
5. Server /chassis/server/storageadapter/physical-drive # **make-global-hot-spare**
6. Server /chassis/server/storageadapter/physical-drive # **get-operation-status**

## DETAILED STEPS

|               | Command or Action                                                                       | Purpose                                                           |
|---------------|-----------------------------------------------------------------------------------------|-------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                                           | Enters chassis command mode.                                      |
| <b>Step 2</b> | Server /chassis # <b>scope server</b> {1   2}                                           | Enters server command mode of server 1 or 2.                      |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>                     | Enters storage adapter command mode.                              |
| <b>Step 4</b> | Server /chassis/server/storageadapter # <b>scope physical-drive</b> <i>drive-number</i> | Enters command mode for the specified physical drive.             |
| <b>Step 5</b> | Server /chassis/server/storageadapter/physical-drive # <b>make-global-hot-spare</b>     |                                                                   |
| <b>Step 6</b> | Server /chassis/server/storageadapter/physical-drive # <b>get-operation-status</b>      | Displays the status of the task that is in progress on the drive. |

## Example

This example shows how to make physical drive 3 a global hot spare:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # make-global-hot-spare
Server /chassis/server/storageadapter/physical-drive #
```

## Preparing a Drive for Removal

You can confirm this task only on physical drives that display the **Unconfigured Good** status.

### Before you begin

You must log in with admin privileges to perform this task.

## SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *Slot-ID*
4. Server /chassis/server/storageadapter # **scope physical-drive** *drive-number*
5. Server /chassis/server/storageadapter/physical-drive # **prepare-for-removal**

## DETAILED STEPS

|               | Command or Action             | Purpose                      |
|---------------|-------------------------------|------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b> | Enters chassis command mode. |

|        | Command or Action                                                                       | Purpose                                               |
|--------|-----------------------------------------------------------------------------------------|-------------------------------------------------------|
| Step 2 | Server /chassis # <b>scope server</b> {1   2}                                           | Enters server command mode of server 1 or 2.          |
| Step 3 | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>                     | Enters storage adapter command mode.                  |
| Step 4 | Server /chassis/server/storageadapter # <b>scope physical-drive</b> <i>drive-number</i> | Enters command mode for the specified physical drive. |
| Step 5 | Server /chassis/server/storageadapter/physical-drive # <b>prepare-for-removal</b>       |                                                       |

### Example

This example shows how to prepare physical drive 3 for removal.

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # prepare-for-removal
Server /chassis/server/storageadapter/physical-drive #
```

## Removing a Drive from Hot Spare Pools

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *Slot-ID*
4. Server /chassis/server/storageadapter # **scope physical-drive** *drive-number*
5. Server /chassis/server/storageadapter/physical-drive # **remove-hot-spare**

### DETAILED STEPS

|        | Command or Action                                                                       | Purpose                                               |
|--------|-----------------------------------------------------------------------------------------|-------------------------------------------------------|
| Step 1 | Server # <b>scope chassis</b>                                                           | Enters chassis command mode.                          |
| Step 2 | Server /chassis # <b>scope server</b> {1   2}                                           | Enters server command mode of server 1 or 2.          |
| Step 3 | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>                     | Enters storage adapter command mode.                  |
| Step 4 | Server /chassis/server/storageadapter # <b>scope physical-drive</b> <i>drive-number</i> | Enters command mode for the specified physical drive. |
| Step 5 | Server /chassis/server/storageadapter/physical-drive # <b>remove-hot-spare</b>          | Removes a drive from the host spare pool.             |

### Example

This example shows how to remove physical drive 3 from the hot spare pools:

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # remove-hot-spare
Server /chassis/server/storageadapter/physical-drive #
```

## Undo Preparing a Drive for Removal

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *Slot-ID*
4. Server /chassis/server/storageadapter # **scope physical-drive** *drive-number*
5. Server /chassis/server/storageadapter/physical-drive # **undo-prepare-for-removal**

### DETAILED STEPS

|               | Command or Action                                                                       | Purpose                                               |
|---------------|-----------------------------------------------------------------------------------------|-------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                                           | Enters chassis command mode.                          |
| <b>Step 2</b> | Server /chassis # <b>scope server</b> {1   2}                                           | Enters server command mode of server 1 or 2.          |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>                     | Enters storage adapter command mode.                  |
| <b>Step 4</b> | Server /chassis/server/storageadapter # <b>scope physical-drive</b> <i>drive-number</i> | Enters command mode for the specified physical drive. |
| <b>Step 5</b> | Server /chassis/server/storageadapter/physical-drive # <b>undo-prepare-for-removal</b>  |                                                       |

### Example

This example shows how to respin physical drive 3 after preparing the drive for removal.

```
Server# scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # undo-prepare-for-removal
Server /chassis/server/storageadapter/physical-drive #
```

# Enabling Auto Learn Cycles for the Battery Backup Unit

## Before you begin

You must log in with admin privileges to perform this task.

## SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis/server # **scope storageadapter Slot-ID**
4. Server /chassis/server/storageadapter # **scope bbu**
5. Server /chassis/server/storageadapter # **enable-auto-learn**

## DETAILED STEPS

|               | Command or Action                                                | Purpose                                      |
|---------------|------------------------------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                    | Enters chassis command mode.                 |
| <b>Step 2</b> | Server /chassis # <b>scope server {1   2}</b>                    | Enters server command mode of server 1 or 2. |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter Slot-ID</b>     | Enters storage adapter command mode.         |
| <b>Step 4</b> | Server /chassis/server/storageadapter # <b>scope bbu</b>         | Enter the battery backup unit command mode.  |
| <b>Step 5</b> | Server /chassis/server/storageadapter # <b>enable-auto-learn</b> | Enables the battery auto-learn cycles        |

## Example

This example shows how to enable the battery auto-learn cycles:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-2
Server /chassis/server/storageadapter # scope bbu
Server /chassis/server/storageadapter/bbu # enable-auto-learn
Automatic BBU learn cycles will occur without notice if enabled.
Are you sure? [y/n] --> y
enable-auto-learn initiated
Server /chassis/server/storageadapter/bbu #
```

# Disabling Auto Learn Cycles for the Battery Backup Unit

## Before you begin

You must log in with admin privileges to perform this task.

**SUMMARY STEPS**

1. Server # **scope chassis**
2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *Slot-ID*
4. Server /chassis/server/storageadapter # **scope bbu**
5. Server /chassis/server/storageadapter # **disable-auto-learn**

**DETAILED STEPS**

|               | Command or Action                                                   | Purpose                                      |
|---------------|---------------------------------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                       | Enters chassis command mode.                 |
| <b>Step 2</b> | Server /chassis # <b>scope server</b> {1   2}                       | Enters server command mode of server 1 or 2. |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i> | Enters storage adapter command mode.         |
| <b>Step 4</b> | Server /chassis/server/storageadapter # <b>scope bbu</b>            | Enter the battery backup unit command mode.  |
| <b>Step 5</b> | Server /chassis/server/storageadapter # <b>disable-auto-learn</b>   | Disables the battery auto-learn cycles       |

**Example**

This example shows how to disable the battery auto-learn cycles:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-2
Server /chassis/server/storageadapter # scope bbu
Server /chassis/server/storageadapter/bbu # disable-auto-learn
Automatic BBU learn cycles will no longer occur if disabled.
Are you sure? [y/n] --> y
disable-auto-learn initiated

Server /chassis/server/storageadapter/bbu #
```

# Starting a Learn Cycle for a Battery Backup Unit

**Before you begin**

You must be logged in as an admin to use this command.

**SUMMARY STEPS**

1. Server # **scope chassis**
2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *Slot-ID*
4. Server /chassis/server/storageadapter # **scope bbu**
5. Server /chassis/server/storageadapter # **start-learn-cycle**

## DETAILED STEPS

|        | Command or Action                                                   | Purpose                                      |
|--------|---------------------------------------------------------------------|----------------------------------------------|
| Step 1 | Server # <b>scope chassis</b>                                       | Enters chassis command mode.                 |
| Step 2 | Server /chassis # <b>scope server</b> {1   2}                       | Enters server command mode of server 1 or 2. |
| Step 3 | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i> | Enters storage adapter command mode.         |
| Step 4 | Server /chassis/server/storageadapter # <b>scope bbu</b>            | Enter the battery backup unit command mode.  |
| Step 5 | Server /chassis/server/storageadapter # <b>start-learn-cycle</b>    | Starts the learn cycle for the battery.      |

## Example

This example shows how to initiate the learn cycles for a battery:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-2
Server /chassis/server/storageadapter # scope bbu
Server /chassis/server/storageadapter/bbu # start-learn-cycle
Server /chassis/server/storageadapter/bbu #
```

## Toggling the Locator LED for a Physical Drive

### Before you begin

You must be logged in as an admin to perform this task.

## SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *Slot-ID*
4. Server /chassis/server/storageadapter # **scope physical-drive** 3
5. Server /chassis/server/storageadapter/physical-drive # **locator-led** {on | off}

## DETAILED STEPS

|        | Command or Action                                                     | Purpose                                      |
|--------|-----------------------------------------------------------------------|----------------------------------------------|
| Step 1 | Server # <b>scope chassis</b>                                         | Enters chassis command mode.                 |
| Step 2 | Server /chassis # <b>scope server</b> {1   2}                         | Enters server command mode of server 1 or 2. |
| Step 3 | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i>   | Enters storage adapter command mode.         |
| Step 4 | Server /chassis/server/storageadapter # <b>scope physical-drive</b> 3 | Enters the physical drive command mode.      |

|               | Command or Action                                                                       | Purpose                                             |
|---------------|-----------------------------------------------------------------------------------------|-----------------------------------------------------|
| <b>Step 5</b> | Server /chassis/server/storageadapter/physical-drive #<br><b>locator-led</b> {on   off} | Enables or disables the physical drive locator LED. |

### Example

This example shows how to enable the locator LED for physical drive 3:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-2
Server /chassis/server/storageadapter # scope physical-drive 3
Server /chassis/server/storageadapter/physical-drive # locator-led on
Server /chassis/server/storageadapter/physical-drive* # commit
Server /chassis/server/storageadapter/physical-drive #
```

## Clearing Controller Configuration

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *Slot-ID*
4. Server /chassis/server/storageadapter # **clear-all-config**

### DETAILED STEPS

|               | Command or Action                                                   | Purpose                                                                           |
|---------------|---------------------------------------------------------------------|-----------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                       | Enters chassis command mode.                                                      |
| <b>Step 2</b> | Server /chassis # <b>scope server</b> {1   2}                       | Enters server command mode of server 1 or 2.                                      |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter</b> <i>Slot-ID</i> | Enters storage adapter command mode.                                              |
| <b>Step 4</b> | Server /chassis/server/storageadapter # <b>clear-all-config</b>     | Enter <b>yes</b> at the confirmation prompt. Clears the controller configuration. |

### Example

The following example shows how to clear the controller configuration:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # clear-all-config
```



```

Are you sure you want to clear the controller's config and delete all VDs?
Enter 'yes' to confirm -> yes
Enter administrative password to proceed with operation\n
Password -> Password accepted. Performing requested operation.
Server /chassis/server/storageadapter #

```

## Restoring Storage Controller to Factory Defaults

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis/server # **scope storageadapter Slot-ID**
4. Server /chassis/server/storageadapter # **set-factory-defaults**

### DETAILED STEPS

|               | Command or Action                                                   | Purpose                                                                                                            |
|---------------|---------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                       | Enters chassis command mode.                                                                                       |
| <b>Step 2</b> | Server /chassis # <b>scope server {1   2}</b>                       | Enters server command mode of server 1 or 2.                                                                       |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter Slot-ID</b>        | Enters storage adapter command mode.                                                                               |
| <b>Step 4</b> | Server /chassis/server/storageadapter # <b>set-factory-defaults</b> | Enter <b>yes</b> at the confirmation prompt. Restores the controller configuration parameters to factory defaults. |

### Example

The following example shows how to restore the controller configuration parameters to factory defaults:

```

Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # set-factory-defaults
This operation will restore controller settings to factory default values. Do you want to
proceed?
Enter 'yes' to confirm -> yes
Server /chassis/server/storageadapter #

```

# Viewing Storage Controller Logs

## Before you begin

You must log in with admin privileges to perform this task.

## SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis/server # **scope storageadapter Slot-ID**
4. Server /chassis/server/storageadapter # **show log**

## DETAILED STEPS

|               | Command or Action                                            | Purpose                                      |
|---------------|--------------------------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                | Enters chassis command mode.                 |
| <b>Step 2</b> | Server /chassis # <b>scope server {1   2}</b>                | Enters server command mode of server 1 or 2. |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter Slot-ID</b> | Enters storage adapter command mode.         |
| <b>Step 4</b> | Server /chassis/server/storageadapter # <b>show log</b>      | Displays the storage controller logs.        |

## Example

This example shows how to display storage controller logs:

```
Server # scope chassis
Server /chassis # scope server 1
Server /chassis/server # scope storageadapter SLOT-3
Server /chassis/server/storageadapter # show log

Time Severity Description
---- -
Fri March 1 09:52:19 2015 Warning Predictive Failure
Fri March 1 07:50:19 2015 Info Battery charge complete
Fri March 1 07:50:19 2015 Info Battery charge started
Fri March 1 07:48:19 2015 Info Battery relearn complete
Fri March 1 07:47:19 2015 Info Battery is discharging
Fri March 1 07:45:19 2015 Info Battery relearn started

Server /chassis/server/storageadapter #
```

# Viewing Physical Drive Details

## SUMMARY STEPS

1. Server# **scope chassis**

2. Server /chassis # **scope server** {1 | 2}
3. Server /chassis/server # **scope storageadapter** *slot*
4. Server /chassis/server/storageadapter # **scope physical-drive** 2
5. Server /chassis/server/storageadapter/physical-drive # **show detail**

## DETAILED STEPS

|               | Command or Action                                                         | Purpose                                      |
|---------------|---------------------------------------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                              | Enters the chassis command mode.             |
| <b>Step 2</b> | Server /chassis # <b>scope server</b> {1   2}                             | Enters server command mode of server 1 or 2. |
| <b>Step 3</b> | Server /chassis/server # <b>scope storageadapter</b> <i>slot</i>          | Enters server storage adapter mode.          |
| <b>Step 4</b> | Server /chassis/server/storageadapter # <b>scope physical-drive</b> 2     | Enters the physical drive command mode.      |
| <b>Step 5</b> | Server /chassis/server/storageadapter/physical-drive # <b>show detail</b> | Displays the physical drive details.         |

### Example

This example shows how to view the physical drive information:

```

Server# scope chassis
Server/chassis # scope server 1
Server /chassis/server/ # scope storageadapter SBMezz1
Server /chassis/server/storageadapter # scope physical-drive 202
Server /chassis/server/storageadapter/physical-drive # show detail
Physical Drive Number 202:
 Controller: SBMezz1
 Info Valid: Yes
 Info Invalid Cause:
 Enclosure Device ID: 252
 Device ID: 8
 Drive Number: 202
 Health: Good
 Status: Online
 Boot Drive: false
 Manufacturer: ATA
 Model: INTEL SSDSC2BB480G4
 Predictive Failure Count: 0
 Drive Firmware: 0370
 Type: SSD
 Block Size: 512
 Physical Block Size: 4096
 Negotiated Link Speed: 6.0 Gb/s
 Locator LED: false
 FDE Capable: 0
 FDE Enabled: 0
 FDE Secured: 0
 FDE Locked: 0
 FDE Locked Foreign Config: 0
 Enclosure Association: Direct Attached
 Enclosure Logical ID: N/A
 Enclosure SAS Address[0]: N/A
 Enclosure SAS Address[1]: N/A
 Power Cycle Count: 106

```

```

Power On Hours: 10471
Percentage Life Left: 100
Wear Status in Days: 1825
Percentage Reserved Capacity Consumed: 0
Time of Last Refresh : 2017-03-04 13:47
Operating Temperature: 34
Media Error Count: 0
Other Error Count: 0
Interface Type: SATA
Block Count: 937703088
Raw Size: 457862 MB
Non Coerced Size: 457350 MB
Coerced Size: 456809 MB
SAS Address 0: 4433221108000000
SAS Address 1: 0x0
Power State: active
Server /chassis/server/storageadapter/physical-drive #

```

## Viewing SIOC NVMe Drive Details

You must scope to a particular CMC to view the NVMe drives in SIOC associated with that CMC.



**Note** This feature is available only on some S-Series servers.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope cmc [1 / 2]**
3. Server /chassis/CMC # **scope nvmeadapter** *adapter name*
4. Server /chassis/CMC/nvmeadapter # **show nvme-physical-drive detail**

### DETAILED STEPS

|               | Command or Action                                                        | Purpose                                        |
|---------------|--------------------------------------------------------------------------|------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                            | Enters the chassis command mode.               |
| <b>Step 2</b> | Server /chassis # <b>scope cmc [1 / 2]</b>                               | Enters the CMC command mode.                   |
| <b>Step 3</b> | Server /chassis/CMC # <b>scope nvmeadapter</b> <i>adapter name</i>       | Enters the NVMe adapter command mode.          |
| <b>Step 4</b> | Server /chassis/CMC/nvmeadapter # <b>show nvme-physical-drive detail</b> | Displays the SIOC NVMe physical drive details. |

### Example

This example shows how to view SIOC NVMe drive details:

```

Server # scope chassis
Server /chassis # scope cmc
Server /chassis/cmc # show detail

```

```
Firmware Image Information:
 ID: 1
 Name: CMC1
 SIOC PID: UCS-S3260-PCISIOC
 Serial Number: FCH21277K8T
 Update Stage: ERROR
 Update Progress: OS_ERROR
 Current FW Version: 4.0(0.166)
 FW Image 1 Version: 0.0(4.r17601)
 FW Image 1 State: BACKUP INACTIVATED
 FW Image 2 Version: 4.0(0.166)
 FW Image 2 State: RUNNING ACTIVATED
 Reset Reason: ac-cycle
 Secure Boot: ENABLED
Server /chassis # scope cmc 1
Server /chassis/cmc # scope nvmeadapter NVMe-direct-U.2-drives
Server /chassis/cmc/nvmeadapter # show nvme-physical-drive detail
Physical Drive Number SIOCNVMe1:
 Product Name: Cisco 2.5 inch 1TB Intel P4501 NVMe Med. Perf. Value Endurance
 Manufacturer: Intel
 Serial Number: PHLF7303008G1P0KGN
 Temperature: 39 degrees C
 % Drive Life Used: 1
 Performance Level: 100
 LED Fault status: Healthy
 Drive Status: Optimal
 % Power on Hours: 8
 Firmware Version: QDV1CP03
 PCI Slot: SIOCNVMe1
 Managed Id: 1
 Controller Type: NVME-SFF
 Controller Temperature: 39
 Throttle State: 0
 Throttle Start Temperature: 70
 Shutdown Temperature: 80
Physical Drive Number SIOCNVMe2:
 Product Name: Cisco 2.5 inch 500GB Intel P4501 NVMe Med. Perf. Value Endurance
 Manufacturer: Intel
 Serial Number: PHLF73440068500JGN
 Temperature: 39 degrees C
 % Drive Life Used: 1
 Performance Level: 100
 LED Fault status: Healthy
 Drive Status: Optimal
 % Power on Hours: 7
 Firmware Version: QDV1CP03
 PCI Slot: SIOCNVMe2
 Managed Id: 2
 Controller Type: NVME-SFF
 Controller Temperature: 39
 Throttle State: 0
 Throttle Start Temperature: 70
 Shutdown Temperature: 80
Server /chassis/cmc/nvmeadapter #
```





## CHAPTER 12

# Configuring Communication Services

This chapter includes the following sections:

- [Enabling or Disabling TLS v1.2, on page 259](#)
- [Enabling TLS Static Key Cipher, on page 261](#)
- [Configuring HTTP, on page 262](#)
- [Configuring SSH, on page 264](#)
- [Configuring XML API, on page 265](#)
- [Enabling Redfish, on page 266](#)
- [Configuring IPMI, on page 266](#)
- [Configuring SNMP, on page 270](#)
- [Configuring a Server to Send Email Alerts Using SMTP, on page 275](#)

## Enabling or Disabling TLS v1.2

Beginning with release 4.2(2a), Cisco IMC supports disabling TLS v1.2 and also customize the cipher values for both v1.2 and v1.3.

### Before you begin

If CC (Common Criteria) under **Security Configuration** is enabled, you cannot disable TLS v1.2. Ensure that CC is disabled before you disable TLS v1.2.

Enabling or disabling TLS v1.2, restarts vKVM, Webserver, XML API, and Redfish API sessions.

### SUMMARY STEPS

1. Server# **scope cimc**
2. Server# **scope tls-config**
3. Server/tls-config # **set tlv2Enabled** *yes/no*
4. Server/tls-config\* # **Commit**
5. Server/tls-config # **set tlv2CipherMode** *Custom/High/Low/Medium*
6. (Optional) Server/tls-config # **set tlv2CipherMode Custom** *Cipher\_Value*
7. Server/tls-config\* # **Commit**

## DETAILED STEPS

|               | Command or Action                                                             | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|---------------|-------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope cimc</b>                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Step 2</b> | Server# <b>scope tls-config</b>                                               | Enters the TLS configuration mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Step 3</b> | Server/tls-config # <b>set tlsv2Enabled yes/no</b>                            | Enter <b>y</b> to confirm.<br>Enables or Disables TLS v1.2.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Step 4</b> | Server/tls-config* # <b>Commit</b>                                            | Saves the changes.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Step 5</b> | Server/tls-config # <b>set tlsv2CipherMode Custom/High/Low/Medium</b>         | Selecting <b>High</b> , <b>Low</b> , or <b>Medium</b> automatically provides preset cipher values.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Step 6</b> | (Optional) Server/tls-config # <b>set tlsv2CipherMode Custom Cipher_Value</b> | Enter a valid cipher value for <b>Custom</b> cipher mode.<br><br><b>Note</b> Refer <a href="https://www.openssl.org/docs/man1.0.2/man1/ciphers.html">https://www.openssl.org/docs/man1.0.2/man1/ciphers.html</a> for OpenSSL equivalent cipher name for a specific cipher to be provided in custom cipher.<br><br>If the cipher value entered is invalid or unsupported, then while saving the configuration, Cisco IMC automatically changes the <b>TLS v1.2 Cipher Mode</b> value to <b>High</b> and saves the configuration. You may see the following status:<br><br>TLS v1.2 Custom Cipher Status: Error: Configuring an invalid or unsupported TLS v1.2 Cipher List-'Cipher_Name'. Setting TLS v1.2 Cipher Mode to High. |
| <b>Step 7</b> | Server/tls-config* # <b>Commit</b>                                            | Saves the changes.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |

**Example**

Following example shows how to enable TLS v1.2 and set cipher mode to high:

```
Server# scope cimc
Server /cimc # scope tls-config
Server /cimc/tls-config # set tlsv2Enabled yes
Server /cimc/tls-config* # commit
Server /cimc/tls-config # set tlsv2CipherMode high
Server /cimc/tls-config* # commit
```

Following example shows how to enable TLS v1.2 and set cipher mode to custom:

```
server# scope cimc
server /cimc # scope tls-config
server /cimc/tls-config # set tlsv2CipherMode Custom
server /cimc/tls-config *# set tlsv2CipherList ECDHE-RSA-AES256-GCM-SHA384
server /cimc/tls-config *# commit
```



# Enabling TLS Static Key Cipher

Perform this procedure to enable TLS static key cipher for Cisco UCS servers. TLS static key cipher is disabled by default.



**Note** You can enable this feature only through Cisco IMC CLI interface.

Static key cipher option is not applicable when **TLS v1.2 Cipher Mode** is set to **High** or **Custom**.

Static key cipher, if enabled, switches to NA automatically when **TLS v1.2 Cipher Mode** changes from **Medium/Low** to **High/Custom**.

## SUMMARY STEPS

1. Server# **scope cimc**
2. Server /chassis # **scope tls-config**
3. Server /chassis/tls-config # **show detail**
4. Server /chassis/tls-config # **set static-cipher-enabled yes**
5. Server /chassis/tls-config # **commit**
6. Type **y** and press **Enter**.

## DETAILED STEPS

|               | Command or Action                                                 | Purpose                                                                                                                                                                                     |
|---------------|-------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope cimc</b>                                         | Enters the Cisco IMC command mode.                                                                                                                                                          |
| <b>Step 2</b> | Server /chassis # <b>scope tls-config</b>                         | Enters the TLS configuration mode.                                                                                                                                                          |
| <b>Step 3</b> | Server /chassis/tls-config # <b>show detail</b>                   | Displays the <b>TLS Static Cipher Enabled</b> status:<br>TLS Configuration : TLS Static Cipher Enabled: no                                                                                  |
| <b>Step 4</b> | Server /chassis/tls-config # <b>set static-cipher-enabled yes</b> | Enables TLS cipher.                                                                                                                                                                         |
| <b>Step 5</b> | Server /chassis/tls-config # <b>commit</b>                        | Following warning is displayed.<br>Warning: This will enable static ciphers in TLS. KVM, Webserver, XMLAPI and Redfish sessions will be disconnected. Do you wish to continue? [[Y]es/[N]o] |
| <b>Step 6</b> | Type <b>y</b> and press <b>Enter</b> .                            | Commits the transaction to the system configuration.                                                                                                                                        |

### Example

This example shows how to enable TLS static key cipher:

```

Server# scope cimc
Server /cimc # scope tls-config
Server /cimc/tls-config # show detail
TLS Configuration :
 TLS Static Cipher Enabled: no
Server /cimc/tls-config #
Server /cimc/tls-config # set static-cipher-enabled yes
Server /cimc/tls-config *# commit
Warning: This will enable static ciphers in TLS.
 KVM, Webserver, XMLAPI and Redfish sessions will be disconnected.
Do you wish to continue? [[Y]es/[N]o] y
Server /cimc/tls-config # show detail
TLS Configuration :
 TLS Static Cipher Enabled: yes

```

## Configuring HTTP

Beginning with release 4.1(2b), Cisco IMC supports separate HTTPS and HTTP communication services. You can disable only HTTP services using this functionality.

This functionality is supported only on the following servers:

- Cisco UCS C220 M5
- Cisco UCS C240 M5
- Cisco UCS C480 M5
- Cisco UCS C480 ML M5
- Cisco UCS C240 SD M5
- Cisco UCS C125 M5
- Cisco UCS S3260 M4/M5




---

**Note** If **Redirect HTTP to HTTPS Enabled** was disabled in any release earlier than 4.1(2b), then after upgrading to release 4.1(2b) or later, **HTTP Enabled** value is set to **Disabled** by the system.

---

### Before you begin

You must log in as a user with admin privileges to configure HTTP.

### SUMMARY STEPS

1. Server# **scope http**
2. Server /http # **set https-enabled** {yes | no}
3. Server /http # **set http-enabled** {yes | no}
4. Server /http # **set http-port** *number*
5. Server /http # **set https-port** *number*
6. Server /http # **set http-redirect** {yes | no}
7. Server /http # **set timeout** *seconds*

8. Server /http # commit

DETAILED STEPS

|        | Command or Action                                  | Purpose                                                                                                                                                                                |
|--------|----------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | Server# <b>scope http</b>                          | Enters the HTTP command mode.                                                                                                                                                          |
| Step 2 | Server /http # <b>set https-enabled {yes   no}</b> | Enables the HTTPS services or disables both HTTPS and HTTP services on Cisco IMC.                                                                                                      |
| Step 3 | Server /http # <b>set http-enabled {yes   no}</b>  | Enables or disables HTTP services on the Cisco IMC.                                                                                                                                    |
| Step 4 | Server /http # <b>set http-port number</b>         | Sets the port to use for HTTP communication. The default is 80.                                                                                                                        |
| Step 5 | Server /http # <b>set https-port number</b>        | Sets the port to use for HTTPS communication. The default is 443.                                                                                                                      |
| Step 6 | Server /http # <b>set http-redirect {yes   no}</b> | <b>Note</b> This option is applicable only when HTTP is enabled.<br><br>Enables or disables the redirection of an HTTP request to HTTPS.                                               |
| Step 7 | Server /http # <b>set timeout seconds</b>          | Sets the number of seconds to wait between HTTP requests before the times out and terminates the session.<br><br>Enter an integer between 60 and 10,800. The default is 1,800 seconds. |
| Step 8 | Server /http # <b>commit</b>                       | Commits the transaction to the system configuration.                                                                                                                                   |

Example

This example configures HTTP for the Cisco IMC:

```

Server# scope http
Server /http # set https-enabled yes
Server /http # set http-enabled yes
Server /http *# set http-port 80
Server /http *# set https-port 443
Server /http *# set http-redirect yes
Server /http *# set timeout 1800
Server /http *# commit
Server /http # show
HTTP Port HTTPS Port Timeout Active Sessions HTTPS Enabled HTTP Redirected HT
TP Enabled

80 443 1800 0 yes yes yes
Server /http #

```

# Configuring SSH

## Before you begin

You must log in as a user with admin privileges to configure SSH.

## SUMMARY STEPS

1. Server# **scope ssh**
2. Server /ssh # **set enabled {yes | no}**
3. Server /ssh # **set ssh-port number**
4. Server /ssh # **set timeout seconds**
5. Server /ssh # **commit**
6. Server /ssh # **show [detail]**

## DETAILED STEPS

|               | Command or Action                           | Purpose                                                                                                                                                                     |
|---------------|---------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope ssh</b>                    | Enters the SSH command mode.                                                                                                                                                |
| <b>Step 2</b> | Server /ssh # <b>set enabled {yes   no}</b> | Enables or disables SSH on the .                                                                                                                                            |
| <b>Step 3</b> | Server /ssh # <b>set ssh-port number</b>    | Sets the port to use for secure shell access. The default is 22.                                                                                                            |
| <b>Step 4</b> | Server /ssh # <b>set timeout seconds</b>    | Sets the number of seconds to wait before the system considers an SSH request to have timed out.<br><br>Enter an integer between 60 and 10,800. The default is 300 seconds. |
| <b>Step 5</b> | Server /ssh # <b>commit</b>                 | Commits the transaction to the system configuration.                                                                                                                        |
| <b>Step 6</b> | Server /ssh # <b>show [detail]</b>          | (Optional) Displays the SSH configuration.                                                                                                                                  |

## Example

This example configures SSH for the :

```

Server# scope ssh
Server /ssh # set enabled yes
Server /ssh *# set ssh-port 22
Server /ssh *# set timeout 600
Server /ssh *# commit
Server /ssh # show
SSH Port Timeout Active Sessions Enabled

22 600 1 yes

Server /ssh #

```

# Configuring XML API

## XML API for

The Cisco XML application programming interface (API) is a programmatic interface to for a C-Series Rack-Mount Server. The API accepts XML documents through HTTP or HTTPS.

For detailed information about the XML API, see *Cisco UCS Rack-Mount Servers XML API Programmer's Guide*.

## Enabling XML API

### Before you begin

You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. Server# **scope xmlapi**
2. Server /xmlapi # **set enabled {yes | no}**
3. Server /xmlapi # **commit**

### DETAILED STEPS

|               | Command or Action                              | Purpose                                              |
|---------------|------------------------------------------------|------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope xmlapi</b>                    | Enters XML API command mode.                         |
| <b>Step 2</b> | Server /xmlapi # <b>set enabled {yes   no}</b> | Enables or disables XML API control of .             |
| <b>Step 3</b> | Server /xmlapi # <b>commit</b>                 | Commits the transaction to the system configuration. |

### Example

This example enables XML API control of and commits the transaction:

```
Server# scope xmlapi
Server /xmlapi # set enabled yes
Server /xmlapi *# commit
Server /xmlapi # show detail
XMLAPI Settings:
 Enabled: yes
 Active Sessions: 0
 Max Sessions: 4

Server /xmlapi #
```

# Enabling Redfish

## Before you begin

You must log in as a user with admin privileges to perform this task.

## SUMMARY STEPS

1. Server# **scope redfish**
2. Server /redfish # **set enabled {yes | no}**
3. Server /redfish\* # **commit**

## DETAILED STEPS

|               | Command or Action                               | Purpose                                              |
|---------------|-------------------------------------------------|------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope redfish</b>                    | Enters redfish command mode.                         |
| <b>Step 2</b> | Server /redfish # <b>set enabled {yes   no}</b> | Enables or disables redfish control of .             |
| <b>Step 3</b> | Server /redfish* # <b>commit</b>                | Commits the transaction to the system configuration. |

## Example

This example enables redfish control of and commits the transaction:

```
Server# scope redfish
Server /redfish # set enabled yes
Server /redfish *# commit
Server /redfish # show detail
REDFISH Settings:
 Enabled: yes
 Active Sessions: 0
 Max Sessions: 4

Server /redfish #
```

# Configuring IPMI

## IPMI Over LAN

Intelligent Platform Management Interface (IPMI) defines the protocols for interfacing with a service processor embedded in a server platform. This service processor is called a Baseboard Management Controller (BMC) and resides on the server motherboard. The BMC links to a main processor and other on-board elements using a simple serial bus.

During normal operations, IPMI lets a server operating system obtain information about system health and control system hardware. For example, IPMI enables the monitoring of sensors, such as temperature, fan speeds and voltages, for proactive problem detection. If server temperature rises above specified levels, the

server operating system can direct the BMC to increase fan speed or reduce processor speed to address the problem.

## Configuring IPMI over LAN for Cisco IMC

Configure IPMI over LAN when you want to manage the with IPMI messages.

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server # **scope ipmi**
3. Server /server/ipmi # **set enabled** {yes | no}
4. Server /server/ipmi # **set privilege-level** {readonly | user | admin}
5. Server /server/ipmi # **set encryption-key** *key*
6. Server /server/ipmi # **commit**
7. Server /server/ipmi # **randomise-key**
8. At the prompt, enter **y** to randomize the encryption key.

### DETAILED STEPS

|               | Command or Action                                                          | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------|----------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}                                       | Enters server command mode of server 1 or 2.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Step 2</b> | Server /server # <b>scope ipmi</b>                                         | Enters the IPMI command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Step 3</b> | Server /server/ipmi # <b>set enabled</b> {yes   no}                        | Enables or disables IPMI access on this server.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Step 4</b> | Server /server/ipmi # <b>set privilege-level</b> {readonly   user   admin} | Specifies the highest privilege level that can be assigned to an IPMI session on this server. This can be: <ul style="list-style-type: none"> <li>• <b>readonly</b> — IPMI users can view information but cannot make any changes. If you select this option, IPMI users with the "Administrator", "Operator", or "User" user roles can only create read-only IPMI sessions, regardless of their other IPMI privileges.</li> <li>• <b>user</b> — IPMI users can perform some functions but cannot perform administrative tasks. If you select this option, IPMI users with the "Administrator" or "Operator" user role can create user and read-only sessions on this server.</li> <li>• <b>admin</b> — IPMI users can perform all available actions. If you select this option, IPMI users with the "Administrator" user role can create admin, user, and read-only sessions on this server.</li> </ul> |

|               | Command or Action                                              | Purpose                                                                                                                        |
|---------------|----------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 5</b> | Server /server/ipmi # <b>set encryption-key</b> <i>key</i>     | Sets the IPMI encryption key to use for IPMI communications. The key value must be 40 hexadecimal numbers.                     |
| <b>Step 6</b> | Server /server/ipmi # <b>commit</b>                            | Commits the transaction to the system configuration.                                                                           |
| <b>Step 7</b> | Server /server/ipmi # <b>randomise-key</b>                     | Sets the IPMI encryption key to a random value.<br><br><b>Note</b> You can perform the Step 6 action instead of Steps 4 and 5. |
| <b>Step 8</b> | At the prompt, enter <b>y</b> to randomize the encryption key. | Sets the IPMI encryption key to a random value.                                                                                |

### Example

This example configures IPMI over LAN for the :

```

Server # scope server 1
Server /server # scope ipmi
Server /server/ipmi # set enabled yes
Server /server/ipmi *# set privilege-level admin
Server /server/ipmi *# set encryption-key abcdef01234567890abcdef01234567890abcdef
Server /server/ipmi *# commit
Server /server/ipmi *# show
Enabled Encryption Key Privilege Level Limit

yes ABCDEF01234567890ABCDEF01234567890ABCDEF admin

Server /server/ipmi # randomise-key
This operation will change the IPMI Encryption Key to a random value
Continue?[y|N]y
Setting IPMI Encryption Key to a random value...

Server /server/ipmi # show
Enabled Encryption Key Privilege Level Limit

yes abcdef01234567890abcdef01234567890abcdef admin

Server /server/ipmi #

```

## Configuring IPMI over LAN for CMCs

Configure IPMI over LAN when you want to manage the CMC with IPMI messages.

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope cmc** {1 | 2}
3. Server /server # **scope ipmi**



4. Server /chassis/cmc/ipmi # **set enabled** {yes | no}
5. Server /chassis/cmc/ipmi # **set privilege-level** {readonly | user | admin}
6. Server /chassis/cmc/ipmi # **set encryption-key** *key*
7. Server /chassis/cmc/ipmi # **commit**
8. Server /chassis/cmc/ipmi # **randomise-key**
9. At the prompt, enter **y** to randomize the encryption key.

## DETAILED STEPS

|               | Command or Action                                                               | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------|---------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                                   | Enters server command mode of server 1 or 2.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Step 2</b> | Server /chassis # <b>scope cmc</b> {1   2}                                      | Enters CMC command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Step 3</b> | Server /server # <b>scope ipmi</b>                                              | Enters the IPMI command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Step 4</b> | Server /chassis/cmc/ipmi # <b>set enabled</b> {yes   no}                        | Enables or disables IPMI access on this server.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Step 5</b> | Server /chassis/cmc/ipmi # <b>set privilege-level</b> {readonly   user   admin} | Specifies the highest privilege level that can be assigned to an IPMI session on this server. This can be: <ul style="list-style-type: none"> <li>• <b>readonly</b> — IPMI users can view information but cannot make any changes. If you select this option, IPMI users with the "Administrator", "Operator", or "User" user roles can only create read-only IPMI sessions, regardless of their other IPMI privileges.</li> <li>• <b>user</b> — IPMI users can perform some functions but cannot perform administrative tasks. If you select this option, IPMI users with the "Administrator" or "Operator" user role can create user and read-only sessions on this server.</li> <li>• <b>admin</b> — IPMI users can perform all available actions. If you select this option, IPMI users with the "Administrator" user role can create admin, user, and read-only sessions on this server.</li> </ul> |
| <b>Step 6</b> | Server /chassis/cmc/ipmi # <b>set encryption-key</b> <i>key</i>                 | Sets the IPMI encryption key to use for IPMI communications. The key value must be 40 hexadecimal numbers.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Step 7</b> | Server /chassis/cmc/ipmi # <b>commit</b>                                        | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Step 8</b> | Server /chassis/cmc/ipmi # <b>randomise-key</b>                                 | Sets the IPMI encryption key to a random value.<br><br><b>Note</b> You can perform the Step 6 action instead of Steps 4 and 5.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Step 9</b> | At the prompt, enter <b>y</b> to randomize the encryption key.                  | Sets the IPMI encryption key to a random value.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

**Example**

This example configures IPMI over LAN for the CMC 1:

```
Server # scope chassis
Server # scope cmc 1
Server /chassis # scope ipmi
Server /chassis/cmc/ipmi # set enabled yes
Server /chassis/cmc/ipmi *# set privilege-level admin
Server /chassis/cmc/ipmi *# set encryption-key abcdef01234567890abcdef01234567890abcdef
Server /chassis/cmcipmi *# commit
Server /chassis/cmc/ipmi *# show
Enabled Encryption Key Privilege Level Limit

yes ABCDEF01234567890ABCDEF01234567890ABCDEF admin

Server /chassis/cmc/ipmi # randomise-key
This operation will change the IPMI Encryption Key to a random value
Continue?[y|N]y
Setting IPMI Encryption Key to a random value...

Server /chassis/cmc/ipmi # show
Enabled Encryption Key Privilege Level Limit

yes abcdef01234567890abcdef01234567890abcdef admin

Server /chassis/cmc/ipmi #
```

# Configuring SNMP

## SNMP

The Cisco UCS C-Series Rack-Mount Servers support the Simple Network Management Protocol (SNMP) for viewing server configuration and status and for sending fault and alert information by SNMP traps. For information on Management Information Base (MIB) files supported by Cisco IMC, see the *MIB Quick Reference for Cisco UCS* at this URL: [http://www.cisco.com/c/en/us/td/docs/unified\\_computing/ucs/sw/mib/b-series/b\\_UCS\\_MIBRef.html](http://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/sw/mib/b-series/b_UCS_MIBRef.html).

Beginning with release 4.1(3b), Cisco IMC introduces enhanced authentication protocol for SNMP v3 version. SNMP v3 users cannot be added with **DES** security protocol.

Cisco IMC GUI displays a warning when you select an existing v3 version with unsupported security level, authentication type, or privacy type. You may select and modify the user details.

## Configuring SNMP Properties

This procedure is applicable for Cisco UCS C-Series M6 and earlier servers. To configure SNMP user for Cisco UCS C-Series M7 and later servers, see [Configuring Local Users for Cisco UCS C-Series M7 and Later Servers](#), on page 115.

**Before you begin**

You must log in as a user with admin privileges to perform this task.

### Procedure

|                | Command or Action                                        | Purpose                                                                                                                                                                                                                                                                            |
|----------------|----------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b>  | Server# <b>scope snmp</b>                                | Enters SNMP command mode.                                                                                                                                                                                                                                                          |
| <b>Step 2</b>  | Server /snmp # <b>set enabled {yes   no}</b>             | Enables or disables SNMP.<br><br><b>Note</b> SNMP must be enabled and saved before additional SNMP configuration commands are accepted.                                                                                                                                            |
| <b>Step 3</b>  | Server /snmp # <b>commit</b>                             | Commits the transaction to the system configuration.                                                                                                                                                                                                                               |
| <b>Step 4</b>  | Server /snmp # <b>set enable-serial-num {yes   no}</b>   | Prefixes the traps with the serial number of the server.                                                                                                                                                                                                                           |
| <b>Step 5</b>  | Server /snmp # <b>set community-str</b> <i>community</i> | Specifies the default SNMP v1 or v2c community name that includes on any trap messages it sends to the SNMP host. The name can be up to 18 characters.                                                                                                                             |
| <b>Step 6</b>  | Server /snmp # <b>set community-access</b>               | This can be one of the following : Disabled, Limited, or Full.                                                                                                                                                                                                                     |
| <b>Step 7</b>  | Server /snmp # <b>set trap-community-str</b>             | Specifies the SNMP community group to which trap information should be sent. The name can be up to 18 characters                                                                                                                                                                   |
| <b>Step 8</b>  | Server /snmp # <b>set sys-contact</b> <i>contact</i>     | Specifies the system contact person responsible for the SNMP implementation. The contact information can be up to 254 characters, such as an email address or a name and telephone number. To enter a value that contains spaces, you must enclose the entry with quotation marks. |
| <b>Step 9</b>  | Server /snmp # <b>set sys-location</b> <i>location</i>   | Specifies the location of the host on which the SNMP agent (server) runs. The location information can be up to 254 characters. To enter a value that contains spaces, you must enclose the entry with quotation marks.                                                            |
| <b>Step 10</b> | Server /snmp # <b>commit</b>                             | Commits the transaction to the system configuration.                                                                                                                                                                                                                               |

### Example

This example configures the SNMP properties and commits the transaction:

### What to do next

Configure SNMP trap settings as described in [Configuring SNMP Trap Settings, on page 272](#).

## Configuring SNMP Trap Settings

### Before you begin

- You must log in with admin privileges to perform this task.
- SNMP must be enabled and saved before trap settings can be configured.

### Procedure

|               | Command or Action                                                | Purpose                                                                                                                                                                                                     |
|---------------|------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope snmp</b>                                        | Enters the SNMP command mode.                                                                                                                                                                               |
| <b>Step 2</b> | Server /snmp # <b>scope trap-destinations number</b>             | Enters the SNMP trap destination command mode for the specified destination. Four SNMP trap destinations are available. The destination <i>number</i> is an integer between 1 and 15.                       |
| <b>Step 3</b> | Server /snmp/trap-destinations # <b>set enabled {yes   no}</b>   | Enables or disables the SNMP trap destination.                                                                                                                                                              |
| <b>Step 4</b> | Server /snmp/trap-destinations # <b>set version {   2   3}</b>   | Specify the desired SNMP version of the trap message.<br><br><b>Note</b> SNMPv3 traps will be delivered only to locations where the SNMPv3 user and key values are configured correctly.                    |
| <b>Step 5</b> | Server /snmp/trap-destinations # <b>set type {trap   inform}</b> | Specifies whether SNMP notification messages are sent as simple traps or as inform requests requiring acknowledgment by the receiver.<br><br><b>Note</b> The inform option can be chosen only for V2 users. |
| <b>Step 6</b> | Server /snmp/trap-destinations # <b>set user user</b>            | <b>Note</b> While Configuring SNMP v3 version, you cannot use SNMP users with Encryption Method set as <b>DES</b> .                                                                                         |
| <b>Step 7</b> | Server /snmp/trap-destination # <b>commit</b>                    | Commits the transaction to the system configuration.                                                                                                                                                        |

### Example

This example configures general SNMP trap settings and trap destination number 1 and commits the transaction:

```
Server# scope snmp
Server /snmp # Scope trap-destinations 1
Server /snmp/trap-destination *# set enabled yes
Server /snmp/trap-destination *# set version 2
Server /snmp/trap-destination *# set type inform
Server /snmp/trap-destination *# set user user1
```

```

Server /snmp/trap-destination *# commit
Server /snmp/trap-destination # show detail
Trap Destination 1:
 Enabled: yes
 SNMP version: 2
 Trap type: inform
 SNMP user: user1

Delete Trap: no
Server /snmp/trap-destination #

```

## Sending a Test SNMP Trap Message

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

|               | Command or Action                    | Purpose                                                                                                                                                                       |
|---------------|--------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope snmp</b>            | Enters the SNMP command mode.                                                                                                                                                 |
| <b>Step 2</b> | Server /snmp # <b>send-test-trap</b> | Sends an SNMP test trap to the configured SNMP trap destination that are enabled.<br><br><b>Note</b> The trap must be configured and enabled in order to send a test message. |

### Example

This example sends a test message to all the enabled SNMP trap destinations:

```

Server# scope snmp
Server /snmp # send-test-trap
SNMP Test Trap sent to the destination.
Server /snmp #

```

## Configuring SNMPv3 Users

### Before you begin

- You must log in as a user with admin privileges to perform this task.
- SNMP must be enabled and saved before these configuration commands are accepted.

### SUMMARY STEPS

1. Server# **scope snmp**
2. Server /snmp # **scope v3users number**

3. Server /snmp/v3users # **set v3add** {yes | no}
4. Server /snmp/v3users # **set v3security-name** *security-name*
5. Server /snmp/v3users # **set v3security-level** {noauthnopriv | authnopriv | authpriv}
6. Server /snmp/v3users # **set v3proto** {MD5 | SHA}
7. Server /snmp/v3users # **set v3auth-key** *auth-key*
8. Server /snmp/v3users # **set v3priv-proto** {DES | AES}
9. Server /snmp/v3users # **set v3priv-auth-key** *priv-auth-key*
10. Server /snmp/v3users # **commit**

## DETAILED STEPS

|               | Command or Action                                                                         | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------|-------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope snmp</b>                                                                 | Enters the SNMP command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Step 2</b> | Server /snmp # <b>scope v3users</b> <i>number</i>                                         | Enters the SNMPv3 users command mode for the specified user number.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Step 3</b> | Server /snmp/v3users # <b>set v3add</b> {yes   no}                                        | <p>Adds or deletes an SNMPv3 user. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>yes</b>—This user is enabled as an SNMPv3 user and is allowed to access the SNMP OID tree.</li> </ul> <p><b>Note</b> The security name and security level must also be configured at this time or the user addition will fail.</p> <ul style="list-style-type: none"> <li>• <b>no</b>—This user configuration is deleted.</li> </ul>                                                                                                                                                                                                                                                |
| <b>Step 4</b> | Server /snmp/v3users # <b>set v3security-name</b> <i>security-name</i>                    | Enter an SNMP username for this user.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Step 5</b> | Server /snmp/v3users # <b>set v3security-level</b> {noauthnopriv   authnopriv   authpriv} | <p>Select a security level for this user. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>noauthnopriv</b>—The user does not require an authorization or privacy password.</li> <li>• <b>authnopriv</b>—The user requires an authorization password but not a privacy password. If you select this option, you must configure an authentication key.</li> <li>• <b>authpriv</b>—The user requires both an authorization password and a privacy password. If you select this option, you must configure an authentication key and a private encryption key.</li> </ul> <p><b>Note</b> For a v3 version, only authnopriv and authpriv security levels are available.</p> |
| <b>Step 6</b> | Server /snmp/v3users # <b>set v3proto</b> {MD5   SHA}                                     | <p><b>Note</b> For a v3 version, only SHA authentication methods are available.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |

|                | Command or Action                                                      | Purpose                                                                                                         |
|----------------|------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|
|                |                                                                        | Select an authentication protocol for this user.                                                                |
| <b>Step 7</b>  | Server /snmp/v3users # <b>set v3auth-key</b> <i>auth-key</i>           | Enter an authorization password for this user.                                                                  |
| <b>Step 8</b>  | Server /snmp/v3users # <b>set v3priv-proto</b> {DES   AES}             | <b>Note</b> For a v3 version, only AES option is available.<br><br>Select an encryption protocol for this user. |
| <b>Step 9</b>  | Server /snmp/v3users # <b>set v3priv-auth-key</b> <i>priv-auth-key</i> | Enter a private encryption key (privacy password) for this user.                                                |
| <b>Step 10</b> | Server /snmp/v3users # <b>commit</b>                                   | Commits the transaction to the system configuration.                                                            |

### Example

This example configures SNMPv3 user number 2 and commits the transaction:

```

Server# scope snmp
Server /snmp # scope v3users 2
Server /snmp/v3users # set v3add yes
Server /snmp/v3users *# set v3security-name ucsSNMPV3user
Server /snmp/v3users *# set v3security-level authpriv
Server /snmp/v3users *# set v3proto SHA
Server /snmp/v3users *# set v3auth-key
Please enter v3auth-key:ex4mplek3y
Please confirm v3auth-key:ex4mplek3y
Server /snmp/v3users *# set v3priv-proto AES
Server /snmp/v3users *# set v3priv-auth-key
Please enter v3priv-auth-key:!1@2#3$4%5^6&7*8
Please confirm v3priv-auth-key:!1@2#3$4%5^6&7*8
Server /snmp/v3users *# commit
Settings are being applied ... allow a few minutes for the process to complete
Server /snmp/v3users # show detail
User 2:
 Add User: yes
 Security Name: ucsSNMPV3user
 Security Level: authpriv
 Auth Type: SHA
 Auth Key: *****
 Encryption: AES
 Private Key: *****

Server /snmp/v3users #

```

## Configuring a Server to Send Email Alerts Using SMTP

The Cisco IMC supports email-based notification of server faults to recipients without relying on the SNMP. The system uses the Simple Mail Transfer Protocol (SMTP) to send server faults as email alerts to the configured SMTP server.

A maximum of four recipients is supported.

# Configuring SMTP Servers for Receiving E-Mail Alerts

## Before you begin

You must log in as a user with admin privileges to perform this task.

## SUMMARY STEPS

1. Server# **scope smtp**
2. Server /smtp # **set enabled {yes | no}**
3. Server /smtp \* # **set server-addr IP\_Address**
4. Server /smtp \* # **set port port\_number**
5. Server /smtp # **set-mail-addr email\_address recipient\_minimum\_severity informational | warning | minor | major | critical**
6. Server /smtp \* # **commit**
7. Server /smtp # **send-test-mail recipient1**

## DETAILED STEPS

|               | Command or Action                                                                                                               | Purpose                                                                        |
|---------------|---------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope smtp</b>                                                                                                       | Enters the SMTP command mode.                                                  |
| <b>Step 2</b> | Server /smtp # <b>set enabled {yes   no}</b>                                                                                    | Enables or disables the SMTP feature.                                          |
| <b>Step 3</b> | Server /smtp * # <b>set server-addr IP_Address</b>                                                                              | Assigns the SMTP server IP address.                                            |
| <b>Step 4</b> | Server /smtp * # <b>set port port_number</b>                                                                                    | Sets the port number for the SMTP server.                                      |
| <b>Step 5</b> | Server /smtp # <b>set-mail-addr email_address recipient_minimum_severity informational   warning   minor   major   critical</b> | Sets recipient email address with minimum severity level.                      |
| <b>Step 6</b> | Server /smtp * # <b>commit</b>                                                                                                  | Commits the transaction to the system configuration.                           |
| <b>Step 7</b> | Server /smtp # <b>send-test-mail recipient1</b>                                                                                 | Sends a test mail alert to the email address assigned to the chosen recipient. |

## Example

This example shows how to configure SMTP for receiving mail alerts:

```

Server # scope smtp
Server /smtp # set enabled yes
Server /smtp * # set server-addr 10.10.10.10
Server /smtp * # set port 25
Server /smtp * # set-mail-addr recipient4 user@cisco.com critical
This operation will add the recipient4
Continue?[y|N]y
Server /smtp * #
Server /smtp * # commit
Server /smtp #

```





# CHAPTER 13

## Managing Certificates and Server Security

---

This chapter includes the following sections:

- [Managing the Server Certificate, on page 277](#)
- [Managing the External Certificate, on page 283](#)
- [Key Management Interoperability Protocol, on page 287](#)
- [KMIP, on page 305](#)
- [FIPS 140-2 Compliance in Cisco IMC, on page 324](#)

## Managing the Server Certificate

### Managing the Server Certificate

You can generate a certificate signing request (CSR) to obtain a new certificate, and you can upload the new certificate to Cisco IMC to replace the current server certificate. The server certificate may be signed either by a public Certificate Authority (CA), such as Verisign, or by your own certificate authority. The generated certificate key length is 2048 bits.



---

**Note** Before performing any of the following tasks in this chapter, ensure that the Cisco IMC time is set to the current time.

---

#### SUMMARY STEPS

1. Generate the CSR from Cisco IMC.
2. Submit the CSR file to a certificate authority that will issue and sign your certificate. If your organization generates its own self-signed certificates, you can use the CSR file to generate a self-signed certificate.
3. Upload the new certificate to Cisco IMC.

#### DETAILED STEPS

---

**Step 1** Generate the CSR from Cisco IMC.

**Step 2** Submit the CSR file to a certificate authority that will issue and sign your certificate. If your organization generates its own self-signed certificates, you can use the CSR file to generate a self-signed certificate.

**Step 3** Upload the new certificate to Cisco IMC.

**Note** The uploaded certificate must be created from a CSR generated by Cisco IMC. Do not upload a certificate that was not created by this method.

## Generating a Certificate Signing Request

You can either generate a self-signed certificate manually using the **generate-csr** command, or automatically when you change the hostname. For information on changing the hostname and auto generation of the self-signed certificate, see the **Configuring Common Properties** section.

To manually generate a certificate signing request, follow these steps:

### Before you begin

- You must log in as a user with admin privileges to configure certificates.
- Ensure that the time is set to the current time.

### SUMMARY STEPS

1. Server# **scope certificate**
2. Server /certificate # **generate-csr**

### DETAILED STEPS

|               | Command or Action                         | Purpose                                                                      |
|---------------|-------------------------------------------|------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope certificate</b>          | Enters the certificate command mode.                                         |
| <b>Step 2</b> | Server /certificate # <b>generate-csr</b> | Launches a dialog for the generation of a certificate signing request (CSR). |

You will be prompted to enter the following information for the certificate signing request:

| Name                           | Description                                                                                                                                                                                                                                            |
|--------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Common Name</b> field       | The fully qualified name of the .<br><br>By default the CN of the servers appears in CXXX-YYYYYY format, where XXX is the model number and YYYYYY is the serial number of the server.<br><br>When you upgrade to latest version, CN is retained as is. |
| <b>Organization Name</b> field | The organization requesting the certificate.                                                                                                                                                                                                           |
| <b>Organization Unit</b> field | The organizational unit.                                                                                                                                                                                                                               |

| Name                        | Description                                                                             |
|-----------------------------|-----------------------------------------------------------------------------------------|
| Locality field              | The city or town in which the company requesting the certificate is headquartered.      |
| State Name field            | The state or province in which the company requesting the certificate is headquartered. |
| Country Code drop-down list | The country in which the company resides.                                               |
| Email field                 | The email contact at the company.                                                       |

After you have entered the requested information, the system will generate and display a certificate signing request in the console output. A CSR file will not be created, but you can copy the CSR information from the console output and paste the information into a text file.

### Example

This example generates a certificate signing request:

```
Server# scope certificate
Server /certificate # generate-csr
Common Name (CN): test.example.com
Organization Name (O): Example, Inc.
Organization Unit (OU): Test Department
Locality (L): San Jose
StateName (S): CA
Country Code (CC): US
Email: user@example.com
Continue to generate CSR? [y|N]y

-----BEGIN CERTIFICATE REQUEST-----
MIIB/zCCAwgCAQAwZkxkCzAJBgNVBAYTAlVTMQswCQYDVQQIEwJkQTEVMBMGA1UE
BxMMU2FuIEpvc2UsIENBMRUwEwYDVQQKEwxFeGFtcGx1IEluYy4xEzARBgNVBASt
ClRlc3QgR3JvdXAxGTAXBgNVBAMTEHRlc3QuZXhhbXBsZS5jb20xHzAdBgkqhkiG
9w0BCQEWEHVzZXJAZXhhbXBsZS5jb20wgZ8wDQYJKoZIhvcNAQEBBQADgY0AMIGJ
AoGBAMZw4nTepNIDhVzb0j7Z2Je4xAG56zmSHRMQeOGHemdh66u2/XAoLx7YccYU
ZgAMivyCsKgb/6CjQtsofvzxmC/eAehuK3/SINv7wd6Vv2pBt6ZpXgD4VBNKOND1
GMbkPayVlQjbG4MD2dx2+H8EH3LMtdZrgKvPxPTE+bF5wZVNAGMBAAGgJTAjBgkq
hkiG9w0BCQcxFhMUQSEjaGFsbGVuZ2UgcGFzc3dvcmQwDQYJKoZIhvcNAQEFBQAD
gYEAG61CaJoJaVMhzC1903O6Mg51zq1zXcz75+VFj2I6rH9asckCl3mkOVx5gJU
Ptt5CVQpNgNLdvdDPSsXretysOhgHmp9+CLv8FDuy1CDYfuaLtlvWvfhevskv0j6
mK3Ku+YiORnv6DhxrOoqau8r/hyI/L43l7IPN1HhOi3oha4=
-----END CERTIFICATE REQUEST-----

Copy everything from "-----BEGIN ..." to "END CERTIFICATE REQUEST-----",
paste to a file, send to your chosen CA for signing,
and finally upload the signed certificate via upload command.
---OR---
Continue to self sign CSR and overwrite the current certificate?
All HTTPS and SSH sessions will be disconnected. [y|N]N
```

### What to do next

Perform one of the following tasks:

- If you do not want to obtain a certificate from a public certificate authority, and if your organization does not operate its own certificate authority, you can allow to internally generate a self-signed certificate from the CSR and upload it immediately to the server. Type **y** after the final prompt in the example to perform this action.
- If your organization operates its own certificate server for generating self-signed certificates, copy the command output from "-----BEGIN ..." to "END CERTIFICATE REQUEST-----" and paste to a file named csr.txt. Input the CSR file to your certificate server to generate a self-signed certificate.
- If you will obtain a certificate from a public certificate authority, copy the command output from "-----BEGIN ..." to "END CERTIFICATE REQUEST-----" and paste to a file named csr.txt. Submit the CSR file to the certificate authority to obtain a signed certificate.
- Ensure that the certificate is of type **Server**.

If you did not use the first option, in which internally generates and uploads a self-signed certificate, you must upload the new certificate using the **upload** command in certificate command mode.

## Creating an Untrusted CA-Signed Certificate

As an alternative to using a public Certificate Authority (CA) to generate and sign a server certificate, you can operate your own CA and sign your own certificates. This section shows commands for creating a CA and generating a server certificate using the OpenSSL certificate server running on Linux. For detailed information about OpenSSL, see <http://www.openssl.org>.



**Note** These commands are to be entered on a Linux server with the OpenSSL package, not in the .

### Before you begin

- Obtain and install a certificate server software package on a server within your organization.
- Ensure that the time is set to the current time.

### Procedure

|               | Command or Action                                                                                                         | Purpose                                                                                                                                                                                                                                                                                         |
|---------------|---------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | <pre>openssl genrsa -out CA_keyfilename keysize</pre> <p><b>Example:</b></p> <pre># openssl genrsa -out ca.key 2048</pre> | <p>This command generates an RSA private key that will be used by the CA.</p> <p><b>Note</b> To allow the CA to access the key without user input, do not use the <code>-des3</code> option for this command.</p> <p>The specified file name contains an RSA key of the specified key size.</p> |
| <b>Step 2</b> | <pre>openssl req -new -x509 -days numdays -key CA_keyfilename -out CA_certfilename</pre> <p><b>Example:</b></p>           | <p>This command generates a new self-signed certificate for the CA using the specified key. The certificate is valid for the specified period. The command prompts the user for additional certificate information.</p>                                                                         |

|               | Command or Action                                                                                                                                                                                                                                                                                                                    | Purpose                                                                                                                                                                                                                                                                                                                                                                                     |
|---------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               | <code># openssl req -new -x509 -days 365 -key ca.key -out ca.crt</code>                                                                                                                                                                                                                                                              | The certificate server is an active CA.                                                                                                                                                                                                                                                                                                                                                     |
| <b>Step 3</b> | <p><b>echo "nsCertType = server" &gt; openssl.conf</b></p> <p><b>Example:</b></p> <pre># echo "nsCertType = server" &gt; openssl.conf</pre>                                                                                                                                                                                          | <p>This command adds a line to the OpenSSL configuration file to designate the certificate as a server-only certificate. This designation is a defense against a man-in-the-middle attack, in which an authorized client attempts to impersonate the server.</p> <p>The OpenSSL configuration file <code>openssl.conf</code> contains the statement <code>"nsCertType = server"</code>.</p> |
| <b>Step 4</b> | <p><b>openssl x509 -req -days numdays -in CSR_filename -CA CA_certfilename -set_serial 04 -CAkey CA_keyfilename -out server_certfilename -extfile openssl.conf</b></p> <p><b>Example:</b></p> <pre># openssl x509 -req -days 365 -in csr.txt -CA ca.crt -set_serial 04 -CAkey ca.key -out myserver05.crt -extfile openssl.conf</pre> | <p>This command directs the CA to use your CSR file to generate a server certificate.</p> <p>Your server certificate is contained in the output file.</p>                                                                                                                                                                                                                                   |
| <b>Step 5</b> | <p><b>openssl x509 -noout -text -purpose -in &lt;cert file&gt;</b></p> <p><b>Example:</b></p> <pre>openssl x509 -noout -text -purpose -in &lt;cert file&gt;</pre>                                                                                                                                                                    | <p>Verifies if the generated certificate is of type <b>Server</b>.</p> <p><b>Note</b> If the values of the fields <b>Server SSL</b> and <b>Netscape SSL</b> server are not yes, ensure that <code>openssl.conf</code> is configured to generate certificates of type server.</p>                                                                                                            |
| <b>Step 6</b> | (Optional) If the generated certificate does not have the correct validity dates, ensure the time is set to the current time, and regenerate the certificate by repeating steps 1 through 5.                                                                                                                                         | Certificate with the correct validity dates is created.                                                                                                                                                                                                                                                                                                                                     |

**Example**

This example shows how to create a CA and to generate a server certificate signed by the new CA. These commands are entered on a Linux server running OpenSSL.

```
/usr/bin/openssl genrsa -out ca.key 2048
Generating RSA private key, 2048 bit long modulus
.....+++++
.....+++++
e is 65537 (0x10001)
/usr/bin/openssl req -new -x509 -days 365 -key ca.key -out ca.crt
You are about to be asked to enter information that will be incorporated
into your certificate request.
What you are about to enter is what is called a Distinguished Name or a DN.
There are quite a few fields but you can leave some blank
For some fields there will be a default value,
If you enter '.', the field will be left blank.

Country Name (2 letter code) [GB]:US
State or Province Name (full name) [Berkshire]:California
```

```

Locality Name (eg, city) [Newbury]:San Jose
Organization Name (eg, company) [My Company Ltd]:Example Incorporated
Organizational Unit Name (eg, section) []:Unit A
Common Name (eg, your name or your server's hostname) []:example.com
Email Address []:admin@example.com
echo "nsCertType = server" > openssl.conf
/usr/bin/openssl x509 -req -days 365 -in csr.txt -CA ca.crt -set_serial 01
-CAkey ca.key -out server.crt -extfile openssl.conf
Signature ok
subject=/C=US/ST=California/L=San Jose/O=Example Inc./OU=Unit
A/CN=example.com/emailAddress=john@example.com
Getting CA Private Key
#

```

### What to do next

Upload the new certificate to the .

## Uploading a Server Certificate

### Before you begin

- You must log in as a user with admin privileges to upload a certificate.
- The certificate to be uploaded must be available as readable text. During the upload procedure, you will copy the certificate text and paste it into the CLI.
- Ensure that the generated certificate is of type **Server**.
- The following certificate formats are supported:
  - .crt
  - .cer
  - .pem




---

**Note** You must first generate a CSR using the certificate management CSR generation procedure, and you must use that CSR to obtain the certificate for uploading. Do not upload a certificate that was not obtained by this method.

---




---

**Note** All current HTTPS and SSH sessions are disconnected when the new server certificate is uploaded.

---

### SUMMARY STEPS

1. Server# **scope certificate**
2. Server /certificate # **upload**

## DETAILED STEPS

|        | Command or Action                   | Purpose                                                                  |
|--------|-------------------------------------|--------------------------------------------------------------------------|
| Step 1 | Server# <b>scope certificate</b>    | Enters the certificate command mode.                                     |
| Step 2 | Server /certificate # <b>upload</b> | Launches a dialog for entering and uploading the new server certificate. |

Copy the certificate text, paste it into the console when prompted, and type CTRL+D to upload the certificate.

**Example**

This example uploads a new certificate to the server:

```
Server# scope certificate
Server /certificate # upload
Please paste your certificate here, when finished, press CTRL+D.
-----BEGIN CERTIFICATE-----
MIIB/zCAAwgCAQAwgZkxCzAJBgNVBAYTA1VTMQswCQYDVQQIEwJDQTEVMBMGAlUE
BxMMU2FuIEpvc2UsIENBMRUwEwYDVQQKEwxFeGFtcGxlIEluYy4xEzARBgNVBAst
ClRlc3QgR3JvdXAxGTAXBgNVBAMTEHRlc3QuZXhhbXBsZS5jb20xHzAdBgkqhkiG
9w0BCQEWEHVzZXJAZXhhbXBsZS5jb20wgZ8wDQYJKoZIhvcNAQEBBQADgY0AMIGJ
AoGBAMZw4nTepNIDhVzb0j7Z2Je4xAG56zmSHRMQeOGHemdh66u2/XAoLx7YCCyU
ZgAMivyCsKgb/6CjQtsofvzxmC/eAehuK3/SINv7wd6Vv2pBt6ZpXgD4VBNKOND1
GMbkPayVlQjB4MD2dx2+H8EH3LMtdZrgKvPxPTE+bF5wZVNAGMBAAGgJTAjBgkq
hkiG9w0BCQcxFhMUQSBjaGFsbGVuZ2UgcGFzc3dvcmQwDQYJKoZIhvcNAQEFBQAD
gYEAG61CaJoJaVMhzC190306Mg51zq1zXcz75+VFj2I6rH9asckCld3mkOVx5gJU
Ptt5CVQpNgNLdvbDPSsXretysOhqHmp9+CLv8FDuy1CDYfuaLtlv1WvfhevskV0j6
mK3Ku+YiORnv6DhxrOoqau8r/hyI/L4317IPN1HhOi3oha4=
-----END CERTIFICATE-----
<CTRL+D>
```

# Managing the External Certificate

## Uploading an External Certificate

**Before you begin**

- You must log in as a user with admin privileges.
- The certificate file to be uploaded must reside on a locally accessible file system.
- The following certificate formats are supported:
  - .crt
  - .cer
  - .pem

**Step 1** Server# **scope certificate**

Enters Cisco IMC certificate command mode.

**Step 2** Server /certificate # **upload-remote-external-certificate** *remote-protocol server\_address path certificate\_filename*

Specify the protocol to connect to the remote server. It can be of the following types:

- TFTP
- FTP
- SFTP
- SCP
- HTTP

**Note** If you enter the protocol as FTP, SCP or SFTP, you will be prompted to enter your username and password.

Along with the remote protocol, enter the filepath from where you want to upload the external certificate. After validating your remote server username and password, uploads the external certificate from the remote server.

**Step 3** (Optional) Server /certificate #**upload-paste-external-certificate**

This is an additional option to upload the external certificate.

At the prompt, paste the content of the certificate and press CTRL+D.

**Example**

- This example uploads an external certificate from a remote server:

```
Server # scope certificate
Server /certificate # upload-remote-external-certificate scp 10.10.10.10
/home/user-xyz/ext-certif.cert
Server (RSA) key fingerprint is dd:b5:2b:07:ad:c0:30:b2:d5:6a:6a:78:80:85:93:b0
Do you wish to continue? [y/N]y
Username: user-xyz
Password:
External Certificate uploaded successfully
Server /certificate #
```

- This example uploads an external certificate using paste option:

```
Server # scope certificate
Server /certificate # upload-paste-external-certificate
Please paste your certificate here, when finished, press CTRL+D.
-----BEGIN CERTIFICATE-----
MIID8zCCAtugAwIBAgIBBDANBgkqhkiG9w0BAQwFADCBsDELMAkGA1UEBhmCSU4x
EjAQBgNVBAGMCUthcm5hdGFrYTESMBAGA1UEBwwJQmFuZ2Fsb3JlMSQwIgyDVQOK
DBtDaXNjbyBTeXN0ZW1zIEluZG1hIFB2dCBMdGQxGDAWBgNVBAsMD1VUy1SYWNR
LVNlcnZlcjEwMBQGA1UEAwwNQ21zY28gU31zdGVtczEhMB8GCSqGSIb3DQEJARYS
c3JpdmF0c3NAY21zY28uY29tMB4XDTEwMDEwMDEwMDEwMDEwMDEwMDEwMDEwMDEw
NVowgbExCzAJBgNVBAYTAk1OMR1wEAYDVQQIEw1LYXJuYXRha2ExEjAQBgNVBAcT
CUJlbmdhbHVydTEkMCIgA1UEChMhbnVzY28gU31zdGVtcyBjBmRpbYsBQdnQgTHRk
MRgwFgyDVQOLEw9VQ1MUMFjay1TZXJ2ZXIxFjAUBgNVBAMTDUNpc2NvIFN5YXRl
bXMxIjAgBgkqhkiG9w0BCQEWES3NyaXZhdHNzQGnpc2NvLmNvbW0wggeiMA0GCSqG
```



```

SIB3DQEBAQUAA4IBDwAwggEKAoIBAQC6fcG9QISg6t1fi6U3+czmek2LvfhAxSGd
r2g7uMssgdTrBh59TEgZl5aza15zWazm/liO69D6/iabyoli8+MiQAtANnKxqWM3
STeih+3U2jOf39lI1LzrAMpd4Ag/OtK5OcUtwUHM52ixm/UU61geVPZ5mJpKzq3T
JNcv6TR90K8v0nEILml1goA96y64I9YN3ufSE4gm9VOS/sFughmAYYersgvgoJpn
SQZUYxwdueBm4XV48QY7Mc7neUVYCN07TcfBX7DC/N0BHv3h1KhGCCQ+5if63uOh
ja8ahdBoIPJqI0h70a92yBK5lv4dxSHexccw2D40kar4CzfvSqx9AgMBAAGjFTAT
MBEGCWGSAGG+EIBAQQEAWIGQDANBgkqhkiG9w0BAQwFAAOCQAQEAXdVTJevqNyI9
DEVibfjGXiKnJ2gEuYr8MdhpDeff/WrsLk7lxhOomVrDZ3iyCX99tNoCIvtOMGns
jOu9OEjNtBulOlgwdQ9ugwp/JToohbD+2JHRK/MgrFpZmewHloKKDNpOdayR6u9m
SNfvMNBgvxg+cMcbkif0pJU3XhlniPF6UVgj/LJDyBSGrULpnyDwTOq2UEF6g9Dc
6gOgRGYNHn7MRzigPJtyjbJsbxgPQ9C46I3Me9N2sJNaSLSVQhOxW7KonPI6USRs
e2iEAYaaCvThGE4HTwOMF9dJ24inU+SKTci1AFq2+V4I3P9v+ah5ao1H9T/p/AUP
ho6MuZ+wWg==
-----END CERTIFICATE-----
External Certificate pasted successfully.
Server /certificate #

```

### What to do next

You must upload an external private key and then activate the external certificate.

## Uploading an External Private Key

### Before you begin

- You must log in as a user with admin privileges to upload an external private key.



#### Note

- Cisco IMC supports external private key size of 2048 bits, 4096 bits and 8192 bits in Cisco UCS S-Series M5 servers.

### Step 1 Server# scope certificate

Enters Cisco IMC certificate command mode.

### Step 2 Server /certificate # upload-remote-external-private-key remote-protocol server\_address path key\_filename

Specify the protocol to connect to the remote server. It can be one of the following:

- SFTP
- SCP

Along with the remote protocol, enter the filepath from where you want to upload the private key. After validating your remote server username and password, uploads the private key from the remote server.

### Step 3 (Optional) Server /certificate #upload-paste-external-private-key

This is an additional option to upload the private key.

At the prompt, paste the content of the private key and press `CTRL+D`.

- Note** The maximum file size supported for upload:
- Up to 8 KB in Cisco UCS S-Series M5 servers

### Example

- This example uploads an external private key from a remote server:

```
Server # scope certificate
Server /certificate # upload-remote-external-private-key scp 10.10.10.10
/home/user-xyz/ext-pvt-key.pem
Server (RSA) key fingerprint is dd:b5:2b:07:ad:c0:30:b2:d5:6a:6a:78:80:85:93:b0
Do you wish to continue? [y/N]y
Username: user-xyz
Password:
External Private Key uploaded successfully
Server /certificate #
```

- This example uploads an external private key using paste option:

```
Server # scope certificate
Server /certificate # upload-paste-external-private-key
Please paste your private key here, when finished, press CTRL+D.
-----BEGIN RSA PRIVATE KEY-----
MIIEoQIBAAKCAQEAAun3BvUCEoOrdX4ulN/nM5npNi734QMuhna9o07jLLIHU6wYe
fUxIGZeWs2pec1mmZv9YjuvQ+v4mm8qJYvPjIkALQDZysaljN0k3ooft1Nozn9/Z
SJWawDKXeAIPzrSuTnFLcFBzOdosZv1FOtYHlT2eZiaT5M6t0yTXL+k0fdCvL9Jx
CC5tZYKAPesuuCPWdd7n0hOIJvVTkv7BboIZgMmBK7IL4KCaZ0kGVGMchbngZuF1
ePEGOzHO53lFWAjaO03HwV+wwvzdAR794ZSoRggkPuYn+t7joY2vGoXQaCDyainI
e9GvdsgSuZb+HcUh3sXHMNg+NJGq+As3lUqsFQIDAQABAoH/MSv3aW8ZiVRkCk1H
wqajCqzR6VPT8SqmGknkpem+pVBDrcOUvtKB3Vwxt3FCaUZuw6YyxZig8t/YpSE
pRkPUN6SGNxCYZXIE0u635/3lafy9LSRFhJcO1EbnwjsIhSB4Sz+Nx7/QsHD82PU
XS8R0MfufACv/iSAsKuGEZvru0BWexDlycojGTDRhGgWZGzsN6ncsbhQ0kItC0Pv
Ycx+9NeKfGwO+P9NwyWwaKW9M4nOyx3/MviMx9QRbnjgxjrdTj+A0aBUEzgdZOf
WCJ/LlSbHmJ46HYZOILL4KDBbow/c7a1c2JcFwn01m33qNCRWdkb5H+1UZA+el7g
XnxDAoGBALzBdW26GGIZjj42Ayr9PAXFs08n0MonqVHRlRTvxuL0vHYdD9HzgkH
CFXA0IGmNk/1RuWEArx6U6ezSP6z7za9B63MskE7t3Vs28/OJg14KptRftGKUIbZ
NRf1o3J7VUf9mYk9u3pc/PJ8oVweFoml/SwRTDvZyUn5WRLq7zJ3AoGBAPztx24M
qj0Gcbqa7U5pUM+9bD9eGPxrGranF1Dp79eobG+9kva286clp0Yr5XrNsQpx42Q6
RULBVEwrB03D7X9UIOaAgyiaDbDMbIeAcRqOC9qpLDUXrpMvrdvVhtcPrKS8VAp4
h0le6zYKMSHMxDeH3EHaQ7aVOQRpt5GoGrAoGBAKBX1uE3TK9I9kRyrY4/QFXG
8d62++4+ct9GI1Z+uKq2w4PeVCHNZYDVsIboHDeGcmzJ901WutxRLe8vpbp4L6VY
PsWtNV+k0tuldaS5gim/ArKeMBTgYjerHCcWS5pcmr1k+KBVCIWRqG504L3X8V1M
3BwrNY9CGnP0lW40lK1RAoGASikuIIZ2JA6Pqjdi/WrD1yWjZ7EfgmO1IYk8cd0m
BgXMRbdAMDbUml3f/iNA1hEZqAZctjafhKhLH0o+if641GzGeM+VpYIGIaD08awn
fbHIqASSgb6/4UCqCZtCPIzKYkMWITvVPNGn/2BdqYM6RPJP9tBaIJ2K9IWIJLm0D
6KECgYB9rmj/8YW7Rz1Isfg7JhK32p7LC+5xSSbpxQc8s/3PftZ5uQnsXXHoZJOH
cfA4mbj4nttyFwX+kuUpQdG/ZhoJ/SDqE5lvzVM4stMRKFEJq8ksld+KGGzLFEKj
OotvpQor5dHHU46IIu9tv5ctrJImMjSM7wro26kW2EE3UzZMYw==
-----END RSA PRIVATE KEY-----
External Private Key pasted successfully.
Server /certificate #
```

### What to do next

You must activate the external certificate.

## Activating the External Certificate

- You must log in as a user with admin privileges.
- You can activate the external certificate only after the certificate and private key are uploaded.
- Activating the external certificate replaces the existing certificate and disconnects any active HTTPS or SSH sessions.

- 
- Step 1** Server# **scope certificate**  
Enters Cisco IMC certificate command mode.
- Step 2** Server /certificate # **activate-external-certificate**  
Activates the uploaded external certificate.
- 

### Example

This example activates the uploaded certificate:

```
Server # scope certificate
Server /certificate # activate-external-certificate
This operation will overwrite the current certificate with the uploaded external certificate.
All HTTPS and SSH sessions will be disconnected.
Continue?[y|N]y
A system reboot has been initiated.
Server /certificate #
```

## Key Management Interoperability Protocol

Key Management Interoperability Protocol (KMIP) is a communication protocol that defines message formats to handle keys or classified data on a key management server. KMIP is an open standard and is supported by several vendors. Key management involves multiple interoperable implementations, so a KMIP client works effectively with any KMIP server.

Self-Encrypting Drives (SEDs) contain hardware that encrypts incoming data and decrypts outgoing data in realtime. A drive or media encryption key controls this function. However, the drives need to be locked in order to maintain security. A security key identifier and a security key (key encryption key) help achieve this goal. The key identifier provides a unique ID to the drive.

Different keys have different usage requirements. Currently, the responsibility of managing and tracking local keys lies primarily with the user, which could result in human error. The user needs to remember the different keys and their functions, which could prove to be a challenge. KMIP addresses this area of concern to manage the keys effectively without human involvement.

## Enabling or Disabling KMIP

### Before you begin

You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. Server# **scope kmip**
2. Server/kmip# **set enabled {yes | no}**
3. Server/kmip\*# **commit**
4. (Optional) Server/kmip # **show detail**

### DETAILED STEPS

|               | Command or Action                           | Purpose                                              |
|---------------|---------------------------------------------|------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope kmip</b>                   | Enters the KMIP command mode.                        |
| <b>Step 2</b> | Server/kmip# <b>set enabled {yes   no}</b>  | Enables or disables KMIP.                            |
| <b>Step 3</b> | Server/kmip*# <b>commit</b>                 | Commits the transaction to the system configuration. |
| <b>Step 4</b> | (Optional) Server/kmip # <b>show detail</b> | Displays the KMIP status.                            |

### Example

This example enables KMIP:

```
Server # scope kmip
Server /kmip # set enabled yes
Server /kmip *# commit
Server /kmip # show detail
 Enabled: yes
Server /kmip #
```

## Creating a Client Private Key and Client Certificate for KMIP Configuration

As an alternative to using a public Certificate Authority (CA) to generate and sign a server certificate, you can operate your own CA and sign your own certificates. This section shows commands for creating a CA and generating a server certificate using the OpenSSL certificate server running on Linux. For detailed information about OpenSSL, see <http://www.openssl.org>.



**Note** These commands are to be entered on a Linux server with the OpenSSL package, not in the .

### Before you begin

- Obtain and install a certificate server software package on a server within your organization.

- Ensure that the time is set to the current time.

## SUMMARY STEPS

1. `openssl genrsa -out Client_Privatekeyfilename keysize`
2. `openssl req -new -x509 -days numdays -key Client_Privatekeyfilename -out Client_certfilename`
3. Obtain the KMIP root CA certificate from the KMIP server.

## DETAILED STEPS

|        | Command or Action                                                                                                                                                                                                             | Purpose                                                                                                                                                                                                                                                                                                          |
|--------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1 | <p><code>openssl genrsa -out Client_Privatekeyfilename keysize</code></p> <p><b>Example:</b></p> <pre># openssl genrsa -out client_private.pem 2048</pre>                                                                     | <p>This command generates a client private key that will be used to generate the client certificate.</p> <p>The specified file name contains an RSA key of the specified key size.</p>                                                                                                                           |
| Step 2 | <p><code>openssl req -new -x509 -days numdays -key Client_Privatekeyfilename -out Client_certfilename</code></p> <p><b>Example:</b></p> <pre># openssl req -new -x509 -key client_private.pem -out client.pem -days 365</pre> | <p>This command generates a new self-signed client certificate using the client private key obtained from the previous step. The certificate is valid for the specified period. The command prompts the user for additional certificate information.</p> <p>A new self-signed client certificate is created.</p> |
| Step 3 | Obtain the KMIP root CA certificate from the KMIP server.                                                                                                                                                                     | Refer to the KMIP vendor documentation for details on obtaining the root CA certificate.                                                                                                                                                                                                                         |

### What to do next

Upload the new certificate to the .

## Downloading a KMIP Client Certificate

### Before you begin

You must log in as a user with admin privileges to perform this task.

## SUMMARY STEPS

1. Server# `scope kmip`
2. Server/kmip # `set enabled yes`
3. Server/kmip\*# `commit`
4. Server/kmip # `scope kmip-client-certificate`
5. Server /kmip/kmip-client-certificate # `download-client-certificate remote-protocol IP Address KMIP client certificate file`
6. At the confirmation prompt, enter `y`.
7. (Optional) Server /kmip/kmip-client-certificate # `paste-client-certificate`

## DETAILED STEPS

|               | Command or Action                                                                                                                                     | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope kmip</b>                                                                                                                             | Enters the KMIP command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Step 2</b> | Server/kmip # <b>set enabled yes</b>                                                                                                                  | Enables KMIP.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Step 3</b> | Server/kmip*# <b>commit</b>                                                                                                                           | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Step 4</b> | Server/kmip # <b>scope kmip-client-certificate</b>                                                                                                    | Enters the KMIP client certificate command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Step 5</b> | Server /kmip/kmip-client-certificate #<br><b>download-client-certificate</b> <i>remote-protocol IP Address</i><br><i>KMIP client certificate file</i> | <p>Specifies the protocol to connect to the remote server. It can be of the following types:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> |
| <b>Step 6</b> | At the confirmation prompt, enter <b>y</b> .                                                                                                          | This begins the download of the KMIP client certificate.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Step 7</b> | (Optional) Server /kmip/kmip-client-certificate #<br><b>paste-client-certificate</b>                                                                  | <p>At the prompt, paste the content of the signed certificate and press <b>CTRL+D</b>.</p> <p><b>Note</b> You can either use the remote server method from the previous steps or use the paste option to download the client certificate.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

**Example**

This example downloads the KMIP client certificate:

```

Server # scope kmip
Server /kmip # set enabled yes
Server /kmip *# commit
Server /kmip # scope kmip-client-certificate
Server /kmip/kmip-client-certificate # show detail
 KMIP client certificate Available: 1
 Download client certificate Status: COMPLETED
 Export client certificate Status: NONE
Server /kmip/kmip-client-certificate # download-client-certificate tftp 10.10.10.10
KmpCertificates/
svbu-xx-blr-dn1-13_ClientCert.pem
 You are going to overwrite the KMIP client certificate.
 Are you sure you want to proceed and overwrite the KMIP client certificate? [y|N]y
KMIP client certificate downloaded successfully

```

You can either use the remote server method from the previous steps or use the paste option to download the client certificate.

```

Server /kmip/kmip-client-certificate # paste-client-certificate
Please paste your certificate here, when finished, press CTRL+D.
-----BEGIN CERTIFICATE-----
MIIDTzCCAjegAwIBAgIQXuWpDbbyTb5M7/FT8aAjZTANBgkqhkiG9w0BAQUFADA6
MRMwEQYKZCZImiZPyLQOBGRYDY29tMRMwEQYKZCZImiZPyLQOBGRYDbmV3MQ4wDAYD
VQQDEWVuzXZdQTAeFw0xNTAzMTIxMTM5MTZaFw0yMDAzMTIxMTQ5MTVaMDoxEzAR
BgoJkiaJk/IsZAEZFgNjb20xEzARBgoJkiaJk/IsZAEZFgNuZXcxZjAMBgNVBAMT
BW5ld0NBMIIBIjANBgkqhkiG9w0BAQEFAAOCAQ8AMIIBCgKCAQEAuPSAwHtk0IbM
Cd5tYdCa498bfX5Nfdgnq5zE+cGIOqv0dAkucocF/Y0+m7hne9H12aQ9SqtOK1+L
5IT3PVCczhasI7L7jAa+Oe5AOYw7Nsugw5Bd23n42BTVMmp7xsgr1mVfFoHXbBkQ
wiT9DieyImSyGiq5n0/8Iooc0iN5WPMVcHO2ys76jR8p07xRqgYNCl6cbKAhWfZ
oYIwjhpZv0+SXEs8sEJZKDUhWifOIpnDL7MoZYgl/kymgs/OhsW4L338jy303c7T
TwnG2/7BOMK0YFkEhqcjlkamGP7MKB2T9e/Cug6VkvFskkim8M1eHx1gEnQxRtAG
YgPln55iHQIDAQABo1EwTzALBgnVHQ8EBAMCAYYwDwYDVR0TAQH/BAUwAwEB/zAd
BgNVHQ4EFgQU12F3U7cggzCuvRW1iZWg91n5lccwEAYJKwYBBAGCNxUBBAMCAQAw
DQYJKoZIhvcNAQEFBQADggEBAJXoJJDDb3QH0q8VY8G/oc1SkAwYOE1dh0NdxFES
tNqQMTaRB2Sb2L/ZzAtfIaZ0Xab9Ig4MqNIMBbHDCw1zhD5gX42GPYWhA/GjrJ30
Q5KcRaEFomxp+twRrJ25ScVSczKJaRonWqKdVL9TwoSuDar3ObiS9ZC0KuBBf0vu
dzrJEYY/1zz7WVpZVYevhba3Vst4LW75URTqOKBSuKO+fvGyyNHwvMPFEIEEnJAKt
7Qmh02fiWhD8CxaPFfByqkvrJ96no6oBxdEcm9n1MttF/UJcypSPH+46mRn5Az
SzgCBftYNjBPLcwbZGJkF/GpPwj0TclMM08UodqiTxR7Ts=
-----END CERTIFICATE-----
 You are going to overwrite the KMIP Client Certificate.
 Are you sure you want to proceed and overwrite the KMIP Client Certificate? [y|N]
y
Server /kmip/kmip-client-certificate #

```

## Exporting a KMIP Client Certificate

### Before you begin

- You must log in as a user with admin privileges to perform this task.
- You should have downloaded KMIP client certificate before you can export it.

### SUMMARY STEPS

1. Server# scope kmip

2. Server /kmip # **scope kmip-client-certificate**
3. Server /kmip/kmip-client-certificate # **export-client-certificate** *remote-protocol IP Addresss KMIP root CA Certificate file*
4. (Optional) Server /kmip/kmip-client-certificate # **show detail**

## DETAILED STEPS

|               | Command or Action                                                                                                                           | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|---------------|---------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope kmip</b>                                                                                                                   | Enters the KMIP command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Step 2</b> | Server /kmip # <b>scope kmip-client-certificate</b>                                                                                         | Enters the KMIP client certificate command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Step 3</b> | Server /kmip/kmip-client-certificate #<br><b>export-client-certificate</b> <i>remote-protocol IP Addresss KMIP root CA Certificate file</i> | <p>Specifies the protocol to connect to the remote server. It can be of the following types:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p>Initiates the export of the certificate.</p> |
| <b>Step 4</b> | (Optional) Server /kmip/kmip-client-certificate # <b>show detail</b>                                                                        | Displays the status of the certificate export.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

### Example

This example exports the KMIP client certificate:

```
Server # scope kmip
Server /kmip # scope kmip-client-certificate
Server /kmip/kmip-client-certificate # export-client-certificate ftp 10.10.10.10
```



```

/TFTP_DIR/KmipCertificates
/svbu-xx-blr-dn1-13_ClientCert.pem_exported_ftp
Username: username
Password:
KMIP Client Certificate exported successfully
Server /kmip/kmip-client-certificate # show detail
 KMIP Client Certificate Available: 1
 Download KMIP Client Certificate Status: COMPLETED
 Export KMIP Client Certificate Status: COMPLETED
Server /kmip/kmip-client-certificate #

```

## Deleting a KMIP Client Certificate

### Before you begin

You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. Server# **scope kmip**
2. Server# /kmip **scope kmip-client-certificate**
3. Server /kmip/kmip-client-certificate # **delete-client-certificate**
4. At the confirmation prompt, enter **y**.

### DETAILED STEPS

|               | Command or Action                                                          | Purpose                                                  |
|---------------|----------------------------------------------------------------------------|----------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope kmip</b>                                                  | Enters the KMIP command mode.                            |
| <b>Step 2</b> | Server# /kmip <b>scope kmip-client-certificate</b>                         | Enters the KMIP client certificate binding command mode. |
| <b>Step 3</b> | Server /kmip/kmip-client-certificate #<br><b>delete-client-certificate</b> | Confirmation prompt appears.                             |
| <b>Step 4</b> | At the confirmation prompt, enter <b>y</b> .                               | This deletes the KMIP client certificate.                |

### Example

This example deletes the KMIP client certificate:

```

Server # scope kmip
Server /kmip # scope kmip-client-certificate
Server /kmip/kmip-client-certificate # delete-client-certificate
 You are going to delete the KMIP Client Certificate.
 Are you sure you want to proceed and delete the KMIP Client Certificate? [y|N]y
 KMIP Client Certificate deleted successfully.

```

## Downloading a KMIP Root CA Certificate

### Before you begin

You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. Server# **scope kmip**
2. Server/kmip # **set enabled yes**
3. Server/kmip \* # **commit**
4. Server /kmip # **scope kmip-root-ca-certificate**
5. Server /kmip/kmip-root-ca-certificate # **download-root-ca-certificate** *remote-protocol IP Address KMIP CA Certificate file*
6. At the confirmation prompt, enter **y**.
7. (Optional) Server /kmip/kmip-root-ca-certificate # **paste-root-ca-certificate**

### DETAILED STEPS

|               | Command or Action                                                                                                                             | Purpose                                                                                                                                                                                                          |
|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope kmip</b>                                                                                                                     | Enters the KMIP command mode.                                                                                                                                                                                    |
| <b>Step 2</b> | Server/kmip # <b>set enabled yes</b>                                                                                                          | Enables KMIP.                                                                                                                                                                                                    |
| <b>Step 3</b> | Server/kmip * # <b>commit</b>                                                                                                                 | Commits the transaction to the system configuration.                                                                                                                                                             |
| <b>Step 4</b> | Server /kmip # <b>scope kmip-root-ca-certificate</b>                                                                                          | Enters the KMIP root CA certificate command mode.                                                                                                                                                                |
| <b>Step 5</b> | Server /kmip/kmip-root-ca-certificate #<br><b>download-root-ca-certificate</b> <i>remote-protocol IP Address<br/>KMIP CA Certificate file</i> | Specifies the protocol to connect to the remote server. It can be of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> |

|               | Command or Action                                                                   | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|---------------|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                                                     | <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> |
| <b>Step 6</b> | At the confirmation prompt, enter y.                                                | This begins the download of the KMIP root CA certificate.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Step 7</b> | (Optional) Server /kmip/kmip-root-ca-certificate # <b>paste-root-ca-certificate</b> | <p>At the prompt, paste the content of the root CA certificate and press <b>CTRL+D</b>.</p> <p><b>Note</b> You can either use the remote server method from the previous steps or use the paste option to download the root CA certificate.</p>                                                                                                                                                                                                                                                                                                                                                                                                        |

**Example**

This example downloads the KMIP root CA certificate:

```

Server # scope kmip
Server /kmip # set enabled yes
Server /kmip *# commit
Server /kmip # scope kmip-root-ca-certificate
Server /kmip/kmip-root-ca-certificate # show detail
 KMIP Root CA Certificate Available: 1
 Download Root CA Certificate Status: COMPLETED
 Export Root CA Certificate Status: NONE
Server /kmip/kmip-root-ca-certificate # download-root-ca-certificate tftp 10.10.10.10
KmipCertificates/
svbu-xx-blr-dn1-13_ServerCert.pem
 You are going to overwrite the KMIP Root CA Certificate.
 Are you sure you want to proceed and overwrite the KMIP Root CA Certificate? [y|N]y
KMIP Root CA Certificate downloaded successfully

```

You can either use the remote server method from the previous steps or use the paste option to download the client certificate.

```

Server /kmip/kmip-root-ca-certificate # paste-root-ca-certificate
Please paste your certificate here, when finished, press CTRL+D.
----BEGIN CERTIFICATE-----
MIIDTzCCAjegAwIBAgIQXuWpdBbyTb5M7/FT8aAjZTANBgkqhkiG9w0BAQUFADA6
MRMwEQYKCZImiZPyLGBGRYDY29tMRMwEQYKCZImiZPyLGBGRYDhmV3MQ4wDAYD
VQQDEwVuZXZhdDQTAeFw0xNTAzMTIxMTM5MTZaFw0yMDAzMTIxMTQ5MTVhMDoxEzAR

```

```

BgoJkiaJk/IsZAEZFgNjb20xEzARBgoJkiaJk/IsZAEZFgNuZXcxDjAMBgnVBAMT
BW5ld0NBMIIBIjANBgkqhkiG9w0BAQEFAAOCAQ8AMIIBCgKCAQEAuPSAwHtk0IbM
Cd5tYdCa498bfX5Nfdgnq5zE+cGIOqv0dAkucocfC/Y0+m7hne9H12aQ9SqtOK1+L
5IT3PVCczhasI7L7jAa+Oe5AOYw7Nsugw5Bd23n42BTVMmp7xsgrlmVfFoHXbBkQ
wiT9DieyImSyGiq5n0/8Iooc0iN5WPMVcHO2ysz76jr8p07xRggYNC16cbKAhWfZ
oYIwjhpZv0+SXEs8sEJZKDUhWIFoIpnDL7MoZYgl/kymgs/0hsW4L338jy303c7T
TwnG2/7BOMK0YFkEhqcjlkamGP7MKB2T9e/Cug6VkvFSkkim8M1eHx1gEnQxRtAG
YGpln55iHQIDAQABo1EwTzALBgNVHQ8EBAMCAYwDwYDVR0TAQH/BAUwAwEB/zAd
BgNVHQ4EFgQU12F3U7cggzCuvRWliZWg91n51ccwEAYJKwYBBAGCNxUBBAMCAQAw
DQYJKoZIhvcNAQEFBQADggEBAJXoJJDDb3QH0q8VY8G/oC1SkAwyoE1dH0NdxFES
tNqQMTaRB2Sb2L/ZzAtfIaZ0Xab9Ig4MqNIMBbHDCw1zhD5gX42GPYWhA/GjRj30
Q5KcRaEFomxp+twRrJ25ScvSczKJaRonWqKDVL9TwoSuDar3Obis9ZC0KuBBf0vu
dzrJEYY/1zz7WVPZVvevha3Vst4LW75URTqOKBSuKO+fvGyyNHwvMPFEIEnJAKt
7QmhO2fiWhD8CxaPFIByqkvrJ96no6oBxdEcjm9n1MttF/UJcypSPH+46mRn5Az
SzgCBftYNjBPLcwbZGJkF/GpPwjD0Tc1MM08UOdqiTxR7Ts=
-----END CERTIFICATE-----
You are going to overwrite the KMIP Root CA Certificate.
Are you sure you want to proceed and overwrite the KMIP Root CA Certificate? [y/N]
y
Server /kmip/kmip-root-ca-certificate #

```

## Exporting a KMIP Root CA Certificate

### Before you begin

- You must log in as a user with admin privileges to perform this task.
- You should have downloaded KMIP root CA certificate before you can export it.

### SUMMARY STEPS

1. Server # **scope kmip**
2. Server /kmip # **scope kmip-root-ca-certificate**
3. Server /kmip/kmip-root-ca-certificate # **export-root-ca-certificate remote-protocol IP Addresss KMIP root CA Certificate file**
4. (Optional) Server /kmip/kmip-root-ca-certificate # **show detail**

### DETAILED STEPS

|               | Command or Action                                                                                                                      | Purpose                                                                                                                                                                                          |
|---------------|----------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope kmip</b>                                                                                                             | Enters the KMIP command mode.                                                                                                                                                                    |
| <b>Step 2</b> | Server /kmip # <b>scope kmip-root-ca-certificate</b>                                                                                   | Enters the KMIP root CA certificate command mode.                                                                                                                                                |
| <b>Step 3</b> | Server /kmip/kmip-root-ca-certificate #<br><b>export-root-ca-certificate remote-protocol IP Addresss KMIP root CA Certificate file</b> | Specifies the protocol to connect to the remote server. It can be of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> </ul> |

|               | Command or Action                                                     | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|---------------|-----------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                                       | <p>• HTTP</p> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p>Initiates the export of the certificate.</p> |
| <b>Step 4</b> | (Optional) Server /kmip/kmip-root-ca-certificate # <b>show detail</b> | Displays the status of the certificate export.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

**Example**

This example exports the KMIP root CA certificate:

```
Server # scope kmip
Server /kmip # scope kmip-root-ca-certificate
Server /kmip/kmip-root-ca-certificate # export-root-ca-certificate tftp 10.10.10.10
KmipCertificates/
svbu-xx-blr-dn1-13_ServerCert.pem_exported_tftp
KMIP Root CA Certificate exported successfully
Server /kmip/kmip-root-ca-certificate # show detail
 KMIP Root CA Certificate Available: 1
 Download Root CA Certificate Status: COMPLETED
 Export Root CA Certificate Status: COMPLETED
Server /kmip/kmip-root-ca-certificate #
```

## Deleting a KMIP Root CA Certificate

**Before you begin**

You must log in as a user with admin privileges to perform this task.

**SUMMARY STEPS**

1. Server# **scope kmip**
2. Server# /kmip **scope kmip-root-ca-certificate**
3. Server /kmip/kmip-root-ca-certificate # **delete-root-ca-certificate**

- At the confirmation prompt, enter **y**.

#### DETAILED STEPS

|               | Command or Action                                                            | Purpose                                                   |
|---------------|------------------------------------------------------------------------------|-----------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope kmip</b>                                                    | Enters the KMIP command mode.                             |
| <b>Step 2</b> | Server# /kmip <b>scope kmip-root-ca-certificate</b>                          | Enters the KMIP root CA certificate binding command mode. |
| <b>Step 3</b> | Server /kmip/kmip-root-ca-certificate #<br><b>delete-root-ca-certificate</b> | Confirmation prompt appears.                              |
| <b>Step 4</b> | At the confirmation prompt, enter <b>y</b> .                                 | This deletes the KMIP root CA certificate.                |

#### Example

This example deletes the KMIP root CA certificate:

```
Server # scope kmip
Server /kmip # scope kmip-root-ca-certificate
Server /kmip/kmip-root-ca-certificate # delete-root-ca-certificate
You are going to delete the KMIP root CA certificate.
Are you sure you want to proceed and delete the KMIP root CA certificate? [y|N]y
KMIP root CA certificate deleted successfully.
```

## Downloading a KMIP Client Private Key

#### Before you begin

You must log in as a user with admin privileges to perform this task.

#### SUMMARY STEPS

- Server# **scope kmip**
- Server/kmip# **set enabled yes**
- Server/kmip\*# **commit**
- Server/kmip # **scope kmip-client-private-key**
- Server /kmip/kmip-client-private-key # **download-client-pvt-key remote-protocol IP Address KMIP client private key file**
- At the confirmation prompt, enter **y**.
- (Optional) Server /kmip/kmip-client-private-key # **paste-client-pvt-key**

#### DETAILED STEPS

|               | Command or Action                   | Purpose                       |
|---------------|-------------------------------------|-------------------------------|
| <b>Step 1</b> | Server# <b>scope kmip</b>           | Enters the KMIP command mode. |
| <b>Step 2</b> | Server/kmip# <b>set enabled yes</b> | Enables KMIP.                 |

|               | Command or Action                                                                                                                                 | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|---------------|---------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 3</b> | Server/kmip*# <b>commit</b>                                                                                                                       | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Step 4</b> | Server/kmip # <b>scope kmip-client-private-key</b>                                                                                                | Enters the KMIP client private key command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Step 5</b> | Server /kmip/kmip-client-private-key #<br><b>download-client-pvt-key</b> <i>remote-protocol IP Address</i><br><i>KMIP client private key file</i> | <p>Specifies the protocol to connect to the remote server. It can be of the following types:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> |
| <b>Step 6</b> | At the confirmation prompt, enter <b>y</b> .                                                                                                      | This begins the download of the KMIP client private key.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Step 7</b> | (Optional) Server /kmip/kmip-client-private-key #<br><b>paste-client-pvt-key</b>                                                                  | <p>At the prompt, paste the content of the private key and press <b>CTRL+D</b>.</p> <p><b>Note</b> You can either use the remote server method from the previous steps or use the paste option to download the client private key.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |

### Example

This example downloads the KMIP client private key:

```
Server # scope kmip
Server /kmip # set enabled yes
Server /kmip *# commit
Server /kmip # scope kmip-client-private-key
Server /kmip/kmip-client-private-key # show detail
 KMIP Client Private Key Available: 1
```

```

Download Client Private Key Status: COMPLETED
Export Client Private Key Status: NONE
Server /kmip/kmip-client-private-key # download-client-pvt-key tftp 10.10.10.10
KmipCertificates/
svbu-xx-blr-dn1-13_ClientPvtKey.pem
You are going to overwrite the KMIP Client Private Key.
Are you sure you want to proceed and overwrite the KMIP Client Private Key? [y|N]y
KMIP Client Private Key downloaded successfully

```

You can either use the remote server method from the previous steps or use the paste option to download the client certificate.

```

Server /kmip/kmip-client-private-key # paste-client-pvt-key
Please paste your client private here, when finished, press CTRL+D.
-----BEGIN CERTIFICATE-----
MIIDTzCCAjegAwIBAgIQXuWpdBbyTb5M7/FT8aAjZTANBgkqhkiG9w0BAQUFADA6
MRMwEQYKCZImiZPyLQGGRYDY29tMRMwEQYKCZImiZPyLQGGRYDbmV3MQ4wDAYD
VQQDEwVuZXNDQTAeFw0xNTAzMTIxMTM5MTZaFw0yMDAzMTIxMTQ5MTVaMDoxEzAR
BgoJkiaJk/IsZAEZFgNjb20xEzARBgoJkiaJk/IsZAEZFgNuZXcxZjAMBGNVBAMT
BW5ld0NBMIIBIjANBgkqhkiG9w0BAQEFAAOCAQ8AMIIBCgKCAQEApSAwHtk0IbM
Cd5tYdCa498bfX5Nfdgnq5ze+cGIOqv0dAkucofC/Y0+m7hne9H12aQ9SqtOK1+L
5IT3PVCczhasI7L7jAa+Oe5AOYw7Nsugw5Bd23n42BTVMmp7xsgr1mVfF0HXbBkQ
wiT9DieyImSyGiq5n0/8Iooc0iN5WPMVcho2ysz76jR8p07xrqgYnc16cbKAhWfZ
oYIwjhpZv0+SXEs8sEJZKDUhWIf0IpnDL7MoZYgl/kymgs/0hsW4L338jy303c7T
TwnG2/7BOMK0YFkEhqcjlkamGP7MKB2T9e/Cug6VkvFSkkim8M1eHx1gEnQxRtAg
Ygp1n55ihQIDAQABo1EwTzALBgNVHQ8EBAMCAYYwDwYDVR0TAQH/BAUwAwEB/zAd
BgNVHQ4EFgQUl2F3U7cggzCuvRWliZWg91n5lccwEAYJKwYBBAGCNxUBBAMCAQAw
DQYJKoZIhvcNAQEFBQADggEBAJXoJJDDb3QH0q8VY8G/oc1SkAwyoE1dH0NdxFES
tNqQMTARb2Sb2L/ZzAtfIaZ0Xab9Ig4MqNIMBbHDCw1zhD5gX42GPYWhA/GjRj30
Q5KcRaEFomxp+twRrJ25ScVSczKJaRonWqKDVL9TwoSuDar3ObiS9ZC0KuBBf0vu
dzrJEYY/1zz7WVPZVvevha3VSt4LW75URTqOKBSuKO+fvGyyNHwvMPFEIEnJAKt
7Qmh02fiWhD8CxaPFIBYqkvrJ96no6oBxdEcjm9n1MttF/UJcypSPH+46mRn5Az
SgzCBftYNjBPLcwbZGJkF/GpPwjD0TclMM08UOdqiTxr7Ts=
-----END CERTIFICATE-----
You are going to overwrite the KMIP client private key.
Are you sure you want to proceed and overwrite the KMIP Client Private Key? [y|N]
y
Server /kmip/kmip-client-private-key #

```

## Exporting KMIP Client Private Key

### Before you begin

- You must log in as a user with admin privileges to perform this task.
- You should have downloaded KMIP client private key before you can export it.

### SUMMARY STEPS

1. Server# **scope kmip**
2. Server /kmip # **scope kmip-client-private-key**
3. Server /kmip/kmip-client-private-key # **export-client-pvt-key remote-protocol IP Addresss KMIP root CA Certificate file**
4. (Optional) Server /kmip/kmip-client-private-key # **show detail**



## DETAILED STEPS

|               | Command or Action                                                                                                                           | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|---------------|---------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope kmip</b>                                                                                                                   | Enters the KMIP command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Step 2</b> | Server /kmip # <b>scope kmip-client-private-key</b>                                                                                         | Enters the KMIP client private key command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Step 3</b> | Server /kmip/kmip-client-private-key #<br><b>export-client-pvt-key</b> <i>remote-protocol IP Addresss KMIP<br/>root CA Certificate file</i> | <p>Specifies the protocol to connect to the remote server. It can be of the following types:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p>Initiates the export of the certificate.</p> |
| <b>Step 4</b> | (Optional) Server /kmip/kmip-client-private-key # <b>show detail</b>                                                                        | Displays the status of the certificate export.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

**Example**

This example exports the KMIP client private key:

```

Server # scope kmip
Server /kmip # scope kmip-client-private-key
Server /kmip/kmip-client-private-key # export-client-pvt-key tftp 10.10.10.10
KmipCertificates
/svbu-xx-blr-dn1-13_ClientPvtKey.pem_exported_tftp
KMIP Client Private Key exported successfully
Server /kmip/kmip-client-private-key # show detail
 KMIP Client Private Key Available: 1
 Download Client Private Key Status: COMPLETED

```

```
Export Client Private Key Status: COMPLETED
Server /kmip/kmip-client-private-key #
```

## Deleting a KMIP Client Private Key

### Before you begin

You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. Server# **scope kmip**
2. Server# /kmip **scope kmip-client-private-key**
3. Server /kmip/kmip-client-private-key # **delete-client-pvt-key**
4. At the confirmation prompt, enter **y**.

### DETAILED STEPS

|               | Command or Action                                                      | Purpose                                                  |
|---------------|------------------------------------------------------------------------|----------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope kmip</b>                                              | Enters the KMIP command mode.                            |
| <b>Step 2</b> | Server# /kmip <b>scope kmip-client-private-key</b>                     | Enters the KMIP client private key binding command mode. |
| <b>Step 3</b> | Server /kmip/kmip-client-private-key #<br><b>delete-client-pvt-key</b> | Confirmation prompt appears.                             |
| <b>Step 4</b> | At the confirmation prompt, enter <b>y</b> .                           | This deletes the KMIP client private key.                |

### Example

This example deletes the KMIP client private key:

```
Server # scope kmip
Server /kmip # scope kmip-client-private-key
Server /kmip/kmip-client-private-key # delete-client-pvt-key
 You are going to delete the KMIP client private key.
 Are you sure you want to proceed and delete the KMIP client private key? [y|N]y
KMIP client private key deleted successfully.
```

## Configuring KMIP Server Login Credentials

This procedure shows you how to configure the login credentials for the KMIP server and make the KMIP server login credentials mandatory for message authentication.

### Before you begin

You must log in as a user with admin privileges to perform this task.

## SUMMARY STEPS

1. Server# **scope kmip**
2. Server /kmip # **scope kmip-login**
3. Server/kmip/kmip-login # **set login username**
4. Server/kmip/kmip-login \* # **set password**
5. Server/kmip/kmip-login \* # **set use-kmip-cred {yes | no}**
6. Server/kmip/kmip-login \* # **commit**
7. (Optional) Server/kmip/kmip-login # **restore**

## DETAILED STEPS

|               | Command or Action                                              | Purpose                                                                                                                                |
|---------------|----------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope kmip</b>                                      | Enters the KMIP command mode.                                                                                                          |
| <b>Step 2</b> | Server /kmip # <b>scope kmip-login</b>                         | Enters the KMIP login command mode.                                                                                                    |
| <b>Step 3</b> | Server/kmip/kmip-login # <b>set login username</b>             | Sets the KMIP server user name.                                                                                                        |
| <b>Step 4</b> | Server/kmip/kmip-login * # <b>set password</b>                 | Enter the password at the prompt and enter the same password again at the confirm password prompt. This sets the KMIP server password. |
| <b>Step 5</b> | Server/kmip/kmip-login * # <b>set use-kmip-cred {yes   no}</b> | Decides whether the KMIP server login credentials should be mandatory for message authentication.                                      |
| <b>Step 6</b> | Server/kmip/kmip-login * # <b>commit</b>                       | Commits the transaction to the system configuration.                                                                                   |
| <b>Step 7</b> | (Optional) Server/kmip/kmip-login # <b>restore</b>             | Restores the KMIP settings to defaults.                                                                                                |

## Example

This example shows how to configure the KMIP server credentials:

```
Server /kmip # scope kmip-login
Server /kmip/kmip-login # set login username
Server /kmip/kmip-login * # set password
Please enter password:
Please confirm password:
Server /kmip/kmip-login * # set use-kmip-cred yes
Server /kmip/kmip-login * # commit
Server /kmip/kmip-login # show detail
 Use KMIP Login: yes
 Login name to KMIP server: username
 Password to KMIP server: *****
```

You can restore the KMIP server credentials to default settings by performing the following step:

```
Server /kmip/kmip-login # restore
Are you sure you want to restore KMIP settings to defaults?
Please enter 'yes' to confirm: yes
Restored factory-default configuration.
Server /kmip/kmip-login # show detail
 Use KMIP Login: no
```

```

Login name to KMIP server:
Password to KMIP server: *****
Server /kmip/kmip-login #

```

## Configuring KMIP Server Properties

### Before you begin

You must log in with admin privileges to perform this task.

### Procedure

|               | Command or Action                                         | Purpose                                          |
|---------------|-----------------------------------------------------------|--------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope kmip</b>                                | Enters the KMIP command mode.                    |
| <b>Step 2</b> | Server /kmip # <b>scope kmip-server</b> <i>server ID</i>  | Enters the chosen KMIP server command mode.      |
| <b>Step 3</b> | Server /kmip/kmip-server # <b>set</b> <i>kmip-port</i>    | Sets the KMIP port.                              |
| <b>Step 4</b> | Server /kmip/kmip-server *# <b>set</b> <i>kmip-server</i> | Sets the KMIP server ID.                         |
| <b>Step 5</b> | Server /kmip/kmip-server # <b>set</b> <i>kmip-timeout</i> | Sets the KMIP server timeout.                    |
| <b>Step 6</b> | Server /kmip/kmip-server # <b>commit</b>                  | Commits the transaction to system configuration. |
| <b>Step 7</b> | (Optional) Server /kmip/kmip-server # <b>show detail</b>  | Displays the KMIP server details.                |

### Example

This example tests the KMIP server connection:

```

Server # scope kmip
Server /kmip # scope kmip-server 1
Server /kmip/kmip-server # set kmip-port 5696
Server /kmip/kmip-server * # set kmip-server kmipserver.com
Server /kmip/kmip-server * # set kmip-timeout 10
Server /kmip/kmip-server * # commit
Server /kmip/kmip-server # show detail
Server number 1:
 Server domain name or IP address: kmipserver.com
 Port: 5696
 Timeout: 10
Server /kmip/kmip-server #

```

# KMIP

## Key Management Interoperability Protocol

Key Management Interoperability Protocol (KMIP) is a communication protocol that defines message formats to handle keys or classified data on a key management server. KMIP is an open standard and is supported by several vendors. Key management involves multiple interoperable implementations, so a KMIP client works effectively with any KMIP server.

Self-Encrypting Drives (SEDs) contain hardware that encrypts incoming data and decrypts outgoing data in realtime. A drive or media encryption key controls this function. However, the drives need to be locked in order to maintain security. A security key identifier and a security key (key encryption key) help achieve this goal. The key identifier provides a unique ID to the drive.

Different keys have different usage requirements. Currently, the responsibility of managing and tracking local keys lies primarily with the user, which could result in human error. The user needs to remember the different keys and their functions, which could prove to be a challenge. KMIP addresses this area of concern to manage the keys effectively without human involvement.

## Enabling or Disabling KMIP

### Before you begin

You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server # **scope bmc**
3. Server /server/bmc # **scope kmip**
4. Server /server/bmc/kmip # **set enabled** {yes | no}
5. Server /server/bmc/kmip \*# **commit**
6. (Optional) Server /server/bmc/kmip # **show detail**

### DETAILED STEPS

|               | Command or Action                                       | Purpose                                              |
|---------------|---------------------------------------------------------|------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}                    | Enters server command mode of server 1 or 2.         |
| <b>Step 2</b> | Server /server # <b>scope bmc</b>                       | Enters bmc command mode.                             |
| <b>Step 3</b> | Server /server/bmc # <b>scope kmip</b>                  | Enters the KMIP command mode.                        |
| <b>Step 4</b> | Server /server/bmc/kmip # <b>set enabled</b> {yes   no} | Enables or disables KMIP.                            |
| <b>Step 5</b> | Server /server/bmc/kmip *# <b>commit</b>                | Commits the transaction to the system configuration. |
| <b>Step 6</b> | (Optional) Server /server/bmc/kmip # <b>show detail</b> | Displays the KMIP status.                            |

**Example**

This example enables KMIP:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # set enabled yes
Server /server/bmc/kmip *# commit
Server /server/bmc/kmip # show detail
 Enabled: yes
Server /server/bmc/kmip #
```

## Configuring KMIP Server Login Credentials

This procedure shows you how to configure the login credentials for the KMIP server and make the KMIP server login credentials mandatory for message authentication.

**Before you begin**

You must log in as a user with admin privileges to perform this task.

**SUMMARY STEPS**

1. Server # **scope server** {1 | 2}
2. Server /server # **scope bmc**
3. Server /server/bmc # **scope kmip**
4. Server /server/bmc/kmip # **scope kmip-login**
5. Server /server/bmc/kmip/kmip-login # **set login** *username*
6. Server /server/bmc/kmip/kmip-login \* # **set password**
7. Server /server/bmc/kmip/kmip-login \* # **set use-kmip-cred** {yes | no}
8. Server /server/bmc/kmip/kmip-login \* # **commit**
9. (Optional) Server /server/bmc/kmip/kmip-login # **restore**

**DETAILED STEPS**

|               | Command or Action                                                     | Purpose                                                                                                                                |
|---------------|-----------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}                                  | Enters server command mode of server 1 or 2.                                                                                           |
| <b>Step 2</b> | Server /server # <b>scope bmc</b>                                     | Enters bmc command mode.                                                                                                               |
| <b>Step 3</b> | Server /server/bmc # <b>scope kmip</b>                                | Enters the KMIP command mode.                                                                                                          |
| <b>Step 4</b> | Server /server/bmc/kmip # <b>scope kmip-login</b>                     | Enters the KMIP login command mode.                                                                                                    |
| <b>Step 5</b> | Server /server/bmc/kmip/kmip-login # <b>set login</b> <i>username</i> | Sets the KMIP server user name.                                                                                                        |
| <b>Step 6</b> | Server /server/bmc/kmip/kmip-login * # <b>set password</b>            | Enter the password at the prompt and enter the same password again at the confirm password prompt. This sets the KMIP server password. |

|               | Command or Action                                                          | Purpose                                                                                           |
|---------------|----------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|
| <b>Step 7</b> | Server /server/bmc/kmip/kmip-login * # <b>set use-kmip-cred</b> {yes   no} | Decides whether the KMIP server login credentials should be mandatory for message authentication. |
| <b>Step 8</b> | Server /server/bmc/kmip/kmip-login * # <b>commit</b>                       | Commits the transaction to the system configuration.                                              |
| <b>Step 9</b> | (Optional) Server /server/bmc/kmip/kmip-login # <b>restore</b>             | Restores the KMIP settings to defaults.                                                           |

### Example

This example shows how to configure the KMIP server credentials:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # scope kmip-login
Server /server/bmc/kmip/kmip-login # set login username
Server /server/bmc/kmip/kmip-login * # set password
Please enter password:
Please confirm password:
Server /server/bmc/kmip/kmip-login * # set use-kmip-cred yes
Server /server/bmc/kmip/kmip-login * # commit
Server /server/bmc/kmip/kmip-login # show detail
 Use KMIP Login: yes
 Login name to KMIP server: username
 Password to KMIP server: *****
```

You can restore the KMIP server credentials to default settings by performing the following step:

```
Server /server/bmc/kmip/kmip-login # restore
Are you sure you want to restore KMIP settings to defaults?
Please enter 'yes' to confirm: yes
Restored factory-default configuration.
Server /server/bmc/kmip/kmip-login # show detail
 Use KMIP Login: no
 Login name to KMIP server:
 Password to KMIP server: *****
Server /server/bmc/kmip/kmip-login #
```

## Creating a Client Private Key and Client Certificate for KMIP Configuration

As an alternative to using a public Certificate Authority (CA) to generate and sign a server certificate, you can operate your own CA and sign your own certificates. This section shows commands for creating a CA and generating a server certificate using the OpenSSL certificate server running on Linux. For detailed information about OpenSSL, see <http://www.openssl.org>.



**Note** These commands are to be entered on a Linux server with the OpenSSL package, not in the .

### Before you begin

- Obtain and install a certificate server software package on a server within your organization.

- Ensure that the time is set to the current time.

## SUMMARY STEPS

1. `openssl genrsa -out Client_Privatekeyfilename keysize`
2. `openssl req -new -x509 -days numdays -key Client_Privatekeyfilename -out Client_certfilename`
3. Obtain the KMIP root CA certificate from the KMIP server.

## DETAILED STEPS

|               | Command or Action                                                                                                                                                                                                             | Purpose                                                                                                                                                                                                                                                                                                          |
|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | <p><code>openssl genrsa -out Client_Privatekeyfilename keysize</code></p> <p><b>Example:</b></p> <pre># openssl genrsa -out client_private.pem 2048</pre>                                                                     | <p>This command generates a client private key that will be used to generate the client certificate.</p> <p>The specified file name contains an RSA key of the specified key size.</p>                                                                                                                           |
| <b>Step 2</b> | <p><code>openssl req -new -x509 -days numdays -key Client_Privatekeyfilename -out Client_certfilename</code></p> <p><b>Example:</b></p> <pre># openssl req -new -x509 -key client_private.pem -out client.pem -days 365</pre> | <p>This command generates a new self-signed client certificate using the client private key obtained from the previous step. The certificate is valid for the specified period. The command prompts the user for additional certificate information.</p> <p>A new self-signed client certificate is created.</p> |
| <b>Step 3</b> | Obtain the KMIP root CA certificate from the KMIP server.                                                                                                                                                                     | Refer to the KMIP vendor documentation for details on obtaining the root CA certificate.                                                                                                                                                                                                                         |

### What to do next

Upload the new certificate to the .

## Testing the KMIP Server Connection

### Procedure

|               | Command or Action                                                    | Purpose                                      |
|---------------|----------------------------------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <code>scope server {1   2}</code>                           | Enters server command mode of server 1 or 2. |
| <b>Step 2</b> | Server /server # <code>scope bmc</code>                              | Enters bmc command mode.                     |
| <b>Step 3</b> | Server /server/bmc # <code>scope kmip</code>                         | Enters the KMIP command mode.                |
| <b>Step 4</b> | Server /server/bmc/kmip # <code>scope kmip-server server ID</code>   | Enters the chosen KMIP server command mode.  |
| <b>Step 5</b> | Server /server/bmc/kmip/kmip-server # <code>test-connectivity</code> | Verifies the connection of the KMIP server.  |



**Example**

This example tests the KMIP server connection:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # scope kmip-server 1
Server /server/bmc/kmip/kmip-server # test-connectivity
Able to connect to KMIP server.
Server /server/bmc/kmip/kmip-server #
```

## Configuring KMIP Server Properties

**Before you begin**

You must log in with admin privileges to perform this task.

**Procedure**

|               | Command or Action                                                    | Purpose                                          |
|---------------|----------------------------------------------------------------------|--------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}                                 | Enters server command mode of server 1 or 2.     |
| <b>Step 2</b> | Server /server # <b>scope bmc</b>                                    | Enters bmc command mode.                         |
| <b>Step 3</b> | Server /server/bmc # <b>scope kmip</b>                               | Enters the KMIP command mode.                    |
| <b>Step 4</b> | Server /server/bmc/kmip # <b>scope kmip-server</b> <i>server ID</i>  | Enters the chosen KMIP server command mode.      |
| <b>Step 5</b> | Server /server/bmc/kmip/kmip-server # <b>set</b> <i>kmip-port</i>    | Sets the KMIP port.                              |
| <b>Step 6</b> | Server /server/bmc/kmip/kmip-server *# <b>set</b> <i>kmip-server</i> | Sets the KMIP server ID.                         |
| <b>Step 7</b> | Server /server/bmc/kmip/kmip-server # <b>set</b> <i>kmip-timeout</i> | Sets the KMIP server timeout.                    |
| <b>Step 8</b> | Server /server/bmc/kmip/kmip-server # <b>commit</b>                  | Commits the transaction to system configuration. |
| <b>Step 9</b> | (Optional) Server /server/bmc/kmip/kmip-server # <b>show detail</b>  | Displays the KMIP server details.                |

**Example**

This example tests the KMIP server connection:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # scope kmip-server 1
Server /server/bmc/kmip/kmip-server # set kmip-port 5696
Server /server/bmc/kmip/kmip-server * # set kmip-server kmipserver.com
Server /server/bmc/kmip/kmip-server * # set kmip-timeout 10
Server /server/bmc/kmip/kmip-server * # commit
```

```

Server /server/bmc/kmip/kmip-server # show detail
Server number 1:
 Server domain name or IP address: kmipserver.com
 Port: 5696
 Timeout: 10
Server /server/bmc/kmip/kmip-server #

```

## Downloading a KMIP Client Certificate

### Before you begin

You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server # **scope bmc**
3. Server /server/bmc # **scope kmip**
4. Server /server/bmc/kmip # **set enabled yes**
5. Server /server/bmc/kmip \*# **commit**
6. Server /server/bmc/kmip # **scope kmip-client-certificate**
7. Server /server/bmc/kmip/kmip-client-certificate # **download-client-certificate** *remote-protocol IP Address*  
*KMIP client certificate file*
8. At the confirmation prompt, enter **y**.
9. (Optional) Server /server/bmc/kmip/kmip-client-certificate # **paste-client-certificate**

### DETAILED STEPS

|               | Command or Action                                                                                                                                                | Purpose                                                                                                                                                                                          |
|---------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}                                                                                                                             | Enters server command mode of server 1 or 2.                                                                                                                                                     |
| <b>Step 2</b> | Server /server # <b>scope bmc</b>                                                                                                                                | Enters bmc command mode.                                                                                                                                                                         |
| <b>Step 3</b> | Server /server/bmc # <b>scope kmip</b>                                                                                                                           | Enters the KMIP command mode.                                                                                                                                                                    |
| <b>Step 4</b> | Server /server/bmc/kmip # <b>set enabled yes</b>                                                                                                                 | Enables KMIP.                                                                                                                                                                                    |
| <b>Step 5</b> | Server /server/bmc/kmip *# <b>commit</b>                                                                                                                         | Commits the transaction to the system configuration.                                                                                                                                             |
| <b>Step 6</b> | Server /server/bmc/kmip # <b>scope kmip-client-certificate</b>                                                                                                   | Enters the KMIP client certificate command mode.                                                                                                                                                 |
| <b>Step 7</b> | Server /server/bmc/kmip/kmip-client-certificate #<br><b>download-client-certificate</b> <i>remote-protocol IP Address</i><br><i>KMIP client certificate file</i> | Specifies the protocol to connect to the remote server. It can be of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> </ul> |

|               | Command or Action                                                                            | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|---------------|----------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                                                              | <p>• HTTP</p> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> |
| <b>Step 8</b> | At the confirmation prompt, enter y.                                                         | This begins the download of the KMIP client certificate.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Step 9</b> | (Optional) Server /server/bmc/kmip/kmip-client-certificate # <b>paste-client-certificate</b> | <p>At the prompt, paste the content of the signed certificate and press <b>CTRL+D</b>.</p> <p><b>Note</b> You can either use the remote server method from the previous steps or use the paste option to download the client certificate.</p>                                                                                                                                                                                                                                                                                                                                                                                                                        |

**Example**

This example downloads the KMIP client certificate:

```

Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # set enabled yes
Server /server/bmc/kmip *# commit
Server /server/bmc/kmip # scope kmip-client-certificate
Server /server/bmc/kmip/kmip-client-certificate # show detail
 KMIP client certificate Available: 1
 Download client certificate Status: COMPLETED
 Export client certificate Status: NONE
Server /server/bmc/kmip/kmip-client-certificate # download-client-certificate tftp
10.10.10.10 KmipCertificates/
svbu-xx-blr-dn1-13_ClientCert.pem
 You are going to overwrite the KMIP client certificate.
 Are you sure you want to proceed and overwrite the KMIP client certificate? [y|N]y
KMIP client certificate downloaded successfully

```

You can either use the remote server method from the previous steps or use the paste option to download the client certificate.

```

Server /server/bmc/kmip/kmip-client-certificate # paste-client-certificate
Please paste your certificate here, when finished, press CTRL+D.

```

```

-----BEGIN CERTIFICATE-----
MIIDTzCCAjegAwIBAgIQXuWpDbbyTb5M7/FT8aAjZTANBgkqhkiG9w0BAQUFADA6
MRMwEQYKCZImiZPyLGBGRYDY29tMRMwEQYKCZImiZPyLGBGRYDbmV3MQ4wDAYD
VQODEwVuZkdDQTAeFw0xNTAzMTIxMTM5MTZaFw0yMDAzMTIxMTQ5MTVaMDoxeZAR
BgoJkiaJk/IsZAEZFgNjb20xEzARBgoJkiaJk/IsZAEZFgNuZXcxZjAMBGNVBAMT
BW5ld0NBMIIBIjANBgkqhkiG9w0BAQEFAAOCAQ8AMIIBCgKCAQEAuPSAwHtk0IbM
Cd5tYdCa498bfX5Nfdgnq5ze+cGIOqv0dAkucofC/Y0+m7hne9H12aQ9SqtOK1+L
5IT3PVCczhasI7L7jAa+Oe5AOYw7Nsugw5Bd23n42BTVMmp7xsgr1mVfFoHXbBkQ
wiT9DieyImSyGiq5n0/8Iooc0iN5WPMVcHO2ys76jR8p07xRqgYNC16cbKAhWfZ
oYIwjhpZv0+SXES8seEJZKDUhWIfOIpnDL7MoZYgl/kymgs/0hsW4L338jy303c7T
TwnG2/7BOMK0YFkEhqcj1kamGP7MKB2T9e/Cug6VkvFskkim8M1eHx1gEnQxRtAG
YGp1n55iHQIDAQABo1EwTzALBGNVHQ8EBAMCAYYwDwYDVR0TAQH/BAUwAwEB/zAd
BgNVHQ4EFgQU12F3U7cggzCuvRWliZWg91n51ccwEAYJKwYBBAGCNxUBBAMCAQAw
DQYJKoZIhvcNAQEFBQADggEBAJXoJUDD3QH0q8VY8G/oC1SkAwyoE1dH0NdxFES
tNqQMTaRB2Sb2L/ZzAtfIaZ0Xab9Ig4MqNIMBbHDCw1zhd5gX42GPYWhA/GjRj30
Q5KcRaEFomxp+twRrJ25ScVSczKJaRonWqKDVl9TwoSuDar3ObiS9ZC0KuBBf0vu
dzrJEYY/1zz7WVPZVvvhba3VSt4LW75URTqOKBSuKO+fvGyyNHwvMPFEIEnJAKt
7Qmh02fiWhd8CxaPFIByqkvrJ96no6oBxdEcjm9n1MttF/UJcypSPH+46mRn5Az
SzgCBftYNjBPLcwbZGJkF/GpPwjD0Tc1MM08UOdqiTxR7Ts=
-----END CERTIFICATE-----

```

You are going to overwrite the KMIP Client Certificate.

Are you sure you want to proceed and overwrite the KMIP Client Certificate? [y|N]

y

Server /server/bmc/kmip/kmip-client-certificate #

## Exporting a KMIP Client Certificate

### Before you begin

- You must log in as a user with admin privileges to perform this task.
- You should have downloaded KMIP client certificate before you can export it.

### SUMMARY STEPS

- Server # **scope server** {1 | 2}
- Server /server # **scope bmc**
- Server /server/bmc # **scope kmip**
- Server /server/bmc/kmip # **scope kmip-client-certificate**
- Server /server/bmc/kmip/kmip-client-certificate # **export-client-certificate** *remote-protocol IP Address*  
*KMIP root CA Certificate file*
- (Optional) Server /server/bmc/kmip/kmip-client-certificate # **show detail**

### DETAILED STEPS

|               | Command or Action                      | Purpose                                      |
|---------------|----------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}   | Enters server command mode of server 1 or 2. |
| <b>Step 2</b> | Server /server # <b>scope bmc</b>      | Enters bmc command mode.                     |
| <b>Step 3</b> | Server /server/bmc # <b>scope kmip</b> | Enters the KMIP command mode.                |

|        | Command or Action                                                                                                                                      | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|--------|--------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 4 | Server /server/bmc/kmip # <b>scope kmip-client-certificate</b>                                                                                         | Enters the KMIP client certificate command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Step 5 | Server /server/bmc/kmip/kmip-client-certificate #<br><b>export-client-certificate</b> <i>remote-protocol IP Addresss KMIP root CA Certificate file</i> | <p>Specifies the protocol to connect to the remote server. It can be of the following types:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p>Initiates the export of the certificate.</p> |
| Step 6 | (Optional) Server /server/bmc/kmip/kmip-client-certificate # <b>show detail</b>                                                                        | Displays the status of the certificate export.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

**Example**

This example exports the KMIP client certificate:

```

Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # scope kmip-client-certificate
Server /server/bmc/kmip/kmip-client-certificate # export-client-certificate ftp 10.10.10.10
/TFTP_DIR/KmipCertificates
/svbu-xx-blr-dn1-13_ClientCert.pem_exported_ftp
Username: username
Password:
KMIP Client Certificate exported successfully
Server /server/bmc/kmip/kmip-client-certificate # show detail
 KMIP Client Certificate Available: 1
 Download KMIP Client Certificate Status: COMPLETED

```

```
Export KMIP Client Certificate Status: COMPLETED
Server /server/bmc/kmip/kmip-client-certificate #
```

## Deleting a KMIP Client Certificate

### Before you begin

You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope server {1 | 2}**
2. Server /server # **scope bmc**
3. Server /server/bmc # **scope kmip**
4. Server /server/bmc/kmip # **scope kmip-client-certificate**
5. Server /server/bmc/kmip/kmip-client-certificate # **delete-client-certificate**
6. At the confirmation prompt, enter **y**.

### DETAILED STEPS

|               | Command or Action                                                                     | Purpose                                                  |
|---------------|---------------------------------------------------------------------------------------|----------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server {1   2}</b>                                                  | Enters server command mode of server 1 or 2.             |
| <b>Step 2</b> | Server /server # <b>scope bmc</b>                                                     | Enters bmc command mode.                                 |
| <b>Step 3</b> | Server /server/bmc # <b>scope kmip</b>                                                | Enters the KMIP command mode.                            |
| <b>Step 4</b> | Server /server/bmc/kmip # <b>scope kmip-client-certificate</b>                        | Enters the KMIP client certificate binding command mode. |
| <b>Step 5</b> | Server /server/bmc/kmip/kmip-client-certificate #<br><b>delete-client-certificate</b> | Confirmation prompt appears.                             |
| <b>Step 6</b> | At the confirmation prompt, enter <b>y</b> .                                          | This deletes the KMIP client certificate.                |

### Example

This example deletes the KMIP client certificate:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # scope kmip-client-certificate
Server /server/bmc/kmip/kmip-client-certificate # delete-client-certificate
 You are going to delete the KMIP Client Certificate.
 Are you sure you want to proceed and delete the KMIP Client Certificate? [y|N]y
 KMIP Client Certificate deleted successfully.
```

## Downloading a KMIP Client Private Key

### Before you begin

You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server # **scope bmc**
3. Server /server/bmc # **scope kmip**
4. Server /server/bmc/kmip # **set enabled yes**
5. Server /server/bmc/kmip \*# **commit**
6. Server /server/bmc/kmip # **scope kmip-client-private-key**
7. Server /server/bmc/kmip/kmip-client-private-key # **download-client-pvt-key** *remote-protocol IP Address*  
*KMIP client private key file*
8. At the confirmation prompt, enter **y**.
9. (Optional) Server /server/bmc/kmip/kmip-client-private-key # **paste-client-pvt-key**

### DETAILED STEPS

|               | Command or Action                                                                                                                                         | Purpose                                                                                                                                                                                                          |
|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}                                                                                                                      | Enters server command mode of server 1 or 2.                                                                                                                                                                     |
| <b>Step 2</b> | Server /server # <b>scope bmc</b>                                                                                                                         | Enters bmc command mode.                                                                                                                                                                                         |
| <b>Step 3</b> | Server /server/bmc # <b>scope kmip</b>                                                                                                                    | Enters the KMIP command mode.                                                                                                                                                                                    |
| <b>Step 4</b> | Server /server/bmc/kmip # <b>set enabled yes</b>                                                                                                          | Enables KMIP.                                                                                                                                                                                                    |
| <b>Step 5</b> | Server /server/bmc/kmip *# <b>commit</b>                                                                                                                  | Commits the transaction to the system configuration.                                                                                                                                                             |
| <b>Step 6</b> | Server /server/bmc/kmip # <b>scope kmip-client-private-key</b>                                                                                            | Enters the KMIP client private key command mode.                                                                                                                                                                 |
| <b>Step 7</b> | Server /server/bmc/kmip/kmip-client-private-key # <b>download-client-pvt-key</b> <i>remote-protocol IP Address</i><br><i>KMIP client private key file</i> | Specifies the protocol to connect to the remote server. It can be of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> |

|               | Command or Action                                                                        | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|---------------|------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                                                          | <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> |
| <b>Step 8</b> | At the confirmation prompt, enter <b>y</b> .                                             | This begins the download of the KMIP client private key.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Step 9</b> | (Optional) Server /server/bmc/kmip/kmip-client-private-key # <b>paste-client-pvt-key</b> | <p>At the prompt, paste the content of the private key and press <b>CTRL+D</b>.</p> <p><b>Note</b> You can either use the remote server method from the previous steps or use the paste option to download the client private key.</p>                                                                                                                                                                                                                                                                                                                                                                                                                 |

### Example

This example downloads the KMIP client private key:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # set enabled yes
Server /server/bmc/kmip *# commit
Server /server/bmc/kmip # scope kmip-client-private-key
Server /server/bmc/kmip/kmip-client-private-key # show detail
 KMIP Client Private Key Available: 1
 Download Client Private Key Status: COMPLETED
 Export Client Private Key Status: NONE
Server /server/bmc/kmip/kmip-client-private-key # download-client-pvt-key tftp 10.10.10.10
 KmipCertificates/
 svbu-xx-blr-dn1-13_ClientPvtKey.pem
 You are going to overwrite the KMIP Client Private Key.
 Are you sure you want to proceed and overwrite the KMIP Client Private Key? [y|N]y
 KMIP Client Private Key downloaded successfully
```

You can either use the remote server method from the previous steps or use the paste option to download the client certificate.

```
Server /server/bmc/kmip/kmip-client-private-key # paste-client-pvt-key
Please paste your client private here, when finished, press CTRL+D.
----BEGIN CERTIFICATE-----
MIIDTzCCAjegAwIBAgIQXuWpdBbyTb5M7/FT8aAjZTANBgkqhkiG9w0BAQUFADA6
```



```
MRMwEQYKCZImiZPyLQGGRYDY29tMRMwEQYKCZImiZPyLQGGRYDmV3MQ4wDAYD
VQQDEwVuzXZdQTAEfW0xNTAzMTIxMTM5MTZaFw0yMDAzMTIxMTQ5MTVaMDoxEzAR
BgoJkiaJk/IsZAEZFgNjb20xEzARBgoJkiaJk/IsZAEZFgNuZXcxZjAMBgNVBAMT
BW5ld0NBMIIBIjANBgkqhkiG9w0BAQEFAAOCAQ8AMIIBCgKCAQEAuPSAWhTk0IbM
Cd5tYdCa498bfX5Nfdgnq5zE+cGIOqv0dAkucocfC/Y0+m7hne9H12aQ9SQTOK1+L
5IT3PVCczhasI7L7jAa+Oe5AOYw7Nsugw5Bd23n42BTVMmp7xsgr1mVfFoHXbBkQ
wiT9DieyImSyGi5n0/8Iooc0iN5WPMVcHO2ys76jR8p07xRggYnc16cbKAhWfZ
oYIwJhpZv0+SXE8sEJZKDUhWIFoIpnDL7MoZYgl/kymgs/0hsW4L338jy303c7T
TwnG2/7BOMK0YFkEhqcjlkamGP7MKB2T9e/Cug6VkvFskkim8M1eHx1gEnQxRtAG
Ygp1n55iHQIDAQABo1EwTzALBgNVHQ8EBAMCAYYwDwYDVR0TAQH/BAUwAwEB/zAd
BgNVHQ4EFgQU12F3U7cggzCuvRWLiZWg91n5lccwEAYJKwYBBAGCNxUBBAMCAQAw
DQYJKoZIhvcNAQEFBQADggEBAJXoJJDDDB3QH0q8VY8G/oc1SkAwyOE1dH0NdxFES
tNqQMTaRB2Sb2L/ZzAtfIaZ0Xab9Ig4MqNIMBbHDCw1zhD5gX42GPYWhA/Gjrj30
Q5KcRaEFomxp+twRrJ25ScVSczKJaRonWqKDVl9TwoSuDar30biS9ZC0KuBBf0vu
dzrJEYY/1z7WVPZVYevhba3Vst4LW75URTqOKBSuKo+fvGyyNHwvMPFEIEEnJAKt
7Qmh02fiWhD8CxaPFIBYqkvrJ96no6oBxdEcm9n1MttF/UJcypSPH+46mRn5Az
SzgCBftYNjBPLcwbZGJkF/GpPwjD0TclMM08UOdqiTxR7Ts=
-----END CERTIFICATE-----
You are going to overwrite the KMIP client private key.
Are you sure you want to proceed and overwrite the KMIP Client Private Key? [y|N]
y
Server /server/bmc/kmip/kmip-client-private-key #
```

## Exporting KMIP Client Private Key

### Before you begin

- You must log in as a user with admin privileges to perform this task.
- You should have downloaded KMIP client private key before you can export it.

### SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server # **scope bmc**
3. Server /server/bmc # **scope kmip**
4. Server /server/bmc/kmip # **scope kmip-client-private-key**
5. Server /server/bmc/kmip/kmip-client-private-key # **export-client-pvt-key** *remote-protocol IP Addresss KMIP root CA Certificate file*
6. (Optional) Server /server/bmc/kmip/kmip-client-private-key # **show detail**

### DETAILED STEPS

|               | Command or Action                                              | Purpose                                          |
|---------------|----------------------------------------------------------------|--------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}                           | Enters server command mode of server 1 or 2.     |
| <b>Step 2</b> | Server /server # <b>scope bmc</b>                              | Enters bmc command mode.                         |
| <b>Step 3</b> | Server /server/bmc # <b>scope kmip</b>                         | Enters the KMIP command mode.                    |
| <b>Step 4</b> | Server /server/bmc/kmip # <b>scope kmip-client-private-key</b> | Enters the KMIP client private key command mode. |

|               | Command or Action                                                                                                                             | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 5</b> | Server /server/bmc/kmip/kmip-client-private-key #<br><b>export-client-pvt-key</b> remote-protocol IP Address KMIP<br>root CA Certificate file | <p>Specifies the protocol to connect to the remote server. It can be of the following types:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p>Initiates the export of the certificate.</p> |
| <b>Step 6</b> | (Optional) Server /server/bmc/kmip/kmip-client-private-key<br># <b>show detail</b>                                                            | Displays the status of the certificate export.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

### Example

This example exports the KMIP client private key:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # scope kmip-client-private-key
Server /server/bmc/kmip/kmip-client-private-key # export-client-pvt-key tftp 10.10.10.10
KmpCertificates
/svbu-xx-blr-dn1-13_ClientPvtKey.pem_exported_tftp
KMIP Client Private Key exported successfully
Server /server/bmc/kmip/kmip-client-private-key # show detail
 KMIP Client Private Key Available: 1
 Download Client Private Key Status: COMPLETED
 Export Client Private Key Status: COMPLETED
Server /server/bmc/kmip/kmip-client-private-key #
```

## Deleting a KMIP Client Private Key

### Before you begin

You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope server {1 | 2}**
2. Server /server # **scope bmc**
3. Server /server/bmc # **scope kmip**
4. Server /server/bmc/kmip # **scope kmip-client-private-key**
5. Server /server/bmc//kmip/kmip-client-private-key # **delete-client-pvt-key**
6. At the confirmation prompt, enter **y**.

### DETAILED STEPS

|               | Command or Action                                                               | Purpose                                                  |
|---------------|---------------------------------------------------------------------------------|----------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server {1   2}</b>                                            | Enters server command mode of server 1 or 2.             |
| <b>Step 2</b> | Server /server # <b>scope bmc</b>                                               | Enters bmc command mode.                                 |
| <b>Step 3</b> | Server /server/bmc # <b>scope kmip</b>                                          | Enters the KMIP command mode.                            |
| <b>Step 4</b> | Server /server/bmc/kmip # <b>scope kmip-client-private-key</b>                  | Enters the KMIP client private key binding command mode. |
| <b>Step 5</b> | Server /server/bmc//kmip/kmip-client-private-key # <b>delete-client-pvt-key</b> | Confirmation prompt appears.                             |
| <b>Step 6</b> | At the confirmation prompt, enter <b>y</b> .                                    | This deletes the KMIP client private key.                |

### Example

This example deletes the KMIP client private key:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # scope kmip-client-private-key
Server /server/bmc/kmip/kmip-client-private-key # delete-client-pvt-key
 You are going to delete the KMIP client private key.
 Are you sure you want to proceed and delete the KMIP client private key? [y|N]y
 KMIP client private key deleted successfully.
```

## Downloading a KMIP Root CA Certificate

### Before you begin

You must log in as a user with admin privileges to perform this task.

**SUMMARY STEPS**

1. Server # **scope server {1 | 2}**
2. Server /server # **scope bmc**
3. Server /server/bmc # **scope kmip**
4. Server /server/bmc/kmip # **set enabled yes**
5. Server /server/bmc/kmip \* # **commit**
6. Server server/bmc/kmip # **scope kmip-root-ca-certificate**
7. Server server/bmc/kmip/kmip-root-ca-certificate # **download-root-ca-certificate** *remote-protocol IP Address KMIP CA Certificate file*
8. At the confirmation prompt, enter **y**.
9. (Optional) Server server/bmc/kmip/kmip-root-ca-certificate # **paste-root-ca-certificate**

**DETAILED STEPS**

|               | <b>Command or Action</b>                                                                                                                                | <b>Purpose</b>                                                                                                                                                                                                   |
|---------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server {1   2}</b>                                                                                                                    | Enters server command mode of server 1 or 2.                                                                                                                                                                     |
| <b>Step 2</b> | Server /server # <b>scope bmc</b>                                                                                                                       | Enters bmc command mode.                                                                                                                                                                                         |
| <b>Step 3</b> | Server /server/bmc # <b>scope kmip</b>                                                                                                                  | Enters the KMIP command mode.                                                                                                                                                                                    |
| <b>Step 4</b> | Server /server/bmc/kmip # <b>set enabled yes</b>                                                                                                        | Enables KMIP.                                                                                                                                                                                                    |
| <b>Step 5</b> | Server /server/bmc/kmip * # <b>commit</b>                                                                                                               | Commits the transaction to the system configuration.                                                                                                                                                             |
| <b>Step 6</b> | Server server/bmc/kmip # <b>scope kmip-root-ca-certificate</b>                                                                                          | Enters the KMIP root CA certificate command mode.                                                                                                                                                                |
| <b>Step 7</b> | Server server/bmc/kmip/kmip-root-ca-certificate #<br><b>download-root-ca-certificate</b> <i>remote-protocol IP Address<br/>KMIP CA Certificate file</i> | Specifies the protocol to connect to the remote server. It can be of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> |

|               | Command or Action                                                                             | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|---------------|-----------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                                                               | <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> |
| <b>Step 8</b> | At the confirmation prompt, enter <b>y</b> .                                                  | This begins the download of the KMIP root CA certificate.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Step 9</b> | (Optional) Server server/bmc/kmip/kmip-root-ca-certificate # <b>paste-root-ca-certificate</b> | <p>At the prompt, paste the content of the root CA certificate and press <b>CTRL+D</b>.</p> <p><b>Note</b> You can either use the remote server method from the previous steps or use the paste option to download the root CA certificate.</p>                                                                                                                                                                                                                                                                                                                                                                                                        |

**Example**

This example downloads the KMIP root CA certificate:

```

Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # set enabled yes
Server /server/bmc/kmip *# commit
Server /server/bmc/kmip # scope kmip-root-ca-certificate
Server /server/bmc/kmip/kmip-root-ca-certificate # show detail
 KMIP Root CA Certificate Available: 1
 Download Root CA Certificate Status: COMPLETED
 Export Root CA Certificate Status: NONE
Server /server/bmc/kmip/kmip-root-ca-certificate # download-root-ca-certificate tftp
10.10.10.10 KmipCertificates/
svbu-xx-blr-dn1-13_ServerCert.pem
 You are going to overwrite the KMIP Root CA Certificate.
 Are you sure you want to proceed and overwrite the KMIP Root CA Certificate? [y|N]y
KMIP Root CA Certificate downloaded successfully

```

You can either use the remote server method from the previous steps or use the paste option to download the client certificate.

```

Server /server/bmc/kmip/kmip-root-ca-certificate # paste-root-ca-certificate
Please paste your certificate here, when finished, press CTRL+D.
----BEGIN CERTIFICATE-----
MIIDTzCCAjegAwIBAgIQXuWpdBbyTb5M7/FT8aAjZTANBgkqhkiG9w0BAQUFADA6

```

```
MRMwEQYKCZImiZPyLQGGRYDY29tMRMwEQYKCZImiZPyLQGGRYDbmV3MQ4wDAYD
VQQDEwVuZXZkdQTAeFw0xNTAzMTIxMTM5MTZaFw0yMDAzMTEyMTQ5MTVaMDoxEzAR
BgoJkiaJk/IsZAEZFgNjb20xEzARBgoJkiaJk/IsZAEZFgNuZXcxZjAMBGNVBAMT
BW5ld0NBMIIBIjANBgkqhkiG9w0BAQEFAAOCAQ8AMIIBCgKCAQEaUwPSAwHtk0IbM
Cd5tYdCa498bfX5Nfdgnq5zE+cGIOqv0dAkucocF/Y0+m7hne9H12aQ9SqtOK1+L
5IT3PVCczhasI7L7jAa+Oe5AOYw7Nsugw5Bd23n42BTVMmp7xsgr1mVfFoHXbBkQ
wiT9DIEyImSyGiq5n0/8Iooc0iN5WPMVcHO2ysz76jR8p07xRqgYnc16cbKAHwFz
oYIwjhpZv0+SXEs8sEJZKDUhWIFoIpnDL7MoZYgl/kymgs/0hsW4L338jy303c7T
TwnG2/7BOMK0YFkEhqcjlkamGP7MKB2T9e/Cug6VkvFSkKim8M1eHx1gEnQxRtAG
YGp1n55iHQIDAQABo1EwTzALBgNVHQ8EBAMCAYYwDwYDVR0TAQH/BAUwAwEB/zAd
BgNVHQ4EFgQU12F3U7cggzCuvRWliZWg91n51ccwEAYJKwYBBAGCNxUBBAMCAQAw
DQYJKoZIhvcNAQEFBQADggEBAJXoJJDB3QH0q8VY8G/oc1SkAwYOE1dH0NdxFES
tNqQMTARb2Sb2L/ZzAtfIaz0Xab9Ig4MqNIMbbHDCw1zhD5gX42GPYWhA/GjRj30
Q5KcRaEFomxp+twRrJ25ScVSczKJaRonWqKDVl9TwsuDar3ObiS9ZCOKuBBf0vu
dzrJEYY/1zz7WVPZVYevhba3VSt4LW75URTqOKBSuKO+fvGyyNHwvMPFEIEEnJAKt
7QmhO2fiWhD8CxaPFIBYqkvrJ96no6oBxdEcjm9n1MttF/UJcypySPH+46mRn5Az
SzgCBftYNjBPLcwbZGJkF/GpPwjD0TclMM08UOdqiTxR7Ts=
-----END CERTIFICATE-----
```

You are going to overwrite the KMIP Root CA Certificate.

Are you sure you want to proceed and overwrite the KMIP Root CA Certificate? [y|N]

```
y
Server /server/bmc/knip/knip-root-ca-certificate #
```

## Exporting a KMIP Root CA Certificate

### Before you begin

- You must log in as a user with admin privileges to perform this task.
- You should have downloaded KMIP root CA certificate before you can export it.

### SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server # **scope bmc**
3. Server /server/bmc # **scope knip**
4. Server /server/bmc/knip # **scope knip-root-ca-certificate**
5. Server /server/bmc/knip/knip-root-ca-certificate # **export-root-ca-certificate** *remote-protocol IP Address*  
*KMIP root CA Certificate file*
6. (Optional) Server /server/bmc/knip/knip-root-ca-certificate # **show detail**

### DETAILED STEPS

|               | Command or Action                                               | Purpose                                           |
|---------------|-----------------------------------------------------------------|---------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}                            | Enters server command mode of server 1 or 2.      |
| <b>Step 2</b> | Server /server # <b>scope bmc</b>                               | Enters bmc command mode.                          |
| <b>Step 3</b> | Server /server/bmc # <b>scope knip</b>                          | Enters the KMIP command mode.                     |
| <b>Step 4</b> | Server /server/bmc/knip # <b>scope knip-root-ca-certificate</b> | Enters the KMIP root CA certificate command mode. |

|        | Command or Action                                                                                                                                        | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 5 | <pre>Server /server/bmc/kmip/kmip-root-ca-certificate # <b>export-root-ca-certificate</b> remote-protocol IP Address KMIP root CA Certificate file</pre> | <p>Specifies the protocol to connect to the remote server. It can be of the following types:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p>Initiates the export of the certificate.</p> |
| Step 6 | <pre>(Optional) Server /server/bmc/kmip/kmip-root-ca-certificate # <b>show detail</b></pre>                                                              | <p>Displays the status of the certificate export.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

**Example**

This example exports the KMIP root CA certificate:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /server/bmc/kmip # scope kmip-root-ca-certificate
Server /server/bmc/kmip/kmip-root-ca-certificate # export-root-ca-certificate tftp
10.10.10.10 KmipCertificates/
svbu-xx-blr-dn1-13_ServerCert.pem_exported_tftp
KMIP Root CA Certificate exported successfully
Server /server/bmc/kmip/kmip-root-ca-certificate # show detail
 KMIP Root CA Certificate Available: 1
 Download Root CA Certificate Status: COMPLETED
 Export Root CA Certificate Status: COMPLETED
Server /server/bmc/kmip/kmip-root-ca-certificate #
```

## Deleting a KMIP Root CA Certificate

### Before you begin

You must log in as a user with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server # **scope bmc**
3. Server /server/bmc # **scope kmip**
4. Server /server/bmc/kmip # **scope kmip-root-ca-certificate**
5. Server /server/bmc/kmip/kmip-root-ca-certificate # **delete-root-ca-certificate**
6. At the confirmation prompt, enter **y**.

### DETAILED STEPS

|               | Command or Action                                                                    | Purpose                                                   |
|---------------|--------------------------------------------------------------------------------------|-----------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}                                                 | Enters server command mode of server 1 or 2.              |
| <b>Step 2</b> | Server /server # <b>scope bmc</b>                                                    | Enters bmc command mode.                                  |
| <b>Step 3</b> | Server /server/bmc # <b>scope kmip</b>                                               | Enters the KMIP command mode.                             |
| <b>Step 4</b> | Server /server/bmc/kmip # <b>scope kmip-root-ca-certificate</b>                      | Enters the KMIP root CA certificate binding command mode. |
| <b>Step 5</b> | Server /server/bmc/kmip/kmip-root-ca-certificate # <b>delete-root-ca-certificate</b> | Confirmation prompt appears.                              |
| <b>Step 6</b> | At the confirmation prompt, enter <b>y</b> .                                         | This deletes the KMIP root CA certificate.                |

### Example

This example deletes the KMIP root CA certificate:

```
Server # scope server 1
Server /server # scope bmc
Server /server/bmc # scope kmip
Server /kmip # scope kmip-root-ca-certificate
Server /kmip/kmip-root-ca-certificate # delete-root-ca-certificate
 You are going to delete the KMIP root CA certificate.
 Are you sure you want to proceed and delete the KMIP root CA certificate? [y|N]y
 KMIP root CA certificate deleted successfully.
```

## FIPS 140-2 Compliance in Cisco IMC

The Federal Information Processing Standard (FIPS) Publication 140-2, (FIPS PUB 140-2), is a U.S. government computer security standard used to approve cryptographic modules. Prior to the 3.1(3) release, the Rack Cisco IMC is not FIPS compliant as per NIST guideline. It does not follow FIPS 140-2 approved cryptographic



algorithms and modules. With this release, all CIMC services will use the Cisco FIPS Object Module (FOM), which provides the FIPS 140-2 compliant cryptographic module.

The Cisco FIPS Object Module is a software library that provides cryptographic services to a vast array of Cisco's networking and collaboration products. The module provides FIPS 140 validated cryptographic algorithms and KDF functionality for services such as IPSec (IKE), SRTP, SSH, TLS, and SNMP.

## Enabling Security Configuration

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server # **scope cimc**
2. Server /cimc # **scope security-configuration**
3. Server /chassis/security-configuration # **set fips enabled** or **disabled**
4. Server /chassis/security-configuration\* # **commit**
5. Server /chassis/security-configuration # **set cc enabled** or **disabled**
6. Server /chassis/security-configuration\* # **commit**

### DETAILED STEPS

|               | Command or Action                                                                   | Purpose                                                                                                                                                                                                                  |
|---------------|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope cimc</b>                                                          | Enters the Cisco IMC command mode.                                                                                                                                                                                       |
| <b>Step 2</b> | Server /cimc # <b>scope security-configuration</b>                                  | Enters the security configuration command mode.                                                                                                                                                                          |
| <b>Step 3</b> | Server /chassis/security-configuration # <b>set fips enabled</b> or <b>disabled</b> | If you choose enabled, it enables FIPS.                                                                                                                                                                                  |
| <b>Step 4</b> | Server /chassis/security-configuration* # <b>commit</b>                             | Enter <b>y</b> at the warning prompt to enable FIPS and commit the transaction to the system.<br><br><b>Note</b> When you switch the FIPS mode, it restarts the SSH, KVM, SNMP, webserver, XMLAPI, and redfish services. |

|               | Command or Action                                                                 | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|---------------|-----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                                                   | <p><b>Note</b> When you enable FIPS, or both FIPS and CC, the following SNMP configuration changes occur:</p> <ul style="list-style-type: none"> <li>• The community string configuration for the SNMPv2 protocols, and the SNMPv3 users configured with <b>noAuthNoPriv</b> or <b>authNoPriv</b> security-level option are disabled.</li> <li>• The traps configured for SNMPv2 or SNMPv3 users with the <b>noAuthNoPriv</b> security-level option are disabled.</li> <li>• The <b>MD5</b> and <b>DES</b> Authentication type and Privacy type are disabled.</li> <li>• It also ensures only FIPS-compliant ciphers in SSH, webserver, and KVM connections.</li> </ul>                                                                                                                                                                                                                                 |
| <b>Step 5</b> | Server /chassis/security-configuration # <b>set cc enabled</b> or <b>disabled</b> | <p><b>Note</b> FIPS must be in enabled state to enable CC.</p> <p>If you choose enabled, it enables CC.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Step 6</b> | Server /chassis/security-configuration* # <b>commit</b>                           | <p>Enter <b>y</b> at the warning prompt to enable FIPS and commit the transaction to the system.</p> <p><b>Note</b> When you switch the FIPS mode, it restarts the SSH, KVM, SNMP, webserver, XMLAPI, and redfish services.</p> <p><b>Note</b> When you enable FIPS, or both FIPS and CC, the following SNMP configuration changes occur:</p> <ul style="list-style-type: none"> <li>• The community string configuration for the SNMPv2 protocols, and the SNMPv3 users configured with <b>noAuthNoPriv</b> or <b>authNoPriv</b> security-level option are disabled.</li> <li>• The traps configured for SNMPv2 or SNMPv3 users with the <b>noAuthNoPriv</b> security-level option are disabled.</li> <li>• The <b>MD5</b> and <b>DES</b> Authentication type and Privacy type are disabled.</li> <li>• It also ensures only FIPS-compliant ciphers in SSH, webserver, and KVM connections.</li> </ul> |

## Example

This example shows how to view the controller information:

```
Server# scope cimc
Server /cimc # scope security-configuration
Server /cimc/security-configuration # set fips enabled
Enabling FIPS would
1. Disables support for SNMP V2 and V3 with No 'Auth/Priv' security level.
2. Disables support for 'MD5/DES' crypto algorithms in SNMP 'Auth/Priv' keys.
3. Ensures use of only FIPS-compliant ciphers in SSH, webserver and KVM connections.
Server /cimc/security-configuration* # commit
Server/cimc/security-configuration # set cc enabled
Enabling Common Criteria
Server /cimc/security-configuration* # commit
Warning: changing "fips" or "CC" will restart SSH, KVM, SNMP, webserver, XMLAPI and redfish
services.
Do you wish to continue? [y/N] y
Server /cimc/security-configuration #
```





# CHAPTER 14

## Configuring Platform Event Filters

This chapter includes the following sections:

- [Platform Event Filters, on page 329](#)
- [Configuring Platform Event Filters, on page 329](#)

### Platform Event Filters

### Configuring Platform Event Filters

You can configure actions and alerts for the following platform event filters:

#### SUMMARY STEPS

1. Server# **scope fault**
2. Server /fault # **scope pef id**
3. Server /fault/pef # **set action {none | reboot | power-cycle | power-off}**
4. Server /fault/pef # **commit**

#### DETAILED STEPS

|               | Command or Action                                                               | Purpose                                                                                                                                                                                                                                                                                                |
|---------------|---------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope fault</b>                                                      | Enters the fault command mode.                                                                                                                                                                                                                                                                         |
| <b>Step 2</b> | Server /fault # <b>scope pef id</b>                                             | Enters the platform event filter command mode for the specified event.<br>See the Platform Event Filter table for event ID numbers.                                                                                                                                                                    |
| <b>Step 3</b> | Server /fault/pef # <b>set action {none   reboot   power-cycle   power-off}</b> | Selects the desired system action when this event occurs. The action can be one of the following: <ul style="list-style-type: none"><li>• <b>none</b> —No system action is taken.</li><li>• <b>reboot</b> —The server is rebooted.</li><li>• <b>power-cycle</b> —The server is power cycled.</li></ul> |

|               | Command or Action                 | Purpose                                                                                          |
|---------------|-----------------------------------|--------------------------------------------------------------------------------------------------|
|               |                                   | <ul style="list-style-type: none"> <li>• <b>power-off</b> —The server is powered off.</li> </ul> |
| <b>Step 4</b> | Server /fault/pef # <b>commit</b> | Commits the transaction to the system configuration.                                             |

### Example

This example configures the platform event alert for an event:

```

Server# scope fault
Server /fault # scope pef 5
Server /fault/pef # set action reboot
Server /fault/pef *# commit
Server /fault/pef # show
Platform Event Filter Event Action

5 Processor Assert Filter reboot

Server /fault/pef #

```



## CHAPTER 15

# Cisco IMC Firmware Management

---

This chapter includes the following sections:

- [Overview of Firmware, on page 331](#)
- [Obtaining Firmware from Cisco, on page 332](#)
- [Installing Cisco IMC Firmware from a Remote Server, on page 334](#)
- [Activating Installed Firmware, on page 336](#)
- [Installing BIOS Firmware from a Remote Server, on page 338](#)
- [Activating Installed BIOS Firmware, on page 339](#)
- [Canceling a Pending BIOS Activation, on page 341](#)
- [Installing CMC Firmware from a Remote Server, on page 342](#)
- [Activating Installed CMC Firmware, on page 343](#)
- [Managing SAS Expander and HDD Firmware, on page 344](#)

## Overview of Firmware

C-Series servers use Cisco-certified firmware that is specific to the C-Series server model that you are using. You can download new releases of the firmware for all supported server models from Cisco.com.



---

**Note** If you choose to update the firmware of individual components, **you must first update and activate the CMC firmware** to the version that you want to update the individual component.

---



---

**Caution** When you install the new BIOS firmware, it must be from the same software release as the firmware that is running on the server. Do not install the new BIOS firmware until after you have activated the matching firmware or the server will not boot.

To avoid potential problems, we strongly recommend that you use the Cisco Host Upgrade Utility (HUU), which upgrades the BIOS, , and other firmware to compatible levels. For detailed information about this utility, see the *Cisco Host Upgrade Utility Guide* for the version of the HUU that goes with the software release that you want to install. The HUU guides are available at the following URL:  
[http://www.cisco.com/en/US/products/ps10493/products\\_user\\_guide\\_list.html](http://www.cisco.com/en/US/products/ps10493/products_user_guide_list.html).

---

If you want to update the firmware manually, you must update the firmware first. The firmware update process is divided into the following stages to minimize the amount of time that the server is offline:

- **Installation**—During this stage, installs the selected firmware in the nonactive, or backup, slot on the server.
- **Activation**—During this stage, sets the nonactive firmware version as active, causing a disruption in service. When the server reboots, the firmware in the new active slot becomes the running version.

After you activate the firmware, you can update the BIOS firmware.



**Note**

- You can either upgrade an older firmware version to a newer one, or downgrade a newer firmware version to an older one.
- This procedure only applies to the Cisco UCS C-Series server running on Stand-Alone mode. Contact Cisco Technical Assistance Center to upgrade firmware for UCS C-Series running on Cisco UCS Manager integrated mode.

## Obtaining Firmware from Cisco

- Step 1** Navigate to <http://www.cisco.com>.
- Step 2** If you are not already logged in, click **Log In** at the top right-hand edge of the page and log in using your Cisco.com credentials.
- Step 3** In the menu bar at the top, click **Support**.
- Step 4** Click **All Downloads** in the roll down menu.
- Step 5** If your server model is listed in the **Recently Used Products** list, click the server name. Otherwise, do the following:
- In the left-hand box, click **Products**.
  - In the center box, click **Unified Computing and Servers**.
  - In the right-hand box, click **Cisco UCS C-Series Rack-Mount Standalone Server Software**.
  - In the right-hand box, click the server model whose software you want to download.
- Step 6** Click the **Unified Computing System (UCS) Server Firmware** link.
- Step 7** (Optional) Select a prior release from the menu bar on the left-hand side of the page.
- Step 8** Click the **Download** button associated with the Cisco Host Upgrade Utility ISO for the selected release.
- Step 9** Click **Accept License Agreement**.
- Step 10** Save the ISO file to a local drive.
- We recommend you upgrade the and BIOS firmware on your server using this ISO file, which contains the Cisco Host Upgrade Utility. For detailed information about this utility, see the *Cisco Host Upgrade Utility Guide* for the version of the HUU that goes with the software release that you want to install. The HUU guides are available at the following URL: [http://www.cisco.com/en/US/products/ps10493/products\\_user\\_guide\\_list.html](http://www.cisco.com/en/US/products/ps10493/products_user_guide_list.html).
- Step 11** (Optional) If you plan to upgrade the and BIOS firmware manually, do the following:



Beginning with Release 3.0, the BIOS and Cisco IMC firmware files are no longer embedded inside the HUU as a standalone .zip file. BIOS and Cisco IMC firmware must now be extracted using the **getfw** utility, which is available in the GETFW folder of the HUU. Perform the following steps to extract the BIOS or Cisco IMC firmware files:

**Note** To perform this:

- Openssl must be installed in the target system.
- Squashfs kernel module must be loaded in the target system.

**Viewing the GETFW help menu:**

```
[root@RHEL65-***** tmp]# cd GETFW/
[root@RHEL65-***** GETFW]# ./getfw -h
Help:
Usage: getfw {-b -c -C -H -S -V -h} [-s SRC] [-d DEST]
-b : Get BIOS Firmware
-c : Get CIMC Firmware
-C : Get CMC Firmware
-H : Get HDD Firmware
-S : Get SAS Firmware
-V : Get VIC Firmware
-h : Display Help
-s SRC : Source of HUU ISO image
-d DEST : Destination to keep Firmware/s
Note : Default BIOS & CIMC get extracted
```

**Extracting the BIOS firmware:**

```
[root@RHEL65-***** GETFW]# ./getfw -s /root/Desktop/HUU/ucs-c2xxx-huu-3.0.1c.iso -d /tmp/HUU
FW/s available at '/tmp/HUUucs-c2xxx-huu-3.0.1c'
[root@RHEL65-***** GETFW]# cd /tmp/HUU/
[root@RHEL65-***** HUU]# cd ucs-c2xxx-huu-3.0.1c/
[root@RHEL65-***** ucs-c2xxx-huu-3.0.1c]# ls
bios cimc
[root@RHEL65-***** ucs-c2xxx-huu-3.0.1c]# cd bios/
[root@RHEL65-***** bios]# ls
bios.cap
[root@RHEL65-***** bios]#
```

**Extracting the CIMC firmware:**

```
[root@RHEL65-***** GETFW]# ./getfw -s /root/Desktop/HUU/ucs-c2xxx-huu-3.0.1c.iso -d /tmp/HUU
FW/s available at '/tmp/HUUucs-c2xxx-huu-3.0.1c'
[root@RHEL65-***** GETFW]# cd /tmp/HUU/
[root@RHEL65-***** HUU]# cd ucs-c2xxx-huu-3.0.1c/
[root@RHEL65-***** ucs-c2xxx-huu-3.0.1c]# ls
bios cimc
[root@RHEL65-***** ucs-c2xxx-huu-3.0.1c]# cd cimc/
[root@RHEL65-***** cimc]# ls
cimc.cap
[root@RHEL65-***** cimc]#
```

**Step 12**

(Optional) If you plan to install the firmware from a remote server, copy the BIOS installation CAP file and the installation BIN file to the remote server you want to use.

The remote server can be one of the following:

- TFTP
- FTP
- SFTP

- SCP
- HTTP

The server must have read permission for the destination folder on the remote server.

**Note** The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.

If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is <server\_finger\_print\_ID> Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.

The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.

---

### What to do next

Use the Cisco Host Upgrade Utility to upgrade all firmware on the server or manually install the firmware on the server.

## Installing Cisco IMC Firmware from a Remote Server

### Before you begin

- Log in to the Cisco IMC as a user with admin privileges.
- Activate the Cisco IMC firmware that goes with the BIOS version you want to install, as described in the **Activating Installed Cisco IMC Firmware** section.
- Power off the server.




---

**Note** You must not initiate a Cisco IMC update when another Cisco IMC update is already in progress.

---

### SUMMARY STEPS

1. Server /server # **scope server** {1 | 2}
2. server /server # **scope bmc**
3. server /server/bmc # **scope firmware**
4. server /server/bmc/firmware # **update** *protocol IP Address path*
5. (Optional) server /server/bmc/firmware # **show detail**

## DETAILED STEPS

|               | Command or Action                                                    | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|---------------|----------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server /server # <b>scope server</b> {1   2}                         | Enters server command mode of server 1 or 2.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Step 2</b> | server /server # <b>scope bmc</b>                                    | Enters bmc command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Step 3</b> | server /server/bmc # <b>scope firmware</b>                           | Enters the firmware command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Step 4</b> | server /server/bmc/firmware # <b>update protocol IP Address path</b> | <p>Specifies the protocol, IP address of the remote server, and the file path to the firmware file on the server. The protocol can be one of the following:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> |
| <b>Step 5</b> | (Optional) server /server/bmc/firmware # <b>show detail</b>          | Displays the progress of the firmware update.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

**Example**

This example shows how to update the firmware:

```
server# scope server 1
server /server # scope bmc
server /server/bmc # scope firmware
server /server/bmc/firmware # update ftp 192.0.20.34 //test/dnld-ucs-k9-bundle.1.0.2h.bin
Firmware update has started.
Please check the status using "show detail"
server /server/bmc/firmware # show detail
Firmware Image Information:
 Update Stage: NONE
```

```

Update Progress: 5
Current FW Version: 2.0(6.56)
FW Image 1 Version: 2.0(6.56)
FW Image 1 State: RUNNING ACTIVATED
FW Image 2 Version: 2.0(6.55)
FW Image 2 State: BACKUP INACTIVATED
Boot-loader Version: 2.0(6.56).36
Secure Boot: ENABLED

```

```
server /server/bmc/firmware #
```

### What to do next

Activate the new firmware.

## Activating Installed Firmware

### Before you begin

Install the firmware on the server.



#### Important

While the activation is in progress, do not:

- Reset, power off, or shut down the server.
- Reboot or reset Cisco IMC.
- Activate any other firmware.
- Export technical support or configuration data.

### SUMMARY STEPS

1. Server /server # **scope server** {1 | 2}
2. server /server # **scope bmc**
3. server /server/bmc # **scope firmware**
4. Server /server/bmc/firmware # **show detail**
5. Server /server/bmc/firmware # **activate**
6. At the prompt, enter **y** to activate the selected firmware image.
7. (Optional) Log back into the CLI and repeat steps 1–4 to verify the activation.

### DETAILED STEPS

|               | Command or Action                            | Purpose                                      |
|---------------|----------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server /server # <b>scope server</b> {1   2} | Enters server command mode of server 1 or 2. |
| <b>Step 2</b> | server /server # <b>scope bmc</b>            | Enters bmc command mode.                     |

|               | Command or Action                                                               | Purpose                                                                                                           |
|---------------|---------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
| <b>Step 3</b> | server /server/bmc # <b>scope firmware</b>                                      | Enters the firmware command mode.                                                                                 |
| <b>Step 4</b> | Server /server/bmc/firmware # <b>show detail</b>                                | Displays the available firmware images and statuses.                                                              |
| <b>Step 5</b> | Server /server/bmc/firmware # <b>activate</b>                                   | Activates the selected image. If no image number is specified, the server activates the currently inactive image. |
| <b>Step 6</b> | At the prompt, enter <b>y</b> to activate the selected firmware image.          | The BMC reboots, terminating all CLI and GUI sessions until the reboot completes.                                 |
| <b>Step 7</b> | (Optional) Log back into the CLI and repeat steps 1–4 to verify the activation. |                                                                                                                   |

### Example

This example activates firmware image 2 and then verifies the activation after the BMC reboots:

```

Server# scope server 1
Server/server# scope bmc
Server /server/bmc # scope firmware
Server /server/bmc/firmware # show detail
Firmware Image Information:
 Update Stage: NONE
 Update Progress: 100
 Current FW Version: 2.0(6.55)
 FW Image 1 Version: 2.0(6.56)
 FW Image 1 State: BACKUP INACTIVATED
 FW Image 2 Version: 2.0(6.55)
 FW Image 2 State: RUNNING ACTIVATED
 Boot-loader Version: 2.0(6.55).36
 Secure Boot: ENABLED

Server /server/bmc/firmware # activate
This operation will activate firmware 1 and reboot the BMC.
Continue?[y|N]y
.
.
-- BMC reboot --
.
.
-- Log into CLI as Admin --

Server# scope server 1
Server/server# scope bmc
Server /server/bmc # scope firmware
Server /server/bmc/firmware # show detail
Firmware Image Information:
 Update Stage: NONE
 Update Progress: 100
 Current FW Version: 2.0(6.55)
 FW Image 1 Version: 2.0(6.56)
 FW Image 1 State: RUNNING ACTIVATED
 FW Image 2 Version: 2.0(6.55)
 FW Image 2 State: BACKUP INACTIVATED
 Boot-loader Version: 2.0(6.55).36
 Secure Boot: ENABLED
Server /server/bmc/firmware #

```

# Installing BIOS Firmware from a Remote Server

## Before you begin

- Log in to the Cisco IMC as a user with admin privileges.
- Activate the Cisco IMC firmware that goes with the BIOS version you want to install, as described in the **Activating Installed BIOS Firmware** section.
- Power off the server.



**Note** You must not initiate a BIOS update while another BIOS update is already in progress.

## SUMMARY STEPS

1. Server /server # **scope server** {1 | 2}
2. server /server # **scope bios**
3. server /server/bios # **update protocol IP Address pathrecovery**
4. (Optional) server /server/bios # **show detail**

## DETAILED STEPS

|               | Command or Action                                                    | Purpose                                                                                                                                                                                                                                                                         |
|---------------|----------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server /server # <b>scope server</b> {1   2}                         | Enters server command mode of server 1 or 2.                                                                                                                                                                                                                                    |
| <b>Step 2</b> | server /server # <b>scope bios</b>                                   | Enters BIOS command mode.                                                                                                                                                                                                                                                       |
| <b>Step 3</b> | server /server/bios # <b>update protocol IP Address pathrecovery</b> | Specifies the protocol, IP address of the remote server, and the file path to the firmware file on the server. The protocol can be one of the following: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> |

|               | Command or Action                                   | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|---------------|-----------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                     | <p><b>Note</b></p> <p>The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> |
| <b>Step 4</b> | (Optional) server /server/bios # <b>show detail</b> | Displays the progress of the firmware update.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

### Example

This example updates the BIOS firmware to software release 2.0(7c):

```

Server# scope server 1
Server /server# scope bios
Server /server/bios# show detail
BIOS:
 BIOS Version: server-name.2.0.7c.0.071620151216
 Backup BIOS Version: server-name.2.0.7c.0.071620151216
 Boot Order: (none)
 Boot Override Priority:
 FW Update/Recovery Status: None, OK
 UEFI Secure Boot: disabled
 Configured Boot Mode: Legacy
 Actual Boot Mode: Legacy
 Last Configured Boot Order Source: CIMC
Server /server/bios # update ftp 192.0.20.34 //upgrade_bios_files/C3620-BIOS-2-0-7c-0.CAP
<CR> Press Enter key
Firmware update has started.
Check the status using "show detail"
Server /bios #

```

## Activating Installed BIOS Firmware

### Before you begin

- Install the BIOS firmware on the server.
- Power off the host.



- Important** While the activation is in progress, do not:
- Reset, power off, or shut down the server.
  - Reboot or reset Cisco IMC.
  - Activate any other firmware.
  - Export technical support or configuration data.

## SUMMARY STEPS

1. Server /server # **scope server {1 | 2}**
2. server /server # **scope bios**
3. Server /server/bios # **activate**
4. At the prompt, enter **y** to activate the selected firmware image.

## DETAILED STEPS

|               | Command or Action                                                      | Purpose                                      |
|---------------|------------------------------------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server /server # <b>scope server {1   2}</b>                           | Enters server command mode of server 1 or 2. |
| <b>Step 2</b> | server /server # <b>scope bios</b>                                     | Enters BIOS command mode.                    |
| <b>Step 3</b> | Server /server/bios # <b>activate</b>                                  | Activates the currently inactive image.      |
| <b>Step 4</b> | At the prompt, enter <b>y</b> to activate the selected firmware image. | Initiates the activation.                    |

### Example

This example activates firmware and then verifies the activation:

```
Server# scope server 1
Server /server# scope bios
Server /server/bios# show detail
BIOS:
 BIOS Version: server-name.2.0.7c.0.071620151216
 Backup BIOS Version: server-name.2.0.7c.0.071620151216
 Boot Order: (none)
 Boot Override Priority:
 FW Update/Recovery Status: None, OK
 UEFI Secure Boot: disabled
 Configured Boot Mode: Legacy
 Actual Boot Mode: Legacy
 Last Configured Boot Order Source: CIMC

Server /server/bios # activate
This operation will activate "C240M4.2.0.2.66.071820142034" after next host power off
Continue?[y|N]

Server# scope server 1
Server /server# scope bios
```



```

Server /server/bios# show detail
BIOS:
 BIOS Version: server-name.2.0.7c.0.071620151216
 Backup BIOS Version: server-name.2.0.7c.0.071620151216
 Boot Order: (none)
 Boot Override Priority:
 FW Update/Recovery Status: None, OK
 UEFI Secure Boot: disabled
 Configured Boot Mode: Legacy
 Actual Boot Mode: Legacy
 Last Configured Boot Order Source: CIMC

```

## Canceling a Pending BIOS Activation

### Before you begin

BIOS firmware must be in pending state.

### SUMMARY STEPS

1. Server# **scope bios**
2. Server /bios # **show detail**
3. Server /bios # **cancel-activate**
4. At the prompt, enter **y** to cancel activation.

### DETAILED STEPS

|               | Command or Action                                   | Purpose                                                                                            |
|---------------|-----------------------------------------------------|----------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope bios</b>                           | Enters the BIOS command mode.                                                                      |
| <b>Step 2</b> | Server /bios # <b>show detail</b>                   | Displays the available firmware images and status.                                                 |
| <b>Step 3</b> | Server /bios # <b>cancel-activate</b>               | <b>Note</b> BIOS firmware must be in pending state.<br>Cancel the BIOS activation that is pending. |
| <b>Step 4</b> | At the prompt, enter <b>y</b> to cancel activation. |                                                                                                    |

### Example

This example cancels a pending BIOS firmware activation:

```

Server# scope bios
Server /bios # show detail
BIOS:
 BIOS Version: Cxxx.4.0.0.19.0528180450
 Backup BIOS Version: Cxxx.4.0.0.23.0612180433
 Boot Order: (none)
 FW Update Status: Done, Activation pending
 UEFI Secure Boot: disabled
 Actual Boot Mode: Uefi
 Last Configured Boot Order Source: BIOS

```

```

One time boot device: (none)
Server /bios # cancel-activate
This will cancel Pending BIOS activation[y|N]y
Server /bios # show detail
BIOS:
 BIOS Version: Cxxx.4.0.0.19.0528180450
 Backup BIOS Version: Cxxx.4.0.0.23.0612180433
 Boot Order: (none)
 FW Update Status: None, OK
 UEFI Secure Boot: disabled
 Actual Boot Mode: Uefi
 Last Configured Boot Order Source: BIOS
 One time boot device: (none)
Server /bios #

```

## Installing CMC Firmware from a Remote Server



**Note** You must not initiate a CMC update while another CMC update is already in progress.

### Before you begin

- Log in to the as a user with admin privileges.
- Obtain the Cisco Host Upgrade Utility ISO file from Cisco.com and extract the firmware installation files as described in [Obtaining Firmware from Cisco, on page 332](#).

### SUMMARY STEPS

1. server # **scope chassis**
2. server /chassis # **scope cmc 1|2**
3. server /chassis/cmc # **update protocol IP Address path**
4. (Optional) server /chassis/cmc # **show detail**

### DETAILED STEPS

|               | Command or Action                                            | Purpose                                                                                                                                                                                                                                          |
|---------------|--------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | server # <b>scope chassis</b>                                | Enters chassis command mode.                                                                                                                                                                                                                     |
| <b>Step 2</b> | server /chassis # <b>scope cmc 1 2</b>                       | Enters CMC on the chosen SIOC controller command mode.                                                                                                                                                                                           |
| <b>Step 3</b> | server /chassis/cmc # <b>update protocol IP Address path</b> | Specifies the protocol, IP address of the remote server, and the file path to the firmware file on the server. The protocol can be one of the following: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> </ul> |

|               | Command or Action                                   | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|---------------|-----------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                     | <ul style="list-style-type: none"> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> |
| <b>Step 4</b> | (Optional) server /chassis/cmc # <b>show detail</b> | Displays the progress of the firmware update.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

**Example**

This example shows how to update the CMC firmware:

**What to do next**

Activate the new firmware.

## Activating Installed CMC Firmware



**Note** CMCs are configured to have one in an active state while other acts as a backup, when you activate the backup CMC the previously active CMC changes to backup CMC activating the other.

**Before you begin**

Install the CMC firmware on the server.



- Important** While the activation is in progress, do not:
- Reset, power off, or shut down the server.
  - Reboot or reset .
  - Activate any other firmware.
  - Export technical support or configuration data.
- 
- CMC-1 activation interrupts network connectivity.

### Procedure

|               | Command or Action                                                      | Purpose                                                                                                                                   |
|---------------|------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | server # <b>scope chassis</b>                                          | Enters chassis command mode.                                                                                                              |
| <b>Step 2</b> | Server# <b>scope cmc</b>   2                                           | Enters the CMC of the chosen SIOC slot command mode.                                                                                      |
| <b>Step 3</b> | Server /cmc # <b>activate</b>                                          | Activates the selected image for the chosen CMC.                                                                                          |
| <b>Step 4</b> | At the prompt, enter <b>y</b> to activate the selected firmware image. | The CMC-1 reboots, terminating all CLI and GUI sessions until the reboot completes, but CMC-2 reboot will not affect any active sessions. |

### Example

This example activates CMC firmware on the SIOC slot 1:

```
Server # scope chassis
Server /chassis # scope cmc 1
Server /chassis/cmc # activate
Warning: The CMC will be rebooted immediately to complete the activation.
The network may go down temporarily till CMC boots up again
Continue?[y|N]y
```

## Managing SAS Expander and HDD Firmware

### Updating and Activating SAS Expander Firmware

#### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope sas-expandersas expander ID**
3. Server /chassis/sas-expander # **update protocol IP Address path**
4. (Optional) Server /chassis/sas-expander # **show detail**

## DETAILED STEPS

|               | Command or Action                                                     | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|---------------|-----------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                         | Enters chassis command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Step 2</b> | Server /chassis # <b>scope sas-expandersas expander ID</b>            | Enters SAS expander mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Step 3</b> | Server /chassis/sas-expander # <b>update protocol IP Address path</b> | <p>Initiates the firmware update by specifying the protocol, IP address of the remote server, and the file path to the firmware file on the server. The protocol can be one of the following:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> |
| <b>Step 4</b> | (Optional) Server /chassis/sas-expander # <b>show detail</b>          | Displays the status of the firmware upgrade.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

**Example**

This example shows how to update and activate the SAS expander firmware:

```

Server# scope chassis
Server /chassis # scope sas-expander 1
Updating the firmware
Server /chassis/sas-expander# update tftp 10.10.10.10 /tftpboot/skasargo/<firmware file>
updating the firmware.
Checking the status of the upgrade
Server /chassis/sas-expander# show detail
Firmware Image Information:
 ID: 1
 Name: SASEXP1

```

```

Update Stage: In Progress
Update Progress: 25
Current FW Version: 04.08.01_B056
FW Image 1 Version: 04.08.01_B056
FW Image 1 State: RUNNING ACTIVATED
FW Image 2 Version: 04.08.01_B056
FW Image 2 State: BACKUP INACTIVATED

```

**Activating the firmware**

```

svbu-huu-sanity-col2-1-vcmc /chassis/sas-expander # activate
This operation will activate backup firmware and reboot the SAS-Expander.
Continue?[y|N]y

```

```

Server /chassis/sas-expander #

```

## Updating HDD Firmware

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis/dynamic-storage # **scope dynamic-storage**
3. Server /chassis/dynamic-storage # **update-drive** *protocol IP Address path HDD slot-ids*
4. (Optional) Server /chassis/dynamic-storage # **show physical-drive-fw**

### DETAILED STEPS

|               | Command or Action                                                                                  | Purpose                                                                                                                                                                                                                                                                         |
|---------------|----------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                                                      | Enters chassis command mode.                                                                                                                                                                                                                                                    |
| <b>Step 2</b> | Server /chassis/dynamic-storage # <b>scope dynamic-storage</b>                                     | Enters dynamic storage command mode.                                                                                                                                                                                                                                            |
| <b>Step 3</b> | Server /chassis/dynamic-storage # <b>update-drive</b> <i>protocol IP Address path HDD slot-ids</i> | Specifies the protocol, IP address of the remote server, and the file path to the firmware file on the server. The protocol can be one of the following: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> |

|               | Command or Action                                                          | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|---------------|----------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                                            | <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> <p><b>Note</b> You can update firmware for multiple servers from the same vendor.</p> |
| <b>Step 4</b> | (Optional) Server /chassis/dynamic-storage # <b>show physical-drive-fw</b> | Displays the status of the firmware upgrade.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

### Example

This example provides steps to update the HDD firmware:

```
Server# scope chassis
Server /chassis # scope dynamic-storage
Updating for a single HDD
Server /chassis/dynamic-storage #update-drive tftp 10.10.10.10 /tftpboot/skasargo/sg4.1od
14
updating FW for slot 1 HDD
Updating for Multiple HDD
Server /chassis/dynamic-storage#update-drive tftp 10.10.10.10 /tftpboot/skasargo/sg4.1od
1-14
updating fw for multiple HDDs
Viewing the Status of the Upgrade
Server /chassis/dynamic-storage# show physical-drive-fw
```

| Slot | Vendor  | Product ID | Current_FW | Update Stage | Update Progress |
|------|---------|------------|------------|--------------|-----------------|
| 1    | TOSHIBA | MG03SCA400 | 5702       | Progress     | 25              |
| 2    | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 3    | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 4    | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 5    | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 6    | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 7    | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 8    | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 9    | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 10   | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 11   | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 12   | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 13   | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |
| 14   | TOSHIBA | MG03SCA400 | 5702       | NONE         | 0               |

```
Server /chassis/dynamic-storage #
```





# CHAPTER 16

## Viewing Faults and Logs

This chapter includes the following sections:

- [Fault Summary, on page 349](#)
- [Cisco IMC Log, on page 350](#)
- [System Event Log, on page 354](#)
- [Logging Controls, on page 357](#)

## Fault Summary

### Viewing the Faults and Logs Summary

#### Procedure

|               | Command or Action                  | Purpose                           |
|---------------|------------------------------------|-----------------------------------|
| <b>Step 1</b> | Server # <b>scope fault</b>        | Enters fault command mode.        |
| <b>Step 2</b> | Server # <b>show fault-entries</b> | Displays a log of all the faults. |

#### Example

This example displays a summary of faults:

```
Server # scope fault
Server /fault # show fault-entries

Time Severity Distinguished Name (DN)

2015-08-18T06:44:02 major sys/chassis-1/server-2/board/memarray-1/mem-2
2015-08-18T06:43:48 major sys/chassis-1/server-2/board/memarray-1/mem-1

Description

"DDR3_P1_A2_ECC: DIMM 2 is inoperable : Check or replace DIMM"
"DDR3_P1_A1_ECC: DIMM 1 is inoperable : Check or replace DIMM"

Server /fault #
```

# Cisco IMC Log

## Viewing Cisco IMC Log

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope log**
3. Server /chassis/log # **show entries detail**

### DETAILED STEPS

|               | Command or Action                                | Purpose                             |
|---------------|--------------------------------------------------|-------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                    | Enters chassis command mode.        |
| <b>Step 2</b> | Server /chassis # <b>scope log</b>               | Enters log command mode.            |
| <b>Step 3</b> | Server /chassis/log # <b>show entries detail</b> | Displays the CMC trace log details. |

### Example

This example displays the CMC trace log details:

```

Server# scope chassis
Server /chassis # scope log
Server /chassis/log # show entries detail
Trace Log:
 Time: 2015 Jul 26 06:35:15
 Severity: Notice
 Source: CMC:dropbear:19566
 Description: PAM password auth succeeded for 'cli' from 10.127.148.234:53791
 Order: 0
Trace Log:
 Time: 2015 Jul 26 06:35:15
 Severity: Notice
 Source: CMC:AUDIT:19566
 Description: Session open (user:admin, ip:10.127.148.234, id:6, type:CLI)
 Order: 1
Trace Log:
 Time: 2015 Jul 26 06:35:15
 Severity: Informational
 Source: CMC:dropbear:19566
 Description: " pam_session_manager(sshd:session): session (6) opened for user admin
from 10.127.148.234 by (uid=0) "
 Order: 2
Trace Log:
 Time: 2015 Jul 26 06:35:15
 Severity: Notice
 Source: CMC:AUDIT:1779
.
.
.

```

```
Server /chassis/log #
```

## Clearing Trace Logs

### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope log**
3. Server /chassis/log # **clear**

### DETAILED STEPS

|        | Command or Action                  | Purpose                          |
|--------|------------------------------------|----------------------------------|
| Step 1 | Server# <b>scope chassis</b>       | Enters the chassis command mode. |
| Step 2 | Server /chassis # <b>scope log</b> | Enters the log command mode.     |
| Step 3 | Server /chassis/log # <b>clear</b> | Clears the trace log.            |

### Example

The following example clears the log of trace logs:

```
Server# scope chassis
Server /chassis # scope log
Server /chassis/log # clear

Server /chassis/log #
```

## Configuring the Cisco IMC Log Threshold

You can specify the lowest level of messages that will be included in the syslog log.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope log**
3. Server /chassis/log # **set local-syslog-severity level**
4. Server /chassis/log # **set remote-syslog-severity level**
5. Server /chassis/log # **commit**
6. (Optional) Server /chassis/log # **show**

### DETAILED STEPS

|        | Command or Action             | Purpose                      |
|--------|-------------------------------|------------------------------|
| Step 1 | Server # <b>scope chassis</b> | Enters chassis command mode. |

|               | Command or Action                                             | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|---------------|---------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 2</b> | Server /chassis # <b>scope log</b>                            | Enters log command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Step 3</b> | Server /chassis/log # <b>set local-syslog-severity level</b>  | <p>The severity <i>level</i> can be one of the following, in decreasing order of severity:</p> <ul style="list-style-type: none"> <li>• emergency</li> <li>• alert</li> <li>• critical</li> <li>• error</li> <li>• warning</li> <li>• notice</li> <li>• informational</li> <li>• debug</li> </ul> <p><b>Note</b> does not log any messages with a severity below the selected severity. For example, if you select <b>error</b>, then the log will contain all messages with the severity Emergency, Alert, Critical, or Error. It will not show Warning, Notice, Informational, or Debug messages.</p> |
| <b>Step 4</b> | Server /chassis/log # <b>set remote-syslog-severity level</b> | <p>The severity <i>level</i> can be one of the following, in decreasing order of severity:</p> <ul style="list-style-type: none"> <li>• emergency</li> <li>• alert</li> <li>• critical</li> <li>• error</li> <li>• warning</li> <li>• notice</li> <li>• informational</li> <li>• debug</li> </ul> <p><b>Note</b> does not log any messages with a severity below the selected severity. For example, if you select <b>error</b>, then the log will contain all messages with the severity Emergency, Alert, Critical, or Error. It will not show Warning, Notice, Informational, or Debug messages.</p> |
| <b>Step 5</b> | Server /chassis/log # <b>commit</b>                           | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

|        | Command or Action                            | Purpose                                 |
|--------|----------------------------------------------|-----------------------------------------|
| Step 6 | (Optional) Server /chassis/log # <b>show</b> | Displays the configured severity level. |

### Example

This example shows how to configure the logging of messages with a minimum severity of Debug for the local syslogs and error for the remote syslog:

```
Server# scope chassis
Server /chassis # scope log
Server /chassis/log # set local-syslog-severity debug
Server /chassis/log # set remote-syslog-severity error
Server /chassis/log *# commit
Server /chassis/log # show
Local Syslog Severity Remote Syslog Severity

debug error

Server /chassis/log #
```

## Sending the Cisco IMC Log to a Remote Server

You can configure profiles for one or two remote syslog servers to receive system log entries.

### Before you begin

- The remote syslog server must be configured to receive logs from a remote host.
- The remote syslog server must be configured to receive all types of logs, including authentication-related logs.
- The remote syslog server's firewall must be configured to allow syslog messages to reach the syslog server.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope log**
3. Server /chassis/log # **scope server {1 | 2}**
4. Server /chassis/log/server # **set enabled {yes | no}**
5. Server /chassis/log/server # **commit**
6. Server /chassis/log/server # **exit**
7. Server /chassis/log/server # **showserver**

### DETAILED STEPS

|        | Command or Action                  | Purpose                      |
|--------|------------------------------------|------------------------------|
| Step 1 | Server # <b>scope chassis</b>      | Enters chassis command mode. |
| Step 2 | Server /chassis # <b>scope log</b> | Enters log command mode.     |

|               | Command or Action                                          | Purpose                                                                                                       |
|---------------|------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|
| <b>Step 3</b> | Server /chassis/log # <b>scope server</b> {1   2}          | Selects one of the two remote syslog server profiles and enters the command mode for configuring the profile. |
| <b>Step 4</b> | Server /chassis/log/server # <b>set enabled</b> {yes   no} | Enables the sending of system log entries to this syslog server.                                              |
| <b>Step 5</b> | Server /chassis/log/server # <b>commit</b>                 | Commits the transaction to the system configuration.                                                          |
| <b>Step 6</b> | Server /chassis/log/server # <b>exit</b>                   | Exits to the log command mode.                                                                                |
| <b>Step 7</b> | Server /chassis/log/server # <b>showserver</b>             | Exits to the log command mode.                                                                                |

### Example

This example shows how to configure a remote syslog server profile and enable the sending of system log entries:

# System Event Log

## Viewing the System Event Log

### SUMMARY STEPS

1. Server# **scope sel**
2. Server /sel # **show entries [detail]**

### DETAILED STEPS

|               | Command or Action                          | Purpose                                                                                                                                                                                          |
|---------------|--------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope sel</b>                   | Enters the system event log (SEL) command mode.                                                                                                                                                  |
| <b>Step 2</b> | Server /sel # <b>show entries [detail]</b> | For system events, displays timestamp, the severity of the event, and a description of the event. The <b>detail</b> keyword displays the information in a list format instead of a table format. |

### Example

This example displays the system event log:

```
Server# scope sel
Server /sel # show entries
Time Severity Description

[System Boot] Informational " LED_PSU_STATUS: Platform sensor, OFF event was asserted"
```

```

[System Boot] Informational " LED_HLTH_STATUS: Platform sensor, GREEN was asserted"
[System Boot] Normal " PSU_REDUNDANCY: PS Redundancy sensor, Fully Redundant
was asserted"
[System Boot] Normal " PSU2 PSU2_STATUS: Power Supply sensor for PSU2, Power
Supply input lost (AC/DC) was deasserted"
[System Boot] Informational " LED_PSU_STATUS: Platform sensor, ON event was asserted"

[System Boot] Informational " LED_HLTH_STATUS: Platform sensor, AMBER was asserted"
[System Boot] Critical " PSU_REDUNDANCY: PS Redundancy sensor, Redundancy Lost
was asserted"
[System Boot] Critical " PSU2 PSU2_STATUS: Power Supply sensor for PSU2, Power
Supply input lost (AC/DC) was asserted"
[System Boot] Normal " HDD_01_STATUS: Drive Slot sensor, Drive Presence was
asserted"
[System Boot] Critical " HDD_01_STATUS: Drive Slot sensor, Drive Presence was
deasserted"
[System Boot] Informational " DDR3_P2_D1_INFO: Memory sensor, OFF event was asserted"

2001-01-01 08:30:16 Warning " PSU2 PSU2_VOUT: Voltage sensor for PSU2, failure event
was deasserted"
2001-01-01 08:30:16 Critical " PSU2 PSU2_VOUT: Voltage sensor for PSU2, non-recoverable
event was deasserted"
2001-01-01 08:30:15 Informational " LED_PSU_STATUS: Platform sensor, ON event was asserted"

2001-01-01 08:30:15 Informational " LED_HLTH_STATUS: Platform sensor, AMBER was asserted"
2001-01-01 08:30:15 Informational " LED_HLTH_STATUS: Platform sensor, FAST BLINK event was
asserted"
2001-01-01 08:30:14 Non-Recoverable " PSU2 PSU2_VOUT: Voltage sensor for PSU2, non-recoverable
event was asserted"
2001-01-01 08:30:14 Critical " PSU2 PSU2_VOUT: Voltage sensor for PSU2, failure event
was asserted"
--More--

```

## Viewing the System Event Log for Servers

### SUMMARY STEPS

1. Server# **scope server** {1 | 2 }
2. Server /server # **scope sel**
3. Server /server/sel # **show entries** [detail]

### DETAILED STEPS

|               | Command or Action                                 | Purpose                                                                                                                                                                                          |
|---------------|---------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope server</b> {1   2 }              | Enters the server mode for server 1 or 2.                                                                                                                                                        |
| <b>Step 2</b> | Server /server # <b>scope sel</b>                 | Enters the system event log (SEL) command mode.                                                                                                                                                  |
| <b>Step 3</b> | Server /server/sel # <b>show entries</b> [detail] | For system events, displays timestamp, the severity of the event, and a description of the event. The <b>detail</b> keyword displays the information in a list format instead of a table format. |

**Example**

This example displays the system event log:

```
Server # scope server 1
Server/server # scope sel
Server /server/sel # show entries
Time Severity Description

2015-08-18 08:46:03 Normal "BIOS_POST_CMPLT: Presence sensor, Device Inserted / Device Present was asserted"
2015-08-18 08:46:00 Normal "System Software event: System Event sensor, OEM System Boot Event was asserted"
2010-03-21 00:17:42 Normal "System Software event: System Event sensor, Timestamp Clock Synch (second of pair) was asserted"
2015-08-18 08:44:34 Normal "System Software event: System Event sensor, Timestamp Clock Synch (first of pair) was asserted"
2015-08-18 08:44:00 Normal "BIOS_POST_CMPLT: Presence sensor, Device Removed / Device Absent was asserted"
2015-08-18 08:44:00 Normal "MAIN_POWER_PRS: Presence sensor, Device Inserted / Device Present was asserted"
2015-08-18 08:43:39 Normal "MAIN_POWER_PRS: Presence sensor, Device Removed / Device Absent was asserted"
2015-08-18 08:16:18 Normal "BIOS_POST_CMPLT: Presence sensor, Device Inserted / Device Present was asserted"
2015-08-18 08:16:16 Normal "System Software event: System Event sensor, OEM System Boot Event was asserted"
2010-03-20 23:47:59 Normal "System Software event: System Event sensor, Timestamp Clock Synch (second of pair) was asserted"
2015-08-18 08:14:50 Normal "System Software event: System Event sensor, Timestamp Clock Synch (first of pair) was asserted"
2015-08-18 08:14:20 Normal "BIOS_POST_CMPLT: Presence sensor, Device Removed / Device Absent was asserted"
2015-08-18 08:14:20 Normal "MAIN_POWER_PRS: Presence sensor, Device Inserted / Device Present was asserted"
2015-08-18 08:13:44 Normal "MAIN_POWER_PRS: Presence sensor, Device Removed / Device Absent was asserted"
2015-08-18 08:12:57 Normal "FRU_RAM_SEL_FULLNESS: Event Log sensor for FRU_RAM, Log Area Reset/Cleared was asserted"
```

## Clearing the System Event Log

**SUMMARY STEPS**

1. Server# **scope sel**
2. Server /sel # **clear**

**DETAILED STEPS**

|               | Command or Action          | Purpose                                                                                                       |
|---------------|----------------------------|---------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope sel</b>   | Enters the system event log command mode.                                                                     |
| <b>Step 2</b> | Server /sel # <b>clear</b> | You are prompted to confirm the action. If you enter <b>y</b> at the prompt, the system event log is cleared. |



**Example**

This example clears the system event log:

```
Server# scope sel
Server /sel # clear
This operation will clear the whole sel.
Continue?[y|N]y
```

## Logging Controls

### Configuring the Cisco IMC Log Threshold

You can specify the lowest level of messages that will be included in the syslog log.

**SUMMARY STEPS**

1. Server # **scope chassis**
2. Server /chassis # **scope log**
3. Server /chassis/log # **set local-syslog-severity level**
4. Server /chassis/log # **set remote-syslog-severity level**
5. Server /chassis/log # **commit**
6. (Optional) Server /chassis/log # **show**

**DETAILED STEPS**

|               | <b>Command or Action</b>                                     | <b>Purpose</b>                                                                                                                                                                                                                                                                             |
|---------------|--------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                | Enters chassis command mode.                                                                                                                                                                                                                                                               |
| <b>Step 2</b> | Server /chassis # <b>scope log</b>                           | Enters log command mode.                                                                                                                                                                                                                                                                   |
| <b>Step 3</b> | Server /chassis/log # <b>set local-syslog-severity level</b> | The severity <i>level</i> can be one of the following, in decreasing order of severity: <ul style="list-style-type: none"> <li>• emergency</li> <li>• alert</li> <li>• critical</li> <li>• error</li> <li>• warning</li> <li>• notice</li> <li>• informational</li> <li>• debug</li> </ul> |

|               | Command or Action                                             | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|---------------|---------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                               | <p><b>Note</b> does not log any messages with a severity below the selected severity. For example, if you select <b>error</b>, then the log will contain all messages with the severity Emergency, Alert, Critical, or Error. It will not show Warning, Notice, Informational, or Debug messages.</p>                                                                                                                                                                                                                                                                                                   |
| <b>Step 4</b> | Server /chassis/log # <b>set remote-syslog-severity level</b> | <p>The severity <i>level</i> can be one of the following, in decreasing order of severity:</p> <ul style="list-style-type: none"> <li>• emergency</li> <li>• alert</li> <li>• critical</li> <li>• error</li> <li>• warning</li> <li>• notice</li> <li>• informational</li> <li>• debug</li> </ul> <p><b>Note</b> does not log any messages with a severity below the selected severity. For example, if you select <b>error</b>, then the log will contain all messages with the severity Emergency, Alert, Critical, or Error. It will not show Warning, Notice, Informational, or Debug messages.</p> |
| <b>Step 5</b> | Server /chassis/log # <b>commit</b>                           | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Step 6</b> | (Optional) Server /chassis/log # <b>show</b>                  | Displays the configured severity level.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

### Example

This example shows how to configure the logging of messages with a minimum severity of Debug for the local syslogs and error for the remote syslog:

```

Server# scope chassis
Server /chassis # scope log
Server /chassis/log # set local-syslog-severity debug
Server /chassis/log # set remote-syslog-severity error
Server /chassis/log *# commit
Server /chassis/log # show
Local Syslog Severity Remote Syslog Severity

debug error

Server /chassis/log #

```

## Sending the Cisco IMC Log to a Remote Server

You can configure profiles for one or two remote syslog servers to receive system log entries.

### Before you begin

- The remote syslog server must be configured to receive logs from a remote host.
- The remote syslog server must be configured to receive all types of logs, including authentication-related logs.
- The remote syslog server's firewall must be configured to allow syslog messages to reach the syslog server.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope log**
3. Server /chassis/log # **scope server {1 | 2}**
4. Server /chassis/log/server # **set enabled {yes | no}**
5. Server /chassis/log/server # **commit**
6. Server /chassis/log/server # **exit**
7. Server /chassis/log/server # **showserver**

### DETAILED STEPS

|               | Command or Action                                          | Purpose                                                                                                       |
|---------------|------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                              | Enters chassis command mode.                                                                                  |
| <b>Step 2</b> | Server /chassis # <b>scope log</b>                         | Enters log command mode.                                                                                      |
| <b>Step 3</b> | Server /chassis/log # <b>scope server {1   2}</b>          | Selects one of the two remote syslog server profiles and enters the command mode for configuring the profile. |
| <b>Step 4</b> | Server /chassis/log/server # <b>set enabled {yes   no}</b> | Enables the sending of system log entries to this syslog server.                                              |
| <b>Step 5</b> | Server /chassis/log/server # <b>commit</b>                 | Commits the transaction to the system configuration.                                                          |
| <b>Step 6</b> | Server /chassis/log/server # <b>exit</b>                   | Exits to the log command mode.                                                                                |
| <b>Step 7</b> | Server /chassis/log/server # <b>showserver</b>             | Exits to the log command mode.                                                                                |

### Example

This example shows how to configure a remote syslog server profile and enable the sending of system log entries:

## Sending a Test Cisco IMC Log to a Remote Server

### Before you begin

- The remote syslog server must be configured to receive logs from a remote host.
- The remote syslog server must be configured to receive all types of logs, including authentication-related logs.
- The remote syslog server's firewall must be configured to allow syslog messages to reach the syslog server.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope log**
3. Server /chassis/log # **send-test-syslog**

### DETAILED STEPS

|               | Command or Action                             | Purpose                                |
|---------------|-----------------------------------------------|----------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                 | Enters chassis command mode.           |
| <b>Step 2</b> | Server /chassis # <b>scope log</b>            | Enters log command mode.               |
| <b>Step 3</b> | Server /chassis/log # <b>send-test-syslog</b> | Sends a test log to the remote server. |

### Example

This example shows how send a test log to a remote server:

## Uploading Remote Syslog Certificate

### Before you begin

- You must log in as a user with admin privileges.
- The certificate file to be uploaded must reside on a locally accessible file system.
- The following certificate formats are supported:
  - .crt
  - .cer
  - .pem

Beginning with release 4.2(2a), you can upload a remote syslog certificate to Cisco UCS C-series servers. You can upload the certificate to one or two Cisco UCS C-series servers.

- 
- Step 1** Server # **scope cimc**  
Enters Cisco IMC command mode.
- Step 2** Server /cimc # **scope log**  
Enters Cisco IMC log command mode.
- Step 3** Server /cimc/log # **scope server{1|2}**  
Selects one of the two remote syslog server profiles and enters the command mode for uploading the remote syslog certificate and enabling secure remote syslog on the selected server.
- Step 4** Server /cimc/log/server # **upload-certificate** *remote-protocol server\_address path certificate\_filename*  
Specify the protocol to connect to the remote server. It can be of the following types:
- TFTP
  - FTP
  - SFTP
  - SCP
  - HTTP
- Note** If you enter the protocol as FTP, SCP or SFTP, you will be prompted to enter your username and password.
- Along with the remote protocol, enter the filepath from where you want to upload the remote syslog certificate. After validating your remote server username and password, uploads the remote syslog certificate from the remote server.
- Step 5** (Optional) Server /cimc/log/server # **paste-certificate**  
This is an additional option to upload the remote syslog certificate.  
At the prompt, paste the content of the certificate and press CTRL+D.
- Step 6** Server /cimc/log/server # **setsecure-enabledyes**  
Enables secure remote syslog on the server.
- Step 7** Server /cimc/log/server # **commit**  
Commits the transaction to the system configuration.
- 

### Example

- This example uploads a remote syslog certificate from a remote server and enables secure remote syslog on the selected server:

```
Server # scope cimc
Server /cimc # scope log
Server /cimc/log # scope server
Server /cimc/log/server # upload-certificate scp 10.10.10.10
/home/user-xyz/rem-sys-log-certif.cert
Server (RSA) key fingerprint is dd:b5:2b:07:ad:c0:30:b2:d5:6a:6a:78:80:85:93:b0
```

```

Do you wish to continue? [y/N]y
Username: user-xyz
Password:
Syslog Certificate uploaded successfully
Server /cimc/log/server # set secure-enabled yes
Server /cimc/log/server # commit
Server /cimc/log/server #

```

- This example uploads a remote syslog certificate using paste option:

```

Server # scope cimc
Server /cimc # scope log
Server /cimc/log # scope server
Server /cimc/log/server # paste-certificate
Please paste your certificate here, when finished, press CTRL+D.
-----BEGIN CERTIFICATE-----
MIIFUDCCBDigAwIBAgIKYRF49gAAAAAAjANBgkqhkiG9w0BAQUFADBLMRMwEQYK
CZImiZPyLQGBGRYDY29tMRMwEQYKZImiZPyLQGBGRYDdmV3MR8wHQYDVQDExZu
ZXctV01OLU9WQ1NBNElFUONBLUNBMB4XDTE3MDczMDIxNTA1NVoxDTE5MDczMDIy
MDA1NVowSzETMBEGCgmSJomT8ixkArkWA2NvbTETMBEGCgmSJomT8ixkArkWA25l
dzEfMBOGA1UEAxMwV3V3LWV3LWV3LWV3LWV3LWV3LWV3LWV3LWV3LWV3LWV3LWV3
AQEBBQADggEPADCCAQoCggEBALd8c+hhJddfUH6XKqBv11zVtIAiHfCx+17z9o7F
bELOWu0LDVSC9pC1zpJ9wykr6VqUsVhZTkqQan23+84X41YBsd92shQp9bri2gKj
MgntmnXE6qP3b6Trw94j6JVyWXXImYEda/Sftx722orLap8Sdliurue62JGNfg56
vxXB1SNUHOMgOdfTOenJvYeh51jceOCdKTPpBij4wuq+jJfknhdW7KKE7ubmyRv
xpRSkiVaqNypf8jv7uG8Kwx1Q8jbCr0wG4nAbPndwhkyJpgyA5zuCdMRU2cN47om
u0VfMzJeVu+HuAif25BqKn4cJwHGOnrWKZcfHtnpKEbbmv0CAwEAaOAJQwggIw
MBAGCSsGAQQBgjcvAQQDAgEAMB0GA1UdDgQWBBR2+YJQuCmHKckBkqVim0/kvFzB
bTAZBgkrBgEEAYI3FAIEDB4KAFMAdQBiAEMAQTAOBgNVHQ8BAf8EBAMCAYYwDwYD
VR0TAQH/BAUwAwEB/zAfBgNVHSMEGDAWgBRo6OQnLNNVa71Vt11YAVRPMw8LQjCB
2AYDVR0FBiHQMihNMLHkoIHh0IHEhoHBbGRhcDovLy9DTj1uZXctV01OLU9WQ1NB
NElFUONBLUNBLENOPvdJTi1PVkJTQTRJRVNDQsxDtj1DRFAsQ049UHVibG1jJTIw
S2V5JTIwU2Vydm1jZXMzQ049U2Vydm1jZXMzQ049Q29uZmlndXhhdGlvbixEQz1u
ZXcsREM9Y29tP2NlcnRpZmljYXRlUmV2b2NhdGlvbkxpc3Q/YmFzZT9vYmplY3RD
bGFzc21jUkxEaXN0cmliZXRpb25Qb21udDCBxAYIKwYBBQUHAQEegbcwgbQwgbEG
CsGAQUFBzAChOGkbGRhcDovLy9DTj1uZXctV01OLU9WQ1NBNElFUONBLUNBLENO
PUFJQSxDtj1QdWJsaWMLMjBLZXk1MjBTZXJ2aWN1cyxDtj1TZXJ2aWN1cyxDtj1D
b25maWdlcmF0aW9uLERDPW51dyxQz1jb20/Y0FDZXJ0aWZpY2F0ZT9iYXN1P29i
amVjdENsYXNzPWNlcnRpZmljYXRpb25BdXR0b3JpdHkwdQYJKoZIhvcNAQEFBQAD
ggEBAE8IWarFEqrrwMHNaJunoomON2rdBWRNAM1JhKdIzi49J/9Yy9I1OGF+10wR
Q5TeKFYcWxBj5ltLYVWVdB+9YtTKsoEoq7/MeSg/c5KuprJhugqN3OU6zCqU4vq
rS1UHNnYkOJiSdOjkOdNet9EG2YUqiDPr6CqIUcdU4+e36LdtQZW0T1Iko+0z/be
bwIgtmxzkhlyDU711SuKmyz3uRrKq1CWhiIhSaOq4yYFQ0iw6TmFFKJGZ1KnjOrA
AwHh8QvBBJhPMOwncWGL6DLFb7md21E2YBu+zcVPLdXyM0Xgk81XsE22bRjYJU
gyHqA2enmHAMJequLFoSH9apKU=
-----END CERTIFICATE-----
Syslog Certificate pasted successfully.
Server /cimc/log/server #

```

- This example displays that the remote syslog certificate exists on the server and secure remote syslog is enabled on the server:

```

Server # scope cimc
Server /cimc # scope log
Server /cimc/log # scope server
Server /cimc/log/server # show detail
Syslog Server 1:
Syslog Server Address: 10.10.10.10
Syslog Server Port: 514
Enabled: yes
Secure Enabled: yes
Syslog Server protocol: udp
Certificate Exists: yes
Server /cimc/log/server #

```

# Deleting Remote Syslog Certificate

## Before you begin

You must log in as a user with admin privileges.

- 
- Step 1** Server # **scope cimc**  
Enters Cisco IMC command mode.
- Step 2** Server /cimc # **scope log**  
Enters Cisco IMC log command mode.
- Step 3** Server /cimc/log # **scope server{1|2}**  
Selects one of the two remote syslog server profiles and enters the command mode for deleting the remote syslog certificate on the selected server.
- Step 4** Server /cimc/log/server # **show detail**  
Displays the server details and confirms that the remote syslog certificate exists on the selected server.
- Step 5** Server /cimc/log/server # **delete-client-certificate**  
Enter **y** at the confirmation prompt to delete the remote syslog certificate from the selected server.
- Step 6** Server /cimc/log/server # **show detail**  
Displays the server details and confirms that the remote syslog certificate is not available on the selected server.
- 

## Example

- This example displays that the remote syslog certificate exists on the server:

```
Server # scope cimc
Server /cimc # scope log
Server /cimc/log # scope server
Server /cimc/log/server # show detail
Server /cimc/log/server # commit
 Syslog Server 1:
 Syslog Server Address: 10.10.10.10
 Syslog Server Port: 514
 Enabled: yes
 Secure Enabled: yes
 Syslog Server protocol: udp
 Certificate Exists: yes
Server /cimc/log/server #
```

- This example deletes the remote syslog certificate on the server:

```
Server # scope cimc
Server /cimc # scope log
Server /cimc/log # scope server
Server /cimc/log/server # show detail
 Syslog Server 1:
 Syslog Server Address: 10.10.10.10
```

```
Syslog Server Port: 514
Enabled: yes
Secure Enabled: yes
Syslog Server protocol: udp
Certificate Exists: yes
Server /cimc/log/server # delete-client-certificate
You are going to delete the Syslog Certificate.
Are you sure you want to proceed and delete the Syslog Certificate? [y|N]y
Syslog Certificate deleted successfully
Server /cimc/log/server #
```





# CHAPTER 17

## Server Utilities

---

This chapter includes the following sections:

- [Exporting Technical Support Data, on page 365](#)
- [Rebooting the Cisco IMC, on page 368](#)
- [Clearing the BIOS CMOS, on page 369](#)
- [Resetting the BMC to factory Defaults, on page 369](#)
- [Resetting to Factory Defaults, on page 370](#)
- [Resetting to Factory Defaults, on page 372](#)
- [Exporting and Importing the Cisco IMC and BMC Configuration, on page 374](#)
- [Generating Non-Maskable Interrupts to the Host, on page 382](#)
- [Adding Cisco IMC Banner, on page 383](#)
- [Downloading and Viewing Inventory Details, on page 384](#)

## Exporting Technical Support Data

Perform this task when requested by the Cisco Technical Assistance Center (TAC). This utility creates a summary report containing configuration information, logs and diagnostic data that will help TAC in troubleshooting and resolving a technical issue.



---

**Important** If any firmware or BIOS updates are in progress, do not export the technical support data until those tasks are complete.

---

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope tech-support**
3. Server /chassis/tech-support # **set collect-from** {all | cmc | peeremc | bmc1 | bmc2}
4. Server /chassis/tech-support # **set remote-ip** *ip-address*
5. Server /chassis/tech-support # **set remote-path** *path/filename*
6. Server /chassis/tech-support # **set remote-protocol** *protocol*
7. Server /chassis/tech-support # **set remote-username** *name*
8. Server /chassis/tech-support # **set remote-password** *password*

9. Server /chassis/tech-support # **commit**
10. Server /chassis/tech-support # **start**
11. (Optional) Server /chassis/tech-support # **show detail**
12. (Optional) Server /chassis/tech-support # **cancel**

## DETAILED STEPS

|               | Command or Action                                                                                                               | Purpose                                                                                                                                                                                                                                                                                                                             |
|---------------|---------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                                                                                   | Enters chassis command mode.                                                                                                                                                                                                                                                                                                        |
| <b>Step 2</b> | Server /chassis # <b>scope tech-support</b>                                                                                     | Enters the tech-support command mode.                                                                                                                                                                                                                                                                                               |
| <b>Step 3</b> | Server /chassis/tech-support # <b>set collect-from</b> { <b>all</b>   <b>cmc</b>   <b>peercmc</b>   <b>bmc1</b>   <b>bmc2</b> } | Specifies the component for which the technical support data has to be exported.                                                                                                                                                                                                                                                    |
| <b>Step 4</b> | Server /chassis/tech-support # <b>set remote-ip</b> <i>ip-address</i>                                                           | Specifies the IP address of the remote server on which the technical support data file should be stored.                                                                                                                                                                                                                            |
| <b>Step 5</b> | Server /chassis/tech-support # <b>set remote-path</b> <i>path/filename</i>                                                      | Specifies the file name in which the support data should be stored on the remote server. When you enter this name, include the relative path for the file from the top of the server tree to the desired location.<br><br><b>Tip</b> To have the system auto-generate the file name, enter the file name as <b>default.tar.gz</b> . |
| <b>Step 6</b> | Server /chassis/tech-support # <b>set remote-protocol</b> <i>protocol</i>                                                       | Specifies the protocol to connect to the remote server. It can be of the following types: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul>                                                                                                                    |

|                | Command or Action                                                         | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|----------------|---------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                |                                                                           | <p><b>Note</b></p> <p>The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> |
| <b>Step 7</b>  | Server /chassis/tech-support # <b>set remote-username</b> <i>name</i>     | Specifies the user name on the remote server on which the technical support data file should be stored. This field does not apply if the protocol is TFTP or HTTP.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Step 8</b>  | Server /chassis/tech-support # <b>set remote-password</b> <i>password</i> | Specifies the password on the remote server on which the technical support data file should be stored. This field does not apply if the protocol is TFTP or HTTP.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>Step 9</b>  | Server /chassis/tech-support # <b>commit</b>                              | Commits the transaction to the system configuration.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Step 10</b> | Server /chassis/tech-support # <b>start</b>                               | Begins the transfer of the data file to the remote server.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| <b>Step 11</b> | (Optional) Server /chassis/tech-support # <b>show detail</b>              | Displays the progress of the transfer of the data file to the remote server.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Step 12</b> | (Optional) Server /chassis/tech-support # <b>cancel</b>                   | Cancels the transfer of the data file to the remote server.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

### Example

This example creates a technical support data file and transfers the file to a TFTP server:

```

Server# scope chassis
Server /chassis # scope tech-support
Server /chassis/tech-support # set collect-from all
Server /chassis/tech-support* # set remote-ip 192.0.20.41
Server /chassis/tech-support* # set remote-protocol tftp
Server /chassis/tech-support *# set remote-path /user/user1/default.tar.gz
Server /chassis/tech-support *# commit
Server /chassis/tech-support # start
Tech Support upload started.

Server /chassis/tech-support # show detail

Tech Support:
 Server Address: 192.0.20.41
 Path('default' for auto-naming): default.tar.gz
 Protocol: tftp

```

```

Username:
Password: *****
Collect from: all
Progress(%): 100
Status: COMPLETED

```

```
Server /chassis/tech-support #
```

### What to do next

Provide the generated report file to Cisco TAC.

## Rebooting the Cisco IMC

On rare occasions, such as an issue with the current running firmware, troubleshooting a server may require you to reboot the . This procedure is not part of the normal maintenance of a server. After you reboot the , you are logged off and the will be unavailable for a few minutes.




---

**Note** If you reboot the while the server is performing power-on self test (POST) or is operating in the Extensible Firmware Interface (EFI) shell, the server will be powered down until the reboot is complete.

---

### SUMMARY STEPS

1. Server # **scope server {1 | 2}**
2. Server /server # **scope bmc**
3. Server /server/bmc # **reboot**

### DETAILED STEPS

|               | Command or Action                    | Purpose                                      |
|---------------|--------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server {1   2}</b> | Enters server command mode of server 1 or 2. |
| <b>Step 2</b> | Server /server # <b>scope bmc</b>    | Enters bmc command mode.                     |
| <b>Step 3</b> | Server /server/bmc # <b>reboot</b>   | The reboots.                                 |

### Example

This example reboots the :

```

Server# scope server 1
Server /server # scope bmc
Server /server/bmc # reboot

```

# Clearing the BIOS CMOS

On rare occasions, troubleshooting a server may require you to clear the server's BIOS CMOS memory. This procedure is not part of the normal maintenance of a server.

## SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server # **scope bios**
3. Server /server/bios # **clear-cmos**

## DETAILED STEPS

|               | Command or Action                       | Purpose                                            |
|---------------|-----------------------------------------|----------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}    | Enters server command mode of server 1 or 2.       |
| <b>Step 2</b> | Server /server # <b>scope bios</b>      | Enters the bios command mode.                      |
| <b>Step 3</b> | Server /server/bios # <b>clear-cmos</b> | After a prompt to confirm, clears the CMOS memory. |

### Example

This example clears the BIOS CMOS memory:

```
Server# scope server 2
Server/server # scope bios
Server /server/bios # clear-cmos
```

This operation will clear the BIOS CMOS.

Note: Server should be in powered off state to clear CMOS.

Continue?[y|n] **y**

```
Server /server/bios #
```

# Resetting the BMC to factory Defaults

On rare occasions, such as an issue with the current running firmware, troubleshooting a server may require you to reset the BMC to the factory default. When this happens, all user-configurable settings are reset.

This procedure is not part of the normal server maintenance. After you reset the BMC, you are logged off and must log in again. You may also lose connectivity and may need to reconfigure the network settings.

## SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server # **scope bmc**
3. Server /server/bmc # **factory-default**

## DETAILED STEPS

|               | Command or Action                           | Purpose                                                                                                                                                                                                      |
|---------------|---------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}        | Enters server command mode of server 1 or 2.                                                                                                                                                                 |
| <b>Step 2</b> | Server /server # <b>scope bmc</b>           | Enters bmc command mode.<br><br><b>Note</b> Depending on the server number you have chosen, enters the BMC1 or BMC2 mode.                                                                                    |
| <b>Step 3</b> | Server /server/bmc # <b>factory-default</b> | After a prompt to confirm, the BMC resets to factory defaults. All your BMC configuration is lost and some of the inventory information may not be available until the server is powered on or power cycled. |

## Example

This example resets BMC1 to factory defaults:

```
Server# scope server 1
Server /server # scope bmc
Server /server/bmc # factory-default
This operation will reset the Server BMC configuration to factory default.
All your configuration will be lost. Some inventory information may
not be available until the server is powered on or power cycled.
Continue?[y|N] y
```

## Resetting to Factory Defaults

### Before you begin

You must log in with admin privileges to perform this task.

## SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **factory-default** {storage | vic | bmc1 | bmc2 | cmc | all}
3. (Optional) Server /chassis # **show factory-reset-status**

## DETAILED STEPS

|               | Command or Action                                                                  | Purpose                                                                                                                                                                                                 |
|---------------|------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                       | Enters the chassis command mode.                                                                                                                                                                        |
| <b>Step 2</b> | Server /chassis # <b>factory-default</b> {storage   vic   bmc1   bmc2   cmc   all} | Depending on the component that you choose to reset to factory default, the configuration parameters of that component is restored to factory defaults. You can choose one of the following components: |

|               | Command or Action                                             | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------|---------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                               | <ul style="list-style-type: none"> <li>• <b>all</b>—Resets the storage controllers, VIC, BMC1, BMC2, and CMCs settings to factory defaults.</li> <li>• <b>bmc1</b> —Resets the BMC1 settings to factory defaults.</li> <li>• <b>bmc2</b> —Resets the BMC2 settings to factory defaults.</li> <li>• <b>cmc</b> —Resets the CMCs settings to factory defaults.</li> <li>• <b>storage</b> —Resets the storage controller settings to factory default.</li> <li>• <b>vic</b> —Resets the VICs settings to factory default.</li> </ul> <p>Enter <b>y</b> at the confirmation prompt to reset the chosen component to default.</p> <p><b>Note</b> When you reset the CMC to defaults, all your CMC configuration is lost and the network configuration mode is set to <b>Cisco Card</b> mode by default. The CMCs factory defaults include the following conditions:</p> <ul style="list-style-type: none"> <li>• SSH is enabled for access to the CLI. Telnet is disabled.</li> <li>• HTTPS is enabled for access to the GUI.</li> <li>• A single user account exists (user name is <b>admin</b> , password is <b>password</b> ).</li> <li>• DHCP is enabled on the management port.</li> <li>• KVM and vMedia are enabled.</li> <li>• USB is enabled.</li> <li>• SoL is disabled.</li> </ul> |
| <b>Step 3</b> | (Optional) Server /chassis # <b>show factory-reset-status</b> | Displays the factory defaults status.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

### Example

This example resets to factory defaults:

```
Server# scope chassis
Server /chassis # factory-default vic
his factory-default operation does the following on these components without any back-up:
VIC - all user configured data will deleted and controller properties reset to default
values
(Host power-cycle is required for it to be effective)
Storage - all user configured data (including OS VD/drive if any) will be deleted,
controller properties and zoning settings reset to default values (Host power-cycle is
required for it to be effective)
```

```

BMC - all Server BMC configuration reset to factory default values
CMC - all user configured data (including admin password) will be deleted and CMC settings
 reset to default values
Continue?[y|N]y
factory-default for ' vic' started. Please check the status using "show factory-reset-status".
Server /chassis # show factory-reset-status
Factory Reset Status:
 Storage: NA
 VIC: Pending
 BMC1: NA
 BMC2: NA
 CMC: NA
Server /chassis #

```

## Resetting to Factory Defaults

### Before you begin

You must log in with admin privileges to perform this task.

### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **factory-default {storage | vic | bmc1 | bmc2 | cmc | all}**
3. (Optional) Server /chassis # **show factory-reset-status**

### DETAILED STEPS

|               | Command or Action                                                                  | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|---------------|------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                       | Enters the chassis command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Step 2</b> | Server /chassis # <b>factory-default {storage   vic   bmc1   bmc2   cmc   all}</b> | <p>Depending on the component that you choose to reset to factory default, the configuration parameters of that component is restored to factory defaults. You can choose one of the following components:</p> <ul style="list-style-type: none"> <li>• <b>all</b>—Resets the storage controllers, VIC, BMC1, BMC2, and CMCs settings to factory defaults.</li> <li>• <b>bmc1</b> —Resets the BMC1 settings to factory defaults.</li> <li>• <b>bmc2</b> —Resets the BMC2 settings to factory defaults.</li> <li>• <b>cmc</b> —Resets the CMCs settings to factory defaults.</li> <li>• <b>storage</b> —Resets the storage controller settings to factory default.</li> <li>• <b>vic</b> —Resets the VICs settings to factory default.</li> </ul> <p>Enter <b>y</b> at the confirmation prompt to reset the chosen component to default.</p> |



|               | Command or Action                                             | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|---------------|---------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                                               | <p><b>Note</b> When you reset the CMC to defaults, all your CMC configuration is lost and the network configuration mode is set to <b>Cisco Card</b> mode by default. The CMCs factory defaults include the following conditions:</p> <ul style="list-style-type: none"> <li>• SSH is enabled for access to the CLI. Telnet is disabled.</li> <li>• HTTPS is enabled for access to the GUI.</li> <li>• A single user account exists (user name is <b>admin</b> , password is <b>password</b> ).</li> <li>• DHCP is enabled on the management port.</li> <li>• KVM and vMedia are enabled.</li> <li>• USB is enabled.</li> <li>• SoL is disabled.</li> </ul> |
| <b>Step 3</b> | (Optional) Server /chassis # <b>show factory-reset-status</b> | Displays the factory defaults status.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

### Example

This example resets to factory defaults:

```

Server# scope chassis
Server /chassis # factory-default vic
his factory-default operation does the following on these components without any back-up:
VIC - all user configured data will deleted and controller properties reset to default
values
(Host power-cycle is required for it to be effective)
Storage - all user configured data (including OS VD/drive if any) will be deleted,
controller properties and zoning settings reset to default values (Host power-cycle is
required for it to be effective)
BMC - all Server BMC configuration reset to factory default values
CMC - all user configured data (including admin password) will be deleted and CMC settings
reset to default values
Continue?[y|N]y
factory-default for ' vic' started. Please check the status using "show factory-reset-status".
Server /chassis # show factory-reset-status
Factory Reset Status:
Storage: NA
VIC: Pending
BMC1: NA
BMC2: NA
CMC: NA
Server /chassis #

```

# Exporting and Importing the Cisco IMC and BMC Configuration

## Importing a CMC Configuration



**Important** If any firmware or BIOS updates are in progress, do not import the configuration until those tasks are complete.

### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope import-export**
3. Server /chassis/import-export # **import-config protocol ip-address path-and-filename**

### DETAILED STEPS

|               | Command or Action                                                                          | Purpose                                                                                                                                                                                                                                                                                                                            |
|---------------|--------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                               | Enters the chassis command mode.                                                                                                                                                                                                                                                                                                   |
| <b>Step 2</b> | Server /chassis # <b>scope import-export</b>                                               | Enters the import-export command mode.                                                                                                                                                                                                                                                                                             |
| <b>Step 3</b> | Server /chassis/import-export # <b>import-config protocol ip-address path-and-filename</b> | <p>The configuration file at the specified path and file name on the remote server at the specified IPv4 or IPv6 address or a hostname will be imported. The remote server can be one of the following:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> |

|  | Command or Action | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|--|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  |                   | <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> |

To determine whether the import operation has completed successfully, use the **show detail** command. To abort the operation, type CTRL+C.

### Example

This example shows how to import a configuration:

## Importing BMC Configuration



**Important** If any firmware or BIOS updates are in progress, do not import the configuration until those tasks are complete.

### SUMMARY STEPS

1. Server # **scope server** {1 | 2}
2. Server /server # **scope bmc**
3. Server /server/bmc # **scope import-export**
4. Server /server/bmc/import-export # **import-config** *protocol ip-address path-and-filename*

### DETAILED STEPS

|               | Command or Action                               | Purpose                                      |
|---------------|-------------------------------------------------|----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}            | Enters server command mode of server 1 or 2. |
| <b>Step 2</b> | Server /server # <b>scope bmc</b>               | Enters bmc command mode.                     |
| <b>Step 3</b> | Server /server/bmc # <b>scope import-export</b> | Enters the import-export command mode.       |

|               | Command or Action                                                                                    | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------------|------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 4</b> | Server /server/bmc/import-export # <b>import-config</b> <i>protocol ip-address path-and-filename</i> | <p>The configuration file at the specified path and file name on the remote server at the specified IPv4 or IPv6 address or a hostname will be imported. The remote server can be one of the following:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> |

To determine whether the import operation has completed successfully, use the **show detail** command. To abort the operation, type CTRL+C.

#### Example

This example shows how to import a configuration:

## Exporting the BMC Configuration



**Note** For security reasons, this operation does not export user accounts or the server certificate.



**Important** If any firmware or BIOS updates are in progress, do not export the configuration until those tasks are complete.

**Before you begin**

Obtain the backup remote server IP address.

**SUMMARY STEPS**

1. Server # **scope server** {1 | 2}
2. Server /server # **scope bmc**
3. Server /server/bmc # **scope import-export**
4. Server /server/bmc/import-export # **export-config** *protocol ip-address path-and-filename*

**DETAILED STEPS**

|               | <b>Command or Action</b>                                                                             | <b>Purpose</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|---------------|------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope server</b> {1   2}                                                                 | Enters server command mode of server 1 or 2.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Step 2</b> | Server /server # <b>scope bmc</b>                                                                    | Enters bmc command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| <b>Step 3</b> | Server /server/bmc # <b>scope import-export</b>                                                      | Enters the import-export command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Step 4</b> | Server /server/bmc/import-export # <b>export-config</b> <i>protocol ip-address path-and-filename</i> | <p>The configuration file will be stored at the specified path and file name on a remote server at the specified IPv4 or IPv6 address or a hostname. The remote server could be one of the following types:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> |

To determine whether the export operation has completed successfully, use the **show detail** command. To abort the operation, type CTRL+C.

### Example

This example shows how to back up the configuration:

```

Server# scope server 2
Server /server# scope bmc
Server /server/bmc # scope import-export
Server /server/bmc/import-export # export-config tftp 192.0.2.34 /ucs/backups/cimc5.xml
Username:pynj
Password:****
Export config started. Please check the status using "show detail".
Server /cimc/import-export # show detail
Import Export:
 Operation: EXPORT
 Status: COMPLETED
 Error Code: 100 (No Error)
 Diagnostic Message: NONE

Server /server/bmc/import-export #

```

## Exporting the CMC Configuration



**Note** For security reasons, this operation does not export user accounts or the server certificate.



**Important** If any firmware or BIOS updates are in progress, do not export the configuration until those tasks are complete.

### Before you begin

Obtain the backup remote server IP address.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope import-export**
3. Server /chassis/import-export # **export-config protocol ip-address path-and-filename**

### DETAILED STEPS

|               | Command or Action                                                                          | Purpose                                                                                                                                                                                                  |
|---------------|--------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                                                              | Enters chassis command mode.                                                                                                                                                                             |
| <b>Step 2</b> | Server /chassis # <b>scope import-export</b>                                               | Enters the import-export command mode.                                                                                                                                                                   |
| <b>Step 3</b> | Server /chassis/import-export # <b>export-config protocol ip-address path-and-filename</b> | The configuration file will be stored at the specified path and file name on a remote server at the specified IPv4 or IPv6 address or a hostname. The remote server could be one of the following types: |

|  | Command or Action | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|--|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  |                   | <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> |

To determine whether the export operation has completed successfully, use the **show detail** command. To abort the operation, type CTRL+C.

### Example

This example shows how to back up the configuration:

```

Server# scope chassis
Server /chassis # scope import-export
Server /chassis/import-export # export-config tftp 192.0.2.34 /ucs/backups/cimc5.xml
Username:pynj
Password:****
Passphrase:***
Export config started. Please check the status using "show detail".
Server /chassis/import-export # show detail
Import Export:
 Operation: EXPORT
 Status: COMPLETED
 Error Code: 100 (No Error)
 Diagnostic Message: NONE

Server /chassis/import-export #

```

## Exporting VIC Adapter Configuration



**Important** If any firmware or BIOS updates are in progress, do not export the VIC adapter configuration until those tasks are complete.

### SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **export-all-adapters** *protocol ip-address path-and-filename*

### DETAILED STEPS

|               | Command or Action                                                                         | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------------|-------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                              | Enters the chassis command mode.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Step 2</b> | Server /chassis # <b>export-all-adapters</b> <i>protocol ip-address path-and-filename</i> | <p>The configuration file at the specified path and file name on the remote server at the specified IPv4 or IPv6 address or a hostname will be imported. The remote server can be one of the following:</p> <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> <p><b>Note</b> The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> |

To determine whether the export operation has completed successfully, use the **show detail** command. To abort the operation, type CTRL+C.



**Example**

This example shows how to export a VIC adapter configuration:

## Importing VIC Adapter Configuration




---

**Important** If any firmware or BIOS updates are in progress, do not import the VIC Adapter configuration until those tasks are complete.

---

**SUMMARY STEPS**

1. Server# **scope chassis**
2. Server /chassis # **import-all-adapters protocol ip-address path-and-filename**
3. Enter the username, and password.

**DETAILED STEPS**

|               | <b>Command or Action</b>                                                           | <b>Purpose</b>                                                                                                                                                                                                                                                                                                              |
|---------------|------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server# <b>scope chassis</b>                                                       | Enters the chassis command mode.                                                                                                                                                                                                                                                                                            |
| <b>Step 2</b> | Server /chassis # <b>import-all-adapters protocol ip-address path-and-filename</b> | The configuration file at the specified path and file name on the remote server at the specified IPv4 or IPv6 address or a hostname will be imported. The remote server can be one of the following: <ul style="list-style-type: none"> <li>• TFTP</li> <li>• FTP</li> <li>• SFTP</li> <li>• SCP</li> <li>• HTTP</li> </ul> |

|               | Command or Action                 | Purpose                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|---------------|-----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|               |                                   | <p><b>Note</b></p> <p>The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type.</p> <p>If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is &lt;server_finger_print_ID&gt; Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint.</p> <p>The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.</p> |
| <b>Step 3</b> | Enter the username, and password. | Starts the import operation.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

To determine whether the import operation has completed successfully, use the **show detail** command. To abort the operation, type CTRL+C.

### Example

This example shows how to import the VIC adapter configuration:

## Generating Non-Maskable Interrupts to the Host

In some situations, the server might hang and not respond to traditional debug mechanisms. By generating a non maskable interrupt (NMI) to the host, you can create and send a crash dump file of the server and use it to debug the server.

Depending on the type of operating system associated with the server, this task might restart the OS.

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis/server # **generate-nmi**

### DETAILED STEPS

|               | Command or Action                             | Purpose                                       |
|---------------|-----------------------------------------------|-----------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                 | Enters chassis command mode.                  |
| <b>Step 2</b> | Server /chassis # <b>scope server {1   2}</b> | Enters server command mode of server 1 or 2.  |
| <b>Step 3</b> | Server /chassis/server # <b>generate-nmi</b>  | Generates the crash dump file for the server. |

|  | Command or Action | Purpose                                                                                            |
|--|-------------------|----------------------------------------------------------------------------------------------------|
|  |                   | To use this command, the server must be powered on, and you must be logged in as an administrator. |

### Example

This example shows how to generate NMI signals to the host:

```
Server # scope chassis
Server /chassis # scope server 2
Server /chassis/server # generate-nmi
This operation will send NMI to host and may cause reboot of OS
OS reboot depends on it's NMI configuration
Do you want to continue? [y|N] y
Server /chassis/server #
```

## Adding Cisco IMC Banner

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **upload-banner**
3. Enter the banner and press CTRL+D.
4. (Optional) Server /chassis # **show-banner**

### DETAILED STEPS

|               | Command or Action                               | Purpose                                                                                                                            |
|---------------|-------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>                   | Enters chassis command mode.                                                                                                       |
| <b>Step 2</b> | Server /chassis # <b>upload-banner</b>          | A prompt to enter the banner displays.                                                                                             |
| <b>Step 3</b> | Enter the banner and press CTRL+D.              | At the prompt, enter <b>y</b> . This results in a loss of the current session, when you log back on again, the new banner appears. |
| <b>Step 4</b> | (Optional) Server /chassis # <b>show-banner</b> | The banner that you have added displays.                                                                                           |

### Example

This example shows how to add the Cisco IMC banner:

```
Server # scope chassis
Server /chassis # upload-banner
Please paste your custom banner here, when finished, press enter and CTRL+D.
hello world
This will terminate all open SSH session to take an immediate action.
Do you wish to continue? [y/N] yy
Server /chassis # show-banner
```

```
hello world
Server /chassis #
```

## Downloading and Viewing Inventory Details

You can retrieve and save in a file, the following inventory details from the Web UI:

- System Properties
- CPU Information
- Power supply unit inventory
- PCI adapters Cards
- Memory Details
- Trusted Platform Module information
- Disk Information
- Network interface card
- Storage adapter card
- Virtual interface card
- Fan status
- Flex flash card
- BBU Status

### SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **inventory-refresh**
3. Server /chassis # **inventory-all**

### DETAILED STEPS

|               | Command or Action                          | Purpose                                                              |
|---------------|--------------------------------------------|----------------------------------------------------------------------|
| <b>Step 1</b> | Server # <b>scope chassis</b>              | Enters chassis command mode.                                         |
| <b>Step 2</b> | Server /chassis # <b>inventory-refresh</b> | Initiates the data collection activity and saves the data in a file. |
| <b>Step 3</b> | Server /chassis # <b>inventory-all</b>     | Displays inventory information.                                      |

### Example

This example shows the inventory details and the status of inventory collection :

```
Server# scope chassis
Server /chassis #inventory-refresh

Inventory data collection started.

Server /chassis #inventory-all

Hardware Inventory Information:
Status: IN-PROGRESS
Progress(%): 5
...
Progress(%): 50
sysProductName: UCS C240 M3S
sysProductID: UCSC-C240-M3S
sysSerialNum: FCH1925V21U
...
CPU
id: 1
SocketDesignation: CPU1
ProcessorManufacturer: Intel(R) Corporation
ProcessorFamily: Xeon
ThreadCount: 4
Server /chassis #
```





## APPENDIX **A**

# BIOS Parameters by Server Model

This appendix contains the following sections:

- [S3260 M3 Servers, on page 387](#)
- [S3260 M4 Servers, on page 407](#)
- [S3260 M5 Servers, on page 432](#)

## S3260 M3 Servers

### Main Tab

| Name                                       | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|--------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Reboot Host Immediately</b><br>checkbox | Upon checking, reboots the host server immediately. You must check the checkbox after saving changes.                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>TPM Support</b><br>set TPMAdminCtrl     | <p>TPM (Trusted Platform Module) is a microchip designed to provide basic security-related functions primarily involving encryption keys. This option allows you to control the TPM Security Device support for the system. It can be one of the following:</p> <ul style="list-style-type: none"><li>• <b>Disabled</b>—The server does not use the TPM.</li><li>• <b>Enabled</b>—The server uses the TPM.</li></ul> <p><b>Note</b> We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p> |

| Name                                          | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-----------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Power ON Password Support</b><br>drop-down | <p>This token requires that you set a BIOS password before using the F2 BIOS configuration. If enabled, password needs to be validated before you access BIOS functions such as IO configuration, BIOS set up, and booting to an operating system using BIOS. It can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>Enabled</b>—Support is enabled.</li> </ul> <p><b>Note</b> This field is available only on some C-series servers.</p> |

#### Actions Area

| Name                           | Description                                                                                                                                                                                                                                                                                                           |
|--------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Save</b> button             | <p>Saves the settings for the BIOS parameters on all three tabs and closes the dialog box.</p> <p>If the <b>Reboot Host Immediately</b> check box is checked, the server is rebooted immediately and the new BIOS settings go into effect. Otherwise the changes are saved until the server is manually rebooted.</p> |
| <b>Reset</b> button            | Resets the values for the BIOS parameters on all three tabs to the settings that were in effect when this dialog box was first opened.                                                                                                                                                                                |
| <b>Restore Defaults</b> button | Sets the BIOS parameters on all three tabs to their default settings.                                                                                                                                                                                                                                                 |

## Advanced Tab

#### Reboot Server Option

If you want to apply your changes at a later time, clear the **Reboot Host Immediately** check box. stores the changes and applies them the next time the server reboots.




---

**Note** If there are existing BIOS parameter changes pending, automatically overwrites the stored values with the current settings when you click **Save Changes**.

---



## Processor Configuration Parameters

| Name                                                                   | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Intel Hyper-Threading Technology</b><br><b>set IntelHyperThread</b> | <p>Whether the processor uses Intel Hyper-Threading Technology, which allows multithreaded software applications to execute threads in parallel within each processor. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit hyperthreading.</li> <li>• <b>Enabled</b>—The processor allows for the parallel execution of multiple threads.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>                                                                                                                                           |
| <b>Number of Enabled Cores</b><br><b>set CoreMultiProcessing</b>       | <p>Allows you to disable one or more of the physical cores on the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>All</b>—Enables all physical cores. This also enables Hyper Threading on the associated logical processor cores.</li> <li>• <b>1 through <i>n</i></b>—Specifies the number of physical processor cores that can run on the server. Each physical core has an associated logical core.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>                                                                                                            |
| <b>Execute Disable</b><br><b>set ExecuteDisable</b>                    | <p>Classifies memory areas on the server to specify where application code can execute. As a result of this classification, the processor disables code execution if a malicious worm attempts to insert code in the buffer. This setting helps to prevent damage, worm propagation, and certain classes of malicious buffer overflow attacks. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not classify memory areas.</li> <li>• <b>Enabled</b>—The processor classifies memory areas.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p> |
| <b>Intel VT</b><br><b>set IntelVT</b>                                  | <p>Whether the processor uses Intel Virtualization Technology (VT), which allows a platform to run multiple operating systems and applications in independent partitions. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit virtualization.</li> <li>• <b>Enabled</b>—The processor allows multiple operating systems in independent partitions.</li> </ul> <p><b>Note</b> If you change this option, you must power cycle the server before the setting takes effect.</p>                                                                                                                                              |

| Name                                                               | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|--------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Intel VT-d</b><br><b>set IntelVTD</b>                           | Whether the processor uses Intel Virtualization Technology for Directed I/O (VT-d). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not use virtualization technology.</li> <li>• <b>Enabled</b>—The processor uses virtualization technology.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Intel VT-d Coherency Support</b><br><b>set CoherencySupport</b> | Whether the processor supports Intel VT-d Coherency. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support coherency.</li> <li>• <b>Enabled</b>—The processor uses VT-d Coherency as required.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Intel VT-d ATS Support</b><br><b>set ATS</b>                    | Whether the processor supports Intel VT-d Address Translation Services (ATS). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support ATS.</li> <li>• <b>Enabled</b>—The processor uses VT-d ATS as required.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>CPU Performance</b><br><b>set CPUPerformance</b>                | Sets the CPU performance profile for the server. The performance profile consists of the following options: <ul style="list-style-type: none"> <li>• DCU Streamer Prefetcher</li> <li>• DCU IP Prefetcher</li> <li>• Hardware Prefetcher</li> <li>• Adjacent Cache-Line Prefetch</li> </ul> This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Enterprise</b>—All options are enabled.</li> <li>• <b>High Throughput</b>—Only the DCU IP Prefetcher is enabled. The rest of the options are disabled.</li> <li>• <b>HPC</b>—All options are enabled. This setting is also known as high performance computing.</li> <li>• <b>Custom</b>—All performance profile options can be configured from the BIOS setup on the server. In addition, the Hardware Prefetcher and Adjacent Cache-Line Prefetch options can be configured in the fields below.</li> </ul> |

| Name                                                                          | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|-------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Hardware Prefetcher</b><br><b>set HardwarePrefetch</b>                     | Whether the processor allows the Intel hardware prefetcher to fetch streams of data and instruction from memory into the unified second-level cache when necessary. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The hardware prefetcher is not used.</li> <li>• <b>Enabled</b>—The processor uses the hardware prefetcher when cache issues are detected.</li> </ul>                                                                                                                          |
| <b>Adjacent Cache Line Prefetcher</b><br><b>set AdjacentCacheLinePrefetch</b> | Whether the processor fetches cache lines in even/odd pairs instead of fetching just the required line. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor only fetches the required line.</li> <li>• <b>Enabled</b>— The processor fetches both the required line and its paired line.</li> </ul>                                                                                                                                                                                     |
| <b>DCU Streamer Prefetch</b><br><b>set DcuStreamerPrefetch</b>                | Whether the processor uses the DCU IP Prefetch mechanism to analyze historical cache access patterns and preload the most relevant lines in the L1 cache. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not try to anticipate cache read requirements and only fetches explicitly requested lines.</li> <li>• <b>Enabled</b>—The DCU prefetcher analyzes the cache read pattern and prefetches the next line in the cache if it determines that it may be needed.</li> </ul> |
| <b>DCU IP Prefetcher</b><br><b>set DcuIpPrefetch</b>                          | Whether the processor uses the DCU IP Prefetch mechanism to analyze historical cache access patterns and preload the most relevant lines in the L1 cache. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not preload any cache data.</li> <li>• <b>Enabled</b>—The DCU IP prefetcher preloads the L1 cache with the data it determines to be the most relevant.</li> </ul>                                                                                                    |
| <b>Direct Cache Access Support</b><br><b>set DirectCacheAccess</b>            | Allows processors to increase I/O performance by placing data from I/O devices directly into the processor cache. This setting helps to reduce cache misses. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Data from I/O devices is not placed directly into the processor cache.</li> <li>• <b>Enabled</b>—Data from I/O devices is placed directly into the processor cache.</li> </ul>                                                                                                       |

| Name                                                                                    | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-----------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Power Technology</b><br/>set <b>CPUPowerManagement</b></p>                        | <p>Enables you to configure the CPU power management settings for the following options:</p> <ul style="list-style-type: none"> <li>• Enhanced Intel Speedstep Technology</li> <li>• Intel Turbo Boost Technology</li> <li>• Processor Power State C6</li> </ul> <p>Power Technology can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Custom</b>—The server uses the individual settings for the BIOS parameters mentioned above. You must select this option if you want to change any of these BIOS parameters.</li> <li>• <b>Disabled</b>—The server does not perform any CPU power management and any settings for the BIOS parameters mentioned above are ignored.</li> <li>• <b>Energy_Efficient</b>—The server determines the best settings for the BIOS parameters mentioned above and ignores the individual settings for these parameters.</li> </ul> |
| <p><b>Enhanced Intel Speedstep Technology</b><br/>set <b>EnhancedIntelSpeedStep</b></p> | <p>Whether the processor uses Enhanced Intel SpeedStep Technology, which allows the system to dynamically adjust processor voltage and core frequency. This technology can result in decreased average power consumption and decreased average heat production. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor never dynamically adjusts its voltage or frequency.</li> <li>• <b>Enabled</b>—The processor utilizes Enhanced Intel SpeedStep Technology and enables all supported processor sleep states to further conserve power.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p> <p><b>Note</b>      <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>                |

| Name                                                                      | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Intel Turbo Boost Technology</b><br><b>set IntelTurboBoostTech</b>     | <p>Whether the processor uses Intel Turbo Boost Technology, which allows the processor to automatically increase its frequency if it is running below power, temperature, or voltage specifications. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not increase its frequency automatically.</li> <li>• <b>Enabled</b>—The processor utilizes Turbo Boost Technology if required.</li> </ul> <p><b>Note</b>      <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>                                                         |
| <b>Processor Power State C6</b><br><b>set ProcessorC6Report</b>           | <p>Whether the BIOS sends the C6 report to the operating system. When the OS receives the report, it can transition the processor into the lower C6 power state to decrease energy usage while maintaining optimal processor performance. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The BIOS does not send the C6 report.</li> <li>• <b>Enabled</b>—The BIOS sends the C6 report, allowing the OS to transition the processor to the C6 low power state.</li> </ul> <p><b>Note</b>      <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p> |
| <b>Processor Power State C1 Enhanced</b><br><b>set ProcessorC1EReport</b> | <p>Whether the CPU transitions to its minimum frequency when entering the C1 state. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The CPU continues to run at its maximum frequency in C1 state.</li> <li>• <b>Enabled</b>—The CPU transitions to its minimum frequency. This option saves the maximum amount of power in C1 state.</li> </ul>                                                                                                                                                                                                                                                               |
| <b>Frequency Floor Override</b><br><b>set CpuFreqFloor</b>                | <p>Whether the CPU is allowed to drop below the maximum non-turbo frequency when idle. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>— The CPU can drop below the maximum non-turbo frequency when idle. This option decreases power consumption but may reduce system performance.</li> <li>• <b>Enabled</b>— The CPU cannot drop below the maximum non-turbo frequency when idle. This option improves system performance but may increase power consumption.</li> </ul>                                                                                                                                    |

| Name                                                    | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|---------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>P-STATE Coordination</b><br/>set PsdCoordType</p> | <p>Allows you to define how BIOS communicates the P-state support model to the operating system. There are 3 models as defined by the Advanced Configuration and Power Interface (ACPI) specification.</p> <ul style="list-style-type: none"> <li>• <b>HW_ALL</b>—The processor hardware is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a package).</li> <li>• <b>SW_ALL</b>—The OS Power Manager (OSPM) is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a physical package), and must initiate the transition on all of the logical processors.</li> <li>• <b>SW_ANY</b>—The OS Power Manager (OSPM) is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a package), and may initiate the transition on any of the logical processors in the domain.</li> </ul> <p><b>Note</b>      <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p> |
| <p><b>Energy Performance</b><br/>set CpuEngPerfBias</p> | <p>Allows you to determine whether system performance or energy efficiency is more important on this server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Balanced_Energy</b></li> <li>• <b>Balanced_Performance</b></li> <li>• <b>Energy_Efficient</b></li> <li>• <b>Performance</b></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

### Memory Configuration Parameters

| Name                                                           | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|----------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Select Memory RAS</b><br><b>set SelectMemoryRAS</b>         | <p>How the memory reliability, availability, and serviceability (RAS) is configured for the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Maximum_Performance</b>—System performance is optimized.</li> <li>• <b>Mirroring</b>—System reliability is optimized by using half the system memory as backup.</li> <li>• <b>Lockstep</b>—If the DIMM pairs in the server have an identical type, size, and organization and are populated across the SMI channels, you can enable lockstep mode to minimize memory access latency and provide better performance. This option offers better system performance than Mirroring and better reliability than Maximum Performance but lower reliability than Mirroring and lower system performance than Maximum Performance.</li> </ul> |
| <b>DRAM Clock Throttling</b><br><b>set DRAMClockThrottling</b> | <p>Allows you to tune the system settings between the memory bandwidth and power consumption. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Balanced</b>—DRAM clock throttling is reduced, providing a balance between performance and power.</li> <li>• <b>Performance</b>—DRAM clock throttling is disabled, providing increased memory bandwidth at the cost of additional power.</li> <li>• <b>Energy_Efficient</b>—DRAM clock throttling is increased to improve energy efficiency.</li> </ul>                                                                                                                                                                                                                                                                                      |
| <b>NUMA</b><br><b>set NUMAOptimize</b>                         | <p>Whether the BIOS supports Non-Uniform Memory Access (NUMA). This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The BIOS does not support NUMA.</li> <li>• <b>Enabled</b>—The BIOS includes the ACPI tables that are required for NUMA-aware operating systems. If you enable this option, the system must disable Inter-Socket Memory interleaving on some platforms.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                              |

| Name                                                 | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Low Voltage DDR Mode</b><br>set LvDDRMode         | Whether the system prioritizes low voltage or high frequency memory operations. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Power_Saving_Mode</b>—The system prioritizes low voltage memory operations over high frequency memory operations. This mode may lower memory frequency in order to keep the voltage low.</li> <li>• <b>Performance_Mode</b>—The system prioritizes high frequency operations over low voltage operations.</li> </ul>                                                                             |
| <b>DRAM Refresh rate</b><br>set DramRefreshRate      | Allows you to set the rate at which the DRAM cells are refreshed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>1x</b>—DRAM cells are refreshed every 64ms.</li> <li>• <b>2x</b>—DRAM cells are refreshed every 32ms.</li> <li>• <b>3x</b>—DRAM cells are refreshed every 21ms.</li> <li>• <b>4x</b>—DRAM cells are refreshed every 16ms.</li> <li>• <b>Auto</b>—DRAM cells refresh rate is automatically chosen by the BIOS based on the system configuration. This is the recommended setting for this parameter.</li> </ul> |
| <b>Channel Interleaving</b><br>set ChannelInterLeave | Whether the CPU divides memory blocks and spreads contiguous portions of data across interleaved channels to enable simultaneous read operations. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines what interleaving is done.</li> <li>• <b>1_Way</b>—Some channel interleaving is used.</li> <li>• <b>2_Way</b></li> <li>• <b>3_Way</b></li> <li>• <b>4_Way</b>—The maximum amount of channel interleaving is used.</li> </ul>                                                                       |
| <b>Rank Interleaving</b><br>set RankInterLeave       | Whether the CPU interleaves physical ranks of memory so that one rank can be accessed while another is being refreshed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines what interleaving is done.</li> <li>• <b>1_Way</b>—Some rank interleaving is used.</li> <li>• <b>2_Way</b></li> <li>• <b>4_Way</b></li> <li>• <b>8_Way</b>—The maximum amount of rank interleaving is used.</li> </ul>                                                                                                       |



| Name                                          | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|-----------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Patrol Scrub</b><br><b>set PatrolScrub</b> | <p>Whether the system actively searches for, and corrects, single bit memory errors even in unused portions of the memory on the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The system checks for memory ECC errors only when the CPU reads or writes a memory address.</li> <li>• <b>Enabled</b>—The system periodically reads and writes memory searching for ECC errors. If any errors are found, the system attempts to fix them. This option may correct single bit errors before they become multi-bit errors, but it may adversely affect performance when the patrol scrub is running.</li> </ul> |
| <b>Demand Scrub</b><br><b>set DemandScrub</b> | <p>Whether the system corrects single bit memory errors encountered when the CPU or I/O makes a demand read. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Single bit memory errors are not corrected.</li> <li>• <b>Enabled</b>— Single bit memory errors are corrected in memory and the corrected data is set in response to the demand read.</li> </ul>                                                                                                                                                                                                                                                         |
| <b>Altitude</b><br><b>set Altitude</b>        | <p>The approximate number of meters above sea level at which the physical server is installed. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines the physical elevation.</li> <li>• <b>300_M</b>—The server is approximately 300 meters above sea level.</li> <li>• <b>900_M</b>—The server is approximately 900 meters above sea level.</li> <li>• <b>1500_M</b>—The server is approximately 1500 meters above sea level.</li> <li>• <b>3000_M</b>—The server is approximately 3000 meters above sea level.</li> </ul>                                                                                   |

## QPI Configuration Parameters

| Name                                                            | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|-----------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>QPI Link Frequency Select</b><br>set <b>QPILinkFrequency</b> | The Intel QuickPath Interconnect (QPI) link frequency, in gigatransfers per second (GT/s). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines the QPI link frequency.</li> <li>• <b>6.4_GT/s</b></li> <li>• <b>7.2_GT/s</b></li> <li>• <b>8.0_GT/s</b></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>QPI Snoop Mode</b> Drop-down list                            | The Intel QuickPath Interconnect (QPI) snoop mode. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU automatically recognizes this as Early Snoop mode.</li> <li>• <b>Early Snoop</b>—The distributed cache ring stops can send a snoop probe or a request to another caching agent directly. This mode has lower latency and it is best for workloads that have shared data sets across threads and can benefit from a cache-to-cache transfer, or for workloads that are not NUMA optimized.</li> <li>• <b>Home Snoop</b>—The snoop is always spawned by the home agent (centralized ring stop) for the memory controller. This mode has a higher local latency than early snoop, but it provides extra resources for a larger number of outstanding transactions.</li> <li>• <b>Home Directory Snoop</b>— The home directory is an optional enabled feature that is implemented at both the HA and iMC logic in the processor. The goal of the directory is to filter snoops to the remote sockets and a node controller in scalable platforms and 2S and 4S configurations.</li> <li>• <b>Home Directory Snoop with OSB</b>— In the Opportunistic Snoop Broadcast (OSB) directory mode, the HA could choose to do speculative home snoop broadcast under very lightly loaded conditions even before the directory information has been collected and checked.</li> <li>• <b>Cluster on Die</b>—Enables Cluster On Die. When enabled LLC is split into two parts with an independent caching agent for each. This helps increase the performance in some workloads. This mode is available only for processors that have 10 or more cores. It is the best mode for highly NUMA optimized workloads.</li> </ul> |

**SATA Configuration Parameters**

| Name                                    | Description                                                                                                                                                                                                                                                                                                                                                       |
|-----------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>SATA Mode</b><br><b>set SataMode</b> | Mode of operation of Serial Advanced Technology Attachment (SATA) Solid State Drives (SSD). <ul style="list-style-type: none"> <li>• <b>Disabled</b>— All SATA ports is disabled, and drivers are not enumerated.</li> <li>• <b>AHCI Mode</b>—The default mode. Drives operate according to newer standard of Advance Host Controller Interface(AHCI).</li> </ul> |

**USB Configuration Parameters**

| Name                                                     | Description                                                                                                                                                                                                                                                                                                                                                                                                                          |
|----------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Legacy USB Support</b><br><b>set LegacyUSBSupport</b> | Whether the system supports legacy USB devices. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—USB devices are only available to EFI applications.</li> <li>• <b>Enabled</b>—Legacy USB support is always available.</li> <li>• <b>Auto</b>—Disables legacy USB support if no USB devices are connected.</li> </ul>                                                                      |
| <b>Port 60/64 Emulation</b><br><b>set UsbEmul6064</b>    | Whether the system supports 60h/64h emulation for complete USB keyboard legacy support. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—60h/64 emulation is not supported.</li> <li>• <b>Enabled</b>—60h/64 emulation is supported.</li> </ul> You should select this option if you are using a non-USB aware operating system on the server.                                             |
| <b>All USB Devices</b><br><b>set AllUsbDevices</b>       | Whether all physical and virtual USB devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—All USB devices are disabled.</li> <li>• <b>Enabled</b>—All USB devices are enabled.</li> </ul>                                                                                                                                                                     |
| <b>USB Port: Rear</b><br><b>set UsbPortRear</b>          | Whether the rear panel USB devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the rear panel USB ports. Devices connected to these ports are not detected by the BIOS and operating system.</li> <li>• <b>Enabled</b>—Enables the rear panel USB ports. Devices connected to these ports are detected by the BIOS and operating system.</li> </ul> |

| Name                                                      | Description                                                                                                                                                                                                                                                                                                                                                                                                                    |
|-----------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>USB Port: Internal</b><br>set <code>UsbPortInt</code>  | Whether the internal USB devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the internal USB ports. Devices connected to these ports are not detected by the BIOS and operating system.</li> <li>• <b>Enabled</b>—Enables the internal USB ports. Devices connected to these ports are detected by the BIOS and operating system.</li> </ul> |
| <b>USB Port: KVM</b><br>set <code>UsbPortKVM</code>       | Whether the vKVM ports are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the vKVM keyboard and/or mouse devices. Keyboard and/or mouse will not work in the vKVM window.</li> <li>• <b>Enabled</b>—Enables the vKVM keyboard and/or mouse devices.</li> </ul>                                                                                       |
| <b>USB Port: vMedia</b><br>set <code>UsbPortVMedia</code> | Whether the virtual media devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the vMedia devices.</li> <li>• <b>Enabled</b>—Enables the vMedia devices.</li> </ul>                                                                                                                                                                            |

### PCI Configuration Parameters

| Name                                                | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|-----------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>PCI ROM CLP</b><br>set <code>PciRomClp</code>    | PCI ROM Command Line Protocol (CLP) controls the execution of different Option ROMs such as PxE and iSCSI that are present in the card. By default, it is disabled. <ul style="list-style-type: none"> <li>• <b>Enabled</b>— Enables you to configure execution of different option ROMs such as PxE and iSCSI for an individual ports separately.</li> <li>• <b>Disabled</b>—The default option. You cannot choose different option ROMs. A default option ROM is executed during PCI enumeration.</li> </ul> |
| <b>ASPM Support</b><br>set <code>ASPMSupport</code> | Allows you to set the level of ASPM (Active Power State Management) support in the BIOS. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—ASPM support is disabled in the BIOS.</li> <li>• <b>Force L0s</b>—Force all links to L0 standby (L0s) state.</li> <li>• <b>Auto</b>—The CPU determines the power state.</li> </ul>                                                                                                                                         |

## Serial Configuration Parameters

| Name                                                     | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|----------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Out-of-Band Mgmt Port</b><br><b>set comSpcrEnable</b> | <p>Allows you to configure the COM port 0 that can be used for Windows Emergency Management services. ACPI SPCR table is reported based on this setup option. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Configures the COM port 0 as a general purpose port for use with the Windows Operating System.</li> <li>• <b>Enabled</b>—Configures the COM port 0 as a remote management port for Windows Emergency Management services.</li> </ul>                                                                                     |
| <b>Console Redirection</b><br><b>set ConsoleRedir</b>    | <p>Allows a serial port to be used for console redirection during POST and BIOS booting. After the BIOS has booted and the operating system is responsible for the server, console redirection is irrelevant and has no effect. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—No console redirection occurs during POST.</li> <li>• <b>COM_0</b>—Enables console redirection on COM port 0 during POST.</li> <li>• <b>COM_1</b>—Enables console redirection on COM port 1 during POST.</li> </ul>                                    |
| <b>Terminal Type</b><br><b>set TerminalType</b>          | <p>What type of character formatting is used for console redirection. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>PC-ANSI</b>—The PC-ANSI terminal font is used.</li> <li>• <b>VT100</b>—A supported vt100 video terminal and its character set are used.</li> <li>• <b>VT100+</b>—A supported vt100-plus video terminal and its character set are used.</li> <li>• <b>VT-UTF8</b>—A video terminal with the UTF-8 character set is used.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p> |

| Name                                          | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-----------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Bits per second</b><br><b>set BaudRate</b> | <p>What BAUD rate is used for the serial port transmission speed. If you disable Console Redirection, this option is not available. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>9600</b>—A 9,600 BAUD rate is used.</li> <li>• <b>19200</b>—A 19,200 BAUD rate is used.</li> <li>• <b>38400</b>—A 38,400 BAUD rate is used.</li> <li>• <b>57600</b>—A 57,600 BAUD rate is used.</li> <li>• <b>115200</b>—A 115,200 BAUD rate is used.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p> |
| <b>Flow Control</b><br><b>set FlowCtrl</b>    | <p>Whether a handshake protocol is used for flow control. Request to Send / Clear to Send (RTS/CTS) helps to reduce frame collisions that can be introduced by a hidden terminal problem. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>None</b>—No flow control is used.</li> <li>• <b>Hardware_RTS/CTS</b>—RTS/CTS is used for flow control.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p>                                                                                          |

| Name                                                                  | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-----------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Putty KeyPad</b><br><b>set PuttyFunctionKeyPad</b>                 | <p>Allows you to change the action of the PuTTY function keys and the top row of the numeric keypad. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>VT100</b>—The function keys generate <b>ESC OP</b> through <b>ESC O[</b>.</li> <li>• <b>LINUX</b>—Mimics the Linux virtual console. Function keys F6 to F12 behave like the default mode, but F1 to F5 generate <b>ESC [ [A</b> through <b>ESC [ [E</b>.</li> <li>• <b>XTERMR6</b>—Function keys F5 to F12 behave like the default mode. Function keys F1 to F4 generate <b>ESC OP</b> through <b>ESC OS</b>, which are the sequences produced by the top row of the keypad on Digital terminals.</li> <li>• <b>SCO</b>—The function keys F1 to F12 generate <b>ESC [M</b> through <b>ESC [X</b>. The function and shift keys generate <b>ESC [Y</b> through <b>ESC [j</b>. The control and function keys generate <b>ESC [k</b> through <b>ESC [v</b>. The shift, control and function keys generate <b>ESC [w</b> through <b>ESC [t</b>.</li> <li>• <b>ESCN</b>—The default mode. The function keys match the general behavior of Digital terminals. The function keys generate sequences such as <b>ESC [11~</b> and <b>ESC [12~</b>.</li> <li>• <b>VT400</b>—The function keys behave like the default mode. The top row of the numeric keypad generates <b>ESC OP</b> through <b>ESC OS</b>.</li> </ul> |
| <b>Redirection After BIOS POST</b><br><b>set RedirectionAfterPOST</b> | <p>Whether BIOS console redirection should be active after BIOS POST is complete and control given to the OS bootloader. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Always_Enable</b>—BIOS Legacy console redirection is active during the OS boot and run time.</li> <li>• <b>Bootloader</b>—BIOS Legacy console redirection is disabled before giving control to the OS boot loader.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |

### LOM and PCIe Slots Configuration Parameters

| Name                                               | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|----------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>CDN Support for VIC</b><br><b>set CdnEnable</b> | <p>Whether the Ethernet Network naming convention is according to Consistent Device Naming (CDN) or the traditional way of naming conventions. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>— CDN support for VIC cards is disabled.</li> <li>• <b>Enabled</b>— CDN support is enabled for VIC cards.</li> </ul> <p><b>Note</b>      CDN support for VIC cards work with Windows 2012 or the latest OS only.</p> |

| Name                                                                              | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>All PCIe Slots OptionROM</b><br>set <code>PcieOptionROMs</code>                | Whether the server can use Option ROM present in the PCIe Cards. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for all PCIe slots are not available.</li> <li>• <b>Enabled</b>—The Option ROMs for all the PCIe slots are available.</li> <li>• <b>UEFI_Only</b>—The Option ROMs for slot <i>n</i> are available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot <i>n</i> are available for legacy only.</li> </ul>    |
| <b>PCIe Slot:<i>n</i> OptionROM</b><br>set <code>PcieSlot<i>n</i>OptionROM</code> | Whether the server can use the Option ROMs present in the PCIe Cards. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for slot <i>n</i> is not available.</li> <li>• <b>Enabled</b>—The Option ROM for slot <i>n</i> is available.</li> <li>• <b>UEFI_Only</b>—The Option ROM for slot <i>n</i> is available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot <i>n</i> is available for legacy only.</li> </ul>           |
| <b>PCIe Mezzanine OptionROM</b><br>set <code>PcieMezzOptionROM</code>             | Whether the PCIe mezzanine slot expansion ROM is available to the server. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— The Option ROM for slot <i>M</i> is not available.</li> <li>• <b>Enabled</b>— The Option ROM for slot <i>M</i> is available.</li> <li>• <b>UEFI_Only</b>—The Option ROM for slot <i>M</i> is available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The expansion slot for slot <i>M</i> is available for legacy only.</li> </ul> |
| <b>SIOC1 Link Speed</b><br>Set <code>PcieSlot1LinkSpeed</code>                    | System IO Controller 1 (SIOC1) add-on slot 1 link speed. <ul style="list-style-type: none"> <li>• <b>GEN1</b> — Link speed can reach up to first generation.</li> <li>• <b>GEN2</b> — Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— The default link speed. Link speed can reach up to third generation.</li> <li>• <b>Disabled</b> — Slot is disabled, and the card is not enumerated.</li> </ul>                                                                              |



| Name                                                     | Description                                                                                                                                                                                                                                                                                                                                                                                                                |
|----------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>SIOC2 Link Speed</b><br><b>set PcieSlot2LinkSpeed</b> | System IO Controller 2 (SIOC2) add-on slot 2 link speed. <ul style="list-style-type: none"> <li>• <b>GEN1</b> — Link speed can reach up to first generation.</li> <li>• <b>GEN2</b> — Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— The default link speed. Link speed can reach up to third generation.</li> <li>• <b>Disabled</b> — Slot is disabled, and the card is not enumerated.</li> </ul> |
| <b>Mezz Link Speed</b>                                   | Mezz link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>—The default link speed. Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>         |

### BIOS Configuration Dialog Box Button Bar



**Important** The buttons in this dialog box affect all BIOS parameters on all available tabs, not just the parameters on the tab that you are viewing.

| Name                           | Description                                                                                                                                                                                                                                                                                                    |
|--------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Save Changes</b> button     | Saves the settings for the BIOS parameters on all three tabs and closes the dialog box.<br><br>If the <b>Reboot Host Immediately</b> check box is checked, the server is rebooted immediately and the new BIOS settings go into effect. Otherwise the changes are saved until the server is manually rebooted. |
| <b>Reset</b> button            | Restores the values for the BIOS parameters on all three tabs to the settings that were in effect when this dialog box was first opened.                                                                                                                                                                       |
| <b>Restore Defaults</b> button | Sets the BIOS parameters on all three tabs to their default settings.                                                                                                                                                                                                                                          |

## Server Management Tab

### Server Management BIOS Parameters

| Name                                                                      | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>FRB-2 Timer</b><br><b>set FRB-2</b>                                    | Whether the FRB2 timer is used by to recover the system if it hangs during POST. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The FRB2 timer is not used.</li> <li>• <b>Enabled</b>—The FRB2 timer is started during POST and used to recover the system if necessary.</li> </ul>                                                                                                                                                                                                                                                                                                                                                              |
| <b>OS Watchdog Timer</b><br><b>set OSBootWatchdogTimer</b>                | Whether the BIOS programs the watchdog timer with a specified timeout value. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The watchdog timer is not used to track how long the server takes to boot.</li> <li>• <b>Enabled</b>—The watchdog timer tracks how long the server takes to boot. If the server does not boot within the length of time specified by the <b>set OSBootWatchdogTimerTimeout</b> command, the logs an error and takes the action specified by the <b>set OSBootWatchdogTimerPolicy</b> command.</li> </ul>                                                                                                             |
| <b>OS Watchdog Timer Timeout</b><br><b>set OSBootWatchdogTimerTimeOut</b> | If OS does not boot within the specified time, OS watchdog timer expires and system takes action according to timer policy. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>5_Minutes</b>—The OS watchdog timer expires 5 minutes after it begins to boot.</li> <li>• <b>10_Minutes</b>—The OS watchdog timer expires 10 minutes after it begins to boot.</li> <li>• <b>15_Minutes</b>—The OS watchdog timer expires 15 minutes after it begins to boot.</li> <li>• <b>20_Minutes</b>—The OS watchdog timer expires 20 minutes after it begins to boot.</li> </ul> <p><b>Note</b> This option is only applicable if you enable the OS Boot Watchdog Timer.</p> |

| Name                                                             | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>OS Watchdog Timer Policy</b><br>set OSBootWatchdogTimerPolicy | <p>What action the system takes if the watchdog timer expires. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Do_Nothing</b>—The server takes no action if the watchdog timer expires during OS boot.</li> <li>• <b>Power_Down</b>—The server is powered off if the watchdog timer expires during OS boot.</li> <li>• <b>Reset</b>—The server is reset if the watchdog timer expires during OS boot.</li> </ul> <p><b>Note</b> This option is only applicable if you enable the OS Boot Watchdog Timer.</p> |

## S3260 M4 Servers

### Main Tab

| Name                                          | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|-----------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Reboot Host Immediately</b><br>checkbox    | Upon checking, reboots the host server immediately. You must check the checkbox after saving changes.                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>TPM Support</b>                            | <p>TPM (Trusted Platform Module) is a microchip designed to provide basic security-related functions primarily involving encryption keys. This option allows you to control the TPM Security Device support for the system. It can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The server does not use the TPM.</li> <li>• <b>Enabled</b>—The server uses the TPM.</li> </ul> <p><b>Note</b> We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p> |
| <b>Power ON Password Support</b><br>drop-down | <p>This token requires that you set a BIOS password before using the F2 BIOS configuration. If enabled, password needs to be validated before you access BIOS functions such as IO configuration, BIOS set up, and booting to an operating system using BIOS. It can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>Enabled</b>—Support is enabled.</li> </ul>                                                                                                                       |

**Actions Area**

| Name                    | Description                                                                                                                                                                                                                                                                                                    |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Save button             | Saves the settings for the BIOS parameters on all three tabs and closes the dialog box.<br><br>If the <b>Reboot Host Immediately</b> check box is checked, the server is rebooted immediately and the new BIOS settings go into effect. Otherwise the changes are saved until the server is manually rebooted. |
| Reset button            | Resets the values for the BIOS parameters on all three tabs to the settings that were in effect when this dialog box was first opened.                                                                                                                                                                         |
| Restore Defaults button | Sets the BIOS parameters on all three tabs to their default settings.                                                                                                                                                                                                                                          |

## Advanced Tab

**Reboot Server Option**

If you want your changes applied automatically after you click **Save Changes**, check the **Reboot Host Immediately** check box. immediately reboots the server and applies your changes.

If you want to apply your changes at a later time, clear the **Reboot Host Immediately** check box. stores the changes and applies them the next time the server reboots.




---

**Note** If there are existing BIOS parameter changes pending, automatically overwrites the stored values with the current settings when you click **Save Changes**.

---

**Processor Configuration Parameters**

| Name                                                            | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-----------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Intel Hyper-Threading Technology</b><br>set IntelHyperThread | Whether the processor uses Intel Hyper-Threading Technology, which allows multithreaded software applications to execute threads in parallel within each processor. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit hyperthreading.</li> <li>• <b>Enabled</b>—The processor allows for the parallel execution of multiple threads.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p> |

| Name                                                      | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-----------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Number of Enabled Cores</b><br>set CoreMultiProcessing | <p>Allows you to disable one or more of the physical cores on the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>All</b>—Enables all physical cores. This also enables Hyper Threading on the associated logical processor cores.</li> <li>• <b>1 through <i>n</i></b>—Specifies the number of physical processor cores that can run on the server. Each physical core has an associated logical core.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p>                                                                                                            |
| <b>Execute Disable</b><br>set ExecuteDisable              | <p>Classifies memory areas on the server to specify where application code can execute. As a result of this classification, the processor disables code execution if a malicious worm attempts to insert code in the buffer. This setting helps to prevent damage, worm propagation, and certain classes of malicious buffer overflow attacks. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not classify memory areas.</li> <li>• <b>Enabled</b>—The processor classifies memory areas.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p> |
| <b>Intel VT</b><br>set IntelVT                            | <p>Whether the processor uses Intel Virtualization Technology (VT), which allows a platform to run multiple operating systems and applications in independent partitions. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit virtualization.</li> <li>• <b>Enabled</b>—The processor allows multiple operating systems in independent partitions.</li> </ul> <p><b>Note</b> If you change this option, you must power cycle the server before the setting takes effect.</p>                                                                                                                                              |
| <b>Intel VT-d</b><br>set IntelVTD                         | <p>Whether the processor uses Intel Virtualization Technology for Directed I/O (VT-d). This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not use virtualization technology.</li> <li>• <b>Enabled</b>—The processor uses virtualization technology.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                     |

| Name                                                               | Description                                                                                                                                                                                                                                                                                        |
|--------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Intel VT-d Interrupt Remapping</b><br><b>set InterruptRemap</b> | Whether the processor supports Intel VT-d Interrupt Remapping. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support remapping.</li> <li>• <b>Enabled</b>—The processor uses VT-d Interrupt Remapping as required.</li> </ul>  |
| <b>Intel VT-d PassThrough DMA</b><br><b>set PassThroughDMA</b>     | Whether the processor supports Intel VT-d Pass-through DMA. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support pass-through DMA.</li> <li>• <b>Enabled</b>—The processor uses VT-d Pass-through DMA as required.</li> </ul> |
| <b>Intel VT-d Coherency Support</b><br><b>set CoherencySupport</b> | Whether the processor supports Intel VT-d Coherency. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support coherency.</li> <li>• <b>Enabled</b>—The processor uses VT-d Coherency as required.</li> </ul>                      |
| <b>Intel VT-d ATS Support</b><br><b>set ATS</b>                    | Whether the processor supports Intel VT-d Address Translation Services (ATS). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support ATS.</li> <li>• <b>Enabled</b>—The processor uses VT-d ATS as required.</li> </ul>         |

| Name                                                                           | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|--------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>CPU Performance</b><br/>set CPUPerformance</p>                           | <p>Sets the CPU performance profile for the server. The performance profile consists of the following options:</p> <ul style="list-style-type: none"> <li>• DCU Streamer Prefetcher</li> <li>• DCU IP Prefetcher</li> <li>• Hardware Prefetcher</li> <li>• Adjacent Cache-Line Prefetch</li> </ul> <p>This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Enterprise</b>—All options are enabled.</li> <li>• <b>High_Throughput</b>—Only the DCU IP Prefetcher is enabled. The rest of the options are disabled.</li> <li>• <b>HPC</b>—All options are enabled. This setting is also known as high performance computing.</li> <li>• <b>Custom</b>—All performance profile options can be configured from the BIOS setup on the server. In addition, the Hardware Prefetcher and Adjacent Cache-Line Prefetch options can be configured in the fields below.</li> </ul> |
| <p><b>Hardware Prefetcher</b><br/>set HardwarePrefetch</p>                     | <p>Whether the processor allows the Intel hardware prefetcher to fetch streams of data and instruction from memory into the unified second-level cache when necessary. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The hardware prefetcher is not used.</li> <li>• <b>Enabled</b>—The processor uses the hardware prefetcher when cache issues are detected.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <p><b>Adjacent Cache Line Prefetcher</b><br/>set AdjacentCacheLinePrefetch</p> | <p>Whether the processor fetches cache lines in even/odd pairs instead of fetching just the required line. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor only fetches the required line.</li> <li>• <b>Enabled</b>— The processor fetches both the required line and its paired line.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |

| Name                                                               | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|--------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>DCU Streamer Prefetch</b><br><b>set DcuStreamerPrefetch</b>     | <p>Whether the processor uses the DCU IP Prefetch mechanism to analyze historical cache access patterns and preload the most relevant lines in the L1 cache. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not try to anticipate cache read requirements and only fetches explicitly requested lines.</li> <li>• <b>Enabled</b>—The DCU prefetcher analyzes the cache read pattern and prefetches the next line in the cache if it determines that it may be needed.</li> </ul>                                                                                                                                                                                                                                                                                                                                         |
| <b>DCU IP Prefetcher</b><br><b>set DcuIpPrefetch</b>               | <p>Whether the processor uses the DCU IP Prefetch mechanism to analyze historical cache access patterns and preload the most relevant lines in the L1 cache. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not preload any cache data.</li> <li>• <b>Enabled</b>—The DCU IP prefetcher preloads the L1 cache with the data it determines to be the most relevant.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Direct Cache Access Support</b><br><b>set DirectCacheAccess</b> | <p>Allows processors to increase I/O performance by placing data from I/O devices directly into the processor cache. This setting helps to reduce cache misses. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Data from I/O devices is not placed directly into the processor cache.</li> <li>• <b>Enabled</b>—Data from I/O devices is placed directly into the processor cache.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| <b>Power Technology</b><br><b>set CPUPowerManagement</b>           | <p>Enables you to configure the CPU power management settings for the following options:</p> <ul style="list-style-type: none"> <li>• Enhanced Intel Speedstep Technology</li> <li>• Intel Turbo Boost Technology</li> <li>• Processor Power State C6</li> </ul> <p>Power Technology can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Custom</b>—The server uses the individual settings for the BIOS parameters mentioned above. You must select this option if you want to change any of these BIOS parameters.</li> <li>• <b>Disabled</b>—The server does not perform any CPU power management and any settings for the BIOS parameters mentioned above are ignored.</li> <li>• <b>Energy Efficient</b>—The server determines the best settings for the BIOS parameters mentioned above and ignores the individual settings for these parameters.</li> </ul> |



| Name                                                                            | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Enhanced Intel Speedstep Technology</b><br><b>set EnhancedIntelSpeedStep</b> | <p>Whether the processor uses Enhanced Intel SpeedStep Technology, which allows the system to dynamically adjust processor voltage and core frequency. This technology can result in decreased average power consumption and decreased average heat production. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor never dynamically adjusts its voltage or frequency.</li> <li>• <b>Enabled</b>—The processor utilizes Enhanced Intel SpeedStep Technology and enables all supported processor sleep states to further conserve power.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p> <p><b>Note</b>      <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p> |
| <b>Intel Turbo Boost Technology</b><br><b>set IntelTurboBoostTech</b>           | <p>Whether the processor uses Intel Turbo Boost Technology, which allows the processor to automatically increase its frequency if it is running below power, temperature, or voltage specifications. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not increase its frequency automatically.</li> <li>• <b>Enabled</b>—The processor utilizes Turbo Boost Technology if required.</li> </ul> <p><b>Note</b>      <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>                                                                                                                                                                                                                                                                        |
| <b>Processor C3 Report</b><br><b>set ProcessorC3Report</b>                      | <p>Whether the BIOS sends the C3 report to the operating system. When the OS receives the report, it can transition the processor into the lower C3 power state to decrease energy usage while maintaining optimal processor performance. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—BIOS does not send C3 report.</li> <li>• <b>Enabled</b>—BIOS sends the C3 report, allowing the OS to transition the processor to the C3 low power state.</li> </ul> <p><b>Note</b>      <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>                                                                                                                                                                                                                            |

| Name                                                                      | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|---------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Processor C6 Report</b><br><b>set ProcessorC6Report</b>                | <p>Whether the BIOS sends the C6 report to the operating system. When the OS receives the report, it can transition the processor into the lower C6 power state to decrease energy usage while maintaining optimal processor performance. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The BIOS does not send the C6 report.</li> <li>• <b>Enabled</b>—The BIOS sends the C6 report, allowing the OS to transition the processor to the C6 low power state.</li> </ul> <p><b>Note</b>      <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Processor Power State C1 Enhanced</b><br><b>set ProcessorC1EReport</b> | <p>Whether the CPU transitions to its minimum frequency when entering the C1 state. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The CPU continues to run at its maximum frequency in C1 state.</li> <li>• <b>Enabled</b>—The CPU transitions to its minimum frequency. This option saves the maximum amount of power in C1 state.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>P-STATE Coordination</b><br><b>set PsdCoordType</b>                    | <p>Allows you to define how BIOS communicates the P-state support model to the operating system. There are 3 models as defined by the Advanced Configuration and Power Interface (ACPI) specification.</p> <ul style="list-style-type: none"> <li>• <b>HW_ALL</b>—The processor hardware is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a package).</li> <li>• <b>SW_ALL</b>—The OS Power Manager (OSPM) is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a physical package), and must initiate the transition on all of the logical processors.</li> <li>• <b>SW_ANY</b>—The OS Power Manager (OSPM) is responsible for coordinating the P-state among logical processors with dependencies (all logical processors in a package), and may initiate the transition on any of the logical processors in the domain.</li> </ul> <p><b>Note</b>      <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p> |

| Name                                                                          | Description                                                                                                                                                                                                                                                                                                                    |
|-------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Boot Performance Mode</b> drop-down list<br><b>set BootPerformanceMode</b> | Allows the user to select the BIOS performance state that is set before the operating system handoff. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Max Performance</b>—Processor P-state ratio is maximum</li> <li>• <b>Max Efficient</b>— Processor P-state ratio is minimum</li> </ul>      |
| <b>Energy Performance Tuning</b><br><b>set PwrPerfTuning</b>                  | Allows you to choose BIOS or Operating System for energy performance bias tuning. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>OS</b>— Chooses OS for energy performance tuning.</li> <li>• <b>BIOS</b>— Chooses BIOS for energy performance tuning.</li> </ul>                               |
| <b>Energy Performance</b><br><b>set CpuEngPerfBias</b>                        | Allows you to determine whether system performance or energy efficiency is more important on this server. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Balanced_Energy</b></li> <li>• <b>Balanced_Performance</b></li> <li>• <b>Energy_Efficient</b></li> <li>• <b>Performance</b></li> </ul> |

| Name                                                   | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|--------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Package C State Limit</b><br>set PackageCStateLimit | <p>The amount of power available to the server components when they are idle. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>C0_state</b>—The server provides all server components with full power at all times. This option maintains the highest level of performance and requires the greatest amount of power.</li> <li>• <b>C1_state</b>—When the CPU is idle, the system slightly reduces the power consumption. This option requires less power than C0 and allows the server to return quickly to high performance mode.</li> <li>• <b>C3_state</b>—When the CPU is idle, the system reduces the power consumption further than with the C1 option. This requires less power than C1 or C0, but it takes the server slightly longer to return to high performance mode.</li> <li>• <b>C6_state</b>—When the CPU is idle, the system reduces the power consumption further than with the C3 option. This option saves more power than C0, C1, or C3, but there may be performance issues until the server returns to full power.</li> <li>• <b>C7_state</b>—When the CPU is idle, the server makes a minimal amount of power available to the components. This option saves the maximum amount of power but it also requires the longest time for the server to return to high performance mode.</li> <li>• <b>No_Limit</b>—The server may enter any available C state.</li> </ul> |
| <b>Extended APIC</b><br>set LocalX2Apic                | <p>Allows you to enable or disable extended APIC support. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>XAPIC</b>—Enables APIC support.</li> <li>• <b>X2APIC</b>—Enables APIC and also enables Intel VT-d and Interrupt Remapping .</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Workload Configuration</b><br>set WorkLdConfig      | <p>Allows you to set a parameter to optimize workload characterization. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Balanced</b>— Chooses balanced option for optimization.</li> <li>• <b>I/O Sensitive</b>— Chooses I/O sensitive option for optimization.</li> </ul> <p><b>Note</b> We recommend you to set the workload configuration to <b>Balanced</b>.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |

| Name                                                                             | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>CPU HWPM</b> drop-down list<br><b>set HWPMEnable</b>                          | Enables the Hardware Power Management (HWPM) interface for better CPU performance and energy efficiency. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The P-States are controlled the same way as on predecessor processor generations.</li> <li>• <b>Native Mode</b>—HWPM works with the operating system through a software interface.</li> <li>• <b>OOB Mode</b>—The CPU autonomously controls its frequency based on the operating system energy efficiency.</li> </ul> |
| <b>CPU Autonomous Cstate</b> drop-down list<br><b>set AutonomousCstateEnable</b> | Enables CPU Autonomous C-State, which converts the HALT instructions to the MWAIT instructions. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—CPU Autonomous C-state is disabled. This is the default value.</li> <li>• <b>Enabled</b>—CPU Autonomous C-state is enabled.</li> </ul>                                                                                                                                                                                         |
| <b>Processor CMCI</b> drop-down list<br><b>set CmcEnable</b>                     | Allows the CPU to trigger interrupts on corrected machine check events. The corrected machine check interrupt (CMCI) allows faster reaction than the traditional polling timer. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables CMCI.</li> <li>• <b>Enabled</b>—Enables CMCI. This is the default value.</li> </ul>                                                                                                                                                   |

### Memory Configuration Parameters

| Name                                                   | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|--------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Select Memory RAS</b><br><b>set SelectMemoryRAS</b> | How the memory reliability, availability, and serviceability (RAS) is configured for the server. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Maximum_Performance</b>—System performance is optimized.</li> <li>• <b>Mirroring</b>—System reliability is optimized by using half the system memory as backup.</li> <li>• <b>Lockstep</b>—If the DIMM pairs in the server have an identical type, size, and organization and are populated across the SMI channels, you can enable lockstep mode to minimize memory access latency and provide better performance. This option offers better system performance than Mirroring and better reliability than Maximum Performance but lower reliability than Mirroring and lower system performance than Maximum Performance.</li> </ul> |

| Name                                                 | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>NUMA</b><br>set NUMAOptimize                      | Whether the BIOS supports Non-Uniform Memory Access (NUMA). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The BIOS does not support NUMA.</li> <li>• <b>Enabled</b>—The BIOS includes the ACPI tables that are required for NUMA-aware operating systems. If you enable this option, the system must disable Inter-Socket Memory interleaving on some platforms.</li> </ul>                                                                                                                                                                                                                                       |
| <b>Channel Interleaving</b><br>set ChannelInterLeave | Whether the CPU divides memory blocks and spreads contiguous portions of data across interleaved channels to enable simultaneous read operations. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines what interleaving is done.</li> <li>• <b>1_Way</b>—Some channel interleaving is used.</li> <li>• <b>2_Way</b></li> <li>• <b>3_Way</b></li> <li>• <b>4_Way</b>—The maximum amount of channel interleaving is used.</li> </ul>                                                                                                                                                                       |
| <b>Rank Interleaving</b><br>set RankInterLeave       | Whether the CPU interleaves physical ranks of memory so that one rank can be accessed while another is being refreshed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines what interleaving is done.</li> <li>• <b>1_Way</b>—Some rank interleaving is used.</li> <li>• <b>2_Way</b></li> <li>• <b>4_Way</b></li> <li>• <b>8_Way</b>—The maximum amount of rank interleaving is used.</li> </ul>                                                                                                                                                                                                       |
| <b>Patrol Scrub</b><br>set PatrolScrub               | Whether the system actively searches for, and corrects, single bit memory errors even in unused portions of the memory on the server. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The system checks for memory ECC errors only when the CPU reads or writes a memory address.</li> <li>• <b>Enabled</b>—The system periodically reads and writes memory searching for ECC errors. If any errors are found, the system attempts to fix them. This option may correct single bit errors before they become multi-bit errors, but it may adversely affect performance when the patrol scrub is running.</li> </ul> |

| Name                                                                        | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|-----------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Demand Scrub</b><br><b>set DemandScrub</b>                               | Whether the system corrects single bit memory errors encountered when the CPU or I/O makes a demand read. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Single bit memory errors are not corrected.</li> <li>• <b>Enabled</b>— Single bit memory errors are corrected in memory and the corrected data is set in response to the demand read.</li> </ul>                                                                                                                                                                       |
| <b>Altitude</b><br><b>set Altitude</b>                                      | The approximate number of meters above sea level at which the physical server is installed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines the physical elevation.</li> <li>• <b>300_M</b>—The server is approximately 300 meters above sea level.</li> <li>• <b>900_M</b>—The server is approximately 900 meters above sea level.</li> <li>• <b>1500_M</b>—The server is approximately 1500 meters above sea level.</li> <li>• <b>3000_M</b>—The server is approximately 3000 meters above sea level.</li> </ul> |
| <b>Panic and High Watermark drop-down list</b><br><b>PanicHighWatermark</b> | When set to low, the memory controller does not postpone refreshes while <b>Memory Refresh Rate</b> is set to <b>1X Refresh</b> . This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Low</b>—Refresh rate is set to low.</li> <li>• <b>High</b> —Refresh rate is set to high.</li> </ul>                                                                                                                                                                                                                                                          |

#### QPI Configuration Parameters

| Name                                                            | Description                                                                                                                                                                                                                                                                                                              |
|-----------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>QPI Link Frequency Select</b><br><b>set QPILinkFrequency</b> | The Intel QuickPath Interconnect (QPI) link frequency, in gigatransfers per second (GT/s). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>—The CPU determines the QPI link frequency.</li> <li>• <b>6.4_GT/s</b></li> <li>• <b>7.2_GT/s</b></li> <li>• <b>8.0_GT/s</b></li> </ul> |

| Name                                      | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|-------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>QPI Snoop Mode</b><br>set QpiSnoopMode | <p>The Intel QuickPath Interconnect (QPI) snoop mode. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Home Snoop</b>—The snoop is always spawned by the home agent (centralized ring stop) for the memory controller. This mode has a higher local latency than early snoop, but it provides extra resources for a larger number of outstanding transactions.</li> <li>• <b>Cluster on Die</b>—Enables Cluster On Die. When enabled LLC is split into two parts with an independent caching agent for each. This helps increase the performance in some workloads. This mode is available only for processors that have 10 or more cores. It is the best mode for highly NUMA optimized workloads.</li> <li>• <b>Early Snoop</b>—The distributed cache ring stops can send a snoop probe or a request to another caching agent directly. This mode has lower latency and it is best for workloads that have shared data sets across threads and can benefit from a cache-to-cache transfer, or for workloads that are not NUMA optimized.</li> </ul> |

### USB Configuration Parameters

| Name                                              | Description                                                                                                                                                                                                                                                                                                                                                                                            |
|---------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Legacy USB Support</b><br>set LegacyUSBSupport | <p>Whether the system supports legacy USB devices. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—USB devices are only available to EFI applications.</li> <li>• <b>Enabled</b>—Legacy USB support is always available.</li> <li>• <b>Auto</b>—Disables legacy USB support if no USB devices are connected.</li> </ul>                                 |
| <b>Port 60/64 Emulation</b><br>set UsbEmul6064    | <p>Whether the system supports 60h/64h emulation for complete USB keyboard legacy support. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—60h/64 emulation is not supported.</li> <li>• <b>Enabled</b>—60h/64 emulation is supported.</li> </ul> <p>You should select this option if you are using a non-USB aware operating system on the server.</p> |
| <b>xHCI Mode</b><br>set PchUsb30Mode              | <p>Whether the xHCI controller legacy support is enabled or disabled. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the xHCI controller legacy support.</li> <li>• <b>Enabled</b>—Enables the xHCI controller legacy support.</li> </ul>                                                                                                     |



| Name                                                                   | Description                                                                                                                                                                                                                                                                                                                                                                                                                          |
|------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>xHCI Legacy Support</b> drop-down list<br><b>set UsbXhciSupport</b> | Whether the system supports legacy xHCI controller. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables xHCI legacy support.</li> <li>• <b>Enabled</b>—Enables xHCI legacy support. This is the default value.</li> </ul>                                                                                                                                                            |
| <b>All USB Devices</b><br><b>set AllUsbDevices</b>                     | Whether all physical and virtual USB devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—All USB devices are disabled.</li> <li>• <b>Enabled</b>—All USB devices are enabled.</li> </ul>                                                                                                                                                                     |
| <b>USB Port: Rear</b><br><b>set UsbPortRear</b>                        | Whether the rear panel USB devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the rear panel USB ports. Devices connected to these ports are not detected by the BIOS and operating system.</li> <li>• <b>Enabled</b>—Enables the rear panel USB ports. Devices connected to these ports are detected by the BIOS and operating system.</li> </ul> |
| <b>USB Port: KVM</b><br><b>set UsbPortKVM</b>                          | Whether the vKVM ports are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the vKVM keyboard and/or mouse devices. Keyboard and/or mouse will not work in the vKVM window.</li> <li>• <b>Enabled</b>—Enables the vKVM keyboard and/or mouse devices.</li> </ul>                                                                                             |
| <b>USB Port: vMedia</b><br><b>set UsbPortVMedia</b>                    | Whether the virtual media devices are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables the vMedia devices.</li> <li>• <b>Enabled</b>—Enables the vMedia devices.</li> </ul>                                                                                                                                                                                  |

### PCI Configuration Parameters

| Name                                                                    | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Memory Mapped I/O Above 4GB</b><br><b>set MemoryMappedIOAbove4GB</b> | <p>Whether to enable or disable MMIO above 4GB or not. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The server does not map I/O of 64-bit PCI devices to 4GB or greater address space.</li> <li>• <b>Enabled</b>—The server maps I/O of 64-bit PCI devices to 4GB or greater address space.</li> </ul> <p><b>Note</b> PCI devices that are 64-bit compliant but use a legacy option ROM may not function correctly with this setting enabled.</p> |
| <b>SrIov</b><br><b>set SrIov</b>                                        | <p>Whether SR-IOV (Single Root I/O Virtualization) is enabled or disabled on the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—SR-IOV is disabled.</li> <li>• <b>Enabled</b>—SR-IOV is enabled.</li> </ul>                                                                                                                                                                                                                                 |

### Serial Configuration Parameters

| Name                                                     | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|----------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Out-of-Band Mgmt Port</b><br><b>set comSpcrEnable</b> | <p>Allows you to configure the COM port 0 that can be used for Windows Emergency Management services. ACPI SPCR table is reported based on this setup option. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Configures the COM port 0 as a general purpose port for use with the Windows Operating System.</li> <li>• <b>Enabled</b>—Configures the COM port 0 as a remote management port for Windows Emergency Management services.</li> </ul>                                                  |
| <b>Console Redirection</b><br><b>set ConsoleRedir</b>    | <p>Allows a serial port to be used for console redirection during POST and BIOS booting. After the BIOS has booted and the operating system is responsible for the server, console redirection is irrelevant and has no effect. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—No console redirection occurs during POST.</li> <li>• <b>COM_0</b>—Enables console redirection on COM port 0 during POST.</li> <li>• <b>COM_1</b>—Enables console redirection on COM port 1 during POST.</li> </ul> |

| Name                                            | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|-------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Terminal Type</b><br><b>set TerminalType</b> | <p>What type of character formatting is used for console redirection. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>PC-ANSI</b>—The PC-ANSI terminal font is used.</li> <li>• <b>VT100</b>—A supported vt100 video terminal and its character set are used.</li> <li>• <b>VT100+</b>—A supported vt100-plus video terminal and its character set are used.</li> <li>• <b>VT-UTF8</b>—A video terminal with the UTF-8 character set is used.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p> |
| <b>Bits per second</b><br><b>set BaudRate</b>   | <p>What BAUD rate is used for the serial port transmission speed. If you disable Console Redirection, this option is not available. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>9600</b>—A 9,600 BAUD rate is used.</li> <li>• <b>19200</b>—A 19,200 BAUD rate is used.</li> <li>• <b>38400</b>—A 38,400 BAUD rate is used.</li> <li>• <b>57600</b>—A 57,600 BAUD rate is used.</li> <li>• <b>115200</b>—A 115,200 BAUD rate is used.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p>     |
| <b>Flow Control</b><br><b>set FlowCtrl</b>      | <p>Whether a handshake protocol is used for flow control. Request to Send / Clear to Send (RTS/CTS) helps to reduce frame collisions that can be introduced by a hidden terminal problem. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>None</b>—No flow control is used.</li> <li>• <b>Hardware_RTS/CTS</b>—RTS/CTS is used for flow control.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p>                                                                                              |

| Name                                                                  | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|-----------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Putty KeyPad</b><br><b>set PuttyFunctionKeyPad</b>                 | <p>Allows you to change the action of the PuTTY function keys and the top row of the numeric keypad. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>VT100</b>—The function keys generate <b>ESC OP</b> through <b>ESC O[</b> .</li> <li>• <b>LINUX</b>—Mimics the Linux virtual console. Function keys F6 to F12 behave like the default mode, but F1 to F5 generate <b>ESC [ [A</b> through <b>ESC [ [E</b>.</li> <li>• <b>XTERMR6</b>—Function keys F5 to F12 behave like the default mode. Function keys F1 to F4 generate <b>ESC OP</b> through <b>ESC OS</b>, which are the sequences produced by the top row of the keypad on Digital terminals.</li> <li>• <b>SCO</b>—The function keys F1 to F12 generate <b>ESC [M</b> through <b>ESC [X</b>. The function and shift keys generate <b>ESC [Y</b> through <b>ESC [j</b>. The control and function keys generate <b>ESC [k</b> through <b>ESC [v</b>. The shift, control and function keys generate <b>ESC [w</b> through <b>ESC [ {</b>.</li> <li>• <b>ESCN</b>—The default mode. The function keys match the general behavior of Digital terminals. The function keys generate sequences such as <b>ESC [11~</b> and <b>ESC [12~</b>.</li> <li>• <b>VT400</b>—The function keys behave like the default mode. The top row of the numeric keypad generates <b>ESC OP</b> through <b>ESC OS</b>.</li> </ul> |
| <b>Redirection After BIOS POST</b><br><b>set RedirectionAfterPOST</b> | <p>Whether BIOS console redirection should be active after BIOS POST is complete and control given to the OS bootloader. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Always_Enabled</b>—BIOS Legacy console redirection is active during the OS boot and run time.</li> <li>• <b>Bootloader</b>—BIOS Legacy console redirection is disabled before giving control to the OS boot loader.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |

### LOM and PCIe Slots Configuration Parameters

| Name                                               | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|----------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>CDN Support for VIC</b><br><b>set CdnEnable</b> | <p>Whether the Ethernet Network naming convention is according to Consistent Device Naming (CDN) or the traditional way of naming conventions. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>— CDN support for VIC cards is disabled.</li> <li>• <b>Enabled</b>— CDN support is enabled for VIC cards.</li> </ul> <p><b>Note</b>      CDN support for VIC cards work with Windows 2012 or the latest OS only.</p> |

| Name                                                         | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|--------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>PCI ROM CLP</b><br><b>set PciRomClp</b>                   | PCI ROM Command Line Protocol (CLP) controls the execution of different Option ROMs such as PxE and iSCSI that are present in the card. By default, it is disabled. <ul style="list-style-type: none"> <li>• <b>Enabled</b>— Enables you to configure execution of different option ROMs such as PxE and iSCSI for an individual ports separately.</li> <li>• <b>Disabled</b>—The default option. You cannot choose different option ROMs. A default option ROM is executed during PCI enumeration.</li> </ul> |
| <b>All PCIe Slots OptionROM</b><br><b>set PcieOptionROMs</b> | Whether the server can use Option ROM present in the PCIe Cards. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for slot <i>n</i> is not available.</li> <li>• <b>Enabled</b>—The Option ROM for slot <i>n</i> is available.</li> <li>• <b>UEFI_Only</b>—The Option ROM for slot <i>n</i> is available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot <i>n</i> is available for legacy only.</li> </ul>                       |
| <b>PCH SATA Mode</b><br><b>set SataModeSelect</b>            | This options allows you to select the PCH SATA mode. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>AHCI</b>—Sets both SATA and sSATA controllers to AHCI mode.</li> <li>• <b>Disabled</b>—Disables both SATA and sSATA controllers.</li> <li>• <b>LSI SW Raid</b>— Sets both SATA and sSATA controllers to raid mode for LSI SW Raid</li> </ul>                                                                                                                                |
| <b>SBNVMe1 OptionROM</b><br><b>set SBNVMe1OptionROM</b>      | Whether the server can use Option ROM present in SBNVMe1 controller. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for SBNVMe1 controllers is not available.</li> <li>• <b>Enabled</b>—The Option ROMs for SBNVMe1 controller is available.</li> <li>• <b>UEFI_Only</b>—The Option ROMs for slot are available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot are available for legacy only.</li> </ul>                      |

| Name                                             | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|--------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>SIOC1 OptionROM</b><br>set SIOC1OptionROM     | Whether the server can use Option ROM present in System IO Controller 1 (SIOC1). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for System IO Controller 1 (SIOC1) is not available.</li> <li>• <b>Enabled</b>—The Option ROMs for System IO Controller 1 (SIOC1) is available.</li> <li>• <b>UEFI_Only</b>—The Option ROMs for slot are available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot are available for legacy only.</li> </ul> |
| <b>SIOC2 OptionROM</b><br>set SIOC2OptionROM     | Whether the server can use Option ROM present in System IO Controller 2 (SIOC2). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for System IO Controller 2 (SIOC2) is not available.</li> <li>• <b>Enabled</b>—The Option ROMs for System IO Controller 2 (SIOC2) is available.</li> <li>• <b>UEFI_Only</b>—The Option ROMs for slot are available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot are available for legacy only.</li> </ul> |
| <b>SBMezz1 OptionROM</b><br>set SBMezz1OptionROM | Whether the server can use Option ROM present in SBMezz1 controller. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for SBMezz1 controllers is not available.</li> <li>• <b>Enabled</b>—The Option ROMs for SBMezz1 controller is available.</li> <li>• <b>UEFI_Only</b>—The Option ROMs for slot are available for UEFI only.</li> <li>• <b>Legacy_Only</b>—The Option ROM for slot are available for legacy only.</li> </ul>                                    |

| Name                                                                   | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>SBMezz2 OptionROM</b> drop-down list<br><b>set SBMezz2OptionROM</b> | Whether the server can use Option ROM that is available in the SBMezz2 controller. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The Option ROM for SBMezz 2 controllers is not available.</li> <li>• <b>Enabled</b>—The Option ROM for SBMezz 2 controllers is available.</li> <li>• <b>UEFI Only</b>—The Option ROMs for slot are available for UEFI only.</li> <li>• <b>Legacy Only</b>—The Option ROMs for slot are available for legacy only.</li> </ul> |
| <b>IOESlot1 OptionROM</b><br><b>set IOESlot1OptionROM</b>              | Whether option ROM is enabled on the IOE slot 1. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Option ROM is disabled.</li> <li>• <b>Enabled</b>— Default value. Option ROM is enabled.</li> <li>• <b>UEFI Only</b>— slot 1 option ROM is available for UEFI only.</li> <li>• <b>Legacy Only</b>— slot 1 option ROM is available for legacy only.</li> </ul>                                                                                                 |
| <b>IOEMezz1 OptionROM</b><br><b>set IOEMezz1OptionROM</b>              | Whether option ROM is enabled on the IOE Mezz1. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Option ROM is disabled.</li> <li>• <b>Enabled</b>— Default value. Option ROM is enabled.</li> <li>• <b>UEFI Only</b>— Mezz1 option ROM is available for UEFI only.</li> <li>• <b>Legacy Only</b>— Mezz1 option ROM is available for legacy only.</li> </ul>                                                                                                    |
| <b>IOESlot2 OptionROM</b><br><b>set IOESlot2OptionROM</b>              | Whether option ROM is enabled on the IOE slot 2. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Option ROM is disabled.</li> <li>• <b>Enabled</b>— Default value. Option ROM is enabled.</li> <li>• <b>UEFI Only</b>— slot 2 option ROM is available for UEFI only.</li> <li>• <b>Legacy Only</b>— slot 2 option ROM is available for legacy only.</li> </ul>                                                                                                 |

| Name                                                      | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-----------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>IOENVMe1 OptionROM</b><br><b>set IOENVMe1OptionROM</b> | Whether option ROM is enabled on the IOE NVMe1. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Option ROM is disabled.</li> <li>• <b>Enabled</b>— Default value. Option ROM is enabled.</li> <li>• <b>UEFI Only</b>— Mezz1 option ROM is available for UEFI only.</li> <li>• <b>Legacy Only</b>— Mezz1 option ROM is available for legacy only.</li> </ul>                                                     |
| <b>IOENVMe2 OptionROM</b><br><b>set IOENVMe2OptionROM</b> | Whether option ROM is enabled on the IOE NVMe2. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Option ROM is disabled.</li> <li>• <b>Enabled</b>— Default value. Option ROM is enabled.</li> <li>• <b>UEFI Only</b>— Mezz1 option ROM is available for UEFI only.</li> <li>• <b>Legacy Only</b>— Mezz1 option ROM is available for legacy only.</li> </ul>                                                     |
| <b>SBNVMe1 Link Speed</b><br><b>Set SBNVMe1LinkSpeed</b>  | SBNVMe1 add-on slot 1 link speed. <ul style="list-style-type: none"> <li>• <b>Auto</b>—Link speed is automatically assigned.</li> <li>• <b>GEN1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN2</b>—The default link speed. Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul> |
| <b>SIOC1 Link Speed</b><br><b>Set PcieSlot1LinkSpeed</b>  | System IO Controller 1 (SIOC1) add-on slot 1 link speed. <ul style="list-style-type: none"> <li>• <b>GEN1</b> — Link speed can reach up to first generation.</li> <li>• <b>GEN2</b> — Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— The default link speed. Link speed can reach up to third generation.</li> <li>• <b>Disabled</b> — Slot is disabled, and the card is not enumerated.</li> </ul>                                  |
| <b>SIOC2 Link Speed</b><br><b>set PcieSlot2LinkSpeed</b>  | System IO Controller 2 (SIOC2) add-on slot 2 link speed. <ul style="list-style-type: none"> <li>• <b>GEN1</b> — Link speed can reach up to first generation.</li> <li>• <b>GEN2</b> — Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— The default link speed. Link speed can reach up to third generation.</li> <li>• <b>Disabled</b> — Slot is disabled, and the card is not enumerated.</li> </ul>                                  |



| Name                                                                    | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|-------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>SBMezz1 Link Speed</b><br><b>set SBMezz1LinkSpeed</b>                | SBMezz1 add-on slot 1 link speed. <ul style="list-style-type: none"> <li>• <b>Auto</b>—Link speed is automatically assigned.</li> <li>• <b>GEN1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN2</b>—The default link speed. Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>                  |
| <b>SBMezz2 Link Speed</b> drop-down list<br><b>set SBMezz2LinkSpeed</b> | Assigns SBMezz2 add-on slot 2 link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>— Default value. Slot is enabled.</li> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul> |
| <b>IOESlot1 Link Speed</b><br><b>set IOESlot1LinkSpeed</b>              | Slot 1 link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>— Default value. Slot is enabled.</li> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>                        |
| <b>IOEMezz1 Link Speed</b><br><b>set IOEMezz1LinkSpeed</b>              | Mezz1 link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>— Default value. Slot is enabled.</li> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>                         |

| Name                                                | Description                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|-----------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>IOESlot2 Link Speed</b><br>set IOESlot2LinkSpeed | Slot 2 link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>— Default value. Slot is enabled.</li> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul> |
| <b>IOENVMe1 Link Speed</b><br>set IOENVMe1LinkSpeed | NVMe1 link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>— Default value. Slot is enabled.</li> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>  |
| <b>IOENVMe2 Link Speed</b><br>set IOENVMe2LinkSpeed | NVMe2 link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Auto</b>— Default value. Slot is enabled.</li> <li>• <b>GEN 1</b>— Link speed can reach up to first generation.</li> <li>• <b>GEN 2</b>— Link speed can reach up to second generation.</li> <li>• <b>GEN 3</b>— Link speed can reach up to third generation.</li> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> </ul>  |

### BIOS Configuration Dialog Box Button Bar



**Important** The buttons in this dialog box affect all BIOS parameters on all available tabs, not just the parameters on the tab that you are viewing.

| Name                       | Description                                                                                                                                                                                                                                                                                                    |
|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Save Changes</b> button | Saves the settings for the BIOS parameters on all three tabs and closes the dialog box.<br><br>If the <b>Reboot Host Immediately</b> check box is checked, the server is rebooted immediately and the new BIOS settings go into effect. Otherwise the changes are saved until the server is manually rebooted. |
| <b>Reset Values</b> button | Restores the values for the BIOS parameters on all three tabs to the settings that were in effect when this dialog box was first opened.                                                                                                                                                                       |

| Name                           | Description                                                           |
|--------------------------------|-----------------------------------------------------------------------|
| <b>Restore Defaults</b> button | Sets the BIOS parameters on all three tabs to their default settings. |
| <b>Cancel</b> button           | Closes the dialog box without making any changes.                     |

## Server Management Tab

### Server Management BIOS Parameters

| Name                                                                      | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|---------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>FRB-2 Timer</b><br>set <b>FRB-2</b>                                    | Whether the FRB2 timer is used by to recover the system if it hangs during POST. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The FRB2 timer is not used.</li> <li>• <b>Enabled</b>—The FRB2 timer is started during POST and used to recover the system if necessary.</li> </ul>                                                                                                                                                                                                                                                                                                                                                              |
| <b>OS Watchdog Timer</b><br>set <b>OSBootWatchdogTimer</b>                | Whether the BIOS programs the watchdog timer with a specified timeout value. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The watchdog timer is not used to track how long the server takes to boot.</li> <li>• <b>Enabled</b>—The watchdog timer tracks how long the server takes to boot. If the server does not boot within the length of time specified by the <b>set OSBootWatchdogTimerTimeout</b> command, the logs an error and takes the action specified by the <b>set OSBootWatchdogTimerPolicy</b> command.</li> </ul>                                                                                                             |
| <b>OS Watchdog Timer Timeout</b><br>set <b>OSBootWatchdogTimerTimeOut</b> | If OS does not boot within the specified time, OS watchdog timer expires and system takes action according to timer policy. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>5_Minutes</b>—The OS watchdog timer expires 5 minutes after it begins to boot.</li> <li>• <b>10_Minutes</b>—The OS watchdog timer expires 10 minutes after it begins to boot.</li> <li>• <b>15_Minutes</b>—The OS watchdog timer expires 15 minutes after it begins to boot.</li> <li>• <b>20_Minutes</b>—The OS watchdog timer expires 20 minutes after it begins to boot.</li> </ul> <p><b>Note</b> This option is only applicable if you enable the OS Boot Watchdog Timer.</p> |

| Name                                                             | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>OS Watchdog Timer Policy</b><br>set OSBootWatchdogTimerPolicy | <p>What action the system takes if the watchdog timer expires. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Do_Nothing</b>—The server takes no action if the watchdog timer expires during OS boot.</li> <li>• <b>Power_Down</b>—The server is powered off if the watchdog timer expires during OS boot.</li> <li>• <b>Reset</b>—The server is reset if the watchdog timer expires during OS boot.</li> </ul> <p><b>Note</b> This option is only applicable if you enable the OS Boot Watchdog Timer.</p> |

## S3260 M5 Servers

### I/O Tab



**Note** BIOS parameters listed in this tab may vary depending on the server.

*Table 2: BIOS Parameters in I/O Tab*

| Name                                                             | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Reboot Host Immediately</b> checkbox                          | <p>Upon checking, reboots the host server immediately. You must check the checkbox after saving changes.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Legacy USB Support</b> drop-down list<br>set UsbLegacySupport | <p>Whether the system supports legacy USB devices. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—USB devices are only available to EFI applications.</li> <li>• <b>Enabled</b>—Legacy USB support is always available.</li> </ul>                                                                                                                                                                                                                                                                    |
| <b>Intel VT for directed IO</b> drop-down list<br>set IntelVTD   | <p>Whether the processor uses Intel Virtualization Technology (VT), which allows a platform to run multiple operating systems and applications in independent partitions. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit virtualization.</li> <li>• <b>Enabled</b>—The processor allows multiple operating systems in independent partitions.</li> </ul> <p><b>Note</b> If you change this option, you must power cycle the server before the setting takes effect.</p> |

| Name                                                                             | Description                                                                                                                                                                                                                                                                                                                      |
|----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Intel VTD coherency support</b> drop-down list<br><b>set CoherencySupport</b> | Whether the processor supports Intel VT-d Coherency. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support coherency.</li> <li>• <b>Enabled</b>—The processor uses VT-d Coherency as required.</li> </ul>                                                    |
| <b>Intel VTD ATS support</b> drop-down list<br><b>set ATS</b>                    | Whether the processor supports Intel VT-d Address Translation Services (ATS). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not support ATS.</li> <li>• <b>Enabled</b>—The processor uses VT-d ATS as required.</li> </ul>                                       |
| <b>PCIe RAS Support</b> drop-down list                                           | Whether PCIe RAS Support is available on the PCIe slot. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Enabled</b>— PCIe RAS is available on the slot.</li> <li>• <b>Disabled</b>— PCIe RAS is not available on port.</li> </ul>                                                                  |
| <b>All Onboard LOM Ports</b> drop-down list                                      | Whether all LOM ports are enabled or disabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Enabled</b>— All LOM ports are enabled.</li> <li>• <b>Disabled</b>— All LOM ports are disabled.</li> </ul>                                                                                          |
| <b>LOM Port 0 OptionROM</b> drop-down list                                       | Whether Option ROM is available on the LOM port 0. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Option ROM is not available on LOM port 0.</li> <li>• <b>Enabled</b>—Option ROM is available on LOM port 0.</li> </ul>                                                             |
| <b>LOM Port 1 OptionROM</b>                                                      | Whether Option ROM is available on the LOM port 1. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Option ROM is not available on LOM port 1.</li> <li>• <b>Enabled</b>—Option ROM is available on LOM port 1.</li> </ul>                                                             |
| <b>PCIe Slot nOptionROM</b> drop-down list                                       | Whether the server can use the Option ROMs present in the PCIe Cards. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Option ROM is not available on slot <i>n</i>.</li> <li>• <b>Enabled</b>—Option ROM is available on slot <i>n</i>.</li> </ul>                                    |
| <b>MRAID OptionROM</b>                                                           | Whether the server can use the RAID Option ROMs present in the PCIe card slot designated by <i>n</i> . This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Option ROM for slot <i>n</i> is not available.</li> <li>• <b>Enabled</b>—Option ROM for slot <i>n</i> is available.</li> </ul> |

| Name                                                                                       | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|--------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>MLOM Oprom</b><br>drop-down list<br><br><b>set</b><br><b>PcieSlotMLOMOptionROM</b>      | This options allows you to control the Option ROM execution of the PCIe adapter connected to the MLOM slot. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Does not execute Option ROM of the PCIe adapter connected to the MLOM slot.</li> <li>• <b>Enabled</b>—Executes Option ROM of the PCIe adapter connected to the MLOM slot.</li> </ul>                                                                                                                                   |
| <b>HBA Oprom</b><br>drop-down list<br><br><b>set</b><br><b>PcieSlotHBAOptionROM</b>        | This options allows you to control the Option ROM execution of the PCIe adapter connected to the HBA slot. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Does not execute Option ROM of the PCIe adapter connected to the HBA slot.</li> <li>• <b>Enabled</b>—Executes Option ROM of the PCIe adapter connected to the HBA slot.</li> </ul>                                                                                                                                      |
| <b>Front NVME1 Oprom</b><br>drop-down list<br><br><b>set</b><br><b>PcieSlotN1OptionROM</b> | This options allows you to control the Option ROM execution of the PCIe adapter connected to the SSD:NVMe1 slot. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Does not execute Option ROM of the PCIe adapter connected to the SSD:NVMe1 slot.</li> <li>• <b>Enabled</b>—Executes Option ROM of the PCIe adapter connected to the SSD:NVMe1 slot</li> </ul>                                                                                                                     |
| <b>Front NVME2 Oprom</b><br>drop-down list<br><br><b>set</b><br><b>PcieSlotN2OptionROM</b> | This options allows you to control the Option ROM execution of the PCIe adapter connected to the SSD:NVMe2 slot. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Does not execute Option ROM of the PCIe adapter connected to the SSD:NVMe2 slot.</li> <li>• <b>Enabled</b>—Executes Option ROM of the PCIe adapter connected to the SSD:NVMe2 slot</li> </ul>                                                                                                                     |
| <b>HBA Link Speed</b><br>drop-down list<br><br><b>set</b><br><b>PcieSlotHBALinkSpeed</b>   | This option allows you to restrict the maximum speed of an adapter card installed in PCIe HBA slot. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The maximum speed is not restricted.</li> <li>• <b>Auto</b>—System selects the maximum speed allowed.</li> <li>• <b>GEN1</b>—2.5GT/s (gigatransfers per second) is the maximum speed allowed.</li> <li>• <b>GEN2</b>—5GT/s is the maximum speed allowed.</li> <li>• <b>GEN3</b>—8GT/s is the maximum speed allowed.</li> </ul> |

| Name                                                                                                                 | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|----------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>MLOM Link Speed</b><br>drop-down list<br><br><b>set</b><br><b>PcieSlotMLOMLinkSpeed</b>                           | This option allows you to restrict the maximum speed of an adapter card installed in PCIe MLOM slot. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The maximum speed is not restricted.</li> <li>• <b>Auto</b>—System selects the maximum speed allowed.</li> <li>• <b>GEN1</b>—2.5GT/s (gigatransfers per second) is the maximum speed allowed.</li> <li>• <b>GEN2</b>—5GT/s is the maximum speed allowed.</li> <li>• <b>GEN3</b>—8GT/s is the maximum speed allowed.</li> </ul>           |
| <b>MRAID Link Speed</b><br>drop-down list                                                                            | This option allows you to restrict the maximum speed of an adapter card installed in MRAID slot. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The maximum speed is not restricted.</li> <li>• <b>Auto</b>—System selects the maximum speed allowed.</li> <li>• <b>GEN1</b>—2.5GT/s (gigatransfers per second) is the maximum speed allowed.</li> <li>• <b>GEN2</b>—5GT/s is the maximum speed allowed.</li> <li>• <b>GEN3</b>—8GT/s is the maximum speed allowed.</li> </ul>               |
| <b>PCIe Slot<math>n</math> Link Speed</b><br>drop-down list<br><br><b>set</b> <b>PcieSlot<math>n</math>LinkSpeed</b> | System IO Controller $n$ (SIOCN) add-on slot (designated by $n$ ) link speed. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> <li>• <b>Auto</b>— The default link speed. Link speed is automatically assigned.</li> <li>• <b>GEN1</b>—Link speed can reach up to first generation.</li> <li>• <b>GEN2</b>—Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>—Link speed can reach up to third generation.</li> </ul> |
| <b>Front NVME1 Link Speed</b><br>drop-down list<br><br><b>set</b><br><b>PcieSlotFrontNvme1LinkSpeed</b>              | Link speed for NVMe front slot 1. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> <li>• <b>Auto</b>—The default link speed. Link speed is automatically assigned.</li> <li>• <b>GEN1</b>—Link speed can reach up to first generation.</li> <li>• <b>GEN2</b>—Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>—Link speed can reach up to third generation.</li> </ul>                                              |

| Name                                                                               | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Front NVME2 Link Speed</b> drop-down list<br>set<br>PcieSlotFrontNvme2LinkSpeed | Link speed for NVMe front slot 2. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> <li>• <b>Auto</b>—The default link speed. Link speed is automatically assigned.</li> <li>• <b>GEN1</b>—Link speed can reach up to first generation.</li> <li>• <b>GEN2</b>—Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>—Link speed can reach up to third generation.</li> </ul>                                                                                                                                                                                                 |
| <b>Rear NVME1 Link Speed</b> drop-down list<br>set<br>PcieSlotRearNvme1LinkSpeed   | Link speed for NVMe rear slot 1. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> <li>• <b>Auto</b>—The default link speed. Link speed is automatically assigned.</li> <li>• <b>GEN1</b>—Link speed can reach up to first generation.</li> <li>• <b>GEN2</b>—Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>—Link speed can reach up to third generation.</li> </ul>                                                                                                                                                                                                  |
| <b>Rear NVME2 Link Speed</b> drop-down list<br>set<br>PcieSlotRearNvme2LinkSpeed   | Link speed for NVMe rear slot 2. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Slot is disabled, and the card is not enumerated.</li> <li>• <b>Auto</b>—The default link speed. Link speed is automatically assigned.</li> <li>• <b>GEN1</b>—Link speed can reach up to first generation.</li> <li>• <b>GEN2</b>—Link speed can reach up to second generation.</li> <li>• <b>GEN3</b>—Link speed can reach up to third generation.</li> </ul>                                                                                                                                                                                                  |
| <b>VGA Priority</b> drop-down list<br>set <b>VgaPriority</b>                       | Allows you to set the priority for VGA graphics devices if multiple VGA devices are found in the system. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>OnBoard</b>—Priority is given to the onboard VGA device. BIOS post screen and OS boot are driven through the onboard VGA port.</li> <li>• <b>OffBoard</b>—Priority is given to the PCIE Graphics adapter. BIOS post screen and OS boot are driven through the external graphics adapter port.</li> <li>• <b>OnBoard VGA Disabled</b>—Priority is given to the PCIe Graphics adapter, and the onboard VGA device is disabled. The vKVM does not function when the onboard VGA is disabled.</li> </ul> |
| <b>P-SATA OptionROM</b> drop-down list<br>set <b>pSATA</b>                         | Allows you to select the PCH SATA optionROM mode. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>LSI SW Raid</b>— Sets both SATA and sSATA controllers to raid mode for LSI SW Raid.</li> <li>• <b>Disabled</b>— Disables both SATA and sSATA controllers.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                        |



| Name                                                                        | Description                                                                                                                                                                                                                                                                                                                                                                                                                              |
|-----------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>M2.SATA OptionROM</b><br>drop-down list<br><br><b>set SataModeSelect</b> | Mode of operation of Serial Advanced Technology Attachment (SATA) Solid State Drives (SSD). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>AHCI</b>—<br/>Sets both SATA and sSATA controllers to AHCI mode.</li> <li>• <b>LSI SW Raid</b>— Sets both SATA and sSATA controllers to raid mode for LSI SW Raid.</li> <li>• <b>Disabled</b>— Disables both SATA and sSATA controllers.</li> </ul>            |
| <b>USB Port Rear</b><br>drop-down list<br><br><b>set UsbPortRear</b>        | Whether the rear panel USB devices are enabled or disabled. This can be one of the following <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Disables the rear panel USB ports. Devices connected to these ports are not detected by the BIOS and operating system.</li> <li>• <b>Enabled</b>— Enables the rear panel USB ports. Devices connected to these ports are detected by the BIOS and operating system.</li> </ul>    |
| <b>USB Port Front</b><br>drop-down list<br><br><b>set UsbPortFront</b>      | Whether the front panel USB devices are enabled or disabled. This can be one of the following <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Disables the front panel USB ports. Devices connected to these ports are not detected by the BIOS and operating system.</li> <li>• <b>Enabled</b>— Enables the front panel USB ports. Devices connected to these ports are detected by the BIOS and operating system.</li> </ul> |
| <b>USB Port Internal</b><br>drop-down list<br><br><b>set UsbPortInt</b>     | Whether the internal USB devices are enabled or disabled. This can be one of the following <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Disables the internal USB ports. Devices connected to these ports are not detected by the BIOS and operating system.</li> <li>• <b>Enabled</b>— Enables the internal USB ports. Devices connected to these ports are detected by the BIOS and operating system.</li> </ul>          |
| <b>USB Port KVM</b><br>drop-down list<br><br><b>set UsbPortKVM</b>          | Whether the vKVM ports are enabled or disabled. This can be one of the following <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Disables the vKVM keyboard and/or mouse devices. Keyboard and/or mouse will not work in the KVM window.</li> <li>• <b>Enabled</b>— Enables the vKVM keyboard and/or mouse devices.</li> </ul>                                                                                                 |
| <b>USB Port Internal</b><br>drop-down list                                  | Whether the USB Port Internal is enabled or disabled. This can be one of the following <ul style="list-style-type: none"> <li>• <b>Disabled</b>— Disables the USB Port Internal. Devices connected to these ports are not detected by the BIOS and operating system.</li> <li>• <b>Enabled</b>— Enables the USB Port Internal. Devices connected to these ports are detected by the BIOS and operating system.</li> </ul>                |

| Name                                                                                | Description                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>IPv6 PXE Support</b><br>drop-down list<br>set <b>IPV6PXE</b>                     | Enables or disables IPv6 support for PXE. This can be one of the following <ul style="list-style-type: none"> <li>• <b>disabled</b>—IPv6 PXE support is not available.</li> <li>• <b>enabled</b>—IPv6 PXE support is always available.</li> </ul>                                                                                                                                                                                                    |
| <b>IPv4 HTTP Support</b>                                                            | Enables or disables IPv4 support for HTTP. This can be one of the following <ul style="list-style-type: none"> <li>• <b>disabled</b>—IPv4 HTTP support is not available.</li> <li>• <b>enabled</b>—IPv4 HTTP support is always available.</li> </ul>                                                                                                                                                                                                 |
| <b>IPv6 HTTP Support</b>                                                            | Enables or disables IPv6 support for HTTP. This can be one of the following <ul style="list-style-type: none"> <li>• <b>disabled</b>—IPv6 PXE support is not available.</li> <li>• <b>enabled</b>—IPv6 PXE support is always available.</li> </ul>                                                                                                                                                                                                   |
| <b>PCIe PLL SSC</b><br>drop-down list<br>set <b>PciePllSsc</b>                      | Enable this feature to reduce EMI interference by down spreading clock 0.5%. Disable this feature to centralize the clock without spreading.<br><br>This can be one of the following: <ul style="list-style-type: none"> <li>• <b>auto</b>—EMI interference is auto adjusted.</li> <li>• <b>Disabled</b>—EMI interference is auto adjusted.</li> <li>• <b>ZeroPointFive</b>—EMI interference is reduced by down spreading the clock 0.5%.</li> </ul> |
| <b>IPv4 PXE Support</b><br>drop-down list<br>set <b>IPV4PXE</b>                     | Enables or disables IPv4 support for PXE. This can be one of the following <ul style="list-style-type: none"> <li>• <b>disabled</b>—IPv4 PXE support is not available.</li> <li>• <b>enabled</b>—IPv4 PXE support is always available.</li> </ul>                                                                                                                                                                                                    |
| <b>Network Stack</b><br>drop-down list<br>set <b>NetworkStack</b>                   | This option allows you to monitor IPv6 and IPv4. This can be one of the following <ul style="list-style-type: none"> <li>• <b>disabled</b>—Network Stack support is not available.</li> </ul> <p><b>Note</b> When disabled, the value set for <b>IPV4 PXE Support</b> does not impact the system.</p> <ul style="list-style-type: none"> <li>• <b>enabled</b>—Network Stack support is always available.</li> </ul>                                  |
| <b>External SSC enable</b><br>drop-down list<br>set<br><b>EnableClockSpreadSpec</b> | This option allows you to reduce the EMI of your motherboard by modulating the signals it generates so that the spikes are reduced to flatter curves.<br><br>This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Clock Spread Spectrum support is not available.</li> <li>• <b>Enabled</b>—Clock Spread Spectrum support is always available.</li> </ul>                                                      |

| Name                                                                                                | Description                                                                                                                                                                                                                                                      |
|-----------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>PCIe Slot MSTOR RAID OptionROM</b><br>drop-down list<br>set<br><b>PCIeSlotMSTORRAIDOptionROM</b> | Whether the server can use the Option ROMs present in the PCIe MSTOR RAID. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Option ROM is not available.</li> <li>• <b>Enabled</b>—Option ROM is available.</li> </ul> |

## Server Management Tab



**Note** BIOS parameters listed in this tab may vary depending on the server.

*Table 3: BIOS Parameters in Server Management Tab*

| Name                                                                                        | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|---------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Reboot Host Immediately</b> checkbox                                                     | If the Reboot Host Immediately check box is checked, the server is rebooted immediately and the new BIOS settings go into effect. Otherwise the changes are saved until the server is manually rebooted.                                                                                                                                                                                                                                                                                                                                                                         |
| <b>OS Boot Watchdog Timer Policy</b> drop-down list<br>set <b>OSBootWatchdogTimerPolicy</b> | What action the system takes if the watchdog timer expires. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Power Off</b>—The server is powered off if the watchdog timer expires during OS boot.</li> <li>• <b>Reset</b>—The server is reset if the watchdog timer expires during OS boot.</li> </ul> <p><b>Note</b> This option is only applicable if you enable the OS Boot Watchdog Timer.</p>                                                                                                                                                 |
| <b>OS Watchdog Timer</b> drop-down list<br>set <b>OSBootWatchdogTimer</b>                   | Whether the BIOS programs the watchdog timer with a specified timeout value. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The watchdog timer is not used to track how long the server takes to boot.</li> <li>• <b>Enabled</b>—The watchdog timer tracks how long the server takes to boot. If the server does not boot within the length of time specified in the <b>OS Boot Watchdog Timer Timeout</b> field, the Cisco IMC logs an error and takes the action specified in the <b>OS Boot Watchdog Policy</b> field.</li> </ul> |

| Name                                                                                             | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|--------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>OS Watchdog Timer Timeout</b> drop-down list<br/>set <b>OSBootWatchdogTimerTimeOut</b></p> | <p>If OS does not boot within the specified time, OS watchdog timer expires and system takes action according to timer policy. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>5 Minutes</b>—The OS watchdog timer expires 5 minutes after it begins to boot.</li> <li>• <b>10 Minutes</b>—The OS watchdog timer expires 10 minutes after it begins to boot.</li> <li>• <b>15 Minutes</b>—The OS watchdog timer expires 15 minutes after it begins to boot.</li> <li>• <b>20 Minutes</b>—The OS watchdog timer expires 20 minutes after it begins to boot.</li> </ul> <p><b>Note</b> This option is only applicable if you enable the OS Boot Watchdog Timer.</p> |
| <p><b>Baud Rate</b> drop-down list<br/>set <b>BaudRate</b></p>                                   | <p>What Baud rate is used for the serial port transmission speed. If you disable Console Redirection, this option is not available. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>9.6k</b>—A 9,600 Baud rate is used.</li> <li>• <b>19.2k</b>—A 19,200 Baud rate is used.</li> <li>• <b>38.4k</b>—A 38,400 Baud rate is used.</li> <li>• <b>57.6k</b>—A 57,600 Baud rate is used.</li> <li>• <b>115.2k</b>—A 115,200 Baud rate is used.</li> </ul> <p>This setting must match the setting on the remote terminal application.</p>                                                                                                                               |
| <p><b>Console Redirection</b> drop-down list<br/>set <b>ConsoleRedir</b></p>                     | <p>Allows a serial port to be used for console redirection during POST and BIOS booting. After the OS has booted, console redirection is irrelevant. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Serial Port A</b>—Enables console redirection on serial port A during POST.</li> <li>• <b>Serial Port B</b>—Enables console redirection on serial port B during POST.</li> <li>• <b>Disabled</b>—No console redirection occurs during POST.</li> </ul>                                                                                                                                                                                                       |

| Name                                   | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|----------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Adaptive Memory Training</b></p> | <p>When this option is <b>Enabled</b>:</p> <p>The Memory training will not happen in every boot but the BIOS will use the saved memory training result in every re-boot.</p> <p>Some exceptions when memory training happens in every boot are:</p> <p>BIOS update, CMOS reset, CPU or Memory configuration change, SPD or run-time uncorrectable error or the last boot has occurred more than 24 hours before.</p> <p>When this option is <b>Disabled</b>, the Memory training happens in every boot.</p> <p>Default value: <b>Enabled</b>.</p> <p><b>Note</b> To disable the Fast Boot option, the end user must set the following tokens as mentioned below:</p> <p>Adaptive Memory Training to <b>Disabled</b></p> <p>BIOS Techlog level to <b>Normal</b></p> <p>OptionROM Launch Optimization to <b>Disabled</b>.</p> |
| <p><b>BIOS Techlog Level</b></p>       | <p>This option denotes the type of messages in <b>BIOS tech log</b> file.</p> <p>The log file can be one of the following types:</p> <ul style="list-style-type: none"> <li>• <b>Minimum</b> - Critical messages will be displayed in the log file.</li> <li>• <b>Normal</b> - Warning and loading messages will be displayed in the log file.</li> <li>• <b>Maximum</b> - Normal and information related messages will be displayed in the log file.</li> </ul> <p>Default value: <b>Minimum</b>.</p> <p><b>Note</b> This option is mainly for internal debugging purposes.</p>                                                                                                                                                                                                                                            |

| Name                                                      | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|-----------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>OptionROM Launch Optimization</b>                      | <p>When this option is <b>Enabled</b>, the OptionROMs only for the controllers present in the boot order policy will be launched.</p> <p><b>Note</b> Some controllers such as Onboard storage controllers, Emulex FC adapters, and GPU controllers though not listed in the boot order policy will have the OptionROM launched.</p> <p>When this option is <b>Disabled</b>, all the OptionROMs will be launched.</p> <p>Default value: <b>Enabled</b></p>                       |
| <b>CDN Control</b> drop-down list<br><b>set cdnEnable</b> | <p>Whether the Ethernet Network naming convention is according to Consistent Device Naming (CDN) or the traditional way of naming conventions. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>— CDN support for VIC cards is disabled</li> <li>• <b>Enabled</b>— CDN support is enabled for VIC cards.</li> </ul>                                                                                                                |
| <b>FRB 2 Timer</b> drop-down list<br><b>set FRB-2</b>     | <p>Whether the FRB2 timer is used by Cisco IMC to recover the system if it hangs during POST. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The FRB2 timer is not used.</li> <li>• <b>Enabled</b>—The FRB2 timer is started during POST and used to recover the system if necessary.</li> </ul>                                                                                                                                |
| <b>Flow Control</b> drop-down list<br><b>set FlowCtrl</b> | <p>Whether a handshake protocol is used for flow control. Request to Send / Clear to Send (RTS/CTS) helps to reduce frame collisions that can be introduced by a hidden terminal problem. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>None</b>—No flow control is used.</li> <li>• <b>RTS/CTS</b>—RTS/CTS is used for flow control.</li> </ul> <p><b>Note</b> This setting must match the setting on the remote terminal application.</p> |

| Name                                                                          | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Terminal type</b> drop-down list<br><b>set TerminalType</b>                | What type of character formatting is used for console redirection. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>PC-ANSI</b>—The PC-ANSI terminal font is used.</li> <li>• <b>VT100</b>—A supported VT100 video terminal and its character set are used.</li> <li>• <b>VT100-PLUS</b>—A supported VT100-plus video terminal and its character set are used.</li> <li>• <b>VT-UTF8</b>—A video terminal with the UTF-8 character set is used.</li> </ul>    |
| <b>PCIe Slots CDN Control</b> drop-down list<br><b>set PcieSlotsCdnEnable</b> | <p><b>Note</b> This option is available only on Cisco UCS C240 M5 servers equipped with Qlogic cards in slots 2 or 5.</p> <p>Whether the Ethernet Network naming convention is according to Consistent Device Naming (CDN) or the traditional way of naming conventions. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>— CDN support for VIC cards is disabled</li> <li>• <b>Enabled</b>— CDN support is enabled for VIC cards.</li> </ul> |

## Security Tab



**Note** BIOS parameters listed in this tab may vary depending on the server.

Table 4: BIOS Parameters in Security Tab

| Name                                                                           | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|--------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Reboot Host Immediately</b> checkbox                                        | <b>If the Reboot Host Immediately check box is checked, the server is rebooted immediately and the new BIOS settings go into effect. Otherwise the changes are saved until the server is manually rebooted.</b>                                                                                                                                                                                                                                                                                                                    |
| <b>Trusted Platform Module State</b> drop-down list<br><b>set TPMAdminCtrl</b> | Trusted Platform Module (TPM ) is a microchip designed to provide basic security-related functions primarily involving encryption keys. This option allows you to control the TPM Security Device support for the system. It can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The server does not use the TPM.</li> <li>• <b>Enabled</b>—The server uses the TPM.</li> </ul> <p><b>Note</b> Contact your operating system vendor to make sure the operating system supports this feature.</p> |
| <b>SHA-1 PCR Bank</b>                                                          | Enable or Disable SHA-1 PCR Bank. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>Enabled</b>—Support is enabled.</li> </ul>                                                                                                                                                                                                                                                                                                                         |
| <b>SHA256 PCR Bank</b>                                                         | Enable or Disable SHA256 PCR Bank. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>Enabled</b>—Support is enabled.</li> </ul>                                                                                                                                                                                                                                                                                                                        |
| <b>Intel Trusted Execution Technology Support</b>                              | Can be Enabled only when Trusted Platform Module (TPM) is Enabled. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>Enabled</b>—Support is enabled.</li> </ul>                                                                                                                                                                                                                                                                                        |
| <b>Power ON Password</b> drop-down list<br><b>set PowerOnPassword</b>          | This token requires that you set a BIOS password before using the F2 BIOS configuration. If enabled, password needs to be validated before you access BIOS functions such as IO configuration, BIOS set up, and booting to an operating system using BIOS. It can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>Enabled</b>—Support is enabled.</li> </ul>                                                                                                  |



## Processor Tab



**Note** BIOS parameters listed in this tab may vary depending on the server.

*Table 5: BIOS Parameters in Processor Tab*

| Name                                                                        | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-----------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Intel Virtualization Technology</b> drop-down list<br><b>set IntelVT</b> | Whether the processor uses Intel Virtualization Technology (VT), which allows a platform to run multiple operating systems and applications in independent partitions. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit virtualization.</li> <li>• <b>Enabled</b>—The processor allows multiple operating systems in independent partitions.</li> </ul>                                     |
| <b>Extended APIC</b> drop-down list<br><b>set LocalX2Apic</b>               | Allows you to enable or disable extended APIC support. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Enabled</b>—Enables APIC support</li> <li>• <b>Disabled</b>—Disables APIC support.</li> </ul>                                                                                                                                                                                                                                  |
| <b>Processor C1E</b> drop-down list<br><b>set ProcessorC1E</b>              | Whether the CPU transitions to its minimum frequency when entering the C1 state. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The CPU continues to run at its maximum frequency in C1 state.</li> <li>• <b>Enabled</b>—The CPU transitions to its minimum frequency. This option saves the maximum amount of power in C1 state.</li> </ul> <p><b>Note</b> This option is available only on some C-Series servers.</p> |

| Name                                                                              | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Processor C6 Report</b> drop-down list<br/>set <b>ProcessorC6Report</b></p> | <p>Whether the BIOS sends the C6 report to the operating system. When the OS receives the report, it can transition the processor into the lower C6 power state to decrease energy usage while maintaining optimal processor performance. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The BIOS does not send the C6 report.</li> <li>• <b>Enabled</b>—The BIOS sends the C6 report, allowing the OS to transition the processor to the C6 low power state.</li> </ul> <p><b>Note</b>      <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p> <p><b>Note</b>      This option is available only on some C-Series servers.</p> |
| <p><b>Execute Disable Bit</b> drop-down list<br/>set <b>ExecuteDisable</b></p>    | <p>Classifies memory areas on the server to specify where application code can execute. As a result of this classification, the processor disables code execution if a malicious worm attempts to insert code in the buffer. This setting helps to prevent damage, worm propagation, and certain classes of malicious buffer overflow attacks. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not classify memory areas.</li> <li>• <b>Enabled</b>—The processor classifies memory areas.</li> </ul> <p><b>Note</b>      Contact your operating system vendor to make sure the operating system supports this feature.</p>                                                 |

| Name                                                                       | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|----------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Turbo Mode</b> drop-down list<br/>set <b>IntelTurboBoostTech</b></p> | <p>Whether the processor uses Intel Turbo Boost Technology, which allows the processor to automatically increase its frequency if it is running below power, temperature, or voltage specifications. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not increase its frequency automatically.</li> <li>• <b>Enabled</b>—The processor utilizes Turbo Boost Technology if required.</li> </ul> <p><b>Note</b>      <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p>                                                                                                                                                    |
| <p><b>EIST PSD Function</b> drop-down list</p>                             | <p>EIST reduces the latency inherent with changing the voltage-frequency pair (P-state), thus allowing those transitions to occur more frequently. This allows for more granular, demand-based switching and can optimize the power-to-performance balance, based on the demands of the applications. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>HW ALL:</b> The processor is coordinates the P-state among logical processors dependencies. The OS keeps the P-state request up to date on all logical processors.</li> <li>• <b>SW ALL:</b> The OS Power Manager coordinates the P-state among logical processors with dependencies and initiates the transition on all of those Logical Processors.</li> </ul> |

| Name                                                                                   | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|----------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>SpeedStep (Pstates)</b> drop-down list<br/>set <b>EnhancedIntelSpeedStep</b></p> | <p>Whether the processor uses Enhanced Intel SpeedStep Technology, which allows the system to dynamically adjust processor voltage and core frequency. This technology can result in decreased average power consumption and decreased average heat production. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor never dynamically adjusts its voltage or frequency.</li> <li>• <b>Enabled</b>—The processor utilizes Enhanced Intel SpeedStep Technology and enables all supported processor sleep states to further conserve power.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p> <p><b>Note</b>        <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p> |
| <p><b>HyperThreading [ALL]</b> drop-down list<br/>set <b>IntelHyperThread</b></p>      | <p>Whether the processor uses Intel Hyper-Threading Technology, which allows multithreaded software applications to execute threads in parallel within each processor. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not permit hyperthreading.</li> <li>• <b>Enabled</b>—The processor allows for the parallel execution of multiple threads.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <p><b>Cores Enabled</b> drop-down list<br/>set <b>CoreMultiProcessing</b></p>          | <p>Allows you to disable one or more of the physical cores on the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>All</b>—Enables all physical cores. This also enables Hyper Threading on the associated logical processor cores.</li> <li>• <b>1 through 27</b>—Specifies the number of physical processor cores that can run on the server. Each physical core has an associated logical core.</li> </ul> <p><b>Note</b>        Contact your operating system vendor to make sure the operating system supports this feature.</p>                                                                                                                                                                                                                                                                                                 |

| Name                                                                                             | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|--------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Processor CMCI</b> drop-down list<br/>set <b>ProcessorCMCI</b></p>                         | <p>Allows the CPU to trigger interrupts on corrected machine check events. The corrected machine check interrupt (CMCI) allows faster reaction than the traditional polling timer. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Disables CMCI.</li> <li>• <b>Enabled</b>—Enables CMCI. This is the default value.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <p><b>Enhanced Intel SpeedStep Tech</b> drop-down list<br/>set <b>EnhancedIntelSpeedStep</b></p> | <p>Whether the processor uses Enhanced Intel SpeedStep Technology, which allows the system to dynamically adjust processor voltage and core frequency. This technology can result in decreased average power consumption and decreased average heat production. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor never dynamically adjusts its voltage or frequency.</li> <li>• <b>Enabled</b>—The processor utilizes Enhanced Intel SpeedStep Technology and enables all supported processor sleep states to further conserve power.</li> </ul> <p>We recommend that you contact your operating system vendor to make sure the operating system supports this feature.</p> <p><b>Note</b> <b>CPUPowerManagement</b> must be set to <b>Custom</b> or the server ignores the setting for this parameter.</p> |
| <p><b>Workload Configuration</b> drop-down list<br/>set <b>WorkLdConfig</b></p>                  | <p>This feature allows for workload optimization. The options are Balanced and I/O Sensitive:</p> <ul style="list-style-type: none"> <li>• <b>NUMA</b></li> <li>• <b>UMA</b></li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <p><b>Sub NUMA Clustering</b> drop-down list</p>                                                 | <p>Whether the CPU supports sub NUMA clustering, in which the tag directory and the memory channel are always in the same region. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>disabled</b>— Sub NUMA clustering does not occur.</li> <li>• <b>enabled</b>— Sub NUMA clustering occurs.</li> <li>• <b>auto</b> — The BIOS determines what Sub NUMA clustering is done.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

| Name                                  | Description                                                                                                                                                                                                                                                                                                                                                                           |
|---------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Energy/Performance Bias Config</b> | <p>Displays the energy or performance bias configuration.</p> <p>This can be one of the following:</p> <ul style="list-style-type: none"> <li>• Balanced Performance</li> <li>• Performance</li> <li>• Balanced Power</li> <li>• Power</li> </ul>                                                                                                                                     |
| <b>XPT Prefetch</b> drop-down list    | <p>Whether XPT prefetch is used to enable a read request sent to the last level cache to issue a copy of that request to the memory controller prefetcher. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>disabled</b>—The CPU does not use the XPT Prefetch option.</li> <li>• <b>enabled</b>—The CPU enables the XPT prefetch option.</li> </ul> |
| <b>UPI Prefetch</b> drop-down list    | <p>UPI prefetch is a mechanism to get the memory read started early on a DDR bus. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>disabled</b>—The processor does not preload any cache data.</li> <li>• <b>enabled</b>—The UPI prefetcher preloads the L1 cache with the data it determines to be the most relevant.</li> </ul>                    |

| Name                                                                              | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Energy Performance Bias Config</b> drop-down list<br><b>set CpuEngPerfBias</b> | <p>Allows you to determine whether system performance or energy efficiency is more important on this server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• — The server provides all server components with full power at all times. This option maintains the highest level of performance and requires the greatest amount of power.</li> <li>• — The server provides all server components with enough power to keep a balance between performance and power.</li> <li>• — The server provides all server components with enough power to keep a balance between performance and power.</li> <li>• — The server provides all server components with maximum power to keep reduce power consumption.</li> </ul> |
| <b>Power Performance Tuning</b> drop-down list<br><b>set PwrPerfTuning</b>        | <p>Determines if the BIOS or Operating System can turn on the energy performance bias tuning. The options are BIOS and OS.</p> <ul style="list-style-type: none"> <li>• <b>bios</b>—<br/>Chooses BIOS for energy performance tuning.</li> <li>• <b>os</b>—<br/>Chooses OS for energy performance tuning.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>LLC Prefetch</b> drop-down list                                                | <p>Whether the processor uses the LLC Prefetch mechanism to fetch the date into the LLC. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>disabled</b>—The processor does not preload any cache data.</li> <li>• <b>enabled</b>—The LLC prefetcher preloads the L1 cache with the data it determines to be the most relevant.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                          |

| Name                                                                                                             | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Package C State</b></p> <p><b>set package-c-state-limit-config</b></p> <p><b>package-c-state-limit</b></p> | <p>The amount of power available to the server components when they are idle. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>no-limit</b>—The server may enter any available C state.</li> <li>• <b>auto</b> —The CPU determines the physical elevation.</li> <li>• —The server provides all server components with full power at all times. This option maintains the highest level of performance and requires the greatest amount of power.</li> <li>• —When the CPU is idle, the system reduces the power consumption further than with the C1 option. This requires less power than C1 or C0, but it takes the server slightly longer to return to high performance mode.</li> <li>• —When the CPU is idle, the system reduces the power consumption further than with the C3 option. This option saves more power than C0, C1, or C3, but there may be performance issues until the server returns to full power.</li> <li>• —When the CPU is idle, the system reduces the power consumption further than with the C3 option. This option saves more power than C0, C1, or C3, but there may be performance issues until the server returns to full power.</li> </ul> |
| <p><b>Hardware P-States</b> drop-down list</p> <p><b>set CpuHWPM</b></p>                                         | <p>Enables processor Hardware P-State. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>disabled</b>—HWPM is disabled.</li> <li>• <b>hwpm-native-mode</b>—HWPM native mode is enabled.</li> <li>• <b>hwpm-oob-mode</b>—HWPM Out-Of-Box mode is enabled.</li> <li>• <b>Native Mode with no Legacy</b> (only GUI)</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |



| Name                                                                              | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Intel Speed Select</b> drop-down list<br/>set <b>IntelSpeedSelect</b></p>   | <p><b>Intel Speed Select</b> modes will allow users to run the CPU with different speed and cores.</p> <p>This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Base</b>— It will allow users to access maximum core and Thermal Design Power (TDP) ratio.</li> <li>• <b>Config 1</b>— It will allow users to access core and TDP ratio lesser than <b>Base</b>.</li> <li>• <b>Config 2</b>— It will allow users to access core and TDP ratio lesser than <b>Config 1</b>.</li> </ul> <p>Default value: <b>Base</b>.</p>                                                                                                                   |
| <p><b>Uncore Frequency Scaling</b> drop-down list<br/>set <b>UFSDisable</b></p>   | <p>This feature allows you configure the scaling of uncore frequency of the processor. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>enabled</b>—Uncore frequency of the processor scales up or down based on the load.</li> <li>• <b>disabled</b>—Uncore frequency of the processor remains fixed.</li> </ul> <p>Refer Intel® Dear Customer Letter (DCL) to know the fixed higher and lower values for <b>Uncore Frequency Scaling</b>.</p>                                                                                                                                                                                       |
| <p><b>Configurable TDP Level</b> drop-down list<br/>set <b>ConfigTDPLevel</b></p> | <p><b>Configurable TDP Level</b> feature allows adjustments in processor thermal design power values. By modifying the processor behavior and the performance levels, power consumption of a processor can be configured and TDP can be adjusted as the same time. Hence, a processor operates at higher or lower performance levels, depending on the available cooling capacities and desired power consumption. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Normal</b></li> <li>• <b>Level 1</b></li> <li>• <b>Level 2</b></li> </ul> <p>Refer Intel® Dear Customer Letter (DCL) to know the values for <b>TDP level</b>.</p> |

| Name                                                                                    | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-----------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>UPI Link Speed</b> drop-down list<br/>set <b>QpiLinkSpeed</b></p>                 | <p><b>Note</b>      <b>UPI Link Frequency Select</b> token is not applicable for single socket configuration.</p> <p>This feature allows you to configure the Intel Ultra Path Interconnect (UPI) link speed between multiple sockets. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Auto</b>—This option configures the optimal link speed automatically.</li> <li>• <b>9.6 GT/s</b>—This option configures the optimal link speed at 9.6GT/s.</li> <li>• <b>10.4 GT/s</b>—This option configures the optimal link speed at 10.4GT/s</li> </ul> |
| <p><b>Energy Efficient Turbo</b> drop-down list<br/>set <b>EnergyEfficientTurbo</b></p> | <p>When energy efficient turbo is enabled, the optimal turbo frequency of the CPU turns dynamic based on CPU utilization. The power/performance bias setting also influences energy efficient turbo. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Energy Efficient Turbo is disabled.</li> <li>• <b>Enabled</b>—Energy Efficient Turbo is enabled.</li> </ul>                                                                                                                                                                      |
| <p><b>Processor EPP Enable</b></p>                                                      | <p>Displays the selected value for Processor EPP Enable.</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Processor EPP Enable is disabled.</li> <li>• <b>Enabled</b>—Processor EPP Enable is enabled.</li> </ul>                                                                                                                                                                                                                                                                                                                                                        |
| <p><b>Autonomous Core C-state</b> drop-down list<br/>set <b>AutoCCState</b></p>         | <p>Enables CPU Autonomous C-State, which converts the HALT instructions to the MWAIT instructions. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—CPU Autonomous C-state is disabled.</li> <li>• <b>Enabled</b>—CPU Autonomous C-state is enabled.</li> </ul>                                                                                                                                                                                                                                                                        |

| Name                                                                 | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|----------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Patrol Scrub</b> drop-down list<br><b>set PatrolScrub</b>         | Allows the system to actively search for, and correct, single bit memory errors even in unused portions of the memory on the server. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The system checks for memory ECC errors only when the CPU reads or writes a memory address.</li> <li>• <b>Enabled</b>—The system periodically reads and writes memory searching for ECC errors. If any errors are found, the system attempts to fix them. This option may correct single bit errors before they become multi-bit errors, but it may adversely affect performance when the patrol scrub is running.</li> <li>• <b>Enable at End of POST</b>—The system checks for memory ECC errors after BIOS POST.</li> </ul> |
| <b>Processor EPP Profile</b> drop-down list<br><b>set EPPProfile</b> | Allows you to determine whether system performance or energy efficiency is more important on this server. This can be one of the following: <ul style="list-style-type: none"> <li>• Performance</li> <li>• Balanced Performance</li> <li>• Balanced Power</li> <li>• Power</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |

## Memory Tab



**Note** BIOS parameters listed in this tab may vary depending on the server.

*Table 6: BIOS Parameters in Memory Tab*

| Name                                    | Description                                                                                           |
|-----------------------------------------|-------------------------------------------------------------------------------------------------------|
| <b>Reboot Host Immediately</b> checkbox | Upon checking, reboots the host server immediately. You must check the checkbox after saving changes. |

| Name                                                                                | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Select Memory RAS configuration</b> drop-down list<br><b>set SelectMemoryRAS</b> | <p>Determines how the memory reliability, availability, and serviceability (RAS) is configured for the server. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Maximum Performance</b>—System performance is optimized.</li> <li>• <b>ADDDC Sparing</b>—Adaptive virtual lockstep is an algorithm implemented in the hardware and firmware to support the ADDDC mode. When selected, the system performance is optimized till the algorithm is activated. The algorithm is activated in case of DRAM device failure. Once the algorithm is activated, the virtual lockstep regions are activated to map out the failed region during run-time dynamically, and the performance impact is restricted at a region level.</li> <li>• <b>Mirror Mode 1LM</b>—System reliability is optimized by using half the system memory as backup.</li> <li>• <b>Partial Mirror Mode 1LM</b>—Partial DIMM Mirroring creates a mirrored copy of a specific region of memory cells, rather than keeping the complete mirror copy. Partial Mirroring creates a mirrored region in memory map with the attributes of a partial mirror copy. Up to 50% of the total memory capacity can be mirrored, using up to 4 partial mirrors.</li> </ul> |
| <b>Above 4G Decoding</b> drop-down list<br><b>set MemoryMappedIOAbove4GB</b>        | <p>Enables or disables MMIO above 4GB or not. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The server does not map I/O of 64-bit PCI devices to 4GB or greater address space.</li> <li>• <b>Enabled</b>—The server maps I/O of 64-bit PCI devices to 4GB or greater address space.</li> </ul> <p><b>Note</b> PCI devices that are 64-bit compliant but use a legacy option ROM may not function correctly with this setting enabled.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>DCPMM Firmware Downgrade</b> drop-down list<br><b>set DCPMMFirmwareDowngrade</b> | <p>Whether the BIOS supports downgrading the DCPMM firmware. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>Enabled</b>—Support is enabled.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

| Name                                                                                   | Description                                                                                                                                                                                                                                                                                                                                                   |
|----------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Partial Memory Mirror Mode</b> drop-down list<br><b>set PartialMirrorModeConfig</b> | The partial memory size is either in percentage or in GB. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Percentage</b>—The partial memory mirror is defined in percentage.</li> <li>• <b>Value in GB</b>—The partial memory mirror is defined in GB.</li> <li>• <b>Disabled</b>—Partial memory mirror is disabled.</li> </ul> |
| <b>Partial Mirror percentage</b> field<br><b>set PartialMirrorPercent</b>              | Percentage of memory to mirror above 4GB.<br>Enter an integer between 0 and 50.                                                                                                                                                                                                                                                                               |
| <b>Partial Mirror1 Size in GB</b> field<br><b>set PartialMirrorValue1</b>              | Size of the first partial memory mirror in GB.<br>Enter an integer between 0 and 65535.<br><b>Note</b> The combined memory size of all the partial mirror should not exceed 50% of the physical memory size.                                                                                                                                                  |
| <b>Partial Mirror2 Size in GB</b> field<br><b>set PartialMirrorValue2</b>              | Size of the second partial memory mirror in GB.<br>Enter an integer between 0 and 65535.<br><b>Note</b> The combined memory size of all the partial mirror should not exceed 50% of the physical memory size.                                                                                                                                                 |
| <b>Partial Mirror3 Size in GB</b> field<br><b>set PartialMirrorValue3</b>              | Size of the third partial memory mirror in GB.<br>Enter an integer between 0 and 65535.<br><b>Note</b> The combined memory size of all the partial mirror should not exceed 50% of the physical memory size.                                                                                                                                                  |
| <b>Partial Mirror4 Size in GB</b> field<br><b>set PartialMirrorValue4</b>              | Size of the fourth partial memory mirror in GB.<br>Enter an integer between 0 and 65535.<br><b>Note</b> The combined memory size of all the partial mirror should not exceed 50% of the physical memory size.                                                                                                                                                 |
| <b>Memory Size Limit in GB</b> field<br><b>set MemorySizeLimit</b>                     | Use this option to reduce the size of the physical memory limit in GB.<br>Enter an integer between 0 and 65535.                                                                                                                                                                                                                                               |

| Name                                                                    | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>NUMA</b> drop-down list<br><b>set NUMAOptimize</b>                   | Whether the BIOS supports Non-Uniform Memory Access (NUMA). This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>Enabled</b>—Support is enabled.</li> </ul>                                                                                                                                                                                                                                                                                                                |
| <b>BME DMA Mitigation</b> drop-down list<br><b>set BmeDmaMitigation</b> | Allows you to disable the PCI BME bit to mitigate the threat from an unauthorized external DMA. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—PCI BME bit is disabled in the BIOS.</li> <li>• <b>Enabled</b>—PCI BME bit is enabled in the BIOS.</li> </ul>                                                                                                                                                                                                                                            |
| <b>Select PPR Type</b> drop-down list<br><b>set SelectPprType</b>       | Cisco IMC supports <b>Hard-PPR</b> , which permanently remaps accesses from a designated faulty row to a designated spare row.<br><br>This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Hard PPR</b>—Support is enabled.</li> </ul> <p><b>Note</b> Hard PPR can be used only when <b>Memory RAS Configuration</b> is set to <b>ADDDC Sparing</b>. For other RAS selections, this setting should be set to <b>Disabled</b>.</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> </ul> |
| <b>CR QoS</b> drop-down list<br><b>CRQoS</b>                            | Enables you to select the CR QoS tuning.<br><br>This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Recipe 1</b>—For QoS knobs and is recommended for 2-2-2 memory configuration in active directory.</li> <li>• <b>Recipe 2</b>—For QoS knobs and is recommended for other memory configuration in active directory.</li> <li>• <b>Recipe 3</b>—For QoS knobs and is recommended for 1 DIMM per channel configuration.</li> <li>• <b>Disabled</b>—CR QoS feature is disabled.</li> </ul>                                 |

| Name                                                                         | Description                                                                                                                                                                                                                                                                                                                    |
|------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Snoopy mode for AD</b> drop-down list<br><b>SnoopyModeForAD</b>           | Enables new AD specific feature to avoid directory updates to DDRT memory from non-NUMA optimized workloads.<br><br>This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>Enabled</b>—Support is enabled.</li> </ul>                                   |
| <b>CR FastGo Config</b> drop-down list<br><b>CrfastgoConfig</b>              | Enables you to select CR QoS configuration profiles.<br><br>This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Default</b></li> <li>• <b>Option 1</b></li> <li>• <b>Option 2</b></li> <li>• <b>Option 3</b></li> <li>• <b>Option 4</b></li> <li>• <b>Option 5</b></li> <li>• <b>Auto</b></li> </ul> |
| <b>NVM Performance Setting</b> drop-down list<br><b>NvmdimmPerformConfig</b> | Enables you to configure NVM baseline performance settings depending on the workload behavior. <ul style="list-style-type: none"> <li>• <b>BW Optimized</b></li> <li>• <b>Latency Optimized</b></li> <li>• <b>Balanced Profile</b></li> </ul>                                                                                  |
| <b>Snoopy mode for 2LM</b> drop-down list<br><b>SnoopyModeFor2LM</b>         | Enables you to avoid directory updates to far-memory from non-NUMA optimized workloads.<br><br>This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>Enabled</b>—Support is enabled.</li> </ul>                                                        |

| Name                                                                                   | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|----------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Memory Thermal Throttling Mode</b> drop-down list<br><b>MemoryThermalThrottling</b> | <p>This function is used for adjusting memory temperature. If memory temperature is excessively high after the function is enabled, the memory access rate is reduced and Baseboard Management Controller (BMC) adjusts the fan to cool down the memory to avoid any DIMM damage.</p> <p>This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>CLTT with PECE</b>—Enables Closed Loop Thermal Throttling with Platform Environment Control Interface.</li> </ul> |
| <b>Memory Refresh Rate</b> drop-down list<br><b>MemoryRefreshRate</b>                  | <p>Enables you to increase or decrease memory refresh rate. Increasing the DRAM refresh rate reduces the maximum number of activates (hammers) that can occur before the next refresh.</p> <p>This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>1X Refresh</b>—Refresh rate is at minimum.</li> <li>• <b>2X Refresh</b>—Refresh is 2X faster.</li> </ul>                                                                                                                                                     |
| <b>Panic and High Watermark</b> drop-down list<br><b>PanicHighWatermark</b>            | <p>When set to low, the memory controller does not postpone refreshes while <b>Memory Refresh Rate</b> is set to <b>1X Refresh</b>.</p> <p>This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Low</b>—Refresh rate is set to low.</li> <li>• <b>High</b>—Refresh rate is set to high.</li> </ul>                                                                                                                                                                                                              |
| <b>Advanced Memory Test</b> drop-down list<br><b>AdvancedMemTest</b>                   | <p><b>Note</b> This feature is applicable only to Samsung, Hynix and Micron DIMMs.</p> <p>You can enable advance DIMM testing during BIOS POST using this feature. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>Enabled</b>—Support is enabled.</li> </ul>                                                                                                                                                                                              |
| <b>Enhanced Memory Test</b> drop-down list                                             | <p>This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Auto</b>—Support is set to Auto.</li> <li>• <b>Disabled</b>—Support is disabled.</li> <li>• <b>Enabled</b>—Support is enabled.</li> </ul>                                                                                                                                                                                                                                                                                                               |



## Power/Performance Tab



**Note** BIOS parameters listed in this tab may vary depending on the server.

*Table 7: BIOS Parameters in Power/Performance Tab*

| Name                                                                                            | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|-------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Reboot Host Immediately</b><br>checkbox                                                      | Upon checking, reboots the host server immediately. You must check the checkbox after saving changes.                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Hardware Prefetcher</b> drop-down list<br><b>set HardwarePrefetch</b>                        | Whether the processor allows the Intel hardware prefetcher to fetch streams of data and instruction from memory into the unified second-level cache when necessary. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The hardware prefetcher is not used.</li> <li>• <b>Enabled</b>—The processor uses the hardware prefetcher when cache issues are detected.</li> </ul>                                                                                                                          |
| <b>Adjacent Cache Line Prefetcher</b><br>drop-down list<br><b>set AdjacentCacheLinePrefetch</b> | Whether the processor fetches cache lines in even or odd pairs instead of fetching just the required line. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor only fetches the required line.</li> <li>• <b>Enabled</b>—The processor fetches both the required line and its paired line.</li> </ul>                                                                                                                                                                                   |
| <b>DCU Streamer Prefetch</b><br>drop-down list<br><b>set DcuStreamerPrefetch</b>                | Whether the processor uses the DCU IP Prefetch mechanism to analyze historical cache access patterns and preload the most relevant lines in the L1 cache. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not try to anticipate cache read requirements and only fetches explicitly requested lines.</li> <li>• <b>Enabled</b>—The DCU prefetcher analyzes the cache read pattern and prefetches the next line in the cache if it determines that it may be needed.</li> </ul> |
| <b>DCU IP Prefetcher</b> drop-down list<br><b>set DcuIpPrefetch</b>                             | Whether the processor uses the DCU IP Prefetch mechanism to analyze historical cache access patterns and preload the most relevant lines in the L1 cache. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Disabled</b>—The processor does not preload any cache data.</li> <li>• <b>Enabled</b>—The DCU IP prefetcher preloads the L1 cache with the data it determines to be the most relevant.</li> </ul>                                                                                                    |

| Name                                                               | Description                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|--------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>CPU Performance</b> drop-down list<br>set <b>CPUPerformance</b> | Sets the CPU performance profile for the options listed above. This can be one of the following: <ul style="list-style-type: none"><li>• <b>Enterprise</b>—All options are enabled.</li><li>• <b>HPC</b>—All options are enabled. This setting is also known as high performance computing.</li><li>• <b>Hight Throughput</b>—Only the DCU IP Prefetcher is enabled. The rest of the options are disabled.</li><li>• <b>Custom</b>—All performance profile options can be configured from the BIOS setup on the server. In addition, the Hardware Prefetcher and Adjacent Cache-Line Prefetch options can be configured as well.</li></ul> |



## APPENDIX **B**

# BIOS Token Name Comparison for Multiple Interfaces

This appendix contains the following section:

- [BIOS Token Name Comparison for Multiple Interfaces, on page 463](#)

## BIOS Token Name Comparison for Multiple Interfaces

The following table lists the BIOS token names used in the XML, CLI and Web GUI interfaces. You can use this list to map the names across these interfaces.



**Note** The parameters that are available depend on the type of Cisco UCS server you are using.

| BIOS Token Group             | BIOS Token Name                     | XML Object                                                              | CLI and Web GUI Object |
|------------------------------|-------------------------------------|-------------------------------------------------------------------------|------------------------|
| <b>Main</b>                  | TPM Support                         | biosVfTPMSupport/<br>vpTPMSupport                                       | TPMAdminCtrl           |
| <b>Process Configuration</b> | Intel(R) Hyper-Threading Technology | biosVfIntelHyperThreadingTech/<br>vpIntelHyperThreadingTech             | IntelHyperThread       |
|                              | Number of Enable Cores              | biosVfCoreMultiProcessing/<br>vpCoreMultiProcessing                     | CoreMultiProcessing    |
|                              | Execute Disable                     | biosVfExecuteDisableBit/<br>vpExecuteDisableBit                         | ExecuteDisable         |
|                              | Intel(R) VT                         | biosVfIntelVirtualizationTechnology/<br>vpIntelVirtualizationTechnology | IntelVT                |

| BIOS Token Group | BIOS Token Name                        | XML Object                                                        | CLI and Web GUI Object    |
|------------------|----------------------------------------|-------------------------------------------------------------------|---------------------------|
|                  | Intel(R) VT-d                          | biosVfIntelVTForDirectedIO/<br>vpIntelVTForDirectedIO             | IntelVTD                  |
|                  | Intel(R) VT-d Coherency Support        | biosVfIntelVTForDirectedIO/<br>vpIntelVTDCoherencySupport         | CoherencySupport          |
|                  | Intel(R) VT-d ATS Support              | biosVfIntelVTForDirectedIO/<br>vpIntelVTDATSSupport               | ATS                       |
|                  | CPU Performance                        | biosVfCPUPerformance/<br>vpCPUPerformance                         | CpuPerformanceProfile     |
|                  | Hardware Prefetcher                    | biosVfHardwarePrefetch/<br>vpHardwarePrefetch                     | HardwarePrefetch          |
|                  | Adjacent Cache Line Prefetcher         | biosVfAdjacentCacheLinePrefetch/<br>vpAdjacentCacheLinePrefetch   | AdjacentCacheLinePrefetch |
|                  | DCU Streamer Prefetch                  | biosVfDCUPrefetch/<br>vvpStreamerPrefetch                         | DcuStreamerPrefetch       |
|                  | DCU IP Prefetcher                      | biosVfDCUPrefetch/<br>vpIPPrefetch                                | DcuIpPrefetch             |
|                  | Direct Cache Access Support            | biosVfDirectCacheAccess/<br>vpDirectCacheAccess                   | DirectCacheAccess         |
|                  | Power Technology                       | biosVfCPUPowerManagement/<br>vpCPUPowerManagement                 | CPUPowerManagement        |
|                  | Enhanced Intel Speedstep(R) Technology | biosVfEnhancedIntelSpeedStepTech/<br>vpEnhancedIntelSpeedStepTech | EnhancedIntelSpeedStep    |
|                  | Intel(R) Turbo Boost Technology        | biosVfIntelTurboBoostTech/<br>vpIntelTurboBoostTech               | IntelTurboBoostTech       |
|                  | Processor Power state C6               | biosVfProcessorCState/<br>vpProcessorCState                       | ProcessorC6Report         |
|                  | Processor Power state C1 Enhanced      | biosVfProcessorC1E/<br>vpProcessorC1E                             | ProcessorC1E              |

| BIOS Token Group            | BIOS Token Name           | XML Object                                                            | CLI and Web GUI Object |
|-----------------------------|---------------------------|-----------------------------------------------------------------------|------------------------|
|                             | Frequency Floor Override  | biosVfCPUFrequencyFloor/<br>vpCPUFrequencyFloor                       | CpuFreqFloor           |
|                             | P-STATE Coordination      | biosVfPStateCoordType/<br>vpPStateCoordType                           | PsdCoordType           |
|                             | Energy Performance        | biosVfCPUEnergyPerformance/<br>vpCPUEnergyPerformance                 | CpuEngPerfBias         |
| <b>Memory Configuration</b> | Select Memory RAS         | biosVfSelectMemoryRASConfiguration/<br>vpSelectMemoryRASConfiguration | SelectMemoryRAS        |
|                             | DRAM Clock Throttling     | biosVfDRAMClockThrottling/<br>vpDRAMClockThrottling                   | DRAMClockThrottling    |
|                             | NUMA                      | biosVfNUMAOptimized/<br>vpNUMAOptimized                               | NUMAOptimize           |
|                             | Low Voltage DDR Mode      | biosVfLvDIMMSupport/<br>vpNUMAOptimized                               | LvDDRMode              |
|                             | DRAM Refresh rate         | biosVfDramRefreshRate/<br>vpDramRefreshRate                           | DramRefreshRate        |
|                             | Channel Interleaving      | biosVfMemoryInterleave/<br>vpChannelInterLeave                        | ChannelInterLeave      |
|                             | Rank Interleaving         | biosVfMemoryInterleave/<br>vpRankInterLeave                           | RankInterLeave         |
|                             | Patrol Scrub              | biosVfPatrolScrub/<br>vpPatrolScrub                                   | PatrolScrub            |
|                             | Demand Scrub              | biosVfDemandScrub/<br>vpDemandScrub                                   | DemandScrub            |
|                             | Altitude                  | biosVfAltitude/<br>vpAltitude                                         | Altitude               |
| <b>QPI Configuration</b>    | QPI Link Frequency Select | biosVfQPICongfig/<br>vpQPILinkFrequency                               | QPILinkFrequency       |
|                             | Cluster on Die            | biosVfCODEnable/<br>vpCODEnable                                       | CODEnable              |

| BIOS Token Group          | BIOS Token Name              | XML Object                                                | CLI and Web GUI Object |
|---------------------------|------------------------------|-----------------------------------------------------------|------------------------|
|                           | Snoop Mode                   | biosVfEarlySnoop/<br>vpEarlySnoop                         | EarlySnoop             |
| <b>SATA Configuration</b> | SATA Mode                    | Not supported                                             | SATAMode               |
| <b>Onboard Storage</b>    | Onboard SCU Storage Support  | biosVfOnboardStorage/<br>vpOnboardSCUStorageSupport       | DisableSCU             |
|                           | Onboard SCU Storage SW Stack | biosVfOnboardStorageSWStack<br>vpOnboardSCUStorageSWStack | PchScuOromSelect       |
| <b>USB Configuration</b>  | Legacy USB Support           | biosVfLegacyUSBSupport/<br>vpLegacyUSBSupport             | LegacyUSBSupport       |
|                           | Port 60/64 Emulation         | biosVfUSBEmulation/<br>vpUSBEmul6064                      | UsbEmul6064            |
|                           | All USB Devices              | biosVfUSBPortsConfig/<br>vpAllUsbDevices                  | AllUsbDevices          |
|                           | USB Port:Rear                | biosVfUSBPortsConfig/<br>vpUsbPortRear                    | UsbPortRear            |
|                           | USB Port:Front               | biosVfUSBPortsConfig/<br>vpUsbPortFront                   | UsbPortFront           |
|                           | USB Port:Internal            | biosVfUSBPortsConfig/<br>vpUsbPortInternal                | UsbPortInt             |
|                           | USB Port:KVM                 | biosVfUSBPortsConfig/<br>vpUsbPortKVM                     | UsbPortKVM             |
|                           | USB Port:Vmedia              | biosVfUSBPortsConfig/<br>vpUsbPortVMedia                  | UsbPortVMedia          |
|                           | USB Port:SD Card             | biosVfUSBPortsConfig/<br>vpUsbPortSDCard                  | UsbPortSdCard          |
|                           | xHCI Mode                    | biosVfPchUsb30Mode/<br>vpPchUsb30Mode                     | PchUsb30Mode           |
| <b>PCI Configuration</b>  | PCI ROM CLP                  | Not Supported                                             | PciRomClp              |

| BIOS Token Group                        | BIOS Token Name             | XML Object                                                | CLI and Web GUI Object |
|-----------------------------------------|-----------------------------|-----------------------------------------------------------|------------------------|
|                                         | MMIO above 4GB              | biosVfMemoryMappedIOAbove4GB/<br>vpMemoryMappedIOAbove4GB | MemoryMappedIOAbove4GB |
|                                         | ASPM Support                | biosVfASPMSupport/<br>vpASPMSupport                       | ASPMSupport            |
|                                         | VGA Priority                | biosVfVgaPriority/<br>vpVgaPriority                       | VgaPriority            |
| <b>Serial Configuration</b>             | Console Redirection         | biosVfConsoleRedirection/<br>vpConsoleRedirection         | ConsoleRedir           |
|                                         | Terminal Type               | biosVfConsoleRedirection/<br>vpTerminalType               | TerminalType           |
|                                         | Bits per second             | biosVfConsoleRedirection/<br>vpBaudRate                   | BaudRate               |
|                                         | Flow Control                | biosVfConsoleRedirection/<br>vpFlowControl                | FlowCtrl               |
|                                         | Putty KeyPad                | biosVfConsoleRedirection/<br>vpPuttyKeyPad                | PuttyFunctionKeyPad    |
|                                         | Redirection After BIOS POST | biosVfConsoleRedirection/<br>vpLegacyOSRedirection        | RedirectionAfterPOST   |
| <b>LOM and PCIe Slots Configuration</b> | PCH SATA Mode               | biosVfSataModeSelect/<br>vpSataModeSelect                 | SataModeSelect         |
|                                         | All Onboard LOM Ports       | biosVfSataModeSelect/<br>vpSataModeSelect                 | AllLomPortControl      |
|                                         | LOM Port 0 OptionROM        | biosVfLOMPortOptionROM/<br>vpLOMPort0State                | LomOpromControlPort0   |
|                                         | LOM Port 1 OptionROM        | biosVfLOMPortOptionROM/<br>vpLOMPort1State                | LomOpromControlPort1   |
|                                         | All PCIe Slots OptionROM    | biosVfPCIOptionROMs/<br>vpPCIOptionROMs                   | PcieOptionROMs         |

| BIOS Token Group         | BIOS Token Name                                  | XML Object                                                       | CLI and Web GUI Object      |
|--------------------------|--------------------------------------------------|------------------------------------------------------------------|-----------------------------|
|                          | PCIe Slot: <i>n</i> OptionROM                    | biosVfPCISlotOptionROMEnable/<br>vpSlot <i>n</i> State           | PcieSlot <i>n</i> OptionROM |
|                          | PCIe Mezzanine OptionROM                         | biosVfPCISlotOptionROMEnable/<br>vpSlotMezzState                 | PcieMezzOptionROM           |
|                          | PCIe Slot:1 Link Speed<br>or<br>SIOC1 Link Speed | biosVfPCISlotOptionROMEnable/<br>vpSlot1LinkSpeed                | PcieSlot1LinkSpeed          |
|                          | PCIe Slot:2 Link Speed<br>or<br>SIOC2 Link Speed | biosVfPCISlotOptionROMEnable/<br>vpSlot2LinkSpeed                | PcieSlot2LinkSpeed          |
|                          | PCIe Slot:MLOM OptionROM                         | biosVfPCISlotOptionROMEnable/<br>vpSlotMLOMState                 | PcieSlotMLOMOptionROM       |
|                          | PCIe Slot:HBA OptionROM                          | biosVfPCISlotOptionROMEnable/<br>vpSlotHBAState                  | PcieSlotHBAOptionROM        |
|                          | PCIe Slot:N1 OptionROM                           | biosVfPCISlotOptionROMEnable/<br>vpSlotN1State                   | PcieSlotN1OptionROM         |
|                          | PCIe Slot:N2 OptionROM                           | biosVfPCISlotOptionROMEnable/<br>vpSlotN2State                   | PcieSlotN2OptionROM         |
| <b>Server Management</b> | FRB-2 Timer                                      | biosVfFRB2Enable/<br>vpFRB2Enable                                | FRB-2                       |
|                          | OS Watchdog Timer                                | biosVfOSBootWatchdogTimer/<br>vpOSBootWatchdogTimer              | OSBootWatchdogTimer         |
|                          | OS Watchdog Timer Timeout                        | biosVfOSBootWatchdogTimerPolicy/<br>vpOSBootWatchdogTimerPolicy  | OSBootWatchdogTimerTimeout  |
|                          | OS Watchdog Timer Policy                         | biosVfOSBootWatchdogTimerTimeOut/<br>vpOSBootWatchdogTimerPolicy | OSBootWatchdogTimerPolicy   |



| <b>BIOS Token Group</b> | <b>BIOS Token Name</b> | <b>XML Object</b>                                      | <b>CLI and Web GUI Object</b> |
|-------------------------|------------------------|--------------------------------------------------------|-------------------------------|
|                         | Boot Order Rules       | biosVfUCSMBootOrderRuleControl/<br>vpUCSMBootOrderRule | UCSMBootOrderRule             |

