



Viewing Server Properties

This chapter includes the following sections:

- [Viewing Server Properties, on page 1](#)
- [Viewing CMC Properties, on page 2](#)
- [Viewing Server CPU Details, on page 2](#)
- [Viewing Memory Properties, on page 3](#)
- [Viewing PCI Adapter Properties for a Server, on page 5](#)
- [Viewing HDD Details for a Server, on page 6](#)
- [Viewing Storage Adapter Properties for a Server, on page 7](#)
- [Viewing TPM Properties, on page 7](#)

Viewing Server Properties

SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis /server # **show detail**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters chassis command mode.
Step 2	Server /chassis # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 3	Server /chassis /server # show detail	Displays server properties.

Example

This example displays server properties:

```
Server# scope chassis  
Server /chassis #scope server 1  
Server /chassis /Server #show
```

```

Server ID Power Serial Number Product Name PID UUID
-----
2 on FCH183978RD UCS S3260 UCSC-C3X60-SVRNB
207BD0D4-C589-40C1-A73E-EF6E7F773198

Server /chassis /Server #show detail
Server ID 1:
  Power: off
  Serial Number: FCH1848794D
  Product Name: UCS S3260
  PID: UCSC-C3X60-SVRNB
  UUID: 60974271-A514-484C-BAE3-A5EE4FD16E06
Server /chassis /Server #

```

Viewing CMC Properties

SUMMARY STEPS

1. server # **scope chassis**
2. server /chassis # **scope cmc I|2**
3. server /chassis/cmc # **show detail**

DETAILED STEPS

	Command or Action	Purpose
Step 1	server # scope chassis	Enters chassis command mode.
Step 2	server /chassis # scope cmc I 2	Enters CMC on the chosen SIOC controller command mode.
Step 3	server /chassis/cmc # show detail	Displays the CMC details for the chosen SIOC controller.

This example shows how to view the CMC details:

Viewing Server CPU Details

SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis /server # **show cpu**
4. Server# **show cpu-pid**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters chassis command mode.
Step 2	Server /chassis # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 3	Server /chassis /server # show cpu	Displays CPU details for the server.
Step 4	Server# show cpu-pid	Displays the CPU product IDs .

Example

This example displays the CPU details for the server:

```
Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show cpu
Name          Cores    Version
-----
CPU1          6        Intel(R) Xeon(R) CPU E5-2620 v2 @ 2.10GHz
CPU2          6        Intel(R) Xeon(R) CPU E5-2620 v2 @ 2.10GHz

Server /chassis /Server #show cpu-pid
Socket Product ID      Model
-----
CPU1   UCS-CPU-E52620B      Intel(R) Xeon(R) CPU E5-2620 v2 @ 2.1...
CPU2   UCS-CPU-E52620B      Intel(R) Xeon(R) CPU E5-2620 v2 @ 2.1...

Server /chassis /Server #
```

Viewing Memory Properties

SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis /server # **show dimm**
4. Server# **show dimm-pid**
5. Server# **show dimm-summary**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters chassis command mode.
Step 2	Server /chassis # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 3	Server /chassis /server # show dimm	Displays DIMM details for the server.
Step 4	Server# show dimm-pid	Displays the DIMM product IDs.

	Command or Action	Purpose
Step 5	Server# show dimm-summary	Displays the DIMM summary information .

Example

This example displays the DIMM details for the server.:

```
Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show dimm
Name                Capacity           Channel Speed (MHz) Channel Type
-----
DIMM_A1             16384 MB           1866                DDR3
DIMM_A2             16384 MB           1866                DDR3
DIMM_B1             16384 MB           1866                DDR3
DIMM_B2             16384 MB           1866                DDR3
DIMM_C1             16384 MB           1866                DDR3
DIMM_C2             16384 MB           1866                DDR3
DIMM_D1             16384 MB           1866                DDR3
DIMM_D2             16384 MB           1866                DDR3
DIMM_E1             16384 MB           1866                DDR3
DIMM_E2             16384 MB           1866                DDR3
DIMM_F1             16384 MB           1866                DDR3
DIMM_F2             16384 MB           1866                DDR3
DIMM_G1             16384 MB           1866                DDR3
DIMM_G2             16384 MB           1866                DDR3
DIMM_H1             16384 MB           1866                DDR3
DIMM_H2             16384 MB           1866                DDR3
```

```
Server /chassis /Server #show dimm-pid
Name                Product ID          Vendor ID           Capacity           Speed
-----
DIMM_A1             UCS-MR-1X162RZ-A   0xCE00             16384 MB           1866
DIMM_A2             UCS-MR-1X162RZ-A   0xCE00             16384 MB           1866
DIMM_B1             UCS-MR-1X162RZ-A   0xCE00             16384 MB           1866
DIMM_B2             UCS-MR-1X162RZ-A   0xCE00             16384 MB           1866
DIMM_C1             UCS-MR-1X162RZ-A   0xCE00             16384 MB           1866
DIMM_C2             UCS-MR-1X162RZ-A   0xCE00             16384 MB           1866
DIMM_D1             UCS-MR-1X162RZ-A   0xCE00             16384 MB           1866
DIMM_D2             UCS-MR-1X162RZ-A   0xCE00             16384 MB           1866
DIMM_E1             UCS-MR-1X162RZ-A   0xCE00             16384 MB           1866
DIMM_E2             UCS-MR-1X162RZ-A   0xCE00             16384 MB           1866
DIMM_F1             UCS-MR-1X162RZ-A   0xCE00             16384 MB           1866
DIMM_F2             UCS-MR-1X162RZ-A   0xCE00             16384 MB           1866
DIMM_G1             UCS-MR-1X162RZ-A   0xCE00             16384 MB           1866
DIMM_G2             UCS-MR-1X162RZ-A   0xCE00             16384 MB           1866
DIMM_H1             UCS-MR-1X162RZ-A   0xCE00             16384 MB           1866
DIMM_H2             UCS-MR-1X162RZ-A   0xCE00             16384 MB           1866
```

```
Server /chassis /Server #show dimm-summary
DIMM Summary:
Memory Speed: 1600 MHz
Total Memory: 262144 MB
Effective Memory: 262144 MB
Redundant Memory: 0 MB
Failed Memory: 0 MB
Ignored Memory: 0 MB
Number of Ignored Dimms: 0
Number of Failed Dimms: 0
Memory RAS possible: Independent Mirroring Lockstep
Memory Configuration: Independent
```

```
Server /chassis /Server #
```

Viewing PCI Adapter Properties for a Server

SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis /server # **show pci-adapter**
4. Server# **show pciadapter-pid**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters chassis command mode.
Step 2	Server /chassis # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 3	Server /chassis /server # show pci-adapter	Displays PCI adapter details for the server.
Step 4	Server# show pciadapter-pid	Displays the PCI adapter product IDs.

Example

This example displays the PCI adapter details for the server.:

```
Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show pci-adapter
```

```
Slot          Vendor ID  Device ID  SubVendor ID  SubDevice ID  Firmware Version  Product Name
-----
L              0x8086    0x1521     0x1137        0x00d5        0x80000E74... Intel(R) I350 1
Gbps N...
1              0x1cc7    0x0200     0x1cc7        0x0200        N/A              Radian RMS-200
NVRAM card
MLOM          0x1137    0x0042     0x1137        0x0139        4.1 (3S1)       Cisco UCS VIC
1227T MLOM
HBA           0x1000    0x005d     0x1137        0x00db        24.12.1-0107   Cisco 12G SAS
Modular ...
```

```
Option ROM Status
```

```
-----
Loaded
Not-Loaded
Not-Loaded
Loaded
```

```
Server /chassis /Server #show pciadapter-pid
```

```

Slot      Product ID      Vendor ID  Device ID  SubVendor ID  SubDevice ID
-----
1         UNKNOWN         0x1137    0x0042    0x1137        0x0157
M        UCSC-C3X60-RAID 0x1000    0x005d    0x1137        0x012d

Server /chassis /Server #

```

Viewing HDD Details for a Server

SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis /server # **show hdd-pid**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters chassis command mode.
Step 2	Server /chassis # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 3	Server /chassis /server # show hdd-pid	Displays HDD details for the server.

Example

This example displays the HDD details for the server:

```

Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show hdd-pid
Disk Controller  Product ID      Vendor  Model
-----
1   SLOT-MEZZ     UCS-HD4T7KS3-E  TOSHIBA  MG03SCA400
2   SLOT-MEZZ     UCS-HD4T7KS3-E  TOSHIBA  MG03SCA400
3   SLOT-MEZZ     UCS-HD4T7KS3-E  TOSHIBA  MG03SCA400
4   SLOT-MEZZ     UCS-HD4T7KS3-E  TOSHIBA  MG03SCA400
5   SLOT-MEZZ     UCS-HD4T7KS3-E  TOSHIBA  MG03SCA400
6   SLOT-MEZZ     UCS-HD4T7KS3-E  TOSHIBA  MG03SCA400
7   SLOT-MEZZ     UCS-HD4T7KS3-E  TOSHIBA  MG03SCA400
8   SLOT-MEZZ     UCS-HD4T7KS3-E  TOSHIBA  MG03SCA400
9   SLOT-MEZZ     UCS-HD4T7KS3-E  TOSHIBA  MG03SCA400
10  SLOT-MEZZ     UCS-HD4T7KS3-E  TOSHIBA  MG03SCA400
11  SLOT-MEZZ     UCS-HD4T7KS3-E  TOSHIBA  MG03SCA400
12  SLOT-MEZZ     UCS-HD4T7KS3-E  TOSHIBA  MG03SCA400
13  SLOT-MEZZ     UCS-HD4T7KS3-E  TOSHIBA  MG03SCA400
14  SLOT-MEZZ     UCS-HD4T7KS3-E  TOSHIBA  MG03SCA400

Server /chassis /Server#

```

Viewing Storage Adapter Properties for a Server

SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis /server # **show storageadapter**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters chassis command mode.
Step 2	Server /chassis # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 3	Server /chassis /server # show storageadapter	Displays storage adapter details for the server.

Example

This example displays the storage adapter details for the server.:

```
Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show storageadapter
PCI Slot      Health          Controller Status ROC Temperature Product Name
-----
SLOT-MEZZ     Good             Optimal           48 degrees C   RAID controller for UCS S3260
S...

Serial Number  Firmware Package Build  Product ID  D Battery Status  Cache Memory Size
-----
FCH184972F5   24.7.3-0006             LSI Logic   Optimal           3534 MB

Boot Drive    Boot Drive is PD
-----
0             false
Server /chassis /Server #
```

Viewing TPM Properties

SUMMARY STEPS

1. Server # **scope chassis**
2. Server /chassis # **scope server {1 | 2}**
3. Server /chassis/server # **show tpm-inventory**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server # scope chassis	Enters chassis command mode.
Step 2	Server /chassis # scope server {1 2}	Enters server command mode of server 1 or 2.
Step 3	Server /chassis/server # show tpm-inventory	Displays TPM properties for the server.

Example

This example displays the TPM properties for the server:

```

Server# scope chassis
Server /chassis #scope server 1
Server /chassis /Server #show tpm-inventory
Version      Presence      Enabled-Status      Active-Status      Ownership Revision
-----
NA           empty         unknown             unknown            unknown  NA
Model        Vendor        Serial
-----
Server chassis /Server#

```