



Managing Network Adapters

This chapter includes the following sections:

- [Overview of the Cisco UCS C-Series Network Adapters, on page 1](#)
- [Viewing Network Adapter Properties, on page 3](#)
- [Configuring Network Adapter Properties, on page 4](#)
- [Managing vHBAs, on page 7](#)
- [Managing vNICs, on page 22](#)
- [Backing Up and Restoring the Adapter Configuration, on page 48](#)
- [Managing Adapter Firmware, on page 51](#)

Overview of the Cisco UCS C-Series Network Adapters



Note The procedures in this chapter are available only when a Cisco UCS C-Series network adapter is installed in the chassis.

A Cisco UCS C-Series network adapter can be installed to provide options for I/O consolidation and virtualization support. The following adapters are available:

- Cisco UCS VIC 15238 Virtual Interface Card
- Cisco UCS VIC 15428 Virtual Interface Card
- Cisco UCS VIC 1497 Virtual Interface Card
- Cisco UCS VIC 1495 Virtual Interface Card
- Cisco UCS VIC 1457 Virtual Interface Card
- Cisco UCS VIC 1455 Virtual Interface Card
- Cisco UCS VIC 1387 Virtual Interface Card
- Cisco UCS VIC 1385 Virtual Interface Card
- Cisco UCS VIC 1227T Virtual Interface Card
- Cisco UCS VIC 1225 Virtual Interface Card



Note You must have same generation VIC cards on a server. For example, you cannot have a combination of 3rd generation and 4th generation VIC cards on a single server.

The interactive *UCS Hardware and Software Interoperability Utility* lets you view the supported components and configurations for a selected server model and software release. The utility is available at the following URL: <http://www.cisco.com/web/techdoc/ucs/interoperability/matrix/matrix.html>

Cisco UCS VIC 1497 Virtual Interface Card

The Cisco VIC 1497 is a dual-port Small Form-Factor (QSFP28) mLOM card designed for the M5 generation of Cisco UCS C-Series Rack Servers. The card supports 40/100-Gbps Ethernet and FCoE. The card can present PCIe standards-compliant interfaces to the host, and these can be dynamically configured as NICs and HBAs.

Cisco UCS VIC 1495 Virtual Interface Card

The Cisco UCS VIC 1495 is a dual-port Small Form-Factor (QSFP28) PCIe card designed for the M5 generation of Cisco UCS C-Series Rack Servers. The card supports 40/100-Gbps Ethernet and FCoE. The card can present PCIe standards-compliant interfaces to the host, and these can be dynamically configured as NICs and HBAs.

Cisco UCS VIC 1457 Virtual Interface Card

The Cisco UCS VIC 1457 is a quad-port Small Form-Factor Pluggable (SFP28) mLOM card designed for M5 generation of Cisco UCS C-Series rack servers. The card supports 10/25-Gbps Ethernet or FCoE. It incorporates Cisco's next-generation CNA technology and offers a comprehensive feature set, providing investment protection for future feature software releases. The card can present PCIe standards-compliant interfaces to the host, and these can be dynamically configured as NICs and HBAs.

Cisco UCS VIC 1455 Virtual Interface Card

The Cisco UCS VIC 1455 is a quad-port Small Form-Factor Pluggable (SFP28) half-height PCIe card designed for M5 generation of Cisco UCS C-Series rack servers. The card supports 10/25-Gbps Ethernet or FCoE. It incorporates Cisco's next-generation CNA technology and offers a comprehensive feature set, providing investment protection for future feature software releases. The card can present PCIe standards-compliant interfaces to the host, and these can be dynamically configured as NICs and HBAs.

Cisco UCS VIC 1387 Virtual Interface Card

The Cisco UCS VIC 1387 Virtual Interface Card is a dual-port Enhanced Quad Small Form-Factor Pluggable (QSFP) 40 Gigabit Ethernet and Fibre Channel over Ethernet (FCoE)-capable half-height PCI Express (PCIe) card designed exclusively for Cisco UCS C-Series Rack Servers. It incorporates Cisco's next-generation converged network adapter (CNA) technology, with a comprehensive feature set, providing investment protection for future feature software releases.

Cisco UCS VIC 1385 Virtual Interface Card

The Cisco UCS VIC 1385 Virtual Interface Card is a dual-port Enhanced Quad Small Form-Factor Pluggable (QSFP) 40 Gigabit Ethernet and Fibre Channel over Ethernet (FCoE)-capable half-height PCI Express (PCIe) card designed exclusively for Cisco UCS C-Series Rack Servers. It incorporates Cisco's next-generation converged network adapter (CNA) technology, with a comprehensive feature set, providing investment protection for future feature software releases.

Cisco UCS VIC 1227T Virtual Interface Card

The Cisco UCS VIC 1227T Virtual Interface Card is a dual-port 10GBASE-T (RJ-45) 10-Gbps Ethernet and Fibre Channel over Ethernet (FCoE)-capable PCI Express (PCIe) modular LAN-on-motherboard (mLOM) adapter designed exclusively for Cisco UCS C-Series Rack Servers. New to Cisco rack servers, the mLOM slot can be used to install a Cisco VIC without consuming a PCIe slot, which provides greater I/O expandability. It incorporates next-generation converged network adapter (CNA) technology from Cisco, providing Fibre Channel connectivity over low-cost twisted pair cabling with a bit error rate (BER) of 10 to 15 up to 30 meters and investment protection for future feature releases.

Cisco UCS VIC 1225 Virtual Interface Card

The Cisco UCS VIC 1225 Virtual Interface Card is a high-performance, converged network adapter that provides acceleration for the various new operational modes introduced by server virtualization. It brings superior flexibility, performance, and bandwidth to the new generation of Cisco UCS C-Series Rack-Mount Servers.

Viewing Network Adapter Properties

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # show adapter [<i>index</i>] [<i>detail</i>]	Displays adapter properties. To display the properties of a single adapter, specify the PCI slot number as the <i>index</i> argument.

Example

- This example displays the properties of adapter:

```
Server# scope chassis
Server /chassis # show adapter
PCI Slot Product Name      Serial Number  Product ID    Vendor
-----
11      UCS VIC 1455      FCH233770S8  UCSC-PCIE-C... Cisco Systems Inc
Server /chassis # show adapter detail
PCI Slot 11:
  Product Name: UCS VIC 1455
  Serial Number: FCH233770S8
  Product ID: UCSC-PCIE-C25Q-04
  Adapter Hardware Revision: 5
  Current FW Version: 5.1(1.64)
  VNTAG: Disabled
  FIP: Enabled
  LLDP: Enabled
  PORT CHANNEL: Enabled
  Configuration Pending: no
  Cisco IMC Management Enabled: no
  VID: V04
  Vendor: Cisco Systems Inc
  Description:
```

```

Bootloader Version: 5.0(3c)
FW Image 1 Version: 5.1(1.64)
FW Image 1 State: RUNNING ACTIVATED
FW Image 2 Version: 5.1(1.59)
FW Image 2 State: BACKUP INACTIVATED
FW Update Status: Fwupdate never issued
FW Update Error: No error
FW Update Stage: No operation (0%)
FW Update Overall Progress: 0%
Server /chassis #

```

Configuring Network Adapter Properties

Before you begin

- You must log in with admin privileges to perform this task.
- A supported Virtual Interface Card (VIC) must be installed in the chassis and the server must be powered on.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # show adapter	(Optional) Displays the available adapter devices.
Step 3	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 4	Server /chassis/adapter # set fip-mode { disable enable }	Enables or disables FCoE Initialization Protocol (FIP) on the adapter card. FIP is enabled by default. Note <ul style="list-style-type: none"> • We recommend that you disable this option only when explicitly directed to do so by a technical support representative.
Step 5	Server /chassis/adapter # set lldp { disable enable }	Note For LLDP change to be effective, it is required that you reboot the server. In case of S3260 chassis with two nodes, ensure to reboot the secondary node after making LLDP changes in the primary node. Enables or disables Link Layer Discovery Protocol (LLDP) on the adapter card. LLDP is enabled by default.

	Command or Action	Purpose
		<p>Note We recommend that you do not disable LLDP option, as it disables all the Data Center Bridging Capability Exchange protocol (DCBX) functionality.</p>
<p>Step 6</p>	<p>Server /chassis/adapter # set vntag-mode {disabled enabled}</p>	<p>Enables or disables VNTAG on the adapter card. VNTAG is disabled by default.</p> <p>Note If VNTAG mode is enabled:</p> <ul style="list-style-type: none"> • vNICs and vHBAs can be assigned to a specific channel. • vNICs and vHBAs can be associated to a port profile. • vNICs can fail over to another vNIC if there are communication problems.
<p>Step 7</p>	<p>Server /chassis/adapter # set portchannel disabled</p>	<p>Allows you to enable or disable the port channel. When you disable port channel, four vNICs and vHBAs are available for use on the adapter.</p> <p>When Port channel is enabled:</p> <ul style="list-style-type: none"> • Only two vNICs and vHBAs are available for use. • Port 0 and 1 are bundled as one port channel and Port 2 and 3 are bundled as the other port channel. <p>Note</p> <ul style="list-style-type: none"> • This option is enabled by default on Cisco UCS VIC 1455 and 1457. • When you change the port channel configuration, all the previously created vNICs and vHBAs will be deleted and the configuration will be restored to factory defaults. • VNTAG mode is supported only in the port-channel mode.
<p>Step 8</p>	<p>Server /chassis/adapter # set physical-nic-mode enabled</p>	<p>Allows you to enable or disable the physical NIC mode. This option is disabled by default.</p> <p>When Physical NIC Mode is enabled, up-link ports of the VIC are set to pass-through mode. This allows the host to transmit packets without any modification. VIC ASIC does not rewrite the VLAN tag of the packets based on the VLAN and CoS settings for the vNIC.</p>

	Command or Action	Purpose
		<p>Note</p> <p>This option is available only for Cisco UCS VIC 14xx series and 15xxx series adapters.</p> <p>For the VIC configuration changes to be effective, you must reboot the host.</p> <p>This option cannot be enabled on an adapter that has:</p> <ul style="list-style-type: none"> • Port Channel mode enabled • VNTAG mode enabled • LLDP enabled • FIP mode enabled • Cisco IMC Management Enabled value set to Yes • multiple user created vNICs
Step 9	Server /chassis/adapter* # commit	Commits the transaction to the system configuration.

Example

This example configures the properties of adapter 1:

```

Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # set fip-mode enable
Server /chassis/adapter *# set vntag-mode enabled
Server /chassis/adapter* # set portchannel disabled
Server /chassis/adapter *# commit
Warning: Enabling VNTAG mode
All the vnic configuration will be reset to factory defaults
New vNIC adapter settings will take effect upon the next server reset
Server /chassis/adapter # show detail
PCI Slot 1:
  Product Name: UCS VIC xxxx
  Serial Number: FCHXXXXXZV4
  Product ID: UCSC-PCIE-xxx-04
  Adapter Hardware Revision: 3
  Current FW Version: x.0(0.345)
  VNTAG: Enabled
  FIP: Enabled
  LLDP: Enabled
  PORT CHANNEL: Disabled
  Configuration Pending: no
  Cisco IMC Management Enabled: no
  VID: V00
  Vendor: Cisco Systems Inc
  Description:
  Bootloader Version: xxx
  FW Image 1 Version: x.0(0.345)
  FW Image 1 State: RUNNING ACTIVATED
  FW Image 2 Version: gafskl-dev-170717-1500-orosz-ET

```

```

FW Image 2 State: BACKUP INACTIVATED
FW Update Status: Fwupdate never issued
FW Update Error: No error
FW Update Stage: No operation (0%)
FW Update Overall Progress: 0%
Server /chassis/adapter #

```

Managing vHBAs

Guidelines for Managing vHBAs

When managing vHBAs, consider the following guidelines and restrictions:

- The SIOCs with the Cisco UCS Virtual Interface Cards provide two vHBAs and two vNICs by default. You can create up to 14 additional vHBAs or vNICs on these adapter cards.

The Cisco UCS 1455 and 1457 Virtual Interface Cards, in non-port channel mode, provide four vHBAs and four vNICs by default. You can create up to 10 additional vHBAs or vNICs on these adapter cards in VNTAG mode.



Note If VNTAG mode is enabled for the adapter, you must assign a channel number to a vHBA when you create it.

- When using the Cisco UCS Virtual Interface Cards in an FCoE application, you must associate the vHBA with the FCoE VLAN. Follow the instructions in the **Modifying vHBA Properties** section to assign the VLAN.
- After making configuration changes, you must reboot the host for settings to take effect.

Viewing vHBA Properties

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter index**
3. Server /chassis/adapter # **show host-fc-if [fc0 | fc1 | name] [detail]**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope adapter index	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.

	Command or Action	Purpose
Step 3	Server /chassis/adapter # show host-fc-if [fc0 fc1 <i>name</i>] [detail]	Displays properties of a single vHBA, if specified, or all vHBAs.

Example

This example displays all vHBAs on adapter card 1 and the detailed properties of fc0:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # show host-fc-if
Name          World Wide Port Name      FC SAN Boot Uplink Port
-----
fc0           20:00:00:22:BD:D6:5C:35   Disabled    0
fc1           20:00:00:22:BD:D6:5C:36   Disabled    1

Server /chassis/adapter # show host-fc-if fc0 detail
Name fc0:
  World Wide Node Name: 10:00:70:0F:6A:C0:97:43
  World Wide Port Name: 20:00:70:0F:6A:C0:97:43
  FC SAN Boot: disabled
  FC Type: fc-initiator
  Persistent LUN Binding: disabled
  Uplink Port: 0
  PCI Link: 0
  MAC Address: 70:0F:6A:C0:97:43
  CoS: 3
  VLAN: NONE
  Rate Limiting: OFF
  PCIe Device Order: 2
  EDTOV: 2000
  RATOV: 10000
  Maximum Data Field Size: 2112
  Channel Number: N/A
  Port Profile: N/A

Server /chassis/adapter #
```

Modifying vHBA Properties

Before you begin

You must log in with admin privileges to perform this task.

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **show adapter**
3. Server /chassis # **scope adapter** *index*
4. Server /chassis/adapter # **scope host-fc-if** {**fc0** | **fc1** | *name*}
5. Server /chassis/adapter/host-fc-if # **set wwnn** *wwnn*
6. Server /chassis/adapter/host-fc-if # **set wwpn** *wwpn*
7. Server /chassis/adapter/host-fc-if # **set boot** {**disable** | **enable**}

8. Server /chassis/adapter/host-fc-if # **set persistent-lun-binding** {**disable** | **enable**}
9. Server /chassis/adapter/host-fc-if # **set mac-addr** *mac-addr*
10. Server /chassis/adapter/host-fc-if # **set vlan** {**none** | *vlan-id*}
11. Server /chassis/adapter/host-fc-if # **set cos** *cos-value*
12. Server /chassis/adapter/host-fc-if # **set rate-limit** {**off** | *rate*}
13. Server /chassis/adapter/host-fc-if # **set order** {**any** | *0-99*}
14. Server /chassis/adapter/host-fc-if # **set error-detect-timeout** *msec*
15. Server /chassis/adapter/host-fc-if # **set resource-allocation-timeout** *msec*
16. Server /chassis/adapter/host-fc-if # **set max-data-field-size** *size*
17. Server /chassis/adapter/host-fc-if # **set channel-number** *channel number*
18. Server /chassis/adapter/host-fc-if # **set pci-link** *0/1*
19. Server /chassis/adapter/host-fc-if # **set uplink** *Port number*
20. Server /chassis/adapter/host-fc-if # **set vhma-type** *fc-initiator|fc-target|fc-nvme-initiator|fc-nvme-target*
21. Server /chassis/adapter/host-fc-if # **scope error-recovery**
22. Server /chassis/adapter/host-fc-if/error-recovery # **set fcp-error-recovery** {**disable** | **enable**}
23. Server /chassis/adapter/host-fc-if/error-recovery # **set link-down-timeout** *msec*
24. Server /chassis/adapter/host-fc-if/error-recovery # **set port-down-io-retry-count** *count*
25. Server /chassis/adapter/host-fc-if/error-recovery # **set port-down-timeout** *msec*
26. Server /chassis/adapter/host-fc-if/error-recovery # **exit**
27. Server /chassis/adapter/host-fc-if # **scope interrupt**
28. Server /chassis/adapter/host-fc-if/interrupt # **set interrupt-mode** {**intx** | **msi** | **msix**}
29. Server /chassis/adapter/host-fc-if/interrupt # **exit**
30. Server /chassis/adapter/host-fc-if # **scope port**
31. Server /chassis/adapter/host-fc-if/port # **set outstanding-io-count** *count*
32. Server /chassis/adapter/host-fc-if/port # **set max-target-luns** *count*
33. Server /chassis/adapter/host-fc-if/port # **exit**
34. Server /chassis/adapter/host-fc-if # **scope port-f-logi**
35. Server /chassis/adapter/host-fc-if/port-f-logi # **set flogi-retries** {**infinite** | *count*}
36. Server /chassis/adapter/host-fc-if/port-f-logi # **set flogi-timeout** *msec*
37. Server /chassis/adapter/host-fc-if/port-f-logi # **exit**
38. Server /chassis/adapter/host-fc-if # **scope port-p-logi**
39. Server /chassis/adapter/host-fc-if/port-p-logi # **set plogi-retries** *count*
40. Server /chassis/adapter/host-fc-if/port-p-logi # **set plogi-timeout** *msec*
41. Server /chassis/adapter/host-fc-if/port-p-logi # **exit**
42. Server /chassis/adapter/host-fc-if # **scope scsi-io**
43. Server /chassis/adapter/host-fc-if/scsi-io # **set cdb-wq-count** *count*
44. Server /chassis/adapter/host-fc-if/scsi-io # **set cdb-wq-ring-size** *size*
45. Server /chassis/adapter/host-fc-if/scsi-io # **exit**
46. Server /chassis/adapter/host-fc-if # **scope trans-queue**
47. Server /chassis/adapter/host-fc-if/trans-queue # **set fc-wq-ring-size** *size*
48. Server /chassis/adapter/host-fc-if/trans-queue # **exit**
49. Server /chassis/adapter/host-fc-if # **scope recv-queue**
50. Server /chassis/adapter/host-fc-if/recv-queue # **set fc-rq-ring-size** *size*
- 51.
52. Server /chassis/adapter/host-fc-if/recv-queue # **exit**

53. Server /chassis/adapter/host-fc-if # **commit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # show adapter	(Optional) Displays the available adapter devices.
Step 3	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 4	Server /chassis/adapter # scope host-fc-if { fc0 fc1 <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
Step 5	Server /chassis/adapter/host-fc-if # set wwnn <i>wwnn</i>	Specifies a unique World Wide Node Name (WWNN) for the adapter in the form hh:hh:hh:hh:hh:hh:hh:hh. Unless specified by this command, the WWNN is generated automatically by the system.
Step 6	Server /chassis/adapter/host-fc-if # set wwpn <i>wwpn</i>	Specifies a unique World Wide Port Name (WWPN) for the adapter in the form hh:hh:hh:hh:hh:hh:hh:hh. Unless specified by this command, the WWPN is generated automatically by the system.
Step 7	Server /chassis/adapter/host-fc-if # set boot { disable enable }	Enables or disables FC SAN boot. The default is disable.
Step 8	Server /chassis/adapter/host-fc-if # set persistent-lun-binding { disable enable }	Enables or disables persistent LUN binding. The default is disable.
Step 9	Server /chassis/adapter/host-fc-if # set mac-addr <i>mac-addr</i>	Specifies a MAC address for the vHBA.
Step 10	Server /chassis/adapter/host-fc-if # set vlan { none <i>vlan-id</i> }	Specifies the default VLAN for this vHBA. Valid VLAN numbers are 1 to 4094; the default is none.
Step 11	Server /chassis/adapter/host-fc-if # set cos <i>cos-value</i>	Specifies the class of service (CoS) value to be marked on received packets unless the vHBA is configured to trust host CoS. Valid CoS values are 0 to 6; the default is 0. Higher values indicate more important traffic. This setting is not functional in NIV mode.
Step 12	Server /chassis/adapter/host-fc-if # set rate-limit { off <i>rate</i> }	Specifies a maximum data rate for the vHBA. The range is 1 to 100000 Mbps; the default is off. This setting is not functional in NIV mode.
Step 13	Server /chassis/adapter/host-fc-if # set order { any <i>0-99</i> }	Specifies the relative order of this device for PCIe bus device number assignment; the default is any.

	Command or Action	Purpose
Step 14	Server /chassis/adapter/host-fc-if # set error-detect-timeout msec	Specifies the error detect timeout value (EDTOV), the number of milliseconds to wait before the system assumes that an error has occurred. The range is 1000 to 100000; the default is 2000 milliseconds.
Step 15	Server /chassis/adapter/host-fc-if # set resource-allocation-timeout msec	Specifies the resource allocation timeout value (RATOV), the number of milliseconds to wait before the system assumes that a resource cannot be properly allocated. The range is 5000 to 100000; the default is 10000 milliseconds.
Step 16	Server /chassis/adapter/host-fc-if # set max-data-field-size size	Specifies the maximum size of the Fibre Channel frame payload (in bytes) that the vHBA supports. The range is 1 to 2112; the default is 2112 bytes.
Step 17	Server /chassis/adapter/host-fc-if # set channel-number channel number	The channel number that will be assigned to this vHBA. Enter an integer between 1 and 1,000. Note VNTAG mode is required for this option.
Step 18	Server /chassis/adapter/host-fc-if # set pci-link 0/1	The link through which vNICs can be connected. These are the following values: <ul style="list-style-type: none"> • 0 — The first cross-edged link where the vNIC is placed. • 1 — The second cross-edged link where the vNIC is placed. Note This option is available only on some Cisco UCS C-Series servers.
Step 19	Server /chassis/adapter/host-fc-if # set uplink Port number	The uplink port associated with the vHBA. Note This value cannot be changed for the system-defined vHBAs fc0 and fc1.
Step 20	Server /chassis/adapter/host-fc-if # set vhma-type fc-initiator/fc-target/fc-nvme-initiator/fc-nvme-target	The vHBA type used in this policy. vHBAs supporting FC and FC-NVMe can now be created on the same adapter. The vHBA type used in this policy can be one of the following: <ul style="list-style-type: none"> • fc-initiator—Legacy SCSI FC vHBA initiator • fc-target—vHBA that supports SCSI FC target functionality Note This option is available as a Tech Preview. <ul style="list-style-type: none"> • fc-nvme-initiator—vHBA that is an FC NVME initiator, which discovers FC NVME targets and connects to them.

	Command or Action	Purpose
		<ul style="list-style-type: none"> • fc-nvme-target—vHBA that acts as an FC NVME target and provides connectivity to the NVME storage.
Step 21	Server /chassis/adapter/host-fc-if # scope error-recovery	Enters the Fibre Channel error recovery command mode.
Step 22	Server /chassis/adapter/host-fc-if/error-recovery # set fcp-error-recovery { disable enable }	Enables or disables FCP Error Recovery. The default is disable.
Step 23	Server /chassis/adapter/host-fc-if/error-recovery # set link-down-timeout <i>msec</i>	Specifies the link down timeout value, the number of milliseconds the uplink port should be offline before it informs the system that the uplink port is down and fabric connectivity has been lost. The range is 0 to 240000; the default is 30000 milliseconds.
Step 24	Server /chassis/adapter/host-fc-if/error-recovery # set port-down-io-retry-count <i>count</i>	Specifies the port down I/O retries value, the number of times an I/O request to a port is returned because the port is busy before the system decides the port is unavailable. The range is 0 to 255; the default is 8 retries.
Step 25	Server /chassis/adapter/host-fc-if/error-recovery # set port-down-timeout <i>msec</i>	Specifies the port down timeout value, the number of milliseconds a remote Fibre Channel port should be offline before informing the SCSI upper layer that the port is unavailable. The range is 0 to 240000; the default is 10000 milliseconds.
Step 26	Server /chassis/adapter/host-fc-if/error-recovery # exit	Exits to the host Fibre Channel interface command mode.
Step 27	Server /chassis/adapter/host-fc-if # scope interrupt	Enters the interrupt command mode.
Step 28	Server /chassis/adapter/host-fc-if/interrupt # set interrupt-mode { intx msi msix }	Specifies the Fibre Channel interrupt mode. The modes are as follows: <ul style="list-style-type: none"> • intx —Line-based interrupt (INTx) • msi —Message-Signaled Interrupt (MSI) • msix —Message Signaled Interrupts with the optional extension (MSIX). This is the recommended and default option.
Step 29	Server /chassis/adapter/host-fc-if/interrupt # exit	Exits to the host Fibre Channel interface command mode.
Step 30	Server /chassis/adapter/host-fc-if # scope port	Enters the Fibre Channel port command mode.
Step 31	Server /chassis/adapter/host-fc-if/port # set outstanding-io-count <i>count</i>	Specifies the I/O throttle count, the number of I/O operations that can be pending in the vHBA at one time. The range is 1 to 1024; the default is 512 operations.
Step 32	Server /chassis/adapter/host-fc-if/port # set max-target-luns <i>count</i>	Specifies the maximum logical unit numbers (LUNs) per target, the maximum number of LUNs that the driver will

	Command or Action	Purpose
		discover. This is usually an operating system platform limitation. The range is 1 to 1024; the default is 256 LUNs.
Step 33	Server /chassis/adapter/host-fc-if/port # exit	Exits to the host Fibre Channel interface command mode.
Step 34	Server /chassis/adapter/host-fc-if # scope port-f-logic	Enters the Fibre Channel fabric login command mode.
Step 35	Server /chassis/adapter/host-fc-if/port-f-logic # set flogi-retries { infinite <i>count</i> }	Specifies the fabric login (FLOGI) retries value, the number of times that the system tries to log in to the fabric after the first failure. Enter a number between 0 and 4294967295 or enter infinite ; the default is infinite retries.
Step 36	Server /chassis/adapter/host-fc-if/port-f-logic # set flogi-timeout <i>msec</i>	Specifies the fabric login (FLOGI) timeout value, the number of milliseconds that the system waits before it tries to log in again. The range is 1 to 255000; the default is 2000 milliseconds.
Step 37	Server /chassis/adapter/host-fc-if/port-f-logic # exit	Exits to the host Fibre Channel interface command mode.
Step 38	Server /chassis/adapter/host-fc-if # scope port-p-logic	Enters the Fibre Channel port login command mode.
Step 39	Server /chassis/adapter/host-fc-if/port-p-logic # set plogi-retries <i>count</i>	Specifies the port login (PLOGI) retries value, the number of times that the system tries to log in to the fabric after the first failure. The range is 0 and 255; the default is 8 retries.
Step 40	Server /chassis/adapter/host-fc-if/port-p-logic # set plogi-timeout <i>msec</i>	Specifies the port login (PLOGI) timeout value, the number of milliseconds that the system waits before it tries to log in again. The range is 1 to 255000; the default is 2000 milliseconds.
Step 41	Server /chassis/adapter/host-fc-if/port-p-logic # exit	Exits to the host Fibre Channel interface command mode.
Step 42	Server /chassis/adapter/host-fc-if # scope scsi-io	Enters the SCSI I/O command mode.
Step 43	Server /chassis/adapter/host-fc-if/scsi-io # set cdb-wq-count <i>count</i>	The number of command descriptor block (CDB) transmit queue resources to allocate. For Cisco UCS VIC 14xx series adapters, enter an integer between 1 and 64. For any other VIC adapter, enter an integer between 1 and 245.
Step 44	Server /chassis/adapter/host-fc-if/scsi-io # set cdb-wq-ring-size <i>size</i>	The number of descriptors in the command descriptor block (CDB) transmit queue. The range is 64 to 512; the default is 512.
Step 45	Server /chassis/adapter/host-fc-if/scsi-io # exit	Exits to the host Fibre Channel interface command mode.
Step 46	Server /chassis/adapter/host-fc-if # scope trans-queue	Enters the Fibre Channel transmit queue command mode.
Step 47	Server /chassis/adapter/host-fc-if/trans-queue # set fc-wq-ring-size <i>size</i>	The number of descriptors in the Fibre Channel transmit queue. The range is 64 to 128; the default is 64.
Step 48	Server /chassis/adapter/host-fc-if/trans-queue # exit	Exits to the host Fibre Channel interface command mode.

	Command or Action	Purpose
Step 49	Server /chassis/adapter/host-fc-if # scope rcv-queue	Enters the Fibre Channel receive queue command mode.
Step 50	Server /chassis/adapter/host-fc-if/rcv-queue # set fc-rq-ring-size size	The number of descriptors in the Fibre Channel receive queue. The range is 64 to 128; the default is 64.
Step 51		
Step 52	Server /chassis/adapter/host-fc-if/rcv-queue # exit	Exits to the host Fibre Channel interface command mode.
Step 53	Server /chassis/adapter/host-fc-if # commit	Commits the transaction to the system configuration. Note The changes will take effect upon the next server reboot.

Example

This example configures the properties of a vHBA (only few options are shown):

```
Server# scope chassis
Server /chassis # show adapter
PCI Slot Product Name Serial Number Product ID Vendor
-----
1 UCS VIC P81E QCI1417A0QK N2XX-ACPCI01 Cisco Systems Inc

Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-fc-if fcl
Server /chassis/adapter/host-fc-if # set boot enable
Server /chassis/adapter/host-fc-if *# scope scsi-io
Server /chassis/adapter/host-fc-if/scsi-io *# set cdb-wq-count 2
Server /chassis/adapter/host-fc-if/scsi-io *# exit
Server /chassis/adapter/host-fc-if *# commit
Server /chassis/adapter/host-fc-if #
```

What to do next

Reboot the server to apply the changes.

Creating a vHBA

The adapter provides two permanent vHBAs. If NIV mode is enabled, you can create up to 16 additional vHBAs.



Note Additional vHBAs can be created only in **VNTAG** mode.

Before you begin

You must log in with admin privileges to perform this task.

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **create host-fc-if** *name*
4. Server /chassis/adapter/host-fc-if # **set channel-number** *number*
5. Server /chassis/adapter/host-fc-if # **commit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 3	Server /chassis/adapter # create host-fc-if <i>name</i>	Creates a vHBA and enters the host Fibre Channel interface command mode. The <i>name</i> argument can be up to 32 ASCII characters.
Step 4	Server /chassis/adapter/host-fc-if # set channel-number <i>number</i>	Assign a channel number to this vHBA. The range is 1 to 1000.
Step 5	Server /chassis/adapter/host-fc-if # commit	Commits the transaction to the system configuration. Note The changes will take effect upon the next server reboot.

Example

This example creates a vHBA on adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # create host-fc-if Vhba5
Server /chassis/adapter/host-fc-if *# commit
New host-fc-if settings will take effect upon the next server reset
Server /chassis/adapter/host-fc-if #
```

What to do next

- Reboot the server to create the vHBA.
- If configuration changes are required, configure the new vHBA as described in [Modifying vHBA Properties, on page 8](#).

Deleting a vHBA

Before you begin

You cannot delete the default vHBAs.

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **delete host-fc-if** *name*
4. Server /chassis/adapter # **commit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 3	Server /chassis/adapter # delete host-fc-if <i>name</i>	Deletes the specified vHBA. Note You cannot delete either of the two default vHBAs, fc0 or fc1.
Step 4	Server /chassis/adapter # commit	Commits the transaction to the system configuration. Note The changes will take effect upon the next server reboot.

Example

This example deletes a vHBA on adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # delete host-fc-if Vhba5
Server /chassis/adapter *# commit
Server /chassis/adapter #
```

vHBA Boot Table

In the vHBA boot table, you can specify up to four LUNs from which the server can boot.

Viewing the Boot Table

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **scope host-fc-if** {**fc0** | **fc1** | *name*}
4. Server /chassis/adapter/host-fc-if # **show boot**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 3	Server /chassis/adapter # scope host-fc-if { fc0 fc1 <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
Step 4	Server /chassis/adapter/host-fc-if # show boot	Displays the boot table of the Fibre Channel interface.

Example

This example displays the boot table for a vHBA:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # show boot
Boot Table Entry  Boot Target WWPN          Boot LUN ID
-----
0                 20:00:00:11:22:33:44:55  3
1                 20:00:00:11:22:33:44:56  5

Server /chassis/adapter/host-fc-if #
```

Creating a Boot Table Entry

You can create up to four boot table entries.

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **scope host-fc-if** {**fc0** | **fc1** | *name*}
4. Server /chassis/adapter/host-fc-if # **create-boot-entry** *wwpn lun-id*

5. Server /chassis/adapter/host-fc-if # **commit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 3	Server /chassis/adapter # scope host-fc-if { fc0 fc1 <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
Step 4	Server /chassis/adapter/host-fc-if # create-boot-entry <i>wwpn lun-id</i>	Creates a boot table entry. <ul style="list-style-type: none"> • <i>wwpn</i> — The World Wide Port Name (WWPN) for the boot target in the form hh:hh:hh:hh:hh:hh:hh:hh. • <i>lun-id</i> — The LUN ID of the boot LUN. The range is 0 to 255.
Step 5	Server /chassis/adapter/host-fc-if # commit	Commits the transaction to the system configuration. Note The changes will take effect upon the next server reboot.

Example

This example creates a boot table entry for vHBA fc1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # create-boot-entry 20:00:00:11:22:33:44:55 3
Server /chassis/adapter/host-fc-if *# commit
New boot table entry will take effect upon the next server reset
Server /chassis/adapter/host-fc-if #
```

Deleting a Boot Table Entry

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **scope host-fc-if** {**fc0** | **fc1** | *name*}
4. Server /chassis/adapter/host-fc-if # **show boot**
5. Server /chassis/adapter/host-fc-if # **delete boot entry**

6. Server /chassis/adapter/host-fc-if # **commit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 3	Server /chassis/adapter # scope host-fc-if { fc0 fc1 <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
Step 4	Server /chassis/adapter/host-fc-if # show boot	Displays the boot table. From the Boot Table Entry field, locate the number of the entry to be deleted.
Step 5	Server /chassis/adapter/host-fc-if # delete boot <i>entry</i>	Deletes the boot table entry at the specified position in the table. The range of <i>entry</i> is 0 to 3. The change will take effect upon the next server reset.
Step 6	Server /chassis/adapter/host-fc-if # commit	Commits the transaction to the system configuration. Note The changes will take effect upon the next server reboot.

Example

This example deletes boot table entry number 1 for the vHBA fc1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # show boot
Boot Table Entry  Boot Target WWPN                Boot LUN ID
-----
0                  20:00:00:11:22:33:44:55      3
1                  20:00:00:11:22:33:44:56      5

Server /chassis/adapter/host-fc-if # delete boot 1
Server /chassis/adapter/host-fc-if # commit
New host-fc-if settings will take effect upon the next server reset
Server /chassis/adapter/host-fc-if # show boot
Boot Table Entry  Boot Target WWPN                Boot LUN ID
-----
0                  20:00:00:11:22:33:44:55      3

Server /chassis/adapter/host-fc-if #
```

What to do next

Reboot the server to apply the changes.

vHBA Persistent Binding

Persistent binding ensures that the system-assigned mapping of Fibre Channel targets is maintained after a reboot.

Enabling Persistent Binding

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **scope host-fc-if** {**fc0** | **fc1** | *name*}
4. Server /chassis/adapter/host-fc-if # **scope perbi**
5. Server /chassis/adapter/host-fc-if/perbi # **set persistent-lun-binding enable**
6. Server /chassis/adapter/host-fc-if/perbi # **commit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 3	Server /chassis/adapter # scope host-fc-if { fc0 fc1 <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
Step 4	Server /chassis/adapter/host-fc-if # scope perbi	Enters the persistent binding command mode for the vHBA.
Step 5	Server /chassis/adapter/host-fc-if/perbi # set persistent-lun-binding enable	Enables persistent binding for the vHBA.
Step 6	Server /chassis/adapter/host-fc-if/perbi # commit	Commits the transaction to the system configuration.

Example

This example enables persistent binding for a vHBA:

```
Server# scope chassis
Server /chassis # scope adapter 4
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # scope perbi
Server /chassis/adapter/host-fc-if/perbi # set persistent-lun-binding enable
Server /chassis/adapter/host-fc-if/perbi *# commit
Server /chassis/adapter/host-fc-if/perbi #
```

Disabling Persistent Binding

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **scope host-fc-if** {**fc0** | **fc1** | *name*}
4. Server /chassis/adapter/host-fc-if # **scope perbi**
5. Server /chassis/adapter/host-fc-if/perbi # **set persistent-lun-binding disable**
6. Server /chassis/adapter/host-fc-if/perbi # **commit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 3	Server /chassis/adapter # scope host-fc-if { fc0 fc1 <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
Step 4	Server /chassis/adapter/host-fc-if # scope perbi	Enters the persistent binding command mode for the vHBA.
Step 5	Server /chassis/adapter/host-fc-if/perbi # set persistent-lun-binding disable	Disables persistent binding for the vHBA.
Step 6	Server /chassis/adapter/host-fc-if/perbi # commit	Commits the transaction to the system configuration.

Example

This example disables persistent binding for a vHBA:

```
Server# scope chassis
Server /chassis # scope adapter 4
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # scope perbi
Server /chassis/adapter/host-fc-if/perbi # set persistent-lun-binding disable
Server /chassis/adapter/host-fc-if/perbi *# commit
Server /chassis/adapter/host-fc-if/perbi #
```

Rebuilding Persistent Binding

Before you begin

Persistent binding must be enabled in the vHBA properties.

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **scope host-fc-if** {**fc0** | **fc1** | *name*}
4. Server /chassis/adapter/host-fc-if # **scope perbi**
5. Server /chassis/adapter/host-fc-if/perbi # **rebuild**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 3	Server /chassis/adapter # scope host-fc-if { fc0 fc1 <i>name</i> }	Enters the host Fibre Channel interface command mode for the specified vHBA.
Step 4	Server /chassis/adapter/host-fc-if # scope perbi	Enters the persistent binding command mode for the vHBA.
Step 5	Server /chassis/adapter/host-fc-if/perbi # rebuild	Rebuilds the persistent binding table for the vHBA.

Example

This example rebuilds the persistent binding table for a vHBA:

```
Server# scope chassis
Server /chassis # scope adapter 4
Server /chassis/adapter # scope host-fc-if fc1
Server /chassis/adapter/host-fc-if # scope perbi
Server /chassis/adapter/host-fc-if/perbi # rebuild

Server /chassis/adapter/host-fc-if/perbi #
```

Managing vNICs

Guidelines for Managing vNICs

When managing vNICs, consider the following guidelines and restrictions:

- The Cisco UCS Virtual Interface Cards provide two vHBAs and two vNICs by default. You can create up to 14 additional vHBAs or vNICs on these adapter cards.

Additional vHBAs can be created using VNTAG mode.

The Cisco UCS 1455 and 1457 Virtual Interface Cards, in non-port channel mode, provide four vHBAs and four vNICs by default. You can create up to 10 additional vHBAs or vNICs on these adapter cards.



Note If VNTAG mode is enabled for the adapter, you must assign a channel number to a vNIC when you create it.

- After making configuration changes, you must reboot the host for settings to take effect.

Viewing vNIC Properties

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 3	Server /chassis/adapter # show host-eth-if [eth0 eth1 <i>name</i>] [detail]	Displays properties of a single vNIC, if specified, or all vNICs.
Step 4	Server /chassis/adapter # show ext-eth-if [detail]	Displays the external ethernet interfaces' details.

Example

Following examples display the brief properties of all vNICs and the detailed properties of eth0 and the external interfaces:



Note These examples may show features available only with certain releases.

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # show host-eth-if
Name   MTU   Uplink Port   MAC Address           CoS VLAN PXE Boot iSCSI Boot usNIC
-----
eth0   1500  0              74:A2:E6:28:C6:AE    N/A N/A  disabled disabled  0
eth1   1500  1              74:A2:E6:28:C6:AF    N/A N/A  disabled disabled  0
srg    1500  0              74:A2:E6:28:C6:B2    N/A N/A  disabled disabled  64
hhh    1500  0              74:A2:E6:28:C6:B3    N/A N/A  disabled disabled  0

Server /chassis/adapter # show host-eth-if eth0 detail
Name eth0:
    MTU: 1500
    Uplink Port: 0
    MAC Address: B0:8B:CF:4C:ED:FF
```

```

CoS: 0
Trust Host CoS: disabled
PCI Link: 0
PCI Order: 0
VLAN: NONE
VLAN Mode: TRUNK
Rate Limiting: OFF
PXE Boot: disabled
iSCSI Boot: disabled
usNIC: 0
Channel Number: N/A
Port Profile: N/A
Uplink Failover: N/A
Uplink Failback Timeout: N/A
aRFS: disabled
VMQ: disabled
NVGRE: disabled
VXLAN: disabled
CDN Name: VIC-MLOM-eth0
RoCE Version1: disabled
RoCE Version2: disabled
RDMA Queue Pairs: 0
RDMA Memory Regions: 0
RDMA Resource Groups: 0
RDMA COS: 0
Multi Queue: disabled
No of subVnics:
Multi Queue Transmit Queue Count:
Multi Queue Receive Queue Count:
Multi Queue Completion Queue Count:
Multi Queue RoCE Version1:
Multi Queue RoCE Version2:
Multi Queue RDMA Queue Pairs:
Multi Queue RDMA Memory Regions:
Multi Queue RDMA Resource Groups:
Multi Queue RDMA COS:
Advanced Filters: disabled
Geneve Offload: disabled

```

```
Server# scope chassis
```

```
Server /chassis # scope adapter 1
```

```
Server /chassis/adapter # show ext-eth-if
```

Port	MAC Address	Link State	Encap..	Mode	Admin Speed	Oper..Speed	Link Training
Connector	Present	Connector	Supported				
0	74:A2:E6:28:C6:A2	Link	CE		40Gbps	40Gbps	N/A
Yes	Yes	Yes	Yes				
1	74:A2:E6:28:C6:A3	Link	CE		40Gbps	40Gbps	N/A
Yes	Yes	Yes	Yes				

```
Server /chassis/adapter # show ext-eth-if detail
```

```
C220-FCH1834V23X /chassis/adapter # show ext-eth-if detail
```

```
Port 0:
```

```

MAC Address: 74:A2:E6:28:C6:A2
Link State: Link
Encapsulation Mode: CE
Admin Speed: 40Gbps
Operating Speed: 40Gbps
Link Training: N/A
Connector Present: Yes
Connector Supported: Yes
Connector Type: QSFP_XCVR_CR4

```



```

Connector Vendor: CISCO
Connector Part Number: 2231254-3
Connector Part Revision: B
Port 1:
MAC Address: 74:A2:E6:28:C6:A3
Link State: Link
Encapsulation Mode: CE
Admin Speed: 40Gbps
Operating Speed: 40Gbps
Link Training: N/A
Connector Present: Yes
Connector Supported: Yes
Connector Type: QSFP_XCVR_CR4
Connector Vendor: CISCO
Connector Part Number: 2231254-3
Connector Part Revision: B

```

```
Server /chassis/adapter #
```

Modifying vNIC Properties

Before you begin

You must log in with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # show adapter	(Optional) Displays the available adapter devices.
Step 3	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 4	Server /chassis/adapter # scope host-eth-if { eth0 eth1 <i>name</i> }	Enters the host Ethernet interface command mode for the specified vNIC.
Step 5	Server /chassis/adapter/host-eth-if # set mtu <i>mtu-value</i>	Specifies the maximum transmission unit (MTU) or packet size that the vNIC accepts. Valid MTU values are 1500 to 9000 bytes; the default is 1500.
Step 6	Server /chassis/adapter/host-eth-if # set uplink { 0 1 }	Specifies the uplink port associated with this vNIC. All traffic for this vNIC goes through this uplink port.
Step 7	Server /chassis/adapter/host-eth-if # set mac-addr <i>mac-addr</i>	Specifies a MAC address for the vNIC in the form hh:hh:hh:hh:hh:hh or hhhh:hhhh:hhhh.
Step 8	Server /chassis/adapter/host-eth-if # set cos <i>cos-value</i>	Specifies the class of service (CoS) value to be marked on received packets unless the vNIC is configured to trust

	Command or Action	Purpose
		<p>host CoS. Valid CoS values are 0 to 6; the default is 0. Higher values indicate more important traffic.</p> <p>Note</p> <ul style="list-style-type: none"> You must set the COS value to 5 for the RDMA enabled interfaces. If NIV is enabled, this setting is determined by the switch, and the command is ignored.
Step 9	Server /chassis/adapter/host-eth-if # set trust-host-cos { disable enable }	<p>Specifies whether the vNIC will trust host CoS or will remark packets. The behavior is as follows:</p> <ul style="list-style-type: none"> disable —Received packets are remarked with the configured CoS. This is the default. enable —The existing CoS value of received packets (host CoS) is preserved.
Step 10	Server /chassis/adapter/host-eth-if # set order { any 0-99}	Specifies the relative order of this device for PCI bus device number assignment; the default is any.
Step 11	Server /chassis/adapter/host-eth-if # set vlan { none <i>vlan-id</i> }	<p>Specifies the default VLAN for this vNIC. Valid VLAN numbers are 1 to 4094; the default is none.</p> <p>Note If NIV is enabled, this setting is determined by the switch, and the command is ignored.</p>
Step 12	Server /chassis/adapter/host-eth-if # set vlan-mode { access trunk }	<p>Specifies the VLAN mode for the vNIC. The modes are as follows:</p> <ul style="list-style-type: none"> access —The vNIC belongs to only one VLAN. When the VLAN is set to access mode, any frame received from the specified default VLAN (1-4094) that is received from the switch with a TAG removes that TAG when it is sent to the host OS through the vNIC. trunk —The vNIC can belong to more than one VLAN. This is the default. <p>Note If NIV is enabled, this setting is determined by the switch, and the command is ignored.</p>
Step 13	Server /chassis/adapter/host-eth-if # set rate-limit { off <i>rate</i> }	<p>Specifies a maximum data rate for the vNIC. The range is 1 to 10000 Mbps; the default is off.</p> <p>For VIC 13xx controllers, you can enter an integer between 1 and 40,000.</p> <p>For VIC 1455 and 1457 controllers:</p>

	Command or Action	Purpose
		<ul style="list-style-type: none"> • If the adapter is connected to 25 Gbps link on a switch, then you can enter an integer between 1 to 25,000 Mbps. • If the adapter is connected to 10 Gbps link on a switch, then you can enter an integer between 1 to 10,000 Mbps. <p>For VIC 1495 and 1497 controllers:</p> <ul style="list-style-type: none"> • If the adapter is connected to 40 Gbps link on a switch, then you can enter an integer between 1 to 40,000 Mbps. • If the adapter is connected to 100 Gbps link on a switch, then you can enter an integer between 1 to 100,000 Mbps. <p>Note If NIV is enabled, this setting is determined by the switch, and the command is ignored.</p>
Step 14	Server /chassis/adapter/host-eth-if # set boot {disable enable}	Specifies whether the vNIC can be used to perform a PXE boot. Default value is set to disable for the default vNICs and user-created vNICs.
Step 15	Server /chassis/adapter/host-eth-if # set channel-number number	If NIV mode is enabled for the adapter, select the channel number that will be assigned to this vNIC. The range is 1 to 1000.
Step 16	Server /chassis/adapter/host-eth-if # set port-profile name	If NIV mode is enabled for the adapter, select the port profile that should be associated with the vNIC. Note The <i>name</i> must be a port profile defined on the switch to which this server is connected.
Step 17	Server /chassis/adapter/host-eth-if # set uplink-failover {disable enable}	If NIV mode is enabled for the adapter, enable this setting if traffic on this vNIC should fail over to the secondary interface if there are communication problems.
Step 18	Server /chassis/adapter/host-eth-if # set uplink-failback-timeout seconds	After a vNIC has started using its secondary interface, this setting controls how long the primary interface must be available before the system resumes using the primary interface for the vNIC. Enter a number of <i>seconds</i> between 0 and 600.
Step 19	Server /chassis/adapter/host-eth-if # set multi-queue {disabled enabled}	Enables or disables the multi queue option for this adapter and allows you to set the following multi queue parameters: <ul style="list-style-type: none"> • mq-rq-count—The number of receive queue resources to allocate. Enter an integer between 1 and 1000.

	Command or Action	Purpose
		<ul style="list-style-type: none"> • mq-wq-count—The number of transmit queue resources to allocate. Enter an integer between 1 and 1000. • mq-cq-count—The number of completion queue resources to allocate. In general, the number of completion queue resources you should allocate is equal to the number of transmit queue resources plus the number of receive queue resources. Enter an integer between 1 and 2000. <p>Note</p> <ul style="list-style-type: none"> • Multi queue is supported only on C-Series servers with 14xx adapters. • VMQ must be in enabled state to enable this option. • When you enable this option on one of the vNICs, configuring only VMQ (without choosing multi-queue) on other vNICs is not supported. • When this option is enabled usNIC configuration will be disabled.
Step 20	Server /chassis/adapter/host-eth-if # set geneve {disable enable}	<p>Beginning with release 4.1(2a), Cisco IMC supports Generic Network Virtualization Encapsulation (Geneve) Offload feature with Cisco VIC 14xx series adapters in ESX 7.0 (NSX-T 3.0) and ESX 6.7U3(NSX-T 2.5) OS.</p> <p>Geneve is a tunnel encapsulation functionality for network traffic. Enable this feature if you want to enable Geneve Offload encapsulation in Cisco VIC 14xx series adapters.</p> <p>Disable this feature to disable Geneve Offload, in order to prevent non-encapsulated UDP packets whose destination port numbers match with the Geneve destination port from being treated as tunneled packets.</p> <p>If you enable Geneve Offload feature, then Cisco recommends the following settings:</p> <ul style="list-style-type: none"> • Transmit Queue Count—1 • Transmit Queue Ring Size—4096 • Receive Queue Count—8 • Receive Queue Ring Size—4096 • Completion Queue Count—9 • Interrupt Count—11

	Command or Action	Purpose
		<p>Note You cannot enable the following when Geneve Offload is enabled:</p> <ul style="list-style-type: none"> • RDMA on the same vNIC • usNIC on the same vNIC • Non-Port Channel Mode • aRFS • Advanced Filters • NetQueue <p>Outer IPV6 is not supported with GENEVE Offload feature.</p> <p>Downgrade Limitation—If Geneve Offload is enabled, you cannot downgrade to any release earlier than 4.1(2a).</p>
Step 21	Server /chassis/adapter/host-eth-if # scope interrupt	Enters the interrupt command mode.
Step 22	Server /chassis/adapter/host-eth-if/interrupt # set interrupt-count <i>count</i>	Specifies the number of interrupt resources. The range is 1 to 514; the default is 8. In general, you should allocate one interrupt resource for each completion queue.
Step 23	Server /chassis/adapter/host-eth-if/interrupt # set coalescing-time <i>usec</i>	<p>The time to wait between interrupts or the idle period that must be encountered before an interrupt is sent.</p> <p>The range is 1 to 65535 microseconds; the default is 125. To turn off coalescing, enter 0 (zero).</p>
Step 24	Server /chassis/adapter/host-eth-if/interrupt # set coalescing-type { <i>idle</i> <i>min</i> }	<p>The coalescing types are as follows:</p> <ul style="list-style-type: none"> • idle —The system does not send an interrupt until there is a period of no activity lasting as long as the time specified in the coalescing time configuration. • min —The system waits for the time specified in the coalescing time configuration before sending another interrupt event. This is the default.
Step 25	Server /chassis/adapter/host-eth-if/interrupt # set interrupt-mode { <i>intx</i> <i>msi</i> <i>msix</i> }	<p>Specifies the Ethernet interrupt mode. The modes are as follows:</p> <ul style="list-style-type: none"> • intx —Line-based interrupt (PCI INTx) • msi —Message-Signaled Interrupt (MSI) • msix —Message Signaled Interrupts with the optional extension (MSI-X). This is the recommended and default option.

	Command or Action	Purpose
Step 26	Server /chassis/adapter/host-eth-if/interrupt # exit	Exits to the host Ethernet interface command mode.
Step 27	Server /chassis/adapter/host-eth-if # scope rcv-queue	Enters receive queue command mode.
Step 28	Server /chassis/adapter/host-eth-if/rcv-queue # set rq-count count	The number of receive queue resources to allocate. The range is 1 to 256; the default is 4.
Step 29	Server /chassis/adapter/host-eth-if/rcv-queue # set rq-ring-size size	The number of descriptors in the receive queue. The range is 64 and 16384; the default is 512. VIC 14xx Series adapters support a 4K (4096) maximum Ring Size.
Step 30	Server /chassis/adapter/host-eth-if/rcv-queue # exit	Exits to the host Ethernet interface command mode.
Step 31	Server /chassis/adapter/host-eth-if # scope trans-queue	Enters transmit queue command mode.
Step 32	Server /chassis/adapter/host-eth-if/trans-queue # set wq-count count	The number of transmit queue resources to allocate. The range is 1 to 256; the default is 1.
Step 33	Server /chassis/adapter/host-eth-if/trans-queue # set wq-ring-size size	The number of descriptors in the transmit queue. The range is 64 to 16384; the default is 256. VIC 14xx Series adapters support a 4K (4096) maximum Ring Size.
Step 34	Server /chassis/adapter/host-eth-if/trans-queue # exit	Exits to the host Ethernet interface command mode.
Step 35	Server /chassis/adapter/host-eth-if # scope comp-queue	Enters completion queue command mode.
Step 36	Server /chassis/adapter/host-eth-if/comp-queue # set cq-count count	The number of completion queue resources to allocate. The range is 1 to 512; the default is 5. In general, the number of completion queues equals the number of transmit queues plus the number of receive queues.
Step 37	Server /chassis/adapter/host-eth-if/comp-queue # exit	Exits to the host Ethernet interface command mode.
Step 38	Server /chassis/adapter/host-eth-if/ # set rdma_mr number	Sets the number of memory regions to be used per adapter. The values range from 4096 to 524288.
Step 39	Server /chassis/adapter/host-eth-if/ # set rdma_qp number	Sets the number of queue pairs to be used per adapter. The values range from 1-8192 queue pairs.
Step 40	Server /chassis/adapter/host-eth-if/ # set rdma_resgrp number	Sets the number of resource groups to be used. The values range from 1-128 resource groups. Note After committing the RoCE details, you are required to reboot the server for the changes to take place.
Step 41	Server /chassis/adapter/host-eth-if # scope offload	Enters TCP offload command mode.

	Command or Action	Purpose
Step 42	Server /chassis/adapter/host-eth-if/offload # set tcp-segment-offload {disable enable}	<p>Enables or disables TCP Segmentation Offload as follows:</p> <ul style="list-style-type: none"> • disable —The CPU segments large TCP packets. • enable —The CPU sends large TCP packets to the hardware to be segmented. This option may reduce CPU overhead and increase throughput rate. This is the default. <p>Note This option is also known as Large Send Offload (LSO).</p>
Step 43	Server /chassis/adapter/host-eth-if/offload # set tcp-rx-checksum-offload {disable enable}	<p>Enables or disables TCP Receive Offload Checksum Validation as follows:</p> <ul style="list-style-type: none"> • disable —The CPU validates all packet checksums. • enable —The CPU sends all packet checksums to the hardware for validation. This option may reduce CPU overhead. This is the default.
Step 44	Server /chassis/adapter/host-eth-if/offload # set tcp-tx-checksum-offload {disable enable}	<p>Enables or disables TCP Transmit Offload Checksum Validation as follows:</p> <ul style="list-style-type: none"> • disable —The CPU validates all packet checksums. • enable —The CPU sends all packet checksums to the hardware for validation. This option may reduce CPU overhead. This is the default.
Step 45	Server /chassis/adapter/host-eth-if/offload # set tcp-large-receive-offload {disable enable}	<p>Enables or disables TCP Large Packet Receive Offload as follows:</p> <ul style="list-style-type: none"> • disable —The CPU processes all large packets. • enable —The hardware reassembles all segmented packets before sending them to the CPU. This option may reduce CPU utilization and increase inbound throughput. This is the default.
Step 46	Server /chassis/adapter/host-eth-if/offload # exit	Exits to the host Ethernet interface command mode.
Step 47	Server /chassis/adapter/host-eth-if # scope rss	Enters Receive-side Scaling (RSS) command mode.
Step 48	Server /chassis/adapter/host-eth-if/rss # set rss {disable enable}	Enables or disables RSS, which allows the efficient distribution of network receive processing across multiple CPUs in multiprocessor systems. The default is enable for the two default vNICs, and disable for user-created vNICs.
Step 49	Server /chassis/adapter/host-eth-if/rss # set rss-hash-ipv4 {disable enable}	Enables or disables IPv4 RSS. The default is enable.

	Command or Action	Purpose
Step 50	Server /chassis/adapter/host-eth-if/rss # set rss-hash-tcp-ipv4 {disable enable}	Enables or disables TCP/IPv4 RSS. The default is enable.
Step 51	Server /chassis/adapter/host-eth-if/rss # set rss-hash-ipv6 {disable enable}	Enables or disables IPv6 RSS. The default is enable.
Step 52	Server /chassis/adapter/host-eth-if/rss # set rss-hash-tcp-ipv6 {disable enable}	Enables or disables TCP/IPv6 RSS. The default is enable.
Step 53	Server /chassis/adapter/host-eth-if/rss # set rss-hash-ipv6-ex {disable enable}	Enables or disables IPv6 Extension RSS. The default is disable.
Step 54	Server /chassis/adapter/host-eth-if/rss # set rss-hash-tcp-ipv6-ex {disable enable}	Enables or disables TCP/IPv6 Extension RSS. The default is disable.
Step 55	Server /chassis/adapter/host-eth-if/rss # exit	Exits to the host Ethernet interface command mode.
Step 56	Server /chassis/adapter/host-eth-if # commit	Commits the transaction to the system configuration. Note The changes will take effect upon the next server reboot.
Step 57	Server /chassis/adapter/host-eth-if # set vf-count <i>Count</i>	Specify number of VFs for each PF. Enter an integer between 1 and 64; the default is zero.
Step 58	Server /chassis/adapter/host-eth-if* # set vf-intr-count <i>Count</i>	Specify number of interrupts for each VF. Enter an integer between 1 and 16
Step 59	Server /chassis/adapter/host-eth-if* # set vf-rq-count <i>Count</i>	Specify number of Receive queues for each VF. Enter an integer between 1 and 8.
Step 60	Server /chassis/adapter/host-eth-if* # set vf-wq-count <i>Count</i>	Specify number of Transmit Queues for each VF. Enter an integer between 1 and 8.
Step 61	Server /chassis/adapter/host-eth-if* # set vf-cq-count <i>Count</i>	Specify number of Completion Queues for each VF. Enter an integer between 1 and 16; the default is zero. The value is sum of wq and rq.
Step 62	Server /chassis/adapter/host-eth-if* # set qinq_vlan <i>4090</i>	Specify the QinQ VLAN id for this vNIC. Enter an integer between 2 and 4094. Beginning with release 4.3.2.230207, Cisco IMC provides VIC QinQ Tunneling support on Cisco UCS C-series M5, M6 and M7 servers with UCS VIC 14xx and 15xxx series adapters.

	Command or Action	Purpose
		<p>Note</p> <ul style="list-style-type: none"> • QinQ is not supported on 13xx adapters. • Default vLAN should not be none when QinQ is configured and vLAN mode is trunk. <p>You cannot enable the following when VIC QinQ Tunneling is enabled in a setup with Cisco VIC 14xx:</p> <ul style="list-style-type: none"> • usNIC on the same vNIC • Geneve offload on the same vNIC • VMMQ on the same vNIC • RDMA v2 on the same vNIC • SR-IOV on the same vNIC <p>You cannot enable the following when VIC QinQ Tunneling is enabled in a setup with Cisco VIC 15xxx:</p> <ul style="list-style-type: none"> • usNIC on the same vNIC • VMMQ on the same vNIC • RDMA v2 on the same vNIC • SR-IOV on the same vNIC
Step 63	Server /chassis/adapter/host-eth-if* # commit	Commits the transaction to the system configuration.

Example

The below examples configure the properties of a vNIC.

- The below example enables QinQ tunneling in a vNIC:

```
Server# scope chassis
Server /chassis # show adapter
Server /chassis # scope adapter MLOM
Server /chassis/adapter # scope host-eth-if eth0
Server /chassis/adapter/host-eth-if # set qinq enabled
Server /chassis/adapter/host-eth-if *# set qinq_vlan 4090
Server /chassis/adapter/host-eth-if *# commit
Committed host-eth-if settings will take effect upon the next host power cycle
Server /chassis/adapter/host-eth-if #
```

- The below example configure the properties of a vNIC (VMQ, Multi-queue, SR-IOV)

```
Server# scope chassis
Server /chassis # show adapter
PCI Slot Product Name Serial Number Product ID Vendor
-----
1 UCS VIC P81E QCI1417A0QK N2XX-ACPCI01 Cisco Systems Inc

Server /chassis # scope adapter 1
```

```

Server /chassis/adapter # scope host-eth-if Test1
Server /chassis/adapter/host-eth-if # set uplink 1
Server /chassis/adapter/host-eth-if # set vmq enabled
Server /chassis/adapter/host-eth-if # set multi-queue enabled
Server /chassis/adapter/host-eth-if # enable arfs
Server /chassis/adapter/host-eth-if *# scope offload
Server /chassis/adapter/host-eth-if/offload *# set tcp-segment-offload enable
Server /chassis/adapter/host-eth-if/offload *# exit
Server /chassis/adapter/host-eth-if *# commit
Server /chassis/adapter/host-eth-if # set vf-count 8
Server /chassis/adapter/host-eth-if *# set vf-intr-count 8
Server /chassis/adapter/host-eth-if *# set vf-cq-count 8
Server /chassis/adapter/host-eth-if *# set vf-rq-count 4
Server /chassis/adapter/host-eth-if *# set vf-wq-count 4
Server /chassis/adapter/host-eth-if *# commit
Server /chassis/adapter/host-eth-if #

```

What to do next

Reboot the server to apply the changes.

Setting Admin Link Training on External Ethernet Interfaces

Admin link training for the port profile on the external ethernet interfaces of the specified vNIC can be enabled or disabled.

Before you begin

You must log in with admin privileges to perform this task.



Note This option is available only on some of the adapters and servers.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # show adapter	(Optional) Displays the available adapter devices.
Step 3	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 4	Server /chassis / adapter # scope ext-eth-if 0 1 name	Enters the external ethernet interface command mode for the specified vNIC.
Step 5	Server /chassis / adapter / ext-eth-if # set admin-link-training on off auto	Sets the admin link training to the chosen option for the specified vNIC.

	Command or Action	Purpose
		<p>Admin Link Training is set to <code>auto</code>, by default.</p> <p>Beginning from 4.2(2a), the below different settings apply only to Cisco UCS VIC 15xxx adapters and Copper cables at speeds 10G/25G/50G only.</p> <ul style="list-style-type: none"> • If <code>admin-link-training</code> is set to <code>auto</code>, then Adapter firmware sets <code>oper-link-training</code> value as <code>on</code> or <code>off</code>, depending upon the transceivers. <ul style="list-style-type: none"> • Auto Negotiate disabled with 25G copper • Auto Negotiate enabled with 50G copper • If <code>admin-link-training</code> is set to <code>on</code>, then Adapter firmware sets <code>oper-link-training</code> as <code>on</code>. <ul style="list-style-type: none"> • Auto Negotiate enabled with 25G copper • Auto Negotiate enabled with 50G copper • If <code>admin-link-training</code> is <code>off</code>, then Adapter firmware sets <code>oper-link-training</code> as <code>off</code>. <ul style="list-style-type: none"> • Auto Negotiate disabled with 25G copper • Auto Negotiate disabled for 50G copper <p>Note</p> <ul style="list-style-type: none"> • For all non-passive copper cables, <code>oper-link-training mode</code> is set to <code>off</code>, irrespective of the <code>admin-link-training mode</code>. • Any changes in the <code>admin-link-training</code> settings leads to the reset of the Series for that port, even if the <code>oper-link-training</code> value remains the same.
Step 6	Server /chassis / adapter / ext-eth-if * # commit	Commits the transaction to the system configuration.

Example

This example shows how to set admin link training to `auto` on the external ethernet interface.

```

Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope ext-eth-if 1
Server /chassis/adapter/ext-eth-if # set admin-link-training auto
Server /chassis/adapter/ext-eth-if* # commit
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
    
```

```

Port 1:
  MAC Address: 74:A2:E6:28:C6:A3
  Link State: Link
  Encapsulation Mode: CE
  Admin Speed: 40Gbps
  Operating Speed: -
  Admin Link Training: Auto
  Connector Present: Yes
  Connector Supported: Yes
  Connector Type: QSFP_XCVR_CR4
  Connector Vendor: CISCO
  Connector Part Number: 2231254-3
  Connector Part Revision: B
Server /chassis/adapter/ext-eth-if

```

Setting Admin FEC Mode on External Ethernet Interfaces

Before you begin

You must log in with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # show adapter	(Optional) Displays the available adapter devices.
Step 3	Server /chassis # scope adapter index	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 4	Server /chassis / adapter # scope ext-eth-if {0 1 name}	Enters the external ethernet interface command mode for the specified vNIC.
Step 5	Server /chassis / adapter / ext-eth-if # set admin-fec-mode {cl108 cl91-cons16 cl91 cl74 off}	Sets the admin FEC mode. The default value is cl91 . Note Admin Forward Error Correction (FEC) mode apply only to Cisco UCS VIC 14xx adapters at speed 25/100G and Cisco UCS VIC 15xxx adapters at speeds 25G/50G. Operating FEC Mode— The value of Operating FEC Mode is the same as Admin FEC mode with these exceptions: <ul style="list-style-type: none"> • The value is Off when the speed is 10 Gbps or 40 Gbps. This is because FEC is not supported. • The value is Off for QSFP-100G-LR4-S transceiver. • The value is Off for QSFP-40/100-SRBD transceiver.

	Command or Action	Purpose
Step 6	Server /chassis / adapter / ext-eth-if * # commit	At the prompt, select y . Commits the transaction to the system configuration.

Example

This example shows how to set the admin FEC mode on the external ethernet interface.

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope ext-eth-if 1
Server /chassis/adapter/ext-eth-if # set admin-fec-mode cl74
Server /chassis/adapter/ext-eth-if* # commit
Changes to the network settings will be applied immediately.
You may lose connectivity to the Cisco IMC and may have to log in again.
Do you wish to continue? [y/N] y
Port 1:
  MAC Address: 00:5D:73:1C:6C:58
  Link State: LinkDown
  Encapsulation Mode: CE
  Admin Speed: Auto
  Operating Speed: -
  Admin Link Training: N/A
  Admin FEC Mode: cl74
  Operating FEC Mode: Off
  Connector Present: NO
  Connector Supported: N/A
  Connector Type: N/A
  Connector Vendor: N/A
  Connector Part Number: N/A
  Connector Part Revision: N/A
Server /chassis/adapter/ext-eth-if #
```

Creating a vNIC

The adapter provides two permanent vNICs. You can create up to 16 additional vNICs.

Before you begin

You must log in with user or admin privileges to perform this task.

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **create host-eth-if** *name*
4. (Optional) Server /chassis/adapter/host-eth-if # **set channel-number** *number*
5. Server /chassis/adapter/host-eth-if # **commit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.

	Command or Action	Purpose
Step 2	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 3	Server /chassis/adapter # create host-eth-if <i>name</i>	Creates a vNIC and enters the host Ethernet interface command mode. The <i>name</i> argument can be up to 32 ASCII characters.
Step 4	(Optional) Server /chassis/adapter/host-eth-if # set channel-number <i>number</i>	If NIV mode is enabled for the adapter, you must assign a channel number to this vNIC. The range is 1 to 1000.
Step 5	Server /chassis/adapter/host-eth-if # commit	Commits the transaction to the system configuration. Note The changes will take effect upon the next server reboot.

Example

This example creates a vNIC on adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # create host-eth-if Vnic5
Server /chassis/adapter/host-eth-if *# commit
New host-eth-if settings will take effect upon the next server reset
Server /chassis/adapter/host-eth-if #
```

Deleting a vNIC

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **delete host-eth-if** *name*
4. Server /chassis/adapter # **commit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.

	Command or Action	Purpose
Step 3	Server /chassis/adapter # delete host-eth-if <i>name</i>	Deletes the specified vNIC. Note You cannot delete either of the two default vNICs, eth0 or eth1.
Step 4	Server /chassis/adapter # commit	Commits the transaction to the system configuration. Note The changes will take effect upon the next server reboot.

Example

This example deletes a vNIC on adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # delete host-eth-if Vnic5
Server /chassis/adapter *# commit
Server /chassis/adapter #
```

Creating Cisco usNIC Using the CLI



Note Even though several properties are listed for Cisco usNIC in the usNIC properties dialog box, you must configure only the following properties because the other properties are not currently being used.

- **cq-count**
- **rq-count**
- **tq-count**
- **usnic-count**

Before you begin

You must log in to the CLI with administrator privileges to perform this task.

SUMMARY STEPS

1. server# **scope chassis**
2. server/chassis# **scope adapter** *index*
3. server/chassis/adapter# **scope host-eth-if** {eth0 | eth1}
4. server/chassis/adapter/host-eth-if# **create usnic-config** 0
5. server/chassis/adapter/host-eth-if/usnic-config# **set cq-count** *count*
6. server/chassis/adapter/host-eth-if/usnic-config# **set rq-count** *count*
7. server/chassis/adapter/host-eth-if/usnic-config# **set tq-count** *count*
8. server/chassis/adapter/host-eth-if/usnic-config# **set usnic-count** *number of usNICs* .

9. server/chassis/adapter/host-eth-if /usnic-config# **commit**
10. server/chassis/adapter/host-eth-if/usnic-config# **exit**
11. server/chassis/adapter/host-eth-if# **exit**
12. server/chassis/adapter# **exit**
13. server/chassis# **exit**
14. server# **scope bios**
15. server/bios# **scope advanced**
16. server/bios/advanced# **set IntelVTD Enabled**
17. server/bios/advanced# **set ATS Enabled**
18. server/bios/advanced# **set CoherencySupport Enabled**
19. server /bios/advanced# **commit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	server# scope chassis	Enters chassis command mode.
Step 2	server/chassis# scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note Make sure that the server is powered on before you attempt to view or change adapter settings. To view the index of the adapters configured on your server, use the show adapter command.
Step 3	server/chassis/adapter# scope host-eth-if { eth0 eth1 }	Enters the command mode for the vNIC. Specify the Ethernet ID based on the number of vNICs that you have configured in your environment. For example, specify eth0 if you configured only one vNIC.
Step 4	server/chassis/adapter/host-eth-if# create usnic-config 0	Creates a usNIC config and enters its command mode. Make sure that you always set the index value to 0. Note To create a Cisco usNIC for the first time for a given vNIC using the CLI, you must first create a usnic-config . Subsequently, you only need to scope into the usnic-config and modify the properties for Cisco usNIC. For more information about modifying Cisco usNIC properties, see Modifying a Cisco usNIC value using the CLI, on page 42 .
Step 5	server/chassis/adapter/host-eth-if/usnic-config# set cq-count <i>count</i>	Specifies the number of completion queue resources to allocate. We recommend that you set this value to 6. The number of completion queues equals the number of transmit queues plus the number of receive queues.
Step 6	server/chassis/adapter/host-eth-if/usnic-config# set rq-count <i>count</i>	Specifies the number of receive queue resources to allocate. We recommend that you set this value to 6.

	Command or Action	Purpose
Step 7	server/chassis/adapter/host-eth-if/usnic-config# set tq-count <i>count</i>	Specifies the number of transmit queue resources to allocate. We recommend that you set this value to 6.
Step 8	server/chassis/adapter/host-eth-if/usnic-config# set usnic-count <i>number of usNICs</i> .	Specifies the number of Cisco usNICs to create. Each MPI process that is running on the server requires a dedicated Cisco usNIC. Therefore, you might need to create up to 64 Cisco usNICs to sustain 64 MPI processes running simultaneously. We recommend that you create at least as many Cisco usNICs, per Cisco usNIC-enabled vNIC, as the number of physical cores on your server. For example, if you have 8 physical cores on your server, create 8 Cisco usNICs.
Step 9	server/chassis/adapter/host-eth-if/usnic-config# commit	Commits the transaction to the system configuration. Note The changes take effect when the server is rebooted.
Step 10	server/chassis/adapter/host-eth-if/usnic-config# exit	Exits to host Ethernet interface command mode.
Step 11	server/chassis/adapter/host-eth-if# exit	Exits to adapter interface command mode.
Step 12	server/chassis/adapter# exit	Exits to chassis interface command mode.
Step 13	server/chassis# exit	Exits to server interface command mode.
Step 14	server# scope bios	Enters Bios command mode.
Step 15	server/bios# scope advanced	Enters the advanced settings of BIOS command mode.
Step 16	server/bios/advanced# set IntelVTD Enabled	Enables the Intel Virtualization Technology.
Step 17	server/bios/advanced# set ATS Enabled	Enables the Intel VT-d Address Translation Services (ATS) support for the processor.
Step 18	server/bios/advanced# set CoherencySupport Enabled	Enables Intel VT-d coherency support for the processor.
Step 19	server /bios/advanced# commit	Commits the transaction to the system configuration. Note The changes take effect when the server is rebooted.

Example

This example shows how to configure Cisco usNIC properties:

```
Server # scope chassis
server /chassis # show adapter
server /chassis # scope adapter 2
server /chassis/adapter # scope host-eth-if eth0
server /chassis/adapter/host-eth-if # create usnic-config 0
server /chassis/adapter/host-eth-if/usnic-config *# set usnic-count 64
```

```

server /chassis/adapter/host-eth-if/usnic-config *# set cq-count 6
server /chassis/adapter/host-eth-if/usnic-config *# set rq-count 6
server /chassis/adapter/host-eth-if/usnic-config *# set tq-count 6
server /chassis/adapter/host-eth-if/usnic-config *# commit
Committed settings will take effect upon the next server reset
server /chassis/adapter/host-eth-if/usnic-config # exit
server /chassis/adapter/host-eth-if # exit
server /chassis/adapter # exit
server /chassis # exit
server # exit
server# scope bios
server /bios # scope advanced
server /bios/advanced # set IntelVTD Enabled
server /bios/advanced *# set ATS Enabled*
server /bios/advanced *# set CoherencySupport Enabled
server /bios/advanced *# commit
Changes to BIOS set-up parameters will require a reboot.
Do you want to reboot the system?[y|N]y
A system reboot has been initiated.

```

Modifying a Cisco usNIC value using the CLI

Before you begin

You must log in to the GUI with administrator privileges to perform this task.

SUMMARY STEPS

1. server# **scope chassis**
2. server/chassis# **scope adapter** *index*
3. server/chassis/adapter# **scope host-eth-if** {eth0 | eth1}
4. server/chassis/adapter/host-eth-if# **scope usnic-config** 0
5. server/chassis/adapter/host-eth-if/usnic-config# **set usnic-count** *number of usNICs* .
6. server /chassis/adapter/host-eth-if /usnic-config# **commit**
7. server/chassis/adapter/host-eth-if/usnic-config# **exit**
8. server/chassis/adapter/host-eth-if# **exit**
9. server/chassis/adapter# **exit**
10. server/chassis# **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	server# scope chassis	Enters chassis command mode.
Step 2	server/chassis# scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note Make sure that the server is powered on before you attempt to view or change adapter settings. To view the index of the adapters configured on you server, use the show adapter command.

	Command or Action	Purpose
Step 3	server/chassis/adapter# scope host-eth-if {eth0 eth1}	Enters the command mode for the vNIC. Specify the Ethernet ID based on the number of vNICs that you have configured in your environment. For example, specify eth0 if you configured only one vNIC.
Step 4	server/chassis/adapter/host-eth-if# scope usnic-config 0	Enters the command mode for the usNIC. Make sure that you always set the index value as 0 to configure a Cisco usNIC.
Step 5	server/chassis/adapter/host-eth-if/usnic-config# set usnic-count <i>number of usNICs</i> .	Specifies the number of Cisco usNICs to create. Each MPI process running on the server requires a dedicated Cisco usNIC. Therefore, you might need to create up to 64 Cisco usNIC to sustain 64 MPI processes running simultaneously. We recommend that you create at least as many Cisco usNIC, per Cisco usNIC-enabled vNIC, as the number of physical cores on your server. For example, if you have 8 physical cores on your server, create 8 usNICs.
Step 6	server /chassis/adapter/host-eth-if/usnic-config# commit	Commits the transaction to the system configuration. Note The changes take effect when the server is rebooted.
Step 7	server/chassis/adapter/host-eth-if/usnic-config# exit	Exits to host Ethernet interface command mode.
Step 8	server/chassis/adapter/host-eth-if# exit	Exits to adapter interface command mode.
Step 9	server/chassis/adapter# exit	Exits to chassis interface command mode.
Step 10	server/chassis# exit	Exits to server interface command mode.

Example

This example shows how to configure Cisco usNIC properties:

```
server # scope chassis
server /chassis # show adapter
server /chassis # scope adapter 2
server /chassis/adapter # scope host-eth-if eth0
server /chassis/adapter/host-eth-if # scope usnic-config 0
server /chassis/adapter/host-eth-if/usnic-config # set usnic-count 32
server /chassis/adapter/host-eth-if/usnic-config # commit
Committed settings will take effect upon the next server reset
server /chassis/adapter/host-eth-if/usnic-config # exit
server /chassis/adapter/host-eth-if # exit
server /chassis/adapter # exit
server /chassis # exit
server # exit
```

Viewing usNIC Properties

Before you begin

You must log in with admin privileges to perform this task.

usNIC must be configured on a vNIC.

Procedure

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 3	Server /chassis/adapter # scope host-eth-if { eth0 eth1 <i>name</i> }	Enters the host Ethernet interface command mode for the specified vNIC.
Step 4	Server /chassis/adapter/host-eth-if # show usnic-config <i>index</i>	Displays the usNIC properties for a vNIC.

Example

This example displays the usNIC properties for a vNIC:

```
Server # scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-eth-if eth0
Server /chassis/adapter/host-eth-if # show usnic-config 0
Idx usNIC Count TQ Count RQ Count CQ Count TQ Ring Size RQ Ring Size Interrupt Count
-----
0 113 2 2 4 256 512 4
Server /chassis/adapter/host-eth-if #
```

Deleting Cisco usNIC from a vNIC

Before you begin

You must log in to CLI with admin privileges to perform this task.

Procedure

	Command or Action	Purpose
Step 1	server# scope chassis	Enters chassis command mode.

	Command or Action	Purpose
Step 2	server/chassis# scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note Make sure that the server is powered on before you attempt to view or change adapter settings. To view the index of the adapters configured on your server, use the show adapter command.
Step 3	server/chassis/adapter# scope host-eth-if {eth0 eth1}	Enters the command mode for the vNIC. Specify the Ethernet ID based on the number of vNICs that you have configured in your environment. For example, specify eth0 if you configured only one vNIC.
Step 4	Server/chassis/adapter/host-eth-if# delete usnic-config 0	Deletes the Cisco usNIC configuration for the vNIC.
Step 5	Server/chassis/adapter/host-eth-if# commit	Commits the transaction to the system configuration. Note The changes take effect when the server is rebooted.

Example

This example shows how to delete the Cisco usNIC configuration for a vNIC:

```
server # scope chassis
server/chassis # show adapter
server/chassis # scope adapter 1
server/chassis/adapter # scope host-eth-if eth0
server/chassis/adapter/host-eth-if # delete usnic-config 0
server/chassis/host-eth-if/iscsi-boot *# commit
New host-eth-if settings will take effect upon the next adapter reboot

server/chassis/host-eth-if/usnic-config #
```

Configuring iSCSI Boot Capability

Configuring iSCSI Boot Capability for vNICs

To configure the iSCSI boot capability on a vNIC:

- You must log in with admin privileges to perform this task.
- To configure a vNIC to boot a server remotely from an iSCSI storage target, you must enable the PXE boot option on the vNIC.



Note You can configure a maximum of 2 iSCSI vNICs for each host.

Configuring iSCSI Boot Capability on a vNIC

You can configure a maximum of 2 iSCSI vNICs for each host.

Before you begin

- To configure a vNIC to boot a server remotely from an iSCSI storage target, you must enable the PXE boot option on the vNIC.
- You must log in with admin privileges to perform this task.

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **scope host-eth-if** {**eth0** | **eth1** | *name*}
4. Server /chassis/adapter/host-eth-if # **create iscsi-boot** *index*
5. Server /chassis/adapter/host-eth-if/iscsi-boot* # **create iscsi-target** *index*
6. Server /chassis/adapter/host-eth-if/iscsi-boot* # **set dhcp-net-settings enabled**
7. Server /chassis/adapter/host-eth-if/iscsi-boot* # **set initiator-name** *string*
8. Server /chassis/adapter/host-eth-if/iscsi-boot* # **set dhcp-iscsi-settings enabled**
9. Server /chassis/adapter/host-eth-if/iscsi-boot* # **commit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 3	Server /chassis/adapter # scope host-eth-if { eth0 eth1 <i>name</i> }	Enters the host Ethernet interface command mode for the specified vNIC.
Step 4	Server /chassis/adapter/host-eth-if # create iscsi-boot <i>index</i>	Creates the iSCSI boot index for the vNIC. At this moment, only 0 is allowed as the index.
Step 5	Server /chassis/adapter/host-eth-if/iscsi-boot* # create iscsi-target <i>index</i>	Creates an iSCSI target for the vNIC. The value can either be 0 or 1.
Step 6	Server /chassis/adapter/host-eth-if/iscsi-boot* # set dhcp-net-settings enabled	Enables the DHCP network settings for the iSCSI boot.
Step 7	Server /chassis/adapter/host-eth-if/iscsi-boot* # set initiator-name <i>string</i>	Sets the initiator name. It cannot be more than 223 characters.
Step 8	Server /chassis/adapter/host-eth-if/iscsi-boot* # set dhcp-iscsi-settings enabled	Enables the DHCP iSCSI settings.

	Command or Action	Purpose
Step 9	Server /chassis/adapter/host-eth-if/iscsi-boot* # commit	Commits the transaction to the system configuration. Note The changes will take effect upon the next server reboot.

Example

This example shows how to configure the iSCSI boot capability for a vNIC:

```
Server # scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-eth-if eth0
Server /chassis/adapter/host-eth-if # create iscsi-boot 0
Server /adapter/host-eth-if/iscsi-boot *# set dhcp-net-settings enabled
Server /adapter/host-eth-if/iscsi-boot *# set initiator-name iqn.2012-01.com.adser:abcde
Server /adapter/host-eth-if/iscsi-boot *# set dhcp-iscsi-settings enabled
Server /adapter/host-eth-if/iscsi-boot *# commit
```

New host-eth-if settings will take effect upon the next server reset
Server /adapter/host-eth-if/iscsi-boot #

Deleting an iSCSI Boot Configuration for a vNIC

Before you begin

You must log in with admin privileges to perform this task.

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **scope host-eth-if** {eth0 | eth1 | *name*}
4. Server /chassis/adapter/host-eth-if # **delete iscsi-boot 0**
5. Server /chassis/adapter/host-eth-if* # **commit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 3	Server /chassis/adapter # scope host-eth-if {eth0 eth1 <i>name</i> }	Enters the host Ethernet interface command mode for the specified vNIC.

	Command or Action	Purpose
Step 4	Server /chassis/adapter/host-eth-if # delete iscsi-boot 0	Deletes the iSCSI boot capability for the vNIC.
Step 5	Server /chassis/adapter/host-eth-if* # commit	Commits the transaction to the system configuration Note The changes will take effect upon the next server reboot.

Example

This example shows how to delete the iSCSI boot capability for a vNIC:

```
Server # scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # scope host-eth-if eth0
Server /chassis/adapter/host-eth-if # delete iscsi-boot 0
Server /adapter/host-eth-if/iscsi-boot *# commit
New host-eth-if settings will take effect upon the next server reset

Server /adapter/host-eth-if/iscsi-boot #
```

Backing Up and Restoring the Adapter Configuration

Exporting the Adapter Configuration

The adapter configuration can be exported as an XML file to a TFTP server.



Important If any firmware or BIOS updates are in progress, do not export the adapter configuration until those tasks are complete.

Before you begin

A supported Virtual Interface Card (VIC) must be installed in the chassis and the server must be powered on.
Obtain the TFTP server IP address.

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **export-vnic protocol** *remote server IP address*

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 3	Server /chassis/adapter # export-vnic <i>protocol remote server IP address</i>	Starts the export operation. The adapter configuration file will be stored at the specified path and filename on the remote server at the specified IP address. The protocol can be one of the following: <ul style="list-style-type: none"> • TFTP • FTP • SFTP • SCP • HTTP Note The Cisco UCS C-Series server now supports fingerprint confirmation of the server when you update firmware through a remote server. This option is available only if you choose SCP or SFTP as the remote server type. If you chose SCP or SFTP as the remote server type while performing this action, a prompt with the message Server (RSA) key fingerprint is <server_finger_print_ID> Do you wish to continue? Click y or n depending on the authenticity of the server fingerprint. The fingerprint is based on the host's public key and helps you to identify or verify the host you are connecting to.

Example

This example exports the configuration of adapter 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # export-vnic ftp 192.0.20.34 //test/dnld-ucs-k9-bundle.1.0.2h.bin
Server /chassis/adapter #
```

Importing the Adapter Configuration



Important If any firmware or BIOS updates are in progress, do not import the adapter configuration until those tasks are complete.

Before you begin

You must log in with admin privileges to perform this task.

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **scope adapter** *index*
3. Server /chassis/adapter # **import-vnic** *tftp-ip-address path-and-filename*

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # scope adapter <i>index</i>	Enters the command mode for the adapter card at the PCI slot number specified by <i>index</i> . Note The server must be powered on before you can view or change adapter settings.
Step 3	Server /chassis/adapter # import-vnic <i>tftp-ip-address path-and-filename</i>	Starts the import operation. The adapter downloads the configuration file from the specified path on the TFTP server at the specified IP address. The configuration will be installed during the next server reboot.

Example

This example imports a configuration for the adapter in PCI slot 1:

```
Server# scope chassis
Server /chassis # scope adapter 1
Server /chassis/adapter # import-vnic 192.0.2.34 /ucs/backups/adapter4.xml
Import succeeded.
New VNIC adapter settings will take effect upon the next server reset.
Server /chassis/adapter #
```

What to do next

Reboot the server to apply the imported configuration.

Restoring Adapter Defaults

Before you begin

You must log in with admin privileges to perform this task.

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **adapter-reset-defaults index**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # adapter-reset-defaults index	Restores factory default settings for the adapter at the PCI slot number specified by the <i>index</i> argument. Note Resetting the adapter to default settings sets the port speed to 4 X 10 Gbps. Choose 40 Gbps as the port speed only if you are using a 40 Gbps switch.

Example

This example restores the default configuration of the adapter in PCI slot 1:

```
Server# scope chassis
Server /chassis # adapter-reset-defaults 1
This operation will reset the adapter to factory default.
All your configuration will be lost.
Continue?[y|N] y
Server /chassis #
```

Managing Adapter Firmware

Adapter Firmware

A Cisco UCS C-Series network adapter contains the following firmware components:

- Adapter firmware—The main operating firmware, consisting of an active and a backup image, can be installed from the GUI or CLI interface or from the Host Upgrade Utility (HUU). You can upload a firmware image from either a local file system or a TFTP server.
- Bootloader firmware—The bootloader firmware cannot be installed from the . You can install this firmware using the Host Upgrade Utility.

Installing Adapter Firmware



Important If any firmware or BIOS updates are in progress, do not install the adapter firmware until those tasks are complete.

Before you begin

You must log in with admin privileges to perform this task.

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **update-adapter-fw** *tftp-ip-address path-and-filename* {**activate** | **no-activate**} [*pci-slot*]
[*pci-slot*]
3. (Optional) Server /chassis # **recover-adapter-update** [*pci-slot*] [*pci-slot*]

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # update-adapter-fw <i>tftp-ip-address path-and-filename</i> { activate no-activate } [<i>pci-slot</i>] [<i>pci-slot</i>]	Downloads the specified adapter firmware file from the TFTP server, then installs the firmware as the backup image on one or two specified adapters or, if no adapter is specified, on all adapters. If the activate keyword is specified, the new firmware is activated after installation.
Step 3	(Optional) Server /chassis # recover-adapter-update [<i>pci-slot</i>] [<i>pci-slot</i>]	Clears an incomplete firmware update condition on one or two specified adapters or, if no adapter is specified, on all adapters.

Example

This example begins an adapter firmware upgrade on the adapter in PCI slot 1:

```
Server# scope chassis
Server /chassis # update-adapter-fw 192.0.2.34 /ucs/adapters/adapter4.bin activate 1
Server /chassis #
```

What to do next

To activate the new firmware, see [Activating Adapter Firmware, on page 53](#).

Activating Adapter Firmware



- Important** While the activation is in progress, do not:
- Reset, power off, or shut down the server.
 - Reboot or reset .
 - Activate any other firmware.
 - Export technical support or configuration data.

Before you begin

You must log in with admin privileges to perform this task.

SUMMARY STEPS

1. Server# **scope chassis**
2. Server /chassis # **activate-adapter-fw pci-slot {1 | 2}**

DETAILED STEPS

	Command or Action	Purpose
Step 1	Server# scope chassis	Enters the chassis command mode.
Step 2	Server /chassis # activate-adapter-fw pci-slot {1 2}	Activates adapter firmware image 1 or 2 on the adapter in the specified PCI slot. Note The changes will take effect upon the next server reboot.

Example

This example activates adapter firmware image 2 on the adapter in PCI slot 1:

```
Server# scope chassis
Server /chassis # activate-adapter-fw 1 2
Firmware image activation succeeded
Please reset the server to run the activated image
Server /chassis #
```

What to do next

Reboot the server to apply the changes.

