



## Server-Related Faults

---

This chapter contains the following sections:

- [fltAdapterUnitMissing](#), on page 1
- [fltComputeBoardCmosVoltageThresholdCritical](#), on page 2
- [fltComputeBoardCmosVoltageThresholdNonRecoverable](#), on page 3
- [fltComputeBoardMotherBoardVoltageLowerThresholdCritical](#), on page 3
- [fltComputeBoardMotherBoardVoltageThresholdLowerNonRecoverable](#), on page 4
- [fltComputeBoardMotherBoardVoltageThresholdUpperNonRecoverable](#), on page 5
- [fltComputeBoardMotherBoardVoltageUpperThresholdCritical](#), on page 6
- [fltComputeBoardPowerError](#), on page 6
- [fltComputeBoardPowerFail](#), on page 7
- [fltComputeBoardPowerUsageProblem](#), on page 8
- [fltComputeBoardThermalProblem](#), on page 8
- [fltComputeIOHubThermalNonCritical](#), on page 9
- [fltComputeIOHubThermalThresholdCritical](#), on page 10
- [fltComputeIOHubThermalThresholdNonRecoverable](#), on page 10
- [fltComputePhysicalBiosPostTimeout](#), on page 11
- [fltComputePhysicalPostfailure](#), on page 12
- [fltComputePhysicalUnidentified](#), on page 12
- [fltEquipmentTpmTpmMismatch](#), on page 13
- [fltMgmtIfMissing](#), on page 14
- [fltPowerBudgetPowerBudgetBmcProblem](#), on page 15
- [fltPowerBudgetPowerBudgetCmcProblem](#), on page 15

### fltAdapterUnitMissing

**Fault Code**

F0203

**Description**

[sensor\_name]:[id] missing: reseal or replace [id].

**Explanation**

This fault occurs when the adapter is missing in the adapter slot, or when the endpoint cannot detect or communicate with the adapter.

**Recommended Action**

If you see this fault, take the following actions:

1. Make sure the adapter is inserted properly in the adapter slot.
2. Check whether the adapter is connected, configured, and running the recommended firmware version.

**Fault Details**

**Severity:** warning

**Cause:** equipment-missing

**mibFaultCode:** 203

**mibFaultName:**fltAdapterUnitMissing

**moClass:** compute:adapter

**Type:** equipment

## fltComputeBoardCmosVoltageThresholdCritical

**Fault Code**

F0424

**Description**

Battery voltage level is upper critical: Replace battery.

**Explanation**

This fault occurs when the CMOS battery voltage drops lower than the normal operating range. The low battery voltage might affect the clock and other CMOS settings.

**Recommended Action**

If you see this fault, replace the CMOS battery.

Before replacing this component, see the server-specific Installation and Service Guide for prerequisites, safety recommendations, and warnings.

**Fault Details**

**Severity:** critical

**Cause:** voltage-problem

**mibFaultCode:** 424

**mibFaultName:** fltComputeBoardCmosVoltageThresholdCritical

**moClass:** compute:Board

**Type:** environmental

## fltComputeBoardCmosVoltageThresholdNonRecoverable

### Fault Code

F0425

### Description

Battery voltage level is upper non-recoverable: Replace battery.

### Explanation

This fault indicates that the CMOS battery voltage has dropped and is unlikely to recover. The low voltage impacts the clock and other CMOS settings.

### Recommended Action

If you see this fault, replace the CMOS battery.

Before replacing this component, see the server-specific Installation and Service Guide for prerequisites, safety recommendations and warnings.

### Fault Details

**Severity:** major

**Cause:** voltage-problem

**mibFaultCode:** 425

**mibFaultName:** fltComputeBoardCmosVoltageThresholdNonRecoverable

**moClass:** compute:Board

**Type:** environmental

## fltComputeBoardMotherBoardVoltageLowerThresholdCritical

### Fault Code

F0921

### Description

You see one of the following messages when this fault is raised:

- Stand-by voltage ([Val] V) to the motherboard is lower critical: Check the power supply.

- Auxiliary voltage ([Val] V) to the motherboard is lower critical: Check the power supply.
- Motherboard voltage ([Val] V) is lower critical: Check the power supply.

### Explanation

This fault indicates that one or more motherboard input voltages have crossed lower critical thresholds.

### Recommended Action

If you see this fault, take the following actions:

1. Reseat or replace the power supply.  
Before replacing this component, see the server-specific Installation and Service Guide for prerequisites, safety recommendations and warnings.
2. If the issue persists, create a tech-support file and contact TAC.

### Fault Details

**Severity:** major

**Cause:** voltage-problem

**mibFaultCode:** 921

**mibFaultName:** fltComputeBoardMotherBoardVoltageLowerThresholdCritical

**moClass:** compute: Board

**Type:** environmental

## fltComputeBoardMotherBoardVoltageThresholdLowerNonRecoverable

### Fault Code

F0919

### Description

You see one of the following messages when this fault is raised:

- Stand-by voltage ([Val] V) to the motherboard is lower non-recoverable: Check the power supply.
- Auxiliary voltage ([Val] V) to the motherboard is lower non-recoverable: Check the power supply.
- Motherboard voltage ([Val] V) is lower non-recoverable: Check the power supply.

### Explanation

This fault indicates that one or more motherboard input voltages has dropped too low and is unlikely to recover.

**Recommended Action**

If you see this fault, create a tech-support file and contact Cisco TAC.

**Fault Details**

**Severity:** critical

**Cause:** voltage-problem

**mibFaultCode:** 919

**mibFaultName:** fltComputeBoardMotherBoardVoltageThresholdLowerNonRecoverable

**moClass:** compute: Board

**Type:** environmental

## fltComputeBoardMotherBoardVoltageThresholdUpperNonRecoverable

**Fault Code**

F0918

**Description**

You see one of the following messages when this fault is raised:

- Stand-by voltage ([Val] V) to the motherboard is upper non-recoverable: Check the power supply.
- Motherboard voltage ([Val] V) is upper non-recoverable: Check the power supply.
- Auxiliary voltage ([Val] V) to the motherboard is upper non-recoverable: Check the power supply.

**Explanation**

This fault indicates that one or more motherboard input voltages are high and are unlikely to recover.

**Recommended Action**

If you see this fault, create a tech-support file and contact Cisco TAC.

**Fault Details**

**Severity:** critical

**Cause:** voltage-problem

**mibFaultCode:** 918

**mibFaultName:** fltComputeBoardMotherBoardVoltageThresholdUpperNonRecoverable

**moClass:** compute:Board

**Type:** environmental

# fltComputeBoardMotherBoardVoltageUpperThresholdCritical

**Fault Code**

F0920

**Description**

You see one of the following messages when this fault is raised:

- Stand-by voltage (xV) to the motherboard is upper critical: Check the power supply.
- Auxiliary voltage (xV) to the motherboard is upper critical: Check the power supply.
- Motherboard voltage (xV) is upper critical: Check the power supply.

**Explanation**

This fault indicates that one or more motherboard input voltages have exceeded upper critical thresholds.

**Recommended Action**

If you see this fault, take the following actions:

1. Reseat or replace the power supply.
2. If the issue persists, create a tech-support file and contact Cisco TAC.

**Fault Details**

**Severity:** major

**Cause:** voltage-problem

**mibFaultCode:** 920

**mibFaultName:** fltComputeBoardMotherBoardVoltageUpperThresholdCritical

**moClass:** compute: Board

**Type:** environmental

# fltComputeBoardPowerError

**Fault Code**

F0310

**Description**

P[Id]V[Id]\_AU[Id]\_PWRGD: Voltage rail Power Good dropped due to PSU or HW failure, please contact CISCO TAC for assistance.

**Explanation**

This fault indicates that the server power sensors have detected a problem.

**Recommended Action**

If you see this fault, take the following actions:

1. Reseat or replace the power supply.  
Before replacing this component, see the server-specific Installation and Service Guide for prerequisites, safety recommendations, and warnings.
2. If the recommended action did not resolve the issue, create a tech-support file and contact Cisco TAC.

**Fault Details**

**Severity:** major

**Cause:** power-problem

**mibFaultCode:** 310

**mibFaultName:** fltComputeBoardPowerError

**moClass:** compute:Board

**Type:** environmental

## fltComputeBoardPowerFail

**Fault Code**

F0868

**Description**

The server failed to power on: Check Power Supply.

**Explanation**

This fault indicates that the power sensors on the server have detected a problem.

**Recommended Action**

If you see this fault, create a tech-support file and contact Cisco TAC.

**Fault Details**

**Severity:** critical

**Cause:** power-problem

**mibFaultCode:** 868

**mibFaultName:** fltComputeBoardPowerFail

**moClass:** compute:Board

**Type:** environmental

## fltComputeBoardPowerUsageProblem

### Fault Code

F1040

### Description

You see one of the following messages when this fault is raised:

- Motherboard Power usage is upper critical: Check hardware.
- Motherboard Power usage is upper non-recoverable: Check hardware.

### Explanation

This fault occurs when the motherboard power consumption exceeds a certain threshold limit.

### Recommended Action

If you see this fault, create a tech-support file and contact Cisco TAC.

### Fault Details

**Severity:** warning

**Cause:** power-problem

**mibFaultCode:** 1040

**mibFaultName:** fltComputeBoardPowerUsageProblem

**moClass:** compute:Board

**Type:** environmental

## fltComputeBoardThermalProblem

### Fault Code

F0869

### Description

Motherboard chipset inoperable due to high temperature.

### Explanation

This fault indicates that the motherboard thermal sensors on the server have detected a problem.



**Recommended Action**

If you see this fault, take the following actions:

1. Verify that the server fans are working properly.
2. Wait for 24 hours to see if the problem resolves itself.
3. If the problem still persists, create a tech-support file and contact Cisco TAC.

**Fault Details**

**Severity:** major

**Cause:** thermal-problem

**mibFaultCode:** 869

**mibFaultName:** fltComputeBoardThermalProblem

**moClass:** compute:Board

**Type:** environmental

## fltComputeIOHubThermalNonCritical

**Fault Code**

F0538

**Description**

[sensor\_name]: Motherboard chipset temperature is upper non-critical.

**Explanation**

This fault indicates that the I/O controller temperature is outside the upper or lower non-critical threshold.

**Recommended Action**

If you see this fault, take the following actions:

1. Monitor other environmental events related to this server and make sure that the temperature is within the recommended range.
2. If the problem still persists, create a tech-support file and contact Cisco TAC.

**Fault Details**

**Severity:** minor

**Cause:** thermal-problem

**mibFaultCode:** 538

**mibFaultName:** fltComputeIOHubThermalNonCritical

**moClass:** compute:IOHub

**Type:** environmental

## fltComputeIOHubThermalThresholdCritical

### Fault Code

F0539

### Description

[sensor\_name]: Motherboard chipset temperature is upper critical.

### Explanation

This fault occurs when the I/O controller temperature is outside the upper or lower critical threshold.

### Recommended Action

If you see this fault, take the following actions:

1. Monitor other environmental events related to the server and make sure that the temperature is within the recommended range.
2. Consider turning off the server for a while if possible.
3. If the problem still persists, create a tech-support file and contact Cisco TAC.

### Fault Details

**Severity:** major

**Cause:** thermal-problem

**mibFaultCode:** 539

**mibFaultName:** fltComputeIOHubThermalThresholdCritical

**moClass:** compute:IOHub

**Type:** environmental

## fltComputeIOHubThermalThresholdNonRecoverable

### Fault Code

F0540

### Description

[sensor\_name]: Motherboard chipset temperature is upper non-recoverable.

**Explanation**

This fault indicates that the I/O controller temperature is outside the recoverable range of operation.

**Recommended Action**

If you see this fault, take the following actions:

1. Shut down the server immediately.
2. Create a tech-support file and contact Cisco TAC.

**Fault Details**

**Severity:** critical

**Cause:** thermal-problem

**mibFaultCode:** 540

**mibFaultName:** fltComputeIOHubThermalThresholdNonRecoverable

**moClass:** compute:IOHub

**Type:** environmental

## fltComputePhysicalBiosPostTimeout

**Fault Code**

F0313

**Description**

BIOS POST Timeout occurred: Contact Cisco TAC.

**Explanation**

This fault indicates that the server did not complete the BIOS POST.

**Recommended Action**

If you see this fault, take the following actions:

1. Connect to the CIMC Web UI and launch the KVM console to monitor the BIOS POST completion.
2. If the problem still persists, create a tech-support file and contact Cisco TAC.

**Fault Details**

**Severity:** critical

**Cause:** equipment-inoperable

**mibFaultCode:** 313

**mibFaultName:** fltComputePhysicalBiosPostTimeout

**moClass:** compute:Physical

**Type:** equipment

## fltComputePhysicalPostfailure

### Fault Code

F0517

### Description

[sensor\_name]: BIOS POST Failed: Check hardware.

### Explanation

This fault indicates that the server has encountered a diagnostic failure or an error during POST.

### Recommended Action

If you see this fault, take the following actions:

1. Check the POST result for the server.
2. Reboot the server.
3. If the problem still persists, create a tech-support file and contact Cisco TAC.

### Fault Details

**Severity:** critical

**Cause:** equipment-problem

**mibFaultCode:** 517

**mibFaultName:** fltComputePhysicalPostfailure

**moClass:** compute:Physical

**Type:** server

## fltComputePhysicalUnidentified

### Fault Code

F0320

### Description

[sensor\_name]: server [id] Chassis Intrusion detected: Please secure the server chassis.

**Explanation**

This fault indicates that the server chassis or cover is open.

**Recommended Action**

Make sure that the server chassis/cover is in place.

**Fault Details**

**Severity:** warning

**Cause:** equipment-problem

**mibFaultCode:** 320

**mibFaultName:** fltComputePhysicalUnidentified

**moClass:** equipment: Chassis

**Type:** equipment

## fltEquipmentTpmTpmMismatch

**Fault Code**

F1783

**Description**

PM\_FAULT\_STATUS: Check TPM, either wrong TPM revision installed for CPU type or previously installed TPM has been removed.

**Explanation**

This fault indicates that a wrong TPM has been installed or a previously installed TPM has been removed.

**Recommended Action**

If you see this fault, take the following actions:

1. If an incorrect revision of the TPM has been installed, remove the TPM.
2. Install the correct revision of the TPM.
3. If the problem still persists, create a tech-support file and contact Cisco TAC.

**Fault Details**

**Severity:** warning

**Cause:** equipment-inoperable

**mibFaultCode:** 1783

**mibFaultName:** fltEquipmentTpmTpmMismatch

**Type:** equipment

## fltMgmtIfMissing

### Fault Code

F0717

### Description

Link Down : <Interface> Check the network cable connection

Here <Interface> can be one of the following:

- DEDICATED\_MODE\_<port>
- LOM\_ACTIVE\_STANDBY\_<port>
- LOM\_ACTIVE\_ACTIVE\_<port>
- CISCO\_CARD\_ACTIVE\_STANDBY\_<port>
- CISCO\_CARD\_ACTIVE\_ACTIVE\_<port>
- LOM10G\_ACTIVE\_STANDBY\_<port>
- LOM10G\_ACTIVE\_ACTIVE\_<port>
- LOM\_EXT\_MODE\_<port>

### Explanation

This fault indicates that the corresponding interface cable is not connected.

### Recommended Action

If you see this fault, take the following actions:

1. Check whether the interface cable is connected properly.
2. If the problem persists, create a tech-support file and contact Cisco TAC.

### Fault Details

**Severity:** info

**Cause:** link-missing

**mibFaultCode:** 717

**mibFaultName:** fltMgmtIfMissing

# fltPowerBudgetPowerBudgetBmcProblem

**Fault Code**

F0637

**Description**

Power capping failed: System shutdown is initiated by Node Manager.

**Explanation**

This fault indicates that the assigned power-cap value is not maintained. If the power-cap fail exception action is set as shutdown, then the host shut down is initiated.

**Recommended Action**

If you see this fault, take the following action:

1. Disable the corresponding power profile in the Power Cap Configuration page and power on the host.
2. Increase the power-cap value in the Power Cap profile page for which the shutdown action is configured.
3. If the assigned power-cap value needs to be maintained (irrespective of the host performance impact), reduce the load on the host.
4. If the problem still persists, create a tech-support file and contact Cisco TAC.

**Fault Details**

**Severity:** major

**Cause:** power-cap-fail

**mibFaultCode:** 637

**mibFaultName:** fltPowerBudgetPowerBudgetBmcProblem

**moClass:** compute:Board

**Type:** environmental

# fltPowerBudgetPowerBudgetCmcProblem

**Fault Code**

F0635

**Description**

Power capping correction time exceeded: Please set an appropriate power limit.

**Explanation**

This fault indicates that the assigned power-cap value is not attainable for the correction time set.

**Recommended Action**

If you see this fault, take the following actions:

1. Increase the power-cap value and the power limiting correction time in the corresponding power-profile settings.
2. If the problem still persists, create a tech-support file and contact Cisco TAC.

**Fault Details**

**Severity:** major

**Cause:** power-cap-fail

**mibFaultCode:** 635

**mibFaultName:** fltPowerBudgetPowerBudgetCmcProblem

**moClass:** compute:Board

**Type:** environmental