



## **Cisco UCS B420 M3 High Performance Blade Server Installation and Service Note**

[Cisco UCS B420 M3 High Performance Blade Server](#) 2

[Related Cisco UCS Documentation](#) 35

[Obtaining Documentation and Submitting a Service Request](#) 36

[Full Cisco Trademarks with Hardware License](#) ?


## Cisco UCS B420 M3 High Performance Blade Server

This document describes how to install and service the Cisco UCS B420 M3 High Performance Blade Server, a full-width blade server meaning up to four of these high-density, four-socket blade servers can reside in a Cisco UCS 5108 Blade Server chassis.

The B420 M3 Blade Server has the following features:

- Up to four Intel Xeon processor E5-4600 processor family CPUs, with up to 32 cores per server
- 48 DIMM slots for registered ECC DIMMs, with up to 1.5-TB memory capacity (using 32-GB LRDIMMs)
- 3 adapter connectors for up to 160-Gb/s bandwidth:
  - One dedicated connector for the Cisco VIC 1240 modular LAN-on-motherboard (mLOM)
  - Two connectors for Cisco the VIC 1280, VIC Port Expander, or third-party network adapter cards
- Four hot-plug drive bays that support SAS or SATA SSD drives
- LSI 2208R controller that provides RAID 0, 1, 5, and 10 with an optional 1-GB flash-backed write cache

**Figure 1: B420 M3 Blade Server Front Panel**



<b>1</b>	Drive bay 1	<b>8</b>	Power button and LED
<b>2</b>	Drive bay 2	<b>9</b>	Network link status LED
<b>3</b>	Drive bay 3	<b>10</b>	Blade health LED
<b>4</b>	Drive bay 4	<b>11</b>	Local console connection
<b>5</b>	Left ejector handle	<b>12</b>	Reset button access
<b>6</b>	Asset Tag Each server has a blank plastic tag that pulls out of the front panel so you can add your own asset tracking label without interfering with the intended air flow.	<b>13</b>	Beaconing button and LED
<b>7</b>	Right ejector handle		

## LEDs

Server LEDs indicate whether the blade server is in active or standby mode, the status of the network link, the overall health of the blade server, and whether the server is set to give a blinking blue locator light from the locator button.

The removable drives also have LEDs indicating hard disk access activity and disk health.

**Table 1: Blade Server LEDs**

LED	Color	Description
Power	Off	Power off.
	Green	Main power state. Power is supplied to all server components and the server is operating normally.
	Amber	Standby power state. Power is supplied only to the service processor of the server so that the server can still be managed.  <b>Note</b> The front-panel power button is disabled by default. It can be re-enabled through Cisco UCS Manager. After it's enabled, if you press and release the front-panel power button, the server performs an orderly shutdown of the 12 V main power and goes to standby power state. You cannot shut down standby power from the front-panel power button. See the Cisco UCS Manager Configuration Guides for information about completely powering off the server from the software interface.
Link	Off	None of the network links are up.
	Green	At least one network link is up.
Health	Off	Power off.
	Green	Normal operation.
	Amber	Minor error.
	Blinking Amber	Critical error.
Blue locator button and LED	Off	Blinking is not enabled.
	Blinking blue 1 Hz	Blinking to locate a selected blade—If the LED is not blinking, the blade is not selected. You can control the blinking in UCS Manager or by using the blue locator button/LED.

LED	Color	Description
Activity (Disk Drive) 	Off	Inactive.
	Green	Outstanding I/O to disk drive.
Health (Disk Drive)	Off	Can mean either no fault detected or the drive is not installed.
	Flashing Amber 4 hz	Rebuild drive active.  If the Activity LED is also flashing amber, a drive rebuild is in progress.
	Amber	Fault detected.

## Buttons

The Reset button is recessed in the front panel of the server. You can press the button with the tip of a paper clip or a similar item. Hold the button down for five seconds, and then release it to restart the server if other methods of restarting do not work.


The locator function for an individual server may get turned on or off by pressing the locator button/LED.

The front-panel power button is disabled by default. It can re-enabled through Cisco UCS Manager. After it's enabled, The power button allows you to manually take a server temporarily out of service but leave it in a state where it can be restarted quickly. If the desired power state for a service profile associated with a blade server is set to "off," using the power button or Cisco UCS Manager to reset the server will cause the desired power state of the server to become out of sync with the actual power state and the server may unexpectedly shut down at a later time. To safely reboot a server from a power-down state, use the Boot Server action in Cisco UCS Manager.

## Local Console Connection

The local console connector allows a direct connection to a blade server to allow operating system installation and other management tasks to be done directly rather than remotely. The port uses the KVM dongle cable that provides a connection into a Cisco UCS blade server; it has a DB9 serial connector, a VGA connector for a monitor, and dual USB ports for a keyboard and mouse. With this cable, you can create a direct connection to the operating system and the BIOS running on a blade server. A KVM cable ships standard with each blade chassis accessory kit.

**Figure 2: KVM Cable for Blade Servers**



<b>1</b>	Connector to blade server local console connection	<b>2</b>	DB9 serial connector
----------	--	----------	----------------------

<b>3</b>	VGA connector for a monitor	<b>4</b>	2-port USB connector for a mouse and keyboard
----------	-----------------------------	----------	---

## Drive Replacement

Each blade has up to four front-accessible, hot plug capable, 2.5-inch SAS or SATA drive bays. Unused hard drive bays should always be covered with cover plates to ensure proper cooling and ventilation.

You can remove and install hard drives without removing the blade server from the chassis.

The drives supported in this blade server come with the drive sled attached. Spare drive sleds are not available. A list of currently supported drives is in the specification sheets at this

URL:<http://www.cisco.com/c/en/us/products/servers-unified-computing/ucs-b-series-blade-servers/datasheet-listing.html>

Before upgrading or adding a drive to a running blade server, check the service profile in Cisco UCS Manager and make sure the new hardware configuration will be within the parameters allowed by the service profile.



---

**Caution** To prevent ESD damage, wear grounding wrist straps during these procedures.

---

### Removing a Blade Server Hard Drive


To remove a hard drive from a blade server, follow these steps:

#### Procedure

---

- Step 1** Push the button to release the ejector, and then pull the hard drive from its slot.
- Step 2** Place the hard drive on an antistatic mat or antistatic foam if you are not immediately reinstalling it in another server.
- Step 3** Install a hard disk drive blank faceplate to keep dust out of the blade server if the slot will remain empty.

**Figure 3: Removing and Installing a Drive**



---

## Installing a Blade Server Drive

To install a drive in a blade server, follow these steps:

### Procedure

- 
- Step 1** Place the drive ejector into the open position by pushing the release button.
  - Step 2** Gently slide the drive into the opening in the blade server until it seats into place.
  - Step 3** Push the drive ejector into the closed position.

You can use Cisco UCS Manager to format and configure RAID services. For details, see the *Configuration Guide* for the version of Cisco UCS Manager that you are using. The configuration guides are available at the following URL:

[http://www.cisco.com/en/US/products/ps10281/products\\_installation\\_and\\_configuration\\_guides\\_list.html](http://www.cisco.com/en/US/products/ps10281/products_installation_and_configuration_guides_list.html)

If you need to move a RAID cluster, see the [Cisco UCS Manager Troubleshooting Reference Guide](#).

---

## Basic Troubleshooting: Reseating a SAS/SATA Drive

Sometimes it is possible for a false positive UBAD error to occur on SAS/SATA HDDs installed in the server.

- Only drives that are managed by the UCS MegaRAID controller are affected.
- Drives can be affected regardless where they are installed in the server (front-loaded, rear-loaded, and so on).
- Both SFF and LFF form factor drives can be affected.
- Drives installed in all Cisco UCS C-Series servers with M3 processors and later can be affected.
- Drives can be affected regardless of whether they are configured for hotplug or not.
- The UBAD error is not always terminal, so the drive is not always defective or in need of repair or replacement. However, it is also possible that the error is terminal, and the drive will need replacement.

**Before submitting the drive to the RMA process**, it is a best practice to reseat the drive. If the false UBAD error exists, reseating the drive can clear it. If successful, reseating the drive reduces inconvenience, cost, and service interruption, and optimizes your server uptime.



---

**Note** Reseat the drive only if a UBAD error occurs. Other errors are transient, and you should not attempt diagnostics and troubleshooting without the assistance of Cisco personnel. Contact Cisco TAC for assistance with other drive errors.

---

To reseat the drive, see [Reseating a SAS/SATA Drive, on page 7](#).

### Reseating a SAS/SATA Drive

Sometimes, SAS/SATA drives can throw a false UBAD error, and reseating the drive can clear the error.

Use the following procedure to reseat the drive.



---

**Caution** This procedure might require powering down the server. Powering down the server will cause a service interruption.

---

### Before you begin

Before attempting this procedure, be aware of the following:

- Before reseating the drive, it is a best practice to back up any data on it.
- When reseating the drive, make sure to reuse the same drive bay.
  - Do not move the drive to a different slot.
  - Do not move the drive to a different server.
  - If you do not reuse the same slot, the Cisco management software (for example, Cisco IMM) might require a rescan/rediscovery of the server.
- When reseating the drive, allow 20 seconds between removal and reinsertion.

## Procedure

---

**Step 1** Attempt a hot reset of the affected drive(s). Choose the appropriate option.

**Note** While the drive is removed, it is a best practice to perform a visual inspection. Check the drive bay to ensure that no dust or debris is present. Also, check the connector on the back of the drive and the connector on the inside of the server for any obstructions or damage.

Also, when reseating the drive, allow 20 seconds between removal and reinsertion.

**Step 2** During boot up, watch the drive's LEDs to verify correct operation.

See [LEDs](#).

**Step 3** If the error persists, cold reset the drive, which requires a server power down. Choose the appropriate option:

a) Use your server management software to gracefully power down the server.

See the appropriate Cisco management software documentation.

b) If server power down through software is not available, you can power down the server by pressing the power button.

See [Buttons](#).

c) Reseat the drive as documented in Step 1.

d) When the drive is correctly reseated, restart the server, and check the drive LEDs for correct operation as documented in Step 2.

**Step 4** If hot and cold reseating the drive (if necessary) does not clear the UBAD error, choose the appropriate option:

a) Contact Cisco Systems for assistance with troubleshooting.

b) Begin an RMA of the errored drive.

---

## Blade Server Removal and Installation

Before performing any internal operations on this blade server, you must remove it from the chassis.



---

**Caution** To prevent ESD damage, wear grounding wrist straps during these procedures and handle modules by the carrier edges only.

---

### Powering Off a Blade Server Using the Power Button



---

**Note** The front panel power button is disabled by default to ensure that servers are decommissioned through the UCS management software interface before shutdown. If you prefer to shut down the server locally with the button, you can enable front power-button control in the UCS management software interface.

---



---

**Tip** You can also shut down servers remotely using the UCS management software interface. For details, see the configuration guide for the version the UCS management software interface that you are using. The configuration guides are available at the URLs documented in [Server Configuration, on page 34](#).

---

## Procedure

---

- Step 1** If you are local to the server, check the color of the **Power Status** LED for each server in the chassis that you want to power off.
- Green indicates that the server is running and must be shut down before it can be safely powered off. Go to Step 2.
  - Amber indicates that the server is already in standby mode and can be safely powered off. Go to Step 3.
- Step 2** If you previously enabled front power-button control through the UCS management software interface, press and release the **Power** button, then wait until the **Power Status** LED changes to amber.
- The operating system performs a graceful shutdown, and the server goes to standby mode.
- Caution** To avoid data loss or damage to your operating system, you should always invoke a graceful shutdown of the operating system.
- Step 3** (Optional) Although not recommended, if you are shutting down all blade servers in a chassis, you can disconnect the power cords from the chassis to completely power off the servers.
- Caution** To avoid data loss or damage to your operating system, you should always invoke a graceful shutdown of the operating system.

---

The blade servers will power down. You can now perform additional tasks with the blades as needed, for example, replacing a blade.

## Removing a Blade Server

You must decommission the server using Cisco UCS Manager before physically removing the blade server.

## Procedure

---

- Step 1** Turn off the blade server using either Cisco UCS Manager.
- Step 2** Completely loosen the captive screws on the front of the blade.
- Step 3** Remove the blade from the chassis by pulling the ejector levers on the blade until it unseats the blade server.
- Step 4** Slide the blade part of the way out of the chassis, and place your other hand under the blade to support its weight.
- Step 5** Once removed, place the blade on an antistatic mat or antistatic foam if you are not immediately reinstalling it.
- Step 6** If the blade server slot is to remain empty, reinstall the slot divider and install two blade server blanking panels to maintain proper thermal temperatures and to keep dust out of the chassis.
-

## Installing a Blade Server

For installations of UCS blades with differing widths and heights in a chassis, the guideline is to load the heaviest and largest blades at the bottom of the chassis. Therefore, if a UCS B460 blade server is present, it should be installed at the bottom, followed by full-width blades such as the UCS B420 or UCS B480 above the UCS B460, and then half-width blades such as the UCS B200 at the top of the chassis.

### Before you begin


The blade server must have its cover installed before installing it into the chassis to ensure adequate airflow.

### Procedure

---

- Step 1** If necessary, remove the slot divider from the chassis.
- Simultaneously pull up on the left side catch and push down on the right side catch as shown in callout 1 of the following figure.
  - Pull the slot divider out of the chassis as shown in callout 2 of the following figure. Keep the slot divider in case it is needed at another time.


**Figure 4: Removing a Slot Divider**



**Tip** To reinstall the slot divider, align it with the dimples in the slot top and bottom and slide it back in until it clicks into place.

- Step 2** Grasp the front of the blade server and place your other hand under the blade to support it.

**Figure 5: Positioning a Blade Server in the Chassis**



**Step 3** Open the ejector levers in the front of the blade server.

**Step 4** Gently slide the blade into the opening until you cannot push it any farther.

**Step 5** Press the ejectors so that they catch the edge of the chassis and press the blade server all the way in.

**Step 6** Tighten the captive screw on the front of the blade to no more than 3 in-lbs. Tightening only with bare fingers is unlikely to lead to stripped or damaged captive screws.

Cisco UCS Manager automatically reacknowledges, reassociates, and recommissions the server, provided any hardware changes are allowed by the service profile.

---

## Secure Digital Cards

Secure Digital (SD) card slots are provided and one or two SD cards can be populated. If two SD cards are populated, they can be used in a mirrored mode.



---

**Note** Do not mix different capacity cards in the same server.

---



---

**Note** Due to technical limitations, if the server is running a Cisco UCS Manager version earlier than release 2.2(3a) with the 32-GB SD card, only 16-GB usable capacity is available (regardless of mirroring) in the server.

---

**Figure 6: SD Card Slots**


## Removing a Blade Server Cover

### Procedure

---




Figure 8: Cisco UCS B420 Air Baffles



## Internal Components

Figure 9: Inside View of the Blade Server



1	Hard drive bay 1	2	Drive bay 2
3	Hard drive bay 3	4	Drive bay 4
5	CMOS battery	6	Internal USB connector  Cisco UCS-USBFLSH-S-4GB= is recommended, but if you use another USB drive it must be no wider than 0.8 inches (20 mm), and no more than 1.345 inches (34 mm) long in order to provide needed clearances to install or remove the USB drive. Third-party USB flash memory is allowed but not subject to support by Cisco and is at the user's risk.
7	Diagnostics Button	8	Transferable Flash-backed Write Cache Module (TFM) for flash-backed write cache  The flash-backed write cache feature is not supported at the initial server release.
9	DIMM slots for CPU 1	10	DIMM slots for CPU 2
11	DIMM slots for CPU 3	12	DIMM slots for CPU 4

<b>13</b> mLOM card This slot is shown in Cisco UCS Manager as “Adapter 1” but the BIOS lists it as “mLOM.” The VIC 1240 is a type of adapter with a specific footprint that can only be used in this slot.	<b>14</b> Adapter card This slot is shown in Cisco UCS Manager as “Adapter 2,” but is shown in the BIOS as “Mezz 1.” Mixing adapter types is supported.
<b>15</b> Supercap for flash-backed write cache The flash-backed write cache feature is not supported at the initial server release.	<b>16</b> Adapter card This slot is shown in Cisco UCS Manager as “Adapter 3,” but it is shown in the BIOS as “Mezz 2.” Mixing adapter types is supported.



**Note**

- A squeeze-to-remove retaining clip is provided to secure the internal USB flash memory, the clip must always be securely fastened when the flash memory is in use. Third party memory that will not fit in the clip should not be used.
- Use of this server may require an upgrade to the FEX in the chassis. The 2104XP fabric extender is not compatible when any Cisco-certified adapter is installed in slot 1 or slot 2. If a VIC 1240 modular LOM card is installed, you will have connectivity through the mLOM but other adapters will not be recognized.

## Diagnostics Button and LEDs

At blade start-up, POST diagnostics test the CPUs, DIMMs, HDDs, and rear mezzanine modules, and any failure notifications are sent to Cisco UCS Manager. You can view these notifications in the Cisco UCS Manager System Error Log or in the output of the **show tech-support** command. If errors are found, an amber diagnostic LED also lights up next to the failed component. During run time, the blade BIOS and component drivers monitor for hardware faults and will light up the amber diagnostic LED as needed.

LED states are saved, and if you remove the blade from the chassis the LED values will persist for up to 10 minutes. Pressing the LED diagnostics button on the motherboard causes the LEDs that currently show a component fault to light for up to 30 seconds for easier component identification. LED fault values are reset when the blade is reinserted into the chassis and booted, and the process begins from its start.

If DIMM insertion errors are detected, they may cause the blade discovery process to fail and errors will be reported in the server POST information, which is viewable using the UCS Manager GUI or CLI. DIMMs must be populated according to specific rules. The rules depend on the blade server model. Refer to the documentation for a specific blade server for those rules.

Faults on the DIMMs or rear mezzanine modules also cause the server health LED to light solid amber for minor error conditions or blinking amber for critical error conditions.

## Working Inside the Blade Server

### Installing a CMOS Battery

All Cisco UCS blade servers use a CR2032 battery to preserve BIOS settings while the server is not installed in a powered-on chassis. Cisco supports the industry standard CR2032 battery that is available at most electronics stores.



**Warning**

There is danger of explosion if the battery is replaced incorrectly. Replace the battery only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer’s instructions.

To install or replace the battery, follow these steps:

## Procedure

---

- Step 1** Remove the existing battery:
- Power off the blade, remove it from the chassis, and remove the top cover.
  - Push the battery socket retaining clip away from the battery.
  - Lift the battery from the socket. Use needle-nose pliers to grasp the battery if there is not enough clearance for your fingers.
- Step 2** Install the replacement battery:
- Push the battery socket retaining clip away from where the battery fits in the housing.
  - Insert the new battery into the socket with the battery's positive (+) marking facing away from the retaining clip. Ensure that the retaining clip can click over the top of the battery to secure it in the housing.
  - Replace the top cover.
  - Replace the blade server in the chassis.
- 

## Removing a CPU and Heat Sink

You will use these procedures to move a CPU from one server to another, to replace a faulty CPU, or to upgrade from one CPU to another.




- Caution** The Pick-and-Place tools used in this procedure are required to prevent damage to the contact pins between the motherboard and the CPU. Do not attempt this procedure without the required tools. If you do not have the tool, you can order a spare.
- UCS-CPU-EP-PNP=; Pick n place CPU tools for M3/EP 10/8/6/4/2 core CPUs (Green)
  - UCS-CPU-EP2-PNP=; Pick n place CPU tools for M3/EP v2 12 core CPUs (Purple)
- 

## Procedure

---

- Step 1** Unscrew the four captive screws securing the heat sink to the motherboard.  
Loosen one screw by a quarter turn, then move to the next screw. Continue loosening until the heat sink can be lifted off.
- Step 2** Remove the heat sink.  
Remove the existing thermal compound from the bottom of the heat sink using the cleaning kit included with each CPU option kit. Follow the instructions on the two bottles of cleaning solvent.
- Step 3** Unhook the first socket hook, which has the following icon:  See callout 3 in the following figure.
- Step 4** Unhook the second socket hook, which has the following icon:  See callout 4 in the following figure.
- Step 5** Open the socket latch.

**Figure 10: Removing the Heat Sink and Accessing the CPU Socket**




**Step 6** Press the central button on the CPU Pick-and-Place tool to release the catch.

**Step 7** Remove an old CPU as follows:

- a) Place the CPU Pick-and-Place tool on the CPU socket aligned with the arrow pointing to the CPU registration mark.
- b) Press the button/handle on the tool to grasp the installed CPU.
- c) Lift the tool and CPU straight up.

**Figure 11: Proper Alignment of CPU Pick-and-Place Tool**



<b>1</b>	Alignment mark on the button/handle of the Pick-and-Place tool	<b>2</b>	Alignment mark on the socket
----------	--	----------	------------------------------

## Installing a New CPU and Heat Sink

Before installing a new CPU in a server, verify the following:

- The CPU is supported for that given server model. Refer to the Specification Sheet for this server to see the list of supported CPUs. The Specification Sheets are available at this URL: <http://www.cisco.com/c/en/us/products/servers-unified-computing/ucs-b-series-blade-servers/datasheet-listing.html>
- A BIOS update is available and installed that supports the CPU and the given server configuration.
- If the server will be managed by Cisco UCS Manager, the service profile for this server in Cisco UCS Manager will recognize and allow the new CPU.




**Caution** The Pick-and-Place tools used in this procedure are required to prevent damage to the contact pins between the motherboard and the CPU. Do not attempt this procedure without the required tools. If you do not have the tool, you can order a spare.

- UCS-CPU-EP-PNP=; Pick n place CPU tools for M3/EP 10/8/6/4/2 core CPUs (Green)
- UCS-CPU-EP2-PNP=; Pick n place CPU tools for M3/EP v2 12 core CPUs (Purple)

## Procedure

**Step 1** Required: To install a CPU in an empty socket, remove the protective cap that is intended to prevent bent or touched contact pins. The pick and pull cap tool provided can be used in a manner similar to a pair of tweezers. Grasp the protective cap and pivot as shown.

**Figure 12: Protective Cap Removal**




**Step 2** Release the catch on the pick and pull tool by pressing the handle/button.

**Step 3** Remove the new CPU from the packaging, and load it into the pick and place tool as follows:

- a) Confirm that the pedestal is set up correctly for your processor. The pedestal ships configured with the markings “LGA2011-R1” facing upward, and this is the correct orientation.
- b) Place the CPU on the pedestal. The CPU corners should fit snugly at the pedestal corners and the notches should meet the pegs perfectly.
- c) Place the CPU pick and place tool on the CPU pedestal aligned with the A1 arrow pointing to the A1 registration mark on the pedestal.
- d) Press the button/handle on the tool to grasp the CPU.
- e) Lift the tool and CPU straight up off of the pedestal.

**Figure 13: Loading the Pick and Place Tool**




<b>1</b>	Alignment mark on the pick and place tool, CPU and pedestal
----------	---

**Step 4** Place the CPU and tool on the CPU socket with the registration marks aligned as shown.

**Step 5** Press the button/handle on the pick and place tool to release the CPU into the socket.

**Figure 14: Using the CPU Pick and Place Tool to Insert the CPU**




<b>1</b>	Alignment mark on the tool button/handle	<b>2</b>	Alignment mark on the CPU socket
----------	--	----------	----------------------------------

**Step 6** Close the socket latch. See callout 1 in the following figure.

**Step 7** Secure the first hook, which has the following icon:  See callout 2 in the following figure.

**Step 8** Secure the second hook, which has the following icon:  See callout 3 in the following figure.

**Figure 15: Replacing the Heat Sink (B200 M3 Shown)**




**Step 9** Using the syringe of thermal grease provided with replacement CPUs and servers, add 2 cubic centimeters of thermal grease to the top of the CPU where it will contact the heat sink. Use the pattern shown. This should require half the contents of the syringe.

**Caution** The thermal grease has very specific thermal properties. Thermal grease from other sources should not be substituted because it may lead to damage.

**Note** CPU spares come with two syringes of thermal grease; one with a blue cap and one with a red cap. The syringe with the blue cap is used with this server.

**Figure 16: Thermal Grease Application Pattern**



**Step 10** Replace the heat sink. See callout 4.

**Caution** On certain models, heat sinks are keyed to fit into the plastic baffle extending from the motherboard. Do not force a heat sink if it is not fitting well, rotate it and re-orient the heat sink.

**Step 11** Secure the heat sink to the motherboard by tightening the four captive screws a quarter turn at a time in an X pattern as shown in the upper right.

---

## Installing Memory

To install a DIMM into the blade server, follow these steps:

### Procedure

**Step 1** Press the DIMM into its slot evenly on both ends until it clicks into place.

DIMMs are keyed. If a gentle force is not sufficient, make sure the notch on the DIMM is correctly aligned.

**Note** Be sure that the notch in the DIMM aligns with the slot. If the notch is misaligned you may damage the DIMM, the slot, or both.

**Step 2** Press the DIMM connector latches inward slightly to seat them fully.

---

## Supported DIMMs


The DIMMs supported in this blade server are constantly being updated. A list of currently supported and available DIMMs is in the Cisco UCS B420 M3 specification sheet: [http://www.cisco.com/c/dam/en/us/products/collateral/servers-unified-computing/ucs-b-series-blade-servers/b420m3\\_specsheet.pdf](http://www.cisco.com/c/dam/en/us/products/collateral/servers-unified-computing/ucs-b-series-blade-servers/b420m3_specsheet.pdf).


Do not use any memory DIMMs other than those listed in the specification sheet. Doing so may irreparably damage the server and require an RMA and down time.

### **Memory Arrangement**

The Cisco UCS B420 high-performance blade server contains 48 slots for installing DIMMs—12 for each CPU. Each CPU has 12 DIMM slots spread over 4 channels. This blade server needs at least one DIMM attached to all populated CPUs. DIMMs installed in slots for an absent CPU will not be recognized. For optimal performance, distribute DIMMs evenly across all CPUs. DIMM connector latches are color coded blue, black, and white, and the DIMMs must be installed in that order.

Figure 17: Memory Slots Within the Blade Server





305429

<b>1</b>	DIMMs for CPU 1	<b>3</b>	DIMMs for CPU 3
<b>2</b>	DIMMs for CPU 2	<b>4</b>	DIMMs for CPU 4

### Channels

Each CPU has 4 channels, consisting of 3 DIMMs. Each channel is identified by a letter. Each channel member is identified by numbers, 0, 1 or 2.

The DIMM slots are contiguous to their associated CPU. When installing DIMMs, you must add them in the configurations shown in the following table.

**Table 2: UCS B420 M3 DIMM Slot Population**

DIMMs per CPU	Populate CPU 1 Slots	Populate CPU 2 Slots	Populate CPU 3 Slots	Populate CPU 4 Slots	Color Coding
1	A0	E0	I0	M0	Blue
2	A0, B0	E0, F0	I0, J0	M0, N0	Blue

<b>DIMMs per CPU</b>	<b>Populate CPU 1 Slots</b>	<b>Populate CPU 2 Slots</b>	<b>Populate CPU 3 Slots</b>	<b>Populate CPU 4 Slots</b>	<b>Color Coding</b>
3	A0, B0, C0	E0, F0, G0	I0, J0, K0	M0, N0, O0	Blue
4	A0, B0, C0, D0	E0, F0, G0, H0	I0, J0, K0, L0	M0, N0, O0, P0	Blue
5	Not recommended for performance reasons.				
6	A0, B0, C0, A1, B1, C1	E0, F0, G0, E1, F1, G1	I0, J0, K0, I1, J1, K1	M0, N0, O0, M1, N1, O1	Blue, Black
7	Not recommended for performance reasons.				
8	A0, B0, C0, D0, A1, B1, C1, D1	E0, F0, G0, H0, E1, F1, G1, H1	I0, J0, K0, L0, I1, J1, K1, L1	M0, N0, O0, P0, M1, N1, O1, P1	Blue, Black
9	A0, B0, C0, A1, B1, C1, A2, B2, C2	E0, F0, G0, E1, F1, G1, E2, F2, G2	I0, J0, K0, I1, J1, K1, I2, J2, K2	M0, N0, O0, M1, N1, O1, M2, N2, O2	Blue, Black White
10	Not recommended for performance reasons.				
11	Not recommended for performance reasons.				
12	A0, B0, C0, D0, A1, B1, C1, D1, A2, B2, C2, D2	E0, F0, G0, H0, E1, F1, G1, H1, E2, F2, G2, H2	I0, J0, K0, L0, I1, J1, K1, L1, I2, J2, K2, L2	M0, N0, O0, P0, M1, N1, O1, P1, M2, N2, O2, P2	Blue, Black White

Figure 18: Physical Representation of DIMMs and CPUs





Figure 19: Logical Representation of Channels



## Memory Performance

When configuring your server, consider the following:

- DIMMs within the blade can be of different speeds, but all DIMMs will run at the speed of the DIMM with the lowest speed.
- No mixing of DIMM type (LRDIMM, RDIMM, TSV-RDIMM) is allowed.
- Your selected CPU(s) can have some affect on performance. CPUs used must be of the same type.
- Mixing DIMM ranks and densities can lower performance.
- Unevenly populating DIMMs between CPUs can lower performance.

### Bandwidth and Performance

You can achieve maximum bandwidth, performance, and system memory by using the following configuration:

- DDR3, 1600 millions of transfers per second (MT/s) across four Channels
- 12 DIMMs per CPU (48 DIMMs total)
- Maximum capacity of 1536 GB (using 32-GB DIMMs)

Performance is less than optimal if the following memory configurations are used:

- Mixing DIMM sizes and densities
- Unevenly populating DIMMs between CPUs

Depending on the application needed, performance loss might or might not be noticeable or measurable.

### Installing a Virtual Interface Card Adapter



---

**Note** You must remove the adapter card to service it.

---


To install a Cisco VIC 1340 or VIC 1240 in the blade server, follow these steps:

#### Procedure

---

- Step 1** Position the VIC board connector above the motherboard connector and align the captive screw to the standoff post on the motherboard.
- Step 2** Firmly press the VIC board connector into the motherboard connector.
- Step 3** Tighten the captive screw.
- Tip** To remove a VIC, reverse the above procedure. You might find it helpful when removing the connector from the motherboard to gently rock the board along the length of the connector until it loosens.

**Figure 20: Installing a VIC mLOM Adapter**



---

## Installing an Adapter Card

All the supported mezzanine cards have a common installation process. These cards are updated frequently. Currently supported cards and the available models for this server are listed in the specification sheets at this URL:

<http://www.cisco.com/c/en/us/products/servers-unified-computing/ucs-b-series-blade-servers/datasheet-listing.html>

If you are switching from one type of adapter card to another, before you physically perform the switch make sure that you download the latest device drivers and load them into the server's operating system. For more information, see the firmware management chapter of one of the Cisco UCS Manager software configuration guides.

Adapter cards can be installed in either slot 1 or slot 2; they can be of the same type or a mixed configuration.



---

**Note** Cisco UCS Manager will recognize adapters in these slots as “Adapter 2” and “Adapter 3,” and counts the mLOM as being “Adapter 1.” This does not match the markings on the motherboard.

---

### Procedure

---


**Step 1** Position the adapter board connector above the motherboard connector and align the two adapter captive screws to the standoff posts (see callout 1) on the motherboard.

**Step 2** Firmly press the adapter connector into the motherboard connector (see callout 2).

**Step 3** Tighten the two captive screws (see callout 3).

**Tip** Removing an adapter card is the reverse of installing it. You might find it helpful when removing the connector from the motherboard to gently rock the board along the length of the connector until it loosens.

*Figure 21: Installing an Adapter Card*



---

## Installing the Flash-Backed Write Cache and Supercap

The Flash-backed Write Cache (FBWC) is an intelligent backup solution that protects disk write cache data during a long term power loss on the RAID controller. It has two components, the TFM memory and the Supercap module, which provides emergency power. The TFM installs into a dedicated slot, but the installation steps are identical to installing a DIMM. The flash-backed write cache feature and its components are not supported at the initial server release.


Verify whether replacement is required by using the **show raid-battery detail** command in the CLI.

To install the Supercap module, follow these steps:

## Procedure

- 
- Step 1** Using Cisco UCS Manager, perform a graceful shutdown of the server. Without a graceful shutdown, data can be permanently lost.
  - Step 2** Remove the server from the chassis.
  - Step 3** Remove the top cover from the server.
  - Step 4** Remove the adapter in slot 2.
  - Step 5** With a No.1 Phillips screwdriver, remove the four screws holding the top plate of the Supercap's enclosure.
  - Step 6** Angle the top plate up and remove the tabs from the slots at the rear. Set the plate aside.
  - Step 7** Press the clip at the end of the Supercap's wires into the clip attached to the enclosure.
  - Step 8** Place the Supercap inside the enclosure.
  - Step 9** Slide the tabs on the top plate into the slots at the rear of the Supercap enclosure.
  - Step 10** With a No.1 Phillips screwdriver, replace the four screws and attach the top plate to the enclosure as shown below.
  - Step 11** Replace the adapter, top cover, and the server in the chassis. Cisco UCS Manager reestablishes management of the server and the service profile.

**Figure 22: Supercap Installation**



---

## Installing and Enabling a Trusted Platform Module

The Trusted Platform Module (TPM) is a component that can securely store artifacts used to authenticate the server. These artifacts can include passwords, certificates, or encryption keys. A TPM can also be used to store platform measurements that help ensure that the platform remains trustworthy. Authentication (ensuring that the platform can prove that it is what it claims to be) and attestation (a process helping to prove that a platform is trustworthy and has not been breached) are necessary steps to ensure safer computing in all environments. It is a requirement for the Intel Trusted Execution Technology (TXT) security feature, which must be enabled in the BIOS settings for a server equipped with a TPM.



---

**Note** TPM installation is supported after-factory. However, a TPM installs with a one-way screw and cannot be replaced or moved to another server. If a server with a TPM is returned, the replacement server must be ordered with a new TPM.


---

### Procedure

---

- Step 1** Install the TPM hardware.
- Power off, decommission, and remove the blade server from the chassis.
  - Remove the blade server cover.
  - Install the TPM to the TPM socket on the server motherboard and secure it using the one-way screw that is provided. See the figure below for the location of the TPM socket.
  - Return the blade server to the chassis, power it on, and allow it to be automatically reacknowledged, reassociated, and recommissioned.
  - Continue with enabling TPM support in the server BIOS in the next step.

**Figure 23: TPM Socket Location**



<b>1</b>	Front of server	<b>2</b>	TPM socket on motherboard
----------	-----------------	----------	---------------------------

- Step 2** Enable TPM Support in the BIOS.
- a) Enable **Quiet Mode** in the BIOS policy of the server's service profile.
  - b) Establish a direct connection to the server, either by connecting a keyboard, monitor, and mouse to the front panel using a KVM dongle (N20-BKVM) or by other means.
  - c) Reboot the server.
  - d) Press **F2** during reboot to enter the BIOS setup screens.
  - e) On the **Advanced** tab, select **Trusted Computing** and press **Enter** to open the TPM Security Device Configuration window.
  - f) Set the TPM Support option to **Enabled**.
  - g) Press **F10** to save and exit. Allow the server to reboot, but watch for the prompt to press F2 in the next step.
- Step 3** Enable TPM State in the BIOS.
- a) Press **F2** during reboot to enter the BIOS setup screens.
  - b) On the **Advanced** tab, select **Trusted Computing** and press **Enter** to open the TPM Security Device Configuration window.
  - c) Set the TPM State option to **Enabled**.
  - d) Press **F10** to save and exit. Allow the server to reboot, but watch for the prompt to press F2 in the next step.
- Step 4** Verify that TPM Support and TPM State are enabled.
- a) Press **F2** during reboot to enter the BIOS setup screens.
  - b) On the **Advanced** tab, select **Trusted Computing** and press **Enter** to open the TPM Security Device Configuration window.
  - c) Verify that TPM Support and TPM State are set to **Enabled**.
  - d) Continue with enabling the Intel TXT feature in the next step.
- Step 5** Enable the Intel TXT feature in the BIOS.
- a) Choose the **Advanced** tab.
  - b) Choose **Intel TXT (LT-SX) Configuration** to open the Intel TXT (LT-SX) Hardware Support window.
  - c) Set TXT Support to **Enabled**.
  - d) Verify that the following items are listed as Enabled:
    - VT Support (default is Enabled)
    - VT-d Support (default is Enabled)
    - TPM Support
    - TPM State
- If VT Support and VT-d Support are not enabled, return to the **Advanced** tab, select **Processor Configuration**, and then set Intel (R) VT and Intel (R) VT-d to **Enabled**.
- e) Press **F10** to save and exit.

---

## Server Troubleshooting

For general troubleshooting information, see the [Cisco UCS Manager Troubleshooting Reference Guide](#).

## Server Configuration

Cisco UCS blade servers can be configured and managed using the following UCS management software interfaces.

### Cisco Intersight Managed Mode

Cisco UCS blade servers can be configured and managed using the Cisco Intersight management platform in Intersight Managed Mode (Cisco Intersight Managed Mode). For details, see the *Cisco Intersight Managed Mode Configuration Guide*, which is available at the following URL: [https://www.cisco.com/c/en/us/td/docs/unified\\_computing/Intersight/b\\_Intersight\\_Managed\\_Mode\\_Configuration\\_Guide.html](https://www.cisco.com/c/en/us/td/docs/unified_computing/Intersight/b_Intersight_Managed_Mode_Configuration_Guide.html)

### Cisco UCS Manager

Cisco UCS blade servers can be configured and managed using Cisco UCS Manager. For details, see the *Configuration Guide* for the version of Cisco UCS Manager that you are using. The configuration guides are available at the following URL: [http://www.cisco.com/en/US/products/ps10281/products\\_installation\\_and\\_configuration\\_guides\\_list.html](http://www.cisco.com/en/US/products/ps10281/products_installation_and_configuration_guides_list.html)

## Physical Specifications for the Cisco UCS B420 M3

Specification	Value
Height	1.95 inches (50 mm)
Width	16.50 inches (419.1 mm)
Depth	24.4 inches (620 mm)
Weight	34.5 lbs (15.65 kg)  The system weight listed here is an estimate for a fully configured system and will vary depending on peripheral devices installed.

# Related Cisco UCS Documentation

## Documentation Roadmaps

For a complete list of all B-Series documentation, see the *Cisco UCS B-Series Servers Documentation Roadmap* available at the following URL: [https://www.cisco.com/c/en/us/td/docs/unified\\_computing/ucs/overview/guide/UCS\\_roadmap.html](https://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/overview/guide/UCS_roadmap.html)

For a complete list of all C-Series documentation, see the *Cisco UCS C-Series Servers Documentation Roadmap* available at the following URL: [https://www.cisco.com/c/en/us/td/docs/unified\\_computing/ucs/overview/guide/ucs\\_rack\\_roadmap.html](https://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/overview/guide/ucs_rack_roadmap.html).

For information on supported firmware versions and supported UCS Manager versions for the rack servers that are integrated with the UCS Manager for management, refer to [Release Bundle Contents for Cisco UCS Software](#).

# Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly [What's New in Cisco Product Documentation](#), which also lists all new and revised Cisco technical documentation.

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.

Follow [Cisco UCS Docs on Twitter](#) to receive document update notifications.

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The following information is for FCC compliance of Class A devices: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to correct the interference at their own expense.

The following information is for FCC compliance of Class B devices: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment causes interference to radio or television reception, which can be determined by turning the equipment off and on, users are encouraged to try to correct the interference by using one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications to this product not authorized by Cisco could void the FCC approval and negate your authority to operate the product.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2012–2016 Cisco Systems, Inc. All rights reserved.



**Americas Headquarters**  
Cisco Systems, Inc.  
San Jose, CA 95134-1706  
USA

**Asia Pacific Headquarters**  
CiscoSystems(USA)Pte.Ltd.  
Singapore

**Europe Headquarters**  
CiscoSystemsInternationalBV  
Amsterdam,TheNetherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).