



## Directly Upgrading Firmware at Endpoints

---

This chapter includes the following sections:

- [Direct Firmware Upgrade at Endpoints, page 1](#)
- [Updating and Activating the Firmware on an Adapter, page 4](#)
- [Updating and Activating the BIOS Firmware on a Server, page 7](#)
- [Updating and Activating the CIMC Firmware on a Server, page 8](#)
- [Updating and Activating the Firmware on an IOM, page 11](#)
- [Activating the Board Controller Firmware on a Cisco UCS B-Series M2 Blade Server, page 13](#)
- [Activating the Board Controller Firmware on Cisco UCS B-Series M3 and M4 Blade Servers, page 14](#)
- [Activating the Board Controller Firmware on a Cisco UCS C-Series M3 and M4 Rack Servers, page 15](#)
- [Activating the Cisco UCS Manager Software, page 17](#)
- [Activating the Firmware on a Fabric Interconnect, page 17](#)
- [Forcing a Fabric Interconnect Failover, page 18](#)

## Direct Firmware Upgrade at Endpoints

If you follow the correct procedure and apply the upgrades in the correct order, a direct firmware upgrade and the activation of the new firmware version on the endpoints is minimally disruptive to traffic in a Cisco UCS domain.

You can directly upgrade the firmware on the following endpoints:

- Adapters
- CIMCs
- I/O modules
- Board controllers
- Cisco UCS Manager

- Fabric interconnects

The adapter and board controller firmware can also be upgraded through the host firmware package in the service profile. If you use a host firmware package to upgrade this firmware, you can reduce the number of times a server needs to be rebooted during the firmware upgrade process.

**Note**


---

Upgrades of a CIMC through a management firmware package or an adapter through a firmware package in the service profile associated with the server take precedence over direct firmware upgrades. You cannot directly upgrade an endpoint if the service profile associated with the server includes a firmware package. To perform a direct upgrade, you must remove the firmware package from the service profile.

---

## Stages of a Direct Firmware Upgrade

Cisco UCS Manager separates the direct upgrade process into two stages to ensure that you can push the firmware to an endpoint while the system is running without affecting uptime on the server or other endpoints.

### Update

During this stage, the system copies the selected firmware version from the primary fabric interconnect to the backup partition in the endpoint and verifies that the firmware image is not corrupt. The update process always overwrites the firmware in the backup slot.

The update stage applies only to the following endpoints:

- Adapters
- CIMCs
- I/O modules

**Caution**


---

Do not remove the hardware that contains the endpoint or perform any maintenance on it until the update process has completed. If the hardware is removed or otherwise unavailable due to maintenance, the firmware update fails. This failure may corrupt the backup partition. You cannot update the firmware on an endpoint with a corrupted backup partition.

---

### Activate

During this stage, the system sets the specified image version (normally the backup version) as the startup version and, if you do not specify **Set Startup Version Only**, immediately reboots the endpoint. When the endpoint is rebooted, the backup partition becomes the active partition, and the active partition becomes the backup partition. The firmware in the new active partition becomes the startup version and the running version.

The following endpoints only require activation because the specified firmware image already exists on the endpoint:

- Cisco UCS Manager
- Fabric interconnects
- Board controllers on those servers that support them

When the firmware is activated, the endpoint is rebooted and the new firmware becomes the active kernel version and system version. If the endpoint cannot boot from the startup firmware, it defaults to the backup version and raises a fault.

**Caution**

When you configure **Set Startup Version Only** for an I/O module, the I/O module is rebooted when the fabric interconnect in its data path is rebooted. If you do not configure **Set Startup Version Only** for an I/O module, the I/O module reboots and disrupts traffic. In addition, if Cisco UCS Manager detects a protocol and firmware version mismatch between the fabric interconnect and the I/O module, Cisco UCS Manager automatically updates the I/O module with the firmware version that matches the firmware in the fabric interconnect and then activates the firmware and reboots the I/O module again.

## Outage Impacts of Direct Firmware Upgrades

When you perform a direct firmware upgrade on an endpoint, you can disrupt traffic or cause an outage in one or more of the endpoints in the Cisco UCS domain.

### Outage Impact of a Fabric Interconnect Firmware Upgrade

When you upgrade the firmware for a fabric interconnect, you cause the following outage impacts and disruptions:

- The fabric interconnect reboots.
- The corresponding I/O modules reboot.

### Outage Impact of a Cisco UCS Manager Firmware Upgrade

A firmware upgrade to Cisco UCS Manager causes the following disruptions:

- Cisco UCS Manager GUI—All users logged in to Cisco UCS Manager GUI are logged out and their sessions ended.  
Any unsaved work in progress is lost.
- Cisco UCS Manager CLI—All users logged in through telnet are logged out and their sessions ended.

### Outage Impact of an I/O Module Firmware Upgrade

When you upgrade the firmware for an I/O module, you cause the following outage impacts and disruptions:

- For a standalone configuration with a single fabric interconnect, data traffic is disrupted when the I/O module reboots. For a cluster configuration with two fabric interconnects, data traffic fails over to the other I/O module and the fabric interconnect in its data path.
- If you activate the new firmware as the startup version only, the I/O module reboots when the corresponding fabric interconnect is rebooted.
- If you activate the new firmware as the running and startup version, the I/O module reboots immediately.
- An I/O module can take up to ten minutes to become available after a firmware upgrade.

### Outage Impact of a CIMC Firmware Upgrade

When you upgrade the firmware for a CIMC in a server, you impact only the CIMC and internal processes. You do not interrupt server traffic. This firmware upgrade causes the following outage impacts and disruptions to the CIMC:

- Any activities being performed on the server through the KVM console and vMedia are interrupted.
- Any monitoring or IPMI polling is interrupted.

### Outage Impact of an Adapter Firmware Upgrade

If you activate the firmware for an adapter and do not configure the **Set Startup Version Only** option, you cause the following outage impacts and disruptions:

- The server reboots.
- Server traffic is disrupted.

## Updating and Activating the Firmware on an Adapter



#### Caution

Do not remove the hardware that contains the endpoint or perform any maintenance on it until the update process has completed. If the hardware is removed or otherwise unavailable due to maintenance, the firmware update fails. This failure may corrupt the backup partition. You cannot update the firmware on an endpoint with a corrupted backup partition.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	UCS-A# <b>scope adapter</b> <i>chassis-id / blade-id / adapter-id</i>	Enters chassis server adapter mode for the specified adapter.
<b>Step 2</b>	UCS-A /chassis/server/adapter # <b>show image</b>	Displays the available software images for the adapter.
<b>Step 3</b>	UCS-A /chassis/server/adapter # <b>update firmware</b> <i>version-num</i>	Updates the selected firmware version on the adapter.
<b>Step 4</b>	UCS-A /chassis/server/adapter # <b>commit-buffer</b>	(Optional) Commits the transaction.  Use this step only if you intend to use the <b>show firmware</b> command in Step 5 to verify that the firmware update completed successfully before activating the firmware in Step 6. You can skip this step and commit the <b>update-firmware</b> and <b>activate-firmware</b> commands in the same transaction; however, if the firmware update does not complete successfully, the firmware activation does not start.

	Command or Action	Purpose
		Cisco UCS Manager copies the selected firmware image to the backup memory partition and verifies that image is not corrupt. The image remains as the backup version until you explicitly activate it.
<b>Step 5</b>	UCS-A /chassis/server/adapter # <b>show firmware</b>	(Optional) Displays the status of the firmware update.  Use this step only if you want to verify that the firmware update completed successfully. The firmware update is complete when the update status is Ready. The CLI does not automatically refresh, so you may have to enter the <b>show firmware</b> command multiple times until the task state changes from Updating to Ready. Continue to Step 6 when the update status is Ready.
<b>Step 6</b>	UCS-A /chassis/server/adapter # <b>activate firmware</b> <i>version-num</i> <b>[set-startup-only]</b>	Activates the selected firmware version on the adapter.  Use the <b>set-startup-only</b> keyword if you want to move the activated firmware into the pending-next-boot state and not immediately reboot the server. The activated firmware does not become the running version of firmware on the adapter until the server is rebooted. You cannot use the <b>set-startup-only</b> keyword for an adapter in the host firmware package.
<b>Step 7</b>	UCS-A /chassis/server/adapter # <b>commit-buffer</b>	Commits the transaction.  If a server is not associated with a service profile, the activated firmware remains in the pending-next-boot state. Cisco UCS Manager does not reboot the endpoints or activate the firmware until the server is associated with a service profile. If necessary, you can manually reboot or reset an unassociated server to activate the firmware.
<b>Step 8</b>	UCS-A /chassis/server/adapter # <b>show firmware</b>	(Optional) Displays the status of the firmware activation.  Use this step only if you want to verify that the firmware activation completed successfully. The CLI does not automatically refresh, so you may have to enter the <b>show firmware</b> command multiple times until the task state changes from Activating to Ready.

The following example updates and activates the adapter firmware to version 2.2(1b) in the same transaction, without verifying that the firmware update and firmware activation completed successfully:

```
UCS-A# scope adapter 1/1/1
UCS-A# /chassis/server/adapter # show image
-----
Name                                     Type          Version      State
-----
ucs-m81kr-vic.2.2.1b.bin                 Adapter       2.2(1b)
Active
UCS-A# /chassis/server/adapter # update firmware 2.2(1b)
UCS-A# /chassis/server/adapter* # activate firmware 2.2(1b) set-startup-only
UCS-A# /chassis/server/adapter* # commit-buffer
UCS-A# /chassis/server/adapter #
```

The following example updates the adapter firmware to version 2.2(1b), verifies that the firmware update completed successfully before starting the firmware activation, activates the adapter firmware, and verifies that the firmware activation completed successfully:

```
UCS-A# scope adapter 1/1/1
UCS-A# /chassis/server/adapter # show image
Name                                                    Type                Version             State
-----
ucs-m81kr-vic.2.2.1b.bin                               Adapter             2.2(1b)
Active

UCS-A# /chassis/server/adapter # update firmware 2.2(1b)
UCS-A# /chassis/server/adapter* # commit-buffer
UCS-A# /chassis/server/adapter # show firmware
Adapter 1:
  Running-Vers: 2.1(2a)
  Package-Vers: 2.1(2a)B
  Update-Status: Updating
  Activate-Status: Ready

UCS-A# /chassis/server/adapter # show firmware
Adapter 1:
  Running-Vers: 2.1(2a)
  Package-Vers: 2.1(2a)B
  Update-Status: Ready
  Activate-Status: Ready

UCS-A# /chassis/server/adapter # activate firmware 2.2(1b)
Warning: When committed this command will reset the end-point
UCS-A# /chassis/server/adapter* # commit-buffer
UCS-A# /chassis/server/adapter # show firmware
Adapter 1:
  Running-Vers: 2.1(2a)
  Package-Vers: 2.1(2a)B
  Update-Status: Ready
  Activate-Status: Activating

UCS-A# /chassis/server/adapter # show firmware
Adapter 1:
  Running-Vers: 2.1(2a)
  Package-Vers: 2.1(2a)B
  Update-Status: Ready
  Activate-Status: Pending Next Boot

UCS-A# /chassis/server/adapter # exit
UCS-A# /chassis/server # cycle cycle-immediate
UCS-A# /chassis/server* # commit-buffer
UCS-A# /chassis/server # scope adapter 1
UCS-A# /chassis/server/adapter # show firmware
Adapter 1:
  Running-Vers: 2.2(1b)
  Package-Vers: 2.2(1b)B
  Update-Status: Ready
  Activate-Status: Ready
UCS-A# /chassis/server/adapter #
```

# Updating and Activating the BIOS Firmware on a Server



## Important

You can update and activate BIOS firmware on a server using the Cisco UCS Manager CLI on all M3 generation servers. The earlier servers do not support BIOS firmware update using the Cisco UCS Manager CLI.



## Caution

Do not remove the hardware that contains the endpoint or perform any maintenance on it until the update process has completed. If the hardware is removed or otherwise unavailable due to maintenance, the firmware update fails. This failure may corrupt the backup partition. You cannot update the firmware on an endpoint with a corrupted backup partition.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	UCS-A# <b>scope server</b> <i>chassis-id / blade-id</i>	Enters chassis server mode for the specified server.
<b>Step 2</b>	UCS-A /chassis/server # <b>scope bios</b>	Enters chassis server BIOS mode.
<b>Step 3</b>	UCS-A /chassis/server/bios # <b>show image</b>	Displays the available BIOS firmware images.
<b>Step 4</b>	UCS-A /chassis/server/bios # <b>update firmware</b> <i>version-num</i>	Updates the selected BIOS firmware for the server.
<b>Step 5</b>	UCS-A /chassis/server/bios # <b>commit-buffer</b>	(Optional) Commits the transaction.  Use this step only if you intend to use the <b>show firmware</b> command in Step 6 to verify that the firmware update completed successfully before activating the firmware in Step 7. You can skip this step and commit the <b>update-firmware</b> and <b>activate-firmware</b> commands in the same transaction; however, if the firmware update does not complete successfully, the firmware activation does not start.  Cisco UCS Manager copies the selected firmware image to the backup memory partition and verifies that image is not corrupt. The image remains as the backup version until you explicitly activate it.
<b>Step 6</b>	UCS-A /chassis/server/bios # <b>show firmware</b>	(Optional) Displays the status of the firmware update.  Use this step only if you want to verify that the firmware update completed successfully. The firmware update is complete when the update status is Ready. The CLI does not automatically refresh, so you may have to enter the <b>show firmware</b> command

	Command or Action	Purpose
		multiple times until the task state changes from Updating to Ready. Continue to Step 7 when the update status is Ready.
<b>Step 7</b>	UCS-A /chassis/server/bios # <b>activate firmware</b> <i>version-num</i>	Activates the selected server BIOS firmware version.
<b>Step 8</b>	UCS-A /chassis/server/bios # <b>commit-buffer</b>	Commits the transaction.
<b>Step 9</b>	UCS-A /chassis/bios # <b>show firmware</b>	(Optional) Displays the status of the firmware activation.  Use this step only if you want to verify that the firmware activation completed successfully. The CLI does not automatically refresh, so you may have to enter the <b>show firmware</b> command multiple times until the task state changes from Activating to Ready.

The following example updates and activates the BIOS firmware in the same transaction, without verifying that the firmware update and activation completed successfully:

```
UCS-A# scope server 1/1
UCS-A# /chassis/server # scope bios
UCS-A# /chassis/server/bios # show image
Name                                     Type          Version
-----
ucs-b230-m1-bios.B230.2.0.1.1.49.gbin  Server Bios   B230.2.0.1.1.49
ucs-b230-m1-bios.B230.2.0.2.0.00.gbin  Server Bios   B230.2.0.2.0.00

UCS-A# /chassis/server/bios # update firmware B230.2.0.2.0.00
UCS-A# /chassis/server/bios* # activate firmware B230.2.0.2.0.00
UCS-A# /chassis/server/bios* # commit-buffer
UCS-A# /chassis/server/bios #
```

## Updating and Activating the CIMC Firmware on a Server

The activation of firmware for a CIMC does not disrupt data traffic. However, it will interrupt all KVM sessions and disconnect any vMedia attached to the server.



### Caution

Do not remove the hardware that contains the endpoint or perform any maintenance on it until the update process has completed. If the hardware is removed or otherwise unavailable due to maintenance, the firmware update fails. This failure may corrupt the backup partition. You cannot update the firmware on an endpoint with a corrupted backup partition.



## Procedure

	Command or Action	Purpose
<b>Step 1</b>	UCS-A# <b>scope server</b> <i>chassis-id / blade-id</i>	Enters chassis server mode for the specified server.
<b>Step 2</b>	UCS-A /chassis/server # <b>scope cimc</b>	Enters chassis server CIMC mode.
<b>Step 3</b>	UCS-A /chassis/server/cimc # <b>show image</b>	Displays the available software images for the adapter.
<b>Step 4</b>	UCS-A /chassis/server/cimc # <b>update firmware</b> <i>version-num</i>	Updates the selected firmware version on the CIMC in the server.
<b>Step 5</b>	UCS-A /chassis/server/cimc # <b>commit-buffer</b>	<p>(Optional) Commits the transaction.</p> <p>Use this step only if you intend to use the <b>show firmware</b> command in Step 6 to verify that the firmware update completed successfully before activating the firmware in Step 7. You can skip this step and commit the <b>update-firmware</b> and <b>activate-firmware</b> commands in the same transaction; however, if the firmware update does not complete successfully, the firmware activation does not start.</p> <p>Cisco UCS Manager copies the selected firmware image to the backup memory partition and verifies that image is not corrupt. The image remains as the backup version until you explicitly activate it.</p>
<b>Step 6</b>	UCS-A /chassis/server/cimc # <b>show firmware</b>	<p>(Optional) Displays the status of the firmware update.</p> <p>Use this step only if you want to verify that the firmware update completed successfully. The firmware update is complete when the update status is Ready. The CLI does not automatically refresh, so you may have to enter the <b>show firmware</b> command multiple times until the task state changes from Updating to Ready. Continue to Step 7 when the update status is Ready.</p>
<b>Step 7</b>	UCS-A /chassis/server/cimc # <b>activate firmware</b> <i>version-num</i>	Activates the selected firmware version on the CIMC in the server.
<b>Step 8</b>	UCS-A /chassis/server/cimc # <b>commit-buffer</b>	Commits the transaction.
<b>Step 9</b>	UCS-A /chassis/server/cimc # <b>show firmware</b>	<p>(Optional) Displays the status of the firmware activation.</p> <p>Use this step only if you want to verify that the firmware activation completed successfully. The CLI does not automatically refresh, so you may have to enter the <b>show firmware</b> command multiple times until the task state changes from Activating to Ready.</p>

Command or Action	Purpose
-------------------	---------

The following example updates and activates the CIMC firmware to version 2.2(1b) in the same transaction, without verifying that the firmware update and firmware activation completed successfully:

```
UCS-A# scope server 1/1
UCS-A# /chassis/server # scope cimc
UCS-A# /chassis/server/cimc # show image
Name                                     Type                                     Version
-----
ucs-b200-m1-k9-cimc.2.2.1b.bin          CIMC                                     2.2 (1b)
ucs-b200-m3-k9-cimc.2.2.1b.bin          CIMC                                     2.2 (1b)
ucs-b22-m3-k9-cimc.2.2.1b.bin          CIMC                                     2.2 (1b)
...

UCS-A# /chassis/server/cimc # update firmware 2.2(1b)
UCS-A# /chassis/server/cimc* # activate firmware 2.2(1b) set-startup-only
UCS-A# /chassis/server/cimc* # commit-buffer
UCS-A# /chassis/server/cimc #
```

The following example updates the CIMC firmware to version 2.2(1b), verifies that the firmware update completed successfully before starting the firmware activation, activates the CIMC firmware, and verifies that the firmware activation completed successfully:

```
UCS-A# scope server 1/1
UCS-A# /chassis/server # scope cimc
UCS-A# /chassis/server/cimc # show image
Name                                     Type                                     Version
-----
ucs-b200-m1-k9-cimc.2.2.1b.bin          CIMC                                     2.2 (1b)
ucs-b200-m3-k9-cimc.2.2.1b.bin          CIMC                                     2.2 (1b)
ucs-b22-m3-k9-cimc.2.2.1b.bin          CIMC                                     2.2 (1b)
...

UCS-A# /chassis/server/cimc # update firmware 2.2(1b)
UCS-A# /chassis/server/cimc* # commit-buffer
UCS-A# /chassis/server/cimc # show firmware
Running-Vers  Update-Status  Activate-Status
-----
2.1(1)        Updating        Ready

UCS-A# /chassis/server/cimc # show firmware
Running-Vers  Update-Status  Activate-Status
-----
2.1(1)        Ready         Ready

UCS-A# /chassis/server/cimc # activate firmware 2.2(1b)
UCS-A# /chassis/server/cimc* # commit-buffer
UCS-A# /chassis/server/cimc # show firmware
Running-Vers  Update-Status  Activate-Status
-----
2.1(1)        Ready         Activating

UCS-A# /chassis/server/cimc # show firmware
Running-Vers  Update-Status  Activate-Status
-----
2.2(1b)       Ready         Ready
```

# Updating and Activating the Firmware on an IOM

If your system is running in a high availability cluster configuration, you must update and activate both I/O modules.



## Caution

Do not remove the hardware that contains the endpoint or perform any maintenance on it until the update process has completed. If the hardware is removed or otherwise unavailable due to maintenance, the firmware update fails. This failure may corrupt the backup partition. You cannot update the firmware on an endpoint with a corrupted backup partition.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	UCS-A# <b>scope chassis</b> <i>chassis-id</i>	Enters chassis mode for the specified chassis.
<b>Step 2</b>	UCS-A /chassis# <b>scope iom</b> <i>iom-id</i>	Enters chassis I/O module mode for the selected I/O module.
<b>Step 3</b>	UCS-A /chassis/iom# <b>show image</b>	Displays the available software images for the I/O module.
<b>Step 4</b>	UCS-A /chassis/iom# <b>update firmware</b> <i>version-num</i>	Updates the selected firmware version on the I/O module.
<b>Step 5</b>	UCS-A /chassis/iom# <b>commit-buffer</b>	(Optional) Commits the transaction.  Use this step only if you intend to use the <b>show firmware</b> command in Step 6 to verify that the firmware update completed successfully before activating the firmware in Step 7. You can skip this step and commit the <b>update-firmware</b> and <b>activate-firmware</b> commands in the same transaction; however, if the firmware update does not complete successfully, the firmware activation does not start.  Cisco UCS Manager copies the selected firmware image to the backup memory partition and verifies that image is not corrupt. The image remains as the backup version until you explicitly activate it.
<b>Step 6</b>	UCS-A /chassis/iom# <b>show firmware</b>	(Optional) Displays the status of the firmware update.  Use this step only if you want to verify that the firmware update completed successfully. The firmware update is complete when the update status is Ready. The CLI does not automatically refresh, so you may have to enter the <b>show firmware</b> command multiple times until the task state changes from Updating to Ready. Continue to Step 7 when the update status is Ready.

	Command or Action	Purpose
<b>Step 7</b>	UCS-A /chassis/iom # <b>activate firmware</b> <i>version-num</i> [ <b>set-startup-only</b> ]	Activates the selected firmware version on the I/O module.  Use the <b>set-startup-only</b> keyword if you want to reboot the I/O module only when the fabric interconnect in its data path reboots. If you do not use the <b>set-startup-only</b> keyword, the I/O module reboots and disrupts traffic. In addition, if Cisco UCS Manager detects a protocol and firmware version mismatch between it and the I/O module, it updates the I/O module with the firmware version that matches its own and then activates the firmware and reboots the I/O module again.
<b>Step 8</b>	UCS-A /chassis/iom # <b>commit-buffer</b>	Commits the transaction.
<b>Step 9</b>	UCS-A /chassis/iom # <b>show firmware</b>	(Optional) Displays the status of the firmware activation.  Use this step only if you want to verify that the firmware activation completed successfully. The CLI does not automatically refresh, so you may have to enter the <b>show firmware</b> command multiple times until the task state changes from Activating to Ready.

The following example updates and activates the I/O module firmware to version 2.2(1b) in the same transaction, without verifying that the firmware update and firmware activation completed successfully:

```
UCS-A# scope chassis 1
UCS-A# /chassis # scope iom 1
UCS-A# /chassis/iom # show image
Name                                     Type                                     Version
-----
ucs-2100.2.2.1b.bin                      Iom                                     2.2 (1b)
ucs-2200.2.2.1b.bin                      Iom                                     2.2 (1b)

UCS-A# /chassis/iom # update firmware 2.2(1b)
UCS-A# /chassis/iom* # activate firmware 2.2(1b) set-startup-only
UCS-A# /chassis/iom* # commit-buffer
UCS-A# /chassis/iom #
```

The following example updates the I/O module firmware to version 2.2(1b), verifies that the firmware update completed successfully before starting the firmware activation, activates the I/O module firmware, and verifies that the firmware activation completed successfully:

```
UCS-A# scope chassis 1
UCS-A# /chassis # scope iom 1
UCS-A# /chassis/iom # show image
Name                                     Type                                     Version
-----
ucs-2100.2.2.1b.bin                      Iom                                     2.2 (1b)
ucs-2200.2.2.1b.bin                      Iom                                     2.2 (1b)

UCS-A# /chassis/iom # update firmware 2.2(1b)
UCS-A# /chassis/iom* # commit-buffer
UCS-A# /chassis/iom # show firmware
IOM      Fabric ID Running-Vers   Update-Status   Activate-Status
-----
      1 A          2.1 (1)        Updating       Ready
```

```

UCS-A# /chassis/iom # show firmware
IOM      Fabric ID Running-Vers  Update-Status  Activate-Status
-----
      1 A          2.1(1)          Ready          Ready

UCS-A# /chassis/iom # activate firmware 2.2(1b) ignorecompcheck
UCS-A# /chassis/iom* # commit-buffer
UCS-A# /chassis/iom # show firmware
IOM      Fabric ID Running-Vers  Update-Status  Activate-Status
-----
      1 A          2.1(1)          Ready          Activating

UCS-A# /chassis/iom # show firmware
IOM      Fabric ID Running-Vers  Update-Status  Activate-Status
-----
      1 A          2.2(1b)         Ready          Ready

```

## Activating the Board Controller Firmware on a Cisco UCS B-Series M2 Blade Server

The board controller firmware controls many of the server functions, including eUSBs, LEDs, and I/O connectors.



### Note

This activation procedure causes the server to reboot. Depending upon whether or not the service profile associated with the server includes a maintenance policy, the reboot can occur immediately. To reduce the number of times a server needs to be rebooted during the upgrade process, we recommend that you upgrade the board controller firmware through the host firmware package in the service profile as the last step of upgrading a Cisco UCS domain, along with the server BIOS.

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	UCS-A# <b>scope server</b> <i>chassis-id / server-id</i>	Enters chassis server mode for the specified server.
<b>Step 2</b>	UCS-A /chassis/server # <b>scope boardcontroller</b>	Enters board controller mode for the server.
<b>Step 3</b>	UCS-A /chassis/server/boardcontroller # <b>show image</b>	(Optional) Displays the available software images for the board controller.
<b>Step 4</b>	UCS-A /chassis/server/boardcontroller # <b>show firmware</b>	(Optional) Displays the current running software image for the board controller.
<b>Step 5</b>	UCS-A /chassis/server/boardcontroller # <b>activate firmware</b> <i>version-num</i>	Activates the selected firmware version on the board controller in the server.

	Command or Action	Purpose
<b>Step 6</b>	UCS-A /chassis/server/boardcontroller # <b>commit-buffer</b>	Commits the transaction to the system configuration.

Cisco UCS Manager disconnects all active sessions, logs out all users, and activates the software. When the upgrade is complete, you are prompted to log back in. If you are prompted to re-login immediately after being disconnected, the login will fail. You must wait until the activation of Cisco UCS Manager is completed, which takes a few minutes.

The following example activates the board controller firmware:

```
UCS-A# scope server 1/1
UCS-A# /chassis/server # scope boardcontroller
UCS-A# /chassis/server/boardcontroller # show image
Name                                     Type                               Version                             State
-----
ucs-b440-m1-pld.B440100C-B4402006.bin   Board Controller                   B440100C-B4402006                   Active

UCS-A# /chassis/server/boardcontroller # show firmware
BoardController:
  Running-Vers: B440100C-B4402006
  Activate-Status: Ready

UCS-A# /chassis/server/boardcontroller # activate firmware B440100C-B4402006
UCS-A# /chassis/server/boardcontroller* # commit-buffer
```

## Activating the Board Controller Firmware on Cisco UCS B-Series M3 and M4 Blade Servers

The board controller firmware controls many of the server functions, including eUSBs, LEDs, and I/O connectors.



### Note

This activation procedure causes the server to reboot. Depending upon whether or not the service profile associated with the server includes a maintenance policy, the reboot can occur immediately. To reduce the number of times a server needs to be rebooted during the upgrade process, we recommend that you upgrade the board controller firmware through the host firmware package in the service profile as the last step of upgrading a Cisco UCS domain, along with the server BIOS.

The following limitations apply to M3 and M4 board controller firmware:

- You cannot downgrade the firmware after the upgrade is complete.
- You must be using Cisco UCS Manager, Release 2.1(2a) or greater.
- The board controller firmware version of the blade server should be the same or newer than the installed software bundle version.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	UCS-A# <b>scope server</b> <i>chassis-id / server-id</i>	Enters chassis server mode for the specified server.
<b>Step 2</b>	UCS-A /chassis/server # <b>scope boardcontroller</b>	Enters board controller mode for the server.
<b>Step 3</b>	UCS-A /chassis/server/boardcontroller # <b>show image</b>	(Optional) Displays the available software images for the board controller.
<b>Step 4</b>	UCS-A /chassis/server/boardcontroller # <b>show firmware</b>	(Optional) Displays the current running software image for the board controller.
<b>Step 5</b>	UCS-A /chassis/server/boardcontroller # <b>activate firmware</b> <i>version-num</i>	Activates the selected firmware version on the board controller in the server.
<b>Step 6</b>	UCS-A /chassis/server/boardcontroller # <b>commit-buffer</b>	Commits the transaction to the system configuration.

Cisco UCS Manager disconnects all active sessions, logs out all users, and activates the software. When the upgrade is complete, you are prompted to log back in. If you are prompted to re-login immediately after being disconnected, the login will fail. You must wait until the activation of Cisco UCS Manager is completed, which takes a few minutes.

The following example activates the M3 board controller firmware:

```
UCS-A# scope server 1/1
UCS-A# /chassis/server # scope boardcontroller
UCS-A# /chassis/server/boardcontroller # show image
Name                                     Type                Version             State
-----
ucs-b200-m3-brdprog.11.0.bin             Board Controller    11.0               Active
ucs-b22-m3-brdprog.8.0.bin              Board Controller    8.0                Active

UCS-A# /chassis/server/boardcontroller # show firmware
BoardController:
  Running-Vers: 11.0
  Package-Vers:
  Activate-Status: Ready

UCS-A# /chassis/server/boardcontroller # activate firmware 11.0
UCS-A# /chassis/server/boardcontroller* # commit-buffer
```

## Activating the Board Controller Firmware on a Cisco UCS C-Series M3 and M4 Rack Servers

The board controller firmware controls many of the server functions, including eUSBs, LEDs, and I/O connectors.

**Note**

This activation procedure causes the server to reboot. Depending upon whether or not the service profile associated with the server includes a maintenance policy, the reboot can occur immediately. To reduce the number of times a server needs to be rebooted during the upgrade process, we recommend that you upgrade the board controller firmware through the host firmware package in the service profile as the last step of upgrading a Cisco UCS domain, along with the server BIOS.

The following limitations apply to M3 and M4 board controller firmware:

- You must be using Cisco UCS Manager, Release 2.2(1a) or greater.
- The board controller firmware and the CIMC firmware must be of the same package version.
- If the activation status of the board controller displays **Pending Power Cycle** after you upgrade the board controller, a manual power cycle is required. A fault is also generated. After the power cycle is complete, the fault is cleared and the board controller activation status displays **Ready**.

**Procedure**

	<b>Command or Action</b>	<b>Purpose</b>
<b>Step 1</b>	UCS-A# <b>scope server</b> <i>server-id</i>	Enters chassis server mode for the specified server.
<b>Step 2</b>	UCS-A /server # <b>scope boardcontroller</b>	Enters board controller mode for the server.
<b>Step 3</b>	UCS-A /server/boardcontroller # <b>show image</b>	(Optional) Displays the available software images for the board controller.
<b>Step 4</b>	UCS-A /server/boardcontroller # <b>show firmware</b>	(Optional) Displays the current running software image for the board controller.
<b>Step 5</b>	UCS-A /server/boardcontroller # <b>activate firmware</b> <i>version-num</i>	Activates the selected firmware version on the board controller in the server.
<b>Step 6</b>	UCS-A /server/boardcontroller # <b>commit-buffer</b>	Commits the transaction to the system configuration.

The following example activates the M3 board controller firmware:

```
UCS-A# scope server 7
UCS-A# /server # scope boardcontroller
UCS-A# /server/boardcontroller # show image
Name                                     Type                Version             State
-----
ucs-c220-m3-brdprog.3.0.bin             Board Controller    3.0                 Active
ucs-c220-m3-brdprog.3.0.bin             Board Controller    3.0                 Active

UCS-A# /server/boardcontroller # show firmware
BoardController:
  Running-Vers: N/A
  Package-Vers:
  Activate-Status: Ready
```



```
UCS-A# /server/boardcontroller # activate firmware 3.0 force
Warning: When committed this command will reset the end-point.

UCS-A# /server/boardcontroller* # commit-buffer
```

## Activating the Cisco UCS Manager Software

### Procedure

	Command or Action	Purpose
<b>Step 1</b>	UCS-A# <b>scope system</b>	Enters system mode.
<b>Step 2</b>	UCS-A /system # <b>show image</b>	Displays the available software images for Cisco UCS Manager (system).
<b>Step 3</b>	UCS-A /system # <b>activate firmware</b> <i>version-num</i>	Activates the selected firmware version on the system.  <b>Note</b> Activating Cisco UCS Manager does not require rebooting the fabric interconnect; however, management services will briefly go down and all VSH shells will be terminated as part of the activation.
<b>Step 4</b>	UCS-A /system # <b>commit-buffer</b>	Commits the transaction.  Cisco UCS Manager makes the selected version the startup version and schedules the activation to occur when the fabric interconnects are upgraded.

The following example upgrades Cisco UCS Manager to version 2.2(1b) and commits the transaction:

```
UCS-A# scope system
UCS-A# /system # show image
Name                                     Type                Version             State
-----
ucs-manager-k9.2.2.1b.bin                System              2.2(1b)            Active

UCS-A# /system # activate firmware 2.2(1b)
UCS-A# /system* # commit-buffer
UCS-A# /system #
```

## Activating the Firmware on a Fabric Interconnect

When updating the firmware on two fabric interconnects in a high availability cluster configuration, you must activate the subordinate fabric interconnect before activating the primary fabric interconnect. For more information about determining the role for each fabric interconnect, see [Verifying the High Availability Status and Roles of a Cluster Configuration](#).

For a standalone configuration with a single fabric interconnect, you can minimize the disruption to data traffic when you perform a direct firmware upgrade of the endpoints. However, you must reboot the fabric interconnect to complete the upgrade and, therefore, cannot avoid disrupting traffic.

**Tip**

If you ever need to recover the password to the admin account that was created when you configured the fabric interconnects for the Cisco UCS domain, you must know the running kernel version and the running system version. If you do not plan to create additional accounts, we recommend that you save the path to these firmware versions in a text file so that you can access them if required.

**Procedure**

	Command or Action	Purpose
<b>Step 1</b>	UCS-A# <b>scope fabric-interconnect</b> {a   b}	Enters fabric interconnect mode for the specified fabric interconnect.
<b>Step 2</b>	UCS-A /fabric-interconnect # <b>show image</b>	Displays the available software images for the fabric interconnect.
<b>Step 3</b>	UCS-A /fabric-interconnect # <b>activate firmware</b> {kernel-version <i>kernel-ver-num</i>   system-version <i>system-ver-num</i> }	Activates the selected firmware version on the fabric interconnect.
<b>Step 4</b>	UCS-A /fabric-interconnect # <b>commit-buffer</b>	Commits the transaction.  Cisco UCS Manager updates and activates the firmware, and then reboots the fabric interconnect and any I/O module in the data path to that fabric interconnect, disrupting data traffic to and from that fabric interconnect.

The following example upgrades the fabric interconnect to version 5.2(3)N2(2.21.92) and commits the transaction:

```
UCS-A# scope fabric-interconnect a
UCS-A /fabric-interconnect # show image
Name
-----
ucs-6100-k9-kickstart.5.2.3.N2.2.21b.bin      Fabric Interconnect  5.2(3)N2(2.21.92)
ucs-6100-k9-system.5.2.3.N2.2.21b.bin        Fabric Interconnect  5.2(3)N2(2.21.92)

UCS-A /fabric-interconnect # activate firmware kernel-version 5.2(3)N2(2.21.92) system-version
5.2(3)N2(2.21.92)
UCS-A /fabric-interconnect* # commit-buffer
UCS-A /fabric-interconnect #
```

## Forcing a Fabric Interconnect Failover

This operation can only be performed in the Cisco UCS Manager CLI.

You must force the failover from the primary fabric interconnect.

## Procedure

	Command or Action	Purpose
<b>Step 1</b>	UCS-A# <b>show cluster state</b>	Displays the state of fabric interconnects in the cluster and whether the cluster is HA ready.
<b>Step 2</b>	UCS-A# <b>connect local-mgmt</b>	Enters local management mode for the cluster.
<b>Step 3</b>	UCS-A (local-mgmt) # <b>cluster {force primary   lead {a   b}}</b>	Changes the subordinate fabric interconnect to primary using one of the following commands:  <b>force</b> Forces local fabric interconnect to become the primary.  <b>lead</b> Makes the specified subordinate fabric interconnect the primary.

The following example changes fabric interconnect b from subordinate to primary:

```
UCS-A# show cluster state
Cluster Id: 0xfc436fa8b88511e0-0xa370000573cb6c04

A: UP, PRIMARY
B: UP, SUBORDINATE

HA READY
UCS-A# connect local-mgmt
Cisco Nexus Operating System (NX-OS) Software
TAC support: http://www.cisco.com/tac
Copyright (c) 2002-2011, Cisco Systems, Inc. All rights reserved.
The copyrights to certain works contained in this software are
owned by other third parties and used and distributed under
license. Certain components of this software are licensed under
the GNU General Public License (GPL) version 2.0 or the GNU
Lesser General Public License (LGPL) Version 2.1. A copy of each
such license is available at
http://www.opensource.org/licenses/gpl-2.0.php and
http://www.opensource.org/licenses/lgpl-2.1.php

UCS-A(local-mgmt) # cluster lead b
UCS-A(local-mgmt) #
```

