



# MPLS-IP Configuration Mode Commands

---

## Command Modes

The MPLS-IP Configuration Mode is used for configuration of Multiprotocol Label Switching (MPLS) IP forwarding specific parameters. This mode is entered from the Context Configuration Mode.

Exec > Global Configuration > Context Configuration > MPLS-IP Configuration

**configure > context *context\_name* > mpls-ip**

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-mpls) #
```



## Important

The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).

- [end, on page 2](#)
- [exit, on page 3](#)
- [protocol ldp, on page 4](#)

# end

Exits the current configuration mode and returns to the Exec mode.

---

**Product** All

---

**Privilege** Security Administrator, Administrator

---

**Syntax Description** `end`

---

**Usage Guidelines** Use this command to return to the Exec mode.

# exit

Exits the current mode and returns to the parent configuration mode.

---

**Product**

All

---

**Privilege**

Security Administrator, Administrator

---

**Syntax Description**

**exit**

---

**Usage Guidelines**

Use this command to return to the parent configuration mode.

# protocol ldp

Creates or removes the MPLS label distribution protocol (LDP) configuration, or configures an existing protocol and enters the MPLS-LDP Configuration Mode in the current context. This command configures the protocol parameters for MPLS LDP.

---

## Product

GGSN  
P-GW  
SAEGW

---

## Privilege

Security Administrator, Administrator

---

## Command Modes

Exec > Global Configuration > Context Configuration > MPLS-IP Configuration

**configure > context *context\_name* > mpls-ip**

Entering the above command sequence results in the following prompt:

```
[context_name]host_name(config-mpls)#
```

---

## Syntax Description

**[ no ] protocol ldp**

**no**

Removes the configured MPLS-LDP mode from MPLS-IP Configuration mode.

---

## Usage Guidelines

Use this command to create/ or remove the MPLS LDP configuration, or configure an existing protocol. If required mode already exists it enters the MPLS-LDP Configuration Mode in the current context.

Entering this command results in the following prompt:

```
[context_name]hostname(config-ldp)#
```

The commands configured in this mode are defined in the *MPLS-LDP Configuration Mode Commands* chapter.

## Example

The following command creates and enters the MPLS-LDP Protocol mode:

```
protocol ldp
```