



Core File Exporter

- [Core File Exporter \(1 ページ\)](#)
- [Configuring the Core File Exporter, on page 1](#)
- [Disabling the Core File Exporter, on page 2](#)

Core File Exporter

ファブリック インターコネクタや I/O モジュールなどの Cisco UCS コンポーネントで重大な障害が発生すると、システムはコアダンプファイルを作成することがあります。Cisco UCS Manager では、この Core File Exporter で TFTP からネットワーク上の指定ロケーションに直ちにコア ダンプ ファイルをエクスポートします。この機能を使用することにより、tar ファイルをコア ダンプ ファイルのコンテンツと一緒にエクスポートできます。Core File Exporter は、システムをモニタリングし、TAC Case に含める必要のあるコア ダンプ ファイルを自動的にエクスポートします。

Configuring the Core File Exporter

SUMMARY STEPS

1. UCS-A# **scope monitoring**
2. UCS-A /monitoring # **scope sysdebug**
3. UCS-A /monitoring/sysdebug # **enable core-export-target**
4. UCS-A /monitoring/sysdebug # **set core-export-target path** *path*
5. UCS-A /monitoring/sysdebug # **set core-export-target port** *port-num*
6. UCS-A /monitoring/sysdebug # **set core-export-target server-description** *description*
7. UCS-A /monitoring/sysdebug # **set core-export-target server-name** *hostname*
8. UCS-A /monitoring/sysdebug # **commit-buffer**

DETAILED STEPS

| | Command or Action | Purpose |
|--------|---|--------------------------------------|
| Step 1 | UCS-A# scope monitoring | Enters monitoring mode. |
| Step 2 | UCS-A /monitoring # scope sysdebug | Enters monitoring system debug mode. |

| | Command or Action | Purpose |
|---------------|--|---|
| Step 3 | UCS-A /monitoring/sysdebug # enable core-export-target | Enables the core file exporter. When the core file exporter is enabled and an error causes the server to perform a core dump, the system exports the core file via TFTP to the specified remote server. |
| Step 4 | UCS-A /monitoring/sysdebug # set core-export-target path <i>path</i> | Specifies the path to use when exporting the core file to the remote server. |
| Step 5 | UCS-A /monitoring/sysdebug # set core-export-target port <i>port-num</i> | Specifies the port number to use when exporting the core file via TFTP. The range of valid values is 1 to 65,535. |
| Step 6 | UCS-A /monitoring/sysdebug # set core-export-target server-description <i>description</i> | Provides a description for the remote server used to store the core file. |
| Step 7 | UCS-A /monitoring/sysdebug # set core-export-target server-name <i>hostname</i> | Specifies the hostname of the remote server to connect with via TFTP. |
| Step 8 | UCS-A /monitoring/sysdebug # commit-buffer | Commits the transaction. |

Example

The following example enables the core file exporter, specifies the path and port to use when sending the core file, specifies the remote server hostname, provides a description for the remote server, and commits the transaction.

```
UCS-A# scope monitoring
UCS-A /monitoring # scope sysdebug
UCS-A /monitoring/sysdebug # enable core-export-target
UCS-A /monitoring/sysdebug* # set core-export-target path /root/CoreFiles/core
UCS-A /monitoring/sysdebug* # set core-export-target port 45000
UCS-A /monitoring/sysdebug* # set core-export-target server-description CoreFile102.168.10.10
UCS-A /monitoring/sysdebug* # set core-export-target server-name 192.168.10.10
UCS-A /monitoring/sysdebug* # commit-buffer
UCS-A /monitoring/sysdebug #
```

Disabling the Core File Exporter

SUMMARY STEPS

1. UCS-A# **scope monitoring**
2. UCS-A /monitoring # **scope sysdebug**
3. UCS-A /monitoring/sysdebug # **disable core-export-target**
4. UCS-A /monitoring/sysdebug # **commit-buffer**

DETAILED STEPS

| | Command or Action | Purpose |
|---------------|--------------------------------|-------------------------|
| Step 1 | UCS-A# scope monitoring | Enters monitoring mode. |

| | Command or Action | Purpose |
|---------------|--|---|
| Step 2 | UCS-A /monitoring # scope sysdebug | Enters monitoring system debug mode. |
| Step 3 | UCS-A /monitoring/sysdebug # disable core-export-target | Disables the core file exporter. When the core file exporter is disabled core files are not automatically exported. |
| Step 4 | UCS-A /monitoring/sysdebug # commit-buffer | Commits the transaction. |

Example

The following example disables the core file exporter and commits the transaction.

```
UCS-A# scope monitoring
UCS-A /monitoring # scope sysdebug
UCS-A /monitoring/sysdebug # disable core-export-target
UCS-A /monitoring/sysdebug* # commit-buffer
UCS-A /monitoring/sysdebug #
```

