



CHAPTER 5

Configuring the PA-4T+ Interfaces

To continue your PA-4T+ port adapter installation, you must configure the serial interfaces. The instructions that follow apply to all supported platforms. Minor differences between the platforms are noted.

This chapter contains the following sections:

- [Using the EXEC Command Interpreter, page 5-1](#)
- [Configuring the Interfaces, page 5-2](#)
- [Configuring Half-Duplex and Binary Synchronous Communications in Cisco 7200 Series Routers, page 5-16](#)
- [Checking the Configuration, page 5-18](#)

Using the EXEC Command Interpreter

You modify the configuration of your router through the software command interpreter called the EXEC (also called enable mode). You must enter the privileged level of the EXEC command interpreter with the **enable** command before you can use the **configure** command to configure a new interface or to change the existing configuration of an interface. The system prompts you for a password if one is set.

The system prompt for the privileged level ends with a pound sign (#) instead of an angle bracket (>). At the console terminal, use the following procedure to enter the privileged level:

-
- Step 1** At the user-level EXEC prompt, enter the **enable** command. The EXEC prompts you for a privileged-level password as follows:

```
Router> enable
```

```
Password:
```

- Step 2** Enter the password (the password is case-sensitive). For security purposes, the password is not displayed.

When you enter the correct password, the system displays the privileged-level system prompt (#):

```
Router#
```

Configuring the Interfaces

After you verify that the new PA-4T+ is installed correctly (the enabled LED goes on), use the privileged-level **configure** command to configure the new interfaces. Be prepared with the information you will need, such as the following:

- Protocols you plan to route on each new interface
- IP addresses if you will configure the interfaces for IP routing
- Whether or not the new interfaces will use bridging
- Timing source for each new interface and clock speeds for external timing

If you installed a new PA-4T+ or if you want to change the configuration of an existing interface, you must enter configuration mode using the **configure** command. If you replaced a PA-4T+ that was previously configured, the system will recognize the new PA-4T+ interfaces and bring each of them up in their existing configurations.

For a summary of the configuration options available and instructions for configuring interfaces on the PA-4T+, refer to the appropriate configuration publications listed in the [“Related Documentation” section on page viii](#).

You execute configuration commands from the privileged level of the EXEC command interpreter, which usually requires password access. Contact your system administrator, if necessary, to obtain password access. (See the [“Using the EXEC Command Interpreter” section on page 5-1](#) for an explanation of the privileged level of the EXEC.)

This section contains the following subsections:

- [Shutting Down an Interface, page 5-2](#)
- [Performing a Basic Configuration, page 5-8](#)
- [Configuring Timing \(Clock\) Signals, page 5-11](#)
- [Configuring NRZI Format, page 5-14](#)
- [Configuring Cyclic Redundancy Checks, page 5-15](#)

Shutting Down an Interface

Before you remove an interface that you will not replace, replace a compact serial cable, or replace port adapters, use the **shutdown** command to shut down (disable) the interfaces to prevent anomalies when you reinstall the new or reconfigured interface processor. When you shut down an interface, it is designated administratively down in the **show** command displays.

Follow these steps to shut down an interface:

-
- Step 1** Enter the privileged level of the EXEC command interpreter. (See the [“Using the EXEC Command Interpreter” section on page 5-1](#) for instructions.)
 - Step 2** At the privileged-level prompt, enter configuration mode and specify that the console terminal will be the source of the configuration subcommands as follows:

```
Router# configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
Router(config)#
```
 - Step 3** Shut down interfaces by entering the **interface serial** subcommand (followed by the interface address of the interface), and then enter the **shutdown** command.

When you have finished, press **Ctrl-Z**—hold down the **Control** key while you press **Z**—or enter **end** or **exit** to exit configuration mode and return to the EXEC command interpreter

Table 5-1 shows the **shutdown** command syntax for the supported platforms.

Table 5-1 Syntax of the **shutdown** Command for the Supported Platforms

Platform	Command	Example
Catalyst RSM/VIP2 in Catalyst 5000 family switches	interface , followed by the <i>type (serial)</i> and <i>slot/port</i> (port-adapter-slot-number/interface-port-number) shutdown	The example is for interface 0 and interface 1 on a port adapter in port adapter slot 1. Router(config-if)# interface serial 1/0 Router(config-if)# shutdown Router(config-if)# interface serial 1/1 Router(config-if)# shutdown Ctrl-Z Router#
Catalyst 6000 family FlexWAN module in Catalyst 6000 family switches	interface , followed by the <i>type (serial)</i> and <i>mod_num/bay/port</i> (module-slot-number/port-adapter-bay-number/interface-port-number) shutdown	The example is for interface 0 and interface 1 on a port adapter in port adapter bay 0 of a FlexWAN module installed in module slot 3. Router(config-if)# interface serial 3/0/0 Router(config-if)# shutdown Router(config-if)# interface serial 3/0/1 Router(config-if)# shutdown Ctrl-Z Router#
Cisco 7120 series routers	interface , followed by the <i>type (serial)</i> and <i>slot/port</i> (port-adapter-slot-number/interface-port-number) shutdown	The example is for interface 0 and interface 1 on a port adapter in port adapter slot 3. Router(config-if)# interface serial 3/0 Router(config-if)# shutdown Router(config-if)# interface serial 3/1 Router(config-if)# shutdown Ctrl-Z Router#
Cisco 7140 series routers	interface , followed by the <i>type (serial)</i> and <i>slot/port</i> (port-adapter-slot-number/interface-port-number) shutdown	The example is for interface 0 and interface 1 on a port adapter in port adapter slot 4. Router(config-if)# interface serial 4/0 Router(config-if)# shutdown Router(config-if)# interface serial 4/1 Router(config-if)# shutdown Ctrl-Z Router#
Cisco 7200 series routers and Cisco 7200 VXR routers	interface , followed by the <i>type (serial)</i> and <i>slot/port</i> (port-adapter-slot-number/interface-port-number) shutdown	The example is for interface 0 and interface 1 on a port adapter in port adapter slot 6. Router(config-if)# interface serial 6/0 Router(config-if)# shutdown Router(config-if)# interface serial 6/1 Router(config-if)# shutdown Ctrl-Z Router#

Table 5-1 Syntax of the shutdown Command for the Supported Platforms (continued)

Platform	Command	Example
Cisco 7201 router	interface , followed by the <i>type</i> (serial) and <i>slot/port</i> (port-adapter-slot-number/interface-port-number) shutdown	The example is for interface 0 and interface 1 on a port adapter in port adapter slot 1. Router(config-if)# interface serial 1/0 Router(config-if)# shutdown Router(config-if)# interface serial 1/1 Router(config-if)# shutdown Ctrl-Z Router#
Cisco uBR7223 router	interface , followed by the <i>type</i> (serial) and <i>slot/port</i> (port-adapter-slot-number/interface-port-number) shutdown	The example is for interface 0 and interface 1 on a port adapter in port adapter slot 1. Router(config-if)# interface serial 1/0 Router(config-if)# shutdown Router(config-if)# interface serial 1/1 Router(config-if)# shutdown Ctrl-Z Router#
Cisco uBR7246 router	interface , followed by the <i>type</i> (serial) and <i>slot/port</i> (port-adapter-slot-number/interface-port-number) shutdown	The example is for interface 0 and interface 1 on a port adapter in port adapter slot 2. Router(config-if)# interface serial 2/0 Router(config-if)# shutdown Router(config-if)# interface serial 2/1 Router(config-if)# shutdown Ctrl-Z Router#
Cisco 7301 router	interface , followed by the <i>type</i> (serial) and <i>slot/port</i> (port-adapter-slot-number/interface-port-number) shutdown	The example is for interface 0 and interface 1 on a port adapter in port adapter slot 1. Router(config-if)# interface serial 1/0 Router(config-if)# shutdown Router(config-if)# interface serial 1/1 Router(config-if)# shutdown Ctrl-Z Router#
Cisco 7304 PCI Port Adapter Carrier Card in a Cisco 7304 router	interface , followed by the <i>type</i> (serial) and <i>slot/port</i> (module-slot-number/interface-port-number) shutdown	The example is for interface 0 and interface 1 on a port adapter in a Cisco 7304 PCI Port Adapter Carrier Card in module slot 3 of a Cisco 7304 router. Router(config-if)# interface serial 3/0 Router(config-if)# shutdown Router(config-if)# interface serial 3/1 Router(config-if)# shutdown Ctrl-Z Router#

Table 5-1 Syntax of the shutdown Command for the Supported Platforms (continued)

Platform	Command	Example
Cisco 7401ASR router	interface , followed by the <i>type (serial)</i> and <i>slot/port</i> (port-adapter-slot-number/interface-port-number) shutdown	The example is for interface 0 and interface 1 on a port adapter in port adapter slot 1. Router(config-if)# interface serial 1/0 Router(config-if)# shutdown Router(config-if)# interface serial 1/1 Router(config-if)# shutdown Ctrl-Z Router#
VIP in Cisco 7000 series routers or Cisco 7500 series routers	interface , followed by the <i>type (serial)</i> and <i>slot/port adapter/port</i> (interface-processor-slot-number/port-adapter-slot-number/interface-port-number) shutdown	The example is for interface 1 and interface 0 on a port adapter in port adapter slot 1 of a VIP installed in interface processor slot 1. Router(config-if)# interface serial 1/1/1 Router(config-if)# shutdown Router(config-if)# interface serial 1/1/0 Router(config-if)# shutdown Ctrl-Z Router#

**Note**

If you need to shut down additional interfaces, enter the **interface serial** command (followed by the interface address of the interface) for each of the interfaces on your port adapter. Use the **no shutdown** command to enable the interface.

Step 4 Write the new configuration to NVRAM as follows:

```
Router# copy running-config startup-config
[OK]
Router#
```

The system displays an OK message when the configuration has been stored.

Step 5 Verify that new interfaces are now in the correct state (shut down) using the **show interfaces** command (followed by the interface type and interface address of the interface) to display the specific interface.

Table 5-2 provides examples of the **show interfaces serial** command for the supported platforms.

Table 5-2 Examples of the **show interfaces serial** Command for the Supported Platforms

Platform	Command	Example
Catalyst RSM/VIP2 in Catalyst 5000 family switches	show interfaces serial , followed by <i>slot/port</i> (port-adapter-slot-number/interface-port-number)	The example is for interface 0 on a port adapter in port adapter slot 1. Router# show interfaces serial 1/0 Serial 1/0 is administratively down, line protocol is down [Additional display text omitted from this example]
Catalyst 6000 family FlexWAN module in Catalyst 6000 family switches	show interfaces serial , followed by <i>mod_num/bay/port</i> (module-slot-number/port-adapter-bay-number/interface-port-number)	The example is for interface 0 on a port adapter in port adapter bay 0 of a FlexWAN module in module slot 3. Router# show interfaces serial 3/0/0 Serial 3/0/0 is administratively down, line protocol is down [Additional display text omitted from this example]
Cisco 7120 series routers	show interfaces serial , followed by <i>slot/port</i> (port-adapter-slot-number/interface-port-number)	The example is for interface 0 on a port adapter in port adapter slot 3. Router# show interfaces serial 3/0 Serial 3/0 is administratively down, line protocol is down [Additional display text omitted from this example]
Cisco 7140 series routers	show interfaces serial , followed by <i>slot/port</i> (port-adapter-slot-number/interface-port-number)	The example is for interface 0 on a port adapter in port adapter slot 4. Router# show interfaces serial 4/0 Serial 4/0 is administratively down, line protocol is down [Additional display text omitted from this example]
Cisco 7200 series routers and Cisco 7200 VXR routers	show interfaces serial , followed by <i>slot/port</i> (port-adapter-slot-number/interface-port-number)	The example is for interface 0 on a port adapter in port adapter slot 6. Router# show interfaces serial 6/0 Serial 6/0 is administratively down, line protocol is down [Additional display text omitted from this example]

Table 5-2 Examples of the `show interfaces serial` Command for the Supported Platforms (continued)

Platform	Command	Example
Cisco 7201 router	show interfaces serial , followed by <i>slot/port</i> (port-adapter-slot-number/interface-port-number)	The example is for interface 0 on a port adapter in port adapter slot 1. Router# show interfaces serial 1/0 Serial 1/0 is administratively down, line protocol is down [Additional display text omitted from this example]
Cisco uBR7223 router	show interfaces serial , followed by <i>slot/port</i> (port-adapter-slot-number/interface-port-number)	The example is for interface 0 on a port adapter in port adapter slot 1. Router# show interfaces serial 1/0 Serial 1/0 is administratively down, line protocol is down [Additional display text omitted from this example]
Cisco uBR7246 router	show interfaces serial , followed by <i>slot/port</i> (port-adapter-slot-number/interface-port-number)	The example is for interface 0 on a port adapter in port adapter slot 2. Router# show interfaces serial 2/0 Serial 2/0 is administratively down, line protocol is down [Additional display text omitted from this example]
Cisco 7301 router	show interfaces serial , followed by <i>slot/port</i> (port-adapter-slot-number/interface-port-number)	The example is for interface 0 on a port adapter in port adapter slot 1. Router# show interfaces serial 1/0 Serial 1/0 is administratively down, line protocol is down [Additional display text omitted from this example]
Cisco 7304 PCI Port Adapter Carrier Card in a Cisco 7304 router	show interfaces serial , followed by <i>slot/port</i> (module-slot-number/interface-port-number)	The example is for interface 0 on a port adapter in a Cisco 7304 PCI Port Adapter Carrier Card in module slot 3 of a Cisco 7304 router. Router# show interfaces serial 3/0 Serial 3/0 is administratively down, line protocol is down [Additional display text omitted from this example]

Table 5-2 Examples of the `show interfaces serial` Command for the Supported Platforms (continued)

Platform	Command	Example
Cisco 7401ASR router	show interfaces serial , followed by <i>slot/port</i> (port-adapter-slot-number/interface-port-number)	The example is for interface 0 on a port adapter in port adapter slot 1. Router# show interfaces serial 1/0 Serial 1/0 is administratively down, line protocol is down [Additional display text omitted from this example]
VIP in Cisco 7000 series routers or Cisco 7500 series routers	show interfaces serial , followed by <i>slot/port adapter/port</i> (interface-processor-slot-number/port-adapter-slot-number/interface-port-number)	The example is for interface 0 on a port adapter in port adapter slot 1 of a VIP in interface processor slot 1. Router# show interfaces serial 1/1/0 Serial 1/1/0 is administratively down, line protocol is down [Additional display text omitted from this example]

- Step 6** Re-enable the interfaces by doing the following:
- Repeat Step 3 to re-enable an interface. Substitute the **no shutdown** command for the **shutdown** command.
 - Repeat Step 4 to write the new configuration to memory. Use the **copy running-config startup-config** command.
 - Repeat Step 5 to verify that the interfaces are in the correct state. Use the **show interfaces** command followed by the interface type and interface address of the interface.

For complete descriptions of software configuration commands, refer to the publications listed in the [“Related Documentation” section on page viii](#). Proceed to the following section to configure the new interfaces.

Performing a Basic Configuration

Following are instructions for a basic interface configuration, which includes enabling an interface, specifying IP routing, and setting up external timing on a DCE interface. You might also need to enter other configuration subcommands, depending on the requirements for your system configuration and the protocols you plan to route on the interface. For complete descriptions of configuration subcommands and the configuration options available for serial interfaces, refer to the appropriate software documentation.

In the following procedure, press the **Return** key after each step unless otherwise noted. At any time you can exit the privileged level and return to the user level by entering **disable** at the prompt as follows:

```
Router# disable
```

```
Router>
```

- Step 1** At the privileged-level prompt, enter configuration mode and specify that the console terminal will be the source of the configuration subcommands as follows:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#
```

- Step 2** Specify the first interface to configure by entering the **interface serial** subcommand, followed by the interface address of the interface you plan to configure.

Table 5-3 provides examples of the **interface serial** subcommand for the supported platforms.

Table 5-3 Examples of the interface serial Subcommand for the Supported Platforms

Platform	Command	Example
Catalyst RSM/VIP2 in Catalyst 5000 family switches	interface serial , followed by <i>slot/port</i> (port-adapter-slot-number/ interface-port-number)	The example is for interface 0 of a port adapter in port adapter slot 0. Router(config)# interface serial 0/0 Router(config-if)#
Catalyst 6000 family FlexWAN module in Catalyst 6000 family switches	interface serial , followed by <i>mod_num/bay/port</i> (module-slot-number/ port-adapter-bay-number/ interface-port-number)	The example is for interface 0 of a port adapter in port adapter bay 0 of a FlexWAN module in module slot 3. Router(config)# interface serial 3/0/0 Router(config-if)#
Cisco 7120 series routers	interface serial , followed by <i>slot/port</i> (port-adapter-slot-number/ interface-port-number)	The example is for interface 0 of a port adapter in port adapter slot 3. Router(config)# interface serial 3/0 Router(config-if)#
Cisco 7140 series routers	interface serial , followed by <i>slot/port</i> (port-adapter-slot-number/ interface-port-number)	The example is for interface 0 of a port adapter in port adapter slot 4. Router(config)# interface serial 4/0 Router(config-if)#
Cisco 7200 series routers and Cisco 7200 VXR routers	interface serial , followed by <i>slot/port</i> (port-adapter-slot-number/ interface-port-number)	The example is for interface 0 of a port adapter in port adapter slot 6. Router(config)# interface serial 6/0 Router(config-if)#
Cisco 7201 router	interface serial , followed by <i>slot/port</i> (port-adapter-slot-number/ interface-port-number)	The example is for interface 0 of a port adapter in port adapter slot 1. Router(config)# interface serial 1/0 Router(config-if)#
Cisco uBR7223 router	interface serial , followed by <i>slot/port</i> (port-adapter-slot-number/ interface-port-number)	The example is for interface 0 of a port adapter in port adapter slot 1. Router(config)# interface serial 1/0 Router(config-if)#
Cisco uBR7246 router	interface serial , followed by <i>slot/port</i> (port-adapter-slot-number/ interface-port-number)	The example is for interface 0 of a port adapter in port adapter slot 2. Router(config)# interface serial 2/0 Router(config-if)#

Table 5-3 Examples of the interface serial Subcommand for the Supported Platforms (continued)

Platform	Command	Example
Cisco 7301 router	interface serial , followed by <i>slot/port</i> (port-adapter-slot-number/ interface-port-number)	The example is for interface 0 of a port adapter in port adapter slot 1. Router (config)# interface serial 1/0 Router (config-if)#
Cisco 7304 PCI Port Adapter Carrier Card in a Cisco 7304 router	interface serial , followed by <i>slot/port</i> (module-slot-number/ interface-port-number)	The example is for interface 0 on a port adapter in a Cisco 7304 PCI Port Adapter Carrier Card in module slot 3 of a Cisco 7304 router. Router (config)# interface serial 3/0 Router (config-if)#
Cisco 7401ASR router	interface serial , followed by <i>slot/port</i> (port-adapter-slot-number/ interface-port-number)	The example is for interface 0 of a port adapter in port adapter slot 1. Router (config)# interface serial 1/0 Router (config-if)#
VIP in Cisco 7000 series or Cisco 7500 series routers	interface serial , followed by <i>slot/port adapter/port</i> (interface-processor-slot-number/ port-adapter-slot-number/ interface-port-number)	The example is for interface 0 of a port adapter in port adapter slot 1 of a VIP in interface processor slot 1. Router (config)# interface serial 1/1/0 Router (config-if)#

- Step 3** Assign an IP address and subnet mask to the interface (if IP routing is enabled on the system) by using the **ip address** configuration subcommand, as in the following example:

```
Router (config-if)# ip address 10.10.10.10 255.255.255.255
```

- Step 4** Add any additional configuration subcommands required to enable routing protocols and set the interface characteristics.



Note If you are configuring a DTE interface, proceed to Step 6. If you are configuring a DCE interface, you need to configure the external clock signal, as described in the next step.

The example in Step 5 applies to all systems in which the PA-4T+ is supported.

- Step 5** Set the clock rate with the **clock rate** command. (See the “[Configuring Timing \(Clock\) Signals](#)” section on page 5-11.)

```
Router (config-if)# clock rate 64000
```

- Step 6** Re-enable the interfaces using the **no shutdown** command. (See the “[Shutting Down an Interface](#)” section on page 5-2.)

- Step 7** Configure all additional port adapter interfaces as required.

- Step 8** When you have included all of the configuration subcommands to complete the configuration, press **Ctrl-Z** (hold down the **Control** key while you press **Z**) or enter **end** to exit configuration mode and return to the EXEC command interpreter prompt.

Step 9 Write the new configuration to NVRAM as follows:

```
Router# copy running-config startup-config
[OK]
Router#
```

This completes the procedure for creating a basic configuration.

Configuring Timing (Clock) Signals

All PA-4T+ interfaces support both DTE and DCE mode, depending on the mode of the interface cable attached to the port. To use a port as a DTE interface, you need only connect a DTE cable to the port. When the system detects the DTE mode cable, it automatically uses the external timing signal. To use a port in DCE mode, you must connect a DCE interface cable and set the clock speed with the **clock rate** configuration command. You must also set the clock rate to perform a loopback test. This section describes how to set the clock rate on a DCE port and, if necessary, how to invert the clock to correct a phase shift between the data and clock signals. [Table 5-4](#) summarizes some of the commands used to configure the clock rate. See the specific sections that follow for further details.

The PA-4T+ provides four synchronous serial ports, and each port supports full-duplex operations at T1 and E1 speeds. A single port can support up to E2 speeds.

Speed is controlled by three variables:

- the number of ports in use
- the maximum speed allowed by the port adapter
- the maximum speed of the attached CSU/DSU.

The CSU/DSU determines the maximum speed of the full-duplex port. No configuration is necessary. If a CSU/DSU runs at a maximum speed of 1.55 Mbps (T1 speed), using only one port in the port adapter will not make this CSU/DSU run at E2 speed. On the other hand, if a CSU/DSU is capable of E2 speed (8 Mbps), this CSU/DSU will take the maximum bandwidth of the port adapter. To ensure this speed, no other port can be used. If you use another port, the speed of the CSU/DSU capable of E2 speed is reduced, because the port adapter shares the bandwidth between the two ports.

The PA-4T+ maximum speed can be attained only if the maximum aggregate speed per port adapter is 8 Mbps (E2) when only one full-duplex port is in use. When two full-duplex ports are in use, the maximum speed for each is 4 Mbps. When four full-duplex ports are in use, the maximum speed for each is 1.55 Mbps (T1) or 2.048 Mbps (E1).

Table 5-4 Clock Rate Configuration Commands

Purpose	Command	Example	Additional Information
Set standard clock rate.	clock rate	The example is for a serial interface with a standard clock rate of 72 kbps. Router(config)# interface serial 3/0 Router(config-if)# clock rate 7200	“Setting the Clock Rate”
Set nonstandard clock rate.	clock rate	The example is for a serial interface with a nonstandard clock rate of 1234567 kbps. Router(config)# interface serial 3/0 Router(config-if)# clock rate 1234567	“Setting the Clock Rate”
Remove a clock rate that has been set.	no clock rate	The example is for a serial interface and removes a standard clock rate of 72 kbps. Router(config)# interface serial 3/0 Router(config-if)# clock rate 7200 Router(config-if)# no clock rate	“Setting the Clock Rate”
Invert the transmit clock signal.	invert-txc	The example inverts the transmit clock signal for a serial interface. Router(config)# interface serial 3/0 Router(config-if)# invert-txc	“Inverting the Clock Signal”
Change the clock signal back to its original phase.	no invert-txc	The example sets the transmit clock signal for a serial interface back to its original phase. Router(config)# interface serial 3/0 Router(config-if)# no invert-txc	“Inverting the Clock Signal”
Invert the data signal.	invert data	The example inverts the data stream for both transmit and receive for a serial interface: Router(config)# interface serial 3/0 Router(config-if)# invert-txc	“Inverting the Data Signal”

Setting the Clock Rate

The default operation on a PA-4T+ DCE interface is for the DCE device to generate its own clock signal (TxC) and send it to the remote DTE. The remote DTE device returns the clock signal to the DCE (PA-4T+). Set the clock rate of an interface using the **clock rate** subcommand, which specifies the clock rate as a bits-per-second value. This subcommand functions in the same way on all supported platforms.

Before you can assign a clock rate, you must use the **interface serial** command (followed by the interface address of the interface) to select the interface to which you want to assign the clock rate value.

In the following example, the clock rate is specified as 72 kbps:

```
Router(config-if)# clock rate 72000
```

The preceding command example applies to all systems in which the PA-4T+ is supported. Use the **no clock rate** command to remove the clock rate.

Following are the standard clock rates:

```
1200, 2400, 4800, 9600, 19200 38400, 56000, 64000,  
72000, 125000 148000, 250000, 500000, 800000, 1000000,  
1300000, 2000000, 4000000, 8000000
```

When you have finished, press **Ctrl-Z**—hold down the **Control** key while you press **Z**—or enter **end** or **exit** to exit configuration mode and return to the EXEC command interpreter prompt. Then write the new configuration to NVRAM using the **copy running-config startup-config** command.



Note

Cisco IOS Release 11.2(7a)P or later, or 11.1(10)CA or later loaded on your Cisco 7200 series router, Cisco 7000 series router, or Cisco 7500 series router with a VIP2-40(=) support nonstandard clock rates (any value from 1200 to 8000000) on PA-4T+ interfaces.

Cisco IOS Release 12.0(3)T or later, or 12.0(1)XE or later support nonstandard clock rates on PA-4T+ interfaces installed in Cisco 7204VXR router and Cisco 7206VXR router.

Cisco IOS Release 11.3(6)NA or later loaded on your Cisco uBR7200 series router supports nonstandard clock rates (any value from 1200 to 8000000) on PA-4T+ interfaces.

Set a nonstandard clock rate for an interface using the **clock rate** subcommand. Before you can assign a nonstandard clock rate, you must use the **interface serial** command (followed by the interface address of the interface) to select the interface to which you want to assign the nonstandard clock rate value.

In the following example, a nonstandard clock rate of 1234567 bps is specified:

```
Router(config-if)# clock rate 1234567
```

The preceding command example applies to all systems in which the PA-4T+ is supported. Use the **no clock rate** command to remove the clock rate.

When you have finished, press **Ctrl-Z**—hold down the **Control** key while you press **Z**—or enter **end** or **exit** to exit configuration mode and return to the EXEC command interpreter prompt.

Then write the new configuration to NVRAM using the **copy running-config startup-config** command.

The following example shows how to use the **show running-config** command to determine the exact clock rate to which the nonstandard clock rate was rounded:

```
Router# show running-config
Building configuration...
...
!
interface Serial11/0 (interface Serial3/1/0 on a VIP2 or FlexWAN module)

    no ip address
    clockrate 1151526
!
...
```

In the preceding example, only the relevant output from the **show running-config** command is shown; other information is omitted.

Inverting the Clock Signal

Systems that use long cables or cables that are not transmitting the TxC (clock) signal might experience high error rates when operating at higher transmission speeds. If a PA-4T+ DCE port is reporting a high number of error packets, a phase shift might be the problem. Inverting the clock might correct this shift.

When the PA-4T+ interface is a DTE, the **invert-txc** command inverts the TxC signal it receives from the remote DCE. When the PA-4T+ interface is a DCE, this command inverts the clock signal to the remote DTE port. Use the **no invert-txc** command to change the clock signal back to its original phase.

Inverting the Data Signal

If the interface on the PA-4T+ synchronous serial port adapter is used to drive a dedicated T1 line that does not have B8ZS encoding (a method to avoid 15 zeros), the data stream must be inverted (both TxD and RxD) either in the connecting CSU/DSU or the interface. To invert the data stream coming out of the PA-4T+, use the **invert data** command. By inverting the (HDLC) data stream, the HDLC zero insertion algorithm becomes a ones insertion algorithm that satisfies the T1 requirements.



Note

Invert data *only* on the PA-4T+ interface *or* on the CSU/DSU; inverting both cancels out both data inversions.

Configuring NRZI Format

All PA-4T+ interfaces support nonreturn-to-zero (NRZ) and nonreturn-to-zero inverted (NRZI) formats. Both formats use two different voltage levels for transmission. NRZ signals maintain constant voltage levels with no signal transitions (no return to a zero voltage level) during a bit interval and are decoded using absolute values (0 and 1). NRZI uses the same constant signal levels but interprets the absence of data (a space) at the beginning of a bit interval as a signal transition and the presence of data (a mark) as no transition. NRZI uses relational encoding to decode signals rather than determining absolute values.

Table 5-5 summarizes NRZI format commands.

Table 5-5 NRZI Format Commands

Command	Purpose	Example
nrzi-encoding [mark] ¹	Enable NRZI encoding.	The example is for a serial interface with NRZI mark encoding specified: <pre>Router(config)# interface serial 3/0 Router(config-if)# nrzi-encoding mark</pre> The example is for a serial interface with NRZI space encoding specified: <pre>Router(config)# interface serial 3/0 Router(config-if)# nrzi-encoding</pre>
no nrzi-encoding	Disable NRZI encoding.	The example disables NRZI encoding on a serial interface: <pre>Router(config)# interface serial 3/0 Router(config-if)# no nrzi-encoding</pre>

1. *Mark* is an optional argument. When *mark* is used, it means there is no signal transition; there is data (a mark) at the beginning of a bit interval. When *mark* is not used, it means there is a signal transition; there is no data (a space) at the beginning of a bit interval.

NRZ format, the factory default on all interfaces, is most common. NRZI format, which is configured with a software command, is commonly used with EIA/TIA-232 connections in IBM environments.

Enable NRZI encoding on any interface using the **nrzi-encoding [mark]** command, where no argument after the command is interpreted as a signal transition, and **mark** is interpreted as no signal transition. This command functions in the same way on all supported platforms. Before you can enable NRZI encoding, you must use the **interface serial** command (followed by the interface address of the interface) to select the interface on which you want to enable NRZI encoding.

In the example that follows, NRZI encoding with a signal transition—no argument—is specified:

```
Router(config-if)# nrzi-encoding
```

In the example that follows, NRZI encoding with no signal transition—with argument—is specified:

```
Router(config-if)# nrzi-encoding mark
```

Use the **no nrzi-encoding** command to disable NRZI encoding.

When you have finished, press **Ctrl-Z**—hold down the **Control** key while you press **Z**—or enter **end** or **exit** to exit configuration mode and return to the EXEC command interpreter prompt. Then write the new configuration to NVRAM using the **copy running-config startup-config** command.

For complete command descriptions and instructions, refer to the *Configuration Fundamentals Configuration Guide* on Cisco.com.

Configuring Cyclic Redundancy Checks

Cyclic redundancy check (CRC) is an error-checking technique that uses a calculated numeric value to detect errors in transmitted data. All interfaces use a 16-bit CRC (CRC-CITT) by default, but also support a 32-bit CRC. The sender of a data frame calculates the *frame check sequence* (FCS). Before it sends a frame, the sender appends the FCS value to the message. The receiver recalculates the FCS and compares its calculation to the FCS from the sender. If there is a difference between the two calculations, the receiver assumes that a transmission error occurred and sends a request to the sender to resend the frame.

Table 5-6 summarizes CRC commands.

Table 5-6 CRC Commands

Command	Purpose	Example
<code>crc size</code>	Enable 32-bit CRC	The example enables 32-bit CRC on a serial interface: <pre>Router(config)# interface serial 3/0 Router(config-if)# crc 32</pre>
<code>no crc size</code>	Return to default 16-bit CRC.	The example disables 32-bit CRC on a serial interface and returns to the default 16-bit CRC: <pre>Router(config)# interface serial 3/0 Router(config-if)# no crc 32</pre>

Enable 32-bit CRC using the **crc 32** command. Before you can enable 32-bit CRC, you must use the **interface serial** command (followed by the interface address of the interface) to select the interface on which you want to enable 32-bit CRC. This command functions in the same way on all supported platforms.

In the example that follows, 32-bit CRC is specified:

```
Router(config-if)# crc 32
```

The preceding command example applies to all systems in which the PA-4T+ is supported. Use the **no crc 32** command to disable CRC-32 and return the interface to the default CRC-16 (CRC-CITT) setting.

When you have finished, press **Ctrl-Z**—hold down the **Control** key while you press **Z**—or enter **end** or **exit** to exit configuration mode and return to the EXEC command interpreter prompt. Then write the new configuration to NVRAM using the **copy running-config startup-config** command.

For command descriptions, refer to the *Configuration Fundamentals Configuration Guide* on Cisco.com.



Note

If you are configuring a PA-4T+ in a Cisco 7200 series router and you want to configure the interface for half-duplex or Bisync operation, proceed to the next section, “[Configuring Half-Duplex and Binary Synchronous Communications in Cisco 7200 Series Routers](#)”; otherwise, proceed to the “[Checking the Configuration](#)” section on page 5-18.

Configuring Half-Duplex and Binary Synchronous Communications in Cisco 7200 Series Routers

This section explains how to configure PA-4T+ interfaces for half-duplex and Bisync operation in Cisco 7200 series routers, including Cisco 7200 VXR routers and Cisco 7201 routers.



Note

Cisco IOS Release 11.2(7a)P or a later release of 11.2P supports half-duplex and Bisync operation on the PA-4T+ in Cisco 7200 series routers.

Cisco IOS Release 11.1(19)CC1 or a later release of 11.1 CC, or Release 11.3(4)AA or a later release of 11.3AA supports half-duplex and Bisync operation on the PA-4T+ installed in Cisco 7202 routers.

Cisco IOS Release 12.0(3)T or a later release of 12.0T, or Release 12.0(2)XE or a later release of 12.0XE supports half-duplex and Bisync operation on the PA-4T+ in the Cisco 7204VXR router and Cisco 7206VXR router.

The Catalyst RSM/VIP2, Catalyst 6000 family FlexWAN module, Cisco 7100 series routers, Cisco uBR7200 series routers, and the VIP do *not* support half-duplex and Bisync operation on the PA-4T+.

Use the **half-duplex** command to configure PA-4T+ interfaces for half-duplex mode; full-duplex mode is the default for low-speed serial interfaces. Serial DCE interfaces in half-duplex mode can be configured for controlled-carrier mode or constant-carrier mode; constant-carrier mode is the default. Controlled-carrier mode sets the PA-4T+ interface to deactivate data carrier detect (DCD) until a transmission is sent to the interface. After a transmission is received, DCD is activated and the interface waits a user-configured amount of time, and then transmits the data. After the transmission, the interface waits a user-configured amount of time and then deactivates DCD. Constant-carrier mode activates DCD at all times.

Use the **half-duplex controlled-carrier** command to configure a PA-4T+ interface for controlled-carrier mode. Use the **no half-duplex controlled-carrier** command to return the interface to constant-carrier mode.

Follow these steps to configure controlled-carrier mode on a PA-4T+ interface:

- Step 1** Enter configuration mode and specify that the console terminal is the source of the configuration subcommands, as follows:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#
```

- Step 2** Specify the interface to configure for controlled-carrier mode using the **interface serial** subcommand (followed by the interface address of the interface) and then enter the **half-duplex controlled-carrier** subcommand.

The following example is for the first interface of the port adapter in port adapter slot 1:

```
Router(config)# interface serial 1/0
Router(config-if)# half-duplex controlled-carrier
```

- Step 3** Specify the length of the timer delay the interface uses when it is configured for controlled-carrier mode by using the following command:

```
Router(config-if)# half-duplex timer {cts-delay value | cts-drop-timeout value |
dcd-drop-delay value | dcd-txstart-delay value | rts-drop-delay value | rts-timeout value
| transmit-delay value}
```

where *value* is the length of the timer delay in milliseconds.

The following example specifies a Data Carrier Detect (DCD) drop delay of 100 milliseconds on the first interface of a port adapter in port adapter slot 1:

```
Router(config)# interface serial 1/0
Router(config-if)# half-duplex timer dcd-drop-delay 100 ms
```

[Table 5-7](#) lists the default delay settings and the *value* argument for each timer you can use with the **half-duplex timer** command.

Table 5-7 Half-Duplex Timer Default Delay Settings

Timer	Command Syntax	Default Settings ¹
CTS delay ²	half-duplex timer cts-delay	0
CTS drop timeout	half-duplex timer cts-drop-timeout	250
DCD drop delay ³	half-duplex timer dcd-drop-delay	100
DCD transmission start delay	half-duplex timer dcd-txstart-delay	100
RTS drop delay ⁴	half-duplex timer rts-drop-delay	3
RTS timeout	half-duplex timer rts-timeout	3
Transmit delay	half-duplex transmit-delay	0

1. In milliseconds (ms).
2. Clear To Send (CTS).
3. Data Carrier Detect (DCD).
4. Request To Send (RTS).

- Step 4** Complete the configuration by pressing **Ctrl-Z**—hold down the **Control** key while you press **Z**—or entering **end** or **exit** to exit configuration mode and return to the EXEC command interpreter prompt.

Step 5 Write the new configuration to NVRAM as follows:

```
Router# copy running-config startup-config
[OK]
Router#
```

This completes the procedure for configuring controlled-carrier mode on a PA-T4+ interface. For additional information on configuring half-duplex operation on low-speed serial interfaces, refer to the chapter “Configuring Interfaces” of the *Configuration Fundamentals Configuration Guide* on Cisco.com.



Note

To configure PA-4T+ interfaces for Binary Synchronous (Bisync) operation in Cisco 7200 series routers, refer to the “Block Serial Tunneling (BSTUN)” section of the “Configuring Serial Tunnel (STUN) and Block Serial Tunnel (BSTUN)” chapter of the *Bridging and IBM Networking Configuration Guide* on Cisco.com.

Checking the Configuration

After configuring the new interface, use the **show** commands to display the status of the new interface or all interfaces and the **ping** and **loopback** commands to check connectivity.

This section contains the following subsections:

- [Using show Commands to Verify the New Interface Status, page 5-18](#)
- [Using the ping Command to Verify Network Connectivity, page 5-33](#)
- [Using loopback Commands, page 5-34](#)

Using show Commands to Verify the New Interface Status

[Table 5-8](#) demonstrates how you can use the **show** commands to verify that new interfaces are configured and operating correctly and that the PA-4T+ appears in them correctly. Sample displays of the output of selected **show** commands appear in the sections that follow. For complete command descriptions and examples, refer to the publications listed in the “[Related Documentation](#)” section on [page viii](#).



Note

The outputs that appear in this document may not match the output you receive when running these commands. The outputs in this document are examples only.

Table 5-8 Using show Commands

Command	Function	Example
show version or show hardware	Displays system hardware configuration, the number of each interface type installed, Cisco IOS software version, names and sources of configuration files, and boot images	Router# show version
show controllers	Displays all the current interface processors and their interfaces	Router# show controllers
show diag slot Note The <i>slot</i> argument is not required with Catalyst 5000 family switches.	Displays types of port adapters installed in your system and information about a specific port adapter slot, interface processor slot, or chassis slot	Router# show diag 2
show interfaces type 0 or 1/ interface-port-number	Displays status information about a specific type of interface (for example, serial) on a Catalyst RSM/VIP2	Router# show interfaces serial 1/0
show interfaces type module-slot-number/port-adapter-bay-number/ interface-port-number	Displays status information about a specific type of interface (for example, serial) on a Catalyst 6000 family FlexWAN module	Router# show interfaces serial 3/0/0
show interfaces type 3/interface-port-number	Displays status information about a specific type of interface (for example, serial) in a Cisco 7120 series router	Router# show interfaces serial 3/1
show interfaces type 4/interface-port-number	Displays status information about a specific type of interface (for example, serial) in a Cisco 7140 series router	Router# show interfaces serial 4/1
show interfaces type slot-number/interface-port-number	Displays status information about a specific type of interface (for example, serial) on a Cisco 7200 series router, Cisco 7200 VXR routers, Cisco 7201 router, Cisco 7301 router, or Cisco 7401ASR router	Router# show interfaces serial 1/0
show interfaces type 1/interface-port-number	Displays status information about a specific type of interface (for example, serial) in a Cisco uBR7223 router	Router# show interfaces serial 1/1

Table 5-8 Using show Commands (continued)

Command	Function	Example
show interfaces <i>type 1 or 2/ interface-port-number</i>	Displays status information about a specific type of interface (for example, serial) in a Cisco uBR7246 router	Router# show interfaces serial 2/0
show interfaces <i>type 2 or 3 or 4 or 5/ interface-port-number</i>	Displays status information about a serial interface on a Cisco 7304 PCI Port Adapter Carrier Card in a Cisco 7304 router	Router# show interfaces serial 3/0
show interfaces <i>type interface-processor-slot-number/port-adapter-slot-number/ interface-port-number</i>	Displays status information about a specific type of interface (for example, serial) on a VIP in a Cisco 7000 series or Cisco 7500 series router	Router# show interfaces serial 3/1/0
show protocols	Displays protocols configured for the entire system and for specific interfaces	Router# show protocols
show running-config	Displays the running configuration file	Router# show running-config
show startup-config	Displays the configuration stored in NVRAM	Router# show startup-config

If an interface is shut down and you configured it as up, or if the displays indicate that the hardware is not functioning properly, ensure that the interface is properly connected and terminated. If you still have problems bringing up the interface, contact a service representative for assistance. This section includes the following subsections:

- [Using the show version or show hardware Commands, page 5-20](#)
- [Using the show diag Command, page 5-25](#)
- [Using the show interfaces Command, page 5-28](#)

Choose the subsection appropriate for your system. Proceed to the [“Using the ping Command to Verify Network Connectivity”](#) section on page 5-33 when you have finished using the **show** commands.

Using the show version or show hardware Commands

Display the configuration of the system hardware, the number of each interface type installed, the Cisco IOS software version, the names and sources of configuration files, and the boot images, using the **show version** (or **show hardware**) command.



Note

The outputs that appear in this document may not match the output you receive when running these commands. The outputs in this document are examples only.

The following sections provide platform-specific output examples using the **show version** command:

- [Catalyst RSM/VIP2 in Catalyst 5000 Family Switches—Example Output of the show version Command, page 5-21](#)
- [Catalyst 6000 Family FlexWAN Module in Catalyst 6000 Family Switches—Example Output of the show version Command, page 5-22](#)
- [Cisco 7100 Series Routers, Cisco 7200 Series Routers, Cisco 7200 VXR Routers, and Cisco uBR7200 Series Routers—Example Output of the show version Command, page 5-22](#)
- [Cisco 7201 Router—Example Output of the show version Command, page 5-23](#)
- [Cisco 7401ASR Router—Example Output of the show version Command, page 5-24](#)
- [VIP in Cisco 7000 Series Routers and Cisco 7500 Series Routers—Example Output of the show version Command, page 5-24](#)

Catalyst RSM/VIP2 in Catalyst 5000 Family Switches—Example Output of the show version Command

Following is an example of the **show version** command from a Catalyst 5000 family switch with the PA-4T+ installed:

```
Router# show version

Cisco Internetwork Operating System Software
IOS (tm) GS Software (image-name), Version 11.1(8)CA, RELEASED SOFTWARE
Synced to mainline version: 11.1(8)
Copyright (c) 1986-1997 by cisco Systems, Inc.
Compiled Thu 23-Jan-97 18:14 by bellb
Image text-base: 0x60010900, data-base: 0x609EE000

ROM: System Bootstrap, Version 11.5 [kmac 3.2], RELEASED SOFTWARE
ROM: GS Software (image-name), Released version 11.1(5) [sglee 112]

GEN1 uptime is 2 minutes
System restarted by reload
System image file is "image-name", booted via tftp from 10.10.10.1

cisco RSP2 (R4600) processor with 32768K bytes of memory.
R4600 processor, Implementation 32, Revision 2.0
Last reset from power-on
G.703/E1 software, Version 1.0.
SuperLAT software copyright 1990 by Meridian Technology Corp).
Bridging software.
X.25 software, Version 2.0, NET2, BFE and GOSIP compliant.
TN3270 Emulation software (copyright 1994 by TGV Inc).
Chassis Interface.
1 VIP2 controller (4 Ethernet)(4 Serial).
4 Ethernet/IEEE 802.3 interfaces.
4 Network Serial interfaces.
125K bytes of non-volatile configuration memory.

16384K bytes of Flash PCMCIA card at slot 1 (Sector size 128K).
8192K bytes of Flash internal SIMM (Sector size 256K).
Configuration register is 0x0
```

Catalyst 6000 Family FlexWAN Module in Catalyst 6000 Family Switches—Example Output of the show version Command

Following is an example of the **show version** command from a Catalyst 6000 family switch with a PA-4T+ installed:

```
Router# show version

Cisco Internetwork Operating System Software
IOS (tm) MSFC Software (C6MSFC-JSV-M), Experimental Version 12.1(20000209:134547)
[amcrae-cosmos_e_nightly 163]
Copyright (c) 1986-2000 by cisco Systems, Inc.
Compiled Wed 09-Feb-00 07:10 by
Image text-base: 0x60008900, data-base: 0x6140E000

ROM: System Bootstrap, Version 12.0(3)XE, RELEASE SOFTWARE

const-uut uptime is 5 minutes
System returned to ROM by reload
System image file is "bootflash:c6msfc-jsv-mz.Feb9"

cisco Cat6k-MSFC (R5000) processor with 122880K/8192K bytes of memory.
Processor board ID SAD03457061
R5000 CPU at 200Mhz, Implementation 35, Rev 2.1, 512KB L2 Cache
Last reset from power-on
Channelized E1, Version 1.0.
Bridging software.
X.25 software, Version 3.0.0.
SuperLAT software (copyright 1990 by Meridian Technology Corp).
TN3270 Emulation software.
Primary Rate ISDN software, Version 1.1.
6 FlexWAN controllers (13 Serial)(8 E1)(8 T1)(2 HSSI)(2 ATM)(1 Channelized T3)(1
Channelized E3)(2 POS).
1 Virtual Ethernet/IEEE 802.3 interface(s)
17 Serial network interface(s)
2 HSSI network interface(s)
2 ATM network interface(s)
2 Packet over SONET network interface(s)
1 Channelized T3 port(s)
1 Channelized E3 port(s)
123K bytes of non-volatile configuration memory.
4096K bytes of packet SRAM memory.

16384K bytes of Flash internal SIMM (Sector size 256K).
Configuration register is 0x1
```

Cisco 7100 Series Routers, Cisco 7200 Series Routers, Cisco 7200 VXR Routers, and Cisco uBR7200 Series Routers—Example Output of the show version Command

Following is an example of the **show version** command from a Cisco 7200 series router with a PA-4T+ installed:

```
Router# show version

Cisco Internetwork Operating System Software
IOS (tm) 7200 Software (C7200-J-M), RELEASED VERSION 11.1(8)CA [sglee 108]
Synced to mainline version: 11.1
Copyright (c) 1986-1997 by cisco Systems, Inc.
Compiled Thu 27-Feb-97 23:54 by sglee
Image text-base: 0x600088F0, data-base: 0x6072C000

ROM: System Bootstrap, Version 11.1(5) RELEASED SOFTWARE
ROM: 7200 Software (software-image), Released Version 11.1(8)CA [sglee 101]
```

```

pulp uptime is 2 hours, 19 minutes
System restarted by reload
System image file is "image-name", booted via tftp from 10.10.10.1

cisco 7206 (NPE150) processor with 26624K/6144K bytes of memory.
R4700 processor, Implementation 33, Revision 1.0 (512KB Level 2 Cache)
Last reset from power-on
Bridging software.
SuperLAT software copyright 1990 by Meridian Technology Corp).
X.25 software, Version 2.0, NET2, BFE and GOSIP compliant.
TN3270 Emulation software (copyright 1994 by TGV Inc).
Chassis Interface.
3 Ethernet/IEEE 802.3 interfaces.
1 FastEthernet/IEEE 802.3 interface.
4 Serial interfaces.
125K bytes of non-volatile configuration memory.
1024K bytes of packet SRAM memory.

8192K bytes of Flash PCMCIA card at slot 0 (Sector size 128K).
4096K bytes of Flash internal SIMM (Sector size 256K).
Configuration register is 0x0

```

Cisco 7201 Router—Example Output of the show version Command

Following is an example of the **show version** command from a Cisco 7201 router:

```

Router# show version

Cisco IOS Software, 7200 Software (C7200P-ADVENTERPRISEK9-M), Version
12.4(biffDEV.061001), INTERIM SOFTWARE Copyright (c) 1986-2006 by Cisco Systems, Inc.
Compiled Sun 01-Oct-06 23:42 by biff
ROM: System Bootstrap, Version 12.4(4r)XD5, RELEASE SOFTWARE (fc1)
BOOTLDR: Cisco IOS Software, 7200 Software (C7200P-KBOOT-M), Version 12.4(TAZ3DEV.060927),
INTERIM SOFTWARE
c7201alpha1 uptime is 5 days, 18 hours, 32 minutes System returned to ROM by power-on
System image file is "disk0:c7200p-adventerprisek9-mz.2006-10-01.biffdev"
This product contains cryptographic features and is subject to United States and local
country laws governing import, export, transfer and use. Delivery of Cisco cryptographic
products does not imply third-party authority to import, export, distribute or use
encryption.
Importers, exporters, distributors and users are responsible for compliance with U.S. and
local country laws. By using this product you agree to comply with applicable laws and
regulations. If you are unable to comply with U.S. and local laws, return this product
immediately.
A summary of U.S. laws governing Cisco cryptographic products may be found at:
http://www.cisco.com/wwl/export/crypto/tool/stqrg.html
If you require further assistance please contact us by sending email to export@cisco.com.
Cisco 7201 (c7201) processor (revision A) with 917504K/65536K bytes of memory.
Processor board ID 222222222222
MPC7448 CPU at 1666Mhz, Implementation 0, Rev 2.2
1 slot midplane, Version 2.255
Last reset from power-on
1 FastEthernet interface
4 Gigabit Ethernet interfaces
2045K bytes of NVRAM.
62443K bytes of USB Flash usbflash0 (Read/Write)
250880K bytes of ATA PCMCIA card at slot 0 (Sector size 512 bytes).
65536K bytes of Flash internal SIMM (Sector size 512K).
Configuration register is 0x2

```

Cisco 7401ASR Router—Example Output of the show version Command

Following is an example of the **show version** command from a Cisco 7401ASR router with a PA-4T+ installed:

```
Router# show version

Cisco Internetwork Operating System Software
IOS (tm) 7401ASR Software (C7401ASR-J-M), RELEASED VERSION 11.1(8)CA [sglee 108]
Synced to mainline version: 11.1
Copyright (c) 1986-1997 by cisco Systems, Inc.
Compiled Thu 27-Feb-97 23:54 by sglee
Image text-base: 0x600088F0, data-base: 0x6072C000

ROM: System Bootstrap, Version 11.1(5) RELEASED SOFTWARE
ROM: 7401ASR Software (software-image), Released Version 11.1(8)CA [sglee 101]

pulp uptime is 2 hours, 19 minutes
System restarted by reload
System image file is "image-name", booted via tftp from 10.10.10.1

cisco 7206 (NPE150) processor with 26624K/6144K bytes of memory.
R4700 processor, Implementation 33, Revision 1.0 (512KB Level 2 Cache)
Last reset from power-on
Bridging software.
SuperLAT software copyright 1990 by Meridian Technology Corp).
X.25 software, Version 2.0, NET2, BFE and GOSIP compliant.
TN3270 Emulation software (copyright 1994 by TGV Inc).
Chassis Interface.
3 Ethernet/IEEE 802.3 interfaces.
1 FastEthernet/IEEE 802.3 interface.
4 Serial interfaces.
125K bytes of non-volatile configuration memory.
1024K bytes of packet SRAM memory.

8192K bytes of Flash PCMCIA card at slot 0 (Sector size 128K).
4096K bytes of Flash internal SIMM (Sector size 256K).
Configuration register is 0x0
```

VIP in Cisco 7000 Series Routers and Cisco 7500 Series Routers—Example Output of the show version Command

Following is an example of the **show version** command from a Cisco 7500 series router with a PA-4T+ installed:

```
Router# show version

Cisco Internetwork Operating System Software
IOS (tm) GS Software (image-name), Version 11.1(8)CA, RELEASED SOFTWARE
Synced to mainline version: 11.1(8)
Copyright (c) 1986-1997 by cisco Systems, Inc.
Compiled Thu 23-Jan-97 18:14 by bellb
Image text-base: 0x60010900, data-base: 0x609EE000

ROM: System Bootstrap, Version 11.5 [kmac 3.2], RELEASED SOFTWARE
ROM: GS Software (image-name), Released version 11.1(5) [sglee 112]

GEN1 uptime is 2 minutes
System restarted by reload
System image file is "image-name", booted via tftp from 10.10.10.1

cisco RSP2 (R4600) processor with 32768K bytes of memory.
R4600 processor, Implementation 32, Revision 2.0
```

```
Last reset from power-on
G.703/E1 software, Version 1.0.
SuperLAT software copyright 1990 by Meridian Technology Corp).
Bridging software.
X.25 software, Version 2.0, NET2, BFE and GOSIP compliant.
TN3270 Emulation software (copyright 1994 by TGV Inc).
Chassis Interface.
1 VIP2 controller (4 Ethernet)(4 Serial).
4 Ethernet/IEEE 802.3 interfaces.
4 Network Serial interfaces.
125K bytes of non-volatile configuration memory.

16384K bytes of Flash PCMCIA card at slot 1 (Sector size 128K).
8192K bytes of Flash internal SIMM (Sector size 256K).
Configuration register is 0x0
```

Using the show diag Command

Display the types of port adapters installed in your system (and specific information about each) using the **show diag slot** command, where *slot* is the *port adapter slot* in a Catalyst 5000 family switch, a Cisco 7100 series router, Cisco 7200 series router, Cisco 7200 VXR router, Cisco uBR7200 series, Cisco 7201 router, Cisco 7301 router, and Cisco 7401ASR router, the *module slot* in a Cisco 7304 PCI Port Adapter Carrier Card in a Cisco 7304 router, and the *interface processor slot* in a Cisco 7000 series router or Cisco 7500 series router with a VIP. In the FlexWAN module, the **show diag** command is used without the *slot* designation.



Note

The outputs that appear in this document may not match the output you receive when running these commands. The outputs in this document are examples only.



Note

The *slot* argument is not required for Catalyst 5000 family switches.

The following sections provide platform-specific output examples using the **show diag** command:

- [Catalyst RSM/VIP2 in Catalyst 5000 Family Switches—Example Output of the show diag Command, page 5-26](#)
- [Catalyst 6000 Family FlexWAN Module—Example Output of the show diag Command, page 5-26](#)
- [Cisco 7100 Series Routers, Cisco 7200 Series Routers, Cisco 7200 VXR Routers, and Cisco uBR7200 Series Routers—Example Output of the show diag Command, page 5-26](#)
- [Cisco 7201 Router—Example Output of the show diag Command, page 5-27](#)
- [Cisco 7401ASR Router—Example Output of the show diag Command, page 5-27](#)
- [VIP in Cisco 7000 Series Routers and Cisco 7500 Series Routers—Example Output of the show diag Command, page 5-28](#)

Catalyst RSM/VIP2 in Catalyst 5000 Family Switches—Example Output of the show diag Command

Following is an example of the **show diag** command that shows a PA-4T+ installed in a Catalyst RSM/VIP2:

```
Router# show diag 0
Slot 0:
  Physical slot 0, ~physical slot 0x6, logical slot 0, CBus 0
  Microcode Status 0xC
  Master Enable, LED, WCS Loaded
  Board is analyzed
  Pending I/O Status: Console I/O
  EEPROM format version 1
  VIP2 controller, HW rev 2.2, board revision UNKNOWN
  Serial number: 03517093 Part number: 73-1684-03
  Test history: 0x00          RMA number: 00-00-00
  Flags: cisco 7000 board; 7500 compatible

  EEPROM contents (hex):
    0x20: 01 15 02 03 00 35 AA A5 49 06 94 03 00 00 00 00
    0x30: 50 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

  Slot database information:
  Flags: 0x4          Insertion time: 0x5314 (01:20:55 ago)
[Additional display text omitted]
```

Catalyst 6000 Family FlexWAN Module—Example Output of the show diag Command

Following is an example of the **show diag** command that shows a PA-4T+ installed in a Catalyst 6000 family FlexWAN module:

```
Router# show diag

[Additional display text omitted]

Slot 8: Logical_index 17
  Board is analyzed ipc ready FlexWAN controller

  Slot database information:
  Flags: 0x2004Insertion time: unknown

  CWAN Controller Memory Size: Unknown

  PA Bay 1 Information:
    Mx Serial PA, 8 ports
    EEPROM format version 0
    HW rev 0.00, Board revision UNKNOWN
    Serial number: 00000000 Part number: 00-0000-00
```

Cisco 7100 Series Routers, Cisco 7200 Series Routers, Cisco 7200 VXR Routers, and Cisco uBR7200 Series Routers—Example Output of the show diag Command

Following is an example of the **show diag** command that shows a PA-4T+ installed in port adapter slot 1 of a Cisco 7200 series router:

```
Router# show diag 1
Slot 1:
  Mueslix serial (RS232) port adapter, 8 ports
  Port adapter is analyzed
  Port adapter insertion time 2d09h ago
```

```

Hardware revision 255.255                Board revision UNKNOWN
Serial number 4294967295                Part number 255-65535-255
Test history 0xFF                       RMA number 255-255-255
EEPROM format version 1
EEPROM contents (hex):
0x20: 01 0D FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x30: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

```

Cisco 7201 Router—Example Output of the show diag Command

Following is an example of the **show diag** command from a Cisco 7201 router:

```

Router# show diag 1
Slot 1:
Dual OC3 POS Port adapter, 2 ports
Port adapter is analyzed
Port adapter insertion time 00:02:19 ago
EEPROM contents at hardware discovery:
Hardware Revision : 1.0
PCB Serial Number : JAE07520DYL
Part Number : 73-8220-02
Board Revision : A0
RMA Test History : 00
RMA Number : 0-0-0-0
RMA History : 00
Deviation Number : 0
Product (FRU) Number : PA-POS-2OC3
Top Assy. Part Number : 800-21857-02
EEPROM format version 4
EEPROM contents (hex):
0x00: 04 FF 40 03 E3 41 01 00 C1 8B 4A 41 45 30 37 35
0x10: 32 30 44 59 4C 82 49 20 1C 02 42 41 30 03 00 81
0x20: 00 00 00 00 04 00 88 00 00 00 00 00 CB 94 50 41 2D
0x30: 50 4F 53 2D 32 4F 43 33 20 20 20 20 20 20 20 20
0x40: 20 C0 46 03 20 00 55 61 02 FF FF FF FF FF FF FF
0x50: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x60: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x70: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

```

Cisco 7401ASR Router—Example Output of the show diag Command

Following is an example of the **show diag** command that shows a PA-4T+ installed in port adapter slot 1 of a Cisco 7401ASR router:

```

Router# show diag 1
Slot 1:
Mueslix serial (RS232) port adapter, 8 ports
Port adapter is analyzed
Port adapter insertion time 2d09h ago
Hardware revision 255.255                Board revision UNKNOWN
Serial number 4294967295                Part number 255-65535-255
Test history 0xFF                       RMA number 255-255-255
EEPROM format version 1
EEPROM contents (hex):
0x20: 01 0D FF FF FF FF FF FF FF FF FF FF FF FF FF FF
0x30: FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF FF

```

VIP in Cisco 7000 Series Routers and Cisco 7500 Series Routers—Example Output of the show diag Command

Following is an example of the **show diag** command that shows a PA-4T+ installed in port adapter slot 0 on a VIP in interface processor slot 3:

```
Router# show diag 3
Slot 3:
  Physical slot 3, ~physical slot 0x6, logical slot 3, CBus 0
  Microcode Status 0xC
  Master Enable, LED, WCS Loaded
  Board is analyzed
  Pending I/O Status: Console I/O
  EEPROM format version 1
  VIP2 controller, HW rev 2.2, board revision UNKNOWN
  Serial number: 03517093 Part number: 73-1684-03
  Test history: 0x00          RMA number: 00-00-00
  Flags: cisco 7000 board; 7500 compatible

  EEPROM contents (hex):
    0x20: 01 15 02 03 00 35 AA A5 49 06 94 03 00 00 00 00
    0x30: 50 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00

  Slot database information:
  Flags: 0x4          Insertion time: 0x5314 (01:20:55 ago)

  Controller Memory Size: 8 MBytes DRAM, 1024 KBytes SRAM

  PA Bay 0 Information:
    Mx Serial PA, 4 ports
    EEPROM format version 1
    HW rev 1.0, Board revision 154
    Serial number: 03699540 Part number: 73-1577-03

  PA Bay 1 Information:
    Ethernet PA, 4 ports
    EEPROM format version 1
    HW rev 1.0, Board revision 160
    Serial number: 02023164 Part number: 73-1556-03
```

Using the show interfaces Command

Display status information (including the physical slot and interface address) for the interfaces you specify using the **show interfaces** command.

For complete descriptions of interface subcommands and the configuration options available for the individual platforms, refer to the publications listed in the [“Related Documentation” section on page viii](#).



Note

The outputs that appear in this document may not match the output you receive when running these commands. The outputs in this document are examples only.

The following sections provide platform-specific output examples using the **show interfaces** command:

- [Catalyst RSM/VIP2 in Catalyst 5000 Family Switches—Example Output of the show interfaces Command, page 5-29](#)
- [Catalyst 6000 Family FlexWAN Module in Catalyst 6000 Family Switches—Example Output of the show interfaces Command, page 5-30](#)

- [Cisco 7100 Series Routers, Cisco 7200 Series Routers, Cisco 7200 VXR Routers, and Cisco uBR7200 Series Routers—Example Output of the show interfaces Command, page 5-30](#)
- [Cisco 7201 Router—Example Output of the show interfaces Command, page 5-31](#)
- [Cisco 7401ASR Router—Example Output of the show interfaces Command, page 5-32](#)
- [VIP in Cisco 7000 Series Routers or Cisco 7500 Series Routers—Example Output of the show interfaces Command, page 5-32](#)

Catalyst RSM/VIP2 in Catalyst 5000 Family Switches—Example Output of the show interfaces Command

Following are examples of the **show interfaces serial** command for a Catalyst 5000 Family switch. In these examples, the eight serial interfaces (0 to 7) are on a port adapter in port adapter slot 1 of a Catalyst RSM/VIP2; also, most of the status information for each interface is omitted. (Interfaces are administratively shut down until you enable them.)

```
Router# show interfaces serial 1/0
Serial1/0 is up, line protocol is up
  Hardware is cyBus Serial
  Internet address is 10.10.10.1
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation PPP, loopback not set, keepalive set (10 sec)
[Additional display text for remaining interfaces omitted]
```

```
Router# show interfaces serial 1/1
Serial1/1 is up, line protocol is up
  Hardware is cyBus Serial
  Internet address is 10.10.10.2
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation PPP, loopback not set, keepalive set (10 sec)
[Additional display text for remaining interfaces omitted]
```

```
Router# show interfaces serial 1/2
Serial1/2 is up, line protocol is up
  Hardware is cyBus Serial
  Internet address is 10.10.10.3
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation PPP, loopback not set, keepalive set (10 sec)
[Additional display text for remaining interfaces omitted]
```

```
Router# show interfaces serial 1/3
Serial1/3 is up, line protocol is up
  Hardware is cyBus Serial
  Internet address is 10.10.10.3
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation PPP, loopback not set, keepalive set (10 sec)
[Additional display text for remaining interfaces omitted]
```

Catalyst 6000 Family FlexWAN Module in Catalyst 6000 Family Switches—Example Output of the show interfaces Command

Following is an example of the **show interfaces serial** command for a Catalyst 6000 Family FlexWAN module in a Catalyst 6000 family switch. This example shows all of the information specific to interface port 0 on a PA-4T+ installed in port adapter slot 8 (interfaces are administratively shut down until you enable them):

```
Router# show interfaces serial 8/1/0
Serial8/1/0 is administratively down, line protocol is down
  Hardware is Serial
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec,
    reliability 255/255, txload 1/255, rxload 1/255
  Encapsulation HDLC, crc 16, loopback not set
  Keepalive not set
  Last input never, output never, output hang never
  Last clearing of "show interface" counters never
  Queueing strategy: fifo
  Output queue 0/40, 0 drops; input queue 0/75, 0 drops
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
    0 packets input, 0 bytes, 0 no buffer
  Received 0 broadcasts, 0 runts, 0 giants, 0 throttles
  0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
  0 packets output, 0 bytes, 0 underruns
  0 output errors, 0 collisions, 0 interface resets
  0 output buffer failures, 0 output buffers swapped out
  0 carrier transitions
  RTS down, CTS down, DTR down, DCD down, DSR down
```

Cisco 7100 Series Routers, Cisco 7200 Series Routers, Cisco 7200 VXR Routers, and Cisco uBR7200 Series Routers—Example Output of the show interfaces Command

Following are examples of the **show interfaces serial** command from a Cisco 7100 series routers. In these examples, the eight serial interfaces (0 to 7) are on a port adapter in port adapter slot 1; also, most of the status information for each interface is omitted. (Interfaces are administratively shut down until you enable them.)

```
Router# show interfaces serial 1/0
Serial1/0 is up, line protocol is up
  Hardware is M4T
  Internet address is 10.10.10.1
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation PPP, loopback not set, keepalive set (10 sec)
(display text omitted)
```

```
Router# show interfaces serial 1/1
Serial1/1 is up, line protocol is up
  Hardware is M4T
  Internet address is 10.10.10.2
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation PPP, loopback not set, keepalive set (10 sec)
(display text omitted)
```

```
Router# show interfaces serial 1/2
Serial1/2 is up, line protocol is up
  Hardware is M4T
  Internet address is 10.10.10.3
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation PPP, loopback not set, keepalive set (10 sec)
(display text omitted)
```

```

Router# show interfaces serial 1/3
Serial1/3 is up, line protocol is up
  Hardware is M4T
  Internet address is 10.10.10.4
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation PPP, loopback not set, keepalive set (10 sec)
(display text omitted)

```

Following is an example of the **show interfaces serial** command, which shows all of the information specific to interface port 0 on a PA-4T+ installed in port adapter slot 1:

```

Router# show interfaces serial 1/0
Serial1/0 is up, line protocol is up
  Hardware is M4T
  Internet address is 10.10.10.1
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation PPP, loopback not set, keepalive set (10 sec)
  LCP Open
  Open: ipcp
  Last input 00:00:09, output 00:00:09, output hang never
  Last clearing of "show interface" counters never
  Input queue: 0/75/0 (size/max/drops); Total output drops: 0
  Queueing strategy: weighted fair
  Output queue: 0/64/0 (size/threshold/drops)
    Conversations 0/1 (active/max active)
    Reserved Conversations 0/0 (allocated/max allocated)
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
    1675 packets input, 26792 bytes, 0 no buffer
    Received 0 broadcasts, 0 runts, 0 giants
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
    1676 packets output, 26806 bytes, 0 underruns
    0 output errors, 0 collisions, 3 interface resets
    0 output buffer failures, 0 output buffers swapped out
    0 carrier transitions      DCD=up DSR=up DTR=up RTS=up CTS=up

```

Cisco 7201 Router—Example Output of the show interfaces Command

Following is an example of the **show interfaces** command from a Cisco 7201 router:

```

Router# show interfaces
GigabitEthernet0/0 is up, line protocol is up
  Hardware is MV64460 Internal MAC, address is 0019.56c5.2adb (bia
0019.56c5.2adb)
  Internet address is 209.165.200.225
  MTU 1500 bytes, BW 1000000 Kbit, DLY 10 usec,
    reliability 255/255, txload 1/255, rxload 45/255
  Encapsulation ARPA, loopback not set
  Keepalive set (10 sec)
  Full-duplex, 1000Mb/s, media type is RJ45
  output flow-control is XON, input flow-control is XON
  ARP type: ARPA, ARP Timeout 04:00:00
  Last input 00:07:03, output 00:00:07, output hang never
  Last clearing of "show interface" counters 00:00:04
  Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
  Queueing strategy: fifo
  Output queue: 0/40 (size/max)
  5 minute input rate 180240000 bits/sec, 430965 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
    2222975 packets input, 133378500 bytes, 0 no buffer
    Received 0 broadcasts, 0 runts, 0 giants, 0 throttles
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored

```

```

0 watchdog, 0 multicast, 0 pause input
0 input packets with dribble condition detected
0 packets output, 0 bytes, 0 underruns
0 output errors, 0 collisions, 0 interface resets
0 babbles, 0 late collision, 0 deferred
0 lost carrier, 0 no carrier, 0 pause output
0 output buffer failures, 0 output buffers swapped out

```

Cisco 7401ASR Router—Example Output of the show interfaces Command

Following is an example of the **show interfaces serial** command from a Cisco 7401ASR router, which shows all of the information specific to interface port 0 on a PA-4T+ installed in port adapter slot 1:

```

Router# show interfaces serial 1/0
Serial1/0 is up, line protocol is up
  Hardware is M4T
  Internet address is 10.10.10.1
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation PPP, loopback not set, keepalive set (10 sec)
  LCP Open
  Open: ipcp
  Last input 00:00:09, output 00:00:09, output hang never
  Last clearing of "show interface" counters never
  Input queue: 0/75/0 (size/max/drops); Total output drops: 0
  Queueing strategy: weighted fair
  Output queue: 0/64/0 (size/threshold/drops)
    Conversations 0/1 (active/max active)
    Reserved Conversations 0/0 (allocated/max allocated)
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
    1675 packets input, 26792 bytes, 0 no buffer
    Received 0 broadcasts, 0 runts, 0 giants
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
    1676 packets output, 26806 bytes, 0 underruns
    0 output errors, 0 collisions, 3 interface resets
    0 output buffer failures, 0 output buffers swapped out
    0 carrier transitions      DCD=up DSR=up DTR=up RTS=up CTS=up

```

VIP in Cisco 7000 Series Routers or Cisco 7500 Series Routers—Example Output of the show interfaces Command

Following are examples of the **show interfaces serial** command from a VIP. In these examples, the eight serial interfaces (0 to 7) are on a port adapter in port adapter slot 1 of a VIP in interface processor slot 3; also, most of the status information for each interface is omitted. (Interfaces are administratively shut down until you enable them.)

```

Router# show interfaces serial 3/1/0
Serial3/1/0 is up, line protocol is up
  Hardware is cyBus Serial
  Internet address is 10.0.0.0
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation HDLC, loopback not set, keepalive not set
  [Additional display text omitted from this example]

```

```

Router# show interfaces serial 3/1/1
Serial3/1/1 is up, line protocol is up
  Hardware is cyBus Serial
  Internet address is 10.0.0.1
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation HDLC, loopback not set, keepalive not set
  [Additional display text omitted from this example]

```

```

Router# show interfaces serial 3/1/2
Serial3/1/2 is up, line protocol is up
  Hardware is cyBus Serial
  Internet address is 10.0.0.2
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation HDLC, loopback not set, keepalive not set
  [Additional display text for remaining interfaces omitted]

```

Following is an example of the **show interfaces serial** command, which shows all of the information specific to interface 0 on a port adapter in port adapter slot 1 of a VIP in interface processor slot 3:

```

Router# show interfaces serial 3/1/0
Serial3/1/0 is up, line protocol is up
  Hardware is cyBus Serial
  Internet address is 10.0.0.0
  MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 255/255, load 1/255
  Encapsulation HDLC, loopback not set, keepalive not set
  Last input 2d18h, output 00:00:54, output hang never
  Last clearing of "show interface" counters never
  Input queue: 0/75/0 (size/max/drops); Total output drops: 0
  Queueing strategy: weighted fair
  Output queue: 0/64/0 (size/threshold/drops)
    Conversations 0/1 (active/max active)
    Reserved Conversations 0/0 (allocated/max allocated)
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
    16 packets input, 1620 bytes, 0 no buffer
    Received 0 broadcasts, 0 runts, 0 giants
    0 input errors, 0 CRC, 0 frame, 0 overrun, 1 ignored, 0 abort
    3995 packets output, 1147800 bytes, 0 underruns
    0 output errors, 0 collisions, 0 interface resets
    0 output buffer failures, 0 output buffers swapped out
    1 carrier transitions
  RTS up, CTS up, DTR up, DCD up, DSR up

```

Using the ping Command to Verify Network Connectivity

Using the **ping** command, you can verify that an interface port is functioning properly. This section provides a brief description of this command. Refer to the publications listed in the [“Related Documentation” section on page viii](#) for detailed command descriptions and examples.

The **ping** command sends an echo request out to a remote device at an IP address that you specify. After sending a series of signals, the command waits a specified time for the remote device to echo the signals. Each returned signal is displayed as an exclamation point (!) on the console terminal; each signal that is not returned before the specified time-out is displayed as a period (.). A series of exclamation points (!!!!) indicates a good connection; a series of periods (.....) or the messages [timed out] or [failed] indicate that the connection failed.

Following is an example of a successful **ping** command to a remote server with the address 10.10.10.10:

```

Router# ping 10.10.10.10 <Return>
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echoes to 10.10.10.10, timeout is 2 seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/15/64 ms
Router#

```

If the connection fails, verify that you have the correct IP address for the server and that the server is active (powered on), and repeat the **ping** command.

Using loopback Commands

The loopback test allows you to detect and isolate equipment malfunctions by testing the connection between the PA-4T+ interface and a remote device such as modems or CSU/DSUs. The **loopback** subcommand sends a series of packets out to and through the device (or cable), and back to the PA-4T+ interface. If the packets complete the loop, the connection is good. If not, you can isolate a fault to the remote device or interface cable in the path of the loopback test.

**Note**

You must configure a clock rate on the port *before* performing a loopback test. However, if no cable is attached to the port, the port is administratively up, and the port is in loopback mode, you do not have to configure a clock rate on the port *before* performing a loopback test.

Depending on the mode of the port, issuing the **loopback** command checks the following path:

- When no interface cable is attached to the PA-4T+ interface, or if a DCE cable is attached to a port that is configured as line protocol up, the **loopback** command tests the path between the network processing engine and the interface port only (without leaving the network processing engine and port adapter).
- When a DTE cable is attached to the port, the **loopback** command tests the path between the network processing engine and the near (network processing engine) side of the DSU or modem to test the PA-4T+ interface and interface cable.

**Note**

The X.21 interface definition does not include a loopback definition. On the PA-4T+, the X.21 DTE interface does not support the loopback function. Because of the internal clock signal present on the PA-4T+ interfaces, loopback will function on an X.21 DCE interface.
