



# Rebooting and Reloading - Configuring Image Loading Characteristics

---

The basic processes completed by a Cisco device (such as a router) when it reboots can be specifically configured to improve function and performance by using the ROM monitor.

- [Finding Feature Information, page 1](#)
- [Prerequisites for Rebooting and Reloading Procedures, page 1](#)
- [Restrictions for Rebooting and Reloading Procedures, page 2](#)
- [Information About Rebooting and Reloading Procedures, page 2](#)
- [How to Configure Rebooting and Reloading Procedures, page 9](#)

## Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see [Bug Search Tool](#) and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table at the end of this module.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to [www.cisco.com/go/cfn](http://www.cisco.com/go/cfn). An account on Cisco.com is not required.

## Prerequisites for Rebooting and Reloading Procedures

- You should have at least a basic familiarity with the Cisco IOS environment and the command-line interface.
- You should have at least a minimal configuration running on your system.

## Restrictions for Rebooting and Reloading Procedures

- You must have your network up and running, with Cisco IOS Release 12.2 or a later release installed.
- Some of the Cisco IOS configuration commands are only available on certain router platforms, and the command syntax may vary on different platforms.

## Information About Rebooting and Reloading Procedures

### Determination of Configuration File the Router Uses for Startup

On all platforms except Class A Flash file system platforms:

- If the configuration register is set to ignore NVRAM, the router enters setup mode.
- If the configuration register is not set to ignore NVRAM,
  - The startup software checks for configuration information in NVRAM.
  - If NVRAM holds valid configuration commands, the Cisco IOS software executes the commands automatically at startup.
  - If the software detects a problem with NVRAM or the configuration it contains (a CRC checksum error), it enters **setup** mode and prompts for configuration.

On Class A Flash file system platforms:

- If the configuration register is set to ignore NVRAM, the router enters setup mode.
- If the configuration register is not set to ignore NVRAM,
  - The startup software uses the configuration pointed to by the CONFIG\_FILE environment variable.
  - When the CONFIG\_FILE environment variable does not exist or is null (such as at first-time startup), the router uses NVRAM as the default startup device.
  - When the router uses NVRAM to start up and the system detects a problem with NVRAM or the configuration it contains, the router enters **setup** mode.

Problems can include a bad checksum for the information in NVRAM or an empty NVRAM with no configuration information.

For more information on environment variables, refer to the “Setting the BOOTLDR Environment Variable” section.

### Determination of Image File the Router Uses for Startup

When a router is powered on or rebooted, the following events happen:

- The ROM monitor initializes.

- The ROM monitor checks the boot field (the lowest four bits) in the configuration register.
  - If the last digit of the boot field is 0 (for example, 0x100), the system does not boot. Instead the system enters ROM monitor mode and waits for user intervention. From ROM monitor mode, you can manually boot the system using the **boot** or **b** command.
  - If the last digit of the boot field is 1 (for example, 0x101), the boot helper image is loaded from ROM. (On some platforms, the boot helper image is specified by the BOOTLDR environment variable.)
  - If the last digit of the boot field is 2 through F (for example, 0x102 through 0x10F), the router boots the first valid image specified in the configuration file or specified by the BOOT environment variable.

**Note**

The configuration register boot field value is expressed in hexadecimal. Because the boot field only encompasses the last four bits (represented by the last hexadecimal digit) of the configuration register value, the only digit we are concerned with in this discussion is the last digit. Consequently, 0x1 (0000 0001) is equivalent to 0x101 (1 0000 0001) in discussions of the boot field, because in both cases the last four bits are 0001.

When the boot field is 0x102 through 0x10F, the router goes through each **bootssystem** command in order until it boots a valid image. If bit 13 in the configuration register is set, each command will be tried once (bit 13 is indicated by the position occupied by *b* in the following hexadecimal notation: 0xb 000). If bit 13 is not set, the **bootssystem** commands specifying a network server will be tried up to five more times. The timeouts between each consecutive attempt are 2, 4, 16, 256, and 300 seconds.

If the router cannot find a valid image, the following events happen:

- If all boot commands in the system configuration file specify booting from a network server and all commands fail, the system attempts to boot the first valid file in Flash memory.
- If the “boot-default-ROM-software” option in the configuration register is set, the router will start the boot image (the image contained in boot ROM or specified by the BOORLDR environment variable).
- If the “boot-default-ROM-software” option in the configuration register is not set, the system waits for user intervention at the ROM monitor prompt. You must boot the router manually.
- If a fully functional system image is not found, the router will not function and must be reconfigured through a direct console port connection.

**Note**

Refer to your platform documentation for information on the default location of the boot image.

When looking for a bootable file in Flash memory:

- The system searches for the filename in Flash memory. If a filename is not specified, the software searches through the entire Flash directory for a bootable file instead of picking only the first file.
- The system attempts to recognize the file in Flash memory. If the file is recognized, the software decides whether it is bootable by performing the following checks:
  - For run-from-Flash images, the software determines whether it is loaded at the correct execution address.

- For run-from-RAM images, the software determines whether the system has enough RAM to execute the image.

The figure below illustrates the basic booting decision process.

**Figure 1: Booting Process**

## How the Router Uses the Boot Field

The lowest four bits of the 16-bit configuration register (bits 3, 2, 1, and 0) form the boot field. The following boot field values determine if the router loads an operating system and where it obtains the system image:

- When the entire boot field equals 0-0-0-0 (0x0), the router does not load a system image. Instead, it enters ROM monitor or “maintenance” mode from which you can enter ROM monitor commands to manually load a system image. Refer to the “Manually Booting from Flash Memory in ROMMON” section for details on ROM monitor mode.
- When the entire boot field equals 0-0-0-1 (0x1), the router loads the boot helper or rxboot image.
- When the entire boot field equals a value between 0-0-1-0 (0x2) and 1-1-1-1 (0xF), the router loads the system image specified by **bootsystem** commands in the startup configuration file. When the startup configuration file does not contain **bootsystem** commands, the router tries to load a default system image stored on a network server.

When loading a default system image from a network server, the router uses the configuration register settings to determine the default system image filename for booting from a network server. The router forms the default boot filename by starting with the word `cisco` and then appending the octal equivalent of the boot field number in the configuration register, followed by a hyphen (-) and the processor type name (`cisconn-cpu`). See the appropriate hardware installation guide for details on the configuration register and the default filename.

## Hardware Versus Software Configuration Register Boot Fields

You modify the boot field from either the hardware configuration register or the software configuration register, depending on the platform.

Most platforms have use a software configuration register. Refer to your hardware documentation for information on the configuration register for your platform.

The hardware configuration register can be changed only on the processor card with dual in-line package (DIP) switches located at the back of the router. For information on modifying the hardware configuration register, refer to the appropriate hardware installation guide.

## Environment Variables

Because many platforms can boot images from several locations, these systems use special ROM monitor environment variables to specify the location and filename of images that the router is to use. In addition, Class A Flash file systems can load configuration files from several locations and use an environment variable to specify startup configurations:

### BOOT Environment Variable

The BOOT environment variable specifies a list of bootable system images on various file systems.

After you save the BOOT environment variable to your startup configuration, the router checks the variable upon startup to determine the device and filename of the image to boot.

The router tries to boot the first image in the BOOT environment variable list. If the router is unsuccessful at booting that image, it tries to boot the next image specified in the list. The router tries each image in the list

until it successfully boots. If the router cannot boot any image in the BOOT environment variable list, the router attempts to boot the boot image.

If an entry in the BOOT environment variable list does not specify a device, the router assumes the device is **tftp**. If an entry in the BOOT environment variable list specifies an invalid device, the router skips that entry.

## BOOTLDR Environment Variable

The BOOTLDR environment specifies the Flash file system and filename containing the boot image that the ROM monitor uses if it cannot find a valid system image. In addition, a boot image is required to boot the router with an image from a network server.

You can change the BOOTLDR environment variable on platforms that use a software boot image rather than boot ROMs. On these platforms, the boot image can be changed without having to replace the boot ROM.

This environment variable allows you to have several boot images. After you save the BOOTLDR environment variable to your startup configuration, the router checks the variable upon startup to determine which boot image to use if the system cannot be loaded.



### Note

---

Refer to your platform documentation for information on the default location of the boot image.

---

## CONFIG\_FILE Environment Variable

For Class A Flash file systems, the CONFIG\_FILE environment variable specifies the file system and filename of the configuration file to use for initialization (startup). Valid file systems can include **nvr**am:, **bootflash**:, **slot0**:, and **slot1**:. Refer to the “Managing Configuration Files” chapter for more information on devices. After you save the CONFIG\_FILE environment variable to your startup configuration, the router checks the variable upon startup to determine the location and filename of the configuration file to use for initialization.

The router uses the NVRAM configuration during initialization when the CONFIG\_FILE environment variable does not exist or when it is null (such as at first-time startup). If the router detects a problem with NVRAM or a checksum error, the router enters **setup** mode.

## Controlling Environment Variables

Although the ROM monitor controls environment variables, you can create, modify, or view them with certain commands. To create or modify the BOOT, BOOTLDR, and CONFIG\_FILE environment variables, use the **boot**system, **boot**bootldr, and **boot**config global configuration commands, respectively.

Refer to the “Specify the Startup System Image in the Configuration File” section in the “Loading and Maintaining System Images” book for details on setting the BOOT environment variable. Refer to the “Specify the Startup Configuration File” section in the “Managing Configuration Files” chapter of this document for details on setting the CONFIG\_FILE variable.

**Note**

When you use these three global configuration commands, you affect only the running configuration. You must save the environment variable settings to your startup configuration to place the information under ROM monitor control and for the environment variables to function as expected. Use the **copysystem:running-confignvram:startup-config** command to save the environment variables from your running configuration to your startup configuration.

You can view the contents of the BOOT, BOOTLDR, and the CONFIG\_FILE environment variables by issuing the **showbootvar** command. This command displays the settings for these variables as they exist in the startup configuration as well as in the running configuration if a running configuration setting differs from a startup configuration setting.

Use the **morenvram:startup-config** command to display the contents of the configuration file pointed to by the CONFIG\_FILE environment variable.

## Manually Loading a System Image from ROM Monitor

If your router does not find a valid system image, or if its configuration file is corrupted at startup, or the configuration register is set to enter ROM monitor mode, the system enters ROM monitor mode. From this mode, you can manually load a system image from the following locations:

- Internal Flash memory or a Flash memory PC card
- A network server file
- ROM
- A local or remote computer, using the Xmodem or Ymodem protocol (Cisco 1600 series and Cisco 3600 series routers only)

You may only boot from a location if the router can store an image there. Therefore, not all platforms can manually load from these locations.

You can also enter ROM monitor mode by restarting the router and then pressing the **Break** key or issuing a “send break” command from a telnet session during the first 60 seconds of startup.

**Note**

Versions of ROMMON are forward compatible with versions released subsequent to it. ROMMON is not backward compatible with previous releases. It isn't possible to roll-back ROMMON to a previous version.

## Aliasing ROM Monitoring Commands

The ROM monitor supports command aliasing modeled on the aliasing function built into the Korn shell. The **alias** command is used to set and view aliased names. This allows the user to alias command names to a letter or word. Aliasing is often used to shorten command names or automatically invoke command options.

Aliases are stored in NVRAM and remain intact across periods of no power. These are some of the set aliases:

- **b** --boot
- **h** --history

- **i** --initialize/reset
- **r** --repeat
- **k** --stack
- **?** --help

The following example shows a pre-aliased menu-type list for ROMMON commands:

```
> ?
$ state      Toggle cache state (? for help)
B [filename] [TFTP Server IP address | TFTP Server Name]
              Load and execute system image from ROM or from TFTP server
C [address]  Continue execution [optional address]
D /S M L V   Deposit value V of size S into location L with modifier M
E /S M L     Examine location L with size S with modifier M
G [address]  Begin execution
H           Help for commands
I           Initialize
K           Stack trace
L [filename] [TFTP Server IP address | TFTP Server Name]
              Load system image from ROM or from TFTP server, but do not
              begin execution
O           Show configuration register option settings
P           Set the break point
S           Single step next instruction
T function   Test device (? for help)
Deposit and Examine sizes may be B (byte), L (long) or S (short).
Modifiers may be R (register) or S (byte swap).
Register names are: D0-D7, A0-A6, SS, US, SR, and PC
```

If your options appear in the above menu-type format, you can use the listed aliased commands. To initialize the router or access server, enter the **i** command. The **i** command causes the bootstrap program to reinitialize the hardware, clear the contents of memory, and boot the system. To boot the system image file, use the **b** command.

The ROM monitor software characteristics will vary depending on your platform. For further details on ROM monitor mode commands, refer to the appropriate hardware installation guide, or perform a search on Cisco.com.

## How to Configure Rebooting and Reloading Procedures

### Displaying Boot Information

To display information about system software, system image files, and configuration files, complete the tasks in this section:

#### SUMMARY STEPS

1. **enable**
2. **show bootvar**
3. **more nvram:startup-config**
4. **show version**

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode.  <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
Step 2	<b>show bootvar</b>  <b>Example:</b> Router# show bootvar	Lists the contents of the BOOT environment variable, the name of the configuration file pointed to by the CONFIG_FILE environment variable, and the contents of the BOOTLDR environment variable.
Step 3	<b>more nvram:startup-config</b>  <b>Example:</b> Router# more nvram:startup-config	Lists the startup configuration information.  On all platforms except the Class A Flash file systems, the startup configuration is usually in NVRAM. On Class A Flash file systems, the CONFIG_FILE environment variable points to the startup configuration, defaulting to NVRAM.
Step 4	<b>show version</b>  <b>Example:</b> Router# show version	Lists the system software release version, system image name, configuration register setting, and other information.  <b>Note</b> You can also use the <b>o</b> command (or the <b>confreg</b> command for some platforms) in ROM monitor mode to list the configuration register settings on some platforms.

## Modifying the Configuration Register Boot Field

To modify the configuration register boot field to determine whether the router loads an operating system image, and if so, where it obtains this system image, complete the tasks in this section:

## SUMMARY STEPS

1. **enable**
2. **show version**
3. **configure terminal**
4. **config-register** *value*
5. **end**
6. **show version**
7. **copy running-config startup-config**
8. **reload**

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<p><b>enable</b></p> <p><b>Example:</b></p> <pre>Router&gt; enable</pre>	<p>Enables privileged EXEC mode.</p> <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
Step 2	<p><b>show version</b></p> <p><b>Example:</b></p> <pre>Router# show version</pre>	<p>Obtains the current configuration register setting. The configuration register is listed as a hexadecimal value.</p>
Step 3	<p><b>configure terminal</b></p> <p><b>Example:</b></p> <pre>Router# configure terminal</pre>	<p>Enters global configuration mode.</p>
Step 4	<p><b>config-register</b> <i>value</i></p> <p><b>Example:</b></p> <pre>Router(config)# config-register 0x0101</pre>	<p>Modify the current configuration register setting to reflect the way in which you want to load a system image. To do so, change the least significant hexadecimal digit to one of the following:</p> <ul style="list-style-type: none"> <li>• 0 to load the system image manually using the <b>bootcommand</b> in ROM monitor mode.</li> <li>• 1 to load the system image from boot ROMs. On the Cisco 7200 series and Cisco 7500 series, this setting configures the system to automatically load the system image from bootflash.</li> <li>• 2-F to load the system image from <b>bootssystem</b> commands in the startup configuration file or from a default system image stored on a network server.</li> </ul> <p>For example, if the current configuration register setting is 0x101 and you want to load a system image from <b>bootssystem</b> commands in the startup configuration file, you would change the configuration register setting to 0x102.</p> <p><b>Note</b> In ROM monitor mode, use the <b>o</b> command or the <b>confreg</b> command on some platforms to list the value of the configuration register boot field.</p>
Step 5	<p><b>end</b></p> <p><b>Example:</b></p> <pre>Router(config)# end</pre>	<p>Exits configuration mode.</p>

	Command or Action	Purpose
<b>Step 6</b>	<b>show version</b>  <b>Example:</b> Router# show version	(Optional) Verifies that the configuration register setting is correct. Repeat steps 2 through 5 if the setting is not correct.
<b>Step 7</b>	<b>copy running-config startup-config</b>  <b>Example:</b> Router# copy running-config startup-config	Saves the running configuration to the startup configuration.
<b>Step 8</b>	<b>reload</b>  <b>Example:</b> Router# reload	(Optional) Reboots the router to make your changes take effect.

## Examples

In the following example, the **showversion** command indicates that the current configuration register is set so that the router does not automatically load an operating system image. Instead, it enters ROM monitor mode and waits for user-entered ROM monitor commands. The new setting instructs the router to load a system image from commands in the startup configuration file or from a default system image stored on a network server.

```

Router1# show version
Cisco IOS (tm) Software
4500 Software (C4500-J-M), Version 11.1(10.4), RELEASE SOFTWARE
Copyright (c) 1986-1997 by Cisco Systems, Inc.
Compiled Mon 07-Apr-97 19:51 by lmiller
Image text-base: 0x600088A0, data-base: 0x60718000
ROM: System Bootstrap, Version 5.1(1), RELEASE SOFTWARE (fc1)
FLASH: 4500-XBOOT Bootstrap Software, Version 10.1(1), RELEASE SOFTWARE (fc1)
Router1 uptime is 6 weeks, 5 days, 2 hours, 22 minutes
System restarted by error - a SegV exception, PC 0x6070F7AC
System image file is "c4500-j-mz.111-current", booted via flash
cisco 4500 (R4K) processor (revision 0x00) with 32768K/4096K bytes of memory.
Processor board ID 01242622
R4600 processor, Implementation 32, Revision 1.0
G.703/E1 software, Version 1.0.
Bridging software.
SuperLAT software copyright 1990 by Meridian Technology Corp).
X.25 software, Version 2.0, NET2, BFE and GOSIP compliant.
TN3270 Emulation software (copyright 1994 by TGV Inc).
Basic Rate ISDN software, Version 1.0.
2 Ethernet/IEEE 802.3 interfaces.
2 Token Ring/IEEE 802.5 interfaces.
4 ISDN Basic Rate interfaces.
128K bytes of non-volatile configuration memory.
8192K bytes of processor board System flash (Read/Write)
4096K bytes of processor board Boot flash (Read/Write)
Configuration register is 0x2100
Router1# configure terminal

```

```
Router1(config)# config-register 0x210F
Router1(config)# end
Router1# reload
```

## Setting the BOOTLDR Environment Variable

To set the BOOTLDR environment variable, complete the tasks in this section:

### Examples

The following example sets the BOOTLDR environment to change the location of the boot helper image from internal Flash to slot 0:

```
Router# dir bootflash:
-#- -length- ----date/time----- name
1  620      May 04 1995 26:22:04 rsp-boot-m
2  620      May 24 1995 21:38:14 config2
7993896 bytes available (1496 bytes used)
Router# configure terminal
Router (config)# boot bootldr slot0:rsp-boot-m
Router (config)# end
Router# copy system:running-config nvram:startup-config
[ok]
Router# show bootvar
BOOT variable = slot0:rsp-boot-m
CONFIG_FILE variable = nvram:
Current CONFIG_FILE variable = slot0:router-config

Configuration register is 0x0
```

## Scheduling a Reload of the System Image

To schedule a reload of the system image to occur on the router at a later time (for example, late at night or during the weekend when the router is used less) or to synchronize a reload network-wide (for example, to perform a software upgrade on all routers in the network), complete the task in this section.



#### Note

A scheduled reload must take place within approximately 24 days.

### SUMMARY STEPS

1. **enable**
2. **reload in** *[hh:]mm* *[text]*
3. **reload at** *hh : mm* *[month day | day month]* *[text]*

### DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.

	Command or Action	Purpose
	<p><b>Example:</b></p> <pre>Router&gt; enable</pre>	<ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
<b>Step 2</b>	<p><b>reload in</b> <i>[hh:]mm</i> [<i>text</i> ]</p> <p><b>Example:</b></p> <pre>Router# reload in 05:00</pre>	Schedules a reload of the software to take effect in <i>mm</i> minutes (or <i>hh</i> hours and <i>mm</i> minutes) from now.
<b>Step 3</b>	<p><b>reload at</b> <i>hh : mm</i> [<i>month day</i>   <i>day month</i> ] [<i>text</i> ]</p> <p><b>Example:</b></p> <pre>Router# reload at 02:00 jun 20</pre>	<p>Schedules a reload of the software to take place at the specified time (using a 24-hour clock). If you specify the month and day, the reload is scheduled to take place at the specified time and date. If you do not specify the month and day, the reload takes place at the specified time on the current day (if the specified time is later than the current time), or on the next day (if the specified time is earlier than the current time). Specifying 00:00 schedules the reload for midnight.</p> <p><b>Note</b> The <b>at</b> keyword can only be used if the system clock has been set on the router (either through NTP, the hardware calendar, or manually). The time is relative to the configured time zone on the router. To schedule reloads across several routers to occur simultaneously, the time on each router must be synchronized with NTP.</p>

## Examples

The following example illustrates how to use the **reload** command to reload the software on the router on the current day at 7:30 p.m.:

```
Router# reload at 19:30
Reload scheduled for 19:30:00 UTC Wed Jun 5 1996 (in 2 hours and 25 minutes)
Proceed with reload? [confirm]
```

The following example illustrates how to use the **reload** command to reload the software on the router at a future time:

```
Router# reload at 02:00 jun 20
Reload scheduled for 02:00:00 UTC Thu Jun 20 1996 (in 344 hours and 53 minutes)
Proceed with reload? [confirm]
```

## Displaying Information about a Scheduled Reload

To display information about a previously scheduled reload or to determine if a reload has been scheduled on the router, complete the task in this section:

**SUMMARY STEPS**

1. enable
2. show reload

**DETAILED STEPS**

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
<b>Step 2</b>	<b>show reload</b>  <b>Example:</b> Router# show reload	Displays reload information, including the time the reload is scheduled to occur, and the reason for the reload if it was specified when the reload was scheduled.

## Cancelling a Scheduled Reload

To cancel a previously scheduled reload, complete the task in this section:

**SUMMARY STEPS**

1. enable
2. reload cancel

**DETAILED STEPS**

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
<b>Step 2</b>	<b>reload cancel</b>  <b>Example:</b> Router# reload cancel	Cancels a previously scheduled reload of the software.

## Examples

The following example illustrates how to use the **reloadcancel** command to stop a scheduled reload:

```
Router# reload cancel
Router#
***
*** --- SHUTDOWN ABORTED ---
***
```

## Entering ROM Monitor Mode

During the first 60 seconds of startup, you can force the router to stop booting. The router will enter ROM monitor mode, where you can change the configuration register value or boot the router manually. To stop booting and enter ROM monitor mode, complete the tasks in this section:

### SUMMARY STEPS

1. **enable**
2. **reload**
3. Press the Break key during the first 60 seconds while the system is booting.
4. **?**

### DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
<b>Step 2</b>	<b>reload</b>  <b>Example:</b> Router# reload	Reboots the router.
<b>Step 3</b>	Press the Break key during the first 60 seconds while the system is booting.	<b>Note</b> Enters ROM monitor mode from privileged EXEC mode. This key will not work on the Cisco 7000 unless it has at least Cisco IOS Release 10 boot ROMs.
<b>Step 4</b>	<b>?</b>  <b>Example:</b> ROMMON> ?	List the ROM monitor commands.

## What to Do Next

If you are planning to use ROM monitor mode on a regular basis, or wish users to load using ROM monitor commands, you can configure the system to default to ROMMON. To automatically boot your system in ROM monitor mode, reset the configuration register to 0x0 by using the **config-register0x0** configuration command. The new configuration register value, 0x0, takes effect after the router or access server is rebooted with the **reload** command. If you set the configuration to 0x0, you will have to manually boot the system from the console each time you reload the router or access server.

To exit ROMMON mode, use the **continue** command. If you have changed the configuration, use the **copyrunning-configstartup-config** command and then issue the **reload** command to save your configuration changes.

## Manually Booting from Flash Memory in ROMMON

To manually boot from Flash memory, complete the tasks in Step 1, 2, and 3, and then one of the commands in Step 4:

### SUMMARY STEPS

1. **enable**
2. **reload**
3. Press the Break key during the first 60 seconds while the system is booting.
4. Do one of the following:
  - **boot flash** *[filename]*
  - 
  - **boot flash** *partition-number* : *[filename]*
  - 
  - **boot flash flash:** [ *partition-number:* ] *[filename]*
  - 
  - **boot** [*flash-fs:* ] [ *partition-number:* ] *[filename]* (Cisco 1600 series and Cisco 3600 series)
  - 
  - **boot** *device* : *[filename]* (Cisco 7000 family)

### DETAILED STEPS

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.

	Command or Action	Purpose
	<p><b>Example:</b></p> <pre>Router&gt; enable</pre>	<ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
<b>Step 2</b>	<p><b>reload</b></p> <p><b>Example:</b></p> <pre>Router# reload</pre>	Reboots the router.
<b>Step 3</b>	Press the Break key during the first 60 seconds while the system is booting.	<p><b>Note</b> Enters ROM monitor mode from privileged EXEC mode. This key will not work on the Cisco 7000 unless it has at least Cisco IOS Release 10 boot ROMs.</p>
<b>Step 4</b>	<p>Do one of the following:</p> <ul style="list-style-type: none"> <li>• <b>boot flash</b> <i>[filename]</i></li> <li>•</li> <li>• <b>boot flash</b> <i>partition-number : [filename]</i></li> <li>•</li> <li>• <b>boot flash flash:</b> <i>[ partition-number: ][filename]</i></li> <li>•</li> <li>• <b>boot</b> <i>[flash-fs:][partition-number:][filename]</i> (Cisco 1600 series and Cisco 3600 series)</li> <li>•</li> <li>• <b>boot device</b> <i>: [filename]</i> (Cisco 7000 family)</li> </ul> <p><b>Example:</b></p> <pre>ROMMON&gt; boot tftp://172.16.15.112/routertest</pre> <p><b>Example:</b></p> <p><b>Example:</b></p> <pre>ROMMON&gt; boot flash flash:2:igs-bpx-1</pre>	<p>Manually boot the router from Flash. Refer to your hardware documentation for the correct form of this command to use.</p> <ul style="list-style-type: none"> <li>• If the filename is not specified, the first bootable file found in the device and partition is used.</li> </ul>



## Manually Booting from a Network File in ROMMON

To manually boot from a network file, complete the task in this section:

### SUMMARY STEPS

1. **enable**
2. **reload**
3. Press the Break key during the first 60 seconds while the system is booting.
4. **boot filename [ip-address ]**

### DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
<b>Step 2</b>	<b>reload</b>  <b>Example:</b> Router# reload	Reboots the router.
<b>Step 3</b>	Press the Break key during the first 60 seconds while the system is booting.  <b>Example:</b> or  <b>Example:</b>  <div style="text-align: center;"><b>config-register 0x0</b></div> <b>Example:</b> Router# <brk>	Enters ROM monitor mode from privileged EXEC mode.  The <b>config-register0x0</b> commands instructs the router to boot from ROMMON on the next reload.
<b>Step 4</b>	<b>boot filename [ip-address ]</b>  <b>Example:</b> ROMMON> boot network1	Manually boots the router from a network file.

## Examples

In the following example, a router is manually booted from the network file *network1*:

```
ROMMON>boot network1
```

## Manually Booting from ROM in ROMMON

To manually boot the router from ROM, complete the task in this section:

### SUMMARY STEPS

1. **enable**
2. **reload**
3. Press the Break key during the first 60 seconds while the system is booting.
4. **boot**

### DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
<b>Step 2</b>	<b>reload</b>  <b>Example:</b> Router# reload	Reboots the router.
<b>Step 3</b>	Press the Break key during the first 60 seconds while the system is booting.  <b>Example:</b> or  <b>Example:</b>  <div style="text-align: center;"><b>config-register 0x0</b></div>	Enters ROM monitor mode from privileged EXEC mode.  The <b>config-register0x0</b> commands instructs the router to boot from ROMMON on the next reload.

	Command or Action	Purpose
	<b>Example:</b> Router# <brk>	
<b>Step 4</b>	<b>boot</b>  <b>Example:</b> ROMMON> boot	Manually boots the router from ROM.  <b>Note</b> On the Cisco 7200 series and Cisco 7500 series, the <b>boot</b> command loads the first bootable image located in bootflash.

## Examples

In the following example, a router is manually booted from ROM:

```
ROMMON> boot
```

## Manually Booting Using MOP in ROMMON

You can interactively boot system software using MOP. Typically, you do this to verify that system software has been properly installed on the MOP boot server before configuring the router to automatically boot the system software image. To manually boot the router using MOP, complete the task in this section:

### SUMMARY STEPS

1. **enable**
2. **reload**
3. Press the Break key during the first 60 seconds while the system is booting.
4. **boot system mop filename [mac-address ] [interface ]**

### DETAILED STEPS

	Command or Action	Purpose
<b>Step 1</b>	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>

	Command or Action	Purpose
<b>Step 2</b>	<b>reload</b>  <b>Example:</b> Router# reload	Reboots the router.
<b>Step 3</b>	Press the Break key during the first 60 seconds while the system is booting.  <b>Example:</b> or  <b>Example:</b>  <div style="text-align: center;"><b>config-register 0x0</b></div>  <b>Example:</b> Router# <brk>	Enters ROM monitor mode from privileged EXEC mode. The <b>config-register0x0</b> commands instructs the router to boot from ROMMON on the next reload.
<b>Step 4</b>	<b>boot system mop filename [mac-address ] [interface ]</b>  <b>Example:</b> ROMMON> boot mop network1	Manually boots the router using MOP.  <b>Note</b> The Cisco 7200 series and Cisco 7500 series do not support the <b>bootmop</b> command.

## Examples

In the following example, a router is manually booted from a MOP server:

```
ROMMON> boot mop network1
```

## Exiting from ROMMON

To return to EXEC mode from the ROM monitor, you must continue loading from the default system image. To exit ROMMON mode and resume loading, use the following command in ROM monitor mode:

Command	Purpose
<p style="text-align: center;"><b>continue</b></p> <p>ROMMON &gt; continue</p>	Resumes loading the startup configuration file and brings the user to EXEC mode.