



Enterprise Application Interoperability for H.323-to-SIP and SIP-to-SIP Configuration Guide, Cisco IOS Release 15M&T

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <http://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

© 2014 Cisco Systems, Inc. All rights reserved.



CONTENTS

CHAPTER 1

Enterprise Application Interoperability for H.323-to-SIP and SIP-to-SIP 1

Finding Feature Information 1

Configuration of Enterprise Application Interoperability for H.323-to-SIP and SIP-to-SIP
Features 1

CHAPTER 2

Configuring SIP 181 Call is Being Forwarded Message 3

Finding Feature Information 3

Prerequisites for SIP 181 Call is Being Forwarded Message 4

Configuring SIP 181 Call is Being Forwarded Message Globally 4

Configuring SIP 181 Call is Being Forwarded Message at the Dial-Peer Level 5

Configuring Mapping of SIP Provisional Response Messages Globally 6

Configuring Mapping of SIP Provisional Response Messages at the Dial-Peer Level 8

Feature Information for Configuring SIP 181 Call is Being Forwarded Message 9

CHAPTER 3

Expires Timer Reset on Receiving or Sending SIP 183 Message 11

Finding Feature Information 11

Prerequisites for Expires Timer Reset on Receiving or Sending SIP 183 Message 12

How to Configure Expires Timer Reset on Receiving or Sending SIP 183 Message 12

Configuring Reset of Expires Timer Globally 12

Configuring Reset of Expires Timer at the Dial-Peer Level 13

Feature Information for Configuring Support for Expires Timer Reset on Receiving or Sending
SIP 183 Message 14

CHAPTER 4

Cisco Unified Communications Manager Line-Side Support 17

Finding Feature Information 17

Restrictions for Cisco Unified Communications Manager Line-Side Support 17

Information About Cisco Unified Communications Manager Line-Side Support 18

Cisco UBE Line-Side Deployment 18

Line-Side Support for CUCM on CUBE	18
Configuring SIP Extension	20
Configuring a PKI Trustpoint	21
Importing the CUCM and CAPF Key	22
Creating a CTL File	24
Configuring a Phone Proxy	25
Attaching a Phone Proxy to a Dial Peer	26
Verifying CUCM Lineside Support	28
Example: Configuring a PKI Trustpoint	30
Example: Importing the CUCM and CAPF Key	30
Example: Creating a CTL File	31
Example: Configuring a Phone Proxy	31
Example: Attaching a Phone Proxy to a Dial Peer	31
Feature Information for Cisco Unified Communications Manager Line-Side Support	31

CHAPTER 5

Cisco Unified Border Element Intercluster Lookup Service	33
Finding Feature Information	33
Information About Cisco UBE Intercluster Lookup Service	34
Cisco UBE Intercluster Lookup Service Overview	34
Cisco UBE Enterprise Support for URIs	34
How to Configure Cisco UBE Intercluster Lookup Service	35
Configuring a Route String Pattern	35
Configuring a Call Route on a Destination Route String Globally	36
Configuring a Route String Passthrough List Header	37
Configuring a Destination Route String Call Route at the Dial-Peer Level	38
Configuring a Route String Header Pass-Through Using Pass-Through List	40
Verifying Cisco UBE Intercluster Lookup Service Configuration	41
Configuration Examples for Cisco UBE Intercluster Lookup Service	44
Example: Configuring a Route String Pattern	44
Example: Configuring a Call Route on a Destination Route String Globally	44
Example: Configuring a Route String Passthrough List Header	44
Example: Configuring a Destination Route String Call Route at the Dial-Peer Level	44
Example: Configuring a Route String Header Pass-Through Using Pass-Through List	44
Feature Information for Cisco UBE Intercluster Lookup Service	45



CHAPTER

1

Enterprise Application Interoperability for H.323-to-SIP and SIP-to-SIP

This Cisco Unified Border Element (Enterprise) is a special Cisco IOS XE software image that runs on Cisco ASR1000. It provides a network-to-network interface point for billing, security, call admission control, quality of service, and signaling interworking. This chapter describes basic gateway functionality, software images, topology, and summarizes supported features.



Note

Cisco Product Authorization Key (PAK)--A Product Authorization Key (PAK) is required to configure some of the features described in this guide. Before you start the configuration process, please register your products and activate your PAK at the following URL <http://www.cisco.com/go/license> .

- [Finding Feature Information, page 1](#)
- [Configuration of Enterprise Application Interoperability for H.323-to-SIP and SIP-to-SIP Features, page 1](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see [Bug Search Tool](#) and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table at the end of this module.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Configuration of Enterprise Application Interoperability for H.323-to-SIP and SIP-to-SIP Features

This chapter contains the following configuration topics:

Cisco UBE (Enterprise) Prerequisites and Restrictions

- Prerequisites for Cisco Unified Border Element (Enterprise)
- Restrictions for Cisco Unified Border Element (Enterprise)

CUCM Interworking

- [Cisco Interoperability Portal](#)

www.cisco.com/go/interoperability

Third Party PBX Interworking

- [Cisco Interoperability Portal](#)

www.cisco.com/go/interoperability

Application specific interworking notes

- Support for SIP 181 "call is being forwarded" message
- Support for Expires timer reset on receiving or sending SIP 183 message



Configuring SIP 181 Call is Being Forwarded Message

You can configure support for SIP 181 Call is Being Forwarded messages either globally or on a specific dial-peer. Use the **block** command in voice service SIP configuration mode to globally configure Cisco IOS voice gateways and Cisco UBEs to drop specified SIP provisional response messages. To configure settings for an individual dial peer, use the **voice-class sip block** command in dial peer voice configuration mode. Both globally and at the dial peer level, you can also use the **sdp** keyword to further control when the specified SIP message is dropped based on either the absence or presence of SDP information.

Additionally, you can use commands introduced for this feature to configure a Cisco UBE, either globally or at the dial peer level, to map specific received SIP provisional response messages to a different SIP provisional response message on the outgoing SIP dial peer. To do so, use the **map resp-code** command in voice service SIP configuration mode for global configuration or, to configure a specific dial peer, use the **voice-class sip map resp-code** in dial peer voice configuration mode.

This section contains the following tasks:

- [Finding Feature Information, page 3](#)
- [Prerequisites for SIP 181 Call is Being Forwarded Message, page 4](#)
- [Configuring SIP 181 Call is Being Forwarded Message Globally, page 4](#)
- [Configuring SIP 181 Call is Being Forwarded Message at the Dial-Peer Level, page 5](#)
- [Configuring Mapping of SIP Provisional Response Messages Globally, page 6](#)
- [Configuring Mapping of SIP Provisional Response Messages at the Dial-Peer Level, page 8](#)
- [Feature Information for Configuring SIP 181 Call is Being Forwarded Message, page 9](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see [Bug Search Tool](#) and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table at the end of this module.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Prerequisites for SIP 181 Call is Being Forwarded Message

Cisco Unified Border Element

Cisco IOS Release 15.0(1)XA or a later release must be installed and running on your Cisco Unified Border Element.

Cisco Unified Border Element (Enterprise)

- Cisco IOS XE Release 3.1S or a later release must be installed and running on your Cisco ASR 1000 Series Router.

Configuring SIP 181 Call is Being Forwarded Message Globally

Perform this task to configure support for SIP 181 messages at a global level in SIP configuration (conf-serv-sip) mode.

SUMMARY STEPS

1. `enable`
2. `configure terminal`
3. `voice service voip`
4. `sip`
5. `block {180 | 181 | 183} [sdp {absent | present}]`
6. `exit`

DETAILED STEPS

	Command or Action	Purpose
Step 1	<p><code>enable</code></p> <p>Example:</p> <pre>Router> enable</pre>	<p>Enters privileged EXEC mode, or other security level set by a system administrator.</p> <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	<p><code>configure terminal</code></p> <p>Example:</p> <pre>Router# configure terminal</pre>	<p>Enters global configuration mode.</p>

	Command or Action	Purpose
Step 3	voice service voip Example: Router(config)# voice service voip	Enters voice service VoIP configuration mode.
Step 4	sip Example: Router(conf-voi-serv)# sip	Enters SIP configuration mode.
Step 5	block {180 181 183} [sdp {absent present}] Example: Router(conf-serv-sip)# block 181 sdp present	Configures support of SIP 181 messages globally so that messages are passed as is. The sdp keyword is optional and allows for dropping or passing of SIP 181 messages based on the presence or absence of SDP.
Step 6	exit Example: Router(conf-serv-sip)# exit	Exits the current mode.

Configuring SIP 181 Call is Being Forwarded Message at the Dial-Peer Level

Perform this task to configure support for SIP 181 messages at the dial-peer level, in dial peer voice configuration (config-dial-peer) mode.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **dial-peer voice tag voip**
4. **voice-class sip block {180 | 181 | 183} [sdp {absent | present}]**
5. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enters privileged EXEC mode, or other security level set by a system administrator. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	dial-peer voice tag voip Example: Router(config)# dial-peer voice 2 voip	Enters dial peer VoIP configuration mode.
Step 4	voice-class sip block {180 181 183} [sdp {absent present}] Example: Router(config-dial-peer)# voice-class sip block 181 sdp present	Configures support of SIP 181 messages on a specific dial peer so that messages are passed as is. The sdp keyword is optional and allows for dropping or passing of SIP 181 messages based on the presence or absence of SDP.
Step 5	exit Example: Router(config-dial-peer)# exit	Exits the current mode.

Configuring Mapping of SIP Provisional Response Messages Globally

Perform this task to configure mapping of specific received SIP provisional response messages at a global level in SIP configuration (conf-serv-sip) mode.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **voice service voip**
4. **sip**
5. **map resp-code 181 to 183**
6. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enters privileged EXEC mode, or other security level set by a system administrator. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	voice service voip Example: Router(config)# voice service voip	Enters voice service VoIP configuration mode.
Step 4	sip Example: Router(conf-voi-serv)# sip	Enters SIP configuration mode.
Step 5	map resp-code 181 to 183 Example: Router(conf-serv-sip)# map resp-code 181 to 183	Enables mapping globally of received SIP messages of a specified message type to a different SIP message type.
Step 6	exit Example: Router(conf-serv-sip)# exit	Exits the current mode.

Configuring Mapping of SIP Provisional Response Messages at the Dial-Peer Level

Perform this task to configure mapping of received SIP provisional response messages at the dial-peer level, in dial peer voice configuration (config-dial-peer) mode.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **dial-peer voice tag voip**
4. **voice-class sip map resp-code 181 to 183**
5. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enters privileged EXEC mode, or other security level set by a system administrator. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	dial-peer voice tag voip Example: Router(config)# dial-peer voice 2 voip	Enters dial peer VoIP configuration mode.
Step 4	voice-class sip map resp-code 181 to 183 Example: Router(config-dial-peer)# voice-class sip map resp-code 181 to 183	Enables mapping of received SIP messages of a specified SIP message type on a specific dial peer to a different SIP message type.
Step 5	exit Example: Router(config-dial-peer)# exit	Exits the current mode.

Feature Information for Configuring SIP 181 Call is Being Forwarded Message

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Feature History Table entry for the Cisco Unified Border Element.

Table 1: Feature Information for SIP 181 Call is Being Forwarded Messages

Feature Name	Releases	Feature Information
SIP 181 Call is Being Forwarded Message	12.2(13)T	This feature allows users to configure support for SIP 181 Call is Being Forwarded messages either globally or on a specific dial-peer. This feature includes the following new or modified commands: block , map resp-code , voice-class sip block , voice-class sip map resp-code .

Feature History Table entry for the Cisco Unified Border Element (Enterprise).

Table 2: Feature Information for SIP 181 Call is Being Forwarded Messages

Feature Name	Releases	Feature Information
SIP 181 Call is Being Forwarded Message	Cisco IOS XE Release 3.1S	This feature allows users to configure support for SIP 181 Call is Being Forwarded messages either globally or on a specific dial-peer. This feature includes the following new or modified commands: block , map resp-code , voice-class sip block , voice-class sip map resp-code .



Expires Timer Reset on Receiving or Sending SIP 183 Message

This feature enables support for resetting the Expires timer when receiving or sending SIP 183 messages on Cisco Unified Communications Manager Express (Cisco Unified CME), a Cisco IOS voice gateway, or a Cisco Unified Border Element (Cisco UBE). When the terminating device lacks answer supervision or does not send the required SIP 200 OK message within the timer expiry, you can enable this feature to send periodic SIP 183 messages to reset the Expires timer and preserve the call until final response. This feature can be enabled globally or on a specific dial peer. Additionally, you can configure this feature based on the presence or absence of Session Description Protocol (SDP).

For details about enabling this feature, see the **reset timer expires** and **voice-class sip reset timer expires** commands in the Cisco IOS Voice Command Reference.

- [Finding Feature Information, page 11](#)
- [Prerequisites for Expires Timer Reset on Receiving or Sending SIP 183 Message, page 12](#)
- [How to Configure Expires Timer Reset on Receiving or Sending SIP 183 Message, page 12](#)
- [Feature Information for Configuring Support for Expires Timer Reset on Receiving or Sending SIP 183 Message, page 14](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see [Bug Search Tool](#) and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table at the end of this module.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Prerequisites for Expires Timer Reset on Receiving or Sending SIP 183 Message

Before configuring support for Expires timer reset for SIP 183 on Cisco IOS SIP time-division multiplexing (TDM) gateways, Cisco UBEs, or Cisco Unified CME, verify the SIP configuration within the VoIP network for the appropriate originating and terminating gateways as described in the Cisco IOS SIP Configuration Guide.

Cisco Unified Border Element

- Cisco IOS Release 15.0(1)XA or a later release must be installed and running on your Cisco Unified Border Element.

Cisco Unified Border Element (Enterprise)

- Cisco IOS XE Release 3.1S or a later release must be installed and running on your Cisco ASR 1000 Series Router.

How to Configure Expires Timer Reset on Receiving or Sending SIP 183 Message

To configure the Support for Expires Timer Reset on Receiving or Sending SIP 183 Message feature, complete the tasks in this section. You can enable this feature globally, using the **reset timer expires** command in voice service SIP configuration mode, or on a specific dial-peer using the **voice-class sip reset timer expires** command in dial peer voice configuration mode.

Configuring Reset of Expires Timer Globally

Perform this task to enable resetting of the Expires timer at the global level in SIP configuration (conf-serv-sip) mode.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **voice service voip**
4. **sip**
5. **reset timer expires 183**
6. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	voice service voip Example: Router(config)# voice service voip	Enters voice service VoIP configuration mode.
Step 4	sip Example: Router(conf-voi-serv)# sip	Enters SIP configuration mode.
Step 5	reset timer expires 183 Example: Router(conf-serv-sip)# reset timer expires 183	Enables resetting of the Expires timer upon receipt of SIP 183 messages globally.
Step 6	exit Example: Router(conf-serv-sip)# exit	Exits the current mode.

Configuring Reset of Expires Timer at the Dial-Peer Level

Perform this task to enable resetting of the Expires timer at the dial-peer level in dial peer voice configuration (config-dial-peer) mode.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **dial-peer voice tag voip**
4. **voice-class sip reset timer expires 183**
5. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	dial-peer voice tag voip Example: Router(config)# dial-peer voice 2 voip	Enters dial peer VoIP configuration mode.
Step 4	voice-class sip reset timer expires 183 Example: Router(config-dial-peer)# voice-class sip reset timer expires 183	Enables resetting of the Expires timer upon receipt of SIP 183 messages on a specific dial peer.
Step 5	exit Example: Router(config-dial-peer)# exit	Exits the current mode.

Feature Information for Configuring Support for Expires Timer Reset on Receiving or Sending SIP 183 Message

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required. Feature History Table entry for the Cisco Unified Border Element.

Table 3: Feature Information for Support for Expires Timer Reset on Receiving or Sending SIP 183 Message

Feature Name	Releases	Feature Information
Support for Expires Timer Reset on Receiving or Sending SIP 183 Message	15.0(1)XA 15.1(1)T	This feature enables support for resetting the Expires timer upon receipt of SIP 183 messages on Cisco Unified Communications Manager Express (Cisco Unified CME), a Cisco IOS voice gateway, or a Cisco Unified Border Element (Cisco UBE). The following commands were introduced or modified: reset timer expires and voice-class sip reset timer expires .

Feature History Table entry for the Cisco Unified Border Element (Enterprise) .

Table 4: Feature Information for Support for Expires Timer Reset on Receiving or Sending SIP 183 Message

Feature Name	Releases	Feature Information
Support for Expires Timer Reset on Receiving or Sending SIP 183 Message	Cisco IOS XE Release 3.1S	This feature enables support for resetting the Expires timer upon receipt of SIP 183 messages on Cisco Unified Communications Manager Express (Cisco Unified CME), a Cisco IOS voice gateway, or a Cisco Unified Border Element (Cisco UBE). The following commands were introduced or modified: reset timer expires and voice-class sip reset timer expires .



Cisco Unified Communications Manager Line-Side Support

Cisco Unified Communications Manager is an enterprise-class IP communications processing system. It extends enterprise telephony features and capabilities to IP phones, media processing devices, VoIP gateways, mobile devices, and multimedia applications. Cisco Unified Border Element (Cisco UBE) provides line-side support for Cisco Unified Communications Manager. This support enables communication between devices (such as phones) used by remote users on different logical networks, in both cloud-based and premise-based deployments.

- [Finding Feature Information, page 17](#)
- [Restrictions for Cisco Unified Communications Manager Line-Side Support, page 17](#)
- [Information About Cisco Unified Communications Manager Line-Side Support, page 18](#)
- [Feature Information for Cisco Unified Communications Manager Line-Side Support, page 31](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see [Bug Search Tool](#) and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table at the end of this module.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Restrictions for Cisco Unified Communications Manager Line-Side Support


- In Cisco Unified Communications Manager Line-Side Support deployments, Cisco Unified Border Element does not support TFTP encrypted configuration files.

Information About Cisco Unified Communications Manager Line-Side Support

Cisco UBE Line-Side Deployment

In a typical deployment Cisco Unified Border Element (Cisco UBE) is placed between the Cisco Unified Communications Manager and the endpoint. Before invoking a service the phone contacts the CUBE Trivial File Transfer Protocol (TFTP) server to get configuration information such as the Certificate Trust List (CTL) file and phone-specific configuration settings. The phone then registers with Cisco Unified Communications Manager. In the deployment shown below, Cisco Unified Communications Manager and the phone configuration operate in unsecured mode (TCP to Real-Time Transport Protocol). The phone configuration can be changed to operate in a secure mode (Transport Layer Security Secure to Real-Time Transport Protocol) if needed. When the phone registration is completed the phone can invoke all normal call services.

Figure 1: Cisco UBE Line-Side Deployment



300105

Line-Side Support for CUCM on CUBE

For an IP phone to register on a CUCM through CUBE, CUBE must be configured to do the following requirements.

- TCP must be used for registration.
- The MAC address of the device (device ID) and the device name, present in the CONTACT header of the REGISTER message, need to be copied to the outgoing messages and passed to the CUCM intact.

Table 5: Command for Line-Side Support for CUCM on CUBE

Dial-Peer Configuration Mode (config-dial-peer)	Global VoIP Configuration mode (config-voi-serv)
voice-class sip extension cucm	sip extension cucm

When Line Side Support for CUCM on CUBE feature is configured, the following supported, nonmandatory headers are passed through automatically without the need for further configuration:

- Call-Info
- Content-ID
- Allow-Events
- Supported
- Remote-Party-ID
- Require
- Referred-By

Figure 2: Predefined Supported NonMandatory Headers

```
!-- predefined hidden supported non-mandatory header pass-through list
!-- the list number 20001 is out of user configuration range

voice class sip-hdr-passthruelist 20001
passthru-hdr Call-Info
passthru-hdr Content-ID
passthru-hdr Allow-Events
passthru-hdr Supported
passthru-hdr Remote-Party-ID
passthru-hdr Require
passthru-hdr Referred-By
```

371467

When Line Side Support for CUCM on CUBE is configured, predefined SIP profiles automatically remove the Cisco-Guide header from the outgoing INVITE.

Figure 3: Predefined SIP Profile

```
!-- predefined hidden sip profile
!-- the profile number 20001 is out of user configuration range

voice class sip-profiles 20001
request INVITE sip-header Cisco-Guid remove
```

371468



Note

If a user explicitly configures the above configurations, ensure that the configurations are merged with the above automatic configurations.

Configuring SIP Extension

You can use the SIP extension to enable support of CUCM-specific features. Configure the SIP extension under dial-peer facing CUCM lineside and CUCM. You can also configure the SIP extension command in global SIP configuration.

SUMMARY STEPS

1. **dial-peer voice *tag* voip**
2. **voice-class sip extension {*cucm* | *system*}**
3. **end**

DETAILED STEPS

	Command or Action	Purpose
Step 1	dial-peer voice <i>tag</i> voip Example: Device(config)# dial-peer voice 2 voip	Enters dial peer configuration mode.
Step 2	voice-class sip extension {<i>cucm</i> <i>system</i>} Example: Device(config-dial-peer)# voice-class sip extension cucm	Configures SIP extension to enable support for CUCM. • Use the keyword system to configure the SIP extension globally.

	Command or Action	Purpose
Step 3	end Example: Device(config-dial-peer)# end	Returns to privileged EXEC mode.

Configuring a PKI Trustpoint

SUMMARY STEPS

1. **crypto key generate rsa** [*label key-label*] [*modulus modulus-size*] **general-keys**
2. **crypto pki trustpoint** *name*
3. **enrollment selfsigned**
4. **subject-name** [*x.500-name*]
5. **subject-alt-name** *sip-security-profile-name*
6. **revocation-check** *method1*[*method2* [*method3*]]
7. **rsakeypair** *key-label*

DETAILED STEPS

	Command or Action	Purpose
Step 1	crypto key generate rsa [<i>label key-label</i>] [<i>modulus modulus-size</i>] general-keys Example: Device(config)# crypto key generate rsa label pp_rsa modulus 1024 general-keys	Generates a RSA key pair. Note A self-signed key can only support a <i>modulus-size</i> value of 1024 bits.
Step 2	crypto pki trustpoint <i>name</i> Example: Device(config)# crypto pki trustpoint callmg23	Declares the trustpoint that the device should use and enters ca-trustpoint configuration mode.
Step 3	enrollment selfsigned Example: Device(config-ca-trustpoint)# enrollment selfsigned	Specifies self-signed enrollment for a trustpoint.

	Command or Action	Purpose
Step 4	subject-name <i>[x.500-name]</i> Example: Device(config-ca-trustpoint)# subject-name CN=ASR1006-CCN-4	Specifies the subject name in the certificate request.
Step 5	subject-alt-name <i>sip-security-profile-name</i> Example: Device(config-ca-trustpoint)# subject-alt-name 6961_SEC.cisco.com 8941_SEC.cisco.com 8945_SEC.cisco.com 7975_SEC.cisco.com 7970_SEC.cisco.com	Specifies the alternative subject name in the certificate request. <ul style="list-style-type: none"> • Use the subject-alt-name command only when Cisco UBE is interacting with CUCM in secure mode. • The value of subject-alt-name must be the SIP security profile name under CUCM.
Step 6	revocation-check <i>method1[method2 [method3]]</i> Example: Device(config-ca-trustpoint)# revocation-check crl	Checks the revocation status of a certificate.
Step 7	rsa keypair <i>key-label</i> Example: Device(config-ca-trustpoint)# rsakeypair ppl	Specifies which RSA keypair to associate with the certificate.

What to Do Next

Import the CUCM and CAPF key.

Importing the CUCM and CAPF Key

Before You Begin

Download the CUCM key (the CallManager.pem file) from the Cisco Unified Communications Manager Operating System Administration web page.

Login to Cisco Unified OS Administration and Security and Certificate Management, download the CUCM key (the CallManager.pem file), and copy and paste the CUCM key to CUBE

SUMMARY STEPS

1. `crypto pki trustpoint name`
2. `revocation-check method1[method2 [method3]]`
3. `enrollment terminal`
4. `crypto pki authenticate name`

DETAILED STEPS

	Command or Action	Purpose
Step 1	<p><code>crypto pki trustpoint <i>name</i></code></p> <p>Example:</p> <pre>Device(config)# crypto pki trustpoint cucm_trustpoint</pre>	Creates a trustpoint for the CUCM key and enters ca-trustpoint configuration mode.
Step 2	<p><code>revocation-check <i>method1</i>[<i>method2</i> [<i>method3</i>]]</code></p> <p>Example:</p> <pre>Device(config-ca-trustpoint)# revocation-check none</pre>	Checks the revocation status of a certificate.
Step 3	<p><code>enrollment terminal</code></p> <p>Example:</p> <pre>Device(config-ca-trustpoint)# enrollment terminal</pre>	Specifies manual cut-and-paste certificate enrollment.
Step 4	<p><code>crypto pki authenticate <i>name</i></code></p> <p>Example:</p> <pre>Device(config-ca-trustpoint)# crypto pki authenticate cucm_trustpoint</pre>	<p>Authenticates the trustpoint. At the prompt to enter the certificate, copy the contents of the CallManager.pem file that you downloaded above and paste it at the prompt. At the prompt to accept the file, enter "yes".</p> <p>Note When you copy the certificate, ensure that you also copy the BEGIN and END lines.</p>

What to Do Next

Repeat the above steps for the CAPF key (the CAPF.pem file).

Creating a CTL File

SUMMARY STEPS

1. **voice-ctl-file** *ctl-filename*
2. **record-entry selfsigned trustpoint** *trustpoint-name*
3. **record-entry capf trustpoint** *trustpoint-name*
4. **record-entry cucm-tftp trustpoint** *trustpoint-name*
5. **complete**

DETAILED STEPS

	Command or Action	Purpose
Step 1	voice-ctl-file <i>ctl-filename</i> Example: Device(config)#voice-ctl-file ctl	Creates a CTL file and enters CTL file configuration mode.
Step 2	record-entry selfsigned trustpoint <i>trustpoint-name</i> Example: Device(config-ctl-file)#record-entry selfsigned trustpoint self-trustpoint6s	Configures the trustpoints to be used for creating the CTL file.
Step 3	record-entry capf trustpoint <i>trustpoint-name</i> Example: Device(config-ctl-file)#record-entry capf trustpoint capf-trustpoint6s	Specifies that the trustpoint is created using the CAPF certificate imported from Cisco Unified Communications Manager to the device.
Step 4	record-entry cucm-tftp trustpoint <i>trustpoint-name</i> Example: Device(config-ctl-file)#record-entry cucm-tftp trustpoint cucm-trustpoint	Specifies that the trustpoint is created using the specified TFTP and Cisco Unified Communications Manager certificate imported to the device.
Step 5	complete Example: Device(config-ctl-file)# complete	Completes the CTL-file creation.

Configuring a Phone Proxy

SUMMARY STEPS

1. `voice-phone-proxy phone-proxy-name`
2. `voice-phone-proxy file-buffer size`
3. `tftp-server-address [ipv4 server-ip-address | domain-name]`
4. `ctl-file ctl-filename`
5. `access-secure`
6. complete

DETAILED STEPS

	Command or Action	Purpose
Step 1	<p><code>voice-phone-proxy phone-proxy-name</code></p> <p>Example:</p> <pre>Device(config)# voice-phone-proxy pp</pre>	Configures a phone proxy and enters phone-proxy configuration mode.
Step 2	<p><code>voice-phone-proxy file-buffer size</code></p> <p>Example:</p> <pre>Device(config)# voice-phone-proxy file-buffer 30</pre>	Configures the phone-proxy file buffering parameter, in MB.
Step 3	<p><code>tftp-server-address [ipv4 server-ip-address domain-name]</code></p> <p>Example:</p> <pre>Device(config-phone-proxy)# tftp-server-address ipv4 172.110.36.2</pre>	Configures the TFTP server address.
Step 4	<p><code>ctl-file ctl-filename</code></p> <p>Example:</p> <pre>Device(config-phone-proxy)# ctl-file ctl</pre>	Configures the CTL filename.
Step 5	<p><code>access-secure</code></p> <p>Example:</p> <pre>Device(config-phone-proxy)# access-secure</pre>	Specifies that the secure (encrypted) mode is to be used for access.

	Command or Action	Purpose
Step 6	complete Example: Device(config-phone-proxy)# complete	Completes the phone-proxy configuration.

Attaching a Phone Proxy to a Dial Peer

SUMMARY STEPS

1. dial-peer voice *tag* voip
2. phone-proxy *phone-proxy-name* signal-addr ipv4 *ipv4-address* cucm ipv4 *ipv4-address*
3. session protocol sipv2
4. session target registrar
5. session transport {udp | tcp [tls]}
6. incoming uri {from | request | to | via} *tag*
7. destination uri *tag*
8. voice-class sip call-route url
9. voice-class sip profiles *number*
10. voice-class sip registration passthrough [registrar-index *index*]
11. voice-class sip pass-thru headers
12. voice-class sip copy-list {*tag* | system}
13. codec transparent

DETAILED STEPS

	Command or Action	Purpose
Step 1	dial-peer voice <i>tag</i> voip Example: Device(config)# dial-peer voice 10 voip	Defines a particular dial peer, specifies the method of voice encapsulation, and enters dial peer configuration mode.
Step 2	phone-proxy <i>phone-proxy-name</i> signal-addr ipv4 <i>ipv4-address</i> cucm ipv4 <i>ipv4-address</i> Example: Device(config-dial-peer)# phone-proxy pp1 signal-addr ipv4 10.0.0.8 cucm ipv4 198.51.100.1	Configures the phone proxy for the related dial peer.

	Command or Action	Purpose
Step 3	session protocol sipv2 Example: <pre>Device(config-dial-peer)# session protocol sipv2</pre>	Specifies a session protocol (SIPv2) for calls between local and remote devices.
Step 4	session target registrar Example: <pre>Device(config-dial-peer)# session target registrar</pre>	Specifies that a call from a VoIP dial peer is routed to the registrar end point.
Step 5	session transport {udp tcp [tls]} Example: <pre>Device(config-dial-peer)# session transport tcp tls</pre>	Configures the underlying transport layer protocol for SIP messages to transport layer security over TCP (TLS over TCP).
Step 6	incoming uri {from request to via} tag Example: <pre>Device(config-dial-peer)# incoming uri request 11</pre>	Specifies the voice class used to match the VoIP dial peer to the uniform resource identifier (URI) of an incoming call. Any request matching "uri 11" is destined to this dial peer.
Step 7	destination uri tag Example: <pre>Device(config-dial-peer)# destination uri 12</pre>	Specifies the voice class used to match a dial peer to the destination URI of an outgoing call. Any request matching "uri 12" is destined to this dial peer.
Step 8	voice-class sip call-route url Example: <pre>Device(config-dial-peer)# voice-class sip call-route url</pre>	Enables call routing based on the URL.
Step 9	voice-class sip profiles number Example: <pre>Device(config-dial-peer)# voice-class sip profiles 10</pre>	Configures a SIP profile for a voice class.
Step 10	voice-class sip registration passthrough [registrar-index index] Example: <pre>Device(config-dial-peer)# voice-class sip registration passthrough registrar-index 1</pre>	Configures the SIP registration pass-through options on the dial peer.

	Command or Action	Purpose
Step 11	voice-class sip pass-thru headers Example: <pre>Device(config-dial-peer)# voice-class sip pass-thru headers 10</pre>	Configures a list of headers for pass through by referring to a globally configured list.
Step 12	voice-class sip copy-list {tag system} Example: <pre>Device(config-dial-peer)# voice-class sip copy-list 10</pre>	Configures the list of entities to be sent to the peer call leg.
Step 13	codec transparent Example: <pre>Device(config-dial-peer)# codec transparent</pre>	Enables codec capabilities to be passed transparently between endpoints in a Cisco Unified Border Element.

Verifying CUCM Lineside Support

The **show** commands can be entered in any order.

SUMMARY STEPS

1. **enable**
2. **show dial-peer voice *dial-peer-id* | section voice class sip extension**
3. **show dial-peer voice**
4. **show voice class phone-proxy**
5. **show voice class phone-proxy sessions**

DETAILED STEPS

-
- Step 1** **enable**
 Enables privileged EXEC mode.
- Enter your password if prompted.

Example:

```
Device> enable
```

- Step 2** **show dial-peer voice *dial-peer-id* | section voice class sip extension**

Example:

```
CUBE# show dial-peer voice 5678 | section voice class sip extension
voice class sip extension = system,
Displays if extension cucm has not been configured for the dial peer.
```

Example:

```
CUBE# show dial-peer voice 5678 | section voice class sip extension
voice class sip extension = cucm,
Displays if extension cucm has been configured for the dial peer.
```

Example:

```
CUBE# show dial-peer voice 5678 | section voice class sip extension
voice class sip extension = none,
Displays if extension cucm has been removed for the dial peer using the no form of the command.
```

Step 3 show dial-peer voice**Example:**

```
Device# show dial-peer voice 100
voice class sip extension = system,
voice class sip contact-passing = system,
voice class sip requiri-passing = system,
voice class phone proxy name: phone_proxy_secure
voice class phone proxy config: complete
```

Step 4 show voice class phone-proxy**Example:**

```
Device# show voice class phone-proxy
Phone-Proxy 'phone_proxy':
Description:
  Access Secure: non-secure (default)
  Tftp-server address: 20.21.27.146
  Capf server address: 20.21.27.146
  CUCM service settings: preserve (default)
  CTL file name: ctl_file
  Session-timeout: 180 seconds
  Max-concurrent-sessions: 30
  Current sessions: 0
  TFTP sessions: 0
  HTTP download sessions: 0
  HTTP application sessions: 0
  CAPF sessions: 0
  Config status: complete
  SIP dial-peers associated:
    Name
    -----
    1
    -----
Phone-Proxy 'phone_proxy_secure':
Description:
  Access Secure: secure
  Tftp-server address: 20.21.27.146
  Capf server address: 20.21.27.146
```

Example: Configuring a PKI Trustpoint

```

CUCM service settings: preserve (default)
CTL file name: ctl_file
Session-timeout: 180 seconds
Max-concurrent-sessions: 30
Current sessions: 0
TFTP sessions: 0
HTTP download sessions: 0
HTTP application sessions: 0
CAPF sessions: 0
Config status: complete
SIP dial-peers associated:
  Name
  -----
  3
  dialpeer4
-----

```

Step 5 show voice class phone-proxy sessions**Example:**

```
Device# show voice class phone-proxy sessions
```

```

Phone-Proxy 'phone_proxy_ipad':
      Source
----- Sessions of Dial-peer 5 ----- Destination -----
|Access: 10.74.9.219      :45232      10.74.9.209      :6970
|
|Core  : 20.21.29.209    :45300      20.21.27.146    :6970
|
-----

```

Example: Configuring a PKI Trustpoint

```

Device(config)# crypto key generate rsa label pp_rsa modulus 1024 general-keys
Device(config)# crypto pki trustpoint callmg23
Device(config-ca-trustpoint)# enrollment selfsigned
Device(config-ca-trustpoint)# subject-name CN=ASR1006-CCN-4
Device(config-ca-trustpoint)# subject-alt-name 6961_SEC.cisco.com 8941_SEC.cisco.com
8945_SEC.cisco.com 7975_SEC.cisco.com 7970_SEC.cisco.com
Device(config-ca-trustpoint)# revocation-check crl
Device(config-ca-trustpoint)# rsakeypair pp1

```

Example: Importing the CUCM and CAPF Key

The following example shows how to import the CUCM and CAPF key after you have downloaded the CUCM key (the CallManager.pem file) and the CAPF key (the CAPF.pem file) from the Cisco Unified Communications Manager Operating System Administration web page.

```

Device(config)# crypto pki trustpoint cucm_trustpoint
Device(config-ca-trustpoint)# revocation-check none
Device(config-ca-trustpoint)# enrollment terminal
Device(config-ca-trustpoint)# crypto pki authenticate cucm_trustpoint

```

Example: Creating a CTL File

```
Device(config)# voice-ctl-file ctl
Device(config-ctl-file)# record-entry selfsigned trustpoint self-trustpoint6s
Device(config-ctl-file)# record-entry capf trustpoint capf-trustpoint6s
Device(config-ctl-file)# record-entry cucm-tftp trustpoint cucm-trustpoint
Device(config-ctl-file)# complete
```

Example: Configuring a Phone Proxy

```
Device(config)# voice-phone-proxy pp
Device(config-phone-proxy)# voice-phone-proxy pp
Device(config-phone-proxy)# voice-phone-proxy file-buffer size 30
Device(config-phone-proxy)# tftp-server address ipv4 172.110.36.2
Device(config-phone-proxy)# ctl-file ctl
Device(config-phone-proxy)# access-secure
Device(config-phone-proxy)# complete
```

Example: Attaching a Phone Proxy to a Dial Peer

```
Device(config)# dial-peer voice 10 voip
Device(config-dial-peer)# phone-proxy ppl signal-addr ipv4 10.0.0.8 cucm ipv4 198.51.100.1

Device(config-dial-peer)# session-protocol sipv2
Device(config-dial-peer)# session target registrar
Device(config-dial-peer)# session transport tcp tls
Device(config-dial-peer)# incoming uri request 11
Device(config-dial-peer)# destination uri 12
Device(config-dial-peer)# voice-class sip call-route url
Device(config-dial-peer)# voice-class sip profiles 10
Device(config-dial-peer)# voice-class sip registration passthrough registrar-index 1
Device(config-dial-peer)# voice-class sip passthrough headers 10
Device(config-dial-peer)# voice-class sip copy-list 10
Device(config-dial-peer)# codec transparent
```

Feature Information for Cisco Unified Communications Manager Line-Side Support

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 6: Feature Information for Cisco Unified Communications Manager Line-Side Support

Feature Name	Releases	Feature Information
Simplified Line-Side Support of CUCM on CUBE	15.4(2)T Cisco IOS XE Release 3.12S	<p>The Simplified Line-Side Support of CUCM on CUBE feature simplifies the complex CUBE configurations required for registering IP Phones on a CUCM through CUBE using a single CLI that automatically applies all the necessary configurations.</p> <p>The following commands were modified by this feature: extension cucm and voice-class sip extension cucm.</p>
Cisco Unified Communications Manager Line-Side Support	15.3(3)M Cisco IOS XE Release 3.10S	<p>The Cisco Unified Communications Manager Line-Side Support feature provides line-side support for Cisco Unified Communications Manager and IP phones deployed on different logical networks, in both cloud-based and premise-based deployments.</p> <p>The following commands were introduced or modified: access-secure, capf-address, clear voice phone-proxy all-sessions, complete (ctl file), ctl-file (phone proxy), debug voice phone-proxy, description (ctl file), description (phone proxy), disable service-settings, max-concurrent-sessions, phone-proxy (dial peer), port-range, record-entry, show voice class ctl-file, show voice class phone-proxy, service-map, session-timeout, tftp-server address, voice-ctl-file, voice-phone-proxy.</p>



Cisco Unified Border Element Intercluster Lookup Service

The Cisco Unified Border Element (Cisco UBE) Intercluster Lookup Service feature enables Cisco Unified Communications Manager to establish calls using Uniform Resource Identifiers (URIs.) It provides a framework for sharing information about user-contact information between Cisco Unified Communications Manager clusters. All URIs being used within a cluster are grouped together and associated with a cluster identifier called a route string. To interoperate with Cisco Unified Communications Manager, Cisco UBE is enhanced to route the call based on the received destination route string. This feature works with Cisco Unified Communication Manager Version 9.5 and later.

- [Finding Feature Information, page 33](#)
- [Information About Cisco UBE Intercluster Lookup Service, page 34](#)
- [How to Configure Cisco UBE Intercluster Lookup Service, page 35](#)
- [Configuration Examples for Cisco UBE Intercluster Lookup Service, page 44](#)
- [Feature Information for Cisco UBE Intercluster Lookup Service, page 45](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest caveats and feature information, see [Bug Search Tool](#) and the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the feature information table at the end of this module.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Information About Cisco UBE Intercluster Lookup Service

Cisco UBE Intercluster Lookup Service Overview

A Uniform Resource Identifier (URI) is a device-independent user address. A subscriber can use a URI as a personal identity and move from one network to another without any change in the URI. You cannot summarize URIs within an enterprise network (for example, abc@company.com) the same way that directory number ranges are summarized.

The Intercluster Lookup Services is a dynamic mechanism to discover URIs. When it is enabled, Cisco Unified Communications Manager users can initiate calls using URIs. The Intercluster Lookup Service provides a framework for sharing user-contact information between Cisco Unified Communications Manager clusters. All URIs being used within a cluster are grouped together and associated with a cluster identifier called a route string. These URI groups and their associated route strings are shared between all other participating clusters.

While initiating a call, the URI uses the Intercluster Lookup Service to identify the target URI and associated route string to route the call between clusters. Cisco Unified Communications Manager uses a Session Initiation Protocol (SIP) route pattern to match the route string returned by Intercluster Lookup Service and route the call over a SIP trunk. If Intercluster Lookup Service is enabled, the Cisco Unified Communications Manager SIP trunk sends the SIP invite message with destination route string header information.

To interoperate with Cisco Unified Communications Manager, Cisco UBE is enhanced to route the call based on the received destination route string. Cisco UBE supports exact match and wildcard match for a route string and parses the received destination route string header and routes a call forward to the destination. The destination can be a Cisco Unified Communications Manager cluster, public switched telephone network (PSTN), or any third-party unified communications device.

The dial-peer module is enhanced to support the dial-peer matching based on the destination route string header. The destination route string is used to match an outbound dial peer. The match can be an exact match or wildcard match.

For example, consider London.UK.EU as the route string. The SIP dial-peer configuration is as follows:

- Dial-peer 1: London.UK.EU
- Dial-peer 2: *.UK.EU
- Dial-peer 3: *.EU

The destination route string header and route string match are not case-sensitive. In this scenario, London.UK.EU and london.uk.eu match dial-peer 1 and therefore, dial-peer 1 is selected for outbound process.

If call routing policies are enabled, call routing based on a destination route string takes precedence over any other routing configurations. For example, if call routing is configured on a destination route string globally or at the dial-peer level, the call is routed considering the destination route string. If no match is found, then the call is routed using other URLs and header configuration options.

Cisco UBE Enterprise Support for URIs

Cisco UBE Enterprise does not support non-E164 URI number user-part in request line and header. For URI dialing from Cisco Unified Communications Manager phone, the URI in user@dest-route-string format is

used. By default, the integrated services router (ISR) converts this format to the session target IP address of the outbound dial-peer and delivers non-E164 numbers.

As a workaround, you can use a SIP profile to pass through the required URI format. You can configure the SIP profile on an outbound dial-peer to modify the URI to the desired format.

How to Configure Cisco UBE Intercluster Lookup Service

Configuring a Route String Pattern

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **voice class route-string *tag***
4. **pattern *string***
5. **end**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Device> enable	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 3	voice class route-string <i>tag</i> Example: Device(config)# voice class route-string 2	Enters voice class configuration mode.
Step 4	pattern <i>string</i> Example: Device(config-class)# pattern london.uk.eu	Configures a pattern string in the specified route string. Note Multiple patterns can be configured under one route string class and the same route string class can be configured under multiple dial-peers. You also can use an asterisk (*) as the wildcard match option while provisioning the pattern.

	Command or Action	Purpose
Step 5	end Example: Device (config-class) # end	Exits voice class configuration mode and returns to privileged EXEC mode.

Configuring a Call Route on a Destination Route String Globally

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **voice service voip**
4. **sip**
5. **call-route dest-route-string**
6. **end**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Device> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 3	voice service voip Example: Device(config)# voice service voip	Enters voice service configuration mode.
Step 4	sip Example: Device (conf-voi-serv) # sip	Enters SIP configuration mode.

	Command or Action	Purpose
Step 5	call-route dest-route-string Example: <pre>Device(conf-serv-sip)# call-route dest-route-string</pre>	Configures call routing globally on a destination route string. Note By default, call routing on a destination route string is disabled.
Step 6	end Example: <pre>Device(conf-serv-sip)# end</pre>	Exits SIP configuration mode and returns to privileged EXEC mode.

Configuring a Route String Passthrough List Header

SUMMARY STEPS

1. enable
2. configure terminal
3. voice class sip-hdr-passthru-list *tag*
4. passthru-hdr *name*
5. end

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: <pre>Device> enable</pre>	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: <pre>Device# configure terminal</pre>	Enters global configuration mode.
Step 3	voice class sip-hdr-passthru-list <i>tag</i> Example: <pre>Device(config)# voice class sip-hdr-passthru-list 2</pre>	Enters voice class configuration mode.

	Command or Action	Purpose
Step 4	passthru-hdr <i>name</i> Example: Device (config-class) # passthru-hdr x-cisco-dest-route-string	Configures header to be added to the route string passthrough list.
Step 5	end Example: Device (config-class) # end	Exits voice class configuration mode and returns to privileged EXEC mode.

Configuring a Destination Route String Call Route at the Dial-Peer Level

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **dial-peer voice** *tag* **voip**
4. **description** *string*
5. **destination route-string** *tag*
6. **session protocol sipv2**
7. **session target ipv4:***destination address*
8. **voice-class sip call-route dest-route-string**
9. **end**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Device> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: Device# configure terminal	Enters global configuration mode.

	Command or Action	Purpose
Step 3	dial-peer voice tag voip Example: Device(config)# dial-peer voice 1 voip	Enters dial peer voice configuration mode.
Step 4	description string Example: Device(config-dial-peer)# description outbound-dialpeer	Adds descriptive information about the dial peer.
Step 5	destination route-string tag Example: Device(config-dial-peer)# destination route-string 2	Configures a destination route string for the dial peer. Note By default, the call route on a destination route string is disabled. The destination route string call route configuration at the dial-peer level takes precedence over the global configuration when routing a call.
Step 6	session protocol sipv2 Example: Device(config-dial-peer)# session protocol sipv2	Configures the IETF Session Initiation Protocol (SIP) for the dial peer.
Step 7	session target ipv4:destination address Example: Device(config-dial-peer)# session target ipv4:192.0.2.6	Configures the session target IP address of the dial peer.
Step 8	voice-class sip call-route dest-route-string Example: Device(config-dial-peer)# voice-class sip call-route dest-route-string	Configures call routing on the destination route string for a dial peer.
Step 9	end Example: Device(config-dial-peer)# end	Exits dial peer voice configuration mode and returns to privileged EXEC mode.

Configuring a Route String Header Pass-Through Using Pass-Through List

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **voice class sip-hdr-passthru list-tag**
4. **passthru-hdr header-name**
5. **passthru-hdr-unsupp**
6. **exit**
7. **dial-peer voice tag voip**
8. **description string**
9. **session protocol sipv2**
10. **voice-class sip pass-thru headers list-tag**
11. **end**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Device> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted.
Step 2	configure terminal Example: Device# configure terminal	Enters global configuration mode.
Step 3	voice class sip-hdr-passthru list-tag Example: Device(config)# voice class sip-hdr-passthru list 101	Configures list of headers to be passed through and enters voice class configuration mode.
Step 4	passthru-hdr header-name Example: Device(config-class)# passthru-hdr Resource-Priority	Adds header name to the list of headers to be passed through. Repeat this step for every non-mandatory header.
Step 5	passthru-hdr-unsupp Example: Device(config-class)# passthru-hdr-unsupp	Adds the unsupported headers to the list of headers to be passed through.

	Command or Action	Purpose
Step 6	exit Example: Device(config-class)# exit	Exits the current configuration session and returns to global configuration mode.
Step 7	dial-peer voice tag voip Example: Device(config)# dial-peer voice 1 voip	Enters dial peer voice configuration mode.
Step 8	description string Example: Device(config-dial-peer)# description inbound-dialpeer	Adds descriptive information about the dial peer.
Step 9	session protocol sipv2 Example: Device(config-dial-peer)# session protocol sipv2	Configures the IETF Session Initiation Protocol (SIP) for the dial peer.
Step 10	voice-class sip pass-thru headers list-tag Example: Device(config-dial-peer)# voice-class sip pass-thru headers 101	Enables call routing based on the destination route string for a dial peer.
Step 11	end Example: Device(config-dial-peer)# end	Exits the current configuration mode and returns to privileged EXEC mode.

Verifying Cisco UBE Intercluster Lookup Service Configuration

The **show** commands can be entered in any order.

SUMMARY STEPS

1. **enable**
2. **show voice class route-string**
3. **show call active voice**
4. **show call history voice**
5. **show sip call**

DETAILED STEPS

Step 1 **enable**
Enables privileged EXEC mode.

- Enter your password if prompted.

Example:

```
Device> enable
```

Step 2 **show voice class route-string**
Displays the call route-string status for voice ports.

Example:

```
Device# show voice class route-string
voice class route-string 2:
  pattern london.uk.eu
  configured in dial-peers: 7 4 6
```

Step 3 **show call active voice**
Displays call information for voice calls in progress. The sample output below shows the destination route string configuration.

Example:

```
Device# show call active voice
DestinationRouteStr=london.uk.eu
```

Step 4 **show call history voice**
Displays the call history table for voice calls. The sample output below shows the destination route string configuration.

Example:

```
Device# show call history voice | in Des
DestinationRouteStr=london.uk.eu
```

Step 5 **show sip call**
Displays active user agent client (UAC) and user agent server (UAS) information on SIP calls.

Example:

```
Device# show sip call
Total SIP call legs:2, User Agent Client:1, User Agent Server:1
SIP UAC CALL INFO
Call 1
SIP Call ID           : 5A4CAE55-E48D11E2-802BDD60-8693A1D1@192.0.2.1
  State of the call    : STATE_ACTIVE (7)
  Substate of the call : SUBSTATE_NONE (0)
  Calling Number       : 345111
  Called Number        :
  Bit Flags            : 0xC04018 0x10000100 0x80
  CC Call ID          : 12
  Source IP Address (Sig) : 192.0.2.1
  Destn SIP Req Addr:Port : [192.0.2.6]:5060
  Destn SIP Resp Addr:Port: [192.0.2.6]:5060
  Destination Name      : 192.0.2.6
```

```

Number of Media Streams : 1
Number of Active Streams: 1
RTP Fork Object        : 0x0
Media Mode             : flow-through
Media Stream 1
  State of the stream   : STREAM_ACTIVE
  Stream Call ID       : 12
  Stream Type          : voice-only (0)
  Stream Media Addr Type : 1
  Negotiated Codec     : g711ulaw (160 bytes)
  Codec Payload Type   : 0
  Negotiated Dtmf-relay : inband-voice
  Dtmf-relay Payload Type : 0
  QoS ID               : -1
  Local QoS Strength   : BestEffort
  Negotiated QoS Strength : BestEffort
  Negotiated QoS Direction : None
  Local QoS Status     : None
  Media Source IP Addr:Port: [192.0.2.1]:16406
  Media Dest IP Addr:Port  : [192.0.2.6]:6020

```

```

Options-Ping    ENABLED:NO    ACTIVE:NO
  Number of SIP User Agent Client(UAC) calls: 1

```

SIP UAS CALL INFO

Call 1

```

SIP Call ID      : 1-27273@192.0.2.6
  State of the call : STATE_ACTIVE (7)
  Substate of the call : SUBSTATE_NONE (0)
  Calling Number    : 345111
  Called Number     : alice
  Bit Flags        : 0xC0401C 0x10000100 0x4
  CC Call ID       : 11
  Source IP Address (Sig) : 192.0.2.1
  Destn SIP Req Addr:Port : [192.0.2.6]:5061
  Destn SIP Resp Addr:Port: [192.0.2.6]:5061
  Destination Name   : 192.0.2.6
  Destination Route String: london.uk.eu //This is the configured dest-route-string pattern.//
  Number of Media Streams : 1
  Number of Active Streams: 1
  RTP Fork Object    : 0x0
  Media Mode        : flow-through
Media Stream 1
  State of the stream   : STREAM_ACTIVE
  Stream Call ID       : 11
  Stream Type          : voice-only (0)
  Stream Media Addr Type : 1
  Negotiated Codec     : g711ulaw (160 bytes)
  Codec Payload Type   : 0
  Negotiated Dtmf-relay : inband-voice
  Dtmf-relay Payload Type : 0
  QoS ID               : -1
  Local QoS Strength   : BestEffort
  Negotiated QoS Strength : BestEffort
  Negotiated QoS Direction : None
  Local QoS Status     : None
  Media Source IP Addr:Port: [192.0.2.1]:16404
  Media Dest IP Addr:Port  : [192.0.2.6]:6000

```

```

Options-Ping    ENABLED:NO    ACTIVE:NO
  Number of SIP User Agent Server(UAS) calls: 1

```

Configuration Examples for Cisco UBE Intercluster Lookup Service

Example: Configuring a Route String Pattern

```
Device> enable
Device# configure terminal
Device(config)# voice class route-string 2
Device(config-class)# pattern london.uk.eu
Device(config-class)# pattern *.uk.eu
Device(config-class)# pattern *.eu
Device(config-class)# end
```

Example: Configuring a Call Route on a Destination Route String Globally

```
Device> enable
Device# configure terminal
Device(config)# voice service voip
Device(conf-voi-serv)# sip
Device(conf-serv-sip)# call-route dest-route-string
Device(conf-serv-sip)# end
```

Example: Configuring a Route String Passthrough List Header

```
Device> enable
Device# configure terminal
Device(config)# voice class sip-hdr-passthru-list 2
Device(config-class)# passthru-hdr x-cisco-dest-route-string
```

Example: Configuring a Destination Route String Call Route at the Dial-Peer Level

```
Device> enable
Device# configure terminal
Device# dial-peer voice 1 voip
Device(config-dial-peer)# description outbound-dialpeer
Device(config-dial-peer)# destination route-string 2
Device(config-dial-peer)# session protocol sipv2
Device(config-dial-peer)# session target ipv4:192.0.2.6
Device(config-dial-peer)# voice-class sip call-route dest-route-string
```

Example: Configuring a Route String Header Pass-Through Using Pass-Through List

```
Device> enable
```

```

Device# configure terminal
Device(config)# voice class sip-hdr-passthru-list 101
Device(config-class)# passthru-hdr X-hdr-1
Device(config-class)# passthru-hdr Resource-Priority
Device(config-class)# passthru-hdr-unsupp
Device(config-class)# exit
Device(config)# dial-peer voice 1 voip
Device(config-dial-peer)# description inbound-dialpeer
Device(config-dial-peer)# session protocol sipv2
Device(config-dial-peer)# voice-class sip pass-thru headers 101
Device(config-dial-peer)# end

```

Feature Information for Cisco UBE Intercluster Lookup Service

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Table 7: Feature Information for CUBE Inter Cluster Look Up Service

Feature Name	Releases	Feature Information
CUBE Intercluster Lookup Service (ILS)	15.3(3)M	<p>The Cisco UBE Inter Cluster Look up Service feature enables Cisco Unified Communications Manager to establish calls using Uniform Resource Identifiers (URIs.) It provides a framework for sharing information about user-contact information between Cisco Unified Communications Manager clusters. All URIs being used within a cluster are grouped together and associated with a cluster identifier called a route string. To interoperate with Cisco Unified Communications Manager, Cisco UBE is enhanced to route the call based on the received destination route string. This feature works with Cisco Unified Communication Manager Version 9.5 and later.</p> <p>The following commands were introduced or modified:</p> <p>call-route,destination route-string,passthru-hdr,voice class route-string,voice class sip-hdr-passthru-list,voice-class sip call-route,show call active voice,show call history voice.</p>

Feature Name	Releases	Feature Information
CUBE Intercluster Lookup Service (ILS)	Cisco IOS XE Release 3.10S	<p>The Cisco UBE Inter Cluster Lookup Service feature enables Cisco Unified Communications Manager to establish calls using Uniform Resource Identifiers (URIs.) It provides a framework for sharing information about user-contact information between Cisco Unified Communications Manager clusters. All URIs being used within a cluster are grouped together and associated with a cluster identifier called a route string. To interoperate with Cisco Unified Communications Manager, Cisco UBE is enhanced to route the call based on the received destination route string. This feature works with Cisco Unified Communication Manager Version 9.5 and later.</p> <p>The following commands were introduced or modified:</p> <p>call-route,destination route-string, passthru-hdr, voice class route-string, voice class sip-hdr-passthru-list, voice-class sip call-route, show call active voice, show call history voice.</p>