



Support for Media Flow- Around with SIP Signaling control on CUBE

Last Updated: December 20, 2011

- [Finding Feature Information, page 1](#)
- [Prerequisites, page 1](#)
- [Configuring Delayed-Offer to Early-Offer Media Flow-Around at the Global Level, page 2](#)
- [Configuring Delayed-Offer to Early-Offer Media Flow-Around for a Dial-Peer, page 3](#)
- [Configuring Delayed-Offer to Early-Offer Media Flow-Around for High-Density Transcoding Calls, page 5](#)
- [Feature Information for Media Flow- Around with SIP Signaling control on Cisco UBE, page 7](#)

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the Feature Information Table at the end of this document.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

Prerequisites

Cisco Unified Border Element

- Cisco IOS Release 15.1(3)T or a later release must be installed and running on your Cisco Unified Border Element.

Cisco Unified Border Element (Enterprise)

- Cisco IOS XE Release <TBD> or a later release must be installed and running on your Cisco ASR 1000 Series Router.



Americas Headquarters:
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

Configuring Delayed-Offer to Early-Offer Media Flow-Around at the Global Level

Perform this task to configure delayed-offer (DO) to early-offer (EO) media flow-around at the voice service configuration mode.

SUMMARY STEPS

1. enable
2. configure terminal
3. voice service voip
4. media flow-around
5. sip
6. early offer-forced
7. exit
8. exit
9. exit

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	voice service voip Example: Router(config)# voice service voip	Enters voice service configuration mode.
Step 4	media flow-around Example: Router(config-voi-serv)# media flow-around	Enables media flow-around.

Command or Action	Purpose
Step 5 sip Example: Router(config-voi-serv)# sip	Enters SIP configuration mode.
Step 6 early offer-forced Example: Router(config-serv-sip)# early offer-forced	Forcefully sends SIP EO invites on the Out-Leg(OL).
Step 7 exit Example: Router(config-serv-sip)# exit	Exits SIP configuration mode and returns to voice service configuration mode.
Step 8 exit Example: Router(config-voi-serv)# exit	Exits voice service configuration mode and returns to global configuration mode.
Step 9 exit Example: Router(config# exit Example:	Exits global configuration mode and returns to privileged EXEC mode.

Configuring Delayed-Offer to Early-Offer Media Flow-Around for a Dial-Peer

Perform this task to configure DO to EO Media Flow-Around for an individual dial peer.

SUMMARY STEPS

1. enable
2. configure terminal
3. dial-peer voice *number* voip
4. media flow-around
5. voice class sip early-offer forced
6. exit
7. exit

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	dial-peer voice <i>number</i> voip Example: Router(config)# dial-peer voice 1 voip	Enters dial peer voice configuration mode for the specified VoIP dial peer.
Step 4	media flow-around Example: Router(config-dial-peer)# media flow-around	Enables media flow-around.
Step 5	voice class sip early-offer forced Example: Router(config-dial-peer)# voice class sip early-offer forced	Forcefully sends SIP EO invites on the Out-Leg.

Command or Action	Purpose
Step 6 <code>exit</code> Example: Router(config-dial-peer)# <code>exit</code>	Exits dial peer voice configuration mode and returns to global configuration mode.
Step 7 <code>exit</code> Example: Router(config)# <code>exit</code>	Exits global configuration mode and returns to privileged EXEC mode.

Configuring Delayed-Offer to Early-Offer Media Flow-Around for High-Density Transcoding Calls

Perform this task to configure Delayed-Offer to Early-Offer Media transcoding high-density calls.

SUMMARY STEPS

1. `enable`
2. `configure terminal`
3. `voice service voip`
4. `media transcoder high-density`
5. `sip`
6. `early offer-forced`
7. `exit`
8. `exit`
9. `exit`

DETAILED STEPS

Command or Action	Purpose
Step 1 <code>enable</code> Example: Router> <code>enable</code>	Enables privileged EXEC mode. • Enter your password if prompted.

Command or Action	Purpose
Step 2 <code>configure terminal</code> Example: Router# <code>configure terminal</code>	Enters global configuration mode.
Step 3 <code>voice service voip</code> Example: Router(config)# <code>voice service voip</code>	Enters voice service configuration mode.
Step 4 <code>media transcoder high-density</code> Example: Router(config-voi-serv)# <code>media transcoder high-density</code>	Enables media transcoder high-density for transcoding high-density media calls.
Step 5 <code>sip</code> Example: Router(config-voi-serv)# <code>sip</code>	Enters SIP configuration mode.
Step 6 <code>early offer-forced</code> Example: Router(config-serv-sip)# <code>early offer-forced</code>	Forcefully sends SIP EO invites on the Out-Leg.
Step 7 <code>exit</code> Example: Router(config-serv-sip)# <code>exit</code>	Exits SIP configuration mode and returns to voice service configuration mode.
Step 8 <code>exit</code> Example: Router(config-voi-serv)# <code>exit</code>	Exits voice service configuration mode and returns to global configuration mode.

Command or Action	Purpose
Step 9 <code>exit</code> Example: Router(config)# <code>exit</code> Example:	Exits global configuration mode and returns to privileged EXEC mode.

Feature Information for Media Flow- Around with SIP Signaling control on Cisco UBE

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to www.cisco.com/go/cfn. An account on Cisco.com is not required.

ISR Feature table entry

Table 1 Feature Information for Media Flow- Around with SIP Signaling control on Cisco UBE

Feature Name	Releases	Feature Information
Media Flow- Around with SIP Signaling control on CiscoUBE	15.1(3)T	Support for Media Flow-Around for Delayed-Offer to Early-Offer audio calls on Cisco UBE were introduced.The following section provides information about this feature: No new commands were introduced or modified.

ASR Feature table entry

Table 2 **Feature Information for Media Flow- Around with SIP Signaling control on CUBE**

Feature Name	Releases	Feature Information
Media Flow- Around with SIP Signaling control on CiscoUBE	TBD	Support for Media Flow-Around for Delayed-Offer to Early-Offer audio calls on Cisco UBE were introduced.The following section provides information about this feature: No new commands were introduced or modified.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2011 Cisco Systems, Inc. All rights reserved.