



show vdev through show voice statistics memory-usage

- [show vdev](#), on page 3
- [show vfc](#), on page 5
- [show vfc cap-list](#), on page 6
- [show vfc default-file](#), on page 7
- [show vfc directory](#), on page 8
- [show vfc version](#), on page 10
- [show video call summary](#), on page 13
- [show voice accounting method](#), on page 14
- [show voice accounting response pending](#), on page 16
- [show voice busyout](#), on page 17
- [show voice cable-status](#), on page 18
- [show voice call](#), on page 19
- [show voice call rate](#), on page 29
- [show voice cause-code](#), on page 31
- [show voice class called-number](#), on page 33
- [show voice class called-number-pool](#), on page 34
- [show voice class e164-pattern-map](#), on page 36
- [show voice class e164-translation](#), on page 37
- [show voice class phone-proxy](#), on page 39
- [show voice class resource-group](#), on page 41
- [show voice class server-group](#), on page 43
- [show voice class sip-options-keepalive](#), on page 45
- [show voice class sip-predefined-profiles](#), on page 46
- [show voice class uri](#), on page 47
- [show voice connectivity summary](#), on page 50
- [show voice data](#), on page 51
- [show voice dnis-map](#), on page 53
- [show voice dsmp stream](#), on page 55
- [show voice dsp](#), on page 62
- [show voice dsp channel](#), on page 69
- [show voice dsp crash-dump](#), on page 72

- [show voice dsp summary](#), on page 74
- [show voice eddri prefix](#), on page 76
- [show voice emergency locations](#), on page 77
- [show voice enum-match-table](#), on page 78
- [show voice hpi capture](#), on page 79
- [show voice iec description](#), on page 80
- [show voice lmr](#), on page 81
- [show voice pcm capture](#), on page 86
- [show voice port](#), on page 87
- [show voice sip license](#), on page 99
- [show voice source-group](#), on page 134
- [show voice statistics csr interval accounting](#), on page 137
- [show voice statistics csr interval aggregation](#), on page 139
- [show voice statistics csr since-reset accounting](#), on page 144
- [show voice statistics csr since-reset aggregation-level](#), on page 146
- [show voice statistics csr since-reset all](#), on page 151
- [show voice statistics iec](#), on page 155
- [show voice statistics interval-tag](#), on page 157
- [show voice statistics memory-usage](#), on page 159

show vdev

To display information about the digital signal processors (DSPs) on a specific card, use the show vdev command in privileged EXEC mode.

show vdev {*slot/port*}

Syntax Description

<i>slot</i>	Slot in which the voice card resides.
<i>port</i>	Port on the voice card.

Command Default

No default behavior or values.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.3(2)T	This command was introduced on the Cisco AS5850.

Usage Guidelines

This command can be used on the standby and active route switch controller (RSC) to verify that dynamic and bulk synchronization have been performed correctly on a specified port.

Examples

The following example shows the output for the last port on a 324 universal port card.

```
Router# show vdev 2/323
flags = 0x0000
dev_status = 0x0000
service = 0x0000
service_type = 0x0
min_speed = 0, max_speed = 0
modulation = 0, err_correction = 0, compression = 0
csm_call_info = 0x0, csm_session = Invalid
vdev_p set to modem_info
DSPLIB information:
dsplib_state = 0x0
dsplib_next_action = 0x0
HDLC information:
call_id = 0x0
called_number =
speed = 0
ces = 0x0
spc = FALSE
d_idb = 0x0
Bulk sync reference = 2, Global bulk syncs = 2
```

The table below displays significant fields shown in the output.

Table 1: show vdev Field Descriptions

Field	Description
flags	Internal vdev flags
dev_status	Additional flags giving status of the resource
service	Service currently running on this DSP
service_type	Service type as passed in by RPM
min_speed	Minimum configured modem speed
max_speed	Maximum configured modem speed
modulation	Maximum modulation to be negotiated
err_correction	Error correction to be negotiated
compression	Compression to be negotiated
csm_call_info	Address of the associated csm_call_info structure
csm_session	Session ID as maintained by CSM
vdev_p	Address of the associated resource structure
dsplib_state	State of the resource as seen by the DSPLIB
dsplib_next_action	Next DSPLIB action that should be taken on this resource
call_id	Call identifier if this resource has a HDLC call
called_number	Called number if this resource has a HDLC call
speed	Speed of the connection if this resource has a HDLC call
ces	Circuit emulation service information
spc	True if semi permanent call link
d_idb	Address of the associated D channel idb, if this resource has a HDLC call
Bulk sync reference	Number of times that this resource has been bulk synchronized
Global bulk syncs	Number of bulk synchronizations that the VDEV High Availability client has performed

Related Commands

Command	Description
debug vdev	Turns on debugging for voice devices.
show redundancy	Displays current or historical status and related information on a redundant RSC.

show vfc

To see the entries in the host-name-and-address cache, use the **show vfc** command in privileged EXEC mode.

show vfc *slot-number* [**technology**]

Syntax Description	
<i>slot-number</i>	VFC slot number.
technology	(Optional) Displays the technology type of the VFC.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
11.3 NA	This command was introduced on the Cisco AS5300.
12.0(2)XH	The technology keyword was added.

Examples

The following is sample output from this command showing that the card in slot 1 is a C549 DSPM:

```
Router# show vfc 1 technology
Technology in VFC slot 1 is C549
```

Field descriptions should be self-explanatory.

Related Commands

Command	Description
voice-card	Configures a voice card and enters voice-card configuration mode.

show vfc cap-list

To show the current list of files on the capability list for this voice feature card (VFC), use the **show vfc cap-list** command in user EXEC mode.

show vfc slot cap-list

Syntax Description

<i>slot</i>	Slot where the VFC is installed. Range is from 0 to 2.
-------------	--

Command Modes

User EXEC (>)

Command History

Release	Modification
11.3 NA	This command was introduced on the Cisco AS5300.

Examples

The following is sample output from this command:

```
Router# show vfc 1 cap-list
Capability List for VFC in slot 1:
1. fax-vfc-1.0.1.bin
2. bas-vfc-1.0.1.bin
3. cdc-g729-1.0.1.bin
4. cdc-g711-1.0.1.bin
5. cdc-g726-1.0.1.bin
6. cdc-g728-1.0.1.bin
7. cdc-gsmfr-1.0.1.bin
```

The first line in this output is a general description, stating that this is the capability list for the VFC residing in slot 1. Below this is a numbered list, each line of which identifies one currently installed in-service file.

Related Commands

Command	Description
show vfc default -file	Displays the default files included in the default file list for this VFC.
show vfc directory	Displays the list of all files residing on this VFC.
show vfc version	Displays the version of the software residing on this VFC.

show vfc default-file

To show the default files included in the default file list for a voice feature card (VFC), use the **show vfc default-file** command in user EXEC mode.

show vfc slot default-file

Syntax Description

<i>slot</i>	Slot where the VFC is installed. Range is from 0 to 2.
-------------	--

Command Modes

User EXEC (>)

Command History

Release	Modification
11.3 NA	This command was introduced on the Cisco AS5300.

Examples

The following is sample output from this command:

```
Router# show vfc 1 default-file
Default List for VFC in slot 1:
1. btl-vfc-1.0.13.0.bin
2. cor-vfc-1.0.1.bin
3. bas-vfc-1.0.1.bin
4. cdc-g729-1.0.1.bin
5. fax-vfc-1.0.1.bin
6. jbc-vfc-1.0.13.0.bin
```

The first line in this output is a general description, stating that this is the default list for the VFC residing in slot 1. Below this is a numbered list, each line of which identifies one default file.

Related Commands

Command	Description
show vfc cap -list	Displays the current list of files on the capability list for this VFC.
show vfc directory	Displays the list of all files residing on this VFC.
show vfc version	Displays the version of the software residing on this VFC.

show vfc directory

To show the list of all files residing on a voice feature card (VFC), use the **show vfc directory** command in user EXEC mode.

show vfc slot directory

Syntax Description

<i>slot</i>	Slot where the VFC is installed. Range is from 0 to 2.
-------------	--

Command Modes

User EXEC (>)

Command History

Release	Modification
11.3 NA	This command was introduced on the Cisco AS5300.

Usage Guidelines

Use this command to display a list of all of the files currently stored in Flash memory for a particular VFC.

Examples

The following is sample output from this command:

```
Router# show vfc 1 directory
Files in slot 1 VFC flash:
  File Name                               Size (Bytes)
 1 . vcw-vfc-mz.gsm.VCW                   292628
 2 . btl-vfc-1.0.13.0.bin                  4174
 3 . cor-vfc-1.0.1.bin                     54560
 4 . jbc-vfc-1.0.13.0.bin                  16760
 5 . fax-vfc-1.0.1.bin                     64290
 6 . bas-vfc-1.0.1.bin                     54452
 7 . cdc-g711-1.0.1.bin                    190
 8 . cdc-g729-1.0.1.bin                    21002
 9 . cdc-g726-1.0.1.bin                     190
10 . cdc-g728-1.0.1.bin                    22270
11 . cdc-gsmfr-1.0.1.bin                    190
```

The table below describes significant fields in this output.

Table 2: show vfc directory Field Descriptions

Field	Description
File Name	Name of the file stored in Flash memory.
Size (Bytes)	Size of the file in bytes.

Related Commands

Command	Description
show vfc cap -list	Displays the current list of files on the capability list for this VFC.
show vfc default -file	Displays the default files included in the default file list for this VFC.

Command	Description
show vfc version	Displays the version of the software residing on this VFC.

show vfc version

To show the version of the software residing on a voice feature card (VFC), use the **show vfc version** command in user EXEC mode.

show vfc slot version {dspware | vcware}

Syntax Description

<i>slot</i>	Slot where the VFC is installed. Range is from 0 to 2.
dspware	Which DSPWare software to display.
vcware	Which VCWare software to display.

Command Modes

Privileged EXEC (#)
User EXEC (>)

Command History

Release	Modification
11.3 NA	This command was introduced on the Cisco AS5300.
12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T with changes to the command output.

Usage Guidelines

Use this command to display the version of the software currently installed in Flash memory on a VFC.

Examples

The following is sample output from this command:

```
Router# show vfc 0 version dspware
Version of Dspware in VFC slot 0 is 0.10
```

The output from this command is a simple declarative sentence stating the version number for the selected type of software (in this example, DSPWare) for the VFC residing in the selected slot number (in this example, slot 0).

Cisco IOS Release 12.2(13)T adds new information to the output of the `show vfc slot version vcware` and `show vfc slot version dspware` commands. Messages are output if the Cisco VCWare or DSPWare is not compatible with the Cisco IOS image. The new information is advisory only, so there is no action taken if the software is compatible or incompatible.

If the versions detected fall within the defined criteria and are compatible, nothing is output at bootup time. A confirmation line is output when the `show vfc version vcware` and `show vfc version dspware` commands are used:

```
Router# show vfc 1 version vcware
Voice Feature Card in Slot 1:
VCWare Version      : 7.35
ROM Monitor Version: 1.3
  DSPWare Version   : 3.4.46L
  Technology        : C549
VCWare/DSPWare version compatibility OK
```

The table below shows output field descriptions for the show vfc version veware command with compatible firmware.

Table 3: show vfc version veware Field Descriptions

Field	Description
Voice Feature Card in Slot	Slot in which the VFC is installed.
VCWare Version	Cisco VCWare version. Version 7.35 is the required minimum for Cisco IOS Release 12.2(11)T and higher.
ROM	ROM monitor version shows 1.3 .
DSPWare Version	The DSPWare version shows 3.4.46L, which is the required minimum for Cisco IOS Release 12.2(11)T and higher .
Technology	The technology shows C549. C549 technology is available to support either medium-complexity codecs or high-complexity codecs.
VCWare/DSPWare version compatibility	The Cisco VCWare and DSPWare versions are compatible with Cisco IOS software . Cisco VCWare/DSPWare version compatibility is either OK or shows a mismatch. Note This option is available only with Cisco IOS Release 12.2(10) mainline and later release or Cisco IOS Release 12.2(11)T and later.

The following is sample output from this command.

```
Router# show vfc 1 version dspware
DSPWare version in VFC slot 1 is 3.4.46L
VCWare/DSPWare version compatibility OK
```

The table below shows output field descriptions for the show vfc version dspware command with compatible firmware.

Table 4: show vfc version dspware Field Descriptions

Field	Description
Voice Feature Card in Slot	Slot in which the VFC is installed .
DSPWare Version	The DSPWare version shows 3.4.46L, which is the required minimum for Cisco IOS Release 12.2(10)T and higher .
VCWare/DSPWare version compatibility	The Cisco VCWare and DSPWare versions are compatible with Cisco IOS software. Cisco VCWare/DSPWare version compatibility is either OK or shows a mismatch. Note This option is available only with Cisco IOS Release 12.2(10) mainline and later or 12.2(11)T and later.

If the found versions are out of range or otherwise mismatched, a representative message is output when you boot up the router or is appended to the output of the `show vfc version veware` and `show vfc version dspware` commands. Other than the output of these messages, the version check has no other effect, and the software functions normally. The following is an example of when a found version is out of range or mismatched at bootup :

```
...
Firmware version mismatch for bundle AS5300 VCWare
- version found (6.04) is lower than minimum required (7.35)
Firmware version mismatch for bundle AS5300 C549
- version found (3.3.10L) is lower than minimum required (3.4.46L)
```

If you were to enter an explicit request, and the software were incompatible, the following output would be displayed :

```
Router# show vfc 1 version veware
Voice Feature Card in Slot 1:
VCWare Version      : 6.04
ROM Monitor Version: 1.3
  DSPWare Version   : 3.3.10L
  Technology        : C549
Firmware version mismatch for bundle AS5300 VCWare
- version found (6.04) is lower than minimum required (7.14)
Firmware version mismatch for bundle AS5300 C549
- version found (3.3.10L) is lower than minimum required (3.4.26L)
Router# show vfc 1 version dspware
DSPWare version in VFC slot 1 is 3.3.10L
Firmware version mismatch for bundle AS5300 VCWare
- version found (6.04) is lower than minimum required (7.14)
Firmware version mismatch for bundle AS5300 C549
- version found (3.3.10L) is lower than minimum required (3.4.26L)
```

Related Commands

Command	Description
<code>show vfc cap -list</code>	Displays the current list of files on the capability list for this VFC.
<code>show vfc default -file</code>	Displays the default files included in the default file list for this VFC.
<code>show vfc directory</code>	Displays the list of all files residing on this VFC.

show video call summary

To display summary information about video calls and the current status of the Video CallManager (ViCM), use the **show video call summary** command in privileged EXEC mode.

show video call summary

Syntax Description

There are no arguments or keywords.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.0(5)XK	This command was introduced on the Cisco MC3810.
12.0(7)T	The command was integrated into Cisco IOS Release 12.0(7)T.

Usage Guidelines

Use this command to quickly examine the status of current video calls. In Cisco IOS Release 12.0(5)XK and Release 12.0(7)T, there can be only one video call in progress.

Examples

The following example displays information about the ViCM when no call is in progress on the serial interface that connects to the local video codec:

```
Router# show video call summary
Serial0:ViCM =
Idle, Codec Ready
```

The following output shows a call starting:

```
Router# show video call summary
Serial0:ViCM = Call Connected
```

The following output shows a call disconnecting:

```
Router# show video call summary
Serial0:ViCM = Idle
```

Related Commands

Command	Description
show call history video record	Displays information about video calls.

show voice accounting method

To display connectivity status information for accounting method lists, use the **show voice accounting method** command in privileged EXEC mode.

show voice accounting method [*method-list-name*]

Syntax Description

<i>method-list-name</i>	(Optional) Name of a specific method list. This option displays connectivity status information for a single method list identified by this argument.
-------------------------	---

Command Default

If no argument is specified, connectivity status information for all accounting method lists is displayed.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.3(4)T	This command was introduced.

Usage Guidelines

Use the **show voice accounting method** command to display the history of status (reachable or unreachable), status transition time, and statistics of the accounting status for a specified accounting method list or all the accounting method lists. A maximum of ten status histories are displayed.

Examples

The following is sample output from the **show voice accounting method** command for a specific method list:

```
Router# show voice accounting method m11
Accounting Method List [m11]
=====
Current Status:
-----
unreachable          [21:52:39 gmt Dec 4 2002]
last record sent time [23:14:59 gmt Dec 4 2002]
total probe sent out  [84]
Status History:
-----
(2) unreachable      [21:52:39 gmt Dec 4 2002]
(1) reachable        [21:46:19 gmt Dec 4 2002]

```

Record Type	SUCCESS			FAILURE		
	[Received from server]	[Notified to client]	[Reported to call]	[Received from server]	[Notified to client]	[Reported to call]
START	[0]	[0]	[0]	[0]	[0]	[0]
UPDATE	[0]	[0]	[0]	[0]	[0]	[0]
STOP	[0]	[0]	[0]	[84]	[84]	[0]
ACCT_ON	[0]	[0]	[0]	[0]	[0]	[0]
TOTAL	[0]	[0]	[0]	[84]	[84]	[0]

If there is no status history, as in the following example, no status history is displayed.

```
Router# show voice accounting method
```

```

Accounting Method List [ml1]
=====
Current Status:
-----
reachable                [21:52:39 gmt Dec 4 2002]
last record sent time    [23:14:59 gmt Dec 4 2002]
total probe sent out     [2]

              SUCCESS                                FAILURE
Record [Received | Notified ] [Received | Notified | Reported ]
Type   [from server| to client] [from server| to client | to call ]
----- [-----|-----] [-----|-----|-----]
START  [ 0 | 0 ] [ 0 | 0 | 0 ]
UPDATE [ 0 | 0 ] [ 0 | 0 | 0 ]
STOP   [ 0 | 0 ] [ 2 | 2 | 0 ]
ACCT_ON [ 0 | 0 ] [ 0 | 0 | 0 ]
----- [-----|-----] [-----|-----|-----]
TOTAL  [ 0 | 0 ] [ 2 | 2 | 0 ]

```

The table below describes the significant fields shown in the display.

Table 5: show voice accounting method Field Descriptions

Field	Description
Current Status: reachable or unreachable	Current status of the method list: reachable or unreachable and the time (in hh:mm:ss) and date the method list reached this status.
last record sent time	Time (in hh:mm:ss) and date the last accounting record was sent to the method list.
total probe sent out	Number of probe records sent up to the time of the show command.
SUCCESS: Received from server	Number of success status of the accounting records of this type received from the method list.
SUCCESS: Notified to client	Number of success status of the accounting records of this type for which notifications were sent to the GAS.
FAILURE: Received from server	Number of failure status of the accounting records of this type received from the method list.
FAILURE: Notified to client	Number of failure status of the accounting records of this type for which notifications were sent to the GAS.
FAILURE: Reported to call	Number of failure status of the accounting records of this type that were reported to the call application.

Related Commands

Command	Description
clear voice accounting method	Clears accounting status statistics for a particular accounting method list or all accounting method lists.

show voice accounting response pending

To display information regarding pending VoIP AAA accounting responses, use the **show voice accounting response pending** command in privileged EXEC mode.

show voice accounting response pending

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.3(4)T	This command was introduced.

Examples

The following example displays information regarding pending VoIP AAA accounting responses:

```
Router# show voice accounting response pending
Total num of acct sessions waiting for acct responses: 0
Total num of acct start responses pending:           0
Total num of acct interim update responses pending:  0
Total num of acct stop responses pending:            0
```

The table below lists and describes the significant output fields.

Table 6: show voice accounting response pending Field Descriptions

Field	Description
Total num of acct sessions waiting for acct responses	Number of accounting sessions that are waiting for accounting responses.
Total num of acct start responses pending	Number of accounting start responses that are pending.
Total num of acct interim update responses pending	Number of accounting interim update responses that are pending.
Total num of acct stop responses pending	Number of accounting stop responses that are pending.

show voice busyout

To display information about the voice-busyout state, use the **show voice busyout** command in privileged EXEC mode.

show voice busyout

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.0(3)T	This command was introduced on the Cisco MC3810.
12.0(7)XK	This command was implemented on the Cisco 2600 series and Cisco 3600 series.
12.1(2)T	This command was integrated into Cisco IOS Release 12.1(2)T.

Usage Guidelines

This command displays the following information:

- Interfaces that are being monitored for busyout events
- Voice ports currently in the busyout state and the reasons

Examples

The following is sample output from this command:

```
Router# show voice busyout
If following network interfaces are down, voice port will be put into busyout state
ATM0
Serial0
The following voice ports are in busyout state
1/1      is forced into busyout state
1/2      is in busyout state caused by network interfaces
1/3      is in busyout state caused by ATM0
1/4      is in busyout state caused by network interfaces
1/5      is in busyout state caused by Serial0
```

Field descriptions should be self-explanatory.

Related Commands

Command	Description
busyout forced	Forces a voice port into the busyout state.
busyout monitor	Places a voice port in the busyout monitor state.
busyout seize	Changes the busyout seize procedure from a voice port.
voice-port busyout	Places all voice ports associated with a serial or ATM interface in a busyout state.

show voice cable-status

To display the current or last cable status of a specific analog voice port or all idle analog voice ports, use the **show voice cable-status** command in privileged EXEC mode.

show voice cable-status {**all** | **summary***x/y/zx/y/z-zI*}

Syntax Description		
	all	Specifies the current cable status of all analog voice ports that have cable polling enabled.
	summary	Specifies the last cable status of all analog voice ports that have cable polling enabled.
	<i>x/y/z</i>	Voice port number.
	<i>x/y/z-zI</i>	Voice port number range. The range is from 0 to 71. Example: 2/0/0-71.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	15.2(4)M	This command was introduced.

Usage Guidelines Before using the **show voice cable-status** command, you must disable the **cable-detect-poll-timer** command.

Examples The following is sample output from the **show voice cable-status all** command:

```
Device# show voice cable-status all

Warning:This may take time to perform and cause call disruption!

PORT          cable-status
=====
0/2/0         cable-detect not configured
0/2/1         connected
0/2/2         connected
0/2/3         busy out
0/3/0         administrative down
0/3/1         in busy state
0/3/2         connected
0/3/3         connected
1/0/16        not connected
```

Related Commands	Command	Description
	cable-detect	Enables cable polling on analog FXOGS, FXOLS, FXSGS, and FXSLS voice ports.
	cable-detect-poll-timer	Configures the cable polling timer value for background polling processes on an analog voice port.

show voice call

To display the call status for voice ports on the Cisco router, use the **show voice call** command in user EXEC or privileged EXEC mode.

Cisco 827, Cisco 1700 Series, and Cisco 7750 with Analog Voice Ports

show voice call [*slot/port* | **status** [*call-id*] [**sample** *seconds*] | **summary**]

Cisco 2600, Cisco 3600, Cisco 3700 Series with Analog Voice Ports

show voice call [*slot/stubunit/port* | **status** [*call-id*] [**sample** *seconds*] | **summary**]

Cisco 2600, Cisco 3600, and Cisco 3700 Series with Digital Voice Ports (with T1 Packet Voice Trunk Network Modules)

show voice call [*slot/port:ds0-group* | **status** [*call-id*] [**sample** *seconds*] | **summary**]

Cisco AS5300, Cisco AS5350, Cisco AS5400, Cisco AS5850, Cisco 7200 Series, and Cisco 7500 Series with Digital Voice Ports

show voice call [*slot/port:ds0-group* | **status** [*call-id*] [**sample** *seconds*] | **summary**]

Syntax Description

Syntax Description	Cisco 827, Cisco 1700 Series, and Cisco 7750 with Analog Voice Ports
<i>slot/port</i>	(Optional) A specific analog voice port: <ul style="list-style-type: none"> • <i>slot--</i> Physical slot in which the analog voice module (AVM) is installed. • <i>/ port --</i>Analog voice port number. Range is from 1 to 6. The slash mark is required.
status [<i>call-id</i>]	(Optional) Displays status of active calls. If <i>call-id</i> is specified, this command displays the status of a specific call .
sample <i>seconds</i>	(Optional) Displays status over a specified sampling interval, in seconds. Range is from 1 to 30. Default is 10.
summary	(Optional) Displays current settings and state of the voice port, regardless of port activity.

Cisco 2600 Series, Cisco 3600 Series, Cisco 3700 Series with Analog Voice Ports	
<i>slot / subunit / port</i>	(Optional) A specific analog voice port: <ul style="list-style-type: none"> • <i>slot</i> --Router slot in which a voice network module (NM) is installed. Valid entries are router slot numbers for the particular platform. • <i>/ subunit</i> -- Voice interface card (VIC) in which the voice port is located. Valid entries are 0 and 1. (The VIC fits into the voice network module.) The slash mark is required. • <i>/ port</i> -- Analog voice port number. Valid entries are 0 and 1. The slash mark is required.
status [<i>call-id</i>]	(Optional) Displays status of active calls. If <i>call-id</i> is specified, this command displays the status of a specific call .
sample <i>seconds</i>	(Optional) Displays status over a specified sampling interval, in seconds. Range is from 1 to 30. Default is 10.
summary	(Optional) Displays current settings and state of the voice port, regardless of port activity.

Cisco 2600, Cisco 3600, and Cisco 3700 Series with Digital Voice Ports (with T1 Packet Voice Trunk Network Modules)	
<i>slot / port : ds0-group</i>	(Optional) A specific digital voice port: <ul style="list-style-type: none"> • <i>slot</i> -- Router slot in which the packet voice trunk network module (NM) is installed. Valid entries are router slot numbers for the particular platform. • <i>/ port</i> --T1 or E1 physical port in the voice WAN interface card (VWIC). Valid entries are 0 and 1. (One VWIC fits in an NM.) The slash mark is required. • <i>: ds0-group</i>--T1 or E1 logical port number. Range is from 0 to 23 for T1 and from 0 to 30 for E1. The colon is required.
status [<i>call-id</i>]	(Optional) Displays status of active calls. If <i>call-id</i> is specified, this command shows the status of a specific call .
sample <i>seconds</i>	(Optional) Displays status over a specified sampling interval, in seconds. Range is from 1 to 30. Default is 10.
summary	(Optional) Displays current settings and state of the DSP port regardless of port activity.

Cisco AS5300, Cisco AS5350, Cisco AS5400, Cisco AS5850, Cisco 7200 Series, and Cisco 7500 Series with Digital Voice Ports	
<i>slot / port : ds0 -group</i>	(Optional) A specific digital voice port: <ul style="list-style-type: none"> • <i>slot</i>--Router slot in which the packet voice trunk network module (NM) is installed. Valid entries are router slot numbers for the particular platform. • <i>/ port</i>-- T1 or E1 physical port in the VWIC. Valid entries are 0 and 1. (One VWIC fits in an NM.) The slash mark is required. • <i>: ds0 -group</i>--T1 or E1 logical port number. Range is from 0 to 23 for T1 and from 0 to 30 for E1. The colon is required.
status [<i>call-id</i>]	(Optional) Displays status of active calls. If <i>call-id</i> is specified, this command shows the status of a specific call .
sample <i>seconds</i>	(Optional) Displays status over a specified sampling interval, in seconds. Range is from 1 to 30. Default is 10.
summary	(Optional) Displays current settings and state of the voice port regardless of port activity.

Command Modes

User EXEC (#)
privileged EXEC (>)

Command History

Release	Modification
11.3(1)MA	This command was introduced on the Cisco MC3810.
12.0(7)XK	This command was implemented on the Cisco 2600 series and Cisco 3600 series.
12.1(2)T	This command was integrated into Cisco IOS Release 12.1(2)T.
12.2(13)T	This command was modified with the status , <i>call-id</i> , and sample seconds command options. This command is available on all voice platforms.
12.4(3d)	This command was modified to support the Cisco AS5350, Cisco AS5400, and Cisco AS5850 platforms for Non-Facility Associated Signaling (NFAS) configuration. Output was modified to provide accurate port information for NFAS configuration on these platforms.
15.1(3)T	This command was modified. The output of this command was enhanced to display the connection status of foreign exchange office (FXO) ports.

Usage Guidelines

This command works on Voice over Frame Relay, Voice over ATM, and Voice over IP by providing the status at the following levels of the call-handling module:

- Call-processing state machine

- End-to-end call manager
- Protocol state machine
- Tandem switch



Note This command is not supported in Cisco AS5350, Cisco AS5400, and Cisco AS5850 platforms for NFAS configuration before Cisco IOS Release 12.4(3d).

This command displays call-processing and protocol state-machine information for a voice port if the information is available. This command also shows information on the DSP channel associated with the voice port if the information is available. All real-time information in the DSP channel, such as jitter and buffer overrun, is queried to the DSP channel, and asynchronous responses are returned to the host side.

If no call is active on a voice port, the **show voice call summary** command displays only the VPM (shutdown) state. If a call is active on a voice port, the **show voice call summary** command displays voice telephony service provider (VTSP) state. For an on-net call or a local call without local bypass (not cross-connected), the codec and voice activity detection (VAD) fields are displayed. For an off-net call or a local call with local bypass, the codec and VAD fields are not displayed.

When a call is active on a voice port, the **show voice call summary** command displays the VTSP state. The VTSP state always shows the VTSP signaling state irrespective of the type of call: voice call or a fax call. A fax call does not display S_Fax. The following output is displayed:

PORT	CODEC	VAD	VTSP STATE	VPM STATE
1/0:1.1	1	y	S_CONNECT	EM_CONNECT



Note Use the **show voice dsmp stream** command to display the current session of the voice Distributed Stream Media Processor (DSMP) media stream and its related applications.

The **show voice call** command does not display the codec and VAD fields because this information is in the summary display. If you use the **show voice call status** command by itself, an immediate list of all the active calls is shown. You can use the *call-id* argument to request that the DSP associated with the *call-id* be queried for run-time statistics twice, once immediately, and a second time after **sample seconds**.

The **sample seconds** is the number of seconds over which the status is to be determined. The results of the run-time statistic queries are then analyzed and presented in a one-line summary format.

When a call terminates during the specified sample period, the following output message is returned:

```
CallID call id cannot be queried
CallID call id second sample responses unavailable
```



Note The Voice Call Tuning feature is not supported on the Cisco AS5300.


```

2/0/2      -      -      -      FXSLS_ONHOOK
2/0/3      -      -      -      FXSLS_ONHOOK
2/0/4      -      -      -      FXSLS_ONHOOK
2/0/5      -      -      -      FXSLS_ONHOOK
2/0/6      -      -      -      FXSLS_ONHOOK
2/0/7      -      -      -      FXSLS_ONHOOK

```



Note Beginning in Cisco IOS Release 15.1(3)T, there is improved status monitoring of FXO ports--any time an FXO port is connected or disconnected, a message is displayed to indicate the status change. For example, the following message is displayed to report that a cable has been connected, and the status is changed to "up" for FXO port 0/2/0: 000118: Jul 14 18:06:05.122 EST: %LINK-3-UPDOWN: Interface Foreign Exchange Office 0/2/0, changed state to operational status up due to cable reconnection

The following is sample output from the **show voice call summary** command showing one regular PRI port and one NFAS PRI port on a Cisco AS5350, Cisco AS5400, or Cisco AS5850 platform. Port 3/2:D belongs to a regular PRI voice port with time slots 0 and 22. Port Se3/1 belongs to an NFAS PRI voice port with time slots 0,1, and 2 on T1 controller 3/1, which is a member of an NFAS group.

In the case of NFAS on Cisco AS5350, Cisco AS5400, and Cisco AS5850 platforms, the port is reported in terms of the serial interface associated with the T1 controller, and the time slot is counted from 0 (for example, 0, 1, 2, 3).

```

Router# show voice call summary
PORT          CODEC    VAD  VTSP STATE          VPM STATE
=====
3/2:D.0       None     y   S_ALERTING      S_TSP_INCALL
3/2:D.22      None     y   S_ALERTING      S_TSP_INCALL
Se3/1:0       None     y   S_CONNECT       S_TSP_CONNECT
Se3/1:1       None     y   S_CONNECT       S_TSP_CONNECT
Se3/1:2       None     y   S_CONNECT       S_TSP_CONNECT

```



Note The output from the **show voice call summary** command is slightly different in the PORT field on platforms other than the Cisco AS5350, Cisco AS5400, and Cisco AS5850. The contrast between platform types is as follows: Platform Regular PRI (T1) NFAS PRI (T1)*
----- non-AS5xxx 3/0:23.TS 3/1:23.TS AS5xxx
3/0:D.TS Ser3/1:(TS-1) * Assumes T1 3/1 is a member of an NFAS group with T1 3/0 as the primary NFAS member, and TS is the time slot counted from a base of 1 (for example 1, 2, 3).

The following is sample output from the **show voice call** command for analog voice ports:

```

Router# show voice call
1/1 vpm level 1 state = FXSLS_ONHOOK
vpm level 0 state = S_UP
1/2 vpm level 1 state = FXSLS_ONHOOK
vpm level 0 state = S_UP
1/3 is shutdown
1/4 vtsp level 0 state = S_CONNECT
vpm level 1 state = S_TRUNKED
vpm level 0 state = S_UP

```

```

1/5 vpm level 1 state = EM_ONHOOK
vpm level 0 state = S_UP
1/6 vpm level 1 state = EM_ONHOOK
vpm level 0 state = S_UP
Router# show voice call 1/4
1/4 vtsp level 0 state = S_CONNECT
vpm level 1 state = S_TRUNCATED
vpm level 0 state = S_UP
router# ***DSP VOICE VP_DELAY STATISTICS***
Clk Offset(ms): 1445779863, Rx Delay Est(ms): 95
Rx Delay Lo Water Mark(ms): 95, Rx Delay Hi Water Mark(ms): 125
***DSP VOICE VP_ERROR STATISTICS***
Predict Conceal(ms): 10, Interpolate Conceal(ms): 0
Silence Conceal(ms): 0, Retroact Mem Update(ms): 0
Buf Overflow Discard(ms): 20, Talkspurt Endpoint Detect Err: 0
***DSP VOICE RX STATISTICS***
Rx Vox/Fax Pkts: 537, Rx Signal Pkts: 0, Rx Comfort Pkts: 0
Rx Dur(ms): 50304730, Rx Vox Dur(ms): 16090, Rx Fax Dur(ms): 0
Rx Non-seq Pkts: 0, Rx Bad Hdr Pkts: 0
Rx Early Pkts: 0, Rx Late Pkts: 0
***DSP VOICE TX STATISTICS***
Tx Vox/Fax Pkts: 567, Tx Sig Pkts: 0, Tx Comfort Pkts: 0
Tx Dur(ms): 50304730, Tx Vox Dur(ms): 17010, Tx Fax Dur(ms): 0
***DSP VOICE ERROR STATISTICS***
Rx Pkt Drops(Invalid Header): 0, Tx Pkt Drops(HPI SAM Overflow): 0
***DSP LEVELS***
TDM Bus Levels(dBm0): Rx -70.3 from PBX/Phone, Tx -68.0 to PBX/Phone
TDM ACOM Levels(dBm0): +2.0, TDM ERL Level(dBm0): +5.6
TDM Bgd Levels(dBm0): -71.4, with activity being voice

```

The following is sample output from the **show voice call** command for analog voice ports on a Cisco 7200 series. The output includes the DSPfarm, T1 interface, and DS0 or TLM slot configuration:

```

Router# show voice call 6/0:0
6/0:0 1 - - - vpm level 1 state = FXOGS_ONHOOK
vpm level 0 state = S_UP
6/0:0 2 - - - vpm level 1 state = FXOGS_ONHOOK
vpm level 0 state = S_UP
6/0:0 3 - - - vpm level 1 state = FXOGS_ONHOOK
vpm level 0 state = S_UP
6/0:0 4 - - - vpm level 1 state = FXOGS_ONHOOK
vpm level 0 state = S_UP
6/0:0 5 - - - vpm level 1 state = FXOGS_ONHOOK
vpm level 0 state = S_UP
6/0:0 6 - - - vpm level 1 state = FXOGS_ONHOOK
vpm level 0 state = S_UP
6/0:0 7 - - - vpm level 1 state = FXOGS_ONHOOK
vpm level 0 state = S_UP
6/0:0 8 - - - vpm level 1 state = FXOGS_ONHOOK
vpm level 0 state = S_UP
6/0:0 9 - - - vpm level 1 state = FXOGS_ONHOOK
6/0:0 10- - - vpm level 1 state = FXOGS_ONHOOK
vpm level 0 state = S_UP
6/0:0 11- - - vpm level 1 state = FXOGS_ONHOOK
vpm level 0 state = S_UP
6/0:0 12- - - vpm level 1 state = FXOGS_ONHOOK
vpm level 0 state = S_UP

```

The following is sample output from the **show voice call status** command on the Cisco 2600 series. You can use this command rather than the **show call active brief** command to obtain the caller ID; the caller ID output of the **show voice call status** command is already in hexadecimal form.

```
Router# show voice call status
CallID      CID  ccVdb      Port      DSP/Ch  Called #  Codec      Dial-peers
0x1         11CE 0x02407B20 1:0.1     1/1     1000     g711ulaw   2000/1000
1 active call found
```

Using the *call-id* argument is a generic means to identify active calls. If the *call-id* is omitted, the query shows all active voice calls. In the following example, a list of all active calls with relevant identifying information is shown:

```
Router# show voice call status
CallID      CID  ccVdb      Port      DSP/Ch  Called #  Codec      Dial-peers
0x3         11D4 0x62972834 1/0/0     1/1     10001    g711ulaw   1/2
0x4         11D4 0x62973AD0 1/0/1     2/1     *10001    g711ulaw   2/1
0xA         11DB 0x62FE9D68 1/1/0     3/1     *2692     g729r8     0/2692
2 active calls found
```



Note You can query only one call at a time. If you attempt queries from different ports (console and Telnet), and if a query is in progress on another port, the system asks you to wait for completion of that query. You can query any call from anywhere, at anytime, except during the sample interval for an enquiry that is already in progress. This simplifies the implementation significantly and does not reduce the usefulness of the command.

The following example shows echo-return-loss (ERL) reflector information where the call ID is 3 and the sample period is 10 seconds:

```
Router# show voice call status 3 sample 10
Gathering information (10 seconds)...
CallID      Port      DSP/Ch  Codec      Rx/Tx      ERL      Jitter
0x3         1/0/0     1/1     g711ulaw   742/154    5.6      50/15
```

In this example, ERL is the echo return loss (in dB) as reported by the DSP. Jitter values are the current delay and the jitter of the packets around that delay.

If the router is running the extended echo canceller, output looks similar to the following if you enter the same command. The output shows a new value under ERL/Reflectr: the time difference, in ms, between the original signal and the loudest echo (peak reflector) as detected by the echo canceller:

```
Router# show voice call status 3 sample 10
Gathering information (10 seconds)...
CallID      Port      DSP/Ch  Codec      Rx/Tx      ERL/Reflectr  Jitter
0x3         1/0/0     1/1     g711ulaw   742/154    5.6/12       50/15
```

The following examples show output using the NextPort version of the standard echo canceller. (Time-slot information is also in the output for digital ports.)

```
Router# show voice call status
CallID      CID  ccVdb      Port      DSP/Ch  Called #  Codec      Dial-peers
0x97         12BB 0x641B0F68 3/0:D.1   1012/2   31001    g711ulaw   3/31000
0x99         12BE 0x641B0F68 3/0:D.2   1012/3   31002    g711ulaw   3/31000
2 active calls found
Router# show voice call status
CallID      CID  ccVdb      Port      DSP/Ch  Called #  Codec      Dial-peers
0x2         11D1 0x62FE6478 1/0/0     1/1     10001    g711ulaw   1/2
0x3         11D1 0x62FE80F0 1/0/1     2/1     *10001    g711ulaw   2/1
1 active call found
```

When using the **test call id** command, you must specify a call ID, which you can obtain by using the **show voice call status** command. The following is an example of how to obtain the call ID for use as the *call-id* argument. The first parameter displayed in the output is the call ID.



Note Do not use the 0x prefix in the *call-id* argument when you enter the resulting call ID in the **test call status** command .

The following shows keyword choices when using the **show voice call** command with the | (pipe) option:

```
Router# show voice call | ?
  append    Append redirected output to URL (URLs supporting append operation
            only)
  begin     Begin with the line that matches
  exclude   Exclude lines that match
  include   Include lines that match
  redirect  Redirect output to a URL
  tee       Copy output to a URL
```

The table below describes significant fields shown in the previous displays.

Table 7: show voice call Field Descriptions

Field (listed alphabetically)	Description
Called #	Called number. <ul style="list-style-type: none"> No "*" before the number denotes an originating call leg. Two of the call legs in the example constitute one locally switched call and one network call, so the call legs refer to two active calls. A "*" before the number denotes a destination call leg (for example, this number was called with Called #).
CallID	This hexadecimal number used for further query is the monotonically increasing number that call control maintains for each call leg (ccCallID_t).
ccVdb	Value that is displayed in many other debugs to identify these call legs.
CID	Conglomerate value derived from the GUID that appears in the show call active brief command.
Codec	Codec.
Dial-peers	Dial peer .
DSP/Ch	DSP and channel allocated to this call leg. The format of these values is platform dependent (particularly the Cisco AS5300, which shows the DSP number as a 3-digit number, <VFC#><DSPM#><DSP#>). Time-slot information is also in the output for digital ports. For example, if you are using a digital port, the time slot is also returned: dsp/ch/ time slot .
ERL	Echo return loss (in dB).

Field (listed alphabetically)	Description
ERL/Refletr	Time difference, in ms, between the original signal and the loudest echo (peak reflector) as detected by the echo canceller.
Jitter	Current values of the delay and the jitter of the packets around that delay.
Port	V oice port.
Rx/Tx	Transmit and receive rates for the connection.
VAD	Voice-activity detection: y or n.
VPM STATE	Voice-port-module (VPM) state.
VTSP STATE	Voice-telephony-service-provider (VTSP) state.

For more information about the extended echo canceller, see *Extended ITU-T G.168 Echo Cancellation*.

Related Commands

Command	Description
show call active brief	Displays a summary of active call information.
show dial-peer voice	Displays the configuration for all VoIP and POTS dial peers configured on the router.
show voice dsmp stream	Displays the current session of the voice DSPM media stream.
show voice dsp	Displays the current status of all DSP voice channels.
show voice port	Displays configuration information about a specific voice port.
test call id	Manipulates the echo canceller and jitter buffer parameters in real time.

show voice call rate



Note With CSCuc53349, the **show voice call rate** command is replaced by the **show call history stats cps** command. See the **show call history stats cps** command for more information.

To display the voice call rate information, use the **show voice call rate** command in privileged EXEC mode.

show voice call rate [table]

Syntax Description

table	(Optional) Displays the voice call rate information in a tabular format.
--------------	--

Command Default

Displays the voice call rate information in a histogram format.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
15.2(2)T	This command was introduced.
15.3(2)T	This command was replaced by the show call history stats cps command.
Cisco IOS XE Release 3.9S	This command was replaced by the show call history stats cps command.

Usage Guidelines

You can use the **show voice call rate** command to display the voice call rate information in the histogram format. Use the **show voice call rate table** command to display the voice call rate information in a tabular format.

Examples

The following is sample output from the **show voice call rate** command. In the output, x-axis measures time in seconds (1 unit = 1 second) and y-axis measures call legs per second (cps) (1 unit = 1 cps):

```
Router# show voice call rate

3845-1  04:35:57 AM Wednesday Sep 7 2011 UTC
      122                11
      5009              2    40    42    64

100
 90
 80
 70
 60
 50
 40
 30
 20  ***
 10  ****                **                *
      0...5...1...1...2...2...3...3...4...4...5...5...6
      0    5    0    5    0    5    0    5    0    5    0
```

VoIP Call switching rate per second (last 60 seconds)
= calls entering the module per second

The following is sample output from the **show voice call rate table** command:

```
Router# show voice call rate table

3845-1 04:35:57 AM Wednesday Sep 7 2011 UTC
        Voice Call switching rate per second (last 60 seconds)
-----
Period      Actual      Average
-----
1-5         0           0
6-10        64          13
11-15       0           0
16-20       0           0
21-25       2           0
26-30       0           0
31-35       24          5
36-40       0           0
41-45       6           1
46-50       10          2
51-55       0           0
56-60       0           0
```

The following table describes the significant fields shown in the display.

Table 8: show voice call rate table Field Descriptions

Field	Description
Period	Duration of 5 seconds.
Actual	Number of call legs created in 5 seconds.
Average	The average call legs created in 5 seconds.

Related Commands

Command	Description
voice call rate monitoring	Enables voice call rate monitoring.

show voice cause-code

To display error category to Q.850 cause code mapping, use the show voice cause-code command in user EXEC mode.

show voice cause-code category-q850

Syntax Description

category q850	Displays error category to Q.850 cause code mapping.
----------------------	--

Command Default

No default behavior or values.

Command Modes

User EXEC (>)

Command History

Release	Modification
12.3(4)T	This command was introduced.

Usage Guidelines

Use this command to display the internal error category to Q.850 cause code mapping table, and configured and default values, with category descriptions.

Examples

The following example displays Q.850 cause code mapping:

```
Router# show voice cause-code category-q850
The Internal Error Category to Q850 cause code mapping table:-
  Error Configured Default   Description
Category Q850      Q850
  128      27         3  Destination address resolution failure
  129      38        102 Call setup timeout
  178      41         41  Internal Communication Error
  179      41         41  External communication Error
  180      47         47  Software Error
  181      47         47  Software Resources Unavailable
  182      47         47  Hardware Resources Unavailable
  183      41         41  Capability Exchange Failure
  184      49         49  QoS Error
  185      41         41  RTP/RTCP receive timer expired or bearer layer failure
  186      38         38  Signaling socket failure
  187      38         38  Gateway or signaling interface taken out of service
  228      50         50  User is denied access to this service
  278      65         65  Media Negotiation Failure due to non-existing Codec
```

The table below describes the significant fields shown in the display.

Table 9: show voice cause-code Field Descriptions

Field	Description
128	Destination address resolution failure
129	Call setup timeout

Field	Description
178	Internal communication error
179	External communication Error
180	Software error
181	Software resources unavailable
182	Hardware resources unavailable
183	Capability exchange failure
184	QoS error
185	RTP/RTCP receive timer expired or bearer layer failure
186	Signaling socket failure
187	Gateway or signaling interface taken out of service
228	User denied access to this service
278	Media negotiation failure due to non existing codec

Related Commands

Command	Description
error-category q850-cause	Specifies Q.850 cause code mapping

show voice class called-number

To display a specific voice class called-number, use the **show voice class called-number** command in privileged EXEC mode.

show voice class called-number [**inbound** | **outbound**] *tag*

Syntax Description	Parameter	Description
	inbound	Displays the specified inbound voice class called-number.
	outbound	Displays the specified outbound voice class called-number.
	<i>tag</i>	Digits that identify this voice class called-number.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(11)T	This command was introduced.

Usage Guidelines

Use this command to display a specific inbound or outbound voice class called-number.

Examples

The following is sample output from this command:

```
Router# show voice class called-number outbound 200
Called Number Outbound: 200
   index 1      4085550100
   index 2      4085550102
   index 3      4085550103
   index 4      4085550104
```

The table below describes significant fields shown in the display.

Table 10: show voice class called-number Field Descriptions

Field	Description
Called Number Inbound/Outbound	The tag for the specified inbound or outbound voice class called-number.
index <i>number</i>	The number or range of numbers for this voice class called number.

Related Commands

Command	Description
show voice class called-number-pool	Displays voice class called number pool configuration information.

show voice class called-number-pool

To display a voice class called-number pool, use the **show voice class called-number-pool** command in privileged EXEC mode.

show voice class called-number-pool tag [detail]

Syntax Description	tag	Digits that identify this voice class called-number-pool. Range is 1 to 10000.
	detail	Displays idle called number and allocated called number information.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.4(11)T	This command was introduced.

Usage Guidelines

Use this command to display the voice class called number pool configuration information. The **detail** keyword displays up to 16 idle called numbers, and up to 4 allocated called numbers for each allocated request.

Examples

The following sample output displays configuration information for voice class called-number-pool 100, including idle called numbers and allocated called numbers:

```
Router(config)# show voice class called-number-pool 100 detail
Called Number Pool: 100
index 1 100A11 - 100A20
index 2 200#55 - 200#77
index 3 5551111 - 6662333
index 99 123C11 - 123C99
All called numbers are generated from table: FALSE
No of idle called numbers: 16
List of idle called numbers:
100A11 100A12 .. Display up to 16 idle called number from the pool
100A13 100A14
100A15 100A16
100A17 100A18
100A19 100A20
200#55 200#56
200#57 200#58
200#59 200#60
No of alloc requests : 1
Ref Id Alloc PC Size
2 41F84190 16
List of alloc called numbers: .. Display the first 4 allocated called number for RefId 2
200#61 200#62
200#63 200#64
```

The table below describes significant fields shown in the display.

Table 11: show voice class called-number-pool Field Descriptions

Field	Description
Called Number Pool	Tag that identifies the called number pool.
index	Number or range of numbers for this called number pool.
All called numbers are generated from table	<ul style="list-style-type: none"> • FALSE--Numbers are not generated from called number table. • TRUE--Numbers are generated from called number table.
No. of idle called numbers	Number of idle called numbers in the called number pool.
List of idle called numbers	List of idle numbers in the called number pool.
No. of alloc requests	Number of requests for numbers from the called number pool.
Ref Id Alloc PC Size	Reference ID for a specific list of allocated numbers.
List of alloc called numbers	List of first four allocated numbers from the called number pool.

Related Commands

Command	Description
show voice class called-number	Displays a specific voice class called-number.

show voice class e164-pattern-map

To display the configuration of a voice class E.164 pattern map, use the **show voice class e164-pattern-map** command in user EXEC or privileged EXEC mode.

```
show voice class e164-pattern-map [summarytag]
```

Syntax Description

summary	(Optional) Displays the summary information of the configuration.
<i>tag</i>	(Optional) Displays the status and content of E.164 pattern maps.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
15.2(4)M	This command was introduced.

Usage Guidelines

You can use the **show voice class e164-pattern-map** command to display the status of a map and all E.164 patterns in the map. This command is used not only to display E.164 patterns in a text file, but E.164 patterns configured through the CLI. But for parsing error, the command applies only to a text file.

Examples

The following is sample output from the **show voice class e164-pattern map** command:

```
Device# show voice class e164-pattern-map summary

e164-pattern-map 1
-----
It has 100 entries
It is populated from url http://http-host/config-files/destination-pattern-map.cfg

e164-pattern-map 2
-----
It has 23 entries

e164-pattern-map 3
-----
Loading failed on url http://http-host/config-files/destination-pattern-map-1.cfg

e164-pattern-map 4
-----
Parsing error on patterns: "123gh" "1*g"
It is populated from url http://http-host/config-files/destination-pattern-map-2.cfg
```

Related Commands

Command	Description
destination e164-pattern-map	Links a destination E.164 pattern map to a dial peer.
url	Specifies the URL of a text file that has E.164 patterns configured on an E.164 pattern map.

show voice class e164-translation

To display the configuration of a voice class E.164 translation table, use the **show voice class e164-translation** command in privileged EXEC mode.

show voice class e164-translation tag

Syntax Description

<i>tag</i>	Displays the status and content of the voice class E.164 translation table. The range is from 1 to 10000.
------------	---

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
IOS XE Fuji Release 16.8.1	This command was introduced.

Examples

The following example displays the E.164 translation table. The incoming call numbers +41993000000 and +41993000001 are translated, and replaced by +418893000000 and +418893000001 respectively.

```
Router#show voice class e164-translation
Voice class e164-translation: 1          AdminStat: Up
Description:
URL: ftp://test:test123@8.0.0.200/test_e164.cfg
   (Loaded:TRUE Valid: TRUE)

Duplicate error count:    0
Syntax error count:      0
Error count:             0

Total Translation Rules: 2

Rule#  Match Call Number                Replace Call Number
-----  -----
1      +41993000000                          +418893000000
2      +41993000001                          +418893000001

Total Rules from Internal Sorted list: 2

Match Reverse Call Number                Match Call Number
-----  -----
00000039914+                            +41993000000
10000039914+                            +41993000001

Lookup Array Setup:

Offset  Match Reverse Number                Match Call Number
-----  -----
12      00000039914+                        +41993000000
```

Related Commands

Command	Description
show voice class e164-pattern-map	Displays status of a map and all E.164 patterns in the map.

show voice class phone-proxy

To display the details of the sessions and file buffer function being conducted through the all the phone proxies, use the **show voice class phone-proxy** command in privileged EXEC mode.

show voice class phone-proxy [**file-buffer** [**detail**] | **sessions**]

Syntax Description	file-buffer	(Optional) Shows the summary of phone proxy file buffer function working status.
	detail	(Optional) Shows the details of phone proxy file buffer.
	sessions	(Optional) Shows the phone proxy instance mapping status between phone and dial peer signal-address and protocol status.
Command Modes	Privileged EXEC mode	
Command History	Release	Modification
	15.3(3)M	This command was introduced.
	IOS XE Fuji Release 16.8.1	This command was modified. The command was enhanced to display phone proxy file buffer details.

Example

The following example shows sample output from the **show voice class phone-proxy** command:

```
Device# show voice class phone-proxy

Phone-Proxy 'mypp':
  Description: mycluster
    Access Secure: secure
    Tftp-client address: 198.51.100.2
    Tftp-server address: 198.51.100.101
    Capf server address: 198.51.100.101
    CUCM service settings: preserve(default)
    Ctl file name: myctl
    Session-timeout: 180 seconds
    Max-concurrent-sessions: 300
    Current sessions: 10
    Configuration status: complete
    Dialpeers associated:
      Name                               State
      -----
      dialpeer1                           inactive
      dialpeer2                           active
      dialpeer3                           active
Phone-Proxy 'test':
  Description: test-cluster
    Access secure: nonsecure (default)
    Tftp-client address: 10.0.0.2
    Tftp-server address: 10.0.0.1
    Local capf server address: 104.0.0.3
    CUCM service settings: disable
    Ctl file name: ctl_test
```

show voice class phone-proxy

```

Session-timeout: 180 seconds
Max-concurrent-sessions: 300
Current sessions: 20
Configuration status: not complete
Dialpeers associated:
  Name                               State
  -----
dialpeer 4                           inactive
dialpeer 5                           inactive

```

The following shows details of the sessions being conducted through the phone proxy:

```
Device# show voice class phone-proxy sessions
```

```
Phone-Proxy 'mypp':
```

```

      srcaddr:port          dstaddr:port      vrf
      -----
-----Sessions of Dialpeer dialpeer1-----
|Access: 10.0.100.11:2000   10.0.100.15:69   test1   |
|Core  : 192.168.0.2:10002 192.169.0.101:69 global   |
-----
|Access: 10.0.100.35:2004   10.0.100.15:69   test1   |
|Core  : 192.168.0.2:10008 192.169.0.101:69 global   |
-----
|Access: 10.0.100.21:4000   10.0.100.15:69   test1   |
|Core  :                               |
-----

```

```
Phone-Proxy 'test':
```

```

      srcaddr:port          dstaddr:port      vrf
      -----
-----Sessions of Dialpeer dialpeer1-----
|Access: 10.2.100.9:2000    10.2.100.15:69   test1   |
|Core  : 20.21.21.101:10002 20.21.21.2:69    global   |
-----
|Access: 10.2.100.21:4000   10.2.100.15:69   test1   |
|Core  :                               |
-----

```

show voice class resource-group

To display the resource group configuration information for a specific resource group or all resource groups, use the **show voice class resource-group** command in privileged EXEC mode.

```
show voice class resource-group {tag | all}
```

Syntax Description

<i>tag</i>	Unique tag for the resource group.
all	Displays information for all voice resource groups.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
15.1(2)T	This command was introduced.

Usage Guidelines

You can use the **show voice class resource-group** command to display the parameters configured to monitor resources.

Examples

The following is sample output from the **show voice class resource-group** command:

```
Router> enable
Router# show voice class resource-group 2
Resource Availability Indicator status
Resource Index 2
Resource Type:SYSTEM
      Status: Low threshold
Resource Type: MEM Subtype: io-mem Low/High watermark: 2/5
      Status: Low threshold
Report Interval 34
-----
```

The table below describes the significant fields shown in the display.

Table 12: show voice class resource-group Field Descriptions

Field	Description
Resource Index	Unique index value to identify the resource group.
Resource Type	Type of the resource being monitored.
Status	Status of the resource.
Subtype	Subtype of the resource being monitored.
Report Interval	Periodic reporting interval for the resource being monitored. The status of the resource being monitored is reported based on the preconfigured timer value.

Related Commands

Command	Description
debug rai	Enables debugging for Resource Allocation Indication (RAI).
rai target	Configures the SIP RAI mechanism.
resource (voice)	Configures parameters for monitoring resources, use the resource command in voice-class configuration mode.
periodic-report interval	Configures periodic reporting parameters for gateway resource entities.
voice class resource-group	Enters voice-class configuration mode and assigns an identification tag number for a resource group.

show voice class server-group

To display the configurations for all configured server groups or a specified server group, use the **show voice class server-group** command in privileged EXEC mode.

show voice class server-group [*server-group-id* | **dialpeer** *dialpeer-tag*]

<i>server-group-id</i>	Unique server group ID to identify the server group.
dialpeer <i>dialpeer-tag</i>	Unique number of a dialpeer that is associated with a server group.

Command Modes
User EXEC (>)
Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Release 3.11S 15.4(1)T	The following commands were introduced or modified: voice class server-group , description , ipv4 port preference , ipv6 port preference , hunt-scheme , show voice class server-group , shutdown (Server Group) .
	Cisco IOS XE Bengaluru 17.4.1a	The following command is introduced under voice class server-group . huntstop rule-tag resp-code from_resp_code to to_resp_code .

Usage Guidelines
You can use the **show voice class server-group** command to display the configurations for all configured server groups or a specified server group.

The following is sample output from the **show voice class server-group** command:

```
Router> enable
Router# show voice class server-group 1
  AdminStatus: Up           OperStatus: Up
  Hunt-Scheme: preference   Last returned server:
  Description: server-group for huntstop feature testing
  Total Huntstop tags: 1
  Tag ID From Response code      To Response code
  -----
  1      404                      404
  2      410                      599
  -----
  Total server entries: 3
  Pref    Type    IP Address      IP Port
  -----
  1       ipv4    10.1.1.1
  2       ipv4    10.1.1.2      34515
  3       ipv4    10.1.1.3
```

The table below describes the significant fields shown in the display.

Table 13: show voice class server-group Field Descriptions

Field	Description
description	Description of the server group.

Field	Description
ipv4 port preference	A server IPv4 address as a part of this server group along with an optional port number and preference order.
ipv6 port preference	A server IPv6 address as a part of this server group along with an optional port number and preference order.
hunt-scheme	A hunt method for the order of selection of target server IP addresses (from the IP addresses configured for this server group) for the setting up of outgoing calls.
hunt-stop	Stops hunting based on (configurable) response codes in the Server Group along with dial-peer.

Related Commands

Command	Description
voice class server-group	Enters voice-class configuration mode and configures server groups (groups of IPv4 and IPv6 addresses), description, hunt-scheme, huntstop, and shutdown (Server Group).

show voice class sip-options-keepalive

To display the details of connectivity between CUBE VoIP dial peers and SIP servers, use **show voice class sip-options-keepalive** command in privileged EXEC mode.

show voice class sip-options-keepalive [**global** | *profile-tag*]

global	Displays information on voice class sip-options-keepalive global.
<i>profile-tag</i>	The unique tag for SIP options keepalive profile. Range: 1–10000.

Command Modes User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
IOS XE Fuji Release 16.8.1	This command was introduced.

Usage Guidelines

Use **show voice class sip-options-keepalive global** command to view the global and the instant status information of the out-of-dialog (OOD) ping mechanism that is configured between the dial peers and SIP servers.

Examples

The following sample output displays the details of the server group and the OOD Keepalive Profiles defined on the server group.

```
Router# show voice class sip-options-keepalive global
Server Group: 1
  List of OOD Keepalive Profile(s):
    171
-----
```

Related Commands

voice-class sip options-keepalive	Monitors connectivity between CUBE VoIP dial-peers and SIP servers. This command also configures OOD ping mechanism between any number of destinations.
--	---

show voice class sip-predefined-profiles

To display the SIP profiles defined on a CUBE router, use **show voice class sip-predefined-profiles** command in privileged EXEC mode.

show voice class sip-predefined-profiles

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC (#)

Release	Modification
IOS XE Fuji Release 16.8.1	This command was introduced.

Usage Guidelines The SIP profiles enable SIP messaging between incompatible devices on the network. Use this command to display the SIP profiles defined on all CUBE routers in a network.

Examples The following sample output displays detailed information about all predefined SIP profiles:

```
Router# show voice class sip-predefined-profiles
voice class sip-hdr-passthruelist 20001
passthru-hdr Call-Info
passthru-hdr Content-ID
passthru-hdr Allow-Events
passthru-hdr Supported
passthru-hdr Remote-Party-I
passthru-hdr Require
passthru-hdr Referred-By

voice class sip-profiles 20001
  request INVITE sip-header Cisco-Guid remove
```

show voice class uri

To display summary or detailed information about configured uniform resource identifier (URI) voice classes, use the **show voice class uri** command in user EXEC or privileged EXEC mode.

show voice class uri [*tag* | **summary**]

Syntax Description	<i>tag</i>	(Optional) Specific URI voice class for which to display detailed information.
	summary	(Optional) Displays a short summary of all URI voice classes.

Command Default Detailed information about the configured URI voice classes is displayed.

Command Modes
User EXEC (>)
Privileged EXEC (#)

Command History	Release	Modification
	12.3(4)T	This command was introduced.
	15.1(2)T	This command was modified. The command was enhanced to display the mutiple hosts in the configured URI classes.

Usage Guidelines If both the *tag* argument and **summary** keyword are omitted, the output displays detailed information about all URI voice classes.

Examples The following is sample output from this command:

```
Router# show voice class uri
Voice URI class: 100
  SNMP status = Active
  Schema = sip
  pattern = 12345
Voice URI class: 101
  SNMP status = Active
  Schema = sip
  pattern = 555....
Voice URI class: 102
  SNMP status = Active
  Schema = sip
  user-id = demo
  host = cisco
  phone context =
Voice URI class: 103
  SNMP status = Active
  Schema = tel
  phone number = 555....
  phone context =
Voice URI class: 700
  SNMP status = Active
  Schema = sip
  pattern = elmo@sip.tgw.com*
```

```

Voice URI class: 104
  SNMP status = Active
  Schema = tel
  pattern = 5550134
Voice URI class: 700
  SNMP status = Active
  Schema = sip
  user-id =
  host = exmp.example.com
  phone context =

host instances:
  ipv4:192.168.0.1
  ipv6:[2001:0DB8:0:1:FFFF:1234::5]
  dns:ogw.example.com

```

The following is sample output from this command with the **summary** keyword:

```
Router# show voice class uri summary
```

Class Name	Schema	SNMP
100	sip	Active
101	sip	Active
102	sip	Active
103	tel	Active
700	sip	Active
104	tel	Active

The table below describes the significant fields in the displays.

Table 14: show voice class uri Field Descriptions

Field	Description
Class Name	Tag that identifies the URI voice class.
Schema	Whether the voice class is used for SIP or TEL URIs.
pattern	Pattern used to match the entire SIP or TEL URI as configured with the pattern command.
user-id	Pattern used to match the user-id field in the SIP URI as configured with the user-id command.
host	Pattern used to match the host field in the SIP URI with the host command.
phone number	Pattern used to match the phone number field in a TEL URI as configured with the phone number command.
phone context	Pattern used to match the phone context field in a SIP or TEL URI as configured with the phone context command.

Related Commands

Command	Description
debug voice uri	Displays debugging messages related to URI voice classes.
show dialplan incall uri	Displays which dial peer is matched for a specific URI in an incoming call.

Command	Description
show dialplan uri	Displays which outbound dial peer is matched for a specific destination URI.
voice class uri	Creates or modifies a voice class for matching dial peers to calls containing a SIP or TEL URI.

show voice connectivity summary

To display the results of the last connectivity checks performed on all analog Foreign Exchange Station (FXS) ports on a router, use the **show voice connectivity summary** command in privileged EXEC mode.

show voice connectivity summary

Syntax Description

This command has no arguments or keywords.

Command Default

A summary of the last connectivity checks performed on all analog FXS ports on a router is displayed.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
15.1(3)T	This command was introduced.

Examples

The following example shows how the **show voice connectivity summary** command is used:

```
Router> enable
Router# show voice connectivity summary
.
.
.
! The summary results include information such as the port address, type of connectivity
! check performed, result of connectivity check for each port
```

show voice data

To display the call control application programming interface (CCAPI) and Telephony Service Provider (VTSP) data structures, use the **show voice data** command in user EXEC or privileged EXEC mode.

```
show voice data {ccapi {ccCallEntry {call-id | all} | ccCallInfo} | vtsp {ccCallInfo | vtsp_cdb
{call-id | all}} | vtsp_sdb {call-id | all}}
```

Syntax Description		
ccapi	Displays all the CCAPI calls.	
ccCallEntry	Displays the call entry.	
<i>call-id</i>	Call identifier (ID) in the range 1 to 4294967295.	
all	Displays all the call entries.	
ccCallInfo	Displays the call information.	
vtsp	Displays all the VTSP calls.	
vtsp_cdb	Displays all the VTSP call control back calls.	
vtsp_sdb	Displays all the VTSP signalling data block calls.	

Command Modes

User EXEC (>)
Privileged EXEC (#)

Command History

Release	Modification
12.4(22)T	This command was introduced in a release earlier than Cisco IOS Release 12.4(22)T.

Examples

The following is sample output from the **show voice data** command:

```
Router# show voice data ccapi ccCallEntry all
CallEntry=0x6B8051B0; CallID=7(0x7)::
element:{ 0x6B8051B0; 0x6B8051B4; 0x6B8051B8; } 7; <appReturnStack>; 1735408; 1; 0x6B8051D8;
7; 8; callInfo:{ 0; 112233; <NULL>; 889988; <NULL>; <NULL>; <NULL>; <NULL>; <NULL>;
<NULL>; FALSE; FALSE; TRUE; <NULL>; 0; 0; 0; <NULL>; RegularLine; Unknown;
D356CC33-E54B-11D7-8005-00169D6EE1AE; D356CC33-E54B-11D7-8005-00169D6EE1AE; 0; 0; 0; 0;
998877; 0x6B80547C; 0; TRUE; FALSE; 0.0.0.0; 0.0.0.0; 0x6B8054A0; 0x6B8054A4; 0x6B8054A8;
0x6B8054AC; 0; FALSE; FALSE; 0x6B8054BC; 0; call_decode:{ redirect_info:{ 0xFF; 0xFF; 0xFF;
0xFF; 0xFF; 0xFF; 0x00; 0xFF; 255; <NULL>; <NULL>; 0x00; FALSE; FALSE; } 0x00; 0x80; 0x00;
0x80; 0; 0x00; <NULL>; 0; 0x00; <NULL>; FALSE; FALSE; FALSE; FALSE; -1; <NULL>; TRUE;
<transfer_info>; FALSE; 129; 40; 104; 0xFF; TRUE; } FALSE;
D357685B-E54B-11D7-8016-CB962D72A90A; 0; 0; 0; 0; 0; 0x6B805634; FALSE; <NULL>; FALSE;
FALSE; FALSE; 0; 0; 0; <NULL>; ISDN 7/0:1:D; FALSE; FALSE; FALSE; 0x00; <NULL>; <NULL>;
0x6B80585C; 0; 0x6B805864; } 0x6B805914; 0x6B805918; 0x6B80591C; 0x6B805920; <altAssocList>;
FALSE; 0x6B80593C; 0x6B805940; 0x6B805944; FALSE; 0; 65535; TRUE; 0; FALSE; 1;
<disconnect_timer>; <inter_digit_timer>; 10000; <initial_timer_timestamp>; 10000; FALSE;
0; 0; -1; <NULL>; 0x6B8059F8; <evCategoryMask>; <evDetailMask>; 4294967295; 0x6B805C48;
FALSE; 0; 0; TRUE; TRUE; TRUE; 0; 0; 0x6B805C6C; FALSE; 0; 4; 0; -1; FALSE;
CallEntry=0x6B805C90; CallID=8(0x8)::
```

```

element:{ 0x6B805C90; 0x6B805C94; 0x6B805C98; } 8; <appReturnStack>; 1735408; 2; 0x6B805CB8;
8; 7; callInfo:{ 0; 112233; <NULL>; 889988; <NULL>; 112233; 112233; <NULL>; <NULL>; <NULL>;
<NULL>; FALSE; FALSE; TRUE; <NULL>; 0; 0; 0; <NULL>; RegularLine; Unknown;
D356CC33-E54B-11D7-8005-00169D6EE1AE; D356CC33-E54B-11D7-8005-00169D6EE1AE; 7; 0; 0; 0; 2;
112233; 0x6B805F5C; 0; FALSE; FALSE; 0.0.0.0; 0.0.0.0; 0x6B805F80; 0x6B805F84; 0x6B805F88;
0x6B805F8C; 0; FALSE; FALSE; 0x6B805F9C; 0; call_decode:{ redirect_info:{ 0xFF; 0xFF; 0xFF;
0xFF; 0xFF; 0xFF; 0x00; 0xFF; 255; <NULL>; <NULL>; 0x00; FALSE; FALSE; } 0x00; 0x80; 0x00;
0x00; 0; 0x00; <NULL>; 0; 0x00; <NULL>; FALSE; FALSE; FALSE; FALSE; -1; <NULL>; TRUE;
<transfer_info>; FALSE; 129; 40; 104; 0xFF; TRUE; } FALSE;
D357685B-E54B-11D7-8016-CB962D72A90A; 0; 0; -1; 0; 0; 0; 0x6B806114; FALSE; <NULL>; FALSE;
FALSE; FALSE; 0; 0; 0; <NULL>; ISDN 7/0:1:D; TRUE; FALSE; FALSE; 0x00; <NULL>; <NULL>;
0x6B80633C; 0; 0x6B806344; } 0x6B8063F4; 0x6B8063F8; 0x6B8063FC; 0x6B806400; <altAssocList>;
FALSE; 0x6B80641C; 0x6B806420; 0x6B806424; FALSE; 0; 65535; FALSE; 0; FALSE; 1;
<disconnect_timer>; <inter_digit_timer>; 10000; <initial_timer_timestamp>; 10000; FALSE;
0; 0; -1; <NULL>; 0x6B8064D8; <evCategoryMask>; <evDetailMask>; 4294967295; 0x6B806728;
FALSE; 0; 0; TRUE; TRUE; TRUE; 0; 0; 0x6B80674C; FALSE; 0; 4; 0; -1; FALSE;

```

The table below describes the significant fields shown in the display.

Table 15: show voice data Field Descriptions

Field	Description
CallEntry	Displays the call entry identification number used for the incoming call leg.
CallID	Displays the specified call identifier value.
element	Indicates the various configuration values for the service element.
callInfo	Displays the call informaton.
call_decode	Displays the status of the audio decoder.
redirect_info	Displays the forwarding request information when a call is being forwarded.
transfer_info	Displays the call transfer request information.
disconnect_timer	Displays the timeout value, in seconds, specified to disconnect the call.
inter_digit_timer	Displays the maximum allowable time, in seconds, between digits dialed by the user.

Related Commands

Command	Description
debug voip ccapi error	Traces error logs in the call control API.

show voice dnis-map

To display current dialed-number identification service (DNIS) map information, use the `show voice dnis-map` command in privileged EXEC mode.

show voice dnis-map [*dnis-map-name* | **summary**]

Syntax Description

<i>dnis -map-name</i>	(Optional) Name of a specific DNIS map.
summary	(Optional) Displays a short summary of each DNIS map.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.2(2)XB	This command was introduced on the Cisco AS5300, Cisco AS5350, and Cisco AS5400.
12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and implemented on the Cisco 3640 and Cisco 3660.

Usage Guidelines

This command displays a detailed description of each configured DNIS map.

If the name of a specific DNIS map is entered, the command displays detailed information about only that DNIS map.

If the **summary** keyword is used, the command displays a one-line summary about each DNIS map.

If an asterisk is displayed next to a DNIS map name when the **summary** keyword is used, it means that the DNIS map is configured, but not running. Normally this is because the external text file was not successfully loaded, for example:

```
dnis-map          Entries      URL
-----          -
dmap1             1
*dmap4            0             http://dnismaps/dnismap4.txt
```

To create a DNIS map, use the **voice dnis-map** command. You can link to an external DNIS map text file or use the **dnis** command to add numbers to a DNIS map in Cisco IOS software.

To associate a DNIS map with a dial peer, use the **dnis-map** command.

Examples

The following is sample output from the `show voice dnis-map` command:

```
Router# show voice dnis-map
There are 2 dnis-maps configured
Dnis-map dmap1
-----
  It has 3 entries
  It is not populated from a file.
DNIS          URL
----          -
4085551212    tftp://global/tickets/movies.vxml
```

show voice dnis-map

```

4085551234          tftp://global/tickets/plays.vxml
4085554321          tftp://global/tickets/games.vxml
Dnis-map dmap4
-----
  It has 0 entries
  It is populated from url http://dnismaps/dnismap4.txt
DNIS                URL
----                ---

```

The table below describes the fields shown in this output.

Table 16: show voice dnis-map Field Descriptions

Field	Description
Dnis-map	Name of a DNIS map that is configured on the gateway.
DNIS	Destination telephone number specified in this DNIS map.
URL	Location of the VoiceXML document to invoke for this DNIS number.

The following is sample output from the show voice dnis-map **summary** command:

```

Router# show voice dnis-map summary
There are 3 dnis-maps configured
dnis-map          Entries      URL
-----          -
dmap1              3
dmap4              0          http://dnismaps/dnismap4.txt
dmap6              8

```

describes the fields shown in this output.

Table 17: show voice dnis-map summary Field Descriptions

Field	Description
dnis-map	Names of the DNIS maps that are configured on the gateway.
Entries	Number of entries in DNIS maps that reside on the gateway. This field displays 0 if the DNIS map is a text file stored on an external server.
URL	Location of externally stored DNIS maps.

Related Commands

Command	Description
dnis	Adds a DNIS number to a DNIS map.
dnis -map	Associates a DNIS map to a dial peer.
voice dnis -map	Enters DNIS map configuration mode to create a DNIS map.
voice dnis -map load	Reloads a DNIS map that has changed since the previous load.

show voice dsmp stream

To display the current session of voice Distributed Stream Media Processor (DSMP) media stream, the recent state transitions, and stream connection, use the **show voice dsmp stream** command in privileged EXEC mode.

```
show voice dsmp stream {stream ID | leg}
```

Syntax Description

<i>stream ID</i>	DSMP media stream identifier. Range: 1 to 4294967295.
leg	Call leg corresponding to a caller ID.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.3(14)T	This command was introduced.

Usage Guidelines

When the calls hang, use this command to get the current sessions of the DSMP media stream. You can look at the DSMP state transitions corresponding to the calls and find out the problems.

Examples

The following example shows an output of a typical DSMP session in a VoIP call. This call consists of four streams, two input streams and two output streams:

```
Router# show voice dsmp stream
Total number of streams in use is: 4

Stream information:: stream=1
Type: TDM, Direction: OUTPUT
Fax/Modem Type: voice
Xmit Function: 0x00000000
Xmit function is Enabled
Call ID: 4, Conference ID: -1

Session information:: session=0x658CA948 dsp_intf=0x642DDD8C dsp_name=1/9:3

connections=2 streams=4 (5 1 4 3 )
current state S_DSMP_VC_RUNNING current container simple_voice_container
State Transitions: timestamp (container, state) -- event -> (container, state)
367121.596 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367121.796 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367122.712 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367122.732 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367122.920 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367122.940 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367123.112 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
```

show voice dsmp stream

```

-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367123.152 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367124.432 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367124.632 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367124.732 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367124.932 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367125.032 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367125.232 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367126.140 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367126.160 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367126.340 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367126.380 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367126.548 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367126.568 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)

```

Session log information::

Regular Timer:

Timer start operations:

Timestamp	Duration(ms)	Caller
367122.652	4000	0x6113397C
367119.388	4000	0x6113397C
367117.624	10000	0x6112ED88

Timer stop operations:

Timestamp	Duration(ms)	Caller
367122.656	0	0x61133A98
367119.392	0	0x61133A98
367117.624	0	0x6112F060
367117.624	0	0x6112EE24

Number of overwritten entries: 2

Periodic Timer:

Timer start operations:

None

Timer stop operations:

None

Packet suppression is disabled

Stream information:: stream=3

Type: PACKET, Direction: OUTPUT

Fax/Modem Type: voice

Xmit Function: 0x6111D324

Xmit function is Enabled

Call ID: 3, Conference ID: 2

DSP Encap: 0x1

Codec Mask: 0x4; Codec Bytes: 20

Fax Rate Mask: 0x2; Fax Bytes: 20; T38 Disabled

VAD Mask: 0x2

Session information:: session=0x658CA948 dsp_intf=0x642DDD8C dsp_name=1/9:3

```

connections=2 streams=4 (5 1 4 3 )
current state S_DSMP_VC_RUNNING current container simple_voice_container
State Transitions: timestamp (container, state) -- event -> (container, state)
367128.452 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367128.652 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367129.556 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367129.588 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367129.756 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367129.796 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367129.968 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367129.988 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367131.276 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367131.472 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367131.572 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367131.772 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367131.872 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367132.072 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367132.980 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367133.000 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367133.180 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367133.220 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367133.400 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367133.420 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)

```

Session log information::

Regular Timer:

Timer start operations:

Timestamp	Duration(ms)	Caller
367131.020	4000	0x6113397C
367128.316	4000	0x6113397C
367122.652	4000	0x6113397C
367119.388	4000	0x6113397C

Number of overwritten entries: 1

Timer stop operations:

Timestamp	Duration(ms)	Caller
367131.024	0	0x61133A98
367128.320	0	0x61133A98
367122.656	0	0x61133A98
367119.392	0	0x61133A98

Number of overwritten entries: 4

Periodic Timer:

Timer start operations:

show voice dsmp stream

```

None
Timer stop operations:
None
Packet suppression is disabled

Stream information:: stream=4
Type: PACKET, Direction: INPUT
Fax/Modem Type: voice
Xmit Function: 0x61F2CA34
Xmit function is Enabled
Call ID: 3, Conference ID: 2
DSP Encap: 0x1
Codec Mask: 0x4; Codec Bytes: 20
Fax Rate Mask: 0x2; Fax Bytes: 20; T38 Disabled
VAD Mask: 0x2

Session information:: session=0x658CA948 dsp_intf=0x642DDD8C dsp_name=1/9:3

connections=2 streams=4 (5 1 4 3 )
current state S_DSMP_VC_RUNNING current container simple_voice_container
State Transitions: timestamp (container, state) -- event -> (container, state)
367133.400 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367133.420 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367134.692 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367134.892 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367134.992 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367135.192 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367135.292 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367135.492 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367136.400 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367136.432 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367136.600 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367136.640 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367136.812 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367136.840 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367138.112 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367138.312 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367138.412 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367138.612 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367138.712 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367138.912 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)

Session log information::
Regular Timer:

```

```

Timer start operations:
  Timestamp      Duration(ms)      Caller
  367137.648     4000              0x6113397C
  367134.440     4000              0x6113397C
  367131.020     4000              0x6113397C
  367128.316     4000              0x6113397C

```

Number of overwritten entries: 3

```

Timer stop operations:
  Timestamp      Duration(ms)      Caller
  367137.648     0                 0x61133A98
  367134.440     0                 0x61133A98
  367131.024     0                 0x61133A98
  367128.320     0                 0x61133A98

```

Number of overwritten entries: 6

```

Periodic Timer:
  Timer start operations:
  None
  Timer stop operations:
  None
Packet suppression is disabled

```

```

Stream information:: stream=5
Type: TDM, Direction: INPUT
Fax/Modem Type: voice
Xmit Function: 0x00000000
Xmit function is Enabled
Call ID: 4, Conference ID: -1

```

Session information:: session=0x658CA948 dsp_intf=0x642DDD8C dsp_name=1/9:3

```

connections=2 streams=4 (5 1 4 3 )
current state S_DSMP_VC_RUNNING current container simple_voice_container
State Transitions: timestamp (container, state) -- event -> (container, state)
367138.712 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367138.912 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367139.824 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367139.844 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367140.024 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367140.064 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367140.244 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367140.252 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367141.536 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367141.736 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367141.836 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367142.036 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367142.136 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367142.336 (simple_voice_container, S_DSMP_VC_RUNNING) -- E_DSMP_CC_PLAY_REQ ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367143.244 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN

```

```

-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367143.264 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367143.444 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367143.484 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)
367143.652 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_BEGIN
-> (simple_voice_container, CNFSM_NO_STATE_CHANGE)
367143.672 (simple_voice_container, CNFSM_CONTAINER_STATE) -- E_DSMP_DSP_DTMF_DIGIT_END ->
(simple_voice_container, CNFSM_NO_STATE_CHANGE)

```

Session log information::

Regular Timer:

Timer start operations:

Timestamp	Duration(ms)	Caller
367137.648	4000	0x6113397C
367134.440	4000	0x6113397C
367131.020	4000	0x6113397C
367128.316	4000	0x6113397C

Number of overwritten entries: 3

Timer stop operations:

Timestamp	Duration(ms)	Caller
367137.648	0	0x61133A98
367134.440	0	0x61133A98
367131.024	0	0x61133A98
367128.320	0	0x61133A98

Number of overwritten entries: 6

Periodic Timer:

Timer start operations:

None

Timer stop operations:

None

Packet suppression is disabled

The table below describes the significant fields shown in the display.

Table 18: show voice dsmp stream Field Descriptions

Field	Description
Stream information	Shows stream ID.
Type	Type of stream.
Direction	Direction of stream.
Fax/Modem Type	Type of fax or modem.
Xmit Function	Transmit function in use.
Call ID	Caller ID of call leg.
Conference ID	Conference ID.
Session information	Information about the associated session.
connections	Number of stream connections.

Field	Description
streams	Number of streams.
current state	Current state and container of the session.
State Transitions	State transitions of the associated session.
DSP Encap	Encapsulation associated with the session.
Codec Mask	Codec mask associated with the session.
Fax Rate Mask	Fax rates associated with the session.
Fax Bytes	Fax bytes associated with the session.
VAD Mask	VAD mask associated with the session.

Related Commands

Command	Description
show call active voice	Displays call information for voice calls in progress.
show voice call	Displays the call status for voice ports on the Cisco router.

show voice dsp

To display either the current status or the selective statistics pertaining to the digital signal processor (DSP) voice channels, use the **show voice dsp** command in User EXEC mode or Privileged EXEC mode.

```
show voice dsp [ active [ slot slot-number [slot-number] ] | capabilities slot slot-number
dsp dsp-number | cpu-load slot slot-number dsp dsp-number [reset] | detailed | error | [
group all | sorted-list ] slot slot-number | signalling | voice | version [ slot | slot / dsp ] [ slot
| slot / dsp ] ]
```

Cisco ASR 1000 Series Routers

```
show voice dsp [ active [slot slot-number] | capabilities slot slot-number dsp dsp-number
| cpu-load slot slot-number dsp dsp-number [reset] | crash-dump | detailed | error | group
{ all | slot slot-number } | signalling | sorted-list slot slot-number | voice ]
```

Syntax Description

active	(Optional) Displays the active channels.
slot <i>slot-number</i> <i>[slot-number]</i>	(Optional) Specifies either a single slot or the first slot in a range. To specify a range of slots, enter a second slot in the syntax of this argument. The second slot specifies the end of the range. All the slots in the range are affected by the command.
capabilities	(Optional) Displays DSP capabilities.
dsp <i>dsp-number</i>	(Optional) Specifies the DSP on the slot.
cpu-load	(Optional) Displays DSP CPU load.
reset	(Optional) Resets DSP CPU statistics.
crash-dump	(Optional) Displays the DSP crash dump status. Note To enable a DSP crash dump, set the file limit to a non-zero number, and set the destination to a valid file name.
detailed	(Optional) Displays detailed information about DSP status.
error	(Optional) Displays DSP errors.
group	(Optional) Displays DSP group information.
all	(Optional) Displays all the DSP group details.
sorted-list	(Optional) Displays a DSP-sorted list.
signaling	(Optional) Displays DSP signaling channel usage.
voice	(Optional) Displays DSP voice channel usage.
version	(Optional) Displays the DSP firmware version.

<i>slot</i>	(Optional) The first slot in a range. To specify a range of slots, you can enter a second slot in the syntax of this argument. The second slot specifies the end of the range. All the slots in the range are affected by the command.
<i>/ dsp</i>	(Optional) The first DSP in a range. To specify a range of DSPs, you can enter a second DSP in the syntax of this argument. The second DSP specifies the end of the range. All the DSPs in the range are affected by the command. The slash mark is required.

Command Default No default behavior or values.

Command Modes User EXEC (>)
Privileged EXEC (#)

Command History	Release	Modification
	11.3(1)MA	This command was introduced on the Cisco MC3810.
	12.0(7)XK	This command was implemented on the Cisco 2600 Series and Cisco 3600 Series, and the display format was modified.
	12.1(2)T	This command was integrated into Cisco IOS Release 12.1(2)T.
	12.3(14)T	The command was modified. The command output was enhanced to display status information pertaining to the NM-HDV network module TI-549 DSPs.
	12.4(4)T	The command was modified. The command output was enhanced to display the codec setting for modem relay operation.
	12.4(4)XC	The command was modified. The version keyword was added and the command was implemented on the Cisco AS5350XM and Cisco AS5400XM platforms.
	12.4(11)T	The command was modified. Command output was enhanced to display information about the DSP H.320 channels.
	Cisco IOS XE Release 2.5	This command was integrated into Cisco IOS XE Release 2.5.
	Cisco IOS XE Release 3.2S	This command was implemented on the Cisco ASR 1000 Series Router.
	Cisco IOS XE Release 3.3.0S	The show voice dsp group all command output was modified for SPA-DSP on the Cisco ASR 1000 Series Router.

Usage Guidelines Use this command when abnormal behavior occurs in the DSP voice channels. The channel or channels should have an active voice call at the time the command is executed.

Cisco ASR 1000 Series Routers

In Cisco IOS XE Release 3.3.0s, the **show voice dsp group all** command output that is displayed when a SPA-DSP undergoes call recovery is enhanced. The command output is seen only during the call recovery process, which lasts for a few milliseconds. The additional information that is included in the command output

pertains to: HA State : DSP_HA_STATE_PENDING1. The additional information is displayed when a SPA-DSP undergoes call recovery.

Examples

The following sample output shows how HA State : DSP_HA_STATE_PENDING1 is added. The additional command output is seen only in Cisco IOS XE Release 3.3.0S and later releases:

```
Router# show voice dsp group all
Show DSP group all

DSP groups on slot 0 bay 0:
dsp 1:
  State: UP
  HA State : DSP_HA_STATE_PENDING1
  Max signal/voice channel: 43/43
  Max credits: 645
  num_of_sig_chnls_allocated: 43
  Transcoding channels allocated: 43
  Group: FLEX_GROUP_XCODE, complexity: LOW
  Shared credits: 0, reserved credits: 645
  Transcoding channels allocated: 24
  Credits used (rounded-up): 360
```

The following sample output shows the current status of the codec, set for modem relay, on channel 1:

```
Router# show voice dsp
-----FLEX VOICE CARD 1 -----
                *DSP VOICE CHANNELS*
DSP   DSP           DSPWARE CURR  BOOT           PAK   TX/RX
TYPE  NUM CH CODEC   VERSION STATE STATE   RST AI VOICEPORT TS ABRT PACK COUNT
=====
C5510 001 01 modem-re 4.5.909 busy  idle   0 0 1/1/0   05  0      298/353
                *DSP SIGNALING CHANNELS*
DSP   DSP           DSPWARE CURR  BOOT           PAK   TX/RX
TYPE  NUM CH CODEC   VERSION STATE STATE   RST AI VOICEPORT TS ABRT PACK COUNT
=====
C5510 001 05 {flex}  4.5.909 alloc idle   0 0 1/1/3   02  0      15/0
C5510 001 06 {flex}  4.5.909 alloc idle   0 0 1/1/2   02  0      17/0
C5510 001 07 {flex}  4.5.909 alloc idle   0 0 1/1/1   06  0      31/0
C5510 001 08 {flex}  4.5.909 alloc idle   0 0 1/1/0   06  0      321/0
-----END OF FLEX VOICE CARD 1 -----
```

Examples

The following sample output shows the current status of all the DSP voice channels:

```
Router# show voice dsp
DSP# 0, channel# 0 G729A BUSY
DSP# 0, channel# 1 G729A BUSY
DSP# 1, channel# 2 FAX IDLE
DSP# 1, channel# 3 FAX IDLE
DSP# 2, channel# 4 NONE BAD
DSP# 2, channel# 5 NONE BAD
DSP# 3, channel# 6 NONE BAD
DSP# 3, channel# 7 NONE BAD
DSP# 4, channel# 8 NONE BAD
DSP# 4, channel# 9 NONE BAD
DSP# 5, channel# 10 NONE BAD
DSP# 5, channel# 11 NONE BAD
```

Examples

The following is a sample output of this command on a Cisco 1750 router:

```
Router# show voice dsp
DSP#0: state IN SERVICE, 2 channels allocated
channel#0: voice port 1/0, codec G711 ulaw, state UP
channel#1: voice port 1/1, codec G711 ulaw, state UP
DSP#1: state IN SERVICE, 2 channels allocated
channel#0: voice port 2/0, codec G711 ulaw, state UP
channel#1: voice port 2/1, codec G711 ulaw, state UP
DSP#2: state RESET, 0 channels allocated
```

Examples

The following is a sample output command on a secure Survivable Remote Site Telephony (SRST) router with the NM-HDV network module and the TI-549 (C549) DSP installed:

```
Router# show voice dsp
DSP DSP      DSPWARE CURR   BOOT
TYPE NUM CH  CODEC   VERSION STATE STATE RST AI VOICEPORT TS ABORT PACK COUNT
==== == ==  =====
C549 1 01 {medium} 4.4.3  IDLE idle  0 0  1/0:0 1 0  9357/9775
C549 1 02 {medium} 4.4.3  IDLE idle  0 0  1/0:0 2 0  0/0
C549 2 01 {medium} 4.4.3  IDLE idle  0 0  1/0:0 3 0  0/0
C549 2 02 {medium} 4.4.3  IDLE idle  0 0  1/0:0 4 0  0/0
C549 3 01 {medium} 4.4.3  IDLE idle  0 0  1/0:0 5 0  0/13
C549 3 02 {medium} 4.4.3  IDLE idle  0 0  1/0:0 6 0  0/13
```

Examples

The following is a sample output of this command on an H.320 network configured for video support:

```
Router# show voice dsp

DSP DSP      DSPWARE CURR   BOOT
TYPE NUM CH  CODEC   VERSION STATE STATE RST AI VOICEPORT TS ABORT PACK COUNT
==== == ==  =====
01 g711ulaw 0.1 IDLE 50/0/1.1 edsp 002 02 g711ulaw 0.1 IDLE 50/0/1.2 edsp 003 01 g729r8
p 0.1 IDLE 50/0/2.1 -----FLEX VOICE CARD 1
-----

          *DSP VOICE CHANNELS*
DSP DSP      DSPWARE CURR   BOOT
TYPE NUM CH  CODEC   VERSION STATE STATE RST AI VOICEPORT TS ABRT PACK COUNT
==== == ==  =====
C5510 001 05 None 9.0.105 idle idle  0 0  0 0/0
C5510 001 06 None 9.0.105 idle idle  0 0  0 0/0
C5510 001 07 None 9.0.105 idle idle  0 0  0 0/0
C5510 001 08 None 9.0.105 idle idle  0 0  0 0/0
C5510 001 09 None 9.0.105 idle idle  0 0  0 0/0
C5510 001 10 None 9.0.105 idle idle  0 0  0 0/0
C5510 001 11 None 9.0.105 idle idle  0 0  0 0/0
C5510 001 12 None 9.0.105 idle idle  0 0  0 0/0
C5510 001 13 None 9.0.105 idle idle  0 0  0 0/0
C5510 001 14 None 9.0.105 idle idle  0 0  0 0/0
C5510 001 15 None 9.0.105 idle idle  0 0  0 0/0
C5510 001 16 None 9.0.105 idle idle  0 0  0 0/0
C5510 003 01 None 9.0.105 idle idle  0 0  0 0/0
C5510 003 02 None 9.0.105 idle idle  0 0  0 0/0
C5510 003 03 None 9.0.105 idle idle  0 0  0 0/0
C5510 003 04 None 9.0.105 idle idle  0 0  0 0/0
C5510 003 05 None 9.0.105 idle idle  0 0  0 0/0
C5510 003 06 None 9.0.105 idle idle  0 0  0 0/0
```

```

C5510 003 07 None      9.0.105 idle  idle      0 0          0          0/0
C5510 003 08 None      9.0.105 idle  idle      0 0          0          0/0
C5510 003 09 None      9.0.105 idle  idle      0 0          0          0/0
C5510 003 10 None      9.0.105 idle  idle      0 0          0          0/0
C5510 003 11 None      9.0.105 idle  idle      0 0          0          0/0
C5510 003 12 None      9.0.105 idle  idle      0 0          0          0/0
C5510 003 13 None      9.0.105 idle  idle      0 0          0          0/0
C5510 003 14 None      9.0.105 idle  idle      0 0          0          0/0
C5510 003 15 None      9.0.105 idle  idle      0 0          0          0/0
C5510 003 16 None      9.0.105 idle  idle      0 0          0          0/0

```

DSP H.320 CHANNELS

```

DSP   DSP   TX/RX      DSPWARE CURR      PAK   TX/RX
TYPE  NUM  CH  CODEC     VERSION STATE VOICEPORT TS  ABRT  PACK COUNT
=====
C5510 001 01  h320p(01) 9.0.105 busy  1/0/0:15 06
      001 02  h320s(02) 9.0.105 busy  1/0/0:15 07
      001 03  h320s(03) 9.0.105 busy  1/0/0:15 08
      001 04  h320s(04) 9.0.105 busy  1/0/0:15 09
      001 01a g711ulaw  9.0.105 busy                0 1013663/5083
                                   00
      001 01v h263 /h263 9.0.105 busy                0 104908/30911
                                   4
-----END OF FLEX VOICE CARD 1 -----

```

The table below describes the significant fields shown in the displays.

Table 19: show voice dsp Field Descriptions

Field	Description
DSP	Number of the DSP.
channel	Number of the channel and its status.
DSP TYPE	TI-549 (C549) DSP.
DSP NUM	Number of the DSP.
CH	Channel number.
CODEC	Complexity setting.
DSPWARE VERSION	Version of DSPware.
CURR STATE	Current status of the channel: alloc (allocated), busy, or idle.
BOOT STATE	DSP readiness, either idle or in service.
RST	Number of times the DSP has been reset or restarted.
AI	Alarm indication count on the channel.
VOICEPORT	Voice card number and slot.
TS	Time slot.
PAK ABORT	Number of dropped packets.
TX/RX PACK COUNT	Number of transmitted and received packets.

Cisco ASR 1000 Series Router

The following sample output shows the DSP Type, DSP number, channel number, codecs running, DSP firmware version, and current state of the channels running on the SPA-DSP inside the Cisco ASR 1000 Series Router:

```
Router# show voice dsp

----- SPA-DSP 1/1 -----
*DSP INFORMATION*
DSP    DSP          DSPWARE CURR
TYPE  NUM CH CODEC    VERSION STATE RST AI
===== == == =====
SP2600 001  None    26.07.00 up    4  0
SP2600 002  None    26.07.00 up    3  0
SP2600 003  None    26.07.00 up    3  0
SP2600 004  None    26.07.00 up    1  0
SP2600 005  None    26.07.00 up    1  0
SP2600 006  None    26.07.00 up    1  0
SP2600 007  None    26.07.00 up    1  0
SP2600 008  None    26.07.00 up    1  0
SP2600 009  None    26.07.00 up    1  0
SP2600 010  None    26.07.00 up    1  0
SP2600 011  None    26.07.00 up    1  0
SP2600 012  None    26.07.00 up    1  0
SP2600 013  None    26.07.00 up    1  0
SP2600 014  None    26.07.00 up    1  0
SP2600 015  None    26.07.00 up    1  0
SP2600 016  None    26.07.00 up    1  0
SP2600 017  None    26.07.00 up    1  0
SP2600 018  None    26.07.00 up    1  0
SP2600 019  None    26.07.00 up    1  0
SP2600 020  None    26.07.00 up    1  0
SP2600 021  None    26.07.00 up    1  0
----- END OF SPA-DSP 1/1 -----
```

The following output shows the active channels on SPA-DSP located in slot 1 of the Cisco ASR 1000 Series Router:

```
Router# show voice dsp active slot 1

----- SPA-DSP 1/1 -----
*DSP VOICE CHANNELS*
DSP    DSP          DSPWARE CURR
TYPE  NUM CH CODEC    VERSION STATE RST AI
===== == == =====
SP2600 001 01 g711ulaw 26.07.00 busy  4  0
SP2600 002 01 g711ulaw 26.07.00 busy  3  0
----- END OF SPA-DSP 1/1 -----
```

The following example shows the channel capabilities of the different types of codecs on the Cisco ASR 1000 Series Router:

```
Router# show voice dsp capabilities slot 1
Card 1/1 DSP 1 Capabilities:
DSP Type: SP2600 - 43
Credits 645 , G711Credits 15, HC Credits 37, MC Credits 23,
FC Channel 43, HC Channel 17, MC Channel 28,
```

```

Conference 8-party credits:
  G711 58 , G729 107, G722 129, ILBC 215
Secure Credits:
  Sec LC Xcode 24,      Sec HC Xcode 64,
  Sec MC Xcode 35,      Sec G729 conf 161,
  Sec G722 conf 215,    Sec ILBC conf 322,
  Sec G711 conf 92 ,
Max Conference Parties per DSP:
  G711 88, G729 48, G722 40, ILBC 24,
  Sec G711 56, Sec G729 32,
  Sec G722 24 Sec ILBC 16,
Voice Channels:
  g711perdsp = 43, g726perdsp = 28, g729perdsp = 17, g729aperdsp = 28,
  g723perdsp = 17, g728perdsp = 17, g723perdsp = 17, gsmperdsp = 28,
  gsmefrperdsp = 17, gsmamrnbperdsp = 17,
  ilbcperdsp = 17, isacperdsp = 8 modemrelayperdsp = 17,
  g72264Perdsp = 28, h324perdsp = 17,
  m_f_thruperdsp = 43, faxrelayperdsp = 28,
  maxchperdsp = 43, minchperdsp = 17,
  srtp_maxchperdsp = 27, srtp_minchperdsp = 14, faxrelay_srtp_perdsp =
4,
  g711_srtp_perdsp = 27, g729_srtp_perdsp = 14, g729a_srtp_perdsp = 24,-----

```

The following example shows the details of the DSP errors on the Cisco ASR 1000 Series Router.



Note The crash dump details must be enabled to display the crash dump for a SPA-DSP. To enable a crash dump, set the destination of the crash dump file to a valid file name, and set the file limit to a non-zero number.

```

Router# show voice dsp crash-dump
Voice DSP Crash-dump status:
  Destination file url is <none>
  File limit is 0
DSP crash dump is currently disabled
To enable DSP crash dump, set file-limit to a non-zero number and set
destination to a valid file name

```

Related Commands

Command	Description
dsp services dspfarm	Enables the DSP farm services.
dspfarm profile	Enters the DSP farm profile configuration mode and defines a profile for DSP farm services.
show dspfarm	Displays DSP farm service information, such as operational status, and DSP resource allocation for transcoding.

show voice dsp channel

To display the voice digital signal processor (DSP) channels, use the **show voice dsp channel** command in user EXEC or privileged EXEC mode.

show voice dsp channel {**operational-status** {*slot* | *ldsp* | *lchannel*} [*slot* | *ldsp* | *lchannel*]} | **statistics** *slot-number* [*slot-number*] | **traffic** *slot-number* [*slot-number*]}

Syntax Description	operational-status	Displays the operational state for active sessions on a specific channel or range of channels.
<i>slot</i>		A single slot or the first slot in a range. To specify a range of slots, you can enter a second slot in the syntax of this argument. The second slot specifies the end of the range. All slots in the range are affected by the command.
<i>l dsp</i>		A single DSP on the slot or the first DSP in a range. To specify a range of DSPs, you can enter a second DSP in the syntax of this argument. The second DSP specifies the end of the range. All DSPs in the range are affected by the command. The slash mark is required.
<i>l channel</i>		A single DSP channel or the first DSP channel in a range. The second occurrence of this argument specifies either a single DSP channel or the last DSP channel in a range. The slash mark is required.
statistics		Displays DSP statistics for a specific channel or range of channels.
<i>slot-number</i>		A single slot or the first slot in a range. To specify a range of slots, you can enter a second slot in the syntax of this argument. The second slot specifies the end of the range. All slots in the range are affected by the command.
traffic		Displays traffic on a specific channel or range of channels.

Command Modes

User EXEC (>)
Privileged EXEC (#)

Command History

Release	Modification
12.4(4)XC	The command was introduced on the Cisco AS5350XM and Cisco AS5400XM platforms.
12.4(11)T	The command was modified. Command output was enhanced to display information about DSP H.320 channels.

Usage Guidelines

Use this command when abnormal behavior occurs in the DSP voice channels. The channel or channels should have an active voice call at the time the command is executed.

Examples

The following is sample output from the **show voice dsp channel operational-status** command on slot 3/13/1:

```

Router# show voice dsp channel operational-status 3/13/1
Operational status of Slot/DSP/Channel : 3/13/1
Servicetype : VOICE
Codec Type : gsmamr-nb
Encapsulation : RTP
Transmitted Packets : 346
Transmitted Bytes : 11740
Received Packets : 411
Received Bytes : 11142
Playout de-jitter mode : None
Playout de-jitter buffer minimum delay : 0 msec
Playout de-jitter buffer initial delay : 0 msec
Playout de-jitter buffer maximum delay : 0 msec
Noise level : -5.0
ERLLevel : 6
ACOMLevel : 6
CodecPktPeriod=20 Milliseconds
CodecFrameFormat=bandwidth-efficient
CodecCrc=Disabled
CodecModes=3,6
CodecEncodeRate=6
CodecDecodeRate=6
CodecEncodeChanges=1
CodecDecodeChanges=0
CodecCrcFails=0
CodecBadFrameQuality=0
CodecInvalidCMRs=0
CodecInvalidFrameType=0
Voice activity detection : Enabled
Dtmf Relay : inband-voice
ComfortNoisePak : 52
TxVoiceDuration : 11560
VoiceRxDuration : 3380
Rx OutOfSeq Paks : 0
Rx Late Paks : 0
Rx Early Paks : 0
Lost Packets : 0
Playout Delay Current : 50
Playout Delay Min : 50
Playout Delay Max : 50
Playout Delay ClockOffset : 80
Playout Delay Jitter : 0
Error Rx Drop : 0
Error Tx Drop : 0
Error Tx Control : 0
Error Rx Control : 0
Playout Error Predictive : 0
Playout Error Interpolative : 0
Playout Error Silence : 0
Playout Error BufferOverflow : 0
Playout Error Retroactive : 0
Playout Error Talkspurt : 0

```

The table below describes the significant fields shown in the display.

Table 20: show voice dsp channel Field Descriptions

Field	Description
DSP	Number of the DSP.
Channel	Number of the channel and its status.

Field	Description
Codec Type	Complexity setting.
TxVoiceDuration	Transmitted voice duration.

Related Commands

Command	Description
show voice dsp	Displays the current status or selective statistics of DSP voice channels,.

show voice dsp crash-dump

To display voice digital signal processor (DSP) crash dump information, use the `show voice dsp crash-dump` command in privileged EXEC configuration mode.

show voice dsp crash-dump

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.3(4)T	This command was introduced.

Examples

The following example checks your configuration:

```
Router# show voice dsp crash-dump
Voice DSP Crash-dump status:
  Destination file url is slot0:banjo-152-s
  File limit is 20
  Last DSP dump file written was
    tftp://112.29.248.12/tester/26-152-t2
  Next DSP dump file written will be slot0:banjo-152-s1
```

The following example shows that the crash dump feature is enabled:

```
Router# show voice dsp crash-dump
Voice DSP Crash-dump status:
  Destination file url is
    tftp://172.29.248.12/xxtir/dspdump6.bin
  File limit is 10
  Last DSP dump file written was
    tftp://172.29.248.12/xxtir/dspdump6.bin1
  Next DSP dump file written will be
    tftp://172.29.248.12/xxtir/dspdump6.bin2
```

The following example shows that the crash dump feature is disabled:

```
Router# show voice dsp crash-dump
Voice DSP Crash-dump status:
  Destination file url is
    tftp://172.29.248.12/xxtir/dspdump6.bin
  File limit is 0
  Last DSP dump file written was
    tftp://172.29.248.12/xxtir/dspdump6.bin1
DSP crash dump is currently disabled
To enable DSP crash dump, set file-limit to a non-zero number
```

Field descriptions should be self-explanatory.

Related Commands

Command	Description
debug voice dsp crash-dump	Displays crash dump debug information.
voice dsp crash-dump	Enables the crash dump feature and specifies the destination file and the file limit.

show voice dsp summary

To display the digital signal processor (DSP) summary, use the **show voice dsp summary** command in user EXEC or privileged EXEC mode.

show voice dsp summary [*slot* | *slot/dsp*] [*slot* | *slot/dsp*]

Syntax Description

<i>slot</i>	(Optional) A single slot or the first slot in a range. To specify a range of slots, you can enter a second slot in the syntax of this argument. The second slot specifies the end of the range. All slots in the range are affected by the command.
<i>/ dsp</i>	(Optional) A single DSP on the slot or the first DSP in a range. To specify a range of DSPs, you can enter a second DSP in the syntax of this argument. The second DSP specifies the end of the range. All DSPs in the range are affected by the command. The slash mark is required.

Command Modes

User EXEC (>)

Privileged EXEC (#)

Command History

Release	Modification
12.4(4)XC	This command was introduced. The command was implemented on the Cisco AS5350XM and Cisco AS5400XM platforms.
12.4(11)T	The command was modified. Command output was enhanced to display information about DSP H.320 channels.
12.4(19)	The command was modified. Command output was modified to accurately show the "Codectype" as "voice" rather than "fax" for T.38 calls.
12.4(18a)	The command was modified. Command output was modified to accurately show the "Codectype" as "voice" rather than "fax" for T.38 calls.
12.4(13f)	The command was modified. Command output was modified to accurately show the "Codectype" as "voice" rather than "fax" for T.38 calls.
12.4(15)T5	The command was modified. Command output was modified to accurately show the "Codectype" as "voice" rather than "fax" for T.38 calls.

Examples

The following sample output from the **show voice dsp summary** command shows summary information about DSPs:

```
Router# show voice dsp summary
Total number of DSPs = 48

Codectype      Calls   Codectype      Calls   Codectype      Calls
g729r8 pre-ietf  0      g729ar8        0      g726r16        0
g726r24        0      g726r32        0      g711ulaw       0
g711alaw       1      g728           0      g723r63        0
g723r53        0      gsmfr          0      gsmevr         0
```

```

g729abr8      0   g729abr8      0   g723ar63      0
g723ar53      0   g729r8        0   t38            0
clear-channel  0   vofr cisco    0   llcc           0
g726r40       0   transparent   0   modem-relay    0
cisco         0                               0
pass-through  0   gsmamr-nb     0
    
```

```

Legend      :
=====
Channel state: (s)shutdown (a)active call (d)download pending
               (b)busiedout (B)bad (p)busyout pending
Call type   : (v)voice (f)fax-relay ( )not in use
    
```

```

Summary     :
=====
Channels    : Total 768 In-Use 001
Calls      : Total 001 Voice 001 Fax 000
            : Free 713 Disabled 000
    
```

DSP#	DSP State	DSP Complexity	DSP Resets	Channel State	Call Type
2/1	ACTIVE	FLEXI	0	_____	_____
2/2	ACTIVE	FLEXI	0	_____	_____
2/3	ACTIVE	FLEXI	0	_____	_____
2/4	ACTIVE	FLEXI	0	_____	_____
2/5	ACTIVE	FLEXI	0	_____	_____
2/6	ACTIVE	FLEXI	0	_____	_____

The table below describes the significant fields shown in the display.

Table 21: show voice dsp summary Field Descriptions

Field	Description
DSP	Number of the DSP.
Codectype	Complexity setting.
Channels	Number of the channel and its status.
State	Status of the calls.

Related Commands

Command	Description
show voice dsp	Displays the current status or selective statistics of DSP voice channels,.

show voice eddri prefix

To show applicable prefixes for the event dispatcher and data repository interface (EDDRI), use the show voice eddri prefix command in privileged EXEC mode.

show voice eddri prefix [prefix_number]

Syntax Description	all	All neighbors
	<i>prefix_number</i>	(Optional) Specified EDDRI prefix.

Command Default No default behavior or values.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.3(1)	This command was introduced.

Usage Guidelines If no prefix is specified, all configured prefixes appear.

The EDDRI notifies threaded grep (TGREP) when an attribute changes on some subsystems. EDDRI interacts with the dial-peer subsystem, trunk-group subsystems, call-control API (CCAPI) subsystem, and customer-relationship-management (CRM) subsystem to notify changes in particular attributes. EDDRI is responsible for creating the prefix database.

Examples

The following example shows output for the show voice eddri prefix command:

```
prefix 4 address family decimal
advertise flag 0x27 ac 24 tc 24 capacity timer 25 sec
AC_avg 24, FD_avg 0, SD_avg 0
succ_curr 0 tot_curr 0
succ_report 0 tot_report 0
changed 0 replacement position 0
trunk group castg2
dial peer tag 1001
```

Field descriptions should be self-explanatory.

Related Commands	Command	Description
	debug voip eddri	Turns on debugging for the EDDRI.

show voice emergency locations

To display the emergency response locations (ERL) for E911 services, use **show voice emergency locations** command in privileged EXEC mode.

show voice emergency locations

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	IOS XE Fuji Release 16.8.1	This command was introduced.

Usage Guidelines Use this command to display an ERL that identifies an area where emergency teams can quickly locate a 911 caller. This command displays ERL assignment by zone, device, and interfaces.

Examples

The following example displays ERL assignment by zone, device, and interfaces.

```
Router# show voice emergency locations
ERL ASSIGNMENT BY ZONE
DIAL-PEER    ZONE
=====
911          10

ERL ASSIGNMENT BY DEVICE AND INTERFACES
ERL          DEVICE
=====
12           dial-peer 100
```

Related Commands	voice emergency response	Configures emergency response location, zone, and settings for E911 services.

show voice enum-match-table

To display the rules of an ENUM match table, use the **show voice enum-match-table** command in privileged EXEC mode.

show voice enum-match-table [*table-number* [*sort*]]

Syntax Description	
<i>table-number</i>	(Optional) ENUM match table to display, by number. Range is from 1 to 15.
sort	(Optional) Sorts the output by ascending table number.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.2(11)T	This command was introduced.

Usage Guidelines

This command displays the ENUM match table rules in the order in which they were defined. The sort keyword changes the display to list the rules from lowest to highest preference.

Examples

The following sample output displays the rules of ENUM match table number 3:

```
Router# show voice enum-match-table 3
voice enum_match_table 3
rule 1 5 /^9\{1,*\}/ /\1/ cisco
rule 2 4 /^9011\{1,*\}/ /\1/ arpa
rule 10 1 /^(.*)/ /\1/ e164.cisco.com
```

The following sample output displays the ENUM match tables in ascending order by table number:

```
Router# show voice enum-match-table
voice enum-match-table 3
rule 1 5 /^9\{1,*\}/ /\1/ cisco
rule 2 4 /^9011\{1,*\}/ /\1/ arpa
rule 10 1 /^(.*)/ /\1/ e164.cisco.com
voice enum-match-table 5
rule 2 4 /^9011\{1,*\}/ /\1/ arpa
rule 10 1 /^(.*)/ /\1/ e164.cisco.com
```

Field descriptions should be self-explanatory.

Related Commands

Command	Description
rule (ENUM configuration)	Defines the ENUM rule.
test enum	Tests the ENUM rule.
voice enum-match-table	Initiates the voice ENUM match table definition.

show voice hpi capture

To display capture status and statistics, use the **show voice hpi capture** command in privileged EXEC mode.

show voice hpi capture

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.2(10)	This command was introduced.
12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T.

Usage Guidelines

This command displays the capture status and statistics. Use this command to confirm logger status and to examine the logger status output when the logger is running.



Caution

Using the message logger feature in a production network environment increases CPU and memory usage on the gateway.



Note

If you are experiencing problems with certain voice calls, the engineering team at Cisco might ask you to capture the control messages using the voice DSP logger. You can capture these messages by turning on the logger, repeating the problematic calls, and capturing the logs. Only Cisco engineers can determine if you should send the logs in for further review.

Examples

The following sample output shows capture statistics (HPI capture and logging) and status:

```
Router# show voice hpi capture
HPI Capture is on and is logging to URL ftp://172.23.184.216/d:\test_data.dat1 messages
sent to URL, 0 messages droppedMessage Buffer (total:inuse:free) 2134:0000:2134Buffer
Memory:699952 bytes, Message size:328 bytes
```

Field descriptions should be self-explanatory.

Related Commands

Command	Description
debug hpi	Enables debugging for HPI message events.
voice hpi capture	Allocates the Host Port Interface (HPI) capture buffer (size in bytes) and sets up or changes the destination URL for captured data.

show voice iec description

To display Internal Error Code (IEC) descriptions, use the `show voice iec description` command in user EXEC mode.

show voice iec description string

Syntax Description

<i>string</i>	Six-part dotted decimal string that displays the definition of an internal error code.
---------------	--

Command Default

No default behavior or values.

Command Modes

User EXEC

Command History

Release	Modification
12.3(4)T	This command was introduced.

Examples

The following example displays IEC descriptions:

```
Router# show voice iec description 1.1.180.2.21.4
IEC Version: 1
Entity: 1 (Gateway)
Category: 180 (Software error)
Subsystem: 2 (TCL IVR)
Error: 21 (Script syntax)
Diagnostic Code: 4
```

The table below describes significant fields shown in the display.

Table 22: show voice iec description Field Descriptions

Field	Description
IEC version	IEC version. A value of 1 indicates the Cisco IOS Release 12.3(4)T version.
Entity	Network physical entity (hardware system) that generated the IEC. The value 1 is assigned to the gateway.
Category	Error category, defined in terms of ITU-based Q.850 cause codes and VoIP network errors.
Subsystem	Specific subsystem within the physical entity where the IEC was generated.
Error Code	Error code within the subsystem.
Diagnostic Code	Cisco internal diagnostic value. Report this value to Cisco Technical Support.

Related Commands

Command	Description
<code>show voice statistics iec</code>	Displays IEC statistics.

show voice lmr

To display the Land Mobile Radio (LMR) related dynamic information and static information for LMR ports or a DS0 group, use the **show voice lmr** command in privileged EXEC mode.

show voice lmr [*slot/subunit/port* | *slot/port:ds0-group*] [**details** | **timing** [**warnings**]]

Syntax	Description
<i>slot/subunit/port</i>	(Optional) Voice port that you specify with the <i>slot/subunit/port</i> designation. <ul style="list-style-type: none"> • <i>slot</i> specifies a router slot in which a voice network module (NM) is installed. Valid entries are router slot numbers for the particular platform. • <i>subunit</i> specifies a voice interface card (VIC) in which the voice port is located. Valid entries are 0 and 1. • <i>port</i> specifies an analog voice port number. Valid entries are 0 and 1. The slash marks are required.
<i>slot/port : ds0-group</i>	(Optional) Voice port that you specify with the <i>slot/port : ds0-group</i> designation. <ul style="list-style-type: none"> • <i>slot</i> specifies a router slot in which the packet voice NM is installed. Valid entries are router slot numbers for the particular platform. • <i>port</i> specifies a T1 or E1 physical port in the voice WAN interface card (VWIC). Valid entries are 0 and 1. • <i>ds0-group</i> specifies a T1 or E1 logical port number. T1 range is from 0 to 23. E1 range is from 0 to 30. The colon is required.
details	(Optional) Displays more information. If this keyword is omitted, less information is displayed.
timing	(Optional) Displays the timing configuration for all LMR ports.
warnings	(Optional) Displays all LMR ports that are having suspicious timing configuration.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.3(4)XD	This command was introduced.
12.3(7)T	This command was integrated into Cisco IOS Release 12.3(7)T.
12.4(24)T	This command was modified in a release earlier than Cisco IOS Release 12.4(24)T. The timing and warnings keywords were added.

Usage Guidelines

This command displays information for LMR voice ports only. If no voice port is specified, the command displays information for all ear and mouth (E&M) LMR voice ports.

When the **details** keyword is used, this command displays information about timeouts, timers, and injected tones and pauses, in addition to detailed voice port and active call information found in the **show voice port** and **show call active voice** commands.

Examples

The following is sample output from the **show voice lmr** command for an E&M LMR analog voice port on a Cisco 3745 router:

```
Router# show voice lmr 2/0/0
2/0/0
=====
Connection type: n/a
Out Attenuation = 0 db, In Gain = 0 dB
E-lead capability is inactive, polarity = normal
M-lead capability is inactive, polarity = normal
voice-class tone-signal test
state = LMR_CONNECT, e-lead = off, m-lead = off
full duplex, voice path = rx
Terminating side of the connection
TransmitPackets=113, TransmitBytes=2241
ReceivePackets=113, ReceiveBytes=2241
CoderTypeRate=g729r8
NoiseLevel=-65, ACOMLevel=22
OutSignalLevel=-68, InSignalLevel=-79
RemoteIPAddress=10.5.25.40, RemoteUDPPort=17272
Remote SignallingIPAddress=10.5.25.40, Port=15418
Remote MediaIPAddress=10.5.25.40, Port=17272
RoundTripDelay=2 ms
SessionProtocol=cisco
VAD =enabled
```

The following is sample output from the **show voice lmr details** command for an E&M LMR analog voice port on a Cisco 3745 router:

```
Router# show voice lmr 2/0/0 details
2/0/0
=====
Description:
Connection type: n/a
Out Attenuation = 0 db, In Gain = 0 dB
Timing hangover: 500 ms
E-lead capability is inactive, polarity = normal
M-lead capability is inactive, polarity = normal
Timing hookflash-in: 480
Timing delay-voice: 470 ms
Music On Hold Threshold: -38 dB, Noise Threshold: -62 dB
E&M type: 1, Operation: 2-wire
Impedance is set to 600r Ohm
lmr tear down timeout is set to 1800 second
lmr PTT transmit timeout is not set
lmr PTT receive timeout is not set
voice-class tone-signal test
    inject tone 1 1950 3 150
    inject tone 2 2000 0 60
    inject pause 3 60
    inject tone 4 2175 3 150
    inject tone 5 1000 0 50
    inject guard-tone 6 1950 -10
```

```

state = LMR_CONNECT, e-lead = off, m-lead = off
full duplex, voice path = rx
Terminating side of the connection
TransmitPackets=113, TransmitBytes=2241
ReceivePackets=113, ReceiveBytes=2241
CoderTypeRate=g729r8
NoiseLevel=-66, ACOMLevel=22
OutSignalLevel=-68, InSignalLevel=-79
PeerAddress=37200
PeerSubAddress=
PeerId=200
SessionTarget=
RemoteIPAddress=10.5.25.40, RemoteUDPPort=17272
Remote SignallingIPAddress=10.5.25.40, Port=15418
Remote MediaIPAddress=10.5.25.40, Port=17272
RoundTripDelay=0 ms
SessionProtocol=cisco
VAD =enabled
SelectedQoS=best-effort
ProtocolCallId=
SessionTarget=

```

The table below describes the significant fields shown in the output, in the order in which they appear.

Table 23: show voice lmr Field Descriptions

Field	Description
Connection type	Type of connection between LMR routers: private line, automatic ringdown (PLAR), trunk, or n/a
Out Attenuation	Output attenuation.
In Gain	Input gain.
E-lead capability	Active or inactive.
polarity	Polarity of the E&M voice port: normal or reverse.
M-lead capability	Active or inactive.
voice class tone-signal	Name of the tone-signal voice class.
state=	Signaling state.
e-lead =	On or off.
m-lead =	On or off.
full duplex	Voice path for the voice port is operating in full duplex mode.
half duplex	Voice path for the voice port is operating in half duplex mode.
voice path	Transmit or receive.
TransmitPackets	Number of packets sent by this peer during this call.
TransmitBytes	Number of bytes sent by this peer during this call.

Field	Description
ReceivePackets	Number of packets received by this peer during this call.
ReceiveBytes	Number of bytes received by the peer during this call.
CoderTypeRate	Negotiated coder rate. This value specifies the send rate of voice or fax compression to its associated call leg for this call.
NoiseLevel	Active noise level for this call.
ACOMLevel	Current ACOM level for this call. ACOM is the combined loss achieved by the echo canceller, which is the sum of the Echo Return Loss, Echo Return Loss Enhancement, and nonlinear processing loss for the call.
OutSignalLevel	Active output signal level to the telephony interface used by this call.
InSignalLevel	Active input signal level from the telephony interface used by this call.
RemoteIPAddress	Remote system IP address for the VoIP call.
RemoteUDPPort	Remote system User Datagram Protocol (UDP) listener port to which voice packets are sent.
Remote SignallingIPAddress, Port	Call control server IP address and signaling port number.
Remote MediaIPAddress, Port	Remote side media server IP address and RTP port number.
RoundTripDelay	Voice packet round trip delay between the local and remote systems on the IP backbone for this call.
SessionProtocol	Session protocol used for an Internet call between the local and remote routers through the IP backbone.
VAD	Whether voice activation detection (VAD) is enabled.
Description	Description of what the port is connected to.
Timing hangover	Number of milliseconds of delay before the digital signal processor (DSP) tells Cisco IOS software to turn off the E-lead after the DSP detects that the voice stream has stopped.
Timing hookflash-in	Maximum duration of a hookflash for a Foreign Exchange Station (FXS) interface.
Timing delay-voice	Delay before a voice packet is played out.
Music On Hold Threshold	Decibel level of music played when calls are put on hold.
Noise Threshold	Noise threshold for incoming calls.
E&M type	E&M signaling type.
Operation	2-wire or 4-wire operation.
Impedance	Terminating impedance of the interface.

Field	Description
lmr tear down timeout	Time for which the voice port waits before tearing down an LMR connection after detecting no voice activity.
lmr PTT transmit timeout	Maximum time for transmitting a voice packet.
lmr PTT receive timeout	Maximum time for receiving a voice packet.
inject pause	Pause injected before the voice packet is played out.
inject tone	Tone injected before the voice packet is played out.
inject guard-tone	Guard tone played out with the voice packet.
PeerAddress	Destination pattern or number associated with this peer.
PeerSubAddress	Subaddress when this call is connected.
PeerId	ID value of the peer table entry to which this call was made.
SessionTarget	Network-specific address to receive calls from the dial peer.
SelectedQoS	Selected RSVP quality of service (QoS) for this call.
ProtocolCallId	Voice signaling specific call ID.

Related Commands

Command	Description
show call active voice	Displays call information for voice calls in progress.
show voice port	Displays configuration information about a specific voice port.

show voice pcm capture

To display PCM capture status and statistics, use the **show voice pcm capture** command in privileged EXEC mode.

show voice pcm capture

Syntax Description This command has no arguments or keywords.

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	15.2(2)T	This command was introduced.

Usage Guidelines This command displays the PCM capture status and statistics. Use this command to confirm logger status and to examine the logger status output when the logger is running.

Examples The following is sample output from the **show voice pcm capture** command :

```
Router# show voice pcm capture
PCM Capture is on and is logging to URL tftp://10.10.1.2/acphan/
50198 messages sent to URL, 0 messages dropped
Message Buffer (total:inuse:free) 200000:0:200000
Buffer Memory: 68000000 bytes, Message size: 340 bytes
```

Related Commands	Command	Description
	voice pcm capture	Allocates the number of Pulse Code Modulation (PCM) capture buffers, sets up or changes the destination URL for captured data, enables PCM capture on-demand, and changes the PCM capture trigger string by the user.

show voice port

To display configuration information about a specific voice port, use the **show voice port** command in privileged EXEC mode.

Cisco 1750 Router

show voice port *slot/port*

Cisco 2600 and Cisco 3600 Series Router with Analog Voice Ports

show voice port [*slot/subunit/port* | **summary**]

Cisco 2600 and Cisco 3600 Series Router with Digital Voice Ports (with T1 Packet Voice Trunk Network Modules)

show voice port [*slot/port:ds0-group* | **summary**]

Cisco AS5300 Universal Access Server

show voice port *controller-number:D*

Cisco 7200 Series Router

show voice port {*slot/port:ds0-group-number* | *slot/subunit/port*}

Syntax	Description
Cisco 1750 Router	
<i>slot</i>	Slot number in the router in which the VIC is installed. Valid entries are 0, 1, and 2, depending on the slot in which it is installed.
<i>/ port</i>	Voice port. Valid entries are 0 and 1. The slash mark is required.
Cisco 2600 and Cisco 3600 Series Router with Analog Voice Ports	
<i>slot / subunit / port</i>	(Optional) The analog voice port designation: <ul style="list-style-type: none"> • <i>slot</i> -- Router slot in which a voice network module (VNM) is installed. Valid entries are router slot numbers for the particular platform. • <i>subunit</i> --Voice Interface Card (VIC) in which the voice port is located. Valid entries are 0 and 1. (The VIC fits into the voice network module.) The slash mark is required. • <i>port</i>-- Analog voice port number. Valid entries are 0 and 1. The slash mark is required.
summary	(Optional) Displays a summary of all voice ports.
Cisco 2600 and Cisco 3600 Series Router with Digital Voice Ports	

Cisco 1750 Router	
<i>slot / port : ds0 -group</i>	(Optional) Specifies the digital voice port designation: <ul style="list-style-type: none"> • <i>slot</i>-- Router slot in which the packet voice trunk network module (NM) is installed. Valid entries are router slot numbers for the particular platform. • <i>/ port</i>-- T1 or E1 physical port in the voice WAN interface card (VWIC). Valid entries are 0 and 1. (One VWIC fits in an NM.) The slash mark is required. • <i>:</i> <i>ds0 -group</i>--T1 or E1 logical port number. T1 range is 0 to 23. E1 range is 0 to 30. The colon is required.
summary	(Optional) Displays a summary of all voice ports.
Cisco AS5300 Universal Access Server	
<i>controller -number</i>	T1 or E1 controller.
:D	D channel that is associated with the ISDN PRI. The colon is required.
Cisco 7200 Series Router	
<i>slot</i>	Router location where the voice port adapter is installed. Range is 0 to 3.
<i>/ port</i>	Voice interface card location. Valid entries are 0 and 1. The slash mark is required.
: ds0-group-number	Defined DS0 group number. Because each defined DS0 group number is represented on a separate voice port, you can define individual DS0s on the digital T1/E1 card. The colon is required.
<i>slot</i>	Slot number in the Cisco router where the VIC is installed. Range is 0 to 3, depending on the slot where it is installed.
<i>/ subunit</i>	Subunit on the VIC where the voice port is located. Valid entries are 0 and 1. The slash mark is required.
<i>/ port</i>	Voice port number. Valid entries are 0 and 1. The slash mark is required.

Command Modes

Privileged EXEC

Command History

Release	Modification
11.3(1)T	This command was introduced on the Cisco 3600 series.
11.3(1)MA	This command was modified. Port-specific values for the Cisco MC3810 were added.
12.0(3)T	This command was modified. Port-specific values for the Cisco MC3810 were added.

Release	Modification
12.0(5)XK	This command was modified. The <i>ds0-group</i> argument was added for the Cisco 2600 series and Cisco 3600 series.
12.0(5)XE	This command was modified. Additional syntax was created for digital voice to allow specification of the DS0 group. This command applies to VoIP on the Cisco 7200 series.
12.0(7)T	This command was integrated into Cisco IOS Release 12.0(7)T.
12.0(7)XK	This command was modified. The summary keyword was added for the Cisco 2600 series and Cisco 3600 series. The <i>ds0-group</i> argument was added for the Cisco MC3810.
12.1(2)T	This command was integrated into Cisco IOS Release 12.1(2)T.
12.2(8)T	This command was modified. This command was implemented for direct inward dial (DID) on the Cisco IAD2420 series.
12.2(2)XN	This command was modified. Support for enhanced Media Gateway Control Protocol (MGCP) voice gateway interoperability was added to Cisco CallManager Version 3.1 for the Cisco 2600 series, Cisco 3600 series, and Cisco Gateway 200 (Cisco VG200).
12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T and Cisco CallManager Version 3.2. It was implemented on the Cisco IAD2420 series.
12.4(11)T	This command was modified. This command was enhanced to display voice class called-number-pool configuration information for the voice port.
12.4(12)	This command was modified. This command was integrated into Cisco IOS Release 12.4(12) and output was modified to display the parameter set by the timing sup-disconnect command.
15.0(1)XA	This command was modified. The output was enhanced to display the logical partitioning class of restriction (LPCOR) policy for incoming and outgoing calls.
15.1(1)T	This command was integrated into Cisco IOS Release 15.1(1)T.
15.1(3)T	This command was modified. The output of this command was enhanced to display the connection status of foreign exchange office (FXO) ports.

Usage Guidelines

Use this command to display configuration and VIC-specific information about a specific port.

This command works on Voice over IP, Voice over Frame Relay, and Voice over ATM.

The **ds0-group** command automatically creates a logical voice port that is numbered as follows on Cisco 2600, Cisco 3600 series, and Cisco 7200 series routers: *slot / port : ds0-group-number*. Although only one voice port is created for each group, applicable calls are routed to any channel in the group.



Note This command is not supported on Cisco AS5350, Cisco AS5400, Cisco AS5800, and Cisco AS5850 platforms for Non-Facility Associated Signaling (NFAS) configuration.

Examples

The following is sample output from the **show voice port** command for an E&M analog voice port:

```

Router# show voice port 1/0/0
E&M Slot is 1, Sub-unit is 0, Port is 0
Type of VoicePort is E&M
Operation State is unknown
Administrative State is unknown
The Interface Down Failure Cause is 0
Alias is NULL
Noise Regeneration is disabled
Non Linear Processing is disabled
Music On Hold Threshold is Set to 0 dBm
In Gain is Set to 0 dB
Out Attenuation is Set to 0 dB
Echo Cancellation is disabled
Echo Cancel Coverage is set to 16ms
Connection Mode is Normal
Connection Number is not set
Initial Time Out is set to 0 s
Interdigit Time Out is set to 0 s
Analog Info Follows:
Region Tone is set for northamerica
Currently processing none
Maintenance Mode Set to None (not in mtc mode)
Number of signaling protocol errors are 0
Voice card specific Info Follows:
Signal Type is wink-start
Operation Type is 2-wire
Impedance is set to 600r Ohm
E&M Type is unknown
Dial Type is dtmf
In Seizure is inactive
Out Seizure is inactive
Digit Duration Timing is set to 0 ms
InterDigit Duration Timing is set to 0 ms
Pulse Rate Timing is set to 0 pulses/second
InterDigit Pulse Duration Timing is set to 0 ms
Clear Wait Duration Timing is set to 0 ms
Wink Wait Duration Timing is set to 0 ms
Wink Duration Timing is set to 0 ms
Delay Start Timing is set to 0 ms
Delay Duration Timing is set to 0 ms

```

The following is sample output from the **show voice port** command for an E&M digital voice port:

```

Router# show voice port 1/0/1
receIve and transMit Slot is 1, Sub-unit is 0, Port is 1
Type of VoicePort is E&M
Operation State is DORMANT
Administrative State is UP
No Interface Down Failure
Description is not set
Noise Regeneration is enabled
Non Linear Processing is enabled
Music On Hold Threshold is Set to -38 dBm
In Gain is Set to 0 dB
Out Attenuation is Set to 0 dB
Echo Cancellation is enabled
Echo Cancel Coverage is set to 8 ms
Connection Mode is normal
Connection Number is not set
Initial Time Out is set to 10 s
Interdigit Time Out is set to 10 s
Region Tone is set for US

```

The following is sample output from the **show voice port** command for a foreign exchange station (FXS) analog voice port:

```
Router# show voice port 1/1/1
Foreign Exchange Station 1/1/1 Slot is 1, Sub-unit is 1, Port is 1
Type of VoicePort is FXS VIC2-2FXS
Operation State is DORMANT
Administrative State is UP
The Last Interface Down Failure Cause is Administrative Shutdown
Description is I am a FXS LoopStart port
Noise Regeneration is enabled
Non Linear Processing is enabled
Non Linear Mute is disabled
Non Linear Threshold is -21 dB
Music On Hold Threshold is Set to -38 dBm
In Gain is Set to 0 dB
Out Attenuation is Set to 3 dB
Echo Cancellation is enabled
Echo Cancellation NLP mute is disabled
Echo Cancellation NLP threshold is -21 dB
Echo Cancel Coverage is set to 64 ms
Echo Cancel worst case ERL is set to 6 dB
Playout-delay Mode is set to adaptive
Playout-delay Nominal is set to 60 ms
Playout-delay Maximum is set to 250 ms
Playout-delay Minimum mode is set to default, value 40 ms
Playout-delay Fax is set to 300 ms
Connection Mode is normal
Connection Number is not set
Initial Time Out is set to 10 s
Interdigit Time Out is set to 10 s
Call Disconnect Time Out is set to 60 s
Supervisory Disconnect Time Out is set to 750 ms
Ringing Time Out is set to 180 s
Wait Release Time Out is set to 30 s
Companding Type is u-law
Region Tone is set for US
Analog Info Follows:
Currently processing none
Maintenance Mode Set to None (not in mtc mode)
Number of signaling protocol errors are 0
Impedance is set to 600r Ohm
Station name None, Station number None
Translation profile (Incoming):
Translation profile (Outgoing):
lpcor (Incoming): local_group
lpcor (Outgoing): local_group
Voice card specific Info Follows:
Signal Type is loopStart
Ring Frequency is 25 Hz
Hook Status is On Hook
Ring Active Status is inactive
Ring Ground Status is inactive
Tip Ground Status is active
Digit Duration Timing is set to 100 ms
InterDigit Duration Timing is set to 100 ms
Hookflash-in Timing is set to max=1000 ms, min=150 ms
Hookflash-out Timing is set to 400 ms
No disconnect acknowledge
Ring Cadence is defined by CPTone Selection
Ring Cadence are [20 40] * 100 msec
Ringer Equivalence Number is set to 1
```

The following is sample output from the **show voice port** command for an FXO analog voice port:

```
Router# show voice port 1/0/1
Foreign Exchange Office 1/0/1 Slot is 1, Sub-unit is 0, Port is 1
Type of VoicePort is FXO
Operation State is DORMANT
Administrative State is UP
The Last Interface Down Failure Cause is Administrative Shutdown
Description is I am an FXO LoopStart port
Noise Regeneration is enabled
Non Linear Processing is enabled
Non Linear Mute is disabled
Non Linear Threshold is -21 dB
Music On Hold Threshold is Set to -38 dBm
In Gain is Set to 0 dB
Out Attenuation is Set to 3 dB
Echo Cancellation is enabled
Echo Cancellation NLP mute is disabled
Echo Cancellation NLP threshold is -21 dB
Echo Cancel Coverage is set to 64 ms
Echo Cancel worst case ERL is set to 6 dB
Playout-delay Mode is set to adaptive
Playout-delay Nominal is set to 60 ms
Playout-delay Maximum is set to 250 ms
Playout-delay Minimum mode is set to default, value 40 ms
Playout-delay Fax is set to 300 ms
Connection Mode is normal
Connection Number is not set
Initial Time Out is set to 10 s
Interdigit Time Out is set to 10 s
Call Disconnect Time Out is set to 60 s
Ringing Time Out is set to 180 s
Wait Release Time Out is set to 30 s
Companding Type is u-law
Region Tone is set for US
Analog Info Follows:
Currently processing none
Maintenance Mode Set to None (not in mtc mode)
Number of signaling protocol errors are 0
Impedance is set to 600r Ohm
Station name None, Station number None
Translation profile (Incoming):
Translation profile (Outgoing):
Voice card specific Info Follows:
Signal Type is loopStart
Battery-Reversal is enabled
Number Of Rings is set to 1
Supervisory Disconnect is signal
Answer Supervision is inactive
Hook Status is On Hook
Ring Detect Status is inactive
Ring Ground Status is inactive
Tip Ground Status is inactive
Dial Out Type is dtmf
Digit Duration Timing is set to 100 ms
InterDigit Duration Timing is set to 100 ms
Pulse Rate Timing is set to 10 pulses/second
InterDigit Pulse Duration Timing is set to 750 ms
Percent Break of Pulse is 60 percent
GuardOut timer is 2000 ms
Minimum ring duration timer is 125 ms
Hookflash-in Timing is set to 600 ms
Hookflash-out Timing is set to 400 ms
```

Supervisory Disconnect Timing (loopStart only) is set to 750 ms
OPX Ring Wait Timing is set to 6000 ms

The following is sample output from the **show voice port summary** command. Note that for the connected FXO analog voice port 0/2/0, which has the ADMIN state of "up" and the OPER state of "dorm," this output shows that the IN STATUS is "idle" and the OUT STATUS is "on-hook":

```
Router# show voice port summary
```

PORT	CH	SIG-TYPE	ADMIN	OPER	IN STATUS	OUT STATUS	EC
0/0/0	--	fxs-ls	up	dorm	on-hook	idle	y
0/0/1	--	fxs-ls	up	dorm	on-hook	idle	y
0/3/0:23	01	isdn-voice	up	dorm	none	none	y
0/3/0:23	02	isdn-voice	up	dorm	none	none	y
.
0/1/0	--	did-in-wnk	up	dorm	idle	idle	y
0/1/1	--	did-in-wnk	up	dorm	idle	idle	y
0/2/0	--	fxo-ls	up	dorm	idle	on-hook	y
0/2/1	--	fxo-ls	up	down	idle	off-hook	y
2/0/0	--	fxs-ls	up	dorm	on-hook	idle	y
2/0/1	--	fxs-ls	up	dorm	on-hook	idle	y
2/0/2	--	fxs-ls	up	dorm	on-hook	idle	y
2/0/3	--	fxs-ls	up	dorm	on-hook	idle	y
2/0/4	--	fxs-ls	up	dorm	on-hook	idle	y
2/0/5	--	fxs-ls	up	dorm	on-hook	idle	y
2/0/6	--	fxs-ls	up	dorm	on-hook	idle	y
2/0/7	--	fxs-ls	up	dorm	on-hook	idle	y



Note If the FXO port 0/2/0 is disconnected, the output of the **show voice port summary** command changes so that the OUT STATUS is reported as "off-hook," and the OPER state changes to "down."

The following is sample output from the **show voice port** command for an ISDN voice port:

```
Router# show voice port
ISDN 2/0:23 Slot is 2, Sub-unit is 0, Port is 23
Type of VoicePort is ISDN-VOICE
Operation State is DORMANT
Administrative State is UP
No Interface Down Failure
Description is not set
Noise Regeneration is enabled
Non Linear Processing is enabled
Non Linear Mute is disabled
Non Linear Threshold is -21 dB
Music On Hold Threshold is Set to -38 dBm
In Gain is Set to 0 dB
Out Attenuation is Set to 0 dB
Echo Cancellation is enabled
Echo Cancellation NLP mute is disabled
Echo Cancellation NLP threshold is -21 dB
Echo Cancel Coverage is set to 64 ms
Echo Cancel worst case ERL is set to 6 dB
Playout-delay Mode is set to adaptive
Playout-delay Nominal is set to 60 ms
Playout-delay Maximum is set to 250 ms
Playout-delay Minimum mode is set to default, value 40 ms
```

```

Playout-delay Fax is set to 300 ms
Connection Mode is normal
Connection Number is not set
Initial Time Out is set to 10 s
Interdigit Time Out is set to 10 s
Call Disconnect Time Out is set to 60 s
Ringing Time Out is set to 180 s
Wait Release Time Out is set to 30 s
Companding Type is u-law
Region Tone is set for US
Station name None, Station number None
Translation profile (Incoming):
Translation profile (Outgoing):
Voice class called number pool:
DS0 channel specific status info:

```

PORT	CH	SIG-TYPE	OPER	IN STATUS	OUT STATUS	TIP	RING
2/0:23	01	isdn-voice	up	none	none		
2/0:23	02	isdn-voice	up	none	none		
2/0:23	03	isdn-voice	up	none	none		
2/0:23	04	isdn-voice	up	none	none		
2/0:23	05	isdn-voice	up	none	none		
2/0:23	06	isdn-voice	up	none	none		
2/0:23	07	isdn-voice	dorm	none	none		
2/0:23	08	isdn-voice	dorm	none	none		
2/0:23	09	isdn-voice	dorm	none	none		
2/0:23	10	isdn-voice	dorm	none	none		
2/0:23	11	isdn-voice	dorm	none	none		
2/0:23	12	isdn-voice	dorm	none	none		
2/0:23	13	isdn-voice	dorm	none	none		
2/0:23	14	isdn-voice	dorm	none	none		
2/0:23	15	isdn-voice	dorm	none	none		
2/0:23	16	isdn-voice	dorm	none	none		
2/0:23	17	isdn-voice	dorm	none	none		
2/0:23	18	isdn-voice	dorm	none	none		
2/0:23	19	isdn-voice	dorm	none	none		
2/0:23	20	isdn-voice	dorm	none	none		
2/0:23	21	isdn-voice	dorm	none	none		
2/0:23	22	isdn-voice	dorm	none	none		
2/0:23	23	isdn-voice	dorm	none	none		

The following is sample output from the **show voice port** command for the connected FXO analog voice port 0/2/0, which has the Administrative State of "UP" and the Operation State of "DORMANT":

```

Router# show voice port 0/2/0
Foreign Exchange Office 0/2/0 Slot is 0, Sub-unit is 2, Port is 0
Type of VoicePort is FXO
Operation State is DORMANT
Administrative State is UP
No Interface Down Failure
Description is not set
Noise Regeneration is enabled
Non Linear Processing is enabled
Non Linear Mute is disabled
Non Linear Threshold is -21 dB
Music On Hold Threshold is Set to -38 dBm
In Gain is Set to 0 dB
Out Attenuation is Set to 3 dB
Echo Cancellation is enabled
Echo Cancellation NLP mute is disabled
Echo Cancellation NLP threshold is -21 dB
Echo Cancel Coverage is set to 128 ms
Echo Cancel worst case ERL is set to 6 dB

```

```

Playout-delay Mode is set to adaptive
Playout-delay Nominal is set to 60 ms
Playout-delay Maximum is set to 1000 ms
Playout-delay Minimum mode is set to default, value 40 ms
Playout-delay Fax is set to 300 ms
Connection Mode is normal
Connection Number is not set
Initial Time Out is set to 15 s
Interdigit Time Out is set to 10 s
Call Disconnect Time Out is set to 60 s
Power Denial Disconnect Time Out is set to 1000 ms
Ringing Time Out is set to 180 s
Wait Release Time Out is set to 30 s
Companding Type is u-law
Region Tone is set for US
Analog Info Follows:
Currently processing none
Maintenance Mode Set to None (not in mtc mode)
Number of signaling protocol errors are 0
Impedance is set to 600r Ohm
Station name None, Station number None
Translation profile (Incoming):
Translation profile (Outgoing):
lpcor (Incoming):
lpcor (Outgoing):
Voice card specific Info Follows:
Signal Type is loopStart
Battery-Reversal is enabled
Number Of Rings is set to 1
Supervisory Disconnect is signal
Answer Supervision is inactive
Hook Status is On Hook
Ring Detect Status is inactive
Ring Ground Status is inactive
Tip Ground Status is inactive
Dial Out Type is dtmf
Digit Duration Timing is set to 100 ms
InterDigit Duration Timing is set to 100 ms
Pulse Rate Timing is set to 10 pulses/second
InterDigit Pulse Duration Timing is set to 750 ms
Percent Break of Pulse is 60 percent
GuardOut timer is 2000 ms
Minimum ring duration timer is 125 ms
Hookflash-in Timing is set to 600 ms
Hookflash-out Timing is set to 400 ms
Supervisory Disconnect Timing (loopStart only) is set to 350 ms
OPX Ring Wait Timing is set to 6000 ms
Secondary dialtone is disabled

```



Note If the FXO port 0/2/0 is disconnected, the output of the **show voice port** command changes so that the Administrative State remains "UP" but the Operation State is "DOWN." Beginning in Cisco IOS Release 15.1(3)T, there is improved status monitoring of FXO ports--any time an FXO port is connected or disconnected, a message is displayed to indicate the status change. For example, the following message is displayed to report that a cable has been connected, and the status is changed to "up" for FXO port 0/2/0: 000118: Jul 14 18:06:05.122 EST: %LINK-3-UPDOWN: Interface Foreign Exchange Office 0/2/0, changed state to operational status up due to cable reconnection

The table below describes significant fields shown in these outputs, in alphabetical order.

Table 24: show voice port Field Descriptions

Field	Description
Administrative State	Administrative state of the voice port.
Alias	User-supplied alias for the voice port.
Clear Wait Duration Timing	Time (in milliseconds [ms]) of inactive seizure signal to declare call cleared.
Companding Type	Companding standard used to convert between analog and digital signals in pulse code modulation (PCM) systems.
Connection Mode	Connection mode of the interface.
Connection Number	Full E.164 telephone number used to establish a connection with the trunk or private line automatic ringdown (PLAR) mode.
Currently Processing	Type of call currently being processed: none, voice, or fax.
Delay Duration Timing	Maximum delay signal duration (in ms) for delay dial signaling.
Delay Start Timing	Timing (in ms) of generation of delayed start signal from detection of incoming seizure.
Dial Type	Out-dialing type of the voice port.
Digit Duration Timing	Dual-tone multifrequency (DTMF) digit duration (in ms).
E&M Type	Type of E&M interface.
Echo Cancel Coverage	Echo cancel coverage for this port.
Echo Cancellation	Whether echo cancellation is enabled for this port.
Impedance	Configured terminating impedance for the E&M interface.
In Gain	Amount of gain (in decibels [dB]) inserted at the receiver side of the interface.
In Seizure	Incoming seizure state of the E&M interface.
Initial Time Out	Amount of time (in seconds) the system waits for an initial input digit from the caller.
Interdigit Duration Timing	DTMF interdigit duration (in seconds).
InterDigit Pulse Duration Timing	Pulse dialing interdigit timing (in ms).
Interdigit Time Out	Amount of time (in seconds) the system waits for a subsequent input digit from the caller.
Lpcor (Incoming)	Setting of the lpcor incoming command.
Lpcor (Outgoing)	Setting of the lpcor outgoing command.

Field	Description
Maintenance Mode	Maintenance mode of the voice port.
Music On Hold Threshold	Configured music-on-hold threshold value for this interface.
Noise Regeneration	Whether background noise should be played to fill silent gaps if voice activity detection (VAD) is activated.
Non Linear Processing	Whether nonlinear processing is enabled for this port.
Number of signaling protocol errors	Number of signaling protocol errors.
Operation State	Operational state of the voice port.
Operation Type	Operation type of the E&M signal: 2-wire or 4-wire.
Out Attenuation	Amount of attenuation (in dB) inserted at the transmit side of the interface.
Out Seizure	Outgoing seizure state of the E&M interface.
Port	Port number for the interface associated with the voice interface card.
Pulse Rate Timing	Pulse dialing rate, in pulses per second (pps).
Region Tone	Configured regional tone for this interface.
Ring Active Status	Ring active indication.
Ring Cadence	Configured ring cadence for this interface.
Ring Frequency	Configured ring frequency (in hertz) for this interface.
Ring Ground Status	Ring ground indication.
Ringing Time Out	Ringing timeout duration (in seconds).
Signal Type	Type of signaling for a voice port: delay-dial, ground-start, immediate, loop-start, and wink-start.
Slot	Slot used in the voice interface card for this port.
Sub-unit	Subunit used in the voice interface card for this port.
Tip Ground Status	Tip ground indication.
Type of VoicePort	Type of voice port: FXO, FXS, or E&M.
The Interface Down Failure Cause	Text string describing why the interface is down,
Wait Release Time Out	Length of time (in seconds) that a voice port stays in call-failure state while a busy tone, reorder tone, or out-of-service tone is sent to the port.
Wink Duration Timing	Maximum wink duration (in ms) for wink-start signaling.

Field	Description
Wink Wait Duration Timing	Maximum wink wait duration (in ms) for wink-start signaling.

Related Commands

Command	Description
ds0 group	Specifies the DS0 time slots that make up a logical voice port on a T1 or E1 controller and specifies the signaling type by which the router communicates with the PBX or PSTN.
timing sup-disconnect	Defines the minimum time to ensure that an on-hook indication is intentional and not an electrical transient on the line before a supervisory disconnect occurs (based on power denial signaled by the PSTN or PBX).

show voice sip license

To display SIP trunk license information, use **show voice sip license** command in privileged EXEC mode.

show voice sip license [stats {table}] | status]

Syntax Description	stats	Displays license usage over time.
	table	(Optional) Displays license usage over time in tabular format.
	status	Displays license status.


Command Modes Privileged EXEC (#)

Command History	Release	Modification
	Cisco IOS XE Amsterdam 17.2.1r	This command was introduced.
	Cisco IOS XE Amsterdam 17.3.2 and Cisco IOS XE Bengaluru 17.4.1a	This command was modified to support Cisco Smart Licensing Using Policy.
	Cisco IOS XE Bengaluru 17.6.1a	This command was modified to display licensing information for WebSockets in CUBE.

Usage Guidelines Use **show voice sip license stats** command to display license usage in graphical format. The output includes eight graphs. Four graphs display "CUBE Standard Trunk License Usage" and four graphs display "TDM-SIP Trunk Sessions" details. The following describes how to interpret the graphical data:

- **License usage for the last 60 seconds**—The graph displays the licenses that are used in the last 60 seconds. X-axis represents the time in seconds and Y-axis represents the licenses that are used. # represents the licenses that are used.


For example, in the following graph, 15 licenses were used at the second second.



- **License usage for the last 60 minutes**—The graph displays the licenses that are used in the last 60 minutes. X-axis represents the time in minutes and Y-axis represents the licenses that are used. The


values on the Y-axis vary based on the licenses used. # represents the average licenses used. * represents the maximum licenses used. The maximum licenses that are used over a minute are calculated by taking the average of top three values of licenses that are used over the 60 seconds in that minute.

For example, in the following graph, on the 48th minute, a maximum of 383 licenses were used.



- **License usage for the last 72 hours**—The graph displays the licenses that are used in the last 72 hours. X-axis represents the time in hours and Y-axis represents the licenses that are used. The values on the Y-axis vary based on the licenses used. # represents the average licenses used. * represents the maximum licenses used. The maximum licenses that are used over each hour are the same as the maximum licenses used over the minutes in that hour. While computing license consumption over a period, the maximum value during that period is considered.


For example, in the following graph, during the first hour, a maximum of 900 licenses were used.




- **License usage for the last 72 days**—The graph displays the licenses that are used for the last 72 days. X-axis represents the time in hours and Y-axis represents the licenses that are used. The values on the Y-axis vary based on the licenses used. # represents the average licenses used. * represents the maximum licenses used. The maximum licenses used each day is the same as the maximum licenses used over the

hours in that day. While computing license consumption over a period, the maximum value during that period is considered.

For example, in the following graph, on day 1, a maximum of 950 licenses were used.



The following is a sample TDM-SIP Trunk Sessions graph. # represents the average licenses used. * represents the maximum licenses used. In the below graph, a maximum of 1 TDM-SIP trunk session was used during the first hour.



Use the **table** keyword to display the licenses used over time in tabular format. The output includes the following tables for "CUBE Standard Trunk License Usage" and "TDM-SIP Trunk Sessions":

- License usage for the last 60 seconds
- License usage for the last 60 minutes
- License usage for the last 72 hours
- License usage for the last 72 days


The license usage for WebSockets in CUBE is displayed in graphical format using **show voice sip license stats**. For display of the licensing usage information in tabular format, use **show voice sip license stats table**. License usage is displayed for Enhanced, Standard, and Aggregate call counts for WebSockets. TDM calls are not counted for WebSockets in CUBE.

Examples

The following are sample outputs for **show voice sip license stats** command:

```
cube#show voice sip license stats
```

```
11:01:01 AM Thursday Aug 29 2019 IST
```



```

          0 5 0 5 0 5 0 5 0 5 0 5 0
CUBE Standard Trunk License Usage (last 72 hours)
* = maximum # = average

10
9
8
7
6
5
4
3
2
1
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6.....6.....7..
          0 5 0 5 0 5 0 5 0 5 0 5 0
CUBE Standard Trunk License Usage (last 72 days)
* = maximum # = average

```

```

          11
10
9
8
7
6
5
4
3
2
1
          ##
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6
          0 5 0 5 0 5 0 5 0 5 0 5 0
TDM-SIP Trunk Sessions (last 60 seconds)

```

```

          1
10
9
8
7
6
5
4
3
2
1
          *
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6
          0 5 0 5 0 5 0 5 0 5 0 5 0
TDM-SIP Trunk Sessions (last 60 minutes)
* = maximum # = average

```

show voice sip license

```

11
10
9
8
7
6
5
4
3
2
1 **
0...5...1...1...2...2...3...3...4...4...5...5...6...6...7...
   0  5  0  5  0  5  0  5  0  5  0  5  0  5  0  5  0
TDM-SIP Trunk Sessions (last 72 hours)
* = maximum # = average
    
```

```

10
9
8
7
6
5
4
3
2
1
0...5...1...1...2...2...3...3...4...4...5...5...6...6...7...
   0  5  0  5  0  5  0  5  0  5  0  5  0  5  0
TDM-SIP Trunk Sessions (last 72 days)
* = maximum # = average
    
```

The following are sample outputs for **show voice sip license stats table** command:

```
cube#show voice sip license stats table
```

02:50:16 PM Wednesday Nov 13 2019 UTC

CUBE Standard Trunk License Usage (last 60 seconds)

Period	Average	Max
1-5	0	0
6-10	0	0
11-15	0	0
16-20	0	0
21-25	0	0
26-30	0	0
31-35	0	0
36-40	0	0
41-45	0	0
46-50	0	0
51-55	0	0
56-60	0	0

CUBE Standard Trunk License Usage (last 60 minutes)

Period	Average	Max
--------	---------	-----

```

-----
 1-5          0          0
 6-10         0          0
11-15         0          0
16-20         0          0
21-25         0          0
26-30         0          0
31-35         0          0
36-40         0          0
41-45         0          0
46-50        324        900
51-55        343        899
56-60        292        600
    
```

CUBE Standard Trunk License Usage (last 72 hours)

```

Period      Average      Max
-----
 1-5          35          900
 6-10          0           0
11-15          0           0
16-20          0           0
21-25          0           0
26-30          0           0
31-35          0           0
36-40          0           0
41-45          0           0
46-50          0           0
51-55          0           0
56-60          0           0
61-65          0           0
66-70          0           0
71-72          0           0
    
```

CUBE Standard Trunk License Usage (last 72 days)

```

Period      Average      Max
-----
 1-5          0           0
 6-10          0           0
11-15          0           0
16-20          0           0
21-25          0           0
26-30          0           0
31-35          0           0
36-40          0           0
41-45          0           0
46-50          0           0
51-55          0           0
56-60          0           0
61-65          0           0
66-70          0           0
71-72          0           0
    
```

TDM-SIP Trunk Sessions (last 60 seconds)

```

Period      Average      Max
-----
 1-5          0           0
 6-10          0           0
11-15          0           0
16-20          0           0
21-25          0           0
26-30          0           0
31-35          0           0
    
```

show voice sip license

36-40	0	0
41-45	0	0
46-50	0	0
51-55	0	0
56-60	0	0

TDM-SIP Trunk	Sessions (last 60 minutes)	
Period	Average	Max
1-5	0	2
6-10	0	1
11-15	0	1
16-20	0	1
21-25	0	0
26-30	0	0
31-35	0	0
36-40	0	0
41-45	0	0
46-50	0	0
51-55	0	0
56-60	0	0

TDM-SIP Trunk	Sessions (last 72 hours)	
Period	Average	Max
1-5	0	0
6-10	0	0
11-15	0	0
16-20	0	0
21-25	0	0
26-30	0	0
31-35	0	0
36-40	0	0
41-45	0	0
46-50	0	0
51-55	0	0
56-60	0	0
61-65	0	0
66-70	0	0
71-72	0	0

TDM-SIP Trunk	Sessions (last 72 days)	
Period	Average	Max
1-5	0	0
6-10	0	0
11-15	0	0
16-20	0	0
21-25	0	0
26-30	0	0
31-35	0	0
36-40	0	0
41-45	0	0
46-50	0	0
51-55	0	0
56-60	0	0
61-65	0	0
66-70	0	0
71-72	0	0

The following example shows output of **show voice sip license status** command when SIP service is enabled:

```
cube#show voice sip license status
```

```
Host Name: cube
Current Time: Nov 25 2019 14:46:41 IST
SIP service: Up
License request interval: 5 Minute(s)
Next request at: Nov 25 2019 14:50:44 IST
Recent request(s) for CUBE Standard Trunk
```

Timestamp	Count	Result
Nov 25 2019 14:45:44 IST	10	Out of compliance
Nov 25 2019 14:40:44 IST	4	Authorized
Nov 25 2019 14:35:44 IST	2	Authorized

After the entitlement request is sent and before receiving the response, the "Result" column in the output shows the same value as that of the previous and appends it with "(Response Pending)". For example, in the following output, the response is awaited for the entitlement request that is sent at "Dec 5 2019 16:17:46 IST". Hence, the "Result" column shows "Authorized(Response Pending)". If the entitlement request is sent for the first time, then the "Result" is shown as "Unknown(Response Pending)".

```
cube#show voice sip license status
```

```
Host Name: cube
Current Time: Dec 5 2019 16:18:22 IST
SIP service: Up
License request interval: 1 Minute(s)
Next request at: Dec 5 2019 16:18:46 IST
Recent request(s) for CUBE Standard Trunk
```

Timestamp	Count	Result
Dec 5 2019 16:17:46 IST	2	Authorized(Response Pending)
Dec 5 2019 15:59:46 IST	0	Authorized
Dec 5 2019 15:58:46 IST	1	Authorized

After receiving the response, the output is updated accordingly. Considering the above example, the result for the entitlement request that is sent at "Dec 5 2019 16:17:46 IST" will be updated as "Authorized" as shown below.

```
cube#show voice sip license status
```

```
Host Name: cube
Current Time: Dec 5 2019 16:18:32 IST
SIP service: Up
License request interval: 1 Minute(s)
Next request at: Dec 5 2019 16:18:46 IST
Recent request(s) for CUBE Standard Trunk
```

Timestamp	Count	Result
Dec 5 2019 16:17:46 IST	2	Authorized
Dec 5 2019 15:59:46 IST	0	Authorized
Dec 5 2019 15:58:46 IST	1	Authorized

The entitlement request is sent only when there is a change in the license request count. For example, in the following output, license request interval is 5 minutes and a request was sent for a count of 3 at Nov 21 2019 14:29:50 IST. There was no change in the license usage during the 5-minute interval and therefore a request is not sent at Nov 21 2019 14:34:50 IST. The license usage got changed in the next 5-minute interval and therefore a request was sent at Nov 21 2019 14:39:50 IST.

```
cube#show voice sip license status
```

```
Host Name: cube
Current Time: Nov 22 2019 04:02:53 IST
SIP service: Up
License request interval: 5 Minute(s)
Next request at: Nov 22 2019 04:04:50 IST
Recent request(s) for CUBE Standard Trunk
```

```
-----
Time                Count      Result
-----
Nov 21 2019 14:39:50 IST    0      Authorized
Nov 21 2019 14:29:50 IST    3      Authorized
```

The following example shows output of the **show voice sip license status** command when the evaluation period has expired and the SIP service is blocked. Although the SIP service is blocked, information about previous requests sent (when the SIP service was up) is available in the output. In the following example, a licenses request was sent for a count of 15 at Nov 26 2019 04:59:53 IST when the SIP service was up. After that, the SIP service was blocked due to expiry of evaluation period.

```
cube#show voice sip license status
```

```
Host Name: cube
Current Time: Nov 26 2019 05:03:08 IST
SIP service: blocked due to eval expiry
License request interval: 5 Minute(s)
Next request at: Nov 26 2019 05:04:53 IST
Recent request(s) for CUBE Standard Trunk
```

```
-----
Timestamp           Count      Result
-----
Nov 26 2019 04:59:53 IST    15      Eval period
```

License Usage for WebSocket-based Forking in CUBE

The following is a sample output for license usage in tabular and graphical format for Standard CUBE trunk calls:

```
Router#show voice sip license stats table
CUBE Standard Trunk License Usage (last 60 seconds)
```

```
Period      Average      Max
-----
1-5         1            1
6-10        0            0
11-15       0            0
16-20       0            0
21-25       0            0
26-30       0            0
31-35       0            0
36-40       0            0
41-45       0            0
46-50       0            0
51-55       0            0
56-60       0            0
```

```
CUBE Standard Trunk License Usage (last 60 minutes)
```

```
Period      Average      Max
-----
```

1-5	0	0
6-10	0	0
11-15	0	0
16-20	0	0
21-25	0	0
26-30	0	0
31-35	0	0
36-40	0	0
41-45	0	0
46-50	0	0
51-55	0	0
56-60	0	0

CUBE Standard Trunk License Usage (last 72 hours)

Period	Average	Max
1-5	0	0
6-10	0	0
11-15	0	0
16-20	2	99
21-25	0	40
26-30	0	0
31-35	0	0
36-40	0	0
41-45	0	43
46-50	0	0
51-55	0	0
56-60	0	0
61-65	0	0
66-70	0	0
71-72	0	0

CUBE Standard Trunk License Usage (last 72 days)

Period	Average	Max
1-5	0	99
6-10	0	0
11-15	0	0
16-20	0	0
21-25	0	0
26-30	0	0
31-35	0	0
36-40	0	0
41-45	0	0
46-50	0	0
51-55	0	0
56-60	0	0
61-65	0	0
66-70	0	0
71-72	0	0

Router#show voice sip license stats

```

111111111111
10
9
8
7
6

```

show voice sip license

```

5
4
3
2
1 #####
0...5...1...1...2...2...3...3...4...4...5...5...6
   0  5  0  5  0  5  0  5  0  5  0  5  0
CUBE Standard Trunk License Usage (last 60 seconds)
    
```

```

10
9
8
7
6
5
4
3
2
1
0...5...1...1...2...2...3...3...4...4...5...5...6
   0  5  0  5  0  5  0  5  0  5  0  5  0
CUBE Standard Trunk License Usage (last 60 minutes)
* = maximum # = average
    
```

```

          9 99 4 2          4
          9 99 0 1          3
100      * **
90       * **
80       * **
70       * **
60       * **
50       * **
40       * ** *          *
30       * ** *          *
20       * ** * *          *
10       * *# * *          *
0...5...1...1...2...2...3...3...4...4...5...5...6...6...7...
   0  5  0  5  0  5  0  5  0  5  0  5  0  5  0
CUBE Standard Trunk License Usage (last 72 hours)
* = maximum # = average
    
```

```

9
9
100
99 *
98 *
97 *
96 *
95 *
94 *
93 *
92 *
    
```

```

91 *
90 *
 0...5...1...1...2...2...3...3...4...4...5...5...6...6...7..
   0   5   0   5   0   5   0   5   0   5   0   5   0
CUBE Standard Trunk License Usage (last 72 days)
* = maximum # = average
    
```

The following is a sample output for license usage in tabular and graphical format for Enhanced CUBE calls:

```

Router#show voice sip license stats table
CUBE Enhanced Trunk License Usage (last 60 seconds)
    
```

Period	Average	Max
1-5	0	0
6-10	0	0
11-15	0	0
16-20	0	0
21-25	0	0
26-30	0	0
31-35	0	0
36-40	0	0
41-45	0	0
46-50	0	0
51-55	0	0
56-60	0	0

```

CUBE Enhanced Trunk License Usage (last 60 minutes)
    
```

Period	Average	Max
1-5	0	0
6-10	0	0
11-15	0	0
16-20	0	0
21-25	0	0
26-30	0	0
31-35	0	0
36-40	0	0
41-45	0	0
46-50	0	0
51-55	0	0
56-60	0	0

```

CUBE Enhanced Trunk License Usage (last 72 hours)
    
```

Period	Average	Max
1-5	0	0
6-10	0	0
11-15	0	0
16-20	0	50
21-25	0	20
26-30	0	0
31-35	0	0
36-40	0	0
41-45	0	41
46-50	0	0
51-55	0	0
56-60	0	0
61-65	0	0



show voice sip license



```
66-70      0      0
71-72      0      0
```

CUBE Enhanced Trunk License Usage (last 72 days)

Period	Average	Max
1-5	0	41
6-10	0	0
11-15	0	0
16-20	0	0
21-25	0	0
26-30	0	0
31-35	0	0
36-40	0	0
41-45	0	0
46-50	0	0
51-55	0	0
56-60	0	0
61-65	0	0
66-70	0	0
71-72	0	0

Router#show voice sip license stats





The following is a sample output for license usage in tabular and graphical format for Aggregate trunk CUBE calls:

```

Router#show voice sip license stats table
CUBE Aggregate Trunk License Usage (last 60 seconds)
Period      Average      Max
-----
1-5         0             0
6-10        0             0
11-15       0             0
16-20       0             0
21-25       0             0
26-30       0             0
31-35       0             0
36-40       0             0
41-45       0             0
46-50       0             0
51-55       0             0
56-60       0             0
    
```

CUBE Aggregate Trunk License Usage (last 60 minutes)

show voice sip license

Period	Average	Max
1-5	0	0
6-10	0	0
11-15	0	0
16-20	0	0
21-25	0	0
26-30	0	0
31-35	0	0
36-40	0	0
41-45	0	0
46-50	0	0
51-55	0	0
56-60	0	0

CUBE Aggregate Trunk License Usage (last 72 hours)

Period	Average	Max
1-5	0	0
6-10	0	0
11-15	0	0
16-20	0	50
21-25	0	20
26-30	0	0
31-35	0	0
36-40	0	0
41-45	0	41
46-50	0	0
51-55	0	0
56-60	0	0
61-65	0	0
66-70	0	0
71-72	0	0

CUBE Aggregate Trunk License Usage (last 72 days)

Period	Average	Max
1-5	0	41
6-10	0	0
11-15	0	0
16-20	0	0
21-25	0	0
26-30	0	0
31-35	0	0
36-40	0	0
41-45	0	0
46-50	0	0
51-55	0	0
56-60	0	0
61-65	0	0
66-70	0	0
71-72	0	0

Router#show voice sip license stats

```

11111111111111111111
10

```

```

9
8
7
6
5
4
3
2
1 #####
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6
   0      5      0      5      0      5      0      5      0      5      0      5      0
CUBE Aggregate Trunk License Usage (last 60 seconds)

```

```

10
9
8
7
6
5
4
3
2
1
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6
   0      5      0      5      0      5      0      5      0      5      0      5      0
CUBE Aggregate Trunk License Usage (last 60 minutes)
* = maximum # = average

```

```

          9 99 422          8
          9 99 001          0
100      * * *
90       * * *
80       * * *          *
70       * * *          *
60       * * *          *
50       * * *          *
40       * * * *        *
30       * * * *        *
20       * * * * *      *
10       * * # * * *    *
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6.....6.....7..
   0      5      0      5      0      5      0      5      0      5      0      5      0
CUBE Aggregate Trunk License Usage (last 72 hours)
* = maximum # = average

```

```

9
9
100
99 *
98 *
97 *
96 *

```

```

95 *
94 *
93 *
92 *
91 *
90 *
 0....5....1....1....2....2....3....3....4....4....5....5....6....6....7...
   0   5   0   5   0   5   0   5   0   5   0   5   0   5   0
CUBE Aggregate Trunk License Usage (last 72 days)
* = maximum # = average

```

The license usage reporting for WebSockets in CUBE includes the summary of last 10 usage reports. The following is a sample output of **show voice sip license** for a CUBE router in B2BHA mode:

```

Router#show voice sip license status
Host Name: Router
Current Time: Apr 30 2021 07:37:12 UTC
SIP service: Up
License use recorded every: 7 Day(s)
Next record at: May 7 2021 07:00:00 UTC
Recent use of license(s) for CUBE Enhanced Trunk
-----
Timestamp                Count
-----
Apr 30 2021 07:00:00 UTC   10
Apr 30 2021 05:55:11 UTC    1
Apr 30 2021 05:54:52 UTC    1
Router#sh log | sec LICENSE_INFO
*Apr 30 07:00:00.751: %CUBE-5-LICENSE_INFO: Requesting for 0 CUBE Enhanced trunk licenses
Router#sh voice sip license stats




Router  07:37:47 AM Friday Apr 30 2021 UTC

```

```

10
 9
 8
 7
 6
 5
 4
 3
 2
 1
 0....5....1....1....2....2....3....3....4....4....5....5....6
   0   5   0   5   0   5   0   5   0   5   0   5   0
CUBE Standard Trunk License Usage (last 60 seconds)

```



Router 07:37:50 AM Friday Apr 30 2021 UTC

show voice sip license

```

10
9
8
7
6
5
4
3
2
1
0....5....1....1....2....2....3....3....4....4....5....5....6
      0   5   0   5   0   5   0   5   0   5   0   5   0
CUBE Enhanced Trunk License Usage (last 60 seconds)

```

```

10
9
8
7
6
5
4
3
2
1
0....5....1....1....2....2....3....3....4....4....5....5....6
      0   5   0   5   0   5   0   5   0   5   0   5   0
CUBE Enhanced Trunk License Usage (last 60 minutes)
* = maximum # = average

```

```

1
0
20
19
18
17
16
15
14
13
12
11
10 *
0....5....1....1....2....2....3....3....4....4....5....5....6....6....7...
      0   5   0   5   0   5   0   5   0   5   0   5   0
CUBE Enhanced Trunk License Usage (last 72 hours)
* = maximum # = average

```

```

10
9
8

```

```

7
6
5
4
3
2
1
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6.....6.....7..
      0      5      0      5      0      5      0      5      0      5      0      5      0
CUBE Enhanced Trunk License Usage (last 72 days)
* = maximum # = average

```

Router 07:37:54 AM Friday Apr 30 2021 UTC

```

10
9
8
7
6
5
4
3
2
1
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6
      0      5      0      5      0      5      0      5      0      5      0      5      0
CUBE Aggregate Trunk License Usage (last 60 seconds)

```

```

10
9
8
7
6
5
4
3
2
1
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6
      0      5      0      5      0      5      0      5      0      5      0      5      0
CUBE Aggregate Trunk License Usage (last 60 minutes)
* = maximum # = average

```

```

1
0
20
19
18

```

show voice sip license

```

17
16
15
14
13
12
11
10 *
0....5....1....1....2....2....3....3....4....4....5....5....6....6....7..
   0   5   0   5   0   5   0   5   0   5   0   5   0   5   0
CUBE Aggregate Trunk License Usage (last 72 hours)
* = maximum # = average

```

```

10
9
8
7
6
5
4
3
2
1
0....5....1....1....2....2....3....3....4....4....5....5....6....6....7..
   0   5   0   5   0   5   0   5   0   5   0   5   0   5   0
CUBE Aggregate Trunk License Usage (last 72 days)
* = maximum # = average

```

Router 07:37:56 AM Friday Apr 30 2021 UTC

```

10
9
8
7
6
5
4
3
2
1
0....5....1....1....2....2....3....3....4....4....5....5....6
   0   5   0   5   0   5   0   5   0   5   0   5   0
TDM-SIP Trunk Sessions (last 60 seconds)

```

```

10
9

```

```

8
7
6
5
4
3
2
1
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6
   0      5      0      5      0      5      0      5      0      5      0      5      0
TDM-SIP Trunk Sessions (last 60 minutes)
* = maximum # = average

```

```

10
9
8
7
6
5
4
3
2
1
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6.....6.....7..
   0      5      0      5      0      5      0      5      0      5      0      5      0      5
TDM-SIP Trunk Sessions (last 72 hours)
* = maximum # = average

```

```

10
9
8
7
6
5
4
3
2
1
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6.....6.....7..
   0      5      0      5      0      5      0      5      0      5      0      5      0      5
TDM-SIP Trunk Sessions (last 72 days)
* = maximum # = average

```

```

=====
STANDBY:

```

```

Router#sh voice sip license status
Host Name: Router
Current Time: Apr 30 2021 07:37:26 UTC
SIP service: Up
License use recorded every: 7 Day(s)
Next record at: Timer not started
Recent use of license(s) for CUBE Enhanced Trunk

```



show voice sip license

```

-----
Timestamp                Count
-----
Apr 30 2021 05:55:11 UTC    1
Router#sh log | sec LICENSE_INFO
Router#
Router#
Router#sh voice sip license stats

Router  07:38:52 AM Friday Apr 30 2021 UTC

```



10
9
8
7
6
5
4
3

```

2
1
0...5...1...1...2...2...3...3...4...4...5...5...6...6...7..
   0   5   0   5   0   5   0   5   0   5   0   5   0   5   0
CUBE Standard Trunk License Usage (last 72 hours)
* = maximum # = average

```

```

10
9
8
7
6
5
4
3
2
1
0...5...1...1...2...2...3...3...4...4...5...5...6...6...7..
   0   5   0   5   0   5   0   5   0   5   0   5   0   5   0
CUBE Standard Trunk License Usage (last 72 days)
* = maximum # = average

```

Router 07:38:52 AM Friday Apr 30 2021 UTC

```

10
9
8
7
6
5
4
3
2
1
0...5...1...1...2...2...3...3...4...4...5...5...6
   0   5   0   5   0   5   0   5   0   5   0   5   0
CUBE Enhanced Trunk License Usage (last 60 seconds)

```

```

10
9
8
7
6
5
4
3

```

show voice sip license

```

2
1
0...5...1...1...2...2...3...3...4...4...5...5...6
   0  5  0  5  0  5  0  5  0  5  0  5  0
CUBE Enhanced Trunk License Usage (last 60 minutes)
* = maximum # = average
    
```

```

1
0
20
19
18
17
16
15
14
13
12
11
10 *
0...5...1...1...2...2...3...3...4...4...5...5...6...6...7..
   0  5  0  5  0  5  0  5  0  5  0  5  0  5  0
CUBE Enhanced Trunk License Usage (last 72 hours)
* = maximum # = average\
    
```




```

10
9
8
7
6
5
4
3
2
1
0...5...1...1...2...2...3...3...4...4...5...5...6...6...7..
   0  5  0  5  0  5  0  5  0  5  0  5  0  5  0
CUBE Enhanced Trunk License Usage (last 72 days)
* = maximum # = average
    
```

Router 07:38:57 AM Friday Apr 30 2021 UTC

```

10
9
8
7
6
5
4
    
```



10
9
8
7
6
5
4
3
2
1

show voice sip license

```

0....5....1....1....2....2....3....3....4....4....5....5....6....6....7...
   0   5   0   5   0   5   0   5   0   5   0   5   0   5   0
CUBE Aggregate Trunk License Usage (last 72 days)
* = maximum # = average

```

Router 07:38:58 AM Friday Apr 30 2021 UTC

```

10
 9
 8
 7
 6
 5
 4
 3
 2
 1
0....5....1....1....2....2....3....3....4....4....5....5....6
   0   5   0   5   0   5   0   5   0   5   0   5   0
TDM-SIP Trunk Sessions (last 60 seconds)

```

```

10
 9
 8
 7
 6
 5
 4
 3
 2
 1
0....5....1....1....2....2....3....3....4....4....5....5....6
   0   5   0   5   0   5   0   5   0   5   0   5   0
TDM-SIP Trunk Sessions (last 60 minutes)
* = maximum # = average

```

```

10
 9
 8
 7
 6
 5
 4
 3
 2
 1

```

```

0...5...1...1...2...2...3...3...4...4...5...5...6...6...7..
  0  5  0  5  0  5  0  5  0  5  0  5  0  5  0
TDM-SIP Trunk Sessions (last 72 hours)
* = maximum # = average

10
9
8
7
6
5
4
3
2
1
0...5...1...1...2...2...3...3...4...4...5...5...6...6...7..
  0  5  0  5  0  5  0  5  0  5  0  5  0  5  0
TDM-SIP Trunk Sessions (last 72 days)
* = maximum # = average

```

The license usage reporting for WebSockets in CUBE includes the summary of last 10 usage reports. The following is a sample output of **show voice sip license** for a CUBE router in Standalone mode:

```

Router#show voice sip license status
Host Name: Router
Current Time: Mar 30 2021 00:32:35 UTC
SIP service: Up
License use recorded every: 8 Hour(s)
Next record at: Mar 30 2021 07:00:00 UTC
Recent use of license(s) for CUBE Standard Trunk
-----
Timestamp                Count
-----
Mar 29 2021 23:00:00 UTC    0
Mar 29 2021 22:00:00 UTC    9
Mar 29 2021 21:00:00 UTC   24
Mar 29 2021 20:00:00 UTC   13
Mar 29 2021 11:00:00 UTC    0
Mar 29 2021 09:00:00 UTC    2
Recent use of license(s) for CUBE Enhanced Trunk
-----
Timestamp                Count
-----
Mar 29 2021 21:00:00 UTC    0
Mar 29 2021 20:00:00 UTC    2
Mar 29 2021 11:00:00 UTC    0
Mar 29 2021 09:00:00 UTC    8




=====

Router#sh voice sip license stats

Router  12:34:22 AM Tuesday Mar 30 2021 UTC

```

show voice sip license



10
9
8

```

7
6
5
4
3
2
1
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6.....6.....7..
   0    5    0    5    0    5    0    5    0    5    0    5    0    5    0
CUBE Standard Trunk License Usage (last 72 days)
* = maximum # = average

```

Router 12:34:23 AM Tuesday Mar 30 2021 UTC

```

10
9
8
7
6
5
4
3
2
1
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6
   0    5    0    5    0    5    0    5    0    5    0    5    0
CUBE Enhanced Trunk License Usage (last 60 seconds)

```

```

10
9
8
7
6
5
4
3
2
1
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6
   0    5    0    5    0    5    0    5    0    5    0    5    0
CUBE Enhanced Trunk License Usage (last 60 minutes)
* = maximum # = average

```

```

10      2      8
9
8      *
```

show voice sip license

```

7          *
6          *
5          *
4          *
3          *
2    *     *
1    *     *
0...5...1...1...2...2...3...3...4...4...5...5...6...6...7..
   0  5  0  5  0  5  0  5  0  5  0  5  0  5  0  5  0
CUBE Enhanced Trunk License Usage (last 72 hours)
* = maximum # = average

```

```

10
9
8
7
6
5
4
3
2
1
0...5...1...1...2...2...3...3...4...4...5...5...6...6...7..
   0  5  0  5  0  5  0  5  0  5  0  5  0  5  0  5  0
CUBE Enhanced Trunk License Usage (last 72 days)
* = maximum # = average

```

Router 12:34:25 AM Tuesday Mar 30 2021 UTC

```

10
9
8
7
6
5
4
3
2
1
0...5...1...1...2...2...3...3...4...4...5...5...6
   0  5  0  5  0  5  0  5  0  5  0  5  0
CUBE Aggregate Trunk License Usage (last 60 seconds)

```

```

10
9
8

```

```

7
6
5
4
3
2
1
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6
      0      5      0      5      0      5      0      5      0      5      0      5      0
CUBE Aggregate Trunk License Usage (last 60 minutes)
* = maximum # = average\

      21      1
945      0

100
90
80
70
60
50
40
30
20
10
**
***      *
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6.....6.....7..
      0      5      0      5      0      5      0      5      0      5      0      5      0
CUBE Aggregate Trunk License Usage (last 72 hours)
* = maximum # = average

10
9
8
7
6
5
4
3
2
1
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6.....6.....7..
      0      5      0      5      0      5      0      5      0      5      0      5      0
CUBE Aggregate Trunk License Usage (last 72 days)
* = maximum # = average

```

Router 12:34:25 AM Tuesday Mar 30 2021 UTC

```

10
9
8

```

show voice sip license

```

7
6
5
4
3
2
1
0...5...1...1...2...2...3...3...4...4...5...5...6
   0  5  0  5  0  5  0  5  0  5  0  5  0
TDM-SIP Trunk Sessions (last 60 seconds)

```

```

10
9
8
7
6
5
4
3
2
1
0...5...1...1...2...2...3...3...4...4...5...5...6
   0  5  0  5  0  5  0  5  0  5  0  5  0
TDM-SIP Trunk Sessions (last 60 minutes)
* = maximum # = average

```

```

10
9
8
7
6
5
4
3
2
1
0...5...1...1...2...2...3...3...4...4...5...5...6...6...7...
   0  5  0  5  0  5  0  5  0  5  0  5  0  5  0
TDM-SIP Trunk Sessions (last 72 hours)
* = maximum # = average

```

```

10
9
8
7
6
5
4

```

```
3
2
1
0.....5.....1.....1.....2.....2.....3.....3.....4.....4.....5.....5.....6.....6.....7..
   0      5      0      5      0      5      0      5      0      5      0      5      0      5      0
TDM-SIP Trunk Sessions (last 72 days)
* = maximum # = average
```

show voice source-group

To display the details of one or more voice source IP groups, use the **show voice source-group** command in privileged EXEC mode.

show voice source-group [*name* | **sort** [**ascending** | **descending**]]

Syntax Description		
	<i>name</i>	(Optional) Name of the source IP group to display.
	sort [ascending descending]	(Optional) Displays the source IP groups in either ascending or descending alphanumerical order.

Command Default Ascending order

Command Modes Privileged EXEC (#)

Command History	Release	Modification
	12.2(11)T	This command was introduced.

Examples

The following sample output shows an invalid configuration.

```
Router# show voice source-group abc
Source Group: abc
  description="",
  carrier-id source="sj_area",
  carrier-id target="",
  trunk-group-label source="",
  trunk-group-label target="ny_main",
  h323zone-id="",
  access-list=,
  disconnect-cause="no-service",
  translation-profile="",
```

The following sample output shows a valid configuration for carrier-ID routing:

```
Router# show voice source-group abc
Source Group: abc
  description="",
  carrier-id source="",
  carrier-id target="",
  trunk-group-label source="texas_backup",
  trunk-group-label target="ny_main",
  h323zone-id="",
  access-list=,
  disconnect-cause="no-service",
  translation-profile="",
```

If you are using carrier-ID routing, both carrier-ID fields are filled in and the "trunk-group-label" fields are blank.

The following sample output displays the source groups in ascending order. Both source IP groups use carrier-ID routing.

```
Router# show voice source-group sort ascending
Source Group:1
  description="routec calls from 1311 to 1411",
  carrier-id source="1311",
  carrier-id target="1411",
  trunk-group-label source="",
  trunk-group-label target="",
  h323zone-id="fr1311",
  access-list= ,
  disconnect-cause="user-busy",
  destination-pattern="",
  incoming called-number="",
  translation-profile="10",
Source Group:2
  description="",
  carrier-id source="abcd",
  carrier-id target="xyz",
  trunk-group-label source="",
  trunk-group-label target="",
  h323zone-id="",
  access-list= ,
  disconnect-cause="no-service",
  destination-pattern="",
  incoming called-number="",
  translation-profile="",
```

The table below describes significant fields shown in this output.

Table 25: show voice source-group Field Descriptions

Field	Description
Source Group	Name of the voice source IP group.
description	Description of the voice source IP group.
carrier-id source	Name of the source carrier ID used by the terminating gateway to select a target carrier.
carrier-id target	Name of the target carrier ID used by the terminating gateway to select a dial peer for routing the call over a POTS line.
trunk-group-label source	Name of the source trunk group used by the originating gateway to route the call over an inbound dial peer.
trunk-group-label target	Name of the target trunk group used by the terminating gateway to select a dial peer for routing an outbound call over a POTS line.
h323zone-id	Name of the zone associated with incoming H.323 calls to the voice source IP group.
access-list	Number of the access list used by the voice source IP group to block calls.
disconnect-cause	Phrase returned by the voice source IP group when a call is blocked.

Field	Description
translation-profile	Name of the translation profile used by the voice source IP group to translate calls.

Related Commands

Command	Description
voice source-group	Initiates a voice source IP group definition.

show voice statistics csr interval accounting

To display accounting statistics by configured intervals, use the **show voice statistics csr interval accounting** command in privileged EXEC mode.

```
show voice statistics csr interval tag-number accounting {all | method-list method-list-name}
[push {all | ftp | syslog}]
```

Syntax Description	tag-number	Interval that represents a specified time range. The valid range is from 1 to 36655. Note You must first enter the show voice statistics interval-tag command to obtain the valid tag numbers that you can enter for this command.
	all	Displays all voice accounting statistics.
	method-list-name <i>method-list-name</i>	Displays accounting statistics by method list. You must specify a method-list name.
	push	(Optional) Statistics are downloaded to an FTP or syslog server, or to both servers. The keywords are as follows: <ul style="list-style-type: none"> • all--Pushes statistics to both the FTP and syslog servers. • ftp--Pushes statistics to the FTP server. • syslog--Pushes statistics to the syslog server.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.3(4)T	This command was introduced.

Examples

The following sample output shows all of the statistics that were collected for interval tag 102 for method list h323-1:

```
Router# show voice statistics csr interval 102 accounting method-list h323-1
Client Type: Voice ACCT Stats
      Start Time: 2002-05-01T19:35:17Z          End Time: 2002-05-01T19:36:29Z
methodlist=h323-1,acc_pass_criteria=1,pstn_in_pass=0,pstn_in_fail=0,pstn_out_pass=0,
pstn_out_fail=0,ip_in_pass=0,ip_in_fail=0,ip_out_pass=0,ip_out_fail=0
```

The table below lists and describes the significant output fields.

Table 26: show voice statistics csr interval accounting Field Descriptions

Field	Description
Client Type	The type of statistics collected.

Field	Description
Start Time	The start time of the statistics collection.
End Time	The ending time of the statistics collection.
method-list	The method list name.
acc_pass_criteria	Accounting pass criteria: <ul style="list-style-type: none"> • 1: all start/interim/stop messages passed. • 2: all start/stop messages passed. • 3: stop-only message passed.
pstn_in_pass	Number of incoming calls on the PSTN leg that meet acc_pass_criteria.
pstn_in_fail	Number of incoming calls on the PSTN leg that fail acc_pass_criteria.
pstn_out_pass	Number of outgoing calls on the PSTN leg that meet acc_pass_criteria.
pstn_out_fail	Number of outgoing calls on the PSTN leg that fail acc_pass_criteria.
ip_in_pass	Number of incoming calls on the IP leg that meet acc_pass_criteria.
ip_in_fail	Number of incoming calls on the IP leg that fail acc_pass_criteria.
ip_out_pass	Number of outgoing calls on the IP leg that meet acc_pass_criteria.
ip_out_fail	Number of outgoing calls on the IP leg that fail acc_pass_criteria.

Related Commands

Command	Description
show event-manager consumers	Displays event-manager statistics.
show voice statistics csr interval aggregation	Displays statistical information by configured intervals for signaling statistics.
show voice statistics csr since-reset accounting	Displays all accounting CSRs since the last reset.
show voice statistics csr since-reset aggregation-level	Displays all signaling CSRs since the last reset.
show voice statistics csr since-reset all	Displays all CSRs since the last reset.
show voice statistics interval-tag	Displays the configured interval numbers.
show voice statistics memory-usage	Displays current memory usage.

show voice statistics csr interval aggregation

To display signaling statistics by configured intervals, use the **show voice statistics** csr interval aggregation command in privileged EXEC mode.

```
show voice statistics csr interval tag-number aggregation {all | gateway | ip | pstn | trunk-group
{trunk-group-label | all} | voice-port {voice-port-label | all}} [mode {concise | verbose}] [push {all
| ftp | syslog}]
```

Syntax Description

tag-number	Interval that represents a specified time range. The valid range is from 1 to 36655. Note You must first enter the show voice statistics interval-tag command to obtain the valid tag numbers that you can enter for this command.
all	Displays all levels of signaling statistics.
gateway	Displays gateway-wide level statistics.
ip	Displays VoIP interface level statistics.
pstn	Displays telephone interface level statistics.
trunk-group	Displays trunk-group level statistics. <ul style="list-style-type: none"> • <i>trunk-group-label</i> --displays statistics for a specific trunk group • all --Displays statistics for all trunk groups.
voice-port	Displays voice-port level statistics: <ul style="list-style-type: none"> • <i>voice-port-label</i> --displays statistics for a specific voice port • all --Displays statistics for all voice ports.
mode	(Optional) Statistics are displayed in a specified mode. The keywords are as follows: <ul style="list-style-type: none"> • concise--Displays output that contains total calls, answered calls, and answered call duration. • verbose--Displays all fields contained in call statistic records (CSRs). This is the default setting.
push	(Optional) Statistics are downloaded to an FTP or syslog server, or to both servers. The keywords are as follows: <ul style="list-style-type: none"> • all--Pushes statistics to both the FTP and syslog servers. • ftp--Pushes statistics to the FTP server. • syslog--Pushes statistics to the syslog server.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.3(4)T	This command was introduced.

Usage Guidelines

This command is valid only if the **voice statistics time-range** command is configured to either the **periodic** or **start-stop** value. If you enter the **show voice statistics csr interval aggregation** command but the gateway has been configured to collect statistics only since the last reset, the gateway displays an error message.

You must first enter the **show voice statistics interval-tag** to obtain the valid tag numbers that you can enter for this command.

Examples

The following sample output shows signaling statistics for all aggregation levels for interval tag 200:

```
Router# show voice statistics csr interval 200 aggregation all
Client Type: VCSR
      Start Time: 2002-04-28T01:48:24Z      End Time: 2002-04-28T01:50:01Z
record_type=gw,trunk_group_id=,voice_port_id=,in_call=0,in_ans=0,in_fail=0,out_call=0,
out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,orig_disconn=0,
in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,in_setup_delay=0,
out_setup_delay=0,lost_pkt=0,latency=0,jitter=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=ip,trunk_group_id=,voice_port_id=,in_call=0,in_ans=0,in_fail=0,out_call=0,
out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,orig_disconn=0,
in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,in_setup_delay=0,
out_setup_delay=0,lost_pkt=0,latency=0,jitter=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=pstn,trunk_group_id=,voice_port_id=,in_call=0,in_ans=0,in_fail=0,out_call=0,
out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,orig_disconn=0,
in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,in_setup_delay=0,
out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=vp,trunk_group_id=,voice_port_id=4/0/0,in_call=0,in_ans=0,in_fail=0,
out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,
orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=vp,trunk_group_id=,voice_port_id=4/0/1,in_call=0,in_ans=0,in_fail=0,
out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,
orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=vp,trunk_group_id=,voice_port_id=4/1/0,in_call=0,in_ans=0,in_fail=0,
out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,
orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=vp,trunk_group_id=,voice_port_id=4/1/1,in_call=0,in_ans=0,in_fail=0,
out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,
orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=vp,trunk_group_id=,voice_port_id=2/0:23,in_call=0,in_ans=0,in_fail=0,
out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,
orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
```

```
record_type=vp, trunk_group_id=, voice_port_id=2/1:23, in_call=0, in_ans=0, in_fail=0
out_call=0, out_ans=0, out_fail=0, in_szre_d=0, out_szre_d=0, in_conn_d=0, out_conn_d=0,
orig_disconn=0, in_ans_abnorm=0, out_ans_abnorm=0, in_mcd=0, out_mcd=0, in_pdd=0, out_pdd=0,
in_setup_delay=0, out_setup_delay=0, in_disc_cc_16=0, out_disc_cc_16=0
```

The table below lists and describes the significant output fields.

Table 27: show voice statistics csr interval aggregation Field Descriptions

Field	Description
Client Type	The type of statistics collected.
Start Time	The start time of the statistics collection.
End Time	The ending time of the statistics collection.
record_type	Call statistics record type. Symbols are gw, ip, pstn, tg, and vp.
trunk_group_id	Trunk group ID. Note For the symbols gw, ip, pstn, and some vp records, this field is empty.
voice_port_id	Voice port ID. Note For the symbols gw, ip, pstn, and some vp records, this field is empty.
in_call	Number of incoming calls.
in_ans	Number of incoming calls answered by the gateway.
in_fail	Number of incoming calls that failed.
out_call	Number of outgoing calls attempted.
out_ans	Number of outgoing calls that received answers.
out_fail	Number of outgoing calls that failed.
in_szre_d	Incoming seizure duration (in seconds).
out_szre_d	Outgoing seizure duration (in seconds).
in_conn_d	Incoming connected duration (in seconds).
out_conn_d	Outgoing connected duration (in seconds).
orig_disconn	Number of calls encountering the originating side having been disconnected before the outgoing calls were connected.
in_ans_abnorm	Number of incoming answered calls terminated with any cause code other than "normal".
out_ans_abnorm	Number of outgoing answered calls terminated with any cause code other than "normal".
in_mcd	Number of incoming calls lasting less than the configured minimum call duration (MCD).

Field	Description
out_mcd	Number of outgoing calls lasting less than the configured MCD.
in_pdd	Total post dial delay duration on incoming calls (in ms).
out_pdd	Total post dial delay duration on outgoing calls (in ms).
in_setup_delay	Total inbound setup delay duration (in ms).
out_setup_delay	Total outbound setup delay duration (in ms).
lost_pkt	Number of calls losing more than the configured number of packets. Note This field will exist only in IP records. In other types of records, this field will be empty and extra commas are expected.
latency	Number of calls encountering more than the configured amount of latency. Note This field will exist only in IP records. In other types of records, this field will be empty and extra commas are expected.
jitter	Number of calls encountering more than configured amount of jitter. Note This field will exist only in IP records. In other types of records, this field will be empty and extra commas are expected.
in_cc_no	Number of the following disconnect cause code counters as per incoming calls (expected to be fewer than 5).
in_disc_cc	Incoming disconnect cause code. For example, in_disc_cc_16=3 indicates that 3 calls were disconnected or finished with a disconnect cause code of 16 (normal).
out_disc_cc	Outgoing disconnect cause code.
out_cc_no	Number of the following disconnect cause code counters as per outgoing calls (expected to be fewer than 5).
in_cc_id	Disconnect cause code ID for the following field for incoming calls.
in_cc_cntr	Disconnect cause code counter for incoming calls (any incoming cause code counter pairs).
out_cc_id	Disconnect cause code ID for the following field for outgoing calls.
out_cc_cntr	Disconnect cause code counter for outgoing calls (any outgoing cause code counter pairs).

Related Commands

Command	Description
show event-manager consumers	Displays event statistics.

Command	Description
show voice statistics csr interval accounting	Displays statistical information by configured intervals for accounting statistics.
show voice statistics csr since-reset accounting	Displays all accounting CSRs since the last reset.
show voice statistics csr since-reset aggregation-level	Displays all signaling CSRs since the last reset.
show voice statistics csr since-reset all	Displays all CSRs since the last reset.
show voice statistics interval-tag	Displays the configured interval numbers.
show voice statistics memory-usage	Displays current memory usage.
voice statistics time-range	Specifies the time range to collect CSRs.

show voice statistics csr since-reset accounting

To display VoIP AAA accounting statistics since the last reset, use the **show voice statistics csr since-reset accounting** command in privileged EXEC mode.

show voice statistics csr since-reset accounting {**all** | **method-list** *method-list-name*} [**push** {**all** | **ftp** | **syslog**}]

Syntax Description

all	All collected statistics since the last reset are displayed.
method-list <i>method-list-name</i>	Collected statistics by method list since the last reset are displayed. The <i>method-list-name</i> argument specifies the name of the method list.
push	(Optional) Statistics are downloaded to an FTP or syslog server, or to both servers. The keywords are as follows: <ul style="list-style-type: none"> • all--Pushes statistics to both the FTP and syslog servers. • ftp--Pushes statistics to the FTP server. • syslog--Pushes statistics to the syslog server.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.3(4)T	This command was introduced.

Usage Guidelines

This command only applies if the **voice statistics time-range** command is configured to the **since-reset** value. Voice statistics collection on the gateway is reset using the **clear voice statistics csr** command.

If you enter the **show voice statistics csr since-reset accounting** command but the gateway has been configured for periodic collection or to a specific interval, the gateway will display an error message.

Examples

The following sample output shows the accounting statistics for method list h323-1 since the last reset:

```
Router# show voice statistics csr since-reset accounting method-list h323-1
Client Type: Voice ACCT Stats
      Start Time: 2002-05-05T17:39:17Z          End Time: 2002-05-09T19:00:16Z
methodlist=h323-1,acc_pass_criteria=1,pstn_in_pass=0,pstn_in_fail=1,pstn_out_pass=0,
pstn_out_fail=0,ip_in_pass=0,ip_in_fail=0,ip_out_pass=0,ip_out_fail=1
```

The table below lists and describes the significant output fields.

Table 28: show voice statistics csr since-reset accounting Field Descriptions

Field	Description
Client Type	The type of statistics collected.

Field	Description
Start Time	The start time of the statistics collection.
End Time	The ending time of the statistics collection.
method-list	The method list name.
acc_pass_criteria	Accounting pass criteria: <ul style="list-style-type: none"> • 1: all start/interim/stop messages passed. • 2: all start/stop messages passed. • 3: stop-only message passed.
pstn_in_pass	Number of incoming calls on the PSTN leg that meet acc_pass_criteria.
pstn_in_fail	Number of incoming calls on the PSTN leg that fail acc_pass_criteria.
pstn_out_pass	Number of outgoing calls on the PSTN leg that meet acc_pass_criteria.
pstn_out_fail	Number of outgoing calls on the PSTN leg that fail acc_pass_criteria.
ip_in_pass	Number of incoming calls on the IP leg that meet acc_pass_criteria.
ip_in_fail	Number of incoming calls on the IP leg that fail acc_pass_criteria.
ip_out_pass	Number of outgoing calls on the IP leg that meet acc_pass_criteria.
ip_out_fail	Number of outgoing calls on the IP leg that fail acc_pass_criteria.

Related Commands

Command	Description
clear voice statistics	Clears voice statistics, resetting the statistics collection.
show event-manager consumers	Displays event statistics.
show voice statistics csr interval accounting	Displays statistical information by configured intervals for accounting statistics.
show voice statistics csr interval aggregation	Displays statistical information by configured intervals for signaling statistics.
show voice statistics csr since-reset aggregation-level	Displays all signaling CSRs since the last reset.
show voice statistics interval-tag	Displays the configured interval numbers
show voice statistics memory-usage	Displays current memory usage.
voice statistics time-range	Specifies a time range to collect statistics from the gateway on a periodic basis, since the last reset, or for a specific time duration.

show voice statistics csr since-reset aggregation-level

To display signaling statistics since the last reset, use the **show voice statistics csr since-reset aggregation-level** command in privileged EXEC mode.

```
show voice statistics csr since-reset aggregation-level {all | gateway | ip | pstn | trunk-group
{alltrunk-group-label} | voice-port {allvoice-port-label}} [mode {concise | verbose}] [push {all | ftp
| syslog}]
```

Syntax Description

all	All signaling statistics.
gateway	Gateway-wide level statistics.
ip	VoIP-interface-level statistics.
pstn	PSTN-level statistics.
trunk-group	Trunk-group-level statistics. Keywords and arguments are as follows. <ul style="list-style-type: none"> • all --Statistics for all trunk groups. • <i>trunk-group-label</i> --Statistics for a specific trunk group.
voice-port	Voice-port-level statistics. Keywords and arguments are as follows: <ul style="list-style-type: none"> • all --Statistics for all voice ports. • <i>voice-port-label</i> --Statistics for a specific voice port.
mode	(Optional) Statistics in a specified mode. Keywords are as follows: <ul style="list-style-type: none"> • concise--Output contains total calls, answered calls, and answered call duration. • verbose--All fields contained in call statistic records (CSRs). This is the default.
push	(Optional) Statistics are downloaded to an FTP or syslog server, or to both servers. Keywords are as follows: <ul style="list-style-type: none"> • all--Pushes statistics to both the FTP and syslog servers. • ftp--Pushes statistics to the FTP server. • syslog--Pushes statistics to the syslog server.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.3(4)T	This command was introduced.

Usage Guidelines

This command applies only if the **voice statistics time-range** command is configured to the **since-reset** value. Voice statistics collection on the gateway is reset using the **clear voice statistics csr** command.

If you enter the **show voice statistics csr since-reset aggregation-level** command but the gateway has been configured for periodic collection or to a specific interval, the gateway will display an error message.

Examples

The following sample output shows signaling statistics for all aggregation levels since the last reset:

```
Router# show voice statistics csr since-reset aggregation-level all
Client Type: VCSR
      Start Time: 2002-04-25T01:48:12Z      End Time: 2002-04-25T01:50:01Z
record_type=gw,trunk_group_id=,voice_port_id=,in_call=0,in_ans=0,in_fail=0,out_call=0,
out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,orig_disconn=0,
in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,in_setup_delay=0,
out_setup_delay=0,lost_pkt=0,latency=0,jitter=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=ip,trunk_group_id=,voice_port_id=,in_call=0,in_ans=0,in_fail=0,out_call=0,
out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,orig_disconn=0,
in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,in_setup_delay=0,
out_setup_delay=0,lost_pkt=0,latency=0,jitter=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=pstn,trunk_group_id=,voice_port_id=,in_call=0,in_ans=0,in_fail=0,out_call=0,
out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,orig_disconn=0,
in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,in_setup_delay=0,
out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=vp,trunk_group_id=,voice_port_id=4/0/0,in_call=0,in_ans=0,in_fail=0,
out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,
orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=vp,trunk_group_id=,voice_port_id=4/0/1,in_call=0,in_ans=0,in_fail=0,
out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,
orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=vp,trunk_group_id=,voice_port_id=4/1/0,in_call=0,in_ans=0,in_fail=0,
out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,
orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=vp,trunk_group_id=,voice_port_id=4/1/1,in_call=0,in_ans=0,in_fail=0,
out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,
orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=vp,trunk_group_id=,voice_port_id=2/0:23,in_call=0,in_ans=0,in_fail=0
,out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,
orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=vp,trunk_group_id=,voice_port_id=2/1:23,in_call=0,in_ans=0,in_fail=0
,out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,
orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
```

The following sample output shows signaling statistics for the IP aggregation level since the last reset:

```
Router# show voice statistics csr since-reset aggregation-level ip
Client Type: VCSR
```

```

Start Time: 2002-04-25T01:48:12Z      End Time: 2002-05-02T21:21:27Z
record_type=ip,trunk_group_id=0,voice_port_id=2,in_call=5,in_ans=5,in_fail=0,out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,orig_disconn=0,
in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,in_setup_delay=0,
out_setup_delay=0,lost_pkt=0,latency=0,jitter=0,in_disc_cc_16=0,out_disc_cc_16=0

```

The following sample output shows signaling statistics for the PSTN aggregation level since the last reset:

```

Router# show voice statistics csr since-reset aggregation-level pstn
Client Type: VCSR
Start Time: 2002-04-25T01:48:12Z      End Time: 2002-05-02T21:21:42Z
record_type=pstn,trunk_group_id=25,voice_port_id=2,in_call=100,in_ans=10,in_fail=90,
out_call=0,out_ans=0,out_fail=0,in_szre_d=100,out_szre_d=0,in_conn_d=0,out_conn_d=0,
orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0

```

The table below lists and describes the significant output fields.

Table 29: show voice statistics csr since-reset aggregation-level Field Descriptions

Field	Description
Client Type	The type of statistics collected.
Start Time	The start time of the statistics collection.
End Time	The ending time of the statistics collection.
record_type	Call statistics record type. Symbols are gw, ip, pstn, tg, and vp.
trunk_group_id	Trunk group ID. Note For the symbols gw, ip, pstn, and some vp records, this field is empty.
voice_port_id	Voice port ID. Note For the symbols gw, ip, pstn, and some vp records, this field is empty.
in_call	Number of incoming calls.
in_ans	Number of incoming calls answered by the gateway.
in_fail	Number of incoming calls that failed.
out_call	Number of outgoing calls attempted.
out_ans	Number of outgoing calls that received answers.
out_fail	Number of outgoing calls that failed.
in_szre_d	Incoming seizure duration (in seconds).
out_szre_d	Outgoing seizure duration (in seconds).
in_conn_d	Incoming connected duration (in seconds).

Field	Description
out_conn_d	Outgoing connected duration (in seconds).
orig_disconn	Number of calls encountering the originating side having been disconnected before the outgoing calls were connected.
in_ans_abnorm	Number of incoming answered calls terminated with any cause code other than "normal".
out_ans_abnorm	Number of outgoing answered calls terminated with any cause code other than "normal".
in_mcd	Number of incoming calls lasting less than the configured minimum call duration (MCD).
out_mcd	Number of outgoing calls lasting less than the configured MCD.
in_pdd	Total post dial delay duration on incoming calls (in ms).
out_pdd	Total post dial delay duration on outgoing calls (in ms).
in_setup_delay	Total inbound setup delay duration (in ms).
out_setup_delay	Total outbound setup delay duration (in ms).
lost_pkt	Number of calls losing more than the configured number of packets. Note This field will exist only in IP records. In other types of records, this field will be empty and extra commas are expected.
latency	Number of calls encountering more than the configured amount of latency. Note This field will exist only in "IP" records. In other types of records, this field will be empty and extra commas are expected.
jitter	Number of calls encountering more than configured amount of jitter. Note This field will exist only in IP records. In other types of records, this field will be empty and extra commas are expected.
in_disc_cc	Incoming disconnect cause code. For example, in_disc_cc_16=3 indicates that 3 calls were disconnected or finished with a disconnect cause code of 16 (normal).
out_disc_cc	Outgoing disconnect cause code.
in_cc_no	Number of the following disconnect cause code counters as per incoming calls (expected to be fewer than 5).
out_cc_no	Number of the following disconnect cause code counters as per outgoing calls (expected to be fewer than 5).
in_cc_id	Disconnect cause code ID for the following field for incoming calls.
in_cc_cntr	Disconnect cause code counter for incoming calls (any incoming cause code counter pairs).

Field	Description
out_cc_id	Disconnect cause code ID for the following field for outgoing calls.
out_cc_cntr	Disconnect cause code counter for outgoing calls (any outgoing cause code counter pairs).

Related Commands

Command	Description
clear voice statistics	Clears voice statistics, resetting the statistics collection.
clear voice statistics csr	Clears voice-statistic collection settings on the gateway.
show event-manager consumers	Displays event statistics.
show voice statistics csr interval accounting	Displays statistical information by configured intervals for accounting statistics.
show voice statistics csr interval aggregation	Displays statistical information by configured intervals for signaling statistics.
show voice statistics csr since-reset accounting	Displays all accounting CSRs since the last reset.
show voice statistics interval-tag	Displays voice statistics within a specified interval.
show voice statistics memory-usage	Displays current memory usage.
voice statistics time-range	Specifies the time range to collect CSRs.

show voice statistics csr since-reset all

To display all voice call statistical information since a reset occurred, use the **show voice statistics csr since-reset all** command in privileged EXEC mode.

```
show voice statistics csr since-reset all [mode {concise | verbose}] [push {all | ftp | syslog}]
```

Syntax Description	mode
	(Optional) Statistics are displayed in a specified mode. The keywords are as follows: <ul style="list-style-type: none"> • concise--Displays output that contains total calls, answered calls, and answered call duration. • verbose--Displays all fields contained in call statistic records (CSRs). This is the default setting.
	push
	(Optional) Statistics are downloaded to an FTP or syslog server, or to both servers. The keywords are as follows: <ul style="list-style-type: none"> • all--Pushes statistics to both the FTP and syslog servers. • ftp--Pushes statistics to the FTP server. • syslog--Pushes statistics to the syslog server.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.3(4)T	This command was introduced.

Usage Guidelines

This command can also be used to display and push VoIP internal error codes (IECs).

Examples

The following example shows all of the statistics that were collected since the last reset:

```
Router# show voice statistics csr since-reset all
Client Type: VCSR
      Start Time: 2002-05-01T19:35:17Z      End Time: 2002-05-01T19:36:26Z
record_type=gw,trunk_group_id=,voice_port_id=,in_call=0,in_ans=0,in_fail=0,out_call=0,
out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,orig_disconn=0,
in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,in_setup_delay=0,
out_setup_delay=0,lost_pkt=0,latency=0,jitter=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=ip,trunk_group_id=,voice_port_id=,in_call=0,in_ans=0,in_fail=0,out_call=0,
out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,orig_disconn=0,
in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,in_setup_delay=0,
out_setup_delay=0,lost_pkt=0,latency=0,jitter=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=pstn,trunk_group_id=,voice_port_id=,in_call=0,in_ans=0,in_fail=0,out_call=0,
out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,orig_disconn=0,
in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,in_setup_delay=0,
out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=vp,trunk_group_id=,voice_port_id=4/0/0,in_call=0,in_ans=0,in_fail=0,
out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,
```

```

orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=vp,trunk_group_id=,voice_port_id=4/0/1,in_call=0,in_ans=0,in_fail=0,
out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,
orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=vp,trunk_group_id=,voice_port_id=4/1/0,in_call=0,in_ans=0,in_fail=0,
out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,
orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=vp,trunk_group_id=,voice_port_id=4/1/1,in_call=0,in_ans=0,in_fail=0,
out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,
orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=vp,trunk_group_id=,voice_port_id=2/0:23,in_call=0,in_ans=0,in_fail=0
out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,
orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
!
record_type=vp,trunk_group_id=,voice_port_id=2/1:23,in_call=0,in_ans=0,in_fail=0
out_call=0,out_ans=0,out_fail=0,in_szre_d=0,out_szre_d=0,in_conn_d=0,out_conn_d=0,
orig_disconn=0,in_ans_abnorm=0,out_ans_abnorm=0,in_mcd=0,out_mcd=0,in_pdd=0,out_pdd=0,
in_setup_delay=0,out_setup_delay=0,in_disc_cc_16=0,out_disc_cc_16=0
Client Type: Voice ACCT Stats
      Start Time: 2002-05-01T19:35:17Z          End Time: 2002-05-01T19:36:29Z
methodlist=h323-1,acc_pass_criteria=1,pstn_in_pass=0,pstn_in_fail=0,pstn_out_pass=0,
pstn_out_fail=0,ip_in_pass=0,ip_in_fail=0,ip_out_pass=0,ip_out_fail=0

```

The table below lists and describes the significant output fields.

Table 30: show voice statistics csr since-reset all Field Descriptions

Field	Description
Client Type	The type of statistics collected.
Start Time	The start time of the statistics collection.
End Time	The ending time of the statistics collection.
record_type	Call statistics record type. Symbols are gw, ip, pstn, tg, and vp.
trunk_group_id	Trunk group ID. Note For the symbols gw, ip, pstn, and some vp records, this field is empty.
voice_port_id	Voice port ID. Note For the symbols gw, ip, pstn, and some vp records, this field is empty.
in_call	Number of incoming calls.
in_ans	Number of incoming calls answered by the gateway.

Field	Description
in_fail	Number of incoming calls that failed.
out_call	Number of outgoing calls attempted.
out_ans	Number of outgoing calls that received answers.
out_fail	Number of outgoing calls that failed.
in_szre_d	Incoming seizure duration (in seconds).
out_szre_d	Outgoing seizure duration (in seconds).
in_conn_d	Incoming connected duration (in seconds).
out_conn_d	Outgoing connected duration (in seconds).
orig_disconn	Number of calls encountering the originating side having been disconnected before the outgoing calls were connected.
in_ans_abnorm	Number of incoming answered calls terminated with any cause code other than "normal".
out_ans_abnorm	Number of outgoing answered calls terminated with any cause code other than "normal".
in_mcd	Number of incoming calls lasting less than the configured minimum call duration (MCD).
out_mcd	Number of outgoing calls lasting less than the configured MCD.
in_pdd	Total post dial delay duration on incoming calls (in ms).
out_pdd	Total post dial delay duration on outgoing calls (in ms).
in_setup_delay	Total inbound setup delay duration (in ms).
out_setup_delay	Total outbound setup delay duration (in ms).
lost_pkt	Number of calls losing more than the configured number of packets. Note This field will exist only in IP records. In other types of records, this field will be empty and extra commas are expected.
latency	Number of calls encountering more than the configured amount of latency. Note This field will exist only in IP records. In other types of records, this field will be empty and extra commas are expected.
jitter	Number of calls encountering more than the configured amount of jitter. Note This field will exist only in IP records. In other types of records, this field will be empty and extra commas are expected.

Field	Description
in_disc_cc	Incoming disconnect cause code. For example, in_disc_cc_16=3 indicates that 3 calls were disconnected or finished with a disconnect cause code of 16 (normal).
out_disc_cc	Outgoing disconnect cause code.
in_cc_no	Number of the following disconnect cause code counters as per incoming calls (expected to be fewer than 5).
out_cc_no	Number of the following disconnect cause code counters as per outgoing calls (expected to be fewer than 5).
in_cc_id	Disconnect cause code ID for the following field for incoming calls.
in_cc_cntr	Disconnect cause code counter for incoming calls (any incoming cause code counter pairs).
out_cc_id	Disconnect cause code ID for the following field for outgoing calls.
out_cc_cntr	Disconnect cause code counter for outgoing calls (any outgoing cause code counter pairs).

Related Commands

Command	Description
clear voice statistics	Clears voice statistics, resetting the statistics collection.
show event-manager consumers	Displays event statistics.
show voice statistics csr interval accounting	Displays statistical information by configured intervals for accounting statistics.
show voice statistics csr interval aggregation	Displays statistical information by configured intervals for signaling statistics.
show voice statistics csr since-reset accounting	Displays all accounting CSRs since the last reset.
show voice statistics csr since-reset aggregation-level	Displays all signaling CSRs since the last reset.
show voice statistics interval-tag	Displays voice statistics within a specified interval.
show voice statistics memory-usage	Displays current memory usage.

show voice statistics iec

To display Internal Error Code (IEC) statistics, use the **show voice statistics iec** command in user EXEC or privileged EXEC mode.

```
show voice statistics iec {interval number | since-reboot | since-reset} [push [all | ftp | syslog]]
```

Syntax Description

interval	Displays statistics for the specified interval.
<i>number</i>	The interval tag number. The range is from 1 to 36655.
since-reboot	Displays IEC statistics since the last reboot.
since-reset	Displays IEC statistics since the last reset.
push	Specifies the off-load pushing interface.
all	Indicates that IEC statistics will be off-loaded to all push interfaces.
ftp	Indicates that IEC statistics will be off-loaded to the FTP server.
syslog	Indicates that IEC statistics will be off-loaded to the syslog server.

Command Modes

User EXEC (#)
Privileged EXEC(#)

Command History

Release	Modification
12.3(4)T	This command was introduced.
12.4(24)T	This command was modified in a release earlier than Cisco IOS Release 12.4(24)T. The push all , ftp and syslog keywords were added.

Usage Guidelines

Before you can display IEC statistics for a specific interval, use the **show voice statistics interval-tag** command to display available interval options. Before you display view IEC statistics since reboot, you must configure the **voice statistics type iec** command. Before you can display IEC statistics since the last reset, you must configure the **voice statistics type iec** command and the **voice statistics time-range since-reset** command.

Examples

The following is sample output from the **show voice statistics iec since-reset** command, which displays statistics since the last instance when IEC counters were cleared:

```
Router# show voice statistics iec since-reset
Internal Error Code counters
-----
Counters since last reset (2002-11-28T01:55:31Z):
  SUBSYSTEM CCAPI [subsystem code 1]
    [errcode 6] No DSP resource                    5
  SUBSYSTEM SSAPP [subsystem code 4]
    [errcode 5] No dial peer match                 2
    [errcode 3] CPU high                           96
```

```

SUBSYSTEM H323 [subsystem code 5]
  [errcode 22] No Usr Responding, H225 timeout          1
  [errcode 27] H225 invalid msg                       1
  [errcode 79] H225 chn, sock fail                    27
SUBSYSTEM VTSP [subsystem code 9]
  [errcode 6] No DSP resource                          83

```

The table below describes the significant fields shown in the display.

Table 31: show voice statistics iec Field Descriptions

Field	Description
SUBSYSTEM	Indicates the specific subsystem within the physical entity where the IEC was generated.
errcode	Identifies the error code within the subsystem.

The following is sample output from the **show voice statistics iec since-reset push all** command, which displays statistics since the last instance when IEC counters were cleared and off-loaded to all push interfaces.

```

Router# show voice statistics iec since-reset push all
Internal Error Code counters
-----
Counters since last reset (2009-07-16T01:40:59Z):
No errors.
Router#
*Jul 16 01:43:39.530: %VSTATS-6-IEC: SEQ=1:
stats_type,version,entity_id,start_time,end_time,record_count
IEC,1,7206-2,2009-07-16T01:40:59Z,2009-07-16T01:43:39Z,0

```

Related Commands

Command	Description
clear voice statistics	Clears voice statistics, resetting the statistics collection.
show voice statistics	Displays voice statistics.
show voice statistics interval-tag	Displays interval options available for IEC statistics.
voice statistics time-range since-reset	Enables collection of call statistics accumulated since the last resetting of IEC counters.
voice statistics type iec	Enables collection of IEC statistics.

show voice statistics interval-tag

To display the interval numbers assigned by the gateway, use the **show voice statistics interval-tag** command in privileged EXEC mode.

show voice statistics interval-tag

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.3(4)T	This command was introduced.

Usage Guidelines

This is used to obtain the interval tag number required for the **show voice statistics csr interval accounting** and **show voice statistics csr interval aggregation** commands.

Examples

The following example shows the start and end times for specific interval tags:

```
Router# show voice statistics interval-tag
Current System Time is: 2002-4-1T010:10:00Z
Interval-Tag   Intervals Start Time      End Time
101            2002-3-31T010:00:00Z           2002-3-31T010:55:00Z
105            2002-3-31T012:15:00Z           2002-3-31T012:30:00Z
```

The table below lists and describes the significant output fields.

Table 32: show voice statistics interval-tag Field Descriptions

Field	Description
Current System Time	Current system time of the gateway.
Interval-Tag	Interval number.
Intervals Start Time	Interval start time.
End Time	Interval end time.

Related Commands

Command	Description
show event-manager consumers	Displays event statistics.
show voice statistics csr interval accounting	Displays statistical information by configured intervals for accounting statistics.
show voice statistics csr interval aggregation	Displays statistical information by configured intervals for signaling statistics.

Command	Description
show voice statistics csr since-reset accounting	Displays all accounting CSRs since the last reset.
show voice statistics csr since-reset aggregation-level	Displays all signaling CSRs since the last reset.
show voice statistics csr since-reset all	Displays all CSRs since the last reset.
show voice statistics memory-usage	Displays current memory usage.

show voice statistics memory-usage

To display the memory used for collecting call statistics and to estimate the future use of memory, use the **show voice statistics memory-usage** command in privileged EXEC mode.

```
show voice statistics memory-usage {all | csr | iec}
```

Syntax Description	all	Memory used to collect both signaling and accounting call statistics records (CSRs).
	csr	Memory used to collect signaling CSRs only.
	iec	Memory used to collect Cisco internal error codes (IECs) only.

Command Modes

Privileged EXEC (#)

Command History

Release	Modification
12.3(4)T	This command was introduced.

Examples

The following example shows all of the memory used at a fixed interval and since the last reset for signaling and accounting; it also shows the estimated future memory to be used.

```
Router# show voice statistics memory-usage all
*** Voice Call Statistics Record Memory Usage ***
  Fixed Interval Option -
    CSR size: 136 bytes
    Number of CSR per interval: 9
    Used memory size (proximate): 0
    Estimated future claimed memory size (proximate): 0
  Since Reset Option -
    CSR size: 136 bytes
    Total count of CSR: 9
    Used memory size (proximate): 1224
*** Voice Call Statistics Accounting Record Memory Usage ***
  Fixed Interval Option -
    ACCT REC size: 80 bytes
    Number of ACCT REC per interval: 1
    Used memory size (proximate): 0
    Estimated future claimed memory size (proximate): 0
  Since Reset Option -
    ACCT REC size: 80 bytes
    Total count of ACCT REC: 1
    Used memory size (proximate): 80
```

The table below lists and describes the significant output fields.

Table 33: show voice statistics memory-usage Field Descriptions

Field	Description
Voice Call Statistics Record Memory Usage	

Field	Description
Fixed Interval Option:	Statistics gathered for a fixed interval.
CSR size	Size of the CSR for the fixed interval.
Number of CSR per interval	Number of CSRs collected for the fixed interval.
Used memory size (proximate)	Amount of memory currently being used to store statistics.
Estimated future claimed memory size (proximate)	Amount of remaining memory available to store statistics.
Since Reset Option:	Statistics gathered since the last reset or reboot of the gateway.
CSR size	Size of the CSR since the last reset.
Total count of CSR	Total number of CSRs gathered since the last reset.
Used memory size (proximate)	Amount of memory currently being used to store statistics.
Voice Call Statistics Accounting Record Memory Usage	
Fixed Interval Option:	Statistics gathered for a fixed interval.
ACCT REC size	Accounting record size.
Number of ACCT REC per interval	Number of accounting records per interval.
Used memory size (proximate)	Amount of memory currently being used to store statistics.
Estimated future claimed memory size (proximate)	Amount of remaining memory available to store statistics.
Since Reset Option:	Statistics gathered since the last reset or reboot of the gateway.
ACCT REC size	Accounting record size.
Total count of ACCT REC	Total number of accounting records since the last reset or reboot of the gateway.
Used memory size (proximate)	Amount of memory currently being used to store statistics.

Related Commands

Command	Description
show event-manager consumers	Displays event statistics.
show voice statistics csr interval accounting	Displays statistical information by configured intervals for accounting statistics.

Command	Description
show voice statistics csr interval aggregation	Displays statistical information by configured intervals for signaling statistics.
show voice statistics csr since-reset accounting	Displays all accounting CSRs since the last reset.
show voice statistics csr since-reset aggregation-level	Displays all signaling CSRs since the last reset.
show voice statistics csr since-reset all	Displays all CSRs since the last reset.
show voice statistics interval-tag	Displays the configured interval numbers.

