

Modifying, Downloading, and Maintaining Configuration Files

This chapter describes how to load and maintain configuration files. Configuration files contain commands entered to customize the function of the Cisco IOS software.

To benefit most from the instructions and organization of this chapter, your router must contain a minimal configuration that allows you to interact with the system software. You can create a basic configuration file using the **setup** command facility. See the user guide for your hardware platform for more information on using **setup** at first-time startup. See the “Using Setup for Configuration Changes” chapter in this publication for information on using **setup** after first-time startup.

For a complete description of the configuration file commands in this chapter, refer to the “Configuration File Commands” chapter in the *Configuration Fundamentals Command Reference*. To locate documentation of other commands that appear in this chapter, use the command reference master index or search online.

Note One or more of the commands that previously appeared in this chapter have been replaced by new commands. Table 51 maps the old commands to their replacements. The old commands continue to perform their normal functions in the current release, but support for these commands will cease in a future release.

Table 51 Mapping Old Commands to New Commands

Old Command	New Command
<code>configure network</code>	<code>copy ftp: system:running-config</code>
<code>copy rcp running-config</code>	<code>copy rcp: system:running-config</code>
<code>copy tftp running-config</code>	<code>copy tftp: system:running-config</code>
<code>configure overwrite-network</code>	<code>copy ftp: nvram:startup-config</code>
<code>copy rcp startup-config</code>	<code>copy rcp: nvram:startup-config</code>
<code>copy tftp startup-config</code>	<code>copy tftp: nvram:startup-config</code>
<code>show configuration</code>	<code>more nvram:startup-config</code>
<code>show startup-config</code>	
<code>write erase</code>	<code>erase nvram:</code>
<code>erase startup-config</code>	
<code>write memory</code>	<code>copy system:running-config nvram:startup-config</code>
<code>copy running-config startup-config</code>	

Table 51 Mapping Old Commands to New Commands (Continued)

Old Command	New Command
write network	copy system:running-config ftp:
copy running-config rcp	copy system:running-config rcp:
copy running-config tftp	copy system:running-config tftp:
write terminal	more system:running-config
show running-config	

Configuration File Task List

To load and maintain configuration files needed for startup, complete any of the tasks in the following sections:

- Display Configuration File Information
- Understand Configuration Files
- Enter Configuration Mode and Select a Configuration Source
- Configure the Cisco IOS Software from the Terminal
- Copy Configuration Files from the Router to a Network Server
- Copy Configuration Files from a Network Server to the Router
- Maintain Configuration Files Larger than NVRAM
- Copy Configuration Files between Different Locations
- Reexecute the Configuration Commands in Startup Configuration
- Clear the Configuration Information
- Specify the Startup Configuration File

Note These tasks assume you have a minimal configuration that you want to modify.

Display Configuration File Information

Use the following commands in EXEC mode to display information about configuration files:

Step	Command	Purpose
1	show bootvar	List the contents of the BOOT environment variable, the name of the configuration file pointed to by the CONFIG_FILE environment variable, and the contents of the BOOTLDR environment variable.
2	more <i>file-url</i>	List the configuration information stored in a specified file.
3	more system:running-config or show running-config	List the configuration information in running memory.

Step	Command	Purpose
4	more nvram:startup-config	List the startup configuration information. On all platforms except the Class A Flash file system platforms, the startup configuration is usually NVRAM. On the Class A Flash file system platforms, the CONFIG_FILE environment variable points to the startup configuration. The CONFIG_FILE variable defaults to NVRAM.

Understand Configuration Files

Configuration files contain the commands the router uses to customize the function of the Cisco IOS software. The **setup** command facility helps you create a basic configuration file. However, you can manually change the configuration by typing commands in a configuration mode.

Types of Configuration Files

Startup configuration files are used during system startup to configure the software. Running configuration files contain the current configuration of the software. The two configuration files can be different. For example, you may want to change the configuration for a short time period rather than permanently. In this case, you would change the running configuration using the **configure terminal** command but not save the configuration using the **copy system:running-config nvram:startup-config** command.

To change the running configuration, use the **configure terminal** command, as described in the “Configure the Cisco IOS Software from the Terminal” section. To change the startup-config, you can either save the running configuration file to the startup configuration using the **copy system:running-config nvram:startup-config** command (which is also described in the “Configure the Cisco IOS Software from the Terminal” section) or copy commands from a file server to the startup configuration without affecting the running configuration (refer to the “Copy Configuration Files from a Network Server to the Router” section).

Location of Configuration Files

The configuration files are stored in the following places:

- The running configuration is stored in RAM.
- On all platforms except the Class A Flash file system platforms, the startup configuration is stored in nonvolatile random-access memory (NVRAM).
- On Class A Flash file system platforms, the startup configuration is stored in the location specified by the CONFIG_FILE environment variable (refer to the “Specify the CONFIG_FILE Environment Variable (Class A Flash File Systems)” section for details). The CONFIG_FILE variable defaults to NVRAM and can be a file in the following file systems:
 - **nvram:** (NVRAM)
 - **bootflash:** (Internal Flash memory)
 - **slot0:** (First PCMCIA slot)
 - **slot1:** (Second PCMCIA slot)

Enter Configuration Mode and Select a Configuration Source

To enter configuration mode, enter the **configure** command at the privileged EXEC prompt. The Cisco IOS software responds with the following prompt asking you to specify the terminal, memory, or a file stored on a network server (network) as the source of configuration commands:

```
Configuring from terminal, memory, or network [terminal]?
```

Configuring from the terminal allows you to enter configuration commands at the command line. Refer to the “Configure the Cisco IOS Software from the Terminal” section for details. Configuring from memory reexecutes the commands in the startup configuration file. See the “Reexecute the Configuration Commands in Startup Configuration” section for more details. Configuring from the network allows you to load and execute configuration commands over the network. See the “Copy Configuration Files from a Network Server to the Router” section for more details.

Configure the Cisco IOS Software from the Terminal

The Cisco IOS software accepts one configuration command per line. You can enter as many configuration commands as you want.

You can add comments to a configuration file describing the commands you have entered. Precede a comment with an exclamation point (!). Because comments are *not* stored in NVRAM or in the active copy of the configuration file, comments do not appear when you list the active configuration with the **show running-config** or **more system:running-config** EXEC command. Also, when the startup configuration is NVRAM, comments do not show up when you list the startup configuration with the **more nvram:startup-config** EXEC command. Comments are stripped out of the configuration file when it is loaded onto the router. However, you can list the comments in configuration files stored on an FTP, rcp, or TFTP server.

When you configure the software from the terminal, the software executes the commands you enter at the system prompts. To configure the software from the terminal, use the following commands:

Step	Command	Purpose
1	configure terminal	Enter configuration mode and select the terminal option.
2	See the appropriate chapter for specific configuration commands.	Enter the necessary configuration commands.
3	end or press Ctrl-Z (^Z)	Quit configuration mode.
4	copy system:running-config nvram:startup-config	Save the configuration file to your startup configuration. On most platforms, this step saves the configuration to NVRAM. On the Class A Flash file system platforms, this step saves the configuration to the location specified by the CONFIG_FILE environment variable. The CONFIG_FILE variable defaults to NVRAM.

In the following example, the software is configured from the terminal. The comment `The following command provides the router host name` identifies the purpose of the next command line. The **hostname** command changes the router name from `router1` to `router2`. By pressing **Ctrl-Z**

(**^Z**) or entering the command **end**, the user quits configuration mode. Finally, the **copy system:running-config nvram:startup-config** command saves the current configuration to the startup configuration.

```
Router1# configure terminal
Router1(config)# !The following command provides the router host name.
Router1(config)# hostname router2
Router2(config)# end
Router2# copy system:running-config nvram:startup-config
```

When the startup configuration is NVRAM, it stores the current configuration information in text format as configuration commands, *recording only nondefault settings*. The memory is checksummed to guard against corrupted data.



Caution Some specific commands might not get saved to NVRAM. You will have to enter these commands again if you reboot the machine. These commands are noted in the documentation. We recommend that you keep a listing of these settings so you can quickly reconfigure your router after rebooting.

Copy Configuration Files from the Router to a Network Server

You can copy configuration files from the router to a file server using FTP, rcp, or TFTP. You might do this task to back up a current configuration file to a server before changing its contents, thereby allowing you to later restore the original configuration file from the server. The following sections describe these tasks:

- Copy a Configuration File from the Router to a TFTP Server
- Copy a Configuration File from the Router to an rcp Server
- Copy a Configuration File from the Router to an FTP Server

The protocol you use depends on which type of server you are using. The FTP and rcp transport mechanisms provide faster performance and more reliable delivery of data than TFTP. These improvements are possible because FTP and rcp are built on and use the Transmission Control Protocol/Internet Protocol (TCP/IP) stack, which is connection-oriented.

Copy a Configuration File from the Router to a TFTP Server

In some implementations of TFTP, you must create a dummy file on the TFTP server and give it read, write, and execute permissions before copying a file over it. Refer to your TFTP documentation for more information.

To store configuration information on a TFTP network server, use the following commands in the EXEC mode:

Step	Command	Purpose
1	<pre>copy system:running-config tftp:[[/location]/directory]/filename] or copy nvram:startup-config tftp:[[/location]/directory]/filename]</pre>	Specify that the running or startup configuration file be stored on a network server.
2		Reply to any router prompts for additional information or confirmation. The prompting will depending on how much information you provide in the copy command and the current setting of the file prompt command.

The following example copies a configuration file from a router to a TFTP server:

```
Tokyo# copy system:running-config tftp://172.16.2.155/tokyo-config
Write file tokyo-config on host 172.16.2.155? [confirm] y
#
Writing tokyo-config!!! [OK]
```

Copy a Configuration File from the Router to an rcp Server

You can copy a configuration file from the router to an rcp server.

If you copy the configuration file to a personal computer used as a file server, the computer must support rsh.

Understand the rcp Username

The rcp protocol requires a client to send a remote username on each rcp request to a server. When you copy a configuration file from the router to a server using rcp, the Cisco IOS software sends the first valid username in the following list:

- 1 The username specified in the **copy** command, if a username is specified.
- 2 The username set by the **ip rcmd remote-username** command, if the command is configured.
- 3 The remote username associated with the current TTY (terminal) process. For example, if the user is connected to the router through Telnet and was authenticated through the **username** command, the router software sends the Telnet username as the remote username.
- 4 The router host name.

For the rcp copy request to execute successfully, an account must be defined on the network server for the remote username. If the server has a directory structure, the configuration file or image is written to or copied from the directory associated with the remote username on the server. For example, if the system image resides in the home directory of a user on the server, you can specify that user's name as the remote username.

Use the **ip rcmd remote-username** command to specify a username for all copies. Include the username in the **copy** command if you want to specify a username for that copy operation only.

If you are writing to the server, the rcp server must be properly configured to accept the rcp write request from the user on the router. For UNIX systems, you must add an entry to the `.rhosts` file for the remote user on the rcp server. For example, suppose the router contains the following configuration lines:

```
hostname Rtr1
ip rcmd remote-username User0
```

If the router's IP address translates to Router1.company.com, then the `.rhosts` file for User0 on the rcp server should contain the following line:

```
Router1.company.com Rtr1
```

Refer to the documentation for your rcp server for more details.

Copy a Configuration File from the Router to the rcp Server Tasks

To copy a startup configuration file or a running configuration file from the router to an rcp server, use the following commands beginning in privileged EXEC mode:

Step	Command	Purpose
1	configure terminal	(Optional) Enter configuration mode from the terminal. This step is required only if you override the default remote username (see Step 2).
2	ip rcmd remote-username <i>username</i>	(Optional) Change the default remote username.
3	end	(Optional) Exit configuration mode. This step is required only if you override the default remote username (see Step 2).
4	copy system:running-config rcp:[[/[<i>username</i>@]<i>location</i>]/<i>directory</i>]/<i>filename</i>] or copy nvram:startup-config rcp:[[/[<i>username</i>@]<i>location</i>]/<i>directory</i>]/<i>filename</i>]	Specify that the router's running configuration or startup configuration file be stored on an rcp server.
5		Reply to any router prompts for additional information or confirmation. The prompting will depend on how much information you provide in the copy command and the current setting of the file prompt command.

Store a Running Configuration File on a Server Example

The following example copies the running configuration file named rtr2-config to the netadmin1 directory on the remote host with an IP address of 172.16.101.101:

```
Router# copy system:running-config rcp://netadmin1@172.16.101.101/Rtr2-config
Write file rtr2-config on host 172.16.101.101?[confirm]
Building configuration...[OK]
Connected to 172.16.101.101
Router#
```

Store a Startup Configuration File on a Server Example

The following example shows how to store a startup configuration file on a server by using rcp to copy the file:

```
Rtr2# configure terminal
Rtr2(config)# ip rcmd remote-username netadmin2
Rtr2(config)# end
Rtr2# copy nvram:startup-config rcp:
Remote host[]? 172.16.101.101
Name of configuration file to write [rtr2-config]?
Write file rtr2-config on host 172.16.101.101?[confirm]
![OK]
```

Copy a Configuration File from the Router to an FTP Server

You can copy a configuration file from the router to an FTP server.

Understand the FTP Username and Password

The FTP protocol requires a client to send a remote username and password on each FTP request to a server. When you copy a configuration file from the router to a server using FTP, the Cisco IOS software sends the first valid username in the following list:

- 1 The username specified in the **copy** command, if a username is specified.
- 2 The username set by the **ip ftp username** command, if the command is configured.
- 3 Anonymous.

The router sends the first valid password in the following list:

- 1 The password specified in the **copy** command, if a password is specified.
- 2 The password set by the **ip ftp password** command, if the command is configured.
- 3 The router forms a password *username@routername.domain*. The variable *username* is the username associated with the current session, *routername* is the configured host name, and *domain* is the domain of the router.

The username and password must be associated with an account on the FTP server. If you are writing to the server, the FTP server must be properly configured to accept the FTP write request from the user on the router.

If the server has a directory structure, the configuration file or image is written to or copied from the directory associated with the username on the server. For example, if the system image resides in the home directory of a user on the server, specify that user’s name as the remote username.

Refer to the documentation for your FTP server for more details.

Use the **ip ftp username** and **ip ftp password** commands to specify a username and password for all copies. Include the username in the **copy** command if you want to specify a username for that copy operation only.

Copy a Configuration File from the Router to the FTP Server Tasks

To copy a startup configuration file or a running configuration file from the router to an FTP server, use the following commands beginning in privileged EXEC mode:

Step	Command	Purpose
1	configure terminal	(Optional) Enter configuration mode from the terminal. This step is required only if you override the default remote username or password (see Steps 2 and 3).
2	ip ftp username <i>username</i>	(Optional) Change the default remote username.
3	ip ftp password <i>password</i>	(Optional) Change the default password.
4	end	(Optional) Exit configuration mode. This step is required only if you override the default remote username or password (see Steps 2 and 3).
5	copy system:running-config ftp:[[[/username[:password]@]location] <i>/directory]/filename]</i> or copy nvram:startup-config ftp:[[[/username[:password]@]location] <i>/directory]/filename]</i>	Specify that the router’s running configuration or startup configuration file be stored on an FTP server.

Step	Command	Purpose
6		Reply to any router prompts for additional information or confirmation. The prompting will depend on how much information you provide in the copy command and the current setting of the file prompt command.

Store a Running Configuration File on an FTP Server Example

The following example copies the running configuration file named rtr2-confg to the netadmin1 directory on the remote host with an IP address of 172.16.101.101:

```
Router# copy system:running-config ftp://netadmin1:mypass@172.16.101.101/Rtr2-confg
Write file rtr2-confg on host 172.16.101.101?[confirm]
Building configuration...[OK]
Connected to 172.16.101.101
Router#
```

Store a Startup Configuration File on an FTP Server Example

The following example shows how to store a startup configuration file on a server by using FTP to copy the file:

```
Rtr2# configure terminal
Rtr2(config)# ip ftp username netadmin2
Rtr2(config)# ip ftp password mypass
Rtr2(config)# end
Rtr2# copy nvram:startup-config rcp:
Remote host[]? 172.16.101.101
Name of configuration file to write [rtr2-confg]?
Write file rtr2-confg on host 172.16.101.101?[confirm]
! [OK]
```

Copy Configuration Files from a Network Server to the Router

You can copy configuration files from a TFTP, rcp, or FTP server to the running configuration or startup configuration of the router. You may want to do this for one of the following reasons:

- To restore a backed up configuration file.
- To use the configuration file for another router. For example, you may add another router to your network and want it to have a similar configuration to the original router. By copying the file to the new router, you can change the relevant parts rather than re-creating the whole file.
- To load the same configuration commands on to all the routers in your network so that all the routers have similar configurations.

The **copy {ftp | rcp | tftp:} system:running-config** command loads the configuration files into the router as if you were typing the commands in at the command line. The router does not erase the existing running configuration before adding the commands. If a command in the copied configuration file replaces a command in the existing configuration file, the existing command will be erased. For example, if the copied configuration file contains a different IP address in a particular command than the existing configuration, the IP address in the copied configuration will be used. However, some commands in the existing configuration may not be replaced or negated. In this case, the resulting configuration file will be a mixture of the existing configuration file and the copied configuration file, with the copied configuration file having precedence.

In order to restore a configuration file to an exact copy of a file stored on a server, you need to copy the configuration file directly to the startup configuration (using the **copy {ftp: | rcp: | tftp:} nvram:startup-config** command) and reload the router.

The following sections describe these tasks:

- Copy a Configuration File from a TFTP Server to the Router
- Copy a Configuration File from an rcp Server to the Router
- Copy a Configuration File from an FTP Server to the Router

The protocol you use depends on which type of server you are using. The FTP and rcp transport mechanisms provide faster performance and more reliable delivery of data than TFTP. These improvements are possible because the FTP and rcp transport mechanisms are built on and use the Transmission Control Protocol/Internet Protocol (TCP/IP) stack, which is connection-oriented.

Copy a Configuration File from a TFTP Server to the Router

To copy a configuration file from a TFTP server to the router, use the following commands in EXEC mode:

Step	Command	Purpose
1	copy tftp:[[[/location]/directory]/filename] system:running-config or copy tftp:[[[/location]/directory]/filename] nvram:startup-config	Copy a file from a TFTP server to the router.
2		Reply to any router prompts for additional information or confirmation. The prompting will depend on how much information you provide in the copy command and the current setting of the file prompt command.

In the following example, the software is configured from the file `tokyo-config` at IP address 172.16.2.155:

```
Router1# copy tftp://172.16.2.155/tokyo-config system:running-config
Configure using tokyo-config from 172.16.2.155? [confirm] y
Booting tokyo-config from 172.16.2.155:!!! [OK - 874 bytes]
```

Copy a Configuration File from an rcp Server to the Router

You can copy configuration files from an rcp server to the router.

If you copy the configuration file to a personal computer used as a file server, the computer must support rsh.

Understand the rcp Username

The rcp protocol requires a client to send a remote username on each rcp request to a server. When you copy a configuration file from the router to a server using rcp, the Cisco IOS software sends the first valid username in the following list:

- 1 The username specified in the **copy** command, if a username is specified.
- 2 The username set by the **ip rcmd remote-username** command, if the command is configured.

- 3 The remote username associated with the current TTY (terminal) process. For example, if the user is connected to the router through Telnet and was authenticated through the **username** command, the router software sends the Telnet username as the remote username.
- 4 The router host name.

For the rcp copy request to execute successfully, an account must be defined on the network server for the remote username. If the server has a directory structure, the configuration file or image is written to or copied from the directory associated with the remote username on the server. For example, if the system image resides in the home directory of a user on the server, specify that user's name as the remote username.

Copy a Configuration File from an rcp Server to the Router Tasks

To copy a configuration file from an rcp server to the running configuration or startup configuration, use the following commands beginning in privileged EXEC mode:

Step	Command	Purpose
1	configure terminal	(Optional) Enter configuration mode from the terminal. This step is required only if you override the default remote username (see Step 2).
2	ip rcmd remote-username <i>username</i>	(Optional) Specify the remote username.
3	end	(Optional) Exit configuration mode. This step is required only if you override the default remote username (see Step 2).
4	copy rcp: [[[/[<i>username</i> @] <i>location</i>]/ <i>directory</i>]/ <i>filename</i>] system:running-config or copy rcp: [[[/[<i>username</i> @] <i>location</i>]/ <i>directory</i>]/ <i>filename</i>] nvrn:startup-config	Using rcp, copy the configuration file from a network server to running memory or the startup configuration.
5		Reply to any router prompts for additional information or confirmation. The prompting will depend on how much information you provide in the copy command and the current setting of the file prompt command.

Copy rcp Running-Config Example

The following example copies a configuration file named `host1-config` from the `netadmin1` directory on the remote server with an IP address of `172.16.101.101`, and loads and runs those commands on the router:

```
Router# copy rcp://netadmin1@172.16.101.101/host1-config system:running-config
Configure using host1-config from 172.16.101.101? [confirm]
Connected to 172.16.101.101
Loading 1112 byte file host1-config:![OK]
Router#
%SYS-5-CONFIG: Configured from host1-config by rcp from 172.16.101.101
```

Copy rcp Startup-Config Example

The following example specifies a remote username of netadmin1. Then it copies the configuration file host2-config from the netadmin1 directory on the remote server with an IP address of 172.16.101.101 to the startup configuration.

```
Rtr2# configure terminal
Rtr2(config)# ip rcmd remote-username netadmin1
Rtr2(config)# end
Rtr2# copy rcp: nvram:startup-config
Address of remote host [255.255.255.255]? 172.16.101.101
Name of configuration file[rtr2-config]? host2-config
Configure using host2-config from 172.16.101.101?[confirm]
Connected to 172.16.101.101
Loading 1112 byte file host2-config:![OK]
[OK]
Rtr2#
%SYS-5-CONFIG_NV:Non-volatile store configured from host2-config by rcp from
172.16.101.101
```

Copy a Configuration File from an FTP Server to the Router

You can copy configuration files from an FTP server to the router.

Understand the FTP Username and Password

The FTP protocol requires a client to send a remote username and password on each FTP request to a server. When you copy a configuration file from the router to a server using FTP, the Cisco IOS software sends the first valid username in the following list:

- 1 The username specified in the **copy** command, if a username is specified.
- 2 The username set by the **ip ftp username** command, if the command is configured.
- 3 Anonymous.

The router sends the first valid password in the following list:

- 1 The password specified in the **copy** command, if a password is specified.
- 2 The password set by the **ip ftp password** command, if the command is configured.
- 3 The router forms a password *username@routername.domain*. The variable *username* is the username associated with the current session, *routername* is the configured host name, and *domain* is the domain of the router.

The username and password must be associated with an account on the FTP server. If you are writing to the server, the FTP server must be properly configured to accept the FTP write request from the user on the router.

If the server has a directory structure, the configuration file or image is written to or copied from the directory associated with the username on the server. For example, if the system image resides in the home directory of a user on the server, specify that user's name as the remote username.

Refer to the documentation for your FTP server for more details.

Use the **ip ftp username** and **ip ftp password** commands to specify a username and password for all copies. Include the username in the **copy** command if you want to specify a username for that copy operation only.

Copy a Configuration File from an FTP Server to the Router Tasks

To copy a configuration file from an FTP server to the running configuration or startup configuration, use the following commands beginning in privileged EXEC mode:

Step	Command	Purpose
1	configure terminal	(Optional) Enter configuration mode from the terminal. This step is required only if you override the default remote username or password (see Steps 2 and 3).
2	ip ftp username <i>username</i>	(Optional) Change the default remote username.
3	ip ftp password <i>password</i>	(Optional) Change the default password.
4	end	(Optional) Exit configuration mode. This step is required only if you override the default remote username or password (see Steps 2 and 3).
5	copy ftp:[[[//[username[:password]@]location] <i>/directory]/filename]</i> system:running-config or copy ftp:[[[//[username[:password]@]location] <i>/directory]/filename]</i> nvrn:startup-config	Using FTP, copy the configuration file from a network server to running memory or the startup configuration.
6		Reply to any router prompts for additional information or confirmation. The prompting will depend on how much information you provide in the copy command and the current setting of the file prompt command.

Copy FTP Running-Config Example

The following example copies a host configuration file named host1-config from the netadmin1 directory on the remote server with an IP address of 172.16.101.101, and loads and runs those commands on the router:

```
Router# copy rcp://netadmin1:mypass@172.16.101.101/host1-config system:running-config
Configure using host1-config from 172.16.101.101? [confirm]
Connected to 172.16.101.101
Loading 1112 byte file host1-config:![OK]
Router#
%SYS-5-CONFIG: Configured from host1-config by ftp from 172.16.101.101
```

Copy FTP Startup-Config Example

The following example specifies a remote username of netadmin1. Then it copies the configuration file host2-config from the netadmin1 directory on the remote server with an IP address of 172.16.101.101 to the startup configuration.

```
Rtr2# configure terminal
Rtr2(config)# ip ftp username netadmin1
Rtr2(config)# ip ftp password mypass
Rtr2(config)# end
Rtr2# copy ftp: nvram:startup-config
Address of remote host [255.255.255.255]? 172.16.101.101
Name of configuration file[rtr2-config]? host2-config
Configure using host2-config from 172.16.101.101?[confirm]
Connected to 172.16.101.101
Loading 1112 byte file host2-config:[OK]
[OK]
Rtr2#
%SYS-5-CONFIG_NV:Non-volatile store configured from host2-config by ftp from
172.16.101.101
```

Maintain Configuration Files Larger than NVRAM

To maintain a configuration file that exceeds size of NVRAM, perform one of the tasks in the following sections:

- Compress the Configuration File
- Store the Configuration in Flash Memory (Class A Flash File Systems)
- Load the Configuration Commands from the Network

Compress the Configuration File

The **service compress-config** global configuration command specifies that the configuration file is to be stored compressed in NVRAM. Once the configuration file has been compressed, the router functions normally. When the system is booted, it recognizes that the configuration file is compressed, expands it, and proceeds normally. The **more nvram:startup-config EXEC** command expands the configuration before displaying it.

To compress configuration files, use the following commands beginning in global configuration mode:

Step	Command	Purpose
1	Refer to the appropriate hardware installation and maintenance publication.	Verify that your system's ROMs support file compression. If not, you can install new ROMs that support file compression.
2	service compress-config	Specify that the configuration file is to be compressed.
3	end	Exit global configuration mode.

Step	Command	Purpose
4	Use FTP, rcp, or TFTP to copy the new configuration. If you try to load a configuration that is more than three times larger than the NVRAM size, the following error message is displayed: “[buffer overflow - <i>file-size</i> / <i>buffer-size</i> bytes].” or configure terminal	Enter the new configuration.
5	copy system:running-config nvrām:startup-config	When you have finished changing the running-configuration, save the new configuration.

The size of the configuration must not exceed three times the NVRAM size. For a 128 KB size NVRAM, the largest expanded configuration file size is 384 KB.

The **service compress-config** command works only if you have Cisco IOS Software Release 10 boot ROMs or later. Installing new ROMs is a one-time operation and is necessary only if you do not already have Cisco IOS Release 10 in ROM. If the boot ROMs do not recognize a compressed configuration, the following message is displayed:

```
Boot ROMs do not support NVRAM compression Config NOT written to NVRAM
```

The example below compresses a 129 KB configuration file to 11 KB.

```
Router# configure terminal
Router(config)# service compress-config
Router(config)# end
Router# copy tftp://172.16.2.15/tokyo-config system:running-config
Configure using tokyo-config from 172.16.2.155? [confirm] y
Booting tokyo-config from 172.16.2.155:!!! [OK - 874 bytes]
Router# copy system:running-config nvrām:startup-config
Building configuration...
Compressing configuration from 129648 bytes to 11077 bytes
[OK]
```

Store the Configuration in Flash Memory (Class A Flash File Systems)

On Class A Flash file system routers, you can store the startup configuration in Flash memory by setting the environment variable CONFIG_FILE to a file in internal Flash memory or Flash memory in a PCMCIA slot.

To store the startup configuration in Flash memory, use the following commands beginning in privileged EXEC mode:

Step	Command	Purpose
1	copy nvrām:startup-config flash-filesystem:filename	Copy the current startup configuration to the new location to create the configuration file.
2	configure terminal	Enter global configuration mode.
3	boot buffersize bytes	The buffer that holds the configuration file is usually the size of NVRAM. Larger configurations need larger buffers. Change the size of the buffer that holds the configuration commands.
4	boot config flash-filesystem:filename	Specify that the startup configuration file is to be stored in Flash memory by setting the CONFIG_FILE variable.

Step	Command	Purpose
5	end	Exit global configuration mode.
6	Use FTP, rcp, or TFTP to copy the new configuration. If you try to load a configuration that is more than three times larger than the NVRAM size, the following error message is displayed: “[buffer overflow - <i>file-size</i> / <i>buffer-size</i> bytes].” or configure terminal	Enter the new configuration.
7	copy system:running-config nvram:startup-config	When you have finished changing the running-configuration, save the new configuration.

Refer to the “Specify the CONFIG_FILE Environment Variable (Class A Flash File Systems)” section for more information.

The following example stores the configuration file in slot 0:

```
Router# copy nvram:startup-config slot0:router-config
Router# configure terminal
Router(config)# boot buffersize 129000
Router(config)# boot config slot0:router-config
Router(config)# end
Router# copy system:running-config nvram:startup-config
```

Care must be taken when editing or changing a large configuration. Flash memory space is used every time a **copy system:running-config nvram:startup-config** is issued. Because file management for Flash memory, such as optimizing free space, is not done automatically, you must pay close attention to available Flash memory. Use the **squeeze** command to reclaim used space. Cisco recommends that you use a large-capacity Flash card of at least 20 MB.

Load the Configuration Commands from the Network

You can also store large configurations on FTP, rcp, or TFTP servers and download them at system startup. To use a network server to store large configurations, use the following commands, beginning in privileged EXEC mode:

Step	Command	Purpose
1	copy system:running-config {ftp: rcp: tftp:}	Save the running configuration to an FTP, rcp, or TFTP server.
2	configure terminal	Enter global configuration mode.
3	boot buffersize bytes	The buffer that holds the configuration file is usually the size of NVRAM. Larger configurations need larger buffers. Change the size of the buffer that holds the configuration commands.
4	boot network {ftp:[[<i>[/username[:password]@]location]/directory]/filename} </i> rcp:[[<i>[/username@]location]/directory]/filename} </i> tftp:[[<i>[/location]/directory]/filename]}</i>	Specify that the startup configuration file is to be loaded from the network server at startup.

Step	Command	Purpose
5	service config	Enable the router to download configuration files at system startup.
6	end	Exit global configuration mode.
7	copy system:running-config nvram:startup-config	Save the configuration.

Refer to the “Copy Configuration Files from the Router to a Network Server” and “Configure the Router to Download Configuration Files” sections for more information on these commands.

Copy Configuration Files between Different Locations

On many platforms, you can copy configuration files from one Flash memory device, such as internal Flash memory or a Flash memory card in a PCMCIA slot, to other locations. You can also copy configuration files from an FTP, rcp, or TFTP server to Flash memory.

Copy Configuration Files from Flash Memory to the Startup or Running Configuration

To copy a configuration file from Flash memory directly to your startup configuration in NVRAM or your running configuration, enter one of the following commands in EXEC mode:

Command	Purpose
copy filesystem:[partition-number:][filename] nvram:startup-config	Load a configuration file directly into NVRAM.
copy filesystem:[partition-number:][filename] system:running-config	Copy a configuration file to your running configuration.

The following example copies the file ios-upgrade-1 from partition 4 of the Flash memory PC Card in slot 0 to the router’s startup configurations.

```
Router# copy slot0:4:ios-upgrade-1 nvram:startup-config

Copy 'ios-upgrade-1' from flash device
as 'startup-config' ? [yes/no] yes
[OK]
```

Copy Configuration Files between Flash Memory File Systems

On platforms with multiple Flash memory file systems, you can copy files from one Flash memory file system, such as internal Flash memory or a Flash memory card in a PCMCIA slot, to another Flash memory file system. Copying files to different Flash memory file systems lets you create backup copies of working configurations and duplicate configurations for other routers.

To copy a configuration file between Flash memory file systems, use the following commands in EXEC mode:

Step	Command	Purpose
1	show source-filesystem:	Display the layout and contents of Flash memory to verify the file name.

Step	Command	Purpose
2	<code>copy source-filesystem:[partition-number:][filename] dest-filesystem:[partition-number:][filename]</code>	Copy a configuration file between Flash memory devices.
3	<code>verify dest-filesystem:[partition-number:][filename]</code>	Verify the checksum of the file you copied.

Note The source device and the destination device cannot be the same. For example, the command **copy slot1: slot1:** is invalid.

Copy a Configuration File between Local Flash Memory Devices Example

The following example copies the file running-config from partition 1 of internal Flash memory to partition 1 of slot 1 on a Cisco 3600 series router. In this example, the source partition is not specified, so the router prompts for the partition number.

```
Router# copy flash: slot1:

System flash

Partition      Size      Used      Free      Bank-Size  State      Copy Mode
-----
1              4096K    3070K     1025K     4096K      Read/Write Direct
2             16384K   1671K     14712K     8192K      Read/Write Direct

[Type ?<no> for partition directory; ? for full directory; q to abort]
Which partition? [default = 1]

System flash directory, partition 1:
File Length Name/status
  1  3142748 dirt/network/mars-test/c3600-j-mz.latest
  2    850   running-config
[3143728 bytes used, 1050576 available, 4194304 total]

PCMCIA Slot1 flash directory:
File Length Name/status
  1 1711088 dirt/gate/c3600-i-mz
  2    850   running-config
[1712068 bytes used, 2482236 available, 4194304 total]

Source file name? running-config

Destination file name [running-config]?
Verifying checksum for 'running-config' (file # 2)... OK

Erase flash device before writing? [confirm]
Flash contains files. Are you sure you want to erase? [confirm]

Copy 'running-config' from flash: device
as 'running-config' into slot1: device WITH erase? [yes/no] yes
Erasing device... eeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeeee
...erased
!
[OK - 850 bytes]

Flash device copy took 00:00:30 [hh:mm:ss]
Verifying checksum... OK (0x16)
```

Copy a Configuration File from a Server to Flash Memory

To copy a configuration file from an FTP server to a Flash memory device, use the following commands in privileged EXEC mode:

Step	Command	Purpose
1	configure terminal	(Optional) Enter configuration mode from the terminal. This step is required only if you override the default remote username or password (see Steps 2 and 3).
2	ip ftp username <i>username</i>	(Optional) Specify the remote username.
3	ip ftp password <i>password</i>	(Optional) Specify the remote password.
4	end	(Optional) Exit configuration mode. This step is required only if you override the default remote username (see Steps 2 and 3).
5	copy ftp: [[[//[<i>username:password@</i>] <i>location</i>] <i>/directory</i>]/ <i>filename</i>] <i>flash-filesystem:</i> [<i>partition-number:</i>] <i>filename</i>]	Use FTP, copy the configuration file from a network server to the Flash memory device.
6		Reply to any router prompts for additional information or confirmation. The prompting will depend on how much information you provide in the copy command and the current setting of the file prompt command.

To copy a configuration file from an rcp server to a Flash memory device, use the following commands in privileged EXEC mode:

Step	Command	Purpose
1	configure terminal	(Optional) Enter configuration mode from the terminal. This step is required only if you override the default remote username (see Step 2).
2	ip rcmd remote-username <i>username</i>	(Optional) Specify the remote username.
3	end	(Optional) Exit configuration mode. This step is required only if you override the default remote username (see Step 2).
4	copy rcp: [[[//[<i>username@</i>] <i>location</i>]/ <i>directory</i>]/ <i>filename</i>] <i>flash-filesystem:</i> [<i>partition-number:</i>] <i>filename</i>]	Using rcp, copy the configuration file from a network server to the Flash memory device.
5		Reply to any router prompts for additional information or confirmation. The prompting will depend on how much information you provide in the copy command and the current setting of the file prompt command.

Reexecute the Configuration Commands in Startup Configuration

To copy a configuration file from a TFTP server to the router, use the following commands from EXEC mode:

Step	Command	Purpose
1	<code>copy tftp:[location]/directory/filename</code> <code>flash-filesystem:[partition-number:]filename</code>	Copy the file from a TFTP server to the Flash memory device.
2		Reply to any router prompts for additional information or confirmation. The prompting will depend on how much information you provide in the <code>copy</code> command and the current setting of the <code>file prompt</code> command.

Copy TFTP example for Cisco 7000 Family

On the Cisco 7000 family, the following example copies the router-config file from a TFTP server to the Flash memory card inserted in slot 0 of the Network Processing Engine (NPE) or Route Switch Processor (RSP) card. The copied file has the name new-config.

```
Router# copy tftp:router-config slot0:new-config
```

Reexecute the Configuration Commands in Startup Configuration

To reexecute the commands located in the startup configuration, use the following command in privileged EXEC mode:

Command	Purpose
<code>configure memory</code>	Reexecute the configuration commands located in the startup configuration.

Clear the Configuration Information

You can clear the configuration information from the startup configuration. If you reboot the router with no startup configuration, the router will enter the setup facility so that you can configure the router from scratch.

Clear the Startup Configuration

To clear the contents of your startup configuration, use the following command in EXEC mode:

Command	Purpose
<code>erase nvram:</code>	Clear the contents of your startup configuration.

For all platforms except the Class A Flash file system platforms, this command erases NVRAM. The startup configuration file cannot be restored once it has been deleted.

On Class A Flash file system platforms, when you use the `erase startup-config` command, the router erases or deletes the configuration pointed to by CONFIG_FILE environment variable. If this variable points to NVRAM, the router erases NVRAM. If the CONFIG_FILE environment variable specifies a Flash memory device and configuration filename, the router deletes the configuration file. That is, the router marks the file as “deleted,” rather than erasing it. This feature allows you to recover a “deleted” file.

Delete a Stored Configuration File

To delete a saved configuration from a specific Flash device, use the following command in EXEC mode:

Command	Purpose
<code>delete flash-filesystem:filename</code>	Delete a specified configuration file on a specified Flash device.

On Class A and B Flash file systems, when you delete a specific file in Flash memory, the system marks the file as deleted, allowing you to later recover a “deleted” file using the **undelete** command. Erased files cannot be recovered. To permanently erase the configuration file, use the **squeeze** command.

On Class C Flash file systems, you cannot recover a file that has been deleted.

If you attempt to erase or delete the configuration file specified by the CONFIG_FILE environment variable, the system prompts you to confirm the deletion.

The following example deletes the myconfig file from a Flash memory card inserted in slot 0:

```
Router# delete slot0:myconfig
```

Specify the Startup Configuration File

Normally, the router uses the startup configuration file in NVRAM or the Flash file system specified by the CONFIG_FILE environment variable (Class A Flash file systems only) at startup. See the “Specify the CONFIG_FILE Environment Variable (Class A Flash File Systems)” section for details on setting the CONFIG_FILE variable.

You can also configure the router to automatically request and receive two configuration files from the network server at startup. See the “Configure the Router to Download Configuration Files” section for details.

Specify the CONFIG_FILE Environment Variable (Class A Flash File Systems)

On Class A Flash file systems, you can configure the Cisco IOS software to load the startup configuration file specified by the CONFIG_FILE environment variable. The CONFIG_FILE variable defaults to NVRAM. To change the CONFIG_FILE variable, use the following commands beginning in EXEC mode:

Step	Command	Purpose
1	<code>copy [flash-url ftp-url rcp-url tftp-url system:running-config nvram:startup-config] dest-flash-url</code>	Copy the configuration file to the Flash file system from which the router will load the file upon restart.
2	<code>configure terminal</code>	Enter configuration mode from the terminal.
3	<code>boot config dest-flash-url</code>	Set the CONFIG_FILE environment variable. This step modifies the runtime CONFIG_FILE environment variable.
4	<code>end</code>	Exit configuration mode.
5	<code>copy system:running-config nvram:startup-config</code>	Save this runtime CONFIG_FILE environment variable to your startup configuration.
6	<code>show bootvar</code>	Optionally, verify the contents of the CONFIG_FILE environment variable.

After you specify a location for the startup configuration file, **nvrn:startup-config** is aliased to the new location of the startup configuration file. The **more nvrn:startup-config** command will display the startup configuration, regardless of its location. The **erase nvrn:startup-config** command will erase the contents of NVRAM and delete the file pointed to by the CONFIG_FILE environment variable.

When you save the configuration using the **copy system:running-config nvrn:startup-config** command, the router saves a complete version of the configuration file to the location specified by the CONFIG_FILE environment variable and a distilled version to NVRAM. A distilled version is one that does not contain access list information. If NVRAM contains a complete configuration file, the router prompts you to confirm your overwrite of the complete version with the distilled version. If NVRAM contains a distilled configuration, the router does not prompt you for confirmation and proceeds with overwriting the existing distilled configuration file in NVRAM.

Note If you specify a file in a Flash device as the CONFIG_FILE variable, every time you save your configuration file with the **copy system:running-config nvrn:startup-config** command, the old configuration file is marked as deleted, and the new configuration file is saved to that device. Eventually, Flash memory will be full, since the old configuration files still take up memory. Use the **squeeze** command to permanently delete the old configuration files and reclaim the space.

The following example copies the running configuration file to the first PCMCIA slot of the RSP card in a Cisco 7500 series. This configuration is then used as the startup configuration when the system is restarted.

```
Router# copy system:running-config slot0:config2
Router# configure terminal
Router(config)# boot config slot0:config2
Router(config)# end
Router# copy system:running-config nvrn:startup-config
[ok]
Router# show bootvar
BOOT variable = slot0:rsp-boot-m
CONFIG_FILE variable = nvrn:
Current CONFIG_FILE variable = slot0:config2

Configuration register is 0x010F
```

Configure the Router to Download Configuration Files

You can configure the router to load one or two configuration files at system startup. The configuration files are loaded into memory and read in as if you were typing the commands at the command line. Thus, the configuration for the router will be a mixture of the original startup configuration and the one or two downloaded configuration files.

Network Versus Host Configuration Files

For historical reasons, the first file the router downloads is called the network configuration file. The second file the router downloads is called the host configuration file. Two configuration files can be used when all of the routers on a network use many of the same commands. The network configuration file contains the standard commands used to configure all of the routers. The host configuration files contain the commands specific to one particular host. If you are loading two configuration files, the host configuration file should be the configuration file you want to have precedence over the other file. Both the network and host configuration files must reside on a network server reachable via TFTP, rcp, or FTP, and must be readable.

Understand the rcp Username

The rcp protocol requires a client to send a remote username on each rcp request to a server. When you copy a configuration file from the router to a server using rcp, the Cisco IOS software sends the first valid username in the following list:

- 1 The username specified in the **boot network** or **boot host** command, if a username is specified.
- 2 The username set by the **ip rcmd remote-username** command, if the command is configured.
- 3 The remote username associated with the current TTY (terminal) process. For example, if the user is connected to the router through Telnet and was authenticated through the **username** command, the router software sends the Telnet username as the remote username.
- 4 The router host name.

For the rcp copy request to execute successfully, an account must be defined on the network server for the remote username. If the server has a directory structure, the configuration file or image is written to or copied from the directory associated with the remote username on the server. For example, if the system image resides in the home directory of a user on the server, specify that user's name as the remote username.

If you copy the configuration file to a personal computer used as a file server, the computer must support rsh.

Understand the FTP Username and Password

The FTP protocol requires a client to send a remote username and password on each FTP request to a server. When you copy a configuration file from the router to a server using FTP, the Cisco IOS software sends the first valid username in the following list:

- 1 The username specified in the **copy** command, if a username is specified.
- 2 The username set by the **ip ftp username** command, if the command is configured.
- 3 Anonymous.

The router sends the first valid password in the following list:

- 1 The password specified in the **copy** command, if a password is specified.
- 2 The password set by the **ip ftp password** command, if the command is configured.
- 3 The router forms a password *username@routername.domain*. The variable *username* is the username associated with the current session, *routername* is the configured host name, and *domain* is the domain of the router.

The username and password must be associated with an account on the FTP server. If you are writing to the server, the FTP server must be properly configured to accept the FTP write request from the user on the router.

If the server has a directory structure, the configuration file or image is written to or copied from the directory associated with the username on the server. For example, if the system image resides in the home directory of a user on the server, specify that user's name as the remote username.

Refer to the documentation for your FTP server for more details.

Use the **ip ftp username** and **ip ftp password** commands to specify a username and password for all copies. Include the username in the **copy** command if you want to specify a username for that copy operation only.

Configure the Router to Download Configuration Files Task List

You can specify an ordered list of network configuration and host configuration filenames. The Cisco IOS software scans this list until it successfully loads the appropriate network or host configuration file.

To configure the router to download configuration files at system startup, perform at least one of the tasks described in the following sections:

- Configure the Router to Download the Network Configuration File
- Configure the Router to Download the Host Configuration File

If the router fails to load a configuration file during startup, it tries again every ten minutes (the default setting) until a host provides the requested files. With each failed attempt, the router displays the following message on the console terminal:

```
Booting host-config... [timed out]
```

Refer to the *Internetwork Troubleshooting Guide* publication for troubleshooting procedures.

If there are any problems with the startup configuration file, or if the configuration register is set to ignore NVRAM, the router enters the **setup** command facility. See the “Using Setup for Configuration Changes” chapter in this publication for details on the **setup** command.

Configure the Router to Download the Network Configuration File

To configure the Cisco IOS software to download a network configuration file from a server at startup, use the following commands:

Step	Command	Purpose
1	configure terminal	Enter configuration mode from the terminal.
2	boot network { ftp :[[[// <i>username[:password]</i> @] <i>location</i>] <i>/directory</i>]/ <i>filename</i>] rcp :[[[// <i>username</i> @] <i>location</i>]/ <i>directory</i>]/ <i>filename</i>] tftp :[[[// <i>location</i>]/ <i>directory</i>]/ <i>filename</i>]}	Enter the network configuration filename to download a file using TFTP, rcp, or FTP.
3	service config	Enable the router to automatically load the network file upon restart.
4	end	Exit configuration mode.
5	copy system:running-config nvram:startup-config	Save the configuration file to your startup configuration.

For Step 2, if you do not specify a network configuration filename, the Cisco IOS software uses the default filename `network-config`. If you omit the address, the router uses the broadcast address.

You can specify more than one network configuration file. The software tries them in order entered until it loads one successfully. This procedure can be useful for keeping files with different configuration information loaded on a network server.

Configure the Router to Download the Host Configuration File

To configure the Cisco IOS software to download a host configuration file from a server at startup, use the following commands in global configuration mode:

Step	Command	Purpose
1	configure terminal	Enter configuration mode from the terminal.
2	boot host {ftp:[[[//[username[:password]@]location]/directory]/filename] rcp:[[[//[username@]location]/directory]/filename] tftp:[[[//[location]/directory]/filename]}	Enter the host configuration filename to be download using FTP, rcp, or TFTP.
3	service config	Enable the device to automatically load the host file upon restart.
4	end	Exit configuration mode.
5	copy system:running-config nvram:startup-config	Save the configuration file to your startup configuration.

If you do not specify a host configuration filename, the router uses its own name to form a host configuration filename by converting the name to all lowercase letters, removing all domain information, and appending -config. If no host name information is available, the software uses the default host configuration filename router-config. If you omit the address, the router uses the broadcast address.

You can specify more than one host configuration file. The Cisco IOS software tries them in order entered until it loads one successfully. This procedure can be useful for keeping files with different configuration information loaded on a network server.

Configure the Router to Download Configuration Files at System Startup Example

In the following example, a router is configured to download the host configuration file hostfile1 and the network configuration file networkfile1: The router uses TFTP and the broadcast address to obtain the file.

```
Router# configure terminal
Router(config)# boot host tftp:hostfile1
Router(config)# boot network tftp:networkfile1
Router(config)# service config
Router(config)# end
Router# copy system:running-config nvram:startup-config
```

Specify the Startup Configuration File
