



# Configuring 8 Queues per Interface on the 1-Port Channelized OC12/STM-1 to DS1/E1 and 4-port Gigabit Ethernet Line Cards on Cisco 12000 Series Routers

Part Number: OL-8684-01 (Rev. A1) November 16, 2007

## Feature History

Release	Modification
12.0(26)S	This feature was introduced on the 4-port Gigabit Ethernet line card on Cisco 12000 series routers.
12.0(32)S	This feature was introduced on the 1-port Channelized OC12/STM-1 to DS1/E1 line card on Cisco 12000 series routers.

This feature module contains the following sections:

- [8 Queues per Interface Feature Overview](#)
- [Supported Platforms](#)
- [Supported Standards, MIBs, and RFCs](#)
- [Prerequisites](#)
- [Configuration Tasks](#)
- [Configuration Examples](#)
- [Command Reference](#)
- [Glossary](#)

## 8 Queues per Interface Feature Overview

The Integrated Services Engine (ISE) line cards running Cisco IOS Release 12.0(32)S can now have up to 8 queues per interface.

ISE line cards support two modes for configure queues on an interface:

- Mode 1 (default)—Allows 4 queues per interface. When 4 queues per interface are in operation, 1008 interfaces are possible.

- Mode 2—Allows 8 queues per interface. When 8 queues per port are in operation, only half the number of interfaces are possible (504).

The default is 4 queues. To switch to 8 queues per port, use the **hw-mod slot <slot num> qos interfaces queues 8** command. You are prompted to reset the line card. To reset the line card, use the **hw-mod slot <slot num> reload** command. When the line card comes up, 8 queues are assigned to each interface.

To revert to 4 queues per interface, use the **no** form of the **hw-mod slot <slot num> qos interfaces queues 8** command. You are prompted to reset the line card. To reset the line card, use the **hw-mod slot <slot num> reload** command. When the line card comes up, 4 queues are assigned to each interface.

## Benefits

Customers can now choose between configuring 4 queues per interface with 1008 interfaces or 8 queues per interface with 504 interfaces.

## Restrictions

Using 8 queues per interface restricts the number of possible interfaces to 504, which is half the amount of interfaces that are possible in 4 queue mode.

## Related Features and Technologies

Cisco IOS Quality of Service (QoS) Solutions for Cisco 12000 series routers

## Related Documents

For information on configuring multicast traffic, refer to:

- *Cisco 12000 Series Router Configuration Guide for Cisco IOS Release 12.0S*

Also refer to the Installation and Configuration Guide for a specific Cisco 12000 series router.

## Supported Platforms

The QoS on 8 Queues per Port feature is supported on the following Engine 5 SPAs and line cards on Cisco IOS Release 12.0(26)S on Cisco 12000 series routers:

- 4-port Gigabit Ethernet

The QoS on 8 Queues per Port feature is supported on the following Engine 5 SPAs and line cards on Cisco IOS Release 12.0(32)S on Cisco 12000 series routers:

- 1-port Channelized OC12/STM-1 to DS1/E1

# Supported Standards, MIBs, and RFCs

## Standards

No new or modified standards are supported, and support for existing standards has not been modified.

## MIBs

No new or modified MIBs are supported, and support for existing MIBs has not been modified.

## RFCs

No new or modified RFCs are supported, and support for existing RFCs has not been modified.

## Prerequisites

For 4-port Gigabit Ethernet, Cisco IOS Release 12.0(26)S software running with 4 queues per interface.

For 1-port Channelized OC12/STM-1 to DS1/E1, Cisco IOS Release 12.0(32)S software running with 4 queues per interface.

## Configuration Tasks

The following sections contain configuration tasks for the 8 Queues per Interface feature. Each task in the list is identified as either required or optional.

- [Switching to 8 Queues per Interface—Optional](#)
- [Switching Back to Default of 4 Queues per Interface—Optional](#)
- [Verifying the Number of Queues per Interface](#)

### Switching to 8 Queues per Interface—Optional

Use the following configuration procedure to switch from the default of 4 queues per interface to 8 queues per interface.

	Command	Purpose
Step 1	Router(config)# <b>confi g t</b>	Enter configuration mode.
Step 2	Router(config-if)# <b>hw-mod slot &lt;slot num&gt;</b> <b>qos interfaces queues 8</b>	Switch to 8 queues per interface mode.
Step 3	Router(config-if)# <b>hw-mod slot &lt;slot num&gt;</b> <b>reload</b>	Reload the line card.

### Switching Back to Default of 4 Queues per Interface—Optional

Use the following configuration procedure to switch from 8 queues per interface back to the default of 4 queues per interface.

	Command	Purpose
Step 1	Router(config)# <b>config t</b>	Enter configuration mode.
Step 2	Router(config-if)# <b>no hw-mod slot &lt;slot num&gt; qos interfaces queues 8</b>	Switch to the default of 4 queues per interface mode.
Step 3	Router(config-if)# <b>hw-mod slot &lt;slot num&gt; reload</b>	Reload the line card.

## Verifying the Number of Queues per Interface

Use the following **show** commands to verify the number of queues per interface on the line card.

Command	Purpose
Router# <b>show controller frfab queues</b>	Displays the number of queues on all interfaces.
Router# <b>show controller frfab queues &lt;ifNum&gt;</b>	Displays the number of queues on the specified interface ( <i>ifNum</i> ) and information about each queue.

## Configuration Examples

This section provides the following configuration examples:

- [Example of Switching to 8 Queues per Interface](#)
- [Example of Switching to 4 Queues per Interface](#)
- [Example of Verifying the Number of Queues per Interface](#)

### Example of Switching to 8 Queues per Interface

This example shows how to switch to 8 queues per interface.

```
Router(config)#config t
Router(config-if)#hw-mod slot 6 qos interfaces queues 8
Router(config-if)#hw-mod slot 6 reload
```

### Example of Switching to 4 Queues per Interface

This example shows how to switch back to the default of 4 queues per interface.

```
Router(config)#config t
Router(config-if)#no hw-mod slot 6 qos interfaces queues 8
Router(config-if)#hw-mod slot 6 reload
```

### Example of Verifying the Number of Queues per Interface

This example shows how to verify the number of queues per interface.

```
Router#show controller frfab queues 1022
FrFab Queue
```

```

Interface 1022
Queue#  Head    Tail    Length  Threshold  Enabled/Port
          pkts   pkts   pkts    pkts
=====
4088    0         0         0       500        Y/1022
4089    0         0         0       500        Y/1022
4090    0         0         0       500        Y/1022
4091    0         0         0       500        Y/1022
    
```

```

Port 1022 queue-map configuration:
MinQ 4088      MaxQ 4091
HPR Enabled Y
    
```

Now, the cfg is

```

Serial6/0.1/1:1      unassigned      YES manual down      down
Serial6/0.1/2:1      unassigned      YES manual down      down
Serial6/0.1/3:1      unassigned      YES manual down      down
Serial6/0.1/4:1      unassigned      YES manual down      down
Serial6/0.1/5:1      unassigned      YES manual down      down
Serial6/0.1/6:1      unassigned      YES manual down      down
Serial6/0.1/7:1      unassigned      YES NVRAM  down      down
Serial6/0.1/8:1      unassigned      YES NVRAM  down      down
    
```

Interfaces with mfrs:

```

Serial6/0.1/2:1 MFR2
Serial6/0.1/3:1 MFR3
Serial6/0.1/4:1 MFR4
Serial6/0.1/7:1 MFR1
    
```

## Command Reference

No new or modified commands were introduced for the 8 Queues per Interface feature for Cisco IOS Release 12.0(26)S or Cisco IOS Release 12.0(32)S.

# Glossary

ISE	Integrated Services Engine
MIB	Management Information Base. Database of network management information that is used and maintained by a network management protocol, such as SNMP or CMIP. The value of a MIB object can be changed or retrieved using SNMP or CMIP commands, usually through a GUI network management system. MIB objects are organized in a tree structure that includes public (standard) and private (proprietary) branches.

CCVP, the Cisco logo, and Welcome to the Human Network are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn is a service mark of Cisco Systems, Inc.; and Access Registrar, Aironet, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, iQuick Study, LightStream, Linksys, MeetingPlace, MGX, Networkers, Networking Academy, Network Registrar, PIX, ProConnect, ScriptShare, SMARTnet, StackWise, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0711R)

© 2006 Cisco Systems, Inc. All rights reserved.