



## Cisco IOS AppleTalk Commands

---

# access-list additional-zones

To define the default action to take for access checks that apply to zones, use the **access-list additional-zones** command in global configuration mode. To remove an access list, use the **no** form of this command.

**access-list** *access-list-number* {**deny** | **permit**} **additional-zones**

**no access-list** *access-list-number* **additional-zones**

## Syntax Description

<i>access-list-number</i>	Number of the access list. This is a decimal number from 600 to 699.
<b>deny</b>	Denies access if the conditions are matched.
<b>permit</b>	Permits access if the conditions are matched.

## Defaults

No access lists are predefined.

## Command Modes

Global configuration

## Command History

Release	Modification
10.0	This command was introduced.

## Usage Guidelines

The **access-list additional-zones** command defines the action to take for access checks not explicitly defined with the **access-list zone** command. If you do not specify this command, the default action is to deny other access.

You apply access lists defined with the **access-list additional-zones** command to outgoing routing updates and GetZoneList (GZL) filters (using the **appletalk distribute-list out**, and **appletalk getzonelist-filter** commands). You cannot apply them to data-packet filters (using the **appletalk access-group** command) or to incoming routing update filters (using the **appletalk distribute-list in** command).

## Examples

The following example creates an access list based on AppleTalk zones:

```
access-list 610 deny zone Twilight
access-list 610 permit additional-zones
```

## Related Commands

Command	Description
<b>access-list cable-range</b>	Defines an AppleTalk access list for a cable range (for extended networks only).
<b>access-list includes</b>	Defines an AppleTalk access list that overlaps any part of a range of network numbers or cable ranges (for both extended and nonextended networks).

Command	Description
<b>access-list nbp</b>	Defines an AppleTalk access list entry for a particular NBP named entity, class of NBP named entities, NBP packet type, or NBP named entities belonging to a specific zone.
<b>access-list network</b>	Defines an AppleTalk access list for a single network number (that is, for a nonextended network).
<b>access-list other-access</b>	Defines the default action to take for subsequent access checks that apply to networks or cable ranges.
<b>access-list other-nbps</b>	Defines the default action to take for access checks that apply to NBP packets from named entities not otherwise explicitly denied or permitted.
<b>access-list within</b>	Defines an AppleTalk access list for an extended or a nonextended network whose network number or cable range is included entirely within the specified cable range.
<b>access-list zone</b>	Defines an AppleTalk access list that applies to a zone.
<b>appletalk access-group</b>	Assigns an access list to an interface.
<b>appletalk distribute-list in</b>	Filters routing updates received from other routers over a specified interface.
<b>appletalk distribute-list out</b>	Filters routing updates sent to other routers.
<b>appletalk getzonelist-filter</b>	Filters GZL replies.
<b>appletalk permit-partial-zones</b>	Permits access to the other networks in a zone when access to one of those networks is denied.

## access-list cable-range

To define an AppleTalk access list for a cable range (for extended networks only), use the **access-list cable-range** command in global configuration mode. To remove an access list, use the **no** form of this command.

```
access-list access-list-number {deny | permit} cable-range cable-range
[broadcast-deny | broadcast-permit]
```

```
no access-list access-list-number [{deny | permit} cable-range cable-range
[broadcast-deny | broadcast-permit]]
```

### Syntax Description

<i>access-list-number</i>	Number of the access list. This is a decimal number from 600 to 699.
<b>deny</b>	Denies access if the conditions are matched.
<b>permit</b>	Permits access if the conditions are matched.
<i>cable-range</i>	Cable range value. The argument specifies the start and end of the cable range, separated by a hyphen. These values are decimal numbers from 1 to 65279. The starting network number must be less than or equal to the ending network number.
<b>broadcast-deny</b>	(Optional) Denies access to broadcast packets if the conditions are matched.
<b>broadcast-permit</b>	(Optional) Permits access to broadcast packets if the conditions are met.

### Defaults

No access lists are predefined.

### Command Modes

Global configuration

### Command History

Release	Modification
10.0	This command was introduced.

### Usage Guidelines

When used as a routing update filter, the **access-list cable-range** command affects matching on extended networks only. The conditions defined by this access list are used only when a cable range in a routing update exactly matches that specified in the **access-list cable-range** command. The conditions are never used to match a network number (for a nonextended network).

When used as a data-packet filter, the **access-list cable-range** command affects matching on any type of network number. The conditions defined by this access list are used only when the packet's source network lies in the range defined by the access list.

You apply access lists defined with the **access-list cable-range** command to data-packet and routing-update filters (using the **appletalk access-group**, **appletalk distribute-list in**, and **appletalk distribute-list out** commands). You cannot apply them to GZL filters (using the **appletalk getzonelist-filter** command).

To delete an access list, specify the minimum number of keywords and arguments needed to delete the proper access list. For example, to delete the entire access list, use the following command:

```
no access-list access-list-number
```

To delete the access list for a specific network, use the following command:

```
no access-list access-list-number {deny | permit} cable-range cable-range
```

Priority queuing for AppleTalk operates on the destination network number, not the source network number.

### Examples

The following access list forwards all packets except those from cable range 10 to 20:

```
access-list 600 deny cable-range 10-20
access-list 600 permit other-access
```

### Related Commands

Command	Description
<a href="#">access-list additional-zones</a>	Defines the default action to take for access checks that apply to zones.
<a href="#">access-list includes</a>	Defines an AppleTalk access list that overlaps any part of a range of network numbers or cable ranges (for both extended and nonextended networks).
<a href="#">access-list nbp</a>	Defines an AppleTalk access list entry for a particular NBP named entity, class of NBP named entities, NBP packet type, or NBP named entities belonging to a specific zone.
<a href="#">access-list network</a>	Defines an AppleTalk access list for a single network number (that is, for a nonextended network).
<a href="#">access-list other-access</a>	Defines the default action to take for subsequent access checks that apply to networks or cable ranges.
<a href="#">access-list other-nbps</a>	Defines the default action to take for access checks that apply to NBP packets from named entities not otherwise explicitly denied or permitted.
<a href="#">access-list within</a>	Defines an AppleTalk access list for an extended or a nonextended network whose network number or cable range is included entirely within the specified cable range.
<a href="#">access-list zone</a>	Defines an AppleTalk access list that applies to a zone.
<a href="#">appletalk access-group</a>	Assigns an access list to an interface.
<a href="#">appletalk distribute-list in</a>	Filters routing updates received from other routers over a specified interface.
<a href="#">appletalk distribute-list out</a>	Filters routing updates sent to other routers.
<a href="#">appletalk getzonelist-filter</a>	Filters GZL replies.
<a href="#">priority-list protocol</a>	Establishes queuing priorities based on the protocol type.

## access-list includes

To define an AppleTalk access list that overlaps any part of a range of network numbers or cable ranges (for both extended and nonextended networks), use the **access-list includes** command in global configuration mode. To remove an access list, use the **no** form of this command.

```
access-list access-list-number {deny | permit} includes cable-range
[broadcast-deny | broadcast-permit]
```

```
no access-list access-list-number {deny | permit} includes cable-range
[broadcast-deny | broadcast-permit]
```

### Syntax Description

<i>access-list-number</i>	Number of the access list. This is a decimal number from 600 to 699.
<b>deny</b>	Denies access if the conditions are matched.
<b>permit</b>	Permits access if the conditions are matched.
<i>cable-range</i>	Cable range or network number. The argument specifies the start and end of the cable range, separated by a hyphen. These values are decimal numbers from 1 to 65279. The starting network number must be less than or equal to the ending network number. To specify a network number, set the starting and ending network numbers to the same value.
<b>broadcast-deny</b>	(Optional) Denies access to broadcast packets if the conditions are matched.
<b>broadcast-permit</b>	(Optional) Permits access to broadcast packets if the conditions are met.

### Defaults

No access lists are predefined.

### Command Modes

Global configuration

### Command History

Release	Modification
10.0	This command was introduced.

### Usage Guidelines

When used as a routing update filter, the **access-list includes** command affects matching on extended and nonextended AppleTalk networks. The conditions defined by this access list are used when a cable range or network number overlaps, either partially or completely, one (or more) of those specified in the **access-list includes** command.

When used as a data-packet filter, the conditions defined by this access list are used when the packet's source network lies in the range defined in the **access-list includes** command.

You apply access lists defined with the **access-list includes** command to data-packet and routing-update filters (using the **appletalk access-group**, **appletalk distribute-list in**, and **appletalk distribute-list out** commands). You cannot apply them to GZL filters (using the **appletalk getzonelist-filter** command).

To delete an access list, specify the minimum number of keywords and arguments needed to delete the proper access list. For example, to delete the entire access list, use the following command:

```
no access-list access-list-number
```

To delete the access list for a specific network, use the following command:

```
no access-list access-list-number {deny | permit} includes cable-range
```

Priority queuing for AppleTalk operates on the destination network number, not the source network number.

### Examples

The following example defines an access list that permits access to any network or cable range that overlaps any part of the range 10 to 20. This means, for example, that cable ranges 13 to 16 and 17 to 25 will be permitted. This access list also permits all other ranges.

```
access-list 600 permit includes 10-20
access-list 600 permit other-access
```

### Related Commands

Command	Description
<a href="#">access-list additional-zones</a>	Defines the default action to take for access checks that apply to zones.
<a href="#">access-list cable-range</a>	Defines an AppleTalk access list for a cable range (for extended networks only).
<a href="#">access-list nbp</a>	Defines an AppleTalk access list entry for a particular NBP named entity, class of NBP named entities, NBP packet type, or NBP named entities belonging to a specific zone.
<a href="#">access-list network</a>	Defines an AppleTalk access list for a single network number (that is, for a nonextended network).
<a href="#">access-list other-access</a>	Defines the default action to take for subsequent access checks that apply to networks or cable ranges.
<a href="#">access-list other-nbps</a>	Defines the default action to take for access checks that apply to NBP packets from named entities not otherwise explicitly denied or permitted.
<a href="#">access-list within</a>	Defines an AppleTalk access list for an extended or a nonextended network whose network number or cable range is included entirely within the specified cable range.
<a href="#">access-list zone</a>	Defines an AppleTalk access list that applies to a zone.
<a href="#">appletalk access-group</a>	Assigns an access list to an interface.
<a href="#">appletalk distribute-list in</a>	Filters routing updates received from other routers over a specified interface.
<a href="#">appletalk distribute-list out</a>	Filters routing updates sent to other routers.
<a href="#">appletalk getzonelist-filter</a>	Filters GZL replies.
<a href="#">priority-list protocol</a>	Establishes queuing priorities based on the protocol type.

## access-list nbp

To define an AppleTalk access list entry for a particular Name Binding Protocol (NBP) named entity, class of NBP named entities, NBP packet type, or NBP named entities that belong to a specific zone, use the **access-list nbp** command in global configuration mode. To remove an NBP access list entry from the access list, use the **no** form of this command.

```
access-list access-list-number {deny | permit} nbp sequence-number {BrRq | FwdRq | Lookup | LkReply | object string | type string | zone string}
```

```
no access-list access-list-number {deny | permit} nbp sequence-number {BrRq | FwdRq | Lookup | LkReply | object string | type string | zone string}
```

Syntax Description		
<i>access-list-number</i>		Number of the access list. This is a decimal number from 600 to 699.
<b>deny</b>		Denies access if conditions are matched.
<b>permit</b>		Permits access if conditions are matched.
<i>sequence-number</i>		Number used to tie together two or three portions of an NBP name tuple and to keep track of the number of <b>access-list nbp</b> entries in an access list. Each command entry must have a sequence number.
<b>BrRq</b>		Broadcast Request packet type.
<b>FwdRq</b>		Forward Request packet type.
<b>Lookup</b>		Lookup packet type.
<b>LkReply</b>		Lookup Reply packet type.
<b>object</b>		Characterizes <i>string</i> as the portion of an NBP name that identifies a particular <b>object</b> or named entity.
<i>string</i>		Portion of an NBP name identifying the <b>object</b> , <b>type</b> , or <b>zone</b> of a named entity. The name string can be up to 32 characters long, and it can include special characters from the Apple Macintosh character set. To include a special character, type a colon followed by two hexadecimal characters. For an NBP name with a leading space, enter the first character as the special sequence :20.
<b>type</b>		Characterizes <i>string</i> as the portion of an NBP name that identifies a category or <b>type</b> of named entity.
<b>zone</b>		Characterizes <i>string</i> as the portion of an NBP name that identifies an AppleTalk <b>zone</b> .

**Defaults** No particular access list entry for an NBP named entity is defined, and the default filtering specified by the **access-list other-nbps** command takes effect.

**Command Modes** Global configuration

Command History	Release	Modification
	11.0	This command was introduced.

## Usage Guidelines

The **access-list nbp** command defines the action to take for filtering NBP packets from a particular **object** (particular named entity), **type** (class of named entities), or **zone** (AppleTalk zone in which named entities reside), or for a particular NBP packet type, superseding the default action for NBP packets from all named entities specified by the **access-list other-nbps** command. For each command that you enter, you must specify a sequence number.

The sequence number serves two purposes:

- Its principal purpose is to allow you to associate two or three portions of an NBP three-part name, referred to as an NBP tuple. To do this, you enter two or three commands having the same sequence number but each specifying a different keyword and NBP name portion: **object**, **type**, or **zone**. The same sequence number binds them together. This provides you with the ability to restrict forwarding of NBP packets at any level, down to a single named entity.
- Its second purpose is to allow you to keep track of the number of **access-list nbp** entries you have made. You must enter a sequence number even if you do not use it to associate portions of an NBP name.

## Examples

The following example adds entries to access list number 607 to allow forwarding of NBP packets from specific sources and deny forwarding of NBP packets from all other sources. The first command adds an entry that allows NBP packets from all printers of type LaserWriter. The second command adds an entry that allows NBP packets from all AppleTalk file servers of type AFPServer. The third command adds an entry that allows NBP packets from all applications called HotShotPaint. For example, there might be an application with a **zone** name of Accounting and an application with a **zone** name of engineering, both having the object name of HotShotPaint. NBP packets forwarded from both applications will be allowed.

The **access-list other-nbps** command denies forwarding of NBP packets from all other sources.

```
access-list 607 permit nbp 1 type LaserWriter
access-list 607 permit nbp 2 type AFPServer
access-list 607 permit nbp 3 object HotShotPaint
access-list 607 deny other-nbps
access-list 607 permit other-access
```

The following example adds entries to access list number 608 to deny forwarding of NBP packets from two specific servers whose fully qualified NBP names are specified. It permits forwarding of NBP packets from all other sources.

```
access-list 608 deny nbp 1 object ServerA
access-list 608 deny nbp 1 type AFPServer
access-list 608 deny nbp 1 zone Bld3
access-list 608 deny nbp 2 object ServerB
access-list 608 deny nbp 2 type AFPServer
access-list 608 deny nbp 2 zone Bld3
access-list 608 permit other-nbps
access-list 608 permit other-access
```

The following example denies forwarding of NBP Lookup Reply packets for all named entities. It permits forwarding of other NBP packet types from all other sources.

```
access-list 600 deny nbp 1 LkReply
access-list 600 permit other-nbps
access-list 600 permit other-access
```

The following example creates an access list that denies forwarding of these packets:

- All NBP Lookup Reply packets
- NBP packets from the server named Bob's Server

- Packets from all AppleTalk file servers of type AFPServer
- All NBP Lookup Reply packets that contain the specified named entities belonging to the zone *twilight*

```
access-list 600 deny nbp 1 LkReply
access-list 600 deny nbp 1 object Bob's Server
access-list 600 deny nbp 1 type AFPServer
access-list 600 deny nbp 1 zone twilight
access-list 600 permit other-nbps
access-list 600 permit other-access
```

**Related Commands**

Command	Description
<a href="#">access-list additional-zones</a>	Defines the default action to take for access checks that apply to zones.
<a href="#">access-list cable-range</a>	Defines an AppleTalk access list for a cable range (for extended networks only).
<a href="#">access-list includes</a>	Defines an AppleTalk access list that overlaps any part of a range of network numbers or cable ranges (for both extended and nonextended networks).
<a href="#">access-list network</a>	Defines an AppleTalk access list for a single network number (that is, for a nonextended network).
<a href="#">access-list other-access</a>	Defines the default action to take for subsequent access checks that apply to networks or cable ranges.
<a href="#">access-list other-nbps</a>	Defines the default action to take for access checks that apply to NBP packets from named entities not otherwise explicitly denied or permitted.
<a href="#">access-list within</a>	Defines an AppleTalk access list for an extended or a nonextended network whose network number or cable range is included entirely within the specified cable range.
<a href="#">access-list zone</a>	Defines an AppleTalk access list that applies to a zone.
<a href="#">appletalk access-group</a>	Assigns an access list to an interface.
<a href="#">appletalk distribute-list in</a>	Filters routing updates received from other routers over a specified interface.
<a href="#">appletalk distribute-list out</a>	Filters routing updates sent to other routers.
<a href="#">appletalk getzonelist-filter</a>	Filters GZL replies.
<a href="#">priority-list protocol</a>	Establishes queueing priorities based on the protocol type.

# access-list network

To define an AppleTalk access list for a single network number (that is, for a nonextended network), use the **access-list network** command in global configuration mode. To remove an access list, use the **no** form of this command.

```
access-list access-list-number {deny | permit} network network
[broadcast-deny | broadcast-permit]
```

```
no access-list access-list-number {deny | permit} network network
[broadcast-deny | broadcast-permit]
```

## Syntax Description

<i>access-list-number</i>	Number of the access list. This is a decimal number from 600 to 699.
<b>deny</b>	Denies access if the conditions are matched.
<b>permit</b>	Permits access if the conditions are matched.
<i>network</i>	AppleTalk network number.
<b>broadcast-deny</b>	(Optional) Denies access to broadcast packets if the conditions are matched.
<b>broadcast-permit</b>	(Optional) Permits access to broadcast packets if the conditions are met.

## Defaults

No access lists are predefined.

## Command Modes

Global configuration

## Command History

Release	Modification
10.0	This command was introduced.

## Usage Guidelines

When used as a routing-update filter, the **access-list network** command affects matching on nonextended networks only. The conditions defined by this access list are used only when the nonextended number in a routing update matches a network number specified in one of the **access-list network** commands. The conditions are never used to match a cable range (for an extended network) even if the cable range has the same starting and ending number.

When used as a data-packet filter, the conditions defined by this access list are used only when the packet's source network matches the network number specified in the **access-list network** command.

You apply access lists defined with the **access-list network** command to data-packet and routing-update filters (using the **appletalk access-group**, **appletalk distribute-list in**, and **appletalk distribute-list out** commands). You cannot apply access lists to GZL filters (using the **appletalk getzonelist-filter** command).

In software releases before 9.0, the syntax of this command was **access-list access-list-number {deny | permit} network**. The current version of the software is still able to interpret commands in this format if it finds them in a configuration or boot file. However, it is recommended that you update the commands in your configuration or boot files to match the current syntax.

Use the **no access-list** command with the *access-list-number* argument only to remove an entire access list from the configuration. Specify the optional arguments to remove a particular clause.

To delete an access list, specify the minimum number of keywords and arguments needed to delete the proper access list. For example, to delete the entire access list, use the following command:

```
no access-list access-list-number
```

To delete the access list for a specific network, use the following command:

```
no access-list access-list-number {deny | permit} network network
```

Priority queuing for AppleTalk operates on the destination network number, not the source network number.

### Examples

The following example defines an access list that forwards all packets except those destined for networks 1 and 2:

```
access-list 650 deny network 1
access-list 650 deny network 2
access-list 650 permit other-access
```

### Related Commands

Command	Description
<a href="#">access-list additional-zones</a>	Defines the default action to take for access checks that apply to zones.
<a href="#">access-list cable-range</a>	Defines an AppleTalk access list for a cable range (for extended networks only).
<a href="#">access-list includes</a>	Defines an AppleTalk access list that overlaps any part of a range of network numbers or cable ranges (for both extended and nonextended networks).
<a href="#">access-list nbp</a>	Defines an AppleTalk access list entry for a particular NBP named entity, class of NBP named entities, NBP packet type, or NBP named entities belonging to a specific zone.
<a href="#">access-list other-access</a>	Defines the default action to take for subsequent access checks that apply to networks or cable ranges.
<a href="#">access-list other-nbps</a>	Defines the default action to take for access checks that apply to NBP packets from named entities not otherwise explicitly denied or permitted.
<a href="#">access-list within</a>	Defines an AppleTalk access list for an extended or a nonextended network whose network number or cable range is included entirely within the specified cable range.
<a href="#">access-list zone</a>	Defines an AppleTalk access list that applies to a zone.
<a href="#">appletalk access-group</a>	Assigns an access list to an interface.
<a href="#">appletalk distribute-list in</a>	Filters routing updates received from other routers over a specified interface.
<a href="#">appletalk distribute-list out</a>	Filters routing updates sent to other routers.
<a href="#">appletalk getzonelist-filter</a>	Filters GZL replies.
<a href="#">priority-list protocol</a>	Establishes queuing priorities based on the protocol type.

# access-list other-access

To define the default action to take for subsequent access checks that apply to networks or cable ranges, use the **access-list other-access** command in global configuration mode. To remove an access list, use the **no** form of this command.

```
access-list access-list-number {deny | permit} other-access
```

```
no access-list access-list-number other-access
```

## Syntax Description

<i>access-list-number</i>	Number of the access list. This is a decimal number from 600 to 699.
<b>deny</b>	Denies access if the conditions are matched.
<b>permit</b>	Permits access if the conditions are matched.

## Defaults

No access lists are predefined.

## Command Modes

Global configuration

## Command History

Release	Modification
11.0	This command was introduced.

## Usage Guidelines

The **access-list other-access** command defines the action to take for access checks not explicitly defined with an **access-list network**, **access-list cable-range**, **access-list includes**, or **access-list within** command. If you do not specify this command, the default action is to deny other access.

You apply access lists defined with the **access-list other-access** command to data-packet and routing-update filters (using the **appletalk access-group**, **appletalk distribute-list in**, and **appletalk distribute-list out** commands). You cannot apply them to GZL filters (using the **appletalk getzonelist-filter** command).

In software releases before 9.0, the syntax of this command was **access-list access-list-number {deny | permit} -1**. The current version of the software is still able to interpret commands in this format if it finds them in a configuration or boot file. However, it is recommended that you update the commands in your configuration or boot files to match the current syntax.

Priority queuing for AppleTalk operates on the destination network number, not the source network number.

## Examples

The following example defines an access list that forwards all packets except those destined for networks 1 and 2:

```
access-list 650 deny network 1
access-list 650 deny network 2
access-list 650 permit other-access
```

Related Commands	Command	Description
	<b>access-list additional-zones</b>	Defines the default action to take for access checks that apply to zones.
	<b>access-list cable-range</b>	Defines an AppleTalk access list for a cable range (for extended networks only).
	<b>access-list includes</b>	Defines an AppleTalk access list that overlaps any part of a range of network numbers or cable ranges (for both extended and nonextended networks).
	<b>access-list nbp</b>	Defines an AppleTalk access list entry for a particular NBP named entity, class of NBP named entities, NBP packet type, or NBP named entities belonging to a specific zone.
	<b>access-list network</b>	Defines an AppleTalk access list for a single network number (that is, for a nonextended network).
	<b>access-list other-nbps</b>	Defines the default action to take for access checks that apply to NBP packets from named entities not otherwise explicitly denied or permitted.
	<b>access-list within</b>	Defines an AppleTalk access list for an extended or a nonextended network whose network number or cable range is included entirely within the specified cable range.
	<b>access-list zone</b>	Defines an AppleTalk access list that applies to a zone.
	<b>appletalk access-group</b>	Assigns an access list to an interface.
	<b>appletalk distribute-list in</b>	Filters routing updates received from other routers over a specified interface.
	<b>appletalk distribute-list out</b>	Filters routing updates sent to other routers.
	<b>priority-list protocol</b>	Establishes queuing priorities based on the protocol type.

## access-list other-nbps

To define the default action to take for access checks that apply to Name Binding Protocol (NBP) packets from named entities not otherwise explicitly denied or permitted, use the **access-list other-nbps** command in global configuration mode. To remove an access list, use the **no** form of this command.

```
access-list access-list-number {deny | permit} other-nbps
```

```
no access-list access-list-number {deny | permit} other-nbps
```

Syntax Description		
<i>access-list-number</i>	Number of the access list for AppleTalk. This is a decimal number from 600 to 699.	
<b>deny</b>	Denies access if conditions are matched.	
<b>permit</b>	Permits access if conditions are matched.	

**Defaults** Access is denied.

**Command Modes** Global configuration

Command History	Release	Modification
	11.0	This command was introduced.

**Usage Guidelines** The **access-list other-nbps** command defines the action to take for filtering of NBP packets from named entities not explicitly defined by an **access-list nbp** command. It allows you to implement the default AppleTalk network security state at the named entity level. Any **access-list nbp** commands you enter affect a particular named entity object, class of named entities, or all named entities within a zone. This command sets the security state for all other NBP named entities. If you do not specify this command, the default action is to deny access.

You can use this command to create an entry in an access list before or after you issue **access-list nbp** commands. The order of the command in the access list is irrelevant.

**Examples** The following example permits forwarding of all NBP packets from all sources except AppleTalk file servers of type AFPServer:

```
access-list 607 deny nbp 2 type AFPServer
access-list 607 permit other-nbps
```

Related Commands	Command	Description
	<b>access-list additional-zones</b>	Defines the default action to take for access checks that apply to zones.
	<b>access-list cable-range</b>	Defines an AppleTalk access list for a cable range (for extended networks only).
	<b>access-list includes</b>	Defines an AppleTalk access list that overlaps any part of a range of network numbers or cable ranges (for both extended and nonextended networks).
	<b>access-list nbp</b>	Defines an AppleTalk access list entry for a particular NBP named entity, class of NBP named entities, NBP packet type, or NBP named entities belonging to a specific zone.
	<b>access-list network</b>	Defines an AppleTalk access list for a single network number (that is, for a nonextended network).
	<b>access-list other-access</b>	Defines the default action to take for subsequent access checks that apply to networks or cable ranges.
	<b>access-list within</b>	Defines an AppleTalk access list for an extended or a nonextended network whose network number or cable range is included entirely within the specified cable range.
	<b>access-list zone</b>	Defines an AppleTalk access list that applies to a zone.
	<b>appletalk access-group</b>	Assigns an access list to an interface.
	<b>appletalk distribute-list in</b>	Filters routing updates received from other routers over a specified interface.
	<b>appletalk distribute-list out</b>	Filters routing updates sent to other routers.
	<b>appletalk getzonelist-filter</b>	Filters GZL replies.
	<b>priority-list protocol</b>	Establishes queueing priorities based on the protocol type.

# access-list within

To define an AppleTalk access list for an extended or a nonextended network whose network number or cable range is included entirely within the specified cable range, use the **access-list within** command in global configuration mode. To remove this access list, use the **no** form of this command.

```
access-list access-list-number {deny | permit} within cable-range
```

```
no access-list access-list-number [{deny | permit} within cable-range]
```

## Syntax Description

<i>access-list-number</i>	Number of the access list. This is a decimal number from 600 to 699.
<b>deny</b>	Denies access if the conditions are matched.
<b>permit</b>	Permits access if the conditions are matched.
<i>cable-range</i>	Cable range or network number. The argument specifies the start and end of the cable range, separated by a hyphen. These values are decimal numbers from 1 to 65279. The starting network number must be less than or equal to the ending network number. To specify a network number, set the starting and ending network numbers to the same value.

## Defaults

No access lists are predefined.

## Command Modes

Global configuration

## Command History

Release	Modification
10.0	This command was introduced.

## Usage Guidelines

When used as a routing update filter, the **access-list within** command affects matching on extended and nonextended AppleTalk networks. The conditions defined by this access list are used when a cable range or network number overlaps, either partially or completely, one (or more) of those specified in the **access-list within** command.

When used as a data-packet filter, the conditions defined by this access list are used when the packet's source network lies in the range defined in the **access-list within** command.

You apply access lists defined with the **access-list within** command to data-packet and routing-update (using the **appletalk access-group**, **appletalk distribute-list in**, and **appletalk distribute-list out**). You cannot apply them to GZL filters (using the **appletalk getzonelist-filter** command).

To delete an access list, specify the minimum number of keywords and arguments needed to delete the proper access list. For example, to delete the entire access list, use the following command:

```
no access-list access-list-number
```

To delete the access list for a specific network, use the following command:

```
no access-list access-list-number {deny | permit} within cable-range
```

Priority queuing for AppleTalk operates on the destination network number, not the source network number.

### Examples

The following example defines an access list that permits access to any network or cable range that is completely included in the range 10 to 20. This means, for example, that cable range 13 to 16 will be permitted, but cable range 17 to 25 will not be. The second line of the access list permits all other packets.

```
access-list 600 permit within 10-20
access-list 600 permit other-access
```

### Related Commands

Command	Description
<a href="#">access-list additional-zones</a>	Defines the default action to take for access checks that apply to zones.
<a href="#">access-list cable-range</a>	Defines an AppleTalk access list for a cable range (for extended networks only).
<a href="#">access-list includes</a>	Defines an AppleTalk access list that overlaps any part of a range of network numbers or cable ranges (for both extended and nonextended networks).
<a href="#">access-list nbp</a>	Defines an AppleTalk access list entry for a particular NBP named entity, class of NBP named entities, NBP packet type, or NBP named entities belonging to a specific zone.
<a href="#">access-list network</a>	Defines an AppleTalk access list for a single network number (that is, for a nonextended network).
<a href="#">access-list other-access</a>	Defines the default action to take for subsequent access checks that apply to networks or cable ranges.
<a href="#">access-list other-nbps</a>	Defines the default action to take for access checks that apply to NBP packets from named entities not otherwise explicitly denied or permitted.
<a href="#">access-list zone</a>	Defines an AppleTalk access list that applies to a zone.
<a href="#">appletalk access-group</a>	Assigns an access list to an interface.
<a href="#">appletalk distribute-list in</a>	Filters routing updates received from other routers over a specified interface.
<a href="#">appletalk distribute-list out</a>	Filters routing updates sent to other routers.
<a href="#">appletalk getzonelist-filter</a>	Filters GZL replies.
<a href="#">priority-list protocol</a>	Establishes queueing priorities based on the protocol type.

# access-list zone

To define an AppleTalk access list that applies to a zone, use the **access-list zone** command in global configuration mode. To remove an access list, use the **no** form of this command.

```
access-list access-list-number { deny | permit } zone zone-name
```

```
no access-list access-list-number [{ deny | permit } zone zone-name]
```

## Syntax Description

<i>access-list-number</i>	Number of the access list. This is a decimal number from 600 to 699.
<b>deny</b>	Denies access if the conditions are matched.
<b>permit</b>	Permits access if the conditions are matched.
<i>zone-name</i>	Name of the zone. The name can include special characters from the Apple Macintosh character set. To include a special character, type a colon followed by two hexadecimal characters. For zone names with a leading space character, enter the first character as the special sequence :20.

## Defaults

No access lists are predefined.

## Command Modes

Global configuration

## Command History

Release	Modification
10.0	This command was introduced.

## Usage Guidelines

You apply access lists defined with the **access-list zone** command to outgoing routing update and GZL filters (using the **appletalk distribute-list out** and **appletalk getzonelist-filter** commands). You cannot apply them to data-packet filters (using the **appletalk access-group** command) or to incoming routing update filters (using the **appletalk distribute-list in** command).

To delete an access list, specify the minimum number of keywords and arguments needed to delete the proper access list. For example, to delete the entire access list, use the following command:

```
no access-list access-list-number
```

To delete the access list for a specific network, use the following command:

```
no access-list access-list-number { deny | permit } zone zone-name
```

Use the **access-list additional-zones** command to define the action to take for access checks not explicitly defined with the **access-list zone** command.

**Note**

AppleTalk zone access lists on an Enhanced Internet Gateway Routing Protocol (Enhanced IGRP) interface will not filter the distribution of Enhanced IGRP routes. When the **appletalk distribute-list out** command is applied to an Enhanced IGRP interface, any **access-list zone** commands in the specified access list will be ignored.

**Examples**

The following example creates an access list based on AppleTalk zones:

```
access-list 610 deny zone Twilight
access-list 610 permit additional-zones
```

**Related Commands**

Command	Description
<a href="#">access-list additional-zones</a>	Defines the default action to take for access checks that apply to zones.
<a href="#">access-list cable-range</a>	Defines an AppleTalk access list for a cable range (for extended networks only).
<a href="#">access-list includes</a>	Defines an AppleTalk access list that overlaps any part of a range of network numbers or cable ranges (for both extended and nonextended networks).
<a href="#">access-list nbp</a>	Defines an AppleTalk access list entry for a particular NBP named entity, class of NBP named entities, NBP packet type, or NBP named entities belonging to a specific zone.
<a href="#">access-list network</a>	Defines an AppleTalk access list for a single network number (that is, for a nonextended network).
<a href="#">access-list other-access</a>	Defines the default action to take for subsequent access checks that apply to networks or cable ranges.
<a href="#">access-list other-nbps</a>	Defines the default action to take for access checks that apply to NBP packets from named entities not otherwise explicitly denied or permitted.
<a href="#">access-list within</a>	Defines an AppleTalk access list for an extended or a nonextended network whose network number or cable range is included entirely within the specified cable range.
<a href="#">appletalk access-group</a>	Assigns an access list to an interface.
<a href="#">appletalk distribute-list in</a>	Filters routing updates received from other routers over a specified interface.
<a href="#">appletalk distribute-list out</a>	Filters routing updates sent to other routers.
<a href="#">appletalk getzonelist-filter</a>	Filters GZL replies.
<a href="#">appletalk permit-partial-zones</a>	Permits access to the other networks in a zone when access to one of those networks is denied.

# appletalk access-group

To assign an access list to an interface, use the **appletalk access-group** command in interface configuration mode. To remove the access list, use the **no** form of this command.

**appletalk access-group** *access-list-number* [**in** | **out**]

**no appletalk access-group** *access-list-number*

## Syntax Description

<i>access-list-number</i>	Number of the access list. This is a decimal number from 600 to 699.
<b>in</b>	(Optional) Filters on incoming packets.
<b>out</b>	(Optional) Filters on outgoing packets. This is the default direction.

## Defaults

No access lists are predefined. The default interface direction is out.

## Command Modes

Interface configuration

## Command History

Release	Modification
10.0	This command was introduced.

## Usage Guidelines

The **appletalk access-group** command applies data-packet filters or NBP-packet filters to an inbound or outbound interface. These filters check data packets being received or sent on an interface. If the source network of the packets has access denied, these packets are not processed and are discarded.

When you apply a data-packet filter to an interface, you should ensure that all networks or cable ranges within a zone are governed by the same filters.

## Examples

The following example applies access list 601 to outbound Ethernet interface 0:

```
access-list 601 deny cable-range 1-10
access-list 601 permit other-access
interface ethernet 0
  appletalk access-group 601
```

The following example applies access list 600 to inbound Ethernet interface 0:

```
interface ethernet 0
  appletalk access-group 600 in
```

Related Commands	Command	Description
	<a href="#">access-list cable-range</a>	Defines an AppleTalk access list for a cable range (for extended networks only).
	<a href="#">access-list includes</a>	Defines an AppleTalk access list that overlaps any part of a range of network numbers or cable ranges (for both extended and nonextended networks).
	<a href="#">access-list network</a>	Defines an AppleTalk access list for a single network number (that is, for a nonextended network).
	<a href="#">access-list other-access</a>	Defines the default action to take for subsequent access checks that apply to networks or cable ranges.
	<a href="#">access-list within</a>	Defines an AppleTalk access list for an extended or a nonextended network whose network number or cable range is included entirely within the specified cable range.
	<a href="#">appletalk distribute-list in</a>	Filters routing updates received from other routers over a specified interface.
	<a href="#">appletalk distribute-list out</a>	Filters routing updates sent to other routers.

# appletalk address

To enable nonextended AppleTalk routing on an interface, use the **appletalk address** command in interface configuration mode. To disable nonextended AppleTalk routing, use the **no** form of this command.

**appletalk address** *network.node*

**no appletalk address** [*network.node*]

<b>Syntax Description</b>	<i>network.node</i>	AppleTalk network address assigned to the interface. The argument <i>network</i> is the 16-bit network number in the range 0 to 65279. The argument <i>node</i> is the 8-bit node number in the range 0 to 254. Both numbers are decimal and separated by a period.
<b>Defaults</b>	Disabled	
<b>Command Modes</b>	Interface configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	10.0	This command was introduced.
<b>Usage Guidelines</b>	<p>You must enable routing on the interface before assigning zone names.</p> <p>Specifying an address of 0.0, or 0.<i>node</i>, places the interface into <i>discovery mode</i>. When in this mode, the Cisco IOS software attempts to determine network address information from another router on the network. You also can enable discovery mode with the <b>appletalk discovery</b> command. Discovery mode does not run over serial lines.</p>	
<b>Examples</b>	<p>The following example enables nonextended AppleTalk routing on Ethernet interface 0:</p> <pre>appletalk routing interface ethernet 0   appletalk address 1.129</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>access-list cable-range</b>	Defines an AppleTalk access list for a cable range (for extended networks only).
	<b>appletalk discovery</b>	Places an interface into discovery mode.
	<b>appletalk zone</b>	Sets the zone name for the connected AppleTalk network.

# appletalk alternate-addressing

To display network numbers in a two-octet format, use the **appletalk alternate-addressing** command in global configuration mode. To return to displaying network numbers in the format *network.node*, use the **no** form of this command.

**appletalk alternate-addressing**

**no appletalk alternate-addressing**

---

**Syntax Description** This command has no arguments or keywords.

---

**Defaults** Disabled

---

**Command Modes** Global configuration

---

Command History	Release	Modification
	10.0	This command was introduced.

---



---

**Usage Guidelines** The **appletalk alternate-addressing** command displays cable ranges in the alternate format wherever applicable. This format consists of printing the upper and lower bytes of a network number as 8-bit decimal values separated by a decimal point. For example, the cable range 511-512 would be printed as 1.255-2.0.

---

**Examples** The following example enables the display of network numbers in a two-octet format:

```
appletalk alternate-addressing
```

# appletalk arp interval

To specify the time interval between retransmissions of Address Resolution Protocol (ARP) packets, use the **appletalk arp interval** command in global configuration mode. To restore both default intervals, use the **no** form of this command.

**appletalk arp** [**probe** | **request**] **interval** *interval*

**no appletalk arp** [**probe** | **request**] **interval** *interval*

Syntax Description		
<b>probe</b>	(Optional) Interval to be used with AppleTalk Address Resolution Protocol (AARP) requests that are trying to determine the address of the local router when the Cisco IOS software is being configured. If you omit <b>probe</b> and <b>request</b> , <b>probe</b> is the default.	
<b>request</b>	(Optional) Indicates that the interval specified is to be used when AARP is attempting to determine the hardware address of another node so that AARP can deliver a packet.	
<i>interval</i>	Interval, in milliseconds, between AARP transmissions. The minimum value is 33 milliseconds. When used with the <b>probe</b> keyword, the default interval is 200 milliseconds. When used with the <b>request</b> keyword, the default interval is 1000 milliseconds.	

## Defaults

If you omit the keywords, probe is the default.

**probe**—200 milliseconds

**request**—1000 milliseconds

## Command Modes

Global configuration

## Command History

Release	Modification
10.0	This command was introduced.

## Usage Guidelines

The time interval you specify takes effect immediately.

Lengthening the interval between AARP transmissions permits responses from devices that respond slowly (such as printers and overloaded file servers) to be received.

AARP uses the **appletalk arp probe interval** value when obtaining the address of the local router. This is done when the Cisco IOS software is being configured. You should not change the default value of this interval unless absolutely necessary, because this value directly modifies the AppleTalk dynamic node assignment algorithm.

AARP uses the **appletalk arp request interval** value when attempting to determine the hardware address of another node so that it can deliver a packet. You can change this interval as desired, although the default value is optimal for most sites.

The **no appletalk arp interval** command restores both the **probe** and **request** intervals specified in the **appletalk arp interval** and **appletalk arp retransmit-count** commands to their default values.

---

**Examples**

The following example lengthens the AppleTalk ARP retry interval to 2000 milliseconds:

```
appletalk arp request interval 2000
```

---

**Related Commands**

Command	Description
<b>appletalk arp retransmit-count</b>	Specifies the number of ARP probe or request transmissions.
<b>appletalk arp-timeout</b>	Specifies the interval at which entries are aged out of the ARP table.
<b>appletalk glean-packets</b>	Derives ARP table entries from incoming packets.
<b>show appletalk globals</b>	Displays information and settings about the AppleTalk internetwork and other parameters.

# appletalk arp retransmit-count

To specify the number of AppleTalk Address Resolution Protocol (AARP) probe or request transmissions, use the **appletalk arp retransmit-count** command in global configuration mode. To restore both default values, use the **no** form of this command.

**appletalk arp** [**probe** | **request**] **retransmit-count** *number*

**no appletalk arp** [**probe** | **request**] **retransmit-count** *number*

## Syntax Description

<b>probe</b>	(Optional) Indicates that the number specified is to be used with AARP requests that are trying to determine the address of the local router when the Cisco IOS software is being configured. If you omit <b>probe</b> and <b>request</b> , <b>probe</b> is the default.
<b>request</b>	(Optional) Indicates that the number specified is to be used when AARP is attempting to determine the hardware address of another node so that AARP can deliver a packet.
<i>number</i>	Number of AARP retransmissions that will occur. The minimum number is 1. When used with the <b>probe</b> keyword, the default value is 10 retransmissions. When used with the <b>request</b> keyword, the default value is 5 retransmissions. Specifying 0 selects the default value.

## Defaults

If you omit the keyword, probe is the default.

**probe**—10 transmissions

**request**—5 transmissions

## Command Modes

Global configuration

## Command History

Release	Modification
10.0	This command was introduced.

## Usage Guidelines

The value you specify takes effect immediately.

Increasing the number of retransmissions permits responses from devices that respond slowly (such as printers and overloaded file servers) to be received.

AARP uses the **appletalk arp probe retransmit-count** value when obtaining the address of the local router. This is done when the Cisco IOS software is being configured. You should not change the default value unless absolutely necessary, because this value directly modifies the AppleTalk dynamic node assignment algorithm.

AARP uses the **appletalk arp request retransmit-count** value when attempting to determine the hardware address of another node so that it can deliver a packet. You can change this interval as desired, although the default value is optimal for most sites.

The **no appletalk arp interval** command restores both the **probe** and **request** intervals specified in the **appletalk arp interval** and **appletalk arp retransmit-count** commands to their default values.

---

### Examples

The following example specifies an AARP retransmission count of 10 for AARP packets that are requesting the hardware address of another node on the network:

```
appletalk arp request retransmit-count 10
```

---

### Related Commands

Command	Description
<a href="#">appletalk arp interval</a>	Specifies the time interval between retransmissions of ARP packets.
<a href="#">appletalk arp-timeout</a>	Specifies the interval at which entries are aged out of the ARP table.
<a href="#">appletalk glean-packets</a>	Derives ARP table entries from incoming packets.
<a href="#">show appletalk globals</a>	Displays information and settings about the AppleTalk internetwork and other parameters.

# appletalk arp-timeout

To specify the interval at which entries are aged out of the Address Resolution Protocol (ARP) table, use the **appletalk arp-timeout** command in interface configuration mode. To return to the default timeout, use the **no** form of this command.

**appletalk arp-timeout** *interval*

**no appletalk arp-timeout** *interval*

Syntax Description	<i>interval</i>	Time, in minutes, after which an entry is removed from the AppleTalk ARP table. The default is 240 minutes (4 hours).
--------------------	-----------------	---

Defaults	240 minutes (4 hours)
----------	-----------------------

Command Modes	Interface configuration
---------------	-------------------------

Command History	Release	Modification
	10.0	This command was introduced.

**Examples** The following example changes the ARP timeout interval on Ethernet interface 0 to 2 hours:

```
interface ethernet 0
appletalk cable-range 2-2
appletalk arp-timeout 120
```

Related Commands	Command	Description
	<a href="#">appletalk arp interval</a>	Specifies the time interval between retransmissions of ARP packets.
	<a href="#">appletalk arp retransmit-count</a>	Specifies the number of ARP probe or request transmissions.
	<a href="#">appletalk glean-packets</a>	Derives ARP table entries from incoming packets.

# appletalk aurp tickle-time

To set the Apple Update-Based Routing Protocol (AURP) last-heard-from timer value, use the **appletalk aurp tickle-time** command in interface configuration mode. To return to the default last-heard-from timer value, use the **no** form of this command.

**appletalk aurp tickle-time** *seconds*

**no appletalk aurp tickle-time** *seconds*

<b>Syntax Description</b>	<i>seconds</i>	Timeout value, in seconds. This value can be a number from 30 to infinity. The default is 90 seconds.
<b>Defaults</b>	90 seconds	
<b>Command Modes</b>	Interface configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	10.3	This command was introduced.
<b>Usage Guidelines</b>	<p>If the tunnel peer has not been heard from within the time specified by the least-heard-from timer value, the Cisco IOS software sends tickle packets to check that the tunnel peer is still up.</p> <p>You can use this command only on tunnel interfaces.</p>	
<b>Examples</b>	<p>The following example changes the AURP last-heard-from timer value on tunnel interface 0 to 120 seconds:</p> <pre>interface tunnel 0  appletalk aurp tickle-time 120</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show appletalk interface</b>	Displays the status of the AppleTalk interfaces configured in the Cisco IOS software and the parameters configured on each interface.

# appletalk aurp update-interval

To set the minimum interval between Apple Update-Based Routing Protocol (AURP) routing updates, use the **appletalk aurp update-interval** command in interface configuration mode. To return to the default interval, use the **no** form of this command.

**appletalk aurp update-interval** *seconds*

**no appletalk aurp update-interval** *seconds*

<b>Syntax Description</b>	<i>seconds</i>	AURP routing update interval, in seconds. This interval must be a multiple of 10. The default is 30 seconds.
---------------------------	----------------	--

<b>Defaults</b>	30 seconds
-----------------	------------

<b>Command Modes</b>	Interface configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	10.3	This command was introduced.

<b>Usage Guidelines</b>	The AURP routing update interval applies only to tunnel interfaces.
-------------------------	---

<b>Examples</b>	The following example changes the AURP routing update interval on tunnel interface 0 to 40 seconds: <pre>interface tunnel 0   appletalk aurp update-interval 40</pre>
-----------------	--

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show appletalk globals</b>	Displays information and settings about the AppleTalk internetwork and other parameters.

# appletalk cable-range

To enable an extended AppleTalk network, use the **appletalk cable-range** command in interface configuration mode. To disable an extended AppleTalk network, use the **no** form of this command.

**appletalk cable-range** *cable-range* [*network.node*]

**no appletalk cable-range** *cable-range* [*network.node*]

## Syntax Description

<i>cable-range</i>	Cable range value. The argument specifies the start and end of the cable range, separated by a hyphen. These values are decimal numbers from 0 to 65279. The starting network number must be less than or equal to the ending network number.
<i>network.node</i>	(Optional) Suggested AppleTalk address for the interface. The argument <i>network</i> is the 16-bit network number, and the argument <i>node</i> is the 8-bit node number. Both numbers are decimal and separated by a period. The suggested network number must fall within the specified range of network numbers.

## Defaults

Disabled

## Command Modes

Interface configuration

## Command History

Release	Modification
10.0	This command was introduced.

## Usage Guidelines

You must enable routing on the interface before assigning zone names.

Specifying a cable range value of 0-0 places the interface into *discovery mode*. When in this mode, the Cisco IOS software attempts to determine cable range information from another router on the network. You can also enable discovery mode with the **appletalk discovery** command. Discovery mode does not run over serial lines.

## Examples

The following example assigns a cable range of 3 to 3 to the interface:

```
interface ethernet 0
 appletalk cable-range 3-3
```

## Related Commands

Command	Description
<b>appletalk address</b>	Enables nonextended AppleTalk routing on an interface.
<b>appletalk discovery</b>	Places an interface into discovery mode.
<b>appletalk zone</b>	Sets the zone name for the connected AppleTalk network.

# appletalk checksum

To enable the generation and verification of checksums for all AppleTalk packets (except routed packets), use the **appletalk checksum** command in global configuration mode. To disable checksum generation and verification, use the **no** form of this command.

**appletalk checksum**

**no appletalk checksum**

**Syntax Description** This command has no arguments or keywords.

**Defaults** Enabled

**Command Modes** Global configuration

Command History	Release	Modification
	10.0	This command was introduced.

**Usage Guidelines**

When the **appletalk checksum** command is enabled, the Cisco IOS software discards incoming Datagram Delivery Protocol (DDP) packets when the checksum is not zero and is incorrect, and when the router is the final destination for the packet.

You might want to disable checksum generation and verification if you have very early devices (such as LaserWriter printers) that cannot receive packets that contain checksums.

The Cisco IOS software does not check checksums on routed packets, thereby eliminating the need to disable checksum to allow operation of some networking applications.

**Examples** The following example disables the generation and verification of checksums:

```
no appletalk checksum
```

Related Commands	Command	Description
	<b>show appletalk globals</b>	Displays information and settings about the AppleTalk internetwork and other parameters.

# appletalk client-mode

To allow users to access an AppleTalk zone when dialing into an asynchronous line (on Cisco routers, only via the auxiliary port) use the **appletalk client-mode** command in interface configuration mode. To disable this function, use the **no** form of this command.

**appletalk client-mode**

**no appletalk client-mode**

**Syntax Description** This command has no arguments or keywords.

**Defaults** Client mode is disabled.

**Command Modes** Interface configuration

Command History	Release	Modification
	10.3	This command was introduced.

**Usage Guidelines** The **appletalk client-mode** command allows a remote client to use an asynchronous interface to access AppleTalk zones, use networked peripherals, and share files with other Macintosh users.

This command works only on asynchronous interfaces on which Point-to-Point Protocol (PPP) encapsulation is enabled. Also, you must first create an internal network for the Macintosh client using the **appletalk virtual-net** global configuration command.

An interface configured with the **appletalk client-mode** interface configuration and **appletalk virtual-net** global configuration commands does not support routing.

**Examples** The following example allows a user to access AppleTalk functionality on an asynchronous line using PPP:

```
interface asynchronous 1
 appletalk client-mode
```

Related Commands	Command	Description
	<b>appletalk virtual-net</b>	Adds AppleTalk users logging in on an asynchronous line and using PPP encapsulation to an internal network.
	<b>encapsulation</b>	Sets the encapsulation method used by the interface.
	<b>interface</b>	Defines the IP addresses of the server, configures an interface type, and enters interface configuration mode.
	<b>ppp</b>	Starts an asynchronous connection using PPP.

# appletalk discovery

To place an interface into discovery mode, use the **appletalk discovery** command in interface configuration mode. To disable discovery mode, use the **no** form of this command.

**appletalk discovery**

**no appletalk discovery**

**Syntax Description** This command has no arguments or keywords.

**Defaults** Disabled

**Command Modes** Interface configuration

Command History	Release	Modification
	10.0	This command was introduced.

**Usage Guidelines** If an interface is connected to a network that has at least one other operational AppleTalk router, you can dynamically configure the interface using *discovery mode*. In discovery mode, an interface acquires network address information about the attached network from an operational router and then uses this information to configure itself.

If you enable discovery mode on an interface, when the Cisco router starts up, that interface must acquire information to configure itself from another operational router on the attached network. If no operational router is present on the connected network, the interface will not start.

If you do not enable discovery mode, the interface must acquire its configuration from memory when the router starts. If the stored configuration is not complete, the interface will not start. If there is another operational router on the connected network, the router will verify the interface's stored configuration with that router. If there is any discrepancy, the interface will not start. If there are no neighboring operational routers, the router will assume the interface's stored configuration is correct and will start.

Once an interface is operational, it can seed the configurations of other routers on the connected network regardless of whether you have enabled discovery mode on any of the routers.

If you enable **appletalk discovery** and the interface is restarted, another operational router must still be present on the directly connected network in order for the interface to start.

It is not advisable to have all routers on a network configured with discovery mode enabled. If all routers were to restart simultaneously (for instance, after a power failure), the network would become inaccessible until at least one router were restarted with discovery mode disabled.

You can also enable discovery mode by specifying an address of 0.0. in the **appletalk address** command or a cable range of 0-0 in the **appletalk cable-range** command.

Discovery mode is useful when you are changing a network configuration, or when you are adding a router to an existing network.

Discovery mode does not run over serial lines.

Use the **no appletalk discovery** command to disable discovery mode. If the interface is not operational when you issue this command (that is, if you have not issued an **access-list zone** command on the interface), you must configure the zone name next. If the interface is operational when you issue the **no appletalk discovery** command, you can save the current configuration (in running memory) in nonvolatile memory by issuing the **copy running-config startup-config** command. (The **copy running-config startup-config** command replaces the **write memory** command. Refer to the description of the **copy running-config startup-config** command for more information.)

---

### Examples

The following example enables discovery mode on Ethernet interface 0:

```
interface ethernet 0
  appletalk discovery
```

---

### Related Commands

Command	Description
<b>appletalk address</b>	Enables nonextended AppleTalk routing on an interface.
<b>appletalk cable-range</b>	Enables an extended AppleTalk network.
<b>appletalk zone</b>	Sets the zone name for the connected AppleTalk network.
<b>show appletalk interface</b>	Displays the status of the AppleTalk interfaces configured in the Cisco IOS software and the parameters configured on each interface.

# appletalk distribute-list in

To filter routing updates received from other routers over a specified interface, use the **appletalk distribute-list in** command in interface configuration mode. To remove the routing table update filter, use the **no** form of this command.

**appletalk distribute-list** *access-list-number* **in**

**no appletalk distribute-list** [*access-list-number*] **in**

## Syntax Description

<i>access-list-number</i>	Number of the access list. This is a decimal number from 600 to 699.
---------------------------	--

## Defaults

No routing filters are preconfigured.

## Command Modes

Interface configuration

## Command History

Release	Modification
10.0	This command was introduced.

## Usage Guidelines

The **appletalk distribute-list in** command controls which networks and cable ranges in routing updates will be entered into the local routing table.

Filters for incoming routing updates use access lists that define conditions for networks and cable ranges only. They cannot use access lists that define conditions for zones. All zone information in an access list assigned to the interface with the **appletalk distribute-list in** command is ignored.

An input distribution list filters network numbers received in an incoming routing update. When AppleTalk routing updates are received on the specified interface, each network number and cable range in the update is checked against the access list. Only network numbers and cable ranges that are permitted by the access list are inserted into the Cisco IOS software AppleTalk routing table.

## Examples

The following example prevents the router from accepting routing table updates received from network 10 and on Ethernet interface 3:

```
access-list 601 deny network 10
access-list 601 permit other-access
interface ethernet 3
  appletalk distribute-list 601 in
```

Related Commands	Command	Description
	<a href="#">access-list cable-range</a>	Defines an AppleTalk access list for a cable range (for extended networks only).
	<a href="#">access-list includes</a>	Defines an AppleTalk access list that overlaps any part of a range of network numbers or cable ranges (for both extended and nonextended networks).
	<a href="#">access-list network</a>	Defines an AppleTalk access list for a single network number (that is, for a nonextended network).
	<a href="#">access-list other-access</a>	Defines the default action to take for subsequent access checks that apply to networks or cable ranges.
	<a href="#">access-list within</a>	Defines an AppleTalk access list for an extended or a nonextended network whose network number or cable range is included entirely within the specified cable range.
	<a href="#">appletalk distribute-list out</a>	Filters routing updates sent to other routers.

# appletalk distribute-list out

To filter routing updates transmitted to other routers, use the **appletalk distribute-list out** command in interface configuration mode. To remove the routing table update filter, use the **no** form of this command.

**appletalk distribute-list** *access-list-number* **out**

**no appletalk distribute-list** [*access-list-number*] **out**

## Syntax Description

<i>access-list-number</i>	Number of the access list. This is a decimal number from 600 to 699.
---------------------------	--

## Defaults

No routing filters are preconfigured.

## Command Modes

Interface configuration

## Command History

Release	Modification
10.0	This command was introduced.

## Usage Guidelines

The **appletalk distribute-list out** command controls which network numbers and cable ranges are included in routing updates and which zones the local router includes in its GetZoneList (GZL) replies.

When an AppleTalk routing update is generated on the specified interface, each network number and cable range in the routing table is checked against the access list. If an undefined access list is used, all network numbers and cable ranges are added to the routing update. Otherwise, if an access list is defined, only network numbers and cable ranges that satisfy the following conditions are added to the routing update:

- The network number or cable range is not explicitly or implicitly denied.
- The network number or cable range is not a member of a zone that is explicitly or implicitly denied.
- If **appletalk permit-partial-zones** is disabled (the default), the network number or cable range is not a member of a zone that is partially obscured.

A zone is considered partially obscured when one or more network numbers or cable ranges that are members of the zone is explicitly or implicitly denied.

When a Zone Information Protocol (ZIP) GZL reply is generated, only zones that satisfy the following conditions are included:

- If **appletalk permit-partial-zones** is enabled, at least one network number or cable range that is a member of the zone is explicitly or implicitly permitted.
- If **appletalk permit-partial-zones** is disabled, all network numbers or cable ranges are explicitly or implicitly permitted.
- The zone is explicitly or implicitly permitted.

**Note**


---

AppleTalk zone access lists on an Enhanced IGRP interface will not filter the distribution of Enhanced IGRP routes. When the **appletalk distribute-list out** command is applied to an Enhanced IGRP interface, any **access-list zone** commands in the specified access list will be ignored.

---

**Examples**

The following example prevents routing updates sent on Ethernet 0 from mentioning any networks in zone Admin:

```
access-list 601 deny zone Admin
access-list 601 permit other-access
interface Ethernet 0
 appletalk distribute-list 601 out
```

**Related Commands**

Command	Description
<a href="#">access-list additional-zones</a>	Defines the default action to take for access checks that apply to zones.
<a href="#">access-list zone</a>	Defines an AppleTalk access list that applies to a zone.
<a href="#">appletalk distribute-list in</a>	Filters routing updates received from other routers over a specified interface.
<a href="#">appletalk getzonelist-filter</a>	Filters GZL replies.
<a href="#">appletalk permit-partial-zones</a>	Permits access to the other networks in a zone when access to one of those networks is denied.

# appletalk domain-group

To assign a predefined domain number to an interface, use the **appletalk domain-group** command in interface configuration mode. To remove an interface from a domain, use the **no** form of this command.

**appletalk domain-group** *domain-number*

**no appletalk domain-group** [*domain-number*]

Syntax Description	<i>domain-number</i>	Number of an AppleTalk domain. It can be a decimal integer from 1 to 1,000,000.
--------------------	----------------------	---

**Defaults** No domain number is assigned to the interface.

**Command Modes** Interface configuration

Command History	Release	Modification
	10.3	This command was introduced.

**Usage Guidelines**

Before you can assign a domain number to an interface, you must create a domain with that domain number using the **appletalk domain name** global configuration command.

One or more interfaces on a router can be members of the same domain. However, a given interface can be in only one domain.

After you assign AppleTalk interenterprise features to an AppleTalk domain, you can attribute those features to a tunnel interface configured for AURP by assigning the AppleTalk domain-group number to the tunnel interface.

**Examples** The following example assigns domain group 1 to Ethernet interface 0:

```
interface ethernet 0
 appletalk domain-group 1
```

The following example assigns domain group 1 to tunnel interface 2. Assuming that domain group 1 is configured for AppleTalk interenterprise and that tunnel interface 2 is configured for AURP, any features configured for domain group 1 are ascribed to AURP on tunnel interface 2.

```
interface tunnel 2
 appletalk domain-group 1
```

■ **appletalk domain-group**

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>appletalk domain name</b>	Creates a domain and assigns it a name and number.
	<b>show appletalk domain</b>	Displays all domain-related information.

# appletalk domain hop-reduction

To reduce the hop-count value in packets that are traveling between segments of a domains, use the **appletalk domain hop-reduction** command in global configuration mode. To disable the reduction of hop-count values, use the **no** form of this command.

**appletalk domain** *domain-number* **hop-reduction**

**no appletalk domain** *domain-number* **hop-reduction**

Syntax Description	<i>domain-number</i>	Number of an AppleTalk domain. It can be a decimal integer from 1 to 1,000,000.
--------------------	----------------------	---

**Defaults** Reduction of hop-count values is disabled.

**Command Modes** Global configuration

Command History	Release	Modification
	10.3	This command was introduced.

**Usage Guidelines** Before you can specify the **appletalk domain hop-reduction** global configuration command, you must have created a domain with that domain number using the **appletalk domain name** global configuration command.

DDP and Routing Table Maintenance Protocol (RTMP) both impose a 15-hop limit when forwarding packets. A packet ages out and is no longer forwarded when its hop count reaches 16. To overcome RTMP's 15-hop limit, the domain router represents all networks accessible to routers on its local network as one hop away. This allows routers to maintain and send routing information about networks beyond the 15-hop limit and achieve full connectivity.

When you enable hop-count reduction, delivery of packets from networks that are farther than 15 hops apart is guaranteed.

When you enable hop-count reduction, the hop count in a packet is set to 1 as it passes from one domain to another. For example, if the hop count was 8 when the packet left one domain, its hop count is 1 when it enters the next segment of the domain.

**Examples** The following example enables hop-count reduction for domain number 1:

```
appletalk domain 1 name Delta
appletalk domain 1 hop-reduction
```

Related Commands	Command	Description
	<b>appletalk domain name</b>	Creates a domain and assigns it a name and number.
	<b>show appletalk domain</b>	Displays all domain-related information.

# appletalk domain name

To create a domain and assign it a name and number, use the **appletalk domain name** command in global configuration mode. To remove a domain, use the **no** form of this command.

**appletalk domain** *domain-number* **name** *domain-name*

**no appletalk domain** *domain-number* **name** *domain-name*

Syntax Description		
	<i>domain-number</i>	Number of an AppleTalk domain. It can be a decimal integer from 1 to 1000000.
	<i>domain-name</i>	Name of an AppleTalk domain. The name must be unique across the AppleTalk internetwork. It can be up to 32 characters long and can include special characters from the Apple Macintosh character set. To include a special character, type a colon followed by two hexadecimal characters. For zone names with a leading space character, enter the first character as the special sequence :20.

**Defaults** No domain is created.

**Command Modes** Global configuration

Command History	Release	Modification
	10.3	This command was introduced.

**Examples** The following example creates domain number 1 and assigns it the domain name *Delta*:

```
appletalk domain 1 name Delta
```

Related Commands	Command	Description
	<b>appletalk routing</b>	Enables AppleTalk routing.
	<b>show appletalk domain</b>	Displays all domain-related information.

# appletalk domain remap-range

To remap ranges of AppleTalk network numbers or cable ranges between two segments of a domain, use the **appletalk domain remap-range** command in global configuration mode. To disable remapping, use the **no** form of this command.

**appletalk domain** *domain-number* **remap-range** { **in** | **out** } *cable-range*

**no appletalk domain** *domain-number* **remap-range** { **in** | **out** } [*cable-range*]

## Syntax Description

<i>domain-number</i>	Number of an AppleTalk domain. It can be a decimal integer from 1 to 1,000,000.
<b>in</b>	Specifies that the remapping is performed on inbound packets (that is, on packets arriving into the local interenterprise network). All network numbers or cable ranges coming from the domain are remapped into the specified range.
<b>out</b>	Specifies that the remapping is performed on outbound packets (that is, on packets exiting from the local interenterprise network). All network numbers or cable ranges going to the domain are remapped into the specified range.
<i>cable-range</i>	Specifies the start and end of the cable range, separated by a hyphen. The starting network must be the first AppleTalk network number or the beginning of the cable range to remap. The number must be immediately followed by a hyphen. The ending network must be the last AppleTalk network number or the end of the cable range to remap.

## Defaults

No remapping is performed.

## Command Modes

Global configuration

## Command History

Release	Modification
10.3	This command was introduced.

## Usage Guidelines

Before you can specify the **appletalk domain remap-range** command, you must create a domain with that domain number using the **appletalk domain name** global configuration command.

Inbound and outbound packets are relative to the domain router.

Ensure that the domain range you specify does not overlap any network addresses or cable ranges that already exist in the AppleTalk interenterprise network.

Each domain can have two domain mapping ranges to which to remap all incoming or outgoing network numbers or cable ranges. Incoming remapping ranges cannot overlap. However, outbound remapping ranges can overlap.

When an AppleTalk network in a domain becomes inactive, its remapped entry is removed from the remapping table. This frees the space for another network to be remapped.

If there are more remote domains than available remapping range numbers, the Cisco IOS software displays an error message and shuts down domains.

---

**Examples**

The following example remaps all network addresses and cable ranges for packets inbound from domain 1 into the address range 1000 to 1999. It also remaps packets inbound from domain 2.

```
appletalk domain 1 name Delta
appletalk domain 2 name Echo
appletalk domain 1 remap-range in 1000-1999
appletalk domain 2 remap-range in 2000-2999
```

---

**Related Commands**

Command	Description
<a href="#">appletalk domain name</a>	Creates a domain and assigns it a name and number.
<a href="#">show appletalk remap</a>	Displays domain remapping information.