

# Configuring Containers

---

This chapter provides information about configuring containers in Cisco Access Manager (CAM). Containers logically organize devices that are managed in CAM. You can configure three container types as described in the following sections:

- Configuring Groups on page 4-2
- Configuring Stacks on page 4-7
- Configuring System Controllers on page 4-42

Groups are the highest level of containers. All stacks and System Controllers you configure in CAM belong to a group. If you do not configure a stack or System Controller to belong to a user-defined group, it will automatically belong to the default group, CAMROOT.

Stacks and System Controllers are hierarchical equivalents. They are the logical and physical containers of shelves. Currently, you can configure the shelves in stacks to be a combination of Cisco AS5300, Cisco 7206, Catalyst 5002, and Cisco 3640 devices and you can configure shelves in System Controllers to be Cisco AS5800 devices.

For information about configuring shelves for stacks and System Controllers, see Chapter 5, “Configuring Shelves.”



## Tips

To configure using CAM, you must supply information for all fields presented in bold in each dialog box of the configuration screens. Pull-down menus and data-entry fields will be disabled if your previous configuration choices make them unnecessary.

# Configuring Groups

Groups provide a method for logically organizing your devices into generic domains. A group can be made up of devices such as stacks, System Controllers, and even other groups. The group can represent geographical regions, classes of users, or some other classification that helps you to categorize your devices.

When configure a group, it belongs to either CAMROOT (the default group) or to a user-defined group.


To configure a group, complete the tasks in the following sections. All three tasks are optional.

- [Creating a Group on page 4-2](#)
- [Modifying a Group on page 4-4](#)
- [Deleting a Group on page 4-6](#)

## Creating a Group

You can create as many user-defined groups as you need. The CAMROOT group is automatically created when you start CAM. The dialog box that appears allows you to create a group. (See Figure 4-1.)

**Figure 4-1 Create Group Dialog Box**



To create a group:

Step	Description
1 Select the CAMROOT group or any user-defined group.	The group to which you want to add the new group. The group you add is subordinate to the group you select in the Device Tree View.
2 Click <b>Configure</b> .	The Task Selection bar displays all the configuration tasks CAM can perform for groups.
3 Click <b>Create Group</b> .	The Create Group dialog box appears. (See Figure 4-1.)
4 Enter the group name.	Define a name that easily identifies the generic domain. For example, if the group logically organizes your devices by geographical region, use the region as its name. The group name can be up to 64 characters in length. This name is stored in the CAM server database.

## Configuring Groups


---

<b>Step</b>	<b>Description</b>
5 Enter a group description.	An optional description to provide useful information about the group. You can specify up to 64 characters.
6 Click <b>OK</b> .	You have successfully created a group. CAM displays the newly created group in the Device Tree View. You can now add a stack, System Controller, or another group to it. For more information about how to do this, see the “Configuring Stacks” section on page 4-7, “Configuring System Controllers” section on page 4-42, or repeat these steps.

## Modifying a Group

You can modify a user-defined group, but not the default group CAMROOT. The dialog box that appears allows you to modify a group. (See Figure 4-2.)

**Figure 4-2**      **Modify Group Dialog Box**



To modify a group:

Step	Description
1 Select any user-defined group in the Device Tree View.	The group you want to modify.
2 Click <b>Configure</b> .	The Task Selection bar displays all the configure tasks CAM can perform for groups.
3 Click <b>Modify</b> .	The Modify Group dialog box appears. (See Figure 4-2.)
4 Enter new information in the Group Name and/or Description field.	The group name and group description can each be up to 64 characters in length.

Step	Description
5	Click <b>OK</b> .
	You have successfully modified a group. If the change is not reflected in the Device Tree View, click <b>Refresh</b> . See “Refreshing Your System” section on page 2-7 for more information.

## Deleting a Group

You can delete any user-defined group that is empty. This means you can only delete a group after all the stacks in the group are deleted. You cannot delete the default group CAMROOT. The dialog box that appears allows you to delete a group. (See Figure 4-3.)

**Figure 4-3** Delete Group Dialog Box



To delete a group:

Step	Description
1	Select a user-defined group in the Device Tree View.
2	Click <b>Configure</b> .
3	Click <b>Delete</b> .
4	Click <b>Yes</b> .

## Configuring Stacks

Stacks are containers for shelves. The devices (switch, number of NAS(s), and number of Cisco 7206s) contained in the stack determine the stack type. CAM supports several stack types, which are listed in the “Supported Cisco AccessPath Stack Types” section on page 4-8.

In addition, the configuration parameters for the stack are interdependent. CAM shows the valid values from which you can make your choice. These parameter dependencies are listed in the “Creating a Stack” section on page 4-8.

To configure a stack, complete the tasks in the following sections. The first two tasks are required; the third and fourth tasks are optional.

- Creating a Stack on page 4-8
- Creating or Modifying a Shelf in a Stack on page 5-2
- Modifying a Stack on page 4-32
- Deleting a Stack on page 4-38

# Supported Cisco AccessPath Stack Types

CAM supports several stack types. The following table lists the CAM-supported stack types and their components:

**Table 4-1 Supported Cisco AccessPath Stack Types**

Stack Type	Cisco AS5300s	Cisco 7206s	Primary Switch	Failover Switch	Cisco 3640s
Entry	1–7	1	1 x Eclipse	1 x Eclipse	1
Midrange	1–11	1	1 x 5002	1 x Eclipse	1
High-End	1–14	2	1 x 5002	2 x Eclipse	1
High-End Extended	15–21	2	1 x 5002	2 x Eclipse	1
Minibundle LS3	1–4	none	none	none	1

## Creating a Stack

The procedure for creating a stack should be thought of as a series of planning sheets, with which you design the stack. This procedure creates a container into which you must then create all of the individual shelves as described in Chapter 5, “Configuring Shelves.”

During the stack creation or stack modification procedure, CAM steps you through a series of dialog boxes in which you provide configuration information. Several dialog boxes are common to both the stack creation and stack modification procedures. At these dialog boxes, you can:

- 1 Configure Stack General Information
- 2 Configure Stack Trunk and Name Server Information
- 3 Configure Stack Trunk Interface
- 4 Configure Stack Addressing
- 5 Configure Stack Network Management
- 6 Configure Stack Security



Several parameters that you configure during the stack creation and stack modification procedures are interdependent. This means that some selections you make on one configuration dialog box can determine the values from which you can select later on (including if the parameter even applies to the type of stack you have configured). The following table provides a matrix that helps you to understand the stack parameter dependencies.

**Table 4-2 Stack Parameter Dependencies**

Trunk Type	Controller Type	ISDN Switch	Signaling Type	CAS Custom (E1-R2 only)	Stack Channel Type
PRI	T1 or E1	primary-5ess primary-4ess primary-dms100 primary-net5 primary-ntt primary-ts014	–	–	multichannel only single channel only single and multichannels
CE1	E1	–	p7 r2-analog r2-digital r2-pulse	(See the “Configure Stack Trunk Interface” section on page 4-16 for a list of countries.)	–
CT1	T1	–	sas-loop-start sas-ground-start fxs-loop-start fxs-ground-start e&m-fgb e&m-fgd e&m-immediatestar	–	–

## Configuring Stacks

---

**Table 4-2 Stack Parameter Dependencies (Continued)**

Trunk Type	Controller Type	ISDN Switch	Signaling Type	CAS Custom (E1-R2 only)	Stack Channel Type
PRI and CE1	E1	primary-5ess primary-4ess primary-dms100 primary-net5 primary-ntt primary-ts014	p7 r2-analog r2-digital r2-pulse	(See the “Configure Stack Trunk Interface” section on page 4-16 for a list of countries.)	multichannel only single channel only single and multi channels
PRI and CT1	T1	primary-5ess primary-4ess primary-dms100 primary-net5 primary-ntt primary-ts014	sas-loop-start sas-ground-start fxs-loop-start fxs-ground-start e&m-fgb e&m-fgd e&m-immediatar	–	multichannel only single channel only single and multichannels

The procedures for creating and modifying a stack are similar but not identical. For information common to both, continue reading this section. For information specific to modifying a stack, skip to the “Modifying a Stack” section on page 4-32.


To add a stack, follow these steps:

Step	Description
1	Select the CAMROOT group or any user-defined group. The group to which you want to add a stack. If you do not select a group, the stack is added to CAMROOT.
2	Click <b>Configure</b> . The Task Selection bar displays all the configuration tasks CAM can perform for groups.
3	Click <b>Create Stack</b> . Proceed to the “Configure Stack General Information” section on page 4-11.

## Configure Stack General Information

The first dialog box that appears allows you to configure general information about the stack. (See Figure 4-4.)

**Figure 4-4 Stack Add for Group Dialog Box (1 of 7)**



## Configuring Stacks

---

To configure general information about the stack:


Step	Description
1	Enter a stack name. The case-sensitive stack group authentication name. It must be unique in the rack.
2	(Optional.) Enter a stack description. Description cannot exceed 64 characters.
3	Select the number of Cisco 7206(s) in the stack. Defines the maximum number of Cisco 7206s. For all stack types that use a Catalyst 5000 series Switch Shelf, the maximum is 2. (See “Supported Cisco AccessPath Stack Types” section on page 4-8 for details.)
4	Select the number of network access servers (NAS) in the stack. Defines the maximum number of Access Server Shelves in the stack. The number of Access Server Shelves depends on your configuration. (See “Supported Cisco AccessPath Stack Types” section on page 4-8 for details.)
5	Select <b>yes</b> or <b>no</b> . The Catalyst 5002 is optional depending on your configuration. (See “Supported Cisco AccessPath Stack Types” section on page 4-8 for details.)
6	(Modify only.) Select <b>now</b> or <b>later</b> for Config the Stack. If you are modifying a stack you can choose whether to configure the stack now or later. If you choose <b>later</b> , then you need to schedule the download. (See “Scheduling a Stack Download” section on page 4-36 for information.)
7	Enter the EIGRP system number. The Enhanced Interior Gateway Routing Protocol (EIGRP) Autonomous system number must be a value from 1 to 65535.
8	Enter a Cisco IOS secret password. The Cisco IOS enable secret password is encrypted so that it cannot be read when crossing a network. After you issue this command, the encryption cannot be reversed. The encrypted version of the password appears in output of the <b>show running-config</b> and <b>show startup-config</b> commands.  The password cannot exceed 25 characters. You must enter the same password in the Confirm field.

Step	Description
9 Enter an SGBP password.	<p>The Stack Group Bidding Protocol (SGBP) password establishes a username-based authentication system; the stack password is used to access the name argument.</p> <p>The password cannot exceed 25 characters. You must enter the same password in the Confirm field.</p>
10 Click <b>next</b> .	Proceed to the “Configure Stack Trunk and Name Server Information” section.

### Configure Stack Trunk and Name Server Information

The second dialog box that appears allows you to configure trunk and name server information about the stack. (See Figure 4-5.)

**Figure 4-5 Stack Add for Group Dialog Box (2 of 7)**



To configure trunk and name server information:

Step	Description
1	Select a stack trunk type.  Select the trunk type supported by your service provider. Available choices include: <ul style="list-style-type: none"><li>• PRI—Primary Rate Interface</li><li>• CE1—Channelized E1</li><li>• CT1—Channelized T1</li><li>• PRI and CE1—A mixture of PRI and Channelized E1</li><li>• PRI and CT1—A mixture of PRI and Channelized T1</li></ul>
2	Select the CAM server time zone.  CAM retrieves the default value for your time zone from your local host. Time zones are expressed relative to Greenwich Mean Time (GMT). Verify that this field has the correct value.
3	Select a stack controller type.  The controller type (T1 or E1) accepts incoming calls and sends outgoing calls through ISDN PRI lines. (For all selections of Stack Trunk Type except PRI, this defaults to the correct selection for your network.)
4	(Optional.) Specify your name server address(es).  Domain name servers resolve host names and IP addresses. You can specify one or more addresses.  To add an address, enter an address in the left box and click the <b>Add</b> button. It displays in the right box. To remove an address, highlight an address in the right box and click the <b>Remove</b> button.
5	(Optional.) Specify your Async DNS server address(es).  This server address enables remote users to gather DNS information transparently as part of the Point-to-Point Protocol (PPP) negotiation. Dial-in clients using PPP applications, such as CiscoRemote and Windows 95, need Domain Name System (DNS) address information as described in RFC 1877.  To add an address, enter an address in the left box and click the <b>Add</b> button. It displays in the right box. To remove an address, highlight an address in the right box and click the <b>Remove</b> button.

Step	Description
<p><b>6</b> (Optional.) Specify your NetBIOS name server address(es).</p>	<p>This server address enables remote users to gather NBNS information transparently as part of the PPP negotiation. Dial-in clients using PPP applications, such as CiscoRemote and Windows 95, need NetBIOS name server (NBNS) address information as described in RFC 1877.</p> <p>To add an address, enter an address in the left box, and click the <b>Add</b> button. It displays in the right box. To remove an address, highlight an address in the right box and click the <b>Remove</b> button.</p>
<p><b>7</b> Click <b>next</b>.</p>	<p>Proceed to the “Configure Stack Trunk Interface” section on page 4-16.</p>

### Configure Stack Trunk Interface

The third dialog box that appears allows you to configure trunk interface information for the stack. (See Figure 4-6.)

**Figure 4-6** Stack Add for Group Dialog Box (3 of 7)

**Stack add for Group - test2**

**Vpdn**

Enable VPDN?  yes  no

**Stack Trunk Interface**

Framing  crc4  no-crc4

Linecode  hdb3  ami

Enable user privileged mode  yes  no

ISDN Switch Type primary-5ess

Signaling Type p7

CAS Custom Country (E1\_R2) None

Stack Channel Type multi channel only

External hostname for chap to use

back next finish cancel

150086



To configure trunk interface information:

Step	Description
<p><b>1</b> Select <b>yes</b> or <b>no</b> to enable or disable Virtual Private Dialup Network (VPDN) support.</p>	<p>If you select <b>no</b>, none of the shelves in this stack can support VPDN. Selecting <b>yes</b> allows for a mixed configuration in which some shelves support VPDN and some do not. (You will configure the use of VPDN on a shelf-by-shelf basis when you create the shelves in the stack. See Chapter 5, “Configuring Shelves.”)</p>
<p><b>2</b> Select your framing.</p>	<p>Framing is the type of transmission unit used in the T1 or E1 link. Available choices for Channelized T1 and PRI include:</p> <ul style="list-style-type: none"> <li>• esf—Extended superframe</li> <li>• sf—Super frame</li> <li>• crc4—Cyclic Redundancy Check for E1</li> <li>• no_crc4—no CRC4</li> </ul>
<p><b>3</b> Select a linecode.</p>	<p>Linecode is the Variety of Zero Code Suppression used on the link, which in turn affects a number of its characteristics. Available choices for PRI and Channelized T1 include:</p> <ul style="list-style-type: none"> <li>• b8zs—Binary 8-zero substitution, a T1/E1 linecode type</li> <li>• ami—Alternate mark inversion, a T1/E1 linecode type</li> <li>• hdb3—high-density bipolar3, a E1 linecode type</li> </ul>
<p><b>4</b> Select <b>yes</b> or <b>no</b> to enable or disable user privileged mode.</p>	<p>Select <b>yes</b> to enable user privileged mode. Select <b>no</b> allow users to access the EXEC facility and start EXEC sessions. User privileged mode provides read/write privileges, but also allows a user to create and modify other users. The default is <b>yes</b>.</p>

Step	Description
5 Select your ISDN switch type.	<p data-bbox="659 293 1220 402">ISDN switch type for your T1 or E1 PRI lines. Set this value if you have selected one of the PRI trunk types. You should obtain the correct switch type from your ISDN service provider (telco). Available choices include:</p> <ul data-bbox="659 418 1220 672" style="list-style-type: none"><li data-bbox="659 418 995 446">• primary-5ess—AT&amp;T 5ess (US)</li><li data-bbox="659 456 995 483">• primary-4ess—AT&amp;T 4ess (US)</li><li data-bbox="659 493 1220 553">• primary-dms100—Northern Telecom (Canada and the US)</li><li data-bbox="659 563 982 591">• primary-net5—NET5 (Europe)</li><li data-bbox="659 600 1197 628">• primary-ntt—Nippon Telephone &amp; Telegraph (Japan)</li><li data-bbox="659 638 1005 665">• primary-ts014—ts014 (Australia)</li></ul> <p data-bbox="659 683 1220 737">CAM provides your selection to the Access Server Shelves in the stack by default.</p>

---

Step	Description
6 Select a signaling type.	<p>The Cisco AS5300 stack supports channel associated signaling (CAS) for channelized T1/E1 lines. Set this value if you have selected one of the PRI trunk types.</p> <p>Typically, all channels of a channelized T1 or E1 line are used for analog calls. However, the Cisco AS5300 stack requires a signal converter to perform conversions between R2 signaling and ear and mouth (E&amp;M) (also called “receive and transmit”) signaling. Valid selections for channelized lines include:</p> <ul style="list-style-type: none"> <li>• Channelized E1</li> <li>• p7</li> <li>• r2-analog</li> <li>• r2-digital</li> <li>• r2-pulse</li> <li>• Channelized T1</li> <li>• fxs-loop-start</li> <li>• fxs-ground-start</li> <li>• e&amp;m-fgb</li> <li>• e&amp;m-fgd</li> <li>• e&amp;m-immediatestart</li> <li>• sas-loop-start</li> <li>• sas-ground-start</li> </ul>


<b>Step</b>	<b>Description</b>
7 Select a CAS custom country.	<p data-bbox="659 293 1214 375">Channel associated signaling (CAS). If you have selected E1 R2 signaling, you might need to select a country customization for this signaling. The options include:</p> <ul data-bbox="659 391 811 1166" style="list-style-type: none"><li data-bbox="659 391 736 418">• None</li><li data-bbox="659 431 780 459">• Argentina</li><li data-bbox="659 472 744 500">• Brazil</li><li data-bbox="659 513 744 540">• China</li><li data-bbox="659 553 780 581">• Columbia</li><li data-bbox="659 594 784 621">• CostaRica</li><li data-bbox="659 634 753 662">• Greece</li><li data-bbox="659 675 780 703">• Indonesia</li><li data-bbox="659 716 740 743">• Israel</li><li data-bbox="659 756 744 784">• Korea</li><li data-bbox="659 797 771 824">• Malaysia</li><li data-bbox="659 837 811 865">• New Zealand</li><li data-bbox="659 878 771 906">• Paraguay</li><li data-bbox="659 919 794 946">• Philippines</li><li data-bbox="659 959 784 987">• Singapore</li><li data-bbox="659 1000 767 1027">• Telemex</li><li data-bbox="659 1040 744 1068">• Telnor</li><li data-bbox="659 1081 771 1109">• Thailand</li><li data-bbox="659 1122 771 1149">• Uruguay</li><li data-bbox="659 1162 784 1190">• Venezuela</li></ul>

Step	Description
8 Select your stack channel type.	<p>Channel type servicing your T1 PRI or E1 PRI lines. The Channel type can be:</p> <ul style="list-style-type: none"> <li>• Single channel—For single-channel configuration throughout the stack</li> <li>• Multi-channel—For multiple-channel configuration throughout the stack</li> <li>• Single and multi-channel—A mixture of single and multiple channels in the stack</li> </ul>
9 Set the external host name for CHAP to use.	Set the Challenge Handshake Authentication Protocol (CHAP) name that the remote users will see when they dial in.
10 Click <b>next</b> .	Proceed to the “Configure Stack Addressing” section on page 4-22.

### Configure Stack Addressing

The fourth dialog box that appears allows to configure stack addressing information. (See Figure 4-7.)

**Figure 4-7 Stack Add for Group Dialog Box (4 of 7)**



To configure stack addressing information:

Step	Description
<b>1</b> Enter the first 3 octets of the starting /24 network.	Depending on the Cisco AccessPath system configuration you have selected, this dialog box shows the number of contiguous class C (/24) networks you need. In this field, enter the first 3 octets of the network address for the first class C network. CAM uses this information to create IP addresses for the ports in your Cisco AccessPath system.
<b>2</b> Enter the first 3 octets of your management network.	In addition to your data network, you need a management network. This network is a /26 network for Cisco AccessPath system stacks.
<b>3</b> Enter the 4th octet.	Select the 4th octet of the starting class C network address. This affects the address map that applies to your configuration. This value applies only to the /26 management network.
<b>4</b> (Optional.) Select a shelf type to show address assignment for the shelves in the stack.	Use this pull-down menu to select the shelves for which you want to see the planned IP addressing. Select from the following: <ul style="list-style-type: none"> <li>• Access Server—Access Server Shelves (Cisco AS5300s)</li> <li>• Offload Server—Router Shelves (Cisco 7206s)</li> <li>• CMS/SW—Console Management Shelves (Cisco 3640) and Switches (Catalyst 5002)</li> </ul>
<b>5</b> Click <b>next</b> .	Proceed to the “Configure Stack Network Management” section on page 4-24.

### Configure Stack Network Management

The fifth dialog box that appears allows you to configure network management information for the stack. (See Figure 4-8.)

**Figure 4-8 Stack Add for Group Dialog Box (5 of 7)**

**Stack add for Group - test2**

**SNMP Information**

Location	Bldg1	Contact	John Smith
Read Only String	public	Write String	private
Read/Write All String	asd	Trap Server IP	101.101.101.2

**NTP Server IP Address**

Primary  Secondary

**Sys Log**

Enable syslogging

Log server IP

Log Level  Log Facility

**back**      **next**      **finish**      **cancel**

150388



To configure network management information:

Step	Description
1	Enter the location of the stack. The physical location of this Cisco AccessPath system (for example, Bldg. 5).
2	Enter a contact. The contact person for this Cisco AccessPath system.
3	Enter a read-only string. The Simple Network Management Protocol (SNMP) read community string.
4	Enter a write string. The SNMP write community string.
5	Enter a read/write all string. This SNMP read/write all community string applies only to stacks that include Catalyst 5002. See the “Supported Cisco AccessPath Stack Types” section on page 4-8 for the devices that make up your stack.
6	Enter the trap server IP address. The IP address of trap server host.
7	(Optional.) Configure the primary Network time Protocol (NTP) server and secondary NTP server IP addresses. The IP address(es) of NTP server(s) synchronize the system clock.
8	(Optional.) Choose to enable or disable syslogging. When this box is checked, syslogging is enabled, and a log of system activity is created.
9	(Optional.) Configure the log server IP address. If you enable syslogging, you must specify the IP address of syslog server host.
10	(Optional.) Configure the log level. You must select a level of logging information. Available levels include: <ul style="list-style-type: none"> <li>• critical</li> <li>• debugging</li> <li>• emergencies</li> <li>• errors</li> <li>• informational</li> <li>• notifications</li> <li>• none</li> <li>• warnings</li> </ul>

Step	Description
11 (Optional.) Select a syslog facility.	This is syslog facility. Available values include: <ul style="list-style-type: none"><li>• auth</li><li>• cron</li><li>• daemon</li><li>• kern</li><li>• local0</li><li>• local1</li><li>• local2</li><li>• local3</li><li>• local4</li><li>• local5</li><li>• local6</li><li>• local7</li><li>• lpr</li><li>• mail</li><li>• news</li><li>• sys10</li><li>• sys11</li><li>• sys12</li><li>• sys13</li><li>• sys14</li><li>• sys9</li><li>• syslog</li><li>• user</li><li>• uucp</li></ul>
12 Click <b>next</b> .	Proceed to the “Configure Stack Security” section on page 4-27.

## Configure Stack Security

The sixth dialog box that appears allows you to configure security information for the stack. CAM supports two types of authentication, authorization, and accounting (AAA) security servers. The dialog box that displays depends on the type of AAA server you select. (See Figure 4-9 through Figure 4-11.) If you select a Remote Access Dial-In User Service (RADIUS) security server, the following dialog box appears:

**Figure 4-9 Stack Add for Group Dialog Box (6 of 7—RADIUS only)**

**Stack add for Group - test2**

**AAA Security Server Used**     Radius     TACACS+     Both

**Radius Configuration**

**Server Address**    101.101.101.4       

**Server Key**    1234

150889

If you select a Terminal Access Controller Access Control System (TACACS+) security server, the following dialog box appears:

**Figure 4-10 Stack Add for Group Dialog Box (6 of 7—TACACS+ only)**

Stack add for Group - test2

AAA Security Server Used     Radius     TACACS+     Both

TACACS+ Configuration

Server Address	101.101.101		
Server Key	1244		

back    next    finish    cancel

15090

If you select Both, the following dialog box appears:

**Figure 4-11 Stack Add for Group Dialog Box (6 of 7—Both)**

**Stack add for Group - test2**

AAA Security Server Used     Radius     TACACS+     **Both**

**Radius Configuration**

Server Address    101.101.101.4    [ ]    [ ]

Server Key    1234

**TACACS+ Configuration**

Server Address    101.101.101    [ ]    [ ]

Server Key    1244

back    next    finish    cancel

15091

To configure security information for the stack:


Step		Description
1	Configure the type of AAA security server used.	You can select RADIUS, TACACS+, or both as your remote security database. If you select RADIUS, see Figure 4-9. If you select TACACS+, see Figure 4-10. If you select Both, see Figure 4-11.
2	Configure the security server IP address.	IP address of the remote RADIUS or TACACS+ server host. This host is typically a UNIX system running RADIUS or TACACS+ software.
3	Configure a server key.	Shared secret text string used between the Access Server Shelf and the RADIUS or TACACS+ server. The Access Server Shelf and RADIUS or TACACS+ server use this text string to encrypt passwords and exchange responses.
4	Click <b>next</b> if you selected Both in Step 1.	Proceed to the “Configure Stack Security Server” section on page 4-31.
5	Click <b>finish</b> if you selected RADIUS or TACACS+ only.	You have successfully added or modified a stack. Proceed to the “Shelf Configuration for Stacks” section on page 5-1.  If you have selected Both in Step 1, proceed to “Scheduling a Stack Download” section on page 4-36.

### Configure Stack Security Server

This dialog box only appears if you have selected Both (TACACS+ and RADIUS) as the AAA security server used. (See Figure 4-12.)

You must configure advanced security features, such as authentication method lists, which you then apply to lines and interfaces. These authentication method lists are security profiles that indicate the protocol AppleTalk Remote Access Protocol (ARAP) or PPP, or login and authentication method (TACACS+, RADIUS, or local authentication).

**Figure 4-12 Stack Add for Group Dialog Box (7 of 7)**



15092

To configure security information for the stack:

Step	Description
1	<p>Configure advanced security features.</p> <p>At this dialog box you can specify whether TACACS+ or RADIUS provide authentication for the following services:</p> <ul style="list-style-type: none"><li>• Login Admin</li><li>• Login Users</li><li>• PPP Users and Tunnels</li><li>• Authorization Network—Prevents unauthorized users from accessing network resources</li><li>• Accounting Network—For the delivery of accounting information</li></ul>
2	<p>Click <b>finish</b>.</p> <p>You have finished everything but the downloading of the configuration.</p> <p>Proceed to the “Shelf Configuration for Stacks” section on page 5-1.</p>

## Modifying a Stack


The procedure for modifying a stack actually alters the configurations of the shelves in the stack instead of simply designing the stack through a series of planning sheets. In most cases, by the time you modify a stack, you probably have already created shelves and configured them. If the shelves in a stack were configured (that is, if CAM downloaded the configurations to the shelves in the stack), modifying a stack automatically updates all of the shelf configurations. The procedures to modify stacks and shelves are similar to those to create the stacks and shelves.

When you modify a stack, CAM creates a new configuration record and saves it in the database. CAM lists the contents of that record in the Modify Stack—Historical Records dialog box. (See Figure 4-13.) At the same time, CAM creates a new configuration record for each shelf in the stack, saves it to the database, and lists the record in their respective Modify Shelf—Historical Record dialog boxes. The stack determines the shelves’ status.

By listing all the records that have been created for the stack, you can select previous configurations or the most recent configuration record to use for your system.



**Figure 4-13**      **Modify Stack—Historical Records Dialog Box**



The Modify Stack—Historical Records dialog box lists the following the stack record fields:

<b>Field</b>	<b>Description</b>
Stack Name	Name you configured for the stack which now displays in the Device Tree View.
Status	Status of the record. The possible status values include: <ul style="list-style-type: none"><li>• Active—Record was successfully configured and is the most recently created record. It is always listed last in the dialog box.</li><li>• Inactive (successful)—Record was successfully configured, but a more recent record exists.</li><li>• Inactive (fail)—Record was not configured successfully.</li><li>• Scheduled—Record was successfully configured but is scheduled to download in the future.</li></ul>
Date	Time the record was created. This date helps you to distinguish the records.

During the stack modification procedure, CAM steps you through a series of dialog boxes in which you can provide new configuration information. Several dialog boxes are common to both the stack modification and stack creation procedures. At these dialog boxes, you can:

- 1 Configure Stack General Information
- 2 Configure Stack Trunk and Name Server Information
- 3 Configure Stack Trunk Interface
- 4 Configure Stack Addressing
- 5 Configure Network Management
- 6 Configure Security

---

**Note** You cannot modify between a E1 controller type and a T1 controller type, but you can modify between a channelized trunk type and a PRI trunk type. In addition, if the stack trunk type is modified from either CT1 or PRI to the CT1 and PRI trunk type, or CE1 or PRI to the CE1 and PRI trunk type, the configuration in the existing shelves will remain unchanged.

---

To modify a stack:

Step	Description
1 Select a stack from the Device Tree View.	The stack you want to modify.
2 Click <b>Configure</b> .	The Task Selection bar displays all the configuration tasks CAM can perform for stacks.
3 Click <b>Modify</b> .	A dialog box containing historical records for the selected stack appears. (See Figure 4-13.)
4 Select a stack record.	The stack record you want to modify.
5 Click <b>Continue</b> .	Proceed to the “Configure Stack General Information” section on page 4-11 to continue the stack modification procedure.

---

## Scheduling a Stack Download

When you modify a stack, you can choose whether to configure the stack now or later. If you choose later, you are able to schedule the download at the last dialog box of the stack modification procedure. (See Figure 4-14.)

**Figure 4-14 Stack Modify for Stack—Schedule Task Dialog Box**

The screenshot shows a dialog box titled "Stack modify for Stack - stack1". It contains the following elements:

- Task Name:** A text box containing "Task48542".
- Comments:** An empty text box.
- Enter the time (CAM Server time) to start the task:** A section with five rows of time selection:
  - Year:** 1998 (range 1998-1999)
  - Month:** 9 (range 1-12)
  - Day:** 4 (range 1-31)
  - Hour:** 8 (range 0-23)
  - Minute:** 5 (range 0-59)
- Buttons:** "back", "next", "finish", and "cancel" are located at the bottom of the dialog.

To schedule a stack download, follow these steps:

Step	Description
1	Enter a task name. Enter a task name for the scheduled stack configuration procedure. This task can be viewed from the Task Manager in the Tools menu.
2	(Optional.) Enter comments. Enter any comments in the comments field.

Step	Description
<p><b>3</b> Enter the time on the server when the download task should start.</p>	<p>Use these fields to schedule the job. The download will occur when the server time matches the time you configure.</p> <ul style="list-style-type: none"> <li>• Year—Year when the download will take place. The first valid year is 1998.</li> <li>• Month—Month when the download will take place. Values are from 1 to 12.</li> <li>• Day—Day when the download will take place. Values are from 1 to 31.</li> <li>• Hour—Hour when the download will take place. Values are from 0 to 23, with 0 being midnight.</li> <li>• Minute—Minute when the download will take place. Values are from 0 to 59.</li> </ul>
<p><b>4</b> Click <b>finish</b>.</p>	<p>You have scheduled the stack download task. You can manage this task through the Task Manager as described in the “Using the Task Manager” section on page 8-59. After a scheduled task executes, you might need to refresh your system. See the “Refreshing Your System” section on page 2-7 for details.</p>

## Deleting a Stack



**Caution** When a stack is deleted, all related information about the stack and its shelves is deleted from the database. Only use this procedure if you are sure you want to delete the stack, its shelves, and its historical data. (See Figure 4-15.)

**Figure 4-15 Delete Stack Dialog Box**



To delete a stack:

Step	Description
1	Select a stack from the Device Tree View. The stack you want to delete.
2	Click <b>Configure</b> . The Task Selection bar displays all the configuration tasks CAM can perform for the stack.

<b>Step</b>	<b>Description</b>
<b>3</b> Click <b>Delete Now</b> , <b>Schedule Later...</b> , or <b>Cancel</b> .	If this is the correct stack, and you are sure you want to delete it and all of its historical data, click <b>Delete Now</b> or <b>Schedule Later...</b> Otherwise, click <b>Cancel</b> .  If you click Schedule Later..., continue with the “Scheduling Stack Deletion” section on page 4-40

### Scheduling Stack Deletion

Scheduling the stack deletion is the final step in the delete stack procedure. (See Figure 4-16.)

**Figure 4-16 Delete Stack Schedule Dialog Box**

**Delete Stack - stack1**

Task Name

Comments

**Enter the time (CAM Server time) to start the task**

Year  (1998-1999)

Month  (1-12)

Day  (1-31)

Hour  (0-23)

Minute  (0-59)

15100

To schedule stack deletion:

Step	Description
1	Enter a task name. Enter a task name for the scheduled stack deletion procedure. This task can be viewed from the Task Manager in the Tools menu.
2	(Optional.) Enter comments. Enter any comments in the comments field.



---

Step	Description
3 Enter the time on the server when the deletion task should start.	<p data-bbox="659 293 1177 375">Use these fields to schedule the job. The deletion will occur when the server time matches the time you configure.</p> <ul data-bbox="659 391 1220 716" style="list-style-type: none"><li data-bbox="659 391 1220 448">• Year—Year when the deletion will take place. The first valid year is 1998.</li><li data-bbox="659 456 1166 513">• Month—Month when the deletion will take place. Values are from 1 to 12.</li><li data-bbox="659 521 1220 578">• Day—Day when the deletion will take place. Values are from 1 to 31.</li><li data-bbox="659 586 1220 643">• Hour—Hour when the deletion will take place. Values are from 0 to 23, with 0 being midnight.</li><li data-bbox="659 651 1177 716">• Minute—Minute when the deletion will take place. Values are from 0 to 59.</li></ul>
4 Click <b>finish</b> .	<p data-bbox="659 737 1220 906">You have scheduled the stack delete task. You can manage this task through the Task Manager as described in the “Using the Task Manager” section on page 8-59. After a scheduled task executes, you might need to refresh your system. See the “Refreshing Your System” section on page 2-7 for details.</p>

---

# Configuring System Controllers

System Controllers provide local gathering and monitoring functions for dial shelves and router shelves within a single point of presence (POP).

To configure a System Controller, complete the following tasks in the following sections. The first two tasks are required; the third and fourth tasks are optional.

- [Creating a System Controller on page 4-42](#)
- [Creating or Modifying a Shelf in a System Controller on page 5-21](#)
- [Modifying a System Controller on page 4-62](#)
- [Deleting a System Controller on page 4-65](#)

## Creating a System Controller


During the System Controller creation or System Controller modification procedure, CAM steps you through a series of dialog boxes in which you provide configuration information. At these dialog boxes, you can:

- 1** [Configure System Controller General Information](#)
- 2** [Configure System Controller Name Server Information](#)
- 3** [Configure System Controller Trunk Interface](#)
- 4** [Configure System Controller Network Management](#)
- 5** [Configure System Controller Security](#)
- 6** [Configure System Controller Security Server](#)
- 7** [Configure System Controller Access and Template](#)
- 8** [Schedule System Controller Download](#)

## Configure System Controller General Information

The first dialog box that appears allows you to configure general information about the System Controller. (See Figure 4-17.)

**Figure 4-17 Create System Controller for Group Dialog Box (1 of 8)**



15084

## Configuring System Controllers

---

To configure general information about the System Controller:

Step	Description
1	(Optional.) Enter a System Controller description. Description cannot exceed 64 characters.
2	Enter a host name. The case-sensitive host name group. It must be unique in the rack.
3	(Optional.) Enter the System Controller serial number. The serial number uniquely identifies the System Controller hardware unit. The serial number can contain up to 32 characters.
4	Select the CAM server time zone. CAM retrieves the default value for your time zone from your local host. Time zones are expressed relative to Greenwich Mean Time (GMT). Verify that this field has the correct value.
5	Enter a Cisco IOS secret password. The Cisco IOS enable secret password is encrypted so that it cannot be read when crossing a network. After you issue this command, the encryption cannot be reversed. The encrypted version of the password appears in output of the <b>show running-config</b> and <b>show startup-config</b> commands. The password cannot exceed 25 characters. You must enter the same password in the Confirm field.
6	Enter a Shelf discovery password. The System Controller uses this password to discover the shelves it manages. This defines the periodic handshake between the System Controller and the shelves. This password must be the same on both the shelf and System Controller. The password cannot exceed 25 characters. You must enter the same password in the Confirm field.
7	Click <b>next</b> . Proceed to the “Configure System Controller Name Server Information” section on page 4-45.

## Configure System Controller Name Server Information

The second dialog box that appears allows you to configure name server information for the System Controller. (See Figure 4-18.)

**Figure 4-18 Create System Controller for Group Dialog Box (2 of 8)**

The dialog box is titled "Create System Controller for Group - test2". It features three distinct sections for configuring name server information:

- IP Name Server(s) Address:** This section includes a text input field, an "Add >>" button, and a "<< Remove" button.
- Async DNS Server(s) Address:** This section includes a text input field, an "Add >>" button, and a "<< Remove" button.
- NetBIOS Name Server(s) Address:** This section includes a text input field, an "Add >>" button, and a "<< Remove" button.

At the bottom of the dialog, there are four buttons: "back", "next", "finish", and "cancel". A vertical number "15074" is located on the right side of the dialog box.

To configure System Controller name server information, follow these steps:

Step	Description
1 (Optional.) Specify your name server address(es).	<p>Domain name servers resolve host names and IP addresses. You can specify one or more addresses.</p> <p>To add an address, enter an address in the left box and click the <b>Add</b> button. It displays in the right box. To remove an address, highlight an address in the right box and click the <b>Remove</b> button.</p>
2 (Optional.) Specify your Async DNS server address(es).	<p>Server address enables remote users to gather DNS information transparently as part of the Point-to-Point Protocol (PPP) negotiation. Dial-in clients using PPP applications such as CiscoRemote and Windows 95 need Domain Name System (DNS) address information as described in RFC 1877.</p> <p>To add an address, enter an address in the left box and click the <b>Add</b> button. It displays in the right box. To remove an address, highlight an address in the right box and click the <b>Remove</b> button.</p>
3 (Optional.) Specify your NetBIOS name server address(es).	<p>Server address enables remote users to gather NBNS information transparently as part of the PPP negotiation. Dial-in clients using PPP applications such as CiscoRemote and Windows 95 need NetBIOS name server (NBNS) address information as described in RFC 1877.</p> <p>To add an address, enter an address in the left box and click the <b>Add</b> button. It displays in the right box. To remove an address, highlight an address in the right box and click the <b>Remove</b> button.</p>
4 Click <b>next</b> .	Proceed to the “Configure System Controller Trunk Interface” section on page 4-47.

### Configure System Controller Trunk Interface

The third dialog box that appears allows you to configure trunk interface information for the System Controller. (See Figure 4-19.)

**Figure 4-19 Create System Controller for Group Dialog Box (3 of 8)**

**Create System Controller for Group - test2**

**CMS IP Addresses**

Ethernet 1/0	101.101.101.6	Mask	255.255.255.255
Loopback1	101.101.101.7	Mask	255.255.255.255
Default-Route IP	101.101.102.5	EIGRP	

**Trunk Interface**

Enable user privileged mode  yes  no

External hostname for chap to use

back      next      finish      cancel

15075

To configure System Controller trunk interface information:

Step	Description
1	Enter the Ethernet I/O IP Address. An IP address in dotted decimal format.
2	Enter the Loopback1 IP address. An IP address in dotted decimal format.
3	Enter the Default-Route IP address. An IP address in dotted decimal format.
4	Enter the mask for the Ethernet I/O and Loopback1. A mask, typically 255.255.255.255 in dotted decimal format.
5	(Optional.) Enter EIGRP network number. We recommend that you specify a routing protocol for the System Controller and its shelves. If you specify an EIGRP network number, CAM automatically configures the System controller and all of its shelves to run EIGRP. If you do not specify EIGRP as the routing protocol for the System Controller and its shelves, you must manually configure the routing protocol for the System Controller and its shelves.
6	Select <b>yes</b> or <b>no</b> to enable or disable user privileged mode. Select <b>yes</b> to enable user privileged mode. Select <b>no</b> to refuse user privileged mode to all but CAM administrators. User privileged mode provides read/write privileges but also allows a user to create and modify other users.
7	Set the external host name for CHAP to use. Set the Challenge Handshake Authentication Protocol (CHAP) name that the remote users will see when they dial in.
8	Click <b>next</b> . Proceed to the “Configure System Controller Network Management” section on page 4-49.



## Configure System Controller Network Management

The fourth dialog box that appears allows you to configure network management information for the System Controller. (See Figure 4-20.)

**Figure 4-20 Create System Controller for Group Dialog Box (4 of 8)**

**Create System Controller for Group - test2**

**SNMP Information**

Location	Bldg 1	Contact	John Smith
Read Only String	public	Write String	private
Read/Write All String	comm1	Trap Server IP	101.101.101.7

NTP Server IP Address

Primary  Secondary

Sys Log

Enable syslogging

Log server IP

Log Level  Log Facility

back next finish cancel

18076

## Configuring System Controllers

---

To configure network management information:

Step	Description
1	Enter the location of the System Controller. The physical location of this System Controller (for example, Bldg. 6).
2	Enter a contact. The contact person for this System Controller system.
3	Enter a read-only string. The Simple Network Management Protocol (SNMP) read community string.
4	Enter a write string. The SNMP write community string.
5	Enter a read/write all string. The SNMP read/write all community string.
6	Enter the trap server IP address. The IP address of trap server host.
7	(Optional.) Configure the primary Network time Protocol (NTP) server and secondary NTP server IP addresses. The IP address(es) of NTP server(s) synchronize the system clock.
8	(Optional.) Choose to enable or disable syslogging. When this box is checked, syslogging is enabled, and a log of system activity is created.
9	(Optional.) Configure the log server IP address. If you enable syslogging, you must specify the IP address of syslog server host.
10	(Optional.) Configure the log level. You must select a level of logging information. Available levels include: <ul style="list-style-type: none"><li>• critical</li><li>• debugging</li><li>• emergencies</li><li>• errors</li><li>• informational</li><li>• notifications</li><li>• none</li><li>• warnings</li></ul>

Step	Description
<p><b>11</b> (Optional.) Select a syslog facility.</p>	<p>The syslog facility to use. Available values include:</p> <ul style="list-style-type: none"> <li>• local 6</li> <li>• local7</li> <li>• lpr</li> <li>• mail</li> <li>• news</li> <li>• sys10</li> <li>• sys11</li> <li>• sys12</li> <li>• sys13</li> <li>• sys14</li> <li>• sys9</li> <li>• syslog</li> <li>• user</li> <li>• uucp</li> </ul>
<p><b>12</b> Click <b>next</b>.</p>	<p>Proceed to the “Configure System Controller Security” section on page 4-52.</p>

### Configure System Controller Security

The fifth dialog box that appears allows you to configure security information for the System Controller. CAM supports two types of authentication, authorization, and accounting (AAA) security servers. The dialog box that displays depends on the type of AAA server you select. (See Figure 4-21 through Figure 4-23.) If you select a Remote Access Dial-In User Service (RADIUS) security server, the following dialog box appears:

**Figure 4-21 Create System Controller for Group Dialog Box (5 of 8—RADIUS)**

The screenshot shows a dialog box titled "Create System Controller for Group - test2". At the top, it says "AAA Security Server Used" with three radio button options: "Radius" (selected), "TACACS+", and "Both". Below this is a "Radius Configuration" section with two main fields: "Server Address" and "Server Key". The "Server Address" field is split into three input boxes, with the first containing "101.101.101.8". The "Server Key" field is a single input box containing "1234". At the bottom of the dialog, there are four buttons: "back", "next", "finish", and "cancel".

Create System Controller for Group - test2			
AAA Security Server Used			
<input checked="" type="radio"/> Radius <input type="radio"/> TACACS+ <input type="radio"/> Both			
Radius Configuration			
Server Address	101.101.101.8		
Server Key	1234		
back	next	finish	cancel

15077

If you select a Terminal Access Controller Access Control System (TACACS+) security server, the following dialog box appears:

**Figure 4-22 Create System Controller for Group Dialog Box (5 of 8—TACACS+)**

The dialog box is titled "Create System Controller for Group - test2". It features a section for "AAA Security Server Used" with three radio button options: "Radius", "TACACS+" (which is selected), and "Both". Below this is a "TACACS+ Configuration" section enclosed in a box. This section contains four input fields: "Server Address" (with the value "101.101.101.9"), "Server Key" (with the value "1234"), and two empty fields. At the bottom of the dialog, there are four buttons: "back", "next", "finish", and "cancel".

15078

If you select Both, the following dialog box appears:

**Figure 4-23 Create System Controller for Group Dialog Box (5 of 8—Both)**

**Create System Controller for Group - test2**

AAA Security Server Used     RADIUS     TACACS+     Both

**Radius Configuration**

Server Address    101.101.101.8    [ ]    [ ]

Server Key    1234

**TACACS+ Configuration**

Server Address    101.101.101.9    [ ]    [ ]

Server Key    1234

back    next    finish    cancel

16079

To configure security information for the System Controller:

Step	Description
1	Configure the type of AAA security server used.      You can select RADIUS, TACACS+, or both as your remote security database. If you select RADIUS, see Figure 4-21. If you select TACACS+, see Figure 4-22. If you select Both, see Figure 4-23.
2	Configure the security server IP address.      IP address of the remote RADIUS or TACACS+ server host. This host is typically a UNIX system running TACACS+ or RADIUS software.

Step	Description
3 Configure a server key.	Shared secret text string used between the Access Server Shelf and the RADIUS or TACACS+ server. The Access Server Shelf and RADIUS or TACACS+ server use this text string to encrypt passwords and exchange responses.
4 Click <b>next</b> .	If you selected Both, proceed to the Configure System Controller Security Server on page 4-55. If you selected either RADIUS or TACACS+, proceed to the “Configure System Controller Access and Template” section.

### Configure System Controller Security Server

The sixth dialog box that appears only applies if you have selected Both (RADIUS and TACACS+) as the AAA security server used. (See Figure 4-24.)

You must configure advanced security features such as authentication method lists, which you then apply to lines and interfaces. These authentication method lists are security profiles that indicate the protocol (AppleTalk Remote Access Protocol [ARAP] or PPP) or login and authentication method (RADIUS, TACACS+, or local authentication).

Figure 4-24 Create System Controller for Group Dialog Box (6 of 8)

**Create System Controller for Group - test2**

AAA Security Server Used     Radius     TACACS+     Both

**Security Server Configuration**

Login Admin	<input checked="" type="radio"/> radius	<input type="radio"/> tacacs
Login Users	<input checked="" type="radio"/> radius	<input type="radio"/> tacacs
PPP Admin	<input checked="" type="radio"/> radius	<input type="radio"/> tacacs
PPP Users and Tunnels	<input checked="" type="radio"/> radius	<input type="radio"/> tacacs
Authorization Network	<input checked="" type="radio"/> radius	<input type="radio"/> tacacs
Accounting Network	<input checked="" type="radio"/> radius	<input type="radio"/> tacacs

back    next    finish    cancel

15080




To configure security information for the system:

Step	Description
<b>1</b> Configure advanced server features.	At this dialog you can specify whether RADIUS or TACACS+ provide authentication for the following services: <ul style="list-style-type: none"> <li>• Login Admin</li> <li>• Login Users</li> <li>• PPP Admin</li> <li>• PPP Users and Tunnels</li> <li>• Authorization Network—Prevents unauthorized users from accessing network resources</li> <li>• Accounting Network—For the delivery of accounting information</li> </ul>
<b>2</b> Click <b>next</b> .	Proceed to the “Configure System Controller Access and Template” section on page 4-58.

### Configure System Controller Access and Template

The seventh dialog box that appears allows you to configure access and template information for the System Controller. (See Figure 4-25.)

**Figure 4-25 Create System Controller for Group Dialog Box (7 of 8)**



To configure security information for the system:

Step	Description
1	Select the access. The access to the System Controller. You can select a terminal server or Ethernet.
2	Enter an IP address. The IP address of Ethernet0 or the terminal server.
3	Enter a Terminal Server Port. The port number for the terminal server. This field only applies if you selected terminal server as the access.

Step	Description
4 Click <b>yes</b> or <b>no</b> to configure the device.	If you click <b>yes</b> , CAM uses this configuration. If you click <b>no</b> , you can use your own configuration tool to download the configuration to the System Controller. However, you cannot use CAM to manage the device, but you need to manually enable the poller to poll the device.
5 The poller is disabled.	This option appears only if you have selected <b>no</b> in Step 4. However, it is always disabled.
6 Click <b>yes</b> or <b>no</b> to backup existing configuration.	If you click <b>yes</b> , CAM will back up the existing configuration on the device. You need to provide a file name (full path) in the file name field. If you click <b>no</b> , the existing configuration is not backed up.
7 Click <b>yes</b> or <b>no</b> to schedule the configuration.	If you click <b>yes</b> , you need to provide schedule information at the Schedule Task dialog box. If you click <b>no</b> , CAM configures after you click <b>finish</b> in Step 10.
8 Select a Configuration Template.	Select from the list of templates. The default template is SC3640-default.txt.
9 Click <b>Preview Configuration File</b> .	You can preview the configuration file created using the selection you made at the previous System Controller dialog boxes. If you need to make changes, click <b>back</b> to the dialog box(es) and make the necessary changes.
10 Click <b>finish</b> .	You have finished everything but the downloading of the configuration.  If you have clicked <b>yes</b> in Step 7, proceed to the “Schedule System Controller Download” section on page 4-60.

### Schedule System Controller Download

When you create or modify a System Controller, you can choose whether to configure the System Controller now or later. If you choose later, you are able to schedule the download at the eighth dialog box that appears. (See Figure 4-26.)

**Figure 4-26 Create System Controller for Group Dialog Box—(8 of 8)**

**Create System Controller for Group - test2**

Task Name:

Comments:

Enter the time (CAM Server time) to start the task

Year:  (1998-1999)

Month:  (1-12)

Day:  (1-31)

Hour:  (0-23)

Minute:  (0-59)

150083

To schedule System Controller download:

Step	Description
1 Enter a task name.	Enter a task name for the scheduled System Controller configuration procedure. This task can be viewed from the Task Manager in the Tools menu.
2 (Optional.) Enter comments.	Enter any comments in the comments field.
3 Enter the time on the server when the download task should start.	<p>Use these fields to schedule the job. The download will occur when the server time matches the time you configure.</p> <ul style="list-style-type: none"> <li>• Year—Year when the download will take place. The first valid year is 1998.</li> <li>• Month—Month when the download will take place. Values are from 1 to 12.</li> <li>• Day—Day when the download will take place. Values are from 1 to 31.</li> <li>• Hour—Hour when the download will take place. Values are from 0 to 23, with 0 being midnight.</li> <li>• Minute—Minute when the download will take place. Values are from 0 to 59.</li> </ul>
4 Click <b>finish</b> .	You have scheduled the System Controller download task. You can manage this task through the Task Manager as described in the “Using the Task Manager” section on page 8-59. After a scheduled task executes, you might need to refresh your system. See the “Refreshing Your System” section on page 2-7 for details.

### Modifying a System Controller

The procedure for modifying a System Controller actually alters the configurations of the shelves in the System Controller instead of simply designing the System Controller through a series of planning sheets. In most cases, by the time you modify a System Controller, you probably have already created shelves and configured them. If the shelves in a System Controller were configured (that is, if CAM downloaded the configurations to the shelves in the System Controller), modifying a System Controller automatically updates all of the shelf configurations. The procedures to modify System Controllers and shelves are similar to those you used to create the System Controllers and shelves.

When you modify a System Controller, CAM creates a new configuration record and saves it in the database. CAM lists the contents of that record in the Modify System Controller—Historical Record dialog box. (See Figure 4-27.) At the same time, CAM creates a new configuration record for each shelf in the System Controller, saves it to the database, and lists the record in their respective Modify Shelf—Historical Record dialog boxes. The System Controller determines the shelves' status.

By listing all the records that have been created for a System Controller, you can select previous configurations or the most recent configuration record to use for your system.

Figure 4-27 Modify System Controller—Historical Records Dialog Box

These are historical records for this stack.  
To reuse the data, select a record and click Continue.  
Otherwise, click Cancel.

Stack Name	Status	Date
SysCon1	inactive succeeded	Mon Aug 31 10:18:19 PDT 1998
SysCon1	inactive succeeded	Mon Aug 31 16:47:14 PDT 1998
SysCon1	active	Thu Sep 03 15:28:00 PDT 1998

◀ | ▶

Continue Cancel

15123

The Modify System Controller—Historical Record dialog box lists the following the system record fields:

<b>Field</b>	<b>Description</b>
Stack Name	Name you configured for the System Controller and which now displays in the Device Tree View.
Status	Status of the record. The possible status values include: <ul style="list-style-type: none"><li>• Active—Record was successfully configured and is the most recently created record. It is always listed last in the dialog box.</li><li>• Inactive (successful)—Record was successfully configured, but a more recent record exists.</li><li>• Inactive (fail)—Record was not configured successfully.</li><li>• Scheduled—Record was successfully configured but is scheduled to download in the future.</li></ul>
Date	Time the record was created. This date helps you to distinguish the records.

During the system modification procedure, CAM steps you through a series of dialog boxes in which you can provide new configuration information. Several dialog boxes are common to both the System Controller modification and System Controller creation procedures. At these dialog boxes, you can:

- 1 Configure System Controller General Information
- 2 Configure System Controller Name Server Information
- 3 Configure System Controller Trunk Interface
- 4 Configure System Controller Network Management
- 5 Configure System Controller Security
- 6 Configure System Controller Security Server
- 7 Configure System Controller Access and Template
- 8 Schedule System Controller Download



To modify a System Controller:

Step	Description
1	Select a System Controller from the Device Tree View.
2	Click <b>Configure</b> .
3	Click <b>Modify</b> .
4	Select a stack record.
5	Click <b>Continue</b> .

## Deleting a System Controller



**Caution** When a System Controller is deleted, all related information about the System Controller and its shelves is deleted from the database. Only use this procedure if you are sure you want to delete the System Controller, its shelves, and its historical data.

To delete a System Controller:

Step	Description
1	Select a System Controller from the Device Tree View.
2	Click <b>Configure</b> .
3	Click <b>Delete Now</b> , <b>Schedule later...</b> , or <b>Cancel</b> .

### Scheduling System Controller Deletion

Scheduling the System Controller deletion is the final step in the delete System Controller procedure. (See Figure 4-28.)

**Figure 4-28 Delete System Controller Dialog Box**



16458

To schedule System Controller deletion:

Step	Description
1 Enter a task name.	Enter a task name for the scheduled System Controller deletion procedure. This task can be viewed from the Task Manager in the Tools menu.
2 (Optional.) Enter comments.	Enter any comments in the comments field.
3 Enter the time on the server when the deletion task should start.	<p>Use these fields to schedule the job. The deletion will occur when the server time matches the time you configure.</p> <ul style="list-style-type: none"> <li>• Year—Year when the deletion will take place. The first valid year is 1998.</li> <li>• Month—Month when the deletion will take place. Values are from 1 to 12.</li> <li>• Day—Day when the deletion will take place. Values are from 1 to 31.</li> <li>• Hour—Hour when the deletion will take place. Values are from 0 to 23, with 0 being midnight.</li> <li>• Minute—Minute when the deletion will take place. Values are from 0 to 59.</li> </ul>
4 Click <b>finish</b> .	You have scheduled the System Controller delete task. You can manage this task through the Task Manager as described in the “Using the Task Manager” section on page 8-59. After a scheduled task executes, you might need to refresh your system. See the “Refreshing Your System” section on page 2-7 for details.

