



Configuring RSVP Support for LLQ

This chapter describes the tasks for configuring the RSVP Support for Low Latency Queueing (LLQ) feature.

For complete conceptual information, see the chapter “[Signalling Overview](#)” in this book.

For a complete description of the RSVP Support for LLQ commands in this chapter, see the [Cisco IOS Quality of Service Solutions Command Reference](#). To locate documentation of other commands that appear in this chapter, use the command reference master index or search online.

To identify the hardware platform or software image information associated with a feature, use the Feature Navigator on Cisco.com to search for information about the feature or refer to the software release notes for a specific release.

RSVP Support for LLQ Configuration Task List

To configure RSVP support for LLQ, perform the tasks described in the following sections. The tasks in the first two sections are required; the tasks in the remaining sections are optional.

- [Configuring Flow Classification, page 2](#) (Required)
- [Enabling RSVP and WFQ, page 2](#) (Required)
- [Configuring a Burst Factor, page 2](#) (Optional)
- [Configuring a Path, page 2](#) (Optional)
- [Configuring a Reservation, page 3](#) (Optional)
- [Verifying RSVP Support for LLQ Configuration](#) (Optional)
- [Monitoring and Maintaining RSVP Support for LLQ, page 4](#) (Optional)

See the end of this chapter for the section “[RSVP Support for LLQ Configuration Examples](#).”



Americas Headquarters:
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

© 2007 Cisco Systems, Inc. All rights reserved.

Configuring Flow Classification

To configure flow classification, use the following command in global configuration mode:

Command	Purpose
Router#(config)# ip rsvp pq-profile	Specifies the criteria for determining which flows go into the priority queue.

Enabling RSVP and WFQ

To enable RSVP and weighted fair queueing (WFQ), use the following commands beginning in global configuration mode:

	Command	Purpose
Step 1	Router(config)# interface s2/0	Enables an interface; for example, serial interface 2/0.
Step 2	Router(config-if)# ip rsvp bandwidth	Enables RSVP on an interface.
Step 3	Router(config-if)# fair-queue	Enables WFQ on an interface with priority queueing (PQ) support.

Configuring a Burst Factor

To configure a burst factor, use the following command in interface configuration mode:

Command	Purpose
Router(config-if)# ip rsvp burst policing	Specifies a burst factor on a per-interface basis.

Configuring a Path

To configure a path, use the following command in global configuration mode:

Command	Purpose
Router(config)# ip rsvp sender	Specifies the RSVP path parameters, including the destination and source addresses, the protocol, the destination and source ports, the previous hop address, the average bit rate, and the burst size.

Configuring a Reservation

To configure a reservation, use the following command in global configuration mode:

Command	Purpose
Router(config)# ip rsvp reservation	Specifies the RSVP reservation parameters, including the destination and source addresses, the protocol, the destination and source ports, the next hop address, the input interface, the service type, the average bit rate, and the burst size.

Verifying RSVP Support for LLQ Configuration

To verify RSVP support for LLQ configuration, perform the following steps:

- Step 1** Enter the **show ip rsvp installed** command to display information about interfaces and their admitted reservations. A sample output is shown.

This output shows that Ethernet interface 2/1 has four reservations and serial interface 3/0 has none.

```
Router# show ip rsvp installed
```

```
RSVP:Ethernet2/1
BPS    To           From           Protoc DPort   Sport   Weight Conversation
44K    145.20.0.202  145.10.0.201  UDP    1000    1000    0         264
44K    145.20.0.202  145.10.0.201  UDP    1001    1001    13        266
98K    145.20.0.202  145.10.0.201  UDP    1002    1002    6         265
1K     145.20.0.202  145.10.0.201  UDP    10      10      0         264
RSVP:Serial3/0 has no installed reservations
Router#
```



Note In the sample output, weight 0 is assigned to voice-like flows, which proceed to the priority queue.

- Step 2** Enter the **show ip rsvp installed detail** command to display additional information about interfaces and their current reservations. A sample output is shown.

```
Router# show ip rsvp installed detail
```

```
RSVP:Ethernet2/1 has the following installed reservations
RSVP Reservation. Destination is 145.20.0.202, Source is 145.10.0.201,
  Protocol is UDP, Destination port is 1000, Source port is 1000
  Reserved bandwidth:44K bits/sec, Maximum burst:1K bytes, Peak rate:44K bits/sec
  Resource provider for this flow:
    WFQ on hw idb Se3/0: PRIORITY queue 264. Weight:0, BW 44 kbps
  Conversation supports 1 reservations
  Data given reserved service:316 packets (15800 bytes)
  Data given best-effort service:0 packets (0 bytes)
  Reserved traffic classified for 104 seconds
  Long-term average bitrate (bits/sec):1212 reserved, 0M best-effort
RSVP Reservation. Destination is 145.20.0.202, Source is 145.10.0.201,
  Protocol is UDP, Destination port is 1001, Source port is 1001
  Reserved bandwidth:44K bits/sec, Maximum burst:3K bytes, Peak rate:44K bits/sec
  Resource provider for this flow:
```

```

WFQ on hw idb Se3/0: RESERVED queue 266.  Weight:13, BW 44 kbps
Conversation supports 1 reservations
Data given reserved service:9 packets (450 bytes)
Data given best-effort service:0 packets (0 bytes)
Reserved traffic classified for 107 seconds
Long-term average bitrate (bits/sec):33 reserved, 0M best-effort
RSVP Reservation. Destination is 145.20.0.202, Source is 145.10.0.201,
Protocol is UDP, Destination port is 1002, Source port is 1002
Router#

```



Note In the sample output, the first flow gets the priority queue (weight = 0) while the second flow does not.

Monitoring and Maintaining RSVP Support for LLQ

To monitor and maintain the RSVP Support for LLQ feature, use the following commands in EXEC mode, as needed:

Command	Purpose
Router# show ip rsvp installed	Displays information about interfaces and their admitted reservations.
Router# show ip rsvp installed detail	Displays additional information about interfaces and their admitted reservations.
Router# show queue <i>interface-type interface-number</i>	Displays queuing configuration and statistics for a particular interface.

RSVP Support for LLQ Configuration Examples

This section provides a configuration example for the RSVP Support for LLQ feature.

For information about configuring RSVP support for LLQ, see the section [“RSVP Support for LLQ Configuration Task List”](#) in this module.

In the following example, PQ parameters, including flow rate and burst factor, are defined:

```

Router(config)# ip rsvp pq-profile ?

<1-1048576>  Max Flow Rate (bytes/second)
voice-like  Voice-like flows
<cr>

Router(config)# ip rsvp pq-profile 11000 1500 ?

<100-4000>      Max Peak to Average Ratio (in %)
ignore-peak-value  Ignore the flow's p/r ratio
<cr>

Router(config)# ip rsvp pq-profile 11000 1500 ignore-peak-value
Router(config)# end

```

```
Router# sh run | include pq-profile
ip rsvp pq-profile 11000 1500 ignore-peak-value
```

In the following example, RSVP is enabled:

```
Router# configure terminal

Enter configuration commands, one per line.  End with CNTL/Z.
Router(config)# interface loopback 40
Router(config-if)# ip rsvp bandwidth ?
    <1-10000000> Reservable Bandwidth(KBPS)
    <cr>

Router(config-if)# ip rsvp bandwidth 300 ?
    <1-10000000> Largest Reservable Flow(KBPS)
    <cr>

Router(config-if)# ip rsvp bandwidth 300 30 ?
    <cr>
Router(config-if)# ip rsvp bandwidth 300 30
Router(config-if)# end
```

In the following example, WFQ is enabled:

```
Router# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
Router(config)# interface e0/1
Router(config-if)# fair-queue
Router(config-if)# fair-queue 64
```

In the following example, a burst factor is configured:

```
Router(config)# interface e3/0
Router(config-if)# ip rsvp burst policing 200
```

In the following example, a path is defined:

```
Router(config)# ip rsvp sender 145.20.20.202 145.10.10.201 udp 10 20
145.10.10.201 loopback 10 80 10
```

In the following example, a reservation is defined:

```
Router(config)# ip rsvp reservation 145.20.20.202 145.10.10.201 udp
10 20 145.20.20.202 lo20 ff load 80 10
```

CCDE, CCENT, CCSI, Cisco Eos, Cisco HealthPresence, Cisco IronPort, the Cisco logo, Cisco Nurse Connect, Cisco Pulse, Cisco SensorBase, Cisco StackPower, Cisco StadiumVision, Cisco TelePresence, Cisco Unified Computing System, Cisco WebEx, DCE, Flip Channels, Flip for Good, Flip Mino, Flipshare (Design), Flip Ultra, Flip Video, Flip Video (Design), Instant Broadband, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn, Cisco Capital, Cisco Capital (Design), Cisco:Financed (Stylized), Cisco Store, Flip Gift Card, and One Million Acts of Green are service marks; and Access Registrar, Aironet, AllTouch, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Lumin, Cisco Nexus, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Collaboration Without Limitation, Continuum, EtherFast, EtherSwitch, Event Center, Explorer, Follow Me Browsing, GainMaker, iLYNX, IOS, iPhone, IronPort, the IronPort logo, Laser Link, LightStream, Linksys, MeetingPlace, MeetingPlace Chime Sound, MGX, Networkers, Networking Academy, PCNow, PIX, PowerKEY, PowerPanels, PowerTV, PowerTV (Design), PowerVu, Prisma, ProConnect, ROSA, SenderBase, SMARTnet, Spectrum Expert, StackWise, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0910R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

© 2007 Cisco Systems, Inc. All rights reserved.