



## **Cisco Active Network Abstraction Customization User Guide Version 3.6**

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

CCVP, the Cisco logo, and the Cisco Square Bridge logo are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn is a service mark of Cisco Systems, Inc.; and Access Registrar, Aironet, BPX, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, iQuick Study, LightStream, Linksys, MeetingPlace, MGX, Networking Academy, Network Registrar, *Packet*, PIX, ProConnect, ScriptShare, SMARTnet, StackWise, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0705R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

*Cisco Active Network Abstraction Customization User Guide Version 3.6*

© 1999-2007 Cisco Systems, Inc. All rights reserved.



# CONTENTS

## CONTENTS

### **Preface**   vii

Preliminary Knowledge Required for Using This Guide   viii

Related Documentation   viii

Obtaining Documentation, Obtaining Support, and Security Guidelines   viii

---

### **CHAPTER 1**

### **Introducing the Cisco ANA Soft Properties Manager**   1-1

About the Soft Properties Manager   1-1

Soft Properties   1-2

Alarm Thresholds   1-2

Basic Concepts and Terms   1-2

---

### **CHAPTER 2**

### **Getting Started**   2-1

Opening the Soft Properties Manager   2-2

Soft Properties Manager Window   2-3

    Properties Panel   2-4

    Element Properties Table   2-4

    Soft Properties Manager Menu Bar   2-5

        Soft Properties File Menu   2-5

        Soft Properties Tools Menu   2-5

    Soft Properties Toolbar   2-5

Soft Properties Manager Workflow   2-7

Creating or Editing a Soft Property   2-8

    Editing a Soft Property   2-8

Defining the General Parameters   2-9

Defining the Parsing Parameters   2-11

    Defining the Parsing Parameters of a Soft Property Table   2-14

Testing the Parsing Rules   2-15

Defining the TCA Alarms Parameters   2-16

Debugging the Soft Property   2-18

Viewing the Soft Property in the Inventory Window   2-19

Publishing the Soft Property 2-20  
 Deleting a Soft Property 2-22  
 Importing and Exporting a Soft Property 2-22  
 Closing the Soft Properties Manager 2-24

**CHAPTER 3**

**Examples 3-1**

Basic Soft Property Example 3-1  
 Soft Property Example Including TCA Alarm 3-8  
 Soft Property Table Example 3-10

**APPENDIX A**

**Parsing Operators/Rules A-1**

Header and Footer A-2  
     Description A-2  
     Dialog Box A-2  
     Parameters A-2  
 Remove Lines A-3  
     Description A-3  
     Dialog Box A-3  
     Parameters A-3  
 Select Lines A-4  
     Description A-4  
     Dialog Box A-4  
     Parameters A-4  
 Replace A-5  
     Description A-5  
     Dialog Box A-5  
     Parameters A-5  
 Match A-6  
     Description A-6  
     Dialog Box A-6  
     Parameters A-7  
 Set A-7  
     Description A-7  
     Dialog Box A-7  
     Parameters A-8  
 Substring A-8  
     Description A-8  
     Dialog Box A-8

Parameters	A-9
Parse Integer	A-9
Description	A-9
Dialog Box	A-9
Parameters	A-10

**APPENDIX B****Alarm Threshold Triggers** B-1

Value Equal	B-1
Value Not Equal	B-2
Upper Threshold	B-2
Lower Threshold	B-3
Upper Rate	B-4
Lower Rate	B-5

**APPENDIX C****Regular Expressions** C-1

Supported Syntax	C-1
Positional Operators	C-1
One-Character Operators	C-1
Character Class Operator	C-2
Branching (Alternation) Operator	C-2
Repeating Operators	C-3
Stingy (Minimal) Matching	C-3
Lookahead	C-3
Unsupported Syntax	C-3





## Preface

---

This Cisco ANA Customization Guide describes managing soft properties and Threshold Crossing Alarms (TCA). Soft properties enable the user to extend the set of supported properties for each Network Element (NE), by adding soft properties to the Virtual Network Elements (VNEs). These properties extend the Cisco IMO and are available through the client GUI as well as through the BQL API. Soft properties are retrieved from the NE using SNMP, or Telnet/SSH. In addition, alarm thresholding enables the user to constantly monitor selected properties and generate an alarm every time they cross a user-defined threshold or violate a condition.

This guide is intended for use by integrators and any other users who want to manage the soft properties and TCA alarms that are executed within the Cisco Active Network Abstraction (ANA) platform.

It includes the following chapters:

- [Chapter 1, “Introducing the Cisco ANA Soft Properties Manager”](#)—Describes the Cisco ANA Soft Properties Manager. In addition, it provides a brief explanation of the terms soft properties and alarm thresholds used throughout this guide.
- [Chapter 2, “Getting Started”](#)—Describes the Soft Properties Manager’s working environment and how to access the Soft Properties Manager’s tools. In addition, it describes how to create, edit and delete a soft property.
- [Chapter 3, “Examples”](#)—Provides several examples of creating a soft property from start to finish, including defining the TCA alarms and defining a soft property table.
- [Appendix A, “Parsing Operators/Rules”](#)—Describes the pre-defined text manipulation operators available for parsing raw device input and turning it into a soft property. In addition, an example of each operator is provided.
- [Appendix B, “Alarm Threshold Triggers”](#)—Describes the pre-defined alarm threshold triggers available for defining TCA alarms.
- [Appendix C, “Regular Expressions”](#)—Describes the package GNU RegExp containing regular expression consists of a character string, where some characters are given special meaning with regard to pattern matching.



### Note

---

Changes to the registry should only be carried out with the support of Cisco Professional Services.

---

## Preliminary Knowledge Required for Using This Guide

The user of the Soft Properties Manager is required to have the following preliminary knowledge before using this tool:

Subject	Description
Networking, device properties	Knowledge of device property retrieval using Telnet/SSH or a SNMP MIB browser.
Data manipulation	Ability to write regular expressions and parse raw strings using basic parsing tools.
Cisco IMO Types	Understanding of the Cisco ANA information model in order to know where to locate/edit the soft property.

## Related Documentation

For more detailed information, refer to the following publications:

- *Cisco Active Network Abstraction Command Builder User Guide*
- *Cisco Active Network Abstraction NetworkVision User Guide*

## Obtaining Documentation, Obtaining Support, and Security Guidelines

For information on obtaining documentation, obtaining support, providing documentation feedback, security guidelines, and also recommended aliases and general Cisco documents, see the monthly *What's New* in Cisco Product Documentation, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>



# CHAPTER 1

## Introducing the Cisco ANA Soft Properties Manager

---

This chapter describes the Cisco ANA Soft Properties Manager. In addition, it provides a brief explanation of the terms soft properties and alarm thresholds used throughout this guide.

- [About the Soft Properties Manager, page 1-1](#)—Describes the Cisco Active Network Abstraction (ANA) platform and architecture. In addition, it provides a brief description of the Soft Properties Manager.
- [Soft Properties, page 1-2](#)—Provides a description of soft properties.
- [Alarm Thresholds, page 1-2](#)—Provides a description of alarm thresholds.
- [Basic Concepts and Terms, page 1-2](#)—Provides a brief description of some basic concepts and terms.



**Note**

---

Changes to the registry should only be carried out with the support of Cisco Professional Services.

---

## About the Soft Properties Manager

Cisco ANA provides deep auto-discovery and maintains a live model of the network. This model is based on Cisco's Device Component Modeling (DCM) architecture, in which each Network Element (NE) is modeled as an interconnected hierarchy of Device Components (DCs), both physical (for example, cards, ports) and logical (for example, forwarding tables, profiles). Each DC maintains a set of properties, which contain its actual data (status, configuration, performance and so on).

When interacting with Northbound clients, the DCM information is translated internally into Information Model Objects (IMO), this is Cisco's TMF513-based Northbound information model, which is the public language of the Cisco ANA system with external systems.

The Cisco ANA property management framework enables the user to extend (in runtime) the system's coverage and capabilities in two areas, namely:

- **Soft Properties**—Extending the NE data collection and modeling, by adding new properties to the DCs, and assigning them to NE MIB variables. The new soft properties are also automatically added to the Northbound IMO.
- **Alarm Thresholds**—Assigning various types of alarm conditions to soft properties.

All property definitions and parameters are maintained in XML meta-data in the registry. To ease the definition process, Cisco ANA provides a friendly, simple-to-use GUI that guides the user through the definition and testing process, and hides the underlying XML definitions.

# Soft Properties

Cisco ANA Virtual Network Elements (VNEs) by default model a subset of the device properties, which cover the most important and commonly used properties. Cisco ANA offers the *Soft Properties* mechanism to enable user-configurable extension of device modeling, which can cover any unsupported MIB variable. This enables adding new monitored NE properties in runtime to the default set of supported properties.

The Soft Properties mechanism enables quick adaptation to new software upgrades and new requirements that arise during ongoing operation and deployment. It provides the field engineer with the ability to adapt the currently installed Cisco ANA software to changes in the deployed network.

Every Soft Property is implemented through a set of definitions that determine how to retrieve, parse and display a certain MIB variable from the NE. The definition process is done through a simple GUI utility, and does not require system restart. Soft properties are retrieved from the NE using SNMP, or Telnet/SSH.

For example, consider the case where the Cisco ANA system monitors the port parameters of an ATM switch, and the operator installs a new software version on the switch that is capable of reporting the BER for each of the ports. Since this capability was not supported in previous software versions of the NE, the Cisco ANA VNE might not support the property. To avoid the need for a new VNE from Cisco, the Soft Property mechanism enables the user to immediately support the new BER feature in the currently installed version.

# Alarm Thresholds

Cisco ANA's main positioning is as a mediation layer between the network and the operational and business support systems. As such, it abstracts the physical network and provides a generic, vendor-neutral network model, with a consistent information model and interface.

Cisco ANA also provides the user with the ability to leverage its live network model for intelligent data processing within the mediation layer. This enables Cisco ANA to conduct advanced processing in areas like fault correlation, root-cause analysis, impact analysis, activation design/validation and so forth. This intelligence enables Cisco ANA to provide processed information to the applications in the upper tiers. This enables Cisco ANA to enhance application functionality, while dramatically reducing the application's complexity and the uploaded data volumes.

Alarm thresholding is one of the major areas in which Cisco ANA can boost its Northbound clients. With this mechanism, Cisco ANA constantly monitors selected properties and generates an alarm every time they cross a user-defined threshold or violate a condition. This eliminates the need for OSS/BSS applications to constantly upload huge amounts of data and process it. Instead, Cisco ANA filters-out irrelevant data, and sends only meaningful notifications.

# Basic Concepts and Terms

- **Managed Element**—Anything managed by the system, usually a component managed by the VNE, for example, a device.
- **Network Element (NE)**—A user-named physical component or device existing in the network.

- **Virtual Network Element (VNE)**—A virtual representation of a single network element as a modeled component. VNEs all communicate with each other to present ANA-based applications with a single, common device abstraction for network element discovery, configuration, status collection, fault analysis and other basic network (FCAPS) functions. VNEs can be extended to support new application functionality.





## CHAPTER 2

# Getting Started

---

This chapter describes the Soft Properties Manager's working environment and how to access the Soft Properties Manager's tools. In addition, it describes from creating to publishing a soft property:

- [Opening the Soft Properties Manager, page 2-2](#)—Describes how to open the Soft Properties Manager.
- [Soft Properties Manager Window, page 2-3](#)—Describes the Soft Properties Manager, including, the toolbar and menu options.
- [Soft Properties Manager Workflow, page 2-7](#)—Describes the steps required to create a new soft property.
- [Creating or Editing a Soft Property, page 2-8](#)—Describes how to start creating a soft property. In addition, it describes how to edit a soft property.
- [Defining the General Parameters, page 2-9](#)—Describes how to define the general parameters of a soft property, including, a soft property table.
- [Defining the Parsing Parameters, page 2-11](#)—Describes how to define the parsing parameters of a soft property
- [Testing the Parsing Rules, page 2-15](#)—Describes how to test the parsing rules.
- [Defining the TCA Alarms Parameters, page 2-16](#)—Describes how to define the TCA alarms parameters of a soft property
- [Debugging the Soft Property, page 2-18](#)—Describes how to debug the soft property.
- [Viewing the Soft Property in the Inventory Window, page 2-19](#)—Describes how to view the newly created or edited soft property in the Inventory window.
- [Publishing the Soft Property, page 2-20](#)—Describes how to publish a soft property to one or more locations across the inheritance hierarchy.
- [Deleting a Soft Property, page 2-22](#)—Describes how to delete a soft property.
- [Importing and Exporting a Soft Property, page 2-22](#)—Describes how to export and import soft properties between managed elements.
- [Closing the Soft Properties Manager, page 2-24](#)—Describes how to close the Soft Properties Manager.

# Opening the Soft Properties Manager

This section provides instructions for launching the Soft Properties Manager. The Soft Properties Manager is launched from a specific network element, which could be a managed element or a selected object within a managed element, such as a port. This network element will be used to develop and test the soft property. The content displayed in the Soft Properties Manager window is based on the location from which it is launched.

Once the soft property has been completed it can be published and attached to a wider scope of managed elements.


**Note**

Initially the soft property only applies to the specific object that you are working on during runtime. Once the soft property has been published and the system has been restarted it will be applied to all objects all objects of the same type, according to the location to which it is published.

To open the Soft Properties Manager:

**Step 1**

Right-click on a managed element in the NetworkVision window's tree pane or workspace to display a shortcut menu.


**Note**

For more information about the NetworkVision window see the *Cisco Active Network Abstraction NetworkVision User Guide*.

or

Open the Inventory window for the required managed element and right-click on the required object in the network element, for example, port or card.


**Note**

For more information about the Inventory window see the *Cisco Active Network Abstraction NetworkVision User Guide*.


**Step 2**

Select **Management | Soft Properties Management** from the shortcut menu. The Soft Properties Manager window is displayed.

# Soft Properties Manager Window

An example of the Soft Properties Manager window is displayed.

**Figure 2-1** Soft Properties Manager Window



1	Menu bar
2	Toolbar
3	Properties panel
4	Element properties table

The Soft Properties Manager window displays a table of all the existing soft properties according to the selected entity from which it has been launched. In addition, the applicable properties panels for the managed entity from which the Soft Properties Manager was launched are displayed. For example, for an ATM port the properties panels displayed are Location Information, ATM, and DS3.



**Note**

No soft properties will be displayed in the Soft Properties Manager window for a managed element and/or required object in the network element when it is opened for the first time.

The Soft Properties Manager enables the user to:

- Add a new soft property.
- Edit an existing soft property.
- Delete a soft property.

- Import and/or export soft properties.
- Test a soft property on the selected managed element.
- Publish a soft property and attach it to a wider scope of managed elements.

The Soft Properties Manager consists of the following:

- [Properties Panel, page 2-4](#)
- [Element Properties Table, page 2-4](#) for the selected managed element or network element
- [Soft Properties File Menu, page 2-5](#)
- [Soft Properties Tools Menu, page 2-5](#)

## Properties Panel

The properties panel is a dropdown list that contains a list of panels equivalent to the panels displayed in NetworkVision for the selected network element from which the Soft Properties Manager was launched. For example, where an ATM port is selected as the launching point the properties panel contains Location Information, ATM and OC3 properties. The user can then select the panel to which to add the property.

## Element Properties Table

The content displayed in the element properties table changes according to the selection made in the properties panel. The following information is displayed in the element properties table of the Soft Properties Manager window:

- **Label**—The name of the property as displayed in the GUI, for example, Port Type. For tables this is the table name displayed in the tab.
- **Type**—The soft property type, namely, Property or Table.
- **Polling**—The polling group specified for the property, for example, system or status.
- **Enabled**—Runs (**true**) or does not run (**false**) the command.
- **Command Line**—The command execution for this protocol that should be sent to the NE to retrieve the property. This command can be either a Telnet/SSH command or an SNMP get for a specific OID.

A table can be sorted:

- According to a column by clicking on the required column heading. The sort icon is displayed next to the selected column heading.
- In ascending or descending order by clicking on the column heading. A triangle is displayed next to the selected column heading.

Clicking on a red triangle displayed in a cell expands the cell to display all the information in the cell.

The Location field displays the number of selected rows and the total number of rows in the table, for example, 2/16 Selected. In addition, it displays the location of the selected row(s) in the table, for example, Line 3.

## Soft Properties Manager Menu Bar

This section provides a description of each option available in the Soft Properties Manager menus. The following menus are available:

- The File menu
- The Tools menu

### Soft Properties File Menu

The File menu is displayed and provides the following options:

- **New Element**—Enables the user to create a new soft property. For more information see [Creating or Editing a Soft Property, page 2-8](#).
- **Edit Element**—Enables the user to edit an existing soft property. For more information see [Editing a Soft Property, page 2-8](#).
- **Delete Element**—Enables the user to delete a soft property whether or not it has been published. For more information see [Deleting a Soft Property, page 2-22](#).

### Soft Properties Tools Menu

The Tools menu is displayed.




The Tools menu provides the following options:

- **Export Element**—Enables the user to save a soft property to a file that can later be imported to another managed element. For more information see [Importing and Exporting a Soft Property, page 2-22](#).
- **Import Element**—Enables the user to copy a soft property from an exported file and import this soft property to another managed element. For more information see [Importing and Exporting a Soft Property, page 2-22](#).
- **Hierarchy Manager**—Enables the user to move the soft property to a different location or change the scope of the soft property across the network hierarchy (publishing). For more information see [Publishing the Soft Property, page 2-20](#).

## Soft Properties Toolbar

The following buttons are displayed in the Soft Properties Manager:

**Table 2-1**      **Soft Properties Manager Toolbar**

	<b>New Element</b> —Enables the user to create a new soft property. For more information see <a href="#">Creating or Editing a Soft Property, page 2-8</a> .
	<b>Edit Element</b> —Enables the user to edit an existing soft property. For more information see <a href="#">Editing a Soft Property, page 2-8</a> .
	<b>Delete Element</b> —Enables the user to delete a soft property whether or not it has been published. For more information see <a href="#">Deleting a Soft Property, page 2-22</a> .

**Table 2-1** *Soft Properties Manager Toolbar (continued)*

**Export Element**—Enables the user to save a soft property to a file that can later be imported to another managed element. For more information see [Importing and Exporting a Soft Property, page 2-22](#).



**Import Element**—Enables the user to copy a soft property from an exported file and import this soft property to another managed element. For more information see [Importing and Exporting a Soft Property, page 2-22](#).




**Hierarchy Manager**—Enables the user to move the soft property to a different location or change the scope of the soft property across the network hierarchy. For more information see [Publishing the Soft Property, page 2-20](#).

The **Close** button closes the Soft Properties Manager window. For more information see [Closing the Soft Properties Manager, page 2-24](#).

# Soft Properties Manager Workflow

The workflow below describes the steps required to define a new soft property definition using the Soft Properties Manager and the order in which they must be performed.

**Figure 2-2** Workflow



At any point after the soft property has been defined, it can be tested, and published to a wider scope of managed elements and/or network elements.

For more information:

- [Creating or Editing a Soft Property, page 2-8](#)
- [Defining the General Parameters, page 2-9](#)
- [Defining the Parsing Parameters, page 2-11](#)
- [Testing the Parsing Rules, page 2-15](#)
- [Defining the TCA Alarms Parameters, page 2-16](#)
- [Debugging the Soft Property, page 2-18](#)
- [Viewing the Soft Property in the Inventory Window, page 2-19](#)

- [Publishing the Soft Property, page 2-20](#)
- [Deleting a Soft Property, page 2-22](#)
- [Importing and Exporting a Soft Property, page 2-22](#)

## Creating or Editing a Soft Property

The Soft Properties Manager enables the user to create or edit an existing soft property using the Add Soft Property dialog box. First the user must determine the managed element and/or selected object in the network element to which the soft property should be added.

To create a Soft Property

- 
- Step 1** Right-click on a managed element in the NetworkVision window's tree pane or workspace to display a shortcut menu,
- or
- Open the Inventory window for the required managed element and right-click on the required object in the network element, for example, port or card. A shortcut menu is displayed.
- Step 2** Select **Management | Soft Properties Management** from the shortcut menu. The Soft Properties Manager window is displayed.
- Step 3** Click **New Element** on the toolbar of the Soft Properties Manager window.
- or
- Select **New Element** from the File menu or shortcut menu. The Add Soft Property dialog box is displayed.
- 

The Add Soft Property dialog box is divided into the following tabs (configuration categories):

- **General** tab enables you to configure general definitions for the soft property. For more information about defining the General parameters see [Defining the General Parameters, page 2-9](#).
- **Parsing** tab enables you to configure parsing definitions for the soft property. For more information about defining the Parsing parameters see [Defining the Parsing Parameters, page 2-11](#).
- **TCA Alarms** tab enables you to configure alarm threshold management for the soft property. For more information about defining the TCA Alarms parameters see [Defining the TCA Alarms Parameters, page 2-16](#).

## Editing a Soft Property

The user can edit an existing soft property and the soft property that is edited will affect only the local instance. When an inherited soft property is edited, the new local instance overrides the generic soft property definition for the specific managed element.

To edit a soft property:

- 
- Step 1** Select the soft property that you want to edit in the table of the Soft Properties Manager window.
- Step 2** Click **Edit Element** on the toolbar of the Soft Properties Manager window.

or

Select **Edit Element** from the File menu or shortcut menu.

The hierarchy manager table is displayed.



**Note** If user-friendly VNE names exist in the schema then the hierarchy manager table will display these user-friendly registry location names in the VNE Hierarchy Location column. A user-friendly VNE name is a hierarchy path that has been defined in the registry and is then displayed in the hierarchy manager table. For more information see [Publishing the Soft Property, page 2-20](#).

- Step 3** Select the required version of the soft property from the hierarchy manager, and click **OK**. The Edit Soft Property dialog box is displayed for the selected soft property.
- Step 4** Edit the soft property as required by changing the existing information using the Soft Properties Manager window.
- Step 5** When the soft property has been successfully edited click **OK** in the Edit Soft Property dialog box to save the edited soft property. The edited soft property is supported and displayed in the Soft Properties Manager window.

For information about viewing the edited soft property in the Inventory window see [Viewing the Soft Property in the Inventory Window, page 2-19](#).

For information about publishing the edited soft property see [Publishing the Soft Property, page 2-20](#).

## Defining the General Parameters

The **General** tab enables the user to configure general definitions for the soft property. The user can also configure just a single soft property field or an entire soft property table.

To define the General parameters:

- Step 1** Select the **General** tab in the Add Soft Property dialog box. The **General** tab is displayed.

The following fields are displayed in the **General** tab of the Add Soft Property dialog box:

- **Name**—The soft property identifier, which is unique to the location and IMO scope. This field is mandatory.



**Note** A warning message is displayed if the name specified already exists. The user will be asked whether to override the existing soft property implementation.

- **Label**—The soft property name that is displayed in the GUI, which is unique to the location and IMO scope. For tables this is the table name that is displayed in the tab. This field is mandatory.
- **Description**—A description of the soft property.

The following dropdown lists are displayed in the **General** tab of the Add Soft Property dialog box:

- **Type**—The soft property type, namely, **Property** or **Table**. By default **Property** is selected. The fields displayed in the **Parsing** tab are dependent on the user's selection.




---

**Note** If Table is selected the TCA Alarms tab is not displayed in the Add Soft Property dialog box.

---

- **Polling Rate**—The polling rate group to which the soft property is assigned, namely one of the following:
  - trapevent
  - topo\_unicast\_pkts
  - topo\_I2
  - buffering
  - topo\_I1
  - configuration
  - status
  - system

The following checkbox is displayed in the **General** tab of the Add Soft Property dialog box:

- **Enabled**—Enables or disables the VNE to run or not run the command. By default this option is enabled.

The following buttons are displayed in the Add Soft Property dialog box:

- **OK**—Validates the changes according to the field's rules, namely, the definitions defined in the **General**, **Parsing** and **TCA Alarms** tabs. If the validation is successful, the changes are saved and the Add Soft Property dialog box is closed.




---

**Note** A warning message is displayed if the validation is unsuccessful.

---

- **Cancel**—Closes the Add Soft Property dialog box without saving any changes.
- **Debug**—Opens the Debug Soft Property dialog box displaying the status of the soft property debug.

**Step 2** Define the soft property's general parameters.




---

**Note** If you selected the soft property type Table proceed to [Defining the Parsing Parameters of a Soft Property Table, page 2-14](#) to continue creating the soft property.

---

Proceed to [Defining the Parsing Parameters, page 2-11](#) to define the parsing parameters of the soft property.

# Defining the Parsing Parameters

The **Parsing** tab enables the user to configure, view and edit parsing definitions defined for the soft property.

To define the Parsing parameters:

- Step 1** Select the **Parsing** tab in the Add Soft Property dialog box. The **Parsing** tab is displayed as shown below when the **Property** type is selected in the **General** tab.



**Note** If the Table type is selected in the General tab only the SNMP option is displayed. For more information about defining parsing parameters for a soft property table see [Defining the Parsing Parameters of a Soft Property Table, page 2-14](#).

The **Parsing** tab enables you to specify either a Telnet/SSH command or a MIB OID for an SNMP GET command.

The following radio buttons are displayed in the **Parsing** tab:

- **Use SNMP get(OID)**—The SNMP retrieval expression. The text field is enabled and mandatory when this option is selected. The expression can include environmental arguments.



**Note** When Use SNMP get(OID) is selected press **Ctrl-Spacebar** in the text box to open a selection list of the entire collection of parameters available for all the protocols.

An example of the output presented when pressing **Ctrl-Spacebar** for a port is displayed below.

**Figure 2-3** Output

```
moduleIfIndex - -1
portAlias - FastEthernet0
ifIndex - 2
specificType - 6
```

Sometimes, when building a soft property the Telnet/SSH command is context sensitive. A good example of this is when you want to retrieve some port related data through SNMP, "walk"ing all the ports to find the relevant port each time is not efficient and can greatly affect system performance. To solve this "Instrumentation Data" is available for the soft property. The instrumentation data is a variant between different elements in the system depending on the context object to which you want to add the soft property to.

In this example, the instrumentation data is the port ifIndex. In order to use the ifIndex in the OID, do the following "1.3.1.6.....\$ifIndex\$.5.6.4". In order to ascertain what instrumentation data is available for your context object press **Ctrl-Spacebar** while the cursor is on the "command" field.

- **Use Telnet/SSH**—The Telnet/SSH retrieval expression. The text field is enabled and mandatory when this option is selected. The expression can include environmental.




---

**Note** When Use Telnet/SSH is selected press Ctrl-Spacebar in the text box to open a selection list of the entire collection of parameters available for all the protocols.

---

The text area in the **Parsing** tab enables you to enter the command line of the protocol. For example, for SNMP enter the OID of the SNMP packet; and for Telnet enter the Telnet command line.




---

**Note** The SNMP OID should start with a dot, for example, if the user wants to retrieve the OID value of “1.3.6...” then the user should write “.1.3.6...”.

---

The following columns are displayed in the table of the **Parsing** tab:

- **Index**—Displays the order of the parsing rules.
- **Operation**—Displays the parsing operator type selected in the Add/Edit Parsing Rule dialog box. For more information about parsing operators see [Appendix A, “Parsing Operators/Rules”](#).

The following buttons are displayed in the **Parsing** tab:

- **Add**—Enables you to add a new operator. The Add/Edit Parsing Rule dialog box is displayed.
- **Edit**—Enables you to edit an existing operator. The Add/Edit Parsing Rule dialog box is displayed.




---

**Note** You can also edit an operator by double-clicking on the required operator in the table.

---

- **Delete**—Enables you to delete the selected operator from the table.




---

**Note** Delete an operator by selecting it in the table and clicking Delete.

---

- **Test**—Enables you to test the soft property parsing. The Test Parsing Rules dialog box is displayed. For more information see [Testing the Parsing Rules, page 2-15](#).


The reorder arrows enable you to move the rules up and down within the sequence in order to change the parsing order.

**Step 2** Select one of the following options:

- Use **SNMP get(OID)** or
- Use **Telnet/SSH** or

**Step 3** Click **Add**. The Add/Edit Parsing Rule dialog box is displayed.

Figure 2-4 Add/Edit Parsing Rule Dialog Box



1	Argument 1
2	Argument n
3	Source
4	Result

The Add/Edit Parsing Rule dialog box is used for adding, editing and testing of the parsing operators. Once the required operator is selected, the corresponding arguments are displayed.

The following dropdown lists are displayed in the Add/Edit Parsing Rule dialog box:

- **Input Buffer**—A dropdown list that displays the list of output arguments defined in previous operators and the default (the standard output buffer of the last predecessor operator that was not redirected into an output argument). This field is mandatory.

The parsing result of operator N is available by default as input for operator N+1 (appear as Default for the Input Buffer). The parsing result of operator N may be directed to a locally defined environment argument. In this case the input for operator N+1 is the same as for operator N. Changing the default input buffer is supported by selecting an input buffer other than Default. The available inputs buffers for Operator N+1 are the set of output arguments defined in Operators 1 through N.

The fields displayed in the **Expression** area of the window change depending on your selection in the **Operator** dropdown list, which is mandatory. When an operator is selected the corresponding arguments are displayed. The **Operator** dropdown list enables you to select one of the available parsing operators, namely:

- **Header And Footer**—Removes a specified number of lines from the header and footer of the input text. For more information see [Header and Footer, page A-2](#).
- **Remove Lines**—Removes a range of lines from the specified starting row to the specified end row of the input text. For more information see [Remove Lines, page A-3](#).

- **Select Lines**—Extracts a range of lines from the specified starting row to the specified end row of the input text. For more information see [Select Lines, page A-4](#).
- **Replace**—Finds one or all occurrences of a substring, which matches a specified regular expression, and replaces it with a specified value. For more information see [Replace, page A-5](#).
- **Match**—Finds and extracts a substring, which matches a specified regular expression. If no match can be found the output buffer receives an empty string. For more information see [Match, page A-6](#).
- **Set**—Formats the input buffer and local arguments defined in previous operators using a regular expression. For more information see [Set, page A-7](#).
- **Substring**—Extracts a substring of a specified length from a specified starting point. For more information see [Substring, page A-8](#).
- **Parse Integer**—Uses the substring rule and when a result is received with the substring it converts it into an integer value. For more information see [Parse Integer, page A-9](#).




---

**Note** If the substring operator contains any characters the parsing integer operator will fail.

---

The **Argument 1** and **Argument n** fields displayed in the Add/Edit Parsing Rule dialog box is dynamic and lists the corresponding arguments according to the selected operator. For more information about the operators and the corresponding arguments that are displayed see [Appendix A, “Parsing Operators/Rules”](#).

The **Direct result to output buffer variable** checkbox and corresponding field enables you to direct the parsing output to the provided argument instead of it being the input value for the next operator. The text box is only enabled when the checkbox is selected and a unique (within the complete parsing sequence of this soft property instance) argument name must be provided in this field.

The **Simulation** area is divided into two text areas:

- The **Source** text box is used to enter or paste parsing information.
- The **Result** text box is used to view the parsed result.

The information entered and displayed in the **Simulation** area is not saved when the dialog box is closed. The **Test Expression** button parses the information entered in the **Source** text box according to the parsing operator defined and displays the result in the **Result** text box.

The following buttons are displayed in the Add/Edit Parsing Rule dialog box:

- **OK**—Validates the operator according to the selected operator’s validation rules. Saves the changes and closes the Add/Edit Parsing Rule dialog box.
- **Cancel**—Closes the Add/Edit Parsing Rule dialog box without saving the changes.

**Step 4** Define the parsing rules.

---

Proceed to [Testing the Parsing Rules, page 2-15](#) to test the parsing rules.

## Defining the Parsing Parameters of a Soft Property Table

The **Parsing** tab displayed in the Add Soft Property dialog box changes when the user selects **Table** type in the **General** tab in order to configure a soft property table.

To define the Parsing parameters of a soft property table:

**Step 1** Select the **Parsing** tab in the Add Soft Property dialog box. The **Parsing** tab is displayed.

The following radio button is displayed in the **Parsing** tab of the Add Soft Property dialog box:

- **Use SNMP get(OID)**—The SNMP retrieval expression. The text field is mandatory when this option is selected. The expression can include environmental arguments.



**Note** When Use SNMP get(OID) is selected press Ctrl-Spacebar in the text box to open a selection list of the entire collection of parameters available for all the protocols.

The following columns are displayed in the table of the **Parsing** tab:

- **Title**—Displays the column headings of the table.
- **OID**—Displays the column information for the table.

For more information about the buttons displayed in this tab see [Defining the Parsing Parameters, page 2-11](#).

**Step 2** Click **Add**. The Add/Edit Column Controller dialog box is displayed.

The Add/Edit Column Controller dialog box enables you to add, and/or edit the columns and information displayed in the table.

The following fields are displayed in the Add/Edit Column Controller dialog box:

- **Column Title**—The column heading displayed in the table.
- **Column Data**—The column information displayed in the table.

The following buttons are displayed in the Add/Edit Column Controller dialog box:

- **OK**—Saves the column information and closes the Add/Edit Column Controller dialog box.
- **Cancel**—Closes the Add/Edit Column Controller dialog box without saving any changes.
- **Apply**—Saves the column information and the Add/Edit Column Controller dialog box remains open.

**Step 3** Define the soft property's table information.

**Step 4** Click **OK**. The **Parsing** tab is displayed along with the newly defined table information.

Proceed to [Debugging the Soft Property, page 2-18](#) to debug the soft property table.

## Testing the Parsing Rules

The Soft Properties Manager provides testing functions, which enable the user to simulate each parsing rule (as well as the whole parsing sequence). In addition, the user can test and debug the property on the NE.

The user can test and simulate the actual input parsing according to the parsing operators and display the parsing result. This tests all the defined parsing rules in the order that they are given.

To test the parsing rules:

- 
- Step 1** Click **Test Expression** in the Add/Edit Parsing Rule dialog box. The Test Parsing Rules dialog box is displayed.
- The **Input Buffer** area enables the user to enter the input to parse. The parsing input can be copied and pasted by the user or be retrieved from the device. The **Input Buffer** area is mandatory.
- The **Output Buffer** area displays the parsing result log. It may contain only the final parsing result or the entire parsing log with comments per parser used.
- The following buttons are displayed in the Test Parsing Rules dialog box:
- **Close**—Closes the Test Parsing Rules dialog box.
  - **Test**—Parses the input entered in the **Input Buffer** area according to the parsing operators. The parsing result is displayed in the **Output Buffer** area.
- Step 2** Click **Test**. The results of the test are displayed Test Parsing Rules dialog box.
- Step 3** Click **Close**. The Add/Edit Parsing Rule dialog box is displayed.
- Step 4** Click **OK**. The **Parsing** tab is displayed.
- 

Proceed to [Defining the TCA Alarms Parameters, page 2-16](#) to define the TCA alarm parameters of the soft property.

## Defining the TCA Alarms Parameters

The **TCA Alarms** tab enables the user to set threshold conditions for the soft property value, which will generate an alarm when crossed.

The user can select the severity level that will be associated with the alarm, and enable/disable the alarm. In addition, the user can select the threshold type.

The user can define multiple alarms for the same soft property. The alarm is displayed in the ticket pane of the NetworkVision window.

To define the TCA Alarms parameters:

- 
- Step 1** Select the **TCA Alarms** tab. The **TCA Alarms** tab is displayed.



**Note** The TCA Alarms tab is only displayed when the Property type is selected in the General tab.

---

The following columns are displayed in the **TCA Alarms** tab:

- **Description**—A free text area used to describe the alarm.
- **Trigger**—Displays the details of the trigger selected, namely, what will cause the alarm to be sent. For more information about triggers see [Appendix B, “Alarm Threshold Triggers”](#).
- **Enabled**—Displays the status of the alarm, namely, enabled (**true**) or disabled (**false**), as defined in the **General** tab of the Add TCA dialog box.

The following buttons are displayed in the **TCA Alarms** tab:

- **Add**—Opens the Add TCA dialog box, enabling you to define the parameters of the TCA alarm.

- **Edit**—Opens the Add TCA dialog box enabling you to edit the parameters of a previously defined TCA alarm.



---

**Note** Edit the parameters of a TCA alarm by selecting it in the table and clicking Edit.

---

- **Delete**—Deletes the selected TCA alarm from the **TCA Alarms** tab.



---

**Note** Delete a TCA alarm by selecting it in the table and clicking Delete.

---

**Step 2** Click **Add**. The Add TCA dialog box is displayed. The Add TCA dialog box is divided into the following tabs:

- **General** tab—Enables you to define the general parameters of the TCA alarm, for example, the severity and the name of the alarm.
- **Trigger** tab—Enables you to define the alarm threshold trigger for the TCA alarm. For more information see [Appendix B, “Alarm Threshold Triggers”](#).

The following fields are displayed in the **General** tab of the Add TCA dialog box:

- **Name**—The alarm name that is displayed in the ticket pane when the alarm is triggered.
- **Description**—A description of the alarm.

The following checkboxes are displayed in the **General** tab of the Add TCA dialog box:

- **Enabled**—Select this option to enable the alarm or deselect this option to disable the alarm.
- **Can be correlated to other alarms**—Select this option to correlate this alarm to other alarms. For more information about correlating alarms see the *Cisco Active Network Abstraction NetworkVision User Guide*.
- **Can other alarms be correlated to this alarm**—Select this option to enable other alarms to be correlated to this alarm. For more information about correlating alarms see the *Cisco Active Network Abstraction NetworkVision User Guide*.

The following dropdown list is displayed in the **General** tab of the Add TCA dialog box:

- **Alarm Severity**—Select the severity level associated with the alarm, namely:
  - Critical
  - Major
  - Minor
  - Warning
  - Normal

For more information about alarm severity see the *Cisco Active Network Abstraction NetworkVision User Guide*.

The **Alarm description preview** area is currently unavailable in this version.

The following buttons are displayed in the **General** tab of the Add TCA dialog box:

- **OK**—Saves the parameters of the TCA alarm and closes the Add TCA dialog box.
- **Cancel**—Closes the Add TCA dialog box without saving any changes.
- **Apply**—Saves the parameters of the TCA alarm and the Add TCA dialog box remains open.

**Step 3** Define the **General** parameters for the TCA alarm.

- Step 4** Select the **Trigger** tab. The **Trigger** tab in the Add TCA dialog box is displayed. The following dropdown list is displayed in the **Trigger** tab of the Add TCA dialog box:
- **Trigger**—Select one of the following threshold types:
    - **Value Equal**—The alarm condition is reached when the soft property value is equal to the value defined in the “Alarm Value” regardless if it is numeric or not. For more information see [Value Equal, page B-1](#).
    - **Value Not Equal**—The alarm condition is reached when the soft property value is NOT equal to the value defined in the “Alarm Value” regardless if it is numeric or not. For more information see [Value Not Equal, page B-2](#).
    - **Upper Threshold**—The upper threshold value, which when crossed triggers the alarm for the defined numeric properties. For more information see [Upper Threshold, page B-2](#).
    - **Lower Threshold**—The lower threshold value, which when crossed triggers the alarm for the defined numeric properties. For more information see [Lower Threshold, page B-3](#).
    - **Upper Rate**—The upper rate threshold value for the performance counters, which when crossed triggers the alarm for the defined numeric properties. For more information see [Upper Rate, page B-4](#).
    - **Lower Rate**—The lower rate threshold value for the performance counters, which when crossed triggers the alarm for the defined numeric properties. For more information see [Lower Rate, page B-5](#).

For more information about triggers see [Appendix B, “Alarm Threshold Triggers”](#).

**Step 5** Define the **Trigger** parameters for the TCA alarm.

**Step 6** Click **OK**. The **TCA Alarms** tab is displayed.

---

Proceed to [Debugging the Soft Property, page 2-18](#) to debug the soft property.


## Debugging the Soft Property

The user can debug the soft property on the managed element or selected object in the network element by opening the Debug Soft Property dialog box, which displays the status of the soft property when it is debugged. For example, to confirm that a selected device supports Telnet (see [Chapter 3, “Examples”](#) for more information).

To debug the soft property:

- 
- Step 1** Click **Debug** in the Add Soft Property dialog box. The Debug Soft Property dialog box is displayed with the results of the debug.

Figure 2-5 Debug Soft Property Dialog Box



```

Debug Soft Property
-----
Loading/Reloading command for:
Component = Managed Element
Command Parameters:
Command 'TelnetStringCommand':
Name = telnet command
IP = null
Context = null
Telnet Commands={show ip vrf example}
-----
Registration Loader
-----
Finished Loading the registration with the following parameters:
Device IP = 80.80.80.63
Device component = Managed Element
Registration Name = debug-1117711957285-debug
Registration ID(regID) = 166
-----
Regular Expression Parser
-----
Initial data for parsing:
Name           Default RD   Interfaces
-----
example        55:55
Result after applying step 0 ('Match \d\d'):
55
Result after applying step 1 ('Substring from 0 To 1'):
5
-----
Finished Parsing
-----
Command Handler
-----
Starting to handle response from the instrumentor
-----
Received result with the following data:
Command Handler = com.sheer.metrocentral.framework.da.SoftPropertyCommandHandler
Device IP: 80.80.80.63
Got response:
Status = Valid
-----
Close
-----
Ready Connected 180294

```

- Step 2** Click **Close**. The Add Soft Property dialog box.
- Step 3** Click **OK**. The Soft Properties Manager window is displayed with the newly created soft property displayed in the **element properties** table.
- Step 4** Click **Close**. The NetworkVision or Inventory window is displayed depending on your original selection.

Proceed to [Viewing the Soft Property in the Inventory Window, page 2-19](#) to view the results of the soft property in the Inventory window.

## Viewing the Soft Property in the Inventory Window

After creating or editing a soft property the user can view the results in the **Properties** pane of the Inventory window for the managed element or selected object in the network element.



### Note

The user will only be able to view the soft property in the Inventory window after it has been closed and reopened. For example, if you open an inventory on a VNE and add a property to one of the ports then it will only be displayed after you close and reopen the inventory on the VNE.

To view the soft property:

- Step 1** Right-click on the required managed element in the tree pane or workspace of the NetworkVision window, and select **Inventory** from the shortcut menu. The Inventory window for the required managed element is displayed with the newly defined soft property or soft property table.
- Step 2** Click in the top right corner to close the Inventory window.

Proceed to [Publishing the Soft Property, page 2-20](#) to publish the soft property.

## Publishing the Soft Property

A property definition is applicable to all objects of the same type in the selected NE. However, the user may want to apply the same property definitions to all NEs of the same type or family. This requires moving the property definition from the specific NE instance to a higher level in the registry hierarchy.


After the soft property has been defined and tested on a specific instance of a managed element it can be published and applied to wider scope of managed elements in the network.

The Soft Properties Manager Soft Properties Publish Controller dialog box enables the user to publish the soft property to one or more locations across the inheritance hierarchy (as defined in the system). In other words the user defines the scope where the soft property will be applied in the hierarchy.

Different variations of a soft property can be used for different managed elements and network elements, where the implementation of the soft property is different for each managed element or network element.

An example of an inheritance hierarchy is displayed below. In this example, the top level of the hierarchy is All devices and the lowest level of the hierarchy is Device XYZ.

**Figure 2-6** Inheritance Hierarchy Example



When a soft property is published to a node in the hierarchy, this overrides any inherited soft properties from a higher level, and automatically applies it to all its children. For example, if a soft property is published to Cisco 7200 it will override any variant of this soft property which is defined at a higher level, and will be assigned to all devices of type Cisco 7200 in the system.



**Note**

It is highly recommended that you measure the affect of publishing the soft property on memory usage of the system before it is published. To view the changes you must restart the VNE or unit in order for the publishing to take affect. For more information about measuring the affect of publishing the soft property, please contact Cisco Professional Services.



**Note**

Soft property publishing sometimes deeply affects the system memory usage, device utilization and system performance. For example, the user can add a property running "show running-config" to the device in status polling and publish it to a group of devices. This will probably cause the system memory usage to jump and the device's utilizations to jump.

To publish a soft property:

- 
- Step 1** Right-click on the required managed element in the tree pane or workspace of the NetworkVision window.
- or
- Open the Inventory window for the required managed element and right-click on the required object in the network element.
- Step 2** Select **Management | Soft Properties Management** from the shortcut menu. The Soft Properties Manager window is displayed.
- Step 3** Select the required **properties panel** and soft property in the **element properties** table.
- Step 4** Click **Hierarchy Manager** on the toolbar of the Soft Properties Manager window.
- or
- Select **Hierarchy Manager** from the Tools menu or shortcut menu.
- The hierarchy manager table is generated and displayed.



**Note** If user-friendly VNE names exist in the schema then the hierarchy manager table will display these user-friendly registry location names in the VNE Hierarchy Location column. A user-friendly VNE name is a hierarchy path that has been defined in the registry and is then displayed in the hierarchy manager table. For more information see [Publishing the Soft Property, page 2-20](#).

Each row that is displayed in the hierarchy manager table represents a different level of the hierarchy. The rows are displayed in descending order; the top row is the highest level of the hierarchy and the bottom row is the lowest level of the hierarchy.

The following information is displayed in the table:

- **Exist**—When a node in the hierarchy is selected this indicates that a local variant of the soft property exists for that node.
- **VNE Hierarchy Location**—The hierarchy path, as defined in the registry.
- **IMO Class Name**—Currently unavailable in this version.

The following tools are displayed in the Hierarchy Manager window:

**Table 2-2** *Hierarchy Manager window tools*



Copies the soft property from a selected node in the hierarchy in order to copy it to another node in the hierarchy. A copy icon is displayed to the left of the selected node.



Cuts the soft property from a selected node in the hierarchy in order to move it to another node in the hierarchy. A cut icon is displayed to the left of the selected node.

**Table 2-2** *Hierarchy Manager window tools (continued)*

Pastes the soft property that was copied or cut from a selected node in the hierarchy to another node in the hierarchy. A paste icon is displayed to the left of the selected node.



Deletes the soft property from the selected node in the hierarchy.

**Note** If the soft property has been deleted from all the nodes, the soft property will be removed from the list in the main dialog of the Soft Properties Manager.

The following button is displayed in the Hierarchy Manager window:

- **Close**—Closes the Hierarchy Manager window without publishing the soft property.

- Step 5** Select the required node in the hierarchy from which you want to publish the soft property.
- Step 6** Click **Copy** or **Cut** on the toolbar to copy or cut the soft property.
- Step 7** Select the required node in the hierarchy where you want to publish the soft property.
- Step 8** Click **Paste** on the toolbar to paste the soft property. The soft property is published to the selected node in the hierarchy.
- 

## Deleting a Soft Property

Soft properties created by the user are by default always created as a local instance. A soft property that is defined locally is selected in the Soft Properties Publish Controller dialog box. The user can delete soft properties whether or not they have been published.

To delete a soft property:


- 
- Step 1** Select the soft property that you want to delete in the element properties table of the Soft Properties Manager dialog box.
- Step 2** Click **Delete Element** on the toolbar of the Soft Properties Manager window.
- or
- Select **Delete Element** from the File menu or shortcut menu.
- A warning message is displayed.
- Step 3** Click **Yes**. The soft property is deleted and no longer displayed in the element properties table of the Soft Properties Manager window.
- 

## Importing and Exporting a Soft Property

The Soft Properties Manager enables the user to export (save) a soft property definition to a file. The soft property definition can then be imported (copied) later to another managed element.

In addition, the user can export and import a soft property definition to a file and publish it to multiple places in the Hierarchy Manager window.

To export a soft property:

- 
- Step 1** Select the soft property that you want to export in the **element properties** table of the Soft Properties Manager dialog box.
- Step 2** Click **Export Element** on the toolbar of the Soft Properties Manager dialog box.
- or
- Select **Export Element** from the Tools menu or shortcut menu.
- The Export dialog box is displayed.
-  **Note** If user-friendly VNE names exist in the schema then the hierarchy manager table will display these user-friendly registry location names in the VNE Hierarchy Location column. A user-friendly VNE name is a hierarchy path that has been defined in the registry and is then displayed in the hierarchy manager table. For more information see [Publishing the Soft Property, page 2-20](#).
- 
- Step 3** Select the version that you want to export in the table of the Export window. The version is selected in the table.
- Step 4** Click **OK**. The Export Property dialog box is displayed.
- Step 5** Browse to the directory where you want to save the soft property.
- Step 6** In the **File name** field, enter a name and extension (for example, **.txt**) for the soft property.
- Step 7** Click **Save**. The soft property is saved in the selected directory. The Export dialog box is displayed.
- Step 8** Click **Close**. The Soft Properties Manager window is displayed.
- 

To import a soft property:

- 
- Step 1** Click **Import Element** on the toolbar of the Soft Properties Manager window.
- or
- Select **Import Element** from the Tools menu.
- The Import Element dialog box is displayed.
- Step 2** Browse to the directory and soft property that you want to import.
- Step 3** Click **Open**. The Import elements window is displayed.
- Step 4** Select the version that you want to import in the table of the Import Elements window. The version is selected in the table.
- Step 5** Click **OK**. The Soft Properties Manager window is displayed.
- Step 6** Click **Close**. The soft property is imported to the selected managed element or network element and displayed in the Soft Properties Manager window.
-

# Closing the Soft Properties Manager

When the user has finished working with the Soft Properties Manager the user can close the Soft Properties Manager.

To close the Soft Properties Manager, click **Close**. The Soft Properties Manager is closed.



## CHAPTER 3

# Examples

---

This chapter provides several examples of creating a soft property from start to finish, including defining the TCA alarms and defining a soft property table:

- [Basic Soft Property Example, page 3-1](#)—Describes how to create a simple soft property from beginning to end, including publishing the soft property to another node in the hierarchy.
- [Soft Property Example Including TCA Alarm, page 3-8](#)—Describes how to define a TCA alarm for a soft property.
- [Soft Property Table Example, page 3-10](#)—Describes how to define a soft property table.

## Basic Soft Property Example


This section describes how to create a simple soft property from beginning to end.

To create a soft property (excl. TCA alarm):

- 
- Step 1** Right-click on a managed element in the tree pane or workspace of the NetworkVision window.  
or  
Open the Inventory window for the required managed element and right-click on the required object in the network element, for example, port or card.
- Step 2** Select **Management | Soft Properties Management** from the shortcut menu. The Soft Properties Manager window is displayed.
- Step 3** Select the required property from the dropdown list in the **properties panel**.
- Step 4** Click **New Element** on the toolbar of the Soft Properties Manager dialog box.  
or  
Select **New Element** from the File menu.  
The Add Soft Property dialog box is displayed.
- Step 5** Define the soft property information in the **General** tab as follows:
- **Name**—sp01
  - **Label**—My Soft Property
  - **Description**—Example of soft property


- **Type**—Property
  - **Polling Rate**—Status
  - **Enabled**—Selected
- Step 6** Select the **Parsing** tab. The **Parsing** tab is displayed.
- Step 7** Define the information in the **Parsing** tab as follows:
- Select **Use Telnet/SSH**
  - In the text box enter **show ip vrf example**
- Step 8** Click **Add**. The Add/Edit Parsing Rule dialog box is displayed.

**Figure 3-1** Add/Edit Parsing Rule Dialog Box




- Step 9** Define the information in the Add/Edit Parsing Rule dialog box as follows:
- **Operator**—Match
  - **Expression**—\d\d
  - **Source text box**—Enter the information as shown in the example.
- Step 10** Click **Test Expression**. The result 55 is displayed in the **Result** text box.
- Step 11** Click **OK**. The **Parsing** tab of the Add Soft Property dialog box is displayed.

**Figure 3-2 Add Soft Property Dialog Box**



**Step 12** Click **Add**. The Add/Edit Parsing Rule dialog box is displayed.

**Figure 3-3 Add/Edit Parsing Rule Dialog Box**




**Step 13** Define the information in the Add/Edit Parsing Rule dialog box as follows:

- **Operator**—Substring
- **From Index**—1
- **To Index**—1
- **Source text box**—55

**Step 14** Click **Test Expression**. The result 5 is displayed in the **Result** text box.


**Step 15** Click **OK**. The **Parsing** tab of the Add Soft Property dialog box is displayed.

**Figure 3-4** Parsing Tab



**Step 16** Click **Test**. The Test Parsing Rules dialog box is displayed enabling you to test all the defined parsing rules in the order given.

Figure 3-5 Test Parsing Rules Dialog Box




**Step 17** Click **Test**. The result of the test is displayed in the **Output Buffer** area.

**Step 18** Click **Close**. The Add Soft Property dialog box is displayed.

**Step 19** Click **Debug**. The Debug Soft Property dialog box is displayed.


Figure 3-6 Debug Soft Property Dialog Box



- After the Status is returned as valid, check the required input parameters returned the correct values, such as— Telnet Commands=[show ip vrf example]

- Step 20** Click **Close**. The Add Soft Property dialog box is displayed.  
(To add a TCA Alarm, go to Step 2 in [Soft Property Example Including TCA Alarm, page 3-8](#)).
- Step 21** Click **OK**. The Soft Properties Manager window is displayed.

**Figure 3-7** *Soft Properties Manager Window*




- Step 22** Click **Close**. The NetworkVision window or Inventory window is displayed depending on your original selection.
- Step 23** In order to view the newly created soft property, click in the right top corner to close the Inventory window and then open the Inventory window again.

or

Move up and down a branch in the tree pane of the Inventory window.

The Inventory window for the required managed element is displayed with the newly defined soft property.

Figure 3-8 Inventory Window



- Step 24** Right-click on the required managed element in the tree pane or workspace of the NetworkVision window.
- or
- Right-click on the required object of the network element in the Inventory window.
- Step 25** Select **Management | Soft Properties Management** from the shortcut menu. The Soft Properties Manager window is displayed.
- Step 26** Select the required **properties panel** and soft property in the **element properties** table.
- Step 27** Click **Hierarchy Manager** on the toolbar of the Soft Properties Manager dialog box.
- or
- Select **Hierarchy Manager** from the Tools menu or shortcut menu.
- The Hierarchy Manager window is displayed.
- Step 28** Select the required node in the hierarchy from which you want to publish the soft property.
- Step 29** Click **Copy** or **Cut** on the toolbar to copy or cut the soft property.
- Step 30** Select the required node in the hierarchy where you want to publish the soft property.
- Step 31** Click **Paste** on the toolbar to paste the soft property. The soft property is published to the selected node in the hierarchy.
- Step 32** Click **Close**. The Soft Properties Manager window is displayed.

For more information about defining a soft property with a TCA alarm see [Soft Property Example Including TCA Alarm](#), page 3-8.

# Soft Property Example Including TCA Alarm

This section describes how to define a TCA alarm for a soft property.

To create a soft property including TCA alarm:


- 
- Step 1** Perform steps 1-20, as described in the [Basic Soft Property Example, page 3-1](#).
  - Step 2** Select the **TCA Alarms** tab. The **TCA Alarms** tab is displayed.
  - Step 3** Click **Add**. The **General** tab of the Add TCA dialog box is displayed.
  - Step 4** Define the information in the **TCA Alarms** tab as follows:
    - **Name**—My value is not 5.
    - **Enabled**—Selected.
    - **Description**—Show this alarm if the value is not equal to 5.
    - **Alarm Severity**—CRITICAL.
  - Step 5** Select the **Trigger** tab in the Add TCA dialog box. The **Trigger** tab is displayed.
  - Step 6** Define the information in the **Trigger** tab as follows:
    - **Trigger**—Value Not Equal.
    - **To value**—5
  - Step 7** Click **OK**. The **TCA Alarms** tab is displayed with the defined TCA alarm.
  - Step 8** Click **OK**. The Soft Properties Manager window is displayed.
  - Step 9** Click **Close**. The NetworkVision window is displayed or Inventory window is displayed depending on your original selection.
  - Step 10** In order to view the newly created soft property, click in the right top corner to close the Inventory window and then open the Inventory window again.

or

Move up and down a branch in the tree pane of the Inventory window.
- The Inventory window for the required managed element is displayed with the newly defined soft property.


The example displays the Inventory window before the defined alarm has been triggered.

**Figure 3-9** Inventory Window Before Alarm Triggered




The example below displays the Inventory window after the alarm has been triggered.

**Figure 3-10** Inventory Window After Alarm Triggered



The example below displays the Inventory window after the alarm has been cleared.

**Figure 3-11** Inventory Window After Alarm Cleared



**Step 11** Perform steps 24-32, as described in [Basic Soft Property Example, page 3-1](#).

For more information about defining a soft property table see [Soft Property Table Example, page 3-10](#).

## Soft Property Table Example

This section describes how to define a soft property table.

To create a soft property table:

**Step 1** Perform steps 1-2, as described in the [Soft Property Example Including TCA Alarm, page 3-8](#).

**Step 2** Click **New Element** on the toolbar of the Soft Properties Manager window.

or

Select **New Element** from the File menu.


The Add Soft Property dialog box is displayed.

**Step 3** Define the soft property information in the **General** tab as follows:

- **Name**—sp02
- **Label**—My Soft Table
- **Description**—Example of a soft table

- **Type**—Table
  - **Polling Rate**—Status
  - **Enabled**—Selected
- Step 4** Select the **Parsing** tab. The **Parsing** tab is displayed.
- Step 5** Define the information in the **Parsing** tab by entering .1.3.6.1.2.1.4.20.1 in the text box.
- Step 6** Click **Add**. The Add Edit Column Controller dialog box is displayed.
- Step 7** Define the information in the Add Edit Column Controller dialog box as follows:
- **Column Title**—My First Column
  - **Column Data**—2
- Step 8** Click **OK**. The **Parsing** tab of the Add Soft Property dialog box is displayed with the defined table information for column 1 of the table.
- Step 9** Click **Add**. The Add Edit Column Controller dialog box is displayed.
- Step 10** Define the information in the Add Edit Column Controller dialog box as follows:
- **Column Title**—My Second Column
  - **Column Data**—3
- Step 11** Click **OK**. The **Parsing** tab of the Add Soft Property dialog box is displayed with the defined table information for column 1 and 2 of the table.

**Figure 3-12 Add Soft Property Dialog Box**



- Step 12** Click **Debug**. The Debug Soft Property dialog box is displayed.
- Step 13** Click **Close**. The Add Soft Property dialog box is displayed.
- Step 14** Click **OK**. The Soft Properties Manager window is displayed.

**Step 15** Click **Close**. The NetworkVision window or Inventory window is displayed depending on your original selection.


**Step 16** In order to view the newly created soft property, click in the top right corner to close the Inventory window and then open the Inventory window again.

or

Move up and down a branch in the tree pane of the Inventory window.

The Inventory window for the required managed element is displayed with the newly defined soft property table.

**Figure 3-13** Inventory Window



**Step 17** Perform steps 24-32, as described in the [Basic Soft Property Example, page 3-1](#).



# APPENDIX **A**

## Parsing Operators/Rules

---

This chapter describes the pre-defined text manipulation operators available for parsing raw device input and turning it into a soft property that are available in the Add/Edit Parsing Rule dialog box. For each operator its name, description, expected input, validation rules and the unique fields displayed in the dialog box are described. An example of each operator is also provided.

For more information about the Add/Edit Parsing Rule dialog box see [Defining the Parsing Parameters, page 2-11](#).

- [Header and Footer, page A-2](#)—Describes the Header And Footer operator and provides an example.
- [Remove Lines, page A-3](#)—Describes the Remove Lines operator and provides an example.
- [Select Lines, page A-4](#)—Describes the Select Lines operator and provides an example.
- [Replace, page A-5](#)—Describes the Replace operator and provides an example.
- [Match, page A-6](#)—Describes the Match operator and provides an example.
- [Set, page A-7](#)—Describes the Set operator and provides an example.
- [Substring, page A-8](#)—Describes the Substring operator and provides an example.
- [Parse Integer, page A-9](#)—Describes the Parse Integer operator and provides an example.

# Header and Footer


## Description

Removes a specified number of lines from the header and footer of the input text.

## Dialog Box

The Add/Edit Parsing Rule dialog box is displayed below when the **Header And Footer** operator is selected. In addition, the dialog box displays an example using the **Header And Footer** operator.

**Figure A-1 Header and Footer Operator**



## Parameters

Parameter	Description	Validation Rule
Header lines	The number of header lines to be removed.	Integers only. Mandatory.
Footer lines	The number of footer lines to be removed.	Integers only. Mandatory.

# Remove Lines


## Description

Removes a range of lines from the specified starting row to the specified end row of the input text.

## Dialog Box

The Add/Edit Parsing Rule dialog box is displayed below when the **Remove Lines** operator is selected. In addition, the dialog box displays an example using the **Remove Lines** operator.

**Figure A-2** Remove Lines Operator



## Parameters

Parameter	Description	Validation Rule
From line	Index of first row to begin removal, inclusive.	Integer only. Mandatory.
To line	Index of last row to be removed, inclusive.	Integer only. Equal to or greater than From line. Mandatory.

# Select Lines


## Description

Extracts a range of lines from the specified starting row to the specified end row of the input text.

## Dialog Box

The Add/Edit Parsing Rule dialog box is displayed below when the **Select Lines** operator is selected. In addition, the dialog box displays an example using the **Select Lines** operator.

**Figure A-3** Select Lines Operator



180314

## Parameters

Parameter	Description	Validation Rule
From line	Index of first row to begin selection, inclusive.	Integer only. Mandatory.
To line	Index of last row to be selected, inclusive.	Integer only. Equal to or greater than From line. Mandatory.

# Replace


## Description

Finds one or all occurrences of a substring, which matches a specified regular expression, and replaces it with a specified value.

## Dialog Box

The Add/Edit Parsing Rule dialog box is displayed below when the **Replace** operator is selected. In addition, the dialog box displays an example using the **Replace** operator.

**Figure A-4** Replace Operator



## Parameters

Parameter	Description	Validation Rule
Expression	Search for value or regular expression.	Text. Mandatory.
With	Replace string with value or regular expression.	Text. Mandatory.

From Index	Starting index.	Integer. Mandatory. <b>Note</b> The value entered in this field must be 1 or higher.
Replace All	Checkbox. Select this option to replace all occurrences of the matching substrings, otherwise only the first instance is replaced.	Default is unchecked.

## Match


### Description

Finds and extracts a substring, which matches a specified regular expression. If no match can be found the output buffer receives an empty string.

### Dialog Box

The Add/Edit Parsing Rule dialog box is displayed below when the **Match** operator is selected. In addition, the dialog box displays an example using the **Match** operator.

**Figure A-5 Match Operator**



## Parameters

Parameter	Description	Validation Rule
Expression	Search for value or regular expression.	Text. Mandatory.

## Set


### Description

Prints the results of the input and output buffers.

### Dialog Box

The Add/Edit Parsing Rule dialog box is displayed below when the **Set** operator is selected. In addition, the dialog box displays an example using the **Set** operator.

**Figure A-6 Set Operator**



180317

## Parameters

Parameter	Description	Validation Rule
Expression	Regular expression template to use for formatting. \$_\$ specifies the main output buffer.	Text. Mandatory.

## Substring


### Description

Extracts a substring of a specified length from a specified starting point.

### Dialog Box

The Add/Edit Parsing Rule dialog box is displayed below when the **Substring** operator is selected. In addition, the dialog box displays an example using the **Substring** operator.

**Figure A-7 Substring Operator**



## Parameters

Parameter	Description	Validation Rule
From Index	Begin index to select.	Integer. Mandatory <b>Note</b> The value entered in this field must be 1 or higher.
Length	How many characters to select.	Integer. Mandatory

## Parse Integer

### Description

Uses the substring rule, and when a result is received with the substring it is converted into an integer value.




#### Note

If the substring operator contains any characters the parsing integer operator will fail.

### Dialog Box

The Add/Edit Parsing Rule dialog box is displayed below when the **Parse Integer** operator is selected. In addition, the dialog box displays an example using the **Parse Integer** operator.

**Figure A-8** Parse Integer Operator



## Parameters

Parameter	Description	Validation Rule
From Index	Starting index to select.	Integer. Mandatory <b>Note</b> The value entered in this field must be 1 or higher.
To Index	Ending index to select.	Integer. Mandatory



## APPENDIX **B**

# Alarm Threshold Triggers

---

This chapter describes the pre-defined alarm threshold triggers available for defining TCA alarms that are displayed in the **Trigger** tab of the Add TCA dialog box. For each alarm threshold trigger its name, description, and the unique fields displayed in the dialog box are described.

The user can define multiple alarms for the same soft property. The alarm is displayed in the ticket pane of the NetworkVision window.

A counter value, as described in this chapter, is a numeric value that always increases.

For more information about the Add TCA dialog box see [Defining the TCA Alarms Parameters](#), page 2-16.

- [Value Equal, page B-1](#)—Describes the **Value Equal** threshold type.
- [Value Not Equal, page B-2](#)—Describes the **Value Not Equal** threshold type.
- [Upper Threshold, page B-2](#)—Describes the **Upper Threshold** type.
- [Lower Threshold, page B-3](#)—Describes the **Lower Threshold** type.
- [Upper Rate, page B-4](#)—Describes the **Upper Rate** threshold type.
- [Lower Rate, page B-5](#)—Describes the **Lower Rate** threshold type.

## Value Equal

The alarm condition is reached when the soft property value is equal to the value defined in the “Alarm Value” regardless if it is numeric or not.

When the **Value Equal** threshold type is selected from the **Trigger** dropdown list of the Add TCA dialog box the **Trigger** tab is displayed.

The following fields are displayed in the **Trigger** tab when the **Value Equal** threshold type is selected:


- **To value**—The target value.
- **Trigger alarm only if change persists more than**—Select this option to trigger the alarm if the alarm criteria persist for the defined period. The time period is defined in milliseconds in the **trigger alarm** field. For example, if CPU usage is over 85% (the alarm criteria) and this persists for more than one minute (the defined period), then the alarm is triggered. Considering that the soft property polls the device every x seconds, if the defined period is less than x, this will be meaningless.

# Value Not Equal

The alarm condition is reached when the soft property value is NOT equal to the value defined in the “Alarm Value” regardless if it is numeric or not.

When the **Value Not Equal** threshold type is selected from the **Trigger** dropdown list of the Add TCA dialog box the **Trigger** tab is displayed as follows:

**Figure B-1** Trigger Tab - Value Not Equal



The following fields are displayed in the **Trigger** tab when the **Value Not Equal** threshold type is selected:

- **To value**—The target value.
- **Trigger alarm only if change persists more than**—Select this option to trigger the alarm if the alarm criteria persist for the defined period. The time period is defined in milliseconds in the **trigger alarm** field.


# Upper Threshold

The upper threshold value, which when crossed triggers the alarm for the defined numeric properties.

This threshold trigger must receive a numeric value. In order to receive a numeric value the parse integer rule must be applied on the soft property as an ending rule. For more information about parsing integers see [Appendix A, “Parsing Operators/Rules”](#).

When the **Upper Threshold** type is selected from the **Trigger** dropdown list of the Add TCA dialog box the **Trigger** tab is displayed as follows:

**Figure B-2** Trigger Tab - Upper Threshold



The following fields are displayed in the **Trigger** tab when the **Upper Threshold** type is selected:

- **Trigger alarm when value is above**—The value which when crossed generates the alarm.
- **Clear alarm when value is below**—The value which when crossed (when going back) clears the alarm.
- **Trigger alarm only if change persists more than**—Select this option to trigger the alarm if the alarm criteria persist for the defined period. The time period is defined in milliseconds in the **trigger alarm** field.


## Lower Threshold

The lower threshold value, which when crossed triggers the alarm for the defined numeric properties.

This threshold trigger must receive a numeric value. In order to receive a numeric value the parse integer rule must be applied on the soft property as an ending rule. For more information about parsing integers see [Appendix A, “Parsing Operators/Rules”](#).

When the **Lower Threshold** type is selected from the **Trigger** dropdown list of the Add TCA dialog box the **Trigger** tab is displayed as follows:

**Figure B-3 Trigger Tab - Lower Threshold**



The following fields are displayed in the **Trigger** tab when the **Lower Threshold** type is selected:

- **Trigger alarm when value is below**—The value which when crossed generates the alarm.
- **Clear alarm when value is above**—The value which when crossed (when going back) clears the alarm.
- **Trigger alarm only if change persists more than**—Select this option to trigger the alarm if the alarm criteria persist for the defined period. The time period is defined in milliseconds in the **trigger alarm** field.

## Upper Rate

The upper rate trigger is used for checking the counter value changes over a period of one second. When the specified rate is crossed it triggers the alarm for the defined numeric property. When this is used together with the **Trigger alarm only if change persists more than** option, described in [Upper Threshold, page B-2](#), you can check that the rate is maintained above the specified value over time.




### Note

The calculation for the "rate every one second" is as follows, if the property is sampled every  $x$  seconds the calculation will be the *current value* less the *previous value* divided by  $x$  seconds.

This threshold trigger must receive a numeric value. In order to receive a numeric value the parse integer rule must be applied on the soft property as an ending rule. For more information about parsing integers see [Appendix A, "Parsing Operators/Rules"](#).

When the **Upper Rate** threshold type is selected from the **Trigger** dropdown list of the Add TCA dialog box the **Trigger** tab is displayed as follows:

**Figure B-4** Trigger Tab - Upper Rate



The following fields are displayed in the **Trigger** tab when the **Upper Rate** threshold type is selected:

- **Trigger alarm when value is above**—The value which when crossed generates the alarm.
- **Clear alarm when value is below**—The value which when crossed (when going back) clears the alarm.
- **Trigger alarm only if change persists more than**—Select this option to trigger the alarm if the alarm criteria persist for the defined period. The time period is defined in milliseconds in the **trigger alarm** field.

## Lower Rate

The lower rate trigger is used for checking the counter value changes over a period of one second. When the specified rate is crossed it triggers the alarm for the defined numeric property. When this is used together with the **Trigger alarm only if change persists more than** option, described in [Upper Threshold](#), page B-2, you can check that the rate is maintained below the specified value over time.




### Note

The calculation for the "rate every one second" is as follows, if the property is sampled every  $x$  seconds the calculation will be the *current value* less the *previous value* divided by  $x$  seconds.

This threshold trigger must receive a numeric value. In order to receive a numeric value the parse integer rule must be applied on the soft property as an ending rule. For more information about parsing integers see [Appendix A, "Parsing Operators/Rules"](#).

When the **Lower Rate** threshold type is selected from the **Trigger** dropdown list of the Add TCA dialog box the **Trigger** tab is displayed as follows:

**Figure B-5** Trigger tab - Lower Rate



The following fields are displayed in the **Trigger** tab when the **Lower Rate** threshold type is selected:

- **Trigger alarm when value is below**—The value which when crossed generates the alarm.
- **Clear alarm when value is above**—The value which when crossed (when going back) clears the alarm.
- **Trigger alarm only if change persists more than**—Select this option to trigger the alarm if the alarm criteria persist for the defined period. The time period is defined in milliseconds in the **trigger alarm** field.



## APPENDIX **C**

# Regular Expressions

---

This section is based on the documentation of the package GNU RegExp.

A regular expression consists of a character string where some characters are given special meaning with regard to pattern matching. Regular expressions have been in use from the early days of computing, and provide a powerful and efficient way to parse, interpret and search and replace text within an application.

## Supported Syntax

Within a regular expression, the following characters have special meaning:

### Positional Operators

`^` matches at the beginning of a line<sup>1</sup>

`$` matches at the end of a line<sup>2</sup>

`\A` matches the start of the entire string

`\Z` matches the end of the entire string

`\b` matches at a word break (Perl5 syntax only)

`\B` matches at a non-word break (opposite of `\b`) (Perl5 syntax only)

`\<` matches at the start of a word (egrep syntax only)

`\>` matches at the end of a word (egrep syntax only)

### One-Character Operators

`.` matches any single character

`\d` matches any decimal digit

`\D` matches any non-digit

`\n` matches a newline character

`\r` matches a return character

`\s` matches any whitespace character

`\S` matches any non-whitespace character

`\t` matches a horizontal tab character

`\w` matches any word (alphanumeric) character

`\W` matches any non-word (alphanumeric) character

`\x` matches the character *x*, if *x* is not one of the above listed escape sequences.

## Character Class Operator

`[abc]` matches any character in the set *a*, *b* or *c*

`[^abc]` matches any character not in the set *a*, *b* or *c*

`[a-z]` matches any character in the range *a* to *z*, inclusive

A leading or trailing dash will be interpreted literally.

Within a character class expression, the following sequences have special meaning if the syntax bit `RE_CHAR_CLASSES` is on:

`[:alnum:]` Any alphanumeric character

`[:alpha:]` Any alphabetical character

`[:blank:]` A space or horizontal tab

`[:cntrl:]` A control character

`[:digit:]` A decimal digit

`[:graph:]` A non-space, non-control character

`[:lower:]` A lowercase letter

`[:print:]` Same as `graph`, but also space and tab

`[:punct:]` A punctuation character

`[:space:]` Any whitespace character, including newline and return

`[:upper:]` An uppercase letter

`[:xdigit:]` A valid hexadecimal digit

### Subexpressions and Backreferences

`(abc)` matches whatever the expression *abc* would match, and saves it as a subexpression. Also used for grouping.

`(?:...)` pure grouping operator, does not save contents

`(?#...)` embedded comment, ignored by engine

`\n` where  $0 < n < 10$ , matches the same thing the *n*th subexpression matched.

## Branching (Alternation) Operator

`a|b` matches whatever the expression *a* would match, or whatever the expression *b* would match.

## Repeating Operators

These symbols operate on the previous atomic expression.

? matches the preceding expression or the null string

\* matches the null string or any number of repetitions of the preceding expression

+ matches one or more repetitions of the preceding expression

{ *m* } matches exactly *m* repetitions of the one-character expression

{ *m,n* } matches between *m* and *n* repetitions of the preceding expression, inclusive

{ *m*, } matches *m* or more repetitions of the preceding expression

## Stingy (Minimal) Matching

If a repeating operator (above) is immediately followed by a ?, the repeating operator will stop at the smallest number of repetitions that can complete the rest of the match.

## Lookahead

Lookahead refers to the ability to match part of an expression without consuming any of the input text. There are two variations to this:

(?= *foo*) matches at any position where *foo* would match, but does not consume any characters of the input.

(?! *foo*) matches at any position where *foo* would not match, but does not consume any characters of the input.

## Unsupported Syntax

Some flavors of regular expression utilities support additional escape sequences, and this is not meant to be an exhaustive list. In the future, `gnu.regex` may support some or all of the following:

(? *mods*) inlined compilation/execution modifiers (Perl5)

\G end of previous match (Perl5)

[. *symbol*.] collating symbol in class expression (POSIX)

[= *class* =] equivalence class in class expression (POSIX)

*s/foo/bar/* style expressions as in `sed` and `awk` (*note: these can be accomplished through other means in the API*).

