



# Installing ONS 15454 SDH MIC-A/P Cards

---

Product Name: 15454E-AP-MIC48V=

This document contains a description of MIC-A/P card features, installation procedures, removal instructions, and technical specifications. Use this document in conjunction with the *Cisco ONS 15454 SDH Installation and Operations Guide* and the *Cisco ONS 15454 SDH Troubleshooting and Reference Guide* when working with MIC-A/P cards.

This document contains the following sections:

- [“MIC-A/P Front Mount Electrical Connection Card Description” section on page 2](#)
- [“MIC-A/P Card Specifications” section on page 3](#)
- [“Installation Procedures” section on page 4](#)
- [“Removal Procedures” section on page 6](#)
- [“Related Documentation” section on page 6](#)
- [“Obtaining Documentation and Submitting a Service Request” section on page 7](#)

This document contains the following procedures:

[“Installation Procedures” procedure on page 4](#)

[“Card Turn Up” procedure on page 5](#)

[“Verify Successful Turn Up of the MIC-A/P Card” procedure on page 5](#)

[“Removal Procedures” procedure on page 6](#)



**Note**

---

For information about circuits and card capacities, see the *Cisco ONS 15454 SDH Installation and Operations Guide*.

---

# MIC-A/P Front Mount Electrical Connection Card Description

The MIC-A/P card ([Figure 1](#)) provides connection for one of the two possible redundant power supply inputs. It also provides connection for eight alarm outputs (coming from the TCC-I card) and for sixteen alarm inputs and four configurable alarm inputs/outputs (to be used in a future release, in conjunction with the future AIC-I card). Its position is in slot 23 in the center of the ONS 15454 SDH subrack EFCA area.


**Note**


Cisco does not recommend nor support operating the ONS 15454 SDH with only one of the MIC-A/P respectively MIC-C/T/P cards. Besides missing power supply redundancy, additional functions of the other card would be missing. To safeguard your system, always operate in a redundant configuration.


**Note**

For proper system operation, both the MIC-A/P card and the MIC-C/T/P card must be installed in the shelf.

[Figure 1](#) shows the MIC-A/P faceplate. [Figure 2](#) shows the block diagram.

**Figure 1** MIC-A/P faceplate




Install the MIC-A/P card in slot 23 in the EFCA (Electrical Facility Connector Assy) on the ONS 15454 SDH.

The following list summarizes MIC-A/P card features:

- Connection for one of the two possible redundant power supply inputs
- Connection for eight alarm outputs (coming from the TCC-I card)
- Connection for four configurable alarm inputs/outputs (coming from the AIC-I card, available in a future release)
- Connection for sixteen alarm inputs (coming from the AIC-I card, available in a future release)
- Storage of manufacturing and inventory data

**Figure 2 MIC-A/P block diagram**



## MIC-A/P Card-Level Indicators

The MIC-A/P card has no card-level LEDs.

## MIC-A/P Card Specifications

- MIC-A/P Power Supply Input
  - System Supply Voltage: Nominal -48 V DC  
Tolerance limits: - 40.5 to - 57.0 V DC
  - Connector: 3WK3 Combo-D Power Cable Connector
- MIC-A/P Alarm Outputs (for future release)
  - Voltage (open contact): max. 60 V DC
  - Current (closed contact): max. 250 mA
  - Connector: 62-pin DB connector (common for inputs/outputs)
- MIC-A/P Alarm Inputs (for future release)
  - Voltage (open contact): max. 60 V DC
  - Current (closed contact): max. 2 mA
  - Connector: 62-pin DB connector (common for inputs/outputs)
- Environmental
  - Operating Temperature: -5 to +45 degrees Celsius
  - Operating Humidity: 5 - 95%, non-condensing
  - Power Consumption: 0.13 W, (provided by +5V from TCC-I), 0.44 BTU/Hr.
- Dimensions
  - Height: 182 mm, (7.165 in.)
  - Width: 32 mm, (1.25 in.)
  - Depth: 92 mm, (3.62 in.)
  - Depth with backplane connector: 98 mm, (3.87 in.)

- Weight not including clam shell: 0.2 kg (0.5 lbs.)
- Compliance

ONS 15454 SDH cards, when installed in a system, comply with these standards:

- Safety: IEC 60950, EN 60950, UL 60950, CSA C22.2 No. 60950, TS 001, AS/NZS 3260

## Installation Procedures

Use this section if you are installing or removing the MIC-A/P card for the first time. After you become familiar with ONS 15454 SDH card installation and boot up, use this section as a reference.



### Caution

Always use the supplied electrostatic discharge (ESD) wristband when working with an ONS 15454 SDH. Plug the wristband cable into the ESD jack located on the lower right outside edge of the shelf assembly and ensure the shelf assembly is properly grounded.




### Caution

Hazardous voltage or energy may be present on the backplane when the system is operating. Use caution when servicing.

- 
- Step 1** Carefully insert the card into the rails of slot 23 ([Figure 3 on page 5](#)).
  - Step 2** Move the upper ejector down and the lower ejector up to enable the card being inserted into the backplane connectors.
  - Step 3** Gently push the card into the connector on the back plane.
  - Step 4** Tighten the front mounting screws with a Phillips or slot screwdriver.
- 

MIC-A/P cards have electrical plugs that plug into electrical connectors on the shelf assembly backplane. When the ejectors are fully closed and the mounting screws are tightened, the card plugs into the shelf assembly backplane. [Figure 3 on page 5](#) shows general card installation. Connecting the power cable is described in Chapter 1 “Installation” of the *Cisco ONS 15454 SDH Installation and Operations Guide*.

**Figure 3** Installing an FMEC card in an ONS 15454 SDH



## Card Turn Up

Follow the steps in this section to verify card turn up. If one or more of the Cisco Transport Controller (CTC) software screen conditions according to [“Verify Successful Turn Up of the MIC-A/P Card” section on page 5](#) are not met, re-install the card. Replace the unit if the faulty state persists.

### Verify Successful Turn Up of the MIC-A/P Card

- 
- Step 1** Verify that power is applied to the shelf assembly.
  - Step 2** Verify that the MIC-A/P card has been installed in slot 23.
  - Step 3** Verify that the card appears in slot 23 on the CTC software screen.
  - Step 4** Verify that the card is white on the CTC software screen.
  - Step 5** Verify that the card is shown in Inventory on the CTC software screen.
-

# Removal Procedures

Use this section if you are installing or removing the MIC-A/P card for the first time. After you become familiar with ONS 15454 SDH card installation and boot up, use this section as a reference.

**Caution**

Always use the supplied electrostatic discharge (ESD) wristband when working with an ONS 15454 SDH. Plug the wristband cable into the ESD jack located on the lower right outside edge of the shelf assembly and ensure the shelf assembly is properly grounded.

**Caution**

Hazardous voltage or energy may be present on the backplane when the system is operating. Use caution when servicing.

**Step 1**

If there is traffic on the system, make sure that the redundant power supply input on the MIC-C/T/P card is properly powered.

**Note**

Failure to do so will result in loss of traffic.

**Caution**

To avoid risk of burn, turn off the power source circuit breaker before disconnecting the power cable.

**Step 2**

Disconnect all the cable connectors from the MIC-A/P card to be removed. Do not forget to mark all the connectors or cables for correct reinstallation afterwards.

**Note**

To disconnect the coaxial cable from the FMEC, first pull the outer ring of the connector, then pull the connector. Pulling the cable without first having pulled the outer ring of the connector to release its locking can result in damage to the cable or the connector or both.

**Step 3**

Loosen the front mounting screws ([Figure 3 on page 5](#)).

**Step 4**

Move the upper ejector up and the lower ejector down to extract the card from the backplane connectors.

**Step 5**

Carefully remove the card from the shelf.

## Related Documentation

- DOC-7813038= *Cisco ONS 15454 SDH Installation and Operations Guide*
- DOC-7813037= *Cisco ONS 15454 SDH Troubleshooting and Reference Guide*

# Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.

This document is to be used in conjunction with the documents listed in the “[Related Documentation](#)” section.

CCVP, the Cisco logo, and Welcome to the Human Network are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn is a service mark of Cisco Systems, Inc.; and Access Registrar, Aironet, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, iQuick Study, LightStream, Linksys, MeetingPlace, MGX, Networkers, Networking Academy, Network Registrar, PIX, ProConnect, ScriptShare, SMARTnet, StackWise, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0711R)

Copyright © 2002, Cisco Systems, Inc.  
All rights reserved.

