



Removing and Installing Line Cards

This chapter describes how to remove the OC12 POS line card from its supported platform, how to install a new or replacement line card, and how to connect cables.

This chapter contains the following sections:

- [Installation Overview, page 3-1](#)
- [Handling Line Cards, page 3-2](#)
- [Online Insertion and Removal, page 3-2](#)
- [Warnings and Cautions, page 3-2](#)
- [Line Card Removal and Installation, page 3-3](#)
- [Connecting OC12 POS Line Card Interface Cables, page 3-5](#)

Installation Overview

Each line card circuit board is mounted to a metal carrier and is sensitive to electrostatic discharge (ESD) damage.



Note


When a slot is not in use, a blank line card must fill the empty slot to allow the router to conform to electromagnetic interference (EMI) emissions requirements and to allow proper airflow across the line cards. If you plan to install a new line card in a slot that is not in use, you must first remove the blank line card.

Handling Line Cards

**Caution**

Always handle the line card by the carrier edges and handle; never touch the line card components or connector pins. (See [Figure 3-1](#).)

Figure 3-1 Handling a Line Card



Online Insertion and Removal

The Cisco 7304 router supports online insertion and removal (OIR) of line cards; therefore, you do not have to power down the router when removing and replacing an OC12 POS line card on a Cisco 7304 router. The Cisco 7304 router also supports *CLI-controlled OIR* (see the [“CLI-Controlled OIR”](#) section on page 4-13), which allows for the completion of data traffic before the active interfaces are shut down.

**Note**

As you disengage the line card from the router, online insertion and removal (OIR) administratively shuts down all active interfaces in the line card.

**Note**

Before you begin installation, read [Chapter 2, “Preparing for Installation,”](#) for a list of parts and tools required for installation.

Warnings and Cautions

Observe the following warnings and cautions when installing or removing line cards.

**Note**

If a line card lever or other retaining mechanism does not move to the locked position, the line card is not completely seated in the backplane. Carefully pull the line card halfway out of the slot, reinsert it, and move the line card lever to the locked position.

**Caution**

To prevent jamming the carrier between the upper and the lower edges of the slot, and to ensure that the connector at the rear of the line card mates with the connection at the rear of the slot, make certain that the carrier is positioned correctly, as shown in the cutaway in the following illustration. If the line card does not slide freely into the backplane, loosen the locking thumbscrews on the neighboring line cards.

**Warning**

When performing the following procedures, wear a grounding wrist strap to avoid ESD damage to the card. Some platforms have an ESD connector for attaching the wrist strap. Do not directly touch the midplane or backplane with your hand or any metal tool, or you could shock yourself.


Line Card Removal and Installation

In this section, the illustration that follows gives step-by-step instructions on how to remove and install line cards in the following supported platform:


- [Cisco 7304—Removing and Installing a Line Card, page 3-4](#)

Cisco 7304—Removing and Installing a Line Card

1. To remove the line card, loosen the locking thumbscrews on both sides of the line card.




2. Pull out the line card levers and carefully slide the line card halfway out of the slot. If you are removing a blank line card, pull the blank line card completely out of the chassis slot.



3. With the line card halfway out of the slot, disconnect all cables from the line card. After disconnecting the cables, pull the line card out of the chassis slot.

4. To insert the line card, carefully align the edges of the carrier or printed circuit board between the upper and the lower edges of the chassis slot.



5. Carefully slide the new line card halfway into the line card slot and connect all required cables.
6. With the cables connected, carefully slide the line card into the slot until the line card makes contact with the backplane.

NOTE: The line card levers must be positioned at a 45-degree angle before the line card makes contact with the backplane.

7. Push the line card levers in until the line card is fully seated in the router backplane.

NOTE: When the chassis is fully populated, seating a new line card may be difficult. In order to properly seat the line card and avoid physical damage, loosen the thumbscrews on the neighboring line cards.

CAUTION: Use of excessive force to seat the line card may damage the router or line card.

8. Tighten the locking thumbscrews on both sides of the line card.

57891

Proceed to the [“Connecting OC12 POS Line Card Interface Cables”](#) section on page 3-5.

Connecting OC12 POS Line Card Interface Cables

To continue your OC12 POS line card installation, you must connect the interface cables.

**Note**

Optical fiber cables are not available from Cisco Systems; they are available from outside commercial cable vendors. (For more information on the cables you should use with this line card, see the [“OC12 POS Line Card Optical Fiber Specifications”](#) section on page 1-5 and the [“Cables and Connectors”](#) section on page 1-8.)

To connect cables to the OC12 POS line card, attach one duplex or two simplex optical fiber cables between the OC12 interface port on your OC12 POS line card and your network.

Ensure that you observe the proper relationship of receive (RX) cable to RX SC-type receptacle and transmit (TX) cable to TX SC-type receptacle on the OC12 POS line card.

**Warning**

Because invisible laser radiation may be emitted from the aperture of the port when no fiber cable is connected, avoid exposure to laser radiation and do not stare into open apertures.

**Warning**

Class 1 laser product.

