



## CHAPTER 8

# Configuring IP Routing

---

This chapter describes how to configure IP routing on the adaptive security appliance. This chapter includes the following sections:

- [How Routing Behaves Within the ASA Security Appliance, page 8-1](#)
- [Configuring Static and Default Routes, page 8-2](#)
- [Defining Route Maps, page 8-7](#)
- [Configuring OSPF, page 8-8](#)
- [Configuring RIP, page 8-20](#)
- [Configuring EIGRP, page 8-24](#)
- [The Routing Table, page 8-33](#)
- [Dynamic Routing and Failover, page 8-36](#)

## How Routing Behaves Within the ASA Security Appliance

The ASA adaptive security appliance uses both routing table and XLATE tables for routing decisions. To handle destination IP translated traffic, that is, untranslated traffic, ASA searches for existing XLATE, or static translation to select the egress interface. The selection process is as follows:

### Egress Interface Selection Process

1. If destination IP translating XLATE already exists, the egress interface for the packet is determined from the XLATE table, but not from the routing table.
2. If destination IP translating XLATE does not exist, but a matching static translation exists, then the egress interface is determined from the static route and an XLATE is created, and the routing table is not used.
3. If destination IP translating XLATE does not exist and no matching static translation exists, the packet is not destination IP translated. The adaptive security appliance processes this packet by looking up the route to select egress interface, then source IP translation is performed (if necessary).

For regular dynamic outbound NAT, initial outgoing packets are routed using the route table and then creating the XLATE. Incoming return packets are forwarded using existing XLATE only. For static NAT, destination translated incoming packets are always forwarded using existing XLATE or static translation rules.

## Next Hop Selection Process

After selecting egress interface using any method described above, an additional route lookup is performed to find out suitable next hop(s) that belong to previously selected egress interface. If there are no routes in routing table that explicitly belong to selected interface, the packet is dropped with level 6 error message 110001 "no route to host", even if there is another route for a given destination network that belongs to different egress interface. If the route that belongs to selected egress interface is found, the packet is forwarded to corresponding next hop.

Load sharing on the adaptive security appliance is possible only for multiple next-hops available using single egress interface. Load sharing cannot share multiple egress interfaces.

If dynamic routing is in use on adaptive security appliance and route table changes after XLATE creation, for example route flap, then destination translated traffic is still forwarded using old XLATE, not via route table, until XLATE times out. It may be either forwarded to wrong interface or dropped with message 110001 "no route to host" if old route was removed from the old interface and attached to another one by routing process.

The same problem may happen when there is no route flaps on the adaptive security appliance itself, but some routing process is flapping around it, sending source translated packets that belong to the same flow through the adaptive security appliance using different interfaces. Destination translated return packets may be forwarded back using the wrong egress interface.

This issue has a high probability in same security traffic configuration, where virtually any traffic may be either source-translated or destination-translated, depending on direction of initial packet in the flow. When this issue occurs after a route flap, it can be resolved manually by using the `clear xlate` command, or automatically resolved by an XLATE timeout. XLATE timeout may be decreased if necessary. To ensure that this rarely happens, make sure that there is no route flaps on adaptive security appliance and around it. That is, ensure that destination translated packets that belong to the same flow are always forwarded the same way through the adaptive security appliance.

## Configuring Static and Default Routes

This section describes how to configure static and default routes on the adaptive security appliance.

Multiple context mode does not support dynamic routing, so you must use static routes for any networks to which the adaptive security appliance is not directly connected; for example, when there is a router between a network and the adaptive security appliance.

You might want to use static routes in single context mode in the following cases:

- Your networks use a different router discovery protocol from EIGRP, OSPF, or RIP.
- Your network is small and you can easily manage static routes.
- You do not want the traffic or CPU overhead associated with routing protocols.

The simplest option is to configure a default route to send all traffic to an upstream router, relying on the router to route the traffic for you. However, in some cases the default gateway might not be able to reach the destination network, so you must also configure more specific static routes. For example, if the default gateway is outside, then the default route cannot direct traffic to any inside networks that are not directly connected to the adaptive security appliance.

In transparent firewall mode, for traffic that originates on the adaptive security appliance and is destined for a non-directly connected network, you need to configure either a default route or static routes so the adaptive security appliance knows out of which interface to send traffic. Traffic that originates on the

adaptive security appliance might include communications to a syslog server, Websense or N2H2 server, or AAA server. If you have servers that cannot all be reached through a single default route, then you must configure static routes.

The adaptive security appliance supports up to three equal cost routes on the same interface for load balancing.

This section includes the following topics:

- [Configuring a Static Route, page 8-3](#)
- [Configuring a Default Static Route, page 8-4](#)
- [Configuring Static Route Tracking, page 8-5](#)

For information about configuring IPv6 static and default routes, see the “[Configuring IPv6 Default and Static Routes](#)” section on page 11-5.

## Configuring a Static Route

To add a static route, enter the following command:

```
hostname(config)# route if_name dest_ip mask gateway_ip [distance]
```

The *dest\_ip* and *mask* is the IP address for the destination network and the *gateway\_ip* is the address of the next-hop router. The addresses you specify for the static route are the addresses that are in the packet before entering the adaptive security appliance and performing NAT.

The *distance* is the administrative distance for the route. The default is 1 if you do not specify a value. Administrative distance is a parameter used to compare routes among different routing protocols. The default administrative distance for static routes is 1, giving it precedence over routes discovered by dynamic routing protocols but not directly connect routes. For example, the default administrative distance for routes discovered by OSPF is 110, for RIP is 120, for EIGRP (internal) is 90, and for EIGRP (external) is 170; see [Table 8-1 on page 8-35](#) for more information. If a static route has the same administrative distance as a dynamic route, the static routes take precedence. Connected routes always take precedence over static or dynamically discovered routes.

Static routes remain in the routing table even if the specified gateway becomes unavailable. If the specified gateway becomes unavailable, you need to remove the static route from the routing table manually. However, static routes are removed from the routing table if the specified interface goes down. They are reinstated when the interface comes back up.



### Note

If you create a static route with an administrative distance greater than the administrative distance of the routing protocol running on the adaptive security appliance, then a route to the specified destination discovered by the routing protocol takes precedence over the static route. The static route is used only if the dynamically discovered route is removed from the routing table.

The following example creates a static route that sends all traffic destined for 10.1.1.0/24 to the router (10.1.2.45) connected to the inside interface:

```
hostname(config)# route inside 10.1.1.0 255.255.255.0 10.1.2.45 1
```

You can define up to three equal cost routes to the same destination per interface. ECMP is not supported across multiple interfaces. With ECMP, the traffic is not necessarily divided evenly between the routes; traffic is distributed among the specified gateways based on an algorithm that hashes the source and destination IP addresses.

The following example shows static routes that are equal cost routes that direct traffic to three different gateways on the outside interface. The adaptive security appliance distributes the traffic among the specified gateways.

```
hostname(config)# route outside 10.10.10.0 255.255.255.0 192.168.1.1
hostname(config)# route outside 10.10.10.0 255.255.255.0 192.168.1.2
hostname(config)# route outside 10.10.10.0 255.255.255.0 192.168.1.3
```

## Configuring a Default Static Route

A default route identifies the gateway IP address to which the adaptive security appliance sends all IP packets for which it does not have a learned or static route. A default static route is simply a static route with 0.0.0.0/0 as the destination IP address. Routes that identify a specific destination take precedence over the default route.

You can define up to three equal cost default route entries per device. Defining more than one equal cost default route entry causes the traffic sent to the default route to be distributed among the specified gateways. When defining more than one default route, you must specify the same interface for each entry.

If you attempt to define more than three equal cost default routes, or if you attempt to define a default route with a different interface than a previously defined default route, you receive the message “ERROR: Cannot add route entry, possible conflict with existing routes.”

You can define a separate default route for tunneled traffic along with the standard default route. When you create a default route with the **tunneled** option, all traffic from a tunnel terminating on the adaptive security appliance that cannot be routed using learned or static routes, is sent to this route. For traffic emerging from a tunnel, this route overrides over any other configured or learned default routes.

The following restrictions apply to default routes with the **tunneled** option:

- Do not enable unicast RPF (**ip verify reverse-path**) on the egress interface of tunneled route. Enabling uRPF on the egress interface of a tunneled route causes the session to fail.
- Do not enable TCP intercept on the egress interface of the tunneled route. Doing so causes the session to fail.
- Do not use the VoIP inspection engines (CTIQBE, H.323, GTP, MGCP, RTSP, SIP, SKINNY), the DNS inspect engine, or the DCE RPC inspection engine with tunneled routes. These inspection engines ignore the tunneled route.

You cannot define more than one default route with the **tunneled** option; ECMP for tunneled traffic is not supported.

To define the default route, enter the following command:

```
hostname(config)# route if_name 0.0.0.0 0.0.0.0 gateway_ip [distance | tunneled]
```



Tip

You can enter 0 0 instead of 0.0.0.0 0.0.0.0 for the destination network address and mask, for example:

```
hostname(config)# route outside 0 0 192.168.1 1
```

The following example shows a adaptive security appliance configured with three equal cost default routes and a default route for tunneled traffic. Unencrypted traffic received by the adaptive security appliance for which there is no static or learned route is distributed among the gateways with the IP addresses 192.168.2.1, 192.168.2.2, 192.168.2.3. Encrypted traffic receive by the adaptive security appliance for which there is no static or learned route is passed to the gateway with the IP address 192.168.2.4.

```
hostname(config)# route outside 0 0 192.168.2.1
hostname(config)# route outside 0 0 192.168.2.2
hostname(config)# route outside 0 0 192.168.2.3
hostname(config)# route outside 0 0 192.168.2.4 tunneled
```

## Configuring Static Route Tracking

One of the problems with static routes is that there is no inherent mechanism for determining if the route is up or down. They remain in the routing table even if the next hop gateway becomes unavailable. Static routes are only removed from the routing table if the associated interface on the adaptive security appliance goes down.

The static route tracking feature provides a method for tracking the availability of a static route and installing a backup route if the primary route should fail. This allows you to, for example, define a default route to an ISP gateway and a backup default route to a secondary ISP in case the primary ISP becomes unavailable.

The adaptive security appliance does this by associating a static route with a monitoring target that you define. It monitors the target using ICMP echo requests. If an echo reply is not received within a specified time period, the object is considered down and the associated route is removed from the routing table. A previously configured backup route is used in place of the removed route.

When selecting a monitoring target, you need to make sure it can respond to ICMP echo requests. The target can be any network object that you choose, but you should consider using:

- the ISP gateway (for dual ISP support) address
- the next hop gateway address (if you are concerned about the availability of the gateway)
- a persistent network object on the destination network (a desktop or notebook computer that may be shut down at night is not a good choice)

You can configure static route tracking for statically defined routes or default routes obtained through DHCP or PPPoE. You can only enable PPPoE clients on multiple interface with route tracking.

To configure static route tracking, perform the following steps:

---

**Step 1** Configure the tracked object monitoring parameters:

- a. Define the monitoring process:

```
hostname(config)# sla monitor sla_id
```

If you are configuring a new monitoring process, you are taken to SLA monitor configuration mode. If you are changing the monitoring parameters for an unscheduled monitoring process that already has a type defined, you are taken directly to the SLA protocol configuration mode.

- b. Specify the monitoring protocol. If you are changing the monitoring parameters for an unscheduled monitoring process that already has a type defined, you are taken directly to SLA protocol configuration mode and cannot change this setting.

```
hostname(config-sla-monitor)# type echo protocol ipIcmpEcho target_ip interface
if_name
```

The *target\_ip* is the IP address of the network object whose availability the tracking process monitors. While this object is available, the tracking process route is installed in the routing table. When this object becomes unavailable, the tracking process removed the route and the backup route is used in its place.

## c. Schedule the monitoring process:

```
hostname(config)# sla monitor schedule sla_id [life {forever | seconds}] [start-time
{hh:mm:ss] [month day | day month] | pending | now | after hh:mm:ss] [ageout
seconds] [recurring]
```

Typically, you will use **sla monitor schedule** *sla\_id* **life forever start-time now** for the monitoring schedule, and allow the monitoring configuration determine how often the testing occurs. However, you can schedule this monitoring process to begin in the future and to only occur at specified times.

**Step 2** Associate a tracked static route with the SLA monitoring process by entering the following command:

```
hostname(config)# track track_id rtr sla_id reachability
```

The *track\_id* is a tracking number you assign with this command. The *sla\_id* is the ID number of the SLA process you defined in [Step 1](#).

**Step 3** Define the static route to be installed in the routing table while the tracked object is reachable using one of the following options:

- To track a static route, enter the following command:

```
hostname(config)# route if_name dest_ip mask gateway_ip [admin_distance] track
track_id
```

You cannot use the **tunneled** option with the **route** command with static route tracking.

- To track a default route obtained through DHCP, enter the following commands:

```
hostname(config)# interface phy_if
hostname(config-if)# dhcp client route track track_id
hostname(config-if)# ip addresss dhcp setroute
hostname(config-if)# exit
```




---

**Note** You must use the **setroute** argument with the **ip address dhcp** command to obtain the default route using DHCP.

---

- To track a default route obtained through PPPoE, enter the following commands:

```
hostname(config)# interface phy_if
hostname(config-if)# pppoe client route track track_id
hostname(config-if)# ip addresss pppoe setroute
hostname(config-if)# exit
```




---

**Note** You must use the **setroute** argument with the **ip address pppoe** command to obtain the default route using PPPoE.

---

**Step 4** Define the backup route to use when the tracked object is unavailable using one of the following options. The administrative distance of the backup route must be greater than the administrative distance of the tracked route, that is, DHCP or PPPoE . If it is not, the backup route will be installed in the routing table instead of the tracked route.

- To use a static route, enter the following command:

```
hostname(config)# route if_name dest_ip mask gateway_ip [admin_distance]
```

The static route must have the same destination and mask as the tracked route. If you are tracking a default route obtained through DHCP or PPPoE, then the address and mask would be 0.0.0.0 0.0.0.0.

- To use a default route obtained through DHCP, enter the following commands:

```
hostname(config)# interface phy_if
hostname(config-if)# dhcp client route track track_id
hostname(config-if)# dhcp client route distance admin_distance
hostname(config-if)# ip addresss dhcp setroute
hostname(config-if)# exit
```

You must use the **setroute** argument with the **ip address dhcp** command to obtain the default route using DHCP.

- To use a default route obtained through PPPoE, enter the following commands:

```
hostname(config)# interface phy_if
hostname(config-if)# pppoe client route track track_id
hostname(config-if)# pppoe client route distance admin_distance
hostname(config-if)# ip addresss pppoe setroute
hostname(config-if)# exit
```

You must use the **setroute** argument with the **ip address pppoe** command to obtain the default route using PPPoE.

## Defining Route Maps

Route maps are used when redistributing routes into an OSPF, RIP, or EIGRP routing process. They are also used when generating a default route into an OSPF routing process. A route map defines which of the routes from the specified routing protocol are allowed to be redistributed into the target routing process.

To define a route map, perform the following steps:

- Step 1** To create a route map entry, enter the following command:

```
hostname(config)# route-map name {permit | deny} [sequence_number]
```

Route map entries are read in order. You can identify the order using the *sequence\_number* option, or the adaptive security appliance uses the order in which you add the entries.

- Step 2** Enter one or more **match** commands:

- To match any routes that have a destination network that matches a standard ACL, enter the following command:

```
hostname(config-route-map)# match ip address acl_id [acl_id] [...]
```

If you specify more than one ACL, then the route can match any of the ACLs.

- To match any routes that have a specified metric, enter the following command:

```
hostname(config-route-map)# match metric metric_value
```

The *metric\_value* can be from 0 to 4294967295.

- To match any routes that have a next hop router address that matches a standard ACL, enter the following command:

```
hostname(config-route-map)# match ip next-hop acl_id [acl_id] [...]
```

If you specify more than one ACL, then the route can match any of the ACLs.

- To match any routes with the specified next hop interface, enter the following command:

```
hostname(config-route-map)# match interface if_name
```

If you specify more than one interface, then the route can match either interface.

- To match any routes that have been advertised by routers that match a standard ACL, enter the following command:

```
hostname(config-route-map)# match ip route-source acl_id [acl_id] [...]
```

If you specify more than one ACL, then the route can match any of the ACLs.

- To match the route type, enter the following command:

```
hostname(config-route-map)# match route-type {internal | external [type-1 | type-2]}
```

### Step 3 Enter one or more **set** commands.

If a route matches the **match** commands, then the following **set** commands determine the action to perform on the route before redistributing it.

- To set the metric, enter the following command:

```
hostname(config-route-map)# set metric metric_value
```

The *metric\_value* can be a value between 0 and 294967295

- To set the metric type, enter the following command:

```
hostname(config-route-map)# set metric-type {type-1 | type-2}
```

The following example shows how to redistribute routes with a hop count equal to 1 into OSPF. The adaptive security appliance redistributes these routes as external LSAs with a metric of 5, metric type of Type 1.

```
hostname(config)# route-map 1-to-2 permit
hostname(config-route-map)# match metric 1
hostname(config-route-map)# set metric 5
hostname(config-route-map)# set metric-type type-1
```

## Configuring OSPF

This section describes how to configure OSPF. This section includes the following topics:

- [OSPF Overview, page 8-9](#)
- [Enabling OSPF, page 8-9](#)
- [Redistributing Routes Into OSPF, page 8-10](#)
- [Configuring OSPF Interface Parameters, page 8-11](#)
- [Configuring OSPF Area Parameters, page 8-14](#)
- [Configuring OSPF NSSA, page 8-15](#)
- [Defining Static OSPF Neighbors, page 8-17](#)
- [Configuring Route Summarization Between OSPF Areas, page 8-16](#)
- [Configuring Route Summarization When Redistributing Routes into OSPF, page 8-16](#)
- [Generating a Default Route, page 8-17](#)

- [Configuring Route Calculation Timers, page 8-18](#)
- [Logging Neighbors Going Up or Down, page 8-18](#)
- [Displaying OSPF Update Packet Pacing, page 8-19](#)
- [Monitoring OSPF, page 8-19](#)
- [Restarting the OSPF Process, page 8-20](#)

## OSPF Overview

OSPF uses a link-state algorithm to build and calculate the shortest path to all known destinations. Each router in an OSPF area contains an identical link-state database, which is a list of each of the router usable interfaces and reachable neighbors.

The advantages of OSPF over RIP include the following:

- OSPF link-state database updates are sent less frequently than RIP updates, and the link-state database is updated instantly rather than gradually as stale information is timed out.
- Routing decisions are based on cost, which is an indication of the overhead required to send packets across a certain interface. The adaptive security appliance calculates the cost of an interface based on link bandwidth rather than the number of hops to the destination. The cost can be configured to specify preferred paths.

The disadvantage of shortest path first algorithms is that they require a lot of CPU cycles and memory.

The adaptive security appliance can run two processes of OSPF protocol simultaneously, on different sets of interfaces. You might want to run two processes if you have interfaces that use the same IP addresses (NAT allows these interfaces to coexist, but OSPF does not allow overlapping addresses). Or you might want to run one process on the inside, and another on the outside, and redistribute a subset of routes between the two processes. Similarly, you might need to segregate private addresses from public addresses.

You can redistribute routes into an OSPF routing process from another OSPF, EIGRP, or RIP routing process, or from connected routes or static routes configured on OSPF-enabled interfaces.

The adaptive security appliance supports the following OSPF features:

- Support of intra-area, interarea, and external (Type I and Type II) routes.
- Support of a virtual link.
- OSPF LSA flooding.
- Authentication to OSPF packets (both password and MD5 authentication).
- Support for configuring the adaptive security appliance as a designated router or a designated backup router. The adaptive security appliance also can be set up as an ABR; however, the ability to configure the adaptive security appliance as an ASBR is limited to default information only (for example, injecting a default route).
- Support for stub areas and not-so-stubby-areas.
- Area boundary router type-3 LSA filtering.

## Enabling OSPF

To enable OSPF, you need to create an OSPF routing process, specify the range of IP addresses associated with the routing process, then assign area IDs associated with that range of IP addresses.

To enable OSPF, perform the following steps:

**Step 1** To create an OSPF routing process, enter the following command:

```
hostname(config)# router ospf process_id
```

This command enters the router configuration mode for this OSPF process.

The *process\_id* is an internally used identifier for this routing process. It can be any positive integer. This ID does not have to match the ID on any other device; it is for internal use only. You can use a maximum of two processes.

**Step 2** To define the IP addresses on which OSPF runs and to define the area ID for that interface, enter the following command:

```
hostname(config-router)# network ip_address mask area area_id
```

The following example shows how to enable OSPF:

```
hostname(config)# router ospf 2
hostname(config-router)# network 10.0.0.0 255.0.0.0 area 0
```

## Redistributing Routes Into OSPF

The adaptive security appliance can control the redistribution of routes between OSPF routing processes. The adaptive security appliance matches and changes routes according to settings in the **redistribute** command or by using a route map. See also the “[Generating a Default Route](#)” section on page 8-17 for another use for route maps.

To redistribute static, connected, EIGRP, RIP, or OSPF routes into an OSPF process, perform the following steps:

**Step 1** (Optional) Create a route-map to further define which routes from the specified routing protocol are redistributed in to the OSPF routing process. See the “[Defining Route Maps](#)” section on page 8-7.

**Step 2** If you have not already done so, enter the router configuration mode for the OSPF process you want to redistribute into by entering the following command:

```
hostname(config)# router ospf process_id
```

**Step 3** Choose one of the following options to redistribute the selected route type into the OSPF routing process.

- To redistribute connected routes into the OSPF routing process, enter the following command:

```
hostname(config-router): redistribute connected [[metric metric-value]
metric-type {type-1 | type-2}] [tag tag_value] [subnets] [route-map map_name]
```

- To redistribute static routes into the OSPF routing process, enter the following command:

```
hostname(config-router): redistribute static [metric metric-value]
metric-type {type-1 | type-2}] [tag tag_value] [subnets] [route-map map_name]
```

- To redistribute routes from an OSPF routing process into the OSPF routing process, enter the following command:

```
hostname(config-router): redistribute ospf pid [match {internal | external [1 | 2] |
nssa-external [1 | 2]}] [metric metric-value] [metric-type {type-1 | type-2}]
[tag tag_value] [subnets] [route-map map_name]
```

You can either use the **match** options in this command to match and set route properties, or you can use a route map. The **tag** and **subnets** options do not have equivalents in the **route-map** command. If you use both a route map and **match** options in the **redistribute** command, then they must match

- To redistribute routes from a RIP routing process into the OSPF routing process, enter the following command:

```
hostname(config-router): redistribute rip [metric metric-value]
[metric-type {type-1 | type-2}] [tag tag_value] [subnets] [route-map map_name]
```

- To redistribute routes from an EIGRP routing process into the OSPF routing process, enter the following command:

```
hostname(config-router): redistribute eigrp as-num [metric metric-value]
[metric-type {type-1 | type-2}] [tag tag_value] [subnets] [route-map map_name]
```

The following example shows route redistribution from OSPF process 1 into OSPF process 2 by matching routes with a metric equal to 1. The adaptive security appliance redistributes these routes as external LSAs with a metric of 5, metric type of Type 1.

```
hostname(config)# route-map 1-to-2 permit
hostname(config-route-map)# match metric 1
hostname(config-route-map)# set metric 5
hostname(config-route-map)# set metric-type type-1
hostname(config-route-map)# router ospf 2
hostname(config-router)# redistribute ospf 1 route-map 1-to-2
```

The following example shows the specified OSPF process routes being redistributed into OSPF process 109. The OSPF metric is remapped to 100.

```
hostname(config)# router ospf 109
hostname(config-router)# redistribute ospf 108 metric 100 subnets
```

The following example shows route redistribution where the link-state cost is specified as 5 and the metric type is set to 1 or 2, indicating that it has lower priority than internal metrics.

```
hostname(config)# router ospf 1
hostname(config-router)# redistribute ospf 2 metric 5 metric-type 1/2
```

## Configuring OSPF Interface Parameters

You can alter some interface-specific OSPF parameters as necessary. You are not required to alter any of these parameters, but the following interface parameters must be consistent across all routers in an attached network: **ospf hello-interval**, **ospf dead-interval**, and **ospf authentication-key**. Be sure that if you configure any of these parameters, the configurations for all routers on your network have compatible values.

To configure OSPF interface parameters, perform the following steps:

- Step 1** To enter the interface configuration mode, enter the following command:

```
hostname(config)# interface interface_name
```

- Step 2** To explicitly specify the hardware of sending a packet on an OSPF interface, enter the following command:

```
hostname(config-router)# interface HardwareID
```

where *HardwareID* is the hardware on your system, such as Gigabit Ethernet 0/0.

**Step 3** Enter any of the following commands:

- To specify the authentication type for an interface, enter the following command:

```
hostname(config-if)# ospf authentication [message-digest | null]
```

- To assign a password to be used by neighboring OSPF routers on a network segment that is using the OSPF simple password authentication, enter the following command:

```
hostname(config-if)# ospf authentication-key key
```

The *key* can be any continuous string of characters up to 8 bytes in length.

The password created by this command is used as a key that is inserted directly into the OSPF header when the adaptive security appliance software originates routing protocol packets. A separate password can be assigned to each network on a per-interface basis. All neighboring routers on the same network must have the same password to be able to exchange OSPF information.

- To explicitly specify the cost of sending a packet on an OSPF interface, enter the following command:

```
hostname(config-if)# ospf cost cost
```

The *cost* is an integer from 1 to 65535; the default cost is 10.

- To set the number of seconds that a device must wait before it declares a neighbor OSPF router down because it has not received a hello packet, enter the following command:

```
hostname(config-if)# ospf dead-interval seconds
```

The value must be the same for all nodes on the network.

- To specify the length of time between the hello packets that the adaptive security appliance sends on an OSPF interface, enter the following command:

```
hostname(config-if)# ospf hello-interval seconds
```

The value must be the same for all nodes on the network.

- To enable OSPF MD5 authentication, enter the following command:

```
hostname(config-if)# ospf message-digest-key key_id md5 key
```

Set the following values:

- *key\_id*—An identifier in the range from 1 to 255.
- *key*—Alphanumeric password of up to 16 bytes.

Usually, one key per interface is used to generate authentication information when sending packets and to authenticate incoming packets. The same key identifier on the neighbor router must have the same key value.

We recommend that you not keep more than one key per interface. Every time you add a new key, you should remove the old key to prevent the local system from continuing to communicate with a hostile system that knows the old key. Removing the old key also reduces overhead during rollover.

- To set the priority to help determine the OSPF designated router for a network, enter the following command:

```
hostname(config-if)# ospf priority number_value
```

The *number\_value* is between 0 to 255.

- To specify the number of seconds between LSA retransmissions for adjacencies belonging to an OSPF interface, enter the following command:

```
hostname(config-if)# ospf retransmit-interval seconds
```

The *seconds* must be greater than the expected round-trip delay between any two routers on the attached network. The range is from 1 to 65535 seconds. The default is 5 seconds.

- To set the estimated number of seconds required to send a link-state update packet on an OSPF interface, enter the following command:

```
hostname(config-if)# ospf transmit-delay seconds
```

The *seconds* is from 1 to 65535 seconds. The default is 1 second.

- To specify the interface as a point-to-point, non-broadcast network, enter the following command:

```
hostname(config-if)# ospf network point-to-point non-broadcast
```

When you designate an interface as point-to-point, non-broadcast, you must manually define the OSPF neighbor; dynamic neighbor discovery is not possible. See [Defining Static OSPF Neighbors, page 8-17](#), for more information. Additionally, you can only define one OSPF neighbor on that interface.

The following example shows how to configure the OSPF interfaces:

```
hostname(config)# router ospf 2
hostname(config-router)# network 2.0.0.0 255.0.0.0 area 0
hostname(config-router)# interface HardwareID
hostname(config-if)# ospf cost 20
hostname(config-if)# ospf retransmit-interval 15
hostname(config-if)# ospf transmit-delay 10
hostname(config-if)# ospf priority 20
hostname(config-if)# ospf hello-interval 10
hostname(config-if)# ospf dead-interval 40
hostname(config-if)# ospf authentication-key cisco
hostname(config-if)# ospf message-digest-key 1 md5 cisco
hostname(config-if)# ospf authentication message-digest
```

The following is sample output from the **show ospf** command:

```
hostname(config)# show ospf

Routing Process "ospf 2" with ID 20.1.89.2 and Domain ID 0.0.0.2
Supports only single TOS(TOS0) routes
Does not support opaque LSA
SPF schedule delay 5 secs, Hold time between two SPFs 10 secs
Minimum LSA interval 5 secs. Minimum LSA arrival 1 secs
Number of external LSA 5. Checksum Sum 0x 26da6
Number of opaque AS LSA 0. Checksum Sum 0x 0
Number of DCbitless external and opaque AS LSA 0
Number of DoNotAge external and opaque AS LSA 0
Number of areas in this router is 1. 1 normal 0 stub 0 nssa
External flood list length 0
  Area BACKBONE(0)
    Number of interfaces in this area is 1
```

```

Area has no authentication
SPF algorithm executed 2 times
Area ranges are
Number of LSA 5. Checksum Sum 0x 209a3
Number of opaque link LSA 0. Checksum Sum 0x      0
Number of DCbitless LSA 0
Number of indication LSA 0
Number of DoNotAge LSA 0
Flood list length 0

```

## Configuring OSPF Area Parameters

You can configure several area parameters. These area parameters (shown in the following task table) include setting authentication, defining stub areas, and assigning specific costs to the default summary route. Authentication provides password-based protection against unauthorized access to an area.

Stub areas are areas into which information on external routes is not sent. Instead, there is a default external route generated by the ABR, into the stub area for destinations outside the autonomous system. To take advantage of the OSPF stub area support, default routing must be used in the stub area. To further reduce the number of LSAs sent into a stub area, you can configure the **no-summary** keyword of the **area stub** command on the ABR to prevent it from sending summary link advertisement (LSA Type 3) into the stub area.

To specify area parameters for your network, perform the following steps:

---

**Step 1** If you have not already done so, enter the router configuration mode for the OSPF process you want to configure by entering the following command:

```
hostname(config)# router ospf process_id
```

**Step 2** Enter any of the following commands:

- To enable authentication for an OSPF area, enter the following command:

```
hostname(config-router)# area area-id authentication
```

- To enable MD5 authentication for an OSPF area, enter the following command:

```
hostname(config-router)# area area-id authentication message-digest
```

- To define an area to be a stub area, enter the following command:

```
hostname(config-router)# area area-id stub [no-summary]
```

- To assign a specific cost to the default summary route used for the stub area, enter the following command:

```
hostname(config-router)# area area-id default-cost cost
```

The *cost* is an integer from 1 to 65535. The default is 1.

---

The following example shows how to configure the OSPF area parameters:

```

hostname(config)# router ospf 2
hostname(config-router)# area 0 authentication
hostname(config-router)# area 0 authentication message-digest
hostname(config-router)# area 17 stub
hostname(config-router)# area 17 default-cost 20

```

## Configuring OSPF NSSA

The OSPF implementation of an NSSA is similar to an OSPF stub area. NSSA does not flood type 5 external LSAs from the core into the area, but it can import autonomous system external routes in a limited way within the area.

NSSA imports Type 7 autonomous system external routes within an NSSA area by redistribution. These Type 7 LSAs are translated into Type 5 LSAs by NSSA ABRs, which are flooded throughout the whole routing domain. Summarization and filtering are supported during the translation.

You can simplify administration if you are an ISP or a network administrator that must connect a central site using OSPF to a remote site that is using a different routing protocol using NSSA.

Before the implementation of NSSA, the connection between the corporate site border router and the remote router could not be run as an OSPF stub area because routes for the remote site could not be redistributed into the stub area, and two routing protocols needed to be maintained. A simple protocol such as RIP was usually run and handled the redistribution. With NSSA, you can extend OSPF to cover the remote connection by defining the area between the corporate router and the remote router as an NSSA.

To specify area parameters for your network as needed to configure OSPF NSSA, perform the following steps:

---

**Step 1** If you have not already done so, enter the router configuration mode for the OSPF process you want to configure by entering the following command:

```
hostname(config)# router ospf process_id
```

**Step 2** Enter any of the following commands:

- To define an NSSA area, enter the following command:

```
hostname(config-router)# area area-id nssa [no-redistribution]  
[default-information-originate] [no-summary]
```

- To summarize groups of addresses, enter the following command:

```
hostname(config-router)# summary address ip_address mask [not-advertise] [tag tag]
```

This command helps reduce the size of the routing table. Using this command for OSPF causes an OSPF ASBR to advertise one external route as an aggregate for all redistributed routes that are covered by the address.

OSPF does not support **summary-address 0.0.0.0 0.0.0.0**.

In the following example, the summary address 10.1.0.0 includes address 10.1.1.0, 10.1.2.0, 10.1.3.0, and so on. Only the address 10.1.0.0 is advertised in an external link-state advertisement:

```
hostname(config-router)# summary-address 10.1.0.0 255.255.0.0
```

Before you use this feature, consider these guidelines:

- You can set a Type 7 default route that can be used to reach external destinations. When configured, the router generates a Type 7 default into the NSSA or the NSSA area boundary router.
  - Every router within the same area must agree that the area is NSSA; otherwise, the routers will not be able to communicate.
-

## Configuring Route Summarization Between OSPF Areas

Route summarization is the consolidation of advertised addresses. This feature causes a single summary route to be advertised to other areas by an area boundary router. In OSPF, an area boundary router advertises networks in one area into another area. If the network numbers in an area are assigned in a way such that they are contiguous, you can configure the area boundary router to advertise a summary route that covers all the individual networks within the area that fall into the specified range.

To define an address range for route summarization, perform the following steps:

- Step 1** If you have not already done so, enter the router configuration mode for the OSPF process you want to configure by entering the following command:

```
hostname(config)# router ospf process_id
```

- Step 2** To set the address range, enter the following command:

```
hostname(config-router)# area area-id range ip-address mask [advertise | not-advertise]
```

The following example shows how to configure route summarization between OSPF areas:

```
hostname(config)# router ospf 1
hostname(config-router)# area 17 range 12.1.0.0 255.255.0.0
```

## Configuring Route Summarization When Redistributing Routes into OSPF

When routes from other protocols are redistributed into OSPF, each route is advertised individually in an external LSA. However, you can configure the adaptive security appliance to advertise a single route for all the redistributed routes that are covered by a specified network address and mask. This configuration decreases the size of the OSPF link-state database.

To configure the software advertisement on one summary route for all redistributed routes covered by a network address and mask, perform the following steps:

- Step 1** If you have not already done so, enter the router configuration mode for the OSPF process you want to configure by entering the following command:

```
hostname(config)# router ospf process_id
```

- Step 2** To set the summary address, enter the following command:

```
hostname(config-router)# summary-address ip_address mask [not-advertise] [tag tag]
```



**Note** OSPF does not support **summary-address 0.0.0.0 0.0.0.0**.

The following example shows how to configure route summarization. The summary address 10.1.0.0 includes address 10.1.1.0, 10.1.2.0, 10.1.3.0, and so on. Only the address 10.1.0.0 is advertised in an external link-state advertisement:

```
hostname(config)# router ospf 1
```

```
hostname(config-router)# summary-address 10.1.0.0 255.255.0.0
```

## Defining Static OSPF Neighbors

You need to define static OSPF neighbors to advertise OSPF routes over a point-to-point, non-broadcast network. This lets you broadcast OSPF advertisements across an existing VPN connection without having to encapsulate the advertisements in a GRE tunnel. Additionally, OSPF packets are unicast.

To define a static OSPF neighbor, perform the following tasks:

---

**Step 1** Create a static route to the OSPF neighbor. See the “[Configuring Static and Default Routes](#)” section on page 8-2 for more information about creating static routes.

**Step 2** Define the OSPF neighbor by performing the following tasks:

- a. Enter router configuration mode for the OSPF process. Enter the following command:

```
hostname(config)# router ospf pid
```

- b. Define the OSPF neighbor by entering the following command:

```
hostname(config-router)# neighbor addr [interface if_name]
```

The *addr* argument is the IP address of the OSPF neighbor. The *if\_name* is the interface used to communicate with the neighbor. If the OSPF neighbor is not on the same network as any of the directly-connected interfaces, you must specify the **interface**.

---

## Generating a Default Route

You can force an autonomous system boundary router to generate a default route into an OSPF routing domain. Whenever you specifically configure redistribution of routes into an OSPF routing domain, the router automatically becomes an autonomous system boundary router. However, an autonomous system boundary router does not by default generate a default route into the OSPF routing domain.

To generate a default route, perform the following steps:

---

**Step 1** If you have not already done so, enter the router configuration mode for the OSPF process you want to configure by entering the following command:

```
hostname(config)# router ospf process_id
```

**Step 2** To force the autonomous system boundary router to generate a default route, enter the following command:

```
hostname(config-router)# default-information originate [always] [metric metric-value] [metric-type {1 | 2}] [route-map map-name]
```

---

The following example shows how to generate a default route:

```
hostname(config)# router ospf 2  
hostname(config-router)# default-information originate always
```

## Configuring Route Calculation Timers

You can configure the delay time between when OSPF receives a topology change and when it starts an SPF calculation. You also can configure the hold time between two consecutive SPF calculations.

To configure route calculation timers, perform the following steps:

- Step 1** If you have not already done so, enter the router configuration mode for the OSPF process you want to configure by entering the following command:

```
hostname(config)# router ospf process_id
```

- Step 2** To configure the route calculation time, enter the following command:

```
hostname(config-router)# timers spf spf-delay spf-holdtime
```

The *spf-delay* is the delay time (in seconds) between when OSPF receives a topology change and when it starts an SPF calculation. It can be an integer from 0 to 65535. The default time is 5 seconds. A value of 0 means that there is no delay; that is, the SPF calculation is started immediately.

The *spf-holdtime* is the minimum time (in seconds) between two consecutive SPF calculations. It can be an integer from 0 to 65535. The default time is 10 seconds. A value of 0 means that there is no delay; that is, two SPF calculations can be done, one immediately after the other.

The following example shows how to configure route calculation timers:

```
hostname(config)# router ospf 1
hostname(config-router)# timers spf 10 120
```

## Logging Neighbors Going Up or Down

By default, the system sends a system message when an OSPF neighbor goes up or down.

Configure this command if you want to know about OSPF neighbors going up or down without turning on the **debug ospf adjacency** command. The **log-adj-changes** router configuration command provides a higher level view of the peer relationship with less output. Configure **log-adj-changes detail** if you want to see messages for each state change.

To log neighbors going up or down, perform the following steps:

- Step 1** If you have not already done so, enter the router configuration mode for the OSPF process you want to configure by entering the following command:

```
hostname(config)# router ospf process_id
```

- Step 2** To configure logging for neighbors going up or down, enter the following command:

```
hostname(config-router)# log-adj-changes [detail]
```



**Note** Logging must be enabled for the the neighbor up/down messages to be sent.

The following example shows how to log neighbors up/down messages:

```
hostname(config)# router ospf 1  
hostname(config-router)# log-adj-changes detail
```

## Displaying OSPF Update Packet Pacing

OSPF update packets are automatically paced so they are not sent less than 33 milliseconds apart. Without pacing, some update packets could get lost in situations where the link is slow, a neighbor could not receive the updates quickly enough, or the router could run out of buffer space. For example, without pacing packets might be dropped if either of the following topologies exist:

- A fast router is connected to a slower router over a point-to-point link.
- During flooding, several neighbors send updates to a single router at the same time.

Pacing is also used between resends to increase efficiency and minimize lost retransmissions. You also can display the LSAs waiting to be sent out an interface. The benefit of the pacing is that OSPF update and retransmission packets are sent more efficiently.

There are no configuration tasks for this feature; it occurs automatically.

To observe OSPF packet pacing by displaying a list of LSAs waiting to be flooded over a specified interface, enter the following command:

```
hostname# show ospf flood-list if_name
```

## Monitoring OSPF

You can display specific statistics such as the contents of IP routing tables, caches, and databases. You can use the information provided to determine resource utilization and solve network problems. You can also display information about node reachability and discover the routing path that your device packets are taking through the network.

To display various OSPF routing statistics, perform one of the following tasks, as needed:

- To display general information about OSPF routing processes, enter the following command:  

```
hostname# show ospf [process-id [area-id]]
```
- To display the internal OSPF routing table entries to the ABR and ASBR, enter the following command:  

```
hostname# show ospf border-routers
```
- To display lists of information related to the OSPF database for a specific router, enter the following command:  

```
hostname# show ospf [process-id [area-id]] database
```
- To display a list of LSAs waiting to be flooded over an interface (to observe OSPF packet pacing), enter the following command:  

```
hostname# show ospf flood-list if-name
```
- To display OSPF-related interface information, enter the following command:  

```
hostname# show ospf interface [if_name]
```
- To display OSPF neighbor information on a per-interface basis, enter the following command:

```
hostname# show ospf neighbor [interface-name] [neighbor-id] [detail]
```

- To display a list of all LSAs requested by a router, enter the following command:

```
hostname# show ospf request-list neighbor if_name
```

- To display a list of all LSAs waiting to be resent, enter the following command:

```
hostname# show ospf retransmission-list neighbor if_name
```

- To display a list of all summary address redistribution information configured under an OSPF process, enter the following command:

```
hostname# show ospf [process-id] summary-address
```

- To display OSPF-related virtual links information, enter the following command:

```
hostname# show ospf [process-id] virtual-links
```

## Restarting the OSPF Process

To restart an OSPF process, clear counters, enter the following command:

```
hostname(config)# clear ospf pid {process | counters [neighbor [neighbor-interface]
[neighbor-id]]}
```

## Configuring RIP

Devices that support RIP send routing-update messages at regular intervals and when the network topology changes. These RIP packets contain information about the networks that the devices can reach, as well as the number of routers or gateways that a packet must travel through to reach the destination address. RIP generates more traffic than OSPF, but is easier to configure.

RIP has advantages over static routes because the initial configuration is simple, and you do not need to update the configuration when the topology changes. The disadvantage to RIP is that there is more network and processing overhead than static routing.

The adaptive security appliance supports RIP Version 1 and RIP Version 2.

This section describes how to configure RIP. This section includes the following topics:

- [Enabling and Configuring RIP, page 8-21](#)
- [Generating a Default RIP Route, page 8-22](#)
- [Redistributing Routes into the RIP Routing Process, page 8-22](#)
- [Configuring RIP Send/Receive Version on an Interface, page 8-23](#)
- [Enabling RIP Authentication, page 8-24](#)
- [Monitoring RIP, page 8-24](#)

## Enabling and Configuring RIP

You can only enable one RIP routing process on the adaptive security appliance. After you enable the RIP routing process, you must define the interfaces that will participate in that routing process using the **network** command. By default, the adaptive security appliance sends RIP Version 1 updates and accepts RIP Version 1 and Version 2 updates.

To enable and configure the RIP routing process, perform the following steps:

---

**Step 1** Start the RIP routing process by entering the following command in global configuration mode:

```
hostname(config): router rip
```

You enter router configuration mode for the RIP routing process.

**Step 2** Specify the interfaces that will participate in the RIP routing process. Enter the following command for each interface that will participate in the RIP routing process:

```
hostname(config-router): network network_address
```

If an interface belongs to a network defined by this command, the interface will participate in the RIP routing process. If an interface does not belong to a network defined by this command, it will not send or receive RIP updates.

**Step 3** (Optional) Specify the version of RIP used by the adaptive security appliance by entering the following command:

```
hostname(config-router): version [1 | 2]
```

You can override this setting on a per-interface basis.

**Step 4** (Optional) To generate a default route into RIP, enter the following command:

```
hostname(config-router): default-information originate
```

**Step 5** (Optional) To specify an interface to operate in passive mode, enter the following command:

```
hostname(config-router): passive-interface [default | if_name]
```

Using the **default** keyword causes all interfaces to operate in passive mode. Specifying an interface name sets only that interface to passive RIP mode. In passive mode, RIP routing updates are accepted by but not sent out of the specified interface. You can enter this command for each interface you want to set to passive mode.

**Step 6** (Optional) Disable automatic route summarization by entering the following command:

```
hostname(config-router): no auto-summarize
```

RIP Version 1 always uses automatic route summarization; you cannot disable it for RIP Version 1. RIP Version 2 uses route summarization by default; you can disable it using this command.

**Step 7** (Optional) To filter the networks received in updates, perform the following steps:

- a. Create a standard access list permitting the networks you want the RIP process to allow in the routing table and denying the networks you want the RIP process to discard.
- b. Enter the following command to apply the filter. You can specify an interface to apply the filter to only those updates received by that interface.

```
hostname(config-router): distribute-list acl in [interface if_name]
```

You can enter this command for each interface you want to apply a filter to. If you do not specify an interface name, the filter is applied to all RIP updates.

- Step 8** (Optional) To filter the networks sent in updates, perform the following steps:
- Create a standard access list permitting the networks you want the RIP process to advertise and denying the networks you do not want the RIP process to advertise.
  - Enter the following command to apply the filter. You can specify an interface to apply the filter to only those updates sent by that interface.

```
hostname(config-router): distribute-list acl out [interface if_name]
```

You can enter this command for each interface you want to apply a filter to. If you do not specify an interface name, the filter is applied to all RIP updates.

## Generating a Default RIP Route

You can force an autonomous system boundary router to generate a default route into an RIP routing domain. Whenever you specifically configure redistribution of routes into an RIP routing domain, the router automatically becomes an autonomous system boundary router. However, an autonomous system boundary router does not by default generate a default route into the RIP routing domain.

To generate a default route, perform the following steps:

- Step 1** If you have not already done so, enter the router configuration mode for the RIP process you want to configure by entering the following command:

```
hostname(config)# router RIP
```

- Step 2** To force the autonomous system boundary router to generate a default route, enter the following command:

```
hostname(config-router)# default-information originate
```

The following example shows how to generate a default route:

```
hostname(config)# router RIP 2  
hostname(config-router)# default-information originate
```

## Redistributing Routes into the RIP Routing Process

You can redistribute routes from the OSPF, EIGRP, static, and connected routing processes into the RIP routing process.

To redistribute a routes into the RIP routing process, perform the following steps:

- Step 1** (Optional) Create a route-map to further define which routes from the specified routing protocol are redistributed in to the RIP routing process. See the [“Defining Route Maps” section on page 8-7](#) for more information about creating a route map.
- Step 2** Choose one of the following options to redistribute the selected route type into the RIP routing process.
- To redistribute connected routes into the RIP routing process, enter the following command:

```
hostname(config-router): redistribute connected [metric {metric_value | transparent}]
[route-map map_name]
```

- To redistribute static routes into the RIP routing process, enter the following command:

```
hostname(config-router): redistribute static [metric {metric_value | transparent}]
[route-map map_name]
```

- To redistribute routes from an OSPF routing process into the RIP routing process, enter the following command:

```
hostname(config-router): redistribute ospf pid [match {internal | external [1 | 2] |
nssa-external [1 | 2]}] [metric {metric_value | transparent}] [route-map map_name]
```

- To redistribute routes from an EIGRP routing process into the RIP routing process, enter the following command:

```
hostname(config-router): redistribute eigrp as-num [metric {metric_value |
transparent}] [route-map map_name]
```

## Configuring RIP Send/Receive Version on an Interface

You can override the globally-set version of RIP the adaptive security appliance uses to send and receive RIP updates on a per-interface basis.

To configure the RIP send and receive version, perform the following steps:

- 
- Step 1** (Optional) To specify the version of RIP advertisements sent from an interface, perform the following steps:
- a. Enter interface configuration mode for the interface you are configuring by entering the following command:

```
hostname(config)# interface phy_if
```
  - b. Specify the version of RIP to use when sending RIP updates out of the interface by entering the following command:

```
hostname(config-if)# rip send version {[1] [2]}
```
- Step 2** (Optional) To specify the version of RIP advertisements permitted to be received by an interface, perform the following steps:
- a. Enter interface configuration mode for the interface you are configuring by entering the following command:

```
hostname(config)# interface phy_if
```
  - b. Specify the version of RIP to allow when receiving RIP updates on the interface by entering the following command:

```
hostname(config-if)# rip receive version {[1] [2]}
```

RIP updates received on the interface that do not match the allowed version are dropped.

---

## Enabling RIP Authentication

The adaptive security appliance supports RIP message authentication for RIP Version 2 messages.

To enable RIP message authentication, perform the following steps:

- 
- Step 1** Enter interface configuration mode for the interface you are configuring by entering the following command:

```
hostname(config)# interface phy_if
```

- Step 2** (Optional) Set the authentication mode by entering the following command. By default, text authentication is used. MD5 authentication is recommended.

```
hostname(config-if)# rip authentication mode {text | md5}
```

- Step 3** Enable authentication and configure the authentication key by entering the following command:

```
hostname(config-if)# rip authentication key key key_id key-id
```

---

## Monitoring RIP

To display various RIP routing statistics, perform one of the following tasks, as needed:

- To display the contents of the RIP routing database, enter the following command:

```
hostname# show rip database
```

- To display the RIP commands in the running configuration, enter the following command:

```
hostname# show running-config router rip
```

Use the following **debug** commands only to troubleshoot specific problems or during troubleshooting sessions with Cisco TAC. Debugging output is assigned high priority in the CPU process and can render the system unusable. It is best to use **debug** commands during periods of lower network traffic and fewer users. Debugging during these periods decreases the likelihood that increased **debug** command processing overhead will affect system performance.

- To display RIP processing events, enter the following command:

```
hostname# debug rip events
```

- To display RIP database events, enter the following command:

```
hostname# debug rip database
```

- To display information on RIP routing transactions, enter the following command:

```
hostname# debug rip
```

## Configuring EIGRP

This section describes the configuration and monitoring of EIGRP routing and includes the following topics:

- [EIGRP Routing Overview, page 8-25](#)

- [Enabling and Configuring EIGRP Routing, page 8-26](#)
- [Enabling and Configuring EIGRP Stub Routing, page 8-27](#)
- [Enabling EIGRP Authentication, page 8-28](#)
- [Generating a Default EIGRP Route, page 8-28](#)
- [Defining an EIGRP Neighbor, page 8-29](#)
- [Redistributing Routes Into EIGRP, page 8-29](#)
- [Configuring the EIGRP Hello Interval and Hold Time, page 8-30](#)
- [Disabling Automatic Route Summarization, page 8-31](#)
- [Configuring Summary Aggregate Addresses, page 8-31](#)
- [Disabling EIGRP Split Horizon, page 8-32](#)
- [Changing the Interface Delay Value, page 8-32](#)
- [Monitoring and Maintaining EIGRP, page 8-33](#)
- [Disabling Neighbor Change and Warning Message Logging, page 8-33](#)

## EIGRP Routing Overview

EIGRP is an enhanced version of IGRP developed by Cisco. Unlike IGRP and RIP, EIGRP does not send out periodic route updates. EIGRP updates are sent out only when the network topology changes.

Neighbor discovery is the process that the adaptive security appliance uses to dynamically learn of other routers on directly attached networks. EIGRP routers send out multicast hello packets to announce their presence on the network. When the adaptive security appliance receives a hello packet from a new neighbor, it sends its topology table to the neighbor with an initialization bit set. When the neighbor receives the topology update with the initialization bit set, the neighbor sends its topology table back to the adaptive security appliance.

The hello packets are sent out as multicast messages. No response is expected to a hello message. The exception to this is for statically defined neighbors. If you use the **neighbor** command to configure a neighbor, the hello messages sent to that neighbor are sent as unicast messages. Routing updates and acknowledgements are sent out as unicast messages.

Once this neighbor relationship is established, routing updates are not exchanged unless there is a change in the network topology. The neighbor relationship is maintained through the hello packets. Each hello packet received from a neighbor contains a hold time. This is the time in which the adaptive security appliance can expect to receive a hello packet from that neighbor. If the adaptive security appliance does not receive a hello packet from that neighbor within the hold time advertised by that neighbor, the adaptive security appliance considers that neighbor to be unavailable.

The EIGRP uses an algorithm called DUAL for route computations. DUAL saves all routes to a destination in the topology table, not just the least-cost route. The least-cost route is inserted into the routing table. The other routes remain in the topology table. If the main route fails, another route is chosen from the feasible successors. A successor is a neighboring router used for packet forwarding that has a least-cost path to a destination. The feasibility calculation guarantees that the path is not part of a routing loop.

If a feasible successor is not found in the topology table, a route recomputation must occur. During route recomputation, DUAL queries the EIGRP neighbors for a route, who in turn query their neighbors. Routers that do not have a feasible successor for the route return an unreachable message.

During route recomputation, DUAL marks the route as active. By default, the adaptive security appliance waits for three minutes to receive a response from its neighbors. If the adaptive security appliance does not receive a response from a neighbor, the route is marked as stuck-in-active. All routes in the topology table that point to the unresponsive neighbor as a feasibility successor are removed.

## Enabling and Configuring EIGRP Routing

You can only enable one EIGRP routing process on the adaptive security appliance.

To enable and configure EIGRP routing, perform the following tasks:

- Step 1** Create the EIGRP routing process and enter router configuration mode for that process by entering the following command:

```
hostname(config)# router eigrp as-num
```

The *as-num* argument is the autonomous system number of the EIGRP routing process.

- Step 2** To configure the interfaces and networks that participate in EIGRP routing, configure one or more **network** statements by entering the following command:

```
hostname(config-router)# network ip-addr [mask]
```

Directly-connected networks that fall within the defined network are advertised by the adaptive security appliance. Static networks are not advertised unless the redistribute static network is configured. Additionally, only interfaces with an IP address that fall within the defined network participate in the EIGRP routing process.

If you have an interface that you do not want to participate in EIGRP routing, but that is attached to a network that you want advertised, configure a **network** command that covers the network the interface is attached to, and use the **passive-interface** command to prevent that interface from sending or receiving EIGRP updates.

- Step 3** (Optional) To prevent an interface from sending or receiving EIGRP routing message, enter the following command:

```
hostname(config-router)# passive-interface {default | if-name}
```

Using the **default** keyword disables EIGRP routing updates on all interfaces. Specifying an interface name, as defined by the **nameif** command, disables EIGRP routing updates on the specified interface. You can have multiple **passive-interface** commands in your EIGRP router configuration.

- Step 4** (Optional) To control the sending or receiving of candidate default route information, enter the following command:

```
hostname(config-router)# no default-information {in | out}
```

Configuring **no default-information in** causes the candidate default route bit to be blocked on received routes. Configuring **no default-information out** disables the setting of the default route bit in advertised routes.

- Step 5** (Optional) To filter networks sent in EIGRP routing updates, perform the following steps:

- a. Create a standard access list that defines the routes you want to advertise.
- b. Enter the following command to apply the filter. You can specify an interface to apply the filter to only those updates sent by that interface.

```
hostname(config-router): distribute-list acl out [interface if_name]
```

You can enter multiple **distribute-list** commands in your EIGRP router configuration.

- Step 6** (Optional) To filter networks received in EIGRP routing updates, perform the following steps:
- Create a standard access list that defines the routes you want to filter from received updates.
  - Enter the following command to apply the filter. You can specify an interface to apply the filter to only those updates received by that interface.

```
hostname(config-router): distribute-list acl in [interface if_name]
```

You can enter multiple **distribute-list** commands in your EIGRP router configuration.

---

## Enabling and Configuring EIGRP Stub Routing

You can configure the adaptive security appliance as an EIGRP stub router. Stub routing decreases memory and processing requirements on the adaptive security appliance. As a stub router, the adaptive security appliance does not need to maintain a complete EIGRP routing table because it forwards all nonlocal traffic to a distribution router. Generally, the distribution router need not send anything more than a default route to the stub router.

Only specified routes are propagated from the stub router to the distribution router. As a stub router, the adaptive security appliance responds to all queries for summaries, connected routes, redistributed static routes, external routes, and internal routes with the message “inaccessible.” When the adaptive security appliance is configured as a stub, it sends a special peer information packet to all neighboring routers to report its status as a stub router. Any neighbor that receives a packet informing it of the stub status will not query the stub router for any routes, and a router that has a stub peer will not query that peer. The stub router depends on the distribution router to send the proper updates to all peers.

To enable and configure and EIGRP stub routing process, perform the following steps:

- Step 1** Create the EIGRP routing process and enter router configuration mode for that process by entering the following command:

```
hostname(config)# router eigrp as-num
```

The *as-num* argument is the autonomous system number of the EIGRP routing process.

- Step 2** Configure the interface connected to the distribution router to participate in EIGRP by entering the following command:

```
hostname(config-router)# network ip-addr [mask]
```

- Step 3** Configure the stub routing process by entering the following command. You must specify which networks are advertised by the stub routing process to the distribution router. Static and connected networks are not automatically redistributed into the stub routing process.

```
hostname(config-router)# eigrp stub {receive-only | [connected] [redistributed] [static] [summary] }
```

---

## Enabling EIGRP Authentication

EIGRP route authentication provides MD5 authentication of routing updates from the EIGRP routing protocol. The MD5 keyed digest in each EIGRP packet prevents the introduction of unauthorized or false routing messages from unapproved sources.

EIGRP route authentication is configured on a per-interface basis. All EIGRP neighbors on interfaces configured for EIGRP message authentication must be configured with the same authentication mode and key for adjacencies to be established.

Before you can enable EIGRP route authentication, you must enable EIGRP.

To enable EIGRP authentication on an interface, perform the following steps:

- 
- Step 1** Enter interface configuration mode for the interface on which you are configuring EIGRP message authentication by entering the following command:

```
hostname(config)# interface phy_if
```

- Step 2** Enable MD5 authentication of EIGRP packets by entering the following command:

```
hostname(config-if)# authentication mode eigrp as-num md5
```

The *as-num* argument is the autonomous system number of the EIGRP routing process configured on the adaptive security appliance. If EIGRP is not enabled or if you enter the wrong number, the adaptive security appliance returns the following error message:

```
% Asystem(100) specified does not exist
```

- Step 3** Configure the key used by the MD5 algorithm by entering the following command:

```
hostname(config-if)# authentication key eigrp as-num key key-id key-id
```

The *as-num* argument is the autonomous system number of the EIGRP routing process configured on the adaptive security appliance. If EIGRP is not enabled or if you enter the wrong number, the adaptive security appliance returns the following error message:

```
% Asystem(100) specified does not exist
```

The *key* argument can contain up to 16 characters. The *key-id* argument is a number from 0 to 255. The *key-id* must match that of the *key-id* in other routers, similarly to how the key must match.

---

## Generating a Default EIGRP Route

You can force an autonomous system boundary router to generate a default route into an EIGRP routing domain. Whenever you specifically configure redistribution of routes into an EIGRP routing domain, the router automatically becomes an autonomous system boundary router. However, an autonomous system boundary router does not by default generate a default route into the EIGRP routing domain.

To generate a default route, perform the following steps:

- 
- Step 1** If you have not already done so, enter the router configuration mode for the EIGRP process you want to configure by entering the following command:

```
hostname(config)# router eigrp process_id
```

- Step 2** To force the autonomous system boundary router to generate a default route, enter the following command:

```
hostname(config-router)# default-information originate [always] [metric metric-value]  
[metric-type {1 | 2}] [route-map map-name]
```

The following example shows how to generate a default route:

```
hostname(config)# router eigrp 2  
hostname(config-router)# default-information originate always
```

## Defining an EIGRP Neighbor

EIGRP hello packets are sent as multicast packets. If an EIGRP neighbor is located across a nonbroadcast network, such as a tunnel, you must manually define that neighbor. When you manually define an EIGRP neighbor, hello packets are sent to that neighbor as unicast messages.

The interface through which EIGRP exchanges routing updates must be specified in the neighbor statement. The interfaces through which two EIGRP neighbors exchange routing updates must be configured with IP addresses from the same network.

To manually define an EIGRP neighbor, perform the following steps:

- Step 1** Enter router configuration mode for the EIGRP routing process by entering the following command:

```
hostname(config)# router eigrp as-num
```

The *as-num* argument is the autonomous system number of the EIGRP routing process.

- Step 2** Define the static neighbor by entering the following command:

```
hostname(config-router)# neighbor ip-addr interface if_name
```

The *ip-addr* argument is the IP address of the neighbor. The *if-name* argument is the name of the interface, as specified by the **nameif** command, through which that neighbor is available. You can define multiple neighbors for an EIGRP routing process.

## Redistributing Routes Into EIGRP

You can redistribute routes discovered by RIP and OSPF into the EIGRP routing process. You can also redistribute static and connected routes into the EIGRP routing process. You do not need to redistribute static or connected routes if they fall within the range of a **network** statement in the EIGRP configuration.

To redistribute routes into the EIGRP routing process, perform the following steps:

- Step 1** (Optional) Create a route-map to further define which routes from the specified routing protocol are redistributed in to the RIP routing process. See the [“Defining Route Maps” section on page 8-7](#) for more information about creating a route map.

- Step 2** Enter router configuration mode for the EIGRP routing process:

```
hostname(config)# router eigrp as-num
```

- Step 3** (Optional) Specify the default metrics that should be applied to routes redistributed into the EIGRP routing process by entering the following command:

```
hostname(config-router)# default-metric bandwidth delay reliability loading mtu
```

If you do not specify a **default-metric** in the EIGRP router configuration, you must specify the metric values in each **redistribute** command. If you specify the EIGRP metrics in the **redistribute** command and have the **default-metric** command in the EIGRP router configuration, the metrics in the **redistribute** command are used. If you redistribute static or connected into EIGRP, specifying a metric in the **redistribute** command is not a requirement, though recommended.

- Step 4** Choose one of the following options to redistribute the selected route type into the EIGRP routing process.

- To redistribute connected routes into the EIGRP routing process, enter the following command:

```
hostname(config-router): redistribute connected [metric bandwidth delay reliability loading mtu] [route-map map_name]
```

- To redistribute static routes into the EIGRP routing process, enter the following command:

```
hostname(config-router): redistribute static [metric bandwidth delay reliability loading mtu] [route-map map_name]
```

- To redistribute routes from an OSPF routing process into the EIGRP routing process, enter the following command:

```
hostname(config-router): redistribute ospf pid [match {internal | external [1 | 2] | nssa-external [1 | 2]}] [metric bandwidth delay reliability loading mtu] [route-map map_name]
```

- To redistribute routes from a RIP routing process into the EIGRP routing process, enter the following command:

```
hostname(config-router): redistribute rip [metric bandwidth delay reliability load mtu] [route-map map_name]
```

You must specify the EIGRP metric values in the **redistribute** command if you do not have a **default-metric** command in the EIGRP router configuration.

## Configuring the EIGRP Hello Interval and Hold Time

The adaptive security appliance periodically sends hello packets to discover neighbors and to learn when neighbors become unreachable or inoperative. By default, hello packets are sent every 5 seconds.

The hello packet advertises the adaptive security appliance hold time. The hold time indicates to EIGRP neighbors the length of time the neighbor should consider the adaptive security appliance reachable. If the neighbor does not receive a hello packet within the advertised hold time, then the adaptive security appliance is considered unreachable. By default, the advertised hold time is 15 seconds (three times the hello interval).

Both the hello interval and the advertised hold time are configured on a per-interface basis. We recommend setting the hold time to be at minimum three times the hello interval.

To configure the hello interval and advertised hold time, perform the following steps:

- 
- Step 1** Enter interface configuration mode for the interface on which you are configuring hello interval or advertised hold time by entering the following command:

```
hostname(config)# interface phy_if
```

- Step 2** To change the hello interval, enter the following command:

```
hostname(config)# hello-interval eigrp as-num seconds
```

- Step 3** To change the hold time, enter the following command:

```
hostname(config)# hold-time eigrp as-num seconds
```

---

## Disabling Automatic Route Summarization

Automatic route summarization is enabled by default. The EIGRP routing process summarizes on network number boundaries. This can cause routing problems if you have non-contiguous networks.

For example, if you have a router with the networks 192.168.1.0, 192.168.2.0, and 192.168.3.0 connected to it, and those networks all participate in EIGRP, the EIGRP routing process creates the summary address 192.168.0.0 for those routes. If an additional router is added to the network with the networks 192.168.10.0 and 192.168.11.0, and those networks participate in EIGRP, they will also be summarized as 192.168.0.0. To prevent the possibility of traffic being routed to the wrong location, you should disable automatic route summarization on the routers creating the conflicting summary addresses.

To disable automatic router summarization, enter the following command in router configuration mode for the EIGRP routing process:

```
hostname(config-router)# no auto-summary
```

**Note**

---

Automatic summary addresses have an administrative distance of 5. You cannot configure this value.

---

## Configuring Summary Aggregate Addresses

You can configure a summary addresses on a per-interface basis. You need to manually define summary addresses if you want to create summary addresses that do not occur at a network number boundary or if you want to use summary addresses on a adaptive security appliance with automatic route summarization disabled. If any more specific routes are in the routing table, EIGRP will advertise the summary address out the interface with a metric equal to the minimum of all more specific routes.

To create a summary address, perform the following steps:

- 
- Step 1** Enter interface configuration mode for the interface on which you are creating a summary address by entering the following command:

```
hostname(config)# interface phy_if
```

- Step 2** Create the summary address by entering the following command:

```
hostname(config-if)# summary-address eigrp as-num address mask [distance]
```

By default, EIGRP summary addresses that you define have an administrative distance of 5. You can change this value by specifying the optional *distance* argument in the **summary-address** command.

---

## Disabling EIGRP Split Horizon

Split horizon controls the sending of EIGRP update and query packets. When split horizon is enabled on an interface, update and query packets are not sent for destinations for which this interface is the next hop. Controlling update and query packets in this manner reduces the possibility of routing loops.

By default, split horizon is enabled on all interfaces.

Split horizon blocks route information from being advertised by a router out of any interface from which that information originated. This behavior usually optimizes communications among multiple routing devices, particularly when links are broken. However, with nonbroadcast networks, there may be situations where this behavior is not desired. For these situations, including networks in which you have EIGRP configured, you may want to disable split horizon.

If you disable split horizon on an interface, you must disable it for all routers and access servers on that interface.

To disable EIGRP split-horizon, perform the following steps:

- 
- Step 1** Enter interface configuration mode for the interface on which you are disabling split horizon by entering the following command:

```
hostname(config)# interface phy_if
```

- Step 2** To disable split horizon, enter the following command:

```
hostname(config-if)# no split-horizon eigrp as-number
```

---

## Changing the Interface Delay Value

The interface delay value is used in EIGRP distance calculations. You can modify this value on a per-interface basis.

To change the delay value, perform the following steps:

- 
- Step 1** Enter interface configuration mode for the interface on which you are changing the delay value used by EIGRP by entering the following command:

```
hostname(config)# interface phy_if
```

- Step 2** To disable split horizon, enter the following command:

```
hostname(config-if)# delay value
```

The *value* entered is in tens of microseconds. So, to set the delay for 2000 microseconds, you would enter a *value* of 200.

- Step 3** (Optional) To view the delay value assigned to an interface, use the **show interface** command.
-

## Monitoring and Maintaining EIGRP

You can use the following commands to monitor the EIGRP routing process. For examples and descriptions of the command output, see the *Cisco Security Appliance Command Reference*.

- To display the EIGRP event log, enter the following command:

```
hostname# show eigrp [as-number] events [{start end} | type]
```

- To display the interfaces participating in EIGRP routing, enter the following command:

```
hostname# show eigrp [as-number] interfaces [if-name] [detail]
```

- To display the EIGRP neighbor table, enter the following command:

```
hostname# show eigrp [as-number] neighbors [detail | static] [if-name]
```

- To display the EIGRP topology table, enter the following command:

```
hostname# show eigrp [as-number] topology [ip-addr [mask] | active | all-links | pending | summary | zero-successors]
```

- To clear EIGRP neighbors, enter the following command:

```
hostname# clear eigrp [as-number] neighbors [ip-addr | interface [if-name]]
```

- To clear EIGRP topology tables, enter the following command:

```
hostname# clear eigrp [as-number] topology [netmask]
```

- To clear the EIGRP event log, enter the following command:

```
hostname# clear eigrp [as-number] events
```

## Disabling Neighbor Change and Warning Message Logging

By default neighbor change, and neighbor warning messages are logged. You can disable the logging of neighbor change message and neighbor warning messages.

- To disable the logging of neighbor change messages, enter the following command in router configuration mode for the EIGRP routing process:

```
hostname(config-router)# no eigrp log-neighbor-changes
```

- To disable the logging of neighbor warning messages, enter the following command in router configuration mode for the EIGRP routing process:

```
hostname(config-router)# no eigrp log-neighbor-warnings
```

## The Routing Table

This section contains the following topics:

- [Displaying the Routing Table, page 8-34](#)
- [How the Routing Table is Populated, page 8-34](#)
- [How Forwarding Decisions are Made, page 8-36](#)

## Displaying the Routing Table

To view the entries in the routing table, enter the following command:

```
hostname# show route
```

```
Codes: C - connected, S - static, I - IGRP, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2, E - EGP
       i - IS-IS, L1 - IS-IS level-1, L2 - IS-IS level-2, ia - IS-IS inter area
       * - candidate default, U - per-user static route, o - ODR
       P - periodic downloaded static route
```

```
Gateway of last resort is 10.86.194.1 to network 0.0.0.0
```

```
S    10.1.1.0 255.255.255.0 [3/0] via 10.86.194.1, outside
C    10.86.194.0 255.255.254.0 is directly connected, outside
S*   0.0.0.0 0.0.0.0 [1/0] via 10.86.194.1, outside
```

## How the Routing Table is Populated

The adaptive security appliance routing table can be populated by statically defined routes, directly connected routes, and routes discovered by the RIP, EIGRP, and OSPF routing protocols. Because the adaptive security appliance can run multiple routing protocols in addition to having static and connected routes in the routing table, it is possible that the same route is discovered or entered in more than one manner. When two routes to the same destination are put into the routing table, the one that remains in the routing table is determined as follows:

- If the two routes have different network prefix lengths (network masks), then both routes are considered unique and are entered in to the routing table. The packet forwarding logic then determines which of the two to use.

For example, if the RIP and OSPF processes discovered the following routes:

- RIP: 192.168.32.0/24
- OSPF: 192.168.32.0/19

Even though OSPF routes have the better administrative distance, both routes are installed in the routing table because each of these routes has a different prefix length (subnet mask). They are considered different destinations and the packet forwarding logic determine which route to use.

- If the adaptive security appliance learns about multiple paths to the same destination from a single routing protocol, such as RIP, the route with the better metric (as determined by the routing protocol) is entered into the routing table.

Metrics are values associated with specific routes, ranking them from most preferred to least preferred. The parameters used to determine the metrics differ for different routing protocols. The path with the lowest metric is selected as the optimal path and installed in the routing table. If there are multiple paths to the same destination with equal metrics, load balancing is done on these equal cost paths.

- If the adaptive security appliance learns about a destination from more than one routing protocol, the administrative distances of the routes are compared and the routes with lower administrative distance is entered into the routing table.

You can change the administrative distances for routes discovered by or redistributed into a routing protocol. If two routes from two different routing protocols have the same administrative distance, then the route with the lower *default* administrative distance is entered into the routing table. In the case of EIGRP and OSPF routes, if the EIGRP route and the OSPF route have the same administrative distance, then the EIGRP route is chosen by default.

Administrative distance is a route parameter that the adaptive security appliance uses to select the best path when there are two or more different routes to the same destination from two different routing protocols. Because the routing protocols have metrics based on algorithms that are different from the other protocols, it is not always possible to determine the “best path” for two routes to the same destination that were generated by different routing protocols.

Each routing protocol is prioritized using an administrative distance value. [Table 8-1](#) shows the default administrative distance values for the routing protocols supported by the adaptive security appliance.

**Table 8-1**      **Default Administrative Distance for Supported Routing Protocols**

Route Source	Default Administrative Distance
Connected interface	0
Static route	1
EIGRP Summary Route	5
Internal EIGRP	90
OSPF	110
RIP	120
EIGRP external route	170
Unknown	255

The smaller the administrative distance value, the more preference is given to the protocol. For example, if the adaptive security appliance receives a route to a certain network from both an OSPF routing process (default administrative distance - 110) and a RIP routing process (default administrative distance - 100), the adaptive security appliance chooses the OSPF route because OSPF has a higher preference. This means the router adds the OSPF version of the route to the routing table.

In the above example, if the source of the OSPF-derived route was lost (for example, due to a power shutdown), the adaptive security appliance would then use the RIP-derived route until the OSPF-derived route reappears.

The administrative distance is a local setting. For example, if you use the **distance-ospf** command to change the administrative distance of routes obtained through OSPF, that change would only affect the routing table for the adaptive security appliance the command was entered on. The administrative distance is not advertised in routing updates.

Administrative distance does not affect the routing process. The OSPF and RIP routing processes only advertise the routes that have been discovered by the routing process or redistributed into the routing process. For example, the RIP routing process advertises RIP routes, even if routes discovered by the OSPF routing process are used in the adaptive security appliance routing table.

## Backup Routes

A backup route is registered when the initial attempt to install the route in the routing table fails because another route was installed instead. If the route that was installed in the routing table fails, the routing table maintenance process calls each routing protocol process that has registered a backup route and requests them to reinstall the route in the routing table. If there are multiple protocols with registered backup routes for the failed route, the preferred route is chosen based on administrative distance.

Because of this process, you can create “floating” static routes that are installed in the routing table when the route discovered by a dynamic routing protocol fails. A floating static route is simply a static route configured with a greater administrative distance than the dynamic routing protocols running on the adaptive security appliance. When the corresponding route discovered by a dynamic routing process fails, the static route is installed in the routing table.

## How Forwarding Decisions are Made

Forwarding decisions are made as follows:

- If the destination does not match an entry in the routing table, the packet is forwarded through the interface specified for the default route. If a default route has not been configured, the packet is discarded.
- If the destination matches a single entry in the routing table, the packet is forwarded through the interface associated with that route.
- If the destination matches more than one entry in the routing table, and the entries all have the same network prefix length, the packets for that destination are distributed among the interfaces associated with that route.
- If the destination matches more than one entry in the routing table, and the entries have different network prefix lengths, then the packet is forwarded out of the interface associated with the route that has the longer network prefix length.

For example, a packet destined for 192.168.32.1 arrives on an interface of a adaptive security appliance with the following routes in the routing table:

```
hostname# show route
.....
R   192.168.32.0/24 [120/4] via 10.1.1.2
O   192.168.32.0/19 [110/229840] via 10.1.1.3
.....
```

In this case, a packet destined to 192.168.32.1 is directed toward 10.1.1.2, because 192.168.32.1 falls within the 192.168.32.0/24 network. It also falls within the other route in the routing table, but the 192.168.32.0/24 has the longest prefix within the routing table (24 bits versus 19 bits). Longer prefixes are always preferred over shorter ones when forwarding a packet.

## Dynamic Routing and Failover

Dynamic routes are not replicated to the standby unit or failover group in a failover configuration. Therefore, immediately after a failover occurs, some packets received by the adaptive security appliance may be dropped because of a lack of routing information or routed to a default static route while the routing table is repopulated by the configured dynamic routing protocols.