



W Commands

The commands in this chapter apply to the Cisco MDS 9000 Family of multilayer directors and fabric switches. All commands are shown here in alphabetical order regardless of command mode. Please see the Command Mode section to determine the appropriate mode for each command. For more information, see the *Cisco MDS 9000 Family Configuration Guide*.

- [write erase](#), page 20-2
- [wn secondary-mac](#), page 20-3

Send documentation comments to mdsfeedback-doc@cisco.com.

write erase

To clear a startup configuration, enter the **write erase** command from the EXEC mode prompt.

write erase [boot | debug]

Syntax Description	boot	Destroys boot configuration.
	debug	Clears the existing debug configuration.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines Once this command is issued, the switch's startup configuration reverts to factory defaults. The running configuration is not affected. The **write erase** command erases the entire startup configuration with the exception of any configuration that affects the loader functionality.

The **write erase boot** command only erases the configuration that affects the loader functionality. The loader functionality configuration includes the boot variables and the mgmt0 IP configuration information (IP address, netmask and default gateway).

Examples The following example clears the existing startup configuration completely.

```
switch# write erase
```

The following example clears the loader functionality configuration.

```
switch# write erase boot
```

This command will erase the boot variables and the ip configuration of interface mgmt 0

Send documentation comments to mdsfeedback-doc@cisco.com.

wwn secondary-mac

To allocate secondary MAC addresses, use the **wwn secondary-mac** command.

wwn secondary-mac *wwn-id* **range** *address-range*

Syntax Description	secondary-mac <i>wwn-id</i> The secondary MAC address with the format <i>hh:hh:hh:hh:hh:hh</i> .
range <i>address-range</i>	The range for the specified WWN (64).

Command Modes	EXEC
----------------------	------

Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
------------------------	---

Usage Guidelines	<p>This command cannot be undone.</p> <p>Changes to the worldwide names are only performed as required. They should not be changed on a daily basis. These changes should be made by an administrator or individual who is completely familiar with switch operations.</p> <p>For more information, refer to the <i>Cisco MDS 9000 Family Configuration Guide</i>.</p>
-------------------------	--

Examples	<pre>switch(config)# wwn secondary-mac 00:99:55:77:55:55 range 64 This command CANNOT be undone. Please enter the BASE MAC ADDRESS again: 00:99:55:77:55:55 Please enter the mac address RANGE again: 64 From now on WWN allocation would be based on new MACs. Are you sure? (yes/no) no You entered: no. Secondary MAC NOT programmed</pre>
-----------------	--

Send documentation comments to mdsfeedback-doc@cisco.com.