



CHAPTER

6

Software Images

This chapter describes how to install and upgrade software images. It includes the following sections:

- [About Software Images, page 6-1](#)
- [Essential Upgrade Prerequisites, page 6-2](#)
- [Software Upgrade Methods, page 6-4](#)
- [Performing an Automated Upgrade, page 6-5](#)
- [Displaying the Status of an Upgrade, page 6-15](#)
- [Performing a Manual Upgrade on a Dual Supervisor Switch, page 6-17](#)
- [Quick Upgrade, page 6-21](#)
- [Maintaining Supervisor Modules, page 6-22](#)
- [Replacing Modules, page 6-22](#)
- [Recovering a Corrupted Bootflash, page 6-24](#)
- [Default Settings, page 6-33](#)

About Software Images

Each switch is shipped with a Cisco MDS SAN-OS operating system for Cisco MDS 9000 Family switches. The Cisco SAN-OS consists of two images—the kickstart image and the system image. To upgrade the switch to a new image, you must specify the variables that direct the switch to the images.

- To select the kickstart image, use the KICKSTART variable.
- To select the system image, use the SYSTEM variable.

The images and variables are important factors in any install procedure. You must specify the variable and the image to upgrade your switch (see the “[Quick Upgrade](#)” section on page 6-21). Both images are not always required for each install.



Note

Unless explicitly stated, the software install procedures in this section apply to any switch in the Cisco MDS 9000 Family.

Dependent Factors for Software Installation

The software image install procedure is dependent on the following factors:

- Software images—The kickstart and system image files reside in directories or folders that can be accessed from the Cisco MDS 9000 Family switch prompt.
- Image version—Each image file has a version.
- Flash disks on the switch—The bootflash: resides on the supervisor and the CompactFlash disk is inserted into the slot0: device.
- Supervisor modules—There are single or dual supervisor modules.

Essential Upgrade Prerequisites

Before attempting to migrate to any software image version, follow these guidelines:

- Customer Service

Before performing any software upgrade, contact your respective customer service representative to review your software upgrade requirements and to provide recommendations based on your current operating environment.



Note If you purchased Cisco support through a Cisco reseller, contact the reseller directly. If you purchased support directly from Cisco Systems, contact Cisco Technical Support at this URL: <http://www.cisco.com/warp/public/687/Directory/DirTAC.shtml>

- Scheduling

Schedule the upgrade when the fabric is stable and steady. Ensure that everyone who has access to the switch or the network is not configuring the switch or the network during this time. All configurations are disallowed at this time.

- Space

Verify that sufficient space is available in the location where you are copying the images. This location includes the active and standby supervisor bootflash: (internal to the switch).

- Standby supervisor module bootflash: directory (see the [Chapter 4, “Initial Configuration”](#)).
- Internal bootflash offers approximately 200 MB of user space.

- Hardware

Avoid power interruption during any install procedure. These kinds of problems can corrupt the software image.

- Connectivity (to retrieve images from remote servers)

- Configure the IP address for the 10/100BASE-T Ethernet port connection (interface mgmt0).
- Ensure the switch has a route to the remote server. The switch and the remote server must be in the same subnetwork if you do not have a router to route traffic between subnets.

- Images
 - Ensure that the specified system and kickstart images are compatible with each other.
 - If the kickstart image is not specified, the switch uses the current running kickstart image.
 - If you specify a different system image, ensure that it is compatible with the running kickstart image.
 - Retrieve images in one of two ways:
 - Locally—images are locally available on the switch.
 - Remotely—images are in a remote location and the user specifies the destination using the remote server parameters and the file name to be used locally.
 - Terminology
- Table 6-1** summarizes terms used in this chapter with specific reference to the install and upgrade process.

Table 6-1 Terms Specific to This Chapter

Term	Definition	
bootable	The modules ability to boot or not boot based on image compatibility.	
impact	The type of software upgrade mechanism—disruptive or nondisruptive.	
install-type	reset	Resets the module.
	sw-reset	Resets the module immediately after switchover.
	rolling	Upgrades each module in sequence.
	copy-only	Updates the software for BIOS, loader, or bootrom.

- Commands
 - Verify connectivity to the remote server using the **ping** command.
 - Ensure that the required space is available for the image files to be copied using the **dir** command.
 - We recommend the one-step **install all** command to upgrade your software. This command upgrades all modules in any Cisco MDS 9000 Family switch (see the “[Benefits of Using the install all Command](#)” section on page 6-5).
 - Only one **install all** command can be running on a switch at any time.
 - No other command can be issued while running the **install all** command.
 - The **install all** command cannot be performed on the standby supervisor module—it can only be issued on the active supervisor module.
 - If the switching module(s) are not compatible with the new supervisor module image, some traffic disruption may be noticed in the related modules, depending on your configuration. These modules are identified in the summary when you issue the **install all** command. You can choose to proceed with the upgrade or end at this point.



Note When you issue the **install all** command, the switch displays a summary of changes that are made to your configuration and waits for your authorization to continue executing the command process.

Software Upgrade Methods

You can upgrade software without any disruptions using the Cisco MDS SAN-OS software designed for mission-critical high availability environments. To realize the benefits of nondisruptive upgrades on the Cisco MDS 9500 Directors, we highly recommend that you install dual supervisor modules.

You can upgrade any switch in the Cisco MDS 9500 Series and the Cisco MDS 9200 Series using one of the following methods:

- Automated, one-step upgrade using the **install all** command. This upgrade is nondisruptive (see the “[Performing an Automated Upgrade](#)” section on page 6-5).
- Quick, one-step upgrade using the **reload** command. This upgrade is disruptive (see the “[Quick Upgrade](#)” section on page 6-21).



Tip The **install all** command compares and presents the results of the compatibility before proceeding with the installation. You can exit if you do not want to proceed with these changes.

In some cases, regardless of which process you use, the software upgrades may be disruptive. These exception scenarios can occur under the following conditions:

- A single supervisor system with kickstart or system image changes
- A dual supervisor system with incompatible system software images

Determining Software Compatibility

If the running image and the image you want to install are incompatible, the software reports the incompatibility. In some cases, you may decide to proceed with this installation. If the active and the standby supervisor modules run different versions of the image, both images may be HA compatible in some cases and incompatible in others.

Compatibility is established based on the image and configuration:

- Image incompatibility—The running image and the image to be installed are not compatible.
- Configuration incompatibility—There is a possible compatibility if certain features in the running image are turned off as they are not supported in the image to be installed. The image to be installed is considered incompatible with the running image if one of the following statements is true:
 - An incompatible feature is enabled in the image to be installed and it is not available in the running image and may cause the switch to move into an inconsistent state. In this case, the incompatibility is *strict*.
 - An incompatible feature is enabled in the image to be installed and it is not available in the running image and does not cause the switch to move into an inconsistent state. In this case, the incompatibility is *loose*.

To view the results of a dynamic compatibility check, issue the **show incompatibility system bootflash:filename** command (see [Example 6-1](#)). Use this command to obtain further information when the **install all** command returns the following message:

Warning: The startup config contains commands not supported by the standby supervisor; as a result, some resources might become unavailable after a switchover.

Do you wish to continue? (y/ n) [y]: **n**

Example 6-1 Displays HA Compatibility Status


```
switch# show incompatibility system bootflash:running-image
The following configurations on active are incompatible with the system image
1) Feature Index : 67 , Capability : CAP FEATURE SPAN_FC_TUNNEL_CFG
Description : SPAN - Remote SPAN feature using fc-tunnels
Capability requirement : STRICT

2) Feature Index : 119 , Capability : CAP FEATURE_FC_TUNNEL_CFG
Description : fc-tunnel is enabled
Capability requirement : STRICT
```

Performing an Automated Upgrade

The **install all** command upgrades all modules in any Cisco MDS 9000 Family switch. Figure 6-1 provides an overview of the switch status before and after issuing the **install all** command.

Figure 6-1 The Effect of the install all Command



The **install all** command automatically verifies if the standby supervisor module is functioning (if present). If it is not functioning, it reloads that module and uses the **reload module slot force-dnld** command to force it to function.



Note The **install all** command is only effective on switches running Cisco MDS SAN-OS Release 1.0(3) and later.

Benefits of Using the **install all** Command

The **install all** command provides the following benefits:

- You can upgrade the entire switch using just one command.
- You can receive descriptive information on the intended changes to your system before continue with the command.
- You have the option to cancel the command. Once the effects of the command are presented, you can continue or cancel when you see this question (the default is **no**):

```
Do you want to continue (y/n) [n] :y
```

- You can upgrade the entire switch using the least disruptive procedure.
- You can see the progress of this command on the console, Telnet, and SSH screens:
 - After a switchover process, you can see the progress from both the supervisor modules.
 - Before a switchover process, you can only see the progress from the active supervisor module.
- The command automatically checks the image integrity. This includes the running kickstart and system images.
- The command performs a platform validity check to verify that a wrong image is not used—for example, to check if an MDS 9509 image is used inadvertently to upgrade an MDS 9216 switch.
- The **Ctrl-c** escape sequence gracefully ends the command. The command sequence completes the update step in progress and returns to the switch prompt. (Other upgrade steps cannot be ended using **Ctrl-c**.)
- After issuing the command, if any step in the sequence fails, the command completes the step in progress and ends.

For example, if a switching module fails to be updated for any reason (for example, due to an unstable fabric state), then the command sequence disruptively updates that module and ends. In such cases, you can verify the problem on the affected switching module and upgrade the other switching modules.

Recognizing Failure Cases

The following situations cause the **install all** command to end:

- If the standby supervisor module bootflash: directory does not have sufficient space to accept the updated image.
- If the specified system and kickstart images are not compatible.
- If the **install all** command is issued on the standby supervisor module.
- If the fabric or switch is configured while the upgrade is in progress.
- If a module is removed while the upgrade is in progress.
- If the switch has any power disruption while the upgrade is in progress.
- If the entire path for the remote location is not specified accurately.
- If images are incompatible after an upgrade. For example, a switching module image may be incompatible with the system image, or a kickstart image may be incompatible with a system image. This is also identified by the **show install all impact** command in the compatibility check section of the output (under the Bootable column).



Caution

If the **install all** command is ended, be sure to verify the state of the switch at every stage and reissue the command after 10 seconds. If you reissue the **install all** command within the 10-second span, the command is rejected with an error message indicating that an installation is currently in progress.

Using the install all Command

To perform an automated software upgrade on any switch, follow these steps:

-
- Step 1** Log into the switch through the console, Telnet, or SSH port of the active supervisor.
 - Step 2** Create a backup of your existing configuration file, if required (see the “[Working with Configuration Files](#)” section on page 4-23).
 - Step 3** Perform the upgrade by issuing the **install all** command.

```
switch# install all system bootflash:isan-1.3.1 kickstart bootflash:boot-1.3.1
```

```
Verifying image bootflash:/boot-1.3.1
[#####] 100% -- SUCCESS
```

```
Verifying image bootflash:/isan-1.3.1
[#####] 100% -- SUCCESS
```

```
Extracting "slc" version from image bootflash:/isan-1.3.1.
[#####] 100% -- SUCCESS
```

```
Extracting "ips" version from image bootflash:/isan-1.3.1.
[#####] 100% -- SUCCESS
```

```
Extracting "system" version from image bootflash:/isan-1.3.1.
[#####] 100% -- SUCCESS
```

```
Extracting "kickstart" version from image bootflash:/boot-1.3.1.
[#####] 100% -- SUCCESS
```

```
Extracting "loader" version from image bootflash:/boot-1.3.1.
[#####] 100% -- SUCCESS
```

Compatibility check is done:

Module	bootable	Impact	Install-type	Reason
1	yes	non-disruptive	rolling	
2	yes	disruptive	rolling	Hitless upgrade is not supported
3	yes	disruptive	rolling	Hitless upgrade is not supported
4	yes	non-disruptive	rolling	
5	yes	non-disruptive	reset	
6	yes	non-disruptive	reset	

Images will be upgraded according to following table:

Module	Image	Running-Version	New-Version	Upg-Required
1	slc	1.3(2a)	1.3(1)	yes
1	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
2	ips	1.3(2a)	1.3(1)	yes
2	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
3	ips	1.3(2a)	1.3(1)	yes
3	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
4	slc	1.3(2a)	1.3(1)	yes
4	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
5	system	1.3(2a)	1.3(1)	yes
5	kickstart	1.3(2a)	1.3(1)	yes
5	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
5	loader	1.2(2)	1.2(2)	no
6	system	1.3(2a)	1.3(1)	yes
6	kickstart	1.3(2a)	1.3(1)	yes
6	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no

■ Performing an Automated Upgrade

```

6           loader           1.2(2)          1.2(2)          no

Do you want to continue with the installation (y/n)? [n] y

Install is in progress, please wait.

Syncing image bootflash:/boot-1.3.1 to standby.
[#####] 100% -- SUCCESS

Syncing image bootflash:/isan-1.3.1 to standby.
[#####] 100% -- SUCCESS
Jan 18 23:40:03 Hacienda %VSHD-5-VSHD_SYSLOG_CONFIG_I: Configuring console from

Performing configuration copy.
[#####] 100% -- SUCCESS

Module 6: Waiting for module online.
|
Auto booting bootflash:/boot-1.3.1 bootflash:/isan-1.3.1...
Booting kickstart image: bootflash:/boot-1.3.1....
.....Image verification OK

Starting kernel...
INIT: version 2.78 booting
Checking all filesystems..r.r.. done.
Loading system software
Uncompressing system image: bootflash:/isan-1.3.1
CCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCC
CCCCCCCCCCCCCCCCCCCCCCCCCCCC
INIT: Entering runlevel: 3

```

- Step 4** Exit the switch console and open a new terminal session to view the upgraded supervisor module using the **show module** command.

If the configuration meets all guidelines when the **install all** command is issued, all modules (supervisor and switching) are upgraded. This is true for any switch in the Cisco MDS 9000 Family.



Caution If a nondisruptive upgrade operation fails for any reason other than those listed in the “[Recognizing Failure Cases](#)” section on page 6-6, contact your reseller or Cisco representative for further assistance.

If you purchased Cisco support through a Cisco reseller, contact the reseller directly. If you purchased support directly from Cisco Systems, contact Cisco Technical Support at this URL: <http://www.cisco.com/warp/public/687/Directory/DirTAC.shtml>

Upgrading Service Modules


Caution

Any software upgrade for the Caching Services Module (CSM) and the IP Storage (IPS) services module is disruptive.

CSMs and IPS modules use a rolling upgrade install mechanism to guarantee a stable state for each module in the switch:

- Each IPS module in a switch requires a 5-minute delay before the next IPS module is upgraded. Refer to the [Chapter 22, “Configuring IP Storage”](#) for further information on IPS modules.
- Each CSM module requires a 30-minute delay before the next CSM module is upgraded. Refer to the *Cisco MDS 9000 Family SAN Volume Controller Configuration Guide* for more information on CSMs.

Sample install all Commands

[Example 6-2](#) displays the result of the **install all** command issued from a console terminal that is connected to the active supervisor. Once a switchover happens, you can see the rest of the output from the console terminal of the standby supervisor module. [Example 6-3](#) displays the file output continuation of the **install all** command on the console of the standby supervisor module.

Similarly, you can view the results of the **install all** command issued from the SSH or Telnet terminal that is connected to the active supervisor. Once a switchover happens, you need to log back into the switch and issue the **show install all status** command (see the [“Displaying the Status of an Upgrade” section on page 6-15](#)).

Example 6-2 Successful install all Command Issued from the Active Console

```
Hacienda# install all sys bootflash:isan-1.3.1 kickstart bootflash:boot-1.3.1

Verifying image bootflash:/boot-1.3.1
[#####] 100% -- SUCCESS

Verifying image bootflash:/isan-1.3.1
[#####] 100% -- SUCCESS

Extracting "slc" version from image bootflash:/isan-1.3.1.
[#####] 100% -- SUCCESS

Extracting "ips" version from image bootflash:/isan-1.3.1.
[#####] 100% -- SUCCESS

Extracting "system" version from image bootflash:/isan-1.3.1.
[#####] 100% -- SUCCESS

Extracting "kickstart" version from image bootflash:/boot-1.3.1.
[#####] 100% -- SUCCESS

Extracting "loader" version from image bootflash:/boot-1.3.1.
[#####] 100% -- SUCCESS

Compatibility check is done:
Module      bootable      Impact      Install-type      Reason
```

■ Performing an Automated Upgrade

1	yes	non-disruptive	rolling	
2	yes	disruptive	rolling	Hitless upgrade is not supported
3	yes	disruptive	rolling	Hitless upgrade is not supported
4	yes	non-disruptive	rolling	
5	yes	non-disruptive	reset	
6	yes	non-disruptive	reset	

Images will be upgraded according to following table:

Module	Image	Running-Version	New-Version	Upg-Required
1	slc	1.3(2a)	1.3(1)	yes
1	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
2	ips	1.3(2a)	1.3(1)	yes
2	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
3	ips	1.3(2a)	1.3(1)	yes
3	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
4	slc	1.3(2a)	1.3(1)	yes
4	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
5	system	1.3(2a)	1.3(1)	yes
5	kickstart	1.3(2a)	1.3(1)	yes
5	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
5	loader	1.2(2)	1.2(2)	no
6	system	1.3(2a)	1.3(1)	yes
6	kickstart	1.3(2a)	1.3(1)	yes
6	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
6	loader	1.2(2)	1.2(2)	no

Do you want to continue with the installation (y/n)? [n] **y**

Install is in progress, please wait.

Syncing image bootflash:/boot-1.3.1 to standby.
[#####] 100% -- SUCCESS

Syncing image bootflash:/isan-1.3.1 to standby.
[#####] 100% -- SUCCESS
Jan 18 23:40:03 Hacienda %VSHD-5-VSHD_SYSLOG_CONFIG_I: Configuring console from

Performing configuration copy.
[#####] 100% -- SUCCESS

Module 6: Waiting for module online.
|
Auto booting bootflash:/boot-1.3.1 bootflash:/isan-1.3.1...
Booting kickstart image: bootflash:/boot-1.3.1....
.....Image verification OK

Starting kernel...
INIT: version 2.78 booting
Checking all filesystems..r.r.. done.
Loading system software
Uncompressing system image: bootflash:/isan-1.3.1
CC
INIT: Entering runlevel: 3

Example 6-3 displays the file output continuation of the **install all** command on the console of the standby supervisor module.

Example 6-3 Successful install all Command Output Continued from the Standby Console

```
Hacienda (standby) #  
  
Auto booting bootflash:/boot-1.3.1 bootflash:/isan-1.3.1...  
Booting kickstart image: bootflash:/boot-1.3.1....  
.....Image verification OK  
  
Starting kernel...  
INIT: version 2.78 booting  
Checking all filesystems..r.r.. done.  
Loading system software  
Uncompressing system image: bootflash:/isan-1.3.1  
CCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCC  
CCCCCCCCCCCCCCCCCCCCCCCCCCCC  
INIT: Entering runlevel: 3  
  
Continue on installation process, please wait.  
The login will be disabled until the installation is completed.  
  
Module 6: Waiting for module online.  
Jan 18 23:43:02 Hacienda %PORT-5-IF_UP: Interface mgmt0 is up  
Jan 18 23:43:19 Hacienda %LICMGR-3-LOG_LIC_NO_LIC: No license(s) present for feature  
FM_SERVER_PKG. Application(s) shutdown in 53 days.  
Jan 18 23:43:19 Hacienda %LICMGR-3-LOG_LIC_NO_LIC: No license(s) present for feature  
ENTERPRISE_PKG. Application(s) shutdown in 50 days.  
Jan 18 23:43:19 Hacienda %LICMGR-3-LOG_LIC_NO_LIC: No license(s) present for feature  
SAN_EXTN_OVER_IP. Application(s) shutdown in 50 days.  
Jan 18 23:43:19 Hacienda %LICMGR-3-LOG_LICAPP_NO_LIC: Application port-security running  
without ENTERPRISE_PKG license, shutdown in 50 days  
Jan 18 23:43:19 Hacienda %LICMGR-4-LOG_LICAPP_EXPIRY_WARNING: Application Roles evaluation  
license ENTERPRISE_PKG expiry in 50 days  
Jan 18 23:44:54 Hacienda %BOOTVAR-5-NEIGHBOR_UPDATE_AUTOCOPY: auto-copy supported by  
neighbor, starting...  
Module 1: Non-disruptive upgrading.  
[#] 0% Jan 18 23:44:56 Hacienda %MODULE-5-STANDBY_SUP_OK: Supervisor 5  
is standby  
Jan 18 23:44:55 Hacienda %IMAGE_DNLD-SLOT1-2-IMG_DNLD_STARTED: Module image download  
process. Please wait until completion...  
Jan 18 23:45:12 Hacienda %IMAGE_DNLD-SLOT1-2-IMG_DNLD_COMPLETE: Module image download  
process. Download successful.  
Jan 18 23:45:48 Hacienda %MODULE-5-MOD_OK: Module 1 is online  
[#####] 100% -- SUCCESS  
Module 4: Non-disruptive upgrading.  
[#] 0% Jan 18 23:46:12 Hacienda %IMAGE_DNLD-SLOT4-2-IMG_DNLD_STARTED:  
Module image download process. Please wait until completion...  
Jan 18 23:46:26 Hacienda %IMAGE_DNLD-SLOT4-2-IMG_DNLD_COMPLETE: Module image download  
process. Download successful.  
Jan 18 23:47:02 Hacienda %MODULE-5-MOD_OK: Module 4 is online  
[#####] 100% -- SUCCESS  
Module 2: Disruptive upgrading.  
...  
-- SUCCESS  
Module 3: Disruptive upgrading.  
...  
-- SUCCESS  
Install has been successful.  
MDS Switch  
Hacienda login:
```

Example 6-4 displays the result of the **install all** command if the system and kickstart files are automatically downloaded using a remote (TFTP, FTP, SCP, or SFTP) download option. It shows an accurate and complete example.

**Caution**

Specify the complete path of the remote location. The system will not allow you to proceed if the entire path is not accurately specified. Here are examples of incomplete **install all** commands.

```
switch# install all system bootflash:system-image kickstart tftp:  
Please provide a complete URI  
switch# install all system scp:  
Please provide a complete URI
```

Example 6-4 A Sample of the *install all* Command Issued Using a Remote Download

```
switch# install all system  
scp://user@171.69.16.26/tftpboot/HKrel/qa/final/m9500-sf1ek9-mz.1.3.2a.bin kickstart  
scp://user@171.69.16.26/tftpboot/HKrel/qa/final/m9500-sf1ek9-kickstart-mz.1.3.2a.bin  
For scp://user@171.69.16.26, please enter password:  
For scp://user@171.69.16.26, please enter password:  
  
Copying image from  
scp://user@171.69.16.26/tftpboot/HKrel/qa/final/m9500-sf1ek9-kickstart-mz.1.3.2a.bin to  
bootflash:///m9500-sf1ek9-kickstart-mz.1.3.2a.bin.  
[#####] 100% -- SUCCESS  
  
Copying image from  
scp://user@171.69.16.26/tftpboot/HKrel/qa/final/m9500-sf1ek9-mz.1.3.2a.bin to  
bootflash:///m9500-sf1ek9-mz.1.3.2a.bin.  
[#####] 100% -- SUCCESS  
  
Verifying image bootflash:///m9500-sf1ek9-kickstart-mz.1.3.2a.bin  
[#####] 100% -- SUCCESS  
  
Verifying image bootflash:///m9500-sf1ek9-mz.1.3.2a.bin  
[#####] 100% -- SUCCESS  
  
Extracting "slc" version from image bootflash:///m9500-sf1ek9-mz.1.3.2a.bin.  
[#####] 100% -- SUCCESS  
  
Extracting "ips" version from image bootflash:///m9500-sf1ek9-mz.1.3.2a.bin.  
[#####] 100% -- SUCCESS  
  
Extracting "system" version from image bootflash:///m9500-sf1ek9-mz.1.3.2a.bin.  
[#####] 100% -- SUCCESS  
  
Extracting "kickstart" version from image  
bootflash:///m9500-sf1ek9-kickstart-mz.1.3.2a.bin.  
[#####] 100% -- SUCCESS  
  
Extracting "loader" version from image bootflash:///m9500-sf1ek9-kickstart-mz.1.3.2a.bin.  
[#####] 100% -- SUCCESS
```

Compatibility check is done:				
Module	bootable	Impact	Install-type	Reason
1	yes	non-disruptive	rolling	
2	yes	disruptive	rolling	Hitless upgrade is not supported
3	yes	non-disruptive	rolling	
4	yes	non-disruptive	rolling	

```

5      yes  non-disruptive      reset
6      yes  non-disruptive      reset
7      yes  non-disruptive      rolling
8      yes  non-disruptive      rolling
9      yes   disruptive       rolling Hitless upgrade is not supported

```

Images will be upgraded according to following table:

Module	Image	Running-Version	New-Version	Upg-Required
1	slc	1.3(1)	1.3(2a)	yes
1	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
2	ips	1.3(1)	1.3(2a)	yes
2	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
3	slc	1.3(1)	1.3(2a)	yes
3	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
4	slc	1.3(1)	1.3(2a)	yes
4	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
5	system	1.3(1)	1.3(2a)	yes
5	kickstart	1.3(1)	1.3(2a)	yes
5	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
5	loader	1.2(2)	1.2(2)	no
6	system	1.3(1)	1.3(2a)	yes
6	kickstart	1.3(1)	1.3(2a)	yes
6	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
6	loader	1.2(2)	1.2(2)	no
7	slc	1.3(1)	1.3(2a)	yes
7	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
8	slc	1.3(1)	1.3(2a)	yes
8	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
9	ips	1.3(1)	1.3(2a)	yes
9	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no

Do you want to continue with the installation (y/n)? [n]

Example 6-5 displays the **install all** command output of a failed operation due to a lack of disk space.

Example 6-5 Failed Operation Due to a Full bootflash: File System

```

switch# install all system bootflash:isan-1.3.2a kickstart bootflash:boot-1.3.2a

Verifying image bootflash:/boot-1.3.2a
[#####] 100% -- SUCCESS

Verifying image bootflash:/isan-1.3.2a
[#####] 100% -- SUCCESS

Extracting "slc" version from image bootflash:/isan-1.3.2a.
[#####] 100% -- SUCCESS

Extracting "ips" version from image bootflash:/isan-1.3.2a.
[#####] 100% -- SUCCESS

Extracting "system" version from image bootflash:/isan-1.3.2a.
[#####] 100% -- SUCCESS

Extracting "kickstart" version from image bootflash:/boot-1.3.2a.
[#####] 100% -- SUCCESS

Extracting "loader" version from image bootflash:/boot-1.3.2a.
[#####] 100% -- SUCCESS

```

■ Performing an Automated Upgrade

```
Compatibility check is done:
Module  bootable      Impact  Install-type  Reason
-----  -----  -----
1       yes    non-disruptive   rolling
2       yes    disruptive     rolling  Hitless upgrade is not supported
3       yes    non-disruptive   rolling
4       yes    non-disruptive   rolling
5       yes    non-disruptive   reset
6       yes    non-disruptive   reset
7       yes    non-disruptive   rolling
8       yes    non-disruptive   rolling
9       yes    disruptive     rolling  Hitless upgrade is not supported
```

Images will be upgraded according to following table:

Module	Image	Running-Version	New-Version	Upg-Required
1	slc	1.3(1)	1.3(2a)	yes
1	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
2	ips	1.3(1)	1.3(2a)	yes
2	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
3	slc	1.3(1)	1.3(2a)	yes
3	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
4	slc	1.3(1)	1.3(2a)	yes
4	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
5	system	1.3(1)	1.3(2a)	yes
5	kickstart	1.3(1)	1.3(2a)	yes
5	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
5	loader	1.2(2)	1.2(2)	no
6	system	1.3(1)	1.3(2a)	yes
6	kickstart	1.3(1)	1.3(2a)	yes
6	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
6	loader	1.2(2)	1.2(2)	no
7	slc	1.3(1)	1.3(2a)	yes
7	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
8	slc	1.3(1)	1.3(2a)	yes
8	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
9	ips	1.3(1)	1.3(2a)	yes
9	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no

Do you want to continue with the installation (y/n)? [n] y

Install is in progress, please wait.

Syncing image bootflash:/boot-1.3.2a to standby.

[#####] 100% -- SUCCESS

Syncing image bootflash:/isan-1.3.2a to standby.

[#] 0% -- FAIL. Return code 0x401E0008 (request was aborted, standby disk may be full).

Install has failed. Return code 0x40930013 (Syncing images to standby failed). <----
-----insufficient space message

Please identify the cause of the failure, and try 'install all' again.

Dec 15 19:36:42 switch %SYSMGR-3-SERVICE_TERMINATED: Service "installer" (PID 5470) has finished with error code SYSMGR_EXITCODE_FAILURE_NOCALLHOME (20).

[Example 6-6](#) displays the **install all** command output of a failed operation due to an invalid image.

Example 6-6 Failed Operation Due to an Invalid Image

```
install all sys bootflash:junk kickstart bootflash:junk

Verifying image bootflash:/junk
[#] 0% -- FAIL. Return code 0x4045001E (mismatch between actual image
type and boot variable).
Compatibility check failed. Return code 0x40930011 (Image verification failed).
Hacienda# Jan 19 00:20:35 Hacienda %SYSMGR-3-SERVICE_TERMINATED: Service "installer" (PID
5664) has finished with error code SYSMGR_EXITCODE_FAILURE_NOCALLHOME (20).
```

Displaying the Status of an Upgrade

Use the **show install all status** command to view the on-going **install all** command or the log of the last installed **install all** command from a console, SSH, or Telnet session.

This command presents the **install all** output on both the active and standby supervisor module even if you are not connected to the console terminal. It only displays the status of an **install all** command that is issued from the CLI (not the GUI). See [Example 6-7](#).

Example 6-7 Displays the install all Command Output

```
switch# show install all status
There is an on-going installation... <----- in progress installation
Enter Ctrl-C to go back to the prompt.

Verifying image bootflash:/b-1.3.0.104
-- SUCCESS

Verifying image bootflash:/i-1.3.0.104
-- SUCCESS

Extracting "system" version from image bootflash:/i-1.3.0.104.
-- SUCCESS

Extracting "kickstart" version from image bootflash:/b-1.3.0.104.
-- SUCCESS

Extracting "loader" version from image bootflash:/b-1.3.0.104.
-- SUCCESS

switch# show install all status
This is the log of last installation.          <<<<< log of last install

Verifying image bootflash:/b-1.3.0.104
-- SUCCESS

Verifying image bootflash:/i-1.3.0.104
-- SUCCESS
```

■ Displaying the Status of an Upgrade

```
Extracting "system" version from image bootflash:/i-1.3.0.104.  
-- SUCCESS
```

```
Extracting "kickstart" version from image bootflash:/b-1.3.0.104.  
-- SUCCESS
```

```
Extracting "loader" version from image bootflash:/b-1.3.0.104.  
-- SUCCESS
```

Performing a Manual Upgrade on a Dual Supervisor Switch

**Caution**

If you are a new user, use the **install all** command to perform a software upgrade. This section is for administrators or individuals who are completely familiar with specific switch functions.

You can manually upgrade the BIOS and the loader in any Cisco MDS switch using the procedures provided in this section. This upgrade process requires you to implement some or all procedures depending on your switch or network configuration.

To perform a manual upgrade for a dual supervisor switch, follow these steps.

Step 1 [“Preparing for a Manual Installation” section on page 6-17](#)

Step 2 [“Upgrading a Loader” section on page 6-18](#)

Step 3 [“Upgrading the BIOS” section on page 6-20](#)

Preparing for a Manual Installation

To prepare any Cisco MDS 9000 Family switch for a manual software installation, follow these steps:

Step 1 Log into the switch through the console port, an SSH session, or a Telnet session.

Step 2 Create a backup of your existing configuration file, if required (see the [“Saving the Configuration” section on page 4-26](#)).

Step 3 Copy the software image from a SCP location to one of two targets: bootflash: or slot0:.

The switch remains operational while the image file is copied.

- Bootflash device (SCP defaults to the bootflash device)—Copy the software image file from the appropriate SCP file system to the bootflash: file system.

```
switch# copy scp://server_IP_address/destination_file_name
```

For example:

```
switch# copy scp://user@10.1.7.2/system-image bootflash:system-image
```



Note The Cisco MDS 9216 Switch does not have an external CompactFlash (see the [“Working with Configuration Files” section on page 4-23](#)). If you are using a switch in this series, use the bootflash: file system to copy and verify files.

- CompactFlash device—Copy the software image file from the appropriate SCP file system to the CompactFlash device in slot0:.

```
switch# copy scp://server_IP_address/file_name_in_SCP slot0:system-image
```

You can also copy the image onto a new Flash disk from a PC and insert it in slot0: in the Cisco MDS 9500 Series switch. After you copy the image and insert it into the slot0: file system, the process is the same as the CompactFlash device after the **copy** command is issued.

Step 4 Verify that the file was copied in the required directory.

■ Performing a Manual Upgrade on a Dual Supervisor Switch

```
switch# dir bootflash:
40295206 Aug 05 15:23:51 1980 ilc1.bin
12456448 Jul 30 23:05:28 1980 kickstart-image1
12288 Jun 23 14:58:44 1980 lost+found/
27602159 Jul 30 23:05:16 1980 system-image1
12447232 Aug 05 15:08:30 1980 kickstart-image2
28364853 Aug 05 15:11:57 1980 system-image2

Usage for bootflash://sup-local
135404544 bytes used
49155072 bytes free
184559616 bytes total
```

- Step 5** Ensure that the software images are not damaged or corrupted in the saved bootflash: file system.

When copying a new image to your switch, confirm that the image was not corrupted during the copy process.

Use the **show version image** command to verify that the required image was copied successfully.

```
switch# show version image bootflash:kickstart-image
image name: m9500-sf1ek9-kickstart-mzg.1.0.3.bin
kickstart: version 1.0(3)
loader: version 1.0(3)
compiled: 2/12/2003 11:00:00
```

 **Note** A verification failed message is generated when you use a Cisco MDS 9500 Series image on a Cisco MDS 9200 Series switch or a Cisco MDS 9200 Series image on a Cisco MDS 9500 Series switch. Be sure to verify the right image.

- Step 6** Compare the running system image and the new image by issuing the **show install all impact** command.

Upgrading a Loader

The **install module slot# of the supervisor module loader** command upgrades the (boot) loader.



Note If the loader is upgraded, you need to reboot to make the new loader effective. You can schedule the reboot at a convenient time so traffic is not impacted.



Caution Before issuing this command, be sure to read the release notes to verify compatibility issues between the loader and the kickstart or system images.

To upgrade the loader on either the active or standby supervisor module, follow these steps.

- Step 1** Use the **show version** command to verify the version on the active and standby supervisor modules.

```
switch# show version
Cisco Storage Area Networking Operating System (SAN-OS) Software
TAC support: http://www.cisco.com/tac
Copyright (c) 2002-2003, Cisco Systems, Inc. All rights reserved.
The copyrights to certain works contained herein are owned by
Andiamo Systems, Inc. and/or other third parties and are used and
distributed under license. Some parts of this software are covered
```

under the GNU Public License. A copy of the license is available at <http://www.gnu.org/licenses/gpl.html>.

```
Software
  BIOS:      version 1.0.8
  loader:    version 1.1(2) <-----current running version
  kickstart: version 2.0(1)
  system:    version 2.0(1)

  BIOS compile time:      08/07/03
  kickstart image file is: bootflash:///m9500-sf1ek9-kickstart-mzg.2.0.0.6.bin
  kickstart compile time: 10/25/2010 12:00:00
  system image file is:   bootflash:///m9500-sf1ek9-mzg.2.0.0.6.bin
  system compile time:    10/25/2020 12:00:00
```

Hardware

RAM 1024584 kB

```
bootflash: 1000944 blocks (block size 512b)
slot0:       0 blocks (block size 512b)
```

172.22.92.181 uptime is 0 days 2 hours 18 minute(s) 1 second(s)

Last reset at 970069 usecs after Tue Sep 16 22:31:25 1980

```
Reason: Reset Requested by CLI command reload
System version: 2.0(0.6)
Service:
```

- Step 2** Issue the **install module** command for the required supervisor module (active or standby). This example displays the command being issued for the standby supervisor module in slot 6.

```
switch# install module 6 loader bootflash:kickstart-image
```



Note If you install a loader version that is the same as the currently installed version, the command will not execute. When both the current version and the installed version are the same, use the **init system** command to force a loader upgrade.

- Step 3** Use the **show version** command to verify the updated image on the supervisor module.

```
switch# show version
Cisco Storage Area Networking Operating System (SAN-OS) Software
TAC support: http://www.cisco.com/tac
Copyright (c) 2002-2003, Cisco Systems, Inc. All rights reserved.
The copyrights to certain works contained herein are owned by
Andiamo Systems, Inc. and/or other third parties and are used and
distributed under license. Some parts of this software are covered
under the GNU Public License. A copy of the license is available
at http://www.gnu.org/licenses/gpl.html.
```

Software

```
  BIOS:      version 1.3.1
  loader:    version 1.2(2) <-----New running version
  kickstart: version 1.3(1) ]
  system:    version 1.3(1)

  BIOS compile time:      08/07/03
  kickstart image file is: bootflash:///m9500-sf1ek9-kickstart-mzg.2.0.0.6.bin
  kickstart compile time: 10/25/2010 12:00:00
  system image file is:   bootflash:///m9500-sf1ek9-mzg.2.0.0.6.bin
  system compile time:    10/25/2020 12:00:00
```

■ Performing a Manual Upgrade on a Dual Supervisor Switch

```

Hardware
  RAM 1024584 kB

bootflash: 1000944 blocks (block size 512b)
slot0:          0 blocks (block size 512b)

172.22.92.181 uptime is 0 days 2 hours 18 minute(s) 1 second(s)

Last reset at 970069 usecs after Tue Sep 16 22:31:25 1980
  Reason: Reset Requested by CLI command reload
  System version: 2.0(0.6)
  Service:

```

Upgrading the BIOS



Tip Refer to the release notes to verify if the BIOS has changed for the image version being used.

Program the supervisor or switching module BIOS only if a new BIOS image is provided by Cisco System. Only use the provided image to upgrade the BIOS. This command does not affect traffic and can be issued at any time on any switch in the Cisco MDS 9200 Series or Cisco MDS 9500 Series.



Note If the BIOS is upgraded, reboot to make the new BIOS take effect. You can schedule the reboot at a convenient time so traffic is not impacted.



Caution The console baud rate automatically reverts to the default rate (9600) after any BIOS upgrade.

To upgrade the BIOS for a module, follow these steps:

Step 1 Use the **show version** command to verify the current running BIOS version.

```

switch# show version
Cisco Storage Area Networking Operating System (SAN-OS) Software
TAC support: http://www.cisco.com/tac
Copyright (c) 2002-2003 by Cisco Systems, Inc. All rights reserved.
The copyright for certain works contained herein are owned by
Andiamo Systems, Inc. and/or other third parties and are used and
distributed under license.
Software
  BIOS:      version 1.0(6) <----- current running version
  loader:    version 1.0(3)
  kickstart: version 1.0(3)
  system:    version 1.0(3)

  BIOS compile time:      01/27/03
  kickstart image file is: bootflash:/kickstart-image
  kickstart compile time: 01/25/2003 12:00:00
  system image file is:   bootflash:/system-image
  system compile time:    01/25/2003 12:00:00

```

Hardware
RAM 1027564 kB

- Step 2** Verify that the BIOS version of the system image is different from the running image.

```
switch# show version image bootflash:system-image
image name: m9500-sf1ek9-mz.1.0.3.bin
bios:          version v1.0.6(01/27/03) <----- BIOS is same version 1.0.6
system:        version 1.0(3)
compiled:      2/28/2003 5:00:00

system service's list

package name           package version
acl                   1.0(3)
ascii-cfg             1.0(3)
bios_daemon           1.0(3)
...
```



- Note** If the versions are different, issue the **install module** command as specified in Step 3. If they are the same, you do not need to update the BIOS image.

- Step 3** Run the **install module slot# bios** command to install each module (if required). In this example, the supervisor module in slot 6 was updated.

```
switch# install module 6 bios system bootflash:system-image
Started bios programming .... please wait
[########################################] 100%
BIOS upgrade succeeded for module 1
```



- Caution** Do not reboot the switch if any errors were indicated in response to this command.

- Step 4** Issue the **show version** command to verify that the module was updated with a the new BIOS version.

```
switch# show version module 6
ModNo  Image Type    SW Version    SW Interim Version  BIOS Version
6      Stby Sup     1.3(2)       1.3(1.1)           1.1.0 [last 1.0.6]
```

Quick Upgrade

To perform a quick upgrade on a Cisco MDS 9000 Family switch, follow these steps:

-
- Step 1** Copy the kickstart and system image files to the required location (see the “[Copying Files](#)” section on page 4-26).
- Step 2** Set the boot variables (see the “[Quick Upgrade](#)” section on page 6-21).
- Step 3** Issue the **reload** command. The **reload** command reboots the system. This upgrade is disruptive.

**Tip**

Use the **install all** command to gracefully reload the switch and handle configuration conversions.

Maintaining Supervisor Modules

This section includes general information about replacing and using supervisor modules effectively.

Standby Supervisor's Boot Variable Version

If the standby supervisor module's boot variable images are not the *same* version as those running on the active supervisor module, the software forces the standby supervisor module to run the same version as the active supervisor module.

If you specifically set the boot variables of the standby supervisor module to a different version and reboot the standby supervisor module, the standby supervisor module will only load the specified boot variable if the same version is also running on the active supervisor module. At this point, the standby supervisor module is *not* running the images set in the boot variables.

Standby Supervisor Boot Alert

If a standby supervisor module fails to boot, the active supervisor module detects that condition and generates a Call Home event and a SYSLOG message and reboots the standby supervisor module approximately 3 to 6 minutes after the standby supervisor module moves to the `loader>` prompt.

The following SYSLOG error message is issued:

```
%DAEMON-2-SYSTEM_MSG:Standby supervisor failed to boot up.
```

This error message is also generated if one of the following situations apply:

- You remain at the `loader>` prompt for an extended period of time.
- You do not set the boot variables appropriately.

Replacing Modules

When you replace any module (supervisor, switching, or services module), you must ensure that the new module is running the same software version as the rest of the switch.

Refer to *Cisco MDS 9000 Family SAN Volume Controller Configuration Guide* for configuration details on replacing the caching services module (CSM).

**Note**

When a spare standby supervisor module is inserted, it uses the same image as the active supervisor module. The SAN-OS image is not automatically copied to the standby flash device.



Tip Issue the **install all** command to copy the Cisco SAN-OS software image to the standby flash device.

Issuing the **install all** command after replacing any module, ensures the following actions:

- The proper system and kickstart images are copied on the standby bootflash: directory.
- The proper boot variables are set.
- The loader and the BIOS are upgraded to the same version available on the active supervisor module.

To replace a module in a Cisco MDS 9216 switch or Cisco MDS 9500 Series director, follow these steps:

Step 1 Create a backup of your existing configuration file, if required, using the **copy running-config startup-config** command.

Step 2 Replace the required module as specified in the *Cisco MDS 9216 Switch Hardware Installation Guide* or the *Cisco MDS 9500 Series Hardware Installation Guide*.

Step 3 Issue the **install all** command to ensure that the new module is running the same software as the rest of the switch.


Step 4 Wait until the new module is online and then ensure that the replacement was successful using the **show module** command.

Recovering a Corrupted Bootflash

All switch configurations reside in the internal bootflash. If you have a corrupted internal bootflash, you could potentially lose your configuration. Be sure to save and back up your configuration files periodically. The regular switch boot goes through the following sequence (see [Figure 6-2](#)):

1. The basic input/output system (BIOS) loads the loader.
2. The loader loads the kickstart image into RAM and starts the kickstart image.
3. The kickstart image loads and starts the system image.
4. The system image reads the startup configuration file.

Figure 6-2 Regular Boot Sequence



If the images on your switch are corrupted and you cannot proceed (error state), you can interrupt the switch boot sequence and recover the image by entering the BIOS configuration utility described in the following section. Access this utility only when needed to recover a corrupted internal disk.



The BIOS changes explained in this section are only required to recover a corrupted bootflash.

Recovery procedures require the regular sequence to be interrupted. The internal switch sequence goes through four phases between the time you turn the switch on and the time the switch prompt appears on your terminal—BIOS, boot loader, kickstart, and system (see [Table 6-2](#) and [Figure 6-3](#)).


Table 6-2 Recovery Interruption

Phase	Normal Prompt ¹	Recovery Prompt ²	Description
BIOS	loader>	No bootable device	The BIOS begins the power-on self test, memory test, and other operating system applications. While the test is in progress, press Ctrl-C to enter the BIOS configuration utility and use the netboot option.
Boot loader	Starting kickstart	loader>	The boot loader uncompresses loaded software to boot an image using its file name as reference. These images are made available through bootflash. When the memory test is over, press Esc to enter the boot loader prompt.

Table 6-2 Recovery Interruption (continued)

Phase	Normal Prompt ¹	Recovery Prompt ²	Description
Kickstart	Uncompressing system	switch(boot) #	When the boot loader phase is over, press Ctrl-J ³ (Control key plus right bracket key) to enter the switch(boot) # prompt. If the corruption causes the console to stop at this prompt, copy the system image and reboot the switch.
System	Login:	—	The system image loads the configuration file of the last saved running configuration and returns a switch login prompt.

1. This prompt or message appears at the end of each phase.
2. This prompt or message appears when the switch cannot progress to the next phase.
3. Depending on your Telnet client, these keys may be reserved and you need to remap the keystroke. Refer to the documentation provided by your Telnet client.

Figure 6-3 Regular and Recovery Sequence


79950

Recovery Using BIOS Setup

To recover a corrupted bootflash image (no bootable device found message) for a switch with a single supervisor module, follow these steps:

-
- Step 1** Connect to the console port of the required switch.
 - Step 2** Boot or reboot the switch.
 - Step 3** Press **Ctrl-C** to interrupt the BIOS setup during the BIOS memory test.

You see the netboot BIOS Setup Utility screen (see [Figure 6-4](#)).

Figure 6-4 BIOS Setup Utility**Note**

Your navigating options are provided at the bottom of the screen.

Tab = Jump to next field

Ctrl-E = Down arrow


Ctrl-X = Up arrow

Ctrl-H = Erase (Backspace might not work if your terminal is not configured properly.)

Step 4 Press the **Tab** key to select the Basic CMOS Configuration, and press **Enter**.

You see the BIOS Setup CMOS Configuration screen (see [Figure 6-5](#)).

Figure 6-5 BIOS Setup Configuration (CMOS)



85639

Step 5 Change the Boot 1st: field to **TFTP**.

Step 6 Press the **Tab** key until you reach the Local IP Address field.

Step 7 Enter the local IP address for the switch, and press the **Tab** key.

Step 8 Enter the subnet mask for the IP address, and press the **Tab** key.

Step 9 Enter the IP address of the default gateway, and press the **Tab** key.

Step 10 Enter the IP address of the TFTP server, and press the **Tab** key.

Step 11 Enter the image name (kickstart), and press the **Tab** key. This path should be relative to the TFTP server root directory.


Caution

The file name must be entered exactly as it is displayed on your TFTP server. For example, if you have a file name **MDS9500-kickstart_mzg.10**, then enter this name using the exact uppercase characters and file extensions as shown on your TFTP server.

■ Recovering a Corrupted Bootflash

You see the configured changes (see Figure 6-6).

Figure 6-6 BIOS Setup Configuration (CMOS) Changes



85640

Step 12 Press the **Esc** key to return to the main menu.

Step 13 Choose **Write to CMOS and Exit** from the main screen to save your changes.



Note These changes are saved in the CMOS.



Caution The switch must have IP connectivity to reboot using the newly configured values.

You see the following prompt:

```
switch(boot) #
```

Step 14 Enter the **init system** command at the `switch(boot)` prompt, and press **Enter**.

```
switch(boot) # init system
```

The `switch(boot) #` prompt indicates that you have a usable kickstart image.



Note The **init system** command also installs a new loader from the existing (running) kickstart image.

Step 15 Follow the procedure specified in the “Recovery from the `switch(boot) #` Prompt” section on page 6-30.

Recovery from the loader> Prompt

To recover a corrupted kickstart image (system error state) for a switch with a single supervisor module, follow these steps:

-
- Step 1** Press the **Esc** key to interrupt the boot loader setup after the BIOS memory test.



- Note** Press **Esc** immediately after you see the following message:

```
00000589K Low Memory Passed
00000000K Ext Memory Passed
Hit ^C if you want to run SETUP....
Wait.....
```

If you wait too long, you will skip the boot loader phase and enter the kickstart phase.

You see the `loader>` prompt.



- Caution** The `loader>` prompt is different from the regular `switch#` or `switch(boot)#` prompt. The CLI command completion feature does not work at this prompt and may result in undesired errors. You must type the command exactly as you want the command to appear.
-



- Tip** Use the **help** command at the `loader>` prompt to display a list of commands available at this prompt or to obtain more information about a specific command in that list.
-

- Step 2** Enter the local IP address and the subnet mask for the switch, and press **Enter**.

```
loader> ip address 172.16.1.2 255.255.255.0
Found Intel EtherExpressPro100 82559ER at 0xe800, ROM address 0xc000
Probing...[Intel EtherExpressPro100 82559ER]Ethernet addr: 00:05:30:00:52:27
Address: 172.16.1.2
Netmask: 255.255.255.0
Server: 0.0.0.0
Gateway: 0.0.0.0
```

- Step 3** Enter the IP address of the default gateway, and press **Enter**.

```
loader> ip default-gateway 172.16.1.1
Address: 172.16.1.2
Netmask: 255.255.255.0
Server: 0.0.0.0
Gateway: 172.16.1.1
```

- Step 4** Boot the kickstart image file from the required server, and press **Enter**.

```
loader> boot tftp://172.16.1.2/kickstart-latest
Address: 172.16.1.2
Netmask: 255.255.255.0
Server: 172.16.10.100
Gateway: 172.16.1.1
Booting: /kick-282 console=ttyS0,9600n8nn quiet loader_ver= "1.0(2)".....
.....Image verification OK
Starting kernel...
INIT: version 2.78 booting
Checking all filesystems..... done.
Loading system software
```

■ Recovering a Corrupted Bootflash

```

INIT: Sending processes the TERM signal
Sending all processes the TERM signal... done.
Sending all processes the KILL signal... done.
Entering single-user mode...
INIT: Going single user
INIT: Sending processes the TERM signal
switch(boot)#

```

The switch(boot) # prompt indicates that you have a usable Kickstart image.

- Step 5** Copy the system and kickstart images again.

```

switch(boot) # copy scp://user@172.16.10.100/system-img bootflash:system-img
Trying to connect to tftp server.....
switch(boot) # copy scp://user@172.16.10.100/kickstart-img bootflash:kickstart-img
Trying to connect to tftp server.....

```

- Step 6** Follow the procedure specified in the “Recovery from the switch(boot)# Prompt” section on page 6-30.
-

Recovery from the switch(boot)# Prompt

To recover a system image using the kickstart image for a switch with a single supervisor module, follow these steps:

- Step 1** Follow this step if you issued an **init system** command. Otherwise, skip to [Step 2](#).

- Change to configuration mode and configure the IP address of the switch’s mgmt0 interface.

```

switch(boot) # config t
switch(boot) (config) # interface mgmt0

```

- Enter the local IP address and the subnet mask for the switch, and press **Enter**.

```
switch(boot) (config-mgmt0) # ip address 172.16.1.2 255.255.255.0
```

- Step 2** Issue the **no shut** command to enable the interface on the switch, and press **Enter**.

```
switch(boot) (config-mgmt0) # no shut
```

- Step 3** Follow this step if you issued an **init system** command. Otherwise, skip to [Step 4](#).

- Enter the IP address of the default gateway, and press **Enter**.

```
switch(boot) (config-mgmt0) # ip default-gateway 172.16.1.1
```

- Step 4** Exit to EXEC mode.

```
switch(boot) (config-mgmt0) # end
```

- Step 5** Copy the system image from the required TFTP server, and press **Enter**.

```
switch(boot) # copy scp://user@172.16.10.100/system-img bootflash:system-img
```

- Step 6** Copy the kickstart image from the required TFTP server, and press **Enter**.

```
switch(boot) # copy scp://user@172.16.10.100/kickstart-img bootflash:kickstart-img
```

- Step 7** Verify that the system and kickstart image files are copied to your bootflash: directory.

```
switch(boot) # dir bootflash:  
40295206 Aug 05 15:23:51 1980 ilc1.bin  
12456448 Jul 30 23:05:28 1980 kickstart-image1  
12288 Jun 23 14:58:44 1980 lost+found/  
27602159 Jul 30 23:05:16 1980 system-image1  
12447232 Aug 05 15:08:30 1980 kickstart-image2  
28364853 Aug 05 15:11:57 1980 system-image2  
  
Usage for bootflash://sup-local  
135404544 bytes used  
49155072 bytes free  
184559616 bytes total
```

- Step 8** Load the system image from the bootflash: directory.

```
switch(boot) # load bootflash:system-image  
Uncompressing system image: bootflash:/system-image  
CCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCC  
  
Would you like to enter the initial configuration mode? (yes/no): yes
```

See the “Initial Setup Routine” section on page 4-2.



- Note** If you enter **no** at this point, you will return to the switch# login prompt, and you must manually configure the switch.

Recovery for Switches with Dual Supervisor Modules

If one supervisor module is functioning and the other is not, boot the functioning supervisor module. Then use the booted supervisor module to bring up the supervisor module that is stuck. At the switch prompt, issue the **reload module slot force-dnld** command, where *slot* is the slot number of the stuck supervisor module.

If both supervisor modules are not functioning, treat it like a single supervisor module recovery. First recover the image on one supervisor module and then follow the single supervisor recovery process.



- Note** If you do not issue the **reload module** command when a boot failure has occurred, the active supervisor module automatically reloads the standby supervisor module within 3 to 6 minutes after the failure (see the “Standby Supervisor Boot Alert” section on page 6-22).

Recognizing Error States

If you see the error messages displayed in [Figure 6-7](#) or [Figure 6-8](#), follow the procedure specified in the “Recovery Using BIOS Setup” section on page 6-25.

Figure 6-7 Error State if Powered On and Ctrl-C Is Entered

```
+-----+
| System BIOS Configuration, (C) 2002 General Software, Inc. |
+-----+
| System CPU      : Pentium III    | Low Memory       : 630KB
| Coprocessor    : Enabled        | Extended Memory : 957MB
| Embedded BIOS Date : 09/10/02   | ROM Shadowing   : Enabled
+-----+
Boot network name is EOBC
Local IP address: 127.1.2.1

Bind to network device '/DEV/TCP/IP/EOBC/BootNet'
SoBindNetName: KeOpenFile failed,
Cannot bind to the network '/DEV/TCP/IP/EOBC/BootNet'
Could not get BOOTP response from the server.
BOOTNET: Dispatch duration could not be restored, reason=1.
Network boot failed, status=317.

No bootable device available.
R - REBOOT
S - SETUP
ESC - BIOS DEBUGGER
```

85642

Figure 6-8 Error State if Powered On and Esc Is Pressed

```
+-----+
| System BIOS Configuration, (C) 2002 General Software, Inc. |
+-----+
| System CPU      : Pentium III    | Low Memory       : 630KB
| Coprocessor    : Enabled        | Extended Memory : 1021MB
| Embedded BIOS Date : 11/13/02   | ROM Shadowing   : Enabled
+-----+
Loader Loading stage1.5.

Loader loading, please wait...
Cannot mount partition (ffff) - Error 17
|
```

85641

Default Settings

Table 6-3 lists the default image settings for all Cisco MDS 9000 Family switches.

Table 6-3 Default Image Settings

Parameters	Default
Kickstart image	No image is specified.
System image	No image is specified.

■ Default Settings