



CHAPTER 7

Configuring Queuing and Scheduling

This chapter describes how to configure the QoS queuing and scheduling features on the device.

This chapter includes the following sections:

- [Information About Queuing and Scheduling, page 7-1](#)
- [Licensing Requirements for Queuing and Scheduling, page 7-3](#)
- [Prerequisites for Queuing and Scheduling, page 7-3](#)
- [Guidelines and Limitations, page 7-4](#)
- [Configuring Queuing and Scheduling, page 7-4](#)
- [Verifying Queuing and Scheduling Configuration, page 7-22](#)
- [Example Configurations, page 7-22](#)

Information About Queuing and Scheduling

Traffic queuing is the ordering of packets and applies to both input and output of data. Device modules can support multiple queues, which you can use to control the sequencing of packets in different traffic classes. You can also set weighted random early detection (WRED) and taildrop thresholds. The device drops packets only when the configured thresholds are exceeded.

Traffic scheduling is the methodical output of packets at a desired frequency to accomplish a consistent flow of traffic. You can apply traffic scheduling to different traffic classes to weight the traffic by priority.

The queuing and scheduling processes allow you to control the bandwidth that is allocated to the traffic classes, so that you achieve the desired trade-off between throughput and latency for your network.

[Table 7-1](#) describes the system-defined queues that you can use to perform queuing and scheduling.

Table 7-1 System-Defined Queue Types

Queue Type	Direction	Description
2q4t	Input	2 queues with 4 WRED or tail drop thresholds per queue
1p3q4t	Output	1 strict priority plus 3 normal queues or 4 normal queues with 4 WRED or tail-drop thresholds per queue

[Send document comments to nexus7k-docfeedback@cisco.com.](mailto:nexus7k-docfeedback@cisco.com)

Table 7-1 System-Defined Queue Types (continued)

Queue Type	Direction	Description
8q2t	Input	8 queues with 2 tail drop thresholds per queue
1p7q4t	Output	1 strict priority queue plus 7 normal queues or 8 normal queues with 4 WRED or tail drop thresholds per queue

The queues match on the Class of Service (CoS) field. The device ensures that every CoS value from 0 to 7 maps to a queue for each queue type. Only one queue for a queue type can be assigned a specific CoS value. For more information about the system-defined queues, see [Table 2-3](#).

This section includes the following topics:

- [Setting Ingress Port CoS, page 7-2](#)
- [Modifying Class Maps, page 7-2](#)
- [Congestion Avoidance, page 7-2](#)
- [Congestion Management, page 7-3](#)
- [Virtualization Support, page 7-3](#)

Setting Ingress Port CoS

You can set the CoS field in all ingress packets for untrusted ports. By default, ports are trusted and the CoS field is not modified. (Use this method to configure the port state to trusted or untrusted.)

For information about configuring ingress port CoS, see the [“Configuring Ingress Port CoS” section on page 7-5](#).

Modifying Class Maps

You can modify the CoS values that are matched by system-defined queuing class maps, which modifies the CoS-to-queue mapping. [Table 2-3 on page 2-7](#) lists the default system-defined CoS values. Each CoS value appears only once in the queues of the same type.



Note

When you modify a system-defined class queuing map, the changes occur immediately and may disrupt traffic on all VDCs.

For information about configuring class maps, see the [“Modifying Queuing Class Maps” section on page 7-6](#).

Congestion Avoidance

You can use the following methods to proactively avoid traffic congestion on the device:

- Apply WRED to a class of traffic, which allows the device to drop packets based on the CoS field. WRED is designed to work with TCP traffic.
- Apply tail drop to a class of traffic, which allows the device to drop packets based on the Class of Service (CoS) field.

[Send document comments to nexus7k-docfeedback@cisco.com.](mailto:nexus7k-docfeedback@cisco.com)

For information about configuring congestion avoidance, see the “[Configuring Congestion Avoidance](#)” section on page 7-8.

Congestion Management

For ingress packets, you can configure congestion management by specifying a bandwidth that allocates a minimum data rate to a queue.

For egress packets, you can choose one of the following congestion management methods:

- Specify a bandwidth that allocates a minimum data rate to a queue.
- Impose a maximum data rate on a class of traffic so that excess packets are retained in a queue to shape the output rate.
- Allocate all data for a class of traffic to a priority queue. The device distributes the remaining bandwidth among the other queues.

For information about configuring congestion management, see the “[Configuring Congestion Management](#)” section on page 7-13.

Virtualization Support

A virtual device context (VDC) is a logical representation of a set of system resources. Other than configuring class maps, queuing and scheduling apply only to the VDC where the commands are entered. For information about configuring class maps, see the “[Modifying Queuing Class Maps](#)” section on page 7-6.

For information about configuring VDCs, see the *Cisco NX-OS Virtual Device Context Configuration Guide*.

Licensing Requirements for Queuing and Scheduling

The following table shows the licensing requirements for this feature:

Product	License Requirement
NX-OS	QoS requires no license. Any feature not included in a license package is bundled with the Cisco NX-OS system images and is provided at no extra charge to you. For a complete explanation of the NX-OS licensing scheme, see the <i>Cisco Nexus 7000 Series NX-OS Licensing Guide, Release 4.0</i> .

However, using VDCs requires an Advanced Services license.

Prerequisites for Queuing and Scheduling

Queuing and scheduling have the following prerequisites:

- You must be familiar with [Chapter 2, “Using Modular QoS CLI.”](#)
- You are logged on to the switch.

Send document comments to nexus7k-docfeedback@cisco.com.

- You are in the correct virtual device context (VDC). A VDC is a logical representation of a set of system resources. You can use the **switchto vdc** command with a VDC number.

Guidelines and Limitations

Use the following guidelines to configure queuing and scheduling:

- Configure system-defined class maps with care as the changes occur immediately and traffic may be disrupted on all VDCs.
- When you are working with 10-Gigabit Ethernet ports in shared mode, the egress queuing policy applies to all the ports in the port group. With 10-Gigabit Ethernet ports in shard mode, all the ports in the port group must be in the same VDC. See the *Cisco NX-OS Interfaces Configuration Guide* for information on shared and dedicated mode, as well as the *Cisco Nexus 7000 Series Hardware Installation and Reference Guide* for information about the port groups.
- You cannot set either the queue limit or WRED on ingress 10-Gigabit Ethernet ports.

Configuring Queuing and Scheduling

You configure queuing and scheduling by creating policy maps of type queuing that you apply to either traffic direction of an interface. You can modify system-defined class maps, which are used in policy maps to define classes of traffic to which you want to apply policies. For information about configuring policy maps and class maps, see [Chapter 2, “Using Modular QoS CLI.”](#)

You can configure the congestion-avoidance features (which include tail drop and WRED) in any queue. You can configure one of the egress congestion management features (which include priority, shaping, and bandwidth) in output queues, and bandwidth in input queues.

We recommend that you modify the CoS value *before* you create a policy map. You can modify the CoS values that are matched by device-defined class map queues. You must assign each CoS value from 0 to 7 to one or more of the queues for each queue type. Each CoS value can be used only once in each queue type.

The system-defined policy maps default-in-policy and default-out-policy are attached to all ports to which you do not apply a queuing policy map. The default policy maps cannot be configured. For more information about the default policy maps, see [Table 2-5](#).

In Cisco NX-OS 4.0(3) and later releases, the WRR for the default-in-policy changed from 50/50 to 80/20.

If you downgrade from Release 4.0(3) to Release 4.0(2) and enter the **show running-configuration** command, the input default queuing policy has an unknown enum in the display, as follows:

```
switch# show running-config
version 4.0(2)
...
...
policy-map type queuing default-in-policy
class type queuing unknown enum 0
queue-limit percent 50
bandwidth percent 80
class type queuing unknown enum 0
queue-limit percent 50
bandwidth percent 20
```

Send document comments to nexus7k-docfeedback@cisco.com.

If you copy and paste this configuration into any NX-OS software release, the device sends errors while executing all the commands starting from the **policy-map type queuing default-in-policy** command. These errors are harmless and will not affect the running of the device.

This section includes the following topics:

- [Configuring Ingress Port CoS, page 7-5](#)
- [Modifying Queuing Class Maps, page 7-6](#)
- [Configuring Congestion Avoidance, page 7-8](#)
- [Configuring Congestion Management, page 7-13](#)
- [Configuring Queue Limits, page 7-20](#)

Configuring Ingress Port CoS

To make a port untrusted, set the CoS value to a static value.



Note

By default, ports are trusted (trust CoS) and the CoS field is not modified. When you configure the ingress port CoS value, the port becomes untrusted.

You use the ingress default queues from the system-defined queue classes for the type of module to which you want to apply the policy map. See [Table 2-3 on page 2-7](#) for the list of system-defined class maps for each type of module.

The CoS values set using this procedure apply to all packets ingressing the specified interfaces, not just to the class-default packets. If you set the CoS value, the device modifies the value before ingress queuing and scheduling so the CoS-modified packets are classified differently.



Note

If you want to change the system-defined queuing class-maps, you must either modify the configured queuing policies or create new queuing policies and attach these to the affected interfaces. If you do not do this, you can render the default queuing or the configured queuing policies invalid, which may affect interfaces in multiple VDCs.

SUMMARY STEPS

1. **config t**
2. **policy-map type queuing [match-first] *policy-map-name***
3. **class type queuing *class-queuing-name***
4. **set cos *value***
5. **exit**
6. **show policy-map type queuing *policy-map-name***
7. **copy running-config startup-config**

Send document comments to nexus7k-docfeedback@cisco.com.

DETAILED STEPS

	Command	Purpose
Step 1	config t Example: switch# config t switch(config)#	Enters configuration mode.
Step 2	policy-map type queuing [match-first] <i>policy-map-name</i> Example: switch(config)# policy-map type queuing untrusted_port_cos switch(config-pmap-que)#	Configures the policy map of type queuing, and then enters policy-map mode for the policy-map name that you specify. Policy-map names can contain alphabetic, hyphen, or underscore characters, are case sensitive, and can be up to 40 characters.
Step 3	class type queuing <i>class-queuing-name</i> Example: switch(config)# class type queuing 2q4t-in-q-default switch(config-pmap-c-que)#	Configures the class map of type queuing, and then enters policy-map class queuing mode. Class queuing names are listed in Table 2-3 . Note To configure port CoS, you can use only an ingress default system-defined queue type.
Step 4	set cos <i>value</i> Example: switch(config-pmap-c-que)# set cos 5	Sets the CoS field in all ingress packet to the value specified. The range is from 0 to 7.
Step 5	exit Example: switch(config-cmap-que)# exit switch(config)#	Exits policy-map queue mode, and enters configuration mode.
Step 6	show policy-map type queuing <i>policy-map-name</i> Example: switch(config)# show policy-map type untrusted_port_cos	(Optional) Displays information about all configured policy maps or a selected policy map of type queuing.
Step 7	copy running-config startup-config Example: switch(config)# copy running-config startup-config	(Optional) Saves the running configuration to the startup configuration.

Modifying Queuing Class Maps

You can modify the CoS values that are matched by system-defined class maps. [Table 2-3 on page 2-7](#) lists the default system-defined CoS values.

The system-defined class maps can only be changed from the default VDC. Changes occur immediately and are applied to all ports on all VDCs that use the modified class map.



Note

When you modify a system-defined class map, the changes occur immediately and may disrupt traffic on all VDCs that use the modified class map.

Send document comments to nexus7k-docfeedback@cisco.com.

The device automatically modifies the CoS values that you configured in other queues so that each CoS value appears only once in the queues of the same type.



Note

If you want to change the system-defined queuing class-maps, you must either modify the configured queuing policies or create new queuing policies and attach these to the affected interfaces. If you do not do this, you can render the default queuing or the configured queuing policies invalid, which may affect interfaces in multiple VDCs.

BEFORE YOU BEGIN

Ensure you are in the default VDC for the device.

SUMMARY STEPS

1. **config t**
2. **class-map type queuing match-any *class-queuing-name***
3. **match cos *value-range***
4. Repeat Steps 2 and 3 to modify CoS values for additional queues
5. **exit**
6. **show class-map type queuing [*class-queuing-name*]**
7. **copy running-config startup-config**

DETAILED STEPS

	Command	Purpose
Step 1	config t Example: switch# config t switch(config)#	Enters configuration mode.
Step 2	class-map type queuing match-any <i>class-queuing-name</i> Example: switch(config)# class-map type queuing match-any 1p3q4t-out-pql switch(config-cmap-que)#	Configures the class map of type queuing, and then enters class-map queuing mode. Class queuing names are listed in Table 2-3 .
Step 3	match cos <i>value-range</i> Example: switch(config-cmap-que)# match 0-3,7	Sets the CoS value range matched by this queue. You can specify a range of values by using a hyphen between the beginning and ending values and a comma between values. The range is from 0 to 7.

Send document comments to nexus7k-docfeedback@cisco.com.

	Command	Purpose
Step 4	Repeat Steps 2 and 3 to modify CoS values for additional queues.	—
Step 5	exit Example: switch(config-cmap-que)# exit switch(config)#	Exits class-map queue mode and enters configuration mode.
Step 6	show class-map type queuing [<i>class-queuing-name</i>] Example: switch(config)# show class-map type queuing	(Optional) Displays information about all configured class maps or a selected class map of type queuing. Class queuing names are listed in Table 2-3 .
Step 7	copy running-config startup-config Example: switch(config)# copy running-config startup-config	(Optional) Saves the running configuration to the startup configuration.

Configuring Congestion Avoidance

You can configure congestion avoidance with tail drop or WRED features. Both features can be used in ingress and egress policy maps.



Note

WRED and tail drop cannot be configured in the same class.

This section includes the following topics:

- [Configuring Tail Drop, page 7-8](#)
- [Configuring WRED, page 7-10](#)

Configuring Tail Drop

You can configure tail drop on both ingress and egress queues by setting thresholds by CoS values. The device will drop packets that exceed the thresholds. You can specify a threshold based on queue size or buffer memory used by the queue.



Note

You cannot configure the queue size on ingress 10-Gigabit Ethernet ports.

You use the system-defined queue classes for the type of module to which you want to apply the policy map. See [Table 2-3 on page 2-7](#).



Note

WRED and tail drop cannot be configured in the same class.

SUMMARY STEPS

1. **config t**

Send document comments to nexus7k-docfeedback@cisco.com.

2. **policy-map type queuing** [**match-first**] *policy-map-name*
3. **class type queuing** *class-queuing-name*
4. **queue-limit cos value** {*threshold* [**packets** | **bytes** | **kbytes** | **mbytes** | **ms** | **us**] | **percent percent_of_queuelimit**}
5. Repeat Step 4 to assign tail drop thresholds for other CoS values.
6. Repeat Steps 3 through 5 to assign tail drop thresholds for other queue classes.
7. **exit**
8. **show policy-map type queuing** *policy-map-name*
9. **copy running-config startup-config**

DETAILED STEPS

	Command	Purpose
Step 1	config t Example: switch# config t switch(config)#	Enters configuration mode.
Step 2	policy-map type queuing [match-first] <i>policy-map-name</i> Example: switch(config)# policy-map type queuing shape_queues switch(config-pmap-que)#	Configures the policy map of type queuing, and then enters policy-map mode for the policy-map name you specify. Policy-map names can contain alphabetic, hyphen, or underscore characters, are case sensitive, and can be up to 40 characters.
Step 3	class type queuing <i>class-queuing-name</i> Example: switch(config)# class type queuing 1p3q4t-out-pq1 switch(config-pmap-c-que)#	Configures the class map of type queuing, and then enters policy-map class queuing mode. Class queuing names are listed in Table 2-3 .
Step 4	queue-limit cos value { <i>threshold</i> [packets bytes kbytes mbytes ms us] percent percent_of_queuelimit }	Assigns a tail drop threshold based on queue size or percentage of the buffer memory used by the queue. The device will drop packets that exceed the specified threshold. You can configure the threshold by the number of packets, number of bytes, or the duration of time at the underlying interface minimum guaranteed link rate. The default threshold is in packets. The size is from 1 to 83886080. The duration is from 1 to 83886080. The percentage is from 1 to 100.
Step 5	(Optional) Repeat Step 4 to assign tail drop thresholds for other CoS values.	—

Send document comments to nexus7k-docfeedback@cisco.com.

	Command	Purpose
Step 6	(Optional) Repeat Steps 3 through 5 to assign tail drop thresholds for other queue classes.	—
Step 7	exit Example: switch(config-cmap-que)# exit switch(config)#	Exits policy-map queue mode and enters configuration mode.
Step 8	show policy-map type queuing <i>policy-map-name</i> Example: switch(config)# show policy-map type queuing shape_queues	(Optional) Displays information about all configured policy maps or a selected policy map of type queuing.
Step 9	copy running-config startup-config Example: switch(config)# copy running-config startup-config	(Optional) Saves the running configuration to the startup configuration.

Configuring WRED

Before configuring WRED, ensure that the CoS values are there (see the “[Modifying Queuing Class Maps](#)” section on page 7-6).

You can configure WRED on both ingress and egress queues to set minimum and maximum packet drop thresholds. The frequency of dropped packets increases as the queue size exceeds the minimum threshold. When the maximum threshold is exceeded, all packets for the CoS value are dropped.



Note

You cannot configure WRED on ingress 10-Gigabit Ethernet ports.

You can configure WRED thresholds by CoS value, and configure a single WRED threshold to use on all CoS values that you do not specifically configure.



Note

WRED and tail drop cannot be configured in the same class.

You use the system-defined queue classes for the type of module to which you want to apply the policy map. See [Table 2-3 on page 2-7](#).

SUMMARY STEPS

1. **config t**
2. **policy-map type queuing** [**match-first**] *policy-map-name*
3. **class type queuing** *class-queuing-name*
4. **random-detect cos-based** [**aggregate** [**minimum-threshold**] {*min-threshold* [**packets** | **bytes** | **kbytes** | **mbytes** | **ms** | **us**] | **percent** *min-percent-of-qsize*} [**maximum-threshold**] {*max-threshold* [**packets** | **bytes** | **kbytes** | **mbytes** | **ms** | **us**] | **percent** *max-percent-of-qsize*}]
5. **random-detect** {**cos** *cos-list* [**minimum-threshold**] {*min-threshold* [**packets** | **bytes** | **kbytes** | **mbytes** | **ms** | **us**] | **percent** *min-percent-of-qsize*} [**maximum-threshold**] {*max-threshold* [**packets** | **bytes** | **kbytes** | **mbytes** | **ms** | **us**] | **percent** *max-percent-of-qsize*}}

Send document comments to nexus7k-docfeedback@cisco.com.

6. Repeat Step 5 to configure WRED for other CoS values.
7. Repeat Steps 3 through 6 to configure WRED for other queuing classes.
8. **exit**
9. **show policy-map type queuing *policy-map-name***
10. **copy running-config startup-config**

Send document comments to nexus7k-docfeedback@cisco.com.

DETAILED STEPS

	Command	Purpose
Step 1	<pre>config t</pre> <p>Example: <pre>switch# config t switch(config)#</pre></p>	Enters configuration mode.
Step 2	<pre>policy-map type queuing [match-first] policy-map-name</pre> <p>Example: <pre>switch(config)# policy-map type queuing shape_queues switch(config-pmap-que)#</pre></p>	Configures the policy map of type queuing, and then enters policy-map mode for the policy-map name you specify. Policy-map names can contain alphabetic, hyphen, or underscore characters, are case sensitive, and can be up to 40 characters.
Step 3	<pre>class type queuing class-queuing-name</pre> <p>Example: <pre>switch(config)# class type queuing lp3q4t-out-pql switch(config-pmap-c-que)#</pre></p>	Configures the class map of type queuing, and then enters policy-map class queuing mode. Class queuing names are listed in Table 2-3 .
Step 4	<pre>random-detect cos-based [aggregate [minimum-threshold] {min-threshold [packets bytes kbytes mbytes ms us] percent min-percent-of-qsize} [maximum-threshold] {max-threshold [packets bytes kbytes mbytes ms us] percent max-percent-of-qsize}]</pre> <p>Example 1: <pre>switch(config-pmap-c-que)# random-detect cos-based aggregate 10 mbytes 20 mbytes</pre></p> <p>Example 2: <pre>switch(config-pmap-c-que)# random-detect cos-based aggregate percent 10 percent 20</pre></p>	<p>Configures WRED for all CoS values not configured by a CoS-specific random-detect command. You can specify minimum and maximum thresholds used to drop packets from the queue. You can configure thresholds by the number of packets, number of bytes, the duration of time at the underlying interface minimum guaranteed link rate, or as the percentage of queue size. Minimum and maximum thresholds must be of the same type. If no aggregate arguments are supplied, then no aggregate WRED is configured. The default threshold is in packets. The thresholds are from 1 to 83886080. The percentage is from 1 to 100.</p> <p>Note You must enter this command, even if you enter the command with no values.</p> <p>Example 1 shows how to set the aggregate WRED thresholds for nonconfigured classes of traffic to a minimum of 10 MB and a maximum of 20 MB.</p> <p>Example 2 shows how to set the aggregate WRED thresholds for nonconfigured classes of traffic to a minimum of 10 percent and a maximum of 20 percent of the queue size.</p> <p>Note You can specify only one random-detect cos-based command in a class.</p>

Send document comments to nexus7k-docfeedback@cisco.com.

	Command	Purpose
Step 5	<pre>random-detect {cos cos-list [aggregate [minimum-threshold] {min-threshold [packets bytes kbytes mbytes ms us] percent min-percent-of-qsize} [maximum-threshold] {max-threshold [packets bytes kbytes mbytes ms us] percent max-percent-of-qsize}}</pre> <p>Example 1: switch(config-pmap-c-que)# random-detect cos 5,7 15 mbytes 20 mbytes</p> <p>Example 2: switch(config-pmap-c-que)# random-detect cos 5 percent 5 percent 15</p>	<p>(Optional) Configures WRED for specific CoS values. You can specify minimum and maximum thresholds used to drop packets from the queue. You can configure thresholds by the number of packets, number of bytes, the duration of time at the underlying interface minimum guaranteed link rate, or as the percentage of the queue size. Minimum and maximum thresholds must be of the same type. The default threshold is in packets. Thresholds are from 1 to 83886080. Percentage is from 1 to 100.</p> <p>Example 1 shows how to set the aggregate WRED thresholds for CoS values 5 and 7 to a minimum of 15 MB and a maximum of 20 MB.</p> <p>Example 2 shows how to set the aggregate WRED thresholds for CoS value 5 to a minimum of 5 percent and a maximum of 15 percent of the queue size.</p>
Step 6	(Optional) Repeat Step 5 to configure WRED for other CoS values.	—
Step 7	(Optional) Repeat Steps 3 through 6 to configure WRED for other queuing classes.	—
Step 8	<pre>exit</pre> <p>Example: switch(config-cmap-que)# exit switch(config)#</p>	Exits policy-map queue mode and enters configuration mode.
Step 9	<pre>show policy-map type queuing policy-map-name</pre> <p>Example: switch(config)# show policy-map type queuing shape_queues</p>	(Optional) Displays information about all configured policy maps or a selected policy map of type queuing.
Step 10	<pre>copy running-config startup-config</pre> <p>Example: switch(config)# copy running-config startup-config</p>	(Optional) Saves the running configuration to the startup configuration.

Configuring Congestion Management

You can configure only one of the following congestion management methods in a policy map:

- Allocate a minimum data rate to a queue by using the **bandwidth** and **bandwidth remaining** commands.
- Allocate all data for a class of traffic to a priority queue by using the **priority** command. You can use the **bandwidth remaining** command to distribute remaining traffic among the nonpriority queues. By default, the system evenly distributes the remaining bandwidth among the nonpriority queues.
- Allocate a maximum data rate to a queue by using the **shape** command.

Send document comments to nexus7k-docfeedback@cisco.com.

In addition to the congestion management feature that you choose, you can configure one of the following queue features in each class of a policy map:

- Taildrop thresholds based on queue size and queue limit usage. For more information, see the “[Configuring Tail Drop](#)” section on page 7-8.
- WRED for preferential packet drops based on CoS. For more information, see the “[Configuring WRED](#)” section on page 7-10.

This section includes the following topics:

- [Configuring Bandwidth and Bandwidth Remaining](#), page 7-14
- [Configuring Priority](#), page 7-16
- [Configuring Shaping](#), page 7-18

Configuring Bandwidth and Bandwidth Remaining

You can configure the bandwidth and bandwidth remaining on both ingress and egress queues to allocate a minimum percentage of the interface bandwidth to a queue. You use the system-defined ingress or egress queue class for the type of module to which you want to apply the policy map. See [Table 2-3 on page 2-7](#) for the list of system-defined ingress or egress queue classes for each module.



Note

If you configure bandwidth, you cannot configure priority or shaping in the same policy map.

SUMMARY STEPS

1. **config t**
2. **policy-map type queuing [match-first] *policy-map-name***
3. **class type queuing *class-queuing-name***
4. **bandwidth {rate [bps | kbps | mbps | gbps] | percent *percent*}**
or
bandwidth remaining percent *percent*
5. Repeat Steps 3 to 4 to assign bandwidth or bandwidth remaining for other queuing classes.
6. **exit**
7. **show policy-map type queuing *policy-map-name***
8. **copy running-config startup-config**

Send document comments to nexus7k-docfeedback@cisco.com.

DETAILED STEPS

	Command	Purpose
Step 1	<pre>config t</pre> <p>Example: switch# config t switch(config)#</p>	Enters configuration mode.
Step 2	<pre>policy-map type queuing [match-first] policy-map-name</pre> <p>Example: switch(config)# policy-map type queuing shape_queues switch(config-pmap-que)#</p>	Configures the policy map of type queuing, and then enters policy-map mode for the policy-map name you specify. Policy-map names can contain alphabetic, hyphen, or underscore characters, are case sensitive, and can be up to 40 characters.
Step 3	<pre>class type queuing class-queuing-name</pre> <p>Example: switch(config)# class type queuing lp3q4t-out-pql switch(config-pmap-c-que)#</p>	Configures the class map of type queuing, and then enters policy-map class queuing mode. You must select one of the system-defined output queues. Class queuing names are listed in Table 2-3 .
Step 4	<pre>bandwidth {rate [bps kbps mbps gbps] percent percent}</pre> <p>Example 1: switch(config-pmap-c-que)# bandwidth 10 mbps</p> <p>Example 2: switch(config-pmap-c-que)# bandwidth percent 25</p>	<p>Assigns a minimum rate of the interface bandwidth to an output queue. You can configure a data rate by the bit rate or as the percentage of the underlying interface link rate. The default units are kbps. The data rate is from 1 to 10,000,000,000. The percentage is from 1 to 100.</p> <p>Note You can use only the percent keyword for interfaces set to autonegotiate.</p> <p>Example 1 shows how to set the bandwidth to a minimum rate of 100 megabits per second (mbps). Example 2 shows how to set the bandwidth to a minimum of 25 percent of the underlying link rate.</p>
	<pre>bandwidth remaining percent percent</pre> <p>Example: switch(config-pmap-c-que)# bandwidth remaining percent 25</p>	<p>(Optional) Assigns the percent of the bandwidth that remains to this queue. The range is from 0 to 100.</p> <p>The example shows how to set the bandwidth for this queue to 25 percent of the remaining bandwidth.</p>

Send document comments to nexus7k-docfeedback@cisco.com.

	Command	Purpose
Step 5	(Optional) Repeat Steps 3 to 4 to assign bandwidth or bandwidth remaining for other queuing classes.	—
Step 6	exit Example: switch(config-cmap-que)# exit switch(config)#	Exits policy-map queue mode and enters configuration mode.
Step 7	show policy-map type queuing <i>policy-map-name</i> Example: switch(config)# show policy-map type queuing shape_queues	(Optional) Displays information about all configured policy maps or a selected policy map of type queuing.
Step 8	copy running-config startup-config Example: switch(config)# copy running-config startup-config	(Optional) Saves the running configuration to the startup configuration.

Configuring Priority

If you don't specify the priority, the system-defined egress **pq** queues behave like normal queues. (See [Chapter 2, "Using Modular QoS CLI"](#) for information on the system-defined type queuing class maps.)

You can configure only one level of priority on an egress priority queue. You use the system-defined priority queue class for the type of module to which you want to apply the policy map. See [Table 2-3 on page 2-7](#) for the list of available system-defined, class maps for each module.

For the nonpriority queues, you can configure how much of the remaining bandwidth to assign to each queue. By default, the device evenly distributes the remaining bandwidth among the nonpriority queues.



Note

If you configure priority, you cannot configure bandwidth or shaping in the same policy map.

SUMMARY STEPS

1. **config t**
2. **policy-map type queuing** [**match-first**] *policy-map-name*
3. **class type queuing** *class-queuing-name*
4. **priority** [**level value**]
5. **class type queuing** *class-queuing-name*
6. **bandwidth remaining percent** *percent*
7. Repeat Steps 5 to 6 to assign bandwidth remaining for the other nonpriority queues.
8. **exit**
9. **show policy-map type queuing** *policy-map-name*
10. **copy running-config startup-config**

Send document comments to nexus7k-docfeedback@cisco.com.

DETAILED STEPS

	Command	Purpose
Step 1	config t Example: switch# config t switch(config)#	Enters configuration mode.
Step 2	policy-map type queuing [match-first] <i>policy-map-name</i> Example: switch(config)# policy-map type queuing priority_queue1 switch(config-pmap-que)#	Configures the policy map of type queuing, and then enters policy-map mode for the policy-map name that you specify. Policy-map names can contain alphabetic, hyphen, or underscore characters, are case sensitive, and can be up to 40 characters.
Step 3	class type queuing class-queuing-name Example: switch(config-pmap-que)# class type queuing lp3q4t-out-pq1 switch(config-pmap-c-que)#	Configures the class map of type queuing, and then enters policy-map class queuing mode. You must select one of the system-defined priority queues. Class queuing names are listed in Table 2-3 .
Step 4	priority [level value] Example: switch(config-pmap-c-que)# priority	Selects this queue as a priority queue. Only 1 priority level is supported.
Step 5	class type queuing class-queuing-name Example: switch(config-pmap-c-que)# class type queuing lp3q4t-out-q2	(Optional) Configures the class map of type queuing, and then enters policy-map class queuing mode. Class queuing names are listed in Table 2-3 . Choose a nonpriority queue where you want to configure the remaining bandwidth. By default, the system evenly distributes the remaining bandwidth among the nonpriority queues.
Step 6	bandwidth remaining percent percent Example: switch(config-pmap-c-que)# bandwidth remaining percent 25	(Optional) Assigns the percent of the bandwidth that remains to this queue. The range is from 1 to 100.

Send document comments to nexus7k-docfeedback@cisco.com.

	Command	Purpose
Step 7	(Optional) Repeat Steps 5 to 6 to assign the remaining bandwidth for the other nonpriority queues.	—
Step 8	exit Example: switch(config-cmap-que)# exit switch(config)#	Exits policy-map queue mode and enters configuration mode.
Step 9	show policy-map type queuing <i>policy-map-name</i> Example: switch(config)# show policy-map type queuing priority_queue1	(Optional) Displays information about all configured policy maps or a selected policy map of type queuing.
Step 10	copy running-config startup-config Example: switch(config)# copy running-config startup-config	(Optional) Saves the running configuration to the startup configuration.

Configuring Shaping



Note

The device forces the shape rate to the closest value in the following percentage intervals: 100, 50, 25, 12.5, 6.25, 3.13, or 1.07.

You can configure shaping on an egress queue to impose a maximum rate on it. You use the system-defined egress queue class for the type of module to which you want to apply the policy map. See [Table 2-3 on page 2-7](#) for the list of available system-defined class maps for each module.



Note

If you configure shaping, you cannot configure bandwidth or priority in the same policy map.

SUMMARY STEPS

1. **config t**
2. **policy-map type queuing [match-first] *policy-map-name***
3. **class type queuing *class-queuing-name***
4. **shape [average] {*rate* [bps | kbps | mbps | gbps] | percent *percent*}**
5. Repeat Steps 3 to 4 to configure shaping for other queuing classes.
6. **exit**
7. **show policy-map type queuing *policy-map-name***
8. **copy running-config startup-config**

Send document comments to nexus7k-docfeedback@cisco.com.

DETAILED STEPS

	Command	Purpose
Step 1	<code>config t</code> Example: switch# config t switch(config)#	Enters configuration mode.
Step 2	<code>policy-map type queuing [match-first] policy-map-name</code> Example: switch(config)# policy-map type queuing shape_queues switch(config-pmap-que)#	Configures the policy map of type queuing, and then enters policy-map mode for the policy-map name you specify. Policy-map names can contain alphabetic, hyphen, or underscore characters, are case sensitive, and can be up to 40 characters.
Step 3	<code>class type queuing class-queuing-name</code> Example: switch(config)# class type queuing lp3q4t-out-pql switch(config-pmap-c-que)#	Configures the class map of type queuing and then enters policy-map class queuing mode. You must select one of the system-defined output queues. Class queuing names are listed in Table 2-3 .
Step 4	<code>shape [average] {rate [bps kbps mbps gbps] percent percent}</code> Example 1: switch(config-pmap-c-que)# shape 10 mbps Example 2: switch(config-pmap-c-que)# shape percent 25	Assigns a maximum rate on an output queue. You can configure a data rate by the bit rate or as a percentage of the underlying interface link rate. The default bit rate is in bits per second (bps). The data rate is from 8000 bps to 10 gbps. The percentage is from 1 to 100. Note You can use only the percent keyword for interfaces set to autonegotiate. Example 1 shows how to shape traffic to a maximum rate of 100 megabits per second (mbps). Example 2 shows how to shape traffic to a maximum of 25 percent of the underlying link rate.
Step 5	(Optional) Repeat Steps 3 to 4 to configure shaping for other queuing classes.	—
Step 6	<code>exit</code> Example: switch(config-cmap-que)# exit switch(config)#	Exits policy-map queue mode and enters configuration mode.
Step 7	<code>show policy-map type queuing policy-map-name</code> Example: switch(config)# show policy-map type queuing shape_queues	(Optional) Displays information about all configured policy maps or a selected policy map of type queuing.
Step 8	<code>copy running-config startup-config</code> Example: switch(config)# copy running-config startup-config	(Optional) Saves the running configuration to the startup configuration.

Send document comments to nexus7k-docfeedback@cisco.com.

Configuring Queue Limits

You can configure the queue limit on both ingress and egress queues. The device drops any packets over the queue limit. You use the system-defined queue classes for the type of module to which you want to apply the policy map. See [Table 2-3 on page 2-7](#).

SUMMARY STEPS

1. **config t**
2. **policy-map type queuing [match-first] *policy-map-name***
3. **class type queuing *class-queuing-name***
4. **queue-limit {*threshold* [packets | bytes | kbytes | mbytes | ms | us] | percent *percent_of_queue-limit*}**
5. **exit**
6. **exit**
7. **show policy-map type queuing *policy-map-name***
8. **copy running-config startup-config**

Send document comments to nexus7k-docfeedback@cisco.com.

DETAILED STEPS

	Command	Purpose
Step 1	config t Example: switch# config t switch(config)#	Enters configuration mode.
Step 2	policy-map type queuing [match-first] <i>policy-map-name</i> Example: switch(config)# policy-map type queuing shape_queues switch(config-pmap-que)#	Configures the policy map of type queuing and then enters policy-map mode for the policy-map name you specify. Policy-map names can contain alphabetic, hyphen, or underscore characters, are case sensitive, and can be up to 40 characters.
Step 3	class type queuing class-queuing-name Example: switch(config)# class type queuing lp3q4t-out-pql switch(config-pmap-c-que)#	Configures the class map of type queuing and then enters policy-map class queuing mode. Class queuing names are listed in Table 2-3 .
Step 4	queue-limit {threshold [packets bytes kbytes mbytes ms us] percent percent_of_queue-limit} Example: switch(config-pmap-c-que)# queue-limit 10 mbytes	<p>Assigns a queue limit based on queue size or percentage of the buffer memory used by the queue. The device will drop packets that exceed the specified threshold. You can configure the threshold by the number of packets, number of bytes, or the duration of time at the underlying interface minimum guaranteed link rate. The default threshold is in packets. The size is from 1 to 83886080. The duration is from 1 to 83886080. The percentage is from 1 to 100.</p> <p>The example shows how to set a queue limit to a maximum size of 10 MB.</p>
Step 5	exit Example: switch(config-pmap-c-que)# exit switch(config-pmap-que)#	Exits class-map queue mode and enters policy-map queue mode.
Step 6	exit Example: switch(config-pmap-que)# exit switch(config)#	Exits policy-map queue mode and enters configuration mode.
Step 7	show policy-map type queuing <i>policy-map-name</i> Example: switch(config)# show policy-map type queuing shape_queues	(Optional) Displays information about all configured policy maps or a selected policy map of type queuing.
Step 8	copy running-config startup-config Example: switch(config)# copy running-config startup-config	(Optional) Saves the running configuration to the startup configuration.

Send document comments to nexus7k-docfeedback@cisco.com.

Verifying Queuing and Scheduling Configuration

To display the queuing and scheduling configuration information, perform one of the following tasks:

Command	Purpose
show class-map type queuing [<i>class-queuing-name</i>]	Displays information about all configured class maps or a selected class map of type queuing. Class queuing names are listed in Table 2-3 .
show policy-map type queuing <i>policy-map-name</i>	Displays information about all configured policy maps or a selected policy map of type queuing.

For detailed information about the fields in the output from these commands, see the *Cisco Nexus 7000 Series NX-OS Quality of Service Command Reference, Release 4.0*.

Example Configurations

In this section you can find examples of configuring queuing and scheduling.

This section includes the following topics:

- [Setting Ingress Port CoS Configuration Example, page 7-22](#)
- [Priority and Queue Limit Configuration Example, page 7-23](#)
- [Shaping and Tail Drop Configuration Example, page 7-23](#)
- [Bandwidth and WRED Configuration Example, page 7-23](#)

Setting Ingress Port CoS Configuration Example



Note

Setting the ingress port CoS value makes the specified interfaces untrusted.



Note

Ensure that you are using the default queue for the port type that you are configuring. See [Chapter 2, “Using Modular QoS CLI”](#) for information on the default queue for the port types.

The following example shows how to configure ingress port CoS for 1-Gigabit Ethernet ports:

```

config t
  policy-map type queuing untrusted_port_cos
    class type queuing 2q4t-in-q-default
      set cos 5
  interface ethernet 2/1
    service-policy type queuing input untrusted_port_cos

```

Send document comments to nexus7k-docfeedback@cisco.com.

The following example shows how to configure ingress port CoS for 10-Gigabit Ethernet ports:

```
config t
  policy-map type queuing untrusted_port_cos
    class type queuing 8q2t-in-q-default
      set cos 5
  interface ethernet 2/1
    service-policy type queuing input untrusted_port_cos
```

Priority and Queue Limit Configuration Example

The following example shows how to configure the priority and queue limit features:

```
config t
  class-map type queuing match-any 1p3q4t-out-pq1
    match cos 5-7
  class-map type queuing match-any 1p3q4t-out-q2
    match cos 3-4
  class-map type queuing match-any 1p3q4t-out-q3
    match cos 0-2
  policy-map type queuing priority_queue1
    class type queue 1p3q4t-out-pq1
      priority
    class type queue 1p3q4t-out-q2
      bandwidth remaining percent 60
      queue-limit 1 mbytes
    class type queue 1p3q4t-out-q3
      bandwidth remaining percent 40
      queue-limit 2 mbytes
```

Shaping and Tail Drop Configuration Example

The following example shows how to configure the shaping and taildrop features:

```
config t
  class-map type queuing match-any 1p3q4t-out-pq1
    match cos 5-7
  class-map type queuing match-any 1p3q4t-out-q2
    match cos 3-4
  policy-map type queuing shape_dt
    class type queue 1p3q4t-out-pq1
      shape percent 50
      queue-limit cos 5 percent 10
      queue-limit cos 6 percent 10
    class type queue 1p3q4t-out-q2
      shape percent 25
      queue-limit cos 4 percent 15
```



Note

If the priority keyword is not specified for a **pq1** queue, the queue is just a normal queue, not a priority queue.

Bandwidth and WRED Configuration Example

The following example shows how to configure the bandwidth and WRED features:

```
config t
  class-map type queuing match-any 1p3q4t-out-pq1
```

Send document comments to nexus7k-docfeedback@cisco.com.

```
match cos 5-7
class-map type queuing match-any lp3q4t-out-q2
  match cos 3-4
policy-map type queuing bandwidth_wred
  class type queuing lp3q4t-out-pq1
    bandwidth percent 50
    random-detect cos-based
    random-detect cos 5 minimum-threshold percent 10 maximum-threshold percent 30
    random-detect cos 6 minimum-threshold percent 40 maximum-threshold percent 60
  class type queuing lp3q4t-out-q2
    bandwidth percent 25
    random-detect cos-based
    random-detect cos 4 minimum-threshold percent 20 maximum-threshold percent 40
```