



## CHAPTER 18

# Configuring HSRP

---

This chapter describes how to configure the Hot Standby Router Protocol (*HSRP*).

This chapter includes the following sections:

- [Information About HSRP, page 18-1](#)
- [Licensing Requirements for HSRP, page 18-6](#)
- [Prerequisites for HSRP, page 18-6](#)
- [Guidelines and Limitations, page 18-6](#)
- [Configuring HSRP, page 18-7](#)
- [Verifying HSRP Configuration, page 18-15](#)
- [HSRP Example Configuration, page 18-16](#)
- [Default Settings, page 18-16](#)
- [Additional References, page 18-17](#)

## Information About HSRP

HSRP is a first-hop redundancy protocol (*FHRP*) that allows a transparent failover of the first-hop IP router. HSRP provides first-hop routing redundancy for IP hosts on Ethernet networks configured with a default gateway IP address. You use HSRP in a group of routers for selecting an active gateway and a standby gateway. In a group of gateways, the active gateway is the gateway that routes packets; the standby gateway is the gateway that takes over when the active gateway fails or when preset conditions are met.

Many host implementations do not support any dynamic router discovery mechanisms but can be configured with a default router. Running a dynamic router discovery mechanism on every host is not feasible for a number of reasons, including administrative overhead, processing overhead, and security issues. HSRP provides failover services to these hosts.

This section includes the following topics:

- [HSRP Overview, page 18-2](#)
- [HSRP Versions, page 18-3](#)
- [HSRP Authentication, page 18-3](#)
- [HSRP Addressing, page 18-4](#)
- [HSRP Messages, page 18-4](#)

***Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com).***

- [HSRP Load Sharing, page 18-4](#)
- [Object Tracking and HSRP, page 18-5](#)

## HSRP Overview

When you use HSRP, you configure the HSRP *virtual IP address* as the host's default gateway (instead of the IP address of the actual gateway). The virtual IP address is an IP address that is shared among a group of gateways that run HSRP.

When you configure HSRP on a network segment, you provide a *virtual MAC address* and a virtual IP address for the HSRP group. You configure the same virtual addresses on each HSRP-enabled interface in the group. You also configure a unique IP address and MAC address on each interface that act as the real addresses. HSRP selects one of these interfaces to be the *active router*. The active router receives and routes packets destined for the virtual MAC address of the group.

HSRP detects when the designated active router fails. At that point, a selected *standby router* assumes control of the virtual MAC and IP addresses of the HSRP group. HSRP also selects a new standby router at that time.

HSRP uses a priority mechanism to determine which HSRP-configured interface becomes the default active router. To configure an interface as the active router, you assign it with a priority that is higher than the priority of all the other HSRP-configured interfaces in the group. The default priority is 100, so if you configure just one interface with a higher priority, that interface becomes the default active router.


Interfaces that run HSRP send and receive multicast User Datagram Protocol (UDP)-based hello messages to detect a failure and to designate active and standby routers. When the active router fails to send a hello message within a configurable period of time, the standby router with the highest priority becomes the active router. The transition of packet forwarding functions between the active and standby router is completely transparent to all hosts on the network.

You can configure multiple HSRP groups on an interface.

**Figure 18-1** shows a network configured for HSRP. By sharing a virtual MAC address and a virtual IP address, two or more interfaces can act as a single *virtual router*. The virtual router does not physically exist but represents the common default gateway for interfaces that are configured to provide backup to each other. You do not need to configure the hosts on the LAN with the IP address of the active router. Instead, you configure them with the IP address (virtual IP address) of the virtual router as their default gateway. If the active router fails to send a hello message within the configurable period of time, the standby router takes over, responds to the virtual addresses, and becomes the active router, assuming the active router duties. From the host perspective, the virtual router remains the same.

**Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com).**

**Figure 18-1 HSRP Topology With Two Enabled Routers**



## HSRP Versions

Cisco NX-OS supports HSRP version 1 by default. You can configure an interface to use HSRP version 2.

HSRP version 2 has the following enhancements to HSRP version 1:

- Adds support for millisecond timers.
- Expands the group number range. HSRP version 1 supports group numbers from 0 to 255. HSRP version 2 supports group numbers from 0 to 4095.
- Uses the new IP multicast address 224.0.0.102 to send hello packets instead of the multicast address of 224.0.0.2, which is used by HSRP version 1.
- Uses MAC address range from 0000.0C9F.F000 to 0000.0C9F.FFFF. HSRP version 1 uses the MAC address range 0000.0C07.AC00 to 0000.0C07.ACFE.
- Adds support for MD5 digest authentication.

When you change the HSRP version, Cisco NX-OS reinitializes the group because it now has a new virtual MAC address.

HSRP version 2 has a different packet format than HSRP version 1. The packet format uses a type-length-value (TLV) format. HSRP version 2 packets received by an HSRP version 1 router are ignored.

## HSRP Authentication

HSRP message digest 5 (MD5) algorithm authentication protects against HSRP-spoofing software and uses the industry-standard MD5 algorithm for improved reliability and security.

***Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com).***

## HSRP Addressing

HSRP routers communicate between each other by exchanging HSRP hello packets. These packets are sent to the destination IP multicast address 224.0.0.2 (reserved multicast address used to communicate to all routers) on UDP port 1985. The active router sources hello packets from its configured IP address and the HSRP virtual MAC address while the standby router sources hellos from its configured IP address and the interface MAC address, which may or may not be the Burned-In MAC address (BIA).

Because hosts are configured with their default gateway as the HSRP virtual IP address, hosts must communicate with the MAC address associated with the HSRP virtual IP address. This MAC address is a virtual MAC address, 0000.0C07.ACxy, where xy is the HSRP group number in hexadecimal based on the respective interface. For example, HSRP group one will use the HSRP virtual MAC address of 0000.0C07.AC01. Hosts on the adjoining LAN segment use the normal Address Resolution Protocol (ARP) process to resolve the associated MAC addresses.

HSRP version 2 uses the new IP multicast address 224.0.0.102 to send hello packets instead of the multicast address of 224.0.0.2, which is used by version 1. HSRP version 2 permits an expanded group number range of 0 to 4095 and uses a new MAC address range of 0000.0C9F.F000 to 0000.0C9F.FFFF.

## HSRP Messages

Routers that are configured with HSRP exchange the following three types of multicast messages:

- Hello—The hello message conveys to other HSRP routers the HSRP priority and state information of the router.
- Coup—When a standby router wants to assume the function of the active router, it sends a coup message.
- Resign—A router that is the active router sends this message when it is about to shut down or when a router that has a higher priority sends a hello or coup message.

## HSRP Load Sharing

HSRP allows you to configure an interface in multiple groups. You can configure two overlapping HSRP groups to load share traffic from the connected hosts while providing the default gateway redundancy expected from HSRP. [Figure 18-2](#) shows an example of a load-sharing HSRP configuration.

**Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com).**

**Figure 18-2 HSRP Load Sharing**




Figure 18-2 shows two routers A and B and two HSRP groups. Router A is the active router for group A, but the standby router for group B. Similarly, router B is the active router for group B and the standby router for group A. If both routers remain active, HSRP load balances the traffic from the hosts across both routers. If either router fails, the remaining router continues to process traffic for both hosts.

## Object Tracking and HSRP

You can use object tracking to modify the priority of an HSRP interface based on the operational state of another interface. Object tracking allows you to router to a standby router if the interface to the main network fails.

Two objects that you can track are the line protocol state of an interface or the reachability of an IP route. If the specified object goes down, Cisco NX-OS reduces the HSRP priority by the configured amount. For more information, see the “[Configuring HSRP Object Tracking](#)” section on page 18-12.

## High Availability

HSRP supports stateful restart. A stateful restart occurs on a supervisor switchover. Cisco NX-OS applies the runtime configuration after the switchover.

**[Send document comments to nexus7k-docfeedback@cisco.com.](mailto:nexus7k-docfeedback@cisco.com)**

## Virtualization Support

HSRP supports Virtual Routing and Forwarding instances (VRFs). VRFs exist within virtual device contexts (VDCs). By default, Cisco NX-OS places you in the default VDC and default VRF unless you specifically configure another VDC and VRF.

If you change the VRF membership of an interface, Cisco NX-OS removes all layer 3 configuration, including HSRP.

For more information, see the *Cisco Nexus 7000 Series NX-OS Virtual Device Context Configuration Guide, Release 4.0* and see [Chapter 14, “Configuring Layer 3 Virtualization.”](#)

## Licensing Requirements for HSRP

The following table shows the licensing requirements for this feature:

Product	License Requirement
NX-OS	HSRP requires no license. Any feature not included in a license package is bundled with the Cisco NX-OS system images and is provided at no extra charge to you. For a complete explanation of the NX-OS licensing scheme, see the <i>Cisco Nexus 7000 Series NX-OS Licensing Guide, Release 4.0</i> .

## Prerequisites for HSRP

HSRP has the following prerequisites:

- You must globally enable HSRP before you can configure and enable any HSRP groups.
- If you configure VDCs, install the Advanced Services license and enter the desired VDC (see the *Cisco Nexus 7000 Series NX-OS Virtual Device Context Configuration Guide, Release 4.0*).

## Guidelines and Limitations

HSRP has the following guidelines and limitations:

- The minimum Hello timer value is 250 milliseconds.
- The minimum Hold timer value is 750 milliseconds.
- You must configure an IP address for the interface that you configure HSRP on and enable that interface before HSRP becomes active.
- The virtual IP address must be in the same subnet as the interface IP address.
- We recommend that you do not configure more than one first-hop redundancy protocol on the same interface.
- HSRP version 2 does not interoperate with HSRP version 1. An interface cannot operate both version 1 and version 2 because both versions are mutually exclusive. However, the different versions can be run on different physical interfaces of the same router.
- You cannot change from version 2 to version 1 if you have configured groups above the group number range allowed for version 1 (0 to 255).

***Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com).***

- Cisco NX-OS removes all layer 3 configuration on an interface when you change the interface VRF membership, port channel membership, or when you change the port mode to layer 2.

## Configuring HSRP

This section includes the following topics:

- [Enabling the HSRP Feature, page 18-7](#)
- [Configuring an HSRP Group, page 18-7](#)
- [Configuring the HSRP Version, page 18-9](#)
- [Configuring the HSRP Virtual MAC Address, page 18-9](#)
- [Authenticating HSRP, page 18-10](#)
- [Configuring HSRP Object Tracking, page 18-12](#)
- [Customizing HSRP, page 18-14](#)



### Note

If you are familiar with the Cisco IOS CLI, be aware that the Cisco NX-OS commands for this feature might differ from the Cisco IOS commands that you would use.

## Enabling the HSRP Feature

You must globally enable the HSRP feature before you can configure and enable any HSRP groups.

To enable the HSRP feature in a VDC, use the following command in global configuration mode:

Command	Purpose
<b>feature hsrp</b>	Enables HSRP.
<b>Example:</b> switch(config)# feature hsrp	

To disable the HSRP feature in a VDC, use the following command in global configuration mode:

Command	Purpose
<b>no feature hsrp</b>	Disables HSRP for all groups in a VDC.
<b>Example:</b> switch(config)# no feature hsrp	

## Configuring an HSRP Group

You can configure an HSRP group on an interface and configure the virtual IP address and virtual MAC address for the HSRP group.

***Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com).***

## BEFORE YOU BEGIN

Ensure that you have enabled the HSRP feature (see the “Enabling the HSRP Feature” section on page 18-7).

Cisco NX-OS enables an HSRP group once you configure the virtual IP address on any member interface in the group. You should configure HSRP attributes such as authentication, timers, and priority before you enable HSRP.

Ensure that you are in the correct VDC (or use the `switchto vdc` command).

## SUMMARY STEPS

1. `config t`
2. `interface type number`
3. `ip ip-address/length`
4. `hsrp group-number`
5. `ip [ip-address [secondary]]`
6. `exit`
7. `no shutdown`
8. `show hsrp [group group-number]`
9. `copy running-config startup-config`

## DETAILED STEPS

	Command	Purpose
Step 1	<code>config t</code>  <b>Example:</b> switch# <code>config t</code> switch(config)#	Enters configuration mode.
Step 2	<code>interface type number</code>  <b>Example:</b> switch(config)# <code>interface ethernet 1/2</code> switch(config-if)#	Enters interface configuration mode.
Step 3	<code>ip ip-address/length</code>  <b>Example:</b> switch(config-if)# <code>ip 192.0.2.2/8</code>	Configures the IPv4 address of the interface.
Step 4	<code>hsrp group-number</code>  <b>Example:</b> switch(config-if)# <code>hsrp 2</code> switch(config-if-hsrp)#	Creates a HSRP group and enters HSRP configuration mode. The range is from 0 to 4095. The default value is 0.
Step 5	<code>ip [ip-address [secondary]]</code>  <b>Example:</b> switch(config-if-hsrp)# <code>ip 192.0.2.1</code>	Configures the virtual IP address for the HSRP group and enables the group. This address should be in the same subnet as the IPv4 address of the interface.

**Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com).**

	Command	Purpose
Step 6	<b>exit</b>  <b>Example:</b> switch(config-if-hsrp)# exit	Exits HSRP configuration mode.
Step 7	<b>no shutdown</b>  <b>Example:</b> switch(config-if)# no shutdown	Enables the interface
Step 8	<b>show hsrp</b> [ <b>group</b> <i>group-number</i> ]  <b>Example:</b> switch(config-if)# show hsrp group 2	(Optional) Displays HSRP information.
Step 9	<b>copy running-config startup-config</b>  <b>Example:</b> switch(config-if)# copy running-config startup-config	(Optional) Saves this configuration change.

**Note**

You should use the no shutdown command to enable the interface after you finish the configuration.

The following example shows how to configure an HSRP group on Ethernet 1/2:

```
switch# confi t
switch(config)# interface ethernet 1/2
switch(config-if)# ip 192.0.2.2/8
switch(config-if)# hsrp 2
switch(config-if-hsrp)# ip 192.0.2.1
switch(config-if-hsrp)# exit
switch(config-if)# no shutdown
switch(config-if)# copy running-config startup-config
```

## Configuring the HSRP Version

You can configure the HSRP version. If you change the version for existing groups, Cisco NX-OS reinitializes HSRP for those groups because the virtual MAC address changes. The HSRP version applies to all groups on the interface.

To configure the HSRP version, use the following command in interface configuration mode:

Command	Purpose
<b>hsrp version</b> {1   2}  <b>Example:</b> switch(config-if)# hsrp version 2	Configures the HSRP version. Version 1 by default.

## Configuring the HSRP Virtual MAC Address

You can override the default virtual MAC address that HSRP derives from the configured group number.

## Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com).

To manually configure the virtual MAC address for an HSRP group, use the following command in HSRP configuration mode:

Command	Purpose
<b>mac-address</b> <i>string</i>  <b>Example:</b> switch(config-if-hsrp)# mac-address 5000.1000.1060	Configures the virtual MAC address for an HSRP group. The string uses the standard MAC address format (xxxx.xxxx.xxxx).

To configure HSRP to use the burned-in MAC address of the interface for the virtual MAC address, use the following command in interface configuration mode:

Command	Purpose
<b>hsrp use-bia</b> [ <b>scope interface</b> ]  <b>Example:</b> switch(config-if)# hsrp use-bia	Configures HSRP to use the burned-in MAC address of the interface for the HSRP virtual MAC address. You can optionally configure HSRP to use the burned-in MAC address for all groups on this interface by using the <b>scope interface</b> keywords.

## Authenticating HSRP

You can configure HSRP to authenticate the protocol using cleartext or MD5 digest authentication. MD5 authentication uses a key chain (see the *Cisco Nexus 7000 Series NX-OS Security Configuration Guide, Release 4.0*).



### Note

HSRP version 1 supports text authentication only.

## BEFORE YOU BEGIN

Ensure that you have enabled the HSRP feature (see the “[Enabling the HSRP Feature](#)” section on [page 18-7](#)).

You must configure the same authentication and keys on all members of the HSRP group.

Ensure that you have created the key chain if you are using MD5 authentication.

Ensure that you are in the correct VDC (or use the **switchto vdc** command).

## SUMMARY STEPS

1. **config t**
2. **interface** *interface-type slot/port*
3. **hsrp** *group-number*
4. **authentication text** *string*  
or  
**authentication md5** {**key-chain** *key-chain* | **key-string** {**0** | **7**} *text* [**timeout** *seconds*]}
5. **show hsrp** [**group** *group-number*]

**Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com).**

## 6. copy running-config startup-config

### DETAILED STEPS

	Command	Purpose
Step 1	<b>config t</b>  <b>Example:</b> switch# config t switch(config)#	Enters configuration mode.
Step 2	<b>interface</b> <i>interface-type slot/port</i>  <b>Example:</b> switch(config)# interface ethernet 1/2 switch(config-if)#	Enters interface configuration mode.
Step 3	<b>hsrp</b> <i>group-number</i>  <b>Example:</b> switch(config-if)# hsrp 2 switch(config-if-hsrp)#	Creates a HSRP group and enters HSRP configuration mode.
Step 4	<b>authentication text</b> <i>string</i>  <b>Example:</b> switch(config-if-hsrp)# authentication text mypassword	Configures cleartext authentication for HSRP on this interface.
	<b>authentication md5</b> { <b>key-chain</b> <i>key-chain</i>   <b>key-string</b> {0   7} <i>text</i> [ <b>timeout</b> <i>seconds</i> ]}	Configures MD5 authentication for HSRP on this interface. You can use a key chain or key string. If you use a key string, you can optionally set the timeout for when HSRP will only accept a new key. The range is from 0 to 32767 seconds.
	<b>Example:</b> switch(config-if-hsrp)# authentication md5 key-chain hsrp-keys	
Step 5	<b>show hsrp</b> [ <b>group</b> <i>group-number</i> ]  <b>Example:</b> switch(config-if-hsrp)# show hsrp group 2	(Optional) Displays HSRP information.
Step 6	<b>copy running-config startup-config</b>  <b>Example:</b> switch(config-if-hsrp)# copy running-config startup-config	(Optional) Saves this configuration change.

The following example shows how to configure MD5 authentication for HSRP on Ethernet 1/2 after creating the key chain:

```
switch# config t
switch(config)# key chain hsrp-keys
switch(config-keychain)# key 0
switch(config-keychain-key)# key-string 7 zqdest
switch(config-keychain-key) accept-lifetime 00:00:00 Jun 01 2008 23:59:59 Sep 12 2008
switch(config-keychain-key) send-lifetime 00:00:00 Jun 01 2008 23:59:59 Aug 12 2008
switch(config-keychain-key) key 1
switch(config-keychain-key) key-string 7 uaeqdyito
switch(config-keychain-key) accept-lifetime 00:00:00 Aug 12 2008 23:59:59 Dec 12 2008
```

***Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com).***

```
switch(config-keychain-key) send-lifetime 00:00:00 Sep 12 2008 23:59:59 Nov 12 2008
switch(config-keychain-key)# interface ethernet 1/2
switch(config-if)# hsrp 2
switch(config-if-hsrp)# authenticate md5 key-chain hsrp-keys
switch(config-if-hsrp)# copy running-config startup-config
```

## Configuring HSRP Object Tracking

You can configure an HSRP group to adjust its priority based on the availability of other interfaces or routes. The priority of a device can change dynamically if it has been configured for object tracking and the object that is being tracked goes down. The tracking process periodically polls the tracked objects and notes any value change. The value change triggers HSRP to recalculate the priority. The HSRP interface with the higher priority becomes the active router if you configure the HSRP interface for preemption. For more information on object tracking, see the [“Configuring HSRP Object Tracking” section on page 18-12](#).

### BEFORE YOU BEGIN

Ensure that you have enabled the HSRP feature (see the [“Enabling the HSRP Feature” section on page 18-7](#)).

Ensure that you are in the correct VDC (or use the `switchto vdc` command).

### SUMMARY STEPS

1. `config t`
2. `track object-id interface interface-type number {ip routing | line-protocol}`
3. `track object-id ip route ip-prefix/length reachability`
4. `interface interface-type slot/port`
5. `hsrp group-number`
6. `priority [value]`
7. `track object-number [decrement value]`
8. `preempt [delay minimum seconds] [reload seconds] [sync seconds]`
9. `show hsrp interface interface-type number`
10. `copy running-config startup-config`

**Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com).**

## DETAILED STEPS

	Command	Purpose
Step 1	<pre>config t</pre> <p><b>Example:</b> switch# config t switch(config)#</p>	Enters configuration mode.
Step 2	<pre>track object-id interface interface-type number {ip routing   line-protocol}</pre> <p><b>Example:</b> switch(config)# track 1 interface ethernet 2/2 line-protocol switch(config-track#</p>	<p>Configures the interface that this HSRP interface tracks. Changes in the state of the interface affect the priority of this HSRP interface as follows:</p> <ul style="list-style-type: none"> <li>You configure the interface and corresponding object number that you use with the <b>track</b> command in HSRP configuration mode.</li> <li>The <b>line-protocol</b> keyword tracks whether the interface is up. The <b>ip</b> keyword also checks that IP routing is enabled on the interface and an IP address is configured.</li> </ul>
	<pre>track object-id ip route ip-prefix/length reachability</pre> <p><b>Example:</b> switch(config)# track 2 ip route 192.0.2.0/8 reachability switch(config-track#</p>	Creates a tracked object for a route and enters tracking configuration mode. The object-id range is from 1 to 500.
Step 3	<pre>interface interface-type slot/port</pre> <p><b>Example:</b> switch(config)# interface ethernet 1/2 switch(config-if)#</p>	Enters interface configuration mode.
Step 4	<pre>hsrp group-number</pre> <p><b>Example:</b> switch(config-if)# hsrp 2 switch(config-if-hsrp)#</p>	Creates an HSRP group and enters HSRP configuration mode.
Step 5	<pre>priority [value]</pre> <p><b>Example:</b> switch(config-if-hsrp)# priority 254</p>	Sets the priority level used to select the active router in an HSRP group. The range is from 0 to 255. The default is 100.
Step 6	<pre>track object-number [decrement value]</pre> <p><b>Example:</b> switch(config-if-hsrp)# track 1 decrement 20</p>	<p>Specifies an object to be tracked that affects the weighting of an HSRP interface.</p> <p>The <i>value</i> argument specifies a reduction in the priority of an HSRP interface when a tracked object fails. The range is from 1 to 255. The default is 10.</p>
Step 7	<pre>preempt [delay [minimum seconds] [reload seconds] [sync seconds]]</pre> <p><b>Example:</b> switch(config-if-hsrp)# preempt delay minimum 60</p>	Configures the router to take over as the active router for an HSRP group if it has a higher priority than the current active router. This command is disabled by default. The range is from 0 to 3600 seconds.

**Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com).**

	Command	Purpose
Step 8	<pre>show hsrp interface interface-type number</pre> <p><b>Example:</b>  <pre>switch(config-if-hsrp)# show hsrp interface ethernet 1/2</pre></p>	(Optional) Displays HSRP information for an interface.
Step 9	<pre>copy running-config startup-config</pre> <p><b>Example:</b>  <pre>switch(config-if-hsrp)# copy running-config startup-config</pre></p>	(Optional) Saves this configuration change.

The following example shows how to configure HSRP object tracking on Ethernet 1/2:

```
switch# config t
switch(config)# track 1 interface ethernet 2/2 line-protocol
switch(config)# interface ethernet 1/2
switch(config-if)# hsrp 2
switch(config-if-hsrp)# track 1 decrement 20
switch(config-if-hsrp)# copy running-config startup-config
```

## Customizing HSRP

You can optionally customize the behavior of HSRP. Be aware that as soon as you enable an HSRP group by configuring a virtual IP address, that group is now operational. If you first enable a HSRP group before customizing HSRP, the router could take over control of the group and become the AVG before you finish customizing the feature. If you plan to customize HSRP, you should do so before you enable the HSRP group.

To customize HSRP, use the following commands in HSRP configuration mode:

Command	Purpose
<pre>name string</pre> <p><b>Example:</b>  <pre>switch(config-if-hsrp)# name HSRP-1</pre></p>	Specifies the IP redundancy name for an HSRP group. The <i>string</i> is from 1 to 255 characters. The default string has the following format:  <pre>hsrp-&lt;interface-short-name&gt;-&lt;group-id&gt;</pre> For example, <code>hsrp-Eth2/1-1</code> .
<pre>priority [level]</pre> <p><b>Example:</b>  <pre>switch(config-if-hsrp)# priority 254</pre></p>	Sets the priority level used to select the active router in an HSRP group. The range is from 0 to 255. The default is 100.

**Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com).**

Command	Purpose
<pre>preempt [delay [minimum seconds] [reload seconds] [sync seconds]]</pre> <p><b>Example:</b> switch(config-if-hsrp)# preempt delay minimum 60</p>	Configures the router to take over as an active router for a HSRP group if it has a higher priority than the current active router. This command is disabled by default. The range is from 0 to 3600 seconds.
<pre>timers [msec] hellotime [msec] holdtime</pre> <p><b>Example:</b> switch(config-if-hsrp)# timers 5 18</p>	<p>Configures the hello and hold time for this HSRP member as follows.</p> <ul style="list-style-type: none"> <li><i>hellotime</i>—The interval between successive hello packets sent. The range is from 1 to 254 seconds.</li> <li><i>holdtime</i>—The interval before the information in the hello packet is considered invalid. The range is from 3 to 255.</li> </ul> <p>The optional <b>msec</b> keyword specifies that the argument is expressed in milliseconds, instead of the default seconds. The timer ranges for milliseconds are as follows:</p> <ul style="list-style-type: none"> <li><i>hellotime</i>—The interval between successive hello packets sent. The range is from 255 to 999 milliseconds.</li> <li><i>holdtime</i>—The interval before the information in the hello packet is considered invalid. The range is from 750 to 3000 milliseconds.</li> </ul>

To customize HSRP, use the following commands in interface configuration mode:

Command or Action	Purpose
<pre>hsrp delay minimum seconds</pre> <p><b>Example:</b> switch(config-if)# hsrp delay minimum 30</p>	Specifies the minimum amount of time that HSRP waits after a group is enabled before participating in the group. The range is from 0 to 10000 seconds. The default is 0.
<pre>hsrp delay reload seconds</pre> <p><b>Example:</b> switch(config-if)# hsrp delay reload 30</p>	Specifies the minimum amount of time that HSRP waits after reload before participating in the group. The range is from 0 to 10000 seconds. The default is 0.

## Verifying HSRP Configuration

To verify HSRP configuration information, use one of the following commands:

Command	Purpose
<pre>show hsrp [group group-number]</pre>	Displays the HSRP status for all or one group.
<pre>show hsrp delay [interface interface-type slot/port]</pre>	Displays the HSRP delay value for all or one interface.

**Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com).**

Command	Purpose
<code>show hsrp [interface interface-type slot/port]</code>	Displays the HSRP status for an interface.
<code>show hsrp [group group-number] [interface interface-type slot/port] [active] [all] [init] [learn] [listen] [speak] [standby]</code>	Displays the HSRP status for a group or interface for virtual forwarders in the active, init, learn, listen, or standby state. Use the <b>all</b> keyword to see all states, including disabled.
<code>show hsrp [group group-number] [interface interface-type slot/port] active] [all] [init] [learn] [listen] [speak] [standby] brief</code>	Displays a brief summary of the HSRP status for a group or interface for virtual forwarders in the active, init, learn, listen, or standby state. Use the <b>all</b> keyword to see all states, including disabled.

## HSRP Example Configuration

The following example enables HSRP on an interface with MD5 authentication and interface tracking:

```
key chain hsrp-keys
key 0
  key-string 7 zqdest
  accept-lifetime 00:00:00 Jun 01 2008 23:59:59 Sep 12 2008
  send-lifetime 00:00:00 Jun 01 2008 23:59:59 Aug 12 2008
key 1
  key-string 7 uaeqdyito
  accept-lifetime 00:00:00 Aug 12 2008 23:59:59 Dec 12 2008
  send-lifetime 00:00:00 Sep 12 2008 23:59:59 Nov 12 2008
feature hsrp
track 2 interface ethernet 2/2 ip
interface ethernet 1/2
ip address 192.0.2.2/8
hsrp 1
  authenticate md5 key-chain hsrp-keys
  priority 90
  track 2 decrement 20
  ip-address 192.0.2.10
no shutdown
```

## Default Settings

Table 18-1 lists the default settings for HSRP parameters.

**Table 18-1** Default HSRP Parameters

Parameters	Default
HSRP	Disabled
Authentication	Enabled as text for version 1, with cisco as the password.
HSRP version	Version 1
Preemption	disabled
Priority	100
virtual MAC address	Derived from HSRP group number

***Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com).***

## Additional References

For additional information related to implementing IP, see the following sections:

- [Related Documents, page 18-17](#)
- [Standards, page 18-17](#)

## Related Documents

Related Topic	Document Title
Configuring the Gateway Load Balancing protocol	<a href="#">Chapter 17, “Configuring GLBP”</a>
Configuring the Virtual Router Redundancy protocol	<a href="#">Chapter 19, “Configuring VRRP”</a>
HSRP CLI commands	<i>Cisco Nexus 7000 Series NX-OS Unicast Routing Command Reference, Release 4.0</i>
Configuring high availability	<i>Cisco Nexus 7000 Series NX-OS High Availability and Redundancy Guide, Release 4.0</i>

## Standards

Standards	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	—

***Send document comments to [nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com).***