



Using the Command-Line Interface

This chapter describes the command-line interface (CLI) you use to configure the Catalyst enterprise LAN switches and modules.



Note

For descriptions of all switch and ROM monitor commands, refer to the *Command Reference* for your switch. For a description of the Catalyst 5000 family ATM module CLI and the commands used to configure the ATM modules, refer to the *ATM Software Configuration Guide and Command Reference—Catalyst 5000 Family and 6000 Family Switches* publication. For descriptions of the commands used to configure the Route Switch Module (RSM) and Route Switch Feature Card (RSFC), refer to the Cisco IOS software command reference publications.

This chapter consists of these sections:

- [Overview of the Switch CLI, page 2-2](#)
- [Accessing the Switch CLI, page 2-2](#)
- [Switch CLI Command Modes, page 2-3](#)
- [Accessing Help, page 2-4](#)
- [Command Line Editing, page 2-5](#)
- [History Substitution, page 2-6](#)
- [Abbreviating a Command, page 2-6](#)
- [Completing a Partial Command, page 2-6](#)
- [Scrolling Down a Line or a Screen, page 2-7](#)
- [Using Command Aliases, page 2-7](#)
- [Specifying Modules, Ports, and VLANs, page 2-7](#)
- [Specifying MAC Addresses, page 2-8](#)
- [Specifying IP Addresses, Host Names, and IP Aliases, page 2-8](#)
- [ROM Monitor Command-Line Interface, page 2-9](#)
- [Example Switch Bootup Displays, page 2-9](#)

Overview of the Switch CLI

The switch CLI is a basic command-line interpreter, similar to the UNIX C shell. Switch commands are not case sensitive. You can abbreviate commands and parameters as long as they contain enough letters to be distinguished from any other currently available commands or parameters.

The Catalyst enterprise LAN switches are multimodule systems. Commands you enter from the CLI might apply to the entire system or to a specific module, port, or VLAN.

You configure the switch using **set** and **clear** commands. Enter **set** commands to change switch parameters. Use **clear** commands (or, in some cases, **set** commands) to overwrite or erase configuration parameters. Use **show** commands to display the current configuration and to monitor the switch.

Accessing the Switch CLI

You can access the CLI through the supervisor engine console port or through a Telnet session.

These sections describe how to access the switch CLI:

- [Accessing the CLI through the Console Port, page 2-2](#)
- [Accessing the CLI through Telnet, page 2-3](#)

Accessing the CLI through the Console Port

To access the switch CLI through the console port, you first must connect a console terminal to the console port through an EIA/TIA-232 (RS-232) cable. Make sure the terminal is connected to the switch and that the terminal is on.



Note

For complete information on how to connect a terminal to the supervisor engine console port, refer to the hardware documentation for your switch.

To access the switch CLI through the console port, perform this task:

-
- Step 1** Connect to the supervisor engine console port using the appropriate application or commands on the terminal (for example, using a terminal emulation program on a PC or using the **tip** command on a UNIX system).
- Step 2** If the switch is not on, power up the switch. The bootup display should appear on the screen (see the [“Example Switch Bootup Displays”](#) section on page 2-9). If the switch is already booted, you will see this display:

```
Cisco Systems, Inc. Console
```

```
Enter password:
```

After you successfully connect to the switch through the console port, you can enter normal-mode commands to monitor the switch or enter commands in privileged mode to change the configuration. For more information, see the [“Switch CLI Command Modes”](#) section on page 2-3.

Accessing the CLI through Telnet

Before you can open a Telnet session to the switch, you must first set the IP address (and in some cases the default gateway) for the switch. For information about setting the IP address and default gateway, see [Chapter 3, “Configuring the Switch IP Address and Default Gateway.”](#)

**Note**

For more information about using Telnet, see the [“Using Telnet” section on page 21-6.](#)

To access the switch CLI from a remote host using Telnet, follow these steps:

- Step 1** Make sure the switch is on and is properly configured with an IP address and default gateway, if necessary.
- Step 2** Using the appropriate application or command on your host system, Telnet to the switch using the IP address or DNS host name of the switch.

You must configure DNS properly on the switch and on your network name server in order to use DNS hostnames. For more information on DNS, see [Chapter 36, “Configuring DNS.”](#)

```
unix_host% telnet Catalyst_1
Trying 172.16.10.10...
Connected to Catalyst_1.
Escape character is '^]'.

```

```
Cisco Systems Console
```

```
Enter password:
```

After you successfully connect to the switch using Telnet, you can enter normal-mode commands to monitor the switch or enter commands in privileged mode to change the configuration. For more information, see the [“Switch CLI Command Modes” section on page 2-3.](#)

Switch CLI Command Modes

The switch CLI supports two modes of operation: normal (also called login or user mode) and privileged (also called enable mode). Both modes are password protected. Use normal-mode commands for system monitoring. Use privileged-mode commands to change the system configuration.

**Note**

For complete information on configuring passwords and controlling access to the switch, see [Chapter 30, “Configuring Switch Access Using AAA.”](#)

To enter normal command mode, follow these steps:

- Step 1** Connect to the switch CLI through the console port or using Telnet (for more information, see the [“Accessing the Switch CLI” section on page 2-2.](#))
- Step 2** On a new switch, the normal-mode password is null. If you are connecting to a new switch, press **Return** at the Enter Password prompt. If the switch is not new, enter the normal-mode password. You will see the normal mode command-line prompt.

```
Enter Password: <normal_mode_password>
Console>
```

Step 3 To disconnect from the switch CLI, use the **exit** command.

```
Console> exit
Session Disconnected...
```

```
Cisco Systems Console          Fri Aug 27 1999, 16:14:41
```

```
Enter password:
```

Many commands (for example, commands that modify the configuration) can be entered only in privileged mode. To enter privileged command mode, follow these steps:

Step 1 From normal mode, enter the **enable** command. On a new switch, the privileged-mode password is null. If you are connecting to a new switch, press **Return** at the Enter Password prompt. If the switch is not new, enter the privileged-mode password.

```
Console> enable
Enter password: <privileged_mode_password>
Console> (enable)
```

Step 2 To exit privileged mode and return to normal mode, use the **disable** command.

```
Console> (enable) disable
Console>
```

Accessing Help

Enter **help** or **?** in normal or privileged mode to see the commands available in those modes. Command usage, the help menu, and when appropriate, parameter ranges are provided if you enter a command using the wrong number of arguments or inappropriate arguments.

Additionally, appending **?** to a command displays a list of valid keywords and arguments for the command. Insert a space between the last parameter and the question mark (?). For example, eight parameters are used by the **set mls** command. To see these parameters, enter **set mls ?** at the privileged prompt. The system displays all valid keywords and arguments as follows:

```
Console> (enable) set mls ?
  agingtime          Set agingtime for MLS cache entry
  disable            Disable MLS in the switch
  enable             Enable MLS in the switch
  nde                Configure Netflow Data Export
  flow               Set minimum flow mask
  include            Include MLS-RP
  multicast          Set MLS feature for multicast
  statistics         Add protocols to protocol statistics list
Console> (enable) set mls
```



Note

The system repeats the command you entered without the ?.

To use the partial-keyword-lookup function, enter `?` to display a list of commands that begin with a specific set of characters. Do not insert a space between the last letter of the variable and the question mark (`?`). For example, enter `co?` at the privileged prompt to display a list of commands that start with `co`. The system displays all commands that begin with `co` as follows:

```
Console> (enable) co?
  configure                Configure system from network
  copy                     Copy files between TFTP/RCP/module/flash devices
Console> (enable) co
```

**Note**

The system repeats the command you entered without the `?`.

Command Line Editing

The switch CLI supports a number of command line editing keystrokes. [Table 2-1](#) lists the keystrokes you can use when entering and editing switch commands.

Table 2-1 Command-Line Editing Keystrokes

| Keystroke | Function |
|--|---|
| Ctrl-A | Jumps to the first character of the command line. |
| Ctrl-B or the left arrow key¹ | Moves the cursor back one character. |
| Ctrl-C | Escapes and terminates prompts and lengthy tasks. |
| Ctrl-D | Deletes the character at the cursor. |
| Ctrl-E | Jumps to the end of the current command line. |
| Ctrl-F or the right arrow key¹ | Moves the cursor forward one character. |
| Ctrl-K | Deletes from the cursor to the end of the command line. |
| Ctrl-L; Ctrl-R | Repeats current command line on a new line. |
| Ctrl-N or the down arrow key¹ | Enters next command line in the history buffer. |
| Ctrl-P or the up arrow key¹ | Enters previous command line in the history buffer. |
| Ctrl-U; Ctrl-X | Deletes from the cursor to the beginning of the command line. |
| Ctrl-W | Deletes last word typed. |
| Esc B | Moves the cursor backward one word. |
| Esc D | Deletes from the cursor to the end of the word. |
| Esc F | Moves the cursor forward one word. |
| Delete key or Backspace key | Erases mistake when entering a command; reenter command after using this key. |

1. The arrow keys function only on ANSI-compatible terminals such as VT100s.

History Substitution

The history buffer stores the last 20 commands you entered during a terminal session. History substitution allows you to repeat these commands using special abbreviated commands, similar to those used on the UNIX command line. Table 2-2 lists the history substitution commands.

Table 2-2 History Substitution Commands

| Command | Function |
|--|--|
| Repeating recent commands: | |
| !! | Repeat the most recent command. |
| !-nn | Repeat the <i>nn</i> th most recent command. |
| !n | Repeat command <i>n</i> . |
| !aaa | Repeat the command beginning with string <i>aaa</i> . |
| !?aaa | Repeat the command containing the string <i>aaa</i> . |
| To modify and repeat the most recent command: | |
| ^aaa^bbb | Replace the string <i>aaa</i> with the string <i>bbb</i> in the most recent command. |
| To add a string to the end of a previous command and repeat it: | |
| !!aaa | Add string <i>aaa</i> to the end of the most recent command. |
| !n aaa | Add string <i>aaa</i> to the end of command <i>n</i> . |
| !aaa bbb | Add string <i>bbb</i> to the end of the command beginning with string <i>aaa</i> . |
| !?aaa bbb | Add string <i>bbb</i> to the end of the command containing the string <i>aaa</i> . |

Abbreviating a Command

You can abbreviate commands and keywords to the number of characters that allow a unique abbreviation.

You can abbreviate the **show** command to **sh**. After entering the command at the system prompt, press **Return** to execute the command.

Completing a Partial Command

The **Tab** key allows you to use the command-completion feature. When you enter a unique partial character string and press the **Tab** key, the system completes the command or keyword on the command line.

For example, if you enter **co** and press the **Tab** key, the system completes the command as **configure** because it is the only command that matches the criteria.

Scrolling Down a Line or a Screen

When the output of a command fills more than one terminal screen, a ---More--- prompt is displayed at the bottom of the screen. To view the next line or screen, perform these tasks:

| Task | Keystrokes |
|-------------------------|------------------------------|
| Scroll down one line. | Press the Return key. |
| Scroll down one screen. | Press the Spacebar . |



Note

The ---More--- prompt is used for any output that has more lines than can be displayed on the terminal screen, including **show** command output.

Using Command Aliases

Aliases are not case sensitive; however, unlike regular commands, some aliases cannot be abbreviated. See [Table 2-3](#) for a list of switch CLI aliases that cannot be abbreviated.

Table 2-3 Switch CLI Command Aliases

| Alias | Command |
|--------|-----------|
| ? | help |
| batch | configure |
| di | show |
| exit | quit |
| logout | quit |

Specifying Modules, Ports, and VLANs

Modules, ports, and VLANs are numbered sequentially, beginning with 1. The supervisor engine module is module 1, residing in slot 1. If your Catalyst 5500 series switch has a redundant supervisor engine, the supervisor engines must be installed in slots 1 and 2.

To designate a specific module, use the module number. In most systems, the module number and the slot number are the same. However, in some cases the slot number and the module number are different. For example, the Route Switch Feature Card (RSFC) on the supervisor engine is physically in slot 1 or slot 2 but is logically identified as module 15 or module 16.

With many commands, you can enter lists of ports. To specify a range of ports, use a comma-separated list (do not insert spaces) to specify individual ports or a hyphen (-) between the port numbers to specify a range of ports. Hyphens take precedence over commas.

Table 2-4 shows examples of how to designate ports and port ranges.

Table 2-4 Designating Ports and Port Ranges

| Example | Function |
|--------------|---|
| 2/1 | Specifies port 1 on module 2 |
| 3/4-8 | Specifies ports 4, 5, 6, 7, and 8 on module 3 |
| 5/2,5/4,6/10 | Specifies ports 2 and 4 on module 5 and port 10 on module 6 |
| 3/1-2,4/8 | Specifies ports 1 and 2 on module 3 and port 8 on module 4 |

VLANs are identified using the VLAN ID, a single number associated with the VLAN. To specify a list of VLANs, use a comma-separated list (do not insert spaces) to specify individual VLANs or a hyphen (-) between the VLAN numbers to specify a range of VLANs.

Table 2-5 shows examples of how to designate VLANs and VLAN ranges.

Table 2-5 Designating VLANs and VLAN Ranges

| Example | Function |
|-----------|--|
| 10 | Specifies VLAN 10 |
| 5,10,15 | Specifies VLANs 5, 10, and 15 |
| 10-50,500 | Specifies VLANs 10 through 50, inclusive, and VLAN 500 |

Specifying MAC Addresses

Some commands require you to specify a Media Access Control (MAC) address, which must be designated in a standard format. The MAC address format must be six hexadecimal numbers separated by hyphens, as shown in the following example:

```
00-00-0c-24-d2-fe
```

Specifying IP Addresses, Host Names, and IP Aliases

Some commands require an IP address, IP host name, or IP alias. The IP address format is 32 bits, written in dotted decimal format, as shown in the following example:

```
172.16.10.1
```

If DNS is configured properly on the switch, you can use IP host names instead of IP addresses. For information on configuring DNS, see [Chapter 36, “Configuring DNS.”](#)

In addition, you can configure IP aliases on the switch that you can use in place of IP addresses. IP aliases can be used for most commands that use an IP address, except for commands that define the IP address or IP alias. For information on using IP aliases, see the [“Creating and Using IP Aliases” section on page 29-6.](#)


```
#####
#####
#####
#####
#####
#####
#####
#####
```

```
System Power On Diagnostics
NVRAM Size .....512 KB
ID Prom Test .....Passed
DPRAM Size .....16KB
DPRAM Data 0x55 Test .....Passed
DPRAM Data 0xaa Test .....Passed
DPRAM Address Test .....Passed
Clearing DPRAM .....Done
System DRAM Memory Size .....32MB
DRAM Data 0x55 Test .....Passed
DRAM Data 0xaa Test .....Passed
DRAM Address Test .....Passed
Clearing DRAM .....Done
EARLII .....Present
EARLII RAM Test .....Passed
EARL Serial Prom Test .....Passed
Level2 Cache .....Present
Level2 Cache test.....Passed
```

```
Boot image: bootflash:cat5000-sup3.5-2-1.bin
Downloading epld sram device please wait ...
Programming successful for Altera 10K50 SRAM EPLD
```

```
Running System Diagnostics from this Supervisor (Module 1)
This may take up to 2 minutes...please wait
```

```
Cisco Systems Console
```

```
Enter password:
1999 Aug 12 15:51:03 %MLS-5-NDEDISABLED:Netflow Data Export disabled
1999 Aug 12 15:51:04 %SYS-5-MOD_OK:Module 1 is online
1999 Aug 12 15:51:17 %SYS-5-MOD_OK:Module 4 is online
1999 Aug 12 15:51:19 %SYS-5-MOD_OK:Module 3 is online
1999 Aug 12 15:51:21 %SYS-5-MOD_OK:Module 8 is online
Sending RARP request with address 00:e0:4f:ac:b3:ff
Sending DHCP packet with address: 00:e0:4f:ac:b3:ff
Sending RARP request with address 00:e0:4f:ac:b3:ff
Sending DHCP packet with address: 00:e0:4f:ac:b3:ff
Sending RARP request with address 00:e0:4f:ac:b3:ff
Sending DHCP packet with address: 00:e0:4f:ac:b3:ff
Sending RARP request with address 00:e0:4f:ac:b3:ff
Sending DHCP packet with address: 00:e0:4f:ac:b3:ff
Sending RARP request with address 00:e0:4f:ac:b3:ff
```

**Note**

The system only initiates DHCP/BOOTP and Reverse Address Resolution Protocol (RARP) requests at startup when the sc0 interface IP address is set to 0.0.0.0. For more information, see the [“Using DHCP or RARP to Obtain an IP Address Configuration”](#) section on page 3-8.

Catalyst 5000 Family Supervisor Engine III G Bootup Display

This example shows the bootup display of a Catalyst 5000 family switch with a Supervisor Engine III G (the display on the Catalyst 5000 family Supervisor Engine II or II G will be similar):

```
ATE0
ATS0=1

ROM Power Up Diagnostics of Apr 20 1999

Init NVRAM Log
LED Test ..... done
ROM Checksum ..... passed
Dual Port RAM r/w Test ..... passed
ID PROM ..... passed
System DRAM Size(mb) ..... 32
DRAM Data Bus Test ..... passed
DRAM Address Test ..... passed
DRAM Byte/Word Access Test .. passed

BOOTROM Version 5.1(1), Dated Apr 20 1999 11:09:48
BOOT date: 08/12/99 BOOT time: 14:45:29
uncompressing nmp image
This will take a minute...
NMP image is successfully uncompressed in DRAM

Running System Diagnostics from this Supervisor (Module 1)
This may take up to 2 minutes...please wait

IP address for Catalyst not configured
DHCP/BOOTP will commence after the ports are online
Ports are coming online ...

Cisco Systems Console

Enter password:
1999 Aug 12 14:46:36 %MLS-5-MLSENABLED:IP Multilayer switching is enabled
1999 Aug 12 14:46:36 %MLS-5-NDEDISABLED:Netflow Data Export disabled
1999 Aug 12 14:46:36 %SYS-5-MOD_OK:Module 1 is online
1999 Aug 12 14:46:48 %SYS-5-MOD_OK:Module 6 is online
1999 Aug 12 14:47:01 %SYS-5-MOD_OK:Module 9 is online
1999 Aug 12 14:47:11 %SYS-5-MOD_OK:Module 3 is online
1999 Aug 12 14:47:13 %SYS-5-MOD_OK:Module 7 is online
Sending RARP request with address 00:e0:1e:9b:31:ff
Sending DHCP packet with address: 00:e0:1e:9b:31:ff
Sending RARP request with address 00:e0:1e:9b:31:ff
Sending DHCP packet with address: 00:e0:1e:9b:31:ff
Sending RARP request with address 00:e0:1e:9b:31:ff
Sending DHCP packet with address: 00:e0:1e:9b:31:ff
Sending RARP request with address 00:e0:1e:9b:31:ff
Sending DHCP packet with address: 00:e0:1e:9b:31:ff
Sending RARP request with address 00:e0:1e:9b:31:ff
```

**Note**

The system only initiates DHCP/BOOTP and Reverse Address Resolution Protocol (RARP) requests at startup when the sc0 interface IP address is set to 0.0.0.0. For more information, see the [“Using DHCP or RARP to Obtain an IP Address Configuration”](#) section on page 3-8.

■ Example Switch Bootup Displays