



Configuring a VoIP Network

This chapter describes how to configure a Voice-over-IP (VoIP) network on the Catalyst 6000 family switches.



Note

While this chapter introduces a number of Cisco networking products related to VoIP, the primary focus of the chapter is to provide configuration information for integrating Catalyst 6000 family products into your VoIP network.



Note

For complete syntax and usage information for the commands used in this chapter, refer to the *Catalyst 6000 Family Command Reference* publication.

This chapter consists of these sections:

- [Hardware and Software Requirements, page 44-1](#)
- [Understanding How a VoIP Network Works, page 44-2](#)
- [Understanding How VLANs Work, page 44-8](#)
- [Configuring VoIP on a Switch, page 44-9](#)

Hardware and Software Requirements

The hardware and software requirements for the Catalyst 6000 family switches and Cisco CallManager are as follows:


- Catalyst 4000, 5000, and 6000 switches running supervisor engine software release 6.1(1) or later releases.
- Cisco CallManager release 3.0 or later releases

Understanding How a VoIP Network Works

A telephony system built on an IP network instead of the traditional circuit-switched private branch exchange (PBX) network is called an IP PBX system. See [Figure 44-1](#); the individual components of this system are described in these sections:

- [Cisco IP Phone 7960, page 44-2](#)
- [Cisco CallManager, page 44-4](#)
- [Access Gateways, page 44-4](#)
- [How a Call Is Made, page 44-7](#)

Figure 44-1 IP PBX System



* Catalyst 4000, 5000, and 6000 10/100 modules

38202

Cisco IP Phone 7960

The Cisco IP Phone 7960 provides connectivity to the IP PBX system. The IP phone has two RJ-45 jacks for connecting to external devices, a LAN-to-phone jack and a PC-to-phone jack. The jacks use either Category 3 or Category 5 unshielded twisted-pair (UTP) cable. The LAN-to-phone jack is used to connect the phone to the LAN using a crossover cable; a workstation or a PC can be connected to the PC-to-phone jack using a straight-through cable.

The IP phone is Dynamic Host Configuration Protocol (DHCP) capable. Optionally, the IP phone can be programmed with a static IP address.

The IP phone can be powered by the following sources:

- External power source—Optional transformer and power cord for connecting to a standard wall receptacle.
- WS-X6348-RJ45V 10/100 switching module—Provides inline power to the IP phone.
- WS-PWR-PNL—Inline-power patch panel provides inline power to the IP phone. The inline patch panel allows the IP phone to be connected to existing Catalyst 4000, 5000, and 6000 family 10/100BASE-TX switching modules.

Examples 1 through 4 in [Figure 44-2](#) show how to connect the Cisco IP Phone 7960 and PCs to the Catalyst 6000 family switch.

Figure 44-2 *Connecting the Cisco IP Phone 7960 to the Catalyst 6000 Family Switch*

Example 1—Single Cisco IP Phone 7960

Example 1 shows one IP phone connected to the 10/100 port on the Catalyst 6000 family switch. The PC-to-phone jack on the phone is not used. The phone can be powered through either the 10/100 port or wall-powered.

Example 2—Single PC

Example 2 shows one PC connected to the 10/100 port on the Catalyst 6000 family switch. The PC is wall-powered.

Example 3—One Cisco IP Phone 7960 and One PC

Example 3 shows one IP phone connected to the 10/100 port on the Catalyst 6000 family switch and one PC connected to the PC-to-phone jack on the phone. The PC behaves as if it is connected directly to the 10/100 port on the Catalyst 6000 family switch. The phone can be powered through the 10/100 port or wall-powered. The PC must be wall-powered.

Example 4—Two Cisco IP Phone 7960s and One PC

Example 4 shows two IP phones connected to the 10/100 port on the Catalyst 6000 family switch and one PC connected to the PC-to-phone jack on the phone. The PC behaves as if it is connected directly to the 10/100 port on the Catalyst 6000 family switch. The first phone can be powered through the 10/100 port or wall-powered. The second phone and the PC must be wall-powered.



Note

For information on configuring Cisco IP phones and third-party vendor phones, refer to the documentation that shipped with the phone.

Cisco CallManager

Cisco CallManager is an open and industry-standard call processing system; its software runs on a Windows NT server and sets up and tears down calls between phones, integrating traditional PBX functionality with the corporate IP network. Cisco CallManager manages the components of the IP PBX system, the phones, access gateways, and the resources necessary for such features as call conferencing and media mixing. Each Cisco CallManager manages the devices within its *zone* and exchanges information with the Cisco CallManager in charge of another zone to make calls possible across multiple zones. Additionally, Cisco CallManager can work with existing PBX systems to route a call over the Public Switched Telephone Network (PSTN).



Note

For information on configuring Cisco CallManager to work with the IP devices described in this chapter, refer to the *Cisco CallManager Administration Guide, Release 3.0*, the *Configuration Notes for Cisco CallManager Release 3.0*, and the *Cisco CallManager v3.0 Remote Serviceability Users Guide* publications.

Access Gateways

Access gateways allow the IP PBX system to talk to existing PSTN or PBX systems. Access gateways consist of analog station gateways, analog trunk gateways, digital trunk gateways, and a *converged* voice gateway.

These sections describe the gateways:

- [Analog Station Gateway, page 44-4](#)
- [Analog Trunk Gateway, page 44-5](#)
- [Digital Trunk Gateway, page 44-6](#)
- [Converged Voice Gateway, page 44-7](#)

Analog Station Gateway

The Catalyst 6000 family 24-port Foreign Exchange Station (FXS) analog interface module allows plain old telephone service (POTS) phones and fax machines to connect to the IP PBX network. The analog station gateway behaves like the PSTN side for the POTS equipment. It requires an IP address, is registered with Cisco CallManager in its domain, and is managed by Cisco CallManager.

The 24-port FXS analog interface module features are listed in [Table 44-1](#).

To configure the analog station interfaces, see the “[Configuring VoIP on a Switch](#)” section on page 44-9.

Table 44-1 24-Port FXS Analog Interface Module Features

Digital Signal Processing Per Port
G.711 and G.729 voice encoding
Silence suppression; voice activity detection
Comfort noise generation
Ringer, software programmable frequency and cadence, based on country
DTMF ¹ detection
Signaling, loop start
Line echo cancellation (32 ms)
Impedance (600 ohms)
Programmable analog gain, signaling timers
Fax passthrough
SPAN ² or port mirroring support
FXS Interface Features
Address signaling formats: In-band DTMF
Signaling formats: Loop start
Ringing tone: Programmable
Ringing voltage: Programmable, based on country
Ringing frequency: Programmable, based on country
Distance: 500-ohms maximum loop
1. DTMF = dual tone multifrequency
2. SPAN = Switched Port Analyzer

Analog Trunk Gateway

Cisco access analog trunk gateways allow the IP PBX to connect to the PSTN or PBX. The gateway supports up to eight trunks to the PSTN and appears like a phone to the trunk lines coming from the PSTN. Using this gateway, the IP PBX places an IP call through the PSTN. Similar to the analog station gateway, the analog trunk gateway provides line echo cancellation and dual tone multifrequency (DTMF) tone generation and detection. The analog trunk gateway does not provide ring voltage as it is not connected to POTS end devices such as POTS-phones or fax machines. The analog trunk gateway requires an IP address, is registered with Cisco CallManager in its domain, and is managed by Cisco CallManager.

To configure the analog trunk gateways, refer to the documentation that shipped with the gateway.

Digital Trunk Gateway

The Catalyst 6000 family 8-port T1/E1 PSTN interface module is a high-density, eight port, T1/E1 VoIP module that can support both digital T1/E1 connectivity to the PSTN or transcoding and conferencing. The module requires an IP address, is registered with Cisco CallManager in its domain, and is managed by Cisco CallManager.

The module software is downloaded from a TFTP server. Depending upon which software you download, the ports can serve as T1/E1 interfaces or the ports support transcoding and conferencing. Transcoding and conferencing functions are mutually exclusive. For every transcoding port in use, one less conferencing port is available and vice versa.

To configure the 8-port T1/E1 PSTN interfaces, see the [“Configuring VoIP on a Switch” section on page 44-9](#).

The 8-port T1/E1 PSTN interface module features are listed in [Table 44-2](#).

Table 44-2 8-Port T1/E1 PSTN Interface Module Features

Digital Signal Processing Per T1/E1 Port
G.711 to G.723 and G.729a transcoding (maximum of 8 x 32 channels of transcoding)
Conference bridging, meet-me and ad-hoc conference modes (maximum of 8 x 16 channels of conferencing)
Comfort noise generation
Fax passthrough
Silence suppression, voice activity detection
Line echo cancellation
Common channel signaling
For T1: 23 DS0 channels for voice traffic; 24th channel is used for signaling
For E1: 29 DS0 channels for voice traffic; 16th channel is reserved for signaling
Any channel can be configured for common channel signaling
ISDN Primary Rate Interface signaling: Each interface supports 23 channels for T1 and 30 channels for E1. The default mode is for the 24th T1 channel or 16th E1 channel to be reserved for signaling. Both network side and user side operation modes are supported.
T1 binary 8-zero substitution/alternate mark inversion (B8ZS/AMI) line coding, u-law or a-law coding
E1 HDB3 line coding
T1 line bit rate: 1.544 Mbps
E1 line bit rate: 2.048 Mbps
T1 line code: AMI, B8ZS
E1 line code: HDB3
Framing format: D4 superframe and extended superframe
Link Management
FDL ¹ is a link management protocol used to help diagnose problems and gather statistics on T1 lines

1. FDL = Facilities Data Link

Converged Voice Gateway

The Cisco Voice Gateway 200 (VG200) allows you to connect standard POTS phones (connected directly to the gateway or anywhere on the PSTN) with Cisco IP or any H.323-compliant telephony devices. When used with Cisco CallManager, the VG200 functions as a Media Gateway Control Protocol (MGCP) gateway. The Cisco VG200 provides a 10/100BASE-T Ethernet port for connection to the data network. The following telephony connections are also available:

- One to four Foreign Exchange Office (FXO) ports for connecting to a central office or PBX
- One to four FXS ports for connecting to POTS telephony devices
- One or two T1 digital ports for connecting to the following:
 - PSTN using FXO emulation
 - T1 channel bank using FXS emulation
 - PBX through a trunk (tie) line using ear and mouth (E&M) emulation

These ports can be used to integrate a VoIP network with POTS devices, PBXs, or the PSTN.

To configure the Cisco VG200, refer to the documentation that shipped with the gateway.

How a Call Is Made

An IP phone connects to a LAN either through a hub port or a switch port. The IP phone boots up and uses DHCP to get its IP address and the IP address of its TFTP file server. The IP phone uses its IP address to talk to the TFTP server and gets its configuration file. The configuration file includes the IP address of the phone's Cisco CallManager(s). The phone then talks with Cisco CallManager and registers itself. Each time a phone boots up, it might get a different IP address. Cisco CallManager knows how to associate a consistent user phone number to a particular phone by using the MAC address of the phone. Cisco CallManager always maintains a table mapping the "phone MAC address" and "phone number." Each time a phone registers, the table is updated with the new IP address. During registration, Cisco CallManager downloads the key pad template and the feature capability for the phone. It tells the phone which run-time image it should use. The phone then goes to the TFTP server to get its run-time image. Each phone has a dedicated TCP connection to Cisco CallManager called the "control channel." All control information, such as key pressing, goes from the phone to Cisco CallManager through this channel. Instructions to generate ring tone, busy tone, and so on comes from Cisco CallManager to the phone through this channel.

Cisco CallManager stores the IP-address-to-phone-number mapping (and vice versa) in its tables. When a user wants to call another user, the user keys in the called party's phone number. Cisco CallManager translates the phone number to an IP address and generates an IP packet version of ring tone to the called IP phone through the TCP connection. When the called IP phone receives the packet, it generates a ring tone. When the user picks up the phone, Cisco CallManager instructs the called IP phone to start talking with the calling party and removes itself from the loop. From this point on, the call goes between the two IP phones through the Real-Time Transport Protocol (RTP) which runs over the User Datagram Protocol (UDP). Because voice packets are sensitive to delays, TCP is not suitable for voice transmission as timeouts and retries increase the delay between packets. When any change occurs during the call due to a feature being pressed on one of the phones, or one of the users hanging up or pressing the flash button, the information goes to Cisco CallManager through the control channel.

If a call is made to a number outside of the IP PBX network, Cisco CallManager routes the call to an analog or digital trunk gateway which in turn routes it to the PSTN.

Understanding How VLANs Work

This section describes native VLANs and auxiliary VLANs. This section uses the following terminology:

- Auxiliary VLAN—Separate VLAN for IP phones
- Native VLAN—Traditional VLAN for data
- Auxiliary VLAN ID—VLAN ID of an auxiliary VLAN
- Native VLAN ID—VLAN ID of a native VLAN

**Note**

For more information about VLANs, see [Chapter 11, “Configuring VLANs.”](#)

[Figure 44-3](#) shows how a Cisco IP Phone 7960 can be connected to a Catalyst 6000 family switch.

Figure 44-3 Switch-to-Phone Connections

When the IP phone connects to a 10/100 port on the Catalyst 6000 family switch, the *access port* (PC-to-phone jack) of the IP phone can be used to connect a PC.

Packets to and from the PC and to and from the phone share the same physical link to the switch and the same port of the switch. Various configurations of connecting the phone and the PC are possible (see the [“Cisco IP Phone 7960” section on page 44-2](#)).

Introducing IP-based phones into existing switch-based networks raises the following issues:

- The current VLANs might be configured on an IP subnet basis and additional IP addresses might not be available to assign the phone to a port so that it belongs to the same subnet as other devices (PC) connected to the same port.
- Data traffic present on the VLAN supporting phones might reduce the quality of VoIP traffic.

You can resolve these issues by isolating the voice traffic onto a separate VLAN on each of the ports connected to a phone. The switch port configured for connecting a phone would have separate VLANs configured for carrying the following:

- Voice traffic to and from the IP phone (auxiliary VLAN)
- Data traffic to and from the PC connected to the switch through the access port of the IP phone (native VLAN)

Isolating the phones on a separate, auxiliary VLAN increases the quality of the voice traffic and allows a large number of phones to be added to an existing network where there are not enough IP addresses. A new VLAN means a new subnet and a new set of IP addresses.

Configuring VoIP on a Switch

This section describes the command-line interface (CLI) commands and the procedures used to configure the Catalyst 6000 family switch for VoIP operation:

- [Voice-Related CLI Commands, page 44-9](#)
- [Configuring Per-Port Power Management, page 44-10](#)
- [Configuring Auxiliary VLANs on Catalyst LAN Switches, page 44-19](#)
- [Configuring the Access Gateways, page 44-21](#)
- [Displaying Active Call Information, page 44-27](#)
- [Configuring QoS in the Cisco IP Phone 7960, page 44-29](#)



Note

You must enable Cisco Discovery Protocol (CDP) on the Catalyst 6000 family switch port connected to the IP phone in order to communicate information such as auxiliary VLAN ID, per-port power management details, and quality of service (QoS) configuration information.

Voice-Related CLI Commands

Table 44-3 lists the CLI commands described in the configuration procedures.

Table 44-3 Voice-Related CLI Command Module and Platform Support

CLI Commands	WS-X6348-RJ45V ¹	WS-X6608-T1/E1 ²	WS-X6624-FXS ³
Inline-power related commands			
set port inlinepower	X ⁴		
set inlinepower defaultallocation	X		
show port inlinepower	X		
show environment power	X	X	X

Table 44-3 Voice-Related CLI Command Module and Platform Support (continued)

CLI Commands	WS-X6348-RJ45V ¹	WS-X6608-T1/E1 ²	WS-X6624-FXS ³
Voice-related commands			
set port auxiliaryvlan	X/X		
show port auxiliaryvlan	X/X		
set port voice interface		X	X
show port voice interface		X	X
show port voice	X	X	X
show port voice fdl		X	
show port voice active	X	X	X
QoS commands related to voice			
set port qos mod/port cos-ext	X/X		
set port qos mod/port trust-ext			
show port qos	X/X		

1. WS-X6348-RJ45V = 48-port 10/100BASE-TX switching module with voice daughter card.
2. WS-X6608-T1 and WS-X6608-E1 = 8-port T1/E1 ISDN PRI modules.
3. WS-X6624-FXS = 24-port FXS analog station interface module.
4. X = Command supported on Catalyst 6000 family switch only; XX = Command supported on Catalyst 4000, 5000, and 6000 family switches (note that all modules listed in Table 44-3 are supported only on Catalyst 6000 family switches).

Configuring Per-Port Power Management

This section describes per-port power management and the CLI commands used to configure power management for IP phones.



Note

To determine the exact power requirements for your configuration to ensure that you are within the system power budget, see the [“Determining System Power Requirements”](#) section on page 20-14.



Note

This section applies to the WS-X6348-RJ45V 10/100BASE-TX Ethernet switching module only. For information on powering IP phones connected to other Catalyst 10/100BASE-TX switching modules, refer to the *Catalyst Family Inline-Power Patch Panel Installation Note* publication.

For each IP phone connected to the WS-X6348-RJ45V module, the supervisor engine software allocates part of the available system power to power up and run the phone. The power can be applied on an individual port basis.

Only one IP phone can be powered per port; the phone must be connected directly to the switch port. If a second phone is daisy chained off the phone connected to the switch port, the second phone cannot be powered by the switch.

This section describes the following:

- [Using show Commands to Display Module Type and Version Information, page 44-11](#)
- [Power Management Modes, page 44-12](#)
- [Phone Detection Summary, page 44-14](#)
- [Error Detection and Handling, page 44-16](#)
- [Setting the Power Mode of a Port or Group of Ports, page 44-17](#)
- [Setting the Default Power Allocation for a Port, page 44-17](#)
- [Displaying the Power Status for Modules and Individual Ports, page 44-17](#)
- [Displaying the Power Status for Modules and Individual Ports, page 44-18](#)

Using show Commands to Display Module Type and Version Information

The Catalyst 6000 family 48-port 10/100BASE-TX Ethernet switching module has three versions:

- WS-X6248-RJ-45—standard 10/100BASE-TX switching module
- WS-X6348-RJ-45—enhanced 10/100BASE-TX switching module (enhanced QoS features and 128K per port packet buffers), accepts field-upgradable voice daughter card
- WS-X6348-RJ45V—enhanced 10/100BASE-TX switching module with voice daughter card

When you enter the **show module** command, the WS-X6348 modules both display as WS-X6348-RJ-45 in the “Model” field. To determine if the module has a voice daughter card installed, look at the “Sub” field. For example, in the following display, the 10/100BASE-TX module in slot 8 does not have a voice daughter card, while the module in slot 9 does have a voice daughter card.

To display module status and information, perform this task in normal mode:

Task	Command
Display module status and information.	show module [<i>mod</i>]

This example shows that there is a submodule field that provides information about submodules. The EARL daughter card is treated as a submodule while the Multilayer Switch Feature Card (MSFC) internal router is not treated as a submodule. The model number for the voice daughter card, as shown in the display, is WS-F6K-VPWR.

```

Console> (enable) show module
Mod Slot Ports Module-Type           Model                Sub Status
-----
 1   1     2   1000BaseX Supervisor    WS-X6K-SUP1A-2GE    yes ok
15   1     1   Multilayer Switch Feature WS-F6K-MSFC         no ok
 8   8    48   10/100BaseTX Ethernet   WS-X6348-RJ-45     no ok
 9   9    48   10/100BaseTX Ethernet   WS-X6348-RJ-45     yes ok

Mod Module-Name          Serial-Num
-----
 1                      SAD03436055
15                      SAD03432597
 9                      SAD03414268

Mod MAC-Address(es)      Hw   Fw   Sw
-----
 1  00-30-80-f7-a5-06 to 00-30-80-f7-a5-07 1.0   5.2(1) 6.2(0.32-Eng)FTL
    00-30-80-f7-a5-04 to 00-30-80-f7-a5-05

```

```

00-30-a3-4a-a0-00 to 00-30-a3-4a-a3-ff
15 00-d0-bc-ee-d0-dc to 00-d0-bc-ee-d1-1b 1.2    12.0(3)XE1 12.0(3)XE1
8  00-d0-c0-c8-83-ac to 00-d0-c0-c8-83-db 1.1    4.2(0.24)V6.1(0.37)FTL
9  00-50-3e-7c-43-00 to 00-50-3e-7c-43-2f 0.201  5.3(1)

Mod Sub-Type          Sub-Model          Sub-Serial  Sub-Hw
-----
1  L3 Switching Engine  WS-F6K-PFC        SAD03451187 1.0
9  Inline Power Module  WS-F6K-VPWR              1.0
Console> (enable)

```

To display the version of modules and submodules, perform this task in normal mode:

Task	Command
Display the version of modules and submodules.	show version [<i>mod</i>]

This example shows the version of modules and submodules:

```

Console> (enable) show version 2
Mod Port Model          Serial #  Versions
-----
2  2    WS-X6K-SUP2-2GE      SAD04450LF1 Hw : 1.1
                               Fw : 6.1(2)
                               Fw1: 6.1(3)
                               Sw : 6.3(0.62) PAN
                               Sw1: 6.3(0.62) PAN
           WS-F6K-PFC2      SAD04440HVU Hw : 1.0
Console>

```

Power Management Modes

Each port is configured through the CLI, SNMP, or a configuration file to be in one of the following modes (configured through the **set port inlinepower** CLI command):

- **Auto**—The supervisor engine directs the switching module to power up the port *only* if the switching module discovers the phone.
- **Off**—The supervisor engine does not direct the switching module to power up the port even if an unpowered phone is connected.

Each port also has a status, defined as one of the following:

- **on**—Power is supplied by the port.
- **off**—Power is not supplied by the port.
- **Power-deny**—The supervisor engine does not have enough power to allocate to the port; power is not being supplied by the port.
- **faulty**—The port is unable to provide power to the connected device.

These sections provide information related to IP phone power requirements and management:

- [Unpowered Phone, page 44-13](#)
- [Power Requirements, page 44-13](#)
- [Wall-Powered Phones, page 44-13](#)
- [Powering Off the Phone, page 44-14](#)
- [Phone Removal, page 44-14](#)
- [High-Availability Support, page 44-14](#)

Unpowered Phone

When an unpowered phone is discovered on a switching module port, the switching module reports to the supervisor engine that an unpowered phone is present and on which module/port. If the port is configured in **Auto** mode, the supervisor engine determines if there is enough available system power to allow the switching module to power up and run the phone. If there is sufficient power, the supervisor engine removes the *default allocated power* required by a phone from the total available system power and then sends a message to the switching module instructing it to provide power to the port. If there is not enough available power for the phone, the supervisor engine sends a message to the switching module indicating that power is denied to the port.

After power is applied to the port, the supervisor engine monitors the port to ensure that the link comes up. If the link does not come up within 4 seconds, the supervisor engine instructs the switching module to turn power off. The entire cycle is repeated, and the switching module performs discovery and reports to the supervisor engine if a device is present on the port.

Power Requirements

IP Phones may have different power requirements. The supervisor engine initially allocates the configured default of 7W (167 mA at 42V) to the Cisco IP Phone. When the correct amount of power is determined from the CDP messaging with the Cisco IP Phone, the supervisor engine reduces or increases the allocated power.

For example, the default allocated power is 7W. A Cisco IP Phone requiring 6.3W is plugged into a port. The supervisor engine allocates 7W for the Cisco IP Phone and powers it up. Once the Cisco IP Phone is operational, it sends a CDP message with the actual power requirement to the supervisor engine. The supervisor engine then decreases the allocated power to the required amount.

Wall-Powered Phones

When a wall-powered phone is present on a switching module port, the switching module cannot detect its presence. The supervisor engine discovers the phone through CDP messaging with the port. If the phone supports inline power (the supervisor engine determines this through CDP), and the mode is set to **Auto** or **Off**, the supervisor engine does not attempt to power on the port. If a power outage occurs, and the mode is set to **Auto**, the phone loses power, but the switching module discovers the phone and informs the supervisor engine, which then applies inline power to the phone.

Powering Off the Phone

The supervisor engine can turn off power to a specific port by sending a message to the switching module. That power is then added back to the available system power. This situation occurs only when you power off the phone through the CLI or SNMP.

Phone Removal

The switching module informs the supervisor engine if a *powered* phone is removed using a link-down message. The supervisor engine then adds the allocated power for that port back to the available system power.

In addition, the switching module informs the supervisor engine if an *unpowered* phone is removed.



Caution

When a phone cable is plugged into a port and power is turned on, the supervisor engine has a 4-second timeout waiting for the link to go up on the line. During those 4 seconds, if the phone cable is unplugged and a network device is plugged in, the device could be damaged. We recommend that you wait at least 10 seconds between unplugging a device and plugging in a new device.

High-Availability Support


To support high availability during a failover from the active supervisor engine to the standby supervisor engine, the per-port power management and phone status information is synchronized between the active and standby supervisor engines.

The information to be synchronized (on a per-port basis) is the presence of a phone, the phone power status (on, off, denied, or faulty), and the amount of power consumed by the phone. The active supervisor engine sends this information to the standby supervisor engine, and the standby supervisor engine updates its internal data structures. When a switchover occurs, the standby supervisor engine allocates power to the modules and ports from the available power, one module at a time. Once the power for each module has been allocated, the supervisor engine allocates power to the phones, beginning with the lowest slot number, until all inline powered ports have been either powered on, off, or denied.

Phone Detection Summary

[Figure 44-4](#) shows how the system detects a phone connected to a Catalyst 6000 family switch port.

Figure 44-4 Power Detection Summary



38205

Error Detection and Handling

This section describes how the Catalyst 6000 family switch handles fault detection and errors related to per-port power management.

These sections discuss fault detection and power-management error scenarios:

- [Device is Powered but Link is Not Up, page 44-16](#)
- [Port is Unable to Provide Inline Power to the Device, page 44-16](#)
- [Not Enough Available Power to Power the Device, page 44-16](#)
- [Power Supply Configured from Nonredundant to Redundant, page 44-16](#)
- [Power Supply Configured from Redundant to Nonredundant, page 44-16](#)

Device is Powered but Link is Not Up

The supervisor engine detects that the device is powered but the link is not up by setting a timeout when the switching module is directed to power up the device. If the timeout occurs and the supervisor engine has not received a “link up” for the port, this syslog message is displayed:

```
1999 Jul 14 10:05:58 %SYS-5-PORT_DEVICENOLINK: Device on Port 4/7 powered, no link up.
```

The supervisor engine also directs the switching module to power off the port. The switching module then performs discovery again on the port.

Port is Unable to Provide Inline Power to the Device

The switching module detects if there is a problem providing inline power to the device and reports this problem to the supervisor engine. This syslog message is displayed:

```
1999 Jul 14 10:05:58 %SYS-5-PORT_INLINEPWRFLTY: Port 4/7 reporting inline power as faulty.
```

Not Enough Available Power to Power the Device

The supervisor engine tracks the available power left in the system and does not power up any ports if no available power remains. This syslog message is displayed:

```
1999 Jul 14 10:05:58 %SYS-5-PORT_NOPOWERAVAIL: Device on Port 4/7 will remain unpowered.
```

The supervisor engine informs the switching module that power to the port is denied.

Power Supply Configured from Nonredundant to Redundant

Depending upon the number and type of modules in the chassis, you might need to power off some modules to prevent overdrawing power from the power supply. The supervisor engine first powers off and reallocates the power supplied by the ports and then starts powering off and reallocating the power used by the module.

Power Supply Configured from Redundant to Nonredundant

Once a module that was powered down due to lack of power is powered up and comes online, the module begins discovery on the ports to determine the presence of unpowered connected devices (phones). The module reports discovered devices to the supervisor engine, which then directs the switching module to power up the device (if the port is configured to do so).

For modules that are already powered on, but have devices connected that are power denied, the supervisor engine attempts to power on the devices starting with the lowest numbered slot to the highest numbered slot, and from the lowest port number to the highest port number, one module at a time.

Setting the Power Mode of a Port or Group of Ports

To set the power mode of a port or group of ports, perform this task in normal mode:

Task	Command
Set the power mode of a port or group of ports.	set port inlinepower <i>mod/port</i> { off auto }

This example shows how to set the power mode of a port or group of ports:

```
Console> (enable) set port inlinepower 2/5 off
Inline power for port 2/5 set to off.
Console> (enable) set port inlinepower 2/3-9 auto
Inline power for ports 2/3-9 set to auto.
Console> (enable)
```

Setting the Default Power Allocation for a Port

To set the default power allocation for a port, perform this task in privileged mode:

Task	Command
Set the default power allocation for a port.	set inlinepower defaultallocation <i>value</i>

This example shows how to set the default power allocation for a port:

```
Console> (enable) set inlinepower defaultallocation 9500
Default inline power allocation set to 9500 mWatt per applicable port.
Console> (enable)
```

Displaying the Power Status for Modules and Individual Ports

To display the power status for modules and individual ports, perform this task in normal mode:

Task	Command
Display the power status for modules and individual ports.	show port inlinepower [<i>mod[/port]</i>]

This example shows how to display the power status for modules and individual ports:

```
Console> show port inlinepower 3/2-6
Default Inline Power allocation per port: 9.500 Watts (0.22 Amps @42V)
Total inline power drawn by module 3: 0 Watt
Port      InlinePowered      PowerAllocated
      Admin Oper   Detected  mWatt mA @42V
-----
3/2 auto on    yes      10.00 0.250
3/3 auto on    yes       9.8   0.198
3/4 auto denied yes       0     0
```

```

3/5 off off no 0 0
3/6 off off yes 0 0
Console> (enable)

```

The Operational (Oper) status field descriptions in the display are as follows:

- on—Power is supplied by the port.
- off—Power is not supplied by the port.
- denied—The system does not have enough available power for the port.
- faulty—The port is unable to supply power.

Displaying the Power Status for Modules and Individual Ports

To display the power status for modules and individual ports, perform this task in privileged mode:

Task	Command
Display the power status for modules and individual ports.	show environment power [<i>mod</i>]

This example shows how to display the power status for modules and individual ports:

```

Console> (enable) show environment power 5
Feature not supported on module 5.
Console> (enable) show environment power 9
Module 9:
Default Inline Power allocation per port: 9.500 Watts (0.22 Amps @42V)
Total inline power drawn by module 9: 0 Watt

Slot power Requirement/Usage :

Slot Card Type           PowerRequested PowerAllocated CardStatus
Watts   A @42V Watts   A @42V
-----
9   WS-X6348             123.06   2.93  123.06   2.93  ok

Default Inline Power allocation per port: 9.500 Watts (0.22 Amps @42V)
Port      InlinePowered   PowerAllocated
Admin Oper   Detected mWatt mA @42V
-----
9/1 auto off no 0 0
9/2 auto off no 0 0
9/3 auto off no 0 0
9/4 auto off no 0 0
9/5 auto off no 0 0
9/6 auto off no 0 0
9/7 auto off no 0 0
9/8 auto off no 0 0
.
(display text omitted)
.
9/48 auto off no 0 0
Console> (enable)

Console> (enable) show environment power
PS1 Capacity: 1153.32 Watts (27.46 Amps @ 42V)
PS2 Capacity: none

```

```

PS Configuration : PS1 and PS2 in Redundant Configuration.
Total Power Available: 1153.32 Watts (27.46 Amps @ 42V)
Total Power Available for Line Card Usage: 1153.32 Watts (27.46 Amps @ 42V)
Total Power Drawn From the System: 289.80 Watts (6.90 Amps @ 42V)
Remaining Power in the System: 863.52 Watts (20.56 Amps @42V)
Default inline power allocation: 10.5 Watts/port (0.25 Amps @ 42V)

```

Slot power Requirement/Usage :

Slot	Card-Type	Power-Requested		Power-Allocated		Card-Status
		Watts	A @ 42V	Watts	A @ 42V	
1		0.00	0.00	126.42	3.01	none
2	WS-X6K-SUP1-2GE	138.60	3.30	138.60	3.30	ok
3	WS-X6348-RJ-45	114.24	2.72	151.20	3.60	ok
5	WS-X6348-RJ-45	109.20	2.60	100.88	2.40	partial-deny
6	Unknown	112.98	2.69	0	0	unknown
7	WS-X6248-RJ-45	84.84	2.02	0	0	power-bad
9	WS-X6416-GE-MT	105.00	2.50	0	0	power-deny

Console> (enable)

A partial-deny status indicates that some module ports are inline powered but not all the ports on the module are inline powered.

Configuring Auxiliary VLANs on Catalyst LAN Switches

These sections describe how to configure auxiliary VLANs:

- [Understanding Auxiliary VLANs, page 44-19](#)
- [Auxiliary VLAN Configuration Guidelines, page 44-20](#)
- [Configuring Auxiliary VLANs, page 44-20](#)
- [Verifying Auxiliary VLAN Configuration, page 44-21](#)

Understanding Auxiliary VLANs

You can configure switch ports to send CDP packets that instruct an attached Cisco IP Phone 7960 to transmit voice traffic to the switch in these frame types:

- 802.1Q frames carrying the auxiliary VLAN ID and Layer 2 CoS set to 5 (the switch port drops all 802.1Q frames except those carrying the auxiliary VLAN ID).
 - Reset the Cisco IP Phone 7960 if the auxiliary VLAN ID changes.
 - Enter the **set port auxiliaryvlan** *mod[/port] aux_vlan_id* command.



Note We recommend that you use 802.1Q frames and a separate VLAN.

- 802.1p frames, which are 802.1Q frames carrying VLAN ID 0 and Layer 2 CoS set to 5 (enter the **set port auxiliaryvlan** *mod[/port] dot1p* command)
- 802.3 frames, which are untagged and carry no VLAN ID and no Layer 2 CoS value (enter the **set port auxiliaryvlan** *mod[/port] untagged* command)



Note

The Cisco IP Phone 7960 always sets Layer 3 IP precedence to 5 in voice traffic.

Auxiliary VLAN Configuration Guidelines

Follow these guidelines when configuring auxiliary VLANs:

- An auxiliary VLAN port is operationally a trunk, even though it is not treated like a “normal” trunk port. When an auxiliary VLAN is added to a port and the **set dot1q-all-tagged** command is enabled, the **set dot1q-all-tagged** command tags the native VLAN on the port where the auxiliary VLAN is configured. A port with an auxiliary VLAN configured is not viewed as a dot1q trunk in the **show trunk** command output, but the port acts like a dot1q trunk if the **set dot1q-all-tagged** command is enabled.
- The IP phone and a device attached to the phone are in the same VLAN and must be in the same IP subnet:
 - If they use the same frame type
 - If the phone uses 802.1p frames and the device uses untagged frames
 - If the phone uses untagged frames and the device uses 802.1p frames
 - If the phone uses 802.1Q frames and the auxiliary VLAN equals the native VLAN
- The IP phone and a device attached to the phone cannot communicate if they are in the same VLAN and subnet but use different frame types, because traffic between devices in the same subnet is not routed (routing would eliminate the frame type difference).
- You cannot use switch commands to configure the frame type used by traffic received from a device attached to the phone’s access port.
- With software release 6.2(1) and later releases, dynamic ports can belong to two VLANs—a native VLAN and an auxiliary VLAN. See [Chapter 18, “Configuring Dynamic Port VLAN Membership with VMPS,”](#) for configuration details for auxiliary VLANs.

Configuring Auxiliary VLANs

To configure auxiliary VLANs, perform this task in privileged mode:

Task	Command
Configure auxiliary VLANs.	set port auxiliaryvlan <i>mod[/ports]</i> { <i>vlan</i> untagged dot1p none }

This example shows how to add voice ports to auxiliary VLANs, specify an encapsulation type, or specify that the VLAN will not send or receive CDP messages with voice-related information:

```

Console> (enable) set port auxiliaryvlan 2/1-3 222
Auxiliaryvlan 222 configuration successful.
AuxiliaryVlan AuxVlanStatus Mod/Ports
-----
222          active          1/2,2/1-3
Console> (enable) set port auxiliaryvlan 5/7 untagged
Port 5/7 allows the connected device send and receive untagged packets and without 802.1p
priority.
Console> (enable) set port auxiliaryvlan 5/9 dot1p
Port 5/9 allows the connected device send and receive packets with 802.1p priority.
Console> (enable) set port auxiliaryvlan 5/12 none
Port 5/12 will not allow sending CDP packets with Voice VLAN information.
Console> (enable)

```

The default setting is **none**. Table 44-4 lists the **set port auxiliaryvlan** command keywords and their descriptions.

Table 44-4 Keyword Descriptions

Keyword	Action of the Phone
dot1p	Specify that the phone send packets with 802.1p priority 5.
untagged	Specify that the phone send untagged packets.
none	Specify that the switch not send any auxiliary VLAN information in the CDP packets from that port.

Verifying Auxiliary VLAN Configuration

To verify auxiliary VLAN configuration status, perform this task in privileged mode:

Task	Command
Verify auxiliary VLAN configuration status.	show port auxiliaryvlan {vlan untagged dot1p none }

This example shows how to verify auxiliary VLAN configuration status:

```
Console> show port auxiliaryvlan 123
AuxiliaryVlan AuxVlanStatus Mod/Ports
-----
222          active          1/2,2/1-3
Console>
```

Configuring the Access Gateways

This section describes the commands used to configure the following Catalyst 6000 family access gateway modules:

- Analog station gateway—24-port FXS analog interface module
- Digital trunk gateway—8-port T1/E1 PSTN interface module

Configuring Port Voice Interface

If DHCP is enabled for a port, the port obtains all other configuration information from the TFTP server. When disabling DHCP on a port, you must specify some mandatory parameters as follows:

- If you do not specify DNS parameters, the software uses the system DNS configuration on the supervisor engine to configure the port.
- 8-port T1/E1 PSTN interface module only: You cannot specify more than one port at a time because a unique IP address must be set for each port.

To configure port voice interface for DHCP, TFTP, and DNS servers, perform this task in privileged mode:

Task	Command
Configure port voice interface for DHCP, TFTP, and DNS servers.	<pre>set port voice interface mod/port dhcp enable [vlan vlan] set port voice interface mod/port dhcp disable {ipaddrspec} {tftp ipaddr} [vlan vlan] [gateway ipaddr] [dns [ipaddr] [domain_name]]</pre>

These examples shows how to configure the port voice interface for DHCP, TFTP, and DNS servers:

```
Console> (enable) set port voice interface 7/1 dhcp enable
Port 7/1 DHCP enabled.
```

```
Console> (enable) set port voice interface 7/3 dhcp disable 171.68.111.41/24 tftp
173.32.43.11 dns 172.20.34.204 cisco.com
Port 7/3 dhcp disabled.
System DNS configurations applied.
```

```
Console> (enable) set port voice interface 7/4-6 dhcp enable vlan 3
Vlan 3 configuration successful
Ports 7/4-6 DHCP enabled.
Console> (enable)
```

Displaying Port Voice Interface

To display the port voice interface configuration, perform this task in privileged mode:

Task	Command
Display the port voice interface configuration.	show port voice interface [mod[/port]]

This example shows how to display the port voice interface configuration (this display is from the 24-port FXS analog interface module):

```
Console> show port voice interface 5
Port    DHCP    MAC-Address    IP-Address    Subnet-Mask
-----
5/1-24  disable  00-10-7b-00-13-ea  10.6.15.158    255.255.255.0

Port    Call-Manager(s)  DHCP-Server    TFTP-Server    Gateway
-----
5/1-24  10.6.15.155      -              10.6.15.155    -

Port    DNS-Server(s)    Domain
-----
5/1-24  12.2.2.1*        cisco.cisco.com
        7.7.7.7
(*) : Primary
Console> (enable)
```

Displaying FDL Statistics



Note

FDL is a link management protocol used to help diagnose problems and gather statistics.

To display Facilities Data Link (FDL) statistics for the specified ports, perform this task in privileged mode:

Task	Command
Display FDL statistics for the specified ports.	show port voice fdl [<i>mod[/port]</i>]

This example shows how to display FDL statistics for the specified ports:

```

Console> (enable) show port voice fdl 7/1-3
Port  ErrorEvents      ErroredSecond      SeverlyErroredSecond
      Last 15' Last 24h Last 15' Last 24h Last 15' Last 24h
-----
7/1  17      18      19      20      21      22
7/2  17      18      19      20      21      22
7/3  17      18      19      20      21      22

Port  FailedSignalState FailedSignalSecond
      Last 15' Last 24h Last 15' Last 24h
-----
7/1  37      38      39      40
7/2  37      38      39      40
7/3  37      38      39      40

Port          LES          BES          LCV
      Last 15' Last 24h Last 15' Last 24h Last 15' Last 24h
-----
7/1  41      48      49      50      53      54
7/2  41      48      49      50      53      54
7/3  41      48      49      50      53      54
Console> (enable)

```

[Table 44-5](#) describes the possible fields (depending on the port type queried) in the **show port voice fdl** command output.

Table 44-5 FDL Field Descriptions

Field	Description
ErrorEvents	Count of errored events.
ErroredSecond	Count of errored seconds.
SeverlyErroredSecond	Count of severely errored seconds.
FailedSignalState	Count of failed signal state errors.
FailedSignalSecond	Count of errored events.
LES	Line errored seconds detected.
BES	Bursty errored seconds detected.
LCV	Line code violation seconds detected.

Displaying the Port Configuration for Individual Ports

To display the port configuration for individual ports, perform this task in normal mode:

Task	Command
Display the port configuration for individual ports.	show port [<i>mod[/port]</i>]

This section provides the **show port** command displays for the following gateway modules:

- [8-Port T1/E1 PSTN Interface Module, page 44-24](#)
- [8-Port T1/E1 PSTN Interface Module Configured for Truncoding/Conferencing, page 44-25](#)
- [24-Port FXS Analog Interface Module, page 44-26](#)

8-Port T1/E1 PSTN Interface Module

The Status field shows Layer 2 status of the ports. Possible values are notconnect, connected, disabled, and faulty. The following display is for the T1 module. The E1 module display would be the same except the port speed for the E1 module would be 2.048.

```
Console> show port 7
```

Port	Name	Status	Vlan	Duplex	Speed	Type
7/1		connected	123	full	1.544	T1
7/2		connected	2	full	1.544	T1
7/3		disable	1	full	1.544	T1
7/4		connected	11	full	1.544	T1
7/5		connected	123	full	1.544	T1
7/6		connected	1	full	1.544	T1
7/7		faulty	2	full	1.544	T1
7/8		faulty	2	full	1.544	T1

Port	DHCP	MAC-Address	IP-Address	Subnet-Mask
7/1	enable	00-10-7b-00-0a-58	172.20.34.68	255.255.255.0
7/2	enable	00-10-7b-00-0a-59	172.20.34.70	255.255.255.0
7/3	enable	00-10-7b-00-0a-5a	172.20.34.64	255.255.255.0
7/4	enable	00-10-7b-00-0a-5b	172.20.34.66	255.255.255.0
7/5	enable	00-10-7b-00-0a-5c	172.20.34.59	255.255.255.0
7/6	enable	00-10-7b-00-0a-5d	172.20.34.67	255.255.255.0
7/7	enable	00-10-7b-00-0a-5e	(Port host processor not online)	
7/8	enable	00-10-7b-00-0a-5f	(Port host processor not online)	

Port	Call-Manager(s)	DHCP-Server	TFTP-Sever	Gateway
7/1	172.20.34.207* callm.cisco.com	172.20.34.207	172.20.34.207	-
7/2	172.20.34.207	172.20.34.207	172.20.34.207	172.20.34.20
7/3	172.20.34.207	172.20.34.207	172.20.34.207	-
7/4	172.20.34.207	172.20.34.207	172.20.34.207	-
7/5	172.20.34.207	172.20.34.207	172.20.34.207	-
7/6	172.20.34.207	172.20.34.207	172.20.34.207	-
7/7	(Port host processor not online)			
7/8	(Port host processor not online)			

```

Port      DNS-Server (s)  Domain
-----
7/1      172.20.34.207  cisco.com
7/2      172.20.34.207* int.cisco.com
          171.69.45.34
          172.78.111.132
7/3      172.20.34.207  -
7/4      172.20.34.207  -
7/5      172.20.34.207  -
7/6      172.20.34.207  -
7/7      (Port host processor not online)
7/8      (Port host processor not online)

Port      CallManagerState DSP-Type
-----
7/1      registered      C549
7/2      registered      C549
7/3      registered      C549
7/4      registered      C549
7/5      registered      C549
7/6      notregistered   C549
7/7      (Port host processor not online)
7/8      (Port host processor not online)

Port      NoiseRegen NonLinearProcessing
-----
7/1      disabled      disabled
7/2      disabled      disabled
7/3      disabled      disabled
7/4      disabled      disabled
7/5      enabled        disabled
7/6      disabled      enabled
7/7      (Port host processor not online)
7/8      (Port host processor not online)

(*) : Primary
Console>

```

8-Port T1/E1 PSTN Interface Module Configured for Truncoding/Conferencing

MTP (media termination point) and Conf Bridge (conference bridge) are types of ports. Truncoding applies to a call on an MTP port.

In this example a truncoding port shows as “MTP” and a conference port shows as “Conf Bridge.”

```

Console> (enable) show port 7
Port  Name          Status      Vlan      Duplex Speed Type
-----
7/1   notconnect    1           full 1.544 T1
7/2   notconnect    1           full 1.544 T1
7/3   connected     1           full 1.544 T1
7/4   connected     1           full 1.544 T1
7/5   connected     1           full 1.544 T1
7/6   connected     1           full 1.544 T1
7/7   enabled       1           full    - Conf Bridge
7/8   enabled       1           full    - MTP

Port      DHCP      MAC-Address      IP-Address      Subnet-Mask
-----
7/1      enable   00-10-7b-00-12-08 10.6.15.165     255.255.255.0
7/2      enable   00-10-7b-00-12-09 10.6.15.166     255.255.255.0
7/3      enable   00-10-7b-00-12-0a 10.6.15.167     255.255.255.0

```

```

7/4    enable  00-10-7b-00-12-0b 10.6.15.168    255.255.255.0
7/5    enable  00-10-7b-00-12-0c 10.6.15.169    255.255.255.0
7/6    enable  00-10-7b-00-12-0d 10.6.15.170    255.255.255.0
7/7    enable  00-10-7b-00-12-0e 10.6.15.171    255.255.255.0
7/8    enable  00-10-7b-00-12-0f 10.6.15.172    255.255.255.0

```

```

Port    Call-Manager(s)    DHCP-Server    TFTP-Server    Gateway
-----
7/1     10.6.15.155       10.6.15.155    10.6.15.155    -
7/2     10.6.15.155       10.6.15.155    10.6.15.155    -
7/3     10.6.15.155       10.6.15.155    10.6.15.155    -
7/4     10.6.15.155       10.6.15.155    10.6.15.155    -
7/5     10.6.15.155       10.6.15.155    10.6.15.155    -
7/6     10.6.15.155       10.6.15.155    10.6.15.155    -
7/7     10.6.15.155       10.6.15.155    10.6.15.155    -
7/8     10.6.15.155       10.6.15.155    10.6.15.155    -

```

```

Port    DNS-Server(s)    Domain
-----
7/1     -                -
7/2     -                -
7/3     -                -
7/4     -                -
7/5     -                -
7/6     -                -
7/7     -                -
7/8     -                -

```

```

Port    CallManagerState    DSP-Type
-----
7/1     registered          C549
7/2     registered          C549
7/3     registered          C549
7/4     registered          C549
7/5     registered          C549
7/6     registered          C549
7/7     registered          C549
7/8     registered          C549

```

```

Port    NoiseRegen    NonLinearProcessing
-----
7/1     enabled       enabled
7/2     enabled       enabled
7/3     enabled       enabled
7/4     enabled       enabled
7/5     enabled       enabled
7/6     enabled       enabled
7/7     disabled      disabled
7/8     disabled      disabled
Console> (enable)

```

24-Port FXS Analog Interface Module

In this example all ports should have a Type of FXS, and all ports in the same module should belong to one VLAN:

```

Console> (enable) show port 3
Port  Name          Status      Vlan      Duplex  Speed  Type
-----
3/1   onhook        onhook      1         full    64k    FXS
3/2   onhook        onhook      1         full    64k    FXS
3/3   onhook        onhook      1         full    64k    FXS
3/4   onhook        onhook      1         full    64k    FXS

```

```

3/5          onhook      1          full      64k FXS
3/6          onhook      1          full      64k FXS
3/7          onhook      1          full      64k FXS
3/8          offhook     1          full      64k FXS
3/9          offhook     1          full      64k FXS
3/10         onhook      1          full      64k FXS
3/11         onhook      1          full      64k FXS
3/12         onhook      1          full      64k FXS
3/13         onhook      1          full      64k FXS
3/14         onhook      1          full      64k FXS
3/15         onhook      1          full      64k FXS
3/16         onhook      1          full      64k FXS
3/17         onhook      1          full      64k FXS
3/18         onhook      1          full      64k FXS
3/19         onhook      1          full      64k FXS
3/20         onhook      1          full      64k FXS
3/21         onhook      1          full      64k FXS
3/22         onhook      1          full      64k FXS
3/23         onhook      1          full      64k FXS
3/24         onhook      1          full      64k FXS

```

```

Port      DHCP      MAC-Address      IP-Address      Subnet-Mask
-----
3/1-24   enable   00-10-7b-00-13-e4 172.20.34.50    255.255.255.0

```

```

Port      Call-Manager(s)  DHCP-Server      TFTP-Sever      Gateway
-----
3/1-24   172.20.34.207    172.20.34.207    172.20.34.207  -

```

```

Port      DNS-Server(s)    Domain
-----
3/1-24   172.20.34.207*   cisco.com
          172.34.23.111

```

```

Port      CallManagerState DSP-Type
-----
3/1-24   registered        C549

```

```

Port      ToneLocal      Impedance InputGain(dB) OutputAtten(dB)
-----
3/1-24   northamerica   0          0          0

```

```

Port      RingFreq Timing      Timing      Timing      Timing
      (Hz)      Digit(ms) InterDigit(ms) Pulse(ms) PulseDigit(ms)
-----
3/1-24   20        100        100        0          0

```

```

(*) : Primary
Console> (enable)

```

Displaying Active Call Information

Enter the **show port voice active** command to display active call information on a port. There are up to 8 calls per port for the 8-port T1/E1 PSTN interface module but only one call per port for the 24-port FXS analog station interface module.

To display active call information, perform this task in normal mode:

Task	Command
Display active call information.	show port voice active [<i>mod/port</i>] [all call conference transcode] [<i>ipaddr</i>]

Entering the **show port voice active** command without any parameters shows all the calls in the system (regular calls, conference calls, and transcoding calls). Display field descriptions are as follows:

- **Type**—The “call” notation is for 24-port FXS analog interface module and 8-port PSTN interface module calls.
When you configure 8-port T1/E1 PSTN interfaces for transcoding and/or conferencing, the Type field displays “conferencing” for conferencing calls and “transcoding” for transcoding calls.
- **Conference-ID, Transcoding-ID, and Party-ID** are only applicable to 8-port T1/E1 PSTN interfaces configured for transcoding and/or conferencing.

This example shows all active calls in the system:

```

Console> show port voice active
Port  Type          Total  Conference-ID/ Party-ID  IP-Address
              Transcoding-ID
-----
3/1  call             1      -         -         199.22.25.254
3/2  call             1      -         -         172.225.25.54
4/5  call             3      -         -         165.34.234.111
              172.32.34.12
              198.96.23.111
3/8  conferencing    2      1         1         255.255.255.241
              2         2         173.23.13.42
              3         3         198.97.123.98
              5         5         182.34.54.26
              2         1         199.22.25.25
              3         3         182.34.54.2
              6         6         121.43.23.43
3/2  call             1      -         -         172.225.25.54
3/8  transcoding     1      1         1         255.255.255.241
              2         2         183.32.43.3

```

This example shows how to display detailed call information for a port (specifying the module only, this example shows detailed call information for all ports on the module):

```

Console> show port voice active 3/2
Port 3/2:
Channel #1:
  Remote IP address      : 165.34.234.111
  Remote UDP port       : 124
  Call state             : Ringing
  Codec Type            : G.711
  Coder Type Rate       : 35243
  Tx duration           : 438543 sec
  Voice Tx duration     : 34534 sec
  ACOM Level Current    : 123213
  ERL Level             : 123 dB
  Fax Transmit Duration : 332433
  Hi Water Payout Delay : 23004 ms
  Logical If index      : 4
  Low water payout delay : 234 ms
  Receive delay         : 23423 ms
  Receive bytes         : 2342342332423

```

```

Receive packets           : 23423423402384
Transmit bytes            : 23472377
Transmit packets         : 94540
Channel #2:
Remote IP address        : 165.34.234.112
Remote UDP port          : 125
Call state               : Ringing
Codec Type               : G.711
Coder Type Rate         : 35243
Tx duration              : 438543 sec
Voice Tx duration        : 34534 sec
ACOM Level Current       : 123213
ERL Level                : 123 dB
Fax Transmit Duration    : 332433
Hi Water Playout Delay   : 23004 ms
Logical If index         : 4
Low water playout delay  : 234 ms
Receive delay            : 23423 ms
Receive bytes            : 2342342332423
Receive packets         : 23423423402384
Transmit bytes           : 23472377
Transmit packets        : 94540
Channel #3:
.
(display text omitted)
.
Console>

```

This example shows how to display a specific call at a specified IP address:

```

Console> show port voice active 3/2 171.69.67.91
Remote IP address        : 171.69.67.91
Remote UDP port          : 125
Call state               : Ringing
Codec Type               : G.711
Coder Type Rate         : 35243
Tx duration              : 438543 sec
Voice Tx duration        : 34534 sec
ACOM Level Current       : 123213
ERL Level                : 123 dB
Fax Transmit Duration    : 332433
Hi Water Playout Delay   : 23004 ms
Logical If index         : 4
Low water playout delay  : 234 ms
Receive delay            : 23423 ms
Receive bytes            : 2342342332423
Receive packets         : 23423423402384
Transmit bytes           : 23472377
Transmit packets        : 94540
Console>

```

Configuring QoS in the Cisco IP Phone 7960

These sections describe QoS in the Cisco IP Phone 7960:

- [Understanding How QoS Works in the Cisco IP Phone 7960, page 44-30](#)
- [Configuring QoS in the Cisco IP Phone 7960, page 44-30](#)

Understanding How QoS Works in the Cisco IP Phone 7960

**Note**

The Cisco IP Phone 7960 always sets Layer 3 IP precedence and Layer 2 CoS to 5 in voice traffic generated by the phone. The Layer 3 IP precedence and Layer 2 CoS values in voice traffic generated by the phone are not configurable.

You can configure the Cisco IP Phone 7960 access port (see [Figure 44-5](#)) to either *trusted* or *untrusted* mode.

Untrusted mode means that all traffic in 802.1Q or 802.1p frames received through the access port is marked with a configured Layer 2 CoS value. The default Layer 2 CoS value is 0. Untrusted mode is the default when the phone is connected to a Cisco LAN switch.

Trusted mode means that all traffic received through the access port passes through the phone switch unchanged. Trusted mode is the default when the phone is not connected to a Cisco LAN switch.

Traffic in frame types other than 802.1Q or 802.1p passes through the phone switch unchanged, regardless of the access port trust state.

Figure 44-5 Configuring QoS on the IP Phone Ports

Configuring QoS in the Cisco IP Phone 7960

These sections describe how to configure QoS in the Cisco IP Phone 7960:

- [Setting the Phone Access Port Trust Mode, page 44-31](#)
- [Setting the Phone Access Port CoS Value, page 44-31](#)
- [Verifying the Phone Access Port QoS Configuration, page 44-31](#)

Setting the Phone Access Port Trust Mode

To set the phone access port trust mode, perform this task in privileged mode:

Task	Command
Set the phone access port trust mode.	set port qos <i>mod/ports...</i> trust-ext { trusted untrusted }

This example shows how to set the phone access port to the trusted mode:

```
Console> (enable) set port qos 3/7 trust-ext trusted
Port in the phone device connected to port 3/7 is configured to be trusted.
Console> (enable)
```

This example shows how to set the phone access port to the untrusted mode:

```
Console> (enable) set port qos 3/7 trust-ext untrusted
Port in the phone device connected to port 3/7 is configured to be untrusted.
Console> (enable)
```

Setting the Phone Access Port CoS Value

To set the phone access port CoS value, perform this task in privileged mode:

Task	Command
Set the phone access port CoS value.	set port qos <i>mod/ports</i> cos <i>cos_value</i> set port qos <i>mod/ports</i> cos-ext <i>cos_value</i>

This example shows how to set the Layer 2 CoS value used by a phone access port in untrusted mode:

```
Console> (enable) set port qos 2/1 cos-ext 3
Port 2/1 qos cos-ext set to 3.
Console> (enable)
```

Verifying the Phone Access Port QoS Configuration

To verify QoS configuration information, perform this task in normal mode:

Task	Command
Verify QoS configuration information.	show port qos [<i>mod[/port]</i>]

This example shows how to verify QoS configuration information:

```
Console> (enable) show port qos 3/4
<...Output Truncated...>
Port  Ext-Trust Ext-Cos
-----
 3/4  untrusted    0
<...Output Truncated...>
```

