



## CHAPTER 4

# Maintaining and Troubleshooting the ISDN System

---

Revised: March 12, 2009, OL-12436-03

## Introduction

This chapter describes ISDN maintenance and troubleshooting commands and procedures for the Cisco BTS 10200 Softswitch. See also the *Cisco BTS 10200 Softswitch Troubleshooting Guide* for more details about causes and corrective actions related to events and alarms.

## Status and Control Commands

This section describes the status and control commands for ISDN.

Table Name: ISDN-DCHAN

Table Containment Area: EMS, Call Agent

---

### Command Types

Status and control

---

### Examples

```
Status isdn-dchan dchan-type=primary;
Status isdn-dchan dchan-type= backup;
Control isdn-dchan dchan-type=primary; mode=forced; target-state=oos;
Control isdn-dchan dchan-type=backup; mode=forced; target-state=oos;
Control isdn-dchan dchan-type=primary; mode=forced; target-state=ins;
Control isdn-dchan dchan-type=backup; mode=forced; target-state=ins;
```

**Usage Guidelines**

Table 4-1 describes the D-channel operational status to status output mappings.

**Table 4-1 D-Channel Operational Status to Status Output Mapping**

<b>D-Channel Operational Status</b>	<b>Status Output</b>
DCHAN_OOS	ISDN D-Channel is Out-Of-Service
DCHAN_INS	ISDN D-Channel is In-Service
DCHAN_RESTORE_SESSION_SET_REQ_NORMAL	ISDN D-Channel restore session set request normal
DCHAN_RESTORE_SESSION_SET_REQ_SWITCHOVER	ISDN D-Channel restore session set request switchover
DCHAN_RESTORE_SESSION_SET_FAIL_NORMAL	ISDN D-Channel restore session set fail normal
DCHAN_RESTORE_SESSION_SET_FAIL_SWITCHOVER	ISDN D-Channel restore session set fail switchover
DCHAN_RESTORE_SCTP_ASSOC_REQ_NORMAL	ISDN D-Channel restore SCTP association request normal
DCHAN_RESTORE_SCTP_ASSOC_REQ_SWITCHOVER	ISDN D-Channel restore SCTP association request switchover
DCHAN_RESTORE_SCTP_ASSOC_ESTB_NORMAL	ISDN D-Channel restore SCTP association establish normal
DCHAN_RESTORE_SCTP_ASSOC_ESTB_SWITCHOVER	ISDN D-Channel restore SCTP association establish switchover
DCHAN_RESTORE_IUA_ACTIVE_NORMAL	ISDN D-Channel restore IUA layer active normal
DCHAN_RESTORE_IUA_ACTIVE_SWITCHOVER	ISDN D-Channel restore IUA layer active switchover
DCHAN_RESTORE_ESTABLISH_REQ_NORMAL	ISDN D-Channel restore establish request normal
DCHAN_RESTORE_ESTABLISH_REQ_SWITCHOVER	ISDN D-Channel restore establish request switchover
DCHAN_RESTORE_ESTABLISH_FAIL_NORMAL	ISDN D-Channel restore establish fail normal
DCHAN_RESTORE_ESTABLISH_FAIL_SWITCHOVER	ISDN D-Channel restore establish fail switchover
DCHAN_DOWN_SESSION_SET_FAIL_SOFT_NORMAL	ISDN D-Channel down session set fail soft normal
DCHAN_DOWN_SESSION_SET_FAIL_HARD_NORMAL	ISDN D-Channel down session set fail hard normal
DCHAN_DOWN_SCTP_ASSOC_FAIL_SOFT_NORMAL	ISDN D-Channel down SCTP association fail soft normal
DCHAN_DOWN_SCTP_ASSOC_FAIL_HARD_NORMAL	ISDN D-Channel down SCTP association fail hard normal
DCHAN_DOWN_IUA_INACTIVE_SOFT_NORMAL	ISDN D-Channel down IUA layer inactive soft normal

**Table 4-1 D-Channel Operational Status to Status Output Mapping (continued)**

D-Channel Operational Status	Status Output
DCHAN_DOWN_IUA_INACTIVE_HARD_NORMAL	ISDN D-Channel down IUA layer inactive hard normal
DCHAN_DOWN_ESTABLISH_REQ_SOFT_NORMAL	ISDN D-Channel down establish request soft normal
DCHAN_DOWN_ESTABLISH_REQ_HARD_NORMAL	ISDN D-Channel down establish request hard normal
DCHAN_DOWN_ESTABLISH_FAIL_SOFT_NORMAL	ISDN D-Channel down establish fail soft normal
DCHAN_DOWN_ESTABLISH_FAIL_HARD_NORMAL	ISDN D-Channel down establish fail hard normal
DCHAN_REMOVE_RELEASE_REQ	ISDN D-Channel remove release request
DCHAN_REMOVE_SESSION_SET_REQ	ISDN D-Channel remove session set request
DCHAN_REMOVE_SCTP_ASSOC_REQ	ISDN D-Channel remove SCTP association request
ISDN_DCHAN_REMOVE_GRACEFUL	ISDN D-Channel remove gracefully

Table 4-2 describes the D-channel NFAS operational status to status output mappings.

**Table 4-2 D-Channel NFAS Operational Status to Status Output Mapping**

D-Channel NFAS Operational Status	Status Output
ISDN_DCHAN_STATE_MOOS	ISDN D-Channel is Manual Out-of-Service
ISDN_DCHAN_STATE_SESSION_DOWN	ISDN D-Channel is Backhaul Session Down
ISDN_DCHAN_STATE_SESSION_UP	ISDN D-Channel is Backhaul Session Up
ISDN_DCHAN_STATE_OOS	ISDN D-Channel is Out-of-Service
ISDN_DCHAN_STATE_ESTB_REQ	ISDN D-Channel sent Establish Request
ISDN_DCHAN_STATE_REL_REQ	ISDN D-Channel sent Release Request
ISDN_DCHAN_STATE_IS	ISDN D-Channel is In-Service
ISDN_DCHAN_STATE_MB	ISDN D-Channel is Maintenance Busy
ISDN_DCHAN_STATE_WAIT	ISDN D-Channel is in Wait for Service Ack
ISDN_DCHAN_STATE_STBY	ISDN D-Channel is Standby
ISDN_DCHAN_STATE_CREATE_SCTP_ASSOC	ISDN D-Channel create SCTP Assoc Request
ISDN_DCHAN_STATE_SCTP_ASSOC_ESTB	ISDN D-Channel SCTP Assoc Established
ISDN_DCHAN_STATE_DELETE_SCTP_ASSOC	ISDN D-Channel delete SCTP Assoc Request

**Syntax Description**

See the *Cisco BTS 10200 Softswitch Command Line Interface Guide for Call Processing*, Chapter 6, ISDN D-Channel section for token information.

# How to Troubleshoot When the ISDN D-Channel Fails to Restore

This section shows how to troubleshoot if the ISDN D-channel fails to restore. Determine if the D-channel failed to restore by entering the following command:

```
status isdn-dchan id=nnn;dchan-type=<primary | backup>;
```

- If the response shows that the D-channel is out-of-service for the administrative state, then enter the control command.

```
status isdn-dchan id=100;dchan-type=primary
```

```
REASON -> ADM executed successfully
RESULT -> ADM configure result in success
ISDN DCHAN ID -> 100
DCHAN TYPE -> PRIMARY
ADMIN STATE -> ADMIN_OOS
OPER STATE -> ISDN D-Channel is Out-Of-Service
```

```
Reply : Success: at 2007-01-03 14:56:18 by btsadmin
```

```
control isdn-dchan id=nnn;dchan-type=<primary | backup>;target-state=ins
```

- If the response does not show that the D-channel is *in-service* (NFAS or D-channel backup may also show ISDN\_DCHAN\_STATE\_INS for the D-channel operational status), then:
  - If the response is *ISDN D-Channel out-of-service* go to Step 1.
  - If the response is *ISDN D-Channel restore session set fail normal or switchover* go to Step 2.
  - If the response is *ISDN D-Channel restore establish fail normal or switchover* go to Step 3.
  - If the response is *ISDN D-Channel is in Wait for Service Ack* or *ISDN D-Channel is Maintenance Busy* go to Step 4.
  - If the response is *ISDN D-Channel down session set fail hard normal* go to Step 5.
  - If the response is *ISDN D-Channel down establish fail hard normal* go to Step 6.
  - If the response is *ISDN D-Channel delete graceful* go to Step 7.

---

**Step 1** D-channel state for FAS: *ISDN D-Channel out-of-service*, or NFAS: *ISDN D-Channel is Manual Out-of-Service*.

This means the administrative state was set to in service, but the command to go to operational state was ignored due to bad provisioning.

### Things to Check:

Make sure that the correct entries exist in the ISDN D-Channel table.

**Step 2** D-channel states for FAS: *ISDN D-Channel restore establish fail normal or switchover*; or NFAS: *ISDN D-Channel is Backhaul Session Down*.

This means the Call Agent and the media gateway are not communicating. The backhaul session is not coming up. The problem has to do with the UDP port numbers, IP addresses or DNS names, or network connectivity. These values are all provisioned in the RUDP Backhaul Session table in the Call Agent. For Cisco IOS gateways, these values are part of the *session group groupn....*

**Things to Check:**

- a. Do the four entries in the RUDP Backhaul Session table of the Call Agent match the values in the gateway (for Cisco IOS gateways, these values are part of session group groupn...)?
- b. If the call-agent-tsap-addr, or the mgw-tsap-addr are DNS names, does **nslookup** on both Call Agents resolve the values to one unique IP address?
- c. Can the call-agent-tsap-addr in the four entries be pinged from the media gateway? Do the Call Agents actually have the IP addresses, or DNS names, specified?
- d. Can the mgw-tsap-addr be pinged from both Call Agents?
- e. Does the isdn-dchan-profile exist (show isdn-dchan-profile id=%)? Keep in mind that the profile id is case sensitive.
- f. Snoop can be used to see if the gateway and Call Agent are talking in order to establish the session. Snoop can be used to eliminate whether the problem is on the Call Agent or the media gateway side.
- g. The **show backhaul session all** command on the media gateway can be useful in debugging.
- h. Look at the trace.log on the Call Agent. Search for BSM\_create\_ss or bsm\_create\_ss. This shows the exact values used by the Call Agent.



**Note**

---

Backhaul deletion is triggered by all D-channels of a backhaul-set being in the admin-oss state. Backhaul creation is triggered by controlling one of the trunk groups to INS. Determine the D-channel list using the **show isdn-dchan set-id** command.

---

- Step 3** D-channel states for FAS: *ISDN D-Channel restore establish fail normal or switchover* or NFAS: *ISDN D-Channel sent Establish Request*.

This means the specific ISDN D-channel could not be restored. This is likely related to ISDN layer1 or layer2 not being up, or related to DCHAN-SLOT and DCHAN-PORT in the ISDN D Channel table. The media gateway and Call Agent are communicating successfully (session came up).

**Things to Check:**

- a. On the media gateway, enter a **show isdn status command**. Is Layer 1 shown as ACTIVE? If not, there may be a cable problem, or the PBX is down.
- b. Does the **show isdn status** command return a *Network side configuration*? The PBX should be set up for the user side. The gateway should be setup for the network side.
- c. Was the media gateway reloaded (rebooted) after setting up parameters? There can be problems when this has not been done. This is usually reflected by having two TEI values for the T1.
- d. Are the DCHAN-SLOT and DCHAN-PORT provisioned correctly in the ISDN D Channel table?
- e. Does the T1 on the media gateway show an alarm (red or yellow lights)? These are more clues that there is an ISDN layer1 or layer2 problem.
- f. Is the controller T1, or interface Serialn:23, provisioned correctly on the gateway?
- g. Look at the trace.log on the Call Agent. Search for BSM\_dchan\_tbl\_insert or bsm\_dchan\_tbl\_insert. The slot-port value is the actual value retrieved from the database. For the AS5300, this value should be 0, 1, 2, or 3. This is a decimal value. The top 16 bits are the slot and the bottom 16 bits are the port.

- Step 4** D-channel states for NFAS: *ISDN D-Channel is in Wait for Service Ack* or *ISDN D-Channel is Maintenance Busy*.

This means the states at the far end are going to send a SERVICE\_ACK to the Cisco BTS 10200 Softswitch service message for PRI.

**Things to Check:**

Make sure the far end is sending a SERVICE\_ACK. There are some other D-channel states that happen after the ISDN backhaul is successfully established.

- Step 5** Trunk group states for FAS: *ISDN D-Channel down session set fail hard normal* or NFAS: *ISDN D-Channel is Backhaul Session Down*.

This is the same as *ISDN D-Channel restore session set fail normal* or *ISDN D-Channel is Backhaul Session Down*. However, in this case, the backhaul session was already successfully established, and then went out. This likely means that the Call Agent and media gateway have lost IP connectivity. Or, the media gateway has lost power. This can also happen if the provisioning was changed, particularly the session settings in the media gateway.

- Step 6** D-channel states for FAS: *ISDN D-Channel down establish fail hard normal* or NFAS: *ISDN D-Channel sent Establish Request*.

This is the same as *ISDN D-Channel restore establish fail normal* or *ISDN D-Channel sent Establish Request*. However, in this case, the D channel was already successfully established, and then went out.

**Things to Check:**

- a. Is, or was, the cable unplugged between the PBX and the gateway?
- b. Was the provisioning changed on the gateway?

**Step 7** Trunk group state for FAS: *ISDN D-Channel delete graceful*.

The following command indicates you are waiting for calls to finish before going to out-of-service. If the wait time is too long, you can control the trunk group with *mode=forced*.

```
control isdn-dchan id=xxxx; mode=graceful; target-state=oos;dchan-type=<primary | backup>
```

---

## Checking the Status of a Trunk Termination

Check the status of a trunk termination using the following command:

```
status trunk-termination tgn-id=<trunk group number>;cic=<cic number>;
```

```
Reply : Success:
```

```
TGN_ID -> 100
CIC -> 8
RESULT -> ADM configure result in success
REASON -> ADM executed successfully
TERM_ADMIN_STATE -> ADMIN_INS
TERM_OPER_STATE -> Term is available for new calls
TERM_REASON -> No fault reason available
TRUNK_STATIC_STATE -> ACTV
TRUNK_DYNAMIC_STATE -> IDLE
TRUNK_REASON -> NON_FAULTY
```

```
Reply : Success: at 2007-01-03 15:41:32 by btsadmin
Entry 1 of 1 returned.
```

The above status shows that the trunk is active, in idle mode, and ready for call use.

If the trunk static state is set to locally blocked, go to the [“Trunk Static State Is Set to Locally Blocked”](#) section.

If the trunk static state is set to TRNS, go to the [“Trunk Static State Is Set to TRNS”](#) section.

If the trunk static state is set to remotely blocked, go to the [“Trunk Static State Is Set to RBLK”](#) section.

If the trunk static state is set to TERM\_STATUS\_FAULTY, go to the [“Termination Status Is Faulty”](#) section.

If the trunk static state returns Cannot Make Call, go to the [“Cannot Make a Call”](#) section.

## Trunk Static State Is Set to Locally Blocked

Perform the following steps to check the *TRUNK REASON* field if the *TRUNK STATIC STATE* is set to locally blocked (LBLK) state.

- 
- Step 1** If the *TRUNK REASON* is set to MAINT-OOS, then a user has manually taken the trunks out of service. The user must manually put the trunks into the in-service mode.
- Use the **control** command on the specified trunk to put the trunk back into the in-service mode.
- Clear the MAINT-OOS. Trunks should be in active or idle mode and ready for use.
- Step 2** If the *TRUNK REASON* is set to SIGNALLING-FAULT, then the D channels are not in-service. Check the D-channels ADMIN and OPER states.
- If the D-channel ADMIN state is ADMIN\_OOS, use the **control** command to put the D-channel into in-service mode.
  - If the D-channel ADMIN state is ADMIN\_INS, verify that the D-channel OPER-STATE is IN-SERVICE (see the [How to Troubleshoot When the ISDN D-Channel Fails to Restore](#) section in case of any issues).
  - Clear any SIGNALLING-FAULT states. Trunks must be in active or idle mode and ready for use.
- Step 3** If *TRUNK REASON* is set to TERM\_FAULT, then the terminations are in FAULTY states. Verify the IP connectivity from the CA to the gateway.
- a. Clear any termination faults at the gateway by turning off, then turning on, MGCP (use the mgcp, no mgcp procedure on the media gateway).
  - b. Clear any TERM\_FAULT on the Cisco BTS 10200 Softswitch. Trunks must be in active or idle mode and ready for use.
- 

## Trunk Static State Is Set to TRNS

Perform the following steps when trunk static state is set to TRNS.



### Note

If trunk static state is set to TRNS, then the PBX has not responded with a SERVICE\_ACK or RESTART\_ACK for the service or restart message set by the Call Agent.

---

- Step 1** Verify that the initialization procedure, as depicted by the associated isdn-dchan-profile, and as used by PBX, is synchronized.
- Step 2** Verify that the isdn-service-supp token is set to N if PBX does not support service messages.
-

## Trunk Static State Is Set to RBLK

Perform the following steps if trunk static state is set to RBLK.

**Note**

If the trunk static state is set to RBLK, and isdn-dchan-profile has isdn-farend-init=Y then the PBX must start the initialization procedure, or the PBX specifically sends a service message with SERVICE-OOS mode to the Cisco BTS 10200 Softswitch to put the trunks into the remote out-of-state mode.

- 
- Step 1** Verify that the initialization procedure (ISDN-FAREND-INIT token), as depicted by associated isdn-dchan-profile in the Cisco BTS 10200 Softswitch, and as used by the PBX, is in sync.
- Step 2** Using the CLI command “control trunk-termination” to reset the RBLK state, perform a control trunk-termination to OOS, then control trunk-termination to INS—in case there is an error on the PBX side. Also, set the isdn-service-supp token in the ISDN D-channel group profile per the procedures supported by the PBX.
- 

## Termination Status Is Faulty

The *TERM\_STATUS\_FAULTY* message indicates an MGCP problem.

**Things to Check:**

- Is the MGW profile set up for the trunk?
- Is the MGW in the in-service operational state?

Perform the “no mgcp, mgcp” commands on the gateway if an MGCP problem is indicated.

## Cannot Make a Call

If you have a problem making a call, perform the following Things to Check, and then go to the [“Checking MGW Provisioning” section on page 4-11](#)

**Things to Check:**

When terminations are added, they have strings like S0/DS1-2/1. The S# refers to the slot number. The DS1-# refers to the port number. The /# at the end refers to the specific B channel (1–23). The slot and port numbers must match the dchan values (dchan-slot, dchan-port) for the related D-channel id (dchan-id), assuming that the DS0 is on a T1 that contains a D channel.

**Things to Check:**

- Are all Cisco BTS 10200 Softswitch ethernet cables plugged in and intact?
- Are all gateway ethernet cables plugged in and intact?

## IUA Traces

The existing Cisco BTS 10200 Softswitch trace capability is used to troubleshoot IUA and SCTP. Use the `get-trace` and `set-trace` CLI commands to enable and disable various trace details of the IUA/SCTP protocol at run time. Set the IUM process trace levels to INFO5 to enable IUA/SCTP traces.

The Call Agent table has an additional field, `IUA-DEBUG-LEVEL`, to enable and disable various trace details of the IUA stack using the `get-trace` and `set-trace` commands. The `IUA-DEBUG-LEVEL` can be set to any of the following:

- `ERROR` (Default)— Only error traces
- `STATE`— State transitions and errors.
- `PACKET`— IUA packets sent or received and errors
- `ALL`— SCTP signals received from SCTP stack, state transitions, IUA packets sent or received and errors.

The following example CLI command enables specific trace details:

```
set-trace call-agent id=CA146; trace-sctp-api=y; trace-sctp-txrxchunks=y;
trace-sctp-state=y; trace-sctp-signal=y; trace-sctp-multihome=y; trace-sctp-congestion=y;
trace-sctp-init=y;
```

The following example displays the output from the `get-trace` command:

```
get-trace call-agent id=CA146

CA ID -> CA146
RESULT -> ADM configure result in success
REASON -> ADM executed successfully
TRACE SCTP API -> Y
TRACE SCTP TXRXCHUNKS -> Y
TRACE SCTP STATE -> Y
TRACE SCTP SIGNAL -> Y
TRACE SCTP MULTIHOME -> Y
TRACE SCTP CONGESTION -> Y
TRACE SCTP INIT -> Y
IUA DEBUG LEVEL -> ERROR

Reply : Success: at 2006-04-10 13:11:59 by btsadmin
```

# Checking MGW Provisioning

This section describes how to check provisioning on IOS and IUA/SCTP gateways.

## IOS Gateway

The following example shows how a Cisco IOS gateway is provisioned for ISDN backhauling using RUDP.



**Note** The typical problem areas are in **bold** type. Look at the problem area after the Call Agent is provisioned.

```
Current configuration:
!
=====
version 12.2
no service pad
service timestamps debug datetime msec
service timestamps log datetime localtime
no service password-encryption
!
hostname c2421.200
!
enable password xxxxxxxx
!
clock timezone CDT -6
network-clock base-rate 56k
network-clock-select 3 T1 0
network-clock-select 1 T1 1
network-clock-select 2 system (SCB)
ip subnet-zero
!
!
ip domain-name ipclab.cisco.com
ip name-server 10.89.224.1
!
ip audit notify log
ip audit po max-events 100
backhaul-session-manager
  set isdn1 client ft
  group group1 set isdn1
  group group2 set isdn1
  session group group1 10.89.225.223 9000 10.89.227.200 9000 1
  session group group1 10.89.226.223 9001 10.89.227.200 9001 2
  session group group2 10.89.225.224 9000 10.89.227.200 9000 1
  session group group2 10.89.226.224 9001 10.89.227.200 9001 2
isdn switch-type primary-ni
isdn voice-call-failure 0
!
!
!
!
!
!
no voice confirmation-tone
voice-card 0
!
```

```

controller T1 0
  framing esf
  linecode b8zs
  channel-group 0 timeslots 1-24 speed 64
!
controller T1 1
  framing esf
  linecode b8zs
  pri-group timeslots 1-24 service mgcp
!
!
!
!
interface Ethernet0
  ip address 10.89.227.200 255.255.255.0
  no cdp enable
!
interface Serial0
  no ip address
  shutdown
!
interface Serial0:0
  no ip address
  ip nat outside
  encapsulation ppp
  shutdown
  no cdp enable
!
interface Serial1:23
  bandwidth 64000
  no ip address
  no logging event link-status
  isdn switch-type primary-ni
  isdn protocol-emulate network
  isdn incoming-voice voice
  isdn bind-13 backhaul isdn1
  no cdp enable
!
ip classless
ip route 0.0.0.0 0.0.0.0 10.89.227.254
no ip http server
ip pim bidir-enable
!
!
access-list 1 permit 10.0.24.0 0.0.0.255
call rsvp-sync
!
voice-port 1:23
!
mgcp
mgcp call-agent mgcp-SYS01CA.ipclab.cisco.com service-type mgcp version 1.0
mgcp dtmf-relay voip codec all mode nte-gw
mgcp package-capability rtp-package
mgcp default-package dt-package
no mgcp timer receive-rtcp
!
mgcp profile default
  timeout tsmx 100
  max2 retries 3
!
dial-peer cor custom
!
!
!

```

```

dial-peer voice 1 pots
  application mgcpapp
  port 1:23
!
!
line con 0
line aux 0
line 2 3
line vty 0 4
  password xxxxxxxx
  login
!
ntp server 10.89.227.254
end

```

## IUA/SCTP Gateway

The following example shows how a gateway is provisioned for IUA/SCTP.



**Note** The typical problem areas are in **bold type**. Look at the problem area after the Call Agent is provisioned.

```

Current configuration:
Current configuration : 3734 bytes
!
! No configuration change since last restart
!
version 12.2
service timestamps debug datetime msec
service timestamps log datetime localtime
no service password-encryption
!
hostname c5400-102
!
boot system flash:c5400-is-mz.sc70930
no boot startup-test
logging queue-limit 100
logging buffered 99999 debugging
enable password callagent
!
!
!
resource-pool disable
clock timezone cdt -5
spe default-firmware spe-firmware-1
aaa new-model
!
!
aaa authentication login default group tacacs+ enable
aaa authorization config-commands
aaa authorization exec default group tacacs+ none
aaa authorization commands 1 default group tacacs+ none
aaa authorization commands 15 default group tacacs+ none
aaa accounting exec default start-stop group tacacs+
aaa accounting commands 1 default start-stop group tacacs+
aaa accounting commands 15 default start-stop group tacacs+
aaa session-id common
ip subnet-zero

```

```

ip cef
ip domain name ipclab.cisco.com
ip name-server 10.89.224.1
ip name-server 10.89.224.9
!
isdn switch-type primary-ni
isdn voice-call-failure 0
isdn debug 0000043D
!
!
!
!
!
!
!
no voice hpi capture buffer
no voice hpi capture destination
!
!
!
mta receive maximum-recipients 0
!
iua
  AS as-tb78 10.89.232.102 9900
  ASP asp-tb78 AS as-tb78 190.101.56.214 190.101.55.214 9900
  ASP asp-sec-tb78 AS as-tb78 190.101.56.212 190.101.55.212 9900
!
!
controller T1 6/0
  framing esf
  linecode b8zs
  pri-group timeslots 1-24 service mgcp
!
controller T1 6/1
  framing esf
  linecode b8zs
!
controller T1 6/2
  framing sf
  linecode ami
!
controller T1 6/3
  framing sf
  linecode ami
  pri-group timeslots 1-24 service mgcp
!
controller T1 6/4
  framing sf
  linecode ami
!
controller T1 6/5
  framing sf
  linecode ami
controller T1 6/6
  framing sf
  linecode ami
!
controller T1 6/7
  framing sf
  linecode ami
!

```

```
controller T1 7/0
  framing sf
  linecode ami
!
controller T1 7/1
  framing sf
  linecode ami
!
controller T1 7/2
  framing sf
  linecode ami
!
controller T1 7/3
  framing sf
  linecode ami
!
controller T1 7/4
  framing sf
  linecode ami
!
controller T1 7/5
  framing sf
  linecode ami
!
controller T1 7/6
  framing sf
  linecode ami
!
controller T1 7/7
  framing sf
  linecode ami
!
!
interface FastEthernet0/0
  ip address 10.89.232.102 255.255.255.0
  duplex auto
!
interface FastEthernet0/1
  no ip address
  shutdown
  duplex auto
  speed auto
!
interface Serial0/0
  no ip address
  shutdown
  clockrate 2000000
!
interface Serial6/0
  no ip address
  shutdown
!
interface Serial7/0
  no ip address
  shutdown
!
interface Serial0/1
  no ip address
  shutdown
  clockrate 2000000
!
```

```

interface Serial6/0:23
  no ip address
  isdn switch-type primary-ni
  isdn protocol-emulate network
  isdn bind-13 iua-backhaul as-tb78
  no cdp enable
!
interface Serial6/3:23
  no ip address
  isdn switch-type primary-ni
  no cdp enable
!
interface Group-Async0
  no ip address
  group-range 1/00 5/107
!
ip classless
ip route 0.0.0.0 0.0.0.0 10.89.232.254
ip http server
!
!
logging trap debugging
logging 10.89.227.251
!
tacacs-server host 10.89.232.104
tacacs-server timeout 15
tacacs-server directed-request
snmp-server community public RO
snmp-server community private RW
snmp-server system-shutdown
snmp-server enable traps tty
!
radius-server authorization permit missing Service-Type
call rsvp-sync
!
voice-port 6/0:23
!
voice-port 6/3:23
!
mgcp
mgcp call-agent mga-SYS78CA146.ipclab.cisco.com service-type mgcp version 1.0
!
mgcp profile default
!
dial-peer cor custom
!
!
!
!
line con 0
line aux 0
line vty 0 4
  exec-timeout 30 0
  password callagent
line 1/00 3/107
  no flush-at-activation
  modem InOut
line 5/00 5/107
  no flush-at-activation
  modem InOut
!

```

```
scheduler allocate 10000 400
ntp server 10.89.227.254
end
```

## Additional CLI Verification

Perform the following steps to provide additional CLI verification of a problem:

- Step 1** Use the control command to put the trunk group out of service (OOS) and back into service (INS):

Place OOS:

```
control tgn-id=17; target-state=oos; mode=graceful;
```

Place INS:

```
control tgn-id=17; target-state=ins; mode=forced;
```

- Step 2** If the B channel is not IDLE, use the control command to put each circuit OOS and back INS:

Place OOS:

```
control trunk-termination tgn-id=17; cic=1; target-state=oos; mode=forced;
```

Place INS:

```
control trunk-termination tgn-id=17; cic=1; target-state=ins; mode=forced;
```

- Step 3** Check the status of the trunk group:

```
status trunk-grp id=<TG ID number>; call-agent-id=<CA ID>;
```

If the trunk group status has still not changed to ADMIN\_INS—even though the commands in Steps 1 and 2 were successful—then it means that communication to the MGW has been lost. Notify your system administrator and have the problem corrected before continuing.

- Step 4** Check trunk termination and trunk status. The single command shown here queries both the trunk-termination status and trunk (channel) status:

```
status trunk-termination tgn-id=17; cic=all;
```

Reply : Request was successful.

```
REPLY=1status is ....
CONFIGURATION COMMAND EXECUTED TRUNK_GRP -17 -CIC -1
TERM ADMINstatus -ADMIN_INS
TERM OPERstatus -TERM_STATE_IDLE
CIC STATIC STATE -ACTV
CIC DYNAMIC STATE -IDLE

...
...

23status is ....
CONFIGURATION COMMAND EXECUTED TRUNK_GRP -17 -CIC -23
TERM ADMINstatus -ADMIN_INS
TERM OPERstatus -TERM_STATE_IDLE
CIC STATIC STATE -ACTV
CIC DYNAMIC STATE -IDLE
```

```
status trunk-termination tgn-id=17; cic=23
```

```
Reply : Request was successful.
```

```
REPLY=CONFIGURATION COMMAND EXECUTED ISDN_TRUNK_GROUP -17 -CIC -23
TERM ADMINstatus -ADMIN_INS
TERM OPERstatus -TERM_STATE_IDLE
CIC STATIC STATE -ACTV
CIC DYNAMIC STATE -IDLE
```

---

## Maintenance of a Call Agent Connected to an ISDN Trunk Group

During system operations, the operator can use the CLI *control* command to switch the Call Agent into one of three states:

- NORMAL
- FORCED-ACTIVE-STANDBY
- FORCED-STANDBY-ACTIVE

When the control command is entered on a Call Agent connected to an ISDN trunk group (D channel), the Call Agent switchover time is approximately 20 seconds. During all but the first 6 seconds of this switchover time, the ISDN D channel is temporarily down. However, the D channel comes back up, and the ISDN trunk group automatically returns to in-service (INS), when the switchover completes.



### Note

This switchover process does not have any impact on stable calls.

---

## ISDN D-Channel and Trunk Group CLI Command Troubleshooting

[Table 4-3](#) describes how the CLI commands to perform common ISDN D-channel and trunk group operations for RUDP and IUA are different in Release 5.0, Release 4.5 and earlier. Use this table to ensure that the correct command for the release was used.

Table 4-3 CLI Command Differences by Release

Command Description	Release 4.5 and Earlier RUDP	Release 5.0 RUDP	Release 5.0 IUA
Bring up a backhaul session	N/A Controlling the trunk group in service automatically creates the backhaul session if the backhaul session was not already created.	N/A Controlling the D-channel in service automatically brings up the backhaul session if the backhaul session was not already created.	<code>control sctp-assoc id=&lt;isdnl1&gt;; mode=forced; target-state=ins;</code>
Bring up a D-channel	N/A Controlling a trunk group in service automatically brings up the D-channel if the D-channel is not already up.	<code>control isdn-dchan id=&lt;dchan1&gt;; dchan-type=primary; target-state=ins; mode=forced;</code>	<code>control isdn-dchan id=&lt;dchan1&gt;; dchan-type=primary; target-state=ins; mode=forced;</code>
Bring up a trunk group	<code>control trunk-grp id=&lt;100&gt;; target-state=ins; mode=forced;</code>	<code>control trunk-grp id=&lt;100&gt;; target-state=ins; mode=forced;</code>	<code>control trunk-grp id=&lt;100&gt;; target-state=ins; mode=forced;</code>
Bring down a trunk group	<code>control trunk-grp id=&lt;100&gt;; target-state=oos; mode=forced;</code> Controlling a trunk group out of service automatically brings down the D-channel. It also brings down the backhaul session if the trunk group was the last trunk group configured in the gateway.	<code>control trunk-grp id=&lt;100&gt;; target-state=oos; mode=forced;</code>	<code>control trunk-grp id=&lt;100&gt;; target-state=oos; mode=forced;</code>
D-channel switchover (NFAS)	<code>control isdn-dchan tgn-id=&lt;100&gt;;</code>	<code>control isdn-dchan id=&lt;dchan1&gt;; mode=forced; target-state=switchover;</code>	<code>control isdn-dchan id=&lt;dchan1&gt;; mode=forced; target-state=switchover;</code>
Bring down the primary D-channel (NFAS)	N/A	<code>control isdn-dchan id=&lt;dchan1&gt;; dchan-type=primary; mode=forced; target-state=oos;</code>  For NFAS, this command brings the backup D-channel to Active state if it is in Standby state. Otherwise, the backup D-channel is not impacted by this command.  Controlling the primary D-channel out of service automatically brings down the backhaul session if the D-channel was the last D-channel configured in the gateway.	<code>control isdn-dchan id=&lt;dchan1&gt;; dchan-type=primary; mode=forced; target-state=oos;</code>  For NFAS, this command brings the backup D-channel to Active state if it is in Standby state. Otherwise, the backup D-channel is not impacted by this command.

Table 4-3 CLI Command Differences by Release (continued)

Command Description	Release 4.5 and Earlier RUDP	Release 5.0 RUDP	Release 5.0 IUA
Bring down the backup D-channel (NFAS)	N/A	<pre>control isdn-dchan id=&lt;dchan1&gt;; dchan-type=backup; mode=forced; target-state=oos;</pre> <p>This command brings the primary D-channel to Active state if it is in Standby state. Otherwise, the primary D-channel is not impacted by this command.</p> <p>Controlling the backup D-channel out of service automatically brings down the backhaul session if the D-channel was the last D-channel configured in the gateway.</p>	<pre>control isdn-dchan id=&lt;dchan1&gt;; dchan-type=backup; mode=forced; target-state=oos;</pre> <p>This command brings the primary D-channel to Active state if it is in Standby state. Otherwise, primary D-channel is not impacted by this command.</p>
Bring down both the primary and backup D-channels (if NFAS is configured)	N/A	<pre>control isdn-dchan id=&lt;dchan1&gt;; mode=forced; target-state=oos;</pre> <p>Controlling D-channel out of service automatically brings down the backhaul session if the D-channel was the last D-channel configured in the gateway.</p>	<pre>control isdn-dchan id=&lt;dchan1&gt;; mode=forced; target-state=oos;</pre>
Bring down the D-channel (if FAS is configured)	N/A	<pre>control isdn-dchan id=&lt;dchan1&gt;; dchan-type=primary; mode=forced; target-state=oos;</pre> <p>Controlling D-channel out of service automatically brings down the backhaul session if the D-channel was the last D-channel configured in the gateway.</p>	<pre>control isdn-dchan id=&lt;dchan1&gt;; dchan-type=primary; mode=forced; target-state=oos;</pre>
Bring down backhaul session	N/A	N/A	<pre>control sctp-assoc id=&lt;isdnl&gt;; target-state=oos; mode=forced;</pre>