



# Replacing a Single Server or Cluster for Cisco Unified CallManager Release 5.1(3)

---

This document describes how to replace a single server or an entire cluster for Cisco Unified CallManager release 5.1(3). Replacement means that you replace the server hardware while preserving the server configuration. The replacement server operates identically to the old server.



## Caution

---

Because this process is designed to work as a server replacement, you need to do it in the live environment. Cisco does not recommend doing this process on a “dead net” because a duplication of the entire network environment is required, which is highly risky.

---

These sections describe the major tasks required to replace a server or cluster:

- [Server or Cluster Replacement Preparation Checklist, page 1](#)
- [Replacing a Single Server or Cluster, page 12](#)
- [Post-Replacement Checklist, page 31](#)

## Server or Cluster Replacement Preparation Checklist

This section describes that tasks that you should perform before you begin the server or cluster replacement.



---

**Corporate Headquarters:**  
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

Copyright © 2006 Cisco Systems, Inc. All rights reserved.

| Pre-Replacement Task  | Important Notes   |
|---|---|
| <b>Step 1</b> Verify the integrity of the new server hardware (such as hard drives and memory) by running any manufacturer-provided utilities.  |   |
| <b>Step 2</b> Make sure that the new servers are listed as supported hardware and sized appropriately to support the load of cluster.   | Refer to the following documentation for information about the capacity of server models: <ul style="list-style-type: none"> <li>• Release notes for your product release</li> <li>• <a href="http://www.cisco.com/en/US/products/hw/voiceapp/ps378/prod_brochure_list.html">http://www.cisco.com/en/US/products/hw/voiceapp/ps378/prod_brochure_list.html</a></li> </ul> Make sure to account for any growth that has occurred since initial system configuration. |
| <b>Step 3</b> Verify that links between servers meet the 40-ms roundtrip requirement and that you have enough bandwidth to support database replication.  | For more information, refer to <i>Cisco Unified Communications SRND Based on Cisco Unified CallManager 5.x</i> .  |
| <b>Step 4</b> Record all system passwords and account IDs.  | See the “ <a href="#">Recording Account Names and Passwords</a> ” section on page 4.<br><br>You must enter identical passwords when configuring the replacement server. You cannot retrieve these passwords from the server.  |
| <b>Step 5</b> Make sure that you have a copy of all custom ring files, phone backgrounds, and music on hold sources.  | Consider this as precautionary because the restore is designed to restore these items.  |
| <b>Step 6</b> Obtain and store COP files for any locales that are installed on the server.  | You might need to reinstall locales after doing the replacement.  |
| <b>Step 7</b> Do not change computer names or IP addresses, or add more nodes to the cluster.   |   |
| <b>Step 8</b> Verify the integrity of your software downloads and DVDs.   | Perform the following tasks: <ul style="list-style-type: none"> <li>• Check the MD5 checksum of downloaded software against the published value to verify that it downloaded properly.</li> <li>• Verify that the DVD is readable by a DVD drive.</li> </ul>  |
| <b>Step 9</b> If your firewall is not in the routing path, disable the firewall between nodes, if possible. Also, increase the firewall timeout settings until after you complete the installation. | It is not always sufficient to temporarily allow network traffic in and out of the nodes (for example, setting the firewall rule for these nodes to <code>IP any/any</code> ). The firewall might still close necessary network sessions between nodes due to timeouts.   |
| <b>Step 10</b> Perform any system tests that you intend to perform after the replacement before the replacement also, to verify that the tests pass before you do the replacement.                  | Document these tests, so you can perform them identically after doing the replacement.  |
| <b>Step 11</b> If you use DNS, verify that all servers to be replaced are configured in DNS properly. All nodes in the cluster must either use DNS or not use it.                                   | See the “ <a href="#">Verifying DNS Registration</a> ” section on page 7.   |
| <b>Step 12</b> Do not run Network Address Translation (NAT) or Port Address Translation (PAT) between Cisco Unified CallManager nodes.  |   |

| Pre-Replacement Task   | Important Notes  |
|--|--|
| <b>Step 13</b> Record all the registration information by using the Cisco Unified CallManager Real-Time Monitoring Tool (RTMT).  | See the <a href="#">“Determining Registration Counts By Using RTMT”</a> section on page 8.<br>You cannot perform this task if your old server is not working.  |
| <b>Step 14</b> Record all the critical services and their activation status by using the Cisco Unified CallManager Real-Time Monitoring Tool (RTMT).   | See the <a href="#">“Recording Critical Service Status”</a> section on page 8.<br>You cannot perform this task if your old server is not working.  |
| <b>Step 15</b> Using the Syslog viewer in the Cisco Unified CallManager Real-Time Monitoring Tool (RTMT), locate any events that have a severity of Error or higher.   | Perform this task to ensure that no system-affecting errors exist on your system.<br>See the <a href="#">“Locating System Errors By Using Syslog Viewer”</a> section on page 9.<br>You cannot perform this task if your old server is not working.   |
| <b>Step 16</b> Record the details of all Trace and Log Central jobs.   | See the <a href="#">“Recording Trace and Log Central Job Details”</a> section on page 9.<br>You cannot perform this task if your old server is not working.  |
| <b>Step 17</b> Record CDR Management configuration and destinations, if applicable.  | See the <a href="#">“Accessing CDR Management Configuration”</a> section on page 10.<br>You cannot perform this task if your old server is not working.  |
| <b>Step 18</b> From Cisco Unified CallManager Administration, determine the number of specific items that are configured on the server.  | See the <a href="#">“Determining System Configuration Counts”</a> section on page 10.<br>You cannot perform this task if your old server is not working.   |
| <b>Step 19</b> From Cisco Unified CallManager Administration, record all the phone loads and device types that display on the Firmware Load Information window.  | See the <a href="#">“Firmware Information”</a> section on page 11.<br>If you have custom device types that do not ship with Cisco Unified CallManager, make sure that you have the appropriate COP files. You might need to reinstall the devices types after performing the replacement.<br>You cannot perform this task if your old server is not working.                                     |
| <b>Step 20</b> Record all network configuration settings and other configuration settings that are described in the sections that are referenced in the Important Notes column for each server to be replaced. | See the following sections: <ul style="list-style-type: none"> <li>• <a href="#">“Recording Network Configuration Settings”</a> section on page 5.</li> <li>• <a href="#">“Recording SMTP Settings”</a> section on page 7</li> <li>• <a href="#">“Recording the Hostname and Timezone Settings”</a> section on page 7</li> </ul> You cannot perform this task if your old server is not working. |

| Pre-Replacement Task   | Important Notes   |
|--|---|
| <p><b>Step 21</b> Compare the system version on each node in your cluster by using Cisco Unified Communications Operating System Administration.</p> <p>Verify that you have DVDs with that version.</p>         | <p>See the <a href="#">“Obtaining System Version Information”</a> section on page 11.</p> <p>If you have a service release, you need media for the base release and the service release.</p>  |
| <p><b>Step 22</b> If your cluster is running in secure mode, make sure that you have USB eToken devices and CTL Client plug-in utility installed on a computer that is running the Windows operating system.</p> | <p>For information about performing these tasks and about Cisco Unified CallManager security, refer to the “Installing the CTL Client” procedures in the <i>Cisco Unified CallManager Security Guide</i>.</p>   |
| <p><b>Step 23</b> Perform a DRS backup on the publisher server to a remote SFTP server and verify that the backup succeeds.</p> <p>Record the DRS backup location and schedule information, if applicable.</p>   | <p>To verify that your SFTP is working, use an SFTP client on a computer on the same subnet as the servers that are being restored and download the backup to that computer.</p> <p>Ensure that all cluster nodes that you will replace or reinstall are online and registered as a node. DRS backs up only registered and online nodes.</p> <p>You cannot perform this task if your old server is not working.</p> <p>See the <a href="#">“Creating a Backup File”</a> section on page 14.</p> |

## Gathering System Configuration Information to Replace or Reinstall a Server

Before replacing or reinstalling a server, you must have the information that is described in this section. The information that is provided must match before and after the restore or reinstall. In the case of a server replacement, this information must match on both the original server and its replacement.

Gather this information for each Cisco Unified CallManager server that you are replacing or reinstalling in the cluster. You may not need to obtain all the information; gather only the information that is pertinent to your system and network configuration.

### Recording Account Names and Passwords

Record all system passwords and account IDs, including those described in [Table 1](#). You cannot retrieve these passwords from the server.



**Caution**

You must enter identical passwords and account IDs when you configure the replacement server.

**Table 1 Password and Accounts Configuration Data**

| Field                           | Description  |
|---------------------------------|--|
| Administrator ID:<br>_____      | The user ID that you use for secure shell access to the CLI, for logging into Cisco Unified Communications Operating System Administration, and for logging into the Disaster Recovery System. |
| Administrator Password<br>_____ | The password that you use to log into the Administrator ID account.  |

**Table 1 Password and Accounts Configuration Data**

| Field                              | Description  |
|------------------------------------|--|
| Application User Password<br>_____ | The password that is used as the default password for applications that are installed on the system, including Cisco Unified CallManager and Cisco Unified CallManager Serviceability.<br><br>When you initially log in, use the default user name: CCMAAdministrator. |
| Security Password:<br>_____        | The security password that Cisco Unified CallManager servers in the cluster use to communicate with one another.<br><br>You must enter the same password for all nodes in the cluster.   |

## Recording Network Configuration Settings

Follow this procedure to record network configuration settings.



### Caution

You must enter identical network settings when configuring the replacement server. Do not attempt to change network settings on the replacement server. The only exceptions are the NIC speed and duplex settings, which you should configure as described in this section.

### Procedure

- 
- Step 1** In Cisco Unified Communications Operating System Administration, navigate to **Show > Network**.
- Step 2** Record all network configuration settings, including those described in [Table 2](#).
- Step 3** Record the NIC speed and duplex settings of the switch port to which you will connect the new server. You should configure the same NIC settings on the server and on the switch port. For GigE (1000/FULL), you should set both NIC and switch port settings to Auto/Auto; do not set hard values. If you are using Network Fault Tolerance, the Network Fault Tolerance configuration gets lost during the replacement. You will need to configure it on each server after the upgrade. Enable PortFast on all switch ports that are connected to Cisco Unified CallManager servers. With Portfast enabled, the switch immediately brings a port from the blocking state into the forwarding state by eliminating the forwarding delay (the amount of time that a port waits before changing from its Spanning-Tree Protocol (STP) learning and listening states to the forwarding state).
-

**Table 2 Network Configuration Information**

| Field Name and Your Entry                       | Description   |
|---|---|
| DHCP status:<br>_____                           | Dynamic Host Configuration Protocol status.<br>If DHCP is not enabled, you must enter a hostname, IP Address, IP Mask, and Gateway.   |
| DNS Enabled:<br>_____                           | DNS status.<br>When DNS is not enabled, you should only enter IP addresses (not hostnames) for all network devices in your Cisco Unified Communications network.  |
| DNS Primary:<br>_____._____._____._____         | The IP address of the primary DNS server that Cisco Unified CallManager contacts first when it attempts to resolve host names.<br>Consider this setting as required if DNS is enabled.  |
| DNS Secondary:<br>_____._____._____._____       | The IP address of the secondary DNS server that Cisco Unified CallManager will attempt to connect if the primary DNS server fails.  |
| Domain:<br>_____                                | The name of the domain in which this machine is located.<br>Consider this setting as required if DNS is enabled.  |
| Gateway Address:<br>_____._____._____._____     | The IP address of the default gateway, which is a network point that acts as an entrance to another network. Outbound packets get sent to the gateway that will forward them to their final destination.<br>If you do not have a gateway, you must still fill in this field by setting it to 255.255.255.255. Not having a gateway may limit you to communicating only with devices on your subnet. |
| Hostname:<br>_____                              | A name that represents an alias that is assigned to an IP address to identify it.<br>This setting is required if DHCP is disabled.  |
| IP Address:<br>_____._____._____._____          | The IP address of this machine. It will uniquely identify the server on this network. Ensure that another machine in this network is not using this IP address.<br>Consider this setting as required is DHCP is disabled.   |
| IP Mask:<br>_____._____._____._____             | The IP subnet mask of this machine. The subnet mask together with the IP address defines the network address and the host address.  |
| NIC Speed:<br>_____                             | The speed of the server network interface card (NIC) in megabits per second.  |
| NIC Duplex:<br>_____                            | The duplex setting of the server NIC.   |
| MTU size  | Maximum transmission unit (MTU): the largest packet, in bytes, that this host will transmit on the network.   |
| NTP Server:<br>_____<br>_____._____._____._____ | The hostname of IP address of the NTP server with which you want to keep time synchronization.<br>Consider this setting as required if you enabled the system to be an NTP client.  |

**Related Topics**

- [Server or Cluster Replacement Preparation Checklist, page 1](#)
- *Cisco Unified Communications Operating System Administration Guide*

## Recording SMTP Settings

Follow this procedure to record the SMTP server setting, which specifies the hostname or IP address of the SMTP host that is used for outbound e-mail.

**Procedure**

- 
- Step 1** In Cisco Unified Communications Operating System Administration, navigate to **Settings > SMTP**.
- Step 2** Record IP address or hostname of the SMTP server.
- 

## Recording the Hostname and Timezone Settings

Follow this procedure to record the hostname and timezone settings.

**Procedure**

- 
- Step 1** In Cisco Unified Communications Operating System Administration, navigate to **Show > System**.
- Step 2** Record the settings in the following fields:
- **Host Name**—The unique host name of the server
  - **Time Zone**—The local time zone and offset from Greenwich Mean Time (GMT)
- 

## Verifying DNS Registration

If you use DNS, verify that all servers to be replaced are registered in DNS properly.

**Procedure**

- 
- Step 1** Open a command prompt.
- Step 2** To ping each server by its DNS name, enter **ping <DNS name>**.
- Step 3** To look up each server by IP address, enter **nslookup <IP address>**.
- 

**Related Topics**

- [Server or Cluster Replacement Preparation Checklist, page 1](#)

## Determining Registration Counts By Using RTMT

Record the number of registered devices, including the numbers of registered phones and gateways, by using the Cisco Unified CallManager Real-Time Monitoring Tool (RTMT).

### Procedure

---

**Step 1** Download and install the Cisco Unified CallManager Real-Time Monitoring Tool (RTMT) by choosing **Application > Plugins** from Cisco Unified CallManager Administration, clicking **Find**, and clicking the **Download** link next to the appropriate RTMT installer.

If you are planning to install the RTMT tool on a computer that is running the Microsoft Windows operating system, click the **Download** link for the Cisco Unified CallManager Real-Time Monitoring Tool-Windows. If you are planning to install the RTMT tool on a computer that is running the Linux operating system, click the **Download** link for the Cisco Unified CallManager Real-Time Monitoring Tool-Linux.

**Step 2** Open RTMT.

**Step 3** Perform one of the following tasks:

- In the Quick Launch Channel, click the **View** tab, click the **Device** category, and click the **Device** icon.
- Choose **Monitor > Device Summary**.

**Step 4** For each Cisco Unified CallManager node, record the number for each device type that is displayed, including the numbers of registered phones, FXS, FXO, T1Cas, PRI, MOH, MTP, CFB, XCODE, and H323 Gateways.

---

### Related Topics

- [Server or Cluster Replacement Preparation Checklist, page 1](#)
- [Post-Replacement Checklist, page 31](#)
- *Cisco Unified CallManager Serviceability Administration Guide*

## Recording Critical Service Status

Record all the critical services and their status by using the Cisco Unified CallManager Real-Time Monitoring Tool (RTMT).

### Procedure

---

**Step 1** Perform one of the following tasks:

- In the Quick Launch Channel, click the **View** tab, click the **Server** category, and click the **Critical Services** icon.
- Choose **Monitor > Server > Critical Services**.

**Step 2** Record the status of all critical services for each node in the cluster.

---

**Related Topics**

- [Server or Cluster Replacement Preparation Checklist, page 1](#)
- [Post-Replacement Checklist, page 31](#)
- *Cisco Unified CallManager Serviceability Administration Guide*

## Locating System Errors By Using Syslog Viewer

Using the Syslog viewer in the Cisco Unified CallManager Real-Time Monitoring Tool (RTMT), locate any events that have a severity of Error or higher.

**Procedure**

- 
- Step 1** Open RTMT and perform one of the following tasks:
- In the Quick Launch Channel, click the **Tools** tab; then, click **SysLog Viewer** and the **SysLog Viewer** icon.
  - Choose **Tools > SysLog Viewer > Open SysLog Viewer**.
- Step 2** From the Select a Node drop-down list box, choose the server where the logs that you want to view are stored.
- Step 3** Double-click the Application Logs folder.
- Step 4** Locate events with a severity of Error or higher.
- Step 5** Review each log to locate system-affecting errors.
- 

**Related Topics**

- [Server or Cluster Replacement Preparation Checklist, page 1](#)
- [Post-Replacement Checklist, page 31](#)
- *Cisco Unified CallManager Serviceability Administration Guide*

## Recording Trace and Log Central Job Details

Record the details of all Trace and Log Central jobs.

**Procedure**

- 
- Step 1** Open RTMT and perform one of the following tasks:
- In the Quick Launch Channel, click the **Tools** tab; then, click **Trace** and the **Job Status** icon.
  - Choose **Tools > Trace > Job Status**.
- Step 2** Double click each scheduled job, and record the details that display for each job in the Show Detail dialog box.
-

**Related Topics**

- [Server or Cluster Replacement Preparation Checklist, page 1](#)
- *Cisco Unified CallManager Serviceability Administration Guide*

## Accessing CDR Management Configuration

Record CDR Management configuration and destinations, if applicable.

You use the CDR Management Configuration window to set the amount of disk space to allocate to call detail record (CDR) and call management record (CMR) files, configure the number of days to preserve files before deletion, and configure up to three billing application server destinations for CDRs. The CDR repository manager service repeatedly attempts to deliver CDR and CMR files to the billing servers that you configure on the CDR Management Configuration window until it delivers the files successfully, until you change or delete the billing application server on the CDR Management Configuration window, or until the files fall outside the preservation window and are deleted.

**Procedure**

- 
- Step 1** From Cisco Unified CallManager Serviceability, choose **Tools > CDR Management**.  
The CDR Management Configuration window displays.
- Step 2** Record the General Parameters and the Billing Application Server Parameters.
- 

**Related Topics**

- [Server or Cluster Replacement Preparation Checklist, page 1](#)
- *Cisco Unified CallManager Serviceability Administration Guide*

## Determining System Configuration Counts

From Cisco Unified CallManager Administration, obtain counts of each of the items that are configured on the system that you want to verify after the replacement. Some examples of items to count follow:

- Phones
- Gateways
- Trunks
- Users
- Route Patterns
- CTI ports
- CTI route points

**Procedure**

- 
- Step 1** In Cisco Unified CallManager Administration, access the windows for each item that you want to count and click **Find** without entering any search parameters. Some examples follow:
- Find and List Phones (**Device > Phone**)

- Find and List Gateway (**Device > Gateway**)
- Find and List Trunks (**Device > Trunk**)
- Find and List Route Patterns (**Call Routing > Route/Hunt > Route Pattern**)
- Find and List Users (**User Management > End Users**)
- Find and List Application Users (**User Management > Application Users**)

**Step 2** Record the number of each of the items (devices, route patterns, and users).

---

#### Related Topics

- [Server or Cluster Replacement Preparation Checklist, page 1](#)
- [Post-Replacement Checklist, page 31](#)
- *Cisco Unified CallManager Administration Guide*

## Firmware Information

Record all of the phone loads and device types that display on the Firmware Load Information window.

#### Procedure

---

**Step 1** In Cisco Unified CallManager Administration, choose **Device > Device Settings > Firmware Load Information**.

The Firmware Load Information window displays.

**Step 2** Record all the phone loads and device types that display.



**Note** If you have custom device types that do not ship with Cisco Unified CallManager, make sure that you have the appropriate COP files, so you can reinsert them, if needed.

---

#### Related Topics

- [Server or Cluster Replacement Preparation Checklist, page 1](#)
- [Post-Replacement Checklist, page 31](#)
- *Cisco Unified CallManager Administration Guide*

## Obtaining System Version Information

Compare the system version on each node in your cluster by using Cisco Unified Communications Operating System Administration.

Verify that you have DVDs with that version. If you have a service release, you need media for base image and the service release.

**Procedure**

- 
- Step 1** From the Cisco Unified Communications Operating System Administration window, navigate to **Show > System**.  
The System Status window displays.
  - Step 2** Make a note of the value that is displayed in the Product Version field.
- 

**Related Topics**

- [Server or Cluster Replacement Preparation Checklist, page 1](#)
- [Post-Replacement Checklist, page 31](#)
- *Cisco Unified Communications Operating System Administration Guide*

## Replacing a Single Server or Cluster



**Caution**

Because this process is designed to work as a server replacement, you must perform it in the live environment. Cisco does not recommend doing this process on a “dead net” because a duplication of entire network environment is required, which is highly risky.

This section provides checklists of the steps that are required to replace a single server or a cluster. If you are replacing an entire cluster, replace the servers in the order that is described in [Table 3](#). If you are replacing one or more subscriber nodes or dedicated TFTP servers, follow the instructions in the [“Replacing a Subscriber or Dedicated TFTP Server Node” section on page 13](#) for each server. If you are replacing a publisher node, you must reinstall or replace all the subscriber nodes and dedicated TFTP servers in the cluster also.

**Table 3 Cluster Replacement Process Overview**

|               | Task  | For More Information  |
|---------------|---|---|
| <b>Step 1</b> | Replace the publisher node.   | <a href="#">“Replacing the Publisher Node” section on page 12</a>                         |
| <b>Step 2</b> | Replace any dedicated TFTP servers or other non-Cisco Unified CallManager cluster nodes.                              | <a href="#">“Replacing a Subscriber or Dedicated TFTP Server Node” section on page 13</a> |
| <b>Step 3</b> | Replace all backup subscriber nodes.  | <a href="#">“Replacing a Subscriber or Dedicated TFTP Server Node” section on page 13</a> |
| <b>Step 4</b> | Replace all primary subscriber nodes.   | <a href="#">“Replacing a Subscriber or Dedicated TFTP Server Node” section on page 13</a> |
| <b>Step 5</b> | Perform any remaining post-replacement tasks in the <a href="#">“Post-Replacement Checklist” section on page 31</a> . |   |

## Replacing the Publisher Node

Complete the following tasks to replace the Cisco Unified CallManager publisher server. If you are replacing a single server that is not part of a cluster, follow this procedure to replace your server.

**Caution**

If you are replacing a publisher node in a cluster, you must also reinstall all the subscriber nodes and dedicated TFTP servers in the cluster, after replacing the publisher node. For instructions on reinstalling these other nodes types, see the [“Replacing a Subscriber or Dedicated TFTP Server Node” section on page 13](#)

Follow the references in the For More Information column to get more information about a step.

**Table 4** *Replacing the Publisher Node Process Overview*

|                | Description   | For More Information  |
|----------------|---|---|
| <b>Step 1</b>  | Perform the tasks in the <a href="#">“Server or Cluster Replacement Preparation Checklist” section on page 1</a> .  | <a href="#">“Server or Cluster Replacement Preparation Checklist” section on page 1</a>   |
| <b>Step 2</b>  | Gather the necessary information about the old publisher server.  | <a href="#">“Gathering System Configuration Information to Replace or Reinstall a Server” section on page 4</a>                                     |
| <b>Step 3</b>  | Back up the publisher server to a remote SFTP server by using the Disaster Recovery System (DRS) and verify that you have a good backup.  | <a href="#">“Creating a Backup File” section on page 14</a>   |
| <b>Step 4</b>  | Get the new license and verify it before system replacement.  | You only need a new license if you are replacing the publisher node.<br><br>See the <a href="#">“Obtaining a License File” section on page 18</a> . |
| <b>Step 5</b>  | Shut down and turn off the old server.  |   |
| <b>Step 6</b>  | Connect the new server.   |   |
| <b>Step 7</b>  | Install the same Cisco Unified CallManager release on the new server that was installed on the old server, including any Engineering Special releases.<br><br>Configure the server as the publisher server for the cluster. | <a href="#">“Installing Cisco Unified CallManager on the New Publisher Server” section on page 18</a>   |
| <b>Step 8</b>  | Upload the new license file to the publisher server.  | <a href="#">“Uploading a License File” section on page 28</a>   |
| <b>Step 9</b>  | Restore backed up data to the publisher server by using DRS.  | <a href="#">“Restoring a Backup File” section on page 29</a>  |
| <b>Step 10</b> | Reboot the publisher server.  |   |
| <b>Step 11</b> | Perform the post-replacement tasks in the <a href="#">“Post-Replacement Checklist” section on page 31</a> .   |   |

## Replacing a Subscriber or Dedicated TFTP Server Node

Complete the following tasks to replace a subscriber node or dedicated TFTP server (or another server type that is not a Cisco Unified CallManager server). A dedicated TFTP server is a node with Cisco Unified CallManager installed but with the Cisco Unified CallManager service disabled. The TFTP service runs as a dedicated TFTP server for the cluster.

If you are also replacing the publisher node, you must replace it before replacing or reinstalling any other nodes. If the cluster uses backup subscriber nodes, replace or reinstall all backup subscriber nodes before replacing or reinstalling primary subscriber nodes. For more information about cluster replacement, see the [“Replacing a Single Server or Cluster” section on page 12](#).

You can replace all backup subscriber nodes at same time if this does not cause outages or oversubscription of primary subscriber nodes. You can replace all primary subscriber nodes at the same time if this does not cause outages or oversubscription of backup subscriber nodes.

Follow the references in the For More Information column to get more information about a step.

**Table 5 Replacing a Subscriber Node or Dedicated TFTP Server Process Overview**

|               | Description  | For More Information  |
|---------------|--|---|
| <b>Step 1</b> | Gather the necessary information about the old server.   | <a href="#">“Gathering System Configuration Information to Replace or Reinstall a Server” section on page 4</a> |
| <b>Step 2</b> | Shut down and turn off the old server.   |   |
| <b>Step 3</b> | Connect the new server.  |   |
| <b>Step 4</b> | Install the same Cisco Unified CallManager release on the new server that was installed on the old server, including any Engineering Special releases.<br><br>Configure the new server to use the same configuration information as the old server. For more information, see the <a href="#">“Gathering System Configuration Information to Replace or Reinstall a Server” section on page 4</a> .                        | <a href="#">“Installing Cisco Unified CallManager on a New Subscriber Server” section on page 22</a>            |
| <b>Step 5</b> | Restore backed up data to the node by using DRS.   | <a href="#">“Restoring a Backup File” section on page 29</a>  |
| <b>Step 6</b> | Reboot the new server.   |   |
| <b>Step 7</b> | Verify that the new server has the same number and status for all Critical services that you gathered before replacing the server.   | <a href="#">“Server or Cluster Replacement Preparation Checklist” section on page 1</a>                         |
| <b>Step 8</b> | Verify that the db Replicate state has a value of 2. This indicates that the database is set up on this node.<br><br>A value of 1 means that replication is still setting up. A value of 0 means that replication setup has not started. A state of greater than 2 indicates that replication is not working correctly (3 means that data is not replicating correctly; 4 means that replication is not set up correctly). | <a href="#">“Post-Replacement Checklist” section on page 31</a>   |
| <b>Step 9</b> | Perform the post-replacement tasks in the <a href="#">“Post-Replacement Checklist” section on page 31</a> .  |   |

**Sections that reference this section**

- [Replacing the Publisher Node, page 12](#)
- [Replacing a Subscriber or Dedicated TFTP Server Node, page 13](#)

## Creating a Backup File

The following sections describe how to set up and run a backup before an upgrade. Refer to the *Disaster Recovery System Administration Guide* for more information.

If you are recovering or replacing a server, you can skip this section on creating backups and restore the server from the most recent backup that is available.

**Sections that reference this section**

- [Replacing the Publisher Node, page 12](#)
- [Replacing a Subscriber or Dedicated TFTP Server Node, page 13](#)

## Supported Features and Components

You can back up and restore the features and subcomponents that are shown in the following table. For each feature that you choose, the system backs up all its subcomponents automatically.

**Table 6**      *Supported Features and Components*

| Feature                       | Components  |
|-------------------------------|---|
| CCM—Cisco Unified CallManager | Cisco Unified CallManager (version 5.0) database (CMDB) |
|                               | Platform  |
|                               | Serviceability  |
|                               | Music On Hold (MOH)                                     |
|                               | Cisco Emergency Responder (CER)                         |
|                               | Bulk Tool (BAT)   |
|                               | Preference  |
|                               | Phone device files (TFTP)                               |
|                               | syslogagt (SNMP syslog agent)                           |
|                               | cdpagent (SNMP cdp agent)                               |
|                               | tct (trace collection tool)                             |
|                               | Call Detail Records (CDR)                               |
|                               | CDR Analysis and Reporting (CAR)                        |

## Configuring Features to Back Up

Before you can schedule or start a backup job, you must configure the features that you want to back up.

**Note**

Changing a backup feature changes it for both manual and scheduled backups.

Perform the following steps to choose the features that you want to back up.

**Procedure**

- Step 1** Navigate to the Disaster Recovery System. Log in to Cisco Unified CallManager Administration, choose **Disaster Recovery System** from the **Navigation** menu in the upper, right corner of the Cisco Unified CallManager Administration window, and click **Go**.

The Disaster Recovery System Logon window displays.

- Step 2** Log in to the Disaster Recovery System by using the same Administrator username and password that you use for Platform Administration.
- Step 3** Navigate to **Backup>Configure Features**.
- Step 4** From the list of available features, choose the feature or features that you want to include in the backup and click **Save**. You must choose at least one feature.
- Step 5** Continue with the next procedure for configuring a storage location.

## Configuring a Storage Location

Before using the Disaster Recover System, you must configure the location where you want the backup file to be stored. Perform the following steps to configure the storage location.

### Procedure

- Step 1** Navigate to the Disaster Recovery System. Log in to Cisco Unified CallManager Administration, choose **Disaster Recovery System** from the **Navigation** menu in the upper, right corner of the Cisco Unified CallManager Administration window, and click **Go**.

The Disaster Recovery System Logon window displays.

- Step 2** Log in to the Disaster Recovery System by using the same Administrator username and password that you use for Platform Administration.
- Step 3** Navigate to **Backup>Storage Location**. The Storage Location window displays.



**Note** You can configure the number of backup sets that are stored on a network directory.

- Step 4** Select the **Network Directory** option to store the backup data on a networked drive that is accessed through an SFTP connection.
- Step 5** Enter the following required information:

- **Server name:** Name or IP address of the network server
- **Path name:** Path name for the directory where you want to store the backup file
- **User name:** Valid username for an account on the remote system
- **Password:** Valid password for the account on the remote system



**Note** You must have access to an SFTP server to configure a network storage location. The SFTP path must exist prior to the backup. Ensure that the account that is used to access the SFTP server has write permission for the selected path.

- Step 6** To update these settings, click **Save**.

**Note**

For network directory backups, after you click the **Save** button, the DRS Master Agent will validate the selected SFTP server. If the user name, password, server name, or directory path is invalid, the save will fail.

**Step 7** Continue with either a manual or a scheduled backup.

## Starting a Manual Backup

You can manually start a backup of the features that you choose on the **Configure Features** menu. Perform the following steps to start a manual backup.

### Procedure

**Step 1** Navigate to the Disaster Recovery System. Log in to Cisco Unified CallManager Administration, choose **Disaster Recovery System** from the **Navigation** menu in the upper, right corner of the Cisco Unified CallManager Administration window, and click **Go**.

The Disaster Recovery System Logon window displays.

**Step 2** Log in to the Disaster Recovery System by using the same Administrator username and password that you use for Platform Administration.

**Step 3** Navigate to **Backup>Manual Backup**. The Manual Backup window displays.

**Step 4** Make sure the features that you want to back up are chosen. To choose other features, see the [“Configuring Features to Back Up” section on page 15](#).

**Note**

Ensure all servers in the cluster are running the same version of Cisco Unified CallManager and are reachable through the network. Servers that are not running at the time of the scheduled backup will not get backed up.

**Step 5** To begin the manual backup, click **Start Backup**.

**Step 6** Make sure that you have configured the backup storage location. See the [“Configuring a Storage Location” section on page 16](#).

## Checking the Status of the Current Backup Job

Perform the following steps to check the status of the current backup job.

### Procedure

**Step 1** Navigate to the Disaster Recovery System. Log in to Cisco Unified CallManager Administration, choose **Disaster Recovery System** from the **Navigation** menu in the upper, right corner of the Cisco Unified CallManager Administration window, and click **Go**.

The Disaster Recovery System Logon window displays.

- Step 2** Log in to the Disaster Recovery System by using the same Administrator username and password that you use for Platform Administration.
- Step 3** Navigate to **Backup>Current Status**. The Backup Status window displays.
- Step 4** To view the backup log file, click the log filename link.
- Step 5** To cancel the current backup, click **Cancel Backup**.




---

**Note** The backup cancels after the current component has completed its backup operation.

---

## Obtaining a License File

If you have to replace the first node in your Cisco Unified CallManager cluster, you must open a case with the licensing team to obtain a license for your replacement server. Contact the licensing team at [licensing@cisco.com](mailto:licensing@cisco.com). After you receive the new license file, upload the software license file as described in “Uploading a License File” section on page 28.

### Sections that reference this section

- [Replacing the Publisher Node, page 12](#)

## Installing Cisco Unified CallManager on the New Publisher Server

Use this procedure to install Cisco Unified CallManager on the new publisher server. For more information about installing this product, refer to the document, *Installing Cisco Unified CallManager*.

### Procedure

---

- Step 1** Insert the installation DVD into the tray and restart the server, so it boots from the DVD. After the server completes the boot sequence, the DVD Found window displays.
- Step 2** To perform the media check, choose **Yes** or to skip the media check, choose **No**.  
The media check checks the integrity of the DVD. If your DVD passed the media check previously, you might choose to skip the media check.
- Step 3** If you choose **Yes** to perform the media check, the system installer performs the media check and displays the Media Check Result window. Perform these tasks:
- If the Media Check Result displays Pass, choose **OK** to continue the installation.
  - If the media fails the media check, either download another copy of the software from Cisco.com or obtain another disc directly from Cisco.
- Step 4** The system installer performs the following hardware checks to ensure that your system is correctly configured. If the installer makes any changes to your hardware configuration settings, you will get prompted to restart your system. Leave the DVD in the drive during the reboot.

- First, the installation process checks for the correct drivers, and you may see the following warning:  
No hard drives have been found. You probably need to manually choose device drivers for install to succeed. Would you like to select drivers now?

To continue the installation, choose **Yes**.

- The installation next checks to see whether you have a supported hardware platform. If your server does not meet the exact hardware requirements, the installation process fails with a critical error. If you think this is not correct, capture the error and report it Cisco support.
- The installation process next verifies RAID configuration and BIOS settings.




---

**Note** If this step repeats, choose **Yes** again.

---

- Step 5** If software is currently installed on the server, the Overwrite Hard Drive window opens and displays the current software version on your hard drive and the version on the DVD. To continue with the installation, choose **Yes**, or choose **No** to cancel.




---

**Caution** If you choose **Yes** on the **Overwrite Hard Drive** window, all existing data on your hard drive gets overwritten and destroyed.

---

- Step 6** The Platform Installation Wizard window displays.

- Step 7** To configure the platform now, choose **Proceed**. The Apply Patch window displays.

- Step 8** Choose the type of installation to perform by doing the following steps.

- a. In the Apply Patch window, choose one option:
  - To upgrade to a later Service Release of the software during installation, choose **Yes**. Continue with the [“Applying a Patch” section on page 25](#).
  - To skip this step, choose **No**.
  - To return to the previous window, choose **Back**.
- b. In the Windows Upgrade window, choose **No**.




---

**Note** This document does not describe the Windows Upgrade. is not described in. To perform a Windows Upgrade, that is, to upgrade from a Windows version of Cisco Unified CallManager to Cisco Unified CallManager 5.1(3), see *Upgrading to Cisco Unified CallManager* for more information.

---

- Step 9** In the Basic Install window, choose **Continue** to install the software version on the DVD.

- Step 10** When the Timezone Configuration displays, choose the appropriate time zone for the server and then choose **OK**.

The Auto Negotiation Configuration window displays.

- Step 11** The installation process allows you to automatically set the speed and duplex settings of the Ethernet network interface card (NIC) by using automatic negotiation. You can change this setting after installation.

- To enable automatic negotiation, choose **Yes** and continue with [Step 13](#).

The MTU Configuration window displays.




---

**Note** To use this option, your hub or Ethernet switch must support automatic negotiation.

---

- To disable automatic negotiation, choose **No** and continue with [Step 12](#).  
The NIC Speed and Duplex Configuration window displays.

**Step 12** If you chose to disable automatic negotiation, manually choose the appropriate NIC speed and duplex settings now and choose **OK** to continue.

The MTU Configuration window displays.

**Step 13** In the MTU Configuration window, you can change the MTU size from the operating system default. The maximum transmission unit (MTU) represents the largest packet, in bytes, that this host will transmit on the network. If you are unsure of the MTU setting for your network, use the default value, which is 1500 bytes.




---

**Caution** Configuring the MTU size incorrectly can affect your network performance.

---

- To accept the default value (1500 bytes), choose **No**.
- To change the MTU size from the operating system default, choose **Yes**, enter the new MTU size, and choose **OK**.

The DHCP Configuration window displays.

**Step 14** For network configuration, you can choose to either set up static network IP address for the node or to use Dynamic Host Configuration Protocol (DHCP).

- If you have a DHCP server that is configured in your network and want to use DHCP, choose **Yes** and continue with [Step 17](#).

The Administrator Login Configuration window displays.

- If you want to configure static IP address for the node, choose **No** and continue with [Step 15](#).

The Static Network Configuration window displays.

**Step 15** If you chose not to use DHCP, enter your static network configuration values and choose **OK**. See [Table 2](#) for field descriptions.

The DNS Client Configuration window displays.

**Step 16** To enable DNS, choose **Yes**, enter your DNS client information, and choose **OK**. See [Table 2](#) for field descriptions.

The Administrator Login Configuration window displays.

**Step 17** Enter your Administrator login and password from [Table 1](#).

The Certificate Signing Request Information window displays.

**Step 18** Enter your certificate signing request information and choose **OK**.

The First Node Configuration window displays.

**Step 19** To configure this server as the first Cisco Unified CallManager node, choose **Yes**.

The Network Time Protocol Client Configuration window displays.

**Step 20** Choose whether you want to configure an external NTP server or manually configure the system time.



**Note** Cisco recommends that you use an external NTP server to ensure accurate system time on the first node. Ensure the external NTP server is stratum 9 or higher (meaning stratum 1-9). Subsequent nodes in the cluster will get their time from the first node.

- To set up an external NTP server, choose **Yes** and enter the IP address, NTP server name, or NTP server pool name for at least one NTP server. You can configure up to five NTP servers, and Cisco recommends that you use at least three. Choose **Proceed** to continue with the installation.

The system contacts an NTP server and automatically sets the time on the hardware clock.



**Note** If you already entered the network configuration information and the system rebooted (a Skip installation), the Test button displays. You can choose **Test** to check whether the NTP servers are accessible.

- To manually configure the system time, choose **No** and enter the appropriate date and time to set the hardware clock. Choose **OK** to continue with the installation.

The Database Access Security Configuration window displays.

**Step 21** Enter the Database Access Security password from [Table 1](#).

The SMTP Host Configuration window displays.

**Step 22** If you want to configure an SMTP server, choose **Yes** and enter the SMTP server name.



**Note** You must configure an SMTP server to use certain platform features; however, you can also configure an SMTP server later by using the operating system GUI or the command line interface.

**Step 23** Choose **OK**.

The Platform Configuration Confirmation window displays.

**Step 24** To continue with the installation, choose **OK**.

The Application User Password Configuration window displays.



**Note** If you need to change one of your previous entries, choose **Back**, make the change, and continue with the installation.

**Step 25** Enter the Application User Password from [Table 1](#) and confirm the password by entering it again.

**Step 26** Choose **OK**.

The system installs and configures the software. The DVD drive ejects, and the server reboots. Do not reinsert the DVD.

**Step 27** When the installation process completes, you get prompted to log in by using the Administrator account and password.

**Step 28** Complete the rest of the tasks that are listed in the [“Replacing the Publisher Node”](#) section on [page 12](#).

# Installing Cisco Unified CallManager on a New Subscriber Server

Use this procedure to install Cisco Unified CallManager on a new subscriber server.

## Procedure

- 
- Step 1** Insert the installation DVD into the tray and restart the server, so it boots from the DVD. After the server completes the boot sequence, the DVD Found window displays.
- Step 2** To perform the media check, choose **Yes**, or to skip the media check, choose **No**.  
The media check checks the integrity of the DVD. If your DVD has passed the media check previously, you might choose to skip the media check.
- Step 3** If you choose **Yes** to perform the media check, the system installer performs the media check and displays the Media Check Result window. Perform these tasks:
- If the Media Check Result displays Pass, choose **OK** to continue the installation.
  - If the media fails the media check, either download another copy of the software from Cisco.com or obtain another disc directly from Cisco.
- Step 4** The system installer performs the following hardware checks to ensure that your system is correctly configured. If the installer makes any changes to your hardware configuration settings, you will get prompted to restart your system. Leave the DVD in the drive during the reboot.
- First, the installation process checks for the correct drivers, and you may see the following warning:  
No hard drives have been found. You probably need to manually choose device drivers for install to succeed. Would you like to select drivers now?  
  
To continue the installation, choose **Yes**.
  - The installation next checks to see whether you have a supported hardware platform. If your server does not meet the exact hardware requirements, the installation process fails with a critical error. If you think this is not correct, capture the error and report it Cisco support.
  - The installation process next verifies RAID configuration and BIOS settings.




---

**Note** If this step repeats, choose **Yes** again.

---

- Step 5** If software is currently installed on the server, the Overwrite Hard Drive window opens and displays the current software version on your hard drive and the version on the DVD. Choose **Yes** to continue with the installation or **No** to cancel.




---

**Caution** If you choose **Yes** on the **Overwrite Hard Drive** window, all existing data on your hard drive gets overwritten and destroyed.

---

- Step 6** The Platform Installation Wizard window displays.
- Step 7** To configure the platform now, choose **Proceed**.
- Step 8** Choose the type of installation to perform by doing the following steps:
- In the Apply Patch window, choose one of the options:

- To upgrade to a later Service Release of the software during installation, choose **Yes**. Continue with the “[Applying a Patch](#)” section on page 25.
- To skip this step, choose **No**.
- To return to the previous window, choose **Back**.

b. In the Windows Upgrade window, choose **No**.




---

**Note** To perform a Windows Upgrade, that is, to upgrade from a Windows version of Cisco Unified CallManager to Cisco Unified CallManager 5.1(3), see *Upgrading to Cisco Unified CallManager* for more information.

---

**Step 9** In the Basic Install window, choose **Continue** to install the software version on the DVD.

**Step 10** When the Timezone Configuration displays, choose the appropriate time zone for the server and then choose **OK**.

The Auto Negotiation Configuration window displays.

**Step 11** The installation process allows you to automatically set the speed and duplex settings of the Ethernet network interface card (NIC) by using automatic negotiation. You can change this setting after installation.

- To enable automatic negotiation, choose **Yes** and continue with [Step 13](#).

The MTU Configuration window displays.




---

**Note** To use this option, ensure that your hub or Ethernet switch supports automatic negotiation.

---

- To disable automatic negotiation, choose **No** and continue with [Step 12](#).

The NIC Speed and Duplex Configuration window displays.

**Step 12** If you chose to disable automatic negotiation, manually choose the appropriate NIC speed and duplex settings now and choose **OK** to continue.

The MTU Configuration window displays.

**Step 13** In the MTU Configuration window, you can change the MTU size from the operating system default.

The maximum transmission unit (MTU) represents the largest packet, in bytes, that this host will transmit on the network. If you are unsure of the MTU setting for your network, use the default value, which is 1500 bytes.




---

**Caution** Configuring the MTU size incorrectly can affect your network performance.

---

- To accept the default value (1500 bytes), choose **No**.
- To change the MTU size from the operating system default, choose **Yes**, enter the new MTU size, and choose **OK**.

The DHCP Configuration window displays.

**Step 14** For network configuration, you can choose to either set up static network IP address for the node or to use Dynamic Host Configuration Protocol (DHCP).

- If you have a DHCP server that is configured in your network and want to use DHCP, choose **Yes** and continue with [Step 17](#).

The Administrator Login Configuration window displays.

- If you want to configure static IP address for the node, choose **No** and continue with [Step 15](#).

The Static Network Configuration window displays.

**Step 15** If you chose not to use DHCP, enter your static network configuration values and choose **OK**. See [Table 2](#) for field descriptions.

The DNS Client Configuration window displays.

**Step 16** To enable DNS, choose **Yes**, enter your DNS client information, and choose **OK**. See [Table 2](#) for field descriptions.

The Administrator Login Configuration window displays.

**Step 17** Enter your Administrator login and password from [Table 1](#).

The Certificate Signing Request Information window displays.

**Step 18** Enter your certificate signing request information and choose **OK**.

The First Node Configuration window displays.

**Step 19** To configure this server as a subsequent node in the cluster, choose **No**.

The First Node Configuration window displays.



**Caution**

You must configure a subsequent node on the first node by using Cisco Unified CallManager Administration before you install the subsequent node. For more information, see the *Cisco Unified CallManager Administration Guide*.

**Step 20** On the First Node Configuration window, read the Warning and make sure that you have correctly configured the first node. To continue with the installation of the subsequent node, choose **OK**.

The Network Connectivity Test Configuration window displays.

**Step 21** During installation of a subsequent node, the system checks to ensure that the subsequent node can connect to the first node.

- To pause the installation after the system successfully verifies network connectivity, choose **Yes**.
- To continue the installation with a pause, choose **No**.

The First Node Access Configuration window displays.

**Step 22** Enter the first node connectivity information to enable this subscriber node to connect to the subscriber node.

If you chose to pause the system after the system successfully verified network connectivity, the Successful Connection to First Node window displays. Choose **Continue**.



**Note**

If the network connectivity test fails, the system always stops and allows you to go back and reenter the parameter information.

The SMTP Host Configuration window displays.

**Step 23** If you want to configure an SMTP server, choose **Yes** and enter the SMTP server name.



**Note** You must configure an SMTP server to use certain operating system features; however, you can also configure an SMTP server later by using the operating system GUI or the command line interface.

The Platform Configuration Confirmation window displays.

- Step 24** To start installing the software, choose **OK**, or if you want to change the configuration, choose **Back**.
- Step 25** When the installation process completes, you get prompted to log in by using the Administrator account and password.
- Step 26** Complete the rest of the tasks in the “[Replacing a Subscriber or Dedicated TFTP Server Node](#)” section on page 13.

#### Sections that reference this section

- [Replacing a Subscriber or Dedicated TFTP Server Node, page 13](#)

## Applying a Patch

If you choose **Yes** in the Apply Patch window, the installation wizard installs the software version on the DVD first and then restarts the system. You then get prompted to enter certain network configuration parameter values and the location of the upgrade file.



**Note** You can upgrade to any higher release, so long as you have a full patch, not an ES or an SR, in which case you can only upgrade to a later service release of the same number.

If you are upgrading from Cisco Unified CallManager Release 5.x, the upgrade file name uses the following format:

```
cisco-ipt-k9-patchX.X.X.X-X.tar.gz.sgn
```

Where X.X.X.X-X represents the release and build number.



**Note** Do not rename the patch file before you install it because the system will not recognize it as a valid file.



**Note** Do not unzip or untar the file. If you do, the system may not be able to read the upgrade files.

You can access the upgrade file during the installation process from either a local disk (CD or DVD) or from a remote FTP or TFTP server.



**Note** You can only apply one patch during the installation process.

#### Procedure

- Step 1** The Install Upgrade Retrieval Mechanism Configuration window displays.

- Step 2** Choose the upgrade retrieval mechanism to use to retrieve the upgrade file:
- **SFTP**—Retrieves the upgrade file from a remote server by using the Secure File Transfer Protocol (SFTP). Skip to the [“Upgrading from a Remote Server” section on page 27](#).
  - **FTP**—Retrieves the upgrade file from a remote server by using File Transfer Protocol (FTP). Skip to the [“Upgrading from a Remote Server” section on page 27](#).
  - **LOCAL**—Retrieves the upgrade file from a local CD or DVD. Continue with the [“Upgrading From a Local Disc” section on page 26](#).

**Sections that reference this section**

- [Installing Cisco Unified CallManager on the New Publisher Server, page 18](#)
- [Installing Cisco Unified CallManager on a New Subscriber Server, page 22](#)

## Upgrading From a Local Disc

Before you can upgrade from a local drive, you must download the appropriate patch file from Cisco.com and copy the file to a CD or DVD. Because of the size of the patch files, you will need to copy it to a DVD in most cases.

- Step 1** When the Local Patch Configuration window displays, enter the patch directory and patch name, if required, and choose **OK**.



**Note** You only need to enter the patch directory when the patch is not stored in the root directory of the CD or DVD.

The Install Upgrade Patch Selection Validation window displays.

- Step 2** The window displays the patch file that is available on the CD or DVD. To update the system with this patch, choose **Continue**.
- Step 3** Choose the upgrade patch to install. The system installs the patch, then restarts the system so it is running the upgraded software version.
- Step 4** After the system restarts, the Preexisting Configuration Information window displays.
- Step 5** To continue the installation, choose **Proceed**.  
The Platform Installation Wizard window displays.
- Step 6** To continue the installation, choose **Proceed**, or choose **Cancel** to stop the installation.  
If you choose **Proceed**, the Apply Patch window displays. Continue with [Step 7](#).  
If you choose **Cancel**, the system halts and you can safely power down the server.
- Step 7** When the Apply Patch window displays, choose **No**.



**Note** You can only apply one patch during the upgrade process.

- Step 8** Continue with the node installation procedure for the node type that you are installing:

- [Step 8](#) of the “Installing Cisco Unified CallManager on the New Publisher Server” section on [page 18](#)
- [Step 8](#) of the “Installing Cisco Unified CallManager on a New Subscriber Server” section on [page 22](#)

## Upgrading from a Remote Server

If you chose to upgrade through an FTP or SFTP connection to a remote server, you must first configure the network settings.

- Step 1** In the Auto Negotiation Configuration window, the installation process allows you to automatically set the speed and duplex settings of the Ethernet network interface card (NIC) by using automatic negotiation. You can change this setting after installation.



**Note** To use this option, your hub or Ethernet switch must support automatic negotiation.

- To enable automatic negotiation, choose **Yes**.  
The MTU Configuration window displays. Continue with [Step 3](#).  
The DHCP Configuration window displays.
- To disable automatic negotiation, choose **No**. The NIC Speed and Duplex Configuration window displays.

- Step 2** If you chose to disable automatic negotiation, manually choose the appropriate NIC speed and duplex settings now and choose **OK** to continue.

- Step 3** In the MTU Configuration window, you can change the MTU size from the operating system default. The maximum transmission unit (MTU) represents the largest packet, in bytes, that this host will transmit on the network. If you are unsure of the MTU setting for your network, use the default value.



**Caution** Configuring the MTU size incorrectly can affect your network performance.

- To accept the default value (1500 bytes), choose **No**.
- To change the MTU size from the operating system default, choose **Yes**, enter the new MTU size, and choose **OK**.

The DHCP Configuration window displays.

- Step 4** For network configuration, you can choose to either set up static network IP addresses for the node and gateway or to use Dynamic Host Configuration Protocol (DHCP).

- If you have a DHCP server that is configured in your network and want to use DHCP, choose **Yes**. The system restarts and checks for network connectivity. Continue with [Step 7](#).
- If you want to configure static IP addresses for the node, choose **No**. The Static Network Configuration window displays.

- Step 5** If you chose not to use DHCP, enter your static network configuration values and choose **OK**. See [Table 2](#) for field descriptions.

The DNS Client Configuration window displays.

**Step 6** To enable DNS, choose **Yes**, enter your DNS client information, and choose **OK**. See [Table 2](#) for field descriptions.

After the system configures the network and checks for connectivity, the Remote Patch Configuration window displays.

**Step 7** Enter the location and login information for the remote file server. After the network restarts, the system connects to the remote server and retrieves a list of available upgrade patches.

If the upgrade file is located on a Linux or Unix server, you must enter a forward slash at the beginning of the directory path. For example, if the upgrade file is in the patches directory, you must enter **/patches**.

If the upgrade file is located on a Windows server, check with your system administrator for the correct directory path.

The Install Upgrade Patch Selection window displays.

**Step 8** Choose the upgrade patch to install. The system downloads, unpacks, and installs the patch and then restarts the system so that it is running the upgraded software version.

After the system restarts, the Preexisting Configuration Information window displays.

**Step 9** To continue the installation, choose **Proceed**.

The Platform Installation Wizard window displays.

**Step 10** To continue the installation, choose **Proceed**, or click **Cancel** to stop the installation.

If you choose **Proceed**, the Apply Patch window displays. Continue with [Step 11](#).

If you choose **Cancel**, the system halts and you can safely power down the server.

**Step 11** When the Apply Patch window displays, choose **No**.




---

**Note** You can only apply one patch during the upgrade process.

---

The Windows Upgrade window displays.

Choose **No** and continue with the node installation procedure for the node type that you are installing:

- [Step 8](#) of the “[Installing Cisco Unified CallManager on the New Publisher Server](#)” section on [page 18](#)
  - [Step 8](#) of the “[Installing Cisco Unified CallManager on a New Subscriber Server](#)” section on [page 22](#)
- 

## Uploading a License File

Use the following procedure to upload a license file to the Cisco Unified CallManager server with the matching MAC address that is provided when a license file is requested. For information about obtaining a license file, see the “[Obtaining a License File](#)” section on [page 18](#). The Cisco Unified CallManager server where the license file is loaded takes on the functionality of the license manager.




---

**Note** Upload the license file only on the first node of Cisco Unified CallManager cluster.

---

### Procedure

**Step 1** Choose **System > License > Upload License File**.

The License File Upload window displays.

**Step 2** The Existing License Files drop-down list box displays the license files that are already uploaded to the server.



**Note** To view the file content of any existing files, choose the file from the drop-down list box and click **View File**.

**Step 3** To choose a new license file to upload, click **Upload License File**.

The Upload File pop-up window displays.

**Step 4** Browse and choose a license file to upload to the server.



**Note** The format of the license file that you receive specifies CCM<timestamp>.lic. If you retain the .lic extension, you can rename the license file. You cannot use the license if you edit the contents of the file in any way.

**Step 5** Click **Upload License File**.

After the upload process completes, the Upload Result file displays.

**Step 6** Click **Close**.

**Step 7** In the License File Upload window, the status of the uploaded file displays.



**Note** The license file is uploaded into the database, only if the version specified in the license file is greater than or equal to the Cisco Unified CallManager version that is running in the cluster. If the version check fails, an alarm gets generated, and you should get a new license file with the correct version. The system bases the version check only on major releases.

#### Sections that reference this section

- [Replacing the Publisher Node, page 12](#)

## Restoring a Backup File

The Restore Wizard walks you through the steps that are required to restore a backup file. To perform a restore, use the procedure that follows.



### Caution

Before you restore Cisco Unified CallManager, ensure that the Cisco Unified CallManager version that is installed on the server matches the version of the backup file that you want to restore.

## Procedure

**Step 1** Navigate to the Disaster Recovery System. Log in to Cisco Unified CallManager Administration, choose **Disaster Recovery System** from the **Navigation** menu in the upper, right corner of the Cisco Unified CallManager Administration window, and click **Go**.

The Disaster Recovery System Logon window displays.

**Step 2** Log in to the Disaster Recovery System by using the same Administrator username and password that you use for Platform Administration.

**Step 3** Navigate to **Restore>Restore Wizard**. The Restore Wizard Step 1 window displays.

**Step 4** Choose the **Network Directory** storage location from which you want to restore the file and enter the following required information for the chosen storage location:

- **Server name:** Name or IP address of the network server
- **Path name:** Path name for the directory from which you want to restore the backup data
- **User name:** Valid username for an SFTP account on the remote system
- **Password:** Valid password for the SFTP account on the remote system

**Step 5** Click **Next**. The Restore Wizard Step 2 window displays.

**Step 6** Choose the backup file that you want to restore.



**Note** The backup filename indicates the date and time that the system created the backup file.

**Step 7** Click **Next**. The Restore Wizard Step 3 window displays.

**Step 8** Choose the features that you want to restore.



**Note** Only the features that were backed up to the file that you chose display.

**Step 9** Click **Next**. The Restore Wizard Step 4 window displays.

**Step 10** To start restoring the data, click **Restore**.

You get prompted to choose the node to restore.

**Step 11** Choose the appropriate node.



**Caution** After you choose the node to which you want the data restored, any existing data on that server gets overwritten.

**Step 12** Your data gets restored on the nodes that you chose. To view the status of the restore, see the [“Viewing the Restore Status”](#) section on page 31.

**Step 13** Restart the server. For more information on restarting, see the *Cisco Unified Communications Operating System Administration Guide*.



**Note** Depending on the size of your database and the components that you choose to restore, the system can require 1 hour or more to restore.

**Sections that reference this section**

- [Replacing the Publisher Node, page 12](#)
- [Replacing a Subscriber or Dedicated TFTP Server Node, page 13](#)

## Viewing the Restore Status


To check the status of the current restore job, perform the following steps:

**Procedure**

- 
- Step 1** Navigate to the Disaster Recovery System. Log in to Cisco Unified CallManager Administration, choose **Disaster Recovery System** from the **Navigation** menu in the upper, right corner of the Cisco Unified CallManager Administration window, and click **Go**.
- The Disaster Recovery System Logon window displays.
- Step 2** Log in to the Disaster Recovery System by using the same Administrator username and password that you use for Platform Administration.
- Step 3** Navigate to **Restore>Status**. The Restore Status window displays.
- Step 4** To view the restore log file, click the log filename link.
- 

## Post-Replacement Checklist

Perform the following tasks after you complete the cluster replacement:

|               | <b>Post-Upgrade Task</b>   | <b>Important Notes</b>   |
|---------------|--|--|
| <b>Step 1</b> | If your server or cluster ran in secure mode, create a new CTL file and distribute it to all of the cluster nodes. Do this step after you finish replacing or reinstalling all of the servers that you intend to replace or reinstall. | <p>For information about performing these tasks and about Cisco Unified CallManager security, refer to the “Configuring the CTL Client” procedures in the <i>Cisco Unified CallManager Security Guide</i>.</p> <p> <b>Caution</b> You must create and distribute a new CTL file or your secure phones will not work because they cannot register with the replaced Cisco Unified CallManager server(s).</p> |
| <b>Step 2</b> | Using the Cisco Unified CallManager Real-Time Monitoring Tool (RTMT), make sure that all the registration information values match the values that you recorded before the server replacement.   | See the “ <a href="#">Determining Registration Counts By Using RTMT</a> ” section on page 8.   |
| <b>Step 3</b> | Using the Cisco Unified CallManager Real-Time Monitoring Tool (RTMT), make sure that all the critical services and their status match those that you recorded before the server replacement.   | See the “ <a href="#">Recording Critical Service Status</a> ” section on page 8.   |

| Post-Upgrade Task   | Important Notes   |
|---|---|
| <p><b>Step 4</b> Using the Syslog viewer in the Cisco Unified CallManager Real-Time Monitoring Tool (RTMT), locate any events that have a severity of Error or higher.</p>  | <p>Perform this task to ensure that no system-affecting errors exist on your system.</p> <p>See the <a href="#">“Locating System Errors By Using Syslog Viewer”</a> section on page 9.</p>  |
| <p><b>Step 5</b> Using the Syslog viewer in the Cisco Unified CallManager Real-Time Monitoring Tool (RTMT), check the Replicate_State counter for the Number of Replicates Created and State of Replication object on all nodes. The value on each node should equal 2.</p> <p>This counter represents the state of replication, which includes the following possible values:</p> <ul style="list-style-type: none"> <li>• 0 (Not Started)—No Subscribers exist or the Database Layer Monitor service is not running and has not been running since the subscriber was installed.</li> <li>• 1 (Started)—Replication is currently being setup.</li> <li>• 2 (Finished)—Replication setup was completed and is working.</li> <li>• 3 (Broken)—Replication failed during setup and is not working.</li> </ul> <p>3=Data is not replicating correctly; 4 = Replication is not setup correctly).</p> | <p>To access the appropriate object and counter, use the following procedure:</p> <ol style="list-style-type: none"> <li>1. Perform one of the following tasks: <ul style="list-style-type: none"> <li>• In the Quick Launch Channel, click <b>Performance</b>; then, click the <b>Performance</b> icon.</li> <li>• Choose <b>Performance &gt; Open Performance Monitoring</b>.</li> </ul> </li> <li>2. Double-click the name of the server where you want to add a counter to monitor.</li> <li>3. Double-click the <b>Number of Replicates Created and State of Replication</b> object.</li> <li>4. Double-click the <b>Replicate_State</b> counter.</li> <li>5. Choose the <b>ReplicateCount</b> instance and click <b>Add</b>.</li> </ol> |
| <p><b>Step 6</b> From Cisco Unified CallManager Administration, make sure that the number of phones, gateways, trunks, users, and route patterns that are configured in the database matches the numbers that you recorded before the server replacement.</p>   | <p>See the <a href="#">“Determining System Configuration Counts”</a> section on page 10.</p>  |
| <p><b>Step 7</b> From the Firmware Load Information window in Cisco Unified CallManager Administration, make sure that the phone load and device type values match those that you recorded before the server replacement.</p>   | <p>If a device type is missing, you may need to reinstall the COP file enabler for that type. Then, reboot the cluster and start post-replacement checklist again.</p> <p>See the <a href="#">“Firmware Information”</a> section on page 11.</p>  |
| <p><b>Step 8</b> Compare the system version on each node in your cluster by using Cisco Unified Communications Operating System Administration and make sure that it matches the version that you recorded before the replacement.</p>  | <p>See the <a href="#">“Obtaining System Version Information”</a> section on page 11.</p>   |
| <p><b>Step 9</b> Reconfigure CDR destinations, if applicable.</p>   | <p>See the <a href="#">“Accessing CDR Management Configuration”</a> section on page 10.</p>   |
| <p><b>Step 10</b> Reconfigure all Trace and Log Central jobs.</p>   | <p>See the <a href="#">“Recording Trace and Log Central Job Details”</a> section on page 9.</p>   |
| <p><b>Step 11</b> Perform any system tests that you performed before the replacement and verify that all test calls succeed.</p>  |   |
| <p><b>Step 12</b> Reconfigure DRS location and schedule, if applicable.</p>   | <p>See the <a href="#">“Creating a Backup File”</a> section on page 14.</p>   |

# Obtaining Documentation, Obtaining Support, and Security Guidelines

For information on obtaining documentation, obtaining support, providing documentation feedback, security guidelines, and also recommended aliases and general Cisco documents, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

---

CCVP, the Cisco logo, and the Cisco Square Bridge logo are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn is a service mark of Cisco Systems, Inc.; and Access Registrar, Aironet, BPX, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, iQuick Study, LightStream, Linksys, MeetingPlace, MGX, Networking Academy, Network Registrar, PIX, ProConnect, ScriptShare, SMARTnet, StackWise, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0709R)

Copyright © 2007. Cisco Systems, Inc. All rights reserved.

