

Cisco 3640 Gateway - PBX Interoperability: Lucent/Avaya Definity G3si V9 PBX with E1 ISDN PRI to an MGCP Gateway

Introduction


This note describes the interoperability of the Lucent/Avaya Definity G3si V9 PBX and the Cisco 3640 router in an MGCP gateway.

The signaling protocol is E1 ISDN PRI and QSIG.

The network topology diagram shows the end-to-end interoperability.

Network Topology

Figure 1. Network Topology



Limitations

None



System Components

Hardware Requirements

Cisco 3640 router

Lucent/Avaya Definity G3si V9 PBX

Software Requirements

Cisco IOS Release 12.2(10.7)T6

PBX Software Version: V9

Configuration

Configure CO loop-start trunk

Configure analog station

Configure digital station

Configuring the Lucent/Avaya Definity G3si V9 PBX

Configure the DS1 circuit pack. Use the following screens as a reference.



DEFINITY® Site Administration - [AvayaV9 GEDI]

File Edit View System Action Tools Window Help

AvayaV9

change ds1 a14 send (return) help (f5) cancel (esc) enter (f3) schedule (f9) next (f7) previous (f8) next form (f6)

1

DS1 CIRCUIT PACK

Location: **01A14** Name: **E1-ISDN QSIG**
Bit Rate: **2.048** Line Coding: **hdb3**

Signaling Mode: **isdn-pri**
Connect: **network**

CentreVu Long Timers? **n** Country Protocol: **1**
Interworking Message: **PROGress** Protocol Version: **b**
Interface Companding: **alaw** CRC? **y**
Idle Code: **11111111**

DCP/Analog Bearer Capability: **3.1kHz**

Slip Detection? **n** Near-end CSU Type: **other**

Right-click in a field to see a list of valid entries or help text

NUM



DEFINITY® Site Administration - [AvayaV9 GEDI]

File Edit View System Action Tools Window Help

AvayaV9

change signaling-group 14 send (return) help (f5) cancel (esc) enter (f3) schedule (f9) next (f7) previous (f8) next form (f6)

1 2 3 4 5

SIGNALING GROUP

Group Number: 14

Associated Signaling?

Primary D-Channel:

Max number of NCA TSC:

Max number of CA TSC:

Trunk Group for NCA TSC:

Trunk Group for Channel Selection:

Supplementary Service Protocol:

Right-click in a field to see a list of valid entries or help text

Ready



DEFINITY® Site Administration - [AvayaV9 GEDI]

File Edit View System Action Tools Window Help

AvayaV9

change trunk-group 14 send (return) help (f5) cancel (esc) enter (f3) schedule (f9) next (f7) previous (f8) next form (f6)

1 2 3 4 5 6 7 8 9 10

TRUNK GROUP

Group Number: 14 Group Type: **isdn** CDR Reports: **y**
Group Name: **E1 ISDN** COR: **1** TN: **1** TAC: **669**
Direction: **two-way** Outgoing Display? **y**
Dial Access? **y** Busy Threshold: **99** Night Service:
Queue Length: **0**
Service Type: **tandem** TestCall ITC: **rest**
Far End Test Line No:
TestCall BCC: **4**

TRUNK PARAMETERS

Codeset to Send Display: **7** Codeset to Send National IEs: **7**
Max Message Size to Send: **260** Charge Advice: **none**
Supplementary Service Protocol: **c** Digit Handling (in/out): **enbloc/enbloc**

Trunk Hunt: **ascend**

Calling Number - Delete: Insert: Digital Loss Group: **13**
Bit Rate: **1200** Synchronization: **async** Duplex: **full**
Disconnect Supervision - In? **y** Out? **y**
Answer Supervision Timeout: **0**

Right-click in a field to see a list of valid entries or help text

Ready NUM



DEFINITY® Site Administration - [AvayaV9 GEDI]

File Edit View System Action Tools Window Help

AvayaV9

change trunk-group 14 send (return) help (f5) cancel (esc) enter (f3) schedule (f9) next (f7) previous (f8) next form (f6)

1 2 3 4 5 6 7 8 9 10

TRUNK FEATURES

ACA Assignment? Measured: Wideband Support?
Maintenance Tests?

Data Restriction? NCA-TSC Trunk Member:
Send Name: Send Calling Number:

Used for DCS? Hop Dgt?

Suppress # Outpulsing? Numbering Format:

Outgoing Channel ID Encoding: UUI IE Treatment:

Replace Restricted Numbers?
Replace Unavailable Numbers?
Send Connected Number:

Send UCID?
Send Codeset 6/7 LAI IE? Ds1 Echo Cancellation?

Right-click in a field to see a list of valid entries or help text

Ready



DEFINITY® Site Administration - [AvayaV9 GEDI]

File Edit View System Action Tools Window Help

AvayaV9

change trunk-group 14 send (return) help (f5) cancel (esc) enter (f3) schedule (f9) next (f7) previous (f8) next form (f6)

1 2 3 4 5 6 7 8 9 10

TRUNK GROUP
Administered Members (min/max): 1/30
Total Administered Members: 30

GROUP MEMBER ASSIGNMENTS

	Port	Code	Sfx	Name	Night	Sig Grp
1:	01A1401	TN464	F			14
2:	01A1402	TN464	F			14
3:	01A1403	TN464	F			14
4:	01A1404	TN464	F			14
5:	01A1405	TN464	F			14
6:	01A1406	TN464	F			14
7:	01A1407	TN464	F			14
8:	01A1408	TN464	F			14
9:	01A1409	TN464	F			14
10:	01A1410	TN464	F			14
11:	01A1411	TN464	F			14
12:	01A1412	TN464	F			14
13:	01A1413	TN464	F			14
14:	01A1414	TN464	F			14
15:	01A1415	TN464	F			14

Right-click in a field to see a list of valid entries or help text

Ready NUM



DEFINITY® Site Administration - [AvayaV9 GEDI]

File Edit View System Action Tools Window Help

AvayaV9

change trunk-group 14 send (return) help (f5) cancel (esc) enter (f3) schedule (f9) next (f7) previous (f8) next form (f6)

1 2 3 4 5 6 7 8 9 10

TRUNK GROUP
Administered Members (min/max): 1/30
Total Administered Members: 30

GROUP MEMBER ASSIGNMENTS

	Port	Code	Sfx	Name	Night	Sig Grp
16:	01A1417	TN464	F			14
17:	01A1418	TN464	F			14
18:	01A1419	TN464	F			14
19:	01A1420	TN464	F			14
20:	01A1421	TN464	F			14
21:	01A1422	TN464	F			14
22:	01A1423	TN464	F			14
23:	01A1424	TN464	F			14
24:	01A1425	TN464	F			14
25:	01A1426	TN464	F			14
26:	01A1427	TN464	F			14
27:	01A1428	TN464	F			14
28:	01A1429	TN464	F			14
29:	01A1430	TN464	F			14
30:	01A1431	TN464	F			14

Right-click in a field to see a list of valid entries or help text

Ready NUM



DEFINITY® Site Administration - [AvayaV9 GEDI]

File Edit View System Action Tools Window Help

AvayaV9

change dialplan send (return) help (f5) cancel (esc) enter (f3) schedule (f9) next (f7) previous (f8) next form (f6)

1

DIAL PLAN RECORD

Local Node Number: 1
ETA Node Number:
Uniform Dialing Plan: 4-digit ETA Routing Pattern:
UDP Extension Search Order: udp-table-first

FIRST DIGIT TABLE

First Digit	- 1 -	- 2 -	- 3 -	- 4 -	- 5 -	- 6 -
1:				peextension		
2:				extension		
3:				extension		
4:				extension		
5:						
6:			dac			
7:						
8:	fac					
9:	fac					
0:	attd					
*:			fac			
#:						

Right-click in a field to see a list of valid entries or help text

Ready

NUM

Configure the Cisco 3640 Router

Verify the loop-start configuration using the **show running-config** command. The following is sample output.

```
3640_Analog#sh running-config
Building configuration...

Current configuration : 2297 bytes
!
version 12.2
```



```
no parser cache
service timestamps debug uptime
service timestamps log uptime
no service password-encryption
no service dhcp
!
hostname 3640_Analog
!
no logging buffered
!
voice-card 1
!
ip subnet-zero
!
no ip domain lookup
!
isdn switch-type primary-net5
isdn voice-call-failure 0
!
voice call carrier capacity active
!
mta receive maximum-recipients 0
!
controller E1 1/0
framing NO-CRC4
ds0-group 1 timeslots 1 type e&m-immediate-start
!
controller E1 1/1
pri-group timeslots 1-31
!
interface Ethernet0/0
ip address 10.10.10.102 255.255.255.0
no ip mroute-cache
shutdown
full-duplex
no cdp enable
!
interface Ethernet0/1
ip address 1.1.1.1 255.255.255.0
no ip mroute-cache
full-duplex
no cdp enable
!
interface Serial1/1:15
no ip address
no logging event link-status
isdn switch-type primary-net5
isdn protocol-emulate network
isdn incoming-voice voice
no cdp enable
!
interface BRI2/0
no ip address
isdn switch-type basic-qsig
isdn protocol-emulate network
isdn layer1-emulate network
isdn incoming-voice voice
isdn static-tei 0
isdn skipsend-idverify
!
interface BRI2/1
no ip address
shutdown
isdn switch-type basic-qsig
isdn overlap-receiving
isdn incoming-voice voice
!
ip classless
no ip http server
!
no cdp run
```



```
!  
snmp-server manager  
call rsvp-sync  
!  
voice-port 1/0:1  
!  
voice-port 1/1:15  
!  
voice-port 2/0/0  
!  
voice-port 2/0/1  
!  
voice-port 3/0/0  
!  
voice-port 3/0/1  
!  
voice-port 3/1/0  
!  
voice-port 3/1/1  
!  
no mgcp timer receive-rtcp  
!  
mgcp profile default  
!  
dial-peer cor custom  
!  
dial-peer voice 1 pots  
shutdown  
destination-pattern 5...  
direct-inward-dial  
port 2/0/0  
forward-digits all  
!  
dial-peer voice 2 voip  
destination-pattern 2...  
session target ipv4:1.1.1.2  
!  
dial-peer voice 3 pots  
destination-pattern 3000  
port 3/0/0  
!  
dial-peer voice 4 pots  
destination-pattern 3001  
port 3/0/1  
!  
dial-peer voice 5 pots  
shutdown  
destination-pattern 3...  
progress_ind setup enable 1  
direct-inward-dial  
port 2/0/1  
forward-digits all  
!  
dial-peer voice 6 pots  
destination-pattern 4...  
port 1/1:15  
prefix 4  
!  
dial-peer voice 7 voip  
destination-pattern 5...  
session target ipv4:1.1.1.2  
!  
dial-peer voice 8 pots  
destination-pattern 8000  
port 3/1/0  
!  
line con 0  
line aux 0  
line vty 0 4  
login  
!
```



end

Important Information

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.



Corporate Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
www.cisco.com
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 526-4100

European Headquarters

Cisco Systems International
BV
Haarlerbergpark
Haarlerbergweg 13-19
1101 CH Amsterdam
The Netherlands
www-europe.cisco.com
Tel: 31 0 20 357 1000
Fax: 31 0 20 357 1100

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
www.cisco.com
Tel: 408 526-7660
Fax: 408 527-0883

Asia Pacific Headquarters

Cisco Systems, Inc.
Capital Tower
168 Robinson Road
#22-01 to #29-01
Singapore 068912
www.cisco.com
Tel: +65 317 7777
Fax: +65 317 7799

Cisco Systems has more than 200 offices in the following countries and regions. Addresses, phone numbers, and fax numbers are listed on **the Cisco Web site at www.cisco.com/go/offices.**

Argentina • Australia • Austria • Belgium • Brazil • Bulgaria • Canada • Chile • China PRC • Colombia • Costa Rica • Croatia • Czech Republic • Denmark • Dubai, UAE • Finland • France • Germany • Greece • Hong Kong SAR • Hungary • India • Indonesia • Ireland • Israel • Italy • Japan • Korea • Luxembourg • Malaysia • Mexico • The Netherlands • New Zealand • Norway • Peru • Philippines • Poland • Portugal • Puerto Rico • Romania • Russia • Saudi Arabia • Scotland • Singapore • Slovakia • Slovenia • South Africa • Spain • Sweden • Switzerland • Taiwan • Thailand • Turkey • Ukraine • United Kingdom • United States • Venezuela • Vietnam • Zimbabwe

Copyright 2003 Cisco Systems, Inc. All rights reserved. Cisco, Cisco Systems, and the Cisco Systems logo are registered trademarks or trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and certain other countries. All other trademarks mentioned in this document or Web site are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0301R)