



## Uninstalling Cisco Unity

---

This chapter contains the following sections:

- [Task List for Uninstalling Cisco Unity, page 12-1](#)
- [Removing Voice Card Software, page 12-1](#)
- [Uninstalling Cisco Unity, page 12-3](#)
- [Removing Cisco Unity Properties from Names.nsf, page 12-3](#)



**Note**

---

To replace one or both servers in a pair of Cisco Unity failover servers or to convert a primary or secondary server to a non-failover server, see the [“Replacing or Converting a Cisco Unity Server or Failover Servers”](#) chapter instead.

---

## Task List for Uninstalling Cisco Unity

1. *If Cisco Unity is integrated with a circuit-switched phone system:* Remove voice card software from the Cisco Unity server. See the [“Removing Voice Card Software”](#) section on page 12-1.
2. *If Cisco Unity failover is configured:* Disable SQL Server replication. See the [“Stopping SQL Server Replication on the Primary Server \(With Failover Configured\)”](#) section on page 12-3.
3. Uninstall Cisco Unity. See the [“Uninstalling Cisco Unity”](#) section on page 12-3.
4. Remove Cisco Unity properties from Names.nsf. See the [“Removing Cisco Unity Properties from Names.nsf”](#) section on page 12-3.

## Removing Voice Card Software



**Note**

---

If Cisco Unity is not integrated with a circuit-switched phone system, skip this section.

---

### To Remove Intel Dialogic Voice Card Software

---

- Step 1** Exit the Cisco Unity software, if it is running. For more information, see the [“Exiting the Cisco Unity Software”](#) section on page A-1.
- Step 2** On the Windows Start menu, click **Programs > Administrative Tools > Services**.

- Step 3** In the right pane of the Services dialog box, right-click **Telephony**, and click **Stop**.
- Step 4** If you are prompted to stop other services, click **Yes**.
- Step 5** On the Windows Start menu, click **Programs > Dialogic Systems Software > Dialogic Configuration Manager–DCM**.
- Dialogic Configuration Manager may display an error message about not detecting devices. This error is harmless. Click **OK**.
- Step 6** On the Service menu, click **Stop Service**.
- Step 7** Click **Close**.
- Step 8** Close the DCM.
- Step 9** On the Windows Start menu, click **Settings > Control Panel > Phone and Modem Options**.
- Step 10** Click the **Advanced** tab.
- Step 11** Click **Dialogic Generation 2 Service Provider for NT** or **DSE Service Provider**, as applicable.
- Step 12** Click **Remove**.
- Step 13** Click **Yes**.
- Step 14** Click **OK** to close the Phone and Modem Options dialog box.
- Step 15** In Control Panel, double-click **Sounds and Multimedia**.
- Step 16** In the Sounds and Multimedia Options dialog box, click the **Hardware** tab.
- Step 17** Click **Legacy Audio Drivers**.
- Step 18** Click **Properties**.
- Step 19** In the Legacy Audio Drivers Properties dialog box, click the **Properties** tab.
- Step 20** Expand **Audio Devices**.
- Step 21** Click **Audio for Dialogic WAVE**.
- Step 22** Click **Remove**.
- Step 23** Click **Yes** to confirm.
- Step 24** When prompted to restart the server, click **Don't Restart Now**.




---

**Caution** If you restart now, the WAVE driver is not removed.

---

- Step 25** Click **OK** to close the Legacy Audio Drivers Properties dialog box.
- Step 26** Click **OK** to close the Sounds and Multimedia Properties dialog box.
- Step 27** Close Control Panel.
- Step 28** On the Windows Start menu, click **Programs > Dialogic System Software > Uninstall**.
- Step 29** Follow the on-screen prompts to uninstall the software.
- If you are prompted to delete shared files, click **No to All**.
- Step 30** Click **OK**.
- Step 31** When the uninstallation is complete, click **Yes** to restart the server. (The Dialogic-triggered restart may not restart the session; in this case, manually restart.)

- Step 32** After the server restarts, log on.
- Step 33** In Windows Explorer, browse to the directory where Cisco Unity is installed (the default directory is CommServer), and delete the **Dialogic** directory.
- 

## Stopping SQL Server Replication on the Primary Server (With Failover Configured)

**Note**

If Cisco Unity failover is not configured, skip this section.

---

**To Stop SQL Server Replication on the Primary Server (With Failover Configured)**

## Uninstalling Cisco Unity

To uninstall Cisco Unity, download, install, and run the latest version of the Cisco Unity Uninstall utility for your version of Cisco Unity. The Uninstall utility is available at <http://ciscounitytools.com>.

**Caution**

Follow Uninstall Help carefully, or the uninstallation will fail. Help also lists the manual steps that must be done to complete the uninstallation.

---

## Removing Cisco Unity Properties from Names.nsf

After you uninstall Cisco Unity from the server, Cisco Unity properties still appear in Names.nsf. To remove Cisco Unity properties from the directory, download, install, and run the Remove Cisco Unity Properties from Notes utility. The utility is available at <http://ciscounitytools.com>.

