



Managing the WLSE via the CLI

This chapter describes the major system administration tasks that you can perform by using the command line interface (CLI). These tasks apply to the WLSE 1105, WLSE 1130, and [WLSE 1130-19](#).

For details on using CLI commands, see [Appendix A, “Using the Command Line Interface \(CLI\).”](#)



Note

For administrative tasks performed from the Web interface, see the WLSE online help or the preceding chapters in this guide.

This chapter contains the following topics:

- [Logging In and Out via CLI, page 12-2](#)
- [User Management via CLI, page 12-3](#)
- [Backing Up and Restoring via CLI, page 12-5](#)
- [Upgrading WLSE Software via CLI, page 12-12](#)
- [Shutting Down and Powering Off the WLSE, page 12-13](#)
- [Rebooting the WLSE via CLI, page 12-12](#)
- [Setting WLSE System Date and Time, page 12-13](#)
- [Configuring Ethernet Interfaces, page 12-16](#)
- [Administering Management Services via CLI, page 12-19](#)
- [Viewing System Information via CLI, page 12-20](#)
- [Recovery Management, page 12-21](#)

Logging In and Out via CLI

Use the following commands to log in and out of the WLSE.

Logging In

To use the CLI to log in:

Procedure

Step 1 Attach a console or connect via Telnet or SSH to the WLSE.

If you are using a console, make sure you are attaching it to the correct port:

- For the WLSE 1105, use the serial port on the front panel; do not use the serial port on the back panel as the console port.
- For the WLSE 1130 and [WLSE 1130-19](#), use the serial port on the back panel as the console port.

For more information about the location of the serial ports and connecting to them, see the Installation and Configuration Guide for your hardware version.

Step 2 At the login prompt, enter `admin` or use another account that has CLI privileges.

Step 3 At the password prompt, enter the password.

Result: The system prompt appears.



Note

Users must have CLI privileges to use the CLI. Users who have only level 0 privileges can use only a subset of the CLI commands. Users who have level 15 privileges can use all commands. For information on setting these privileges via CLI, see [Managing User Accounts, page 12-3](#). For information on setting CLI privileges via the Web interface, see [Managing User Accounts, page 11-59](#).

Logging Out

To log out, use the **exit** command.

User Management via CLI

This section contains the following topics:

- [Managing User Accounts, page 12-3](#)
- [Setting Up TACACS+ or RADIUS Authentication for CLI Login, page 12-4](#)

Managing User Accounts

You can create users via the CLI and grant them CLI privileges. Such users appear in the user management screens of the Web interface, but they do not have access to the Web interface features unless you modify them in the Web interface to add access.

Creating and Modifying User Accounts

**Note**

Your login determines whether you can use this command.

To create or modify user accounts:

Procedure

-
- Step 1** Log in. For more information, see [Logging In and Out via CLI, page 12-2](#).
- Step 2** Enter the following command for each user account you want to add or modify:

```
username name password password privilege 0 | 15
```

where:

- *name* is the username of the account.
- *password* is the user's password.

- **privilege 0** allows access to a subset of the CLI commands (see [Privilege Level 0 Commands, page A-9](#)). This is the default and is assigned to the account even if you omit this argument.
- **privilege 15** allows access to all CLI commands.

Step 3 To allow access to the Web interface, log into the Web interface and modify the user's account to add roles and privileges (see [Managing User Accounts, page 11-59](#) or the online help).

Deleting User Accounts

To delete a user, enter the following command:

```
no username name
```

where *name* is the user to be deleted.

Setting Up TACACS+ or RADIUS Authentication for CLI Login

You can use an authentication server for logging in through Telnet or SSH. This requires configuring the authentication server and setting up the authentication module on the WLSE.

To configure the authentication server, add the WLSE as a client, configure the shared secret, and add the users. The users must also exist on the WLSE; see [Creating and Modifying User Accounts, page 12-3](#).



Note

Your login determines whether you can use this command.

To set up the WLSE's RADIUS module, enter the following command:

```
auth cli radius secret server
```

where *secret* is the shared secret and *server* is the hostname or IP address of the authentication server.

To set up the WLSE's TACACS+ module:

```
auth cli tacacs secret server
```

where *secret* is the shared secret and *server* is the hostname or IP address of the authentication server.

For more information about using alternative authentication, see [auth, page A-17](#), and [Overview: Authentication Modules, page 11-18](#).

Backing Up and Restoring via CLI

You should backup the WLSE at regular intervals and before software updates or system recoveries.

Before attempting to backup or restore your WLSE, make sure you have the following:

- A remote FTP host to serve as the backup location.
- A valid username and password on the backup location.
- A backup directory on the backup location that has the proper permissions for the username and password you will be using.

Backups preserve the database, flash memory (network information and users' CLI privileges), and the user configuration (including users, roles, templates, firmware images, device credentials, policies, and threshold settings).

Backups do not preserve startup templates, the mail route, and AAA server trend data. Also, the four system-defined user roles will be reset to their default privileges.

This section contains procedures for specifying the backup location, backing up the WLSE, and restoring the WLSE. For an example backup sequence, see the description of the **backup** CLI command in [backup, page A-18](#).



Note

You can replace one WLSE with another by backing up and restoring the data from the old WLSE to the new one. See [Installing a Replacement WLSE, page 12-9](#).



Note

You can restore a backup made on one WLSE to another WLSE. For information, see [Copying Configuration Data to another WLSE, page 12-11](#).

Setting Up the Backup Location

Before backing up, you must specify an FTP server as the backup location.

Please observe the following cautions about the backup location:

- Backup has only been tested on the standard Windows 2000, Windows XP, and Unix FTP servers. Therefore, only these servers are explicitly supported for WLSE backups. However, any server that uses standard FTP commands and protocol should work.
- Make sure the target FTP directory has enough free space, especially if you are running frequent backups. If there is not enough space, the backup may fail or the backup data may be corrupted.
- If you are using a Windows 2000 or Windows XP server as the backup location, you must configure the server for UNIX directory mode. See [Configuring a Windows System as a Backup Location, page 11-25](#).

**Note**

Your login determines whether you can use the commands described in this section.

Specifying the Backup Location

To specify the backup location:

Procedure

Step 1 Log in. For more information, see [Logging In and Out via CLI, page 12-2](#).

Step 2 Enter the following command:

```
backupconfig hostname username password directory
```

where:

- *hostname* is the hostname or IP address of the backup system.
- *username* is the username of a user on the backup system.
- *password* is the password of the user on the backup system.
- *directory* is the pathname of the backup directory, if different from user's default directory.

This backup location information will be used by the **backup**, **listbackup**, and **restore** commands.

Displaying the Backup Location

If a backup location has been specified, you can display the hostname and username by entering the following command:

```
show backupconfig
```

Removing the Backup Location

To remove the backup location, enter the following command:

```
no backupconfig
```

Backing Up the WLSE

When backing up via the CLI, you can perform manual, one-time backups. To schedule regular backups, use the Web interface; for information, see [Backing Up and Restoring Data, page 11-22](#).

**Note**

WLSE operations continue during the backup.

**Note**

Your login determines whether you can use this command.

Procedure

To back up the WLSE:

- Step 1** Log in. For more information, see [Logging In and Out via CLI, page 12-2](#).
- Step 2** Make sure the backup location has been configured. See [Setting Up the Backup Location, page 12-6](#).

Step 3 To test the availability of the backup location enter:

```
backup test
```

Step 4 To backup the WLSE, enter:

```
backup
```

Result: The WLSE will be backed up to the location you specified in the **backupconfig** command.

Restoring WLSE Configuration

During the restore procedure, the following occur in sequence:

1. The WLSE shuts down automatically.
2. Data is restored.
3. The WLSE reboots.



Note

Your login determines whether you can use these commands.

Procedure

To restore the WLSE configuration:

Step 1 Log in. For more information, see [Logging In and Out via CLI, page 12-2](#).

Step 2 Set up or point to the backup location by using the **backupconfig** command.

Step 3 To list the available backups, enter:

```
listbackup
```

Step 4 Enter the following command:

```
restore backup_name
```

where *backup_name* is the name of the backup you want to restore.

To restore without overwriting the WLSE flash memory, use the following command:

```
restore -n backup_name
```

The flash memory contains the WLSE's network settings (WLSE hostname, IP address, domain name, name servers, NTP server) and users' CLI privileges.

For information about restoring from one WLSE to another, see:

- [Installing a Replacement WLSE, page 12-9](#)
- [Copying Configuration Data to another WLSE, page 12-11](#)

Installing a Replacement WLSE

This section describes tasks you should perform when installing a replacement WLSE (replacing an existing WLSE with a new one). If you are simply using a backup from one WLSE to restore data on another WLSE, see [Copying Configuration Data to another WLSE, page 12-11](#).

Removing the Old WLSE



Note

Your login determines whether you can use these commands.

Before removing the old WLSE:

- Step 1** Log in to the old WLSE. For more information, see [Logging In and Out via CLI, page 12-2](#).
- Step 2** Record the WLSE's configuration (the information that you entered when you initially set up the WLSE). Use the following command to display the configuration:
- ```
show config
```
- Step 3** Back up the data from the old WLSE. See [Backing Up and Restoring via CLI, page 12-5](#) for details.
- Step 4** Enter the following command:

```
shutdown
```

- Step 5** Power down and remove the old system.
- 

## Installing the Replacement WLSE



**Note** Your login determines whether you can use this command.

---

To install the replacement WLSE:

---

- Step 1** Install and power on the new WLSE, using the instructions in the *Installation and Configuration Guide for the Wireless LAN Solution Engine, Release 2.7*.

- Step 2** If you are using the same basic network information (for example, IP address and hostname) that you used on the old WLSE:

- a. Run the setup program.
- b. Enter the following command to restore all the configuration data from the old system, including the basic network information:

```
restore backup_name
```

- Step 3** If you are *not* using the same basic configuration (for example, IP address and hostname) that you used on the old WLSE:

- a. Run the setup program.
- b. Enter the following command to restore all the configuration data from the old system except the basic network information:

```
restore -n backup_name
```

---

# Copying Configuration Data to another WLSE

You can back up data from one WLSE and copy it to another by using the backup and restore features. If you are replacing one WLSE with another, see [Installing a Replacement WLSE, page 12-9](#).

**Note**

You cannot restore a backup from a WLSE 1130 or [WLSE 1130-19](#) to a WLSE 1105.

**Note**

Your login determines whether you can use this command.

To restore a backup from one WLSE to another:

- Step 1** Back up the data on the original WLSE. For more information, see [Backing Up and Restoring via CLI, page 12-5](#).
- Step 2** If you have installed a new WLSE and have not configured it yet, run the setup program and complete the configuration.  
  
For information on the setup program and additional configuration steps, use the *Installation and Configuration Guide for the Wireless LAN Solution Engine, Release 2.7*.
- Step 3** Restore the configuration data from your backup by entering the following command. Use the backup image name as the argument.

```
restore -n backup_name
```

**Note**

Be sure to use the **-n** option. Otherwise, the network information in flash memory will be overwritten and you will have to erase the WLSE's configuration and run the setup program to reenter the network information.

# Upgrading WLSE Software via CLI

For information about installing software updates on the WLSE by using the CLI, see the *Installation and Configuration Guide for the Wireless LAN Solution Engine, Release 2.7*.

## Rebooting the WLSE via CLI

**Caution**

All processes running on the system stop and restart when you run the **reload** command. The WLSE will not respond while it is reloading.

Rebooting the system restarts its management services, even if the services were stopped prior to the reboot.

**Note**

Your login determines whether you can use this command.

To restart the WLSE:

**Step 1** Log in. See [Logging In and Out via CLI, page 12-2](#).

**Step 2** Enter the following command:

```
reload
```

You are prompted to verify the reload. Enter **yes** to confirm or **no** to cancel the reload.

# Shutting Down and Powering Off the WLSE

**Caution**

If you power off the WLSE improperly, you might disable the system.

**Note**

Your login determines whether you can use this command.

To shut down the WLSE:

**Step 1** Log in. See [Logging In and Out via CLI, page 12-2](#).

**Step 2** Enter the following command:

```
shutdown
```

**Step 3** Power off the WLSE.

## Setting WLSE System Date and Time

The WLSE uses Universal Coordinated Time (UTC) for the system time and date. The WLSE uses UTC to display the time and date when you are connected via Telnet/SSH or the console and when you are viewing log files. The WLSE uses the client's local time to display the time and date when connected via the Web interface.

You can set and maintain the system date and time by:

- [Setting the System Clock Using NTP, page 12-14](#) (the recommended method).
- [Setting the System Clock Manually, page 12-15](#).

**Note**

You can also set the current time by using the Web interface. For information, see [Setting Time, Time Servers, Name Servers, and Web Session Timeout, page 11-49](#).

To display the system time, use the **show clock** command. For more information on this command, see [show clock, page A-11](#).

## Setting the System Clock Using NTP

NTP is the recommended method for configuring time and date on the system. If your network uses NTP to set the date and time on devices, you can specify the NTP servers on the WLSE. If NTP is not enabled, you can set the system clock to UTC manually as described in [Setting the System Clock Manually, page 12-15](#).



### Note

Your login determines whether you can use this command.

To specify NTP servers:

**Step 1** Log in. See [Logging In and Out via CLI, page 12-2](#).

**Step 2** Enter the following command:

```
ntp server ip-address
```

where *ip-address* is the IP address of an NTP server.

To remove NTP servers and disable NTP:

**Step 1** Log in. See [Logging In and Out via CLI, page 12-21](#)

**Step 2** Enter the following command for each NTP server that you specified:

```
no ntp server ip_address
```



### Caution

If you do not set the system clock manually after disabling NTP, the system clock might become inaccurate.

## Setting the System Clock Manually

If your network does not use NTP to set the system time on devices and the time is not set correctly, set the date and time to manually.

**Note**

---

Your login determines whether you can use this command.

---

To set the date and time manually:

---

**Step 1** Log in. See [Logging In and Out via CLI, page 12-2](#).

**Step 2** Enter the following command:

```
clock set hh:mm:ss month day year
```

where:

- *hh:mm:ss* is the current time (for example, 13:32:00).
  - *month* is the current month (for example, December).
  - *day* is the day of the month (for example, 31).
  - *year* is the current year (for example, 2003).
- 

For more information about the **clock** command, see [show clock, page A-11](#).

# Configuring Ethernet Interfaces

The WLSE 1105 uses 10/100 Mbps Ethernet connectors. The WLSE 1130 and [WLSE 1130-19](#) use 10/100/1000 Mbps Ethernet connectors. The Ethernet 0 interface is configured during initial setup of the WLSE, and all protocols are enabled on the Ethernet 0 interface.

**Note**

---

The Ethernet interface labeled “A” on the WLSE 1130 back panel corresponds to Ethernet 0 in software (such as CLI commands). The Ethernet interface labeled “B” corresponds to Ethernet 1 in software.

---

This section contains the following topics:

- [Configuring Protocols on Ethernet Interfaces, page 12-16.](#)
- [Configuring Interface Parameters, page 12-17.](#)
- [Managing Devices on Both Interfaces, page 12-18.](#)
- [Using an AAA Server with Both Interfaces, page 12-18](#)

## Configuring Protocols on Ethernet Interfaces

All protocols are enabled by default on the Ethernet 0 interface. On the Ethernet 1 interface of the dual-interface WLSEs, all protocols except for CDP are enabled.

Any Ethernet interface can be individually configured to allow or prevent connections via the following protocols:

- Cisco Discovery Protocol (CDP)
- Hypertext transfer protocol (HTTP)
- Hypertext transfer protocol secure (HTTPS)
- Internet Control Message Protocol (ICMP)
- Secure shell (SSH) 1 and 2
- Simple network management protocol (SNMP)
- Telnet



---

**Note** Your login determines whether you can use this command.

---

To allow or prevent protocols on an Ethernet interface:

---

**Step 1** Log in. See [Logging In and Out via CLI, page 12-2](#).

**Step 2** To allow CDP on an interface, enter the following command:

```
cdp run port
```

where *port* is the Ethernet interface, either eth0 or eth1.

To disable CDP, enter the following command:

```
no cdp run port
```

For more information on this command, see [cdp, page A-20](#).

**Step 3** To allow or prevent any of the other protocols on an interface, use the **firewall** command. For information on this command, see [firewall, page A-27](#).

---

## Configuring Interface Parameters

To enable or disable Ethernet interfaces and set parameters on the interfaces (IP address, gateway information, speed, half/full duplex), use the following command.



---

**Note** Your login determines whether you can use this command.

---

```
interface eth[ernet] [0-5] { [up | down] | ipaddress netmask
 [default-gateway address] [up | down] }
 [auto | speed [10 | 100 | 1000]] duplex [half | full]
 mtu [46-1500]
```

For detailed information on this command, see [interface, page A-34](#).

## Managing Devices on Both Interfaces

**Note**

---

Your login determines whether you can use this command.

---

The Ethernet 0 interface is configured by the setup program during initial setup of the WLSE. If you are using both interfaces to manage devices, you must configure the second interface as follows:

- Make sure CDP is enabled on the Ethernet 1 interface—See [Configuring Protocols on Ethernet Interfaces, page 12-16](#).
- Configure Ethernet 1 interface parameters—See [Configuring Interface Parameters, page 12-17](#).
- Use the following command to configure a static route to the default gateway for the Ethernet 1 interface to reach the networks connected to the Ethernet 1 interface:

```
route { network address } netmask { network netmask }
 gateway { gateway address }
```

If you do not configure the static route, the WLSE will use only the default gateway configured on the Ethernet 0 interface and will be unable to manage the devices on the networks connected to the Ethernet 1 interface. For more information on the **route** command, see [route, page A-51](#).

## Using an AAA Server with Both Interfaces

If you have configured both the eth0 and eth1 interfaces with IP addresses and you are using an AAA server in the network, you must configure both IP addresses as clients on the AAA server. For information about setting up AAA servers, see the *Installation and Configuration Guide for the Wireless LAN Solution Engine, Release 2.7*. This guide is shipped with the WLSE and is available on Cisco.com.

## Configuring the Mail Route via CLI

To ensure that email arrives at its proper destination, you can specify an SMTP server. This affects email notifications about firmware and configuration jobs, emailing reports, and emailing fault notifications.

**Note**

---

Your login determines whether you can use this command.

---

To specify a mail server:

**Step 1** Log in as the admin user.

**Step 2** Enter the following command:

```
mailroute server
```

where *server* is the IP address or hostname of the email server.

---

## Administering Management Services via CLI

The WLSE allows you to stop and start all management services at once. All commands that affect management services affect all of them, and the logs that collect services information collect information about all of them.

You can stop and restart the management services if the system is not responding correctly. This should cause the services to reset and function properly again. Management services are restarted automatically when you reboot the WLSE.

**Note**

---

Your login determines whether you can use this command.

---

To stop management services, enter the following command:

```
services stop
```

To start management services, enter the following command:

```
services start
```

To view management services status, enter the following command:

```
services status
```

## Viewing System Information via CLI

To view system information, use the following CLI commands.

**Table 12-1** *Commands for Viewing System Information*

| Command                  | Information Displayed                              |
|--------------------------|----------------------------------------------------|
| <b>ps</b>                | Linux processes running on the WLSE                |
| <b>show anilog</b>       | ANI log                                            |
| <b>show auth-cli</b>     | Type of authentication used for secure CLI access  |
| <b>show auth-http</b>    | Type of authentication used for secure HTTP access |
| <b>show backupconfig</b> | Current backup and restore location and username   |
| <b>show bootlog</b>      | Messages from the last system boot                 |
| <b>show cdp neighbor</b> | The WLSE's nearest neighbor on the network         |
| <b>show cdp run</b>      | CDP configuration of the WLSE                      |
| <b>show collectorlog</b> | Collector log                                      |
| <b>show config</b>       | System configuration                               |
| <b>show daemonslog</b>   | Daemons log                                        |
| <b>show dmgtldlog</b>    | Daemon manager log                                 |
| <b>show hosts</b>        | System hosts file                                  |
| <b>show import</b>       | Imported hosts file                                |
| <b>show install logs</b> | Software updates and images in the repository      |
| <b>show interfaces</b>   | Network interface information                      |
| <b>show ipchains</b>     | IP chains for Ethernet interface                   |
| <b>show maillog</b>      | Email log                                          |
| <b>show process</b>      | Statistics for active processes                    |
| <b>show repository</b>   | Status or access log of repository                 |

**Table 12-1** *Commands for Viewing System Information (continued)*

| <b>Command</b>              | <b>Information Displayed</b>                      |
|-----------------------------|---------------------------------------------------|
| <b>show route</b>           | Routes that are currently configured              |
| <b>show securitylog</b>     | Security log                                      |
| <b>show snmp-server</b>     | WLSE's SNMP configuration                         |
| <b>show ssh-version</b>     | Type of SSH enabled on the WLSE                   |
| <b>show syslog</b>          | Syslog                                            |
| <b>show tech</b>            | Information necessary for Cisco TAC to assist you |
| <b>show telnetenable</b>    | Telnet status                                     |
| <b>show tomcatlog</b>       | Tomcat log                                        |
| <b>show webaccesslog</b>    | Web access log                                    |
| <b>show weberror log</b>    | Web error log                                     |
| <b>show websslaccesslog</b> | Web SSL log                                       |

## Recovery Management

Use the following procedures to recover from problems:

- [Erasing System Configuration and Resetting to Factory Defaults, page 12-22](#)
- [Using the Maintenance Image, page 12-23.](#)
- [Reimaging the WLSE—Local Installation Method, page 12-24.](#)
- [Using the Rescue Image, page 12-27](#)
- [Recovering from the Loss of All Administrator Passwords, page 12-28](#)

## Erasing System Configuration and Resetting to Factory Defaults

**Note**

Your login determines whether you can use these commands.

To erase the system configuration and reset the WLSE to factory default:

**Step 1** Log in as the admin user.

**Step 2** Enter the following command. This command resets the WLSE to factory defaults, but leaves the database and logs in place.

```
erase config
```

**Note**

This command stops and restarts system services.

**Step 3** To purge the database, enter the following command:

```
reinitdb
```

**Note**

This command stops and restarts system services.

**Note**

After the system reboots, you must reconfigure the system using the setup program, as described in the *Installation and Configuration Guide for the Wireless LAN Solution Engine, Release 2.7*.

## Using the Maintenance Image

The WLSE's maintenance image consists of an operating system image and default system configuration stored in flash memory. You can use the maintenance image to recover from serious problems.

The following commands are available while the WLSE is running the maintenance image:

- **reload**
- **erase config**
- **fsck**—This command is available only in the maintenance and rescue images.

While the maintenance image is running, you can do the following tasks, which you cannot do when the system is booted normally from the disk:

- Recover from loss of all administrative passwords. See [Recovering from the Loss of All Administrator Passwords, page 12-28](#).
- Perform disk filesystem integrity checks or recover from filesystem corruption. See [fsck, page A-86](#).

## Booting from the Maintenance Image

As a security measure, you can boot from the maintenance image only while connected to the system console.

- 
- Step 1** Connect a console to the WLSE's console port, and log on as **admin**.
- For the WLSE 1105, use the serial port on the front panel; do not use the serial port on the back panel as a console port.
  - For the WLSE 1130 and [WLSE 1130-19](#), the serial/console port is on the back panel.
- Step 2** Reboot the system by doing one of the following:
- Enter the following command to reload the system if it is running:  
`reload`
  - Power on the system, if it is powered off.
  - Power the system off and then back on if you cannot log in because you have lost all user account passwords.

- Step 3** When the `GRUB boot :` prompt appears, press the Tab key.
- Step 4** When the `boot :` prompt appears, enter:
- ```
CiscoBreR
```
- Step 5** After you complete all necessary tasks, reboot the system by entering the following command and allowing the system to boot from the disk (the default boot order)
- ```
reload
```
- 

## Using the Recovery CD

With the Recovery CD included with your WLSE, you can:

- Reimage the WLSE—See [Reimaging the WLSE—Local Installation Method, page 12-24](#) or [Reimaging the WLSE—Remote Installation Method, page 12-26](#).
- Boot from the rescue image—See [Using the Rescue Image, page 12-27](#).



### Caution

Before using the Recovery CD, check the Readme file on the CD for possible changes to procedures.

---

## Reimaging the WLSE—Local Installation Method


Please review the following notes and cautions before using this method to reimage a WLSE:

- This procedure will destroy all data and install a new image. You will need to replace the data by restoring a backup. For information on backups, see [Backing Up the WLSE, page 12-7](#).
- Although every effort has been made to validate the accuracy of the software version on the Recovery CD, you must review the WLSE's software versions on <http://www.cisco.com> and download any necessary software updates. See the Readme files included with the updates to perform the update procedure.

- Reimaging the WLSE by using the recovery CD and the local installation method does not erase the network information in flash memory. After installing the recovery CD, network details and the admin password do not get erased. If you need to erase this information, run the [erase config](#) command either before or after reimaging.

### Procedure

To reimage your WLSE, perform the following steps:

- 
- Step 1** Connect a console to the WLSE's serial port.
- For the WLSE 1105, use the serial port on the front panel; do not use the serial port on the back panel as a console port.
  - For the WLSE 1130 and [WLSE 1130-19](#), the serial/console port is on the back panel.
- Step 2** Log in as the **admin** user, and enter the password created when the WLSE was configured.
- Step 3** Put the Recovery CD in the WLSE's CD drive.  
The CD drive is located on the front panel, under the bezel.
- Step 4** Enter the following command. The WLSE will reboot.
- ```
reload
```
- Step 5** At the following prompt, enter **yes** to start the Recovery CD:
- ```
Do you wish to continue (Yes/[No]/Rescue) yes
```
-  **Caution** If you do not want to re-image the WLSE, enter **rescue**. For more information about the rescue image, see [Using the Rescue Image, page 12-27](#).
- 
- Step 6** When the WLSE ejects the Recovery CD, remove it.
- Step 7** At the following prompt, enter **yes**:
- ```
Do you wish to reload and start the install?(yes/[no]) yes
```
- Result: The WLSE is re-imaged and reboots.
- Step 8** When the Recovery CD ejects from the CD drive, remove it.

When the installation completes, the login prompt appears on the console.

Reimaging the WLSE—Remote Installation Method

**Note**

Although every effort has been made to validate the accuracy of the software version on the Recovery CD, you must review the WLSE's software versions on <http://www.cisco.com> and download any necessary software updates. See the Readme files included with the updates to perform the update procedure.

**Caution**

This procedure will destroy all data and install a new image. You will need to replace the data by restoring a backup. For information on backups, see [Backing Up the WLSE, page 12-7](#).

Procedure

To reimage your WLSE, perform the following steps:

-
- Step 1** Insert the Recovery CD into the CD drive of a system running Microsoft Windows 2000.
 - Step 2** Double-click on the CD drive to display the contents of the Recovery CD.
 - Step 3** Double-click on the autorun.bat file.
A command prompt window appears and as well as a pop-up window displaying instructions for installing the Recovery CD.
 - Step 4** Follow the installation instructions in the pop-up window.

**Note**

Make sure you keep both the command prompt window and pop-up window open until the installation finishes.

Using the Rescue Image

The rescue image is similar to the maintenance image, but is accessible via the Recovery CD. The rescue image is mainly used to aid technical support when diagnosing issues. Use the rescue image if you cannot use the maintenance image, but need to. You can use the rescue image to boot the system to perform some system administration tasks and disaster recovery. For information about the uses of the maintenance image, see [Using the Maintenance Image, page 12-23](#).

You are limited to the following commands while the system is running the rescue image: **reload**, **erase config**, and **fsck**.

To boot from the rescue image, perform the following steps:

-
- Step 1** Connect a console to the WLSE's serial port.
- For the WLSE 1105, use the serial port on the front panel; do not use the serial port on the back panel as a console port.
 - For the WLSE 1130 and [WLSE 1130-19](#), the serial/console port is on the back panel.
- Step 2** Log in as the **admin** user. The **admin** user's password was created when the WLSE was initially configured.
- Step 3** Put the Recovery CD in the WLSE's CD drive.
The CD drive is located on the front panel, under the bezel.
- Step 4** Enter the following command. The WLSE will reboot.
reload
- Step 5** At the following prompt, enter **rescue**.
A prompt appears, and you can run the following CLI commands:

Command	Description
fsck	Check and repair the file system.
reload	Reboot the WLSE.
erase config	Erase the configuration in flash memory and reload the WLSE.

For more information on these commands, see [Appendix A, “Using the Command Line Interface \(CLI\).”](#)

Recovering from the Loss of All Administrator Passwords

If you cannot log on to the system and perform administrative tasks, perform the relevant procedure:

- [Password Recovery Procedure for the CiscoWorks 1130 and 1130-19, page 12-28](#)
- [Password Recovery for the CiscoWorks 1105, page 12-29](#)

Password Recovery Procedure for the CiscoWorks 1130 and 1130-19

Procedure

- Step 1** Connect a console to the WLSE’s console port on the back panel.
- Step 2** Power the system off, then power it back on. Boot messages appear, and then following prompt appears:
- ```

0: CiscoBre
1: CiscoBreR

```
- Step 3** Use the Up Arrow and Down Arrow keys to select **1** for CiscoBreR and press **Enter**. The following prompt appears:
- ```

[root@CiscoMaintImage/]#

```
- Step 4** Enter the following command. This erases the WLSE’s configuration, returns the WLSE to factory defaults, and reloads the WLSE.
- ```

[root@CiscoMaintImage/]# erase config

```
- Step 5** After the WLSE starts up, a login prompt appears. Log in as setup, and use the setup program to configure the system. This allows you to add a password for the admin user.

For more information about the setup program, see the *Installation and Configuration Guide for the Wireless LAN Solution Engine, Release 2.7*.

---

## Password Recovery for the CiscoWorks 1105

Recovering from the loss of the admin password requires the use of the recovery CD.

### Procedure

---

**Step 1** Connect a console to the WLSE's console port. Use the serial port on the front panel; do not use the serial port on the back panel as a console port.

**Step 2** Insert the recovery CD in the CD drive.

**Step 3** Enter the following command:

```
reload
```

**Step 4** When the “Yes/No/Rescue/Reboot” option appears, enter:

```
rescue
```

**Step 5** When the shell prompt appears, enter the following command:

```
erase config
```

This command erases the WLSE's configuration.

**Step 6** When the “Yes/No/Rescue/Reboot” option appears, enter:

```
reboot
```

After the WLSE starts up a login prompt appears; for example:

```
localhostlogin:
```

**Step 7** Log in as the user “setup” and configure the system. This allows you to add a password for the admin user.

For more information about setup, see the *Installation and Configuration Guide for the Wireless LAN Solution Engine, Release 2.7*.

---

