

# Table of Contents

<b><u>Example NTP Configuration for High Availability Catalyst 6000 Switch</u></b> .....	1
<u>Document ID: 14978</u> .....	1
<u>Introduction</u> .....	1
<u>Before You Begin</u> .....	1
<u>Conventions</u> .....	1
<u>Prerequisites</u> .....	1
<u>Components Used</u> .....	1
<u>Example NTP Configuration for High Availability Catalyst 6000 Switch</u> .....	1
<u>Figure 1: Network Topology</u> .....	1
<u>Using NTP Authentication</u> .....	5
<u>Related Information</u> .....	6

# Example NTP Configuration for High Availability Catalyst 6000 Switch

Document ID: 14978

---

**Introduction**

**Before You Begin**

Conventions

Prerequisites

Components Used

**Example NTP Configuration for High Availability Catalyst 6000 Switch**

Figure 1: Network Topology

**Using NTP Authentication**

**Related Information**

---

## Introduction

This document provides an example Network Time Protocol (NTP) configuration for a Catalyst 6000 family switch with redundant supervisor engines, and dual Multilayer Switch Feature Cards (MSFCs) with configuration synchronization enabled.

## Before You Begin

### Conventions

For more information on document conventions, see the Cisco Technical Tips Conventions.

### Prerequisites

There are no specific prerequisites for this document.


### Components Used

This document is not restricted to specific software and hardware versions.

## Example NTP Configuration for High Availability Catalyst 6000 Switch

Figure 1 shows the network topology for this example configuration.

### Figure 1: Network Topology



In this example, we have a Catalyst 6509 with redundant supervisor engines and MSFCs. Below is the show module command output from the switch:

```

Cat6000> (enable) show module
Mod Slot Ports Module-Type Model Sub Status
-----
1 1 2 1000BaseX Supervisor WS-X6K-SUP1A-2GE yes ok
15 1 1 Multilayer Switch Feature WS-F6K-MSFC no ok
2 2 2 1000BaseX Supervisor WS-X6K-SUP1A-2GE yes standby
16 2 1 Multilayer Switch Feature WS-F6K-MSFC no ok
3 3 48 10/100BaseTX Ethernet WS-X6348-RJ-45 no ok

Mod Module-Name Serial-Num
-----
1 SAD04240E48
15 SAD042406UW
2 SAD042400YL
16 SAD042407KG
3 SAL04440WY6

Mod MAC-Address(es) Hw Fw Sw
-----
1 00-30-7b-96-7c-5a to 00-30-7b-96-7c-5b 3.1 5.3(1) 5.5(7)
00-30-7b-96-7c-58 to 00-30-7b-96-7c-59
00-02-7e-02-a0-00 to 00-02-7e-02-a3-ff
15 00-d0-d3-a3-b6-a7 to 00-d0-d3-a3-b6-e6 1.4 12.1(6)E 12.1(6)E
2 00-d0-c0-cf-72-12 to 00-d0-c0-cf-72-13 3.1 5.3(1) 5.5(7)
00-d0-c0-cf-72-10 to 00-d0-c0-cf-72-11
16 00-d0-c0-cf-72-14 to 00-d0-c0-cf-72-53 1.4 12.1(6)E 12.1(6)E
3 00-03-6c-29-ba-b0 to 00-03-6c-29-ba-df 1.4 5.4(2) 5.5(7)

Mod Sub-Type Sub-Model Sub-Serial Sub-Hw
-----
1 L3 Switching Engine WS-F6K-PFC SAD04240L70 1.1
2 L3 Switching Engine WS-F6K-PFC SAD04220KC5 1.1
Cat6000> (enable)

```

In this example, assume that this Catalyst 6509 is a core switch in the network. The dual MSFCs in the switch will function as NTP servers for other routers and switches in the network (including the supervisor engine on

this switch itself).

The MSFCs will synchronize their clocks to a master NTP server located in a remote subnet in the network. In practice, this might be a private local NTP server, or a public NTP server. In either case, this server would typically synchronize its time with another, lower stratum clock, such as an atomic clock.

The dual MSFCs in this example have configuration synchronization (config-sync) enabled. This automatically synchronizes the configuration on the designated MSFC to the non-designated MSFC. See the Related Information section for more information on config-sync.

Here is the configuration of MSFC15 (the designated MSFC). The configuration on MSFC16 is exactly the same, with the exception that for those commands where the **alt** command is specified, MSFC16 uses the command after the **alt** keyword. For example, the hostname of MSFC15 is MSFC15; the hostname of MSFC16 is MSFC16.

```
version 12.1
no service pad
!

!--- Enable service timestamps datetime!

service timestamps debug datetime msec localtime
service timestamps log datetime msec localtime
!
no service password-encryption
!
!

!--- Hostnames for the MSFCs.

hostname MSFC15 alt hostname MSFC16
!
boot system flash bootflash:c6msfc-jsv-mz.121-6.E.bin
enable password cisco
!
!
!Both MSFCs are in the PST timezone
clock timezone PST -8
!

!--- Both MSFCs will adjust the clock for Daylight Saving Time.

clock summer-time PDT recurring
!

!--- If connectivity to the NTP server is lost, the calendar is used.

!as an authoritative time source
clock calendar-valid
!
!
ip subnet-zero
!
!
no ip finger
ip domain-name corp.com
ip name-server 172.16.55.120
ip name-server 171.16.60.120
!
!
```

```

!config-sync is enabled
redundancy
  high-availability
  config-sync
!
!
!

!--- Each MSFC has a loopback0 interface in a different /30 subnet.

interface Loopback0
  ip address 10.10.10.1 255.255.255.252 alt ip address 10.10.10.5 255.255.255.252
!
!

!--- VLAN 1 is the management subnet, where the switch sc0 interface is located.

interface Vlan1
  description Network Management Subnet
  ip address 172.16.100.2 255.255.255.0 alt ip address 172.16.100.3 255.255.255.0
  no ip redirects
  standby 1 priority 105 preempt alt standby 1 priority 100 preempt
  standby 1 ip 172.16.100.1 alt standby 1 ip 172.16.100.1
!

<VARIOUS VLAN INTERFACES NOT RELEVANT TO THIS EXAMPLE>

!
router eigrp 10
  network 10.0.0.0
  network 172.0.0.0
  network 172.0.0.0 0.255.255.255
  no auto-summary
  eigrp log-neighbor-changes
!
ip classless
no ip http server
!
!
!
line con 0
  transport input none
line vty 0 4
  password cisco
  login
  transport input lat pad mop telnet rlogin udptn nasi
!
!

!--- Each MSFC uses the IP address of the loopback0 interface as
!--- the source IP for NTP packets.

ntp source Loopback0
!

!--- The MSFCs will update the hardware calendar with the NTP time.

ntp update-calendar
!

!--- Both MSFCs are getting the time from 10.100.100.1.

ntp server 10.100.100.1
!

```

```
end
```

**Note:** Some commands do not support the **alt** keyword, and therefore cannot be used with config-sync. An example is the **ntp peer** command. Config-sync support for this command would allow MSFC15 and MSFC16 to establish an NTP peer relationship. If this is a requirement in your network, you can disable config-sync and manually ensure that the configurations on the two MSFCs meets the requirements for dual MSFC systems. See the Related Information section for more information.

On the supervisor engine, the sc0 management interface (172.16.100.100) belongs to VLAN 1. The default gateway for the switch is the Hot Standby Router Protocol (HSRP) IP address on the VLAN 1 interface (172.16.100.1)

The supervisor engine points to two NTP servers for redundancy, the loopback0 interfaces on MSFC15 and MSFC16. Other switches and routers in the network are configured to do the same.

One disadvantage of this implementation is that if the entire switch fails, other devices in the network become unsynchronized. An alternate configuration for redundancy would have MSFCs in different chassis configured as NTP servers, so that if one chassis fails, the other continues to function as the NTP server.

Below is the NTP configuration on the switch:

```
#ntp
#
#NTP client mode is enabled
set ntp client enable
#
#NTP server IP addresses (loopback0 interfaces on MSFC15 and MSFC16)
set ntp server 10.10.10.1
set ntp server 10.10.10.5
#
#Switch is in the PST timezone
set timezone PST -8 0
#
#Switch will adjust clock for Daylight Saving Time
set summertime enable PDT
set summertime recurring first Sunday April 02:00 last Sunday October 02:00 60
```

## Using NTP Authentication

NTP authentication adds a level of security to your NTP configuration. You configure an NTP key string on each device. The key is encrypted using a Message Digest 5 (MD5) hashing algorithm, and the encrypted key is passed in each NTP packet. Before an NTP packet is processed, the key is checked against the configured key on the receiving device.

Below is the configuration of MSFC15 (the designated MSFC) with the added NTP authentication commands. The configuration on MSFC16 is exactly the same.

```
!--- The key string for NTP authentication key 10 is "ticktock"

!--- (the key string is shown encrypted in the configuration)

ntp authentication-key 10 md5 ticktock
!
```

```
!--- Enables NTP authentication

ntp authenticate
!

!--- Makes NTP authentication key "10" a trusted key

ntp trusted-key 10
!
ntp source Loopback0
ntp update-calendar
ntp server 10.100.100.1
```

Below is the NTP configuration on the switch with NTP authentication enabled:

```
#ntp
set ntp client enable
#
#Enables NTP authentication
set ntp authentication enable
#
#The key string for NTP authentication key 10 is "ticktock"
#(the key string is shown encrypted in the configuration)
set ntp key 10 trusted md5 ticktock
#
#NTP server IP addresses, configured to use authentication key 10
set ntp server 10.10.10.1 key 10
set ntp server 10.10.10.5 key 10
#
set timezone PST -8 0
set summertime enable PDT
set summertime recurring first Sunday April 02:00 last Sunday October 02:00 60
```

---

## Related Information

- [Performing Basic System Management Configuration Guide for IOS 12.1, including NTP configuration](#)
- [Configuring NTP Configuration Guide for Catalyst 6000 Switches](#)
- [Configuring Redundancy on Catalyst 6000 Switches, including information on config-sync and requirements for redundant MSFC systems](#)
- [Technical Support – Cisco Systems](#)

---

All contents are Copyright © 1992–2005 Cisco Systems, Inc. All rights reserved. Important Notices and Privacy Statement.

---

Updated: Mar 23, 2005

Document ID: 14978

---